



ABB INDUSTRIAL DRIVES

ACS880-07LC drives

Hardware manual

ACS880-07LC drives

Hardware manual

Table of contents



1. Safety instructions



4. Mechanical installation



6. Electrical installation



9. Start-up



Table of contents

1 Safety instructions

Contents of this chapter	13
Use of warnings and notes	13
General safety in installation, start-up and maintenance	14
Work on the liquid cooling system	16
Electrical safety in installation, start-up and maintenance	16
Electrical safety precautions	16
Additional instructions and notes	18
Optical components	18
Printed circuit boards	18
Grounding	19
General safety in operation	20
Additional instructions for permanent magnet motor drives	20
Safety in installation, start-up, maintenance	20
Safety in operation	21

2 Introduction to the manual

Contents of this chapter	23
Target audience	23
Categorization by frame size and option code	23
Use of component designations	24
Quick installation, commissioning and operation flowchart	24
Terms and abbreviations	25
Related manuals	25

3 Operation principle and hardware description

Contents of this chapter	27
Operation principle	27
Overview circuit diagram of the drive	28
Overview diagram of the rectifier bridge	29
12-pulse connection (option +A004)	29
Layout drawings	31
Overview of power and control connections	34
Door switches and lights	35
Main disconnecting device [Q1]	36
Auxiliary voltage switch [Q21]	36
Grounding (earthing) switch [Q9], optional	36
Other devices on the door	36
Control panel	36
Control by PC tools	37
Descriptions of options	38
Degree of protection	38
Definitions	38
Marine construction (option +C121)	38
Plinth height (options +C164 and +C179)	38

Resistor braking (options +D150 and +D151)	38
du/dt filter (option +E205)	38
Cabinet heater with external supply (option +G300)	39
Cabinet lighting (option +G301)	39
Terminals for external control voltage (option +G307)	39
Halogen-free wiring and materials (option +G330)	39
Wire markings	39
Standard wiring	39
Additional wire markings	40
Thermal protection with PTC relays (options +L505, +2L505, +L513, +2L513, +L536, +L537)	41
+L505, +2L505, +L513, +2L513	41
+L536, +L537	41
Thermal protection with Pt100 relays (options +nL506, +nL514)	42
Type designation label	43
Type designation key	43
Option codes	44

4 Mechanical installation

Contents of this chapter	47
Examining the installation site	47
Necessary tools	47
Examining the delivery	48
Moving and unpacking the drive	49
Removing the transport package	49
Moving the unpacked drive cabinet	50
Lifting the cabinet with a crane	50
Moving the cabinet on rollers	51
Moving the cabinet on its back	51
Final placement of the cabinet	52
Attaching the cabinet to the floor and wall or roof	53
General rules	53
Attaching the cabinet (non-marine units)	54
Alternative 1 – Clamping	54
Alternative 2 – Using the holes inside the cabinet	55
Attaching the cabinet (marine units)	56
Joining cabinet sections together	57
Miscellaneous	61
Cable duct in the floor below the cabinet	61
Arc welding	61
Lifting lugs and bars	62
Certificate of conformity	62
Declaration of Conformity	62

5 Guidelines for planning the electrical installation

Contents of this chapter	65
Limitation of liability	65
Selecting the supply disconnecting device	65
Selecting the main contactor or breaker	65
Examining the compatibility of the motor and drive	66
Protecting the motor insulation and bearings	66

Requirements table	66
Availability of du/dt filter and common mode filter by drive type	69
Additional requirements for explosion-safe (EX) motors	69
Additional requirements for ABB motors of types other than M2_, M3_, M4_, HX_ and AM_	69
Additional requirements for ABB high-output and IP23 motors	69
Additional requirements for non-ABB high-output and IP23 motors	69
Additional note for sine filters	70
Selecting the power cables	70
General guidelines	70
Typical power cable sizes	71
Power cable types	71
Preferred power cable types	71
Alternate power cable types	72
Not allowed power cable types	73
Power cable shield	73
Selecting the control cables	74
Shielding	74
Signals in separate cables	74
Signals that can be run in the same cable	74
Relay cable	74
Control panel to drive cable	74
PC tool cable	75
Routing the cables	75
General guidelines – IEC	75
Continuous motor cable shield/conduit or enclosure for equipment on the motor cable	76
Separate control cable ducts	76
Implementing short-circuit and thermal overload protection	76
Protecting the input cabling and the drive upon a short-circuit	76
Protecting the motor and motor cable in short-circuits	76
Protecting the drive and the power cables against thermal overload	76
Protecting the motor against thermal overload	77
Protecting the drive against ground faults	77
Residual current device compatibility	77
Implementing the emergency stop function	77
Implementing the Safe torque off function	77
Implementing the power loss ride-through function	78
Implementing a bypass connection	78
Supplying power for the auxiliary circuits	78
Using power factor compensation capacitors with the drive	79
Using a safety switch between the drive and the motor	79
Implementing the control of a contactor between drive and motor	79
Protecting the contacts of relay outputs	79
Implementing a motor temperature sensor connection	80
Connecting motor temperature sensor to the drive via an option module	81
6 Electrical installation	
Contents of this chapter	83
Warnings	83
Measuring the insulation	83
Measuring the insulation of the drive	83



Measuring the insulation of the motor and motor cable	84
Connecting the control cables	85
Control cable connection procedure	85
Grounding the outer shields of the control cables at the cabinet entry	85
Routing the control cables inside the cabinet	87
Connecting control cabling	87
Connecting the motor cables (units without common motor terminal cubicle)	89
Motor connection diagram (without option +H366)	89
Procedure	90
Connecting the motor cables (units with common motor terminal cubicle)	92
Output busbars	92
Connection diagram	92
Procedure	92
Connecting an external brake resistor assembly	93
Connecting the input power cables	94
Connection diagram, 6-pulse units	94
Connection diagram, 12-pulse units	94
Layout of the input cable connection terminals and cable entries	95
Connection procedure	95
Connecting a PC	98
Panel bus (Control of several units from one control panel)	98
Installing option modules	101
Mechanical installation of I/O extension, fieldbus adapter and pulse encoder interface modules	101
Installation of an FSO-xx safety functions module onto BCU	101
Wiring of option modules	103

7 Control units of the drive

Contents of this chapter	105
BCU-x2 layout	106
Default I/O diagram of the supply control unit	108
Default I/O diagram of the inverter control unit (A41)	111
Additional information on the connections	112
External power supply for the control unit (XPOW)	112
DI6 as a PTC sensor input	112
AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input	113
DIIL input	113
The XD2D connector	113
Safe torque off (XSTO, XSTO OUT)	114
FSO-xx safety functions module connection (X12)	114
SDHC memory card slot	114
Connector data	115
BCU-x2 ground isolation diagram	117

8 Installation checklist

Contents of this chapter	119
Checklist	119

9 Start-up

Contents of this chapter	121
Start-up procedure	121



Switching off the drive	123
10 Fault tracing	
Contents of this chapter	125
Control unit LEDs	125
Control panel and panel platform/holder LEDs	125
Warning and fault messages	126
11 Maintenance	
Contents of this chapter	127
Maintenance intervals	127
Cabinet	129
Cleaning the interior of the cabinet	129
Power connections and quick connectors	129
Retightening the power connections	129
Fans	130
Replacing the fan in the incoming cubicle	131
Replacing the fan in the auxiliary control cubicle	132
Replacing the cooling fan of a D8T supply module	132
Replacing the cooling fan of an R8i inverter module	133
Replacing the common motor terminal cubicle fan	134
Replacing the brake chopper and resistor cubicle fans (options +D150 and +D151)	135
Supply and inverter modules	136
Replacing the D8T supply module	136
Replacing an inverter module	140
Removing the module	141
Reinstalling the module	142
Capacitors	143
Reforming the capacitors	143
Fuses	144
Replacing the AC fuses	144
Replacing the supply module DC fuses	145
Checking and replacing the DC fuses	145
Replacing the inverter module DC fuses	146
Control panel	147
Cleaning the control panel	147
Replacing the control panel battery	147
Control units	148
BCU control unit types	148
Replacing the memory unit	148
Replacing the BCU control unit battery	148
12 Internal cooling circuit	
Contents of this chapter	151
Applicability	151
Internal cooling system	151
Connection to a cooling unit	153
Connection to an ACS880-1007LC cooling unit	153
Connection to a custom cooling unit	153
General requirements	153
Coolant temperature control	153



Filling up and bleeding the internal cooling circuit	154
Drive line-ups with an ACS880-1007LC cooling unit	154
Drive line-ups with a custom cooling unit	154
Draining the internal cooling circuit	156
Maintenance intervals	156
Technical data	156
Coolant specification	156
Coolant type	156
Temperature limits	156
Pressure limits	158
Coolant flow rate limits	158
Cooling circuit materials	158

13 Technical data

Contents of this chapter	161
Ratings	161
Definitions	163
Derating	163
Surrounding air temperature derating	163
Coolant temperature derating	163
Antifreeze content derating	163
Altitude derating	163
Switching frequency derating	164
Output frequency derating	164
Frame sizes and power module types	164
Fuses	166
Internal AC fuses	166
DC fuses	169
Brake chopper DC fuses	172
Dimensions and weights	172
Free space requirements	172
Cooling data, noise	172
Typical power cable sizes	174
Terminal and lead-through data for the power cables	176
Terminal data for the supply and inverter control units	176
Electrical power network specification	176
Motor connection data	176
Efficiency	177
Optical components	177
Protection classes	177
Ambient conditions	178
Materials	179
Applicable standards	179
Markings	180
EMC compliance (IEC/EN 61800-3)	181
Definitions	181
Category C3	181
Category C4	182
Compliance with the European Machinery Directive	182
Tightening torques	185
Electrical connections	185
Mechanical connections	185

Insulation supports	185
Cable lugs	185
Disclaimers	185
Generic disclaimer	185
Cybersecurity disclaimer	186

14 Dimensions

Cabinet line-up dimensions	187
Dimension drawing examples	189
ACS880-07LC-0850A-7	189
ACS880-07LC-1660A-7 (6-pulse)	190
ACS880-07LC-1660A-7+A004 (12-pulse)	191
ACS880-07LC-3260A-7	192
Cabinet height and depth	193
Location and size of input terminals	194
600 mm, with main breaker, single-busbar, bottom cable entry	194
600 mm, with main breaker, double-busbar, bottom cable entry	195
Location and size of output terminals	196
Units without common motor terminal cubicle	196
Inverter module cubicle with one R8i module, bottom cable exit	196
Inverter module cubicle with two R8i modules, bottom cable exit	197
Inverter module cubicle with three R8i modules, bottom cable exit	198
Brake chopper cubicle	199

15 The Safe torque off function

Contents of this chapter	201
Description	201
Compliance with the European Machinery Directive	202
Wiring	203
Activation switch	203
Cable types and lengths	203
Grounding of protective shields	203
Dual-channel connection with internal power supply	204
Single-channel connection of activation switch	205
Multiple drives	206
Internal power supply	206
External power supply	207
Operation principle	208
Start-up including acceptance test	209
Competence	209
Acceptance test reports	209
Acceptance test procedure	209
Use	211
Maintenance	212
Competence	212
Fault tracing	213
Safety data	214
Abbreviations	215
TÜV certificate	215
Declaration of conformity	216

12 *Table of contents*

16 Resistor braking

Further information



1

Safety instructions



Contents of this chapter

This chapter contains the safety instructions which you must obey when you install, start up, operate and do maintenance work on the drive. If you ignore the safety instructions, injury, death or damage can occur.

Use of warnings and notes

Warnings tell you about conditions which can cause injury or death, or damage to the equipment. They also tell you how to prevent the danger. Notes draw attention to a particular condition or fact, or give information on a subject.

The manual uses these warning symbols:

**WARNING!**

Electricity warning tells about hazards from electricity which can cause injury or death, or damage to the equipment.

**WARNING!**

General warning tells about conditions, other than those caused by electricity, which can cause injury or death, or damage to the equipment.

**WARNING!**

Electrostatic sensitive devices warning tells you about the risk of electrostatic discharge which can cause damage to the equipment.

General safety in installation, start-up and maintenance

These instructions are for all personnel who do work on the drive.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Keep the drive in its package until you install it. After unpacking, protect the drive from dust, debris and moisture.
- Use the required personal protective equipment: safety shoes with metal toe cap, safety glasses, protective gloves and long sleeves, etc. Some parts have sharp edges.
- Lift a heavy drive with a lifting device. Use the designated lifting points. See the dimension drawings.
- Incorrect lifting can cause danger or damage. Obey the local laws and regulations applicable to lifting, such as requirements for planning the lift, for capacity and condition of lifting equipment, and for training of personnel.
- The lifting bars attached to large drive cabinets are heavy. Be careful when removing or reinstalling the bars. Whenever possible, use a lifting device attached to the designated lifting points.
- Attach the drive cabinet to the floor to prevent it from toppling over. The cabinet has a high center of gravity. When you pull out heavy components or power modules, there is a risk of overturning. Attach the cabinet also to the wall when necessary.



- Do not stand or walk on the cabinet roof. Make sure that nothing presses against the roof, side or back plates or door. Do not store anything on the roof while the drive is in operation.
- Be careful when handling a tall module. The module overturns easily because it is heavy and has a high center of gravity. Whenever possible, secure the module with chains. Do not leave an unsupported module unattended especially on a sloping floor.



- Beware of hot surfaces. Some parts, such as heatsinks of power semiconductors, and brake resistors, remain hot for a while after disconnection of the electrical supply.
- Make sure that debris from drilling, cutting and grinding does not enter the drive during the installation. Electrically conductive debris inside the drive may cause damage or malfunction.
- Make sure that there is sufficient cooling. See the technical data.
- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists. If you cannot avoid working on a powered drive, obey the local laws and regulations on live working (including – but not limited to – electric shock and arc protection).
- Before you adjust the drive operation limits, make sure that the motor and all driven equipment can operate throughout the set operation limits.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".
- The maximum drive power cycles is five times in ten minutes. Power cycling the drive too often can damage the charging circuit of the DC capacitors.
- If you have connected safety circuits to the drive (for example, Safe torque off or emergency stop), validate them at start-up. See separate instructions for the safety circuits.



Note:

- If you select an external source for the start command and it is on, the drive will start immediately after fault reset unless you configure the drive for pulse start. See the firmware manual.
- If the drive is in remote control mode, you cannot stop or start the drive with the control panel.
- Only authorized persons are allowed to repair a malfunctioning drive.

■ Work on the liquid cooling system


These instructions are intended for all personnel that do installation, commissioning and maintenance work on the liquid cooling system.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Use the required personal protective equipment. See the Safety data sheet for Antifrogen® L coolant by Clariant (www.clariant.com) for the instructions on the respiratory, hand and eye protection when handling the coolant.
- Beware of hot, high-pressure coolant (6 bar, max. 50 °C) that is present in the internal cooling circuit when it is in operation. Before you disconnect a pipe, release the pressure. Close the appropriate stop valve(s). If necessary, stop the cooling circuit pumps.
- Avoid skin contact with coolant. If coolant splashes onto the skin or in the eyes, rinse immediately with plenty of water. Do not syphon it by mouth. If you swallow or get it into the eyes, seek medical advice.
- Before the drive power up, make sure that the internal cooling circuit is filled up with coolant, and the cooling is in operation (coolant circulates).
- Make sure that coolant meets the ABB specification. See the appropriate hardware manual of the drive/unit.
- To avoid breaking the coolant pipes, do not overtighten the nuts of the unions. Leave 2 to 3 millimeters (0.08 to 0.12 inches) of thread visible.



- Do not drain coolant into the sewer system.
- If you need to store the drive in temperature below -15 °C (5 °F), drain the cooling circuit, or make sure that it is filled with the coolant specified by ABB.
- Drives with the cooling unit: Do not open the cooling unit pump inlet or outlet valves before filling up the coolant circuit. The pumps are filled with a mixture at the factory to prevent corrosion and the valves are closed at the factory.
- Drives with the cooling unit: Do not run the cooling unit pump dry.

Electrical safety in installation, start-up and maintenance

■ Electrical safety precautions

These electrical safety precautions are for all personnel who do work on the drive, motor cable or motor.

**WARNING!**

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

Go through these steps before you begin any installation or maintenance work.

1. Clearly identify the work location and equipment.
2. Disconnect all possible voltage sources. Make sure that re-connection is not possible. Lock out and tag out.
 - Open the main disconnecting device of the drive.
 - Open the charging switch if present.
 - Open the disconnecter of the supply transformer. (The main disconnecting device in the drive cabinet does not disconnect the voltage from the AC input power busbars of the drive cabinet.)
 - Open the auxiliary voltage switch-disconnector (if present), and all other possible disconnecting devices that isolate the drive from dangerous voltage sources.
 - In the liquid cooling unit (if present), open the switch-disconnector of the cooling pumps.
 - If you have a permanent magnet motor connected to the drive, disconnect the motor from the drive with a safety switch or by other means.
 - Disconnect all dangerous external voltages from the control circuits.
 - After you disconnect power from the drive, always wait 5 minutes to let the intermediate circuit capacitors discharge before you continue.
3. Protect any other energized parts in the work location against contact.
4. Take special precautions when close to bare conductors.
5. Measure that the installation is de-energized. If the measurement requires removal or disassembly of shrouding or other cabinet structures, obey the local laws and regulations applicable to live working (including – but not limited to – electric shock and arc protection).
 - Before and after measuring the installation, verify the operation of the voltage tester on a known voltage source.
 - Make sure that the voltage between the drive input power terminals (L1, L2, L3) and the grounding (PE) busbar is zero.
 - Make sure that the voltage between the drive output terminals (T1/U, T2/V, T3/W) and the grounding (PE) busbar is zero.
 - Make sure that the voltage between the drive DC busbars (+ and -) and the grounding (PE) busbar is zero.

**WARNING!**

The busbars inside the cabinet of liquid-cooled drives are partially coated. Measurements made through the coating are potentially unreliable, so only measure at uncoated portions. Note that the coating does not constitute a safe or touch-proof insulation.

6. Install temporary grounding as required by the local regulations.
7. Ask the person in control of the electrical installation work for a permit to work.



■ Additional instructions and notes



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
- Make sure that the electrical power network, motor/generator, and environmental conditions agree with the drive data.
- Do not do insulation or voltage withstand tests on the drive.
- If you have a cardiac pacemaker or other electronic medical device, keep away from the area near motor, drive, and the drive power cabling when the drive is in operation. There are electromagnetic fields present which can interfere with the function of such devices. This can cause a health hazard.
- ABB recommends not to attach the cabinet by arc welding. If you have to, obey the welding instructions in the drive manuals.

Note:

- The motor cable terminals of the drive are at a dangerous voltage when the input power is on, regardless of whether the motor is running or not.
- When the input power is on, the drive DC bus is at a dangerous voltage. If brake chopper and resistor are in use, they are at a dangerous voltage. (Option +D150) (Option +D151).
- External wiring can supply dangerous voltages to the relay outputs of the control units of the drive.
- The Safe torque off function does not remove the voltage from the main and auxiliary circuits. The function is not effective against deliberate sabotage or misuse.

Optical components



WARNING!

Obey these instructions. If you ignore them, damage to the equipment can occur.

- Handle the fiber optic cables with care.
- When you unplug the fiber optic cables, always hold the connector, not the cable itself.
- Do not touch the ends of the fibers with bare hands as the ends are extremely sensitive to dirt.
- Do not bend the fiber optic cables too tightly. The minimum allowed bend radius is 35 mm (1.4 in).

Printed circuit boards



WARNING!

Use a grounding wrist band when you handle printed circuit boards. Do not touch the boards unnecessarily. The boards contain components sensitive to electrostatic discharge.

■ Grounding

These instructions are for all personnel who are responsible for the grounding of the drive.



WARNING!

Obey these instructions. If you ignore them, injury or death, or equipment malfunction can occur, and electromagnetic interference can increase.

If you are not a qualified electrical professional, do not do grounding work.

- Always ground the drive, the motor and adjoining equipment. This is necessary for the personnel safety. Proper grounding also reduces electromagnetic emission and interference.
- Make sure that the conductivity of the protective earth (PE) conductors is sufficient. See the electrical planning instructions of the drive. Obey the local regulations.
- Connect the power cable shields to protective earth (PE) terminals of the drive to make sure of personnel safety.
- Make a 360° grounding of the power and control cable shields at the cable entries to suppress electromagnetic disturbances.
- In a multiple-drive installation, connect each drive separately to the protective earth (PE) busbar of the power supply.

Note:

- You can use power cable shields as grounding conductors only when their conductivity is sufficient.
- As the normal touch current of the drive is higher than 3.5 mA AC or 10 mA DC, you must use a fixed protective earth (PE) connection. The minimum size of the protective earth conductor must comply with the local safety regulations for high protective earth conductor current equipment. See standard IEC/EN 61800-5-1 (UL 61800-5-1) and the electrical planning instructions of the drive.



General safety in operation

These instructions are for all personnel that operate the drive.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
- If you have a cardiac pacemaker or other electronic medical device, keep away from the area near motor, drive, and the drive power cabling when the drive is in operation. There are electromagnetic fields present which can interfere with the function of such devices. This can cause a health hazard.
- Give a stop command to the drive before you reset a fault. If you have an external source for the start command and the start is on, the drive will start immediately after the fault reset, unless you configure the drive for pulse start. See the firmware manual.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".

Note:

- The maximum drive power cycles is five times in ten minutes. Power cycling the drive too often can damage the charging circuit of the DC capacitors. If you need to start or stop the drive, use the control panel keys or commands through the I/O terminals of the drive.
- If the drive is in remote control mode, you cannot stop or start the drive with the control panel.

Additional instructions for permanent magnet motor drives

■ Safety in installation, start-up, maintenance

These are additional warnings concerning permanent magnet motor drives. The other safety instructions in this chapter are also valid.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

- Do not do work on the drive when a rotating permanent magnet motor is connected to it. A rotating permanent magnet motor energizes the drive including its input and output power terminals.

Before installation, start-up and maintenance work on the drive:

- Stop the drive.
- Disconnect the motor from the drive with a safety switch or by other means.

- If you cannot disconnect the motor, make sure that the motor cannot rotate during work. Make sure that no other system, like hydraulic crawling drives, can rotate the motor directly or through any mechanical connection like belt, nip, rope, etc.
- Do the steps in section [Electrical safety precautions \(page 16\)](#).
- Install temporary grounding to the drive output terminals (T1/U, T2/V, T3/W). Connect the output terminals together as well as to the PE.

During the start up:

- Make sure that the motor cannot run overspeed, for example, driven by the load. Motor overspeed causes overvoltage that can damage or destroy the capacitors in the intermediate circuit of the drive.


■ Safety in operation



WARNING!

Make sure that the motor cannot run overspeed, for example, driven by the load. Motor overspeed causes overvoltage that can damage or destroy the capacitors in the intermediate circuit of the drive.





2

Introduction to the manual

Contents of this chapter

This chapter describes the manual. It contains a flowchart of steps in checking the delivery, installing and starting up the drive. The flowchart refers to chapters/sections in this manual and to other manuals.

Target audience

This manual is intended for people who plan the installation, install, start up and do maintenance work on the drive, or create instructions for the end user of the drive concerning the installation and maintenance of the drive.

Read the manual before working on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

Categorization by frame size and option code

Some instructions, technical data and dimension drawings which concern only certain frame sizes are marked with the symbol of the frame size. The frame size indicates the number of power modules that form the supply and inverter units respectively.

For example, the marking "2×D8T + 3×R8i" refers to a drive that has a supply unit consisting of two frame D8T supply modules and an inverter unit consisting of three frame R8i inverter modules. The frame size is marked on the type designation label, and can also be determined from the type code.

The instructions, technical data and dimension drawings which only concern certain optional selections are marked with option codes (such as "+E205"). The options included in the drive can be identified from the option codes visible on the type designation label. The option selections are listed in section [Type designation key \(page 43\)](#).

Use of component designations

Some device names in the manual include the item designation in brackets, for example [Q20], to make it possible to identify the components in the circuit diagrams of the drive.

Quick installation, commissioning and operation flowchart

Task	See
<p>Plan the electrical installation and acquire the accessories needed (cables, fuses, etc.).</p> <p>Check the ratings, required cooling air flow, input power connection, compatibility of the motor, motor connection, and other technical data.</p>	<p>Guidelines for planning the electrical installation (page 65)</p> <p>Technical data (page 161)</p>
↓	
<p>Check the installation site.</p>	<p>Ambient conditions (page 178)</p>
↓	
<p>Unpack and check the drive (only intact units may be started up). Make sure that all necessary optional modules and equipment are present and correct.</p> <p>Install the drive mechanically.</p>	<p>Mechanical installation (page 47)</p>
↓	
<p>Route the cables.</p>	<p>Routing the cables (page 75)</p>
↓	
<p>Connect the power cables.</p> <p>Connect the control cables.</p>	<p>Electrical installation (page 83)</p>
↓	
<p>Check the installation.</p>	<p>Installation checklist (page 119)</p> <p>If the drive has been non-operational for more than one year, reform the DC link capacitors. See Converter module capacitor reforming instructions (3BFE64059629 [English]).</p>
↓	
<p>Start the drive up.</p>	<p>Start-up (page 121)</p>
↓	
<p>Operate the drive: start, stop, speed control etc.</p>	<p>ACS880 quick start-up guide, firmware manual</p>

Terms and abbreviations

Term/ Abbreviation	Description
BCU	Type of control unit
Drive	Frequency converter for controlling AC motors
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
FEN-01	Optional TTL incremental encoder interface module
FEN-11	Optional TTL absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL incremental encoder interface module
FIO-11	Optional analog I/O extension module
FPTC-01	Optional thermistor protection module
FPTC-02	Optional ATEX-certified thermistor protection module for potentially explosive atmospheres
Frame, frame size	Physical size of the drive or power module
FSO-12, FSO-21	Optional functional safety modules
IGBT	Insulated gate bipolar transistor
Inverter unit	Inverter module(s) under control of one control unit, and related components. One inverter unit typically controls one motor.
Power module	Common term for drive module, inverter module, supply module, brake chopper module etc.
RFI	Radio-frequency interference
STO	Safe torque off (IEC/EN 61800-5-2)
Supply unit	Supply module(s) under control of one control unit, and related components.

Related manuals

Name	Code
Drive hardware manuals and guides	
ACS880-07LC hardware manual	3AXD50000569786
ACX-AP-x assistant control panels user's manual	3AUA0000085685
Drive firmware manuals and guides	
ACS880 primary control program firmware manual	3AUA0000085967
Quick start-up guide for ACS880 drives with primary control program	3AUA0000098062
ACS880 diode supply control program firmware manual	3AUA0000103295
CIO-01 I/O module for distributed I/O bus control user's manual	3AXD50000126880
Option manuals and guides	
ACS880-1007LC liquid cooling unit user's manual	3AXD50000129607
Drive composer start-up and maintenance PC tool user's manual	3AUA0000094606
FSO-12 safety functions module user's manual	3AXD50000015612
FSO-21 safety functions module user's manual	3AXD50000015614
User's manual for Prevention of unexpected start-up (+Q950) for ACS880-07/17/37 drives	3AUA0000145922
User's manual for Emergency stop, stop category 0 (+Q951) for ACS880-07/17/37 drives	3AUA0000119895
User's manual for Emergency stop, stop category 1 (+Q952) for ACS880-07/17/37 drives	3AUA0000119896

26 Introduction to the manual

Name	Code
User's manual for Prevention of unexpected start-up (+Q957) for ACS880-07/17/37 drives	3AUA0000119910
User's manual for Emergency stop, stop category 0 (+Q963) for ACS880-07/17/37 drives	3AUA0000119908
User's manual for Emergency stop, stop category 1 (+Q964) for ACS880-07/17/37 drives	3AUA0000119909
User's manual for Safely-limited speed with the encoder interface (+Q965) for ACS880-07/17/37 drives	3AXD50000019727
User's manual for ATEX-certified motor thermal protection functions (+L513+Q971 and +L514+Q971) for cabinet-built ACS880 drives	3AXD50000014979
User's manual for Emergency stop, configurable stop category 0 or 1 (+Q978) for ACS880-07/17/37 drives	3AUA0000145920
User's manual for Emergency stop, configurable stop category 0 or 1 (+Q979) for ACS880-07/17/37 drives	3AUA0000145921
Manuals and quick guides for I/O extension modules, fieldbus adapters, etc.	

See www.abb.com/drives/documents for all manuals on the Internet.

3

Operation principle and hardware description

Contents of this chapter

This chapter briefly describes the operation principle and construction of the drive.

Operation principle


The ACS880-07LC is a liquid-cooled cabinet-installed drive for controlling asynchronous AC induction motors, permanent magnet synchronous motors and AC induction servomotors.

The drive consists of several cubicles that contain the supply and motor terminals, 1 to 6 diode supply module(s), 1 to 8 inverter modules, and optional equipment. The actual arrangement of the cubicles varies from type to type and the selected options.

The supply modules of the drive contain a diode-thyristor bridge. The thyristors of the bridge are controlled at start-up so that their firing angle approaches zero as the DC capacitors of drive get charged. During normal operation, the firing angle of the thyristors is zero, so they operate as diodes.


The supply modules have built-in AC chokes that smoothen the current waveform in the power supply network and the voltage in the intermediate DC link of the drive.

■ Overview circuit diagram of the drive



1	Main circuit breaker [Q1]
2	AC fuses
3	Supply module (including choke and rectifier)
4	Supply module DC fuses
5	Inverter module DC fuses
6	Inverter modules
7	Motor
8	*Brake chopper DC fuses
9	*Brake chopper module
10	*Brake resistors
*Brake chopper (+D150) and resistors (+D151) are optional	
11	Auxiliary voltage switch [Q21] with fuses (connection for external supply is optional)
12	Auxiliary voltage transformer

Overview diagram of the rectifier bridge



12-pulse connection (option +A004)


The figure below illustrates the difference between 6-pulse and 12-pulse AC supply connections. 6-pulse connection is standard.

Some drive types are available as a 12-pulse version (option +A004).

The 12-pulse supply connection eliminates the fifth and seventh harmonics, which substantially reduces the harmonic distortion of the line current and the conducted emissions.


The 12-pulse connection requires a three-winding transformer, or two separate transformers. There is a phase shift of 30-degrees between the two 6-pulse supply lines, which are connected to different supply modules through electrically separate switching equipment.

30 Operation principle and hardware description



A	6-pulse connection
B	12-pulse connection
1	Supply transformer
2	Switching equipment
3	Diode supply modules

■ Layout drawings




Cabinet line-up example, doors open (Frame 2×D8T + 2×R8i shown)

A	Auxiliary control cubicle (ACU). Contains control electronics and customer I/O connections.
B	Incoming cubicle (ICU). Contains the power input cable terminals and switchgear. 12-pulse types, as well as large drive types, have two incoming cubicles.
C	Supply module cubicle (DSU). One cubicle contains one or two frame D8T supply modules. Larger drive types have a supply unit consisting of multiple supply module cubicles.
D	Inverter module cubicle (INU). Cubicles with one, two or three frame R8i inverter modules exist, and drive types with four or more inverter modules have multiple inverter module cubicles. As standard, the motor cables are run from each inverter module to the motor unless the drive is equipped with option +H359 (common motor terminal cubicle) or +H366 (common output terminals).
1	CIO-01 I/O module for cooling fan monitoring
2	BCU control units (A51 for supply unit control, A41 for inverter unit control)
3	Auxiliary voltage transformer (behind mounting plate). External auxiliary voltage connection is optional.
4	ACU cooling fan and heat exchanger
5	Auxiliary voltage switch [Q21] (if the drive is fitted with an auxiliary voltage transformer)
6	Grounding switch [Q9] (optional)
7	Main circuit breaker
8	Supply cable connections
9	Supply module 1 AC fuses
10	Supply module 1 DC fuses
11	Supply module 1

32 Operation principle and hardware description

12	Supply module 2 AC fuses
13	Supply module 2 DC fuses
14	Supply module 2
15	Supply module cubicle fan
16	Inverter module DC fuses (at the input of each inverter module)
17	Inverter modules
18	Inverter module cooling fan. A heat exchanger is located between the fan and the module.




Supply module cubicle, cooling circuit

1	Heat exchanger
2	Inlet manifold with stop and drain valves
3	Outlet manifold with stop and drain valves
4	Inlet pipes (cold coolant) from main pipe to modules and heat exchanger
5	Output pipes (hot coolant) to main pipe from modules and heat exchanger
6	Supply modules
7	Draining pipes (inlet draining pipe, and outlet draining pipe)

Overview of power and control connections

The diagram shows the power connections and control interfaces of the drive.




1	Option modules can be inserted into slots 1, 2, 3 and 4 as follows:	
2	Module type	Slots
3	Analog and digital I/O extension modules	1, 2, 3
4	Feedback interface modules	1, 2, 3
	Fieldbus communication modules	1, 2, 3
	RDCO-xx DDCS communication option module (standard equipment). As standard, 4 a fiber optic link connects the supply and inverter control units.	
	Additional modules can be installed on an optional FEA-03 extension adapter connected to an RDCO module on slot 4.	
5	Memory unit	
6	Connection for FSO-xx safety functions module	
7	Control panel and PC connection	
8	Terminal blocks on the inverter control unit. These terminals are optionally wired to terminal block X504 in the auxiliary control cabinet of the drive.	

9	Fiber optic link to each inverter module. Similarly, each supply module is connected to the supply control unit by fiber optic cables.
10	Terminal blocks for customer connections installed in the drive cabinet.
11	Supply unit (consisting of one or more supply modules)
12	DC intermediate link
13	Inverter unit (consisting of one or more inverter modules)
14	Optional brake chopper (+D150) and resistors (+D151)

Door switches and lights



	Label in English	Label in local language	Description				
1	READY	-	Ready light (option +G327)				
2	RUN	-	Run light (option+G328)				
3	FAULT	-	Fault light (option +G329)				
4	ENABLE / RUN 0-1 	-	Run enable signal switch for the supply unit <table border="1" data-bbox="703 1742 1453 1883"> <tr> <td>0</td> <td>Run enable signal off (starting the supply unit not allowed)</td> </tr> <tr> <td>1</td> <td>Run enable signal on (starting the supply unit allowed). Close the main disconnecting device (if present).</td> </tr> </table>	0	Run enable signal off (starting the supply unit not allowed)	1	Run enable signal on (starting the supply unit allowed). Close the main disconnecting device (if present).
0	Run enable signal off (starting the supply unit not allowed)						
1	Run enable signal on (starting the supply unit allowed). Close the main disconnecting device (if present).						
5	E-STOP RE-SET	-	Emergency stop reset push button (with emergency stop options only)				
6	EARTH FAULT	-	Ground (earth) fault light with option +Q954				
7	-	-	Reserved for order-based engineered equipment				

8	EMERGENCY STOP	-	Emergency stop push button (with emergency stop options only)
The layout depends on the options selected.			

■ Main disconnecting device [Q1]

The drive is equipped with a main circuit breaker [Q1]. Units with 12-pulse supply connection (option +A004), as well as some of the largest 6-pulse types, have two breakers, [Q1.1] and [Q1.2]. To close the main breaker, auxiliary voltage must be switched on, and the grounding switch (if present) must be open.

By racking out the breaker, you can isolate the main circuit of the drive from the power line.



WARNING!

The main disconnecting device does not isolate the input power terminals, AC voltage meters, or the auxiliary voltage circuit from the power line. To isolate the auxiliary voltage circuit, open the auxiliary voltage switch [Q21]. To isolate the input power terminals and AC voltage meters, open the main breaker of the supply transformer.

■ Auxiliary voltage switch [Q21]

The auxiliary voltage switch controls the supply to the internal auxiliary voltage transformers. The transformer feeds the control circuits inside the drive such as cooling fans, relays and measuring equipment.

This switch is not present if optional connection for an external auxiliary voltage supply is selected.

■ Grounding (earthing) switch [Q9], optional

The grounding switch [Q9] (option +F259) connects the main AC power bus to the PE busbar. Units with 12-pulse connection (option +A004), as well some of the largest 6-pulse types, have two switches, [Q9.1] and [Q9.2], one for each 6-pulse supply line.

To close the grounding switch, auxiliary voltage must be switched on, and the main disconnecting device must be open.



WARNING!

The grounding switch does not ground the input power terminals of the drive or the auxiliary (control) voltage circuits.

■ Other devices on the door

- Voltmeter (option +G334); comes with a phase selector switch.
Note: The voltage is measured on the supply side of the main switch or breaker.
- AC current meter (option +G335) on one phase.

■ Control panel

The ACS-AP-W is the user interface of the drive. It provides the essential controls such as Start/Stop/Direction/Reset/Reference, and the parameter settings for the inverter control program.

The control panel can be removed by pulling it forward by the top edge and reinstalled in reverse order. For the use of the control panel, see *ACX-AP-x assistant control panel user's manual* (3AUA0000085685 [English]) and the firmware manual.



Control by PC tools

There is a USB connector on the front of the panel that can be used to connect a PC to the drive. When a PC is connected to the control panel, the control panel keypad is disabled.

Descriptions of options

Note: All options are not available for all drive types, do not coexist with certain other options, or may require additional engineering. Check actual availability with ABB.

■ Degree of protection

The standard degree of protection is IP42 (UL type 1). IP54 (UL type 12) is available as option +B055.

Definitions

According to IEC/EN 60529, the degree of protection is indicated by an IP code where the first numeral means protection against ingress of solid foreign objects, and the second numeral protection against ingress of water. The IP codes of the standard cabinet and options covered in this manual are defined below.

IP code	The equipment is protected ...	
	First numeral	Second numeral
IP42	against ingress of solid foreign objects > 1 mm	against dripping (15° tilting) water
IP54	dust-protected	against splashing water

* meaning for protection of persons: against access to hazardous parts with finger

■ Marine construction (option +C121)

The option includes the following accessories and features:

- reinforced mechanics
- grab railings
- door flush bolt which allows the door to open 90 degrees and prevents it from slamming close
- self-extinctive materials
- flat bars at base of the cabinet for fastening
- fastening brackets at the top of the cabinet.

Additional wire markings may be required for classification. See section [Wire markings \(page 39\)](#).

■ Plinth height (options +C164 and +C179)

These options specify a plinth height of 100 mm (+C164) or 200 mm (+C179).

■ Resistor braking (options +D150 and +D151)

See chapter [Resistor braking \(page 219\)](#).

■ du/dt filter (option +E205)

The du/dt filter protects the motor insulating system by reducing the voltage rise speed at the motor terminals. The filter also protects the motor bearings by reducing the bearing currents.

More information on when the option is required: See section [Examining the compatibility of the motor and drive \(page 66\)](#).

■ Cabinet heater with external supply (option +G300)

The option contains:

- heating elements in the cubicles or supply/inverter modules
- load switch for providing electrical isolation during service
- miniature circuit breaker for overcurrent protection
- terminal block for external power supply.

The heater prevents humidity condensation inside the cabinet when the drive is not running. The power output of the semiconductor-type heating elements depends on the environmental temperature. The customer must switch the heating off when it is not needed by cutting the supply voltage off.

The customer must supply the heater from an external 110...240 V AC power source.

For the actual wiring, see the circuit diagrams delivered with drive.

■ Cabinet lighting (option +G301)

This option contains LED lighting fixtures in each cubicle (except joining and brake resistor cubicles) and a 24 V DC power supply. The lighting is powered from the same external 110...240 V AC power source as the cabinet heater (option +G300).

■ Terminals for external control voltage (option +G307)

The option provides terminals for connecting an external uninterruptible control voltage to the control unit and control devices when the drive is not powered.

See also:

- [Supplying power for the auxiliary circuits \(page 78\)](#)
- circuit diagrams delivered with drive for the actual wiring.

■ Halogen-free wiring and materials (option +G330)

The option provides halogen-free cable ducts, control wires and wire sleeves, thus reducing toxic fire gases.

■ Wire markings

Standard wiring

Color

The standard color of the wiring is black, with the following exceptions:

- PE wiring: Yellow/Green, or yellow/green sleeving
- UPS input wiring (option +G307): Orange
- Pt100 sensor wiring with ATEX-certified thermal protection (option +nL514): Light blue.

Markings

As standard, wires and terminals are marked as follows:






- Main circuit terminals: Connector identifier (eg. "U1") marked on terminal, or on insulating material close to the terminal. Input and output main circuit cables are not marked.
 - Plug-in connectors of wire sets (except those that require special tools to disconnect) are labeled with connector designation (eg. "X1"). The marking is either directly on the connector, or near the connector on printed sleeving or tape.
 - Grounding busbars are marked with stickers.
-

40 Operation principle and hardware description

- Fiber optic cable pairs and data cables have component designation and connector designations (eg. "A1:V1", "A1:X1") marked with rings or tape.
- Data cables are marked with tape.
- Ribbon cables are marked with either labels or tape.
- Customer-specific (engineered) wiring (option +P902) is not marked.

Additional wire markings

The following additional wire markings are available.

Option	Additional markings
+G338 (class A1)	<p>Equipment pin identifiers are marked with printing (or equivalent) on conductors that connect to equipment, or are part of the wiring between power modules. (Short, obvious connections, main circuit conductors, and conductors going to terminal blocks or plug-type connectors are not marked.)</p> 
+G339 (class A2)	<p>Equipment pin identifiers are marked with printing (or equivalent) on conductors that connect to equipment or terminal blocks, or are part of the wiring between power modules. Main circuit conductors are marked with white tape or printing. (Short, obvious connections, or conductors going to plug-type connectors are not marked.)</p> 
+G340 (class A3)	<p>Single wires not attached to plug-in connectors are marked with component pin numbers on snap-on or ring markers. Plug-in connectors are marked with an identification label placed on the wires near the connector (individual wires are not marked). Short, obvious connections are not marked. PE wires are not marked unless connected directly to components.</p> 
+G341 (class B1)	<p>Equipment designations and pin identifiers are marked with snap-on markers (or equivalent) on conductors that connect to equipment, terminal blocks or detachable plug-type connectors, or are part of the wiring between power modules. Fiber optic cables are marked in the same way. Plug-type connector identifications are marked on labels near the connectors. The label holders are attached around conductor bundles. Main circuit conductors are marked with white tape or printing. Short and obvious connections are marked with printing (or equivalent) only.</p>  <p>Note: Even wires with equipment and pin identifiers printed on the wire insulation are marked with rings or tubing.</p>
+G342 (class C1)	<p>Single wires connected to components, between modules, or to terminal blocks are marked with component identification and pin numbers for both ends. The marking is printed on sleeving or, if necessary, snap-on markers. Plug-in connectors are marked with an identification label (or snap-on markers) placed on the wires near the connector (individual wires are not marked). Short, obvious connections are not marked. PE wires are not marked unless connected directly to components.</p> 

■ Thermal protection with PTC relays (options +L505, +2L505, +L513, +2L513, +L536, +L537)

PTC thermistor relay options are used for overtemperature supervision of motors equipped with PTC sensors. When the motor temperature rises to the thermistor wake-up level, the resistance of the sensor increases sharply. The relay detects the change and indicates motor overtemperature through its contacts.

+L505, +2L505, +L513, +2L513

Option +L505 provides a thermistor relay and a terminal block. The terminal block has connections for the measuring circuit (one to three PTC sensors in series), an output indication of the relay, and an optional external reset button. The relay can be reset either locally or externally, or the reset circuit can be jumpered for automatic reset.

By default, the thermistor relay is wired internally to digital input DI6 of the drive control unit. The loss of the input is set to trigger an external fault.

The output indication on the terminal block can be wired by the customer, for example, to an external monitoring circuit. See the circuit diagrams delivered with the drive.

Option +L513 is an ATEX-certified thermal protection function that has the same external connectivity as +L505. In addition, +L513 comes with +Q971 (ATEX-certified safe disconnection function) as standard and is wired at the factory to activate the Safe torque off function of the drive in an overtemperature situation. A manual reset for the protection function is required by Ex/ATEX regulations. For more information, see *ATEX-certified motor thermal protection functions for cabinet-built ACS880 drives (options +L513+Q971 and +L514+Q971) user's manual* (3AXD50000014979 [English]).

Options +2L505 and +2L513 duplicate options +L505 and +L513 respectively, containing the relays and connections for two separate measurement circuits.

+L536, +L537

An alternative to a thermistor relay option is the FPTC-01 (option +L536) or FPTC-02 (+L537, also requires +Q971) thermistor protection module. The module mounts onto the inverter control unit, and has reinforced insulation to keep the control unit PELV-compatible. The connectivity of the FPTC-01 and the FPTC-02 is the same; FPTC-02 is Type Examined as a protective device within the scope of the European ATEX Product Directive.

For protection purposes, the FPTC has a "fault" input for the PTC sensor. An overtemperature situation executes the SIL/PL-capable SMT (Safe motor temperature) safety function by activating the Safe torque off function of the drive.

The FPTC also has a "warning" input for the sensor. When the module detects overtemperature through this input, it sends a warning indication to the drive.

For more information and wiring examples, see the module manuals and the circuit diagrams delivered with the drive.

See also

- firmware manual for parameter settings
 - *ATEX-certified motor thermal protection functions for cabinet-built ACS880 drives (options +L513+Q971 and +L514+Q971) user's manual* (3AXD50000014979 [English])
 - *FPTC-01 thermistor protection module (option +L536) for ACS880 drives user's manual* (3AXD50000027750 [English])
-

- *FPTC-02 ATEX-certified thermistor protection module, Ex II (2) GD (option +L537+Q971) for ACS880 drives user's manual (3AXD50000027782 [English])*
- circuit diagrams delivered with the drive for the actual wiring.

■ Thermal protection with Pt100 relays (options +nL506, +nL514)

Pt100 temperature monitoring relays are used for overtemperature supervision of motors equipped with Pt100 sensors. For example, there can be three sensors to measure the temperature of the motor windings and two sensors for the bearings. As the temperature rises, the sensor resistance increases linearly. At an adjustable wake-up level, the monitoring relay de-energizes its output.

The standard Pt100 relay options include three (+3L506), five (+5L506) or eight (+8L506) relays. By default, the relays are wired internally to digital input DI6 of the drive control unit. The loss of the input is set to trigger an external fault. The options include a terminal block for sensor connection. The output indication on the terminal block can be wired by the customer, for example, to an external monitoring circuit. See the circuit diagrams delivered with the drive.

Options +3L514 (3 relays), +5L514 (5 relays) and +8L514 (8 relays) are ATEX-certified thermal protection functions that have the same external connectivity as +nL506. In addition, each monitoring relay has a 0/4...20 mA output that is available on the terminal block. Option +nL514 comes with +Q971 (ATEX-certified safe disconnection function) as standard and is wired at the factory to activate the Safe torque off function of the drive in an overtemperature situation. As the monitoring relay does not have a reset functionality, the manual reset required by Ex/ATEX regulations must be implemented using drive parameters. For more information, see *ATEX-certified motor thermal protection functions for cabinet-built ACS880 drives (options +L513+Q971 and +L514+Q971) user's manual (3AXD50000014979 [English])*.


See also

- firmware manual for parameter settings
 - *ATEX-certified motor thermal protection functions for cabinet-built ACS880 drives (options +L513+Q971 and +L514+Q971) user's manual (3AXD50000014979 [English])*
 - Pt100 relay alarm and trip limit setting instructions in the start-up instructions
 - circuit diagrams delivered with the drive for the actual wiring.
-

Type designation label

The type designation label includes ratings, appropriate markings, a type designation and a serial number, which allow the identification of each unit. A sample label is shown below.

Quote the complete type designation and serial number when contacting technical support.



1	Type designation (see section Type designation key)
2	Frame size
3	Short-time withstand current rating (see chapter Technical data (page 161)); degree of protection; UL/CSA specifications
4	Ratings. See also chapter Technical data (page 161) .
5	Valid markings
6	Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week, respectively. The remaining digits complete the serial number so that there are no two units with the same number.
7	Link to product information

Type designation key

The type designation contains information on the specifications and configuration of the drive. The first digits from left express the basic drive type. The optional selections are given thereafter, separated by plus signs, eg, +E202. Codes preceded by a minus sign (eg. -J400) indicate the absence of the specified feature. The main selections are described below. Not all selections are available for all types. For more information, refer to the ordering instructions available separately on request.

Code	Description
Basic code	
ACS880	Product series
ACS880-07LC	Default configuration: liquid-cooled cabinet-installed drive, IP42 (UL Type 1), supply frequency 50 Hz, control (auxiliary) voltage 230 V AC, half-controlled diode thyristor bridge, IEC industrial cabinet construction, default main switch type: air circuit breaker, aR fuses, degree of protection IP42 (UL type 1), EMC filter (category 3, 2nd Environment), EN/IEC approved components, speed-controlled module cooling fans, DC busbar material copper, cable supply conductors, standard wiring material, power and control cabling through the bottom of the cabinet with lead-through, European motor cabling, ACS-AP-W assistant control panel (with Bluetooth), ACS880 primary control program, Safe torque off function, coated circuit boards, multilingual door device label sticker, complete documentation in English in a USB memory stick.
Size	

44 Operation principle and hardware description

Code	Description
xxxxx	Refer to the rating tables
Voltage range	
7	525...690 V AC. This is indicated in the type designation label as typical input voltage levels (3~ 525/600/690 V AC)

■ Option codes

Code	Description
A004	12-pulse supply connection
A012	50 Hz supply frequency
A013	60 Hz supply frequency
B054	IP42 (UL Type 1)
B055	IP54 (UL Type 12)
C121	Marine construction. See section Marine construction (option +C121) (page 38) .
C132	Marine type approval. Refer to ACS880 +C132 marine type-approved cabinet-built drives supplement (3AXD50000039629 [English]) .
C164	Plinth height 100 mm. See section Plinth height (options +C164 and +C179) (page 38) .
C176	Door hinges on left
C179	Plinth height 200 mm. See section Plinth height (options +C164 and +C179) (page 38) .
C205	Marine product certification issued by DNV GL
C206	Marine product certification issued by the American Bureau of Shipping (ABS)
C207	Marine product certification issued by Lloyd's Register (LR)
C209	Marine product certification issued by Bureau Veritas
C228	Marine product certification issued by China Classification Society (CCS)
C229	Marine product certification issued by Russian Maritime Register of Shipping (RS)
D150	Brake choppers
D151	Brake resistors
E205	du/dt filtering
E210	EMC/RFI filter for 2nd environment TN (grounded) or IT (ungrounded) system, category C3
G300	Cabinet and module heating elements (external supply). See section Cabinet heater with external supply (option +G300) (page 39) .
G301	Cabinet lighting. See section Cabinet lighting (option +G301) (page 39) .
G304	Control (auxiliary) voltage 115 V AC
G307	Terminals for connecting external control voltage (230 V AC or 115 V AC, eg. UPS). See section Terminals for external control voltage (option +G307) (page 39) .
G315	Tin-plated copper DC busbars
G320	Control (auxiliary) voltage 230 V AC
G330	Halogen-free wiring and materials
G338	Additional wire markings. See section Wire markings (page 39) .
G339	
G340	
G341	
G342	
G342	

Code	Description
G344	Auxiliary voltage transformer
H350	Bottom power cable entry
H351	Top power cable entry
H352	Motor cabling direction down
H353	Motor cabling direction up
H358	Cable gland plates (3 mm steel, undrilled)
H364	Cable gland plates (3 mm aluminum, undrilled)
H365	Cable gland plates (6 mm brass, undrilled)
H367	Control cable entry through floor of cabinet
H368	Control cabling through roof of cabinet
K451	FDNA-01 DeviceNet™ adapter module
K454	FPBA-01 PROFIBUS DP adapter module
K457	FCAN-01 CANopen adapter module
K458	FSCA-01 RS-485 (Modbus/RTU) adapter module
K462	FCNA-01 ControlNet™ adapter module
K469	FECA-01 EtherCat adapter module
K470	FEPL-02 EtherPOWERLINK adapter module
K475	FENA-21 Ethernet adapter module for EtherNet/IP™, Modbus TCP and PROFINET IO protocols, 2-port
K490	FEIP-21 Ethernet adapter module for EtherNet/IP™
K491	FMBT-21 Ethernet adapter module for Modbus TCP
K492	FPNO-21 Ethernet adapter module for PROFINET IO
L505	Thermal protection with PTC relays (1 or 2 pcs). See section Thermal protection with PTC relays (options +L505, +2L505, +L513, +2L513, +L536, +L537) (page 41) .
L506	Thermal protection with Pt100 relays (3, 5 or 8 pcs). See section Thermal protection with Pt100 relays (options +nL506, +nL514) (page 42) .
L513	ATEX-certified thermal protection with PTC relays (1 or 2 pcs)
L514	ATEX-certified thermal protection with Pt100 relays (3, 5 or 8 pcs)
L536	FPTC-01 thermistor protection module
L537	FPTC-02 ATEX-certified thermistor protection module
N8010	IEC 61131-3 application programmability
P913	Special color (RAL Classic)
P966	Special color (other than RAL Classic)
Q951	Emergency stop (category 0) with safety relays, by opening the main breaker/contactor
Q952	Emergency stop (category 1) with safety relays, by opening the main breaker/contactor
Q954	Earth fault monitoring for IT (ungrounded) systems
Q963	Emergency stop (category 0) with safety relays, by activating the Safe torque off function
Q964	Emergency stop (category 1) with safety relays, by activating the Safe torque off function
Q978	Emergency stop (configurable for category 0 or 1) with FSO-xx safety functions module, by opening the main breaker/contactor
Q979	Emergency stop (configurable for category 0 or 1) with FSO-xx safety functions module, by activating the Safe torque off function
Q982	PROFIsafe with FSO-xx safety functions module and FENA-21 Ethernet adapter module

46 Operation principle and hardware description

Code	Description
Q984	Emergency stop button monitoring
Q986	FSPS-21 PROFIsafe safety functions module

4

Mechanical installation

Contents of this chapter

This chapter describes the mechanical installation procedure of the drive.



Examining the installation site

Examine the installation site. Make sure that:

- The installation site is sufficiently ventilated or cooled to remove heat from the drive. See the technical data.
- The ambient conditions of the drive meet the specifications. See the technical data.
- There is sufficient free space above the drive for cooling, maintenance, and operation of the pressure relief (if present).
- The floor that the drive cabinet is installed on is of non-flammable material, as smooth as possible, and strong enough to support the weight of the unit. Check the floor flatness with a spirit level. The maximum allowed deviation from the surface level is 5 mm in every 3 meters. Level the installation site, if necessary, as the cabinet is not equipped with adjustable feet.

Necessary tools

The tools required for moving the unit to its final position, fastening it to the floor and wall and tightening the connections are listed below:

- crane, fork-lift or pallet truck (check load capacity!), slate/spud bar, jack and rollers
 - Pozidriv and Torx screwdrivers
 - torque wrench
 - set of wrenches or sockets.
-

Examining the delivery

The drive delivery contains:

- drive cabinet line-up
- optional modules (if ordered) installed onto the control unit(s) at the factory
- appropriate drive and optional module manuals
- delivery documents.

Make sure that there are no signs of damage. Before attempting installation and operation, see the information on the type designation labels of the drive to verify that the delivery is of the correct type.



Moving and unpacking the drive

Move the drive in its original packaging to the installation site as shown below to avoid damaging the cabinet surfaces and door devices. When you are using a pallet truck, check its load capacity before you move the drive.

The drive cabinet is to be moved in the upright position.

The center of gravity of the cabinet is high. Be therefore careful when moving the unit. Avoid tilting.

■ Removing the transport package

Remove the transport package as follows:

1. Undo the screws that attach the wooden parts of the transport crate to each other.
2. Remove the wooden parts.
3. Remove the clamps with which the drive cabinet is mounted onto the transport pallet by undoing the fastening screws.
4. Remove the plastic wrapping.



■ Moving the unpacked drive cabinet

Lifting the cabinet with a crane




WARNING!

Incorrect lifting can cause danger or damage. Obey the local laws and regulations applicable to lifting, such as requirements for planning the lift, for capacity and condition of lifting equipment, and for training of personnel.

Lift the drive cabinet by its designated lifting points. Depending on the size of the cabinet, it has either bolt-on lifting lugs, or lifting bars with lifting holes.

Note: The minimum allowed height of the lifting slings with IP54 units is 2 meters (6'7").




Moving the cabinet on rollers



WARNING!


Do not move marine versions (option +C121) on rollers.

Lay the cabinet on the rollers and move it carefully until close to its final location. Remove the rollers by lifting the unit with a crane, forklift, pallet truck or jack.



Moving the cabinet on its back


If the cabinet needs to be laid on its back, support the cabinet from below alongside the cubicle seams.



1	Cabinet back panel
2	Support

Final placement of the cabinet


Move the cabinet into its final position with a slate bar (spud bar). Place a piece of wood between the edge of the cabinet and the bar to protect the cabinet frame.



Attaching the cabinet to the floor and wall or roof


■ General rules

- The drive must be installed in an upright vertical position.
- Leave 250 mm (9.85") of free space above the cabinet for maintenance, and to allow pressure relief operation.
- The cabinet can be installed with its back against a wall (a), or back-to-back with another unit (b).
- Leave some space (w) at the side where the cabinet outmost hinges are to allow the doors to open sufficiently. The doors must open 120° to allow supply or inverter module replacement.



Note 1: Any height adjustment must be done before fastening the cabinet sections to the floor or to each other. Height adjustment can be done by using metal shims between the cabinet bottom and floor.




Note 2: Depending on the size of the cabinet, it has either bolt-on lifting eyes, or lifting bars with lifting holes. If the cabinet is delivered with lifting bars, remove them. Store the bars for decommissioning. Bolt-on lifting eyes need not be removed unless the holes are used for fastening the cabinet. Plug any unused holes using the existing bolts and sealing rings included. Tighten to 70 N·m (52 lbf·ft).



■ **Attaching the cabinet (non-marine units)**

Alternative 1 – Clamping


1. Insert the clamps (included) into the twin slots along the front and rear edges of the cabinet frame body and fasten them to the floor with a bolt. The recommended maximum distance between the clamps in the front edge is 800 mm (31.5”).
2. If floor mounting at the back is not possible, fasten the top of the cabinet to the wall with L-brackets (not included in the delivery) bolted to the lifting eye/bar holes, and suitable hardware.

Clamping bottom to floor	Attaching top to wall
	
	



Alternative 2 – Using the holes inside the cabinet

1. Attach the cabinet to the floor through the bottom fastening holes with M10 to M12 (3/8" to 1/2") bolts. The recommended maximum distance between the front edge fastening points is 800 mm (31.5").
2. If the back fastening holes are not accessible, fasten the top of the cabinet to the wall with L-brackets (not included in the delivery) bolted to the lifting eye/bar holes.



■ **Attaching the cabinet (marine units)**

See the dimension drawing delivered with the drive for details of the fastening points.

Fasten the cabinet to the floor and roof (wall) as follows:

1. Bolt the unit to the floor through the flat bars at the base of the cabinet using M10 or M12 screws.
2. If there is not enough room behind the cabinet for installation, clamp (a) the rear edges of the flat bars (c) to the floor. See the figure below.
3. Attach corner brackets (d) to the lifting eye holes. Fasten the corner brackets to the rear wall and/or roof with suitable hardware such as U-brackets (e).


<p style="text-align: center;">②</p>	<p style="text-align: center;">③</p>
<p>a Clamp (not included)</p>	<p>d Corner bracket (included)</p>
<p>b Back panel of cabinet</p>	<p>e U-bracket (not included)</p>
<p>c Flat bars at base of cabinet</p>	<p>- -</p>




Joining cabinet sections together

Wide cabinet line-ups are delivered in multiple sections. The sections are to be joined on-site using a 200 mm wide joining cubicle at the end of one section (a common motor terminal cubicle can also act as a joining cubicle). The screws required for the joining are enclosed in a plastic bag inside the cabinet. The threaded bushings are already mounted on the cabinet posts.

1. Fasten the first section to the floor.
2. Remove any plates covering the rear post of the joining cubicle.
3. Slide Axilock connectors onto the coolant pipes at the joint.




4. Align the two sections.
The coolant pipe ends must be aligned as shown.




58 Mechanical installation


- Center the Axilock connectors onto the gaps between coolant pipe ends. Tighten the connector screws to the torque indicated on the connector label.



- Fasten the front and rear posts of the joining cubicle to the posts of the other section with 14 screws (7 per post). Tighten the screws to 5 N·m (3.7 lbf·ft).
- Fasten the second section to the floor.




- Connect the PE busbars using the M10 bolts included. Tighten to 35...40 N·m (25...30 lbf·ft).



- Remove the shroud covering the DC busbars in the joining cubicle.

- Use the joint pieces to connect the DC busbars. Tighten the bolts to 55...70 N·m (40...50 lbf·ft).



WARNING!

Make sure you install the washers in the correct order as shown. For example, placing an unpassivated zinc-coated spring washer directly against the joint piece will cause corrosion.



WARNING!

Do not use any joining parts other than those delivered with the unit. The parts are carefully selected to match the material of the busbars. Other parts or materials can form a galvanic couple and cause corrosion.


- Reinstall any covering plates removed earlier.
- Repeat procedure for any further sections.

Miscellaneous

■ Cable duct in the floor below the cabinet

A cable duct can be constructed below the 500 mm wide middle part of the cabinet. The cabinet weight lies on the two 50 mm wide transverse sections which the floor must carry.

Prevent the cooling air flow from the cable duct to the cabinet by bottom plates. To ensure the degree of protection for the cabinet, use the original bottom plates delivered with the unit. With user-defined cable entries, take care of the degree of protection, fire protection and EMC compliance.



■ Arc welding

ABB does not recommend attaching the cabinet by arc welding. However, if arc welding is the only option, connect the return conductor of the welding equipment to the cabinet frame at the bottom within 0.5 meters (1'6") of the welding point.

Note: The thickness of the zinc plating of the cabinet frame is 100...200 micrometers (4...8 mil).



WARNING!

Make sure that the return wire is connected correctly. Welding current must not return via any component or cabling of the drive. If the welding return wire is connected improperly, the welding circuit can damage electronic circuits in the cabinet.



WARNING!

Do not inhale the welding fumes.



Lifting lugs and bars

■ Certificate of conformity

The certificate is available in ABB Library at www.abb.com/drives/documents (document number 3AXD10001061361).

■ Declaration of Conformity



EU Declaration of Conformity

Machinery Directive 2006/42/EC

We

Manufacturer: ABB Oy

Address: Hiomotie 13, 00380 Helsinki, Finland.

Phone: +358 10 22 11

declare under our sole responsibility that the following products:

Lifting bars, identified with material codes

64300971	64301284	64301411	64485342
64301047	64301306	64456695	64485351
64301063	64301314	64456725	64485369
64301080	64301322	64456822	64485377
64301101	64301331	64456881	64485458
64301136	64301349	64456890	68775558
64301152	64301357	64456920	68775540
64301187	64301365	64485296	3AUA5000013498
64301209	64301373	64485300	3AUA5000013504
64301250	64301381	64485318	3AUA0000055356
64301268	64301390	64485326	3AXD50000435524
64301276	64301403	64485334	3AXD50000435548

Lifting lugs, identified with material codes

64302621 64327151

used for lifting the following **frequency converters** and **frequency converter components**

ACS800LC types -x7LC, LC multidrives, -x07LC

ACS580, ACH580, ACQ580 types -07

ACS880 types -x7, multidrives, -x07, -xx07

ACS880LC types -x7LC, LC multidrives, -x07LC, -xx07

identified with serial numbers beginning with 1 or 8





are in conformity with all the relevant lifting accessory requirements of EU Machinery Directive 2006/42/EC.

Person authorized to compile the technical file:
Name and address: Vesa Tiihonen, Hiomotie 13, 00380 Helsinki, Finland


Helsinki, 16 Dec 2019

Signed for and on behalf of:


Peter Lindgren
Vice President, ABB Oy


Vesa Tiihonen
Manager, Product Engineering and Quality





5

Guidelines for planning the electrical installation

Contents of this chapter

This chapter contains instructions for planning the electrical installation of the drive. Some instructions are mandatory to follow in every installation, others provide useful information that only concerns certain applications.

Limitation of liability

The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

Selecting the supply disconnecting device

The drive is equipped with a main disconnecting device as standard. Depending on the size of the drive, and the selected options, the type of disconnecting device may vary. Examples: switch-disconnector, withdrawable air circuit breaker, etc.

Selecting the main contactor or breaker

Depending on the drive size, you can order it either with a main contactor (option +F250), or a main breaker (option +F255).

Examining the compatibility of the motor and drive

Use asynchronous AC induction motors, permanent magnet synchronous motors, AC induction servomotors or ABB synchronous reluctance motors (SynRM motors) with the drive.

Select the motor size and drive type from the rating table on basis of the AC line voltage and motor load. You can find the rating table in the appropriate hardware manual. You can also use the DriveSize PC tool.

Make sure that the motor withstands the maximum peak voltage in the motor terminals. See [Requirements table \(page 66\)](#). For basics of protecting the motor insulation and bearings in drive systems, see [Protecting the motor insulation and bearings \(page 66\)](#).

Note:

- Consult the motor manufacturer before using a motor whose nominal voltage differs from the AC line voltage connected to the drive input.
- The voltage peaks at the motor terminals are relative to the supply voltage of the drive, not the drive output voltage.
- If the motor and drive are not of the same size, consider the operation limits of the drive control program for the motor nominal voltage and current. See the appropriate parameters in the firmware manual.

■ Protecting the motor insulation and bearings

The drive employs modern IGBT inverter technology. Regardless of frequency, the drive output comprises pulses of approximately the drive DC bus voltage with a very short rise time. The pulse voltage can almost double at the motor terminals, depending on the attenuation and reflection properties of the motor cable and the terminals. This can cause additional stress on the motor and motor cable insulation.

Modern variable speed drives with their fast rising voltage pulses and high switching frequencies can generate current pulses that flow through the motor bearings. This can gradually erode the bearing races and rolling elements.

du/dt filters protect motor insulation system and reduce bearing currents. Common mode filters mainly reduce bearing currents. Insulated N-end (non-drive end) bearings protect the motor bearings.

■ Requirements table

These tables show how to select the motor insulation system and when a drive du/dt and common mode filters and insulated N-end (non-drive end) motor bearings are required. Ignoring the requirements or improper installation may shorten motor life or damage the motor bearings and voids the warranty.

This table shows the requirements when an ABB motor is in use.

Motor type	Nominal AC supply voltage	Requirement for			
		Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings		
			$P_N < 100 \text{ kW}$ and frame size $< \text{IEC 315}$	$100 \text{ kW} \leq P_N < 350 \text{ kW}$ or $\text{IEC 315} \leq \text{frame size} < \text{IEC 400}$	$P_N \geq 350 \text{ kW}$ or frame size $\geq \text{IEC 400}$
$P_N < 134 \text{ hp}$ and frame size $< \text{NEMA 500}$	$134 \text{ hp} \leq P_N < 469 \text{ hp}$ or $\text{NEMA 500} \leq \text{frame size} \leq \text{NEMA 580}$	$P_N \geq 469 \text{ hp}$ or frame size $> \text{NEMA 580}$			
Random-wound M2_, M3_ and M4_	$U_N \leq 500 \text{ V}$	Standard	-	+ N	+ N + CMF
	$500 \text{ V} < U_N \leq 600 \text{ V}$	Standard	+ du/dt	+ N + du/dt	+ N + du/dt + CMF
		or			
	$600 \text{ V} < U_N \leq 690 \text{ V}$ (cable length $\leq 150 \text{ m}$)	Reinforced	-	+ N	+ N + CMF
		Reinforced	+ du/dt	+ N + du/dt	+ N + du/dt + CMF
$600 \text{ V} < U_N \leq 690 \text{ V}$ (cable length $> 150 \text{ m}$)	Reinforced	-	+ N	+ N + CMF	
Form-wound HX_ and AM_	$380 \text{ V} < U_N \leq 690 \text{ V}$	Standard	n.a.	+ N + CMF	$P_N < 500 \text{ kW}$: +N + CMF
					$P_N \geq 500 \text{ kW}$: +N + du/dt + CMF
Old ¹⁾ form-wound HX_ and modular	$380 \text{ V} < U_N \leq 690 \text{ V}$	Check with the motor manufacturer.	+ N + du/dt with voltages over 500 V + CMF		
Random-wound HX_ and AM_ ²⁾	$0 \text{ V} < U_N \leq 500 \text{ V}$	Enamelled wire with fiber glass taping	+ N + CMF		
	$500 \text{ V} < U_N \leq 690 \text{ V}$		+ N + du/dt + CMF		
HDP	Consult the motor manufacturer.				

1) manufactured before 1.1.1998

2) For motors manufactured before 1.1.1998, check for additional instructions with the motor manufacturer.

This table shows the requirements when a non-ABB motor is in use.

Motor type	Nominal AC supply voltage	Requirement for			
		Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings		
			$P_N < 100 \text{ kW}$ and frame size $< \text{IEC 315}$	$100 \text{ kW} \leq P_N < 350 \text{ kW}$ or $\text{IEC 315} \leq \text{frame size} < \text{IEC 400}$	$P_N \geq 350 \text{ kW}$ or frame size $\geq \text{IEC 400}$
$P_N < 134 \text{ hp}$ and frame size $< \text{NEMA 500}$	$134 \text{ hp} \leq P_N < 469 \text{ hp}$ or $\text{NEMA 500} \leq \text{frame size} \leq \text{NEMA 580}$	$P_N \geq 469 \text{ hp}$ or frame size $> \text{NEMA 580}$			
Random-wound and form-wound	$U_N \leq 420 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	-	+ N or CMF	+ N + CMF
	$420 \text{ V} < U_N \leq 500 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	+ du/dt	+ du/dt + (N or CMF)	+ N + du/dt + CMF
		or	Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$, 0.2 micro-second rise time	-	+ N or CMF
	$500 \text{ V} < U_N \leq 600 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$	+ du/dt	+ du/dt + (N or CMF)	+ N + du/dt + CMF
		or	Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	-	+ N or CMF
	$600 \text{ V} < U_N \leq 690 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	+ du/dt	+ du/dt + N	+ N + du/dt + CMF
		Reinforced: $\hat{U}_{LL} = 2000 \text{ V}$, 0.3 micro-second rise time ¹⁾	-	+ N + CMF	+ N + CMF

¹⁾ If the intermediate DC circuit voltage of the drive is increased from the nominal level due to long term resistor braking cycles, check with the motor manufacturer if additional output filters are needed in the applied drive operation range.

The abbreviations used in the tables are defined below.

Abbr.	Definition
U_N	Nominal AC line voltage
\hat{U}_{LL}	Peak line-to-line voltage at motor terminals which the motor insulation must withstand
P_N	Motor nominal power
du/dt	du/dt filter at the output of the drive
CMF	Common mode filter
N	N-end bearing: insulated motor non-drive end bearing
n.a.	Motors of this power range are not available as standard units. Consult the motor manufacturer.

Availability of du/dt filter and common mode filter by drive type

Product type	Availability of du/dt filter	Availability of common mode filter (CMF)
ACS880-07LC	Standard	Standard

Additional requirements for explosion-safe (EX) motors

If you will use an explosion-safe (EX) motor, follow the rules in the requirements table above. In addition, consult the motor manufacturer for any further requirements.

Additional requirements for ABB motors of types other than M2_, M3_, M4_, HX_ and AM_

Use the selection criteria given for non-ABB motors.

Additional requirements for ABB high-output and IP23 motors

The rated output power of high output motors is higher than what is stated for the particular frame size in EN 50347 (2001).

This table shows the requirements for protecting the motor insulation and bearings in drive systems for ABB random-wound motor series (for example, M3AA, M3AP and M3BP).

Nominal AC supply voltage	Requirement for			
	Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings		
		$P_N < 100 \text{ kW}$	$100 \text{ kW} \leq P_N < 200 \text{ kW}$	$P_N \geq 200 \text{ kW}$
		$P_N < 140 \text{ hp}$	$140 \text{ hp} \leq P_N < 268 \text{ hp}$	$P_N \geq 268 \text{ hp}$
$U_N \leq 500 \text{ V}$	Standard	-	+ N	+ N + CMF
$500 \text{ V} < U_N \leq 600 \text{ V}$	Standard	+ du/dt	+ du/dt + N	+ du/dt + N + CMF
	or			
$600 \text{ V} < U_N \leq 690 \text{ V}$	Reinforced	-	+ N	+ N + CMF
	Reinforced	+ du/dt	+ du/dt + N	+ du/dt + N + CMF

Additional requirements for non-ABB high-output and IP23 motors

The rated output power of high-output motors is higher than what is stated for the particular frame size in EN 50347 (2001).

If you plan to use a non-ABB high-output motor or an IP23 motor, consider these additional requirements for protecting the motor insulation and bearings in drive systems:

- If motor power is below 350 kW: Equip the drive and/or motor with the filters and/or bearings according to the table below.
- If motor power is above 350 kW: Consult the motor manufacturer.

Nominal AC supply voltage	Requirement for		
	Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings	
		$P_N < 100 \text{ kW}$ or frame size $< \text{IEC 315}$	$100 \text{ kW} < P_N < 350 \text{ kW}$ or $\text{IEC 315} < \text{frame size} < \text{IEC 400}$
	$P_N < 134 \text{ hp}$ or frame size $< \text{NEMA 500}$	$134 \text{ hp} < P_N < 469 \text{ hp}$ or $\text{NEMA 500} < \text{frame size} < \text{NEMA 580}$	
$U_N \leq 420 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	+ N or CMF	+ N or CMF
$420 \text{ V} < U_N < 500 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	+ du/dt + (N or CMF)	+ N + du/dt + CMF
	or Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$, 0.2 microsecond rise time	+ N or CMF	+ N or CMF
$500 \text{ V} < U_N \leq 600 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$	+ du/dt + (N or CMF)	+ N + du/dt + CMF
	or Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	+ N or CMF	+ N + CMF
$600 \text{ V} < U_N \leq 690 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	+ N + du/dt	+ N + du/dt + CMF
	Reinforced: $\hat{U}_{LL} = 2000 \text{ V}$, 0.3 microsecond rise time ¹⁾	+ N + CMF	+ N + CMF

¹⁾ If the intermediate DC circuit voltage of the drive is increased from the nominal level due to long term resistor braking cycles, check with the motor manufacturer if additional output filters are needed in the applied drive operation range.

Additional note for sine filters

A sine filter also protects the motor insulation system. The peak phase-to-phase voltage with a sine filter is approximately $1.5 \cdot U_N$.

Selecting the power cables

■ General guidelines

Select the input power and motor cables according to local regulations.

- **Current:** Select a cable capable of carrying the maximum load current.
- **Temperature:** For an IEC installation, select a cable rated for at least 70 °C (158 °F) maximum permissible temperature of conductor in continuous use. For North America, select a cable rated for at least 75 °C (167 °F).
- **Voltage:** 600 V AC cable is accepted for up to 500 V AC. 750 V AC cable is accepted for up to 600 V AC. 1000 V AC cable is accepted for up to 690 V AC.

To comply with the EMC requirements of the CE mark, use one of the preferred cable types. See [Preferred power cable types \(page 71\)](#).

Symmetrical shielded cable reduces electromagnetic emission of the whole drive system as well as the stress on motor insulation, bearing currents and wear.

Metal conduit reduces electromagnetic emission of the whole drive system.

The protective conductor must always have an adequate conductivity.

Unless local wiring regulations state otherwise, the cross-sectional area of the protective conductor must agree with the conditions that require automatic disconnection of the supply

required in 411.3.2. of IEC 60364-4-41:2005 and be capable of withstanding the prospective fault current during the disconnection time of the protective device. The cross-sectional area of the protective conductor can either be selected from the table below or calculated according to 543.1 of IEC 60364-5-54.

This table shows the minimum cross-sectional area of the protective conductor related to the phase conductor size according to IEC/UL 61800-5-1 when the phase conductor and the protective conductor are made of the same metal. If this is not so, the cross-sectional area of the protective grounding conductor shall be determined in a manner which produces a conductance equivalent to that which results from the application of this table.

Cross-sectional area of the phase conductors S (mm ²)	Minimum cross-sectional area of the corresponding protective conductor S _p (mm ²)
S ≤ 16	S ¹⁾
16 < S ≤ 35	16
35 < S	S/2

1) To comply with standard IEC/EN 61800-5-1 (UL 61800-5-1)

- use a protective earth conductor with a minimum cross-sectional area of 10 mm² Cu or 16 mm² Al (as an alternative when aluminum cables are permitted),
or
- use a second protective earth conductor of the same cross-sectional area as the original protective earth conductor,
or
- use a device that automatically disconnects the supply if the protective earth conductor is damaged.

If the protective earth conductor is separate (that is, it does not form part of the input power cable or the input power cable enclosure), the minimum cross-sectional area must be:

- 2.5 mm² when the conductor is mechanically protected,
or
- 4 mm² when the conductor is not mechanically protected.


■ Typical power cable sizes



See the technical data.

■ Power cable types

Preferred power cable types

This section presents the preferred cable types. Make sure that the selected cable type also complies with local/state/country electrical codes.



Cable type	Use as input power cabling	Use as motor cabling
 <p>Symmetrical shielded (or armored) cable with three phase conductors and concentric PE conductor as shield (or armor)</p>	Yes	Yes



Cable type	Use as input power cabling	Use as motor cabling
 <p>Symmetrical shielded (or armored) cable with three phase conductors and symmetrically constructed PE conductor and a shield (or armor)</p>	Yes	Yes
 <p>Symmetrical shielded (or armored) cable with three phase conductors and a shield (or armor), and separate PE conductor/cable¹⁾</p>	Yes	Yes

¹⁾ A separate PE conductor is required if the conductivity of the shield (or armor) is not sufficient for the PE use.


Alternate power cable types

Exception for ACS880-304LC +A019 diode supply modules: These power cable types are not allowed.

Cable type	Use as input power cabling	Use as motor cabling
 <p>Four-conductor cabling in metal conduit (three phase conductors and PE), eg, EMT, or four-conductor armored cable</p>	Yes	Yes with phase conductor smaller than 10 mm ² (8 AWG) Cu, or motors up to 30 kW (40 hp)
 <p>Well-shielded (Al/Cu shield or armor) four-conductor cable (three phase conductors and a PE)</p>	Yes	Yes with motors up to 100 kW (135 hp). A potential equalization between the frames of motor and driven equipment is required.

Cable type	Use as input power cabling	Use as motor cabling
 <p>A single-core cable system: three phase conductors and PE conductor on cable tray</p> <p>Preferable cable arrangement to avoid voltage or current unbalance between the phases</p>	<p>Yes</p>  <p>WARNING! If you use unshielded single-core cables in an IT network, make sure that the non-conductive outer sheath (jacket) of the cables have good contact with a properly grounded conductive surface. For example, install the cables on a properly grounded cable tray. Otherwise voltage may become present on the non-conductive outer sheath of the cables, and there is even a risk of an electric shock.</p>	<p>No</p>


Not allowed power cable types

Cable type	Use as input power cabling	Use as motor cabling
 <p>Symmetrical shielded cable with individual shields for each phase conductor</p>	<p>No</p>	<p>No</p>

■ **Power cable shield**

If the cable shield is used as the sole protective earth (PE) conductor, make sure that its conductivity agrees with the PE conductor requirements.

To effectively suppress radiated and conducted radio-frequency emissions, the cable shield conductivity must be at least 1/10 of the phase conductor conductivity. The requirements are easily met with a copper or aluminum shield. The minimum requirement of the motor cable shield of the drive is shown below. It consists of a concentric layer of copper wires with an open helix of copper tape or copper wire. The better and tighter the shield, the lower the emission level and bearing currents.




Selecting the control cables

■ Shielding

Only use shielded control cables.

Use a double-shielded twisted pair cable for analog signals. This type of cable is recommended for the pulse encoder signals also. Use one individually shielded pair for each signal. Do not use common return for different analog signals.

A double-shielded cable (a) is the best alternative for low-voltage digital signals, but single-shielded (b) twisted pair cable is also acceptable.



■ Signals in separate cables

Run analog and digital signals in separate, shielded cables. Do not mix 24 V DC and 115/230 V AC signals in the same cable.

■ Signals that can be run in the same cable

If their voltage does not exceed 48 V, relay-controlled signals can be run in the same cables as digital input signals. The relay-controlled signals should be run as twisted pairs.

■ Relay cable

The cable type with braided metallic shield (for example ÖLFLEX by LAPPKABEL, Germany) has been tested and approved by ABB.

■ Control panel to drive cable

Use EIA-485 with male RJ-45 connector, cable type Cat 5e or better. The maximum permitted length of the cable is 100 m (328 ft).

■ **PC tool cable**


Connect the Drive composer PC tool to the drive through the USB port of the control panel. Use a USB Type A (PC) - Type Mini-B (control panel) cable. The maximum length of the cable is 3 m (9.8 ft).

Routing the cables

■ **General guidelines – IEC**

- Route the motor cable away from other cables. Motor cables of several drives can be run in parallel installed next to each other.
- Install the motor cable, input power cable and control cables on separate trays.
- Avoid long parallel runs of motor cables with other cables.
- Where control cables must cross power cables, make sure that they are arranged at an angle as near to 90 degrees as possible.
- Do not run extra cables through the drive.
- Make sure that the cable trays have good electrical bonding to each other and to the grounding electrodes. Aluminum tray systems can be used to improve local equalizing of potential.

The following figure illustrates the cable routing guidelines with an example drive.




■ Continuous motor cable shield/conduit or enclosure for equipment on the motor cable

To minimize the emission level when safety switches, contactors, connection boxes or similar equipment are installed on the motor cable between the drive and the motor:

- Install the equipment in a metal enclosure.
- Use either a symmetrical shielded cable, or install the cabling in a metal conduit.
- Make sure that there is a good and continuous galvanic connection in the shield/conduit between drive and motor.
- Connect the shield/conduit to the protective ground terminal of the drive and the motor.

■ Separate control cable ducts

Put 24 V DC and 230 V AC (120 V AC) control cables in separate ducts, unless the 24 V DC cable is insulated for 230 V AC (120 V AC) or insulated with an insulation sleeving for 230 V AC (120 V AC).



Implementing short-circuit and thermal overload protection

■ Protecting the input cabling and the drive upon a short-circuit

To protect the input cabling in short-circuit situations, install fuses or a suitable circuit breaker at the supply side of the cabling.

The drive is equipped with internal AC fuses as standard. In case of a short-circuit inside the drive, the AC fuses protect the drive, restrict drive damage, and prevent damage to adjoining equipment.

■ Protecting the motor and motor cable in short-circuits

The drive protects the motor cable and motor in a short-circuit situation when the motor cable is sized according to the nominal current of the drive. No additional protection devices are needed.

■ Protecting the drive and the power cables against thermal overload

The drive protects itself and the input and motor cables against thermal overload when the cables are sized according to the nominal current of the drive. No additional thermal protection devices are needed.



WARNING!

If the drive is connected to multiple motors, use a separate circuit breaker or fuses for protecting each motor cable and motor against overload. The drive overload protection is tuned for the total motor load. It may not trip due to an overload in one motor circuit only.

■ Protecting the motor against thermal overload

According to regulations, the motor must be protected against thermal overload and the current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the current when necessary. Depending on a drive parameter value, the function either monitors a calculated temperature value (based on a motor thermal model) or an actual temperature indication given by motor temperature sensors.

The motor thermal protection model supports thermal memory retention and speed sensitivity. The user can tune the thermal model further by feeding in additional motor and load data.

The most common temperature sensor types are thermal switch (for example Klixon), PTC or Pt100.

For more information, see the firmware manual.

Protecting the drive against ground faults

The drive is equipped with an internal ground fault protective function to protect the unit against ground faults in the motor and motor cable. This function is not a personnel safety or a fire protection feature. See the firmware manual for more information.

An optional ground fault monitoring device (+Q954) is available for IT (ungrounded) systems. The option includes a ground fault indicator on the drive cabinet door.

■ Residual current device compatibility

The drive is suitable to be used with residual current devices of Type B.

Note: As standard, the drive contains capacitors connected between the main circuit and the frame. These capacitors and long motor cables increase the ground leakage current and may cause nuisance faults in residual current devices.

Implementing the emergency stop function

You can order the drive with an emergency stop function (option).

See the appropriate option manual for more information.

Option code	User's manual	Manual code (English)
+Q951	Emergency stop, stop category 0 (using main contactor/breaker)	3AUA0000119895
+Q952	Emergency stop, stop category 1 (using main contactor/breaker)	3AUA0000119896
+Q963	Emergency stop, stop category 0 (using Safe torque off)	3AUA0000119908
+Q964	Emergency stop, stop category 1 (using Safe torque off)	3AUA0000119909
+Q978	Emergency stop, stop category 0 or 1 (using main contactor/breaker and Safe torque off)	3AUA0000145920
+Q979	Emergency stop, stop category 0 or 1 (using Safe torque off)	3AUA0000145921

Implementing the Safe torque off function

See chapter [The Safe torque off function \(page 201\)](#).

Implementing the power loss ride-through function

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive.

The main contactor or breaker of the drive opens in a power loss situation. When the power returns, the main contactor or breaker closes. However, if the power loss lasts so long that the drive trips on undervoltage, a fault reset and a fresh start command is required to continue operation. These are also required if the auxiliary power buffer module (C22, if present) runs out during the break.

Implement the power-loss ride-through function as follows:

1. Enable the power-loss ride-through function of the drive (parameter 30.31).
2. If the installation is equipped with a main contactor, prevent its tripping at the input power break. For example, use a time delay relay (hold) in the contactor control circuit.
3. Enable the automatic restart of the motor after a short power supply break:
 - Set the start mode to automatic (parameter 21.01 or 21.19, depending on the motor control mode being used).
 - Define the automatic restart time (parameter 21.18).



WARNING!

Make sure that a flying restart of the motor will not cause any danger. If you are in doubt, do not implement the power loss ride-through function.

Implementing a bypass connection

If bypassing is required, employ mechanically or electrically interlocked contactors between the motor and the drive and between the motor and the power line. Make sure with interlocking that the contactors cannot be closed simultaneously. The installation must be clearly marked as defined in IEC/EN 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".

Bypass connection is available as a factory-installed option for some cabinet-installed drive types. Consult ABB for more information.



WARNING!

Never connect the drive output to the electrical power network. The connection may damage the drive.

Supplying power for the auxiliary circuits

Depending on selected drive options, the customer/installer may have to provide the auxiliary voltage from an external supply to the drive. For details, see the circuit diagrams delivered with the drive.

The user must supply these options from external power sources:

- +G300/+G301: Cabinet heaters and/or lighting (230 or 115 V AC; external fuse: 16 A gG)
 - +G307: Connection for an external uninterruptible power supply (230 or 115 V AC; external fuse 16 A gG)
 - +G313: Power supply connection for a motor space heater output (230 V AC; external fuse 16 A gG).
-

Using power factor compensation capacitors with the drive

Power factor compensation is not needed with AC drives. However, if a drive is to be connected in a system with compensation capacitors installed, note the following restrictions.



WARNING!

Do not connect power factor compensation capacitors or harmonic filters to the motor cables (between the drive and the motor). They are not meant to be used with AC drives and can cause permanent damage to the drive or themselves.

If there are power factor compensation capacitors in parallel with the input of the drive:

1. Do not connect a high-power capacitor to the power line while the drive is connected. The connection will cause voltage transients that may trip or even damage the drive.
2. If capacitor load is increased/decreased step by step when the AC drive is connected to the power line, make sure that the connection steps are low enough not to cause voltage transients that would trip the drive.
3. Make sure that the power factor compensation unit is suitable for use in systems with AC drives, ie, harmonic generating loads. In such systems, the compensation unit should typically be equipped with a blocking reactor or harmonic filter.

Using a safety switch between the drive and the motor

ABB recommends to install a safety switch between the permanent magnet motor and the drive output. The switch is needed to isolate the motor from the drive during maintenance work on the drive.

Implementing the control of a contactor between drive and motor

Implementing the control of the output contactor depends on the motor control mode and stopping method selected.

When you select the DTC motor control mode and the motor ramp stop mode, use this operation sequence to open the contactor:

1. Give a stop command to the drive.
2. Wait until the drive decelerates the motor to zero speed.
3. Open the contactor.



WARNING!

If DTC motor control mode is in use, do not open the output contactor while the drive controls the motor. The motor control operates faster than the contactor, and tries to maintain the load current. This can cause damage to the contactor.


When you select the DTC motor control mode and the motor coast stop mode, you can open the contactor immediately after the drive has received the stop command. This is the case also if you use the scalar motor control mode.

Protecting the contacts of relay outputs

Inductive loads (relays, contactors, motors) cause voltage transients when switched off.

The relay contacts on the drive control unit are protected with varistors (250 V) against overvoltage peaks. In spite of this, it is highly recommended that inductive loads are equipped with noise attenuating circuits (varistors, RC filters [AC] or diodes [DC]) to minimize the EMC emission at switch-off. If not suppressed, the disturbances may connect capacitively or inductively to other conductors in the control cable and form a risk of malfunction in other parts of the system.

Install the protective component as close to the inductive load as possible. Do not install protective components at the relay outputs.



Implementing a motor temperature sensor connection



WARNING!

IEC 60664 and IEC 61800-5-1 require double or reinforced insulation between live parts and accessible parts when:

- the accessible parts are not conductive, or
- the accessible parts are conductive, but not connected to the protective earth.

Obey this requirement when you plan the connection of the motor temperature sensor to the drive.

You have these implementation alternatives:

1. If there is double or reinforced insulation between the sensor and the live parts of the motor: You can connect the sensor directly to the analog/digital input(s) of the drive. See the control cable connection instructions.
2. If there is basic insulation between the sensor and the live parts of the motor: You can connect the sensor to the analog/digital input(s) of the drive. All other circuits connected to the digital and analog inputs (typically extra-low voltage circuits) must be:
 - protected against contact, and
 - insulated with basic insulation from other low-voltage circuits. The insulation must be rated for the same voltage level as the drive main circuit.

Note: Extra-low voltage circuits (for example, 24 V DC) typically do not meet these requirements.

As an alternative, you can connect the sensor with basic insulation to the analog/digital input(s) of the drive, if you do not connect any other external control circuits to the drive digital and analog inputs.

3. You can connect the sensor to the drive via an option module. The sensor and the module must form a double or reinforced insulation between the motor live parts and the drive control unit. See [Connecting motor temperature sensor to the drive via an option module \(page 81\)](#).
4. You can connect a sensor to a digital input of the drive via an external relay. The sensor and the relay must form a double or reinforced insulation between the motor live parts and the digital input of the drive.

■ **Connecting motor temperature sensor to the drive via an option module**

This table shows:

- the option module types that you can use for the motor temperature sensor connection
 - the insulation or isolation level that each option module forms between its temperature sensor connector and other connectors
 - the temperature sensor types that you can connect to each option module
 - the temperature sensor insulation requirement in order to form, together with the insulation of the option module, a reinforced insulation between the motor live parts and the drive control unit.
-

82 Guidelines for planning the electrical installation

Option module		Temperature sensor type			Temperature sensor insulation requirement
Type	Insulation/Isolation	PTC	KTY	Pt100, Pt1000	
FIO-11	Galvanic isolation between sensor connector and other connectors (including drive control unit connector)	-	x	x	Reinforced insulation
FEN-xx	Galvanic isolation between sensor connector and other connectors (including drive control unit connector)	x	x	-	Reinforced insulation
FAIO-01	Basic insulation between sensor connector and drive control unit connector. No insulation between sensor connector and other I/O connectors.	x	x	x	Basic insulation. Connectors of option module other than sensor connector must be left unconnected.
FPTC-xx ¹⁾	Reinforced insulation between sensor connector and other connectors (including drive control unit connector).	x	-	-	No special requirement

¹⁾ Suitable for use in safety functions (SIL2 / PL c rated).

6

Electrical installation

Contents of this chapter

This chapter gives instructions on the wiring of the drive.

Warnings



WARNING!

Only qualified electricians are allowed to carry out the work described in this chapter. Follow the safety instructions on the first pages of this manual. Ignoring the safety instructions can cause injury or death.

Measuring the insulation

- Measuring the insulation of the drive



WARNING!

Do not do any voltage withstand or insulation resistance tests on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltage-limiting circuits inside the drive which cut down the testing voltage automatically.

■ Measuring the insulation of the motor and motor cable




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

1. Do the steps in section *Electrical safety precautions (page 16)* before you start the work.
2. Make sure that the motor cable is disconnected from the drive output terminals.
3. Measure the insulation resistance between each phase conductor and the protective earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of an ABB motor must be more than 100 Mohm (reference value at 25 °C [77 °F]). For the insulation resistance of other motors, refer to the manufacturer's instructions.

Note: Moisture inside the motor casing reduces the insulation resistance. If you think that there is moisture in the motor, dry the motor and do the measurement again.



Connecting the control cables

See chapter *Control units of the drive (page 105)* for the default I/O connections of the inverter unit (with the ACS880 primary control program). The default I/O connections can be different with some hardware options, see the circuit diagrams delivered with the drive for the actual wiring. For other control programs, see their firmware manuals.

■ Control cable connection procedure



WARNING!


Obey the instructions in chapter *Safety instructions*. If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive (if running) and do the steps in section *Electrical safety precautions (page 16)* before you start the work.
2. Run the control cables into the cabinet as described in section *Grounding the outer shields of the control cables at the cabinet entry* below.
3. Route the control cables as described in section *Routing the control cables inside the cabinet (page 87)*.
4. Connect the control cables as described in section *Connecting control cabling (page 87)*.

Grounding the outer shields of the control cables at the cabinet entry

Ground the outer shields of all control cables 360 degrees at the EMI conductive cushions as follows (example constructions are shown below, the actual hardware may vary):


1. Loosen the tightening screws of the EMI conductive cushions and pull the cushions apart.
2. Cut adequate holes to the rubber grommets in the entry plate and put the cables through the grommets and the cushions.
3. Strip off the cable plastic sheath above the entry plate just enough to ensure proper connection of the bare shield and the EMI conductive cushions.
4. Tighten the two tightening screws so that the EMI conductive cushions press tightly round the bare shield.



Note 1: Keep the shields continuous as close to the connection terminals as possible. Secure the cables mechanically at the entry strain relief.

Note 2: If the outer surface of the shield is non-conductive:

- Cut the shield at the midpoint of the bare part. Be careful not to cut the conductors or the grounding wire (if present).
- Turn the shield inside out to expose its conductive surface.
- Cover the turned shield and the stripped cable with copper foil to keep the shielding continuous.




Note for top entry of cables: When each cable has its own rubber grommet, sufficient IP and EMC protection can be achieved. However, if there is more than one cable per grommet, plan the installation beforehand as follows:

1. Make a list of the cables coming to the cabinet.
2. Sort the cables going to the left into one group and the cables going to the right into another group to avoid unnecessary crossing of cables inside the cabinet.
3. Sort the cables in each group according to size.
4. Group the cables for each grommet as follows ensuring that each cable has a proper contact to the cushions on both sides.

Cable diameter in mm	Max. number of cables per grommet
≤ 13	4
≤ 17	3
< 25	2
≥ 25	1

5. Arrange the bunches according to size from thickest to the thinnest between the EMI conductive cushions.



6. If more than one cable go through a grommet, seal the grommet by applying Loctite 5221 inside the grommet.

Routing the control cables inside the cabinet

Use the existing trunking in the cabinet wherever possible. Use sleeving if cables are laid against sharp edges. When running cables to or from a swing-out frame, leave enough slack at the hinge to allow the frame to open fully.

Connecting control cabling


Connect the conductors to the appropriate terminals. Refer to the wiring diagrams delivered with the drive.

Connect the inner twisted pair shields and all separate grounding wires to the grounding clamps closest to the terminals.

The drawing below represents the grounding of the control cabling when connecting to a terminal block inside the cabinet. The grounding is done in the same way when connecting directly to a component such as the control unit.

Notes:

- Do not ground the outer shield of the cable here since it is grounded at the cable entry.
- Keep any signal wire pairs twisted as close to the terminals as possible. Twisting the wire with its return wire reduces disturbances caused by inductive coupling.



At the other end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, eg. 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.



Connecting the motor cables (units without common motor terminal cubicle)

On units without a common motor terminal cubicle, the motor cables connect to busbars located in the inverter module cubicles. To access the terminals, the cooling fans and other equipment in front of the terminals must be removed from the cubicle.


The location and dimensions of the busbars are visible in the dimension drawings delivered with the drive, as well as the example drawings presented in this manual in chapter Dimensions.

If the drive is equipped with a common motor terminal cubicle (option +H359), follow the instructions in section [Connecting the motor cables \(units with common motor terminal cubicle\) \(page 92\)](#).

■ Motor connection diagram (without option +H366)

All parallel-connected inverter modules are to be cabled separately to the motor.

360° earthing is to be used at cable lead-throughs.




The recommended cable types are given in chapter *Technical data*.



WARNING!

The cabling from all inverter modules to the motor must be physically identical considering cable type, cross-sectional area, and length.



■ Procedure

Refer to the drawings below.



WARNING!

Obey the instructions in chapter *Safety instructions*. If you ignore them, injury or death, or damage to the equipment can occur.




1. Do the steps in section *Electrical safety precautions (page 16)* before you start the work.
2. Open the inverter module cubicle door.
3. Remove the shrouding at the lower part of the cubicle (not shown).
4. Unplug the wiring from the lower front mounting plate. Remove the plate.
5. Disconnect the wiring from the cooling fans.
6. Undo the two retaining screws (a) of each fan.
7. Pull each fan outwards to separate them from the heat exchanger housing.
8. Remove the inner shroud.
9. Peel off 3 to 5 cm (1.2 to 2 inches) of the outer insulation of the cables above the lead-through plate for 360° high-frequency grounding.
10. Prepare the ends of the cables.




WARNING!

Apply grease to stripped aluminum conductors before attaching them to non-coated aluminum cable lugs. Obey the grease manufacturer's instructions. Aluminum-aluminum contact can cause oxidation in the contact surfaces.

11. If fire insulation is used, make an opening in the mineral wool sheet according to the diameter of the cable.
12. Remove the rubber grommets from the cable entries for the cables to be connected. Cut adequate holes into the rubber grommets. Slide the grommets onto the cables. Slide the cables into the cubicle through the conductive sleeves and attach the grommets to the holes.
13. Attach the conductive sleeves to the cable shields with cable ties. Tie up the unused conductive sleeves with cable ties.
14. Connect the twisted shields of the cables to the PE busbar of the cabinet.
15. Connect the phase conductors of the cables to the appropriate terminals. Tighten the screws to the torque given under *Tightening torques (page 185)*.
16. Refit the inner shroud.
17. With each fan, align the guide pins (b) at the rear of the fan cowling with the slots (c) in the module bottom guide, then reinstall the retaining screws (a).
18. Refit the lower front mounting plate. Reconnect the wiring to the components on the mounting plate.
19. Refit the outer shroud.
20. Make sure there are no tools, debris or any other foreign objects in the cubicle. Close the cubicle door.
21. At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order. For minimum radio-frequency interference, ground the cable shield 360 degrees at the cable entry of the motor terminal box, or ground the cable by twisting the shield so that the flattened shield is wider than 1/5 of its length.






Connecting the motor cables (units with common motor terminal cubicle)

■ Output busbars

If the drive is equipped with option +H359, the motor cables connect to a common motor terminal cubicle.

The location and dimensions of the busbars are visible in the dimensional drawings delivered with the drive.

■ Connection diagram



The recommended cable types are given in chapter Technical data.

■ Procedure




WARNING!


Obey the instructions in chapter Safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section [Electrical safety precautions \(page 16\)](#) before you start the work.
2. Open the door of the cubicle and remove the shrouding.

3. Lead the cables into the cubicle. Make the 360° earthing arrangement at the cable entry as shown.



4. Cut the cables to suitable length. Strip the cables and conductors.
5. Twist the cable screens into bundles and connect the bundles to the PE busbar in the cubicle.
6. Connect any separate ground conductors/cables to the PE busbar in the cubicle.
7. Connect the phase conductors to the output terminals. Use the torques specified under *Tightening torques* (page 185).
8. Refit any shrouding removed earlier and close the cubicle doors.
9. At the motor, connect the cables according to instructions from the motor manufacturer. Pay special attention to the phase order. For minimum radio-frequency interference, ground the cable shield 360 degrees at the lead-through of the motor terminal box, or ground the cable by twisting the shield so that the flattened shield is wider than 1/5 of its length.




Connecting an external brake resistor assembly

See chapter *Resistor braking* (page 219).


For the location of the terminals, refer to the dimension drawings delivered with the unit or the dimension drawing examples in chapter *Dimensions*.

Connecting the input power cables

■ Connection diagram, 6-pulse units



■ Connection diagram, 12-pulse units



■ Layout of the input cable connection terminals and cable entries

The location and dimensions of the busbars are visible in the dimensional drawings delivered with the drive. Alternatively, see the example dimension drawings in the manual.

■ Connection procedure



WARNING!


Obey the instructions in chapter *Safety instructions*. If you ignore them, injury or death, or damage to the equipment can occur.

1. Do the steps in section *Electrical safety precautions (page 16)* before you start the work.
2. Open the door of the incoming cubicle.
3. Remove the shrouding covering the input terminals.
4. Peel off 3 to 5 cm of the outer insulation of the cables above the lead-through plate for 360° high-frequency grounding.
5. Prepare the ends of the cables.




WARNING!

Apply grease to stripped aluminum conductors before attaching them to non-coated aluminum cable lugs. Obey the grease manufacturer's instructions. Aluminum-aluminum contact can cause oxidation in the contact surfaces.




6. If fire insulation is used, make an opening in the mineral wool sheet according to the diameter of the cable.

7. Remove rubber grommets from the cable entries for the cables to be connected. Cut adequate holes into the rubber grommets. Slide the grommets onto the cables. Slide the cables into the cubicle through the conductive sleeves and attach the grommets to the holes.



8. Attach the conductive sleeves to the cable shields with cable ties. Tie up the unused conductive sleeves with cable ties.



9. Connect the twisted shields of the cables to the PE busbar of the cabinet.
10. Connect the phase conductors of the input cable to the L1, L2 and L3 terminals. (With 12-pulse connection, the terminals are 1L1, 1L2 and 1L3 for one 6-pulse supply line, 2L1, 2L2 and 2L3 for the other.) Tighten the screws to the torque given under [Tightening torques \(page 185\)](#).

11. Reinstall the shrouding removed earlier.
12. Close the cubicle door.



Connecting a PC




WARNING!

Do not connect the PC directly to the control panel connector of the control unit as this can cause damage.

A PC (with eg, the Drive composer PC tool) can be connected as follows:

1. Connect an ACx-AP-x control panel to the unit either
 - by inserting the control panel into the panel holder or platform, or
 - by using an Ethernet (eg, Cat 5e) networking cable.
2. Remove the USB connector cover on the front of the control panel.
3. Connect an USB cable (Type A to Type Mini-B) between the USB connector on the control panel (3a) and a free USB port on the PC (3b).
4. The panel will display an indication whenever the connection is active.
5. See the documentation of the PC tool for setup instructions.



Panel bus (Control of several units from one control panel)

One control panel (or PC) can be used to control several drives (or inverter units, supply units etc.) by constructing a panel bus. This is done by daisy-chaining the panel connections of the drives. Some drives have the necessary (twin) panel connectors in the control panel holder; those that do not require the installation of an FDPI-02 module (available separately). For further information, see the hardware description and *FDPI-02 diagnostics and panel interface user's manual* (3AUA0000113618 [English]).

The maximum allowed length of the cable chain is 100 m (328 ft).

1. Connect the panel to one drive using an Ethernet (for example Cat 5e) cable.
 - Use Menu - Settings - Edit texts - Drive to give a descriptive name to the drive
 - Use parameter 49.01* to assign the drive with a unique node ID number
 - Set other parameters in group 49* if necessary
 - Use parameter 49.06* to validate any changes.

*The parameter group is 149 with supply (line-side), brake or DC/DC converter units. Repeat the above for each drive.

2. With the panel connected to one unit, link the units using Ethernet cables.



3. Switch on the bus termination on the drive that is farthest from the control panel in the chain.
 - With drives that have the panel mounted on the front cover, move the terminating switch into the outer position.
 - With an FDPI-02 module, move termination switch S2 into the TERMINATED position.

Make sure that bus termination is off on all other drives.





4. On the control panel, switch on the panel bus functionality (Options - Select drive - Panel bus). The drive to be controlled can now be selected from the list under Options - Select drive.

If a PC is connected to the control panel, the drives on the panel bus are automatically displayed in the Drive composer tool.

With twin connectors in the control panel holder:



With FDPI-02 modules:



Installing option modules

■ Mechanical installation of I/O extension, fieldbus adapter and pulse encoder interface modules

See hardware description for the available slots for each module. Install the option modules as follows:



WARNING!

Obey the instructions in chapter [Safety instructions](#). If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 16\)](#) before you start the work.
2. Open the door of the auxiliary control cubicle (ACU).
3. Remove the shrouding at the top of the cubicle.
4. Locate the inverter control unit (A41).
5. Insert the module carefully into its position on the control unit.
6. Fasten the mounting screw.

Note: The screw secures and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

■ Installation of an FSO-xx safety functions module onto BCU



WARNING!


Obey the instructions in chapter [Safety instructions](#). If you ignore them, injury or death, or damage to the equipment can occur.

This procedure describes the installation of an FSO-xx safety functions module onto the BCU control unit. (The FSO-xx can alternatively be installed beside the control unit, which is the standard with factory-installed FSO-xx modules. For instructions, see the FSO-xx manual.)

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 16\)](#) before you start the work.
 2. The FSO-xx comes with alternative bottom plates for mounting on different units. For mounting on the BCU, the mounting points should be located at the long edges of the module as shown. Replace the bottom plate of the FSO-xx if necessary.
-




3. Fasten the FSO-xx onto slot 3 of the BCU control unit [A41] with four screws.



4. Tighten the FSO-xx electronics grounding screw.

Note: The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

5. Connect the FSO-xx data cable between FSO-xx connector X110 and BCU-x2 connector X12.
6. To complete the installation, refer to the instructions in the User's manual delivered with the FSO-xx.



■ **Wiring of option modules**

See the appropriate optional module manual for specific installation and wiring instructions.






Control units of the drive

Contents of this chapter


This chapter

- describes the connections of the control unit(s) used in the drive,
- contains the specifications of the inputs and outputs of the control unit(s).

BCU-x2 layout



	Description
I/O	I/O terminals (see following diagram)
SLOT 1	I/O extension, encoder interface or fieldbus adapter module connection. (This is the sole location for an FDPI-02 diagnostics and panel interface.)
SLOT 2	I/O extension, encoder interface or fieldbus adapter module connection
SLOT 3	I/O extension, encoder interface, fieldbus adapter or FSO-xx safety functions module connection
SLOT 4	RDCO-0x DDCS communication option module connection
X205	Memory unit connection
BATTERY	Holder for real-time clock battery (BR2032)
A11	Mode selector for analog input A11 (I = current, U = voltage)
A12	Mode selector for analog input A12 (I = current, U = voltage)
D2D TERM	Termination switch for drive-to-drive link (D2D)
DICOM= DIOGND	Ground selection. Determines whether DICOM is separated from DIOGND (ie. the common reference for the digital inputs floats). See the ground isolation diagram.
7-segment display	
Multicharacter indications are displayed as repeated sequences of characters	
	("U" is indicated briefly before "o".) Control program running
	Control program startup in progress
	(Flashing) Firmware cannot be started. Memory unit missing or corrupted
	Firmware download from PC to control unit in progress
	At power-up, the display may show short indications of eg. "1", "2", "b" or "U". These are normal indications immediately after power-up. If the display ends up showing any other value than those described, it indicates a hardware failure.







	Description
XAI	Analog inputs
XAO	Analog outputs
XDI	Digital inputs, Digital input interlock (DIIL)
XDIO	Digital input/outputs
XD2D	Drive-to-drive link
XD24	+24 V output (for digital inputs)
XETH	Ethernet port – Not in use
XPOW	External power input
XRO1	Relay output RO1
XRO2	Relay output RO2
XRO3	Relay output RO3
XSTO	Safe torque off connection (input signals)
XSTO OUT	Safe torque off connection (to inverter modules)
X12	(On the opposite side) Connection for FSO-xx safety functions module (optional)
X13	Control panel / PC connection
X485	Not in use
V1T/V1R, V2T/V2R	Fiber optic connection to modules 1 and 2 (VxT = transmitter, VxR = receiver)
V3T/V3R ... V7T/V7R	Fiber optic connection to modules 3...7 (BCU-12/22 only) (VxT = transmitter, VxR = receiver)
V8T/V8R ... V12T/V12R	Fiber optic connection to modules 8...12 (BCU-22 only) (VxT = transmitter, VxR = receiver)
SD CARD	Data logger memory card for inverter module communication
BATT OK	Real-time clock battery voltage is higher than 2.8 V. If the LED is off when the control unit is powered, replace the battery.
FAULT	The control program has generated a fault. See the firmware manual of the supply/inverter unit.
PWR OK	Internal voltage supply is OK
WRITE	Writing to memory card in progress. Do not remove the memory card.

Default I/O diagram of the supply control unit

The diagram below shows the default I/O connections on the supply control unit (A51), and describes the use of the connections in the supply unit. Under normal circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (24...12 AWG). The torque is 0.5 N·m (5 lbf·in).

Terminal			Description	
XD2D			Drive-to-drive link	
1	1	B	Not in use by default	
2	2	A		
3	3	BGND		
4	4	Shield		
 D2D.TERM			Drive-to-drive link termination switch ¹⁾	
X485			RS485 connection	
5	5	B	Cooling fan monitoring (CIO module)	
6	6	A		
7	7	BGND		
8	8	Shield		
XRO1, XRO2, XRO3			Relay outputs	
11	11	NC	Norm. closed	XRO1: Running ²⁾ (Energized = running) 250 V AC / 30 V DC, 2 A
	12	COM	Common	
13	13	NO	Norm. open	
21	21	NC	Norm. closed	XRO2: Fault (-1) ²⁾ (Energized = no fault) 250 V AC / 30 V DC, 2 A
	22	COM	Common	
23	23	NO	Norm. open	
31	31	NC	Norm. closed	XRO3: MCB ctrl ³⁾ (Energized = closes main contactor/breaker) 250 V AC / 30 V DC, 2 A
	32	COM	Common	
33	33	NO	Norm. open	
XSTO, XSTO OUT			Safe torque off ⁴⁾	
1	1	OUT	XSTO: Factory connection. Both circuits must be closed for the drive to start (IN1 and IN2 must be connected to OUT).	
	2	SGND		
3	3	IN1		
4	4	IN2		
5	5	IN1	XSTO OUT: Not in use.	
	6	6		SGND
7	7	IN2		
8	8	SGND		
XDI			Digital inputs	

Terminal		Description	
1 2 3 4 5 6 7	1	DI1	Temp fault²⁾ (0 = overtemperature)
	2	DI2	Run enable²⁾ (1 = run enable)
	3	DI3	MCB feedback³⁾ (0 = main contactor/breaker open)
	4	DI4	Auxiliary circuit breaker fault²⁾
	5	DI5	Not in use by default. Can be used for eg. earth fault monitoring.
	6	DI6	Reset²⁾ (0 -> 1 = fault reset)
	7	DIIL	Not in use by default. Can be used for eg. emergency stop.
XDIO		Digital input/outputs	
1 2 3 4	1	DIO1	Not in use by default
	2	DIO2	Not in use by default
	3	DIOGND	Digital input/output ground
	4	DIOGND	Digital input/output ground
XD24		Auxiliary voltage output	
5 6 7 8	1	+24VD	+24 V DC 200 mA ⁵⁾
	2	DICOM	Digital input ground
	3	+24VD	+24 V DC 200 mA ⁵⁾
	4	DIOGND	Digital input/output ground
	DICOM=DIOGND		Ground selection switch ⁶⁾
XAI		Analog inputs, reference voltage output	
1 2 3 4 5 6 7	1	+VREF	10 V DC, R_L 1...10 kohm
	2	-VREF	-10 V DC, R_L 1...10 kohm
	3	AGND	Ground
	4	AI1+	Not in use by default. 0(2)...10 V, $R_{in} > 200$ kohm ⁷⁾
	5	AI1-	
	6	AI2+	Not in use by default. 0(4)...20 mA, $R_{in} = 100$ ohm ⁸⁾
	7	AI2-	
	AI1		AI1 current/voltage selection switch
	AI2		AI2 current/voltage selection switch
XAO		Analog outputs	
1 2 3 4	1	AO1	Zero (no signal indicated) ²⁾ 0...20 mA, $R_L < 500$ ohm
	2	AGND	
	3	AO2	Zero (not signal indicated) ²⁾ 0...20 mA, $R_L < 500$ ohm
	4	AGND	
XPOW		External power input	
1 2 3 4	1	+24VI	24 V DC, 2.05 A
	2	GND	
	3	+24VI	
	4	GND	
X12		Not in use in supply units	
X13		Control panel connection	

110 Control units of the drive


Terminal	Description
X205	Memory unit connection

- 1) Must be set to ON when the supply unit is the first or last unit on the drive-to-drive (D2D) link. On intermediate units, set termination to OFF.
 - 2) Default use of the signal in the control program. The use can be changed by a parameter. See also the delivery-specific circuit diagrams.
 - 3) Use of the signal in the control program (fixed). See also the delivery-specific circuit diagrams.
 - 4) This input only acts as a true Safe torque off input in inverter units. In other applications (such as a supply or brake unit), de-energizing the IN1 and/or IN2 terminal will stop the unit but not constitute a true safety function.
 - 5) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.
 - 6) Determines whether DICOM is separated from DIOGND (ie, common reference for digital inputs floats). ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.
 - 7) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI1. Change of setting requires reboot of control unit.
 - 8) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI2. Change of setting requires reboot of control unit.
-

Default I/O diagram of the inverter control unit (A41)

The diagram below shows the default I/O connections on the inverter control unit (A41), and describes the use of the connections in the inverter unit. Under normal circumstances, the factory-made wiring should not be changed.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (24...12 AWG). The torque is 0.5 N·m (5 lbf·in).



Notes:

- 1) See section *The XD2D connector (page 113)*.
- 2) See chapter *The Safe torque off function (page 201)*.
- 3) 0 = Acceleration/deceleration ramps defined by parameters 23.12/23.13 in use. 1 = Acceleration/deceleration ramps defined by parameters 23.14/23.15 in use.
- 4) Constant speed 1 is defined by parameter 22.26.
- 5) See section *DIIL input (page 113)*.
- 6) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.
- 7) Determines whether DICOM is separated from DIOGND (ie. common reference for digital inputs floats; in practice, selects whether the digital inputs are used in current sinking or sourcing mode). See also *BCU-x2 ground isolation diagram (page 117)*.
DICOM=DIOGND ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.
- 8) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI1. Change of setting requires reboot of control unit.
- 9) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI2. Change of setting requires reboot of control unit.

Additional information on the connections

External power supply for the control unit (XPOW)


The control unit is powered from a 24 V DC, 2 A supply through terminal block XPOW. With a type BCU control unit, a second supply can be connected to the same terminal block for redundancy.

Using an external supply is recommended if

- the control unit needs to be kept operational during input power breaks, for example, because of continuous fieldbus communication
- immediate restart is needed after a power break (that is, no control unit power-up delay is allowed).

DI6 as a PTC sensor input

PTC sensors can be connected to this input for motor temperature measurement as follows. The sensor can alternatively be connected to FEN-xx encoder interface module. At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points. See the firmware manual of the inverter unit for parameter settings.




**WARNING!**

As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment or the temperature sensor must be isolated from the I/O terminals.

■ AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input

Sensors for motor temperature measurement can be connected between an analog input and output, an example connection is shown below. (Alternatively, you can connect the KTY to an FIO-11 or FAIO-01 analog I/O extension module or FEN-xx encoder interface module.) At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.

**WARNING!**

As the inputs pictured above are not insulated according to IEC/EN 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfill the requirement, the I/O board terminals must be protected against contact and must not be connected to other equipment, or the temperature sensor must be isolated from the I/O terminals.

■ DIIL input

The DIIL input is used for the connection of safety circuits. The input is parametrized to stop the unit when the input signal is lost.

Note: This input is NOT SIL or PI certified.

■ The XD2D connector

The XD2D connector provides an RS-485 connection that can be used for

- basic master/follower communication with one master drive and multiple followers,
- fieldbus control through the embedded fieldbus interface (EFB), or
- drive-to-drive (D2D) communication implemented by application programming.


See the firmware manual of the drive for the related parameter settings.

Enable bus termination on the units at the ends of the drive-to-drive link. Disable bus termination on the intermediate units.

Use shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 to 165 ohm, for example Belden 9842) for the wiring. For best immunity, ABB recommends high quality cable. Keep the cable as short as possible. Avoid unnecessary loops and parallel runs near power cables such as motor cables.

The following diagram shows the wiring between control units.

BCU-x2



■ Safe torque off (XSTO, XSTO OUT)

See chapter [The Safe torque off function \(page 201\)](#).

Note: The XSTO input only acts as a true Safe torque off input on the inverter control unit. De-energizing the IN1 and/or IN2 terminals of other units (supply, DC/DC converter, or brake unit) will stop the unit but not constitute a true safety function.


■ FSO-xx safety functions module connection (X12)

See the user manual of the FSO-xx module. Note that the FSO-xx safety functions module is not in use in supply, DC/DC converter or brake units.

■ SDHC memory card slot


The BCU-x2 has an on-board data logger that collects real-time data from the power modules to help fault tracing and analysis. The data is stored onto the SDHC memory card inserted into the SD CARD slot and can be analyzed by ABB service personnel.

Connector data

Power supply (XPOW)	Connector pitch 5 mm, wire size 2.5 mm ² 24 V ($\pm 10\%$) DC, 2 A External power input. Two supplies can be connected for redundancy.
Relay outputs RO1...RO3 (XRO1...XRO3)	Connector pitch 5 mm, wire size 2.5 mm ² 250 V AC / 30 V DC, 2 A Protected by varistors
+24 V output (XD24:2 and XD24:4)	Connector pitch 5 mm, wire size 2.5 mm ² Total load capacity of these outputs is 4.8 W (200 mA / 24 V) minus the power taken by DIO1 and DIO2.
Digital inputs DI1...DI6 (XDI:1...XDI:6)	Connector pitch 5 mm, wire size 2.5 mm ² 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in} : 2.0 kohm Input type: NPN/PNP (DI1...DI5), NPN (DI6) Hardware filtering: 0.04 ms, digital filtering up to 8 ms DI6 (XDI:6) can alternatively be used as an input for a PTC sensor. "0" > 4 kohm, "1" < 1.5 kohm. I_{max} : 15 mA (DI1...DI5), 5 mA (DI6)
Start interlock input DIIL (XDI:7)	Connector pitch 5 mm, wire size 2.5 mm ² 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in} : 2.0 kohm Input type: NPN/PNP Hardware filtering: 0.04 ms, digital filtering up to 8 ms
Digital inputs/outputs DIO1 and DIO2 (XDIO:1 and XDIO:2) Input/output mode selection by parameters. DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24 V level square wave signal (sinusoidal or other wave form cannot be used). DIO2 can be configured as a 24 V level square wave frequency output. See the firmware manual, parameter group 111/11.	Connector pitch 5 mm, wire size 2.5 mm ² <u>As inputs:</u> 24 V logic levels: "0" < 5 V, "1" > 15 V. R_{in} : 2.0 kohm. Filtering: 1 ms. <u>As outputs:</u> Total output current from +24VD is limited to 200 mA 
Reference voltage for analog inputs +VREF and -VREF (XAI:1 and XAI:2)	Connector pitch 5 mm, wire size 2.5 mm ² 10 V $\pm 1\%$ and -10 V $\pm 1\%$, R_{load} 1...10 kohm Maximum output current: 10 mA
Analog inputs AI1 and AI2 (XAI:4 ... XAI:7). Current/voltage input mode selection by switches	Connector pitch 5 mm, wire size 2.5 mm ² Current input: -20...20 mA, R_{in} = 100 ohm Voltage input: -10...10 V, R_{in} > 200 kohm Differential inputs, common mode range ± 30 V Sampling interval per channel: 0.25 ms Hardware filtering: 0.25 ms, adjustable digital filtering up to 8 ms Resolution: 11 bit + sign bit Inaccuracy: 1% of full scale range

Analog outputs AO1 and AO2 (XAO)	Connector pitch 5 mm, wire size 2.5 mm ² 0...20 mA, $R_{load} < 500 \text{ ohm}$ Frequency range: 0...500 Hz Resolution: 11 bit + sign bit Inaccuracy: 2% of full scale range
XD2D connector	Connector pitch 5 mm, wire size 2.5 mm ² Physical layer: RS-485 Transmission rate: 8 Mbit/s Cable type: Shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 ... 165 ohm, for example Belden 9842) Maximum length of link: 50 m (164 ft) Termination by switch
RS-485 connection (X485)	Connector pitch 5 mm, wire size 2.5 mm ² Physical layer: RS-485
Safe torque off connection (XSTO)	Connector pitch 5 mm, wire size 2.5 mm ² Input voltage range: -3...30 V DC Logic levels: "0" < 5 V, "1" > 17 V. Note: For the unit to start, both connections must be "1". This applies to all control units (including drive, inverter, supply, brake, DC/DC converter etc. control units), but true Safe torque off functionality is only achieved through the XSTO connector of the drive/inverter control unit. Current consumption: 66 mA (continuous) per STO channel per R8i module EMC (immunity) according to IEC 61326-3-1 See also chapter The Safe torque off function (page 201) .
Safe torque off output (XSTO OUT)	Connector pitch 5 mm, wire size 2.5 mm ² To STO connector of inverter module.
Control panel connection (X13)	Connector: RJ-45 Cable length < 3 m
Ethernet connection (XETH)	Connector: RJ-45 This connection is not supported by the firmware.
SDHC memory card slot (SD CARD)	Memory card type: SDHC Maximum memory size: 4 GB
The terminals of the control unit fulfill the Protective Extra Low Voltage (PELV) requirements. The PELV requirements of a relay output are not fulfilled if a voltage higher than 48 V is connected to the relay output.	

■ **BCU-x2 ground isolation diagram**



***Ground selector (DICOM=DIOGND) settings**

DICOM=DIOGND: ON

All digital inputs share a common ground (DICOM connected to DIOGND). This is the default setting.

DICOM=DIOGND: OFF

Ground of digital inputs DI1...DI5 and DIIL (DICOM) is isolated from DIO signal ground (DIOGND). Isolation voltage 50 V.

**Common mode voltage between each AI input and AGND is +30 V

8

Installation checklist

Contents of this chapter

This chapter contains a checklist of the mechanical and electrical installation of the drive.

Checklist

Examine the mechanical and electrical installation of the drive before start-up. Go through the checklist together with another person.



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.



WARNING!

Stop the drive and do the steps in section [Electrical safety precautions \(page 16\)](#) before you start the work.

Make sure that ...	<input checked="" type="checkbox"/>
The ambient operating conditions meet the drive ambient conditions specification, and enclosure rating (IP code or UL enclosure type).	<input type="checkbox"/>
The supply voltage matches the nominal input voltage of the drive. See the type designation label.	<input type="checkbox"/>
The insulation resistance of the input power cable, motor cable and motor is measured according to local regulations and the manuals of the drive.	<input type="checkbox"/>
The drive cabinet is attached to the floor, and if necessary due to vibration etc, also by its top to the wall or roof.	<input type="checkbox"/>
The drive module is fastened properly to the cabinet.	<input type="checkbox"/>

120 Installation checklist

Make sure that ...	<input checked="" type="checkbox"/>
<u>If the drive is connected to a network other than a symmetrically grounded TN-S system:</u> You have done all the required modifications (for example, you may need to disconnect the EMC filter or ground-to-phase varistor). See the electrical installation instructions.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor(s) between the drive and the switchboard, the conductor is connected to correct terminal, and the terminal is tightened to the correct torque. Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
The input power cable is connected to the correct terminals, the phase order is correct, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor between the motor and the drive, and the conductor is connected to the correct terminal, and the terminal is tightened to the correct torque. Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
The motor cable is connected to the correct terminals, the phase order is correct, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
The motor cable is routed away from other cables.	<input type="checkbox"/>
No power factor compensation capacitors are connected to the motor cable.	<input type="checkbox"/>
<u>If an external brake resistor is connected to the drive:</u> There is an adequately sized protective earth (ground) conductor between the brake resistor and the drive, and the conductor is connected to the correct terminal, and the terminals are tightened to the correct torque. Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
<u>If an external brake resistor is connected to the drive:</u> The brake resistor is connected to the correct terminals, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
<u>If an external brake resistor is connected to the drive:</u> The brake resistor cable is routed away from other cables.	<input type="checkbox"/>
The control cables are connected to the correct terminals, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
The voltage setting of the auxiliary voltage transformers (if any) is correct. See the electrical installation instructions.	<input type="checkbox"/>
<u>If a drive bypass connection will be used:</u> The direct-on-line contactor of the motor and the drive output contactor are either mechanically and/or electrically interlocked, that is, they cannot be closed at the same time. A thermal overload device must be used for protection when bypassing the drive. Refer to local codes and regulations.	<input type="checkbox"/>
There are no tools, foreign objects or dust from drilling inside the drive.	<input type="checkbox"/>
Cover(s) of the motor connection box are in place. Cabinet shrouds are in place and doors are closed.	<input type="checkbox"/>
The motor and the driven equipment are ready for power-up.	<input type="checkbox"/>
The coolant connections between cubicles (if any) and to the cooling circuit are tight.	<input type="checkbox"/>
<u>If the drive is equipped with a cooling unit:</u> Refer to the cooling unit documentation for specific tasks.	<input type="checkbox"/>

9

Start-up

Contents of this chapter

This chapter contains the start-up and switch-off procedures of the drive.

Start-up procedure

The tasks which are needed in certain cases only are marked with underlining, and option codes are given in brackets. Default device designations (if any) are given in brackets after the name, for example “main switch-disconnector [Q1]”. The same device designations are also used in the circuit diagrams.


These instructions cannot and do not cover all possible start-up tasks of a customized drive. Always refer to the delivery-specific circuit diagrams when proceeding with the start-up.



WARNING!

Only qualified electricians are allowed to do the work described in this chapter.

Note: For certain options (such as functional safety options +Q950, +Q951, +Q952, +Q957, +Q963, +Q964, +Q978, +Q979), additional start-up instructions are given in their separate manuals.

Action	<input checked="" type="checkbox"/>
Safety	
 WARNING! Obey the safety instructions during the start-up procedure. See chapter Safety instructions (page 13) .	<input type="checkbox"/>
Checks/Settings with no voltage connected	
Ensure that the disconnector of the supply transformer is locked to the off (0) position, ie. no voltage is, and cannot be connected to the drive inadvertently.	<input type="checkbox"/>

Action	<input checked="" type="checkbox"/>
Check that the main switch-disconnector (Q1.1) is switched off, or main breaker (Q1) racked out.	<input type="checkbox"/>
Check the mechanical and electrical installation of the drive. See Installation checklist (page 119) .	<input type="checkbox"/>
Check the settings of breakers/switches in the auxiliary circuits. See the circuit diagrams delivered with the drive.	<input type="checkbox"/>
Check the settings of the auxiliary voltage transformers (either internal or external).	<input type="checkbox"/>
Disconnect any unfinished or uninspected auxiliary voltage (115/230 V AC) cables that lead from the terminal blocks to the outside of the equipment.	<input type="checkbox"/>
Check that both channels of the Safe torque off circuit connected to the STO inputs of both the supply control unit [A51] and the inverter control unit [A41] are closed. Refer to the wiring diagrams delivered with the drive.	<input type="checkbox"/>
If the Safe torque off functionality is used, check that the STO OUT output on the inverter control unit (A41) is chained to the STO inputs of all inverter modules. If the Safe torque off functionality is not used, check that the STO input on all inverter modules is correctly wired to +24 V and ground.	<input type="checkbox"/>
<u>Drives with ground fault monitoring for IT (ungrounded) systems (option +Q954)</u> : Adjust the settings of the ground fault monitor to suit the installation. See the circuit diagrams of the delivery and <i>IRDH275B Ground Fault Monitor Operating Manual</i> by Bender (code: TGH1386en).	<input type="checkbox"/>
<u>Drives with Pt100 relays (option +(n)L506)</u> : <ul style="list-style-type: none"> • Check the connections against the circuit diagrams of the delivery. • Set the alarm and trip levels of the Pt100 relays. Set the alarm and trip levels of the Pt100 relay as low as possible based on the operating temperature and test results of the machine. The trip level can be set, for example, 10 °C higher than what the temperature of the machine is at maximal load in the maximum environmental temperature. We recommend to set the operating temperatures of the relay, typically for example, as follows: <ul style="list-style-type: none"> • 120...140 °C when only tripping is in use • alarm 120...140 °C and trip 130...150 °C when both alarm and tripping are used. 	<input type="checkbox"/>
Powering up the auxiliary circuit of the drive	
Make sure that it is safe to connect voltage. Ensure that <ul style="list-style-type: none"> • nobody is working on the drive or circuits that have been wired from outside into the drive cabinet • the cover of the motor terminal box is in place. 	<input type="checkbox"/>
Close the circuit breakers and/or fuse disconnectors supplying the auxiliary voltage circuits.	<input type="checkbox"/>
Close the cabinet doors.	<input type="checkbox"/>
Close the main breaker of the supply transformer.	<input type="checkbox"/>
Switch on the auxiliary voltage [Q21].	<input type="checkbox"/>
Setting up the supply unit parameters	
Check the voltage range setting in parameter <i>195.01 Supply voltage</i> . If you need more information on the use of the control panel, see the <i>ACX-AP-x Assistant control panels user's manual</i> (3AUA0000085685 [English]).	<input type="checkbox"/>
Setting up the inverter unit parameters, and performing the first start	
Set up the inverter control program. See the appropriate start-up guide and/or firmware manual. There is a separate start-up guide only for some control programs.	<input type="checkbox"/>
Check that parameter <i>95.09 Switch fuse controller</i> is set to <i>Disabled</i> .	<input type="checkbox"/>
<u>Drives with a brake chopper (option +D150)</u> : See chapter Resistor braking (page 219) .	<input type="checkbox"/>
<u>Drives with an fieldbus adapter module (optional)</u> : Set the fieldbus parameters. Activate the appropriate assistant (if present) in the control program, or see the user's manual of the fieldbus adapter module, and the drive firmware manual. Check that the communication works between the drive and the PLC.	<input type="checkbox"/>
<u>Drives with an encoder interface module (optional)</u> : Set the encoder parameters. Activate the appropriate assistant (if present) in the control program, or see the user's manual of the encoder interface module, and the drive firmware manual.	<input type="checkbox"/>



Action	<input checked="" type="checkbox"/>
Powering up the main circuit of the drive	
Close the main switch-disconnector [Q1.1] or main breaker [Q1]. Note: Do not use excessive force. The main switch-disconnector (or main breaker) can only be closed when <ul style="list-style-type: none"> the main input terminals [L1, L2, L3] are powered, and auxiliary voltage is switched on [Q21], and 	<input type="checkbox"/>
Turn the operating switch (S21) to the ON (1) position to activate the run enable signal. Depending on control source settings, this may also close the main contactor (if present). If a main contactor is present and does not close, refer to the circuit diagrams delivered by the drive as well as the appropriate firmware manuals.	<input type="checkbox"/>
On-load checks	
Start the motor to perform the ID run.	<input type="checkbox"/>
Check that the cooling fans rotate freely in the right direction, and the air flows upwards.	<input type="checkbox"/>
Check that the motor starts, stops and follows the speed reference in the correct direction when controlled with the control panel.	<input type="checkbox"/>
Check that the motor starts, stops and follows the speed reference in the correct direction when controlled through the customer-specific I/O or fieldbus.	<input type="checkbox"/>
<u>Drives in which the Safe torque off control circuit is in use:</u> Test and validate the operation of the Safe torque off function. See section Start-up including acceptance test (page 209) .	<input type="checkbox"/>
<u>Drives with an emergency stop circuit (options +Q951, +Q952, +Q963, +Q964, +Q978, +Q979):</u> Test and validate the operation of the emergency-stop circuit. See the delivery specific circuit diagrams and wiring, start-up and operating instructions of the option.	<input type="checkbox"/>

Switching off the drive

1. Stop the motor.
2. Turn the Run enable switch (S21) to the off (0) position to deactivate the Run enable signal and to switch the main contactor/breaker off.





Fault tracing

Contents of this chapter

This chapter describes the fault tracing possibilities of the drive.

Control unit LEDs

LED	Color	Indication
BATT OK	Green	Battery voltage of the real-time clock is OK (higher than 2.8 V). When the LED is not lit, <ul style="list-style-type: none"> • battery voltage is below 2.8 V, • the battery is missing, or • the control unit is not powered.
PWR OK	Green	Internal voltage OK
FAULT	Red	The control program indicates that the equipment is faulty. See the appropriate firmware manual.
WRITE	Yellow	Writing to SD card in progress.

Control panel and panel platform/holder LEDs

The ACS-AP-... control panel has a status LED. The control panel mounting platform or holder has two status LEDs. For their indications, see the following table.

Location	LED	Indication
Control panel	Continuous green	The unit is functioning normally.
	Flickering green	Data is transferred between the PC and the unit through the USB connection of the control panel.
	Blinking green	There is an active warning in the unit.
	Continuous red	There is an active fault in the unit.
	Blinking red	There is a fault that requires the stopping and restarting of the drive/converter/inverter.
	Blinking blue (ACS-AP-W only)	The Bluetooth interface is enabled, in discoverable mode, and ready for pairing.
	Flickering blue (ACS-AP-W only)	Data is being transferred through the Bluetooth interface of the control panel.
Control panel mounting platform or holder (with the control panel removed)	Red	There is an active fault in the unit.
	Green	Power supply for the control unit is OK.

Warning and fault messages

See the firmware manual for the descriptions, causes and remedies of the drive control program warning and fault messages.

11

Maintenance

Contents of this chapter

This chapter contains maintenance instructions.

Maintenance intervals

The table below shows the maintenance tasks which can be done by the end user. The complete maintenance schedule is available on the Internet (www.abb.com/driveservices). For more information, consult your local ABB Service representative (www.abb.com/searchchannels).

Maintenance task/object	Years from start-up													...
	0	1	2	3	4	5	6	7	8	9	10	11	12	
Coolant														
Checking coolant antifreeze concentration		P	P	P	P	P	P	P	P	P	P	P	P	P
Checking coolant quality			P		P		P		P		P		P	
Coolant draining and replacement							R						R	
ABB cooling unit (if present)	See ACS880-1007LC liquid cooling unit user's manual (3AXD50000129607 [English])													
Cooling fans														
Supply module cubicle fan (230 V)										R				
Supply module cubicle fan (115 V)							R						R	
Inverter module fan (230 V)									R					
Inverter module fan (115 V)							R						R	

Maintenance task/object	Years from start-up													
	0	1	2	3	4	5	6	7	8	9	10	11	12	...
Brake chopper and resistor fans (if present)										R				
Batteries														
Control panel battery										R				
Control unit battery							R						R	
Connections and environment														
Quality of supply voltage		P	P	P	P	P	P	P	P	P	P	P	P	P
Spare parts														
Spare parts		I	I	I	I	I	I	I	I	I	I	I	I	I
DC circuit capacitor reforming (spare inverter modules and spare capacitors)		P	P	P	P	P	P	P	P	P	P	P	P	P
Inspections														
Checking tightness of cable and busbar terminals. Tightening if needed.		I	I	I	I	I	I	I	I	I	I	I	I	I
Checking ambient conditions (dustiness, corrosion, temperature)		I	I	I	I	I	I	I	I	I	I	I	I	I
Checking coolant pipe connections		I	I	I	I	I	I	I	I	I	I	I	I	I
3AXD10000578918 F														

Symbols

- I Inspection** (visual inspection and maintenance action if needed)
- P Performance** of on/off-site work (commissioning, tests, measurements or other work)
- R Replacement**

Maintenance and component replacement intervals are based on the assumption that the equipment is operated within the specified ratings and ambient conditions. ABB recommends annual drive inspections to ensure the highest reliability and optimum performance.

Note: Long term operation near the specified maximum ratings or ambient conditions may require shorter maintenance intervals for certain components. Consult your local ABB Service representative for additional maintenance recommendations.

Cabinet

■ Cleaning the interior of the cabinet

**WARNING!**

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

**WARNING!**

Use a vacuum cleaner with antistatic hose and nozzle, and wear a grounding wristband. Using a normal vacuum cleaner creates static discharges which can damage circuit boards.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 16)* before you start the work.
2. Open the cabinet door.
3. Clean the interior of the cabinet. Use a vacuum cleaner and a soft brush.
4. Clean the air inlets of the fans and air outlets of the modules (top).
5. Clean the air inlet gratings (if any) on the door.
6. Close the door.

Power connections and quick connectors

■ Retightening the power connections

**WARNING!**

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 16)* before you start the work.
 2. Examine the tightness of the cable connections. Use the tightening torques given in the technical data.
-

Fans

The lifespan of the cooling fans of the drive depends on the running time, ambient temperature and dust concentration. See the firmware manual for the actual signal which indicates the running time of the cooling fan. Reset the running time signal after fan replacement.


Replacement fans are available from ABB. Do not use other than ABB specified spare parts.

■ Replacing the fan in the incoming cubicle

**WARNING!**

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section *Electrical safety precautions (page 16)* before you start the work.
2. Remove the shrouding in front of the fan (if any).
3. Disconnect the fan wiring. Remove the CIO module.
4. Remove the two screws and slide the fan unit out.
5. Remove the four screws to detach the fan from the fan unit.
6. Remove the eight screws surrounding the fan unit.
7. Install a new fan in reverse order.



■ Replacing the fan in the auxiliary control cubicle


Auxiliary control cubicle has a fan in the lower part of the cubicle.



WARNING!

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section *Electrical safety precautions (page 16)* before you start the work.
2. Open the door of the auxiliary control cubicle.
3. Disconnect the fan wiring.
4. Remove the fastening screws of the fan collar and slide the fan with the collar out.
5. Detach the fan from the collar and replace the fan.
6. Install the new fan in reverse order.




■ Replacing the cooling fan of a D8T supply module



WARNING!

Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section *Electrical safety precautions (page 16)*.
2. Remove any shrouding in front of the cooling fan.
3. Remove the support bracket of the fan.
4. Disconnect the fan wiring.
5. Undo the two retaining screws.
6. Pull the fan outwards to separate it from the heat exchanger housing.
7. Install new fan in reverse order. Align the guide pins at the rear of the fan cowling with the slots in the bottom guide, then reinstall the retaining screws.




■ Replacing the cooling fan of an R8i inverter module



WARNING!

Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section [Electrical safety precautions \(page 16\)](#).
2. Remove any shrouding in front of the cooling fan.
3. Disconnect the fan wiring.
4. Undo the two retaining screws (a).
5. Pull the fan outwards to separate it from the heat exchanger housing.
6. Install new fan in reverse order. Align the guide pins (b) at the rear of the fan cowling with the slots (c) in the module bottom guide, then reinstall the retaining screws (a).




■ Replacing the common motor terminal cubicle fan



WARNING!

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Stop the drive and do the steps in section *Electrical safety precautions (page 16)* before you start the work.
2. Remove any shrouding in front of the cooling fan.
3. Disconnect the fan wiring.
4. Undo the fastening screws.
5. Pull the fan housing up and out.
6. Install a new fan in reverse order to the above.



■ **Replacing the brake chopper and resistor cubicle fans (options +D150 and +D151)**

See chapter *Resistor braking* (page 219).

Supply and inverter modules

■ Replacing the D8T supply module



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.




WARNING!

Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

Keep the module in its package until you install it. After unpacking, protect the module from dust, debris and moisture.


Lift/lower a heavy module with a lifting device. Use the designated lifting points. See the dimension drawings. There is a lifting device available from ABB (order code 3AXD50000047447).


Make sure that the drive cabinet is attached to the floor to prevent it from toppling over. The cabinet has a high center of gravity. When you pull out heavy components or power modules, there is a risk of overturning.




1. Stop the motors connected to the drive.
 2. Repeat the steps described in section [Electrical safety precautions \(page 16\)](#).
 3. Open the cubicle door.
 4. Close the inlet and outlet valve.
 5. Lead the drain hoses into a suitable container. If necessary, extend the hoses. Open the inlet and outlet drain valves. This will drain all modules in the cubicle.
 6. After the cubicle has drained, disconnect the piping from the module.
 7. **2xD8T module:** If lower module needs to be replaced, remove the cooling fan (see the fan replacement instructions).
 8. Remove any shrouding above the module.
 9. Remove the DC fuses above the module. See section [Checking and replacing the DC fuses \(page 145\)](#).
-

10. Disconnect the plug connector and fiber optic connectors in front of the module.
 11. Remove the L-shaped busbars (3 pcs above the module).
 12. Remove the module fastening screws (4 pcs).
 13. Install the module lifting device to the cabinet. See *Converter module lifting device for drive cabinets hardware manual* (3AXD50000210268 [English]).
 14. Attach one lifting hook to the front lifting eye of the module and pull the module out 10 centimeters. Keep the lifting chain tight.
 15. Attach the second lifting hook to the rear lifting eye, and pull the module completely out of the cabinet. Keep the weight constantly on the lifting device.
 16. Lower the module on a pallet. Keep the lifting chain attached to the module and attach the module safely to the pallet.
 17. Remove the lifting chains from the old module and move the pallet out of the way.
 18. Install the new module:
 - a. Attach the lifting hooks to the module, lift the module and place it on the module guide plate. Keep the weight on the lifting device.
 - b. Push the module into cabinet.
 - c. Fasten the module fastening screws.
 - d. Remove the lifting chains.
 - e. Reinstall the DC busbars and fuses above the module.
 - f. Connect the plug connector and fiber optic connectors.
 - g. Reconnect the coolant pipes to the module.
 - h. Fill up the cooling system.
 - i. Reinstall all shrouds removed earlier.
 - j. Remove the lifting device.
-







■ Replacing an inverter module



WARNING!

Obeys the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.



WARNING!

Make sure that the replacement module has exactly the same type code as the old module.



WARNING!

Beware of hot coolant. Do not work on the liquid cooling system until the pressure is lowered down by stopping the pumps and draining the coolant. High-pressure warm coolant (6 bar, max. 50 °C) is present in the internal cooling circuit when it is in operation.




WARNING!


Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

Removing the module


1. Repeat the steps described in section Electrical safety precautions.
2. Remove the shrouding in front of the module.
3. Undo the locking screws of the swing-out frame (if present) and open it.
4. Unplug the wiring from the module and move it aside. Use cable ties to keep the wiring out of the way.
5. Remove the L-shaped DC busbars at the top of the module. Make note of the orientation of the screws as well as the order of the washers.




6. Close the inlet valve (a) and outlet valve (located on the right-hand side of the cubicle). Lead the drain hoses (b, on both sides of the cubicle) into a suitable container. Open the drain valves (c, on both sides of the cubicle). This will drain all modules in the cubicle.



7. After the module has drained, disconnect the piping from the module.



8. Remove the module retaining screws at the top and the bottom of the module.



9. Pull the module carefully out onto a table or other platform. Keep the module secured to a hoist or equivalent to prevent the module from falling. For information on using the lifting device, see *Converter module lifting device for drive cabinets hardware manual* (3AXD50000210268 [English]).

Reinstalling the module

1. Push the module carefully into its bay.
 2. Fasten the retaining screws at the top and the bottom of the module.
 3. Reinstall the DC busbars at the top of the module.
 4. Reconnect the coolant pipes to the module.
 5. Reconnect the control wiring to the module.
 6. Fill up the cooling system. For instructions, see section [Filling up and bleeding the internal cooling circuit](#).
 7. Close the swing-out frame (if present). Reinstall all shrouds removed earlier.
-

Capacitors

The DC link of the drive contains several electrolytic capacitors. Operating time, load, and surrounding air temperature have an effect on the life of the capacitors. Capacitor life can be extended by decreasing the surrounding air temperature.

Capacitor failure is usually followed by damage to the unit and an input cable fuse failure, or a fault trip. If you think that any capacitors in the drive have failed, contact ABB.

■ Reforming the capacitors

The capacitors must be reformed if the drive has not been powered (either in storage or unused) for a year or more. The manufacturing date is on the type designation label. For information on reforming the capacitors, see *Capacitor reforming instructions* ([3BFE64059629](#) [English]).

Fuses

■ Replacing the AC fuses



WARNING!


Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.



WARNING!

Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Stop the motors connected to the drive.
 2. Repeat the steps described in section [Electrical safety precautions \(page 16\)](#).
 3. Open the cubicle door.
 4. Remove any shrouding in front of the fuses.
 5. **2xD8T:** For replacing lower module AC fuses, remove the DC fuse assemblies:
 - Remove the screws, nuts and washers (8 pcs) from the top and bottom of the DC fuses. Write down the correct order of the washers.
 - Remove the screws and nuts from the L-shaped busbars.
 - Remove the DC fuses and the L-shaped busbars.
 6. Remove the screw, nut and washer in the middle.
 7. Remove the screws (3 pcs, 1 per each phase) from the L-shaped busbars above the fuses.
 8. Remove the screws that attach the L-shape busbars below the fuses to the module AC busbars. There is one screw and busbar for each AC phase (3 pcs). Pull out the fuse assemblies with the L-shaped busbars (above and below) attached.
 9. Remove the screws, nuts and washers that attach the old fuses to the busbars, remove the old fuses and attach the new fuses in reverse order. Make sure to keep the washers in the original order. See section [Tightening torques \(page 185\)](#).
 10. Install the fuse assemblies and busbars in reverse order. See section [Tightening torques \(page 185\)](#).
-



■ Replacing the supply module DC fuses

Checking and replacing the DC fuses



WARNING!


Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.



WARNING!

Use the required personal protective equipment. Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Stop the motors connected to the drive.
2. Repeat the steps described in section [Electrical safety precautions \(page 16\)](#).
3. Open the cubicle door.
4. Remove any shrouding in front of the DC fuses.
5. Remove the screws, nuts and washers from the old fuses. Write down the correct order of the washers. Pull the fuses out.
6. Install the new fuses in reverse order. Make sure that the washers are in the correct order. If necessary, loosen the bolts of the L-shape busbars somewhat. Retighten, after the fuses are attached. See section [Tightening torques \(page 185\)](#).



■ Replacing the inverter module DC fuses



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.




WARNING!

Wear protective gloves and long sleeves. Some parts have sharp edges.

1. Repeat the steps described in section *Electrical safety precautions (page 16)* before you start the work.
2. Open the door of the module cubicle.
3. Remove the shrouding in front of the fuses (if any).

4. Check the condition of the fuses. In case of a blown fuse, replace all fuses with similar fuses: slacken the nuts of the fuses and pull the fuses out. Do not unscrew the nuts completely, not to drop them inside the module(s) below. Tighten the nuts first by hand or applying maximum 5 N·m force. Tightening torques for M12 nuts are 50 N·m (37 lbf·ft) for Bussmann fuses, and 46 N·m (34 lbf·ft) for Ferraz Shawmut fuses.
5. Attach the shrouding (if any) and close the door.



Control panel

For detailed information on the control panel, see *ACx-AP-x assistant control panels user's manual* (3AUA0000085685 [English]).

■ Cleaning the control panel

Use a soft damp cloth to clean the control panel. Avoid harsh cleaners which could scratch the display window.

■ Replacing the control panel battery

For instructions on how to replace the control panel battery, see *ACx-AP-x assistant control panels user's manual* (3AUA0000085685 [English]).

Control units

■ BCU control unit types

There are three variants of the BCU control unit used in ACS880 drives: BCU-02, BCU-12 and BCU-22. These have a different number of converter module connections (2, 7 and 12 respectively) but are otherwise identical. The three BCU types are interchangeable as long as the number of connections is sufficient. For example, the BCU-22 can be used as a direct replacement for both BCU-02 and BCU-12.

■ Replacing the memory unit


After replacing a control unit, you can keep the existing parameter settings by transferring the memory unit from the defective control unit to the new control unit.



WARNING!

Do not remove or insert the memory unit when the control unit is powered.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 16\)](#) before you start the work.
2. Make sure that the control unit is not powered.
3. Remove the fastening screw and pull the memory unit out.
4. Install a memory unit in reverse order.




■ Replacing the BCU control unit battery

Replace the real-time clock battery if the BATT OK LED is not illuminated when the control unit is powered.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 16\)](#) before you start the work.
2. Undo the fastening screw and remove the battery.
3. Replace the battery with a new BR2032 battery.

4. Dispose of the old battery according to local disposal rules or applicable laws.
5. Set the real-time clock.





12

Internal cooling circuit

Contents of this chapter

The cooling system of a liquid-cooled drive consists of two circuits: the internal cooling circuit and the external cooling circuit. The internal cooling circuit covers the heat-generating electrical components of the drive and transfers the heat to the cooling unit. In the cooling unit, the heat is transferred to the external cooling circuit which is usually part of a larger external cooling system. This chapter deals with the internal cooling circuit.

Applicability

The information in this chapter is applicable to cabinet-built ACS880 liquid-cooled drives. Except where otherwise indicated, the information is also applicable to drives built out of ACS880 liquid-cooled multidrive modules.

Internal cooling system


Each cubicle has an inlet and an outlet manifold, fitted with a stop valve and a drain valve. The stop valves can be closed to isolate all modules in the cubicle from the main cooling circuit.

In cabinet line-ups built by ABB, valves are color-coded:

- Blue – Open during operation
- Red – Closed during operation

The following diagram shows the coolant pipe connections in a drive system consisting of a supply unit and an inverter unit.

152 Internal cooling circuit



1	Supply modules. The drawing shows the configuration of a diode supply unit, ie. there is a common air-to-liquid exchanger in the cubicle. With an IGBT supply unit, each module has a dedicated air-to-liquid exchanger as shown for item 2.
2	Inverter modules
3	To/From cooling unit
A/L	Air-to-liquid heat exchanger
HS	Heat sink
a	Inlet valve
b	Inlet-side drain valve
c	Outlet valve
d	Outlet-side drain valve

The coolant used with ACS880 liquid-cooled drive systems is Antifrogen® L 25% or 50% mixture. See [Coolant specification \(page 156\)](#).

Connection to a cooling unit

■ Connection to an ACS880-1007LC cooling unit

Refer to *ACS880-1007LC cooling unit user's manual* (3AXD50000129607 [English]).

■ Connection to a custom cooling unit

General requirements

Equip the system with an expansion vessel to damp pressure rise due to volume changes when the temperature varies. Equip the system with a pump that provides a nominal flow and pressure. Keep the pressure within the limits specified in *Technical data (page 156)*. Install a pressure regulator to make sure that the maximum permissible operating pressure is not exceeded.

Install a bleed valve at the highest point of the cooling circuit, and a drain valve at the lowest point.

The materials that can be used are listed in *Cooling circuit materials (page 158)*.

Coolant temperature control

The temperature of the coolant in the internal cooling circuit must be kept within the limits specified in *Technical data (page 156)*. Note that the minimum temperature is dependent on ambient temperature and relative humidity.

Filling up and bleeding the internal cooling circuit

Both the drive and coolant must be at room temperature before filling up the cooling circuit.



WARNING!

Make sure that the maximum permissible operating pressure is not exceeded. When necessary regulate the pressure to appropriate level by draining excess coolant out of the system.



WARNING!

Bleeding of the cooling circuit is very important and has to be done with great care. Air bubbles in the cooling circuit may reduce or completely block coolant flow and lead to overheating. Let the air out of the cooling system while filling in coolant and, eg. after any power module replacements.

■ Drive line-ups with an ACS880-1007LC cooling unit

Follow the filling up and bleeding instructions in *ACS880-1007LC cooling unit user's manual* (3AXD50000129607 [English]).

■ Drive line-ups with a custom cooling unit

Note:

- In filling up the system, the drain valves in the line-up are used only to vent the air from the circuit so that it can be displaced by the coolant. The actual bleeding of the circuit must be done via an external bleed valve installed at the highest point of the cooling circuit. The most practical location for the valve is usually near or at the cooling unit.
 - Observe the instructions given by the manufacturer of the cooling unit. Pay special attention to filling up and bleeding the pumps properly as they may be damaged if operated when dry.
 - Draining coolant into the sewer system is not allowed.
1. Open the bleed valve at the cooling unit.
 2. Open the inlet valve and the outlet-side drain valve of one cubicle. Keep the outlet valve and the inlet-side drain valve closed.
 3. Attach a hose to the outlet-side drain valve and lead it into a suitable container.
 4. Fill the circuit with coolant. For coolant specification, see [Coolant specification \(page 156\)](#).
Note: To minimize foaming, do not exceed the filling flow rate of 5 l/min (1.3 US gallon/min).
 5. As the piping and modules in the cubicle fills up, coolant starts to flow from the hose. Let some coolant flow out, then close the drain valve.
 6. Close the inlet valve.
 7. Repeat steps 2 to 6 for all cubicles in the line-up.
 8. Open the inlet and outlet valves in all cubicles. Let any air remaining in the system out through the bleed valve at the cooling unit.
 9. Close the bleed valve at the cooling unit.
 10. Continue to fill in coolant until a base pressure of 100...150 kPa is achieved.
 11. Open the bleed valve of the pump to let out any air.
 12. Re-check the pressure and add coolant if necessary.
-

13. Start the coolant pump. Let any air remaining in the system out through the bleed valve at the cooling unit.
 14. After one to two minutes, stop the pump or block the coolant flow with a valve.
 15. Re-check the pressure and add coolant if necessary.
 16. Repeat steps 13 to 15 a few times until all air is let out of the cooling circuit. Listen for a humming sound and/or feel the piping for vibration to find out if there is still air left in the circuit.
-

Draining the internal cooling circuit

The modules in each cubicle can be drained through the drain valves without draining the whole internal cooling circuit.



WARNING!

Hot, pressurized coolant can be present in the cooling circuit. Do not work on the cooling circuit before the pressure is released by stopping the pumps and draining coolant.

1. Attach hoses to each drain valve in the cubicle to be drained. Lead the hoses into a suitable container. Make sure the ends of the hoses are not immersed in coolant at any point so that air can displace the coolant in the system.
2. Open the drain valves. Wait until all coolant has drained.
Note: Draining coolant into the sewer system is not allowed.
3. If required, dry the piping with compressed oil-free air of less than 6 bar.
4. If the drive is to be stored in temperatures below 0 °C (32 °F),
 - dry the cooling circuit with air,
 - fill the cooling circuit with coolant specified under *Coolant specification (page 156)*.
 - drain the cooling circuit again.

Maintenance intervals

As a general rule, the quality of the coolant should be checked at intervals of two years. This can be done by distributors of Antifrogen® L (see www.clariant.com) if a 250 milliliter sample is provided.

Technical data

■ Coolant specification

Coolant type

Antifrogen® L (by Clariant International Ltd, www.clariant.com) 25% or 50% mixture, available from Clariant distributors and ABB Service representatives.

Note: Do not dilute the coolant. It is ready to use.

Antifrogen® L 25% mixture is usable in storage temperatures down to -16 °C (3.2 °F).

Antifrogen® L 50% mixture is usable in storage temperatures down to -40 °C (-40 °F).

Note that operation below 0 °C (32 °F) is not allowed regardless of the freezing point of the coolant.



WARNING!

The warranty does not cover damage occurring from use of improper coolant.


■ Temperature limits

Ambient temperature: See the technical data of the drive/unit.

Freeze protection: The freezing point of the coolant is determined by the concentration of heat transfer fluid in the mixture.

The higher the concentration of heat transfer fluid, the higher the viscosity of the coolant. This results in a higher pressure loss in the system. See *Pressure limits (page 158)*.


The nominal current ratings of drive system modules apply to an Antifrogen® L / water solution of 25/75% (volume). With the Antifrogen® L concentration between 25% and 50%, the drive output current must be derated by 1/3 percentage point per 1 p.p. increase in Antifrogen® L concentration. The drawing below shows the derating factor (*k*) in relation to Antifrogen® L concentration.



Incoming coolant temperature:

- 0...40 °C (32...104 °F): no drive output current derating required
- 40...45 °C (104...113 °F): drive output current must be derated by 2 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (a).
- 45...50 °C (113...122 °F):
 - If components with a maximum operating temperature of 55 °C (131 °F) are installed in the same space as the drive modules, drive output current must be derated by 6 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (c).
 - If there are no components with a maximum operating temperature of 55 °C (131 °F) installed in the same space as the drive modules, drive output current must be derated by 2 percentage points per 1 °C (1.8 °F) temperature increase, as shown by curve (b).

The drawing below shows the derating factor (*k*) in relation to coolant temperature.



Condensation is not allowed. The minimum coolant temperature to avoid condensation (at an atmospheric pressure of 1 bar) is shown below as a function of relative humidity (RH) and ambient temperature (T_{air}).

T_{air} (°C)	Min. $T_{coolant}$ (°C)				
	RH = 95%	RH = 80%	RH = 65%	RH = 50%	RH = 40%
5	4.3	1.9	-0.9	-4.5	-7.4

T_{air} (°C)	Min. T_{coolant} (°C)				
	RH = 95%	RH = 80%	RH = 65%	RH = 50%	RH = 40%
10	9.2	6.7	3.7	-0.1	-3.0
15	14.2	11.5	8.4	4.6	1.5
20	19.2	16.5	13.2	9.4	6.0
25	24.1	21.4	17.9	13.8	10.5
30	29.1	26.2	22.7	18.4	15.0
35	34.1	31.1	27.4	23.0	19.4
40	39.0	35.9	32.2	27.6	23.8
45	44.0	40.8	36.8	32.1	28.2
50	49.0	45.6	41.6	36.7	32.8
55	53.9	50.4	46.3	42.2	37.1
	= Not allowed as standard but the coolant temperature must be 0 °C (32 °F) or above.				
Example:	At an air temperature of 45 °C and relative humidity of 65% the coolant temperature may not be below +36.8 °C				

Maximum temperature rise: Depends on heat losses and mass flow. Typically 10 °C (18 °F) with nominal losses and flow.

■ Pressure limits

Base pressure: 250 kPa (recommended); 300 kPa (maximum). “Base pressure” denotes the pressure of the system compared with the atmospheric pressure when the cooling circuit is filled with coolant.

Air counterpressure in expansion vessel (with ACS880-1007LC cooling unit): 80 kPa

Design pressure (PS): 600 kPa

Nominal pressure difference: 120 kPa with Antifrogen® L 25% coolant solution, 140 kPa with Antifrogen® L 50% coolant solution. This has to be taken into account when dimensioning the liquid cooling circuit.

Maximum pressure difference: 160 kPa

■ Coolant flow rate limits

The maximum coolant flow rate for all drive equipment is 1.3 × nominal. See the technical data chapter for nominal values.

■ Cooling circuit materials

Materials used in the internal cooling circuit are listed below. These are also the only materials that can be used in the external cooling circuit.

- stainless steel AISI 316L (UNS 31603)
- heavy gauge aluminum
- plastic materials such as PA, PEX and PTFE

Note: PVC hoses are not suitable for use with antifreeze.

- rubber gasketing NBR (nitrile rubber).



WARNING!

If connecting external piping to the internal cooling circuit, use only materials that are specified above. Copper, brass or bronze must not be used under any circumstances. Even minor dissolution of copper can cause copper precipitation on aluminum and subsequent galvanic corrosion. The liquid cooling system must not contain any zinc (eg. galvanized pipes).

If the plant incorporates normal iron pipes or cast iron accessories (eg. motor housings), a cooling unit with a heat exchanger (such as the ACS880-1007LC) must be used to separate the systems.



13

Technical data

Contents of this chapter

This chapter contains the technical specifications of the drive, for example, the ratings, fuse data, sizes and technical requirements, provisions for fulfilling the requirements for CE and other markings.

Ratings

The nominal ratings for the drives with 50 Hz and 60 Hz supply are given below. The symbols are described below the table.

ACS880-07LC-...	Input rating	Output ratings										
		No-overload use					Light-overload use			Heavy-duty use		
	I_1	I_2	I_{max}	P_N		S_N	I_{Ld}	P_{Ld}		I_{Hd}	P_{Hd}	
	A	A	A	kW	hp	kVA	A	kW	hp	A	kW	hp
$U_N = 690$ V, 6-pulse connection												
0390A-7	357	390	585	355	400	466	374	355	350	292	250	300
0430A-7	394	430	645	400	450	514	413	355	450	322	250	300
0480A-7	439	480	720	450	500	574	461	400	450	359	315	350
0530A-7	485	530	795	500	550	633	509	450	500	396	355	400
0600A-7	549	600	900	560	600	717	576	560	600	449	400	450
0670A-7	613	670	1005	630	700	801	643	630	700	501	450	500
0750A-7	686	750	1125	710	800	896	720	710	700	561	500	600
0850A-7	778	850	1275	800	900	1016	816	800	900	636	560	600
1030A-7	943	1030	1545	1000	1000	1231	989	900	1000	770	710	800
1170A-7	1071	1170	1755	1100	1250	1398	1123	1100	1250	875	800	900
1310A-7	1199	1310	1965	1200	1250	1566	1258	1200	1250	980	900	1000

ACS880-07LC-...	Input rating	Output ratings										
		No-overload use					Light-overload use			Heavy-duty use		
	I_1	I_2	I_{max}	P_N		S_N	I_{Ld}	P_{Ld}		I_{Hd}	P_{Hd}	
	A	A	A	kW	hp	kVA	A	kW	hp	A	kW	hp
1470A-7	1345	1470	2205	1400	1500	1757	1411	1200	1500	1100	1000	1000
1660A-7	1519	1660	2490	1600	1750	1984	1594	1400	1750	1242	1200	1250
1940A-7	1775	1940	2910	1800	2000	2319	1862	1800	2000	1451	1400	1500
2180A-7	1995	2180	3270	2000		2605	2093	2000		1631	1400	1750
2470A-7	2261	2470	3705	2300		2952	2371	2300		1848	1800	2000
2880A-7	2636	2880	4320	2700		3442	2765	2700		2154	2000	
3260A-7	2984	3260	4890	3000		3896	3130	3000		2438	2300	
3580A-7	3276	3580	5370	3400		4279	3437	3200		2678	2600	
4050A-7	3707	4050	6075	3800		4840	3888	3800		3029	2800	
4840A-7	4430	4840	7260	4400		5784	4646	4400		3620	3500	
5650A-7	5171	5650	8475	5200		6752	5424	5200		4226	4000	
6460A-7	5912	6460	9690	6000		7720	6202	6000		4832	4700	
$U_N = 690$ V, 12-pulse connection												
0530A-7+A004	485	530	795	500	550	633	509	450	500	474	355	400
0600A-7+A004	549	600	900	560	600	717	576	560	600	536	400	450
0670A-7+A004	613	670	1005	630	700	801	643	630	700	599	450	500
0750A-7+A004	686	750	1125	710	800	896	720	710	700	670	500	600
0850A-7+A004	778	850	1275	800	900	1016	816	800	900	760	560	600
1030A-7+A004	943	1030	1545	1000	1000	1231	989	900	1000	921	710	800
1170A-7+A004	1071	1170	1755	1100	1250	1398	1123	1100	1250	1046	800	900
1310A-7+A004	1199	1310	1965	1200	1250	1566	1258	1200	1250	1171	900	1000
1470A-7+A004	1345	1470	2205	1400	1500	1757	1411	1200	1500	1314	1000	1000
1660A-7+A004	1519	1660	2490	1600	1750	1984	1594	1400	1750	1484	1200	1250
1940A-7+A004	1775	1940	2910	1800	2000	2319	1862	1800	2000	1734	1400	1500
2180A-7+A004	1995	2180	3270	2000		2605	2093	2000		1949	1400	1750
2470A-7+A004	2261	2470	3705	2300		2952	2371	2300		2208	1800	2000
2880A-7+A004	2636	2880	4320	2700		3442	2765	2700		2575	2000	
3260A-7+A004	2984	3260	4890	3000		3896	3130	3000		2914	2300	
3580A-7+A004	3276	3580	5370	3400		4279	3437	3200		3200	2600	
4050A-7+A004	3707	4050	6075	3800		4840	3888	3800		3620	2800	
4840A-7+A004	4430	4840	7260	4400		5784	4646	4400		4327	3500	
5650A-7+A004	5171	5650	8475	5200		6752	5424	5200		5051	4000	
6460A-7+A004	5912	6460	9690	6000		7720	6202	6000		5775	4700	


■ Definitions

U_N	Supply voltage range.
I_1	Nominal rms input current
I_2	Nominal output current (available continuously with no over-loading)
I_{max}	Maximum output current. Available for 10 seconds at start, then as long as allowed by drive temperature.
P_N	Typical motor power in no-overload use. The horsepower ratings are typical NEMA motor sizes at 575 V.
S_N	Apparent power in no-overload use.
I_{Ld}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes.
P_{Ld}	Typical motor power in light-overload use
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes.
P_{Hd}	Typical motor power in heavy-duty use
<p>Note 1: The ratings apply at an ambient temperature of 40 °C (104 °F).</p> <p>Note 2: To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current.</p> <p>The DriveSize dimensioning tool available from ABB is recommended for selecting the drive, motor and gear combination.</p>	

■ Derating

Surrounding air temperature derating

In the temperature range +45...55 °C (+113...131 °F), the rated output current is derated by 0.5 percentage points for every added 1 °C (1.8 °F). The output current can be calculated by multiplying the current given in the rating table by the derating factor (k):



Coolant temperature derating

See section [Temperature limits \(page 156\)](#).

Antifreeze content derating

See section [Temperature limits \(page 156\)](#).

Altitude derating

At altitudes 1000 ... 2000 m (3281 ... 6562 ft) above sea level, the output current derating is 1 percentage point for every added 100 m (328 ft). For example, the derating factor for 1500 m (4921 ft) is 0.95. For altitudes above 2000 m (6562 ft), contact ABB.

For a more accurate derating, use the DriveSize PC tool.

Switching frequency derating

In the switching frequency range of 3.0 to 7.5 kHz, the output current is derated by 8 percentage points per each kHz. For example, the derating factor for 5 kHz is 0.84.

Output frequency derating

Below the output frequency of 12 Hz, the output current is derated by 3.5 percentage points per each Hz. For example, the derating factor for 9 Hz is 0.895.

Above the output frequency of 150 Hz, the output current is derated by 1 percentage point per each 10 Hz. For example, the derating factor for 175 Hz is 0.975.

Frame sizes and power module types

ACS880-07LC-...	Frame size	Supply module(s) used		Inverter modules used	
		Qty	Type ACS880-304LC-...	Qty	Type ACS880-104LC-...
$U_N = 690$ V, 6-pulse connection					
0390A-7	1×D8T + 1×R8i	1	0490A-7+A018	1	0390A-7+E205
0430A-7	1×D8T + 1×R8i	1	0490A-7+A018	1	0430A-7+E205
0480A-7	1×D8T + 1×R8i	1	0490A-7+A018	1	0480A-7+E205
0530A-7	1×D8T + 1×R8i	1	0490A-7+A018	1	0530A-7+E205
0600A-7	1×D8T + 1×R8i	1	0780A-7+A018	1	0600A-7+E205
0670A-7	1×D8T + 1×R8i	1	0780A-7+A018	1	0670A-7+E205
0750A-7	1×D8T + 1×R8i	1	0780A-7+A018	1	0750A-7+E205
0850A-7	1×D8T + 1×R8i	1	0780A-7+A018	1	0850A-7+E205
1030A-7	1×D8T + 2×R8i	1	1060A-7+A018	2	0530A-7+E205
1170A-7	1×D8T + 2×R8i	1	1060A-7+A018	2	0600A-7+E205
1310A-7	2×D8T + 2×R8i	2	0780A-7+A018	2	0670A-7+E205
1470A-7	2×D8T + 2×R8i	2	0780A-7+A018	2	0750A-7+E205
1660A-7	2×D8T + 2×R8i	2	0780A-7+A018	2	0850A-7+E205
1940A-7	2×D8T + 3×R8i	2	1060A-7+A018	3	0670A-5+E205
2180A-7	2×D8T + 3×R8i	2	1060A-7+A018	3	0750A-7+E205
2470A-7	3×D8T + 3×R8i	3	1060A-7+A018	3	0850A-7+E205
2880A-7	3×D8T + 4×R8i	3	1060A-7+A018	4	0750A-7+E205
3260A-7	3×D8T + 4×R8i	3	1060A-7+A018	4	0850A-7+E205
3580A-7	4×D8T + 5×R8i	4	1060A-7+A018	5	0750A-7+E205
4050A-7	4×D8T + 5×R8i	4	1060A-7+A018	5	0850A-7+E205
4840A-7	5×D8T + 6×R8i	5	1060A-7+A018	6	0850A-7+E205
5650A-7	6×D8T + 7×R8i	6	1060A-7+A018	7	0850A-7+E205
6460A-7	6×D8T + 8×R8i	6	1060A-7+A018	8	0850A-7+E205
$U_N = 690$ V, 12-pulse connection					
0530A-7+A004	2×D8T + 1×R8i	2	0490A-7+A018	1	0530A-7+E205
0600A-7+A004	2×D8T + 1×R8i	2	0490A-7+A018	1	0600A-7+E205
0670A-7+A004	2×D8T + 1×R8i	2	0490A-7+A018	1	0670A-7+E205
0750A-7+A004	2×D8T + 1×R8i	2	0490A-7+A018	1	0750A-7+E205

ACS880-07LC-...	Frame size	Supply module(s) used		Inverter modules used	
		Qty	Type ACS880-304LC-...	Qty	Type ACS880-104LC-...
0850A-7+A004	2xD8T + 1xR8i	2	0490A-7+A018	1	0850A-7+E205
1030A-7+A004	2xD8T + 2xR8i	2	0780A-7+A018	2	0530A-7+E205
1170A-7+A004	2xD8T + 2xR8i	2	0780A-7+A018	2	0600A-7+E205
1310A-7+A004	2xD8T + 2xR8i	2	0780A-7+A018	2	0670A-7+E205
1470A-7+A004	2xD8T + 2xR8i	2	0780A-7+A018	2	0750A-7+E205
1660A-7+A004	2xD8T + 2xR8i	2	0780A-7+A018	2	0850A-7+E205
1940A-7+A004	2xD8T + 3xR8i	2	1060A-7+A018	3	0670A-5+E205
2180A-7+A004	2xD8T + 3xR8i	2	1060A-7+A018	3	0750A-7+E205
2470A-7+A004	4xD8T + 3xR8i	4	0780A-7+A018	3	0850A-7+E205
2880A-7+A004	4xD8T + 4xR8i	4	0780A-7+A018	4	0750A-7+E205
3260A-7+A004	4xD8T + 4xR8i	4	0780A-7+A018	4	0850A-7+E205
3580A-7+A004	4xD8T + 5xR8i	4	1060A-7+A018	5	0750A-7+E205
4050A-7+A004	4xD8T + 5xR8i	4	1060A-7+A018	5	0850A-7+E205
4840A-7+A004	6xD8T + 6xR8i	6	1060A-7+A018	6	0850A-7+E205
5650A-7+A004	6xD8T + 7xR8i	6	1060A-7+A018	7	0850A-7+E205
6460A-7+A004	6xD8T + 8xR8i	6	1060A-7+A018	8	0850A-7+E205

Fuses

■ Internal AC fuses

The drive has AC fuses at the input of each supply module.

Notes:

- Fuses with higher current rating than the recommended ones must not be used.
- Fuses from other manufacturers can be used if they meet the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in the table.

ACS880-07LC-...	AC fuses at supply module input (IEC)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
$U_N = 690\text{ V}$, 6-pulse connection						
0390A-7 0430A-7 0480A-7 0530A-7	1	3	900	690	Bussmann	170M6413
0600A-7 0670A-7 0750A-7 0850A-7	1	3	1250	690	Bussmann	170M6416
1030A-7 1170A-7	2	6	900	690	Bussmann	170M6413
1310A-7 1470A-7 1660A-7	1	6	1250	690	Bussmann	170M6416
1940A-7 2180A-7	2	12	900	690	Bussmann	170M6413
2470A-7 2880A-7 3260A-7	2	18	900	690	Bussmann	170M6413
3580A-7 4050A-7	2	24	900	690	Bussmann	170M6413
4840A-7	2	30	900	690	Bussmann	170M6413
5650A-7 6460A-7	2	36	900	690	Bussmann	170M6413
$U_N = 690\text{ V}$, 12-pulse connection						
0530A-7+A004 0600A-7+A004 0670A-7+A004 0750A-7+A004 0850A-7+A004	1	6	900	690	Bussmann	170M6413
1030A-7+A004 1170A-7+A004 1310A-7+A004 1470A-7+A004 1660A-7+A004	1	6	1250	690	Bussmann	170M6416
1940A-7+A004 2180A-7+A004	2	12	900	690	Bussmann	170M6413

ACS880-07LC-...	AC fuses at supply module input (IEC)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
2470A-7+A004 2880A-7+A004 3260A-7+A004	1	12	1250	690	Bussmann	170M6416
3580A-7+A004 4050A-7+A004	2	24	900	690	Bussmann	170M6413
4840A-7+A004 5650A-7+A004 6460A-7+A004	2	36	900	690	Bussmann	170M6413

ACS880-07LC-...	AC fuses at supply module input (UL)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
$U_N = 690$ V, 6-pulse connection						
0390A-7 0430A-7 0480A-7 0530A-7	1	3	900	690	Bussmann	170M6413
0600A-7 0670A-7 0750A-7 0850A-7	1	3	1250	690	Bussmann	170M6416
1030A-7 1170A-7	1	3	1800		Bussmann	170M6904
1310A-7 1470A-7 1660A-7	1	6	1250	690	Bussmann	170M6416
1940A-7 2180A-7	1	6	1800		Bussmann	170M6904
2470A-7 2880A-7 3260A-7	1	9	1800		Bussmann	170M6904
3580A-7 4050A-7	1	12	1800		Bussmann	170M6904
4840A-7	1	15	1800		Bussmann	170M6904
5650A-7 6460A-7	1	18	1800		Bussmann	170M6904
$U_N = 690$ V, 12-pulse connection						
0530A-7+A004 0600A-7+A004 0670A-7+A004 0750A-7+A004 0850A-7+A004	1	6	900	690	Bussmann	170M6413
1030A-7+A004 1170A-7+A004 1310A-7+A004 1470A-7+A004 1660A-7+A004	1	6	1250	690	Bussmann	170M6416
1940A-7+A004 2180A-7+A004	1	6	1800		Bussmann	170M6904

168 Technical data

ACS880-07LC-...	AC fuses at supply module input (UL)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
2470A-7+A004 2880A-7+A004 3260A-7+A004	1	12	1250	690	Bussmann	170M6416
3580A-7+A004 4050A-7+A004	1	12	1800		Bussmann	170M6904
4840A-7+A004 5650A-7+A004 6460A-7+A004	1	18	1800	690	Bussmann	170M6904

■ **DC fuses**

The drive has DC fuses at the output of each supply module and at the input of each inverter module.

Notes:

- Fuses with higher current rating than the recommended ones must not be used.
- Fuses from other manufacturers can be used if they meet the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in the table.

ACS880-07LC-...	DC fuses at supply module output (IEC)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
$U_N = 690$ V, 6-pulse connection						
0390A-7 0430A-7 0480A-7 0530A-7	1	2	1100	1000	Bussmann	170M6549
0600A-7 0670A-7 0750A-7 0850A-7	2	4	800	1250	Bussmann	170M6546
1030A-7 1170A-7	2	4	1100	1000	Bussmann	170M6549
1310A-7 1470A-7 1660A-7	2	8	800	1250	Bussmann	170M6546
1940A-7 2180A-7	2	8	1100	1000	Bussmann	170M6549
2470A-7 2880A-7 3260A-7	2	12	1100	1000	Bussmann	170M6549
3580A-7 4050A-7	2	16	1100	1000	Bussmann	170M6549
4840A-7	2	20	1100	1000	Bussmann	170M6549
5650A-7 6460A-7	2	24	1100	1000	Bussmann	170M6549
$U_N = 690$ V, 12-pulse connection						
0530A-7+A004 0600A-7+A004 0670A-7+A004 0750A-7+A004 0850A-7+A004	1	4	1100	1000	Bussmann	170M6549
1030A-7+A004 1170A-7+A004 1310A-7+A004 1470A-7+A004 1660A-7+A004	2	8	800	1250	Bussmann	170M6546
1940A-7+A004 2180A-7+A004	2	8	1100	1000	Bussmann	170M6549
2470A-7+A004 2880A-7+A004 3260A-7+A004	2	16	800	1250	Bussmann	170M6546

ACS880-07LC-...	DC fuses at supply module output (IEC)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
3580A-7+A004 4050A-7+A004	2	16	1100	1000	Bussmann	170M6549
4840A-7+A004 5650A-7+A004 6460A-7+A004	2	24	1100	1000	Bussmann	170M6549

ACS880-07LC-...	DC fuses at supply module output (UL)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
$U_N = 690$ V, 6-pulse connection						
0390A-7 0430A-7 0480A-7 0530A-7	1	2	1100	1000	Bussmann	170M6549
0600A-7 0670A-7 0750A-7 0850A-7	1	2	1600	900	Bussmann	170M6792
1030A-7 1170A-7	1	2	2200	1250	Bussmann	170M6827
1310A-7 1470A-7 1660A-7	1	4	1600	900	Bussmann	170M6792
1940A-7 2180A-7	1	4	2200	1250	Bussmann	170M6827
2470A-7 2880A-7 3260A-7	1	6	2200	1250	Bussmann	170M6827
3580A-7 4050A-7	1	8	2200	1250	Bussmann	170M6827
4840A-7	1	10	2200	1250	Bussmann	170M6827
5650A-7 6460A-7	1	12	2200	1250	Bussmann	170M6827
$U_N = 690$ V, 12-pulse connection						
0530A-7+A004 0600A-7+A004 0670A-7+A004 0750A-7+A004 0850A-7+A004	1	4	1100	1000	Bussmann	170M6549
1030A-7+A004 1170A-7+A004 1310A-7+A004 1470A-7+A004 1660A-7+A004	1	4	1600	900	Bussmann	170M6792
1940A-7+A004 2180A-7+A004	1	4	2200	1250	Bussmann	170M6827
2470A-7+A004 2880A-7+A004 3260A-7+A004	1	8	1600	900	Bussmann	170M6792

ACS880-07LC-...	DC fuses at supply module output (UL)					
	Qty (per phase)	Qty (total)	A	V	Manufacturer	Type
3580A-7+A004 4050A-7+A004	1	8	2200	1250	Bussmann	170M6827
4840A-7+A004 5650A-7+A004 6460A-7+A004	1	12	2200	1250	Bussmann	170M6827

ACS880-07LC-...	DC fuses at inverter module input (IEC/UL)				
	Qty	A	V	Manufacturer	Type
$U_N = 690$ V, 6-pulse connection					
0390A-7 0430A-7	2	800	1250	Bussmann	170M6546
0480A-7	2	900	1100	Bussmann	170M6547
0530A-7	2	1000	1100	Bussmann	170M6548
0600A-7	2	1100	1000	Bussmann	170M6549
0670A-7	2	1250	1100	Bussmann	170M6500
0750A-7 0850A-7	2	1400	1100	Bussmann	170M6501
1030A-7	4	1000	1100	Bussmann	170M6548
1170A-7	4	1100	1000	Bussmann	170M6549
1310A-7	4	1250	1100	Bussmann	170M6500
1470A-7 1660A-7	4	1400	1100	Bussmann	170M6501
1940A-7	6	1250	1100	Bussmann	170M6500
2180A-7 2470A-7	6	1400	1100	Bussmann	170M6501
2880A-7 3260A-7	8	1400	1100	Bussmann	170M6501
3580A-7 4050A-7	10	1400	1100	Bussmann	170M6501
4840A-7	12	1400	1100	Bussmann	170M6501
5650A-7	14	1400	1100	Bussmann	170M6501
6460A-7	16	1400	1100	Bussmann	170M6501
$U_N = 690$ V, 12-pulse connection					
0530A-7+A004	2	1000	1100	Bussmann	170M6548
0600A-7+A004	2	1100	1000	Bussmann	170M6549
0670A-7+A004	2	1250	1100	Bussmann	170M6500
0750A-7+A004 0850A-7+A004	2	1400	1100	Bussmann	170M6501
1030A-7+A004	4	1000	1100	Bussmann	170M6548
1170A-7+A004	4	1100	1000	Bussmann	170M6549
1310A-7+A004	4	1250	1100	Bussmann	170M6500
1470A-7+A004 1660A-7+A004	4	1400	1100	Bussmann	170M6501

ACS880-07LC-...	DC fuses at inverter module input (IEC/UL)				
	Qty	A	V	Manufacturer	Type
1940A-7+A004	6	1250	1100	Bussmann	170M6500
2180A-7+A004 2470A-7+A004	6	1400	1100	Bussmann	170M6501
2880A-7+A004 3260A-7+A004	8	1400	1100	Bussmann	170M6501
3580A-7+A004 4050A-7+A004	10	1400	1100	Bussmann	170M6501
4840A-7+A004	12	1400	1100	Bussmann	170M6501
5650A-7+A004	14	1400	1100	Bussmann	170M6501
6460A-7+A004	16	1400	1100	Bussmann	170M6501

■ Brake chopper DC fuses

Optional (+D150) brake choppers have two DC fuses each. The fuse type is Bussmann 170M5146 (630 A 1250 V).

Dimensions and weights

See chapter *Dimensions*.

Free space requirements

The values are as required by cooling, maintenance and/or operation of the pressure relief (if present). Also obey the general mechanical installation instructions.

Front		Sides		Above	
mm	in.	mm	in.	mm	in.
1500	59	0	0	250	9.85

Cooling data, noise

ACS880-07LC-...	Coolant volume		Coolant flow		Heat dissipation	Noise
	l	US gal	l/min	US gal/min	kW	dB(A)
$U_N = 690$ V, 6-pulse connection						
0390A-7	14.8	3.9	52	13.7	9.9	67
0430A-7	14.8	3.9	52	13.7	10.8	67
0480A-7	14.8	3.9	52	13.7	12.1	67
0530A-7	14.8	3.9	52	13.7	13.3	67
0600A-7	14.8	3.9	52	13.7	14.3	67
0670A-7	14.8	3.9	52	13.7	16.0	67
0750A-7	14.8	3.9	52	13.7	18.0	67
0850A-7	14.8	3.9	52	13.7	21	67
1030A-7	18.0	4.75	68	18.0	24	69
1170A-7	18.0	4.75	68	18.0	27	69

ACS880-07LC-...	Coolant volume		Coolant flow		Heat dissipation kW	Noise dB(A)
	l	US gal	l/min	US gal/min		
1310A-7	18.7	4.95	82	21.7	30	69
1470A-7	18.7	4.95	82	21.7	35	69
1660A-7	18.7	4.95	82	21.7	40	69
1940A-7	22.0	5.8	98	25.9	44	71
2180A-7	22.0	5.8	98	25.9	50	71
2470A-7	25.5	6.75	118	31.2	58	71
2880A-7	29.4	7.75	134	35.4	66	72
3260A-7	29.4	7.75	134	35.4	77	72
3580A-7	37.3	9.85	172	45.4	83	73
4050A-7	37.3	9.85	172	45.4	96	74
4840A-7	44.1	11.65	208	54.9	118	74
5650A-7	48.7	12.85	238	62.8	132	75
6460A-7	52.0	13.75	254	67.1	151	75
$U_N = 690$ V, 12-pulse connection						
0530A-7+A004	19.4	5.1	74	19.5	13.3	67
0600A-7+A004	19.4	5.1	74	19.5	15.1	67
0670A-7+A004	19.4	5.1	74	19.5	16.8	67
0750A-7+A004	19.4	5.1	74	19.5	19.0	67
0850A-7+A004	19.4	5.1	74	19.5	22	67
1030A-7+A004	22.6	5.95	90	23.8	24	69
1170A-7+A004	22.6	5.95	90	23.8	27	69
1310A-7+A004	22.6	5.95	90	23.8	30	69
1470A-7+A004	22.6	5.95	90	23.8	35	69
1660A-7+A004	22.6	5.95	90	23.8	40	69
1940A-7+A004	25.9	6.85	106	28.0	44	71
2810A-7+A004	25.9	6.85	106	28.0	50	71
2470A-7+A004	30.1	7.95	140	36.0	58	71
2880A-7+A004	34.0	9.0	156	41.2	67	72
3260A-7+A004	34.0	9.0	156	41.2	77	72
3580A-7+A004	37.3	9.85	172	45.4	83	73
4050A-7+A004	37.3	9.85	172	45.4	96	74
4840A-7+A004	44.8	11.85	222	58.6	114	74
5650A-7+A004	48.7	12.85	238	62.9	132	75
6460A-7+A004	52.0	13.75	254	67.1	151	75

Typical power cable sizes

The tables below give current carrying capacity (I_{Lmax}) for aluminum and copper PVC/XLPE insulated cables. A correction factor $K = 0.70$ is used. Time const is the temperature time constant of the cable.

The cable sizing is based on max. 9 cables laid on the cable trays side by side, three ladder type trays one on top of the other, ambient temperature 30 °C (EN 60204-1 and IEC 60364-5-52).

Aluminum cable		PVC insulation Conductor temperature 70 °C		XLPE insulation Conductor temperature 90 °C	
Size	∅ [mm]	I_{Lmax} [A]	Time const. [s]	I_{Lmax} [A]	Time const. [s]
3 × 35 + 10 Cu	26	67	736	84	669
3 × 50 + 15 Cu	29	82	959	102	874
3 × 70 + 21 Cu	32	105	1182	131	1079
3 × 95 + 29 Cu	38	128	1492	159	1376
3 × 120 + 41 Cu	41	148	1776	184	1637
3 × 150 + 41 Cu	44	171	2042	213	1881
3 × 185 + 57 Cu	49	196	2422	243	2237
3 × 240 + 72 Cu	54	231	2967	286	2740
3 × 300 + 88 Cu	58	267	3478	330	3229
2 × (3 × 70 + 21 Cu)	2 × 32	210	1182	262	1079
2 × (3 × 95 + 29 Cu)	2 × 38	256	1492	318	1376
2 × (3 × 120 + 41 Cu)	2 × 41	297	1776	368	1637
2 × (3 × 150 + 41 Cu)	2 × 44	343	2042	425	1881
2 × (3 × 185 + 57 Cu)	2 × 49	392	2422	486	2237
2 × (3 × 240 + 72 Cu)	2 × 54	462	2967	572	2740
2 × (3 × 300 + 88 Cu)	2 × 58	533	3478	659	3229
3 × (3 × 150 + 41 Cu)	3 × 44	514	2042	638	1881
3 × (3 × 185 + 57 Cu)	3 × 49	588	2422	728	2237
3 × (3 × 240 + 72 Cu)	3 × 54	693	2967	859	2740
3 × (3 × 300 + 88 Cu)	3 × 58	800	3478	989	3229
4 × (3 × 185 + 57 Cu)	4 × 49	784	2422	971	2237
4 × (3 × 240 + 72 Cu)	4 × 54	924	2967	1145	2740
4 × (3 × 300 + 88 Cu)	4 × 58	1067	3478	1319	3229
5 × (3 × 185 + 57 Cu)	5 × 49	980	2422	1214	2237
5 × (3 × 240 + 72 Cu)	5 × 54	1155	2967	1431	2740
5 × (3 × 300 + 88 Cu)	5 × 58	1333	3478	1648	3229
6 × (3 × 240 + 72 Cu)	6 × 54	1386	2967	1718	2740
6 × (3 × 300 + 88 Cu)	6 × 58	1600	3478	1978	3229
7 × (3 × 240 + 72 Cu)	7 × 54	1617	2967	2004	2740
7 × (3 × 300 + 88 Cu)	7 × 58	1867	3478	2308	3229
8 × (3 × 240 + 72 Cu)	8 × 54	1848	2967	2290	2740
8 × (3 × 300 + 88 Cu)	8 × 58	2133	3478	2637	3229
9 × (3 × 240 + 72 Cu)	9 × 54	2079	2967	2577	2740
9 × (3 × 300 + 88 Cu)	9 × 58	2400	3478	2967	3229
10 × (3 × 240 + 72 Cu)	10 × 54	2310	2967	2867	2740
10 × (3 × 300 + 88 Cu)	10 × 58	2667	3478	3297	3229

Copper cable		PVC insulation Conductor temperature 70 °C		XLPE insulation Conductor temperature 90 °C	
Size	∅ [mm]	I_{Lmax} [A]	Time const. [s]	I_{Lmax} [A]	Time const. [s]
3 × 1.5 + 1.5	13	13	85	16	67
3 × 2.5 + 2.5	14	18	121	23	88
(3 × 4 + 4)	16	24	175	30	133
3 × 6 + 6	18	30	251	38	186
3 × 10 + 10	21	42	359	53	268
3 × 16 + 16	23	56	514	70	391
3 × 25 + 16	24	71	791	89	598
3 × 35 + 16	26	88	1000	110	760
3 × 50 + 25	29	107	1308	134	990
3 × 70 + 35	32	137	1613	171	1230
3 × 95 + 50	38	167	2046	209	1551
3 × 120 + 70	41	193	2441	241	1859
3 × 150 + 70	44	223	2820	279	2139
3 × 185 + 95	50	255	3329	319	2525
3 × 240 + 120	55	301	4073	376	3099
3 × 300 + 150	58	348	4779	435	3636
2 × (3 × 70 + 35)	2 × 32	274	1613	342	1230
2 × (3 × 95 + 50)	2 × 38	334	2046	418	1551
2 × (3 × 120 + 70)	2 × 41	386	2441	482	1859
2 × (3 × 150 + 70)	2 × 44	446	2820	558	2139
2 × (3 × 185 + 95)	2 × 50	510	3329	638	2525
2 × (3 × 240 + 120)	2 × 55	602	4073	752	3099
2 × (3 × 300 + 150)	2 × 58	696	4779	869	3636
3 × (3 × 120 + 70)	3 × 41	579	2441	723	1859
3 × (3 × 150 + 70)	3 × 44	669	2820	837	2139
3 × (3 × 185 + 95)	3 × 50	765	3329	957	2525
3 × (3 × 240 + 120)	3 × 55	903	4073	1128	3099
3 × (3 × 300 + 150)	3 × 58	1044	4779	1304	3636
4 × (3 × 150 + 70)	4 × 44	892	2820	1116	2139
4 × (3 × 185 + 95)	4 × 50	1020	3329	1276	2525
4 × (3 × 240 + 120)	4 × 55	1204	4073	1504	3099
4 × (3 × 300 + 150)	4 × 58	1391	4779	1304	3636
5 × (3 × 185 + 95)	5 × 50	1275	3329	1595	2525
5 × (3 × 240 + 120)	5 × 55	1505	4073	1880	3099
5 × (3 × 300 + 150)	5 × 58	1739	4779	2173	3636
6 × (3 × 185 + 95)	6 × 50	1530	3329	1914	2525
6 × (3 × 240 + 120)	6 × 55	1806	4073	2256	3099
6 × (3 × 300 + 150)	6 × 58	2087	4779	2608	3636
7 × (3 × 240 + 120)	7 × 55	2107	4073	2632	3099
7 × (3 × 300 + 150)	7 × 58	2435	4779	3043	3636
8 × (3 × 240 + 120)	8 × 55	2408	4073	3008	3099
8 × (3 × 300 + 150)	8 × 58	2783	4779	3477	3636

Terminal and lead-through data for the power cables

The locations and sizes of lead-throughs are shown by the dimension drawings delivered with the drive, and the dimension drawing examples in this manual.

Terminal data for the supply and inverter control units

See chapter *Control units of the drive (page 105)*.

Electrical power network specification

Voltage (U_1)	690 V units: 525...690 V AC 3-phase $\pm 10\%$ (525...600 V AC $\pm 10\%$ in UL/CSA installations, or corner-grounded TN systems). This is indicated in the type designation label as typical input voltage levels (3~ 525/600/690 V AC).
Network type	TN (grounded) and IT (ungrounded) systems
Frequency	50/60 Hz, variation $\pm 5\%$ of nominal frequency
Imbalance	Max. $\pm 3\%$ of nominal phase-to-phase input voltage
Short-circuit withstand strength (IEC/EN 61439-1)	<u>With main circuit breaker (option +F255) and without grounding/earthing switch (without option +F259):</u> Rated peak withstand current (I_{pk}): 143 kA Rated short-time withstand current (I_{cw}): 65 kA/1 s <u>All other configurations:</u> Rated peak withstand current (I_{pk}): 105 kA Rated short-time withstand current (I_{cw}): 50 kA/1 s
Short-circuit current protection (UL 508A, CSA C22.2 No. 14-13)	The drive is suitable for use on a circuit capable of delivering not more than 100,000 rms symmetrical amperes at 600 V maximum when the input cable is protected with class T fuses.
Short-circuit current protection (UL 508A, CSA C22.2 No. 14-13)	To be defined.
Transformer specification for 12-pulse supply (IEC 60076-1:2011)	<u>Connection:</u> Dy 11 d0 or Dyn 11 d0 <u>Phase shift between secondaries:</u> 30° electrical <u>Voltage difference between secondaries:</u> < 0.5% <u>Short-circuit impedance of secondaries:</u> > 5% <u>Short-circuit impedance difference between secondaries:</u> $\leq 10\%$ of the percentage impedance To avoid a potentially destructive DC voltage level in an earth fault situation, grounding of the secondaries is not allowed. Static shielding is recommended.

Motor connection data

Motor types	Asynchronous AC induction motors, permanent magnet synchronous motors and AC induction servomotors, ABB synchronous reluctance (SynRM) motors
Voltage (U_2)	0 to U_1 , 3-phase symmetrical, U_{max} at the field weakening point
Frequency (f_2)	0...500 Hz <ul style="list-style-type: none"> For higher operational output frequencies, please contact your local ABB representative. Operation outside the range of 12...150 Hz requires derating. See section Derating.
Current	See the rating tables.

Switching frequency	3 kHz (typical). The switching frequency can vary per frame and voltage. For exact values, please contact your local ABB representative.
Maximum recommended motor cable length	500 m (1640 ft). Note: Longer cables cause a motor voltage decrease which limits the available motor power. The decrease depends on the motor cable length and characteristics. Contact ABB for more information. Note: With motor cables longer than 150 m (492 ft) the EMC Directive requirements may not be fulfilled.

Efficiency

97.5 ... 97.8% at nominal power level depending on drive type

Optical components

The specifications of the optic cable are as follows:

- Storage temperature: -55 ... +85 °C (-67 ... +185 °F)
- Installation temperature: -20 ... +70 °C (-4 ... +158 °F)
- Maximum short-term tensile force: 50 N (11.2 lbf)
- Minimum short-term bend radius: 25 mm (1.0 in)
- Minimum long-term bend radius: 35 mm (1.4 in)
- Maximum long-term tensile load: 1 N (3.6 ozf)
- Flexing: Max. 1000 cycles

ABB drive products in general utilize 5 and 10 MBd (megabaud) optical components from Avago Technologies' Versatile Link range. Note that the optical component type is not directly related to the actual communication speed.

Note: The optical components (transmitter and receiver) on a fiber optic link must be of the same type.

Plastic optical fiber (POF) cables can be used with both 5 MBd and 10 MBd optical components. 10 MBd components also enable the use of Hard Clad Silica (HCS®) cables, which allow longer connection distances thanks to their lower attenuation. HCS® cables cannot be used with 5 MBd optical components.

The maximum lengths of fiber optic links for POF and HCS® cables are 20 and 200 meters (65.6 ft and 656 ft) respectively.

Protection classes

Degrees of protection (IEC/EN 60529)	IP42 (standard), IP54 (option +B055)
Enclosure types (UL50)	UL Type 1 (standard), UL Type 12 (option +B055). For indoor use only.
Overvoltage category (IEC/EN 60664-1)	III, except for auxiliary power connections (fan, control, heating, lighting, cooling unit pump etc) which are category II.
Protective class (IEC/EN 61800-5-1)	I

Ambient conditions

Environmental limits for the drive are given below. The drive is to be used in a heated, indoor, controlled environment.

	Operation installed for stationary use	Storage in the protective package	Transportation in the protective package
Installation site altitude	0...2000 m (0...6562 ft) above sea level. For alti- tudes over 2000 m, contact ABB. Output derated above 1000 m (3281 ft).	-	-
Air temperature	0 ... +45 °C (+32 ... +113 °F), no con- densation allowed. Output derated in the range +45 ... +55 °C (+113 ... +131 °F).	-40 to +70 °C (- 40 to +158 °F)	-40 to +70 °C (- 40 to +158 °F)
Relative humidity	Max. 95%	Max. 95%	Max. 95%
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.		
Contamination	IEC/EN 60721-3-3:2002: Classification of environ- mental conditions - Part 3- 3: Classification of groups of environmental paramet- ers and their severities - Stationary use of weather protected locations Chemical gases: Class 3C2 Solid particles: Class 3S2. No conductive dust al- lowed.	IEC 60721-3-1:1997 Chemical gases: Class 1C2 Solid particles: Class 1S3 (packing must support this, otherwise 1S2)	IEC 60721-3-2:1997 Chemical gases: Class 2C2 Solid particles: Class 2S2
Pollution degree	2		
Vibration IEC/EN 61800-5-1 IEC 60068-2-6:2007, EN 60068-2-6:2008 Envir- onmental testing Part 2: Tests –Test Fc: Vibration (sinusoidal)	IEC/EN 60721-3-3:2002 10...57 Hz: max. 0.075 mm amplitude 57...150 Hz: 1 g Units with marine construc- tion (option +C121): Max. 1 mm (0.04 in) (5 ... 13.2 Hz), max. 0.7 g (13.2 ... 100 Hz) sinusoidal	IEC/EN 60721-3-1:1997 10...57 Hz: max. 0.075 mm amplitude 57...150 Hz: 1 g	IEC/EN 60721-3-2:1997 2...9 Hz: max. 3.5 mm amplitude 9...200 Hz: 10 m/s ² (32.8 ft/s ²)
Shock IEC 60068-2-27:2008, EN 60068-2-27:2009 Environmental testing - Part 2-27: Tests - Test Ea and guidance: Shock	Not allowed	With packing max. 100 m/s ² (328 ft/s ²) 11 ms	With packing max. 100 m/s ² (328 ft/s ²) 11 ms

Materials

Cabinet	<ul style="list-style-type: none"> • Zinc coated steel sheet • Polyester thermosetting powder coating on visible surfaces, color RAL 7035 and RAL 9017
Busbars for user power connections	Tin-plated copper
Liquid cooling system	See Cooling circuit materials (page 158)
Fire safety of materials (IEC 60332-1)	Insulating materials and non-metallic items: mostly self-extinctive
Package	<p>Standard package:</p> <ul style="list-style-type: none"> • timber, polyethylene sheet (thickness 0.15 mm), stretch film (thickness 0.023 mm), PP tape, PET strap, sheet metal (steel) • for land and air transport when planned storage time is less than 2 months or when storage can be arranged in clean and dry conditions less than 6 months • can be used when products will not be exposed to corrosive atmosphere during transport or storage <p>Container package:</p> <ul style="list-style-type: none"> • timber, VCI sheet film (PE, thickness 0.10 mm), VCI stretch film (PE, thickness 0.04 mm), VCI emitter bags, PP tape, PET strap, sheet metal (steel) • for sea transport in containers • recommended for land and air transport when storage time prior to installation exceeds 6 months or storage is arranged in partially weather-protected conditions <p>Seaworthy package:</p> <ul style="list-style-type: none"> • timber, plywood, VCI sheet film (PE, thickness 0.10 mm), VCI stretch film (PE, thickness 0.04 mm), VCI emitter bags, PP tape, PET strap, sheet metal (steel) • for sea transport with or without containerization • for long storage periods in environments where roofed and humidity-controlled storage cannot be arranged <p>Cabinets are attached to the pallet with screws and braced from the top end to the package walls to prevent swaying inside the package. Package elements are attached to each other with screws.</p>
Disposal	<p>The main parts of the drive can be recycled to preserve natural resources and energy. Product parts and materials should be dismantled and separated. Generally all metals, such as steel, aluminum, copper and its alloys, and precious metals can be recycled as material. Plastics, rubber, cardboard and other packaging material can be used in energy recovery. Printed circuit boards and large electrolytic capacitors need selective treatment according to IEC 62635 guidelines. To aid recycling, plastic parts are marked with an appropriate identification code. Contact your local ABB distributor for further information on environmental aspects and recycling instructions for professional recyclers. End of life treatment must follow international and local regulations. See <i>ACS880 cabinet-installed drives recycling instructions and environmental information</i> (3AXD50000153909 [English]).</p>


Applicable standards


Standard	Information
European electrical safety requirements product standards	
IEC/EN 61800-5-1:2007	Adjustable speed electrical power drive systems. Part 5-1: Safety requirements – electrical, thermal and energy
IEC 60146-1-1:2009 EN 60146-1-1:2010	Semiconductor converters – General requirements and line commutated converters – Part 1-1: Specification of basic requirements
IEC/EN 60664-1:2007	Insulation coordination for equipment within low-voltage systems. Part 1: Principles, requirements and tests


Standard	Information
IEC 60529:1989 EN 60529:1991	Degrees of protection provided by enclosures (IP code).
IEC 60204-1:2005 + A1:2008 EN 60204-1:2006 + AC:2010	Safety of machinery. Electrical equipment of machines. Part 1: General requirements.
IEC/EN 61439-1:2009	Low-voltage switchgear and controlgear assemblies -- Part 1: General rules
EMC performance	
IEC/EN 61800-3:2004	Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods
Product requirements in North America	
UL 508A 1st edition:2001	Industrial Control Panels
UL 50 12th edition:2007	Enclosures for Electrical Equipment, Non-Environmental Considerations
CSA C22.2 No. 14-13:2013	Industrial control equipment
CSA C22.2 No. 274-13:2013	Adjustable speed drives


Markings


These markings are attached to the drive:


	CE mark Product complies with the applicable European Union legislation. For fulfilling the EMC requirements, see the additional information concerning the drive EMC compliance (IEC/EN 61800-3).
---	---


	TÜV Safety Approved mark (functional safety) Product contains Safe Torque Off and possibly other (optional) safety functions which are certified by TÜV according to the relevant functional safety standards. Applicable to drives and inverters; not applicable to supply, brake or DC/DC converter units or modules.
---	--

	EAC (Eurasian Conformity) mark Product complies with the technical regulations of the Eurasian Customs Union. EAC mark is required in Russia, Belarus and Kazakhstan.
---	--

	Electronic Information Products (EIP) green mark The product complies with <i>the People's Republic of China Electronic Industry Standard (SJ/T 11364-2014)</i> . The product does not contain toxic and hazardous substances or elements above the maximum concentration values, and it is an environmentally-friendly product which can be recycled.
---	---

	RCM mark Product complies with Australian and New Zealand requirements specific to EMC, telecommunications and electrical safety. For fulfilling the EMC requirements, see the additional information concerning the drive EMC compliance (IEC/EN 61800-3).
---	--

	KC mark Product complies with Korea's product safety requirements for electrical and electronic equipment and components that utilize power from 50...1000 V AC.
---	---

	<p>WEEE mark</p> <p>At the end of life the product should enter the recycling system at an appropriate collection point and not placed in the normal waste stream.</p>
---	--

EMC compliance (IEC/EN 61800-3)

■ Definitions

EMC stands for Electromagnetic Compatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

First environment includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

Second environment includes establishments connected to a network not supplying domestic premises.

Drive of category C1: drive of rated voltage less than 1000 V and intended for use in the first environment.

Drive of category C2: drive of rated voltage less than 1000 V and intended to be installed and started up only by a professional when used in the first environment. **Note:** A professional is a person or organization having necessary skills in installing and/or starting up power drive systems, including their EMC aspects.

Drive of category C3: drive of rated voltage less than 1000 V and intended for use in the second environment and not intended for use in the first environment.

Drive of category C4: drive of rated voltage equal to or above 1000 V, or rated current equal to or above 400 A, or intended for use in complex systems in the second environment.

■ Category C3

The drive complies with the standard with the following provisions:

1. The drive is installed according to the instructions given in the appropriate drive hardware manual.
2. Maximum motor cable length is 100 meters (328 ft).




WARNING!

A drive of category C3 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

■ Category C4

The drive complies with the C4 category with these provisions:

1. It is ensured that no excessive emission is propagated to neighboring low-voltage networks. In some cases, the natural suppression in transformers and cables is sufficient. If in doubt, the supply transformer with static screening between the primary and secondary windings can be used.



2. An EMC plan for preventing disturbances is drawn up for the installation. A template is available in *Technical guide No. 3 EMC compliant installation and configuration for a power drive system* (3AFE61348280 (English)).
3. The motor and control cables are selected, and routed according to the electrical planning guidelines of the drive. The EMC recommendations are obeyed.
4. The drive is installed according to its installation instructions. The EMC recommendations are obeyed.



WARNING!

A drive of category C4 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

Compliance with the European Machinery Directive

The drive is an electronic product which is covered by the European Low Voltage Directive. However, the drive includes the Safe torque off function and can be equipped with other safety functions for machinery which, as safety components, are in the scope of the Machinery Directive. These functions of the drive comply with European harmonized standards such as EN 61800-5-2. The declaration of conformity is shown below.



EU Declaration of Conformity

Machinery Directive 2006/42/EC

We

Manufacturer: ABB Oy

Address: Hiomotie 13, 00380 Helsinki, Finland.

Phone: +358 10 22 11

declare under our sole responsibility that the following products:

Frequency converters and frequency converter components

ACS880-04, -14, -34 (frames nxR8i)

ACS880-04XT, -04FXT

ACS880-07, -17, -37

ACS880-104

ACS880 multidrives

ACS880-104LC (frames nxR8i)

ACS880-07CLC

ACS880-17LC, -37LC, -107LC (frames nxR8i)

ACS880 liquid-cooled multidrives

identified with serial numbers beginning with 1 or 8

with regard to the safety functions

Safe torque off

Safe motor temperature with FPTC-01 module (option code +L536)

Safe Stop 1 (SS1-t) with FSPS-21 module (+Q986)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Prevention of unexpected start-up, with FSO-12 module (option code +Q973)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Safe Speed monitor, Safe direction, Prevention of unexpected start-up, with FSO-21 and FSE-31 modules (option codes +Q972 and +L521)



ACS880-07, -17, -37, -07CLC and ACS880 multidrives: Prevention of unexpected start-up (option codes +Q950; +Q957), **Emergency stop** (option codes +Q951; +Q952; +Q963; +Q964; +Q978; +Q979), **Safely-limited speed** (option codes +Q965; Q966)

are in conformity with all the relevant safety component requirements of EU Machinery Directive 2006/42/EC, when the listed safety functions are used for safety component functionality.

The following harmonized standards have been applied:

EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional
EN 62061:2005 + AC:2010 + A1:2013 + A2:2015	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems. Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of the control systems. Part 2: Validation
EN 60204-1:2006 + A1:2009 + AC:2010	Safety of machinery – Electrical equipment of machines – Part 1: General requirements

The following other standard has been applied:


IEC 61508:2010, parts 1-2	Functional safety of electrical / electronic / programmable electronic safety-related systems
IEC 61800-5-2:2016	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional

The products referred in this Declaration of conformity fulfil the relevant provisions of other European Union Directives which are notified in Single EU Declaration of conformity 3AXD10000497305.

Person authorized to compile the technical file:
Name and address: Vesa Tiihonen, Hiomotie 13, 00380 Helsinki, Finland

Helsinki, 16 Dec 2019

Signed for and on behalf of:


Peter Lindgren
Vice President, ABB Oy


Vesa Tiihonen
Manager, Product Engineering and Quality

Tightening torques

Unless a tightening torque is specified in the text, the following torques can be used.

■ Electrical connections

Size	Torque	Note
M3	0.5 N·m (4.4 lbf-in)	Strength class 4.6...8.8
M4	1 N·m (9 lbf-in)	Strength class 4.6...8.8
M5	4 N·m (35 lbf-in)	Strength class 8.8
M6	9 N·m (6.6 lbf-ft)	Strength class 8.8
M8	22 N·m (16 lbf-ft)	Strength class 8.8
M10	42 N·m (31 lbf-ft)	Strength class 8.8
M12	70 N·m (52 lbf-ft)	Strength class 8.8
M16	120 N·m (90 lbf-ft)	Strength class 8.8

■ Mechanical connections

Size	Max. torque	Note
M5	6 N·m (53 lbf-in)	Strength class 8.8
M6	10 N·m (7.4 lbf-ft)	Strength class 8.8
M8	24 N·m (17.7 lbf-ft)	Strength class 8.8

■ Insulation supports

Size	Max. torque	Note
M6	5 N·m (44 lbf-in)	Strength class 8.8
M8	9 N·m (6.6 lbf-ft)	Strength class 8.8
M10	18 N·m (13.3 lbf-ft)	Strength class 8.8
M12	31 N·m (23 lbf-ft)	Strength class 8.8

■ Cable lugs

Size	Max. torque	Note
M8	15 N·m (11 lbf-ft)	Strength class 8.8
M10	32 N·m (23.5 lbf-ft)	Strength class 8.8
M12	50 N·m (37 lbf-ft)	Strength class 8.8

Disclaimers

■ Generic disclaimer

The manufacturer shall have no obligation with respect to any product which (i) has been improperly repaired or altered; (ii) has been subjected to misuse, negligence or accident; (iii) has been used in a manner contrary to the manufacturer's instructions; or (iv) has failed as a result of ordinary wear and tear.

■ **Cybersecurity disclaimer**

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

14

Dimensions

Cabinet line-up dimensions

The drive consists of cubicles built into a cabinet line-up. The table below shows the width and weight of basic drive types without options (for example, the cooling unit is not included). The table is followed by selected dimension drawing examples.

The dimensions are in millimeters (for inches, divide by 25.4).

The data given is preliminary. ABB reserves the right to modify the design at any time without notice. Consult ABB for up-to-date, drive-specific information.


ACS880-07LC-...	Width	Weight	
	mm	kg	lbs
$U_N = 690$ V, 6-pulse connection			
0390A-7	1700	1480	3260
0430A-7	1700	1480	3260
0480A-7	1700	1480	3260
0530A-7	1700	1480	3260
0600A-7	1700	1480	3260
0670A-7	1700	1480	3260
0750A-7	1700	1480	3260
0850A-7	1700	1480	3260
1030A-7	1900	1610	3550
1170A-7	1900	1610	3550
1310A-7	1900	1760	3880
1470A-7	1900	1760	3880
1660A-7	1900	1760	3880
1940A-7	2100	1930	4250

188 Dimensions


ACS880-07LC-...	Width	Weight	
	mm	kg	lbs
2180A-7	2100	1930	4250
2470A-7	2500	2230	4920
2880A-7	2800	2490	5490
3260A-7	2800	2490	5490
3580A-7	3600	3410	7520
4050A-7	3600	3410	7520
4840A-7	4500	4210	9280
5650A-7	4800	4470	9850
6260A-7	5000	4640	10230
$U_N = 690$ V, 12-pulse connection			
0530A-7+A004	2300	2230	4920
0600A-7+A004	2300	2230	4920
0670A-7+A004	2300	2230	4920
0750A-7+A004	2300	2230	4920
0850A-7+A004	2300	2230	4920
1030A-7+A004	2500	2360	5200
1170A-7+A004	2500	2360	5200
1310A-7+A004	2500	2360	5200
1470A-7+A004	2500	2360	5200
1660A-7+A004	2500	2360	5200
1940A-7+A004	2700	2530	5580
2180A-7+A004	2700	2530	5580
2470A-7+A004	3100	2530	5580
2880A-7+A004	3400	3240	7140
3260A-7+A004	3400	3240	7140
3580A-7+A004	3600	3410	7520
4050A-7+A004	3600	3410	7520
4840A-7+A004	4200	4030	8880
5650A-7+A004	4800	4470	9850
6460A-7+A004	5000	4640	10230

■ Dimension drawing examples


ACS880-07LC-0850A-7




ACS880-07LC-1660A-7 (6-pulse)



ACS880-07LC-1660A-7+A004 (12-pulse)




ACS880-07LC-3260A-7




Cabinet height and depth

Non-marine, IP42, side view




Marine construction (option +C121), IP42, side view




Location and size of input terminals

- 600 mm, with main breaker, single-busbar, bottom cable entry




■ 600 mm, with main breaker, double-busbar, bottom cable entry




Location and size of output terminals

■ Units without common motor terminal cubicle


Inverter module cubicle with one R8i module, bottom cable exit




Inverter module cubicle with two R8i modules, bottom cable exit



Inverter module cubicle with three R8i modules, bottom cable exit



Brake chopper cubicle



15

The Safe torque off function

Contents of this chapter

This chapter describes the Safe torque off (STO) function of the drive and gives instructions for its use.

Description



WARNING!

In case of parallel-connected drives or dual-winding motors, the STO must be activated on each drive to remove the torque from the motor.

The Safe torque off function can be used, for example, as the final actuator device of safety circuits that stop the drive in case of danger (such as an emergency stop circuit). Another typical application is a prevention of unexpected start-up function that enables short-time maintenance operations like cleaning or work on non-electrical parts of the machinery without switching off the power supply to the drive.

When activated, the Safe torque off function disables the control voltage of the power semiconductors of the drive output stage (A, see the diagrams below), thus preventing the drive from generating the torque required to rotate the motor. If the motor is running when Safe torque off is activated, it coasts to a stop.

The Safe torque off function has a redundant architecture, that is, both channels must be used in the safety function implementation. The safety data given in this manual is calculated for redundant use, and does not apply if both channels are not used.

The Safe torque off function complies with these standards:

Standard	Name
IEC 60204-1:2016 EN 60204-1:2018	<i>Safety of machinery – Electrical equipment of machines – Part 1: General requirements</i>

Standard	Name
IEC 61000-6-7:2014	<i>Electromagnetic compatibility (EMC) – Part 6-7: Generic standards – Immunity requirements for equipment intended to perform functions in a safety-related system (functional safety) in industrial locations</i>
IEC 61326-3-1:2017	<i>Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications</i>
IEC 61508-1:2010	<i>Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 1: General requirements</i>
IEC 61508-2:2010	<i>Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 2: Requirements for electrical/electronic/programmable electronic safety-related systems</i>
IEC 61511-1:2016	<i>Functional safety – Safety instrumented systems for the process industry sector</i>
IEC 61800-5-2:2016 EN 61800-5-2:2007	<i>Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional</i>
IEC 62061:2005 + A1:2012 + A2:2015 EN 62061:2005 + AC:2010 + A1:2013 + A2:2015	<i>Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems</i>
EN ISO 13849-1:2015	<i>Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design</i>
EN ISO 13849-2:2012	<i>Safety of machinery – Safety-related parts of control systems – Part 2: Validation</i>

The function also corresponds to Prevention of unexpected start-up as specified by EN ISO 14118:2018 (ISO 14118:2017), and Uncontrolled stop (stop category 0) as specified in EN/IEC 60204-1.

■ **Compliance with the European Machinery Directive**

See the technical data.

The Declaration of conformity is shown at the end of this chapter.

Wiring

For the electrical specifications of the STO connection, see the technical data of the control unit.

■ Activation switch

In the wiring diagrams, the activation switch has the designation [K]. This represents a component such as a manually operated switch, an emergency stop push button switch, or the contacts of a safety relay or safety PLC.

- In case a manually operated activation switch is used, the switch must be of a type that can be locked out to the open position.
- The contacts of the switch or relay must open/close within 200 ms of each other.
- An FSO-xx safety functions module or an FPTC-0x thermistor protection module can also be used. For more information, see the module documentation.

■ Cable types and lengths

- Double-shielded twisted-pair cable is recommended.
- Maximum cable lengths:
 - 300 m (1000 ft) between activation switch [K] and drive control unit
 - 60 m (200 ft) between multiple drives
 - 60 m (200 ft) between external power supply and first control unit
 - 30 m (100 ft) between BCU control unit and last inverter module in the chain.

Note: A short-circuit in the wiring between the switch and an STO terminal causes a dangerous fault. Therefore, it is recommended to use a safety relay (including wiring diagnostics) or a wiring method (shield grounding, channel separation) which reduces or eliminates the risk caused by the short-circuit.


Note: The voltage at the STO input terminals of the control unit (or frame R8i inverter module) must be at least 17 V DC to be interpreted as “1”.

The pulse tolerance of the input channels is 1 ms.


■ Grounding of protective shields

- Ground the shield in the cabling between the activation switch and the control unit at the control unit only.
 - Ground the shield in the cabling between two control units at one control unit only.
 - Do not ground the shield in the cabling between BCU and R8i module, or between R8i modules.
-

■ Dual-channel connection with internal power supply



■ Single-channel connection of activation switch




Note:

- Both STO inputs (IN1, IN2) must be connected to the activation switch. Otherwise, no SIL/PL classification is given.
- Pay special attention to avoiding any potential failure modes for the wiring. For example, use shielded cable. For measures for fault exclusion of wiring, see eg. EN ISO 13849-2:2012, table D.4.


1	Drive
2	Control unit
K	Activation switch

■ Multiple drives

Internal power supply



External power supply



1	Drive
2	Control unit
K	Activation switch
* Terminal designation may vary depending on drive type	

Operation principle

1. The Safe torque off activates (the activation switch is opened, or safety relay contacts open).
2. The STO inputs of the drive control unit de-energize.
3. The control unit cuts off the control voltage from the output IGBTs.
4. The control program generates an indication as defined by parameter 31.22 (see the firmware manual of the drive).

The parameter selects which indications are given when one or both STO signals are switched off or lost. The indications also depend on whether the drive is running or stopped when this occurs.

Note: This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset.

Note: The loss of only one STO signal always generates a fault as it is interpreted as a malfunction of STO hardware or wiring.

5. The motor coasts to a stop (if running). The drive cannot restart while the activation switch or safety relay contacts are open. After the contacts close, a reset may be needed (depending on the setting of parameter 31.22). A new start command is required to start the drive.
-

Start-up including acceptance test

To ensure the safe operation of a safety function, validation is required. The final assembler of the machine must validate the function by performing an acceptance test. The acceptance test must be performed

- at initial start-up of the safety function
- after any changes related to the safety function (circuit boards, wiring, components, settings, etc.)
- after any maintenance work related to the safety function.

■ Competence

The acceptance test of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

■ Acceptance test reports


Signed acceptance test reports must be stored in the logbook of the machine. The report shall include documentation of start-up activities and test results, references to failure reports and resolution of failures. Any new acceptance tests performed due to changes or maintenance shall be logged into the logbook.

■ Acceptance test procedure

After wiring the Safe torque off function, validate its operation as follows.

Note: If the drive is equipped with safety option +L536, +L537, +Q950, +Q951, +Q952, +Q957, +Q963, +Q964, +Q978 or +Q979, do the procedure shown in the documentation of the option.

Note: All inverter modules of the drive must be powered and connected to the STO circuit during the acceptance test.

Action	<input checked="" type="checkbox"/>
 WARNING! Obey the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
Make sure that the drive can be run and stopped freely during start-up.	<input type="checkbox"/>
Stop the drive (if running), switch the input power off and isolate the drive from the power line using a disconnecter.	<input type="checkbox"/>
Check the STO circuit connections against the wiring diagram.	<input type="checkbox"/>
Close the disconnecter and switch the power on.	<input type="checkbox"/>
Test the operation of the STO function when the motor is stopped. <ul style="list-style-type: none"> • Give a stop command for the drive (if running) and wait until the motor shaft is at a standstill. Make sure that the drive operates as follows: <ul style="list-style-type: none"> • Open the STO circuit. The drive generates an indication if one is defined for the 'stopped' state in parameter 31.22 (see the firmware manual). • Give a start command to verify that the STO function blocks the drive's operation. The drive generates a warning. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>

210 The Safe torque off function

Action	<input checked="" type="checkbox"/>
<p>Test the operation of the STO function when the motor is running.</p> <ul style="list-style-type: none"> • Start the drive and make sure the motor is running. • Open the STO circuit. The motor should stop. The drive generates an indication if one is defined for the 'running' state in parameter 31.22 (see the firmware manual). • Reset any active faults and try to start the drive. • Make sure that the motor stays at a standstill and the drive operates as described above in testing the operation when the motor is stopped. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the failure detection of the drive. The motor can be stopped or running.</p> <ul style="list-style-type: none"> • Open the 1st channel of the STO circuit. If the motor was running, it should coast to a stop. The drive generates a <i>FA81 Safe Torque Off 1 loss</i> fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the drive's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. • Open the 2nd channel of the STO circuit. If the motor was running, it should coast to a stop. The drive generates a <i>FA82 Safe Torque Off 2 loss</i> fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the drive's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
<p>Document and sign the acceptance test report which verifies that the safety function is safe and accepted for operation.</p>	<input type="checkbox"/>

Use

1. Open the activation switch, or activate the safety functionality that is wired to the STO connection.
2. The STO inputs on the drive control unit de-energize, and the control unit cuts off the control voltage from the output IGBTs.
3. The control program generates an indication as defined by parameter 31.22 (see the firmware manual of the drive).
4. The motor coasts to a stop (if running). The drive will not restart while the activation switch or safety relay contacts are open.
5. Deactivate the STO by closing the activation switch, or resetting the safety functionality that is wired to the STO connection.
6. Reset any faults before restarting.



WARNING!

The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the drive. Therefore maintenance work on electrical parts of the drive or the motor can only be carried out after isolating the drive from the supply and all other voltage sources.



WARNING!

The Safe torque off functionality is only achieved through the XSTO connector of the inverter control unit (A41). True Safe torque off functionality is not achieved through the XSTO connectors of other control units (such as the supply control unit or the brake control unit).

The Safe torque off function is supported by any ACS880 inverter or drive control program. It is not supported by supply, DC/DC converter or brake firmware.



WARNING!

(With permanent magnet or synchronous reluctance [SynRM] motors only)

In case of a multiple IGBT power semiconductor failure, the drive can produce an alignment torque which maximally rotates the motor shaft by $180/p$ degrees (with permanent magnet motors) or $180/2p$ degrees (with synchronous reluctance [SynRM] motors) regardless of the activation of the Safe torque off function. p denotes the number of pole pairs.

Notes:

- If a running drive is stopped by using the Safe torque off function, the drive will cut off the motor supply voltage and the motor will coast to a stop. If this causes danger or is not otherwise acceptable, stop the drive and machinery using the appropriate stop mode before activating the Safe torque off function.
 - The Safe torque off function overrides all other functions of the drive.
 - The Safe torque off function is ineffective against deliberate sabotage or misuse.
 - The Safe torque off function has been designed to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. The assembler of the machine must inform the final user about the residual risks.
-

Maintenance

After the operation of the circuit is validated at start-up, the STO function shall be maintained by periodic proof testing. In high demand mode of operation, the maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is 5 or 2 years; see section [Safety data \(page 214\)](#). It is assumed that all dangerous failures of the STO circuit are detected by the proof test. To perform the proof test, do the [Acceptance test procedure \(page 209\)](#).

Note: See also the Recommendation of Use CNB/M/11.050 (published by the European co-ordination of Notified Bodies) concerning dual-channel safety-related systems with electromechanical outputs:

- When the safety integrity requirement for the safety function is SIL 3 or PL e (cat. 3 or 4), the proof test for the function must be performed at least every month.
- When the safety integrity requirement for the safety function is SIL 2 (HFT = 1) or PL d (cat. 3), the proof test for the function must be performed at least every 12 months.

The STO function of the drive does not contain any electromechanical components.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance procedures are carried out on the machinery.

Include the Safe torque off operation test described above in the routine maintenance program of the machinery that the drive runs.

If any wiring or component change is needed after start up, or the parameters are restored, do the test given in section [Acceptance test procedure \(page 209\)](#).

Use only spare parts approved by ABB.

Record all maintenance and proof test activities in the machine logbook.

■ Competence

The maintenance and proof test activities of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

Fault tracing

The indications given during the normal operation of the Safe torque off function are selected by drive control program parameter 31.22.

The diagnostics of the Safe torque off function cross-compare the status of the two STO channels. In case the channels are not in the same state, a fault reaction function is performed and the drive trips on an "STO hardware failure" fault. An attempt to use the STO in a non-redundant manner, for example activating only one channel, will trigger the same reaction.

See the firmware manual of the drive control program for the indications generated by the drive, and for details on directing fault and warning indications to an output on the control unit for external diagnostics.

Any failures of the Safe torque off function must be reported to ABB.

Safety data

The safety data for the Safe torque off function is given below.

Note: The safety data is calculated for redundant use, and does not apply if both STO channels are not used.

Frame size	SIL/ SILCL	PL	SFF (%)	PFH ($T_1 = 20$ a) (1/h)	PFD _{avg} ($T_1 = 2$ a)	PFD _{avg} ($T_1 = 5$ a)	MTTF _D (a)	DC (%)	Cat.	SC	HFT	CCF	T _M (a)
R8i	3	e	>99	5.0E-11	4.5E-07	1.1E-06	23970	≥90	3	3	1	80	20
2×R8i	3	e	>99	6.2E-11	5.5E-07	1.3E-06	16330	≥90	3	3	1	80	20
3×R8i	3	e	>99	7.3E-11	6.5E-07	1.6E-06	12390	≥90	3	3	1	80	20
4×R8i	3	e	>99	8.4E-11	7.6E-07	1.9E-06	9980	≥90	3	3	1	80	20
5×R8i	3	e	>99	9.5E-11	8.6E-07	2.1E-06	8360	≥90	3	3	1	80	20
6×R8i	3	e	>99	1.1E-10	9.6E-07	2.4E-06	7190	≥90	3	3	1	80	20
7×R8i	3	e	>99	1.2E-10	1.1E-06	2.6E-06	6310	≥90	3	3	1	80	20
8×R8i	3	e	>99	1.3E-10	1.2E-06	2.8E-06	5620	≥90	3	3	1	80	20

3AXD1000078136 F

- The following temperature profile is used in safety value calculations:
 - 670 on/off cycles per year with $\Delta T = 71.66$ °C
 - 1340 on/off cycles per year with $\Delta T = 61.66$ °C
 - 30 on/off cycles per year with $\Delta T = 10.0$ °C
 - 32 °C board temperature at 2.0% of time
 - 60 °C board temperature at 1.5% of time
 - 85 °C board temperature at 2.3% of time.
- The STO is a type B safety component as defined in IEC 61508-2.
- Relevant failure modes:
 - The STO trips spuriously (safe failure)
 - The STO does not activate when requested
 - A fault exclusion on the failure mode “short circuit on printed circuit board” has been made (EN 13849-2, table D.5). The analysis is based on an assumption that one failure occurs at one time. No accumulated failures have been analyzed.
- STO response times:
 - STO reaction time (shortest detectable break): 1 ms
 - STO response time: 2 ms (typical), 25 ms (maximum)
 - Fault detection time: Channels in different states for longer than 200 ms
 - Fault reaction time: Fault detection time + 10 ms
- Indication delays:
 - STO fault indication (parameter 31.22) delay: < 500 ms
 - STO warning indication (parameter 31.22) delay: < 1000 ms

■ Abbreviations

Abbr.	Reference	Description
Cat.	EN ISO 13849-1	Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4.
CCF	EN ISO 13849-1	Common cause failure (%)
DC	EN ISO 13849-1	Diagnostic coverage
HFT	IEC 61508	Hardware fault tolerance
MTTF _D	EN ISO 13849-1	Mean time to dangerous failure: (Total number of life units) / (Number of dangerous, undetected failures) during a particular measurement interval under stated conditions
PFD _{avg}	IEC 61508	Average probability of dangerous failure on demand, that is, mean unavailability of a safety-related system to perform the specified safety function when a demand occurs
PFH	IEC 61508	Average frequency of dangerous failures per hour, that is, average frequency of a dangerous failure of a safety related system to perform the specified safety function over a given period of time
PL	EN ISO 13849-1	Performance level. Levels a...e correspond to SIL
SC	IEC 61508	Systematic capability
SFF	IEC 61508	Safe failure fraction (%)
SIL	IEC 61508	Safety integrity level (1...3)
SILCL	IEC/EN 62061	Maximum SIL (level 1...3) that can be claimed for a safety function or subsystem
STO	IEC/EN 61800-5-2	Safe torque off
T ₁	IEC 61508-6	Proof test interval. T ₁ is a parameter used to define the probabilistic failure rate (PFH or PFD) for the safety function or subsystem. Performing a proof test at a maximum interval of T ₁ is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. See also section Maintenance.
T _M	EN ISO 13849-1	Mission time: the period of time covering the intended use of the safety function/device. After the mission time elapses, the safety device must be replaced. Note that any T _M values given cannot be regarded as a guarantee or warranty.

■ TÜV certificate

The TÜV certificate is available on the Internet at www.abb.com/drives/documents.

■ Declaration of conformity



EU Declaration of Conformity

Machinery Directive 2006/42/EC

We

Manufacturer: ABB Oy

Address: Hiomotie 13, 00380 Helsinki, Finland.

Phone: +358 10 22 11

declare under our sole responsibility that the following products:

Frequency converters and frequency converter components

ACS880-04, -14, -34 (frames nxR8i)

ACS880-04XT, -04FXT

ACS880-07, -17, -37

ACS880-104

ACS880 multidrives

ACS880-104LC (frames nxR8i)

ACS880-07CLC

ACS880-17LC, -37LC, -107LC (frames nxR8i)

ACS880 liquid-cooled multidrives

identified with serial numbers beginning with 1 or 8

with regard to the safety functions

Safe torque off

Safe motor temperature with FPTC-01 module (option code +L536)

Safe Stop 1 (SS1-t) with FSPS-21 module (+Q986)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Prevention of unexpected start-up, with FSO-12 module (option code +Q973)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Safe Speed monitor, Safe direction, Prevention of unexpected start-up, with FSO-21 and FSE-31 modules (option codes +Q972 and +L521)



ACS880-07, -17, -37, -07CLC and ACS880 multidrives: Prevention of unexpected start-up (option codes +Q950; +Q957), **Emergency stop** (option codes +Q951; +Q952; +Q963; +Q964; +Q978; +Q979), **Safely-limited speed** (option codes +Q965; Q966)

are in conformity with all the relevant safety component requirements of EU Machinery Directive 2006/42/EC, when the listed safety functions are used for safety component functionality.

The following harmonized standards have been applied:

EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional
EN 62061:2005 + AC:2010 + A1:2013 + A2:2015	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems. Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of the control systems. Part 2: Validation
EN 60204-1:2006 + A1:2009 + AC:2010	Safety of machinery – Electrical equipment of machines – Part 1: General requirements

The following other standard has been applied:

IEC 61508:2010, parts 1-2	Functional safety of electrical / electronic / programmable electronic safety-related systems
IEC 61800-5-2:2016	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional


The products referred in this Declaration of conformity fulfil the relevant provisions of other European Union Directives which are notified in Single EU Declaration of conformity 3AXD10000497305.

Person authorized to compile the technical file:


Name and address: Vesa Tiihonen, Hiomotie 13, 00380 Helsinki, Finland

Helsinki, 16 Dec 2019

Signed for and on behalf of:


Peter Lindgren
Vice President, ABB Oy


Vesa Tiihonen
Manager, Product Engineering and Quality



16

Resistor braking

The ACS880-07LC employs ACS880-607LC 1-phase brake units. For more information, refer to *ACS880-607LC 1-phase brake units hardware manual* (3AXD50000481491 [English]).

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.



www.abb.com/drives



3AXD50000569786A