
ABB MOTION CONTROL DRIVES

ACSM1 motion control program

Firmware manual



List of related manuals

Drive hardware manuals and guides

	Code (English)
ACSM1-04 (0.75 to 45 kW) Hardware manual	3AFE68797543
ACSM1-04 (55 to 110 kW) Hardware manual	3AFE68912130
ACSM1-04 drive modules (200 to 355 kW, 250 to 450 hp) Hardware manual	3AUA0000117209

Drive firmware manuals and guides

ACSM1 speed and torque control program Firmware Manual	3AFE68848261
ACSM1 motion control program Firmware manual	3AFE68848270

Drive PC tools manuals

DriveStudio User Manual	3AFE68749026
DriveSPC User Manual	3AFE68836590

Application guides

Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives	3AFE68929814
Functional Safety Solutions with ACSM1 Drives Application Guide	3AUA0000031517
ACSM1 System Engineering Manual	3AFE68978297

Option manuals

FIO-01 Digital I/O Extension User's Manual	3AFE68784921
FIO-11 Analog I/O Extension User's Manual	3AFE68784930
FEN-01 TTL Encoder Interface User's Manual	3AFE68784603
FEN-11 Absolute Encoder Interface User's Manual	3AFE68784841
FEN-21 Resolver Interface User's Manual	3AFE68784859
ACSM1 Control Panel User's Guide	3AUA0000020131

You can find manuals and other product documents in PDF format on the Internet. See section Document library on the Internet on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

The code below opens an online listing of the manuals applicable to the product:



[ACSM1 manuals](#)

Firmware manual

ACSM1 motion control program

Table of contents

Table of contents

Introduction to the manual

What this chapter contains	13
Compatibility	13
Safety instructions	13
Reader	13
Contents	14
Product and service inquiries	14
Product training	14
Providing feedback on ABB Drives manuals	14
Cybersecurity disclaimer	15

Start-up

What this chapter contains	17
How to start up the drive	17
How to control the drive through the I/O interface	29

Drive programming using PC tools

What this chapter contains	31
General	31
Programming via parameters	32
Application programming	33
Function blocks	33
User parameters	33
Application events	33
Program execution	34
Application program licensing and protection	34
Operation modes	35

Drive control and features

What this chapter contains	37
Local control vs. external control	37
Operating modes of the drive	38
Speed control mode	38
Torque control mode	38
Drive control chain for speed and torque control	39
Position control	40
Synchron control	40
Homing control	41

Profile velocity control	41
Drive control chain for positioning	42
Motor control features	43
Scalar motor control	43
Autophasing	44
Flux braking	46
Thermal motor protection	46
DC voltage control features	49
Overvoltage control	49
Undervoltage control	49
Voltage control and trip limits	49
Braking chopper	50
Low voltage mode	50
Speed control features	52
Jogging	52
Speed controller tuning	53
Motor feedback features	56
Motor encoder gear function	56
Mechanical brake control	57
Position/synchron control features	61
Position calculation	61
Position estimation	62
Load encoder gear function	63
Position profile generator	66
Dynamic position reference limiter	68
Position correction	70
Emergency stop	84
Miscellaneous features	85
Backup and restore of drive contents	85
Drive-to-drive link	86
Fan control logic	87

Default connections of the control unit

What this chapter contains	89
----------------------------	----

Parameters and firmware blocks

What this chapter contains	91
Types of parameters	91
Firmware blocks	92
Group 01 ACTUAL VALUES	93
ACTUAL VALUES	93
Group 02 I/O VALUES	96
Group 03 CONTROL VALUES	103
Group 04 POS CTRL VALUES	105
Group 06 DRIVE STATUS	107
Group 08 ALARMS & FAULTS	115
Group 09 SYSTEM INFO	120
Group 10 START/STOP	122

DRIVE LOGIC	122
Group 11 START/STOP MODE	128
START/STOP MODE	128
Group 12 DIGITAL IO	131
DIO1	131
DIO2	131
DIO3	131
RO	133
DI	133
Group 13 ANALOGUE INPUTS	135
AI1	135
AI2	136
Group 15 ANALOGUE OUTPUTS	139
AO1	139
AO2	140
Group 16 SYSTEM	142
Group 17 PANEL DISPLAY	145
Group 20 LIMITS	147
LIMITS	147
Group 22 SPEED FEEDBACK	150
SPEED FEEDBACK	151
Group 24 SPEED REF MOD	156
SPEED REF SEL	157
SPEED REF MOD	158
Group 25 SPEED REF RAMP	160
SPEED REF RAMP	161
Group 26 SPEED ERROR	164
SPEED ERROR	165
Group 28 SPEED CONTROL	169
SPEED CONTROL	170
Group 32 TORQUE REFERENCE	176
TORQ REF SEL	177
TORQ REF MOD	178
Group 33 SUPERVISION	180
SUPERVISION	180
Group 34 REFERENCE CTRL	184
REFERENCE CTRL	185
Group 35 MECH BRAKE CTRL	188
MECH BRAKE CTRL	188
Group 40 MOTOR CONTROL	191
MOTOR CONTROL	191
Group 45 MOT THERM PROT	194
MOT THERM PROT	194
Group 46 FAULT FUNCTIONS	198
FAULT FUNCTIONS	198
Group 47 VOLTAGE CTRL	203
VOLTAGE CTRL	203
Group 48 BRAKE CHOPPER	205
BRAKE CHOPPER	205
Group 50 FIELD BUS	207

FIELDBUS	207
Group 51 FBA SETTINGS	211
Group 52 FBA DATA IN	213
Group 53 FBA DATA OUT	214
Group 55 COMMUNICATION TOOL	215
Group 57 D2D COMMUNICATION	216
D2D COMMUNICATION	216
Group 60 POS FEEDBACK	220
POS FEEDBACK	221
Group 62 POS CORRECTION	225
HOMING	225
PRESET	227
CYCLIC CORRECTION	229
Group 65 PROFILE REFERENCE	236
PROFILE REF SEL	237
Group 66 PROFILE GENERATOR	244
PROFILE GENERATOR	245
Group 67 SYNC REF SEL	247
SYNC REF SEL	247
Group 68 SYNC REF MOD	250
SYNC REF MOD	250
Group 70 POS REF LIMIT	252
POS REF LIM	253
Group 71 POSITION CTRL	255
POS CONTROL	256
Group 90 ENC MODULE SEL	258
ENCODER	259
Group 91 ABSOL ENC CONF	263
ABSOL ENC CONF	263
Group 92 RESOLVER CONF	269
RESOLVER CONF	269
Group 93 PULSE ENC CONF	270
PULSE ENC CONF	270
Group 95 HW CONFIGURATION	274
Group 97 USER MOTOR PAR	275
Group 98 MOTOR CALC VALUES	278
Group 99 START-UP DATA	279

Parameter data

What this chapter contains	285
Terms	285
Fieldbus equivalent	286
Pointer parameter format in fieldbus communication	286
32-bit integer value pointers	286
32-bit integer bit pointers	287
Actual signals (Parameter groups 1...9)	288
Parameter groups 10...99	292

Fault tracing

What this chapter contains	307
Safety	307
Alarm and fault indications	307
How to reset	308
Fault history	308
Alarm messages generated by the drive	309
Fault messages generated by the drive	318

Standard function blocks

What this chapter contains	333
Terms	333
Alphabetical index	334
Arithmetic	335
ABS	335
ADD	335
DIV	335
EXPT	336
MOD	336
MOVE	337
MUL	337
MULDIV	337
SQRT	338
SUB	338
Bitstring	339
AND	339
NOT	339
OR	340
ROL	340
ROR	341
SHL	341
SHR	342
XOR	343
Bitwise	344
BGET	344
BITAND	344
BITOR	345
BSET	345
REG	346
SR-D	347
Communication	348
D2D_Conf	348
D2D_McastToken	349
D2D_SendMessage	349
DS_ReadLocal	351
DS_WriteLocal	352
Comparison	353
EQ	353

GE	353
GT	354
LE	354
LT	355
NE	355
Conversion	356
BOOL_TO_DINT	356
BOOL_TO_INT	357
DINT_TO_BOOL	358
DINT_TO_INT	359
DINT_TO_REALn	359
DINT_TO_REALn_SIMP	360
INT_TO_BOOL	361
INT_TO_DINT	362
REAL_TO_REAL24	362
REAL24_TO_REAL	363
REALn_TO_DINT	363
REALn_TO_DINT_SIMP	364
Counters	365
CTD	365
CTD_DINT	366
CTU	366
CTU_DINT	367
CTUD	368
CTUD_DINT	370
Edge & bistable	372
FTRIG	372
RS	372
RTRIG	373
SR	374
Extensions	375
FIO_01_slot1	375
FIO_01_slot2	376
FIO_11_AI_slot1	377
FIO_11_AI_slot2	379
FIO_11_AO_slot1	381
FIO_11_AO_slot2	382
FIO_11_DIO_slot1	384
FIO_11_DIO_slot2	385
Feedback & algorithms	386
CYCLET	386
DATA CONTAINER	386
FUNG-1V	387
INT	388
MOTPOT	389
PID	390
RAMP	392
REG-G	393
SOLUTION_FAULT	395
Filters	396

FILT1	396
Parameters	397
GetBitPtr	397
GetValPtr	397
PARRD	397
PARRDINTR	398
PARRDPTR	398
PARWR	399
Program structure	400
BOP	400
ELSE	400
ELSEIF	401
ENDIF	401
IF	402
Selection	403
LIMIT	403
MAX	403
MIN	403
MUX	404
SEL	404
Switch & Demux	405
DEMUX-I	405
DEMUX-MI	405
SWITCH	406
SWITCHC	407
Timers	408
MONO	408
TOF	409
TON	409
TP	410

Application program template

What this chapter contains	411
----------------------------------	-----

Appendix A – Fieldbus control

What this chapter contains	427
System overview	427
Setting up communication through a fieldbus adapter module	428
Setting the drive control parameters	430
Basics of the fieldbus adapter interface	431
Control Word and Status Word	431
Actual values	432
FBA communication profile	432
Fieldbus references	432
State diagram	433

Appendix B – Drive-to-drive link

What this chapter contains	435
General	435
Wiring	435
Datasets	436
Types of messaging	437
Master point-to-point messaging	438
Read remote messaging	438
Follower point-to-point messaging	439
Standard multicast messaging	439
Broadcast messaging	440
Chained multicast messaging	441
Examples of using standard function blocks in drive-to-drive communication	443
Example of master point-to-point messaging	443
Example of read remote messaging	444
Releasing tokens for follower-to-follower communication	444
Example of follower point-to-point messaging	445
Example of standard master-to-follower(s) multicast messaging	446
Example of broadcast messaging	446

Appendix C – Homing methods

What this chapter contains	447
----------------------------------	-----

Appendix D – Application examples

What this chapter contains	491
Basic motion control configuration	492
Example – Position system commissioning	494
Commissioning procedure	494
Example – Absolute linear positioning	495
Example – Relative linear positioning	496
Example – Synchronisation through drive-to-drive link	497
Example – Synchronisation through drive-to-drive link with synchron gear	499
Example – Cam synchronisation	501
Example – Homing	503

Appendix E – Control chain and drive logic diagrams

What this chapter contains	505
----------------------------------	-----

Introduction to the manual

What this chapter contains

The chapter includes a description of the contents of the manual. In addition it contains information about the compatibility, safety and intended audience.

Compatibility

The manual is compatible with ACSM1 motion control program version UMF12040 and later. See parameter [9.04 FIRMWARE VER](#) or PC tool (View - Properties).

Safety instructions

Follow all safety instructions delivered with the drive.

- Read the **complete safety instructions** before you install, commission, or use the drive. The complete safety instructions are given at the beginning of the *Hardware Manual*.
- Read the **software function specific warnings and notes** before changing the default settings of the function. For each function, the warnings and notes are given in this manual in the section describing the related user-adjustable parameters.

Reader

The reader of the manual is expected to know the standard electrical wiring practices, electronic components, and electrical schematic symbols.

Contents

The manual consists of the following chapters:

- *Start-up* instructs in setting up the control program and how to control the drive through the I/O interface.
- *Drive programming using PC tools* introduces programming via PC tool (DriveStudio and/or DriveSPC).
- *Drive control and features* describes the control locations and operation modes of the drive, and the features of the application program.
- *Default connections of the control unit* presents the default connections of the JCU Control Unit.
- *Parameters and firmware blocks* describes the drive parameters and firmware function blocks.
- *Parameter data* contains more information on the parameters of the drive.
- *Fault tracing* lists the warning and fault messages with the possible causes and remedies.
- *Standard function blocks*
- *Application program template*
- *Appendix A – Fieldbus control* describes the communication between the drive and a fieldbus.
- *Appendix B – Drive-to-drive link* describes the communication between drives connected together by the drive-to-drive link.
- *Appendix C – Homing methods* describes homing methods 1...35.
- *Appendix D – Application examples.*
- *Appendix E – Control chain and drive logic diagrams.*

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type code and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, go to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to new.abb.com/drives/manuals-feedback-form.

Cybersecurity disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

Start-up

What this chapter contains

This chapter describes the basic start-up procedure of the drive and instructs in how to control the drive through the I/O interface.

How to start up the drive

The drive can be operated:

- locally from PC tool or control panel
- externally via I/O connections or fieldbus interface.

The start-up procedure presented uses the DriveStudio PC tool program. Drive references and signals can be monitored with DriveStudio (Data Logger or Monitor Window). For instructions on how to use DriveStudio, see *DriveStudio User Manual* [3AFE68749026 (English)].






The start-up procedure includes actions which need to be performed only when the drive is powered up for the first time (eg, entering the motor data). After the first start-up, the drive can be powered up without using these start-up functions. The start-up procedure can be repeated later if start-up data needs to be changed.




In addition to the PC tool commissioning and drive power-up, the start-up procedure includes the following steps:

- entering the motor data and performing the motor identification run
- setting up the encoder/resolver communication
- checking the emergency stop and Safe Torque Off circuits
- setting up the voltage control
- setting the drive limits
- setting up the motor overtemperature protection
- tuning the speed controller
- setting up the fieldbus control.

If an alarm or a fault is generated during the start-up, see chapter [Fault tracing](#) for the possible causes and remedies. If problems continue, disconnect the main power and wait 5 minutes for the intermediate circuit capacitors to discharge and check the drive and motor connections.




Before you start, ensure you have the motor nameplate and encoder data (if needed) at your hand.

Safety	
	<p>The start-up may only be carried out by a qualified electrician.</p> <p>The safety instructions must be followed during the start-up procedure. See the safety instructions on the first pages of the appropriate hardware manual.</p>
<input type="checkbox"/>	<p>Check the installation. See the installation checklist in the appropriate hardware manual.</p>
<input type="checkbox"/>	<p>Check that the starting of the motor does not cause any danger.</p> <p>De-couple the driven machine if</p> <ul style="list-style-type: none"> - there is a risk of damage in case of an incorrect direction of rotation, or - a normal motor ID run (99.13 IDRUN MODE = (1) Normal) is required during the drive start-up, when the load torque is higher than 20% or the machinery is not able to withstand the nominal torque transient during the motor ID run.
PC tool	
<input type="checkbox"/>	<p>Install the DriveStudio PC tool onto the PC. Install also DriveSPC if block programming is needed. For instructions, see <i>DriveStudio User Manual</i> [3AFE68749026 (English)] and <i>DriveSPC User Manual</i> [3AFE68836590 (English)].</p>
<input type="checkbox"/>	<p>Connect the drive to the PC:</p> <p>Connect the other end of the communication cable (OPCA-02, code: 68239745) to the panel link of the drive. Connect the other end of the communication cable via USB adapter or directly to the PC serial port.</p>
Power up	
<input type="checkbox"/>	<p>Switch the power on.</p>
	<p>7-segment display:</p> 
<p>Note: The drive will indicate an alarm (2021 NO MOTOR DATA) until the motor data is entered later in this procedure. This is completely normal.</p>	
<input type="checkbox"/>	<p>Start the DriveStudio program by clicking the DriveStudio icon on the PC desktop.</p>
	
<input type="checkbox"/>	<p>Check whether an application program exists using the DriveStudio tool. If it does, the rows SOLUTION PROGRAM (SP) and SP EMPTY TEMPLATE are displayed in drive properties (View - Properties, Software category).</p> <p>If an application program already exists, NOTE that some of the drive functions may have been disabled. ENSURE that the application program is suitable for your drive application.</p>
	
<input type="checkbox"/>	<p>Switch to local control to ensure that external control is disabled by clicking the Take/Release button of the DriveStudio tool control panel.</p>
	





Motor data entering		
<input type="checkbox"/>	Open the parameter and signal list by selecting the Parameter Browser of the appropriate drive.	
<input type="checkbox"/>	Select the language. Parameters are set as follows: Select the parameter group (in this case 99 START-UP DATA) by double-clicking it. Select the appropriate parameter by double-clicking it and set the new value.	99.01 LANGUAGE
<input type="checkbox"/>	Select the motor type: asynchronous or permanent magnet motor.	99.04 MOTOR TYPE
<input type="checkbox"/>	Select the motor control mode. DTC is suitable for most cases. For information on scalar control, see parameter 99.05 MOTOR CTRL MODE.	99.05 MOTOR CTRL MODE
<input type="checkbox"/>	<p>Enter the motor data from the motor nameplate.</p> <p>Asynchronous motor nameplate example:</p>  <p>Permanent magnet motor nameplate example:</p>  <p>With DTC control (99.05 MOTOR CTRL MODE = (0) DTC) at least parameters 99.06...99.10 must be set. Better control accuracy can be achieved by setting also parameters 99.11...99.12.</p>	<p>Note: Set the motor data to exactly the same value as on the motor nameplate. For example, if the motor nominal speed is 1470 rpm on the nameplate, setting the value of parameter 99.09 MOT NOM SPEED to 1500 rpm results in wrong operation of the drive.</p>


<p>- motor nominal current Allowed range: approximately $1/6 \cdot I_{2n} \dots 2 \cdot I_{2n}$ of the drive ($0 \dots 2 \cdot I_{2nd}$ if parameter 99.05 MOTOR CTRL MODE = (1) Scalar). With multimotor drives, see section Multimotor drives on page 21.</p> <p>- motor nominal voltage Allowed range: $1/6 \cdot U_N \dots 2 \cdot U_N$ of the drive. (U_N refers to the highest voltage in each of the nominal voltage range, ie, 480 V AC for ACSM1-04). With permanent magnet motors: The nominal voltage is the BackEMF voltage (at motor nominal speed). If the voltage is given as voltage per rpm, eg, 60 V per 1000 rpm, the voltage for 3000 rpm nominal speed is $3 \times 60 \text{ V} = 180 \text{ V}$. Note that the nominal voltage is not equal to the equivalent DC motor voltage (E.D.C.M.) value given by some motor manufactures. The nominal voltage can be calculated by dividing the E.D.C.M. voltage by 1.7 (= square root of 3).</p> <p>- motor nominal frequency Range: 5...500 Hz. With multimotor drives, see section Multimotor drives on page 21.</p> <p>With permanent magnet motor: If the frequency is not given on the motor nameplate, it has to be calculated with the following formula: $f = n \times p / 60$ where p = number of pole pairs, n = motor nominal speed.</p> <p>- motor nominal speed Range: 0...10000 rpm. With multimotor drives, see section Multimotor drives on page 21.</p> <p>- motor nominal power Range: 0...10000 kW. With multimotor drives, see section Multimotor drives on page 21.</p> <p>- motor nominal $\cos\varphi$ (not applicable for permanent magnet motors). This value can be set for better DTC control accuracy. If value is not given by the motor manufacturer, use value 0 (i.e. default value). Range: 0...1.</p> <p>- motor nominal shaft torque. This value can be set for better DTC control accuracy. If value is not given by the motor manufacturer, use value 0 (i.e. default value). Range: 0...2147483.647 Nm.</p>	<p>99.06 MOT NOM CURRENT</p> <p>99.07 MOT NOM VOLTAGE</p> <p>99.08 MOT NOM FREQ</p> <p>99.09 MOT NOM SPEED</p> <p>99.10 MOT NOM POWER</p> <p>99.11 MOT NOM COSFII</p> <p>99.12 MOT NOM TORQUE</p>
<p><input type="checkbox"/> After the motor parameters have been set, alarm ID-RUN is generated to inform that the motor ID run needs to be performed.</p>	<p>Alarm: ID-RUN</p>

Multimotor drives		
ie, more than one motor is connected to one drive.		
<input type="checkbox"/>	<p>Check that the motors have the same relative slip (only for asynchronous motors), nominal voltage and number of poles. If the manufacturer motor data is insufficient, use the following formulas to calculate the slip and the number of poles:</p> $p = \text{Int}\left(\frac{f_N \cdot 60}{n_N}\right)$ $n_s = \frac{f_N \cdot 60}{p}$ $s = \frac{n_s - n_N}{n_s} \cdot 100\%$ <p>where p = number of pole pairs (= motor pole number / 2) f_N = motor nominal frequency [Hz] n_N = motor nominal speed [rpm] s = motor slip [%] n_s = motor synchronous speed [rpm].</p>	
<input type="checkbox"/>	Set the sum of the motor nominal currents.	99.06 MOT NOM CURRENT
<input type="checkbox"/>	Set the nominal motor frequencies. Frequencies must be the same.	99.08 MOT NOM FREQ
<input type="checkbox"/>	Set the sum of the motor nominal powers. If the motor powers are close to each other or the same but the nominal speeds vary slightly, parameter 99.09 MOT NOM SPEED can be set to an average value of the motor speeds.	99.10 MOT NOM POWER 99.09 MOT NOM SPEED
External control unit power supply		
<input type="checkbox"/>	If the control unit of the drive is powered from an external power supply (as specified in <i>Hardware Manual</i>), set parameter 95.01 CTRL UNIT SUPPLY to EXTERNAL 24V.	95.01 CTRL UNIT SUPPLY
External mains choke		
<input type="checkbox"/>	If the drive is equipped with an external choke (specified in <i>Hardware Manual</i>), set parameter 95.02 EXTERNAL CHOKE to YES.	95.02 EXTERNAL CHOKE
Motor overtemperature protection (1)		
<input type="checkbox"/>	Select how the drive reacts when motor overtemperature is detected.	45.01 MOT TEMP PROT
<input type="checkbox"/>	Select the motor temperature protection: motor thermal model or motor temperature measurement. For motor temperature measurement connections, see section <i>Temperature sensors</i> on page 47.	45.02 MOT TEMP SOURCE

ID RUN (motor identification run)		
	<p>WARNING! With Normal or Reduced ID run the motor will run at up to approximately 50...100% of the nominal speed during the motor ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE MOTOR ID RUN!</p>	
<p>Note: Ensure that possible Safe Torque Off and emergency stop circuits are closed during the motor ID run.</p>		
<input type="checkbox"/>	<p>Check the direction of rotation of the motor before starting the motor ID run. During the run (Normal or Reduced), the motor will rotate in the forward direction.</p>	<p>When drive output phases U2, V2 and W2 are connected to the corresponding motor terminals:</p> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <div style="margin-left: 10px;"> <p>forward direction</p> </div> </div> <div style="display: flex; align-items: center;">  <div style="margin-left: 10px;"> <p>reverse direction</p> </div> </div> </div>

<input type="checkbox"/>	<p>Select the motor identification method by parameter 99.13 IDRUN MODE. During the motor ID run, the drive will identify the characteristics of the motor for optimum motor control. The motor ID run is performed at the next start of the drive.</p> <p>Note: The motor shaft must NOT be locked and the load torque must be < 20% during Normal ID run. With permanent magnet motor this restriction applies also when Standstill ID run is selected.</p> <p>Note: Mechanical brake (if present) is not opened during the motor ID run.</p> <p>Note: The motor ID run cannot be performed if par. 99.05 MOTOR CTRL MODE = (1) Scalar.</p> <p>NORMAL ID run should be selected whenever possible.</p> <p>Note: The driven machinery must be de-coupled from the motor with Normal ID run if</p> <ul style="list-style-type: none"> • the load torque is higher than 20%, or • the machinery is not able to withstand the nominal torque transient during the motor ID run. <p>The REDUCED ID run should be selected instead of the Normal ID run if the mechanical losses are higher than 20%, ie, the motor cannot be de-coupled from the driven equipment, or full flux is required to keep the motor brake open (conical motor).</p> <p>The STANDSTILL ID run should be selected only if the Normal or Reduced ID run is not possible due to the restrictions caused by the connected mechanics (eg, with lift or crane applications).</p> <p>AUTOPHASING can only be selected after the Normal/Reduced/Standstill ID run has been performed once. Autophasing is used when an absolute encoder or a resolver (or encoder with commutation signals) has been added/changed to a permanent magnet motor, but there is no need to perform the Normal/Reduced/Standstill ID run again. See parameter 11.07 AUTOPHASING MODE on page 130 for information on autophasing modes, and section Autophasing on page 44.</p>	99.13 IDRUN MODE 11.07 AUTOPHASING MODE
<input type="checkbox"/>	<p>Check the drive limits. The following must apply to all <u>drive ID run</u> methods:</p> <ul style="list-style-type: none"> • 20.05 MAXIMUM CURRENT > 99.06 MOT NOM CURRENT <p>In addition, the following must apply for Reduced and Normal ID run:</p> <ul style="list-style-type: none"> • 20.01 MAXIMUM SPEED > 50% of synchronous speed of the motor • 20.02 MINIMUM SPEED ≤ 0 • supply voltage $\geq 66\%$ of 99.07 MOT NOM VOLTAGE • 20.06 MAXIMUM TORQUE > 100% (asynchronous machines with Normal ID run only) • 20.06 MAXIMUM TORQUE $\geq 30\%$ (asynchronous machines with Reduced ID run, and permanent magnet motors). <p>When the motor ID run has been successfully completed, set the limit values as required by the application.</p>	

<input type="checkbox"/>	<p>Start the motor to activate the motor ID run. Note: RUN ENABLE must be active.</p> <p>Motor ID run is indicated by alarm ID-RUN and by a rotating display on the 7-segment display.</p>	 <p>10.09 RUN ENABLE</p> <p>Alarm: ID-RUN</p> <p>7-segment display:  rotating display ↷</p>
<input type="checkbox"/>	<p>If the motor ID run is not successfully completed, fault ID-RUN FAULT is generated.</p>	<p>Fault ID-RUN FAULT</p>
<p>Speed measurement with encoder/resolver</p>		
<p>An encoder/resolver feedback can be used for more accurate motor control. Follow these instructions when encoder/resolver interface module FEN-xx is installed in drive option Slot 1 or 2. Note: Two encoder interface modules of the same type are not allowed.</p>		
<input type="checkbox"/>	<p>Select the used encoder/resolver. For more information, see parameter group 90 on page 259.</p>	<p>90.01 ENCODER 1 SEL / 90.02 ENCODER 2 SEL</p>
<input type="checkbox"/>	<p>Set other necessary encoder/resolver parameters:</p> <ul style="list-style-type: none"> - Absolute encoder parameters (group 91, page 263) - Resolver parameters (group 92, page 269). - Pulse encoder parameters (group 93, page 270). 	<p>91.01...91.31 / 92.01...92.03 / 93.01...93.22</p>
<input type="checkbox"/>	<p>Set parameter 90.10 ENC PAR REFRESH to (1) Configure so that the new parameter settings take effect.</p>	<p>90.10 ENC PAR REFRESH</p>
<p>Checking the encoder/resolver connection</p>		
<p>Follow these instructions when encoder/resolver interface module FEN-xx is installed in drive option Slot 1 or 2. Note: Two encoder interface modules of the same type are not allowed.</p>		
<input type="checkbox"/>	<p>Set parameter 22.01 SPEED FB SEL to (0) Estimated.</p>	<p>22.01 SPEED FB SEL</p>
<input type="checkbox"/>	<p>Enter a small speed reference value (for example 3% of the nominal motor speed).</p>	
<input type="checkbox"/>	<p>Start the motor.</p>	
<input type="checkbox"/>	<p>Check that the estimated (1.14 SPEED ESTIMATED) and actual speed (1.08 ENCODER 1 SPEED / 1.10 ENCODER 2 SPEED) are equal. If the values differ, check the encoder/resolver parameter settings.</p> <p>Hint: If the actual speed (with absolute or pulse encoder) differs from the reference value by a factor of 2, check the pulse number setting (91.01 SINE COSINE NR / 93.01 ENC1 PULSE NR / 93.11 ENC2 PULSE NR).</p>	<p>1.14 SPEED ESTIMATED</p> <p>1.08 ENCODER 1 SPEED / 1.10 ENCODER 2 SPEED</p>

<input type="checkbox"/>	<p>If the direction of rotation is selected as forward, check that the actual speed (1.08 ENCODER 1 SPEED / 1.10 ENCODER 2 SPEED) is positive:</p> <ul style="list-style-type: none"> • If the actual direction of rotation is forward and the actual speed negative, the phasing of the pulse encoder wires is reversed. • If the actual direction of rotation is reverse and the actual speed negative, the motor cables are incorrectly connected. <p>Changing the connection: Disconnect the main power, and wait for 5 minutes for the intermediate circuit capacitors to discharge. Do the necessary changes. Switch the power on and start the motor again. Check that the estimated and actual speed values are correct.</p> <ul style="list-style-type: none"> • If the direction of rotation is selected as reverse, the actual speed must be negative. <p>Note: Resolver autotuning routines should always be performed after resolver cable connection has been modified. Autotuning routines can be activated by setting parameter 92.02 EXC SIGNAL AMPL or 92.03 EXC SIGNAL FREQ, and then setting parameter 90.10 ENC PAR REFRESH to (1) Configure. If the resolver is used with a permanent magnet motor, an Autophasing ID run should be performed as well.</p>	1.08 ENCODER 1 SPEED / 1.10 ENCODER 2 SPEED
<input type="checkbox"/>	Stop the motor.	
<input type="checkbox"/>	<p>Set parameter 22.01 SPEED FB SEL to (1) Enc1 speed or (2) Enc2 speed.</p> <p>If the speed feedback cannot be used in motor control: In special applications parameter 40.06 FORCE OPEN LOOP must be set to TRUE.</p>	22.01 SPEED FB SEL
<input type="checkbox"/>	<p>Note: Speed filtering needs to be adjusted especially when the encoder pulse number is small. See section <i>Speed filtering</i> on page 27.</p>	
Emergency stop circuit		
<input type="checkbox"/>	<p>If there is an emergency stop circuit in use, check that the circuit functions (emergency stop signal is connected to the digital input which is selected as the source for the emergency stop activation).</p>	10.10 EM STOP OFF3 or 10.11 EM STOP OFF1 (emergency stop control through fieldbus 2.12 FBA MAIN CW bits 2...4)


Safe Torque Off		
<p>The Safe Torque Off function disables the control voltage of the power semiconductors of the drive output stage, thus preventing the inverter from generating the voltage required to rotate the motor. For Safe Torque Off wiring, see the appropriate hardware manual and <i>Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives</i> (3AFE68929814 [English]).</p>		
<input type="checkbox"/>	If there is a Safe Torque Off circuit in use, check that the circuit functions.	
<input type="checkbox"/>	Selects how the drive reacts when the Safe Torque Off function is active (i.e. when the control voltage of the power semiconductors of the drive output stage is disabled).	46.07 STO DIAGNOSTIC
Voltage control		
<p>If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit.</p> <p>To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached.</p> <p>When the overvoltage controller is limiting the generating torque, quick deceleration of the motor is not possible. Thus electrical braking (braking chopper and braking resistor) is needed in some applications to allow the drive to dissipate regenerative energy. The chopper connects the braking resistor to the intermediate circuit of the drive whenever the DC voltage exceeds the maximum limit.</p>		
<input type="checkbox"/>	Check that the overvoltage and undervoltage controllers are active.	47.01 OVERVOLTAGE CTRL 47.02 UNDERVOLT CTRL
<input type="checkbox"/>	<p>If the application requires a braking resistor (the drive has a built-in braking chopper):</p> <ul style="list-style-type: none"> • Set the braking chopper and resistor settings. • Check that the connection functions. <p>For more information on the braking resistor connection, see the appropriate hardware manual.</p>	48.01...48.07 47.01 OVERVOLTAGE CTRL
Start function		
<input type="checkbox"/>	<p>Select the start function.</p> <p>Setting 11.01 START MODE to (2) Automatic selects a general-purpose start function. This setting also makes flying start (starting to a rotating motor) possible.</p> <p>The highest possible starting torque is achieved when 11.01 START MODE is set to (0) Fast (automatic optimised DC magnetising) or (1) Const time (constant DC magnetising with user-defined magnetising time).</p> <p>Note: When 11.01 START MODE setting is (0) Fast or (1) Const time, flying start (start to a rotating motor) is not possible.</p>	11.01 START MODE

Limits		
<input type="checkbox"/>	Set the operation limits according to the process requirements. Note: If load torque is suddenly lost when the drive is operating in torque control mode, the drive will rush to the defined negative or positive maximum speed. For safe operation, ensure the set limits are suitable for your application.	20.01...20.07
Motor overtemperature protection (2)		
<input type="checkbox"/>	Set the alarm and fault limits for the motor overtemperature protection.	45.03 MOT TEMP ALM LIM 45.04 MOT TEMP FLT LIM
<input type="checkbox"/>	Set the typical ambient temperature of the motor.	45.05 AMBIENT TEMP
<input type="checkbox"/>	When 45.02 MOT TEMP SOURCE is set to (0) ESTIMATED, the motor thermal protection model must be configured as follows: - Set the maximum allowed operating load of the motor. - Set the zero speed load. A higher value can be used if the motor has an external motor fan to boost the cooling. - Set the break point frequency of the motor load curve. - Set the motor nominal temperature rise. - Set the time inside which the temperature has reached 63% of the nominal temperature.	45.06 MOT LOAD CURVE 45.07 ZERO SPEED LOAD 45.08 BREAK POINT 45.09 MOTNOM TEMP RISE 45.10 MOT THERM TIME
<input type="checkbox"/>	If possible, perform the motor ID run again at this point (see page 22).	99.13 IDRUN MODE
Speed filtering		
<p>The measured speed always has a small ripple because of electrical and mechanical interferences, couplings and encoder resolution (i.e. small pulse number). A small ripple is acceptable as long as it does not affect the speed control chain. The interferences in the speed measurement can be filtered with a speed error filter or with an actual speed filter.</p> <p>Reducing the ripple with filters may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.</p>		
<input type="checkbox"/>	If the used speed reference changes rapidly (servo application), use the speed error filter to filter the possible interferences in the speed measurement. In this case the speed error filter is more suitable than the actual speed filter: - Set the filter time constant.	26.06 SPD ERR FTIME

□	<p>If the used speed reference remains constant, use the actual speed filter to filter the possible interferences in the speed measurement. In this case the actual speed filter is more suitable than the speed error filter:</p> <ul style="list-style-type: none"> - Set the filter time constant. <p>If there are substantial interferences in the speed measurement, the filter time constant should be proportional to the total inertia of the load and motor, i.e. approximately 10...30% of the mechanical time constant</p> $t_{\text{mech}} = (n_{\text{nom}} / T_{\text{nom}}) \times J_{\text{tot}} \times 2\pi / 60, \text{ where}$ <p>J_{tot} = total inertia of the load and motor (the gear ratio between the load and the motor must be taken into account) n_{nom} = motor nominal speed T_{nom} = motor nominal torque</p> <p>To get a fast dynamic torque or speed response with a speed feedback value other than (0) <i>Estimated</i> (see parameter 22.01 SPEED FB SEL), the actual speed filter time must be set to zero.</p>	22.02 SPEED ACT FTIME
Speed controller tuning		
<p>For the most demanding applications, the P- and I-parts of the speed controller of the drive can be tuned either manually or automatically. See parameter 28.16 PI TUNE MODE.</p> <p>If it is necessary to adjust acceleration (deceleration) compensation, it must be done manually.</p>		
□	<p>Acceleration (deceleration) compensation can be used to improve the speed control dynamic reference change (when the speed ramp times > 0). In order to compensate inertia during acceleration, a derivative of the speed reference is added to the output of the speed controller.</p> <p>Set the derivation time for acceleration (deceleration) compensation. The value should be proportional to the total inertia of the load and motor, i.e. approximately 50...100% of the mechanical time constant (t_{mech}). See the mechanical time constant equation in section Speed filtering on page 27.</p>	26.08 ACC COMP DERTIME
Fieldbus control		
<p>Follow these instructions when the drive is controlled from a fieldbus control system via fieldbus adapter Fxxx. The adapter is installed in drive Slot 3.</p>		
□	Enable the communication between the drive and fieldbus adapter.	50.01 FBA ENABLE
□	Connect the fieldbus control system to the fieldbus adapter module.	
□	Set the communication and adapter module parameters: See section Setting up communication through a fieldbus adapter module on page 428.	
□	Test that the communication functions.	

How to control the drive through the I/O interface

The table below instructs how to operate the drive through the digital and analogue inputs, when the default parameter settings are valid.

PRELIMINARY SETTINGS	
Ensure the control connections are wired according to the connection diagram given in chapter Default connections of the control unit .	
Switch to external control by clicking the Take/Release button of the PC tool control panel.	
STARTING AND CONTROLLING THE SPEED OF THE MOTOR	
Start the drive by switching digital input DI1 on. Digital input status can be monitored with signal 2.01 DI STATUS .	2.01 DI STATUS
Check that analogue input AI1 is used as a voltage input (selected by jumper J1).	Voltage: J1 ○ ○ <input checked="" type="checkbox"/>
Regulate the speed by adjusting the voltage of analogue input AI1.	
Check analogue input AI1 signal scaling. AI1 values can be monitored with signals 2.04 AI1 and 2.05 AI1 SCALED . When AI1 is used as a voltage input, the input is differential and the negative value corresponds to the negative speed and the positive value to the positive speed.	13.02...13.04 2.04 AI1 2.05 AI1 SCALED
STOPPING THE MOTOR	
Stop the drive by switching digital input DI1 off.	2.01 DI STATUS

Drive programming using PC tools

What this chapter contains

This chapter introduces the drive programming using the DriveStudio and DriveSPC applications. For more information, see *DriveStudio User Manual* [3AFE68749026 (English)] and *DriveSPC User Manual* [3AFE68836590 (English)].

General


The drive control program is divided into two parts:

- firmware program
- application program.


The firmware program performs the main control functions, including speed and torque control, drive logic (start/stop), I/O, feedback, communication and protection functions. Firmware functions are configured and programmed with parameters. The functions of the firmware program can be extended with application programming. Application programs are built out of function blocks.

The drive supports two different programming methods:

- parameter programming
- application programming with function blocks (the blocks are based on the IEC-61131 standard).



The following picture presents a view from DriveSPC.



The application program template visible through DriveSPC is presented in chapter [Application program template](#) (page 411).

Programming via parameters

Parameters can be set via DriveStudio, drive control panel (keypad) or the fieldbus interface. All parameter settings are stored automatically to the permanent memory of the drive. However, it is highly recommended to force a save by using parameter [16.07 PARAM SAVE](#) before powering down the drive immediately after any parameter changes. Values are restored after the power switch-off. If necessary, the default values can be restored by parameter [16.04 PARAM RESTORE](#).

Because most parameters are used as firmware function block inputs, parameter values can also be modified via the application program. Note that parameter changes made via the application program override changes made via the DriveStudio PC tool.

Application programming

Application programs are created with the DriveSPC PC tool.

The normal delivery of the drive does not include an application program. The user can create an application program with the standard and firmware function blocks. ABB also offers customised application programs and technology function blocks for specific applications. For more information, contact your local ABB representative.

Function blocks

The application program uses three types of function blocks: firmware function blocks, standard function blocks and technology function blocks.

Firmware function blocks

Most of the firmware functions are represented as function blocks in the DriveSPC tool. Firmware function blocks are part of the drive control firmware, and used as an interface between the application and firmware programs. Drive parameters in groups 10...99 are used as function block inputs and parameters in groups 1...9 as function block outputs. Firmware function blocks are presented in chapter [Parameters and firmware blocks](#).

Standard function blocks (library)

Standard function blocks (eg, ADD, AND) are used to create an executable application program. The standard function blocks available are presented in chapter [Standard function blocks](#).

Standard function block library is always included in the drive delivery.

Technology function blocks

Several technology function block libraries (eg, CAM) are available for different types of applications. One technology library can be used at a time. Technology blocks are used in a similar way as the standard blocks.

User parameters

User parameters can be created with the DriveSPC tool. They are inserted into the application program as blocks that can be connected to existing application blocks.

User parameters can be added to any existing parameter group; the first available index is 70. Parameter groups 5 and 75...89 are available for user parameters starting from index 1. Using attributes, the parameters can be defined as write-protected, hidden, etc.

For more information, see the *DriveSPC User Manual*.

Application events

The application programmer can create his/her own application events (alarms and faults) by adding alarm and fault blocks; these blocks are managed through the Alarm and Fault Managers of the DriveSPC tool.

The operation of alarm and fault blocks is the same: when the block is enabled (by setting the Enable input to 1), an alarm or fault is generated by the drive.

Program execution

The application program is loaded to the permanent (non-volatile) memory of the memory unit (JMU). When the loading finishes, the drive control board is automatically reset, and the downloaded program started. The program is executed in real time on the same Central Processing Unit (CPU of the drive control board) as the drive firmware. The program can be executed at the two dedicated time levels of 1 and 10 milliseconds, as well as other time levels between certain firmware tasks.

Note: Because the firmware and application programs use the same CPU, the programmer must ensure that the drive CPU is not overloaded. See parameter [1.21 CPU USAGE](#).

Application program licensing and protection

Note: This functionality is only available with DriveSPC version 1.5 and later.

The drive can be assigned an application licence consisting of an ID and password using the DriveSPC tool. Likewise, the application program created in DriveSPC can be protected by an ID and password. For instructions, refer to the DriveSPC user manual.

If a protected application program is downloaded to a licensed drive, the IDs and passwords of the application and drive must match. A protected application cannot be downloaded to an unlicensed drive. On the other hand, an unprotected application can be downloaded to a licensed drive.

The ID of the application licence is displayed by DriveStudio in the drive software properties as APPL LICENCE. If the value is 0, no licence has been assigned to the drive.

The parameters that are created using the DriveSPC parameter manager with hide flags can be viewed or hidden by parameter [16.03 PASS CODE](#). The password code must be the same as the drive APPL LICENCE. A wrong password code will hide the visible application parameters again.

Notes:

- The application licence can only be assigned to a complete drive, not a stand-alone control unit.
- A protected application can only be downloaded to a complete drive, not a stand-alone control unit.

Operation modes

The DriveSPC tool offers the following operation modes:

Off-line

When the off-line mode is used without a drive connection, the user can

- open a application program file (if exists).
- modify and save the application program.
- print the program pages.

When the off-line mode is used with a drive(s) connection, the user can

- connect the selected drive to DriveSPC.
- upload an application program from the connected drive (an empty template which includes only the firmware blocks is available by default.)
- download the configured application program to the drive and start the program execution. The downloaded program contains the function block program and the parameter values set in DriveSPC.
- remove the program from the connected drive.

On-line

In the on-line mode, the user can

- modify firmware parameters (changes are stored directly to the drive memory)
- modify application program parameters (ie, parameters created in DriveSPC)
- monitor the actual values of all function blocks in real time.


Drive control and features

What this chapter contains

This chapter describes the control locations and operation modes of the drive, and the features of the application program.

Local control vs. external control

The drive has two main control locations: external and local. The control location is selected with the PC tool (Take/Release button) or with the LOC/REM key on the control panel.



- 1) Extra inputs/outputs can be added by installing optional I/O extension modules (FIO-xx) in drive Slot 1/2.
- 2) Incremental or absolute encoder, or resolver interface module (FEN-xx) installed in drive Slot 1/2
- 3) Two encoder/resolver interface modules of the same type are not allowed.

Local control

The control commands are given from a PC equipped with DriveStudio and/or DriveSPC, or from the control panel keypad when the drive is in local control. Speed, torque and position control modes are available for local control.

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be disabled by parameter [16.01 LOCAL LOCK](#).

The user can select by a parameter ([46.03 LOCAL CTRL LOSS](#)) how the drive reacts to a control panel or PC tool communication break.

External control

When the drive is in external control, control commands (start/stop, reset etc.) are given through the fieldbus interface (via an optional fieldbus adapter module), the I/O terminals (digital inputs), optional I/O extension modules or the drive-to-drive link.

Two external control locations, EXT1 and EXT2, are available. The user can select control signals (eg, [Group 10 START/STOP](#), [Group 24 SPEED REF MOD](#) and [Group 32 TORQUE REFERENCE](#)) and control modes ([Group 34 REFERENCE CTRL](#)) for both external control locations. Depending on the user selection, either EXT1 or EXT2 is active at a time. Selection between EXT1/EXT2 is done via a freely selectable bit pointer parameter [34.01 EXT1/EXT2 SEL](#). In addition, the EXT1 control location is divided into two parts, EXT1 CTRL MODE1 and EXT1 CTRL MODE2. Both use the EXT1 control signals for start/stop, but the control mode can be different; for example, EXT1 CTRL MODE2 can be used in homing.

Operating modes of the drive

The drive can operate in speed and torque control modes as well as position, synchron, homing and profile velocity modes. Block diagrams of the control chain for speed and torque control as well as positioning are presented on page [42](#); more detailed diagrams are presented in [Appendix E – Control chain and drive logic diagrams](#) (page [505](#)).

Speed control mode

Motor rotates at a speed proportional to the speed reference given to the drive. This mode can be used either with estimated speed used as feedback, or with an encoder or resolver for better speed accuracy.


Speed control mode is available in both local and external control.

Torque control mode

Motor torque is proportional to the torque reference given to the drive. This mode can be used either with estimated speed used as feedback, or with an encoder or resolver for more accurate and dynamic motor control.

Torque control mode is available in both local and external control.

Drive control chain for speed and torque control



Position control

In position control, the load is positioned along a single axis from the start position to the defined target position. A position reference is given to the drive to indicate the target position. The path to the target position is calculated by the position profile generator, controlled by position reference sets.

The position reference is taken from a moving target via an encoder, the master drive, the PLC, or the virtual master function. If the drive falls behind the moving target, the difference will be accumulated to the position reference generator as a synchron error. (In section [Position/synchron control features](#) on page 61, the moving target is referred to as the master position (reference) and the controlled drive position is referred to as the follower position.)

Position feedback (encoder or resolver) must always be used in position control to determine the actual position of the load. The same encoder can also be used to provide speed feedback. It is also possible to have separate encoders for the load (position feedback) and motor sides (speed feedback).

Note: It is emphasised that all position relevant parameters are load side related, eg, the setting of parameter [70.04 POS SPEED LIM](#) (dynamic limiter speed limitation) of 300 rpm denotes that, with a load gear ratio of 1:10, the motor can run at up to 3000 rpm.

Position control is available in both local and external control.

Synchron control

Synchron control is used to synchronise several mechanical systems (axes). The control is similar to position control, but in synchron control the position reference is taken from a moving target via an encoder, the master drive, the PLC, or from the virtual master function.

Position feedback (encoder or resolver) must always be used in synchron control to determine the actual position of the load.

Mechanical slippage etc. can be compensated using the cyclic correction functions.

Note: Synchron control is not available in local control mode.

For detailed examples of synchron control with lists of the related parameters, see [Appendix D – Application examples](#).

Virtual master function

With the virtual master function, a physical master drive or PLC is not needed in a synchron-controlled follower. The follower will generate its own synchron reference by converting the speed reference selected by parameter [67.02 VIRT MAS REF SEL](#) into a position reference by integration.

Homing control

Homing establishes a correspondence between the actual position of the driven machinery and the drive internal zero position.

An encoder must always be used in homing control.

See section [Position correction](#) on page 70.

Note: Homing control is not available in local control mode.


Profile velocity control

In profile velocity control, the motor rotates at a speed proportional to the speed reference given to the drive. The reference is given in position scale units (eg, m/s) and handled by the position control reference chain (instead of the speed reference chain).

Profile velocity control is used, eg, with CANopen profile.

Note: Profile velocity control is not available in local control mode.

Drive control chain for positioning



Motor control features

Scalar motor control

It is possible to select scalar control as the motor control method instead of Direct Torque Control (DTC). In scalar control mode, the drive is controlled with a frequency reference. However, the performance of DTC is not achieved in scalar control.

It is recommended to activate the scalar motor control mode in the following situations:

- In multimotor drives: 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after motor identification (motor ID run)
- If the nominal current of the motor is less than 1/6 of the nominal output current of the drive
- If the drive is used without a motor connected (for example, for test purposes)
- If the drive runs a medium-voltage motor through a step-up transformer.

In scalar control, some standard features are not available.


IR compensation for a scalar controlled drive

IR stands for voltage.

$$I \text{ (current)} \times R \text{ (resistance)} = U \text{ (voltage)}.$$

IR compensation is active only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications that require a high break-away torque.


In direct torque control (DTC) mode, IR compensation is automatic and manual adjustment is not needed.



Autophasing

Autophasing is an automatic measurement routine to determine the angular position of the magnetic flux of a permanent magnet synchronous motor or the magnetic axis of a synchronous reluctance motor. The motor control requires the absolute position of the rotor flux to control the motor torque accurately.

Sensors like absolute encoders and resolvers indicate the rotor position at all times after the offset between the zero angle of rotor and that of the sensor has been established. On the other hand, a standard pulse encoder determines the rotor position when it rotates but the initial position is not known. However, a pulse encoder can be used as an absolute encoder if it is equipped with Hall sensors, albeit with coarse initial position accuracy. The Hall sensors generate so-called commutation pulses that change their state six times during one revolution, so it is only known within which 60° sector of a complete revolution the initial position is.



The autophasing routine is performed with permanent magnet synchronous motors in the following cases:

1. One-time measurement of the rotor and encoder position difference when an absolute encoder, a resolver, or an encoder with commutation signals is used
2. At every power-up when an incremental encoder is used
3. With the open-loop motor control, repetitive measurement of the rotor position at every start.

In the open-loop mode, the zero angle of the rotor is determined before the start. In the closed loop mode, the actual angle of the rotor is determined with autophasing when the sensor indicates the zero angle. The offset of the angle must be determined because the actual zero angles of the sensor and the rotor do not usually match. The autophasing mode determines how this operation is done both in the open loop and closed loop modes.

Note: In the open loop mode, the motor always turns when it is started as the shaft is turned towards the remanence flux.

A rotor position offset used in motor control can also be given by the user. See parameter [97.20 POS OFFSET USER](#).

Note: The same parameter is used by the autophasing routine which always writes its result to parameter [97.20 POS OFFSET USER](#). Autophasing ID run results are updated even if the user mode is not enabled (see parameter [97.01 USE GIVEN PARAMS](#)).

Several autophasing modes are available (see parameter [11.07 AUTOPHASING MODE](#)).

The turning mode is recommended especially with case 1 (see the list above) as it is the most robust and accurate method. In the turning mode, the motor shaft is turned back and forward ($\pm 360/\text{polepairs}$)° to determine the rotor position. In case 3 (open-loop control), the shaft is turned only in one direction and the angle is smaller.

The standstill modes can be used if the motor cannot be turned (for example, when the load is connected). As the characteristics of motors and loads differ, testing must be done to find out the most suitable standstill mode.

The drive is capable of determining the rotor position when started to a running motor in the open-loop or closed loop modes. In this situation, the setting of parameter [11.07 AUTOPHASING MODE](#) has no effect.

The autophasing routine can fail and therefore it is recommended to perform the autophasing routine several times and check the value of parameter [97.20 POS OFFSET USER](#).

The autophasing fault can occur in a running motor if the estimated angle of the rotor differs too much from the measured angle of the rotor. One reason for different values in the estimated and measured angles is that there is a slip in the encoder connection to the motor axle.


Another cause for the autophasing fault is a failed autophasing routine. In other words, there has been a wrong value in parameter [97.20 POS OFFSET USER](#) from the beginning.

The third reason for the autophasing fault in a running motor is that there is a wrong motor type in the control program or that the motor ID run has failed.

In addition, fault [0026 AUTOPHASING](#) can occur during the autophasing routine if parameter [11.07 AUTOPHASING MODE](#) is set to Turning. The Turning mode requires that the rotor can be turned during the autophasing routine. If the rotor is locked or cannot be easily turned or if the rotor turns by force of external power, the autophasing fault is triggered. Regardless of the chosen mode, the autophasing fault occurs if the rotor is turning before the autophasing routine is started.

Flux braking

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux with [40.10 FLUX BRAKING](#), the energy generated by the motor during braking can be converted to motor thermal energy.



The drive monitors the motor status continuously, also during flux braking. Therefore, flux braking can be used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.
- The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
- Flux braking can be used with induction motors and permanent magnet synchronous motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.

Thermal motor protection

With the parameters in group [45](#), the user can set up the motor overtemperature protection and configure motor temperature measurement (if present). This block also shows the estimated and measured motor temperature.

The motor can be protected against overheating by

- the motor thermal protection model
- measuring the motor temperature with PTC or KTY84 sensors. This will result in a more accurate motor model.

Thermal motor protection model

The drive calculates the temperature of the motor on the basis of the following assumptions:

- 1) When power is applied to the drive for the first time, the motor is at ambient temperature (defined by parameter **45.05 AMBIENT TEMP**). After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature (value of **1.18 MOTOR TEMP EST**, saved at power switch-off).
- 2) Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30 °C.

It is possible to adjust the motor temperature supervision limits and select how the drive reacts when overtemperature is detected.

Note: The motor thermal model can be used when only one motor is connected to the inverter.


Temperature sensors

It is possible to detect motor overtemperature by connecting a motor temperature sensor to thermistor input TH of the drive or to optional encoder interface module FEN-xx.

The resistance of the sensor increases as the motor temperature rises over the sensor reference temperature T_{ref} , as does the voltage over the resistor.


The figure below shows typical PTC sensor resistance values as a function of the motor operating temperature.

Temperature	PTC resistance
Normal	0...1 kohm
Excessive	≥ 4 kohm*
*The limit for overtemperature protection is 2.5 kohm.	



The figure below shows typical KTY84 sensor resistance values as a function of the motor operating temperature.

KTY84 scaling	
90 °C	= 936 ohm
110 °C	= 1063 ohm
130 °C	= 1197 ohm
150 °C	= 1340 ohm




It is possible to adjust the motor temperature supervision limits and select how the drive reacts when overtemperature is detected.



WARNING! As the thermistor input on the JCU Control Unit is not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. If the assembly does not fulfil the requirement,

- the I/O board terminals must be protected against contact and must not be connected to other equipment
- or
- the temperature sensor must be isolated from the I/O terminals.

The figure below shows a motor temperature measurement when thermistor input TH is used.



For encoder interface module FEN-xx connection, see the *User's Manual* of the appropriate encoder interface module.

DC voltage control features


Overvoltage control

Overvoltage control of the intermediate DC link is needed with two-quadrant line-side converters when the motor operates within the generating quadrant. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached.

Undervoltage control

If the incoming supply voltage is cut off, the drive will continue to operate by utilising the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive. The drive can continue the operation after the break if the main contactor remained closed.

Note: Units equipped with main contactor option must be equipped with a hold circuit (eg, UPS) which keeps the contactor control circuit closed during a short supply break.




U_{DC} = intermediate circuit voltage of the drive, f_{out} = output frequency of the drive, T_M = motor torque

Loss of supply voltage at nominal load ($f_{out} = 40$ Hz). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the supply is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative either to a supply voltage value provided by the user or to an automatically-determined supply voltage. The actual voltage used is shown by parameter **1.19 USED SUPPLY VOLT**. The DC voltage (U_{DC}) equals 1.35 times this value.

Automatic identification of the supply voltage is performed every time the drive is powered. Automatic identification can be disabled by parameter [47.03 SUPPLVOLTAUTO-ID](#); the user can define the voltage manually at parameter [47.04 SUPPLY VOLTAGE](#).



$$U_{DC} = 1.35 \times 1.19 \text{ USED SUPPLY VOLT}$$

$$U_{DC, \text{ high}} = 1.25 \times U_{DC}$$

$$U_{DC, \text{ low}} = 0.8 \times U_{DC}$$

The intermediate DC circuit is charged over an internal resistor which is bypassed when the capacitors are considered charged and the voltage has stabilized.

Braking chopper

The built-in braking chopper of the drive can be used to handle the energy generated by a decelerating motor.

When the braking chopper is enabled and a resistor connected, the chopper will start conducting when the DC link voltage of the drive reaches $U_{DC_BR} - 30 \text{ V}$. The maximum braking power is achieved at $U_{DC_BR} + 30 \text{ V}$.

$$U_{DC_BR} = 1.35 \times 1.25 \times 1.19 \text{ USED SUPPLY VOLT.}$$

Low voltage mode

A Low voltage mode is available to extend the supply voltage range. When the mode is enabled, the drive can operate below the nominal range, for example when it needs to be powered from an emergency supply.

Low voltage mode can be activated by parameter [47.05 LOW VOLT MOD ENA](#). Low voltage mode introduces parameters [47.06 LOW VOLT DC MIN](#) and [47.07 LOW VOLT DC MAX](#) for adjustment of minimum and maximum DC voltage control levels respectively. The following rules apply:

- [47.06 LOW VOLT DC MIN](#) = 250 to 450 V
- [47.07 LOW VOLT DC MAX](#) = 350 to 810 V
- [47.07 LOW VOLT DC MAX](#) > [47.06 LOW VOLT DC MIN](#) + 50 V.

The value of parameter [47.08 EXT PU SUPPLY](#) or its source should be set to 1 (true) when a supply below 270 V DC – such as a battery – is used. In such a configuration, an additional DC power supply (JPO-01) is needed to power the main circuit electronics. With an AC supply, the value of parameter [47.08 EXT PU SUPPLY](#) or its source should be set to 0 (false).

Parameters [47.06...47.08](#) are effective only when the Low voltage mode is active, ie, value of parameter [47.05 LOW VOLT MOD ENA](#) (or its source) is 1 (true).

In the Low voltage mode, the default voltage control and trip levels as well as the braking chopper operation levels (see sections [Voltage control and trip limits](#) and [Braking chopper](#) elsewhere in this chapter) are changed as follows:

Level	Value of parameter 47.08 EXT PU SUPPLY	
	FALSE	TRUE
Supply voltage range	200...240 V AC $\pm 10\%$ 270...324 V DC $\pm 10\%$	*48...270 V DC $\pm 10\%$
Overvoltage trip level	Unaffected	Unaffected
Overvoltage control level	47.07 LOW VOLT DC MAX	47.07 LOW VOLT DC MAX
Undervoltage control level	47.06 LOW VOLT DC MIN	Disabled
Undervoltage trip level	47.06 LOW VOLT DC MIN - 50 V	Disabled
Braking chopper activation level	47.07 LOW VOLT DC MAX - 30 V	47.07 LOW VOLT DC MAX - 30 V
Braking chopper maximum power level	47.07 LOW VOLT DC MAX + 30 V	47.07 LOW VOLT DC MAX + 30 V
*Requires additional DC power supply JPO-01		

Different system configurations are detailed in *ACSM1 System Engineering Manual* (3AFE68978297 [English]).

Note: The Low voltage mode is not available for frames E to G.

Speed control features


Jogging

Jogging is typically used during servicing or commissioning to control the machinery locally. It involves rotating the motor in small increments until the desired load position is achieved.

Two jogging functions (1 or 2) are available. When a jogging function is activated, the drive starts and accelerates to the defined jogging speed (parameters [24.10 SPEED REF JOG1](#) and [24.11 SPEED REF JOG2](#)) along the defined jogging acceleration ramp. When the function is deactivated, the drive decelerates to a stop along the defined jogging deceleration ramp. One push button can be used to start and stop the drive during jogging.

Jogging functions 1 and 2 are activated by a parameter or through fieldbus. The source of the jogging command is selected by bit pointer parameters [10.07 JOG1 START](#) and [10.14 JOG2 START](#). For activation through fieldbus, see [2.12 FBA MAIN CW](#).

The figure and table below describe the operation of the drive during jogging. (Note that they cannot be directly applied to jogging commands through fieldbus as those require no enable signal; see parameter [10.15 JOG ENABLE](#).) They also represent how the drive shifts to normal operation (= jogging inactive) when the drive start command is switched on. Jog cmd = State of the jogging input; Jog enable = Jogging enabled by the source set by parameter [10.15 JOG ENABLE](#); Start cmd = State of the drive start command.



Phase	Jog cmd	Jog enable	Start cmd	Description
1-2	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
2-3	1	1	0	Drive runs at the jogging speed.
3-4	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
4-5	0	1	0	Drive is stopped.
5-6	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
6-7	1	1	0	Drive runs at the jogging speed.
7-8	x	0	1	Jog enable is not active; normal operation continues.
8-9	x	0	1	Normal operation overrides the jogging. Drive follows the speed reference.
9-10	x	0	0	Drive decelerates to zero speed along the active deceleration ramp.
10-11	x	0	0	Drive is stopped.

Phase	Jog cmd	Jog enable	Start cmd	Description
11-12	x	0	1	Normal operation overrides the jogging. Drive accelerates to the speed reference along the active acceleration ramp.
12-13	1	1	1	Start command overrides the jog enable signal.
13-14	1	1	0	Drive decelerates to the jogging speed along the deceleration ramp of the jogging function.
14-15	1	1	0	Drive runs at the jogging speed.
15-16	x	0	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.

Notes:

- Jogging is not operational when the drive start command is on, or when the drive is in local control.
- Normal start is inhibited when jog enable is active.
- The ramp shape time is set to zero during jogging.


Speed controller tuning

The speed controller of the drive can be automatically adjusted using the autotune function (parameter [28.16 PI TUNE MODE](#)). Autotuning is based on the load and inertia of the motor and the machine. It is, however, also possible to manually adjust the controller gain, integration time and derivation time. Autotuning can also be performed from an external control location.

Autotuning can be performed in four different ways depending on the setting of parameter [28.16 PI TUNE MODE](#). The selections (1) [Smooth](#), (2) [Middle](#) and (3) [Tight](#) define how the drive torque reference should react to a speed reference step after tuning. The selection (1) [Smooth](#) will produce a slow response; (3) [Tight](#) will produce a fast response. The selection (4) [User](#) allows customised control sensitivity adjustment through parameters [28.17 TUNE BANDWIDTH](#) and [28.18 TUNE DAMPING](#). Detailed tuning status information is provided by parameter [6.03 SPEED CTRL STAT](#).

Once parameter [28.16 PI TUNE MODE](#) has been set, an autotuning routine will be started when the drive modulation is started the next time. If the autotuning routine fails, the [SPEED CTRL TUNE FAIL](#) alarm will occur for approximately 15 seconds. If a stop command is given to the drive during the autotuning routine, the routine will be aborted.

The figure below illustrates the motor speed and torque behaviour during an autotuning routine.



The prerequisites for performing the autotune routine are:


- The motor ID run has been successfully completed
- Speed, torque, current and acceleration limits (parameter groups [20](#) and [25](#)) are set
- Speed feedback filtering, speed error filtering and zero speed are set (parameter groups [22](#) and [26](#))
- The drive is stopped.

The results of the autotune routine are automatically transferred into parameters

- [28.02 PROPORT GAIN](#) (proportional gain of the speed controller)
- [28.03 INTEGRATION TIME](#) (integration time of the speed controller)
- [1.31 MECH TIME CONST](#) (mechanical time constant of the machinery).


Note: The autotuning routine accelerates and decelerates the motor according to the ramp times set in group [25](#), and these values have an effect on the autotuning results.

The figure below shows speed responses at a speed reference step (typically 1...20%).



- A: Undercompensated
- B: Normally tuned (autotuning)
- C: Normally tuned (manually). Better dynamic performance than with B
- D: Overcompensated speed controller

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



For more information on the use of the autotune function, see the description of parameter [28.16 PI TUNE MODE](#).


Motor feedback features

Motor encoder gear function

The drive provides motor encoder gear function for compensating of mechanical gears between the motor shaft, the encoder and the load.

Motor encoder gear application example:

Speed control uses the motor speed. If no encoder is mounted on the motor shaft, the motor encoder gear function must be applied in order to calculate the actual motor speed on the basis of the measured load speed.



The motor encoder gear parameters [22.03 MOTOR GEAR MUL](#) and [22.04 MOTOR GEAR DIV](#) are set as follows:

$$\frac{22.03 \text{ MOTOR GEAR MUL}}{22.04 \text{ MOTOR GEAR DIV}} = \frac{\text{Actual speed}}{\text{Encoder 1/2 speed}}$$

Note: If the motor gear ratio differs from 1, the motor model uses an estimated speed instead of the speed feedback value.

See also section [Examples of gear function usage](#) on page 64.


Mechanical brake control

The program supports the use of a mechanical brake to hold the motor and load at zero speed when the drive is stopped or not powered.

Mechanical brake control (with or without acknowledgement) is activated by parameter [35.01 BRAKE CONTROL](#). The acknowledgement (supervision) signal can be connected to, for example, a digital input. The brake on/off value is reflected by [3.15 BRAKE COMMAND](#), which should be connected to a relay (or digital) output. The brake will open upon drive start after the delay [35.03 BRAKE OPEN DELAY](#) has elapsed and requested motor start torque [35.06 BRAKE OPEN TORQ](#) is available. The brake will close after motor speed decreases below [35.05 BRAKE CLOSE SPD](#) and the delay [35.04 BRAKE CLOSE DLY](#) has elapsed. When the brake close command is issued, the motor torque is stored into [3.14 BRAKE TORQ MEM](#).

Note: The mechanical brake must be opened manually before the motor ID run.

Mechanical brake state diagram



BSM = Brake State Machine
 * Depends on setting of par. 35.09 BRAKE FAULT FUNC.

State (Symbol NN —W/X/Y/Z)


- NN: State name
- W/X/Y/Z: State outputs/operations
 - W: 1 = Brake open command is active. 0 = Brake close command is active. (Controlled through selected digital/relay output with signal 3.15 BRAKE COMMAND.)
 - X: 1 = Forced start (inverter is modulating). The function keeps the internal Start command on until the brake is closed regardless of the status of the external Stop. Effective only when ramp stop has been selected as the stop mode (11.03 STOP MODE). Run enable and faults override the forced start. 0 = No forced start (normal operation).
 - Y: 1 = Drive control mode is forced to speed/scalar.
 - Z: 1 = Ramp generator output is forced to zero. 0 = Ramp generator output is enabled (normal operation).

State change conditions (Symbol)

- 1) Brake control is active (35.01 BRAKE CONTROL = (1) WITH ACK or (2) NO ACK) OR modulation of the drive is requested to stop. The drive control mode is forced to speed/scalar.
- 2) External start command is on AND brake open request is on (source selected by 35.07 BRAKE CLOSE REQ = 0).
- 3) Starting torque required at brake release is reached (35.06 BRAKE OPEN TORQ) AND brake hold is not active (35.08 BRAKE OPEN HOLD). **Note:** With scalar control, the defined starting torque has no effect.
- 4) Brake is open (acknowledgement = 1, selected by par. 35.02 BRAKE ACKNOWL) AND the brake open delay has passed (35.03 BRAKE OPEN DELAY). Start = 1.
- 5) 6) Start = 0 OR brake close command is active AND actual motor speed < brake close speed (35.05 BRAKE CLOSE SPD).
- 7) Brake is closed (acknowledgement = 0) AND brake close delay has passed (35.04 BRAKE CLOSE DLY). Start = 0.
- 8) Start = 1.
- 9) Brake is open (acknowledgement = 1) AND brake close delay has passed.
- 10) Defined starting torque at brake release is not reached.
- 11) Brake is closed (acknowledgement = 0) AND brake open delay has passed.
- 12) Brake is closed (acknowledgement = 0).
- 13) Brake is open (acknowledgement = 1) AND brake close delay has passed.

Operation time scheme

The simplified time scheme below illustrates the operation of the brake control function.



T_s	Start torque at brake release (parameter 35.06 BRAKE OPEN TORQ)
T_{mem}	Stored torque value at brake close (signal 3.14 BRAKE TORQ MEM)
t_{md}	Motor magnetising delay
t_{od}	Brake open delay (parameter 35.03 BRAKE OPEN DELAY)
n_{cs}	Brake close speed (parameter 35.05 BRAKE CLOSE SPD)
t_{cd}	Brake close delay (parameter 35.04 BRAKE CLOSE DLY)

Example

The figure below shows a brake control application example.




WARNING! Make sure that the machinery into which the drive with brake control function is integrated fulfils the personnel safety regulations. Note that the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonised standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature (such as the brake control function), but it has to be implemented as defined in the application specific regulations.

The brake on/off is controlled via signal [3.15 BRAKE COMMAND](#). The source for the brake supervision is selected by parameter [35.02 BRAKE ACKNOWL](#).

The brake control hardware and wirings need to be done by the user.

- Brake on/off control through selected relay/digital output.
 - Brake supervision through selected digital input.
 - Emergency brake switch in the brake control circuit.
-
- Brake on/off control through relay output (ie, parameter [12.12 RO1 OUT PTR](#) is set to P.03.15 = [3.15 BRAKE COMMAND](#)).
 - Brake supervision through digital input DI5 (ie, parameter [35.02 BRAKE ACKNOWL](#) is set to P.02.01.04 = [2.01 DI STATUS](#) bit 4)



Position/synchron control features

Position calculation

The actual position of the drive is measured using a position feedback device. During normal operation, the actual position is calculated by keeping track of the position change between the current time and the last known position. The position calculation is non-saturating: after the maximum position has been reached, the position gets the negative value with the maximum absolute value.

Depending on the machinery used, different types of scaling can be applied to the position measurement for drive position calculation, such as

- unit (parameter [60.05 POS UNIT](#))
- feed constant, transforming rotational axis movement to translational ([60.06 FEED CONST NUM](#), [60.07 FEED CONST DEN](#))
- gears ([60.03 LOAD GEAR MUL](#), [60.04 LOAD GEAR DIV](#), [71.07 GEAR RATIO MUL](#), [71.08 GEAR RATIO DIV](#))
- axis type ([60.02 POS AXIS MODE](#)), and
- resolution of the position calculation ([60.09 POS RESOLUTION](#)).

The drive position system range is defined by [60.13 MAXIMUM POS](#) and [60.14 MINIMUM POS](#). If the actual position is out of this range, a fault (POSITION ERROR MAX or POSITION ERROR MIN) is generated. The range is supervised in position, synchron and profile velocity modes.

Hardware limits can be established by parameters [62.05 NEG LIMIT SWITCH](#) and [62.06 POS LIMIT SWITCH](#). If a limit switch is triggered, the speed reference in that direction is ramped down along the emergency stop ramp, and only movement in the opposite direction is allowed. In the homing operating mode, when seeking the home position, the drive does not use the limit switches; they are however used in some homing methods to reverse the direction of movement when seeking.

With an absolute type of position feedback, the actual position after a power-up or an encoder refresh request is calculated on the basis of the measured number of revolutions of the absolute encoder and its position inside one mechanical shaft. After this, the actual position is calculated by keeping track of the position changes. The actual position can be reproduced uniquely and clearly after the next power-up only if the encoder position has not moved outside its working area.

Example:

With an absolute multiturn encoder and 12 bits for revolution counting (defined with parameter [91.03 REV COUNT BITS](#)), the encoder position must not exceed 4096 revolutions, or else it will fall below 0 revolutions. If the encoder is run to the position of -10 revolutions, the position at the next power-up will be 4086 revolutions.

The same situation may occur in a roll-over application with a gear different from a power of two, because the old and new encoder readings do not give the same position. This situation can be avoided by activating parameter [91.06 ABS POS TRACKING](#).

With absolute encoders and resolvers, there is often a need to change the position calculation zero permanently without physically rotating the motor. This is possible by using parameter [62.20 POS ACT OFFSET](#). The value of the parameter is added to the position feedback value. The offset can be made permanent after the homing procedure using parameter [62.21 POS COR MODE](#).

Position estimation

With synchronous motors, the drive also supports positioning without a speed and position feedback device. In position estimation, the actual position of the drive ([1.12 POS ACT](#)) is calculated using the estimated speed as the position change between the current time and the last known position. The accuracy of this position estimate depends heavily on the motor model accuracy. The different types of position scaling, the drive position system range and the hardware limits are the same as for position calculation.


Position estimation can be selected as the position feedback value for the position controller via parameter [60.01 POS ACT SEL](#). In addition, at least one latch signal must be available in the revolution to correct the actual position of the drive.

Load encoder gear function

Positioning uses the measured speed and position of the load. The load encoder gear function calculates the actual load position on the basis of the measured motor shaft position.

Load encoder gear application examples:


Positioning uses the measured speed and position of the load. If no encoder is mounted on the load side, the load encoder gear function must be applied in order to calculate the actual load position on the basis of the measured motor shaft position. This configuration also works with the estimated position besides encoder 1.



A second encoder (encoder 2) mounted on the load side is used as the source for the actual position value. (Note: Inverted gear ratio is considered when the position control output (speed reference) is produced).

If the second encoder is an absolute encoder, it must be configured as encoder 1.

This configuration does not work with the estimated position besides encoder 1 because the motor gear ratio is internally set to 1:1 with the estimated speed.



The load encoder gear parameters [60.03 LOAD GEAR MUL](#) and [60.04 LOAD GEAR DIV](#) are set as follows:

$$\frac{\text{60.03 LOAD GEAR MUL}}{\text{60.04 LOAD GEAR DIV}} = \frac{\text{Load speed}}{\text{Encoder 1/2 speed}}$$

Note: The sign of the programmed gear ratio has to match the sign of the mechanical gear ratio.

Because the drive speed control uses motor speed, a gear function between position control (load side) and speed control (motor side) is needed. This gear function is formed from the motor gear function and inverted load gear function. The gear function is applied to the position control output (speed reference) as follows:

$$\frac{71.07 \text{ GEAR RATIO MUL}}{71.08 \text{ GEAR RATIO DIV}} = \frac{\text{Motor speed}}{\text{Load speed}}$$

The equation quite often translates to


$$\frac{71.07 \text{ GEAR RATIO MUL}}{71.08 \text{ GEAR RATIO DIV}} = \frac{22.03 \text{ MOTOR GEAR MUL} \times 60.04 \text{ LOAD GEAR DIV}}{22.04 \text{ MOTOR GEAR DIV} \times 60.03 \text{ LOAD GEAR MUL}}$$



Parameters **71.07 GEAR RATIO MUL** and **71.08 GEAR RATIO DIV** are also inputs of the firmware block **POS CONTROL** (see page 256).

Note: It is emphasised that all position relevant parameters are load side related, eg, the setting of parameter **70.04 POS SPEED LIM** (dynamic limiter speed limitation) of 300 rpm denotes that, with a load gear ratio of 1:10, the motor can run at up to 3000 rpm.

Examples of gear function usage


The following figures demonstrate how the gear functions of the control program are used.






Position profile generator

The position profile generator moves the position reference to the selected target position, taking the positioning speed acceleration/deceleration into account. The generator continuously calculates the speed from which the drive can decelerate to a stop within the target distance using the defined deceleration reference. Acceleration reference is used at start of positioning to increase the positioning speed until reference speed or calculated speed is reached. The calculated speed is used to generate the optimised position reference, which guides the drive to its target position. The filtering is performed by a moving average filter, a Finite Impulse Response (FIR).




The following figure shows how the position profile generator generates a position reference.




The position profile generator is also used to compensate for synchronisation errors in synchron control and for position correction errors in position control. Errors can be caused by

- dynamic limitation of position reference change, or
- cyclic correction of position difference measured by external latches.

Parameters **66.05 POS ENABLE** and **65.03 POS START 1 / 65.11 POS START 2** control the operation of the position profile generator. The following figure shows the positioning commands and signals when parameter **65.24 POS START MODE** is set to **(0) NORMAL**.



The following figure shows the positioning commands and signals when parameter **65.24 POS START MODE** is set to **(1) PULSE**.



* If a pulse start (**65.03 POS START 1 / 65.11 POS START 2**) is received while the positioning enable signal (**66.05 POS ENABLE**) is 0, the start command is stored to drive memory and new positioning is started when the enable signal is set to 1. In this case, the positioning start can be canceled only by changing the start mode (**65.24 POS START MODE**).

Position reference sets

The user can define two different position reference sets. Each reference set consists of

- position reference
- positioning speed reference
- positioning acceleration reference
- positioning deceleration reference
- positioning reference filter time
- positioning style
- positioning speed when target is reached.

One reference set is used at a time. The definition and selection of position reference sets are done using the parameters in group 65.

Dynamic position reference limiter


The dynamic limiter controls the position reference limitation in position control and synchron control modes. Dynamic limitation of the position reference causes a synchron error (4.18 SYNC ERROR). The error is accumulated and fed back to the position profile generator. The synchron error is corrected according to the values of the active positioning table parameters in group 65.

Note: Make sure that parameter 65.05 < 70.04, parameter 65.06 < 70.05 and parameter 65.07 < 70.06. Otherwise, the drive may oscillate.

Start/stop examples with dynamic limiter

The speed curves of the master and follower during the start and stop are presented in the figures below.

When the follower is in synchron control, the reference can be taken from the encoder or from another drive. The master can be in any control mode.




Start: linear axis, absolute synchronisation

Used when the master and the follower are to be driven equal distances.


60.02 POS AXIS MODE is set to (0) Linear. 68.07 SYNCHRON MODE is set (0) Absolute.

To catch the master position, the follower accelerates up to its maximum allowed speed. Master position changes which take place before and after the follower is started are taken into account.

**Stop: linear axis**

60.02 POS AXIS MODE is set to (0) Linear.

The figure shows how the dynamic limiter works together with the position profile generator when the drives are stopped: Before the stop command of the master, the speed of the follower is limited by the dynamic speed limiter (70.04 POS SPEED LIM), which results in a position error. When the master starts to decelerate, the follower uses positioning deceleration, and, eventually, positioning speed to overcome the position error.



Position correction

Homing

Normally, before first homing, the actual position of the driven machinery does not correspond to the internal zero position in the drive position control (for example, with an incremental encoder after each power-up). Homing establishes a correspondence between these two positions. During homing, the direction can be changed by an external latch signal or limit switch.

























Homing is implemented according to the CANopen Standard Proposal 402 for Device Profile Drives and Motion Control. The profile includes 35 different homing sequences (see the following homing method table and [Appendix C – Homing methods](#)). The start direction and used latch signals depend on the selected homing method ([62.01 HOMING METHOD](#)) and the status of the external home switch signal ([62.04 HOME SWITCH TRIG](#)).

A homing sequence (except homing method 35) can be executed only in homing control mode when the drive is modulating. When homing is activated by the homing start signal ([62.03 HOMING START](#)), the drive accelerates, as defined by homing acceleration ([62.27 HOMING ACC](#)), to homing speed 1 ([62.07 HOMING SPEEDREF1](#)). During homing, the direction can only be changed with homing methods 1...14. Homing speed 1 is maintained until an external latch signal for homing speed 2 ([62.08 HOMING SPEEDREF2](#)) or for the home position is received. Homing is stopped with an index pulse/z-pulse or switch signal from an external latch. The actual position is set as the home position ([62.09 HOME POSITION](#)), and the drive decelerates to zero speed using homing deceleration ([62.28 HOMING DEC](#)). Thereafter, the drive uses the position control mode to return to the exact received latch position.

Homing is performed in an absolute way. Parameter [62.10 HOME POS OFFSET](#) can be used to specify an absolute difference between the home position and the end position after homing; this is useful if the home proximity switch cannot be located at the physical home position.

The following table presents homing methods 1...35. For more detailed descriptions, see [Appendix C – Homing methods](#).

Note: Homing methods 1...14, 33 and 34 do not work with an absolute encoder or position estimation. Homing methods 17...30 work with position estimation as well.

Method	Homing latch signal	Homing done condition**	Homing speed 2	Starting direction	Limit switches required
1	Negative limit switch and index pulse		Yes	Negative	Negative
2	Positive limit switch and index pulse		Yes	Positive	Positive
3	Home switch and index pulse		Yes	Positive*	None
4	Home switch and index pulse		Yes	Positive*	None
5	Home switch and index pulse		Yes	Negative*	None
6	Home switch and index pulse		Yes	Negative*	None
7	Home switch and index pulse		Yes	Positive*	Positive
8	Home switch and index pulse		Yes	Positive*	Positive
9	Home switch and index pulse		Yes	Positive	Positive
10	Home switch and index pulse		Yes	Positive	Positive
11	Home switch and index pulse		Yes	Negative*	Negative
12	Home switch and index pulse		Yes	Negative*	Negative
13	Home switch and index pulse		Yes	Negative	Negative
14	Home switch and index pulse		Yes	Negative	Negative
15...16	Reserved				
17	Negative limit switch		No	Negative	None
18	Positive limit switch		No	Positive	None
19	Home switch		No	Positive*	None
20	Home switch		No	Positive*	None
21	Home switch		No	Negative*	None
22	Home switch		No	Negative*	None
23	Home switch		No	Positive*	Positive
24	Home switch		No	Positive*	Positive
25	Home switch		No	Positive	Positive
26	Home switch		No	Positive	Positive

Method	Homing latch signal	Homing done condition**	Homing speed 2	Starting direction	Limit switches required
27	Home switch		No	Negative*	Negative
28	Home switch		No	Negative*	Negative
29	Home switch		No	Negative	Negative
30	Home switch		No	Negative	Negative
31...32	Reserved				
33	Index pulse		No	Negative	None
34	Index pulse		No	Positive	None
35	None	Any	No	None	None

*Opposite direction if home switch is active at start of homing sequence.
**Example:

Preset functions

Preset functions are used to set the position system according to a parameter value (preset position) or actual position. The physical position of the driven machinery is not changed, but the new position value is used as home position. Preset functions can be used, eg, in synchron control to change the follower position without moving the master.

The preset function trigger signal is selected by parameter [62.12 PRESET TRIG](#).

There are three different preset functions:

- SYNCH REF: Preset drive synchron reference chain ([4.16 SYNC REF GEARED](#)) to the value of [62.13 PRESET POSITION](#).
- ACT TO SYNCH: Preset drive synchron reference chain ([4.16 SYNC REF GEARED](#)) to the value of actual position ([1.12 POS ACT](#)).
- WHOLE SYSTEM: Preset whole position system of the drive to the value of [62.13 PRESET POSITION](#). The whole position system consists of the position reference chain and synchron reference chain ([4.13 POS REF IPO](#), [4.16 SYNC REF GEARED](#), [4.17 POS REF LIMITED](#), [1.12 POS ACT](#)).

In addition, homing method 35 (selectable by parameter [62.01 HOMING METHOD](#)) can be used to set the position reference chain ([4.13 POS REF IPO](#), [4.17 POS REF LIMITED](#), [1.12 POS ACT](#)) to the value of [62.09 HOME POSITION](#) on a rising edge of [62.03 HOMING START](#).

Cyclic position correction

Cyclic position correction functions are used to change or correct the system position continuously according to data measured by external probe signals, for example, if there is play in the machinery. The cyclic position correction functions always need an external probe (or probes) to operate. By means of a programmable bit pointer, the probes can be configured to use digital inputs DI1 and DI2 of the encoder interface with different triggering conditions (such as falling or rising edge) or the digital inputs of the drive control board unit as trigger sources.

The cyclic position correction functions use the probe positions in the correction calculations in two ways:

- as an actual position latch to correct the drive actual position ([1.12 POS ACT](#))
- as a master reference latch to correct the drive synchron reference position ([4.16 SYNC REF GEARED](#)).

To enable cyclic position correction, the following settings must be considered:

- Cyclic correction mode ([62.14 CYCLIC CORR MODE](#))
- Probe positions ([62.16 PROBE1 POS](#), [62.18 PROBE2 POS](#))
- Triggering conditions ([62.15 TRIG PROBE1](#), [62.17 TRIG PROBE2](#))
- Maximum allowed correction ([62.19 MAX CORRECTION](#))
- Programmable bit pointer ([62.22 TRIG PROBE1 SW](#), [62.23 TRIG PROBE2 SW](#))

There are five different cyclic position correction functions available:

- CORR ACT POS: Drive actual position correction (Probe 1 used for actual position latch).
- CORR MAST REF: Synchronised master drive reference correction (Probe 1 used for master position reference latch).
- CORR M/F DIST: Master and follower distance correction. The drive synchronised master reference and actual position are both corrected (Probe 1 used for actual position latch and probe 2 for master position reference latch).
- 1 PROBE DIST: Drive actual position correction according to the distance between two consecutive latches from one probe (Probe 1 used for actual position latch).
- 2 PROBE DIST: Drive actual position correction according to the distance between two latches (Probe 1 and probe 2 both used for actual position latch).

When enabled, cyclic correction waits until the triggering conditions of the probes are fulfilled. The encoder positions are then latched (saved) into [4.03 PROBE1 POS MEAS](#) and [4.04 PROBE2 POS MEAS](#). If there is deviation between probe position and measured position, a correction is carried out. The deviation (shown by [4.05 CYCLIC POS ERR](#)) is added to synchronisation error [4.18 SYNC ERROR](#) and corrected using the position profile generator and dynamic limiter parameters. The next correction can be started after the previous correction has been successfully carried out.

If cyclic correction is configured to use two probes, the correction is done after both latches have been received. If multiple latches are received from one probe, the last-received latch is used in the correction calculation.

Actual position correction


The purpose of the actual position correction is to compare the difference between [62.16 PROBE1 POS](#) and the actual encoder position at the moment when the triggering conditions are fulfilled. If there is a deviation, a corresponding correction is carried out on signal [1.12 POS ACT](#). The required transition is determined by the position profile generator parameters.

Note: Probe 1 settings must always be used for the actual position correction.


This configuration also works with the estimated position besides the encoder position.

Example:

The following figure presents a roll-over application. The motor rotates a round table. There is a mechanical gear between the motor and load. The gear is prone to produce some drift on the load side. In order to compensate this drift, actual position correction is used. A proximity switch is located on the load side at 90°.



Parameter	Setting	Information
60.05 POS UNIT	(1) Degree	All position values are in degrees
62.14 CYCLIC CORR MODE	(1) Cor Act Pos	Actual position correction
62.15 TRIG PROBE1	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1. Source of the actual position latching command (proximity switch signal source)
60.02 POS AXIS MODE	(1) Rollover	Positioning is between 0 and 1 revolutions, ie, after 360°, the position calculation starts from 0° again.
62.16 PROBE1 POS	90°	Reference position for the actual position probe



t_1 : Rising edge of encoder digital input DI1 signal (proximity switch signal) is detected when the load position should be 90° . The actual position of the encoder is 120° (stored to signal [4.03 PROBE1 POS MEAS](#)).

Distance between the load position and the actual position is $90^\circ - 120^\circ = -30^\circ$ (= [4.05 CYCLIC POS ERR](#)).


Master reference correction

The purpose of the master reference correction is to correct the difference between [62.16 PROBE1 POS](#) and the synchron reference position [4.16 SYNC REF GEARED](#) at the moment when the triggering conditions are met. If there is a deviation, a corresponding correction is carried out on the drive synchron reference position.

Note: In master reference correction, the follower must always be in synchron control mode. If the follower is not used in synchron control mode, adjusting the drive synchron reference ([4.16 SYNC REF GEARED](#)) will not affect the operation of the drive, and the correction cannot be carried out properly.

Example:

Parameter	Setting	Information
60.05 POS UNIT	(1) Degree	All position values are in degrees
60.02 POS AXIS MODE	(1) Rollover	Positioning is between 0 and 1 revolutions, ie, after 360° , the position calculation starts from 0° again.
68.02 SYNC GEAR MUL	Same as for 68.03 SYNC GEAR DIV	Synchron gear ratio is 1.
62.14 CYCLIC CORR MODE	(2) Cor Mas Ref	Master (motor) reference correction
62.15 TRIG PROBE1	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1. Source of the master (motor) position reference latching command (proximity switch signal source)
62.16 PROBE1 POS	60°	Reference position for the master (motor) reference position probe



t_1 : Rising edge of encoder digital input D11 signal (proximity switch signal) is detected when the master (motor) position should be 60° . The used position reference is 90° (stored to signal [4.03 PROBE1 POS MEAS](#)).

The master reference correction function calculates the position error, [4.05 CYCLIC POS ERR](#), which is the difference between the master (motor) position and the reference position:

$$\text{4.05 CYCLIC POS ERR} = \text{62.16 PROBE1 POS} - \text{4.03 PROBE1 POS MEAS} = 60^\circ - 90^\circ = -30^\circ$$

t_2 : Error has been corrected and the follower (load) is in line with the master (motor). Cyclic function is ready for a new correction if necessary.


Master/Follower distance correction

The purpose of the master/follower distance correction is to measure the distance between the two probe positions and compare it with the distance between reference positions [62.16 PROBE1 POS](#) and [62.18 PROBE2 POS](#). If there is a deviation, a correction is carried out on both the drive synchron reference [4.16 SYNC REF GEARED](#) and actual position [1.12 POS ACT](#).

Note: In master/follower distance correction, the follower must always be in synchron control mode. If the follower is not used in synchron control mode, adjusting the drive synchron reference ([4.16 SYNC REF GEARED](#)) will not affect the operation of the drive, and the correction cannot be carried out properly.

Example 1: Roll-over axis application. Master and follower proximity switches are located at 0°.

Parameter	Setting	Information
60.02 POS AXIS MODE	(1) Rollover	Positioning is between 0 and 1 revolutions, ie, after 360°, the position calculation starts from 0° again.
60.05 POS UNIT	(1) Degree	All position values are in degrees
68.02 SYNC GEAR MUL	Same as for 68.03 SYNC GEAR DIV	Synchron gear ratio is 1.
62.14 CYCLIC CORR MODE	(5) Cor M/F Dist	Cyclic master/follower distance correction
62.15 TRIG PROBE1	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1. Source of the actual position latching command (proximity switch signal source)
62.17 TRIG PROBE2	(3) ENC1 DI2 _-	Rising edge of encoder 1 digital input DI2. Source of the master position latching command (proximity switch signal source)
62.16 PROBE1 POS	0°	Reference position for the actual position probe
62.18 PROBE2 POS	-120°	Reference position for the master position probe, ie, follower is 120° [(0°-120°)-(0°-0°)] behind the master.



t_1 : Rising edge of encoder DI2 signal (proximity switch signal) is detected when the master position is 0° . The follower position is -130° (stored to signal [4.04 PROBE2 POS MEAS](#)).

t_2 : Rising edge of encoder DI1 signal (proximity switch signal) is detected when the follower position is 0° . The actual position of the encoder is -30° (stored to signal [4.03 PROBE1 POS MEAS](#)). Distance between the follower position and the actual position is $0^\circ - (-30^\circ) = 30^\circ$.

According to parameter [62.16 PROBE1 POS](#) and [62.18 PROBE2 POS](#) settings the follower should be 120° behind the master.

The following phase shift between the master and follower is calculated and stored as reference error [4.05 CYCLIC POS ERR](#).

$$(\text{62.18 PROBE2 POS} - \text{4.04 PROBE2 POS MEAS}) - (\text{62.16 PROBE1 POS} - \text{4.03 PROBE1 POS MEAS}) = [-120^\circ - (-130^\circ)] - [0^\circ - (-30^\circ)] = -20^\circ$$

t_3 : Error has been corrected and the follower is 120° behind the master. Cyclic function is ready for a new correction if necessary.

Note 1: Only after the active correction is finished is the next position latching enabled.


Note 2: The cyclic corrections are always performed along the shortest path. This must be taken into account in all rollover applications.

Note 3: In rollover applications, the correction range is limited to $\pm 180^\circ$.


Example 2: Linear axis application

Two conveyer systems are synchronised using two encoders. The follower is in synchron control and follows the master encoder 2 position.

Note: In linear axis applications, only the difference between the master and follower positions is corrected.



Parameter	Setting	Information
60.02 POS AXIS MODE	(0) Linear	Positioning between minimum position 60.14 MINIMUM POS and maximum position 60.13 MAXIMUM POS
60.05 POS UNIT	(2) Meter	All position values are in metres
67.01 SYNC REF SEL	(8) POS 2ND ENC	Synchron position reference (master position) from encoder 2.
68.07 SYNCHRON MODE	(0) Absolute	Absolute synchronisation of the follower. The follower follows the master position after start.
62.14 CYCLIC CORR MODE	(5) Cor M/F Dist	Cyclic master follower distance correction
62.15 TRIG PROBE1	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1. Source of the actual position latching command (proximity switch signal source)
62.17 TRIG PROBE2	(17) ENC2 DI2 _-	Rising edge of encoder 2 digital input DI2. Source of the master position reference latching command (proximity switch signal source)
62.16 PROBE1 POS	0,015 m	Reference position for the actual position probe
62.18 PROBE2 POS	0,025 m	Reference position for the master position probe



t_1 : Rising edge of encoder digital input DI1 signal (proximity switch signal) is detected. The actual position is 20 mm (stored to signal **4.04 PROBE2 POS MEAS**). The distance between the follower position and the actual position is $15 \text{ mm} - 20 \text{ mm} = -5 \text{ mm}$

t_2 : Rising edge of encoder digital input DI2 signal (proximity switch signal) is detected when the actual position is 40 mm (stored to signal **4.03 PROBE1 POS MEAS**).

According to parameter **62.16 PROBE1 POS** and **62.18 PROBE2 POS** settings, the follower should be 10 mm behind the master.

The following correction is calculated and stored as reference error **4.05 CYCLIC POS ERR**:

$$(\mathbf{62.18 \text{ PROBE2 POS} - 4.04 \text{ PROBE2 POS MEAS}}) - (\mathbf{62.16 \text{ PROBE1 POS} - 4.03 \text{ PROBE1 POS MEAS}}) = (25 \text{ mm} - 40 \text{ mm}) - (15 \text{ mm} - 20 \text{ mm}) = -10 \text{ mm}$$


t_3 : Error has been corrected and the follower is 10 mm behind the master. Cyclic function is ready for a new correction if necessary.

Distance correction with one probe


The purpose is to measure the distance between two consecutive latches from one probe and compare it with the distance of the reference positions [62.16 PROBE1 POS](#) and [62.18 PROBE2 POS](#). If there is a deviation, a corresponding correction is carried out on drive actual position [1.12 POS ACT](#). Both latches use the same latch signal source (eg, encoder interface digital input DI1) and latch command (eg, rising edge). If the application requires different latch commands, see section [Distance correction with two probes](#) on page 83.

Example:

The following figure shows a conveyor system where a box should be positioned. The conveyor belt is marked every 40 mm.



Parameter	Setting	Information
60.02 POS AXIS MODE	(0) Linear	Positioning between minimum position 60.14 MINIMUM POS and maximum position 60.13 MAXIMUM POS
60.05 POS UNIT	(2) Meter	All position values are in metres
62.14 CYCLIC CORR MODE	(3) 1 Probe Dist	Distance correction with one probe
62.15 TRIG PROBE1	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1. Source of the actual position latching command (proximity switch signal source)
62.16 PROBE1 POS	0 m	Reference position for position probe 1
62.18 PROBE2 POS	0.040 m (= 40 mm)	Reference position for position probe 2



- Rising edge of encoder DI1 (proximity switch signal) is detected at the first mark of the belt. Position 0 mm is stored to signal [4.03 PROBE1 POS MEAS](#).
- Next rising edge of encoder DI1 (proximity switch signal) is detected at the second mark of the belt. Position 30 mm is stored to signal [4.04 PROBE2 POS MEAS](#).
- The reference distance between the marks is 40 mm and the measured distance between the marks is 30 mm, thus the error is 10 mm:

$$[(62.18 \text{ PROBE2 POS} - 62.16 \text{ PROBE1 POS}) - (4.04 \text{ PROBE2 POS MEAS} - 4.03 \text{ PROBE1 POS MEAS})] = (40 - 0) - (30 - 0) = 10 \text{ mm}$$

Note: Only after the active correction is finished is the next position latching enabled.


Distance correction with two probes

The purpose is to measure the distance between two consecutive latches from two probes and compare it with the distance between the reference positions [62.16 PROBE1 POS](#) and [62.18 PROBE2 POS](#). If there is a deviation, a corresponding correction is carried out on the drive actual position [1.12 POS ACT](#). The latches use different latch sources (eg, encoder interface digital inputs DI1 and DI2) and latch commands (eg, rising and falling edge).


In special applications, this correction function can also be executed by using two consecutive latches from one probe. The latches use the same latch source (eg, encoder digital input DI1) and different latch commands (eg, rising and falling edge).

Example:

The following figure shows a conveyer system where a box should be positioned. The conveyer belt is marked every 60 mm.



Parameter	Setting	Information
60.02 POS AXIS MODE	(0) Linear	Positioning between minimum position 60.14 MINIMUM POS and maximum position 60.13 MAXIMUM POS
60.05 POS UNIT	(2) Meter	All position values are in metres
62.14 CYCLIC CORR MODE	(4) 2 Probe Dist	Distance correction with two probes
62.15 TRIG PROBE1	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1. Source of the actual position latching command (proximity switch signal source)
62.17 TRIG PROBE2	(3) ENC1 DI2 _-	Falling edge of encoder 1 digital input DI2. Source of the actual position reference latching command (proximity switch signal source)
62.16 PROBE1 POS	0 m	Reference position for actual position probe 1
62.18 PROBE2 POS	0.060 m (=60 mm)	Reference position for actual position probe 2



- Rising edge of encoder DI1 (proximity switch signal) is detected at the first mark of the belt. Position 0 mm is stored to signal [4.03 PROBE1 POS MEAS](#).
- Falling edge of encoder DI2 (proximity switch signal) is detected at the second mark of the belt. Position 40 mm is stored to signal [4.04 PROBE2 POS MEAS](#).
- The reference distance between the marks is 60 mm and the measured distance between the marks is 40 mm, thus the error is 20 mm:

$$[(62.18 \text{ PROBE2 POS} - 62.16 \text{ PROBE1 POS}) - (4.04 \text{ PROBE2 POS MEAS} - 4.03 \text{ PROBE1 POS MEAS})] = (60 - 0) - (40 - 0) = 20 \text{ mm}$$

Note: Only after the active correction is finished is the next position latching enabled.

Emergency stop

Note: The user is responsible for installing the emergency stop devices and all the additional devices needed for the emergency stop to fulfil the required emergency stop category classes.

The emergency stop signal is connected to the digital input which is selected as the source for the emergency stop activation (parameter [10.10 EM STOP OFF3](#) or [10.11 EM STOP OFF1](#)). Emergency stop can also be activated through fieldbus ([2.12 FBA MAIN CW](#)).

Note: When an emergency stop signal is detected, the emergency stop function cannot be cancelled even though the signal is cancelled.

For more information, refer to *Application Guide: Functional Safety Solutions with ACSM1 Drives* (3AUA0000031517 [English]).

Miscellaneous features

Backup and restore of drive contents

General

The drive offers a possibility of backing up numerous settings and configurations to external storage such as a PC file (using the DriveStudio tool) and the internal memory of the control panel. These settings and configurations can then be restored to the drive, or a number of drives.

Backup using DriveStudio includes

- Parameter settings
- User parameter sets
- Application program
- CAM files.

Backup using the drive control panel includes

- Parameter settings
- User parameter sets.

For detailed instructions for performing the backup/restore, refer to the DriveStudio and control panel documentation.

Limitations

A backup can be done without interfering with drive operation, but restoring a backup always resets and reboots the control unit, so restore is not possible with the drive running.

Backup/restore between different program variants (such as the motion control program and the speed and torque control program) is not possible.

Restoring backup files from one firmware version to another is considered risky, so the results should be carefully observed and verified when done for the first time. The parameters and application support are bound to change between firmware versions and backups are not always compatible with other firmware versions even if restore is allowed by the backup/restore tool. Before using the backup/restore functions between different firmware versions, refer to the release notes of each version.

Applications should not be transferred between different firmware versions. Contact the supplier of the application when it needs to be updated for a new firmware version.

Parameter restore

Parameters are divided into three different groups that can be restored together or individually:

- Motor configuration parameters and identification (ID) run results
- Fieldbus adapter and encoder settings
- Other parameters.

For example, retaining the existing motor ID run results in the drive will make a new motor ID run unnecessary.

Restore of individual parameters can fail for the following reasons:

- The restored value does not fall within the minimum and maximum limits of the drive parameter
- The type of the restored parameter is different from that in the drive
- The restored parameter does not exist in the drive (often the case when restoring the parameters of a new firmware version to a drive with an older version)
- The backup does not contain a value for the drive parameter (often the case when restoring the parameters of an old firmware version to a drive with a newer version).

In these cases, the parameter is not restored; the backup/restore tool will warn the user and offer a possibility to set the parameter manually.

User parameter sets

The drive has four user parameter sets that can be saved to the permanent memory and recalled using drive parameters. It is also possible to use digital inputs to switch between different user parameter sets. See the descriptions of parameters [16.09...16.12](#).

A user parameter set contains all values of parameter groups 10 to 99 (except the fieldbus communication configuration settings).

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with one drive, the motor ID run needs to be performed with each motor and saved to different user sets. The appropriate set can then be recalled when the motor is switched.

Drive-to-drive link

The drive-to-drive link is a daisy-chained RS-485 transmission line that allows basic master/follower communication with one master drive and multiple followers. For more information, see [Appendix B – Drive-to-drive link](#).

Fan control logic

The fan operation can be controlled via parameter [46.13 FAN CTRL MODE](#). The parameter provides the following four operation modes: Normal, Force OFF, Force ON and Advanced. The control logic (Normal or Advanced) can be overridden by forcing the fan ON or OFF in which case the fan is running always or never.

In the Normal mode the fan operation is based on the ON/OFF status of the modulator. In addition, the fan runs a predetermined period after the modulator has been switched OFF, which prevents the fan from starting and stopping unnecessarily when the modulator is inactive only for a short period.

In the Advanced fan control mode, the fan operation is based on the measured temperature of power stage, braking chopper (BC), interface board (INT board) and DC link voltage. The fan is started if the temperature of the power stage or INT board or BC rises over the predetermined level. Also an exceptionally high long-term DC link voltage generates the running command for the fan. The fan is stopped if the power stage, braking chopper and INT board are cool and the DC link voltage is below the limit.

With the Normal or Advanced mode the DC voltage activation level for the fan ON command is 640 VDC.

The fan runs a short period after a power-up regardless of parameter [46.13 FAN CTRL MODE](#) to remove moisture and dust from the machinery.

Default connections of the control unit

What this chapter contains

This chapter shows the default control connections of the JCU Control Unit.

More information on the connectivity of the JCU is given in the *Hardware Manual* of the drive.

Notes:

*Total maximum current:
200 mA

1) Selected by par. 12.01
DIO1 CONF.

2) Selected by par. 12.02
DIO2 CONF.

3) Selected by par. 12.03
DIO3 CONF.

4) Selected by jumper J1.

5) Selected by jumper J2.

Current:

J1/2  | A1x |

Voltage:

J1/2  | A1x |

External power input 24 V DC, 1.6 A		+24VI	1
		GND	2

X1

Relay output: Brake close/open 250 V AC / 30 V DC 2 A		NO	1
		COM	2
		NC	3

X2

+24 V DC*		+24VD	1
Digital I/O ground		DGND	2
Digital input 1: Stop/start (par. 10.02 and 10.05)		DI1	3
Digital input 2: EXT1/EXT2 (par. 34.01)		DI2	4
+24 V DC*		+24VD	5
Digital I/O ground		DGND	6
Digital input 3: Fault reset (par. 10.08)		DI3	7
Digital input 4: Positioning start (par. 65.03/65.11)		DI4	8
+24 V DC*		+24VD	9
Digital I/O ground		DGND	10
Digital input 5: Position reference set 1/2 (par. 65.02)		DI5	11
Digital input 6: Homing start (par. 62.03 and 34.02)		DI6	12
+24 V DC*		+24VD	13
Digital I/O ground		DGND	14
Digital input/output 1 ¹⁾ : Ready		DIO1	15
Digital input/output 2 ²⁾ : Running		DIO2	16
+24 V DC*		+24VD	17
Digital I/O ground		DGND	18
Digital input/output 3 ³⁾ : Fault		DIO3	19

X3

Reference voltage (+)		+VREF	1
Reference voltage (-)		-VREF	2
Ground		AGND	3
Analogue input 1 (mA or V) ⁴⁾ : Speed reference (par. 24.01)		AI1+	4
		AI1-	5
Analogue input 2 (mA or V) ⁵⁾ : Torque reference (par. 32.01)		AI2+	6
		AI2-	7
AI1 current/voltage selection			J1
AI2 current/voltage selection			J2
Thermistor input		TH	8
Ground		AGND	9
Analogue output 1 (mA): Output current		AO1 (I)	10
Analogue output 2 (V): Actual speed		AO2 (U)	11
Ground		AGND	12

X4





Drive-to-drive link termination			J3
Drive-to-drive link		B	1
		A	2
		BGND	3

X5

Safe Torque Off. Both circuits must be closed for the drive to start. See the appropriate drive hardware manual.		OUT1	1
		OUT2	2
		IN1	3
		IN2	4

X6

Control panel connection			
Memory unit connection			



Parameters and firmware blocks

What this chapter contains

This chapter lists and describes the parameters provided by the firmware.

Types of parameters

Parameters are user-adjustable operation instructions of the drive (groups 10...99). There are four basic types of parameters: Actual signals, value parameters, value pointer parameters and bit pointer parameters.

Actual signal

Type of parameter that is the result of a measurement or calculation by the drive. Actual signals can be monitored, but not adjusted, by the user. Actual signals are typically contained within parameter groups 1...9.

For additional actual signal data, eg, update cycles and fieldbus equivalents, see chapter [Parameter data](#).

Value parameter

A value parameter has a fixed set of choices or a setting range.

Example 1: Motor phase loss supervision is activated by selecting (1) [Fault](#) from the selection list of parameter [46.04 MOT PHASE LOSS](#).

Example 2: The motor nominal power (kW) is set by writing the appropriate value to parameter [99.10 MOT NOM POWER](#), eg, 10.

Value pointer parameter

A value pointer parameter points to the value of another parameter. The source parameter is given in format **P.xx.yy**, where xx = Parameter group; yy = Parameter index. In addition, value pointer parameters may have a set of pre-selected choices.

Example: Motor current signal, [1.05 CURRENT PERC](#), is connected to analogue output AO1 by setting parameter [15.01 AO1 PTR](#) to value P.01.05.

Bit pointer parameter

A bit pointer parameter points to the value of a bit in another parameter, or can be fixed to 0 (FALSE) or 1 (TRUE). In addition, bit pointer parameters may have a set of pre-selected choices.

When adjusting a bit pointer parameter on the optional control panel, CONST is selected in order to fix the value to 0 (displayed as "C.FALSE") or 1 ("C.TRUE"). POINTER is selected to define a source from another parameter.

A pointer value is given in format **P.xx.yy.zz**, where xx = Parameter group, yy = Parameter index, zz = Bit number.

Example: Digital input DI5 status, [2.01 DI STATUS](#) bit 4, is used for brake supervision by setting parameter [35.02 BRAKE ACKNOWL](#) to value P.02.01.04.


Note: Pointing to a non-existing bit will be interpreted as 0 (FALSE).

For additional parameter data, eg, update cycles and fieldbus equivalents, see chapter [Parameter data](#).

Firmware blocks

Firmware blocks accessible from the DriveSPC PC tool are described in the parameter group that contains the most of the block inputs/outputs. Whenever a block has inputs or outputs outside the current parameter group, a reference is given. Likewise, parameters have a reference to the firmware block they are included in (if any).

Note: Not all parameters are available through firmware blocks.



1	Inputs
2	Outputs
3	Input parameter values
4	Pointer parameter indicator "<"
5	Parameter 26.01 is set to value P.1.1, ie, parameter 1.01 SPEED ACT. The "7" means the parameter can be found on page 7 of DriveSPC.
6	Information of the block internal execution order ("TLF4") and time level ("250 μsec"). Time level, ie, update cycle, is application-specific. See the time level of the block in DriveSPC.
7	Firmware block ID number in the application program
8	Firmware block execution order for the selected update cycle ID

Group 01 ACTUAL VALUES

This group contains basic actual signals for monitoring the drive.

Firmware block: ACTUAL VALUES (1)		
1.01	SPEED ACT	FW block: SPEED FEEDBACK (page 151)
	Filtered actual speed in rpm. Used speed feedback is defined by parameter 22.01 SPEED FB SEL. Filter time constant can be adjusted by parameter 22.02 SPEED ACT FTIME.	
1.02	SPEED ACT PERC	FW block: ACTUAL VALUES (see above)
	Actual speed in percent of the motor synchronous speed.	
1.03	FREQUENCY	FW block: ACTUAL VALUES (see above)
	Estimated drive output frequency in Hz.	
1.04	CURRENT	FW block: ACTUAL VALUES (see above)
	Measured motor current in A.	
1.05	CURRENT PERC	FW block: ACTUAL VALUES (see above)
	Motor current in percent of the nominal motor current.	
1.06	TORQUE	FW block: ACTUAL VALUES (see above)
	Motor torque in percent of the motor nominal torque.	
1.07	DC-VOLTAGE	FW block: ACTUAL VALUES (see above)
	Measured intermediate circuit voltage in V.	
1.08	ENCODER 1 SPEED	FW block: ENCODER (page 259)
	Encoder 1 speed in rpm.	
1.09	ENCODER 1 POS	FW block: ENCODER (page 259)
	Actual position of encoder 1 within one revolution.	

1.10	ENCODER 2 SPEED	FW block: ENCODER (page 259)
	Encoder 2 speed in rpm.	
1.11	ENCODER 2 POS	FW block: ENCODER (page 259)
	Actual position of encoder 2 within one revolution.	
1.12	POS ACT	FW block: POS FEEDBACK (page 221)
	Actual position of the encoder. The unit depends on parameter 60.05 POS UNIT selection.	
1.13	POS 2ND ENC	FW block: POS FEEDBACK (page 221)
	Scaled actual position of encoder 2 in revolutions.	
1.14	SPEED ESTIMATED	FW block: ACTUAL VALUES (see above)
	Estimated motor speed in rpm.	
1.15	TEMP INVERTER	FW block: ACTUAL VALUES (see above)
	Measured temperature of the heatsink in Celsius.	
1.16	TEMP BC	FW block: ACTUAL VALUES (see above)
	Braking chopper IGBT temperature in Celsius.	
1.17	MOTOR TEMP	FW block: MOT THERM PROT (page 194)
	Measured motor temperature in Celsius when a KTY sensor is used. (With a PTC sensor, the value is always 0.)	
1.18	MOTOR TEMP EST	FW block: MOT THERM PROT (page 194)
	Estimated motor temperature in Celsius.	
1.19	USED SUPPLY VOLT	FW block: VOLTAGE CTRL (page 203)
	Either the user-given supply voltage (parameter 47.04 SUPPLY VOLTAGE), or, if auto-identification is enabled by parameter 47.03 SUPPLVOLTAUTO-ID , the automatically determined supply voltage.	
1.20	BRAKE RES LOAD	FW block: ACTUAL VALUES (see above)
	Estimated temperature of the braking resistor. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 48.04 BR POWER MAX CNT .	
1.21	CPU USAGE	FW block: None
	Microprocessor load in percent.	
1.22	INVERTER POWER	FW block: ACTUAL VALUES (see above)
	Drive output power in kilowatts.	
1.26	ON TIME COUNTER	FW block: ACTUAL VALUES (see above)
	This counter runs when the drive is powered. The counter can be reset using the DriveStudio tool.	

1.27	RUN TIME COUNTER	FW block: ACTUAL VALUES (see above)
	Motor run time counter. The counter run when the drive modulates. The counter can be reset using the DriveStudio tool.	
1.28	FAN ON-TIME	FW block: ACTUAL VALUES (see above)
	Running time of the drive cooling fan. Can be reset by entering 0.	
1.31	MECH TIME CONST	FW block: ACTUAL VALUES (see above)
	Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. See parameter 28.16 PI TUNE MODE on page 175 .	
1.38	TEMP INT BOARD	FW block: ACTUAL VALUES (see above)
	Measured temperature of the interface board in degrees Celsius.	
1.39	OUTPUT VOLTAGE	FW block: None
	Calculated motor voltage.	
1.42	FAN START COUNT	FW block: None
	Number of times the drive cooling fan has been started.	

Group 02 I/O VALUES

This group contains information on the I/Os of the drive.

2.01	DI STATUS	FW block: DI (page 133)
	Status word of the digital inputs. Example: 000001 = DI1 is on, DI2 to DI6 are off.	
2.02	RO STATUS	FW block: RO (page 133)
	Status of relay output. 1 = RO is energized.	
2.03	DIO STATUS	FW blocks: DIO1 (page 131), DIO2 (page 131), DIO3 (page 131)
	Status word of digital inputs/outputs DIO1...3. Example: 001 = DIO1 is on, DIO2 and DIO3 are off.	
2.04	AI1	FW block: AI1 (page 135)
	Analogue input AI1 value in V or mA. The type is selected with jumper J1 on the JCU Control Unit.	
2.05	AI1 SCALED	FW block: AI1 (page 135)
	Scaled value of analogue input AI1. See parameters 13.04 AI1 MAX SCALE and 13.05 AI1 MIN SCALE .	
2.06	AI2	FW block: AI2 (page 136)
	Analogue input AI2 value in V or mA. The type is selected with jumper J2 on the JCU Control Unit.	
2.07	AI2 SCALED	FW block: AI2 (page 136)
	Scaled value of analogue input AI2. See parameters 13.09 AI2 MAX SCALE and 13.10 AI2 MIN SCALE .	
2.08	AO1	FW block: AO1 (page 139)
	Analogue output AO1 value in mA	
2.09	AO2	FW block: AO2 (page 140)
	Analogue output AO2 value in V	
2.10	DIO2 FREQ IN	FW block: DIO2 (page 131)
	Scaled value of DIO2 when it is used as a frequency input. See parameters 12.02 DIO2 CONF and 12.14 DIO2 F MAX...12.17 DIO2 F MIN SCALE .	
2.11	DIO3 FREQ OUT	FW block: DIO3 (page 131)
	Frequency output value of DIO3 when it is used as a frequency output. See parameters 12.03 DIO3 CONF and 12.08 DIO3 F MAX...12.11 DIO3 F MIN SCALE .	

2.12	FBA MAIN CW	FW block: FIELD BUS (page 207)			
Control Word for fieldbus communication. Log. = Logical combination (ie, Bit AND/OR Selection parameter). Par. = Selection parameter. See State diagram on page 433.					
Bit	Name	Val.	Information	Log.	Par.
0	STOP*	1	Stop according to the stop mode selected by 11.03 STOP MODE or according to the requested stop mode (bits 2...6). Note: Simultaneous STOP and START commands result in a stop command.	OR	10.02 , 10.03 , 10.05 , 10.06
		0	No operation		
1	START	1	Start. Note: Simultaneous STOP and START commands result in a stop command.	OR	10.02 , 10.03 , 10.05 , 10.06
		0	No operation		
2	STPMODE EM OFF*	1	Emergency OFF2 (bit 0 must be 1): Drive is stopped by cutting off the motor power supply (the inverter IGBTs are blocked). The motor coasts to stop. The drive will restart only with the next rising edge of the start signal when the run enable signal is on.	AND	-
		0	No operation		
3	STPMODE EM STOP*	1	Emergency stop OFF3 (bit 0 must be 1): Stop within the time defined by 25.11 EM STOP TIME .	AND	10.10
		0	No operation		
4	STPMODE OFF1*	1	Emergency stop OFF1 (bit 0 must be 1): Stop along the currently active deceleration ramp.	AND	10.11
		0	No operation		
5	STPMODE RAMP*	1	Stop along the currently active deceleration ramp.	-	11.03
		0	No operation		
6	STPMODE COAST*	1	Coast to stop.	-	11.03
		0	No operation		
7	RUN ENABLE	1	Activate run enable.	AND	10.09
		0	Activate run disable.		
8	RESET	0->1	Fault reset if an active fault exists.	OR	10.08
		other	No operation		
9	JOGGING 1	1	Activate jogging function 1. See section Jogging on page 52.	OR	10.07
		0	Jogging function 1 disabled		
* If all stop mode bits 2...6 are 0, stop mode is selected by 11.03 STOP MODE . Coast stop (bit 6) overrides the emergency stop (bit 2/3/4). Emergency stop overrides the normal ramp stop (bit 5).					

2.12		FBA MAIN CW (continued from previous page)				
Bit	Name	Val.	Information	Log.	Par.	
10	JOGGING 2	1	Activate jogging function 2. See section Jogging on page 52 .	OR	10.14	
		0	Jogging function 2 disabled			
11	REMOTE CMD	1	Fieldbus control enabled	-	-	
		0	Fieldbus control disabled			
12	RAMP OUT 0	1	Force Ramp Function Generator output to zero. Drive ramps to a stop (current and DC voltage limits in force).	-	-	
		0	No operation			
13	RAMP HOLD	1	Halt ramping (Ramp Function Generator output held).	-	-	
		0	No operation			
14	RAMP IN 0	1	Force Ramp Function Generator input to zero.	-	-	
		0	No operation			
15	EXT1 / EXT2	1	Switch to external control location EXT2.	OR	34.01	
		0	Switch to external control location EXT1.			
16	REQ STARTINH	1	Activate start inhibit.	-	-	
		0	No start inhibit			
17	LOCAL CTL	1	Request local control for Control Word. Used when the drive is controlled via PC tool or panel or through local fieldbus. - Local fieldbus: Transfer to fieldbus local control (control via fieldbus control word or reference). Fieldbus steals the control. - Panel or PC tool: Transfer to local control.	-	-	
		0	Request external control.			
18	FBLOCAL REF	1	Request fieldbus local control.	-	-	
		0	No fieldbus local control			
19	ABS POSIT	1	Use absolute positioning.	OR	65.09 , 65.17 bit 4	
		0	Use relative positioning.			
20	POS START MODE	1	Select pulse start for positioning: Start by rising edge of a pulse.	OR	65.24	
		0	Select normal start for positioning: Start by signal rising edge. The signal has to stay TRUE during the positioning task.			

2.12	FBA MAIN CW (continued from previous page)				
Bit	Name	Val.	Information	Log.	Par.
21	POSITION- ING ENA	1	Enable position profile generator.	OR	66.05
		0	Disable position profile generator.		
22	PO REF LIM ENA	1	Enable position reference.	OR	70.03
		0	Disable position reference. Position reference speed limit is set to zero. Positioning task is rejected.		
23	Not in use				
24	CHG SET IMMED	1	Interrupt actual positioning and start next positioning.	-	-
		0	Finish actual positioning and then start next positioning.		
25	POS START	1	Activate positioning start. Operation depends on selected start mode (bit 20 POS START MODE).	OR	65.03, 65.11
		0	Deactivate positioning start.		
26	START HOMING	1	Start homing.	OR	62.03
		0	Normal operation.		
27	Not in use				
28	CW B28		Freely programmable control bits.	-	-
29	CW B29				
30	CW B30				
31	CW B31				

2.13	FBA MAIN SW	FW block: FIELD BUS (page 207)	
Status Word for fieldbus communication. See State diagram on page 433.			
Bit	Name	Value	Information
0	READY	1	Drive is ready to receive start command.
		0	Drive is not ready.
1	ENABLED	1	External run enable signal is received.
		0	No external run enable signal is received.
2	RUNNING	1	Drive is modulating.
		0	Drive is not modulating.
3	REF RUNNING	1	Normal operation is enabled. Drive is running and following given reference.
		0	Normal operation is disabled. Drive is not following given reference (for example, modulating during magnetization).
4	EM OFF (OFF2)	1	Emergency OFF2 is active.
		0	Emergency OFF2 is inactive.
5	EM STOP (OFF3)	1	Emergency stop OFF3 (ramp stop) is active.
		0	Emergency OFF3 is inactive.
6	ACK STARTINH	1	Start inhibit is active.
		0	Start inhibit is inactive.
7	ALARM	1	An alarm is active. See chapter Fault tracing .
		0	No alarm is active.
8	AT SETPOINT	1	Drive is at setpoint. Actual value equals reference value (ie, the difference between the actual speed and the speed reference is within the speed window defined by 26.07 SPEED WINDOW).
		0	Drive has not reached setpoint.
9	LIMIT	1	Operation is limited by any torque or current limit.
		0	Operation is within torque/current limits.
10	ABOVE LIMIT	1	Actual speed exceeds the defined limit, 22.07 ABOVE SPEED LIM.
		0	Actual speed is within the defined limits.
11	EXT2 ACT	1	External control location EXT2 is active.
		0	External control location EXT1 is active.
12	LOCAL FB	1	Fieldbus local control is active.
		0	Fieldbus local control is inactive.
13	ZERO SPEED	1	Drive speed is below limit set by par. 22.05 ZERO SPEED LIMIT .
		0	Drive has not reached zero speed limit.
14	REV ACT	1	Drive is running in reverse direction.
		0	Drive is running in forward direction.
15	Not in use		
16	FAULT	1	Fault is active. See chapter Fault tracing .
		0	No fault is active.
17	LOCAL PANEL	1	Local control is active, ie, drive is controlled from PC tool or control panel.
		0	Local control is inactive.

2.13	FBA MAIN SW (continued from previous page)																																																																															
	<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">18</td> <td rowspan="2">FOLLOWING ERROR</td> <td>1</td> <td>The difference between the reference and the actual position is within the defined following error window 71.09 FOLLOW ERR WIN.</td> </tr> <tr> <td>0</td> <td>The difference between the reference and the actual position is outside the defined following error window.</td> </tr> <tr> <td rowspan="2">19</td> <td rowspan="2">TGT REACHED</td> <td>1</td> <td>Target position is reached.</td> </tr> <tr> <td>0</td> <td>Target position is not reached.</td> </tr> <tr> <td rowspan="2">20</td> <td rowspan="2">HOMING DONE</td> <td>1</td> <td>Homing sequence is completed.</td> </tr> <tr> <td>0</td> <td>Homing sequence is not completed.</td> </tr> <tr> <td rowspan="2">21</td> <td rowspan="2">TRAV TASK ACK</td> <td>1</td> <td>New positioning task or setpoint is accepted.</td> </tr> <tr> <td>0</td> <td>No operation</td> </tr> <tr> <td rowspan="2">22</td> <td rowspan="2">MOVING</td> <td>1</td> <td>Positioning task is active. Drive speed is $< > 0$.</td> </tr> <tr> <td>0</td> <td>Positioning task is completed or drive is at standstill.</td> </tr> <tr> <td rowspan="2">23</td> <td rowspan="2">IP MODE ACTIVE</td> <td>1</td> <td>Position reference generator is active.</td> </tr> <tr> <td>0</td> <td>Position reference generator is inactive.</td> </tr> <tr> <td rowspan="2">24</td> <td rowspan="2">REG LEVEL</td> <td>1</td> <td>Position latch signal 1 is active (source selected by parameter 62.15 TRIG PROBE1).</td> </tr> <tr> <td>0</td> <td>Position latch signal 1 is inactive.</td> </tr> <tr> <td rowspan="2">25</td> <td rowspan="2">POSITIVE LIMIT</td> <td>1</td> <td>Positive limit switch is active (source selected by parameter 62.06 POS LIMIT SWITCH).</td> </tr> <tr> <td>0</td> <td>Positive limit switch is inactive.</td> </tr> <tr> <td rowspan="2">26</td> <td rowspan="2">NEGATIVE LIMIT</td> <td>1</td> <td>Negative limit switch is active (source selected by parameter 62.05 NEG LIMIT SWITCH).</td> </tr> <tr> <td>0</td> <td>Negative limit switch is inactive.</td> </tr> <tr> <td rowspan="2">27</td> <td rowspan="2">REQUEST CTL</td> <td>1</td> <td>Control word is requested from fieldbus.</td> </tr> <tr> <td>0</td> <td>Control word is not requested from fieldbus.</td> </tr> <tr> <td>28</td> <td>SW B28</td> <td></td> <td rowspan="4">Programmable status bits (unless fixed by the used profile). See parameters 50.08...50.11 and the user manual of the fieldbus adapter.</td> </tr> <tr> <td>29</td> <td>SW B29</td> <td></td> </tr> <tr> <td>30</td> <td>SW B30</td> <td></td> </tr> <tr> <td>31</td> <td>SW B31</td> <td></td> </tr> </tbody> </table>	Bit	Name	Value	Information	18	FOLLOWING ERROR	1	The difference between the reference and the actual position is within the defined following error window 71.09 FOLLOW ERR WIN .	0	The difference between the reference and the actual position is outside the defined following error window.	19	TGT REACHED	1	Target position is reached.	0	Target position is not reached.	20	HOMING DONE	1	Homing sequence is completed.	0	Homing sequence is not completed.	21	TRAV TASK ACK	1	New positioning task or setpoint is accepted.	0	No operation	22	MOVING	1	Positioning task is active. Drive speed is $< > 0$.	0	Positioning task is completed or drive is at standstill.	23	IP MODE ACTIVE	1	Position reference generator is active.	0	Position reference generator is inactive.	24	REG LEVEL	1	Position latch signal 1 is active (source selected by parameter 62.15 TRIG PROBE1).	0	Position latch signal 1 is inactive.	25	POSITIVE LIMIT	1	Positive limit switch is active (source selected by parameter 62.06 POS LIMIT SWITCH).	0	Positive limit switch is inactive.	26	NEGATIVE LIMIT	1	Negative limit switch is active (source selected by parameter 62.05 NEG LIMIT SWITCH).	0	Negative limit switch is inactive.	27	REQUEST CTL	1	Control word is requested from fieldbus.	0	Control word is not requested from fieldbus.	28	SW B28		Programmable status bits (unless fixed by the used profile). See parameters 50.08...50.11 and the user manual of the fieldbus adapter.	29	SW B29		30	SW B30		31	SW B31			
Bit	Name	Value	Information																																																																													
18	FOLLOWING ERROR	1	The difference between the reference and the actual position is within the defined following error window 71.09 FOLLOW ERR WIN .																																																																													
		0	The difference between the reference and the actual position is outside the defined following error window.																																																																													
19	TGT REACHED	1	Target position is reached.																																																																													
		0	Target position is not reached.																																																																													
20	HOMING DONE	1	Homing sequence is completed.																																																																													
		0	Homing sequence is not completed.																																																																													
21	TRAV TASK ACK	1	New positioning task or setpoint is accepted.																																																																													
		0	No operation																																																																													
22	MOVING	1	Positioning task is active. Drive speed is $< > 0$.																																																																													
		0	Positioning task is completed or drive is at standstill.																																																																													
23	IP MODE ACTIVE	1	Position reference generator is active.																																																																													
		0	Position reference generator is inactive.																																																																													
24	REG LEVEL	1	Position latch signal 1 is active (source selected by parameter 62.15 TRIG PROBE1).																																																																													
		0	Position latch signal 1 is inactive.																																																																													
25	POSITIVE LIMIT	1	Positive limit switch is active (source selected by parameter 62.06 POS LIMIT SWITCH).																																																																													
		0	Positive limit switch is inactive.																																																																													
26	NEGATIVE LIMIT	1	Negative limit switch is active (source selected by parameter 62.05 NEG LIMIT SWITCH).																																																																													
		0	Negative limit switch is inactive.																																																																													
27	REQUEST CTL	1	Control word is requested from fieldbus.																																																																													
		0	Control word is not requested from fieldbus.																																																																													
28	SW B28		Programmable status bits (unless fixed by the used profile). See parameters 50.08...50.11 and the user manual of the fieldbus adapter.																																																																													
29	SW B29																																																																															
30	SW B30																																																																															
31	SW B31																																																																															
2.14	FBA MAIN REF1	FW block: FIELDBUS (page 207)																																																																														
	Scaled fieldbus reference 1. See parameter 50.04 FBA REF1 MODESEL .																																																																															
2.15	FBA MAIN REF2	FW block: FIELDBUS (page 207)																																																																														
	Scaled fieldbus reference 2. See parameter 50.05 FBA REF2 MODESEL .																																																																															
2.16	FEN DI STATUS	FW block: ENCODER (page 259)																																																																														
	Status of digital inputs of FEN-xx encoder interfaces in drive option Slots 1 and 2. Examples: 000001 (01h) = DI1 of FEN-xx in Slot 1 is ON, all others are OFF. 000010 (02h) = DI2 of FEN-xx in Slot 1 is ON, all others are OFF. 010000 (10h) = DI1 of FEN-xx in Slot 2 is ON, all others are OFF. 100000 (20h) = DI2 of FEN-xx in Slot 2 is ON, all others are OFF.																																																																															

2.17	D2D MAIN CW	FW block: D2D COMMUNICATION (page 216)
	Drive-to-drive control word received through the drive-to-drive link. See also actual signal 2.18 below.	
	Bit	Information
	0	Stop.
	1	Start.
	2...6	Reserved.
	7	Run enable. By default, not connected in a follower drive.
	8	Reset. By default, not connected in a follower drive.
	9...14	Freely assignable through bit pointer parameters.
	15	EXT1/EXT2 selection. 0 = EXT1 active, 1 = EXT2 active. By default, not connected in a follower drive.
2.18	D2D FOLLOWER CW	FW block: DRIVE LOGIC (page 122)
	Drive-to-drive control word sent to the followers by default. See also firmware block D2D COMMUNICATION on page 216.	
	Bit	Information
	0	Stop.
	1	Start.
	2...6	Reserved.
	7	Run enable.
	8	Reset.
	9...14	Reserved.
	15	EXT1/EXT2 selection. 0 = EXT1 active, 1 = EXT2 active.
2.19	D2D REF1	FW block: D2D COMMUNICATION (page 216)
	Drive-to-drive reference 1 received through the drive-to-drive link.	
2.20	D2D REF2	FW block: D2D COMMUNICATION (page 216)
	Drive-to-drive reference 2 received through the drive-to-drive link.	

Group 03 CONTROL VALUES

3.01	SPEED REF1	FW block: SPEED REF SEL (page 157)
	Speed reference 1 in rpm.	
3.02	SPEED REF2	FW block: SPEED REF SEL (page 157)
	Speed reference 2 in rpm.	
3.03	SPEEDREF RAMP IN	FW block: SPEED REF MOD (page 158)
	Used speed reference ramp input in rpm.	
3.04	SPEEDREF RAMPED	FW block: SPEED REF RAMP (page 161)
	Ramped and shaped speed reference in rpm.	
3.05	SPEEDREF USED	FW block: SPEED ERROR (page 165)
	Used speed reference in rpm (reference before the speed error calculation).	
3.06	SPEED ERROR FILT	FW block: SPEED ERROR (page 165)
	Filtered speed error value in rpm.	
3.07	ACC COMP TORQ	FW block: SPEED ERROR (page 165)
	Output of the acceleration compensation (torque in %).	
3.08	TORQ REF SP CTRL	FW block: SPEED CONTROL (page 170)
	Limited speed controller output torque in %.	
3.09	TORQ REF1	FW block: TORQ REF SEL (page 177)
	Torque reference 1 in %.	
3.10	TORQ REF RAMPED	FW block: TORQ REF MOD (page 178)
	Ramped torque reference in %.	
3.11	TORQ REF RUSHLIM	FW block: TORQ REF MOD (page 178)
	Torque reference limited by the rush control (value in %). Torque is limited to ensure that the speed is between the defined minimum and maximum speed limits (parameters 20.01 MAXIMUM SPEED and 20.02 MINIMUM SPEED).	
3.12	TORQUE REF ADD	FW block: TORQ REF SEL (page 177)
	Torque reference additive in %.	
3.13	TORQ REF TO TC	FW block: REFERENCE CTRL (page 185)
	Torque reference in % for the torque control. When 99.05 MOTOR CTRL MODE is set to (1) <i>Scalar</i> , this value is forced to 0.	
3.14	BRAKE TORQ MEM	FW block: MECH BRAKE CTRL (page 188)
	Torque value (in %) stored when the mechanical brake close command is issued.	

3.15	BRAKE COMMAND	FW block: MECH BRAKE CTRL (page 188)
	Brake on/off command. 0 = Close. 1 = Open. For brake on/off control, connect this signal to a relay output (or a digital output). See section Mechanical brake control on page 57.	
3.16	FLUX REF USED	FW block: MOTOR CONTROL (page 191)
	Used flux reference in percent.	
3.17	TORQUE REF USED	FW block: MOTOR CONTROL (page 191)
	Used/limited torque reference in percent.	
3.20	MAX SPEED REF	FW block: LIMITS (page 147)
	Maximum speed reference.	
3.21	MIN SPEED REF	FW block: LIMITS (page 147)
	Minimum speed reference.	

Group 04 POS CTRL VALUES

4.01	SPEED REF POS	FW block: POS CONTROL (page 256)
	Position controller output (speed reference) for the speed controller in rpm.	
4.02	SPEED ACT LOAD	FW block: POS FEEDBACK (page 221)
	Filtered actual speed of the load. The unit depends on parameter 60.05 POS UNIT selection. If the load gear ratio is 1:1, 4.02 SPEED ACT LOAD equals 1.01 SPEED ACT .	
4.03	PROBE1 POS MEAS	FW block: HOMING (page 225)
	Measured position (triggered according to latch setting 62.15 TRIG PROBE1). The unit depends on parameter 60.05 POS UNIT selection.	
4.04	PROBE2 POS MEAS	FW block: HOMING (page 225)
	Measured position (triggered according to latch setting 62.17 TRIG PROBE2). The unit depends on parameter 60.05 POS UNIT selection. Used only with cyclic corrections.	
4.05	CYCLIC POS ERR	FW block: HOMING (page 225)
	Calculated cyclic position error for the cyclic correction function (error = reference latch position - measured latch position). The unit depends on parameter 60.05 POS UNIT selection. The error is added to synchron error (4.18 SYNC ERROR). Used only with cyclic corrections.	
4.06	POS REF	FW block: PROFILE REF SEL (page 237)
	Position reference used by the position profile generator. The unit depends on parameter 60.05 POS UNIT selection.	
4.07	PROF SPEED	FW block: PROFILE REF SEL (page 237)
	Positioning speed used by the position profile generator. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
4.08	PROF ACC	FW block: PROFILE REF SEL (page 237)
	Positioning acceleration used by the position profile generator. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
4.09	PROF DEC	FW block: PROFILE REF SEL (page 237)
	Positioning deceleration used by the position profile generator. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
4.10	PROF FILT TIME	FW block: PROFILE REF SEL (page 237)
	Used position reference filter time in ms.	
4.11	POS STYLE	FW block: PROFILE REF SEL (page 237)
	Used positioning behaviour. Defined by parameter 65.09 POS STYLE 1 / 65.17 POS STYLE 2 .	

4.12	POS END SPEED	FW block: PROFILE REF SEL (page 237)
	Positioning speed used after the target has been reached. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
4.13	POS REF IPO	FW block: PROFILE GENERATOR (page 245)
	Position reference from the position profile generator. The unit depends on parameter 60.05 POS UNIT selection.	
4.14	DIST TGT	FW block: PROFILE GENERATOR (page 245)
	Position profile generator distance to target. The unit depends on parameter 60.05 POS UNIT selection.	
4.15	SYNC REF UNGEAR	FW block: SYNC REF SEL (page 247)
	Ungearing synchron reference input. By default, this signal is connected to the input of the SYNC REF MOD firmware block (see page 250). The unit depends on parameter 60.05 POS UNIT selection.	
4.16	SYNC REF GEARED	FW block: SYNC REF MOD (page 250)
	Position reference in synchron control mode (output of the synchron reference chain). The unit depends on parameter 60.05 POS UNIT selection.	
4.17	POS REF LIMITED	FW block: POS REF LIM (page 253)
	Limited position reference. The unit depends on parameter 60.05 POS UNIT selection.	
4.18	SYNC ERROR	FW block: POS REF LIM (page 253)
	Synchronising error, caused by the dynamic limitations or the position correction, fed to the position profile generator. The unit depends on parameter 60.05 POS UNIT selection.	
4.19	POS ERROR	FW block: POS CONTROL (page 256)
	Position error. The unit depends on parameter 60.05 POS UNIT selection.	
4.20	SPEED FEED FWD	FW block: POS CONTROL (page 256)
	Position speed reference in rpm (from the dynamic limiter for the speed controller) multiplied with the speed feed forward gain (71.04 P CTRL FEED GAIN). To improve speed control, this reference is added to the position error (difference between the position reference and actual position).	
4.21	SYNC REF IN	FW block: SYNC REF SEL (page 247)
	Synchron reference input before interpolation.	

Group 06 DRIVE STATUS

6.01	STATUS WORD 1	FW block: DRIVE LOGIC (page 122)	
	Status word 1.		
Bit	Name	Val.	Information
0	READY	1	Drive is ready to receive start command.
		0	Drive is not ready.
1	ENABLED	1	External run enable signal is received.
		0	No external run enable signal is received.
2	STARTED	1	Drive has received start command.
		0	Drive has not received start command.
3	RUNNING	1	Drive is modulating.
		0	Drive is not modulating.
4	EM OFF (OFF2)	1	Emergency OFF2 is active.
		0	Emergency OFF2 is inactive.
5	EM STOP (OFF3)	1	Emergency stop OFF3 (ramp stop) is active.
		0	Emergency OFF3 is inactive.
6	ACK STARTINH	1	Start inhibit is active.
		0	Start inhibit is inactive.
7	ALARM	1	An alarm is active. See chapter Fault tracing .
		0	No alarm
8	EXT2 ACT	1	External control EXT2 is active.
		0	External control EXT1 is active.
9	LOCAL FB	1	Fieldbus local control is active.
		0	Fieldbus local control is inactive.
10	FAULT	1	A fault is active. See chapter Fault tracing .
		0	No fault
11	LOCAL PANEL	1	Local control is active, ie, drive is controlled from PC tool or control panel.
		0	Local control is inactive.
12	NOT FAULTED	1	No fault
		0	A fault is active. See chapter Fault tracing .
13	Reserved		
14	TORQ START ACT	1	Controlled starting torque functionality is active.
		0	Controlled starting torque functionality is inactive.
15	Reserved		

6.02	STATUS WORD 2	FW block: DRIVE LOGIC (page 122)	
Status word 2.			
Bit	Name	Val.	Information
0	START ACT	1	Drive start command is active.
		0	Drive start command is inactive.
1	STOP ACT	1	Drive stop command is active.
		0	Drive stop command is inactive.
2	READY RELAY	1	Ready to function: run enable signal on, no fault, emergency stop signal off, no motor ID run inhibition. Connected by default to DIO1 by par. 12.04 DIO1 OUT PTR . (Can be freely connected anywhere.)
		0	Not ready to function
3	MODULATING	1	Modulating: IGBTs are controlled, ie, the drive is RUNNING.
		0	No modulation: IGBTs are not controlled.
4	REF RUNNING	1	Normal operation is enabled. Running. Drive follows the given reference.
		0	Normal operation is disabled, Drive is not following the given reference (eg, in magnetisation phase drive is modulating).
5	JOGGING	1	Jogging function 1 or 2 is active.
		0	Jogging function is inactive.
6	OFF1	1	Emergency stop OFF1 is active.
		0	Emergency stop OFF1 is inactive.
7	START INH MASK	1	Maskable (by par. 10.12 START INHIBIT) start inhibit is active.
		0	No start inhibit (maskable)
8	START INH NOMASK	1	Non-maskable start inhibit is active.
		0	No start inhibit (non-maskable)
9	CHRG REL CLOSED	1	Charging relay is closed.
		0	Charging relay is open.
10	STO ACT	1	Safe Torque Off function is active. See parameter 46.07 STO DIAGNOSTIC .
		0	Safe Torque Off function is inactive.
11	Reserved		
12	RAMP IN 0	1	Ramp Function Generator input is forced to zero.
		0	Normal operation
13	RAMP HOLD	1	Ramp Function Generator output is held.
		0	Normal operation
14	RAMP OUT 0	1	Ramp Function Generator output is forced to zero.
		0	Normal operation
15	DATA LOGGER ON	1	The drive data logger is on and has not been triggered.
		0	The drive data logger is off, or its post-trigger time has not yet elapsed. See the DriveStudio user manual.

6.03	SPEED CTRL STAT	FW block: DRIVE LOGIC (page 122)	
Speed control status word.			
Bit	Name	Val.	Information
0	SPEED ACT NEG	1	Actual speed is negative.
1	ZERO SPEED	1	Actual speed has reached the zero speed limit (22.05 ZERO SPEED LIMIT).
2	ABOVE LIMIT	1	Actual speed has exceeded the supervision limit (22.07 ABOVE SPEED LIM).
3	AT SETPOINT	1	Difference between 1.01 SPEED ACT and 3.03 SPEEDREF RAMP IN (in speed control) or 3.05 SPEEDREF USED (in position control) is within speed window (26.07 SPEED WINDOW).
4	BAL ACTIVE	1	Speed controller output balancing is active (28.09 SPEEDCTRL BAL EN).
5	PI TUNE ACTIVE	1	Speed controller autotune is active.
6	PI TUNE REQ	1	Speed controller autotune has been requested by parameter 28.16 PI TUNE MODE .
7	PI TUNE DONE	1	Speed controller autotune has been completed successfully.
8...15	Reserved		
6.05	LIMIT WORD 1	FW block: DRIVE LOGIC (page 122)	
Limit word 1.			
Bit	Name	Val.	Information
0	TORQ LIM	1	Drive torque is being limited by the motor control (undervoltage control, overvoltage control, current limitation, load angle limitation, or pull-out limitation), or by parameter 20.06 MAXIMUM TORQUE or 20.07 MINIMUM TORQUE . The source of the limitation is identified by 6.07 TORQ LIM STATUS .
1	SPD CTL TLIM MIN	1	Speed controller output minimum torque limit is active. The limit is defined by parameter 28.10 MIN TORQ SP CTRL .
2	SPD CTL TLIM MAX	1	Speed controller output maximum torque limit is active. The limit is defined by parameter 28.11 MAX TORQ SP CTRL .
3	TORQ REF MAX	1	Torque reference (3.09 TORQ REF1) maximum limit is active. The limit is defined by parameter 32.04 MAXIMUM TORQ REF .
4	TORQ REF MIN	1	Torque reference (3.09 TORQ REF1) minimum limit is active. The limit is defined by parameter 32.05 MINIMUM TORQ REF .
5	TLIM MAX SPEED	1	Torque reference maximum value is limited by the rush control, because of maximum speed limit 20.01 MAXIMUM SPEED .
6	TLIM MIN SPEED	1	Torque reference minimum value is limited by the rush control, because of minimum speed limit 20.02 MINIMUM SPEED .
7...15	Reserved		

6.07	TORQ LIM STATUS	FW block: DRIVE LOGIC (page 122)	
Torque controller limitation status word.			
Bit	Name	Val.	Information
0	UNDERVOLTAGE	1	Intermediate circuit DC undervoltage *
1	OVERVOLTAGE	1	Intermediate circuit DC overvoltage *
2	MINIMUM TORQUE	1	Torque reference minimum limit is active. The limit is defined by parameter 20.07 MINIMUM TORQUE . *
3	MAXIMUM TORQUE	1	Torque reference maximum limit is active. The limit is defined by parameter 20.06 MAXIMUM TORQUE . *
4	INTERNAL CURRENT	1	An inverter current limit is active. The limit is identified by bits 8...11.
5	LOAD ANGLE	1	For permanent magnet motor only: Load angle limit is active, ie, the motor cannot produce more torque.
6	MOTOR PULLOUT	1	For asynchronous motor only: Motor pull-out limit is active, ie, the motor cannot produce more torque.
7	Reserved		
8	THERMAL	1	Bit 4 = 0: Input current is limited by main circuit thermal limit. Bit 4 = 1: Output current is limited by main circuit thermal limit.
9	I2MAX CURRENT	1	Inverter output current limit is active. **
10	USER CURRENT	1	Maximum inverter output current limit is active. The limit is defined by parameter 20.05 MAXIMUM CURRENT . **
11...15	Reserved		
* Only one of bits 0...3 can be on simultaneously. The bit typically indicates the limit that is exceeded first.			
** Only either 9 or 10 can be on simultaneously. The bit typically indicates the limit that is exceeded first.			

6.09	POS CTRL STATUS	FW block: DRIVE LOGIC (page 122)	
Position control status word.			
Bit	Name	Val.	Information
0	IN POSITION	1	Position reference generator has reached the used position reference.
		0	Position reference generator is active, ie, calculating the position reference.
1	IN POS WIN	1	Difference between position reference and actual position is within the defined position window, 66.04 POS WIN .
		0	Difference between position reference and actual position is outside the defined position window.
2	POS START	1	Positioning start command is active. Source for the start signal is selected by parameter 65.03 POS START 1 / 65.11 POS START 2 .
		0	Position start command is inactive.
3	POS ENA-BLED	1	Position control is enabled by parameter 66.05 POS ENABLE or by fieldbus control word 2.12 FBA MAIN CW bit 21.
		0	Position control is not enabled.
4	MOVING	1	Positioning task is active. Drive speed is $\neq 0$.
		0	Positioning task is completed or drive is at standstill.
5	TRAVERSE ACK	1	New positioning task or setpoint is accepted.
		0	No operation
6	IP MODE ACT	1	Position reference generator is active.
		0	Position reference generator is inactive.
7	FOLLOW ERR	1	The difference between the reference and the actual position is outside the defined following error window.
		0	The difference between the reference and the actual position is within the defined following error window 71.09 FOLLOW ERR WIN .
8	ABOVE MAX	1	Actual position (1.12 POS ACT) exceeds the defined maximum position, 60.13 MAXIMUM POS .
		0	Actual position does not exceed the maximum value.
9	BELOW MIN	1	Actual position (1.12 POS ACT) exceeds the defined minimum position, 60.14 MINIMUM POS .
		0	Actual position does not exceed the minimum value.
10	ABOVE THRES	1	Actual position (1.12 POS ACT) exceeds the position threshold supervision limit. The limit is defined by parameter 60.15 POS THRESHOLD .
		0	Actual position does not exceed the position threshold supervision limit.
11	Reserved		
12	PREF SPD LIM	1	Position reference speed is limited to the value defined by parameter 70.04 POS SPEED LIM .
		0	Position reference speed is not limited.
13	PREF ACC LIM	1	Position reference acceleration is limited to the value defined by parameter 70.05 POS ACCEL LIM .
		0	Position reference acceleration is not limited.
14	PREF DEC LIM	1	Position reference deceleration is limited to the value defined by parameter 70.06 POS DECEL LIM .
		0	Position reference deceleration is not limited.
15	Reserved		

6.10	POS CTRL STATUS2	FW block: DRIVE LOGIC (page 122)	
Additional position control status word.			
Bit	Name	Val.	Information
0*	IN SYNC POS	1	Position profile generator distance to target is below the absolute value of the synchron error limit, ie, value of 4.14 DIST TGT is smaller than value of 70.07 SYNC ERR LIM .
		0	Distance to target is greater than synchron error limit.
1*	IN SYNC	1	The difference of synchronous speed and drive load speed (4.02 SPEED ACT LOAD) is below the defined velocity window (70.08 SYNC VEL WINDOW).
		0	The system is not in synchron as defined by the synchron velocity window (70.08 SYNC VEL WINDOW).
2	END SPEED ACTIVE	1	Positioning end speed (defined by parameter 65.10 POS END SPEED 1 or 65.18 POS END SPEED 2 depending on selected position reference set) has been reached.
		0	Positioning end speed has not been reached or end speed is defined as zero.
3...15	Reserved		
* Active in synchron control.			

6.11	POS CORR STATUS	FW block: DRIVE LOGIC (page 122)	
Position correction status word.			
Bit	Name	Val.	Information
0	HOMING START	1	Homing start is active. Source for the homing start is selected by parameter 62.03 HOMING START .
		0	Homing start is inactive.
1	HOMING DONE	1	Homing has been performed.
		0	Homing has not been performed (if bit 2 = 0) or homing is being executed.
2	HOM DONE ONCE	1	Homing has been performed at least once.
		0	Homing has not been performed after power up or there is an error with the actual position encoder.
3	COR DONE ONCE	1	Cyclic correction has been performed at least once (62.14 CYCLIC CORR MODE).
		0	Cyclic correction has not been performed after power up or there is an error with the actual position encoder.
4	POS LIM POS	1	Positive limit switch is active (source selected by parameter 62.06 POS LIMIT SWITCH).
		0	Positive limit switch is inactive.
5	POS LIM NEG	1	Negative limit switch is active (source selected by parameter 62.05 NEG LIMIT SWITCH).
		0	Negative limit switch is inactive.
6	LATCH1 STAT	1	Position latch signal 1 is active (source selected by parameter 62.15 TRIG PROBE1).
		0	Position latch signal 1 is inactive.
7	LATCH2 STAT	1	Position latch signal 2 is active (source selected by parameter 62.17 TRIG PROBE2).
		0	Position latch signal 2 is inactive.
8	LATCH1 DONE	1	Position has been latched according to parameter 62.15 TRIG PROBE1 setting.
		0	No position latch has occurred.
9	LATCH2 DONE	1	Position has been latched according to parameter 62.17 TRIG PROBE2 setting.
		0	No position latch has occurred.
10	Reserved		
11	POSIT AFTER HOM	1	Drive is executing absolute positioning according to par. 62.10 HOME POS OFFSET after home position has been found and set.
		0	The drive has not reached home position yet.
12	CYC CORR ACTIV	1	Cyclic correction is active.
		0	Cyclic correction is inactive.
13	PRESET LATCH STAT	1	Position preset mode is active (source selected by parameter 62.12 PRESET TRIG).
		0	Position preset mode is inactive.
14	LATCH 1 TOGGLE	0 ↔ 1	Position latch selected via 62.15 TRIG PROBE1 has been stored anew.
15	LATCH 2 TOGGLE	0 ↔ 1	Position latch selected via 62.17 TRIG PROBE2 has been stored anew.

6.12	OP MODE ACK	FW block: REFERENCE CTRL (page 185)		
	Operation mode acknowledge: 0 = Stopped, 1 = Speed, 2 = Torque, 3 = Min, 4 = Max, 5 = Add, 6 = Position, 7 = Synchron, 8 = Homing, 9 = Prof vel, 10 = Scalar, 11 = Forced magn (ie, DC Hold).			
6.14	SUPERV STATUS	FW block: SUPERVISION (page 180)		
	Supervision status word. See also parameter group 33 (page 180).			
	Bit	Name	Val.	Information
	0	SUPERV FUNC1 STATUS	1	Supervision function 1 is active (below low limit or over high limit)
	1	SUPERV FUNC2 STATUS	1	Supervision function 2 is active (below low limit or over high limit)
	2	SUPERV FUNC3 STATUS	1	Supervision function 3 is active (below low limit or over high limit)
	3...15	Reserved		
6.17	BIT INVERTED SW	FW block: None		
	Shows the inverted values of the bits selected by parameters 33.17...33.22 .			
	Bit	Name	Information	
	0	INVERTED BIT0	See parameter 33.17 BIT0 INVERT SRC .	
	1	INVERTED BIT1	See parameter 33.18 BIT1 INVERT SRC .	
	2	INVERTED BIT2	See parameter 33.19 BIT2 INVERT SRC .	
	3	INVERTED BIT3	See parameter 33.20 BIT3 INVERT SRC .	
	4	INVERTED BIT4	See parameter 33.21 BIT4 INVERT SRC .	
	5	INVERTED BIT5	See parameter 33.22 BIT5 INVERT SRC .	

Group 08 ALARMS & FAULTS

8.01	ACTIVE FAULT	FW block: FAULT FUNCTIONS (page 198)																																		
	Fault code of the latest (active) fault.																																			
8.02	LAST FAULT	FW block: FAULT FUNCTIONS (page 198)																																		
	Fault code of the 2nd latest fault.																																			
8.03	FAULT TIME HI	FW block: FAULT FUNCTIONS (page 198)																																		
	Time (real time or power-on time) at which the active fault occurred in format dd.mm.yy (=day.month.year).																																			
8.04	FAULT TIME LO	FW block: FAULT FUNCTIONS (page 198)																																		
	Time (real time or power-on time) at which the active fault occurred in format hh.mm.ss (hours.minutes.seconds).																																			
8.05	ALARM LOGGER 1	FW block: FAULT FUNCTIONS (page 198)																																		
	Alarm logger 1. For possible causes and remedies, see chapter Fault tracing . Can be reset by entering a 0.																																			
	<table border="1"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>BRAKE START TORQUE</td> </tr> <tr> <td>1</td> <td>BRAKE NOT CLOSED</td> </tr> <tr> <td>2</td> <td>BRAKE NOT OPEN</td> </tr> <tr> <td>3</td> <td>SAFE TORQUE OFF</td> </tr> <tr> <td>4</td> <td>STO MODE CHANGE</td> </tr> <tr> <td>5</td> <td>MOTOR TEMP</td> </tr> <tr> <td>6</td> <td>EMERGENCY OFF</td> </tr> <tr> <td>7</td> <td>RUN ENABLE</td> </tr> <tr> <td>8</td> <td>ID-RUN</td> </tr> <tr> <td>9</td> <td>EMERGENCY STOP</td> </tr> <tr> <td>10</td> <td>POSITION SCALING</td> </tr> <tr> <td>11</td> <td>BR OVERHEAT</td> </tr> <tr> <td>12</td> <td>BC OVERHEAT</td> </tr> <tr> <td>13</td> <td>DEVICE OVERTEMP</td> </tr> <tr> <td>14</td> <td>INTBOARD OVERTEMP</td> </tr> <tr> <td>15</td> <td>BC MOD OVERTEMP</td> </tr> </tbody> </table>		Bit	Alarm	0	BRAKE START TORQUE	1	BRAKE NOT CLOSED	2	BRAKE NOT OPEN	3	SAFE TORQUE OFF	4	STO MODE CHANGE	5	MOTOR TEMP	6	EMERGENCY OFF	7	RUN ENABLE	8	ID-RUN	9	EMERGENCY STOP	10	POSITION SCALING	11	BR OVERHEAT	12	BC OVERHEAT	13	DEVICE OVERTEMP	14	INTBOARD OVERTEMP	15	BC MOD OVERTEMP
Bit	Alarm																																			
0	BRAKE START TORQUE																																			
1	BRAKE NOT CLOSED																																			
2	BRAKE NOT OPEN																																			
3	SAFE TORQUE OFF																																			
4	STO MODE CHANGE																																			
5	MOTOR TEMP																																			
6	EMERGENCY OFF																																			
7	RUN ENABLE																																			
8	ID-RUN																																			
9	EMERGENCY STOP																																			
10	POSITION SCALING																																			
11	BR OVERHEAT																																			
12	BC OVERHEAT																																			
13	DEVICE OVERTEMP																																			
14	INTBOARD OVERTEMP																																			
15	BC MOD OVERTEMP																																			

8.06	ALARM LOGGER 2	FW block: FAULT FUNCTIONS (page 198)																																		
<p>Alarm logger 2. For possible causes and remedies, see chapter Fault tracing. Can be reset by entering a 0.</p> <table border="1" data-bbox="320 398 836 987"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr><td>0</td><td>IGBT OVERTEMP</td></tr> <tr><td>1</td><td>FIELD BUS COMM</td></tr> <tr><td>2</td><td>LOCAL CTRL LOSS</td></tr> <tr><td>3</td><td>AI SUPERVISION</td></tr> <tr><td>4</td><td>Reserved</td></tr> <tr><td>5</td><td>NO MOTOR DATA</td></tr> <tr><td>6</td><td>ENCODER 1 FAIL</td></tr> <tr><td>7</td><td>ENCODER 2 FAIL</td></tr> <tr><td>8</td><td>LATCH POS 1 FAIL</td></tr> <tr><td>9</td><td>LATCH POS 2 FAIL</td></tr> <tr><td>10</td><td>ENC EMUL FAILURE</td></tr> <tr><td>11</td><td>FEN TEMP FAILURE</td></tr> <tr><td>12</td><td>ENC MAX FREQ</td></tr> <tr><td>13</td><td>ENC REF ERROR</td></tr> <tr><td>14</td><td>RESOLVER ERR</td></tr> <tr><td>15</td><td>ENCODER 1 CABLE</td></tr> </tbody> </table>			Bit	Alarm	0	IGBT OVERTEMP	1	FIELD BUS COMM	2	LOCAL CTRL LOSS	3	AI SUPERVISION	4	Reserved	5	NO MOTOR DATA	6	ENCODER 1 FAIL	7	ENCODER 2 FAIL	8	LATCH POS 1 FAIL	9	LATCH POS 2 FAIL	10	ENC EMUL FAILURE	11	FEN TEMP FAILURE	12	ENC MAX FREQ	13	ENC REF ERROR	14	RESOLVER ERR	15	ENCODER 1 CABLE
Bit	Alarm																																			
0	IGBT OVERTEMP																																			
1	FIELD BUS COMM																																			
2	LOCAL CTRL LOSS																																			
3	AI SUPERVISION																																			
4	Reserved																																			
5	NO MOTOR DATA																																			
6	ENCODER 1 FAIL																																			
7	ENCODER 2 FAIL																																			
8	LATCH POS 1 FAIL																																			
9	LATCH POS 2 FAIL																																			
10	ENC EMUL FAILURE																																			
11	FEN TEMP FAILURE																																			
12	ENC MAX FREQ																																			
13	ENC REF ERROR																																			
14	RESOLVER ERR																																			
15	ENCODER 1 CABLE																																			
8.07	ALARM LOGGER 3	FW block: FAULT FUNCTIONS (page 198)																																		
<p>Alarm logger 3. For possible causes and remedies, see chapter Fault tracing. Can be reset by entering a 0.</p> <table border="1" data-bbox="320 1155 836 1675"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr><td>0</td><td>ENCODER 2 CABLE</td></tr> <tr><td>1</td><td>D2D COMM</td></tr> <tr><td>2</td><td>D2D BUF OVLOAD</td></tr> <tr><td>3</td><td>PS COMM</td></tr> <tr><td>4</td><td>RESTORE</td></tr> <tr><td>5</td><td>CUR MEAS CALIB</td></tr> <tr><td>6</td><td>AUTOPHASING</td></tr> <tr><td>7</td><td>EARTH FAULT</td></tr> <tr><td>8</td><td>Reserved</td></tr> <tr><td>9</td><td>MOTOR NOM VALUE</td></tr> <tr><td>10</td><td>D2D CONFIG</td></tr> <tr><td>11</td><td>STALL</td></tr> <tr><td>12...14</td><td>Reserved</td></tr> <tr><td>15</td><td>SPEED FEEDBACK</td></tr> </tbody> </table>			Bit	Alarm	0	ENCODER 2 CABLE	1	D2D COMM	2	D2D BUF OVLOAD	3	PS COMM	4	RESTORE	5	CUR MEAS CALIB	6	AUTOPHASING	7	EARTH FAULT	8	Reserved	9	MOTOR NOM VALUE	10	D2D CONFIG	11	STALL	12...14	Reserved	15	SPEED FEEDBACK				
Bit	Alarm																																			
0	ENCODER 2 CABLE																																			
1	D2D COMM																																			
2	D2D BUF OVLOAD																																			
3	PS COMM																																			
4	RESTORE																																			
5	CUR MEAS CALIB																																			
6	AUTOPHASING																																			
7	EARTH FAULT																																			
8	Reserved																																			
9	MOTOR NOM VALUE																																			
10	D2D CONFIG																																			
11	STALL																																			
12...14	Reserved																																			
15	SPEED FEEDBACK																																			

8.08	ALARM LOGGER 4	FW block: FAULT FUNCTIONS (page 198)																		
	<p>Alarm logger 4. For possible causes and remedies, see chapter Fault tracing. Can be reset by entering a 0.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>OPTION COMM LOSS</td> </tr> <tr> <td>1</td> <td>SOLUTION ALARM</td> </tr> <tr> <td>2...5</td> <td>Reserved</td> </tr> <tr> <td>6</td> <td>PROT. SET PASS</td> </tr> <tr> <td>7...8</td> <td>Reserved</td> </tr> <tr> <td>9</td> <td>DC NOT CHARGED</td> </tr> <tr> <td>10</td> <td>SPEED TUNE FAIL</td> </tr> <tr> <td>11...15</td> <td>Reserved</td> </tr> </tbody> </table>		Bit	Alarm	0	OPTION COMM LOSS	1	SOLUTION ALARM	2...5	Reserved	6	PROT. SET PASS	7...8	Reserved	9	DC NOT CHARGED	10	SPEED TUNE FAIL	11...15	Reserved
Bit	Alarm																			
0	OPTION COMM LOSS																			
1	SOLUTION ALARM																			
2...5	Reserved																			
6	PROT. SET PASS																			
7...8	Reserved																			
9	DC NOT CHARGED																			
10	SPEED TUNE FAIL																			
11...15	Reserved																			
8.09	ALARM LOGGER 5	FW block: FAULT FUNCTIONS (page 198)																		
	<p>Alarm logger 5. For possible causes and remedies, see chapter Fault tracing. Can be reset by entering a 0.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr> <td>0...15</td> <td>Reserved</td> </tr> </tbody> </table>		Bit	Alarm	0...15	Reserved														
Bit	Alarm																			
0...15	Reserved																			
8.10	ALARM LOGGER 6	FW block: FAULT FUNCTIONS (page 198)																		
	<p>Alarm logger 6. For possible causes and remedies, see chapter Fault tracing. Can be reset by entering a 0.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr> <td>0...1</td> <td>Reserved</td> </tr> <tr> <td>2</td> <td>LOW VOLT MOD CON</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> </tr> </tbody> </table>		Bit	Alarm	0...1	Reserved	2	LOW VOLT MOD CON	3...15	Reserved										
Bit	Alarm																			
0...1	Reserved																			
2	LOW VOLT MOD CON																			
3...15	Reserved																			

8.15	ALARM WORD 1	FW block: FAULT FUNCTIONS (page 198)																																		
<p>Alarm word 1. For possible causes and remedies, see chapter Fault tracing. This alarm word is refreshed, ie, when the alarm goes off, the corresponding alarm bit is cleared from the signal.</p> <table border="1" data-bbox="320 398 836 987"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr><td>0</td><td>BRAKE START TORQUE</td></tr> <tr><td>1</td><td>BRAKE NOT CLOSED</td></tr> <tr><td>2</td><td>BRAKE NOT OPEN</td></tr> <tr><td>3</td><td>SAFE TORQUE OFF</td></tr> <tr><td>4</td><td>STO MODE CHANGE</td></tr> <tr><td>5</td><td>MOTOR TEMP</td></tr> <tr><td>6</td><td>EMERGENCY OFF</td></tr> <tr><td>7</td><td>RUN ENABLE</td></tr> <tr><td>8</td><td>ID-RUN</td></tr> <tr><td>9</td><td>EMERGENCY STOP</td></tr> <tr><td>10</td><td>POSITION SCALING</td></tr> <tr><td>11</td><td>BR OVERHEAT</td></tr> <tr><td>12</td><td>BC OVERHEAT</td></tr> <tr><td>13</td><td>DEVICE OVERTEMP</td></tr> <tr><td>14</td><td>INTBOARD OVERTEMP</td></tr> <tr><td>15</td><td>BC MOD OVERTEMP</td></tr> </tbody> </table>			Bit	Alarm	0	BRAKE START TORQUE	1	BRAKE NOT CLOSED	2	BRAKE NOT OPEN	3	SAFE TORQUE OFF	4	STO MODE CHANGE	5	MOTOR TEMP	6	EMERGENCY OFF	7	RUN ENABLE	8	ID-RUN	9	EMERGENCY STOP	10	POSITION SCALING	11	BR OVERHEAT	12	BC OVERHEAT	13	DEVICE OVERTEMP	14	INTBOARD OVERTEMP	15	BC MOD OVERTEMP
Bit	Alarm																																			
0	BRAKE START TORQUE																																			
1	BRAKE NOT CLOSED																																			
2	BRAKE NOT OPEN																																			
3	SAFE TORQUE OFF																																			
4	STO MODE CHANGE																																			
5	MOTOR TEMP																																			
6	EMERGENCY OFF																																			
7	RUN ENABLE																																			
8	ID-RUN																																			
9	EMERGENCY STOP																																			
10	POSITION SCALING																																			
11	BR OVERHEAT																																			
12	BC OVERHEAT																																			
13	DEVICE OVERTEMP																																			
14	INTBOARD OVERTEMP																																			
15	BC MOD OVERTEMP																																			
8.16	ALARM WORD 2	FW block: FAULT FUNCTIONS (page 198)																																		
<p>Alarm word 2. For possible causes and remedies, see chapter Fault tracing. This alarm word is refreshed, ie, when the alarm goes off, the corresponding alarm bit is cleared from the signal.</p> <table border="1" data-bbox="320 1160 836 1749"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr><td>0</td><td>IGBT OVERTEMP</td></tr> <tr><td>1</td><td>FIELDBUS COMM</td></tr> <tr><td>2</td><td>LOCAL CTRL LOSS</td></tr> <tr><td>3</td><td>AI SUPERVISION</td></tr> <tr><td>4</td><td>Reserved</td></tr> <tr><td>5</td><td>NO MOTOR DATA</td></tr> <tr><td>6</td><td>ENCODER 1 FAIL</td></tr> <tr><td>7</td><td>ENCODER 2 FAIL</td></tr> <tr><td>8</td><td>LATCH POS 1 FAIL</td></tr> <tr><td>9</td><td>LATCH POS 2 FAIL</td></tr> <tr><td>10</td><td>ENC EMUL FAILURE</td></tr> <tr><td>11</td><td>FEN TEMP FAILURE</td></tr> <tr><td>12</td><td>ENC MAX FREQ</td></tr> <tr><td>13</td><td>ENC REF ERROR</td></tr> <tr><td>14</td><td>RESOLVER ERR</td></tr> <tr><td>15</td><td>ENCODER 1 CABLE</td></tr> </tbody> </table>			Bit	Alarm	0	IGBT OVERTEMP	1	FIELDBUS COMM	2	LOCAL CTRL LOSS	3	AI SUPERVISION	4	Reserved	5	NO MOTOR DATA	6	ENCODER 1 FAIL	7	ENCODER 2 FAIL	8	LATCH POS 1 FAIL	9	LATCH POS 2 FAIL	10	ENC EMUL FAILURE	11	FEN TEMP FAILURE	12	ENC MAX FREQ	13	ENC REF ERROR	14	RESOLVER ERR	15	ENCODER 1 CABLE
Bit	Alarm																																			
0	IGBT OVERTEMP																																			
1	FIELDBUS COMM																																			
2	LOCAL CTRL LOSS																																			
3	AI SUPERVISION																																			
4	Reserved																																			
5	NO MOTOR DATA																																			
6	ENCODER 1 FAIL																																			
7	ENCODER 2 FAIL																																			
8	LATCH POS 1 FAIL																																			
9	LATCH POS 2 FAIL																																			
10	ENC EMUL FAILURE																																			
11	FEN TEMP FAILURE																																			
12	ENC MAX FREQ																																			
13	ENC REF ERROR																																			
14	RESOLVER ERR																																			
15	ENCODER 1 CABLE																																			

8.17	ALARM WORD 3	FW block: FAULT FUNCTIONS (page 198)																														
<p>Alarm word 3. For possible causes and remedies, see chapter Fault tracing. This alarm word is refreshed, ie, when the alarm goes off, the corresponding alarm bit is cleared from the signal.</p> <table border="1" data-bbox="411 398 927 920"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr><td>0</td><td>ENCODER 2 CABLE</td></tr> <tr><td>1</td><td>D2D COMM</td></tr> <tr><td>2</td><td>D2D BUF OVLOAD</td></tr> <tr><td>3</td><td>PS COMM</td></tr> <tr><td>4</td><td>RESTORE</td></tr> <tr><td>5</td><td>CUR MEAS CALIB</td></tr> <tr><td>6</td><td>AUTOPHASING</td></tr> <tr><td>7</td><td>EARTH FAULT</td></tr> <tr><td>8</td><td>Reserved</td></tr> <tr><td>9</td><td>MOTOR NOM VALUE</td></tr> <tr><td>10</td><td>D2D CONFIG</td></tr> <tr><td>11</td><td>STALL</td></tr> <tr><td>12...14</td><td>Reserved</td></tr> <tr><td>15</td><td>SPEED FEEDBACK</td></tr> </tbody> </table>			Bit	Alarm	0	ENCODER 2 CABLE	1	D2D COMM	2	D2D BUF OVLOAD	3	PS COMM	4	RESTORE	5	CUR MEAS CALIB	6	AUTOPHASING	7	EARTH FAULT	8	Reserved	9	MOTOR NOM VALUE	10	D2D CONFIG	11	STALL	12...14	Reserved	15	SPEED FEEDBACK
Bit	Alarm																															
0	ENCODER 2 CABLE																															
1	D2D COMM																															
2	D2D BUF OVLOAD																															
3	PS COMM																															
4	RESTORE																															
5	CUR MEAS CALIB																															
6	AUTOPHASING																															
7	EARTH FAULT																															
8	Reserved																															
9	MOTOR NOM VALUE																															
10	D2D CONFIG																															
11	STALL																															
12...14	Reserved																															
15	SPEED FEEDBACK																															
8.18	ALARM WORD 4	FW block: FAULT FUNCTIONS (page 198)																														
<p>Alarm word 4. For possible causes and remedies, see chapter Fault tracing. This alarm word is refreshed, ie, when the alarm goes off, the corresponding alarm bit is cleared from the signal.</p> <table border="1" data-bbox="411 1081 927 1402"> <thead> <tr> <th>Bit</th> <th>Alarm</th> </tr> </thead> <tbody> <tr><td>0</td><td>OPTION COMM LOSS</td></tr> <tr><td>1</td><td>SOLUTION ALARM</td></tr> <tr><td>2...5</td><td>Reserved</td></tr> <tr><td>6</td><td>PROT. SET PASS</td></tr> <tr><td>7...8</td><td>Reserved</td></tr> <tr><td>9</td><td>DC NOT CHARGED</td></tr> <tr><td>10</td><td>SPEED TUNE FAIL</td></tr> <tr><td>11...15</td><td>Reserved</td></tr> </tbody> </table>			Bit	Alarm	0	OPTION COMM LOSS	1	SOLUTION ALARM	2...5	Reserved	6	PROT. SET PASS	7...8	Reserved	9	DC NOT CHARGED	10	SPEED TUNE FAIL	11...15	Reserved												
Bit	Alarm																															
0	OPTION COMM LOSS																															
1	SOLUTION ALARM																															
2...5	Reserved																															
6	PROT. SET PASS																															
7...8	Reserved																															
9	DC NOT CHARGED																															
10	SPEED TUNE FAIL																															
11...15	Reserved																															

Group 09 SYSTEM INFO

9.01	DRIVE TYPE	FW block: None
	Displays the drive application type. (2) ACSM1 Motion: Motion control application	
9.02	DRIVE RATING ID	FW block: None
	Displays the inverter type of the drive. (0) Unconfigured, (1) ACSM1-xxAx-02A5-4, (2) ACSM1-xxAx-03A0-4, (3) ACSM1-xxAx-04A0-4, (4) ACSM1-xxAx-05A0-4, (5) ACSM1-xxAx-07A0-4, (6) ACSM1-xxAx-09A5-4, (7) ACSM1-xxAx-012A-4, (8) ACSM1-xxAx-016A-4, (9) ACSM1-xxAx-024A-4, (10) ACSM1-xxAx-031A-4, (11) ACSM1-xxAx-040A-4, (12) ACSM1-xxAx-046A-4, (13) ACSM1-xxAx-060A-4, (14) ACSM1-xxAx-073A-4, (15) ACSM1-xxAx-090A-4, (20) ACSM1-xxAx-110A-4, (21) ACSM1-xxAx-135A-4, (22) ACSM1-xxAx-175A-4, (23) ACSM1-xxAx-210A-4, (24) ACSM1-xxCx-024A-4, (25) ACSM1-xxCx-031A-4, (26) ACSM1-xxCx-040A-4, (27) ACSM1-xxCx-046A-4, (28) ACSM1-xxCx-060A-4, (29) ACSM1-xxCx-073A-4, (30) ACSM1-xxCx-090A-4, (31) ACSM1-xxLx-110A-4, (32) ACSM1-xxLx-135A-4, (33) ACSM1-xxLx-175A-4, (34) ACSM1-xxLx-210A-4, (35) ACSM1-xxLx-260A-4, (63) ACSM1-390A-4, (64) ACSM1-500A-4, (65) ACSM1-580A-4, (67) ACSM1-635A-4	
9.03	FIRMWARE ID	FW block: None
	Displays the firmware name, eg, UMFI.	
9.04	FIRMWARE VER	FW block: None
	Displays the version of the firmware package in the drive, eg, NNNN hex.	
9.05	FIRMWARE PATCH	FW block: None
	Displays the version of the firmware patch in the drive.	
9.10	INT LOGIC VER	FW block: None
	Displays the version of the logic in the power unit interface.	
9.11	SLOT 1 VIE NAME	FW block: None
	Displays the type of VIE logic used in the optional module in option slot 1.	
9.12	SLOT 1 VIE VER	FW block: None
	Displays the version of VIE logic used in the optional module in option slot 1.	
9.13	SLOT 2 VIE NAME	FW block: None
	Displays the type of VIE logic used in the optional module in option slot 2.	
9.14	SLOT 2 VIE VER	FW block: None
	Displays the version of VIE logic used in the optional module in option slot 2.	

9.20	OPTION SLOT 1	FW block: None
	Displays the type of the optional module in option Slot 1. (0) NO OPTION, (1) NO COMM, (2) UNKNOWN, (3) FEN-01, (4) FEN-11, (5) FEN-21, (6) FIO-01, (7) FIO-11, (8) FPBA-01, (9) FPBA-02, (10) FCAN-01, (11) FDNA-01, (12) FENA-01, (13) FENA-11, (14) FLON-01, (15) FRSA-00, (16) FMBA-01, (17) FFOA-01, (18) FFOA-02, (19) FSEN-01, (20) FEN-31, (21) FIO-21, (22) FSCA-01, (23) FSEA-21, (24) FIO-31, (25) FECA-01, (26) FENA-21, (27) FB COMMON, (28) FMAC-01, (29) FEPL-01, (30) FCNA-01	
9.21	OPTION SLOT 2	FW block: None
	Displays the type of the optional module in option Slot 2. See 9.20 OPTION SLOT 1 .	
9.22	OPTION SLOT 3	FW block: None
	Displays the type of the optional module in option Slot 3. See 9.20 OPTION SLOT 1 .	

Group 10 START/STOP

Settings for

- selecting start/stop/direction signal sources for external control locations EXT1 and EXT2
- selecting sources for external fault reset, run enable and start enable signals
- selecting sources for emergency stop (OFF1 and OFF3)
- selecting source for jogging function activation signal
- enabling the start inhibit function.

See also section [Jogging](#) on page 52.

<p>Firmware block: DRIVE LOGIC (10)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the sources for the start/stop/direction signals for external control locations EXT1 and EXT2 • selects the sources for external fault reset, run enable and start enable signals • selects the sources for emergency stop (OFF1 and OFF3) • selects the source for jogging activation signal • enables the start inhibit function. 	<table border="1"> <thead> <tr> <th colspan="2">DRIVE LOGIC</th> <th>21</th> </tr> </thead> <tbody> <tr> <td>TLF10</td> <td>2 msec</td> <td>(3)</td> </tr> <tr> <td>2.18</td> <td>D2D FOLLOWER CW</td> <td>—</td> </tr> <tr> <td>6.01</td> <td>STATUS WORD 1</td> <td>—</td> </tr> <tr> <td>6.02</td> <td>STATUS WORD 2</td> <td>—</td> </tr> <tr> <td>6.03</td> <td>SPEED CTRL STAT</td> <td>—</td> </tr> <tr> <td>6.05</td> <td>LIMIT WORD 1</td> <td>—</td> </tr> <tr> <td>6.07</td> <td>TORQ LIM STATUS</td> <td>—</td> </tr> <tr> <td>6.09</td> <td>POS CTRL STATUS</td> <td>—</td> </tr> <tr> <td>6.10</td> <td>POS CTRL STATUS2</td> <td>—</td> </tr> <tr> <td>6.11</td> <td>POS CORR STATUS</td> <td>—</td> </tr> <tr> <td>[In1]</td> <td>10.01 EXT1 START FUNC</td> <td></td> </tr> <tr> <td>[DI STATUS0] (2 / 2.01.DI1)</td> <td>< 10.02 EXT1 START IN1</td> <td></td> </tr> <tr> <td>[FALSE]</td> <td>< 10.03 EXT1 START IN2</td> <td></td> </tr> <tr> <td>[In1]</td> <td>10.04 EXT2 START FUNC</td> <td></td> </tr> <tr> <td>[DI STATUS0] (2 / 2.01.DI1)</td> <td>< 10.05 EXT2 START IN1</td> <td></td> </tr> <tr> <td>[FALSE]</td> <td>< 10.06 EXT2 START IN2</td> <td></td> </tr> <tr> <td>[FALSE]</td> <td>< 10.07 JOG1 START</td> <td></td> </tr> <tr> <td>[DI STATUS2] (2 / 2.01.DI3)</td> <td>< 10.08 FAULT RESET SEL</td> <td></td> </tr> <tr> <td>[TRUE]</td> <td>< 10.09 RUN ENABLE</td> <td></td> </tr> <tr> <td>[TRUE]</td> <td>< 10.10 EM STOP OFF3</td> <td></td> </tr> <tr> <td>[TRUE]</td> <td>< 10.11 EM STOP OFF1</td> <td></td> </tr> <tr> <td>[Disabled]</td> <td>10.12 START INHIBIT</td> <td></td> </tr> <tr> <td>[FBA MAIN CW] (4 / 2.12)</td> <td>< 10.13 FB CW USED</td> <td></td> </tr> <tr> <td>[FALSE]</td> <td>< 10.14 JOG2 START</td> <td></td> </tr> <tr> <td>[FALSE]</td> <td>< 10.15 JOG ENABLE</td> <td></td> </tr> <tr> <td>[D2D MAIN CW] (4 / 2.17)</td> <td>< 10.16 D2D CW USED</td> <td></td> </tr> <tr> <td>[TRUE]</td> <td>< 10.17 START ENABLE</td> <td></td> </tr> </tbody> </table>	DRIVE LOGIC		21	TLF10	2 msec	(3)	2.18	D2D FOLLOWER CW	—	6.01	STATUS WORD 1	—	6.02	STATUS WORD 2	—	6.03	SPEED CTRL STAT	—	6.05	LIMIT WORD 1	—	6.07	TORQ LIM STATUS	—	6.09	POS CTRL STATUS	—	6.10	POS CTRL STATUS2	—	6.11	POS CORR STATUS	—	[In1]	10.01 EXT1 START FUNC		[DI STATUS0] (2 / 2.01.DI1)	< 10.02 EXT1 START IN1		[FALSE]	< 10.03 EXT1 START IN2		[In1]	10.04 EXT2 START FUNC		[DI STATUS0] (2 / 2.01.DI1)	< 10.05 EXT2 START IN1		[FALSE]	< 10.06 EXT2 START IN2		[FALSE]	< 10.07 JOG1 START		[DI STATUS2] (2 / 2.01.DI3)	< 10.08 FAULT RESET SEL		[TRUE]	< 10.09 RUN ENABLE		[TRUE]	< 10.10 EM STOP OFF3		[TRUE]	< 10.11 EM STOP OFF1		[Disabled]	10.12 START INHIBIT		[FBA MAIN CW] (4 / 2.12)	< 10.13 FB CW USED		[FALSE]	< 10.14 JOG2 START		[FALSE]	< 10.15 JOG ENABLE		[D2D MAIN CW] (4 / 2.17)	< 10.16 D2D CW USED		[TRUE]	< 10.17 START ENABLE	
DRIVE LOGIC		21																																																																																			
TLF10	2 msec	(3)																																																																																			
2.18	D2D FOLLOWER CW	—																																																																																			
6.01	STATUS WORD 1	—																																																																																			
6.02	STATUS WORD 2	—																																																																																			
6.03	SPEED CTRL STAT	—																																																																																			
6.05	LIMIT WORD 1	—																																																																																			
6.07	TORQ LIM STATUS	—																																																																																			
6.09	POS CTRL STATUS	—																																																																																			
6.10	POS CTRL STATUS2	—																																																																																			
6.11	POS CORR STATUS	—																																																																																			
[In1]	10.01 EXT1 START FUNC																																																																																				
[DI STATUS0] (2 / 2.01.DI1)	< 10.02 EXT1 START IN1																																																																																				
[FALSE]	< 10.03 EXT1 START IN2																																																																																				
[In1]	10.04 EXT2 START FUNC																																																																																				
[DI STATUS0] (2 / 2.01.DI1)	< 10.05 EXT2 START IN1																																																																																				
[FALSE]	< 10.06 EXT2 START IN2																																																																																				
[FALSE]	< 10.07 JOG1 START																																																																																				
[DI STATUS2] (2 / 2.01.DI3)	< 10.08 FAULT RESET SEL																																																																																				
[TRUE]	< 10.09 RUN ENABLE																																																																																				
[TRUE]	< 10.10 EM STOP OFF3																																																																																				
[TRUE]	< 10.11 EM STOP OFF1																																																																																				
[Disabled]	10.12 START INHIBIT																																																																																				
[FBA MAIN CW] (4 / 2.12)	< 10.13 FB CW USED																																																																																				
[FALSE]	< 10.14 JOG2 START																																																																																				
[FALSE]	< 10.15 JOG ENABLE																																																																																				
[D2D MAIN CW] (4 / 2.17)	< 10.16 D2D CW USED																																																																																				
[TRUE]	< 10.17 START ENABLE																																																																																				

Block outputs located in other parameter groups	2.18 D2D FOLLOWER CW (page 102) 6.01 STATUS WORD 1 (page 107) 6.02 STATUS WORD 2 (page 108) 6.03 SPEED CTRL STAT (page 109) 6.05 LIMIT WORD 1 (page 109) 6.07 TORQ LIM STATUS (page 110) 6.09 POS CTRL STATUS (page 111) 6.10 POS CTRL STATUS2 (page 112) 6.11 POS CORR STATUS (page 113)																
10.01	EXT1 START FUNC	FW block: DRIVE LOGIC (see above)															
	Selects the source for the start and stop control in external control location EXT1. Note: This parameter cannot be changed while the drive is running.																
	(0) Not sel	No source selected.															
	(1) In1	Source of the start and stop commands are selected by parameter 10.02 EXT1 START IN1 . The start/stop is controlled as follows: <table border="1" data-bbox="751 824 1050 936"> <thead> <tr> <th>Par. 10.02</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>Start</td> </tr> <tr> <td>1 -> 0</td> <td>Stop</td> </tr> </tbody> </table>	Par. 10.02	Command	0 -> 1	Start	1 -> 0	Stop									
Par. 10.02	Command																
0 -> 1	Start																
1 -> 0	Stop																
	(2) 3-wire	Source of the start and stop commands are selected by parameters 10.02 EXT1 START IN1 and 10.03 EXT1 START IN2 . The start/stop is controlled as follows: <table border="1" data-bbox="751 1070 1187 1205"> <thead> <tr> <th>Par. 10.02</th> <th>Par. 10.03</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>Start</td> </tr> <tr> <td>Any</td> <td>1 -> 0</td> <td>Stop</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table>	Par. 10.02	Par. 10.03	Command	0 -> 1	1	Start	Any	1 -> 0	Stop	Any	0	Stop			
Par. 10.02	Par. 10.03	Command															
0 -> 1	1	Start															
Any	1 -> 0	Stop															
Any	0	Stop															
	(3) FBA	Start and stop control from the source selected by parameter 10.13 FB CW USED .															
	(4) D2D	Start and stop control from another drive via D2D Control Word.															
	(5) IN1 F IN2R	The source selected by 10.02 EXT1 START IN1 is the forward start signal, the source selected by 10.03 EXT1 START IN2 is the reverse start signal. <table border="1" data-bbox="751 1485 1267 1664"> <thead> <tr> <th>Par. 10.02</th> <th>Par. 10.03</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table>	Par. 10.02	Par. 10.03	Command	0	0	Stop	1	0	Start forward	0	1	Start reverse	1	1	Stop
Par. 10.02	Par. 10.03	Command															
0	0	Stop															
1	0	Start forward															
0	1	Start reverse															
1	1	Stop															
	(6) IN1S IN2DIR	The source selected by 10.02 EXT1 START IN1 is the start signal (0 = stop, 1 = start), the source selected by 10.03 EXT1 START IN2 is the direction signal (0 = forward, 1 = reverse).															

10.02	EXT1 START IN1	FW block: DRIVE LOGIC (see above)															
	Selects the source 1 for the start and stop commands in external control location EXT1. See parameter 10.01 EXT1 START FUNC selections (1) In1 and (2) 3-wire. Note: This parameter cannot be changed while the drive is running.																
	Bit pointer: Group, index and bit																
10.03	EXT1 START IN2	FW block: DRIVE LOGIC (see above)															
	Selects the source 2 for the start and stop commands in external control location EXT1. See parameter 10.01 EXT1 START FUNC selection (2) 3-wire. Note: This parameter cannot be changed while the drive is running.																
	Bit pointer: Group, index and bit																
10.04	EXT2 START FUNC	FW block: DRIVE LOGIC (see above)															
	Selects the source for the start and stop control in external control location EXT2. Note: This parameter cannot be changed while the drive is running.																
	(0) Not sel	No source selected.															
	(1) In1	Source of the start and stop commands are selected by parameter 10.05 EXT2 START IN1 . The start/stop is controlled as follows: <table border="1" data-bbox="660 1003 954 1111"> <thead> <tr> <th>Par. 10.05</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>Start</td> </tr> <tr> <td>1 -> 0</td> <td>Stop</td> </tr> </tbody> </table>	Par. 10.05	Command	0 -> 1	Start	1 -> 0	Stop									
Par. 10.05	Command																
0 -> 1	Start																
1 -> 0	Stop																
	(2) 3-wire	Source of the start and stop commands are selected by parameters 10.05 EXT2 START IN1 and 10.06 EXT2 START IN2 . The start/stop is controlled as follows: <table border="1" data-bbox="660 1245 1091 1384"> <thead> <tr> <th>Par. 10.05</th> <th>Par. 10.06</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>Start</td> </tr> <tr> <td>Any</td> <td>1 -> 0</td> <td>Stop</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table>	Par. 10.05	Par. 10.06	Command	0 -> 1	1	Start	Any	1 -> 0	Stop	Any	0	Stop			
Par. 10.05	Par. 10.06	Command															
0 -> 1	1	Start															
Any	1 -> 0	Stop															
Any	0	Stop															
	(3) FBA	Start and stop control from the source selected by parameter 10.13 FB CW USED .															
	(4) D2D	Start and stop control from another drive via D2D Control Word.															
	(5) IN1 F IN2R	The source selected by 10.05 EXT2 START IN1 is the forward start signal, the source selected by 10.06 EXT2 START IN2 is the reverse start signal. <table border="1" data-bbox="660 1662 1174 1836"> <thead> <tr> <th>Par. 10.05</th> <th>Par. 10.06</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table>	Par. 10.05	Par. 10.06	Command	0	0	Stop	1	0	Start forward	0	1	Start reverse	1	1	Stop
Par. 10.05	Par. 10.06	Command															
0	0	Stop															
1	0	Start forward															
0	1	Start reverse															
1	1	Stop															


	(6) IN1S IN2DIR	The source selected by 10.05 EXT2 START IN1 is the start signal (0 = stop, 1 = start), the source selected by 10.06 EXT2 START IN2 is the direction signal (0 = forward, 1 = reverse).
10.05	EXT2 START IN1	FW block: DRIVE LOGIC (see above)
	Selects the source 1 for the start and stop commands in external control location EXT2. See parameter 10.04 EXT2 START FUNC selections (1) In1 and (2) 3-wire. Note: This parameter cannot be changed while the drive is running.	
	Bit pointer: Group, index and bit	
10.06	EXT2 START IN2	FW block: DRIVE LOGIC (see above)
	Selects the source 2 for the start and stop commands in external control location EXT2. See parameter 10.04 EXT2 START FUNC selection (2) 3-wire. Note: This parameter cannot be changed while the drive is running.	
	Bit pointer: Group, index and bit	
10.07	JOG1 START	FW block: DRIVE LOGIC (see above)
	If enabled by parameter 10.15 JOG ENABLE , selects the source for the activation of jogging function 1. 1 = Active. (Jogging function 1 can also be activated through fieldbus regardless of parameter 10.15 .) See section Jogging on page 52. See also other jogging function parameters: 10.14 JOG2 START , 10.15 JOG ENABLE , 24.03 SPEED REF1 IN / 24.04 SPEED REF2 IN , 24.10 SPEED REF JOG1 , 24.11 SPEED REF JOG2 , 25.09 ACC TIME JOGGING , 25.10 DEC TIME JOGGING and 22.06 ZERO SPEED DELAY . Note: This parameter cannot be changed while the drive is running.	
	Bit pointer: Group, index and bit	
10.08	FAULT RESET SEL	FW block: DRIVE LOGIC (see above)
	Selects the source for the external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists. 1 = Fault reset.	
	Bit pointer: Group, index and bit	
10.09	RUN ENABLE	FW block: DRIVE LOGIC (see above)
	Selects the source for the run enable signal. If the run enable signal is switched off, the drive will not start or stops if the drive is running. 1 = Run enable. See also parameter 10.17 START ENABLE . Note: This parameter cannot be changed while the drive is running.	
	Bit pointer: Group, index and bit	
10.10	EM STOP OFF3	FW block: DRIVE LOGIC (see above)
	Selects the source for the emergency stop OFF3. 0 = OFF3 active: The drive is stopped along the emergency stop ramp time, 25.11 EM STOP TIME . Emergency stop can also be activated through fieldbus (2.12 FBA MAIN CW). See section Emergency stop on page 84. Note: This parameter cannot be changed while the drive is running.	


	Bit pointer: Group, index and bit	
10.11	EM STOP OFF1	FW block: DRIVE LOGIC (see above)
	<p>Selects the source for the emergency stop OFF1. 0 = OFF1 active: The drive is stopped with the active deceleration time.</p> <p>Emergency stop can also be activated through fieldbus (2.12 FBA MAIN CW).</p> <p>See section Emergency stop on page 84.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	Bit pointer: Group, index and bit	
10.12	START INHIBIT	FW block: DRIVE LOGIC (see above)
	<p>Enables the start inhibit function. The start inhibit function prevents drive restart (ie, protects against unexpected start) if</p> <ul style="list-style-type: none"> • drive trips on a fault and fault is reset. • run enable signal activates while the start command is active. See parameter 10.09 RUN ENABLE. • control changes from local to remote. • external control switches from EXT1 to EXT2 or from EXT2 to EXT1. <p>An active start inhibit can be reset with a stop command.</p> <p>Note that in certain applications it is necessary to allow the drive to restart.</p>	
	(0) Disabled	Start inhibit function disabled.
	(1) Enabled	Start inhibit function enabled.
10.13	FB CW USED	FW block: DRIVE LOGIC (see above)
	<p>Selects the source for the control word when fieldbus (FBA) is selected as the external start and stop control location (see parameters 10.01 EXT1 START FUNC and 10.04 EXT2 START FUNC). By default, the source is parameter 2.12 FBA MAIN CW.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	Value pointer: Group and index	
10.14	JOG2 START	FW block: DRIVE LOGIC (see above)
	<p>If enabled by parameter 10.15 JOG ENABLE, selects the source for the activation of jogging function 2. 1 = Active. (Jogging function 2 can also be activated through fieldbus regardless of parameter 10.15.)</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	Bit pointer: Group, index and bit	
10.15	JOG ENABLE	FW block: DRIVE LOGIC (see above)
	<p>Selects the source for enabling parameters 10.07 JOG1 START and 10.14 JOG2 START.</p> <p>Note: Jogging can be enabled using this parameter only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location apart from jog commands through fieldbus.</p>	
	Bit pointer: Group, index and bit	


<p>10.16</p>	<p>D2D CW USED</p>	<p>FW block: DRIVE LOGIC (see above)</p>
<p>Selects the source for the control word for drive-to-drive communication. By default, the source is parameter 2.17 D2D MAIN CW.</p>		
<p>Value pointer: Group and index</p>		
<p>10.17</p>	<p>START ENABLE</p>	<p>FW block: DRIVE LOGIC (see above)</p>
<p>Selects the source for the start enable signal. If the start enable signal is switched off, the drive will not start or stops if the drive is running. 1 = Start enable.</p> <p>Note: This parameter cannot be changed while the drive is running.</p> <p>Note: Functionality of the Start enable signal is different from the Run enable signal.</p> <p>Example: External damper control application using Start enable and Run enable. Motor can start only after the damper is fully open.</p> <p>The diagram illustrates the sequence of events for starting a motor with an external damper. It shows the following signals and their timing:</p> <ul style="list-style-type: none"> Start/Stop commands (group 10): A pulse that initiates the drive start. Start enable signal (10.17): A signal that becomes active (high) after the start command. Started (6.01 STATUS WORD 1 bit 2): A signal that becomes active (high) when the drive starts. Damper status: A signal that ramps up from low to high during the 'Damper opening time' and ramps down from high to low during the 'Damper closing time'. Run enable signal from the damper end switch when the damper is fully opened (10.09): A signal that becomes active (high) only when the damper is fully open. Motor speed: A signal that ramps up during the 'Acceleration time (25.03)' and ramps down during the 'Deceleration time (25.04)'. <p>The 'Drive started' event occurs when the start command is received. The 'Damper open' event occurs when the damper status reaches its peak. The 'Damper closed' event occurs when the damper status returns to its initial low state.</p>		
<p>Bit pointer: Group, index and bit</p>		

Group 11 START/STOP MODE

These parameters select the start and stop functions as well as the autophasing mode, define the DC magnetising time of the motor, and configure the DC hold function.




Firmware block: START/STOP MODE (11)	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">START/STOP MODE</th> </tr> </thead> <tbody> <tr> <td style="text-align: right;">TLF10 2 msec</td> <td style="text-align: right;">22 (4)</td> </tr> <tr> <td>[Const time]</td> <td>11.01 START MODE</td> </tr> <tr> <td>[500 ms]</td> <td>11.02 DC MAGN TIME</td> </tr> <tr> <td>[Ramp]</td> <td>11.03 STOP MODE</td> </tr> <tr> <td>[5.0 rpm]</td> <td>11.04 DC HOLD SPEED</td> </tr> <tr> <td>[30 %]</td> <td>11.05 DC HOLD CUR REF</td> </tr> <tr> <td>[Disabled]</td> <td>11.06 DC HOLD</td> </tr> <tr> <td>[Turning]</td> <td>11.07 AUTOPHASING MODE</td> </tr> </tbody> </table>		START/STOP MODE		TLF10 2 msec	22 (4)	[Const time]	11.01 START MODE	[500 ms]	11.02 DC MAGN TIME	[Ramp]	11.03 STOP MODE	[5.0 rpm]	11.04 DC HOLD SPEED	[30 %]	11.05 DC HOLD CUR REF	[Disabled]	11.06 DC HOLD	[Turning]	11.07 AUTOPHASING MODE
START/STOP MODE																				
TLF10 2 msec	22 (4)																			
[Const time]	11.01 START MODE																			
[500 ms]	11.02 DC MAGN TIME																			
[Ramp]	11.03 STOP MODE																			
[5.0 rpm]	11.04 DC HOLD SPEED																			
[30 %]	11.05 DC HOLD CUR REF																			
[Disabled]	11.06 DC HOLD																			
[Turning]	11.07 AUTOPHASING MODE																			
11.01	START MODE	FW block: START/STOP MODE (see above)																		
	Selects the motor start function. Notes: <ul style="list-style-type: none"> This parameter has no effect if parameter 99.05 MOTOR CTRL MODE is set to (1) Scalar. Starting to a rotating machine is not possible when DC magnetising is selected ((0) Fast or (1) Const time). With permanent magnet motors, automatic start must be used. This parameter cannot be changed while the drive is running. 																			
	(0) Fast	DC magnetising should be selected if a high break-away torque is required. The drive pre-magnetises the motor before the start. The pre-magnetising time is determined automatically, being typically 200 ms to 2 s depending on the motor size.																		
	(1) Const time	Constant DC magnetising should be selected instead of FAST DC magnetising if a constant pre-magnetising time is required (eg, if the motor start must be simultaneous with a mechanical brake release). This selection also guarantees the highest possible break-away torque when the pre-magnetising time is set long enough. The pre-magnetising time is defined by parameter 11.02 DC MAGN TIME .  WARNING! The drive will start after the set magnetising time has passed even if motor magnetisation is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetising time is long enough to allow generation of full magnetisation and torque.																		
	(2) Automatic	Automatic start guarantees optimal motor start in most cases. It includes the flying start function (starting to a rotating machine) and the automatic restart function (stopped motor can be restarted immediately without waiting the motor flux to die away). The drive motor control program identifies the flux as well as the mechanical state of the motor and starts the motor instantly under all conditions.																		

11.02	DC MAGN TIME	FW block: START/STOP MODE (see above)										
	<p>Defines the constant DC magnetising time. See parameter 11.01 START MODE. After the start command, the drive automatically premagnetises the motor the set time.</p> <p>To ensure full magnetising, set this value to the same value as or higher than the rotor time constant. If not known, use the rule-of-thumb value given in the table below:</p> <table border="1"> <thead> <tr> <th>Motor rated power</th> <th>Constant magnetising time</th> </tr> </thead> <tbody> <tr> <td>< 1 kW</td> <td>≥ 50 to 100 ms</td> </tr> <tr> <td>1 to 10 kW</td> <td>≥ 100 to 200 ms</td> </tr> <tr> <td>10 to 200 kW</td> <td>≥ 200 to 1000 ms</td> </tr> <tr> <td>200 to 1000 kW</td> <td>≥ 1000 to 2000 ms</td> </tr> </tbody> </table> <p>Note: This parameter cannot be changed while the drive is running.</p>		Motor rated power	Constant magnetising time	< 1 kW	≥ 50 to 100 ms	1 to 10 kW	≥ 100 to 200 ms	10 to 200 kW	≥ 200 to 1000 ms	200 to 1000 kW	≥ 1000 to 2000 ms
Motor rated power	Constant magnetising time											
< 1 kW	≥ 50 to 100 ms											
1 to 10 kW	≥ 100 to 200 ms											
10 to 200 kW	≥ 200 to 1000 ms											
200 to 1000 kW	≥ 1000 to 2000 ms											
	0...10000 ms	DC magnetising time.										
11.03	STOP MODE	FW block: START/STOP MODE (see above)										
	Selects the motor stop function.											
	(1) Coast	<p>Stop by cutting of the motor power supply. The motor coasts to a stop.</p> <p> WARNING! If the mechanical brake is used, ensure it is safe to stop the drive by coasting. For more information on mechanical brake function, see parameter group 35.</p>										
	(2) Ramp	Stop along ramp. See parameter group 25 .										
11.04	DC HOLD SPEED	FW block: START/STOP MODE (see above)										
	Defines the DC hold speed. See parameter 11.06 DC HOLD .											
	0...1000 rpm	DC hold speed.										
11.05	DC HOLD CUR REF	FW block: START/STOP MODE (see above)										
	Defines the DC hold current in percent of the motor nominal current. See parameter 11.06 DC HOLD .											
	0...100%	DC hold current.										

11.06	DC HOLD	FW block: START/STOP MODE (see above)
<p>Enables the DC hold function. The function makes it possible to lock the rotor at zero speed. When both the reference and the speed drop below the value of parameter 11.04 DC HOLD SPEED, the drive will stop generating sinusoidal current and start to inject DC into the motor. The current is set by parameter 11.05 DC HOLD CUR REF. When the reference speed exceeds parameter 11.04 DC HOLD SPEED, normal drive operation continues.</p>  <p>Notes:</p> <ul style="list-style-type: none"> • The DC hold function has no effect if the start signal is switched off. • The DC hold function can only be activated in speed control mode. • The DC hold function cannot be activated if par. 99.05 MOTOR CTRL MODE is set to (1) Scalar. • Injecting DC current into the motor causes the motor to heat up. In applications where long DC hold times are required, externally ventilated motors should be used. If the DC hold period is long, the DC hold cannot prevent the motor shaft from rotating if a constant load is applied to the motor. 		
Bit pointer: Group and index and bit		
(0) Disabled		DC hold function disabled.
(1) Enabled		DC hold function enabled.
11.07	AUTOPHASING MODE	FW block: START/STOP MODE (see above)
Selects the way the autophasing routine is performed. See also section Autophasing on page 44.		
(0) Turning		This mode gives the most accurate autophasing result. This mode can be used, and is recommended if it is allowed for the motor to rotate and the start-up is not time-critical. Note: This mode will cause the motor to rotate during the motor ID run.
(1) Standstill 1		Faster than the (0) Turning mode, but not as accurate. The motor will not rotate.
(2) Standstill 2		An alternative standstill autophasing mode that can be used if the TURNING mode cannot be used, and the (1) Standstill 1 mode gives erratic results. However, this mode is considerably slower than (1) Standstill 1 .

Group 12 DIGITAL IO

Settings for the digital inputs and outputs, and the relay output.

<p>Firmware block: DIO1 (6)</p> <p>Selects whether DIO1 is used as a digital input or as a digital output and connects an actual signal to the digital output. The block also shows the DIO status.</p>		
<p>Block outputs located in other parameter groups</p>	<p>2.03 DIO STATUS (page 96)</p>	
<p>Firmware block: DIO2 (7)</p> <p>Selects whether DIO2 is used as a digital or frequency input or as a digital output and connects an actual signal to the digital output. The block also shows the DIO status.</p> <p>Frequency input can be scaled with standard function blocks. See chapter Standard function blocks.</p>		
<p>Block outputs located in other parameter groups</p>	<p>2.03 DIO STATUS (page 96) 2.10 DIO2 FREQ IN (page 96)</p>	
<p>Firmware block: DIO3 (8)</p> <p>Selects whether DIO3 is used as a digital input or as a digital/frequency output, connects an actual signal to the digital/frequency output and scales the frequency output. The block also shows the DIO status.</p>		
<p>Block outputs located in other parameter groups</p>	<p>2.03 DIO STATUS (page 96) 2.11 DIO3 FREQ OUT (page 96)</p>	
<p>12.01</p>	<p>DIO1 CONF</p>	<p>FW block: DIO1 (see above)</p>
	<p>Selects whether DIO1 is used as a digital input or as a digital output.</p>	
	<p>(0) Output</p>	<p>DIO1 is used as a digital output.</p>
	<p>(1) Input</p>	<p>DIO1 is used as a digital input.</p>

12.02	DIO2 CONF	FW block: DIO2 (see above)
	Selects whether DIO2 is used as a digital input, as a digital output or as a frequency input.	
	(0) Output	DIO2 is used as a digital output.
	(1) Input	DIO2 is used as a digital input.
	(2) Freq input	DIO2 is used as a frequency input.
12.03	DIO3 CONF	FW block: DIO3 (see above)
	Selects whether DIO3 is used as a digital input, as a digital output or as a frequency output.	
	(0) Output	DIO2 is used as a digital output.
	(1) Input	DIO2 is used as a digital input.
	(2) Freq output	DIO2 is used as a frequency output.
12.04	DIO1 OUT PTR	FW block: DIO1 (see above)
	Selects a drive signal to be connected to digital output DIO1 (when 12.01 DIO1 CONF is set to (0) Output).	
	Bit pointer: Group, index and bit	
12.05	DIO2 OUT PTR	FW block: DIO2 (see above)
	Selects a drive signal to be connected to digital output DIO2 (when 12.02 DIO2 CONF is set to (0) Output).	
	Bit pointer: Group, index and bit	
12.06	DIO3 OUT PTR	FW block: DIO3 (see above)
	Selects a drive signal to be connected to digital output DIO3 (when 12.03 DIO3 CONF is set to (0) Output).	
	Bit pointer: Group, index and bit	
12.07	DIO3 F OUT PTR	FW block: DIO3 (see above)
	Selects a drive signal to be connected to frequency output (when 12.03 DIO3 CONF is set to (2) Freq output).	
	Value pointer: Group and index	
12.08	DIO3 F MAX	FW block: DIO3 (see above)
	When 12.03 DIO3 CONF is set to (2) Freq output , defines the maximum DIO3 output frequency.	
	3...32768 Hz	Maximum DIO3 output frequency.
12.09	DIO3 F MIN	FW block: DIO3 (see above)
	When 12.03 DIO3 CONF is set to (2) Freq output , defines the minimum DIO3 output frequency.	
	3...32768 Hz	Minimum DIO3 output frequency.

12.10	DIO3 F MAX SCALE	FW block: DIO3 (see above)
	<p>When 12.03 DIO3 CONF is set to (2) Freq output, defines the real value of the signal (selected by parameter 12.07 DIO3 F OUT PTR) that corresponds to the maximum DIO3 frequency output value (defined by parameter 12.08 DIO3 F MAX).</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>f_{DIO3} (Hz)</p> <p>12.08</p> <p>12.09</p> <p>12.11 12.10</p> <p>Signal (real) selected by par. 12.07</p> </div> <div style="text-align: center;"> <p>f_{DIO3} (Hz)</p> <p>12.08</p> <p>12.09</p> <p>12.10 12.11</p> <p>Signal (real) selected by par. 12.07</p> </div> </div>	
	0...32768	Real signal value corresponding to maximum DIO3 output frequency.
12.11	DIO3 F MIN SCALE	FW block: DIO3 (see above)
	<p>When 12.03 DIO3 CONF is set to (2) Freq output, defines the real value of the signal (selected by parameter 12.07 DIO3 F OUT PTR) that corresponds to the minimum DIO3 frequency output value (defined by parameter 12.09 DIO3 F MIN).</p>	
	0...32768	Real signal value corresponding to minimum DIO3 output frequency.

<p>Firmware block:</p> <p>RO (5)</p> <p>Connects an actual signal to the relay output. The block also shows the relay output status.</p>		
Block outputs located in other parameter groups		2.02 RO STATUS (page 96)
12.12	RO1 OUT PTR	FW block: RO (see above)
	Selects a drive signal to be connected to relay output RO1.	
	Bit pointer: Group, index and bit	

<p>Firmware block:</p> <p>DI (4)</p> <p>Shows the status of the digital inputs. Inverts the status of any DI if desired.</p>		
Block outputs located in other parameter groups		2.01 DI STATUS (page 96)

12.13	DI INVERT MASK	FW block: DI (see above)
	Inverts status of digital inputs as reported by 2.01 DI STATUS . For example, a value of 0b000100 inverts the status of DI3 in the signal.	
	0b000000...0b111111	DI status inversion mask.
12.14	DIO2 F MAX	FW block: DIO2 (see above)
	<p>Defines the maximum input frequency for DIO2 when 12.02 DIO2 CONF is set to (2) Freq input. The frequency signal connected to DIO2 is scaled into an internal signal (2.10 DIO2 FREQ IN) by parameters 12.14...12.17 as follows:</p> <p>2.10 DIO2 FREQ IN</p>	
	3...32768 Hz	DIO2 maximum frequency.
12.15	DIO2 F MIN	FW block: DIO2 (see above)
	Defines the minimum input frequency for DIO2 when 12.02 DIO2 CONF is set to (2) Freq input . See parameter 12.14 DIO2 F MAX	
	3...32768 Hz	DIO2 minimum frequency.
12.16	DIO2 F MAX SCALE	FW block: DIO2 (see above)
	Defines the value that corresponds to the maximum input frequency defined by parameter 12.14 DIO2 F MAX . See parameter 12.14 DIO2 F MAX .	
	-32768...32768	Scaled value corresponding to DIO2 maximum frequency.
12.17	DIO2 F MIN SCALE	FW block: DIO2 (see above)
	Defines the value that corresponds to the minimum input frequency defined by parameter 12.15 DIO2 F MIN . See parameter 12.14 DIO2 F MAX .	
	-32768...32768	Scaled value corresponding to DIO2 minimum frequency.

Group 13 ANALOGUE INPUTS



Settings for the analogue inputs.

The drive offers two programmable analogue inputs, AI1 and AI2. Both inputs can be used either as a voltage or a current input (-11...11 V or -22...22 mA). The input type is selected with jumpers J1 and J2 respectively on the JCU Control Unit.

The inaccuracy of the analogue inputs is 1% of the full scale range and the resolution is 11 bits (+ sign). The hardware filter time constant is approximately 0.25 ms.

Analogue inputs can be used as the source for speed and torque reference.



Analogue input supervision can be added with standard function blocks. See chapter [Standard function blocks](#).

<p>Firmware block: AI1 (12)</p> <p>Filters and scales the analogue input AI1 signal and selects the AI1 supervision. Also shows the value of the input.</p>	
<p>Block outputs located in other parameter groups</p>	<p>2.04 AI1 (page 96) 2.05 AI1 SCALED (page 96)</p>
<p>13.01 AI1 FILT TIME</p>	<p>FW block: AI1 (see above)</p>
<p>Defines the filter time constant for analogue input AI1.</p>  <p>$O = I \cdot (1 - e^{-t/T})$</p> <p>I = filter input (step) O = filter output t = time T = filter time constant</p> <p>Note: The signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.</p>	
<p>0...30 s</p>	<p>Filter time constant for AI1.</p>
<p>13.02 AI1 MAX</p>	<p>FW block: AI1 (see above)</p>
<p>Defines the maximum value for analogue input AI1. The type is selected with jumper J1 on the JCU Control Unit.</p>	
<p>-11...11 V / -22...22 mA</p>	<p>Maximum AI1 input value.</p>

13.03	AI1 MIN	FW block: AI1 (see above)
	Defines the minimum value for analogue input AI1. The type is selected with jumper J1 on the JCU Control Unit.	
	-11...11 V / -22...22 mA	Minimum AI1 input value.
13.04	AI1 MAX SCALE	FW block: AI1 (see above)
	Defines the real value that corresponds to the maximum analogue input value defined by parameter 13.02 AI1 MAX .	
	-32768...32768	Real value corresponding to value of parameter 13.02 .
13.05	AI1 MIN SCALE	FW block: AI1 (see above)
	Defines the real value that corresponds to the minimum analogue input value defined by parameter 13.03 AI1 MIN . See parameter 13.04 AI1 MAX SCALE .	
	-32768...32768	Real value corresponding to value of parameter 13.03 .

Firmware block: AI2 (13) Filters and scales the analogue input AI2 signal and selects the AI2 supervision. Also shows the value of the input.		
Block outputs located in other parameter groups		2.06 AI2 (page 96) 2.07 AI2 SCALED (page 96)
13.06	AI2 FILT TIME	FW block: AI2 (see above)
	Defines the filter time constant for analogue input AI2. See parameter 13.01 AI1 FILT TIME .	
	0...30 s	Filter time constant for AI2.

13.07	AI2 MAX	FW block: AI2 (see above)
	Defines the maximum value for analogue input AI2. The type is selected with jumper J2 on the JCU Control Unit.	
	-11...11 V / -22...22 mA	Maximum AI2 input value.
13.08	AI2 MIN	FW block: AI2 (see above)
	Defines the minimum value for analogue input AI2. The type is selected with jumper J2 on the JCU Control Unit.	
	-11...11 V / -22...22 mA	Minimum AI2 input value.
13.09	AI2 MAX SCALE	FW block: AI2 (see above)
	Defines the real value that corresponds to the maximum analogue input value defined by parameter 13.07 AI2 MAX .	
	<p>The graph illustrates the scaling of the analogue input AI2. The horizontal axis represents the input value in mA/V, and the vertical axis represents the scaled value. A linear relationship is shown between the input and the scaled value, with a slope of 1. The maximum input value is 13.07 mA/V, which corresponds to a scaled value of 13.09. The minimum input value is 13.10 mA/V, which corresponds to a scaled value of 13.08. The graph shows a line that starts at a minimum value (13.10) and goes up to a maximum value (13.09). The x-axis has a point 13.08 and the y-axis has a point 13.07.</p>	
	-32768...32768	Real value corresponding to value of parameter 13.07 .
13.10	AI2 MIN SCALE	FW block: AI2 (see above)
	Defines the real value that corresponds to the minimum analogue input value defined by parameter 13.08 AI2 MIN . See parameter 13.09 AI2 MAX SCALE .	
	-32768...32768	Real value corresponding to value of parameter 13.08 .
13.11	AITUNE	FW block: None
	Triggers the AI tuning function. Connect the signal to the input and select the appropriate tuning function.	
	(0) No action	AI tune is not activated.
	(1) AI1 min tune	Current analogue input AI1 signal value is set as minimum value for AI1, parameter 13.03 AI1 MIN . The value reverts back to (0) No action automatically.
	(2) AI1 max tune	Current analogue input AI1 signal value is set as maximum value for AI1, parameter 13.02 AI1 MAX . The value reverts back to (0) No action automatically.

	(3) AI2 min tune	Current analogue input AI2 signal value is set as minimum value for AI2, parameter 13.08 AI2 MIN . The value reverts back to (0) No action automatically.															
	(4) AI2 max tune	Current analogue input AI2 signal value is set as maximum value for AI2, parameter 13.07 AI2 MAX . The value reverts back to (0) No action automatically.															
13.12	AI SUPERVISION	FW block: None															
	Selects how the drive reacts when analogue input signal limit is reached. The limit is selected by parameter 13.13 AI SUPERVIS ACT .																
	(0) No	No action taken.															
	(1) Fault	The drive trips on fault AI SUPERVISION.															
	(2) Spd ref Safe	The drive generates alarm AI SUPERVISION and sets the speed to the speed defined by parameter 46.02 SPEED REF SAFE .  WARNING! Make sure that it is safe to continue operation in case of a communication break.															
	(3) Last speed	The drive generates alarm AI SUPERVISION and freezes the speed to the level the drive was operating at. The speed is determined by the average speed over the previous 10 seconds.  WARNING! Make sure that it is safe to continue operation in case of a communication break.															
13.13	AI SUPERVIS ACT	FW block: None															
	Selects the analogue input signal supervision limit.																
	<table border="1"> <thead> <tr> <th>Bit</th> <th></th> <th>Supervision selected by parameter 13.12 AI SUPERVISION is activated if</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AI1<min</td> <td>AI1 signal value falls below the value defined by equation: par. 13.03 AI1 MIN - 0.5 mA or V</td> </tr> <tr> <td>1</td> <td>AI1>max</td> <td>AI1 signal value exceeds the value defined by equation: par. 13.02 AI1 MAX + 0.5 mA or V</td> </tr> <tr> <td>2</td> <td>AI2<min</td> <td>AI2 signal value falls below the value defined by equation: par. 13.08 AI2 MIN - 0.5 mA or V</td> </tr> <tr> <td>3</td> <td>AI2>max</td> <td>AI2 signal value exceeds the value defined by equation: par. 13.07 AI2 MAX + 0.5 mA or V</td> </tr> </tbody> </table>	Bit		Supervision selected by parameter 13.12 AI SUPERVISION is activated if	0	AI1<min	AI1 signal value falls below the value defined by equation: par. 13.03 AI1 MIN - 0.5 mA or V	1	AI1>max	AI1 signal value exceeds the value defined by equation: par. 13.02 AI1 MAX + 0.5 mA or V	2	AI2<min	AI2 signal value falls below the value defined by equation: par. 13.08 AI2 MIN - 0.5 mA or V	3	AI2>max	AI2 signal value exceeds the value defined by equation: par. 13.07 AI2 MAX + 0.5 mA or V	
Bit		Supervision selected by parameter 13.12 AI SUPERVISION is activated if															
0	AI1<min	AI1 signal value falls below the value defined by equation: par. 13.03 AI1 MIN - 0.5 mA or V															
1	AI1>max	AI1 signal value exceeds the value defined by equation: par. 13.02 AI1 MAX + 0.5 mA or V															
2	AI2<min	AI2 signal value falls below the value defined by equation: par. 13.08 AI2 MIN - 0.5 mA or V															
3	AI2>max	AI2 signal value exceeds the value defined by equation: par. 13.07 AI2 MAX + 0.5 mA or V															
	Example: If parameter value is set to 0010 (bin), bit 1 AI1>max is selected.																
	0b0000...0b1111	AI1/AI2 signal supervision selection.															



Group 15 ANALOGUE OUTPUTS

Settings for the analogue outputs.

The drive offers two programmable analogue outputs: one current output AO1 (0...20 mA) and one voltage output AO2 (-10...10 V).

The resolution of the analogue outputs is 11 bits (+ sign) and the inaccuracy is 2% of the full scale range.

The analogue output signals can be proportional to motor speed, process speed (scaled motor speed), output frequency, output current, motor torque, motor power, etc. It is possible to write a value to an analogue output through a serial communication link (eg, fieldbus link).

<p>Firmware block: AO1 (14)</p> <p>Connects an actual signal to analogue output AO1, and filters and scales the output signal. Also shows the value of the output.</p>	
<p>Block outputs located in other parameter groups</p>	<p>2.08 AO1 (page 96)</p>
<p>15.01 AO1 PTR</p>	<p>FW block: AO1 (see above)</p>
	<p>Selects a drive signal to be connected to analogue output AO1.</p>
	<p>Value pointer: Group and index</p>
<p>15.02 AO1 FILT TIME</p>	<p>FW block: AO1 (see above)</p>
	<p>Defines the filtering time constant for analogue output AO1.</p>  <p>$O = I \cdot (1 - e^{-t/T})$</p> <p>I = filter input (step) O = filter output t = time T = filter time constant</p> <p>Note: The signal is also filtered due to the signal interface hardware (approximately 0.5 ms time constant). This cannot be changed by any parameter.</p>
<p>0...30 s</p>	<p>Filter time constant for AO1.</p>
<p>15.03 AO1 MAX</p>	<p>FW block: AO1 (see above)</p>
	<p>Defines the maximum value for analogue output AO1.</p>
<p>0...22.7 mA</p>	<p>Maximum AO1 output value.</p>


15.04	AO1 MIN	FW block: AO1 (see above)
	Defines the minimum value for analogue output AO1.	
	0...22.7 mA	Minimum AO1 output value.
15.05	AO1 MAX SCALE	FW block: AO1 (see above)
	Defines the real value that corresponds to the maximum analogue output value defined by parameter 15.03 AO1 MAX .	
	-32768...32767	Real value corresponding to value of parameter 15.03 .
15.06	AO1 MIN SCALE	FW block: AO1 (see above)
	Defines the real value that corresponds to the minimum analogue output value defined by parameter 15.04 AO1 MIN . See parameter 15.05 AO1 MAX SCALE .	
	-32768...32767	Real value corresponding to value of parameter 15.04 .

Firmware block: AO2 (15) Connects an actual signal to analogue output AO2, and filters and scales the output signal. Also shows the value of the output.		
Block outputs located in other parameter groups		2.09 AO2 (page 96)
15.07	AO2 PTR	FW block: AO2 (see above)
	Selects a drive signal to be connected to analogue output AO2.	
	Value pointer: Group and index	
15.08	AO2 FILT TIME	FW block: AO2 (see above)
	Defines the filtering time constant for analogue output AO2. See parameter 15.02 AO1 FILT TIME .	
	0...30 s	Filter time constant for AO2.

15.09	AO2 MAX	FW block: AO2 (see above)
	Defines the maximum value for analogue output AO2.	
	-10...10 V	Maximum AO2 output value.
15.10	AO2 MIN	FW block: AO2 (see above)
	Defines the minimum value for analogue output AO2.	
	-10...10 V	Minimum AO2 output value.
15.11	AO2 MAX SCALE	FW block: AO2 (see above)
	Defines the real value that corresponds to the maximum analogue output value defined by parameter 15.09 AO2 MAX .	
	-32768...32767	Real value corresponding to value of parameter 15.09 .
15.12	AO2 MIN SCALE	FW block: AO2 (see above)
	Defines the real value that corresponds to the minimum analogue output value defined by parameter 15.10 AO2 MIN . See parameter 15.11 AO2 MAX SCALE .	
	-32768...32767	Real value corresponding to value of parameter 15.10 .

Group 16 SYSTEM

Local control and parameter access settings, restoration of default parameter values, save of parameters into permanent memory.

16.01	LOCAL LOCK	FW block: None
	<p>Selects the source for disabling local control (Take/Release button on the PC tool, LOC/REM key of the panel). 1 = Local control disabled. 0 = Local control enabled.</p> <p> WARNING! Before activating, ensure that the control panel is not needed for stopping the drive!</p>	
	Bit pointer: Group, index and bit	
16.02	PARAMETER LOCK	FW block: None
	<p>Selects the state of the parameter lock. The lock prevents parameter changing.</p> <p>Note: This parameter can only be adjusted after the correct pass code has been entered at parameter 16.03 PASS CODE.</p>	
	(0) Locked	Locked. Parameter values cannot be changed from the control panel.
	(1) Open	The lock is open. Parameter values can be changed.
	(2) Not saved	The lock is open. Parameter values can be changed, but the changes will not be stored at power switch off.
16.03	PASS CODE	FW block: None
	<p>After entering 358 at this parameter, parameter 16.02 PARAMETER LOCK can be adjusted. The value reverts back to 0 automatically.</p>	
16.04	PARAM RESTORE	FW block: None
	<p>Restores the original settings of the application, ie, parameter factory default values.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	(0) Done	Restoration is completed.
	(1) Restore defs	All parameter values are restored to default values, except motor data, motor ID run results, and fieldbus, drive-to-drive link and encoder configuration data.
	(2) Clear all	All parameter values are restored to default values, including motor data, motor ID run results and fieldbus and encoder configuration data. PC tool communication is interrupted during the restoration. Drive CPU is re-booted after the restoration is completed.
16.07	PARAM SAVE	FW block: None
	<p>Saves the valid parameter values to permanent memory.</p> <p>See also section Programming via parameters on page 32.</p>	
	(0) Done	Save completed.
	(1) Save	Save in progress.

16.09	USER SET SEL	FW block: None
	<p>Enables the save and restoration of up to four custom sets of parameter settings. The set that was in use before powering down the drive is in use after the next power-up.</p> <p>Note: Any parameter changes made after loading a user set are not automatically stored into the loaded set – they must be saved using this parameter.</p>	
	(1) No request	Load or save operation complete; normal operation.
	(2) Load set 1	Load user parameter set 1.
	(3) Load set 2	Load user parameter set 2.
	(4) Load set 3	Load user parameter set 3.
	(5) Load set 4	Load user parameter set 4.
	(6) Save set 1	Save user parameter set 1.
	(7) Save set 2	Save user parameter set 2.
	(8) Save set 3	Save user parameter set 3.
	(9) Save set 4	Save user parameter set 4.
	(10) IO mode	Load user parameter set using parameters 16.11 and 16.12 .
16.10	USER SET LOG	FW block: None
	Shows the status of the user parameter sets (see parameter 16.09 USER SET SEL). Read-only.	
	N/A	No user sets have been saved.
	(1) Loading	A user set is being loaded.
	(2) Saving	A user set is being saved.
	(4) Faulted	Invalid or empty parameter set.
	(8) Set1 IO act	User parameter set 1 has been selected by parameters 16.11 and 16.12 .
	(16) Set2 IO act	User parameter set 2 has been selected by parameters 16.11 and 16.12 .
	(32) Set3 IO act	User parameter set 3 has been selected by parameters 16.11 and 16.12 .
	(64) Set4 IO act	User parameter set 4 has been selected by parameters 16.11 and 16.12 .
	(128) Set1 par act	User parameter set 1 has been loaded using parameter 16.09 .
	(256) Set2 par act	User parameter set 2 has been loaded using parameter 16.09 .
	(512) Set3 par act	User parameter set 3 has been loaded using parameter 16.09 .
	(1024) Set4 par act	User parameter set 4 has been loaded using parameter 16.09 .

16.11	USER IO SET LO	FW block: None															
	Together with parameter 16.12 USER IO SET HI , selects the user parameter set when parameter 16.09 USER SET SEL is set to (10) IO mode . The status of the source defined by this parameter and parameter 16.12 select the user parameter set as follows:																
	<table border="1"> <thead> <tr> <th>Status of source defined by par. 16.11</th> <th>Status of source defined by par. 16.12</th> <th>User parameter set selected</th> </tr> </thead> <tbody> <tr> <td>FALSE</td> <td>FALSE</td> <td>Set 1</td> </tr> <tr> <td>TRUE</td> <td>FALSE</td> <td>Set 2</td> </tr> <tr> <td>FALSE</td> <td>TRUE</td> <td>Set 3</td> </tr> <tr> <td>TRUE</td> <td>TRUE</td> <td>Set 4</td> </tr> </tbody> </table>		Status of source defined by par. 16.11	Status of source defined by par. 16.12	User parameter set selected	FALSE	FALSE	Set 1	TRUE	FALSE	Set 2	FALSE	TRUE	Set 3	TRUE	TRUE	Set 4
Status of source defined by par. 16.11	Status of source defined by par. 16.12	User parameter set selected															
FALSE	FALSE	Set 1															
TRUE	FALSE	Set 2															
FALSE	TRUE	Set 3															
TRUE	TRUE	Set 4															
	Bit pointer: Group, index and bit																
16.12	USER IO SET HI	FW block: None															
	See parameter 16.11 USER IO SET LO .																
	Bit pointer: Group, index and bit																
16.13	TIME SOURCE PRIO	FW block: None															
	Selects which real-time clock source is adopted by the drive as the master real-time clock. Some selections specify multiple sources that are in order of priority.																
	(0) FB_D2D_MMI	Fieldbus (highest priority); drive-to-drive link; man-machine interface (control panel or PC).															
	(1) D2D_FB_MMI	Drive-to-drive link (highest priority); fieldbus; man-machine interface (control panel or PC).															
	(2) FB_D2D	Fieldbus (highest priority); drive-to-drive link.															
	(3) D2D_FB	Drive-to-drive link (highest priority); fieldbus.															
	(4) FB Only	Fieldbus only.															
	(5) D2D Only	Drive-to-drive link only.															
	(6) MMI_FB_D2D	Man-machine interface (control panel or PC) (highest priority); fieldbus; drive-to-drive link.															
	(7) MMI Only	Man-machine interface (control panel or PC) only.															
	(8) Internal	No external sources are used as master real-time clock.															
16.20	DRIVE BOOT	FW block: None															
	(0) No action	Reboot not requested.															
	(1) Reboot drive	Reboot the drive control unit.															

Group 17 PANEL DISPLAY

Selection of signals for panel display.

17.01	SIGNAL1 PARAM	FW block: None
	Selects the first signal to be displayed on the control panel. The default signal is 1.03 FREQUENCY .	
	Value pointer: Group and index	
17.02	SIGNAL2 PARAM	FW block: None
	Selects the second signal to be displayed on the control panel. The default signal is 1.04 CURRENT .	
	Value pointer: Group and index	
17.03	SIGNAL3 PARAM	FW block: None
	Selects the third signal to be displayed on the control panel. The default signal is 1.06 TORQUE .	
	Value pointer: Group and index	
17.04	SIGNAL1 MODE	FW block: None
	Defines the way the signal selected by parameter 17.01 SIGNAL1 PARAM is displayed on the optional control panel.	
	(-1) Disabled	Signal not displayed. Any other signals that are not disabled are shown together with their respective signal name.
	(0) Normal	Shows the signal as a numerical value followed by unit.
	(1) Bar	Shows the signal as a horizontal bar.
	(2) Drive name	Shows the drive name. (The drive name can be set using the DriveStudio PC tool.)
	(3) Drive type	Shows the drive type.
17.05	SIGNAL2 MODE	FW block: None
	Defines the way the signal selected by parameter 17.01 SIGNAL1 PARAM is displayed on the optional control panel.	
	(-1) Disabled	Signal not displayed. Any other signals that are not disabled are shown together with their respective signal name.
	(0) Normal	Shows the signal as a numerical value followed by unit.
	(1) Bar	Shows the signal as a horizontal bar.
	(2) Drive name	Shows the drive name. (The drive name can be set using the DriveStudio PC tool.)
	(3) Drive type	Shows the drive type.

17.06	SIGNAL3 MODE	FW block: None
	Defines the way the signal selected by parameter 17.01 SIGNAL1 PARAM is displayed on the optional control panel.	
	(-1) Disabled	Signal not displayed. Any other signals that are not disabled are shown together with their respective signal name.
	(0) Normal	Shows the signal as a numerical value followed by unit.
	(1) Bar	Shows the signal as a horizontal bar.
	(2) Drive name	Shows the drive name. (The drive name can be set using the DriveStudio PC tool.)
	(3) Drive type	Shows the drive type.

Group 20 LIMITS

Definition of drive operation limits.

Firmware block: LIMITS (20) Adjusts the drive speed, current and torque limits, selects the source for the positive/negative speed reference enable command and enables the thermal current limitation.		
Block outputs located in other parameter groups		3.20 MAX SPEED REF (page 104) 3.21 MIN SPEED REF (page 104)
20.01	MAXIMUM SPEED	FW block: LIMITS (see above)
	Defines the allowed maximum speed. See also parameter 22.08 SPEED TRIPMARGIN .	
	0...30000 rpm	Allowed maximum speed.
20.02	MINIMUM SPEED	FW block: LIMITS (see above)
	Defines the allowed minimum speed. See also parameter 22.08 SPEED TRIPMARGIN .	
	-30000...0 rpm	Allowed minimum speed.


20.03	POS SPEED ENA	FW block: LIMITS (see above)
<p>Selects the source of the positive speed reference enable command.</p> <p>1 = Positive speed reference is enabled. 0 = Positive speed reference is interpreted as zero speed reference (In the figure below 3.03 SPEEDREF RAMP IN is set to zero after the positive speed enable signal has cleared). Actions in different control modes:</p> <p>Speed control: Speed reference is set to zero and the motor is stopped along the currently active deceleration ramp.</p> <p>Torque control: Torque limit is set to zero and the rush controller stops the motor.</p> <p>Position, synchron, homing and profile velocity control: Dynamic limiter sets the positioning speed limit to zero and the motor is stopped according to 70.06 POS DECEL LIM.</p> <div style="text-align: center;"> </div> <p>Example: The motor is rotating in the forward direction. To stop the motor, the positive speed enable signal is deactivated by a hardware limit switch (eg, via digital input). If the positive speed enable signal remains deactivated and the negative speed enable signal is active, only reverse rotation of the motor is allowed.</p>		
Bit pointer: Group, index and bit		
20.04	NEG SPEED ENA	FW block: LIMITS (see above)
<p>Selects the source of the negative speed reference enable command. See parameter 20.03 POS SPEED ENA.</p>		
Bit pointer: Group, index and bit		
20.05	MAXIMUM CURRENT	FW block: LIMITS (see above)
Defines the allowed maximum motor current.		
	0...30000 A	Maximum allowed motor current.
20.06	MAXIMUM TORQUE	FW block: LIMITS (see above)
Defines the maximum torque limit for the drive (in percent of the motor nominal torque).		
	0...1600%	Maximum torque limit.
20.07	MINIMUM TORQUE	FW block: LIMITS (see above)
Defines the minimum torque limit for the drive (in percent of the motor nominal torque).		
	-1600...0%	Minimum torque limit.

20.08	THERM CURR LIM	FW block: None
	Enables the thermal current limitation. Thermal current limit is calculated by the inverter thermal protection function.	
	(0) Disable	The calculated thermal limit is not used. If the inverter output current is excessive, alarm IGBT OVERTEMP is generated and eventually the drive trips on fault IGBT OVERTEMP.
	(1) Enable	The calculated thermal current value limits the inverter output current (ie, motor current).

Group 22 SPEED FEEDBACK

Settings for


- selection of speed feedback used in drive control
- filtering disturbances in measured speed signal
- motor encoder gear function
- zero speed limit for stop function
- delay for Zero Speed Delay function
- definition of limits for actual speed supervision
- loss of speed feedback signal protection.




<p>Firmware block: SPEED FEEDBACK (22)</p>		
<p>Block outputs located in other parameter groups</p>	<p>1.01 SPEED ACT (page 93)</p>	
<p>22.01</p>	<p>SPEED FB SEL</p>	<p>FW block: SPEED FEEDBACK (see above)</p>
	<p>Selects the speed feedback value used in control.</p>	
	<p>(0) Estimated</p>	<p>Calculated speed estimate.</p>
	<p>(1) Enc1 speed</p>	<p>Actual speed measured with encoder 1. The encoder is selected by parameter 90.01 ENCODER 1 SEL.</p>
	<p>(2) Enc2 speed</p>	<p>Actual speed measured with encoder 2. The encoder is selected by parameter 90.02 ENCODER 2 SEL.</p>
<p>22.02</p>	<p>SPEED ACT FTIME</p>	<p>FW block: SPEED FEEDBACK (see above)</p>
	<p>Defines the time constant of the actual speed filter, ie, time within the actual speed has reached 63% of the nominal speed (filtered speed = 1.01 SPEED ACT).</p> <p>If the used speed reference remains constant, the possible interferences in the speed measurement can be filtered with the actual speed filter. Reducing the ripple with filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.</p> <p>If there are substantial interferences in the speed measurement, the filter time constant should be proportional to the total inertia of the load and motor, in this case 10...30% of the mechanical time constant</p> $t_{\text{mech}} = (n_{\text{nom}} / T_{\text{nom}}) \times J_{\text{tot}} \times 2\pi / 60$, where J_{tot} = total inertia of the load and motor (the gear ratio between the load and motor must be taken into account) n_{nom} = motor nominal speed T_{nom} = motor nominal torque <p>To get a fast dynamic torque or speed response with a speed feedback value other than (0) Estimated (see parameter 22.01 SPEED FB SEL), the actual speed filter time must be set to zero.</p> <p>See also parameter 26.06 SPD ERR FTIME.</p>	
	<p>0... 10000 ms</p>	<p>Time constant for actual speed filter.</p>

22.03	MOTOR GEAR MUL	FW block: SPEED FEEDBACK (see above)
	<p>Defines the motor gear numerator for the motor encoder gear function.</p> $\frac{22.03 \text{ MOTOR GEAR MUL}}{22.04 \text{ MOTOR GEAR DIV}} = \frac{\text{Actual speed}}{\text{Input speed}}$ <p>where input speed is encoder 1/2 speed (1.08 ENCODER 1 SPEED / 1.10 ENCODER 2 SPEED) or speed estimate (1.14 SPEED ESTIMATED).</p> <p>Note: If the motor gear ratio differs from 1, the motor model uses an estimated speed instead of the speed feedback value.</p> <p>See also section Motor encoder gear function on page 56.</p>	
	$-2^{31} \dots 2^{31} - 1$	Numerator for motor encoder gear. Note: A setting of 0 is changed internally to 1.
22.04	MOTOR GEAR DIV	FW block: SPEED FEEDBACK (see above)
	<p>Defines the motor gear denominator for the motor encoder gear function. See parameter 22.03 MOTOR GEAR MUL.</p>	
	$1 \dots 2^{31} - 1$	Denominator for motor encoder gear.
22.05	ZERO SPEED LIMIT	FW block: SPEED FEEDBACK (see above)
	<p>Defines the zero speed limit. The motor is stopped along a speed ramp until the defined zero speed limit is reached. After the limit, the motor coasts to stop.</p> <p>Note: Too low a setting may result in the drive not stopping at all.</p>	
	0...30000 rpm	Zero speed limit.

22.06	ZERO SPEED DELAY	FW block: SPEED FEEDBACK (see above)
<p>Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay the drive knows accurately the rotor position.</p> <div style="display: flex; justify-content: space-around;"> <div data-bbox="400 421 735 739"> <p>No Zero Speed Delay</p> </div> <div data-bbox="735 421 1500 739"> <p>With Zero Speed Delay</p> </div> </div> <p>No Zero Speed Delay The drive receives a stop command and decelerates along a ramp. When the motor actual speed falls below the value of parameter 22.05 ZERO SPEED LIMIT, the speed controller is switched off. The inverter modulation is stopped and the motor coasts to standstill.</p> <p>With Zero Speed Delay The drive receives a stop command and decelerates along a ramp. When the actual motor speed falls below the value of parameter 22.05 ZERO SPEED LIMIT, the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetised and the drive is ready for a quick restart. Zero speed delay can be used, eg, with the jogging function.</p>		
	0...30000 ms	Zero speed delay.
22.07	ABOVE SPEED LIM	FW block: SPEED FEEDBACK (see above)
Defines the supervision limit for the actual speed. See also parameter 2.13 FBA MAIN SW , bit 10.		
	0...30000 rpm	Supervision limit for actual speed.

22.08	SPEED TRIPMARGIN	FW block: SPEED FEEDBACK (see above)
<p>Defines, together with 20.01 MAXIMUM SPEED and 20.02 MINIMUM SPEED, the maximum allowed speed of the motor (overspeed protection). If the actual speed (1.01 SPEED ACT) exceeds the speed limit defined by parameter 20.01 or 20.02 by more than 22.08 SPEED TRIPMARGIN, the drive trips on fault OVERSPEED.</p> <p>Example: If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm.</p> 		
0...10000 rpm		Speed trip margin.
22.09	SPEED FB FAULT	FW block: SPEED FEEDBACK (see above)
<p>Selects the action in case of speed feedback data loss.</p> <p>Note: If this parameter is set to (1) Warning or (2) No, a loss of feedback will cause an internal faulted state. To clear the internal fault and to reactivate speed feedback, use parameter 90.10 ENC PAR REFRESH.</p>		
(0) Fault	Drive trips on a fault (OPTION COMM LOSS, ENCODER 1/2, ENCODER 1/2 CABLE or SPEED FEEDBACK depending on the type of problem).	
(1) Warning	Drive continues operation with open loop control and generates an alarm (OPTION COMM LOSS, ENCODER 1/2 FAILURE, ENCODER 1/2 CABLE or SPEED FEEDBACK depending on the type of problem).	
(2) No	Drive continues operation with open loop control. No faults or alarms are generated. The encoder speed is zero until encoder operation is reactivated with parameter 90.10 ENC PAR REFRESH .	

22.10	SPD SUPERV EST	FW block: FAULT FUNCTIONS (see page 198)
<p>Defines the activation level for encoder supervision. The drive reacts according to 22.09 SPEED FB FAULT when:</p> <ul style="list-style-type: none"> the estimated speed (1.14 SPEED ESTIMATED) is greater than 22.10 SPD SUPERV EST AND the filtered encoder speed* is lower than 22.11 SPD SUPERV ENC.  <p>*Filtered outcome of encoder 1/2 speed. Parameter 22.12 SPD SUPERV FILT defines the filtration coefficient for this speed.</p> <p>**In normal operation, the filtered encoder speed is equal to signal 1.14 SPEED ESTIMATED.</p> <p>Encoder supervision can be disabled by setting this parameter to the maximum speed.</p>		
<p>0...30000 rpm Activation level for encoder supervision.</p>		
22.11	SPD SUPERV ENC	FW block: FAULT FUNCTIONS (see page 198)
<p>Defines the activation level for the encoder speed used in encoder supervision. See parameter 22.10 SPD SUPERV EST.</p>		
<p>0...30000 rpm Activation level for the encoder speed.</p>		
22.12	SPD SUPERV FILT	FW block: FAULT FUNCTIONS (see page 198)
<p>Defines the time constant for the encoder speed filtration used in encoder supervision. See parameter 22.10 SPD SUPERV EST.</p>		
<p>0...10000 ms Time constant for the encoder speed filtration.</p>		

Group 24 SPEED REF MOD

Settings for

- speed reference selection
- speed reference modification (scaling and inversion)
- constant speed and jogging references
- definition of absolute minimum speed reference.


Depending on user selection, either speed reference 1 or speed reference 2 is active at a time.


Speed reference can be any of the following (in priority order):

- fault speed reference (in a control panel or PC tool communication break)
- local speed reference (from panel)
- fieldbus local reference
- jogging reference 1/2
- constant speed reference 1/2
- external speed reference.

Note: Constant speed overrides external speed reference.

Speed reference is limited according to the set minimum and maximum speed values and ramped and shaped according to the defined acceleration and deceleration values. See parameter group [25](#) (page [161](#)).






<p>Firmware block: SPEED REF SEL (23)</p> <p>Selects the sources for two speed references, REF1 or REF2, from a selection list. Also shows the values of both speed references.</p> <p>The sources can alternatively be selected with value pointer parameters. See firmware block SPEED REF MOD on page 158.</p>		
<p>Block outputs located in other parameter groups</p>		<p>3.01 SPEED REF1 (page 103) 3.02 SPEED REF2 (page 103)</p>
24.01	SPEED REF1 SEL	FW block: SPEED REF SEL (see above)
	<p>Selects the source for speed reference 1 (3.01 SPEED REF1).</p> <p>Source for speed reference 1/2 can also be selected by value pointer parameter 24.03 SPEED REF1 IN / 24.04 SPEED REF2 IN.</p>	
	(0) ZERO	Zero reference.
	(1) AI1	Analogue input AI1.
	(2) AI2	Analogue input AI2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive to drive reference 1.

	(6) D2D REF2	Drive to drive reference 2.
	(7) ENC1 SPEED	Encoder 1 (1.08 ENCODER 1 SPEED).
	(8) ENC2 SPEED	Encoder 2 (1.10 ENCODER 2 SPEED).
24.02	SPEED REF2 SEL	FW block: SPEED REF SEL (see above)
	Selects the source for speed reference 2 (3.02 SPEED REF2). See parameter 24.01 SPEED REF1 SEL .	

Firmware block: SPEED REF MOD (24)		
This block <ul style="list-style-type: none"> selects the sources for two speed references, REF1 or REF2 scales and inverts the speed reference defines the constant speed reference defines the speed reference for jogging functions 1 and 2 defines the speed reference absolute minimum limit. 		
Block outputs located in other parameter groups		3.03 SPEEDREF RAMP IN (page 103)
24.03	SPEED REF1 IN	FW block: SPEED REF MOD (see above)
	Selects the source for speed reference 1 (overrides the setting of parameter 24.01 SPEED REF1 SEL). The default value is P.3.1, ie, 3.01 SPEED REF1 , which is the output of the SPEED REF RAMP block.	
	Value pointer: Group and index	
24.04	SPEED REF2 IN	FW block: SPEED REF MOD (see above)
	Selects the source for speed reference 2 (overrides the setting of parameter 24.02 SPEED REF2 SEL). The default value is P.3.2, ie, 3.02 SPEED REF2 , which is the output of the SPEED REF RAMP block.	
	Value pointer: Group and index	
24.05	SPEED REF 1/2SEL	FW block: SPEED REF MOD (see above)
	Selects between speed reference 1 or 2. Reference 1/2 source is defined by parameter 24.03 SPEED REF1 IN / 24.04 SPEED REF2 IN . 0 = Speed reference 1.	
	Bit pointer: Group, index and bit	
24.06	SPEED SHARE	FW block: SPEED REF MOD (see above)
	Defines the scaling factor for speed reference 1/2 (speed reference 1 or 2 is multiplied by the defined value). Speed reference 1 or 2 is selected by parameter 24.05 SPEED REF 1/2SEL .	


	-8...8	Scaling factor for speed reference 1/2.
24.07	SPEEDREF NEG ENA	FW block: SPEED REF MOD (see above)
	Selects the source for the speed reference inversion. 1 = Sign of the speed reference is changed (inversion active).	
	Bit pointer: Group, index and bit	
24.08	CONST SPEED	FW block: SPEED REF MOD (see above)
	Defines the constant speed.	
	-30000...30000 rpm	Constant speed.
24.09	CONST SPEED ENA	FW block: SPEED REF MOD (see above)
	Selects the source for enabling the use of the constant speed reference define by parameter 24.08 CONST SPEED . 1 = Enable.	
	Bit pointer: Group, index and bit	
24.10	SPEED REF JOG1	FW block: SPEED REF MOD (see above)
	Defines the speed reference for jogging function 1. See section Jogging on page 52.	
	-30000...30000 rpm	Speed reference for jogging 1.
24.11	SPEED REF JOG2	FW block: SPEED REF MOD (see above)
	Defines the speed reference for jogging function 2. See section Jogging on page 52.	
	-30000...30000 rpm	Speed reference for jogging 2.
24.12	SPEED REFMIN ABS	FW block: SPEED REF MOD (see above)
	<p>Defines the absolute minimum limit for the speed reference.</p> 	
	0...30000 rpm	Absolute minimum limit for speed reference.

Group 25 SPEED REF RAMP

Speed reference ramp settings such as

- selection of source for speed ramp input
- acceleration and deceleration times (also for jogging)
- acceleration and deceleration ramp shapes
- emergency stop OFF3 ramp time
- the speed reference balancing function (forcing the output of the ramp generator to a predefined value).

Note: Emergency stop OFF1 uses the currently active ramp time.



<p>Firmware block: SPEED REF RAMP (25)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for the speed ramp input • adjusts acceleration and deceleration times (also for jogging) • adjusts acceleration/deceleration ramp shapes • adjusts ramp time for emergency stop OFF3 • forces the output of the ramp generator to a defined value • shows the ramped and shaped speed reference value. 		
Block outputs located in other parameter groups		3.04 SPEEDREF RAMPED (page 103)
25.01	SPEED RAMP IN	FW block: SPEED REF RAMP (see above)
	Shows the source of the speed ramp input. The default value is P.3.3, ie, signal 3.03 SPEEDREF RAMP IN , which is the output of the SPEED REF MOD firmware block.	
	Value pointer: Group and index	
25.02	SPEED SCALING	FW block: SPEED REF RAMP (see above)
	Defines the speed value used in acceleration and deceleration (parameters 25.03/25.09 and 25.04/25.10/25.11). Also affects fieldbus reference scaling (see Appendix A – Fieldbus control , section Fieldbus references on page 432).	
	0...30000 rpm	Speed value for acceleration/deceleration.
25.03	ACC TIME	FW block: SPEED REF RAMP (see above)
	Defines the acceleration time, ie, the time required for the speed to change from zero to the speed value defined by parameter 25.02 SPEED SCALING . If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate. If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference signal. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	
	0...1800 s	Acceleration time.

25.04	DEC TIME	FW block: SPEED REF RAMP (see above)
	<p>Defines the deceleration time, ie, the time required for the speed to change from the speed value defined by parameter 25.02 SPEED SCALING to zero.</p> <p>If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference signal.</p> <p>If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate.</p> <p>If the deceleration time is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits. If there is any doubt about the deceleration time being too short, ensure that the DC overvoltage control is on (parameter 47.01 OVERVOLTAGE CTRL).</p> <p>Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with an electric braking option, eg, with a braking chopper (built-in) and a braking resistor.</p>	
	0...1800 s	Deceleration time.
25.05	SHAPE TIME ACC1	FW block: SPEED REF RAMP (see above)
	<p>Selects the shape of the acceleration ramp at the beginning of the acceleration.</p> <p>0.00 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.</p> <p>0.01...1000.00 s: S-curve ramp. S-curve ramps are ideal for conveyor and lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.</p> <p>Note: When jogging or emergency ramp stop is active, acceleration and deceleration shape times are forced to zero.</p>	
	0...1000 s	Ramp shape at beginning of acceleration.
25.06	SHAPE TIME ACC2	FW block: SPEED REF RAMP (see above)
	<p>Selects the shape of the acceleration ramp at the end of the acceleration. See parameter 25.05 SHAPE TIME ACC1.</p>	
	0...1000 s	Ramp shape at end of acceleration.
25.07	SHAPE TIME DEC1	FW block: SPEED REF RAMP (see above)
	<p>Selects the shape of the deceleration ramp at the beginning of the deceleration. See parameter 25.05 SHAPE TIME ACC1.</p>	
	0...1000 s	Ramp shape at beginning of deceleration.


25.08	SHAPE TIME DEC2	FW block: SPEED REF RAMP (see above)
	Selects the shape of the deceleration ramp at the end of the deceleration. See parameter 25.05 SHAPE TIME ACC1 .	
	0...1000 s	Ramp shape at end of deceleration.
25.09	ACC TIME JOGGING	FW block: SPEED REF RAMP (see above)
	Defines the acceleration time for the jogging function, ie, the time required for the speed to change from zero to the speed value defined by parameter 25.02 SPEED SCALING .	
	0...1800 s	Acceleration time for jogging.
25.10	DEC TIME JOGGING	FW block: SPEED REF RAMP (see above)
	Defines the deceleration time for the jogging function, ie, the time required for the speed to change from the speed value defined by parameter 25.02 SPEED SCALING to zero.	
	0...1800 s	Deceleration time for jogging.
25.11	EM STOP TIME	FW block: SPEED REF RAMP (see above)
	Defines the time inside which the drive is stopped if an emergency stop OFF3 is activated (ie, the time required for the speed to change from the speed value defined by parameter 25.02 SPEED SCALING to zero). Emergency stop activation source is selected by parameter 10.10 EM STOP OFF3 . Emergency stop can also be activated through fieldbus (2.12 FBA MAIN CW). Emergency stop OFF1 uses the active ramp time.	
	0...1800 s	Emergency stop OFF3 deceleration time.
25.12	SPEEDREF BAL	FW block: SPEED REF RAMP (see above)
	Defines the reference for the speed ramp balancing, ie, the output of the speed reference ramp firmware block is forced to a defined value. The source for the balancing enable signal is selected by parameter 25.13 SPEEDREF BAL .	
	-30000...30000 rpm	Speed ramp balancing reference.
25.13	SPEEDREF BAL ENA	FW block: SPEED REF RAMP (see above)
	Selects the source for enabling the speed ramp balancing. See parameter 25.12 SPEEDREF BAL . 1 = Speed ramp balancing enabled.	
	Bit pointer: Group, index and bit	

Group 26 SPEED ERROR

Speed error is determined by comparing the speed reference and speed feedback. The error can be filtered using a first-order low-pass filter if the feedback and reference have disturbances. In addition, a torque boost can be applied to compensate acceleration; the torque is relative to the rate of change (derivative) in the speed reference and inertia of the load. The speed error value can be supervised using the window function.



The signals used as speed reference are (see also parameter group 34 on page 185):

- 3.04 SPEEDREF RAMPED (speed, “min” and “max” control modes)
- 4.01 SPEED REF POS (position, synchron and homing control modes)
- 4.20 SPEED FEED FWD (profile velocity mode).



<p>Firmware block: SPEED ERROR (26)</p> <p>This block</p> <ul style="list-style-type: none"> selects the source for speed error calculation (speed reference - actual speed) in different control modes selects the sources for speed reference and speed reference feedforward defines the speed error filtering time defines an additional speed step to the speed error defines the supervision of speed error with the speed error window function defines inertia compensation during acceleration shows the used speed reference, filtered speed error and the output of the acceleration compensation. 		
<p>Block outputs located in other parameter groups</p>	<p>3.05 SPEEDREF USED (page 103) 3.06 SPEED ERROR FILT (page 103) 3.07 ACC COMP TORQ (page 103)</p>	
<p>26.01</p>	<p>SPEED ACT NCTRL</p>	<p>FW block: SPEED ERROR (see above)</p>
	<p>Selects the source for the actual speed in the speed control mode. Note: This parameter has been locked, ie, no user setting is possible.</p>	
	<p>Value pointer: Group and index</p>	
<p>26.02</p>	<p>SPEED REF NCTRL</p>	<p>FW block: SPEED ERROR (see above)</p>
	<p>Selects the source for the speed reference in the speed control mode. Note: This parameter has been locked, ie, no user setting is possible.</p>	
	<p>Value pointer: Group and index</p>	
<p>26.03</p>	<p>SPEED REF PCTRL</p>	<p>FW block: SPEED ERROR (see above)</p>
	<p>Selects the source for the speed reference in position and synchron control modes. Note: This parameter is only for positioning applications.</p>	
	<p>Value pointer: Group and index</p>	
<p>26.04</p>	<p>SPEED FEED PCTRL</p>	<p>FW block: SPEED ERROR (see above)</p>
	<p>Selects the source for the speed reference feedforward in position and synchron control modes. Selects the source for the speed reference in homing and profile velocity modes.</p>	

	Value pointer: Group and index	
26.05	SPEED STEP	FW block: SPEED ERROR (see above)
	Defines an additional speed step given to the input of the speed controller (added to the speed error value).	
	-30000...30000 rpm	Speed step.
26.06	SPD ERR FTIME	FW block: SPEED ERROR (see above)
	<p>Defines the time constant of the speed error low pass filter.</p> <p>If the used speed reference changes rapidly (servo application), the possible interferences in the speed measurement can be filtered with the speed error filter. Reducing the ripple with filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.</p> <p>See also parameter 22.02 SPEED ACT FTIME.</p>	
	0...1000 ms	Time constant for speed error low pass filter. 0 ms = filtering disabled.
26.07	SPEED WINDOW	FW block: SPEED ERROR (see above)
	<p>Defines the absolute value for the motor speed window supervision, ie, the absolute value for the difference between the actual speed and the unramped speed reference (1.01 SPEED ACT - 3.03 SPEEDREF RAMP IN). When the motor speed is within the limits defined by this parameter, signal 2.13 bit 8 (AT_SETPOINT) value is 1. If the motor speed is not within the defined limits, bit 8 value is 0.</p>	
	0...30000 rpm	Absolute value for motor speed window supervision.

26.08	ACC COMP DERTIME	FW block: SPEED ERROR (see above)
<p>Defines the derivation time for acceleration (deceleration) compensation. Used to improve the speed control dynamic reference change.</p> <p>In order to compensate inertia during acceleration, a derivative of the speed reference is added to the output of the speed controller. The principle of a derivative action is described for parameter 28.04 DERIVATION TIME.</p> <p>Note: The parameter value should be proportional to the total inertia of the load and motor, ie, approximately 50...100% of the mechanical time constant (t_{mech}). See the mechanical time constant equation in parameter 22.02 SPEED ACT FTIME.</p> <p>If parameter value is set to zero, the function is deactivated.</p> <p>The figure below shows the speed responses when a high inertia load is accelerated along a ramp.</p> <div style="display: flex; justify-content: space-around;"> <div data-bbox="416 667 767 696" style="text-align: center;"> <p>No acceleration compensation</p>  </div> <div data-bbox="903 667 1273 696" style="text-align: center;"> <p>With acceleration compensation</p>  </div> </div> <p>See also parameter 26.09 ACC COMP FTIME.</p> <p>The source for the acceleration compensation torque can also be selected by parameter 28.06 ACC COMPENSATION. See parameter group 28.</p>		
0...600 s		Derivation time for acceleration/deceleration compensation.
26.09	ACC COMP FTIME	FW block: SPEED ERROR (see above)
Defines the filter time for the acceleration compensation.		
0...1000 ms		Filter time for acceleration compensation. 0 ms = filtering disabled.
26.10	SPEED WIN FUNC	FW block: SPEED ERROR (see above)
<p>Enables or disables speed error window control.</p> <p>Speed error window control forms a speed supervision function for a speed and torque-controlled drive (Add operating mode). It supervises the speed error value (speed reference – actual speed). In the normal operating range, window control keeps the speed controller input at zero. The speed controller is evoked only if</p> <ul style="list-style-type: none"> • the speed error exceeds the upper boundary of the window (parameter 26.11 SPEED WIN HI), or • the absolute value of the negative speed error exceeds the lower boundary of the window (parameter 26.12 SPEED WIN LO). <p>When the speed error moves outside the window, the exceeding part of the error value is connected to the speed controller. The speed controller produces a reference term relative to the input and gain of the speed controller (parameter 28.02 PROPORT GAIN) which the torque selector adds to the torque reference. The result is used as the internal torque reference for the drive.</p> <p>Example: In a load loss condition, the internal torque reference of the drive is decreased to prevent an excessive rise of the motor speed. If window control were inactive, the motor speed would rise until a speed limit of the drive were reached.</p>		
(0) Disabled		Speed error window control inactive.

	(1) Absolute	Speed error window control active. The boundaries defined by parameters 26.11 and 26.12 are absolute.
	(2) Relative	Speed error window control active. The boundaries defined by parameters 26.11 and 26.12 are relative to speed reference.
26.11	SPEED WIN HI	FW block: SPEED ERROR (see above)
	Defines the upper boundary of the speed error window. Depending on the setting of parameter 26.10 SPEED WIN FUNC , this is either an absolute value or relative to speed reference.	
	0...3000 rpm	Upper boundary of speed error window.
26.12	SPEED WIN LO	FW block: SPEED ERROR (see above)
	Defines the lower boundary of the speed error window. Depending on the setting of parameter 26.10 SPEED WIN FUNC , this is either an absolute value or relative to speed reference.	
	0...3000 rpm	Lower boundary of speed error window.


Group 28 SPEED CONTROL



Speed controller settings such as


- selection of source for speed error
- adjustment of PID-type speed controller variables
- limitation of speed controller output torque
- selection of source for acceleration compensation torque
- forcing an external value to the output of the speed controller (with the balancing function).
- adjustment of the load sharing in a Master/Follower application run by several drives (the drooping function).


The speed controller includes an anti-windup function (ie, I-term is frozen during torque reference limitation).


In torque control mode, the speed controller output is frozen.




<p>Firmware block: SPEED CONTROL (28)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for speed error • adjusts PID-type speed controller variables • defines limits for speed controller output torque • selects the source for acceleration compensation torque • configures the balancing function which forces the output of the speed controller to an external value • configures the drooping function (adjustment of load sharing in a Master/Follower application) • shows the limited speed controller output torque value. 	
<p>Block outputs located in other parameter groups</p>	<p>3.08 TORQ REF SP CTRL (page 103)</p>
<p>28.01 SPEED ERR NCTRL</p>	<p>FW block: SPEED CONTROL (see above)</p>
<p>Selects the source for the speed error (reference - actual). The default value is P.3.6, ie, parameter 3.06 SPEED ERROR FILT, which is the output of the SPEED ERROR firmware block.</p> <p>Note: This parameter has been locked, ie, no user setting is possible.</p>	
<p>Value pointer: Group and index</p>	
<p>28.02 PROPORT GAIN</p>	<p>FW block: SPEED CONTROL (see above)</p>
<p>Defines the proportional gain (K_p) of the speed controller. Too large a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p>If gain is set to 1, a 10% change in error value (reference - actual value) causes the speed controller output to change by 10%.</p> <p>Note: This parameter is automatically set by the speed controller autotune function. See parameter 28.16 PI TUNE MODE.</p>	
<p>0...200</p>	<p>Proportional gain for speed controller.</p>

28.03	INTEGRATION TIME	FW block: SPEED CONTROL (see above)
<p>Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected. Too short integration time makes the control unstable.</p> <p>If parameter value is set to zero, the I-part of the controller is disabled.</p> <p>Anti-windup stops the integrator if the controller output is limited. See 6.05 LIMIT WORD 1.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p>Note: This parameter is automatically set by the speed controller autotune function. See parameter 28.16 PI TUNE MODE.</p>		
	0...600 s	Integration time for speed controller.

28.04	DERIVATION TIME	FW block: SPEED CONTROL (see above)
<p>Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances.</p> <p>The speed error derivative must be filtered with a low pass filter to eliminate disturbances.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p> <div style="text-align: center;"> <p>Gain = $K_p = 1$ T_I = Integration time > 0 T_D = Derivation time > 0 T_s = Sample time period = 250 μs e = Error value Δe = Error value change between two samples</p> </div>  <p>Note: Changing this parameter value is recommended only if a pulse encoder is used.</p>		
	0...10 s	Derivation time for speed controller.
28.05	DERIV FILT TIME	FW block: SPEED CONTROL (see above)
Defines the derivation filter time constant.		
	0...1000 ms	Derivation filter time constant.
28.06	ACC COMPENSATION	FW block: SPEED CONTROL (see above)
<p>Selects the source for the acceleration compensation torque.</p> <p>The default value is P.3.7, ie, signal 3.07 ACC COMP TORQ, which is the output of the SPEED ERROR firmware block.</p> <p>Note: This parameter has been locked, ie, no user setting is possible.</p>		
Value pointer: Group and index		

28.07	DROOPING RATE	FW block: SPEED CONTROL (see above)
	<p>Defines the droop rate (in percent of the motor nominal speed). The drooping slightly decreases the drive speed as the drive load increases. The actual speed decrease at a certain operating point depends on the droop rate setting and the drive load (= torque reference / speed controller output). At 100% speed controller output, drooping is at its nominal level, ie, equal to the value of this parameter. The drooping effect decreases linearly to zero along with the decreasing load.</p> <p>Drooping rate can be used, eg, to adjust the load sharing in a Master/Follower application run by several drives. In a Master/Follower application the motor shafts are coupled to each other.</p> <p>The correct droop rate for a process must be found out case by case in practice.</p> <p>Speed decrease = Speed controller output × Drooping × Max. speed Example: Speed controller output is 50%, drooping rate is 1%, maximum speed of the drive is 1500 rpm. Speed decrease = 0.50 × 0.01 × 1500 rpm = 7.5 rpm.</p> 	
	0...100%	Droop rate.
28.08	BAL REFERENCE	FW block: SPEED CONTROL (see above)
	<p>Defines the reference used in the speed control output balancing, ie, an external value to be forced to the output of the speed controller. In order to guarantee smooth operation during output balancing, the speed controller D-part is disabled and the acceleration compensation term is set to zero.</p> <p>The source for the balancing enable signal is selected by parameter 28.09 SPEEDCTRL BAL EN.</p>	
	-1600...1600%	Speed control output balancing reference.
28.09	SPEEDCTRL BAL EN	FW block: SPEED CONTROL (see above)
	<p>Selects the source for the speed control output balancing enable signal. See parameter 28.08 BAL REFERENCE. 1 = Enabled. 0 = Disabled.</p>	
	Bit pointer: Group, index and bit	
28.10	MIN TORQ SP CTRL	FW block: SPEED CONTROL (see above)
	Defines the minimum speed controller output torque.	
	-1600...1600%	Minimum speed controller output torque.
28.11	MAX TORQ SP CTRL	FW block: SPEED CONTROL (see above)
	Defines the maximum speed controller output torque.	
	-1600...1600%	Maximum speed controller output torque.


28.12	PI ADAPT MAX SPD	FW block: SPEED CONTROL (see above)
<p>Maximum actual speed for speed controller adaptation.</p> <p>Speed controller gain and integration time can be adapted according to actual speed. This is done by multiplying the gain (28.02 PROPORT GAIN) and integration time (28.03 INTEGRATION TIME) by coefficients at certain speeds. The coefficients are defined individually for both gain and integration time.</p> <p>When the actual speed is below or equal to 28.13 PI ADAPT MIN SPD, 28.02 PROPORT GAIN and 28.03 INTEGRATION TIME are multiplied by 28.14 P GAIN ADPT COEF and 28.15 I TIME ADPT COEF respectively.</p> <p>When the actual speed is equal to or exceeds 28.12 PI ADAPT MAX SPD, no adaptation takes place; in other words, 28.02 PROPORT GAIN and 28.03 INTEGRATION TIME are used as such.</p> <p>Between 28.13 PI ADAPT MIN SPD and 28.12 PI ADAPT MAX SPD, the coefficients are calculated linearly on the basis of the breakpoints.</p> <div data-bbox="359 728 1332 1120" style="text-align: center;"> <p style="text-align: center;">Coefficient for K_p or T_i</p> <p style="text-align: center;">K_p = Proportional gain T_i = Integration time</p> <p style="text-align: center;">1.000</p> <p style="text-align: center;">28.14 P GAIN ADPT COEF or 28.15 I TIME ADPT COEF</p> <p style="text-align: center;">0 28.13 PI ADAPT MIN SPD 28.12 PI ADAPT MAX SPD</p> <p style="text-align: right;">Actual speed (rpm)</p> </div>		
	0...30000 rpm	Maximum actual speed for speed controller adaptation.
28.13	PI ADAPT MIN SPD	FW block: SPEED CONTROL (see above)
<p>Minimum actual speed for speed controller adaptation. See parameter 28.12 PI ADAPT MAX SPD.</p>		
	0...30000 rpm	Minimum actual speed for speed controller adaptation.
28.14	P GAIN ADPT COEF	FW block: SPEED CONTROL (see above)
<p>Proportional gain coefficient. See parameter 28.12 PI ADAPT MAX SPD.</p>		
	0.000 ... 10.000	Proportional gain coefficient.
28.15	I TIME ADPT COEF	FW block: SPEED CONTROL (see above)
<p>Integration time coefficient. See parameter 28.12 PI ADAPT MAX SPD.</p>		
	0.000 ... 10.000	Integration time coefficient.

28.16	PI TUNE MODE	FW block: None
	<p>Activates the speed controller autotune function.</p> <p>The autotune will automatically set parameters 28.02 PROPORT GAIN and 28.03 INTEGRATION TIME, as well as 1.31 MECH TIME CONST. If the User autotune mode is chosen, also 26.06 SPD ERR FTIME is automatically set.</p> <p>The status of the autotune routine is shown by parameter 6.03 SPEED CTRL STAT.</p> <p> WARNING! The motor will reach the torque and current limits during the autotune routine. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE AUTOTUNE ROUTINE!</p> <p>Notes:</p> <ul style="list-style-type: none"> • Before using the autotune function, the following parameters should be set: <ul style="list-style-type: none"> • All parameters adjusted during the start-up as described in chapter Start-up (page 17) • 22.05 ZERO SPEED LIMIT • Speed scaling and reference ramp settings in parameter group 25 • 26.06 SPD ERR FTIME • If the User autotune mode is desired: 28.17 TUNE BANDWIDTH and 28.18 TUNE DAMPING. • The drive must be in local control mode and stopped before an autotune is requested. • After requesting an autotune with this parameter, start the drive within 20 seconds. • Wait until the autotune routine is completed (this parameter has reverted to the value (0) Done). The routine can be aborted by stopping the drive. • Check the values of the parameters set by the autotune function. <p>See also section Speed controller tuning on page 53.</p>	
	(0) Done	No tuning has been requested (normal operation). The parameter also reverts to this value after an autotune is completed.
	(1) Smooth	Request speed controller autotune with preset settings for smooth operation.
	(2) Middle	Request speed controller autotune with preset settings for medium-tight operation.
	(3) Tight	Request speed controller autotune with preset settings for tight operation.
	(4) User	Request speed controller autotune with the settings defined by parameters 28.17 TUNE BANDWIDTH and 28.18 TUNE DAMPING .
28.17	TUNE BANDWIDTH	FW block: None
	<p>Speed controller bandwidth for autotune procedure, User mode (see parameter 28.16 PI TUNE MODE).</p> <p>A larger bandwidth results in more restricted speed controller settings.</p>	
	0.00 ... 2000.00 Hz	Tune bandwidth for User autotune mode.
28.18	TUNE DAMPING	FW block: None
	<p>Speed controller damping for autotune procedure, User mode (see parameter 28.16 PI TUNE MODE).</p> <p>Higher damping results in safer and smoother operation.</p>	
	0.0 ... 200.0	Speed controller damping for User autotune mode.


Group 32 TORQUE REFERENCE

Reference settings for torque control.

In torque control, the drive speed is limited between the defined minimum and maximum limits. Speed-related torque limits are calculated and the input torque reference is limited according to these limits. An OVERSPEED fault is generated if the maximum allowed speed is exceeded.




Firmware block: TORQ REF SEL (32)		
Block outputs located in other parameter groups		3.09 TORQ REF1 (page 103) 3.12 TORQUE REF ADD (page 103)
32.01	TORQ REF1 SEL	FW block: TORQ REF SEL (see above)
	Selects the source for torque reference 1. See also parameter 32.03 TORQ REF IN .	
	(0) ZERO	Zero reference.
	(1) AI1	Analogue input AI1.
	(2) AI2	Analogue input AI2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive to drive reference 1.
	(6) D2D REF2	Drive to drive reference 2.
32.02	TORQ REF ADD SEL	FW block: TORQ REF SEL (see above)
	Selects the source for the torque reference addition, 3.12 TORQUE REF ADD . Parameter 34.10 TORQ REF ADD SRC is connected to signal 3.12 TORQUE REF ADD by default. Because the reference is added after the torque reference selection, this parameter can be used in speed and torque control modes. See the block diagram in parameter group 34 (page 185).	
	(0) ZERO	Zero reference addition.
	(1) AI1	Analogue input AI1.
	(2) AI2	Analogue input AI2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive to drive reference 1.
	(6) D2D REF2	Drive to drive reference 2.

<p>Firmware block: TORQ REF MOD (33)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for the torque reference • scales the input torque reference according to the defined load share factor • defines limits for the torque reference • defines ramp-up and ramp-down times for the torque reference • shows the ramped torque reference value and the torque reference value limited by the rush control. 	
<p>Block outputs located in other parameter groups</p>	<p>3.10 TORQ REF RAMPED (page 103) 3.11 TORQ REF RUSHLIM (page 103)</p>
<p>32.03 TORQ REF IN</p>	<p>FW block: TORQ REF MOD (see above)</p>
<p>Selects the source for the torque reference input for the torque ramp function. The default value is P.3.9, ie, signal 3.09 TORQ REF1, which is the output of the TORQ REF SEL firmware block.</p>	
<p>Value pointer: Group and index</p>	
<p>32.04 MAXIMUM TORQ REF</p>	<p>FW block: TORQ REF MOD (see above)</p>
<p>Defines the maximum torque reference.</p>	
<p>0...1000%</p>	<p>Maximum torque reference.</p>
<p>32.05 MINIMUM TORQ REF</p>	<p>FW block: TORQ REF MOD (see above)</p>
<p>Defines the minimum torque reference.</p>	
<p>-1000...0%</p>	<p>Minimum torque reference.</p>
<p>32.06 LOAD SHARE</p>	<p>FW block: TORQ REF MOD (see above)</p>
<p>Scales the external torque reference to a required level (external torque reference is multiplied by the selected value). Note: If local torque reference is used, no load share scaling is applied.</p>	
<p>-8...8</p>	<p>External torque reference multiplier.</p>
<p>32.07 TORQ RAMP UP</p>	<p>FW block: TORQ REF MOD (see above)</p>
<p>Defines the torque reference ramp-up time, ie, the time for the reference to increase from zero to the nominal motor torque.</p>	
<p>0...60 s</p>	<p>Torque reference ramp-up time.</p>

32.08	TORQ RAMP DOWN	FW block: TORQ REF MOD (see above)
	Defines the torque reference ramp-down time, ie, the time for the reference to decrease from the nominal motor torque to zero.	
	0...60 s	Torque reference ramp-down time.
32.09	RUSH CTRL GAIN	FW block: TORQ REF MOD (see above)
	Defines the proportional gain of the rush controller.	
	1...10000	Proportional gain of the rush controller.
32.10	RUSH CTRL TI	FW block: TORQ REF MOD (see above)
	Defines the integration time of the rush controller.	
	0.1...10 s	Integration time of the rush controller.
32.11	TORQ START ABS	FW block: TORQ REF MOD (see above)
	<p>Defines the absolute value of torque to use when the drive is started. If external or local torque reference is negative at start, then the used starting torque is also negative.</p> <p>The controlled starting torque feature activates at start when 32.12 TORQ START TIME1 or 32.13 TORQ START TIME2 is set to a non-zero value, and the absolute value of the torque reference used is lower than defined in parameter 32.11 TORQ START ABS. It automatically deactivates if the sign of the torque reference used is changed.</p> <p>Note: Rush control is active also with starting torque. Consequently, the actual torque used during start might be decreased to a very low value to prevent excessive motor speed, if the requested starting torque (32.11 TORQ START ABS) is too high compared to the actual load on the motor.</p>	
	15...300%	Absolute value of starting torque.
32.12	TORQ START TIME1	FW block: TORQ REF MOD (see above)
	Defines the time that the starting torque specified in 32.11 TORQ START ABS is used after start.	
	0...60 s	Duration of starting torque.
32.13	TORQ START TIME2	FW block: TORQ REF MOD (see above)
	Defines the starting torque ramp time. The torque defined in 32.11 TORQ START ABS is ramped down (or up if negative) to zero within the time defined by this parameter.	
	0...60 s	Starting torque ramp time.

Group 33 SUPERVISION

Configuration of signal supervision.

<p>Firmware block: SUPERVISION (17)</p>	 <p>The diagram shows a block titled 'SUPERVISION' with a width of 45 and a height of 6. It contains parameters 33.01 to 33.12. Lines connect these parameters to the bit 0 of the '6.14 SUPERV STATUS' register. Parameters 33.01, 33.04, 33.05, 33.09, and 33.12 are shown as '[Disabled]'. Parameters 33.02, 33.03, 33.06, 33.07, 33.08, 33.10, and 33.11 are shown with their respective signal names and values: 33.02 SUPERV1 ACT (< [SPEED ACT] (7 / 1.01) [0.00]), 33.03 SUPERV1 LIM HI ([0.00]), 33.04 SUPERV1 LIM LO ([Disabled]), 33.06 SUPERV2 ACT (< [CURRENT] (1 / 1.04) [0.00]), 33.07 SUPERV2 LIM HI ([0.00]), 33.08 SUPERV2 LIM LO ([Disabled]), 33.10 SUPERV3 ACT (< [TORQUE] (1 / 1.06) [0.00]), and 33.11 SUPERV3 LIM HI ([0.00]).</p>	
<p>Block outputs located in other parameter groups</p>	<p>6.14 SUPERV STATUS (page 114)</p>	
<p>33.01</p>	<p>SUPERV1 FUNC</p>	<p>FW block: SUPERVISION (see above)</p>
	<p>Selects the mode of supervision 1.</p>	
	<p>(0) Disabled</p>	<p>Supervision 1 not in use.</p>
	<p>(1) Low</p>	<p>When the signal selected by parameter 33.02 SUPERV1 ACT falls below the value of parameter 33.04 SUPERV1 LIM LO, bit 0 of 6.14 SUPERV STATUS is activated. To clear the bit, the signal must exceed the value of parameter 33.03 SUPERV1 LIM HI.</p>
	<p>(2) High</p>	<p>When the signal selected by parameter 33.02 SUPERV1 ACT exceeds the value of parameter 33.03 SUPERV1 LIM HI, bit 0 of 6.14 SUPERV STATUS is activated. To clear the bit, the signal must fall below the value of parameter 33.04 SUPERV1 LIM LO.</p>
	<p>(3) Abs Low</p>	<p>When the absolute value of the signal selected by parameter 33.02 SUPERV1 ACT falls below the value of parameter 33.04 SUPERV1 LIM LO, bit 0 of 6.14 SUPERV STATUS is activated. To clear the bit, the absolute value of the signal must exceed the value of parameter 33.03 SUPERV1 LIM HI.</p>
	<p>(4) Abs High</p>	<p>When the absolute value of the signal selected by parameter 33.02 SUPERV1 ACT exceeds the value of parameter 33.03 SUPERV1 LIM HI, bit 0 of 6.14 SUPERV STATUS is activated. To clear the bit, the absolute value of the signal must fall below the value of parameter 33.04 SUPERV1 LIM LO.</p>
<p>33.02</p>	<p>SUPERV1 ACT</p>	<p>FW block: SUPERVISION (see above)</p>
	<p>Selects the signal to be monitored by supervision 1. See parameter 33.01 SUPERV1 FUNC.</p>	
	<p>Value pointer: Group and index</p>	

33.03	SUPERV1 LIM HI	FW block: SUPERVISION (see above)
	Sets the upper limit for supervision 1. See parameter 33.01 SUPERV1 FUNC .	
	-32768...32768	Upper limit for supervision 1.
33.04	SUPERV1 LIM LO	FW block: SUPERVISION (see above)
	Sets the lower limit for supervision 1. See parameter 33.01 SUPERV1 FUNC .	
	-32768...32768	Lower limit for supervision 1.
33.05	SUPERV2 FUNC	FW block: SUPERVISION (see above)
	Selects the mode of supervision 2.	
	(0) Disabled	Supervision 2 not in use.
	(1) Low	When the signal selected by parameter 33.06 SUPERV2 ACT falls below the value of parameter 33.08 SUPERV2 LIM LO , bit 1 of 6.14 SUPERV STATUS is activated. To clear the bit, the signal must exceed the value of parameter 33.07 SUPERV2 LIM HI .
	(2) High	When the signal selected by parameter 33.06 SUPERV2 ACT exceeds the value of parameter 33.07 SUPERV2 LIM HI , bit 1 of 6.14 SUPERV STATUS is activated. To clear the bit, the signal must fall below the value of parameter 33.08 SUPERV2 LIM LO .
	(3) Abs Low	When the absolute value of the signal selected by parameter 33.06 SUPERV2 ACT falls below the value of parameter 33.08 SUPERV2 LIM LO , bit 1 of 6.14 SUPERV STATUS is activated. To clear the bit, the absolute value of the signal must exceed the value of parameter 33.07 SUPERV2 LIM HI .
	(4) Abs High	When the absolute value of the signal selected by parameter 33.06 SUPERV2 ACT exceeds the value of parameter 33.07 SUPERV2 LIM HI , bit 1 of 6.14 SUPERV STATUS is activated. To clear the bit, the absolute value of the signal must fall below the value of parameter 33.08 SUPERV2 LIM LO .
33.06	SUPERV2 ACT	FW block: SUPERVISION (see above)
	Selects the signal to be monitored by supervision 2. See parameter 33.05 SUPERV2 FUNC .	
	Value pointer: Group and index	
33.07	SUPERV2 LIM HI	FW block: SUPERVISION (see above)
	Sets the upper limit for supervision 2. See parameter 33.05 SUPERV2 FUNC .	
	-32768...32768	Upper limit for supervision 2.
33.08	SUPERV2 LIM LO	FW block: SUPERVISION (see above)
	Sets the lower limit for supervision 2. See parameter 33.05 SUPERV2 FUNC .	
	-32768...32768	Lower limit for supervision 2.

33.09	SUPERV3 FUNC	FW block: SUPERVISION (see above)
	Selects the mode of supervision 3.	
	(0) Disabled	Supervision 3 not in use.
	(1) Low	When the signal selected by parameter 33.10 SUPERV3 ACT falls below the value of parameter 33.12 SUPERV3 LIM LO , bit 2 of 6.14 SUPERV STATUS is activated. To clear the bit, the signal must exceed the value of parameter 33.11 SUPERV3 LIM HI .
	(2) High	When the signal selected by parameter 33.10 SUPERV3 ACT exceeds the value of parameter 33.11 SUPERV3 LIM HI , bit 2 of 6.14 SUPERV STATUS is activated. To clear the bit, the signal must fall below the value of parameter 33.12 SUPERV3 LIM LO .
	(3) Abs Low	When the absolute value of the signal selected by parameter 33.10 SUPERV3 ACT falls below the value of parameter 33.12 SUPERV3 LIM LO , bit 2 of 6.14 SUPERV STATUS is activated. To clear the bit, the absolute value of the signal must exceed the value of parameter 33.11 SUPERV3 LIM HI .
	(4) Abs High	When the absolute value of the signal selected by parameter 33.10 SUPERV3 ACT exceeds the value of parameter 33.11 SUPERV3 LIM HI , bit 2 of 6.14 SUPERV STATUS is activated. To clear the bit, the absolute value of the signal must fall below the value of parameter 33.12 SUPERV3 LIM LO .
33.10	SUPERV3 ACT	FW block: SUPERVISION (see above)
	Selects the signal to be monitored by supervision 3. See parameter 33.09 SUPERV3 FUNC .	
	Value pointer: Group and index	
33.11	SUPERV3 LIM HI	FW block: SUPERVISION (see above)
	Sets the upper limit for supervision 3. See parameter 33.09 SUPERV3 FUNC .	
	-32768...32768	Upper limit for supervision 3.
33.12	SUPERV3 LIM LO	FW block: SUPERVISION (see above)
	Sets the lower limit for supervision 3. See parameter 33.09 SUPERV3 FUNC .	
	-32768...32768	Lower limit for supervision 3.
33.17	BIT0 INVERT SRC	FW block: None
	Parameters 33.17...33.22 enable the inversion of freely selectable source bits. The inverted bits are shown by parameter 6.17 BIT INVERTED SW . This parameter selects the source bit whose inverted value is shown by parameter 6.17 BIT INVERTED SW , bit 0.	
	DI1	Digital input DI1 (as indicated by 2.01 DI STATUS , bit 0).
	DI2	Digital input DI2 (as indicated by 2.01 DI STATUS , bit 1).
	DI3	Digital input DI3 (as indicated by 2.01 DI STATUS , bit 2).


	DI4	Digital input DI4 (as indicated by 2.01 DI STATUS , bit 3).
	DI5	Digital input DI5 (as indicated by 2.01 DI STATUS , bit 4).
	DI6	Digital input DI6 (as indicated by 2.01 DI STATUS , bit 5).
	RO1	Relay output RO1 (as indicated by 2.02 RO STATUS , bit 0).
	RO2	Relay output RO2 (as indicated by 2.02 RO STATUS , bit 1).
	RO3	Relay output RO3 (as indicated by 2.02 RO STATUS , bit 2).
	RO4	Relay output RO4 (as indicated by 2.02 RO STATUS , bit 3).
	RO5	Relay output RO5 (as indicated by 2.02 RO STATUS , bit 4).
	Running	Bit 3 of 6.01 STATUS WORD 1 (see page 120).
	Const	Constant and bit pointer settings (see Bit pointer parameter on page 91).
	Pointer	
33.18	BIT1 INVERT SRC	FW block: None
		Selects the source bit whose inverted value is shown by 6.17 BIT INVERTED SW , bit 1. For the selections, see parameter 33.17 BIT0 INVERT SRC .
33.19	BIT2 INVERT SRC	FW block: None
		Selects the source bit whose inverted value is shown by 6.17 BIT INVERTED SW , bit 2. For the selections, see parameter 33.17 BIT0 INVERT SRC .
33.20	BIT3 INVERT SRC	FW block: None
		Selects the source bit whose inverted value is shown by 6.17 BIT INVERTED SW , bit 3. For the selections, see parameter 33.17 BIT0 INVERT SRC .
33.21	BIT4 INVERT SRC	FW block: None
		Selects the source bit whose inverted value is shown by 6.17 BIT INVERTED SW , bit 4. For the selections, see parameter 33.17 BIT0 INVERT SRC .
33.22	BIT5 INVERT SRC	FW block: None
		Selects the source bit whose inverted value is shown by 6.17 BIT INVERTED SW , bit 5. For the selections, see parameter 33.17 BIT0 INVERT SRC .


Group 34 REFERENCE CTRL

Reference source and type selection.

Using the parameters in this group, it is possible to select whether external control location EXT1 or EXT2 is used (either one is active at a time). These parameters also select the control mode (SPEED/TORQUE/MIN/MAX/ADD/POSITION/ SYNCHRON/HOMING/PROF VEL) and the used torque reference in local and external control. It is possible to select two different control modes for the EXT1 location by using parameters [34.03 EXT1 CTRL MODE1](#) and [34.04 EXT1 CTRL MODE2](#); the same start/stop commands are used in both modes.

For more information on control locations and control modes, see chapter [Drive control and features](#). For start/stop control in different control locations, see parameter group [10](#) (page [122](#)).






Firmware block: REFERENCE CTRL (34)		<table border="1"> <thead> <tr> <th colspan="2">REFERENCE CTRL</th> </tr> </thead> <tbody> <tr> <td>TLF8</td> <td>250 μsec (3)</td> </tr> <tr> <td colspan="2" style="text-align: center;"> 3.13 TORQ REF TO TC 6.12 OP MODE ACK </td> </tr> <tr> <td>[DI STATUS.1]</td> <td>< 34.01 EXT1/EXT2 SEL</td> </tr> <tr> <td>(2 / 2.01.DI2)</td> <td>< 34.02 EXT1 MODE 1/2SEL</td> </tr> <tr> <td>[DI STATUS.5]</td> <td>< 34.03 EXT1 CTRL MODE1</td> </tr> <tr> <td>(2 / 2.01.DI6)</td> <td>< 34.04 EXT1 CTRL MODE2</td> </tr> <tr> <td>[Speed]</td> <td>< 34.05 EXT2 CTRL MODE1</td> </tr> <tr> <td>[Homing]</td> <td>< 34.07 LOCAL CTRL MODE</td> </tr> <tr> <td>[Position]</td> <td>< 34.08 TREF SPEED SRC</td> </tr> <tr> <td>[Speed]</td> <td>< 34.09 TREF TORQ SRC</td> </tr> <tr> <td>TORQ REF SP CTRL</td> <td>< 34.10 TORQ REF ADD SRC</td> </tr> <tr> <td>(7 / 3.08)</td> <td></td> </tr> <tr> <td>TORQ REF RUSHLIM</td> <td></td> </tr> <tr> <td>(8 / 3.11)</td> <td></td> </tr> <tr> <td>[TORQUE REF ADD]</td> <td></td> </tr> <tr> <td>(8 / 3.12)</td> <td></td> </tr> </tbody> </table>	REFERENCE CTRL		TLF8	250 μsec (3)	3.13 TORQ REF TO TC 6.12 OP MODE ACK		[DI STATUS.1]	< 34.01 EXT1/EXT2 SEL	(2 / 2.01.DI2)	< 34.02 EXT1 MODE 1/2SEL	[DI STATUS.5]	< 34.03 EXT1 CTRL MODE1	(2 / 2.01.DI6)	< 34.04 EXT1 CTRL MODE2	[Speed]	< 34.05 EXT2 CTRL MODE1	[Homing]	< 34.07 LOCAL CTRL MODE	[Position]	< 34.08 TREF SPEED SRC	[Speed]	< 34.09 TREF TORQ SRC	TORQ REF SP CTRL	< 34.10 TORQ REF ADD SRC	(7 / 3.08)		TORQ REF RUSHLIM		(8 / 3.11)		[TORQUE REF ADD]		(8 / 3.12)	
REFERENCE CTRL																																				
TLF8	250 μsec (3)																																			
3.13 TORQ REF TO TC 6.12 OP MODE ACK																																				
[DI STATUS.1]	< 34.01 EXT1/EXT2 SEL																																			
(2 / 2.01.DI2)	< 34.02 EXT1 MODE 1/2SEL																																			
[DI STATUS.5]	< 34.03 EXT1 CTRL MODE1																																			
(2 / 2.01.DI6)	< 34.04 EXT1 CTRL MODE2																																			
[Speed]	< 34.05 EXT2 CTRL MODE1																																			
[Homing]	< 34.07 LOCAL CTRL MODE																																			
[Position]	< 34.08 TREF SPEED SRC																																			
[Speed]	< 34.09 TREF TORQ SRC																																			
TORQ REF SP CTRL	< 34.10 TORQ REF ADD SRC																																			
(7 / 3.08)																																				
TORQ REF RUSHLIM																																				
(8 / 3.11)																																				
[TORQUE REF ADD]																																				
(8 / 3.12)																																				
Block outputs located in other parameter groups		3.13 TORQ REF TO TC (page 103) 6.12 OP MODE ACK (page 114)																																		
34.01	EXT1/EXT2 SEL	FW block: REFERENCE CTRL (see above)																																		
	Selects the source for external control location EXT1/EXT2 selection. 0 = EXT1. 1 = EXT2.																																			
	Bit pointer: Group, index and bit																																			
34.02	EXT1 MODE 1/2SEL	FW block: REFERENCE CTRL (see above)																																		
	Selects the source for EXT1 control mode 1/2 selection. 1 = mode 2. 0 = mode 1. Control mode 1/2 is selected by parameter 34.03 EXT1 CTRL MODE1 / 34.04 EXT1 CTRL MODE2.																																			
	Bit pointer: Group, index and bit																																			
34.03	EXT1 CTRL MODE1	FW block: REFERENCE CTRL (see above)																																		
	Selects control mode 1 for external control location EXT1.																																			
	(1) Speed	Speed control. Torque reference is 3.08 TORQ REF SP CTRL, which is the output of the SPEED CONTROL firmware block. Torque reference source can be changed by parameter 34.08 TREF SPEED SRC.																																		

	(2) Torque	Torque control. Torque reference is 3.11 TORQ REF RUSHLIM , which is the output of the TORQ REF MOD firmware block. Torque reference source can be changed by parameter 34.09 TREF TORQ SRC .
	(3) Min	Combination of selections (1) Speed and (2) Torque : Torque selector compares the torque reference and the speed controller output and the smaller of them is used.
	(4) Max	Combination of selections (1) Speed and (2) Torque : Torque selector compares the torque reference and the speed controller output and the greater of them is used.
	(5) Add	Combination of selections (1) Speed and (2) Torque : Torque selector adds the speed controller output to the torque reference.
	(6) Position	Position control. Torque reference is 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Speed reference is 4.01 SPEED REF POS , which is an output of the POS CONTROL firmware block. Speed reference source can be changed by parameter 26.03 SPEED REF PCTRL .
	(7) Synchron	Synchron control. Torque reference is 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Speed reference is 4.01 SPEED REF POS , which is an output of the POS CONTROL firmware block. Speed reference source can be changed by parameter 26.03 SPEED REF PCTRL .
	(8) Homing	Homing control. Torque reference is 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Speed reference is 4.20 SPEED FEED FWD , which is an output of the POS CONTROL firmware block. Speed reference source can be changed by parameter 26.04 SPEED FEED PCTRL .
	(9) Prof Vel	Profile velocity control. Used, eg, with CANOpen profile. Torque reference is 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Speed reference is 4.20 SPEED FEED FWD , which is an output of the POS CONTROL firmware block. Speed reference source can be changed by parameter 26.04 SPEED FEED PCTRL .
34.04	EXT1 CTRL MODE2	FW block: REFERENCE CTRL (see above)
	Selects control mode 2 for external control location EXT1. For selections, see parameter 34.03 EXT1 CTRL MODE1 .	
34.05	EXT2 CTRL MODE1	FW block: REFERENCE CTRL (see above)
	Selects control mode for external control location EXT2. For selections, see parameter 34.03 EXT1 CTRL MODE1 .	

34.07	LOCAL CTRL MODE	FW block: REFERENCE CTRL (see above)
	Selects the control mode for local control. Note: This parameter cannot be changed while the drive is running.	
	(1) Speed	Speed control. Torque reference is 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Torque reference source can be changed by parameter 34.08 TREF SPEED SRC .
	(2) Torque	Torque control. Torque reference is 3.11 TORQ REF RUSHLIM , which is an output of the TORQ REF MOD firmware block. Torque reference source can be changed by parameter 34.09 TREF TORQ SRC .
	(6) Position	Position control. Torque reference is 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Speed reference is 4.01 SPEED REF POS , which is an output of the POS CONTROL firmware block. Speed reference source can be changed by parameter 26.03 SPEED REF PCTRL .
34.08	TREF SPEED SRC	FW block: REFERENCE CTRL (see above)
	Selects the source for the torque reference (from the speed controller). Default value is P.3.8, ie, 3.08 TORQ REF SP CTRL , which is the output of the SPEED CONTROL firmware block. Note: This parameter has been locked, ie, no user setting is possible.	
	Value pointer: Group and index	
34.09	TREF TORQ SRC	FW block: REFERENCE CTRL (see above)
	Selects the source for the torque reference (from the torque reference chain). Default value is P.3.11, ie, 3.11 TORQ REF RUSHLIM , which is an output of the TORQ REF MOD firmware block. Note: This parameter has been locked, ie, no user setting is possible.	
	Value pointer: Group and index	
34.10	TORQ REF ADD SRC	FW block: REFERENCE CTRL (see above)
	Selects the source for the torque reference added to the torque value after the torque selection. Default value is P.3.12, ie, 3.12 TORQUE REF ADD , which is an output of the TORQ REF SEL firmware block. Note: This parameter has been locked, ie, no user setting is possible.	
	Value pointer: Group and index	

Group 35 MECH BRAKE CTRL

Settings for the control of a mechanical brake. See also section [Mechanical brake control](#) on page 57.

<p>Firmware block: MECH BRAKE CTRL (35)</p>	 <p>The diagram shows the MECH BRAKE CTRL block with parameters 35.01 through 35.09. Each parameter is connected to a value in a yellow box: 35.01 to [NO], 35.02 to [FALSE], 35.03 to [0.00 s], 35.04 to [0.00 s], 35.05 to [100.0 rpm], 35.06 to [0.0 %], 35.07 to [FALSE], 35.08 to [FALSE], and 35.09 to [FAULT]. On the right, parameters 3.14 BRAKE TORQ MEM and 3.15 BRAKE COMMAND are shown with arrows pointing to the right.</p>	
<p>Block outputs located in other parameter groups</p>	<p>3.14 BRAKE TORQ MEM (page 103) 3.15 BRAKE COMMAND (page 104)</p>	
<p>35.01</p>	<p>BRAKE CONTROL</p>	<p>FW block: MECH BRAKE CTRL (see above)</p>
	<p>Activates the brake control function with or without supervision. Note: This parameter cannot be changed while the drive is running.</p>	
	<p>(0) NO</p>	<p>Inactive.</p>
	<p>(1) WITH ACK</p>	<p>Brake control with supervision (supervision is activated by parameter 35.02 BRAKE ACKNOWL).</p>
	<p>(2) NO ACK</p>	<p>Brake control without supervision.</p>
<p>35.02</p>	<p>BRAKE ACKNOWL</p>	<p>FW block: MECH BRAKE CTRL (see above)</p>
	<p>Selects the source for the external brake on/off supervision activation (when par. 35.01 BRAKE CONTROL = (1) WITH ACK). The use of the external on/off supervision signal is optional. 1 = The brake is open. 0 = The brake is closed. Brake supervision is usually controlled with a digital input. It can also be controlled with an external control system, eg, fieldbus. When brake control error is detected the drive reacts as defined by parameter 35.09 BRAKE FAULT FUNC. Note: This parameter cannot be changed while the drive is running.</p>	
	<p>Bit pointer: Group, index and bit</p>	

35.03	BRAKE OPEN DELAY	FW block: MECH BRAKE CTRL (see above)
	<p>Defines the brake open delay (= the delay between the internal open brake command and the release of the motor speed control). The delay counter starts when the drive has magnetised the motor and risen the motor torque to the level required at the brake release (parameter 35.06 BRAKE OPEN TORQ). Simultaneously with the counter start, the brake function energises the relay output controlling the brake and the brake starts opening.</p> <p>Set the delay the same as the mechanical opening delay of the brake specified by the brake manufacturer.</p>	
	0...5 s	Brake open delay.
35.04	BRAKE CLOSE DLY	FW block: MECH BRAKE CTRL (see above)
	<p>Defines the brake close delay. The delay counter starts when the motor actual speed has fallen below the set level (parameter 35.05 BRAKE CLOSE SPD) after the drive has received the stop command. Simultaneously with the counter start, the brake control function de-energises the relay output controlling the brake and the brake starts closing. During the delay, the brake function keeps the motor live preventing the motor speed from falling below zero.</p> <p>Set the delay time to the same value as the mechanical make-up time of the brake (= operating delay when closing) specified by the brake manufacturer.</p>	
	0...60 s	Brake close delay.
35.05	BRAKE CLOSE SPD	FW block: MECH BRAKE CTRL (see above)
	Defines the brake close speed (an absolute value). See parameter 35.04 BRAKE CLOSE DLY .	
	0...1000 rpm	Brake close speed.
35.06	BRAKE OPEN TORQ	FW block: MECH BRAKE CTRL (see above)
	Defines the motor starting torque at brake release (in percent of the motor nominal torque).	
	0...1000%	Motor starting torque at brake release.
35.07	BRAKE CLOSE REQ	FW block: MECH BRAKE CTRL (see above)
	<p>Selects the source for the brake close (open) request. 1 = Brake close request. 0 = Brake open request.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	Bit pointer: Group, index and bit	
35.08	BRAKE OPEN HOLD	FW block: MECH BRAKE CTRL (see above)
	<p>Selects the source for the activation of the brake open command hold. 1 = Hold active. 0 = Normal operation.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	Bit pointer: Group, index and bit	

35.09	BRAKE FAULT FUNC	FW block: MECH BRAKE CTRL (see above)
	Defines how the drive reacts in case of mechanical brake control error. If brake control supervision has not been activated by parameter 35.01 BRAKE CONTROL , this parameter is disabled.	
	(0) FAULT	The drive trips on fault BRAKE NOT CLOSED / BRAKE NOT OPEN if the status of the optional external brake acknowledgement signal does not meet the status presumed by the brake control function. The drive trips on fault BRAKE START TORQUE if the required motor starting torque at brake release is not achieved.
	(1) ALARM	The drive generates alarm BRAKE NOT CLOSED / BRAKE NOT OPEN if the status of the optional external brake acknowledgement signal does not meet the status presumed by the brake control function. The drive generates alarm BRAKE START TORQUE if the required motor starting torque at brake release is not achieved.
	(2) OPEN FLT	The drive generates alarm BRAKE NOT CLOSED (when closing the brake) and trips on fault BRAKE NOT OPEN (when opening the brake) if the status of the optional external brake acknowledgement signal does not match the status presumed by the brake control function. The drive trips on BRAKE START TORQUE if the required motor start torque at brake release is not achieved.

Group 40 MOTOR CONTROL

Motor control settings, such as

- flux reference
- drive switching frequency
- motor slip compensation
- voltage reserve
- flux optimisation
- IR compensation for scalar control mode.


Flux optimisation

Flux optimisation reduces the total energy consumption and motor noise level when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1% to 10%, depending on the load torque and speed.

Note: Flux optimisation limits the dynamic control performance of the drive because with a small flux reference the drive torque cannot be increased fast.


Firmware block: MOTOR CONTROL (40)		
This block defines motor control settings such as <ul style="list-style-type: none"> • flux reference • drive switching frequency • motor slip compensation • voltage reserve • flux optimisation • IR compensation for scalar control mode • flux braking. The block also shows the flux and torque reference used.		
Block outputs located in other parameter groups		3.16 FLUX REF USED (page 104) 3.17 TORQUE REF USED (page 104)
40.01	FLUX REF	FW block: MOTOR CONTROL (see above)
	Defines the flux reference.	
	0...200%	Flux reference.
40.02	SF REF	FW block: MOTOR CONTROL (see above)
	Defines the switching frequency of the drive. When switching frequency exceeds 4 kHz, the allowed drive output current is limited. See switching frequency derating in the appropriate <i>Hardware Manual</i> .	
	1/2/3/4/5/8/16 kHz	Switching frequency.

40.03	SLIP GAIN	FW block: MOTOR CONTROL (see above)
	<p>Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite of the full slip gain.</p> <p>Example (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive. Despite of the full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased. At the 105% gain value, no static speed error exists (2 rpm / 40 rpm = 5%).</p>	
	0...200%	Slip gain.
40.04	VOLTAGE RESERVE	FW block: MOTOR CONTROL (see above)
	<p>Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area.</p> <p>If the intermediate circuit DC voltage $U_{dc} = 550 \text{ V}$ and the voltage reserve is 5%, the RMS value of the maximum output voltage in steady-state operation is</p> $0.95 \times 550 \text{ V} / \sqrt{2} = 369 \text{ V}$ <p>The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier.</p>	
	-4...50%	Minimum allowed voltage reserve.
40.05	FLUX OPT	FW block: MOTOR CONTROL (see above)
	<p>Enables the flux optimisation function. Flux optimisation improves motor efficiency and reduces noise. Flux optimisation is used in drives that usually operate below nominal load.</p> <p>Note: With a permanent magnet motor, flux optimisation is always enabled regardless of this parameter.</p>	
	(0) Disable	Flux optimisation disabled.
	(1) Enable	Flux optimisation enabled.
40.06	FORCE OPEN LOOP	FW block: MOTOR CONTROL (see above)
	Defines the speed/position information used by the motor model.	
	(0) FALSE	Motor model uses the speed feedback selected by parameter 22.01 SPEED FB SEL .
	(1) TRUE	Motor model uses the internal speed estimate (even when parameter 22.01 SPEED FB SEL setting is (1) Enc1 speed / (2) Enc2 speed).

40.07	IR COMPENSATION	FW block: MOTOR CONTROL (see above)
<p>Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with high break-away torque when no DTC motor can be applied.</p> <p>This parameter is only effective when parameter 99.05 MOTOR CTRL MODE is set to (1) Scalar.</p> 		
0...50%		IR compensation.
40.10	FLUX BRAKING	FW block: MOTOR CONTROL (see above)
Defines the level of braking power.		
(0) Disabled		Flux braking is disabled.
(1) Moderate		Flux level is limited during the braking. Deceleration time is longer compared to full braking.
(2) Full		Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor.



Group 45 MOT THERM PROT

Settings for thermal protection of the motor. See also section [Thermal motor protection](#) on page 46.

<p>Firmware block: MOT THERM PROT (45)</p> <p>Configures motor overtemperature protection and temperature measurement. Also shows the estimated and measured motor temperatures.</p>		
<p>Block outputs located in other parameter groups</p>		<p>1.17 MOTOR TEMP (page 94) 1.18 MOTOR TEMP EST (page 94)</p>
45.01	MOT TEMP PROT	FW block: MOT THERM PROT (see above)
	<p>Selects how the drive reacts when motor overtemperature is detected.</p>	
	(0) No	Inactive.
	(1) Alarm	The drive generates alarm MOTOR TEMPERATURE when the temperature exceeds the alarm level defined by parameter 45.03 MOT TEMP ALM LIM .
	(2) Fault	The drive generates alarm MOTOR TEMPERATURE or trips on fault MOTOR OVERTEMP when the temperature exceeds the alarm/fault level defined by parameter 45.03 MOT TEMP ALM LIM / 45.04 MOT TEMP FLT LIM .
45.02	MOT TEMP SOURCE	FW block: MOT THERM PROT (see above)
	<p>Selects the motor temperature protection. When overtemperature is detected the drive reacts as defined by parameter 45.01 MOT TEMP PROT.</p>	
	(0) ESTIMATED	<p>The temperature is supervised based on the motor thermal protection model, which uses the motor thermal time constant (parameter 45.10 MOT THERM TIME) and the motor load curve (parameters 45.06...45.08). User tuning is typically needed only if the ambient temperature differs from the normal operating temperature specified for the motor.</p> <p>The motor temperature increases if it operates in the region above the motor load curve. The motor temperature decreases if it operates in the region below the motor load curve (if the motor is overheated).</p> <p> WARNING! The model does not protect the motor if it does not cool properly due to dust and dirt.</p>

	(1) KTY JCU	The temperature is supervised using a KTY84 sensor connected to drive thermistor input TH.
	(2) KTY 1st FEN	The temperature is supervised using a KTY84 sensor connected to encoder interface module FEN-xx installed in drive Slot 1/2. If two encoder interface modules are used, encoder module connected to Slot 1 is used for the temperature supervision. Note: This selection does not apply for FEN-01. *
	(3) KTY 2nd FEN	The temperature is supervised using a KTY84 sensor connected to encoder interface module FEN-xx installed in drive Slot 1/2. If two encoder interface modules are used, encoder module connected to Slot 2 is used for the temperature supervision. Note: This selection does not apply for FEN-01. *
	(4) PTC JCU	The temperature is supervised using 1...3 PTC sensors connected to drive thermistor input TH.
	(5) PTC 1st FEN	The temperature is supervised using 1...3 PTC sensors connected to encoder interface module FEN-xx installed in drive Slot 1/2. If two encoder interface modules are used, encoder module connected to Slot 1 is used for the temperature supervision. *
	(6) PTC 2nd FEN	The temperature is supervised using 1...3 PTC sensors connected to encoder interface module FEN-xx installed in drive Slot 1/2. If two encoder interface modules are used, encoder module connected to Slot 2 is used for the temperature supervision. *
	(13) PT1000 FEN1	The temperature is supervised using a PT1000 sensor connected to encoder interface module FEN-xx installed in drive Slot 1/2. If two encoder interface modules are used, encoder module connected to Slot 1 is used for the temperature supervision. Note: This selection does not apply for FEN-01.
	(14) PT1000 FEN2	The temperature is supervised using a PT1000 sensor connected to encoder interface module FEN-xx installed in drive Slot 1/2. If two encoder interface modules are used, encoder module connected to Slot 1 is used for the temperature supervision. Note: This selection does not apply for FEN-01.
	*Note: If one FEN-xx module is used, parameter setting must be either (2) KTY 1st FEN or (5) PTC 1st FEN. The FEN-xx module can be in either Slot 1 or Slot 2.	
45.03	MOT TEMP ALM LIM	FW block: MOT THERM PROT (see above)
	Defines the alarm limit for the motor overtemperature protection (when par. 45.01 MOT TEMP PROT = (1) Alarm or (2) Fault).	
	0...200 °C	Motor overtemperature alarm limit.
45.04	MOT TEMP FLT LIM	FW block: MOT THERM PROT (see above)
	Defines the fault limit for the motor overtemperature protection (when par. 45.01 MOT TEMP PROT = (2) Fault).	
	0...200 °C	Motor overtemperature fault limit.

45.05	AMBIENT TEMP	FW block: MOT THERM PROT (see above)
	Defines the ambient temperature for the thermal protection mode.	
	-60...100 °C	Ambient temperature.
45.06	MOT LOAD CURVE	FW block: MOT THERM PROT (see above)
	<p>Defines the load curve together with parameters 45.07 ZERO SPEED LOAD and 45.08 BREAK POINT.</p> <p>The value is given in percent of nominal motor current. When the parameter is set to 100%, the maximum load is equal to the value of the parameter 99.06 MOT NOM CURRENT (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value.</p> <p>The load curve is used by the motor thermal protection model when parameter 45.02 MOT TEMP SOURCE is set to (0) ESTIMATED.</p>	
	50...150%	Motor current above breakpoint.
45.07	ZERO SPEED LOAD	FW block: MOT THERM PROT (see above)
	<p>Defines the load curve together with parameters 45.06 MOT LOAD CURVE and 45.08 BREAK POINT. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations.</p> <p>The value is given in percent of nominal motor current.</p> <p>The load curve is used by the motor thermal protection model when parameter 45.02 MOT TEMP SOURCE is set to (0) ESTIMATED.</p>	
	50...150%	Motor current at zero speed.
45.08	BREAK POINT	FW block: MOT THERM PROT (see above)
	<p>Defines the load curve together with parameters 45.06 MOT LOAD CURVE and 45.07 ZERO SPEED LOAD. Defines the break point frequency of the load curve, ie, the point at which the motor load curve begins to decrease from the value of parameter 45.06 MOT LOAD CURVE to the value of parameter 45.07 ZERO SPEED LOAD.</p> <p>The load curve is used by the motor thermal protection model when parameter 45.02 MOT TEMP SOURCE is set to (0) ESTIMATED.</p>	
	0.01...500 Hz	Load curve breakpoint.



45.09	MOTNOM TEMP RISE	FW block: MOT THERM PROT (see above)
<p>Defines the temperature rise of the motor when the motor is loaded with nominal current. See the motor manufacturer's recommendations.</p> <p>The temperature rise value is used by the motor thermal protection model when parameter 45.02 MOT TEMP SOURCE is set to (0) ESTIMATED.</p> 		
0...300 °C		Motor temperature rise.
45.10	MOT THERM TIME	FW block: MOT THERM PROT (see above)
<p>Defines the thermal time constant for the motor thermal protection model (ie, time inside which the temperature has reached 63% of the nominal temperature). See the motor manufacturer's recommendations.</p> <p>The motor thermal protection model is used when parameter 45.02 MOT TEMP SOURCE is set to (0) ESTIMATED.</p> 		
100...10000 s		Motor thermal time.

Group 46 FAULT FUNCTIONS

Definition of drive behaviour upon a fault situation.

An alarm or a fault message indicates abnormal drive status. For the possible causes and remedies, see chapter [Fault tracing](#).

<p>Firmware block: FAULT FUNCTIONS (46)</p> <p>This block</p> <ul style="list-style-type: none"> configures supervision of external faults by defining the source (for example, a digital input) for external fault indication signal selects the reaction of the drive (alarm; fault; continuation at safe speed in some cases) upon situations like local control communication break, motor/supply phase loss, earth fault, or Safe Torque Off function activation shows the codes of the latest faults, the time at which the active fault occurred, and the alarm words. 	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">FAULT FUNCTIONS 33</p> <p style="font-size: small;">MISC_3 2 msec (10)</p> <ul style="list-style-type: none"> 8.01 ACTIVE FAULT --- 8.02 LAST FAULT --- 8.03 FAULT TIME HI --- 8.04 FAULT TIME LO --- 8.05 ALARM LOGGER 1 --- 8.06 ALARM LOGGER 2 --- 8.07 ALARM LOGGER 3 --- 8.08 ALARM LOGGER 4 --- 8.09 ALARM LOGGER 5 --- 8.10 ALARM LOGGER 6 --- 8.15 ALARM WORD 1 --- 8.16 ALARM WORD 2 --- 8.17 ALARM WORD 3 --- 8.18 ALARM WORD 4 --- (Drive value) 22.10 SPD SUPERV EST (Drive value) 22.11 SPD SUPERV ENC (Drive value) 22.12 SPD SUPERV FILT (Drive value) < 46.01 EXTERNAL FAULT (Drive value) 46.02 SPEED REF SAFE (Drive value) 46.03 LOCAL CTRL LOSS (Drive value) 46.04 MOT PHASE LOSS (Drive value) 46.05 EARTH FAULT (Drive value) 46.06 SUPPL PHS LOSS (Drive value) 46.07 STO DIAGNOSTIC (Drive value) 46.08 CROSS CONNECTION (Drive value) 46.09 STALL FUNCTION (Drive value) 46.10 STALL CURR LIM (Drive value) 46.11 STALL FREQ HI (Drive value) 46.12 STALL TIME </div>
<p>Block inputs located in other parameter groups</p>	<p>22.10 SPD SUPERV EST (page 155) 22.11 SPD SUPERV ENC (page 155) 22.12 SPD SUPERV FILT (page 155)</p>
<p>Block outputs located in other parameter groups</p>	<p>8.01 ACTIVE FAULT (page 115) 8.02 LAST FAULT (page 115) 8.03 FAULT TIME HI (page 115) 8.04 FAULT TIME LO (page 115) 8.05 ALARM LOGGER 1 (page 115) 8.06 ALARM LOGGER 2 (page 116) 8.07 ALARM LOGGER 3 (page 116) 8.08 ALARM LOGGER 4 (page 117) 8.09 ALARM LOGGER 5 (page 117) 8.10 ALARM LOGGER 6 (page 117) 8.15 ALARM WORD 1 (page 118) 8.16 ALARM WORD 2 (page 118) 8.17 ALARM WORD 3 (page 119) 8.18 ALARM WORD 4 (page 119)</p>

46.01	EXTERNAL FAULT	FW block: FAULT FUNCTIONS (see above)
	Selects an interface for an external fault signal. 0 = External fault trip. 1 = No external fault.	
	Bit pointer: Group, index and bit	
46.02	SPEED REF SAFE	FW block: FAULT FUNCTIONS (see above)
	Defines the fault speed. Used as a speed reference when an alarm occurs when parameter 13.12 AI SUPERVISION / 46.03 LOCAL CTRL LOSS / 50.02 COMM LOSS FUNC setting is (2) Spd ref Safe.	
	-30000...30000 rpm	Fault speed.
46.03	LOCAL CTRL LOSS	FW block: FAULT FUNCTIONS (see above)
	Selects how the drive reacts to a control panel or PC tool communication break.	
	(0) No	No action.
	(1) Fault	Drive trips on LOCAL CTRL LOSS fault.
	(2) Spd ref Safe	The drive generates alarm LOCAL CTRL LOSS and sets the speed to the speed defined by parameter 46.02 SPEED REF SAFE .  WARNING! Make sure that it is safe to continue operation in case of a communication break.
	(3) Last speed	The drive generates alarm LOCAL CTRL LOSS and freezes the speed to the level the drive was operating at. The speed is determined by the average speed over the previous 10 seconds.  WARNING! Make sure that it is safe to continue operation in case of a communication break.
46.04	MOT PHASE LOSS	FW block: FAULT FUNCTIONS (see above)
	Selects how the drive reacts when a motor phase loss is detected.	
	(0) No	No action.
	(1) Fault	Drive trips on MOTOR PHASE fault.
46.05	EARTH FAULT	FW block: FAULT FUNCTIONS (see above)
	Selects how the drive reacts when an earth fault or current unbalance is detected in the motor or the motor cable.	
	(0) No	No action.
	(1) Warning	Drive generates alarm EARTH FAULT.
	(2) Fault	Drive trips on EARTH FAULT.


46.06	SUPPL PHS LOSS	FW block: FAULT FUNCTIONS (see above)
	Selects how the drive reacts when a supply phase loss is detected. This parameter is only used with an AC supply.	
	(0) No	No reaction.
	(1) Fault	Drive trips on SUPPLY PHASE fault.
46.07	STO DIAGNOSTIC	FW block: FAULT FUNCTIONS (see above)
	<p>Selects how the drive reacts when it detects the absence of one or both Safe Torque Off (STO) signals.</p> <p>Note: This parameter is for supervision only. The Safe Torque Off function can activate even when this parameter is set to (3) No.</p> <p>For general information on the Safe Torque Off function, see the <i>Hardware Manual</i> of the drive and <i>Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives</i> (3AFE68929814 [English]).</p>	
	(1) Fault	The drive trips on SAFE TORQUE OFF when one or both of the STO signals are lost.
	(2) Alarm	<p><u>Drive running:</u> The drive trips on SAFE TORQUE OFF when one or both of the STO signals is lost.</p> <p><u>Drive stopped:</u> The drive generates a SAFE TORQUE OFF alarm if both STO signals are absent. If only one of the signals is lost, the drive trips on STO1 LOST or STO2 LOST.</p>
	(3) No	<p><u>Drive running:</u> The drive trips on SAFE TORQUE OFF when one or both of the STO signals is lost.</p> <p><u>Drive stopped:</u> No action if both STO signals are absent. If only one of the signals is lost, the drive trips on STO1 LOST or STO2 LOST.</p>
	(4) Only Alarm	The drive generates a SAFE TORQUE OFF alarm if both STO signals are absent. If only one of the signals is lost, the drive trips on STO1 LOST or STO2 LOST.
46.08	CROSS CONNECTION	FW block: FAULT FUNCTIONS (see above)
	Selects how the drive reacts to incorrect input power and motor cable connection (ie, input power cable is connected to drive motor connection). This parameter is only used with an AC supply.	
	(0) No	No reaction.
	(1) Fault	Drive trips on CABLE CROSS CON fault.

46.09	STALL FUNCTION	FW block: FAULT FUNCTIONS (see above)								
	<p>Selects how the drive reacts to a motor stall condition.</p> <p>A stall condition is defined as follows:</p> <ul style="list-style-type: none"> • The drive is at stall current limit (46.10 STALL CURR LIM), and • the output frequency is below the level set by parameter 46.11 STALL FREQ HI, and • the conditions above have been valid longer than the time set by parameter 46.12 STALL TIME. <p>A fast stall condition is defined as follows:</p> <ul style="list-style-type: none"> • The drive is at stall current limit (46.10 STALL CURR LIM), and • the output frequency is below the level set by parameter 46.11 STALL FREQ HI, and • the conditions above have been valid longer than the time set by parameter 46.15 FAST STALL TIME <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Ena sup (Enable supervision) 0 = Disabled: Supervision disabled. 1 = Enabled: Supervision enabled.</td> </tr> <tr> <td>1</td> <td>Ena warn (Enable warning) 0 = Disabled 1 = Enabled: Drive generates an alarm upon a stall condition.</td> </tr> <tr> <td>2</td> <td>Ena fault (Enable fault) 0 = Disabled 1 = Enabled: Drive trips on a fault upon a stall condition.</td> </tr> </tbody> </table>		Bit	Function	0	Ena sup (Enable supervision) 0 = Disabled: Supervision disabled. 1 = Enabled: Supervision enabled.	1	Ena warn (Enable warning) 0 = Disabled 1 = Enabled: Drive generates an alarm upon a stall condition.	2	Ena fault (Enable fault) 0 = Disabled 1 = Enabled: Drive trips on a fault upon a stall condition.
Bit	Function									
0	Ena sup (Enable supervision) 0 = Disabled: Supervision disabled. 1 = Enabled: Supervision enabled.									
1	Ena warn (Enable warning) 0 = Disabled 1 = Enabled: Drive generates an alarm upon a stall condition.									
2	Ena fault (Enable fault) 0 = Disabled 1 = Enabled: Drive trips on a fault upon a stall condition.									
46.10	STALL CURR LIM	FW block: FAULT FUNCTIONS (see above)								
	Stall current limit in percent of the nominal current of the motor. See parameter 46.09 STALL FUNCTION .									
	0 ... 1600%	Stall current limit.								
46.11	STALL FREQ HI	FW block: FAULT FUNCTIONS (see above)								
	Stall frequency limit. See parameter 46.09 STALL FUNCTION . Note: Setting the limit below 10 Hz is not recommended.									
	0.5... 1000 Hz	Stall frequency limit.								
46.12	STALL TIME	FW block: FAULT FUNCTIONS (see above)								
	Stall time. See parameter 46.09 STALL FUNCTION .									
	0...3600 s	Stall time.								
46.13	FAN CTRL MODE	FW block: None								
	Selects the fan control mode. Available in frame sizes A to D. See section Fan control logic .									
	(0) Normal	Control mode based on the modulator ON/OFF status.								
	(1) Force OFF	Fan is always OFF.								
	(2) Force ON	Fan is always ON.								
	(3) Advanced	Control mode based on measured temperatures of the power stage, braking chopper and interface board.								

46.14	FAULT STOP MODE	FW block: None
	<p>Fault class selection for non-critical HW faults. Use this parameter for configuring the following faults to the stop mode: 0003, 0005, 0007, 0008, 0011, 0012, 0015, 0024, 0025, 0029, 0030, 0036, 0038...0045, 0047...0051, 0053, 0054, 0057, 0059...0062, 0073, 0074, 0317.</p>	
	(0) Coast	Stop by cutting off the motor power supply. The motor coasts to stop.
	(1) Emergency ramp stop	The drive is stopped along the emergency stop ramp time, 25.11 EM STOP TIME .
46.15	FAST STALL TIME	FW block: None
	<p>Defines the fast stall time. If a fast stall condition is detected, fast stall detection stops drive modulation and automatically forces a new start (up to a maximum of 5 times). See parameter 46.09 STALL FUNCTION. Fast stall detection is disabled when this parameter is set to 0 ms (default). This function is active only for permanent magnet (PM) motors in open loop (estimated speed feedback) control.</p>	
	0...3600 ms	Fast stall time.

Group 47 VOLTAGE CTRL

Settings for overvoltage and undervoltage control, and supply voltage.

<p>Firmware block: VOLTAGE CTRL (47)</p> <p>This block</p> <ul style="list-style-type: none"> enables/disables overvoltage and undervoltage control enables/disables automatic identification of supply voltage provides a parameter for manual definition of supply voltage shows the supply voltage value used by the control program. 	 <p>(Drive value) 47.01 OVERVOLTAGE CTRL</p> <p>(Drive value) 47.02 UNDERVOLT CTRL</p> <p>(Drive value) 47.03 SUPPLVOLT-AUTO-ID</p> <p>(Drive value) 47.04 SUPPLY VOLTAGE</p> <p>(Drive value) < 47.05 LOW VOLT MOD ENA</p> <p>(Drive value) 47.06 LOW VOLT DC MIN</p> <p>(Drive value) 47.07 LOW VOLT DC MAX</p> <p>(Drive value) < 47.08 EXT PU SUPPLY</p>	
<p>Block outputs located in other parameter groups</p>	<p>1.19 USED SUPPLY VOLT (page 94)</p>	
<p>47.01</p>	<p>OVERVOLTAGE CTRL</p>	<p>FW block: VOLTAGE CTRL (see above)</p>
	<p>Enables the overvoltage control of the intermediate DC link. Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque.</p> <p>It is possible to enable the braking chopper and overvoltage controller at the same time. If both are enabled, the overvoltage controller limits are increased above the braking chopper limits. In this configuration, the controller works as a backup for the braking chopper.</p> <p>Note: If a regenerative supply section is included in the drive, the controller must be disabled.</p>	
	<p>(0) Disable</p>	<p>Overvoltage control disabled.</p>
	<p>(1) Enable</p>	<p>Overvoltage control enabled.</p>
<p>47.02</p>	<p>UNDERVOLT CTRL</p>	<p>FW block: VOLTAGE CTRL (see above)</p>
	<p>Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.</p>	
	<p>(0) Disable</p>	<p>Undervoltage control disabled.</p>
	<p>(1) Enable</p>	<p>Undervoltage control enabled.</p>

47.03	SUPPLVOLTAUTO-ID	FW block: VOLTAGE CTRL (see above)
	Enables the auto-identification of the supply voltage. See also section Voltage control and trip limits on page 49.	
	(0) Disable	Auto-identification of supply voltage disabled. The drive sets the voltage control and trip limits using the value of parameter 47.04 SUPPLY VOLTAGE .
	(1) Enable	Auto-identification of supply voltage enabled. The drive detects the supply voltage level during intermediate circuit charging and sets the voltage control and trip limits accordingly.
47.04	SUPPLY VOLTAGE	FW block: VOLTAGE CTRL (see above)
	Defines the nominal supply voltage. Used if auto-identification of the supply voltage is not enabled by parameter 47.03 SUPPLVOLTAUTO-ID .	
	0...1000 V	Nominal supply voltage.
47.05	LOW VOLT MOD ENA	FW block: None
	Enables/disables (or selects a signal source that enables/disables) Low voltage mode. 0 = Low voltage mode disabled, 1 = Low voltage mode enabled. See section Low voltage mode on page 50.	
	Bit pointer: Group, index and bit	
47.06	LOW VOLT DC MIN	FW block: None
	Minimum DC voltage for Low voltage mode. See section Low voltage mode on page 50.	
	250...450 V	Minimum DC voltage for Low voltage mode.
47.07	LOW VOLT DC MAX	FW block: None
	Maximum DC voltage for Low voltage mode. See section Low voltage mode on page 50. Note: The value of this parameter must be higher than (47.06 LOW VOLT DC MIN + 50 V).	
	350...810 V	Maximum DC voltage for Low voltage mode.
47.08	EXT PU SUPPLY	FW block: None
	Enables/disables (or selects a signal source that enables/disables) external power unit supply, used with low DC supply voltages such as a battery. 0 = External power unit supply disabled, 1 = External power unit supply enabled. See section Low voltage mode on page 50.	
	Bit pointer: Group, index and bit	

Group 48 BRAKE CHOPPER



Configuration of an internal braking chopper.


Firmware block: BRAKE CHOPPER (48) This block configures the braking chopper control and supervision.		
48.01	BC ENABLE	FW block: BRAKE CHOPPER (see above)
	Enables the braking chopper control. Note: Before enabling the braking chopper control, make sure that the braking resistor is installed. The drive has a built-in braking chopper.	
	(0) Disable	Braking chopper control disabled.
	(1) EnableTherm	Enable the braking chopper control with resistor overload protection.
	(2) Enable	Enable the braking chopper control without resistor overload protection. This setting can be used, for example, if the resistor is equipped with a thermal circuit breaker that is wired to stop the drive if the resistor overheats.
48.02	BC RUN-TIME ENA	FW block: BRAKE CHOPPER (see above)
	Selects the source for the quick run-time braking chopper control. 0 = Braking chopper operation is prevented. In other words, although the braking chopper has been enabled with parameter 48.01 and DC voltage rises over the activation level, the braking chopper remains inactive. 1 = Braking chopper is always active, ie, the braking chopper starts switching, if the DC voltage reaches the activation level (even if the drive is not running). This parameter can be used for programming the chopper control to function only when the drive is operating in the generating mode. By default this parameter is connected to parameter 06.01 STATUS WORD 1 bit3 (RUNNING).	
	Bit pointer: Group, index and bit	
48.03	BR THERM TIME CONST	FW block: BRAKE CHOPPER (see above)
	Defines the thermal time constant of the braking resistor for overload protection.	
	0... 10000 s	Braking resistor thermal time constant.
48.04	BR POWER MAX CNT	FW block: BRAKE CHOPPER (see above)
	Defines the maximum continuous braking power which will raise the resistor temperature to the maximum allowed value. The value is used in the overload protection.	
	0... 10000 kW	Maximum continuous braking power.

48.05	R BR	FW block: BRAKE CHOPPER (see above)
	Defines the resistance value of the braking resistor. The value is used for braking chopper protection.	
	0.1...1000 ohm	Resistance.
48.06	BR TEMP FAULTLIM	FW block: BRAKE CHOPPER (see above)
	Selects the fault limit for the braking resistor temperature supervision. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 48.04 BR POWER MAX CNT . When the limit is exceeded the drive trips on fault BR OVERHEAT.	
	0...150%	Resistor temperature fault limit.
48.07	BR TEMP ALARMLIM	FW block: BRAKE CHOPPER (see above)
	Selects the alarm limit for the braking resistor temperature supervision. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 48.04 BR POWER MAX CNT . When limit is exceeded the drive generates alarm BR OVERHEAT.	
	0...150%	Resistor temperature alarm limit.

Group 50 FIELDBUS

Basic settings for fieldbus communication. See also [Appendix A – Fieldbus control](#) on page 427.

<p>Firmware block: FIELDBUS (50)</p> <p>This block</p> <ul style="list-style-type: none"> initialises the fieldbus communication selects communication supervision method defines scaling of the fieldbus references and actual values selects sources for programmable status word bits shows the fieldbus control and status words, and references. 		
<p>Block outputs located in other parameter groups</p>	<p>2.12 FBA MAIN CW (page 97) 2.13 FBA MAIN SW (page 100) 2.14 FBA MAIN REF1 (page 101) 2.15 FBA MAIN REF2 (page 101)</p>	
<p>50.01</p>	<p>FBA ENABLE</p>	<p>FW block: FIELDBUS (see above)</p>
	<p>Enables communication between the drive and fieldbus adapter.</p>	
	<p>(0) Disable</p>	<p>No communication.</p>
	<p>(1) Enable</p>	<p>Communication between drive and fieldbus adapter enabled.</p>
<p>50.02</p>	<p>COMM LOSS FUNC</p>	<p>FW block: FIELDBUS (see above)</p>
	<p>Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter 50.03 COMM LOSS T OUT.</p>	
	<p>(0) No</p>	<p>Communication break detection disabled.</p>
	<p>(1) Fault</p>	<p>Communication break detection active. Upon a communication break, the drive trips on fault FIELDBUS COMM and coasts to stop.</p>
	<p>(2) Spd ref Safe</p>	<p>Communication break detection active. Upon a communication break, the drive generates alarm FIELDBUS COMM and sets the speed to the value defined by parameter 46.02 SPEED REF SAFE.</p> <p> WARNING! Make sure that it is safe to continue operation in case of a communication break.</p>

	(3) Last speed	<p>Communication break detection active. Upon a communication break, the drive generates alarm FIELD BUS COMM and freezes the speed to the level the drive was operating at. The speed is determined by the average speed over the previous 10 seconds.</p> <p> WARNING! Make sure that it is safe to continue operation in case of a communication break.</p>
50.03	COMM LOSS T OUT	FW block: FIELD BUS (see above)
	Defines the time delay before the action defined by parameter 50.02 COMM LOSS FUNC is taken. Time count starts when the link fails to update the message.	
	0.3...6553.5 s	Delay for fieldbus communication loss function.
50.04	FBA REF1 MODESEL	FW block: FIELD BUS (see above)
	Selects the fieldbus reference FBA REF1 scaling and the actual value, which is sent to the fieldbus (FBA ACT1).	
	(0) Raw data	No scaling (ie, data is transmitted without scaling). Source for the actual value, which is sent to the fieldbus, is selected by parameter 50.06 FBA ACT1 TR SRC .
	(1) Torque	Fieldbus adapter module uses torque reference scaling. Torque reference scaling is defined by the used fieldbus profile (eg, with ABB Drives Profile integer value 10000 corresponds to 100% torque value). Signal 1.06 TORQUE is sent to the fieldbus as an actual value. See the <i>User's Manual</i> of the appropriate fieldbus adapter module.
	(2) Speed	Fieldbus adapter module uses speed reference scaling. Speed reference scaling is defined by the used fieldbus profile (eg, with ABB Drives Profile integer value 20000 corresponds to the value of parameter 25.02 SPEED SCALING). Signal 1.01 SPEED ACT is sent to the fieldbus as an actual value. See the <i>User's Manual</i> of the appropriate fieldbus adapter module.
	(3) Position	Fieldbus adapter module uses position reference scaling. Position reference scaling is defined by parameters 60.05 POS UNIT and 60.08 POS2INT SCALE . Signal 1.12 POS ACT is sent to the fieldbus as an actual value.
	(4) Velocity	Fieldbus adapter module uses position speed scaling. Position speed scaling is defined by parameters 60.10 POS SPEED UNIT and 60.11 POS SPEED2INT . Signal 4.02 SPEED ACT LOAD is sent to the fieldbus as an actual value.
	(5) Auto	One of the above selections is chosen automatically according to the currently active control mode. See parameter group 34 .
50.05	FBA REF2 MODESEL	FW block: FIELD BUS (see above)
	Selects the fieldbus reference FBA REF2 scaling. See parameter 50.04 FBA REF1 MODESEL .	

50.06	FBA ACT1 TR SRC	FW block: FIELD BUS (see above)
	Selects the source for fieldbus actual value 1 when parameter 50.04 FBA REF1 MODESEL / 50.05 FBA REF2 MODESEL is set to (0) Raw data .	
	Value pointer: Group and index	
50.07	FBA ACT2 TR SRC	FW block: FIELD BUS (see above)
	Selects the source for fieldbus actual value 2 when parameter 50.04 FBA REF1 MODESEL / 50.05 FBA REF2 MODESEL is set to (0) Raw data .	
	Value pointer: Group and index	
50.08	FBA SW B12 SRC	FW block: FIELD BUS (see above)
	Selects the source for freely programmable fieldbus status word bit 28 (2.13 FBA MAIN SW bit 28). Note that this functionality may not be supported by the fieldbus communication profile.	
	Bit pointer: Group, index and bit	
50.09	FBA SW B13 SRC	FW block: FIELD BUS (see above)
	Selects the source for freely programmable fieldbus status word bit 29 (2.13 FBA MAIN SW bit 29). Note that this functionality may not be supported by the fieldbus communication profile.	
	Bit pointer: Group, index and bit	
50.10	FBA SW B14 SRC	FW block: FIELD BUS (see above)
	Selects the source for freely programmable fieldbus status word bit 30 (2.13 FBA MAIN SW bit 30). Note that this functionality may not be supported by the fieldbus communication profile.	
	Bit pointer: Group, index and bit	
50.11	FBA SW B15 SRC	FW block: FIELD BUS (see above)
	Selects the source for freely programmable fieldbus status word bit 31 (2.13 FBA MAIN SW bit 31). Note that this functionality may not be supported by the fieldbus communication profile.	
	Bit pointer: Group, index and bit	

50.12	FBA CYCLE TIME	FW block: FIELDBUS (see above)												
	<p>Selects the fieldbus communication speed. The default selection is (2) Fast. Lowering the speed reduces the CPU load.</p> <p>The table below shows the read/write intervals for cyclic and cyclic low data with each parameter setting.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Cyclic*</th> <th>Cyclic low*</th> </tr> </thead> <tbody> <tr> <td>Slow</td> <td>10 ms</td> <td>10 ms</td> </tr> <tr> <td>Normal</td> <td>2 ms</td> <td>10 ms</td> </tr> <tr> <td>Fast</td> <td>500 us</td> <td>2 ms</td> </tr> </tbody> </table> <p>*Cyclic data consists of fieldbus CW and SW, Ref1 and Ref2, and Act1 and Act2. **Cyclic low data consists of the parameter data mapped to parameter groups 52 and 53.</p>		Selection	Cyclic*	Cyclic low*	Slow	10 ms	10 ms	Normal	2 ms	10 ms	Fast	500 us	2 ms
Selection	Cyclic*	Cyclic low*												
Slow	10 ms	10 ms												
Normal	2 ms	10 ms												
Fast	500 us	2 ms												
	(0) Slow	Slow speed selected.												
	(1) Normal	Normal speed selected.												
	(2) Fast	Fast speed selected.												
50.20	FB MAIN SW FUNC	FW block: FIELDBUS (see above)												
	<p>Contains various compatibility settings especially for drive retrofits.</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td rowspan="2">Run enable func</td> <td>1 = Parameter only: Bit 1 of 2.13 FBA MAIN SW is set to 1 whenever the external run enable signal (par. 10.09 RUN ENABLE) is 1.</td> </tr> <tr> <td>0 = Param AND Fb cw: Bit 1 of 2.13 FBA MAIN SW is set to 1 whenever both the external run enable signal (par. 10.09 RUN ENABLE) is 1 AND 2.12 FBA MAIN CW bit 7 (RUN ENABLE) are 1.</td> </tr> <tr> <td rowspan="2">1</td> <td rowspan="2">Mech brake func</td> <td>1 = Force ramp stop: Drive always uses ramp stop when a mechanical brake is used.</td> </tr> <tr> <td>0 = Allow coast stop: Coast stop is allowed when a mechanical brake is used.</td> </tr> </tbody> </table>		Bit	Name	Information	0	Run enable func	1 = Parameter only: Bit 1 of 2.13 FBA MAIN SW is set to 1 whenever the external run enable signal (par. 10.09 RUN ENABLE) is 1.	0 = Param AND Fb cw: Bit 1 of 2.13 FBA MAIN SW is set to 1 whenever both the external run enable signal (par. 10.09 RUN ENABLE) is 1 AND 2.12 FBA MAIN CW bit 7 (RUN ENABLE) are 1.	1	Mech brake func	1 = Force ramp stop: Drive always uses ramp stop when a mechanical brake is used.	0 = Allow coast stop: Coast stop is allowed when a mechanical brake is used.	
Bit	Name	Information												
0	Run enable func	1 = Parameter only: Bit 1 of 2.13 FBA MAIN SW is set to 1 whenever the external run enable signal (par. 10.09 RUN ENABLE) is 1.												
		0 = Param AND Fb cw: Bit 1 of 2.13 FBA MAIN SW is set to 1 whenever both the external run enable signal (par. 10.09 RUN ENABLE) is 1 AND 2.12 FBA MAIN CW bit 7 (RUN ENABLE) are 1.												
1	Mech brake func	1 = Force ramp stop: Drive always uses ramp stop when a mechanical brake is used.												
		0 = Allow coast stop: Coast stop is allowed when a mechanical brake is used.												

Group 51 FBA SETTINGS

Further fieldbus communication configuration. These parameters need to be set only if a fieldbus adapter module is installed. See also [Appendix A – Fieldbus control](#) on page 427.

Notes:

- This parameter group is presented in the *User's Manual* of the fieldbus adapter as parameter group 1 or A.
- The new settings will take effect when the drive is powered up the next time (before powering off the drive, wait at least 1 minute), or when parameter [51.27 FBA PAR REFRESH](#) is activated.

51.01	FBA TYPE	FW block: None
	Displays the fieldbus protocol on the basis of the adapter module installed.	
	Not defined	Fieldbus adapter module not found (not properly connected, or disabled by parameter 50.01 FBA ENABLE).
	(Fieldbus protocol)	Fieldbus adapter for the stated protocol installed.
51.02	FBA PAR2	FW block: None
...
51.26	FBA PAR26	FW block: None
	Parameters 51.02...51.26 are adapter module-specific. For more information, see the <i>User's Manual</i> of the fieldbus adapter module. Note that not all of these parameters are necessarily used.	
51.27	FBA PAR REFRESH	FW block: None
	Validates any changed adapter module configuration parameter settings. After refreshing, the value reverts automatically to (0) DONE . Note: This parameter cannot be changed while the drive is running.	
	(0) DONE	Refreshing done.
	(1) REFRESH	Refreshing.
51.28	PAR TABLE VER	FW block: None
	Displays the parameter table revision of the fieldbus adapter module mapping file stored in the memory of the drive. In format xyz, where x = major revision number; y = minor revision number; z = correction number.	
51.29	DRIVE TYPE CODE	FW block: None
	Displays the drive type code of the fieldbus adapter module mapping file stored in the memory of the drive. Example: 520 = ACSM1 speed and torque control program.	

51.30	MAPPING FILE VER	FW block: None
	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive. In hexadecimal format. Example: 0x107 = revision 1.07.	
51.31	D2FBA COMM STA	FW block: None
	Displays the status of the fieldbus adapter module communication.	
	(0) IDLE	Adapter not configured.
	(1) EXEC. INIT	Adapter initializing.
	(2) TIME OUT	A timeout has occurred in the communication between the adapter and the drive.
	(3) CONFIG ERROR	Adapter configuration error – the major or minor revision code of the common program revision in the fieldbus adapter module is not the revision required by the module (see par. 51.32 FBA COMM SW VER), or mapping file upload has failed more than three times.
	(4) OFF-LINE	Adapter is off-line.
	(5) ON-LINE	Adapter is on-line.
	(6) RESET	Adapter is performing a hardware reset.
51.32	FBA COMM SW VER	FW block: None
	Displays the common program revision of the adapter module. In format axyz, where a = major revision number, xy = minor revision numbers. z = correction letter. Example: 190A = revision 1.90A.	
51.33	FBAAPPL SW VER	FW block: None
	Displays the application program revision of the adapter module. In format axyz, where: a = major revision number, xy = minor revision numbers, z = correction letter. Example: 190A = revision 1.90A.	

Group 52 FBA DATA IN

These parameters select the data to be sent by the drive to the fieldbus controller, and need to be set only if a fieldbus adapter module is installed. See also [Appendix A – Fieldbus control](#) on page 427.

Notes:

- This parameter group is presented in the *User's Manual* of the fieldbus adapter as parameter group 3 or C.
- The new settings will take effect when the drive is powered up the next time (before powering off the drive, wait at least 1 minute), or when parameter [51.27 FBA PAR REFRESH](#) is activated.
- The maximum number of data words is protocol-dependent.

52.01	FBA DATA IN1	FW block: None
	Selects data to be transferred from the drive to the fieldbus controller.	
	0	Not in use.
	4	Status Word (16 bits).
	5	Actual value 1 (16 bits).
	6	Actual value 2 (16 bits).
	14	Status Word (32 bits).
	15	Actual value 1 (32 bits).
	16	Actual value 2 (32 bits).
	101...9999	Parameter index.
52.02	FBA DATA IN2	FW block: None
...	...	
52.12	FBA DATA IN12	FW block: None
	See 52.01 FBA DATA IN1 .	

Group 53 FBA DATA OUT

These parameters select the data to be sent by the fieldbus controller to the drive, and need to be set only if a fieldbus adapter module is installed. See also [Appendix A – Fieldbus control](#) on page 427.

Notes:

- This parameter group is presented in the *User's Manual* of the fieldbus adapter as parameter group 2 or B.
- The new settings will take effect when the drive is powered up the next time (before powering off the drive, wait at least 1 minute), or when parameter [51.27 FBA PAR REFRESH](#) is activated.
- The maximum number of data words is protocol-dependent.

53.01	FBA DATA OUT1	FW block: None
	Selects data to be transferred from the fieldbus controller to the drive.	
	0	Not in use.
	1	Control Word (16 bits).
	2	Reference REF1 (16 bits).
	3	Reference REF2 (16 bits).
	11	Control Word (32 bits).
	12	Reference REF1 (32 bits).
	13	Reference REF2 (32 bits).
	1001...9999	Parameter index.
53.02	FBA DATA OUT2	FW block: None
...		
53.12	FBA DATA OUT12	FW block: None
	See 53.01 FBA DATA OUT1 .	

Group 55 COMMUNICATION TOOL

Settings for an RS-485 network implemented using optional JPC-01 Network communication adapters. The network enables the use of a single PC or control panel to control multiple drives.

For more information, see the *JPC-01 Network communication adapter User's manual* (3AUA0000072233).

55.01	MDB STATION ID	FW block: None
	Defines the ID of the drive on the RS-485 network. Each drive must have a dedicated ID number.	
	1...247	ID number. For drives, use a number between 1 and 31. (DriveStudio uses ID number 247.)
55.02	MDB BAUD RATE	FW block: None
	Sets the baud rate on the network. Note: This parameter must be set to (0) Auto if a control panel is used as the controlling device.	
	(0) Auto	Baud rate is determined automatically. At start-up, and after a communication break, the initial rate is 9600 baud.
	(1) 9600	9600 baud.
	(2) 19200	19200 baud.
	(3) 38400	38400 baud.
	(4) 57600	57600 baud.
55.03	MDB PARITY	FW block: None
	Defines the use of parity bits. The same setting must be used in all on-line stations.	
	0...3	Number of parity bits. <ul style="list-style-type: none"> • 0 = 8 none 1 • 1 = 8 none 2 • 2 = 8 even 1 • 3 = 8 odd 1

Group 57 D2D COMMUNICATION

Drive-to-drive communication settings. See [Appendix B – Drive-to-drive link](#) on page 435.

<p>Firmware block: D2D COMMUNICATION (57)</p> <p>This block sets up the drive-to-drive communication. It also shows the main drive-to-drive control word and the two references.</p>	
<p>Block outputs located in other parameter groups</p>	<p>2.17 D2D MAIN CW (page 102) 2.19 D2D REF1 (page 102) 2.20 D2D REF2 (page 102)</p>
<p>57.01 LINK MODE</p>	<p>FW block: D2D COMMUNICATION (see above)</p>
	<p>Activates the drive-to-drive connection.</p>
<p>(0) Disabled</p>	<p>Drive-to-drive connection disabled.</p>
<p>(1) Follower</p>	<p>The drive is a follower on the drive-to-drive link.</p>
<p>(2) Master</p>	<p>The drive is the master on the drive-to-drive link. Only one drive can be the master at a time.</p>
<p>57.02 COMM LOSS FUNC</p>	<p>FW block: D2D COMMUNICATION (see above)</p>
<p>Selects how the drive acts when an erroneous drive-to-drive configuration or a communication break is detected.</p>	
<p>(0) No</p>	<p>Protection inactive.</p>
<p>(1) Alarm</p>	<p>The drive generates an alarm.</p>
<p>(2) Fault</p>	<p>The drive trips on a fault.</p>

57.03	NODE ADDRESS	FW block: D2D COMMUNICATION (see above)
	Sets the node address for a follower drive. Each follower must have a dedicated node address. Note: If the drive is set to be the master on the drive-to-drive link, this parameter has no effect (the master is automatically assigned node address 0).	
	1...62	Node address.
57.04	FOLLOWER MASK 1	FW block: D2D COMMUNICATION (see above)
	On the master drive, selects the followers to be polled. If no response is received from a polled follower, the action selected by parameter 57.02 COMM LOSS FUNC is taken. The least significant bit represents follower with node address 1, while the most significant bit represents follower 31. When a bit is set to 1, the corresponding node address is polled. For example, followers 1 and 2 are polled when this parameter is set to the value of 0x3.	
	0x00000000...0x7FFFFFFF	Follower mask 1.
57.05	FOLLOWER MASK 2	FW block: D2D COMMUNICATION (see above)
	On the master drive, selects the followers to be polled. If no response is received from a polled follower, the action selected by parameter 57.02 COMM LOSS FUNC is taken. The least significant bit represents follower with node address 32, while the most significant bit represents follower 62. When a bit is set to 1, the corresponding node address is polled. For example, followers 32 and 33 are polled when this parameter is set to the value of 0x3.	
	0x00000000...0x7FFFFFFF	Follower mask 2.
57.06	REF 1 SRC	FW block: D2D COMMUNICATION (see above)
	Selects the source of D2D reference 1 sent to the followers. The parameter is effective on the master drive, as well as submasters (57.03 NODE ADDRESS = 57.12 REF1 MC GROUP) in a multicast message chain (see parameter 57.11 REF 1 MSG TYPE). The default value is P.03.04, ie, 3.04 SPEEDREF RAMPED .	
	Value pointer: Group and index.	
57.07	REF 2 SRC	FW block: D2D COMMUNICATION (see above)
	On the master drive, selects the source of D2D reference 2 broadcast to all followers. The default value is P.03.13, ie, 3.13 TORQ REF TO TC .	
	Value pointer: Group and index.	
57.08	FOLLOWER CW SRC	FW block: D2D COMMUNICATION (see above)
	Selects the source of the D2D control word sent to the followers. The parameter is effective on the master drive, as well as submasters in a multicast message chain (see parameter 57.11 REF 1 MSG TYPE). The default value is P.02.18, ie, 2.18 D2D FOLLOWER CW .	
	Value pointer: Group and index.	


57.09	KERNEL SYNC MODE	FW block: D2D COMMUNICATION (see above)
	Determines which signal the time levels of the drive are synchronised with. An offset can be defined by parameter 57.10 KERNEL SYNC OFFS if desired.	
	(0) NoSync	No synchronisation.
	(1) D2DSync	If the drive is the master on a drive-to-drive link, it broadcasts a synchronisation signal to the follower(s). If the drive is a follower, it synchronises its firmware time levels to the signal received from the master.
	(2) FBSync	The drive synchronises its firmware time levels to a synchronisation signal received through a fieldbus adapter.
	(3) FBToD2DSync	If the drive is the master on a drive-to-drive link, it synchronises its firmware time levels to a synchronisation signal received from a fieldbus adapter, and broadcasts the signal on the drive-to-drive link. If the drive is a follower, this setting has no effect.
57.10	KERNEL SYNC OFFS	FW block: D2D COMMUNICATION (see above)
	Defines an offset in microseconds between the synchronisation signal received and the time levels of the drive. With a positive value, the drive time levels will lag behind the synchronisation signal; with a negative value, the drive time levels will lead.	
	-4999...5000 us	Synchronisation offset.
57.11	REF 1 MSG TYPE	FW block: D2D COMMUNICATION (see above)
	<p>By default, in drive-to-drive communication, the master broadcasts the drive-to-drive control word and references 1 and 2 to all followers. This parameter enables multicasting, ie, sending the drive-to-drive control word and reference 1 to a certain drive or group of drives. The message can then be further relayed to another group of drives to form a multicast chain.</p> <p>In the master, as well as any submaster (ie, follower relaying the message to other followers), the sources for the control word and reference 1 are selected by parameters 57.08 FOLLOWER CW SRC and 57.06 REF 1 SRC respectively.</p> <p>Note: Reference 2 is broadcast by the master to all followers.</p> <p>For more information, see Appendix B – Drive-to-drive link on page 435.</p>	
	(0) Broadcast	The control word and reference 1 are sent by the master to all followers. If the master has this setting, the parameter has no effect in the followers.
	(1) Ref1 MC Grps	The drive-to-drive control word and reference 1 are only sent to the drives in the multicast group specified by parameter 57.13 NEXT REF1 MC GRP . This setting can also be used in submasters (followers in which parameters 57.03 NODE ADDRESS and 57.12 REF1 MC GROUP are set to the same value) to form a multicast chain.

57.12	REF1 MC GROUP	FW block: D2D COMMUNICATION (see above)
	Selects the multicast group the drive belongs to. See parameter 57.11 REF 1 MSG TYPE .	
	0...62	Multicast group (0 = none).
57.13	NEXT REF1 MC GRP	FW block: D2D COMMUNICATION (see above)
	Specifies the next multicast group of drives the multicast message is relayed to. See parameter 57.11 REF 1 MSG TYPE . This parameter is effective only in the master or in submasters (followers in which parameters 57.03 NODE ADDRESS and 57.12 REF1 MC GROUP are set to the same value).	
	0...62	Next multicast group in message chain.
57.14	NR REF1 MC GRPS	FW block: D2D COMMUNICATION (see above)
	Sets the number of drives sending messages in the message chain. The value is typically equal to the number of multicast groups in the chain assuming that the last drive is NOT sending an acknowledgement to the master. See parameter 57.11 REF 1 MSG TYPE . Notes: • This parameter is only effective in the master.	
	1...62	Total number of links in multicast message chain.
57.15	D2D COMM PORT	FW block: None
	Defines the hardware to which the drive-to-drive link is connected. In special cases (such as harsh operating conditions), the galvanic isolation provided by the RS-485 interface of the FMBA module may make for more robust communication than the standard drive-to-drive connection.	
	(0) on-board	Connector XD2D on the JCU Control Unit is used.
	(1) Slot 1	An FMBA module installed in JCU option slot 1 is used.
	(2) Slot 2	An FMBA module installed in JCU option slot 2 is used.
	(3) Slot 3	An FMBA module installed in JCU option slot 3 is used.

Group 60 POS FEEDBACK

Configuration of drive position feedback including

- feedback source
- load gear ratio
- axis type
- positioning unit
- scalings for fieldbus
- scaling between rotational and translational systems
- resolution of internal position calculation
- position limit and threshold values.



<p>Firmware block: POS FEEDBACK (60)</p> <p>This block</p> <ul style="list-style-type: none"> selects the source for measured actual position value (encoder 1, encoder 2 or estimated position) selects whether positioning is executed along linear or rollover axis configures the load encoder gear function selects the unit and scaling for the position parameters selects the integer scaling of a position value defines how many bits are used for position count within one revolution defines the minimum and maximum position limits defines the position threshold supervision limit shows actual position of the encoder, scaled actual position of encoder 2 and filtered actual speed of the load. 		
<p>Block outputs located in other parameter groups</p>		<p>1.12 POS ACT (page 94) 1.13 POS 2ND ENC (page 94) 4.02 SPEED ACT LOAD (page 105)</p>
60.01	POS ACT SEL	FW block: POS FEEDBACK (see above)
	Selects the source for the actual position value.	
	(0) ENC1	Encoder 1. Inverted gear ratio is considered when the position control output (speed reference) is produced.
	(1) ENC2	Encoder 2. Inverted gear ratio is considered when the position control output (speed reference) is produced.
	(2) Estimated	Estimated position. Inverted gear ratio is considered when the position control output (speed reference) is produced. See also section Position estimation on page 62.
60.02	POS AXIS MODE	FW block: POS FEEDBACK (see above)
	Selects the positioning axis. Note: This parameter cannot be changed while the drive is running.	
	(0) Linear	Linear motion. Positioning is between minimum position 60.14 MINIMUM POS and maximum position 60.13 MAXIMUM POS .
	(1) Rollover	Rotating motion. Positioning is between 0 and 1 revolutions, ie, after 360°, the position calculation starts from 0° again.

60.03	LOAD GEAR MUL	FW block: POS FEEDBACK (see above)
	<p>Defines the numerator for the load encoder gear function. See also section Load encoder gear function on page 63.</p> $\frac{60.03 \text{ LOAD GEAR MUL}}{60.04 \text{ LOAD GEAR DIV}} = \frac{\text{Load speed}}{\text{Encoder 1/2 speed}}$ <p>Note: When load encoder gear function is set, the gear function defined by parameters 71.07 GEAR RATIO MUL and 71.08 GEAR RATIO DIV must also be set. See also sections Motor encoder gear function (page 56) and Load encoder gear function (page 63).</p>	
	$-2^{31} \dots 2^{31} - 1$	Numerator for load encoder gear.
60.04	LOAD GEAR DIV	FW block: POS FEEDBACK (see above)
	Defines the denominator for the load encoder gear function. See parameter 60.03 LOAD GEAR MUL .	
	$1 \dots 2^{31} - 1$	Denominator for load encoder gear.
60.05	POS UNIT	FW block: POS FEEDBACK (see above)
	<p>Selects the unit and scaling for the position parameters. The scaling factor is equal to one revolution. For positioning speed, acceleration and deceleration units, see parameter 60.10 POS SPEED UNIT. Note: If translatory (m, inch) unit is selected, the range also depends on parameter 60.06 FEED CONST NUM and 60.07 FEED CONST DEN settings.</p>	
	(0) Revolution	Unit: revolution. Scaling factor: 1.
	(1) Degree	Unit: degree. Scaling factor: 360.
	(2) Meter	Unit: metre. Scaling factor: according to parameters 60.06 FEED CONST NUM and 60.07 FEED CONST DEN .
	(3) Inch	Unit: inch. Scaling factor: according to parameters 60.06 FEED CONST NUM and 60.07 FEED CONST DEN .
	(3) Millimetre	Unit: millimetre. Scaling factor: according to parameters 60.06 FEED CONST NUM and 60.07 FEED CONST DEN .
60.06	FEED CONST NUM	FW block: POS FEEDBACK (see above)
	<p>Defines, together with parameter 60.07 FEED CONST DEN, the feed constant for the position calculation:</p> $\frac{60.06 \text{ FEED CONST NUM}}{60.07 \text{ FEED CONST DEN}}$ <p>The feed constant converts rotational motion into translatory motion. The feed constant is the distance the load moves during one turn of the motor shaft ($2\pi r$), when linear positioning has been selected with 60.05 POS UNIT (ie, parameter is set to (2) Meter or (3) Inch). Note: Parameters 60.05 POS UNIT, 60.06 FEED CONST NUM and 60.07 FEED CONST DEN also affect the positioning parameters. If the feed constant is changed, positioning references are re-calculated and the limits are changed. However, the internal motor shaft references remain unchanged.</p>	
	$1 \dots 2^{31} - 1$	Feed constant numerator.

60.07	FEED CONST DEN	FW block: POS FEEDBACK (see above)
	Defines, together with parameter 60.06 FEED CONST NUM , the feed constant for the position calculation.	
	1... $2^{31} - 1$	Feed constant denominator.
60.08	POS2INT SCALE	FW block: POS FEEDBACK (see above)
	Scales position values to integer values. Integer values are used in the control program and fieldbus communication. For positioning speed, acceleration and deceleration value scaling, see parameter 60.11 POS SPEED2INT . Example: If parameter value is set to 100 and 60.05 POS UNIT is set to (2) Meter, integer value of 3000 corresponds to position value of 30 m.	
	1/10/100/1000/10000/ 100000/1000000	Scaling factor.
60.09	POS RESOLUTION	FW block: POS FEEDBACK (see above)
	Defines how many bits are used for the position count within one revolution. Example: If parameter is set to a value of 24, 8 bits (32 - 24) are used for the whole revolution count and 24 bits are used for the fractional revolution count. Note: If you change the value of this parameter, all the position reference value parameters must be given anew, and the homing or preset must be redone as well. Note: This parameter cannot be changed while the drive is running.	
	10/12/14/16/18/20/22/24 bits	Number of bits used for position count.
60.10	POS SPEED UNIT	FW block: POS FEEDBACK (see above)
	Selects, together with parameter 60.05 POS UNIT (position unit), the unit for positioning speed, acceleration and deceleration values.	
	(0) u/s	Position unit/s (s = second). With acceleration/deceleration values: position unit/s ² .
	(1) u/min	Position unit/min (min = minute). With acceleration/deceleration values: position unit/min ² .
	(2) u/h	Position unit/h (h = hour). With acceleration/deceleration values: position unit/h ² .
60.11	POS SPEED2INT	FW block: POS FEEDBACK (see above)
	Scales all positioning speed, acceleration and deceleration values to an integer value. Integer values are used in the control program and fieldbus communication. Example: If parameter value is set to 10, an integer value of 10 corresponds to positioning speed value 1 rev/s.	
	1/10/100/1000/10000/ 100000/1000000	Scaling factor.

60.12	POS SPEED SCALE	FW block: POS FEEDBACK (see above)
	<p>Defines an additional scaling for internal positioning speed, acceleration and deceleration values. Can be used, eg, to improve calculation accuracy at low and high speeds.</p> <p>Example: If parameter value is set to 0.1, internal speed value 1 rev/s is changed to value 10 rev/s.</p>	
	0...32768	Additional scaling factor.
60.13	MAXIMUM POS	FW block: POS FEEDBACK (see above)
	<p>Defines the maximum position value. If the actual position value exceeds the maximum position limit, fault message POSERR MAX is generated.</p> <p>The unit depends on parameter 60.05 POS UNIT selection.</p> <p>Note: If parameters 60.13 and 60.14 are set to 0, position limit supervision is disabled.</p>	
	0...32768	Maximum position value.
60.14	MINIMUM POS	FW block: POS FEEDBACK (see above)
	<p>Defines the minimum position value. If the actual position value falls below the minimum position limit, fault message POSERR MIN is generated.</p> <p>The unit depends on parameter 60.05 POS UNIT selection.</p> <p>Note: If parameters 60.13 and 60.14 are set to 0, position limit supervision is disabled.</p>	
	-32768...0	Minimum position value.
60.15	POS THRESHOLD	FW block: POS FEEDBACK (see above)
	<p>Defines the position threshold supervision limit. If actual position 1.12 POS ACT exceeds the defined limit, 6.09 POS CTRL STATUS bit 10 ABOVE THRES is activated.</p> <p>The unit depends on parameter 60.05 POS UNIT selection.</p>	
	-32768...32768	Position threshold supervision limit.

Group 62 POS CORRECTION

Settings for position correction functions (homing, presets, and cyclic corrections). With these functions, the user can define the relationship between the actual position of the drive positioning system and the driven machinery.

Some of the correction functions need an external probe or limit switch to be connected to the digital inputs of the drive control board or encoder interface module.

See also section [Position correction](#) on page 70.

Note: Only one position correction function can be active at a time. Homing has the highest priority, cyclic correction the lowest.

<p>Firmware block: HOMING (62)</p> <p>This block</p> <ul style="list-style-type: none"> • selects homing method (1...35) • selects the homing start function (NORMAL/PULSE) and the source for the homing start command • selects the source for the home switch signal • selects the sources for the negative and positive limit switch signals • defines two homing speed reference values • defines the home position • shows measured position and calculated cyclic position error for the cyclic correction function (see the block CYCLIC CORRECTION on page 229). 	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: right;">HOMING 37</p> <p>MISC_3 2 msec (6)</p> <p style="text-align: right;">4.03 PROBE1 POS MEAS —</p> <p style="text-align: right;">4.04 PROBE2 POS MEAS —</p> <p style="text-align: right;">4.05 CYCLIC POS ERR —</p> <p>(Drive value) 62.01 HOMING METHOD</p> <p>(Drive value) 62.02 HOMING STARTFUNC</p> <p>(Drive value) < 62.03 HOMING START</p> <p>(Drive value) 62.04 HOME SWITCH TRIG</p> <p>(Drive value) < 62.05 NEG LIMIT SWITCH</p> <p>(Drive value) < 62.06 POS LIMIT SWITCH</p> <p>(Drive value) 62.07 HOMING SPEEDREF1</p> <p>(Drive value) 62.08 HOMING SPEEDREF2</p> <p>(Drive value) 62.09 HOME POSITION</p> <p>(Drive value) 62.10 HOME POS OFFSET</p> <p>(Drive value) 62.20 POS ACT OFFSET</p> <p>(Drive value) 62.21 POS COR MODE</p> <p>(Drive value) < 62.22 TRIG PROBE1 SW</p> <p>(Drive value) < 62.23 TRIG PROBE2 SW</p> <p>(Drive value) 62.25 Z-PULSE SOURCE 1</p> <p>(Drive value) 62.26 Z-PULSE SOURCE 2</p> <p>(Drive value) 62.27 HOMING ACC</p> <p>(Drive value) 62.28 HOMING DEC</p> <p>(Drive value) 62.30 PROBE TRIG FILT</p> </div>
<p>Block outputs located in other parameter groups</p>	<p>4.03 PROBE1 POS MEAS (page 105)</p> <p>4.04 PROBE2 POS MEAS (page 105)</p> <p>4.05 CYCLIC POS ERR (page 105)</p>

62.01	HOMING METHOD	FW block: HOMING (see above)
	<p>Selects the homing method.</p> <p>Note: For cyclic corrections to work, this parameter must be set to (0) No Method.</p> <p>For more information, see</p> <ul style="list-style-type: none"> • section Homing on page 70 • Appendix C – Homing methods on page 447 • <i>CiA Standard Proposal 402: CANopen Device Profile Drives and Motion Control</i>. 	
	(0) No Method	None.
	(1) CAN Method 1 ... (35) CAN Method35	Homing method 1...35.
62.02	HOMING STARTFUNC	FW block: HOMING (see above)
	Selects the homing start function.	
	(0) Normal	Rising edge of a signal from the source defined by 62.03 HOMING START activates the homing. The input signal has to stay TRUE during the homing task.
	(1) Pulse	Rising edge of a pulse from the source defined by 62.03 HOMING START activates the homing.
62.03	HOMING START	FW block: HOMING (see above)
	Selects the source of the start command used in homing. 0 -> 1: Start. The start function is defined by parameter 62.02 HOMING STARTFUNC .	
	Bit pointer: Group, index and bit.	
62.04	HOME SWITCH TRIG	FW block: HOMING (see above)
	Selects the source for the home switch signal.	
	(0) ENC1_DI1	Encoder 1 digital input DI1.
	(1) ENC1_DI2	Encoder 1 digital input DI2.
	(2) ENC2_DI1	Encoder 2 digital input DI1.
	(3) ENC2_DI2	Encoder 2 digital input DI2.
	(4) PROBE1 SW	Trigger probe 1 signal selected by parameter 62.22 TRIG PROBE1 SW . Used with homing methods 19...30.
62.05	NEG LIMIT SWITCH	FW block: HOMING (see above)
	Selects the source for the negative limit switch signal (ie, external latch signal source for the minimum position). Used to prevent movement beyond a certain minimum position (drive stopped along emergency stop ramp), and with homing methods 1, 11...14, 17 and 27...30. Homing method is selected by parameter 62.01 HOMING METHOD .	
	Bit pointer: Group, index and bit.	

62.06	POS LIMIT SWITCH	FW block: HOMING (see above)
	Selects the source for the positive limit switch signal (ie, external latch signal source for the maximum position). Used to prevent movement beyond a certain maximum position (drive stopped along emergency stop ramp), and with homing methods 2, 7...10, 18 and 23...26. Homing method is selected by parameter 62.01 HOMING METHOD .	
	Bit pointer: Group, index and bit.	
62.07	HOMING SPEEDREF1	FW block: HOMING (see above)
	Defines homing speed reference 1, ie, the speed reference used when the homing is started (62.03 HOMING START). The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Homing speed reference 1.
62.08	HOMING SPEEDREF2	FW block: HOMING (see above)
	Defines homing speed reference 2. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Homing speed reference 2.
62.09	HOME POSITION	FW block: HOMING (see above)
	Defines the home position, which is set as the drive actual position after the home switch latch conditions have been fulfilled. The unit depends on parameter 60.05 POS UNIT selection.	
	-32768...32768	Home position.
62.10	HOME POS OFFSET	FW block: HOMING (see above)
	Defines a home position offset value. After reaching the home switch and latching the defined home position as actual position, the drive will rotate the number of runs specified by this parameter. Positioning is executed according to the active positioning table parameters in group 65 . In practice, the offset is required when the home switch cannot be placed at the physical home position. For example, if this parameter is set to a value of 50 and the home position to 0, the motor will run 50 revolutions in the forward direction after receiving a signal from the home switch. Negative values will make the motor run in the reverse direction.	
	-32768...32768	Home position offset.

<p>Firmware block:</p> <p>PRESET (63)</p> <p>This block</p> <ul style="list-style-type: none"> selects the preset mode and source for the preset mode start signal defines the preset position. 	<p>The diagram shows a box labeled 'PRESET' with a value of 38 and a note '(7)'. It is connected to three parameters: '62.11 PRESET MODE' (with a 'Disabled' label), '62.12 PRESET TRIG' (with a 'Homing start' label), and '62.13 PRESET POSITION' (with a '0.000 rev.' label). A 'TLF10 2 msec' label is also present near the top of the box.</p>
--	--

62.11	PRESET MODE	FW block: PRESET (see above)
	<p>Selects the preset mode.</p> <p>Presets are used to set the position system to a parameter value (preset position) or actual position. The physical position of the driven machinery is not changed, but the new position value is used as home position.</p> <p>Note: Selections 1...3 can also be activated by the homing start command (source selected by parameter 62.03 HOMING START).</p>	
	(0) Disabled	Preset mode not in use.
	(1) Synch Ref	Synchron reference chain (parameter group 68) is set to the value of the preset position (62.13 PRESET POSITION).
	(2) Act to Synch	Synchron reference chain (parameter group 68) is set to the value of the actual position (1.12 POS ACT).
	(3) Whole system	Position system (parameter groups 60 , 66 , 68 , 70 and 71) is set to the value of the preset position (62.13 PRESET POSITION).
62.12	PRESET TRIG	FW block: PRESET (see above)
	Selects the source for the preset mode start signal.	
	(0) Homing start	The homing start signal (selected by parameter 62.03 HOMING START) also activates the selected preset mode.
	(1) ENC1 DI1 _-	Rising edge of encoder 1 digital input DI1.
	(2) ENC1 DI1 -_	Falling edge of encoder 1 digital input DI1.
	(3) ENC1 DI2 _-	Rising edge of encoder 1 digital input DI2.
	(4) ENC1 DI2 -_	Falling edge of encoder 1 digital input DI2.
	(5)	Reserved.
	(6) ENC1 Zerop	Rising edge of encoder 1 zero pulse.
	(7) ENC2 DI1 _-	Rising edge of encoder 2 digital input DI1.
	(8) ENC2 DI1 -_	Falling edge of encoder 2 digital input DI1.
	(9) ENC2 DI2 _-	Rising edge of encoder 2 digital input DI2.
	(10) ENC2 DI2 -_	Falling edge of encoder 2 digital input DI2.
	(11)	Reserved.
	(12) ENC2 Zerop	Rising edge of encoder 2 zero pulse.
	(13) PROBE1 SW	Trigger probe 1 signal (selected by parameter 62.22 TRIG PROBE1 SW) also activates the selected preset mode.
	(14) PROBE2 SW	Trigger probe 2 signal (selected by parameter 62.23 TRIG PROBE2 SW) also activates the selected preset mode.

62.13	PRESET POSITION	FW block: PRESET (see above)
	Defines the preset position. The unit depends on parameter 60.05 POS UNIT selection.	
	-32768...32768	Preset position.

<p>Firmware block:</p> <p>CYCLIC CORRECTION (64)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the cyclic correction mode • defines the source for the latching command for position probe 1/2 • defines the reference position for probe 1/2 • defines the maximum absolute value for cyclic correction. <p>When the probe latching conditions are fulfilled, the encoder module saves the encoder position (to signal 4.03 PROBE1 POS MEAS or 4.04 PROBE2 POS MEAS).</p>	
--	--


62.14	CYCLIC CORR MODE	FW block: CYCLIC CORRECTION (see above)	
	Selects the cyclic correction mode.		
	(0) Disabled	No cyclic correction.	
	(1) Cor Act Pos	Actual position correction.	
	(2) Cor Mas Ref	Master reference correction.	
	(3) 1 Probe Dist	Distance correction with one probe.	
	(4) 2 Probe Dist	Distance correction with two probes.	
	(5) Cor M/F Dist	Master/Follower distance correction.	
62.15	TRIG PROBE1	FW block: CYCLIC CORRECTION (see above)	
	Defines the position data source and triggering command used for probe 1 latching. When the triggering condition is fulfilled, the position received from the selected data source is set as probe 1 position. In case the triggering condition is dependent on the zero pulse, the probe is latched upon the rising edge of the zero pulse. The source of the zero pulse is defined by parameter 62.25 Z-PULSE SOURCE 1 .		
	Selection	Position data source	Triggering command
	(0) Homing start	–	–
	(1) ENC1 DI1 _–	Encoder 1 position	Rising edge of digital input DI1
	(2) ENC1 DI1 –_	Encoder 1 position	Falling edge of DI1

	(3) ENC1 DI2 _-	Encoder 1 position	Rising edge of DI2
	(4) ENC1 DI2 -_	Encoder 1 position	Falling edge of DI2
	(5)	Reserved.	
	(6) ENC1 Zerop	Encoder 1 position	Zero pulse
	(7) ENC1 DI1_- z	Encoder 1 position	First zero pulse after rising edge of DI1
	(8) ENC1 DI1-_ z	Encoder 1 position	First zero pulse after falling edge of DI1
	(9) ENC1 DI1=1 z	Encoder 1 position	First zero pulse when DI1 = 1
	(10) ENC1 DI1=0 z	Encoder 1 position	First zero pulse when DI1 = 0
	(11) ENC1 DI2_- z	Encoder 1 position	First zero pulse after rising edge of DI2
	(12) ENC1 DI2-_ z	Encoder 1 position	First zero pulse after falling edge of DI2
	(13) ENC1 DI2=1 z	Encoder 1 position	First rising edge of zero pulse when DI2 = 1
	(14) ENC1 DI2=0 z	Encoder 1 position	First rising edge of zero pulse when DI2 = 0
	(15) ENC2 DI1 _-	Encoder 2 position	Rising edge of DI1
	(16) ENC2 DI1 -_	Encoder 2 position	Falling edge of DI1
	(17) ENC2 DI2 _-	Encoder 2 position	Rising edge of DI2
	(18) ENC2 DI2 -_	Encoder 2 position	Falling edge of DI2
	(19)	Reserved.	
	(20) ENC2 Zerop	Encoder 2 position	Zero pulse
	(21) ENC2 DI1_- z	Encoder 2 position	First zero pulse after rising edge DI1
	(22) ENC2 DI1-_ z	Encoder 2 position	First zero pulse after falling edge of DI1
	(23) ENC2 DI1=1 z	Encoder 2 position	First zero pulse when DI1 = 1
	(24) ENC2 DI1=0 z	Encoder 2 position	First zero pulse when DI1 = 0
	(25) ENC2 DI2_- z	Encoder 2 position	First zero pulse after rising edge of DI2
	(26) ENC2 DI2-_ z	Encoder 2 position	First zero pulse after falling edge of DI2
	(27) ENC2 DI2=1 z	Encoder 2 position	First zero pulse when DI2 = 1

	(28) ENC2 DI2=0 z	Encoder 2 position	First zero pulse when DI2 = 0
	(29) PROBE1 SW	Encoder 1 position	The trigger signal is selected by parameter 62.22 TRIG PROBE1 SW .
	(30) PROBE2 SW	Encoder 1 position	The trigger signal is selected by parameter 62.23 TRIG PROBE2 SW .
62.16	PROBE1 POS	FW block: CYCLIC CORRECTION (see above)	
	Defines the reference position for position probe 1. The unit depends on parameter 60.05 POS UNIT selection.		
	-32768...32768	Reference position for position probe 1.	
62.17	TRIG PROBE2	FW block: CYCLIC CORRECTION (see above)	
	Defines the position data source and triggering condition used for probe 2 latching. When the triggering condition is fulfilled, the position received from the selected data source is set as probe 2 position. In case the triggering condition is dependent on the zero pulse, the probe is latched upon the rising edge of the zero pulse. The source of the zero pulse is defined by parameter 62.26 Z-PULSE SOURCE 2 . For selections, see parameter 62.15 TRIG PROBE1 .		
62.18	PROBE2 POS	FW block: CYCLIC CORRECTION (see above)	
	Defines the reference position for position probe 2. The unit depends on parameter 60.05 POS UNIT selection.		
	-32768...32768	Reference position for position probe 2.	
62.19	MAX CORRECTION	FW block: CYCLIC CORRECTION (see above)	
	Defines the maximum absolute value for cyclic correction. Example: If maximum value is set to 50 revolutions and the requested cyclic correction is 60 revolutions, no correction is made. The unit depends on parameter 60.05 POS UNIT selection.		
	0...32768	Maximum absolute value for cyclic correction.	
62.20	POS ACT OFFSET	FW block: HOMING (see above)	
	Offsets all the position values used by the position system, effectively correcting the position and revolution count signal received from the encoder. For example, this parameter can be used if a non-zero position signal received from the encoder needs to be defined as the zero position for the application. For example, if this parameter is set to a value of -100, the absolute position of 100 revolutions as measured by the encoder is interpreted as the zero position. Notes: <ul style="list-style-type: none"> The offset takes effect upon the next power-up or when an encoder reconfiguration command is given using parameter 90.10 ENC PAR REFRESH. The offset will not be visible through any actual signal or other parameter. 		
	-32768...32768	Offset for actual position value.	

62.21	POS COR MODE	FW block: HOMING (see above)
	Determines if the position change made in homing or in preset mode 2 or 3 is forced permanently into the drive memory by saving it to parameter 62.20 POS ACT OFFSET , or only until the next power-down.	
	(0) Normal	The position change made in homing or in preset mode 2 or 3 is effective only until the next power-down.
	(1) Permanent	The position change made in homing or in preset mode 2 or 3 remains permanently effective.
62.22	TRIG PROBE1 SW	FW block: HOMING (see above)
	Selects the source of the trigger probe 1 signal. The selection is active when parameter 62.15 TRIG PROBE1 or 62.17 TRIG PROBE2 is set to (29) PROBE1 SW . Example: P.2.1.4 (P. DI STATUS.4) selects digital input DI5 of the drive control board as the trigger probe 1 signal.	
	Bit pointer: Group, index and bit.	
62.23	TRIG PROBE2 SW	FW block: HOMING (see above)
	Selects the source of the trigger probe 2 signal. The selection is active when parameter 62.15 TRIG PROBE1 or 62.17 TRIG PROBE2 is set to (30) PROBE2 SW .	
	Bit pointer: Group, index and bit.	
62.25	Z-PULSE SOURCE 1	FW block: HOMING (see above)
	Selects which zero pulse is used for probe 1 latching when a zero pulse dependent triggering condition is selected by parameter 62.15 TRIG PROBE1 .	
	(0) ProbePosSrc	The source of the zero pulse is the same as the source of the position data (see parameter 62.15 TRIG PROBE1).
	(1) Encoder 1	Zero pulse from encoder 1 used. Note: If the position data and zero pulse sources are not the same (ie, the position data is received from encoder 2, and parameters 90.01 ENCODER 1 SEL and 90.02 ENCODER 2 SEL are set to different values), encoders 1 and 2 must be connected to the same FEN-xx extension anyway. In addition, the logic version of the FEN-xx must be VIEx1500 or later.
	(2) Encoder 2	Zero pulse from encoder 2 used. Note: If the position data and zero pulse sources are not the same (ie, the position data is received from encoder 1, and parameters 90.01 ENCODER 1 SEL and 90.02 ENCODER 2 SEL are set to different values), encoders 1 and 2 must be connected to the same FEN-xx extension anyway. In addition, the logic version of the FEN-xx must be VIEx1500 or later.
	(3) Emulated Zp	Emulated zero pulse used. Notes: <ul style="list-style-type: none"> The logic version of the FEN-xx must be VIEx1500 or later. Encoder emulation must be properly activated by parameters 90.03 EMUL MODE SEL and 93.21 EMUL PULSE NR. See also parameter 93.23 EMUL POS OFFSET.

62.26	Z-PULSE SOURCE 2	FW block: HOMING (see above)
	Selects which zero pulse is used for probe 2 latching when a zero pulse dependent triggering condition is selected by parameter 62.17 TRIG PROBE2 .	
	(0) ProbePosSrc	The source of the zero pulse is the same as the source of the position data (see parameter 62.17 TRIG PROBE2).
	(1) Encoder 1	Zero pulse from encoder 1 used. Note: If the position data and zero pulse sources are not the same (ie, the position data is received from encoder 2, and parameters 90.01 ENCODER 1 SEL and 90.02 ENCODER 2 SEL are set to different values), encoders 1 and 2 must be connected to the same FEN-xx extension anyway. In addition, the logic version of the FEN-xx must be VIEx1500 or later.
	(2) Encoder 2	Zero pulse from encoder 2 used. Note: If the position data and zero pulse sources are not the same (ie, the position data is received from encoder 1, and parameters 90.01 ENCODER 1 SEL and 90.02 ENCODER 2 SEL are set to different values), encoders 1 and 2 must be connected to the same FEN-xx extension anyway. In addition, the logic version of the FEN-xx must be VIEx1500 or later.
	(3) Emulated Zp	Emulated zero pulse used. Notes: <ul style="list-style-type: none"> • The logic version of the FEN-xx must be VIEx1500 or later. • Encoder emulation must be properly activated by parameters 90.03 EMUL MODE SEL and 93.21 EMUL PULSE NR. See also parameter 93.23 EMUL POS OFFSET.
62.27	HOMING ACC	FW block: HOMING (see above)
	Defines the homing acceleration when homing is active. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Homing acceleration.
62.28	HOMING DEC	FW block: HOMING (see above)
	Defines the homing deceleration when homing is active. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...0	Homing deceleration.

62.30	PROBE TRIG FILT	FW block: HOMING (see above)
<p>To avoid false latch events due to signal disturbances, latching is verified on the basis of a low-pass filtered signal. The signal is filtered using the time constant (τ) defined by this parameter. In effect, the value of this parameter determines how long the probe signal must stay in its new state to be accepted as a latching.</p> <p>After the state of the selected latch input changes, the state of the filtered signal is checked at 2τ to verify the change. If the signal has remained in its new state, the latching is accepted and new latching events prevented until the drive has read the latched position from the FEN-xx adapter. If the signal has not remained in its new state, the latching is discarded and a new one allowed immediately.</p> <p>The diagram below illustrates an ideal probe signal and a filtered signal. In this instance, the rising edge of the digital input is used as the triggering command.</p> 		
	(0) 125 us	125 μ s.
	(1) 250 us	250 μ s.
	(2) 500 us	500 μ s.
	(3) 1000 us	1000 μ s.
62.31	CYCLIC COR STYLE	FW block: None
Sets the cyclic correction style.		
	(0) Once	Selection Once requires that the previous correction is done before the next measurement for the correction is allowed.
	(1) Continuous	Selection Continuous allows a new correction even though the previous correction is not ready


62.32	MAX COR MODE	FW block: None
	Sets the maximum position correction.	
	(0) Mode 1	If the required cyclic correction is larger than the value defined by parameter 62.19 MAX CORRECTION , no correction is made.
	(1) Mode 2	Cyclic correction is limited to the value defined by parameter 62.19 MAX CORRECTION .
	(2) Mode 3	Only the first cyclic correction can be larger than the value defined by parameter 62.19 MAX CORRECTION . Later corrections are limited to the value of this parameter.

Group 65 PROFILE REFERENCE

Positioning profile and start command settings. The shape of the profile are defined by position reference, speed, acceleration, deceleration, filtering time, style, and end speed.

The position reference can be taken from an analogue input, fieldbus, drive-to-drive link or the position reference table. The positioning speed is taken from fieldbus or the reference table. The remaining values are taken from the reference table.

See also sections [Position reference sets](#) on page 68 and [Profile velocity control](#) on page 41.



<p>Firmware block: PROFILE REF SEL (65)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for position reference • selects the source for position reference set 1/2 selection • defines the position reference sets 1 and 2 • selects the source for an additional position reference • selects the source for speed reference in profile velocity mode • selects the positioning start function • shows the used positioning values: reference, speed, acceleration, deceleration, filter time, positioning behaviour and end speed. 		
<p>Block outputs located in other parameter groups</p>	<p>4.06 POS REF (page 105) 4.07 PROF SPEED (page 105) 4.08 PROF ACC (page 105) 4.09 PROF DEC (page 105) 4.10 PROF FILT TIME (page 105) 4.11 POS STYLE (page 105) 4.12 POS END SPEED (page 106)</p>	
<p>65.01</p>	<p>POS REFSOURCE</p>	<p>FW block: PROFILE REF SEL (see above)</p>
	<p>Selects the source for the used positioning values.</p>	
	<p>(0) Ref table</p>	<p>Reference and other positioning parameters are read from reference set 1/2 which is defined by parameters 65.03...65.10 / 65.11...65.18.</p>
	<p>(1) Block</p>	<p>Reserved.</p>
	<p>(2) Fieldbus</p>	<p>Position reference (FBA REF1) and positioning speed (FBA REF2) are read from the fieldbus. Other positioning values are read from reference set 1 which is defined by parameters 65.03...65.10. Refer to the figure on page 236.</p>

65.02	PROF SET SEL	FW block: PROFILE REF SEL (see above)
	Selects the source for position reference set 1 or 2 selection. 0 = position reference set 1, 1 = position reference set 2. See parameters 65.04 POS REF 1 SEL and 65.12 POS REF 2 SEL .	
	Bit pointer: Group, index and bit.	
65.03	POS START 1	FW block: PROFILE REF SEL (see above)
	Selects the source for the positioning start command when position reference set 1 used.	
	Bit pointer: Group, index and bit.	
65.04	POS REF 1 SEL	FW block: PROFILE REF SEL (see above)
	Selects the source for the positioning reference when position reference set 1 is used.	
	(0) ZERO	Zero position reference.
	(1) AI1	Analogue input 1.
	(2) AI2	Analogue input 2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive-to-drive reference 1.
	(6) D2D REF2	Drive-to-drive reference 2.
	(7) POS REF1	Position reference 1 defined by parameter 65.19 POS REF 1 .
	(8) POS REF2	Position reference 2 defined by parameter 65.20 POS REF 2 .
65.05	POS SPEED 1	FW block: PROFILE REF SEL (see above)
	Defines the positioning speed when position reference set 1 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Positioning speed for position reference set 1.
65.06	PROF ACC 1	FW block: PROFILE REF SEL (see above)
	Defines the positioning acceleration when position reference set 1 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Positioning acceleration for position reference set 1.
65.07	PROF DEC 1	FW block: PROFILE REF SEL (see above)
	Defines the positioning deceleration when position reference set 1 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...0	Positioning deceleration for position reference set 1.
65.08	PROF FILT TIME 1	FW block: PROFILE REF SEL (see above)
	Defines the position reference filter time when position reference set 1 is used.	

	0...1000 ms	Position reference filter time for position reference set 1.
65.09	POS STYLE 1	FW block: PROFILE REF SEL (see above)
	<p>Determines the behaviour of the position profile generator when position reference set 1 is used. The figures below display the behaviour of each bit (different bit combinations are also possible).</p> <p>Bits 0...2 determine in which way the drive moves to an additional position reference or corrects the synchronisation error (caused by position reference limitation or cyclic correction) in synchron control mode. Only one of these bits can be active at a time.</p> <p>The positioning priority order is: 1) bit 2 or according to the linear axis positioning selected by par. 60.02 POS AXIS MODE. 2) bit 0 3) bit 1.</p> <p>Conversion from binary to hexadecimal format examples:</p> <p>bit number 4 0 binary value 0001 0000 decimal value $2^4 = 32$ hex value 10h</p> <p>bit number 5 2 binary value 0010 0100 decimal value $2^5 + 2^2 = 32 + 4 = 36$ hex value 20 + 4 = 24h</p> <p>Bits 3...6 determine the path to the target position. Bit 7 provides one revolution positioning in the roll-over mode.</p>	
	0b0000000...0b1111111	Positioning style for position reference set 1.
Bit 0	1 = Positioning direction depends on the direction of the synchronous (master) speed. 0 = Positioning direction is independent of the synchronous (master) speed.	
Bit 1	<p>1 = Counter-clockwise ↺ positioning to the target position (bit 0 = 0).</p> <p>65.03 POS START 1</p> <p>4.01 SPEED REF POS</p> <p>4.13 POS REF IPO</p> <p>position ref. 180°</p> <p>or positioning in the opposite direction to the synchronous (master) speed when bit 0 = 1.</p> <p>0 = Clockwise positioning ↻ to the target position (bit 0 = 0).</p> <p>65.03 POS START 1</p> <p>4.01 SPEED REF POS</p> <p>4.13 POS REF IPO</p> <p>Position ref. 180°</p> <p>or positioning in the direction of the synchronous (master) speed when bit 0 = 1.</p>	

<p>Bit 2</p>	<p>1 = Positioning to the target position along the shortest path, regardless of bit 0 and 1 values.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>A</p> <p>Actual pos. 90° Pos. reference 180°</p> </div> <div style="text-align: center;"> <p>B</p> <p>Actual pos. 90° Pos. reference 300°</p> </div> </div> <p>A = Shortest path from 90° -> 180°: 90° + 90° = 180° (forward) B = Shortest path from 90° -> 300°: 90° - 150° = 300° (reverse)</p> <p>0 = Positioning to the target position according to bits 0 and 1.</p>
<p>Bit 3</p>	<p>1 = Before the positioning is started, the position system is reset.</p> <div style="text-align: center;"> </div> <p>0 = The position system is not reset.</p>
<p>Bit 4</p>	<p>1 = Selected target position is absolute. (Always the same position reference).</p> <div style="text-align: center;"> </div> <p>0 = Selected target position is relative as defined by bit 6.</p> <div style="text-align: center;"> </div>
<p>Bit 5</p>	<p>1 = Before the positioning is started, the position system is returned to the rollover axis range, ie, between 0...1 revolutions.</p> <div style="text-align: center;"> </div> <p>0 = The position system is not returned into the rollover axis range.</p>
<p>Bit 6</p>	<p>Effective only when bit 4 = 0.</p> <p>1 = Selected target position is relative to the actual position.</p> <p>0 = Selected target position is relative to the previous target position.</p>

Bit 7	Effective only when bit 4 = 1 and bit 2 = 0. 1 = When positioning is started by the rising edge of 65.03 POS START 1 , the motor rotates one revolution exactly according to bits 0 and 1. This feature is provided in the roll-over mode only. 0 = One revolution positioning is disabled.	
65.10	POS END SPEED 1	FW block: PROFILE REF SEL (see above)
	Defines the positioning speed when target is reached when position reference set 1 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...32768	Positioning speed when target is reached for position reference set 1.
65.11	POS START 2	FW block: PROFILE REF SEL (see above)
	Selects the source for the positioning start command when position reference set 2 is used.	
	Bit pointer: Group, index and bit.	
65.12	POS REF 2 SEL	FW block: PROFILE REF SEL (see above)
	Selects the source for the positioning reference when position reference set 2 is used. See 65.04 POS REF 1 SEL .	
65.13	POS SPEED 2	FW block: PROFILE REF SEL (see above)
	Defines the positioning speed when position reference set 2 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Positioning speed for position reference set 2.
65.14	PROF ACC 2	FW block: PROFILE REF SEL (see above)
	Defines the positioning acceleration when position reference set 2 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Positioning acceleration for position reference set 2.
65.15	PROF DEC 2	FW block: PROFILE REF SEL (see above)
	Defines the positioning deceleration when position reference set 2 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...0	Positioning deceleration for position reference set 2.
65.16	PROF FILT TIME 2	FW block: PROFILE REF SEL (see above)
	Defines the position reference filter time when position reference set 2 is used.	
	0...1000 ms	Position reference filter time for position reference set 2.
65.17	POS STYLE 2	FW block: PROFILE REF SEL (see above)
	Determines the behaviour of the position profile generator when position reference set 2 is used. See parameter 65.09 POS STYLE 1 .	
	0b0000000...0b1111111	Positioning style for position reference set 2.


65.18	POS END SPEED 2	FW block: PROFILE REF SEL (see above)
	Defines the positioning speed when target is reached when position reference set 1 is used. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...32768	Positioning speed when target is reached for position reference set 2.
65.19	POS REF 1	FW block: PROFILE REF SEL (see above)
	Defines positioning reference 1. Used when parameter 65.04 POS REF 1 SEL / 65.12 POS REF 2 SEL / 65.21 POS REF ADD SEL is set to (7) POS REF1 . The unit depends on parameter 60.05 POS UNIT selection.	
	-32760...32760	Positioning reference 1.
65.20	POS REF 2	FW block: PROFILE REF SEL (see above)
	Defines positioning reference 2. Used when parameter 65.04 POS REF 1 SEL / 65.12 POS REF 2 SEL / 65.21 POS REF ADD SEL is set to (8) POS REF2 . The unit depends on parameter 60.05 POS UNIT selection.	
	-32760...32760	Positioning reference 2.
65.21	POS REF ADD SEL	FW block: PROFILE REF SEL (see above)
	Selects the source for an additional position reference. The value is added to position reference 1 or 2 (source selected by 65.04 POS REF 1 SEL or 65.12 POS REF 2 SEL) immediately (position start is not needed).	
	(0) ZERO	Zero additional position reference.
	(1) AI1	Analogue input 1.
	(2) AI2	Analogue input 2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive-to-drive reference 1.
	(6) D2D REF2	Drive-to-drive reference 2.
	(7) POS REF1	Position reference 1 defined by parameter 65.19 POS REF 1 .
	(8) POS REF2	Position reference 2 defined by parameter 65.20 POS REF 2 .

65.22	PROF VEL REF SEL	FW block: PROFILE REF SEL (see above)
	Selects the source for the speed reference in profile velocity mode. The profile velocity mode is activated by parameter 34.03 , 34.04 or 34.05 , depending on the control location used.	
	(0) ZERO	Zero reference.
	(1) AI1	Analogue input 1.
	(2) AI2	Analogue input 2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive-to-drive reference 1.
	(6) D2D REF2	Drive-to-drive reference 2.
	(7) POS VEL REF	Profile velocity reference 1 defined by parameter 65.23 PROF VEL REF1 .
65.23	PROF VEL REF1	FW block: PROFILE REF SEL (see above)
	Defines profile velocity reference 1. Used when parameter 65.22 PROF VEL REF SEL is set to (7) POS VEL REF . The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...32768	Profile velocity reference 1.
65.24	POS START MODE	FW block: PROFILE REF SEL (see above)
	Selects the positioning start function. Note that positioning cannot be started if the drive has not been already started.	
	(0) NORMAL	When the drive has already been started, rising edge of a signal from the source defined by parameter 65.03 POS START 1 / 65.11 POS START 2 activates the positioning. The input signal has to stay TRUE during the homing task.
	(1) PULSE	When the drive has already been started, rising edge of a pulse from the source defined by parameter 65.03 POS START 1 / 65.11 POS START 2 activates the positioning.

Group 66 PROFILE GENERATOR

Position profile generator settings. With these settings, the user can change the positioning speed during positioning, define positioning speed limits (for example, because of limited power), and set the window for target position.

See also section [Position profile generator](#) on page 66.




<p>Firmware block: PROFILE GENERATOR (66)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for position profile generator input position reference • defines the online positioning speed multiplier • defines a positioning speed value above which the acceleration/ deceleration time is reduced, ie, defines the power limit used in position reference calculation • configures positioning window supervision • selects the source for enabling the position reference generator and calculation of position reference • shows the position reference from the position profile generator and position profile generator distance to target. 		
<p>Block outputs located in other parameter groups</p>	<p>4.13 POS REF IPO (page 106) 4.14 DIST TGT (page 106)</p>	
<p>66.01</p>	<p>PROF GENERAT IN</p>	<p>FW block: PROFILE GENERATOR (see above)</p>
	<p>Selects the source for the position profile generator input position reference. The default value is P.4.6, ie, signal 4.06 POS REF (also an output of the PROFILE REF SEL firmware block; see page 237).</p> <p>Note: This parameter has been locked, ie, no user setting is possible.</p>	
	<p>Value pointer: Group and index</p>	
<p>66.02</p>	<p>PROF SPEED MUL</p>	<p>FW block: PROFILE GENERATOR (see above)</p>
	<p>Defines the online positioning speed multiplier. The speed is multiplied with the selected value.</p>	
<p>0...1</p>	<p>Online positioning speed multiplier.</p>	

66.03	PROF ACC WEAK SP	FW block: PROFILE GENERATOR (see above)
	<p>Defines a positioning speed value (for the profile generator), above which acceleration/deceleration is slowed down. Because the drive power depends on the torque and angular velocity, this parameter defines the power limit used in the position reference calculation.</p> <p>$P = T \times \omega$ and $T = J \times d\omega/dt$, where T = torque ω = angular speed J = Inertia $d\omega/dt$ = angular acceleration</p> <p>In other words, when the angular velocity exceeds the defined speed value, the power is limited by reducing the angular acceleration(/deceleration).</p> <p>The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.</p>	
	0...32768	Acceleration/deceleration time breakpoint.
66.04	POS WIN	FW block: PROFILE GENERATOR (see above)
	<p>Defines the absolute value for the positioning window supervision.</p> <ul style="list-style-type: none"> • When the difference between position reference and actual position is within the window defined by this parameter, the positioning is completed. Then, 6.09 POS CTRL STATUS bit 1 and 2.13 FBA MAIN SW bit 19 are set to 1. • When the value of position reference generator distance to target is within the window defined by this parameter, 6.09 POS CTRL STATUS bit 0 is set. <p>Parameter value must be smaller than the value set by parameter 71.06 POS ERR LIM.</p> <p>The unit depends on parameter 60.05 POS UNIT selection.</p>	
	0...32768	Absolute value for positioning window supervision.
66.05	POS ENABLE	FW block: PROFILE GENERATOR (see above)
	<p>Selects the source for enabling the position reference generator and the calculation of the position reference. The state of the enable signal is reflected by 6.09 POS CTRL STATUS, bit 3.</p> <p>1 = Enable / Continue position reference calculation. 0 = Disable. Position reference calculation is stopped. Generator output speed is decreased to zero along the position deceleration ramp.</p>	
	Bit pointer: Group, index and bit.	


Group 67 SYNC REF SEL

Synchronisation reference source selection that is used in synchron control mode. Synchron reference can be smoothed with fine interpolation if the reference is updated too slowly or changes drastically because of missing data. If the reference is taken from the virtual master, a rotating position reference is calculated according to the configured virtual master speed.




<p>Firmware block: SYNC REF SEL (67)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for the position reference in synchron control • shows the ungeared synchron reference input • configures the interpolation function for reference smoothing. 	
<p>Block outputs located in other parameter groups</p>	<p>4.15 SYNC REF UNGEAR (page 106) 4.21 SYNC REF IN (page 106)</p>

67.01	SYNC REF SEL	FW block: SYNC REF SEL (see above)
	Selects the source for the position reference in synchron control.	
	(0) ZERO	Zero position reference.
	(1) AI1	Analogue input 1.
	(2) AI2	Analogue input 2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive-to-drive reference 1.
	(6) D2D REF2	Drive-to-drive reference 2.
	(7)	Reserved.
	(8) POS 2ND ENC	Encoder 2.
	(9) VIRT MAST	Virtual master reference selected by parameter 67.02 VIRT MAS REF SEL .
67.02	VIRT MAS REF SEL	FW block: SYNC REF SEL (see above)
	Selects the source for the virtual master speed reference.	
	(0) ZERO	Zero position reference.
	(1) AI1	Analogue input 1.
	(2) AI2	Analogue input 2.
	(3) FBA REF1	Fieldbus reference 1.
	(4) FBA REF2	Fieldbus reference 2.
	(5) D2D REF1	Drive-to-drive reference 1.
	(6) D2D REF2	Drive-to-drive reference 2.
	(7) ENC1 SPEED	Encoder 1.
	(8) ENC2 SPEED	Encoder 2.
	(9) VM SPD REF	Parameter 67.10 VIRT MAS SPD REF .

67.03	INTERPOLAT MODE	FW block: SYNC REF SEL (see above)
	Selects whether the synchronisation reference selected by parameter 67.01 SYNC REF SEL is interpolated or not. This function can be used to smooth out short breaks in the reference.	
	(0) NONE	Interpolation is not used. The synchronisation reference is reflected directly by actual signal 4.15 SYNC REF UNGEAR .
	(1) INTERPOLATE	<p>The synchronisation reference is interpolated as shown in the diagram below.</p> <p>The synchronisation reference is sampled at intervals defined by parameter 67.04 INTERPOLAT CYCLE. Signal 4.15 SYNC REF UNGEAR is updated to the sampled reference value after one cycle.</p> 
67.04	INTERPOLAT CYCLE	FW block: SYNC REF SEL (see above)
	Interpolation cycle for synchronisation reference. Used if the drive does not receive a changing position reference from the synchronisation reference source. During the cycle, the drive calculates an internal synchronisation position reference according to the previous cycle reference delta. After the cycle, the drive updates the new value to signal 4.15 SYNC REF UNGEAR . See also parameter 67.03 INTERPOLAT MODE .	
	1...10000 ms	Interpolation cycle.
67.10	VIRT MAS SPD REF	FW block: SYNC REF SEL (see above)
	Defines the virtual master speed reference when parameter 67.02 VIRT MAS REF SEL is set to (9) VM SPD REF .	
	-30000...30000 rpm	Virtual master speed reference.

Group 68 SYNC REF MOD

Synchronisation reference modification settings that are used to select between absolute or relative synchronisation, to set an electrical gear ratio between the synchronisation reference and the drive positioning system, and to filter the reference.



<p>Firmware block: SYNC REF MOD (68)</p> <p>This block</p> <ul style="list-style-type: none"> • selects the source for the synchron reference chain • defines the gear ratio and selects a scaling factor for the ratio (in synchron control the position reference is first multiplied with the defined gear ratio and then with the defined gear scaling factor) • defines the synchron speed reference filter time • defines the maximum position difference between the unfiltered and filtered synchron speed reference • selects the synchronisation of the follower drive in synchron control mode • shows the position reference in synchron control mode. 		
Block outputs located in other parameter groups		4.16 SYNC REF GEARED (page 106)
68.01	SYNC GEAR IN	FW block: SYNC REF MOD (see above)
	Selects the source for the synchron reference chain. The default value is P.4.15, ie, parameter 4.15 SYNC REF UNGEAR , which is the output of the SYNC REF SEL firmware block (on page 247).	
	Value pointer: Group and index	


68.02	SYNC GEAR MUL	FW block: SYNC REF MOD (see above)
	<p>Defines the numerator for the synchron gear function. The gear function modifies the position alterations of the synchron position reference value in order to obtain a certain ratio between the master and follower motion. See also parameter 68.03 SYNC GEAR DIV.</p> $\frac{\text{68.02 SYNC GEAR MUL}}{\text{68.03 SYNC GEAR DIV}} = \frac{\text{Follower speed}}{\text{Master speed}}$ <p>Example: Parameter 68.02 SYNC GEAR MUL is set to the value of 253 and parameter 68.03 SYNC GEAR DIV is set to the value of 100. Gear ratio is 2.53, ie, follower speed is 2.53 times the master speed.</p>	
	$-2^{31} \dots 2^{31} - 1$	Numerator for synchron gear function.
68.03	SYNC GEAR DIV	FW block: SYNC REF MOD (see above)
	Defines the denominator for the synchron gear function. See parameter 68.02 SYNC GEAR MUL .	
	$1 \dots 2^{31} - 1$	Denominator for synchron gear function.
68.04	SYNC GEAR ADD	FW block: SYNC REF MOD (see above)
	Selects the scaling factor for the gear ratio (defined by parameters 68.02 SYNC GEAR MUL and 68.03 SYNC GEAR DIV) during operation. The synchron gear ratio is multiplied with the selected value.	
	$-30 \dots 30$	Scaling factor for gear ratio.
68.05	SYNC REF FTIME	FW block: SYNC REF MOD (see above)
	<p>Defines the synchron reference filter time. The filter filters synchron reference disturbances, for example those caused by encoder pulse changes. This parameter is used together with parameter 68.06 SYNCFILT DLY LIM to minimise synchron speed reference disturbances.</p> <p>Adjust parameter 68.06 SYNCFILT DLY LIM to maintain dynamic operation during fast reference changes.</p>	
	$0 \dots 1000$ ms	Synchron speed reference filter time.
68.06	SYNCFILT DLY LIM	FW block: SYNC REF MOD (see above)
	<p>Defines the maximum position difference between the unfiltered and filtered synchron reference. If the maximum difference is exceeded, the filter output is forced to follow the filter input.</p> <p>This parameter is used together with parameter 68.05 SYNC REF FTIME to minimise synchron speed reference disturbances.</p> <p>The unit depends on parameter 60.05 POS UNIT selection.</p>	
	$0 \dots 120$	Maximum difference between unfiltered and filtered synchron speed references.
68.07	SYNCHRON MODE	FW block: SYNC REF MOD (see above)
	Selects the synchronisation of the follower drive in synchron mode.	
	(0) Absolute	Absolute synchronisation of the follower. The follower follows the master position (4.15 SYNC REF UNGEAR) after the start.
	(1) Relative	Relative synchronisation of the follower. Only master position changes which take place after the follower is started are taken into account.

Group 70 POS REF LIMIT

Position reference (dynamic) limiter and synchronisation error supervision settings.

The limiter adds the reference changes from the profile reference generator (4.13 POS REF IPO) and synchron reference (4.16 SYNC REF GEARED). The limiter monitors speed, acceleration and deceleration changes in the positioning reference. The limited reference changes generate a synchronous error shown by 4.18 SYNC ERROR. The limits should be set according to the mechanical limits of the driven machinery.

See also section *Dynamic position reference limiter* on page 68.



Firmware block: POS REF LIM (70)		
This block <ul style="list-style-type: none"> selects the sources for the dynamic limiter inputs selects the source for the position reference enable command selects the positioning speed, acceleration rate and deceleration limits defines the synchron error supervision window shows the limited position reference and the synchronising error caused by the dynamic limitations or position correction defines the velocity window for synchronous velocity supervision. 		
Block outputs located in other parameter groups		4.17 POS REF LIMITED (page 106) 4.18 SYNC ERROR (page 106)
70.01	POS REF PROFILE	FW block: POS REF LIM (see above)
	Selects the source for the position reference for the dynamic limiter. Default value is P.4.13, ie, 4.13 POS REF IPO , which is an output of the PROFILE GENERATOR firmware block (see page 245).	
	Value pointer: Group and index.	
70.02	POS REF SYNC	FW block: POS REF LIM (see above)
	Selects the source for the position reference for the dynamic limiter (added to 70.01 POS REF PROFILE). Default value is P.4.16, ie, 4.16 SYNC REF GEARED , which is the output of the SYNC REF MOD firmware block (see page 250).	
	Value pointer: Group and index.	
70.03	POS REF ENA	FW block: POS REF LIM (see above)
	Selects the source for the position reference enable command. 1 = Enabled. 0 = Disabled, position reference speed limit is set to zero and any on-going positioning task is interrupted.	
	Bit pointer: Group, index and bit	
70.04	POS SPEED LIM	FW block: POS REF LIM (see above)
	Limits the positioning reference speed. An active limitation is indicated by 6.09 POS CTRL STATUS , bit 12. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Position reference speed limit.


70.05	POS ACCEL LIM	FW block: POS REF LIM (see above)
	Limits the positioning acceleration rate. An active limitation is indicated by 6.09 POS CTRL STATUS , bit 13. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Positioning acceleration rate limit.
70.06	POS DECEL LIM	FW block: POS REF LIM (see above)
	Limits the positioning deceleration rate. An active limitation is indicated by 6.09 POS CTRL STATUS , bit 14. The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	-32768...0	Positioning deceleration rate limit.
70.07	SYNC ERR LIM	FW block: POS REF LIM (see above)
	Defines the absolute value for the synchron error supervision window. The status is indicated by 6.10 POS CTRL STATUS2 , bit 0. The unit depends on parameter 60.05 POS UNIT selection. Sets the minimum cyclic correction limit. If the measured value is smaller than the limit, no correction is made. Note: If parameters are restored from software version UMF11880 or older, this parameter needs to be changed or restored to the new default value (0). The cyclic correction will not work with the old default value of positive maximum.	
	0...32768	Minimum position correction limit.
70.08	SYNC VEL WINDOW	FW block: POS REF LIM (see above)
	Defines the absolute value for a synchronous velocity supervision window. If the difference between synchronous speed and drive load speed is within the window, the limit bit 2 (IN SYNC) is set in 6.10 POS CTRL STATUS2 . The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.	
	0...32768	Absolute value for synchronous velocity supervision window.


Group 71 POSITION CTRL

Settings for the position controller.

The position controller calculates a speed reference that is used to minimise the difference between position reference and actual values. The user can set the controller gain, the feed forward value and a cyclical delay between the reference and the actual value. The output of the position controller has a gear for transferring position and speed data from the load side to the motor side.

The position controller also supervises the error between the reference position and actual position in position and synchron control modes. The drive trips on a POSITION ERROR fault if the limit (71.06 POS ERR LIM) is exceeded.



<p>Firmware block: POS CONTROL (71)</p> <p>This block</p> <ul style="list-style-type: none"> selects the sources for the actual and reference position inputs of the position controller defines the position control loop gain and the speed feed forward gain defines a delay for the position reference configures position error supervision shows the speed reference, position error and position speed reference multiplied by the speed feed forward gain defines the gear ratio between load and motor defines the following error window. 		
<p>Block outputs located in other parameter groups</p>		<p>4.01 SPEED REF POS (page 105) 4.19 POS ERROR (page 106) 4.20 SPEED FEED FWD (page 106)</p>
71.01	POS ACT IN	FW block: POS CONTROL (see above)
	<p>Selects the source for the actual position input of the position controller. The default value is P.1.12, ie, parameter 1.12 POS ACT, which is an output of the POS FEEDBACK firmware block (see page 221).</p>	
	<p>Value pointer: Group and index.</p>	
71.02	POS CTRL REF IN	FW block: POS CONTROL (see above)
	<p>Selects the source for the position reference input of the position controller. The default value is P.4.17, ie, parameter 4.17 POS REF LIMITED, which is the output of the POS REF LIM firmware block (see page 253).</p> <p>Note: This parameter has been locked, ie, no user setting is possible.</p>	
	<p>Value pointer: Group and index.</p>	
71.03	POS CTRL GAIN	FW block: POS CONTROL (see above)
	<p>Defines the gain for the position control loop. A value of 1 produces a 1 rev/s speed reference when the position difference between the reference and actual position is 1 revolution.</p>	
	0...10000 1/s	Gain for position control loop.

71.04	P CTRL FEED GAIN	FW block: POS CONTROL (see above)
	Defines the speed feed forward gain. The default gain value is suitable for most applications. In some cases the gain can be used to compensate the difference between the reference position and actual position caused by external disturbances.	
	0...10	Speed feed forward gain.
71.05	POS CTRL DELAY	FW block: POS CONTROL (see above)
	Defines the delay for the position reference. The selected number corresponds to the number of the position control cycles: If parameter value is set to 1, the position reference used in the position error calculation is the reference value updated during the previous position control cycle.	
	0...15	Delay for position reference.
71.06	POS ERR LIM	FW block: POS CONTROL (see above)
	Defines the absolute value for the position error supervision window. The drive trips on fault POSITION ERROR if the position error is exceeded. The supervision is active when position feedback is available. The unit depends on parameter 60.05 POS UNIT selection. Note: Position error supervision is not active in profile velocity mode.	
	0...32768	Absolute value for position error supervision window.
71.07	GEAR RATIO MUL	FW block: POS CONTROL (see above)
	Defines the numerator for the gear function between the position control (load side) and speed control (motor side). The gear function is formed from the motor gear function and inverted load gear function. The gear function is applied to the position controller output (speed reference). $\frac{71.07 \text{ GEAR RATIO MUL}}{71.08 \text{ GEAR RATIO DIV}} = \frac{\text{Motor speed}}{\text{Load speed}}$ Note: When motor or load gear functions are set, the gear function must also be set. See also sections Motor encoder gear function (page 56) and Load encoder gear function (page 63).	
	$-2^{31} \dots 2^{31}-1$	Numerator for gear function.
71.08	GEAR RATIO DIV	FW block: POS CONTROL (see above)
	Defines the denominator for the gear function between the position control (load side) and speed control (motor side). See parameter 71.07 GEAR RATIO MUL .	
	$1 \dots 2^{31}-1$	Denominator for gear function.
71.09	FOLLOW ERR WIN	FW block: POS CONTROL (see above)
	Defines the position window for the following error supervision. The error is defined as the difference between the reference and actual position. If the error is outside the defined window, 6.09 POS CTRL STATUS bit 7 FOLLOW ERR is set to 1 (also 2.13 FBA MAIN SW bit 18 FOLLOWING ERROR is set to 1). The supervision is active when position feedback is available. The unit depends on parameter 60.05 POS UNIT selection.	
	0...32768	Position window for error supervision.

Group 90 ENC MODULE SEL

Settings for encoder activation, emulation, TTL echo, and encoder cable fault detection.


The firmware supports two encoders, encoder 1 and 2 (but only one FEN-21 Resolver Interface Module). Revolution counting is only supported for encoder 1. The following optional interface modules are available:

- TTL Encoder Interface Module FEN-01: two TTL inputs, TTL output (for encoder emulation and echo), two digital inputs for position latching, PTC temperature sensor connection
- Absolute Encoder Interface FEN-11: absolute encoder input, TTL input, TTL output (for encoder emulation and echo), two digital inputs for position latching, PTC/KTY temperature sensor connection
- Resolver Interface Module FEN-21: resolver input, TTL input, TTL output (for encoder emulation echo), two digital inputs for position latching, PTC/KTY temperature sensor connection
- HTL Encoder Interface Module FEN-31: HTL encoder input, TTL output (for encoder emulation and echo), two digital inputs for position latching, PTC/KTY temperature sensor connection.

The interface module is connected to drive option Slot 1 or 2. **Note:** Two encoder interface modules of the same type are not allowed.

For encoder/resolver configuration, see parameter groups [91](#) (page [263](#)), [92](#) (page [269](#)) and [93](#) (page [270](#)).

Note: Configuration data is written into the logic registers of the interface module once after the power-up. If parameter values are changed, save values into the permanent memory using parameter [16.07 PARAM SAVE](#). The new settings will take effect when the drive is powered up again, or after re-configuration is forced using parameter [90.10 ENC PAR REFRESH](#).

<p>Firmware block: ENCODER (3)</p> <p>This block</p> <ul style="list-style-type: none"> • activates the communication to encoder interface 1/2 • enables encoder emulation/echo • shows encoder 1/2 speed and actual position. 		
Block inputs located in other parameter groups	93.21 EMUL PULSE NR (page 273) 93.22 EMUL POS REF (page 273)	
Block outputs located in other parameter groups	1.08 ENCODER 1 SPEED (page 93) 1.09 ENCODER 1 POS (page 93) 1.10 ENCODER 2 SPEED (page 94) 1.11 ENCODER 2 POS (page 94) 2.16 FEN DI STATUS (page 101)	
90.01	ENCODER 1 SEL	FW block: ENCODER (see above)
	<p>Activates the communication to optional encoder/resolver interface 1.</p> <p>Note: It is recommended that encoder interface 1 is used whenever possible since the data received through that interface is fresher than the data received through interface 2. On the other hand, when position values used in emulation are determined by the drive software, the use of encoder interface 2 is recommended as the values are transmitted earlier through interface 2 than through interface 1.</p>	
	(0) None	Inactive.
	(1) FEN-01 TTL+	Communication active. Module type: FEN-01 TTL Encoder interface Module. Input: TTL encoder input with commutation support (X32). See parameter group 93 .
	(2) FEN-01 TTL	Communication active. Module type: FEN-01 TTL Encoder interface Module. Input: TTL encoder input (X31). See parameter group 93 .
	(3) FEN-11 ABS	Communication active. Module type: FEN-11 Absolute Encoder Interface. Input: Absolute encoder input (X42). See parameter group 91 . Emulation is not possible with SSI or EnDat in the Continuous mode (parameters 91.25 and 91.30).
	(4) FEN-11 TTL	Communication active. Module type: FEN-11 Absolute Encoder Interface. Input: TTL encoder input (X41). See parameter group 93 .
	(5) FEN-21 RES	Communication active. Module type: FEN-21 Resolver Interface. Input: Resolver input (X52). See parameter group 92 .
	(6) FEN-21 TTL	Communication active. Module type: FEN-21 Resolver Interface. Input: TTL encoder input (X51). See parameter group 93 .

	(7) FEN-31 HTL	Communication active. Module type: FEN-31 HTL Encoder Interface. Input: HTL encoder input (X82). See parameter group 93 .
90.02	ENCODER 2 SEL	FW block: ENCODER (see above)
	<p>Activates the communication to the optional encoder/resolver interface 2.</p> <p>For selections, see parameter 90.01 ENCODER 1 SEL.</p> <p>Note: The counting of full shaft revolutions is not supported for encoder 2.</p>	
90.03	EMUL MODE SEL	FW block: ENCODER (see above)
	<p>Enables the encoder emulation and selects the position value and the TTL output used in the emulation process.</p> <p>In encoder emulation, a calculated position difference is transformed to a corresponding number of TTL pulses to be transmitted via the TTL output. The position difference is the difference between the latest and the previous position values.</p> <p>The position value used in emulation can be either a position determined by the drive software or a position measured by an encoder. If drive software position is used, the source for the used position is selected by parameter 93.22 EMUL POS REF. Because the software causes a delay, it is recommended that actual position is always taken from an encoder. Drive software is recommended to be used only with position reference emulation.</p> <p>Encoder emulation can be used to increase or decrease the pulse number when TTL encoder data is transmitted via the TTL output, eg, to another drive. If the pulse number requires no alternation, use encoder echo for data transformation. See parameter 90.04 TTL ECHO SEL. Note: If encoder emulation and echo are enabled for the same FEN-xx TTL output, the emulation overrides the echo.</p> <p>If an encoder input is selected as emulation source, the corresponding selection must be activated either with parameter 90.01 ENCODER 1 SEL or 90.02 ENCODER 2 SEL.</p> <p>The TTL encoder pulse number used in emulation must be defined by parameter 93.21 EMUL PULSE NR. See parameter group 93.</p>	
	(0) Disabled	Emulation disabled.
	(1) FEN-01 SWref	Module type: FEN-01 TTL Encoder interface Module. Emulation: Drive software position (source selected by par. 93.22 EMUL POS REF) is emulated to FEN-01 TTL output.
	(2) FEN-01 TTL+	Module type: FEN-01 TTL Encoder interface Module. Emulation: FEN-01 TTL encoder input (X32) position is emulated to FEN-01 TTL output.
	(3) FEN-01 TTL	Module type: FEN-01 TTL Encoder interface Module. Emulation: FEN-01 TTL encoder input (X31) position is emulated to FEN-01 TTL output.
	(4) FEN-11 SWref	Module type: FEN-11 Absolute Encoder Interface. Emulation: Drive software position (source selected by par. 93.22 EMUL POS REF) is emulated to FEN-11 TTL output.
	(5) FEN-11 ABS	Module type: FEN-11 Absolute Encoder Interface. Emulation: FEN-11 absolute encoder input (X42) position is emulated to FEN-11 TTL output. Emulation is not possible with SSI or EnDat in the Continuous mode (parameters 91.25 and 91.30).
	(6) FEN-11 TTL	Module type: FEN-11 Absolute Encoder Interface. Emulation: FEN-11 TTL encoder input (X41) position is emulated to FEN-11 TTL output.

	(7) FEN-21 SWref	Module type: FEN-21 Resolver Interface. Emulation: Drive software position (source selected by par. 93.22 EMUL POS REF) is emulated to FEN-21 TTL output.
	(8) FEN-21 RES	Module type: FEN-21 Resolver Interface. Emulation: FEN-21 resolver input (X52) position is emulated to FEN-21 TTL output.
	(9) FEN-21 TTL	Module type: FEN-21 Resolver Interface. Emulation: FEN-21 TTL encoder input (X51) position is emulated to FEN-21 TTL output.
	(10) FEN-31 SWref	Module type: FEN-31 HTL Encoder Interface. Emulation: Drive software position (source selected by par. 93.22 EMUL POS REF) is emulated to FEN-31 TTL output.
	(11) FEN-31 HTL	Module type: FEN-31 HTL Encoder Interface. Emulation: FEN-31 HTL encoder input (X82) position is emulated to FEN-31 TTL output.
90.04	TTL ECHO SEL	FW block: ENCODER (see above)
	Enables and selects the interface for the TTL encoder signal echo. Note: If encoder emulation and echo are enabled for the same FEN-xx TTL output, the emulation overrides the echo.	
	(0) Disabled	TTL echo disabled.
	(1) FEN-01 TTL+	Module type: FEN-01 TTL Encoder Interface. Echo: TTL encoder input (X32) pulses are echoed to the TTL output.
	(2) FEN-01 TTL	Module type: FEN-01 TTL Encoder Interface. Echo: TTL encoder input (X31) pulses are echoed to the TTL output.
	(3) FEN-11 TTL	Module type: FEN-11 Absolute Encoder Interface. Echo: TTL encoder input (X41) pulses are echoed to the TTL output.
	(4) FEN-21 TTL	Module type: FEN-21 Resolver Interface. Echo: TTL encoder input (X51) pulses are echoed to the TTL output.
	(5) FEN-31 HTL	Module type: FEN-31 HTL Encoder Interface. Echo: HTL encoder input (X82) pulses are echoed to the TTL output.

90.05	ENC CABLE FAULT	FW block: ENCODER (see above)
	<p>Selects the action in case an encoder cable fault is detected by the FEN-xx encoder interface.</p> <p>Notes:</p> <ul style="list-style-type: none"> • This functionality is only available with the absolute encoder input of the FEN-11 based on sine/cosine incremental signals, and with the HTL input of the FEN-31. • When the encoder input is used for speed feedback (see 22.01 SPEED FB SEL), this parameter may be overridden by parameter 22.09 SPEED FB FAULT. 	
	(0) No	Cable fault detection inactive.
	(1) Fault	The drive trips on an ENCODER 1/2 CABLE fault.
	(2) Warning	<p>The drive generates an ENCODER 1/2 CABLE warning. This is the recommended setting if the maximum pulse frequency of sine/cosine incremental signals exceeds 100 kHz; at high frequencies, the signals may attenuate enough to invoke the function. The maximum pulse frequency can be calculated as follows:</p> $\frac{\text{Pulses per revolution (par. 91.01)} \times \text{Maximum speed in rpm}}{60}$
90.06	INVERT ENC SIG	FW block: None
	Rotation direction of encoder signals can be inverted separately without cabling changes.	
	(0) No	Encoder rotation directions are not inverted.
	(1) Enc1	Encoder 1 rotation direction is inverted.
	(2) Enc2	Encoder 2 rotation direction is inverted.
	(3) Both	Both encoder 1 and 2 rotation directions are inverted.
90.10	ENC PAR REFRESH	FW block: ENCODER (see above)
	<p>Setting this parameter to 1 forces a reconfiguration of the FEN-xx interfaces, which is needed for any parameter changes in groups 90...93 to take effect.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	(0) Done	Refreshing done.
	(1) Configure	Reconfigure. The value will automatically revert to DONE.

Group 91 ABSOL ENC CONF

Absolute encoder configuration; used when parameter [90.01 ENCODER 1 SEL](#) / [90.02 ENCODER 2 SEL](#) is set to [\(3\) FEN-11 ABS](#).

The optional FEN-11 Absolute Encoder Interface module supports the following encoders:

- Incremental sin/cos encoders with or without zero pulse and with or without sin/cos commutation signals
- Endat 2.1/2.2 with incremental sin/cos signals (partially without sin/cos incremental signals*)
- Hiperface encoders with incremental sin/cos signals
- SSI (Synchronous Serial Interface) with incremental sin/cos signals (partially without sin/cos incremental signals*)
- Tamagawa 17/33-bit digital encoders (the resolution of position data within one revolution is 17 bits; multiturn data includes a 16-bit revolution count).

* EnDat and SSI encoders without incremental sin/cos signals are partially supported only as encoder 1: Speed is not available and the time instant of the position data (delay) depends on the encoder.

See also parameter group [90](#) on page [259](#), and *FEN-11 Absolute Encoder Interface User's Manual* (3AFE68784841 [English]).

Note: Configuration data is written into the logic registers of the interface module once after the power-up. If parameter values are changed, save values into the permanent memory using parameter [16.07 PARAM SAVE](#). The new settings will take effect when the drive is powered up again, or after re-configuration is forced using parameter [90.10 ENC PAR REFRESH](#).

Firmware block: ABSOL ENC CONF (91) This block configures the absolute encoder connection.	<table border="1"> <thead> <tr> <th colspan="2">ABSOL ENC CONF</th> <th>42</th> </tr> </thead> <tbody> <tr> <td></td> <td>MISC_4</td> <td>10 msec (2)</td> </tr> <tr> <td>(Drive value)</td> <td>91.01</td> <td>SINE COSINE NR</td> </tr> <tr> <td>(Drive value)</td> <td>91.02</td> <td>ABS ENC INTERF</td> </tr> <tr> <td>(Drive value)</td> <td>91.03</td> <td>REV COUNT BITS</td> </tr> <tr> <td>(Drive value)</td> <td>91.04</td> <td>POS DATA BITS</td> </tr> <tr> <td>(Drive value)</td> <td>91.05</td> <td>REFMARK ENA</td> </tr> <tr> <td>(Drive value)</td> <td>91.06</td> <td>ABS POS TRACKING</td> </tr> <tr> <td>(Drive value)</td> <td>91.10</td> <td>HIPERFACE PARITY</td> </tr> <tr> <td>(Drive value)</td> <td>91.11</td> <td>HIPERF BAUDRATE</td> </tr> <tr> <td>(Drive value)</td> <td>91.12</td> <td>HIPERF NODE ADDR</td> </tr> <tr> <td>(Drive value)</td> <td>91.20</td> <td>SSI CLOCK CYCLES</td> </tr> <tr> <td>(Drive value)</td> <td>91.21</td> <td>SSI POSITION MSB</td> </tr> <tr> <td>(Drive value)</td> <td>91.22</td> <td>SSI REVOL MSB</td> </tr> <tr> <td>(Drive value)</td> <td>91.23</td> <td>SSI DATA FORMAT</td> </tr> <tr> <td>(Drive value)</td> <td>91.24</td> <td>SSI BAUD RATE</td> </tr> <tr> <td>(Drive value)</td> <td>91.25</td> <td>SSI MODE</td> </tr> <tr> <td>(Drive value)</td> <td>91.26</td> <td>SSI TRANSMIT CYC</td> </tr> <tr> <td>(Drive value)</td> <td>91.27</td> <td>SSI ZERO PHASE</td> </tr> <tr> <td>(Drive value)</td> <td>91.30</td> <td>ENDAT MODE</td> </tr> <tr> <td>(Drive value)</td> <td>91.31</td> <td>ENDAT MAX CALC</td> </tr> </tbody> </table>	ABSOL ENC CONF		42		MISC_4	10 msec (2)	(Drive value)	91.01	SINE COSINE NR	(Drive value)	91.02	ABS ENC INTERF	(Drive value)	91.03	REV COUNT BITS	(Drive value)	91.04	POS DATA BITS	(Drive value)	91.05	REFMARK ENA	(Drive value)	91.06	ABS POS TRACKING	(Drive value)	91.10	HIPERFACE PARITY	(Drive value)	91.11	HIPERF BAUDRATE	(Drive value)	91.12	HIPERF NODE ADDR	(Drive value)	91.20	SSI CLOCK CYCLES	(Drive value)	91.21	SSI POSITION MSB	(Drive value)	91.22	SSI REVOL MSB	(Drive value)	91.23	SSI DATA FORMAT	(Drive value)	91.24	SSI BAUD RATE	(Drive value)	91.25	SSI MODE	(Drive value)	91.26	SSI TRANSMIT CYC	(Drive value)	91.27	SSI ZERO PHASE	(Drive value)	91.30	ENDAT MODE	(Drive value)	91.31	ENDAT MAX CALC
	ABSOL ENC CONF		42																																																													
	MISC_4	10 msec (2)																																																														
(Drive value)	91.01	SINE COSINE NR																																																														
(Drive value)	91.02	ABS ENC INTERF																																																														
(Drive value)	91.03	REV COUNT BITS																																																														
(Drive value)	91.04	POS DATA BITS																																																														
(Drive value)	91.05	REFMARK ENA																																																														
(Drive value)	91.06	ABS POS TRACKING																																																														
(Drive value)	91.10	HIPERFACE PARITY																																																														
(Drive value)	91.11	HIPERF BAUDRATE																																																														
(Drive value)	91.12	HIPERF NODE ADDR																																																														
(Drive value)	91.20	SSI CLOCK CYCLES																																																														
(Drive value)	91.21	SSI POSITION MSB																																																														
(Drive value)	91.22	SSI REVOL MSB																																																														
(Drive value)	91.23	SSI DATA FORMAT																																																														
(Drive value)	91.24	SSI BAUD RATE																																																														
(Drive value)	91.25	SSI MODE																																																														
(Drive value)	91.26	SSI TRANSMIT CYC																																																														
(Drive value)	91.27	SSI ZERO PHASE																																																														
(Drive value)	91.30	ENDAT MODE																																																														
(Drive value)	91.31	ENDAT MAX CALC																																																														

91.01	SINE COSINE NR	FW block: ABSOL ENC CONF (see above)
	<p>Defines the number of sine/cosine wave cycles within one revolution.</p> <p>Note: This parameter does not need to be set when EnDat or SSI encoders are used in continuous mode. See parameter 91.25 SSI MODE / 91.30 ENDAT MODE.</p>	
	0...65535	Number of sine/cosine wave cycles within one revolution.
91.02	ABS ENC INTERF	FW block: ABSOL ENC CONF (see above)
	<p>Selects the source for the encoder absolute position.</p> <p>With (2) EnDat or (3) Hiperface encoder selected and configuration parameters at zero, encoder configuration is automatically initialized when encoder refresh is done. Configured parameters are 91.01 SINE COSINE NR, 91.03 REV COUNT BITS and 91.04 POS DATA BITS.</p> <p>Note: Automatic configuration requires FEN-11 FPGA logic version VIE1 2200.</p>	
	(0) None	Not selected.
	(1) Commut sig	Commutation signals.
	(2) EnDat	Serial interface: EnDat encoder.
	(3) Hiperface	Serial interface: HIPERFACE encoder.
	(4) SSI	Serial interface: SSI encoder.
	(5) Tamag.17/33 bits	Serial interface: Tamagawa 17/33-bit encoder.
91.03	REV COUNT BITS	FW block: ABSOL ENC CONF (see above)
	<p>Defines the number of bits used in revolution counting with multiturn encoders. Used when parameter 91.02 ABS ENC INTERF is set to (2) EnDat, (3) Hiperface or (4) SSI. When 91.02 ABS ENC INTERF is set to (5) Tamag.17/33 bits, setting this parameter to a non-zero value activates multiturn data requesting.</p>	
	0...32	Number of bits used in revolution count. Eg, 4096 revolutions => 12 bits.
91.04	POS DATA BITS	FW block: ABSOL ENC CONF (see above)
	<p>Defines the number of bits used within one revolution when parameter 91.02 ABS ENC INTERF is set to (2) EnDat, (3) Hiperface or (4) SSI. When 91.02 ABS ENC INTERF is set to (5) Tamag.17/33 bits, this parameter is internally set to 17.</p>	
	0...32	Number of bits used within one revolution. Eg, 32768 positions per revolution => 15 bits.
91.05	REFMARK ENA	FW block: ABSOL ENC CONF (see above)
	<p>Enables the encoder zero pulse for the absolute encoder input (X42) of an FEN-11 module (if present). Zero pulse can be used for position latching.</p> <p>Note: With serial interfaces (ie, when parameter 91.02 ABS ENC INTERF is set to (2) EnDat, (3) Hiperface, (4) SSI or (5) Tamag.17/33 bits), the zero pulse does not exist.</p>	
	(0) FALSE	Zero pulse disabled.
	(1) TRUE	Zero pulse enabled.

91.06	ABS POS TRACKING	FW block: ABSOL ENC CONF (see above)
	<p>Enables position tracking, which counts the number of absolute encoder overflows (single and multiturn encoder and resolver) in order to determine the actual position uniquely and clearly after a power-up (or encoder refresh), especially with an odd load gear ratio.</p> <p>Each time the position tracking is enabled or disabled, it must also be activated by setting parameter 90.10 ENC PAR REFRESH to (1) Configure.</p> <p>Note: If the encoder was turned by more than half the encoder range while the drive was switched off, the overflow counter has to be cleared. To clear the counter, set 91.06 ABS POS TRACKING to (0) Disable and 90.10 ENC PAR REFRESH to (1) Configure.</p>	
	(0) Disable	Position tracking disabled.
	(1) Enable	Position tracking enabled.
91.10	HIPERFACE PARITY	FW block: ABSOL ENC CONF (see above)
	<p>Defines the use of parity and stop bit(s) for HIPERFACE encoder (ie, when parameter 91.02 ABS ENC INTERF is set to (3) Hiperface).</p> <p>Typically this parameter does not need to be set.</p>	
	(0) Odd	Odd parity indication bit, one stop bit.
	(1) Even	Even parity indication bit, one stop bit.
91.11	HIPERF BAUDRATE	FW block: ABSOL ENC CONF (see above)
	<p>Defines the transfer rate of the link for HIPERFACE encoder (ie, when parameter 91.02 ABS ENC INTERF is set to (3) Hiperface).</p> <p>Typically this parameter does not need to be set.</p>	
	(0) 4800	4800 bits/s.
	(1) 9600	9600 bits/s.
	(2) 19200	19200 bits/s.
	(3) 38400	38400 bits/s.
91.12	HIPERF NODE ADDR	FW block: ABSOL ENC CONF (see above)
	<p>Defines the node address for HIPERFACE encoder (ie, when parameter 91.02 ABS ENC INTERF is set to (3) Hiperface).</p> <p>Typically this parameter does not need to be set.</p>	
	0...255	HIPERFACE encoder node address.
91.20	SSI CLOCK CYCLES	FW block: ABSOL ENC CONF (see above)
	<p>Defines the length of the SSI message. The length is defined as the number of clock cycles. The number of cycles can be calculated by adding 1 to the number of the bits in a SSI message frame. Used with SSI encoders, ie, when parameter 91.02 ABS ENC INTERF is set to (4) SSI.</p>	
	2...127	SSI message length.

91.21	SSI POSITION MSB	FW block: ABSOL ENC CONF (see above)
	Defines the location of the MSB (main significant bit) of the position data within a SSI message. Used with SSI encoders, ie, when parameter 91.02 ABS ENC INTERF is set to (4) SSI .	
	1...126	Position data MSB location (bit number).
91.22	SSI REVOL MSB	FW block: ABSOL ENC CONF (see above)
	Defines the location of the MSB (main significant bit) of the revolution count within a SSI message. Used with SSI encoders, ie, when parameter 91.02 ABS ENC INTERF is set to (4) SSI .	
	1...126	Revolution count MSB location (bit number).
91.23	SSI DATA FORMAT	FW block: ABSOL ENC CONF (see above)
	Selects the data format for SSI encoder (ie, when parameter 91.02 ABS ENC INTERF is set to (4) SSI).	
	(0) binary	Binary code.
	(1) gray	Gray code.
91.24	SSI BAUD RATE	FW block: ABSOL ENC CONF (see above)
	Selects the baud rate for SSI encoder (ie, when parameter 91.02 ABS ENC INTERF is set to (4) SSI).	
	(0) 10 kbit/s	10 kbit/s.
	(1) 50 kbit/s	50 kbit/s.
	(2) 100 kbit/s	100 kbit/s.
	(3) 200 kbit/s	200 kbit/s.
	(4) 500 kbit/s	500 kbit/s.
	(5) 1000 kbit/s	1000 kbit/s.
	(6) 1500 kbit/s.	1500 kbit/s.
	(7) 2000 kbit/s.	2000 kbit/s.
91.25	SSI MODE	FW block: ABSOL ENC CONF (see above)
	Selects the SSI encoder mode. Note: Parameter needs to be set only when an SSI encoder is used in continuous mode, ie, SSI encoder without incremental sin/cos signals (supported only as encoder 1). SSI encoder is selected by setting parameter 91.02 ABS ENC INTERF to (4) SSI .	
	(0) Initial pos.	Single position transfer mode (initial position).
	(1) Continuous	Continuous position transfer mode. Measured encoder speed is not calculated and is always 0.
	(3) Cont.spd+pos.	Both speed and absolute position are transferred continuously. Measured speed quality depends on the baudrate and may be weak.

91.26	SSI TRANSMIT CYC	FW block: ABSOL ENC CONF (see above)
	<p>Selects the transmission cycle for SSI encoder.</p> <p>Note: This parameter needs to be set only when an SSI encoder is used in continuous mode, ie, SSI encoder without incremental sin/cos signals (supported only as encoder 1). SSI encoder is selected by setting parameter 91.02 ABS ENC INTERF to (4) SSI.</p>	
	(0) 50 us	50 μ s.
	(1) 100 us	100 μ s.
	(2) 200 us	200 μ s.
	(3) 500 us	500 μ s.
	(4) 1 ms	1 ms.
	(5) 2 ms	2 ms.
91.27	SSI ZERO PHASE	FW block: ABSOL ENC CONF (see above)
	<p>Defines the phase angle within one sine/cosine signal period that corresponds to the value of zero on the SSI serial link data. The parameter is used to adjust the synchronization of the SSI position data and the position based on sine/cosine incremental signals. Incorrect synchronization may cause an error of ± 1 incremental period.</p> <p>Note: This parameter needs to be set only when an SSI encoder with sine/cosine incremental signals is used in initial position mode.</p>	
	(0) 315–45 deg	315–45 degrees.
	(1) 45–135 deg	45–135 degrees.
	(2) 135–225 deg	135–225 degrees.
	(3) 225–315 deg	225–315 degrees.
91.30	ENDAT MODE	FW block: ABSOL ENC CONF (see above)
	<p>Selects the EnDat encoder mode.</p> <p>Note: This parameter needs to be set only when an EnDat encoder is used in continuous mode, ie, EnDat encoder without incremental sin/cos signals (supported only as encoder 1). EnDat encoder is selected by setting parameter 91.02 ABS ENC INTERF to (2) EnDat.</p>	
	(0) Initial pos.	Single position transfer mode (initial position).
	(1) Continuous	Continuous position data transfer mode. Measured encoder speed is not calculated and is always 0.
	(3) Cont.spd+pos.	Both speed and absolute position are transferred continuously.
91.31	ENDAT MAX CALC	FW block: ABSOL ENC CONF (see above)
	<p>Selects the maximum encoder calculation time for EnDat encoder.</p> <p>Note: This parameter needs to be set only when an EnDat encoder is used in continuous mode, ie, EnDat encoder without incremental sin/cos signals (supported only as encoder 1). EnDat encoder is selected by setting parameter 91.02 ABS ENC INTERF to (2) EnDat.</p>	
	(0) 10 us	10 μ s.

	(1) 100 us	100 μ s.
	(2) 1 ms	1 ms.
	(3) 50 ms	50 ms.
91.32	ENDAT CLOCK FREQ	FW block: ABSOL ENC CONF (see above)
	Selects the EnDat bitrate. Note: Requires FEN-11 FPGA logic version VIE1 2200.	
	(0) 1 MHz	1 MHz.
	(1) 2 MHz	2 MHz.
	(2) 4 MHz	4 MHz.
	(3) 8 MHz	8 MHz.

Group 92 RESOLVER CONF

Resolver configuration; used when parameter [90.01 ENCODER 1 SEL](#) / [90.02 ENCODER 2 SEL](#) is set to [\(5\) FEN-21 RES](#).

The optional FEN-21 Resolver Interface module is compatible with resolvers which are excited by sinusoidal voltage (to the rotor winding) and which generate sine and cosine signals proportional to the rotor angle (to stator windings).

Note: Configuration data is written into the logic registers of the adapter once after the power-up. If parameter values are changed, save values into the permanent memory by parameter [16.07 PARAM SAVE](#). The new settings will take effect when the drive is powered up again, or after re-configuration is forced by parameter [90.10 ENC PAR REFRESH](#).

Resolver autotuning is performed automatically whenever the resolver input is activated after changes to parameters [92.02 EXC SIGNAL AMPL](#) or [92.03 EXC SIGNAL FREQ](#). Autotuning must be forced after any changes in the resolver cable connection. This can be done by setting either [92.02 EXC SIGNAL AMPL](#) or [92.03 EXC SIGNAL FREQ](#) to its already existing value, and then setting parameter [90.10 ENC PAR REFRESH](#) to 1.

If the resolver (or absolute encoder) is used for feedback from a permanent magnet motor, an Autophasing ID run should be performed after replacement or any parameter changes. See parameter [99.13 IDRUN MODE](#) and section [Autophasing](#) on page [44](#).

See also parameter group [90](#) on page [259](#), and *FEN-21 Resolver Interface User's Manual* (3AFE68784859 [English]).

Firmware block: RESOLVER CONF (92) This block configures the resolver connection.		
92.01	RESOLV POLEPAIRS	FW block: RESOLVER CONF (see above)
	Selects the number of pole pairs.	
	1...32	Number of pole pairs.
92.02	EXC SIGNAL AMPL	FW block: RESOLVER CONF (see above)
	Defines the amplitude of the excitation signal.	
	4.0... 12.0 Vrms	Excitation signal amplitude.
92.03	EXC SIGNAL FREQ	FW block: RESOLVER CONF (see above)
	Defines the frequency of the excitation signal.	
	1...20 kHz	Excitation signal frequency.

Group 93 PULSE ENC CONF

TTL/HTL input and TTL output configuration. See also parameter group [90](#) on page [259](#), and the appropriate encoder extension module manual.

Parameters [93.01](#)...[93.06](#) are used when a TTL/HTL encoder is used as encoder 1 (see parameter [90.01 ENCODER 1 SEL](#)).

Parameters [93.11](#)...[93.16](#) are used when a TTL/HTL encoder is used as encoder 2 (see parameter [90.02 ENCODER 2 SEL](#)).

Typically, only parameter [93.01/93.11](#) needs to be set for TTL/HTL encoders.

Note: Configuration data is written into the logic registers of the adapter once after the power-up. If parameter values are changed, save values into the permanent memory by parameter [16.07 PARAM SAVE](#). The new settings will take effect when the drive is powered up again, or after re-configuration is forced by parameter [90.10 ENC PAR REFRESH](#).

Firmware block: PULSE ENC CONF (93) This block configures the TTL/HTL input and TTL output.		<p>The screenshot shows a list of parameters for the PULSE ENC CONF block. The parameters are: 93.01 ENC1 PULSE NR (value [0]), 93.02 ENC1 TYPE (value [Quadrature]), 93.03 ENC1 SP CALCMODE (value [auto rising]), 93.04 ENC1 POS EST ENA (value [TRUE]), 93.05 ENC1 SP EST ENA (value [FALSE]), 93.06 ENC1 OSC LIM (value [4880Hz]), 93.11 ENC2 PULSE NR (value [0]), 93.12 ENC2 TYPE (value [Quadrature]), 93.13 ENC2 SP CALCMODE (value [auto rising]), 93.14 ENC2 POS EST ENA (value [TRUE]), 93.15 ENC2 SP EST ENA (value [FALSE]), and 93.16 ENC2 OSC LIM (value [4880Hz]).</p>
93.01	ENC1 PULSE NR	FW block: PULSE ENC CONF (see above)
	Defines the pulse number per revolution for encoder 1.	
	0...65535	Pulses per revolution for encoder 1.
93.02	ENC1 TYPE	FW block: PULSE ENC CONF (see above)
	Selects the type of encoder 1.	
	(0) Quadrature	Quadrature encoder (two channels, channels A and B).
	(1) single track	Single track encoder (one channel, channel A).
93.03	ENC1 SP CALCMODE	FW block: PULSE ENC CONF (see above)
	Selects the speed calculation mode for encoder 1. *When single track mode has been selected by parameter 93.02 ENC1 TYPE , the speed is always positive.	

	(0) A&B all	Channels A and B: Rising and falling edges are used for speed calculation. Channel B: Defines the direction of rotation. * Note: When single track mode has been selected by parameter 93.02 ENC1 TYPE , setting 0 acts like setting 1.												
	(1) A all	Channel A: Rising and falling edges are used for speed calculation. Channel B: Defines the direction of rotation. *												
	(2) A rising	Channel A: Rising edges are used for speed calculation. Channel B: Defines the direction of rotation. *												
	(3) A falling	Channel A: Falling edges are used for speed calculation. Channel B: Defines the direction of rotation. *												
	(4) auto rising (5) auto falling	Used mode (0, 1, 2 or 3) is changed automatically depending on the pulse frequency according to the following table: <table border="1" data-bbox="743 741 1481 913"> <thead> <tr> <th>93.03 = 4</th> <th>93.03 = 5</th> <th>Pulse frequency of the channel(s)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>< 2442 Hz</td> </tr> <tr> <td>1</td> <td>1</td> <td>2442...4884 Hz</td> </tr> <tr> <td>2</td> <td>3</td> <td>> 4884 Hz</td> </tr> </tbody> </table>	93.03 = 4	93.03 = 5	Pulse frequency of the channel(s)	0	0	< 2442 Hz	1	1	2442...4884 Hz	2	3	> 4884 Hz
93.03 = 4	93.03 = 5	Pulse frequency of the channel(s)												
0	0	< 2442 Hz												
1	1	2442...4884 Hz												
2	3	> 4884 Hz												
93.04	ENC1 POS EST ENA	FW block: PULSE ENC CONF (see above)												
	Selects whether position estimation is used with encoder 1 to increase position data resolution or not.													
	(0) FALSE	Measured position (Resolution: 4 x pulses per revolution for quadrature encoders, 2 x pulses per revolution for single track encoders.)												
	(1) TRUE	Estimated position. (Uses position extrapolation. Extrapolated at the time of data request.)												
93.05	ENC1 SP EST ENA	FW block: PULSE ENC CONF (see above)												
	Selects whether calculated or estimated speed is used with encoder 1.													
	(0) FALSE	Last calculated speed (calculation interval is 62.5 μ s...4 ms).												
	(1) TRUE	Estimated speed (estimated at the time of data request) Estimation increases the speed ripple in steady state operation, but improves the dynamics.												
93.06	ENC1 OSC LIM	FW block: PULSE ENC CONF (see above)												
	Activates transient filter for encoder 1. Changes of direction of rotation are ignored above the selected pulse frequency.													
	(0) 4880Hz	Change in rotation of direction allowed below 4880 Hz.												
	(1) 2440Hz	Change in rotation of direction allowed below 2440 Hz.												
	(2) 1220Hz	Change in rotation of direction allowed below 1220 Hz.												
	(3) Disabled	Change in rotation of direction allowed at any pulse frequency.												

93.07	ENC1 PULSE FILT	FW block: PULSE ENC CONF (see above)
	<p>Selects pulse edge filtering settings for encoder 1. Pulse edge filtering can improve the reliability of measurements, especially from encoders with a single-ended connection.</p> <p>Note: Requires FEN-31 FPGA logic version VIE3 2200 or later.</p> <p>Note: Pulse edge filtering decreases the maximum pulse frequency. With 2 μs filtering time, the maximum pulse frequency is 200 kHz.</p>	
	(0) No filtering	Filtering disabled.
	(1) 1 μ s	Filtering time: 1 microsecond.
	(2) 2 μ s	Filtering time: 2 microseconds.
93.11	ENC2 PULSE NR	FW block: PULSE ENC CONF (see above)
	Defines the pulse number per revolution for encoder 2.	
	0...65535	Pulses per revolution for encoder 2.
93.12	ENC2 TYPE	FW block: PULSE ENC CONF (see above)
	Selects the type of encoder 2. For selections, see parameter 93.02 ENC1 TYPE .	
93.13	ENC2 SP CALCMODE	FW block: PULSE ENC CONF (see above)
	<p>Selects the speed calculation mode for encoder 2.</p> <p>For selections, see parameter 93.03 ENC1 SP CALCMODE.</p>	
93.14	ENC2 POS EST ENA	FW block: PULSE ENC CONF (see above)
	<p>Selects whether measured or estimated position is used with encoder 2.</p> <p>For selections, see parameter 93.04 ENC1 POS EST ENA.</p>	
93.15	ENC2 SP EST ENA	FW block: PULSE ENC CONF (see above)
	<p>Selects whether calculated or estimated speed is used with encoder 2.</p> <p>For selections, see parameter 93.05 ENC1 SP EST ENA.</p>	
93.16	ENC2 OSC LIM	FW block: PULSE ENC CONF (see above)
	<p>Activates transient filter for encoder 2. Changes of direction of rotation are ignored above the selected pulse frequency.</p> <p>For selections, see parameter 93.06 ENC1 OSC LIM.</p>	

93.17	ENC2 PULSE FILT	FW block: PULSE ENC CONF (see above)
	<p>Selects pulse edge filtering settings for encoder 2. Pulse edge filtering can improve the reliability of measurements, especially from encoders with a single-ended connection.</p> <p>Note: Requires FEN-31 FPGA logic version VIE3 2200 or later.</p> <p>Note: Pulse edge filtering decreases the maximum pulse frequency. With 2 μs filtering time, the maximum pulse frequency is 200 kHz.</p>	
	(0) No filtering	Filtering disabled.
	(1) 1 μ s	Filtering time: 1 microsecond.
	(2) 2 μ s	Filtering time: 2 microseconds.
93.21	EMUL PULSE NR	FW block: ENCODER (page 259)
	<p>Defines the number of TTL pulses per revolution used in encoder emulation. Encoder emulation is enabled by parameter 90.03 EMUL MODE SEL.</p>	
	0...65535	TTL pulses used in encoder emulation.
93.22	EMUL POS REF	FW block: ENCODER (page 259)
	<p>Selects the source for the position value used in encoder emulation when parameter 90.03 EMUL MODE SEL is set to (1) FEN-01 SWref, (4) FEN-11 SWref, (7) FEN-21 SWref or (10) FEN-31 SWref. See parameter group 90.</p> <p>The source can be any actual or reference position value (except 1.09 ENCODER 1 POS and 1.11 ENCODER 2 POS).</p>	
	Value pointer: Group and index	
93.23	EMUL POS OFFSET	FW block: None
	<p>Defines the zero point for emulated position in relation of the zero point of the input position (within one revolution). The input position is selected by parameter 90.03 EMUL MODE SEL.</p> <p>For example, if the offset is 0, an emulated zero pulse is generated each time the input position moves across 0. With an offset of 0.5, an emulated zero pulse is generated each time the input position (within one revolution) moves across 0.5.</p>	
	0 ... 0.99998 rev	Emulated zero pulse position offset.

Group 95 HW CONFIGURATION

Miscellaneous hardware-related settings.

95.01	CTRL UNIT SUPPLY	FW block: None
	Defines the manner in which the drive control unit is powered.	
	(0) Internal 24V	The drive control unit is powered from the drive power unit it is mounted on.
	(1) External 24V	The drive control unit is powered from an external power supply.
95.02	EXTERNAL CHOKE	FW block: None
	Defines if the drive is equipped with an AC choke or not.	
	(0) NO	The drive is not equipped with an AC choke.
	(1) YES	The drive is equipped with an AC choke.

Group 97 USER MOTOR PAR

User adjustment of motor model values estimated during motor ID run. The values can be entered in either “per unit” or SI.

97.01	USE GIVEN PARAMS	FW block: None
	<p>Activates the motor model parameters 97.02...97.14 and the rotor angle offset parameter 97.20.</p> <p>Notes:</p> <ul style="list-style-type: none"> Parameter value is automatically set to zero when motor ID run is selected by parameter 99.13 IDRUN MODE. The values of parameters 97.02...97.20 are updated according to the motor characteristics identified during the motor ID run. This parameter cannot be changed while the drive is running. 	
	(0) NoUserPars	Parameters 97.02...97.20 inactive.
	(1) UserMotPars	The values of parameters 97.02...97.14 are used in the motor model.
	(2) UserPosOffs	The value of parameter 97.20 is used as the rotor angle offset. Parameters 97.02...97.14 are inactive.
	(3) AllUserPars	The values of parameters 97.02...97.14 are used in the motor model, and the value of parameter 97.20 is used as the rotor angle offset.
97.02	RS USER	FW block: None
	Defines the stator resistance R_S of the motor model.	
	0...0.5 p.u. (per unit)	Stator resistance.
97.03	RR USER	FW block: None
	<p>Defines the rotor resistance R_R of the motor model.</p> <p>Note: This parameter is valid only for asynchronous motors.</p>	
	0...0.5 p.u. (per unit)	Rotor resistance.
97.04	LM USER	FW block: None
	<p>Defines the main inductance L_M of the motor model.</p> <p>Note: This parameter is valid only for asynchronous motors.</p>	
	0...10 p.u. (per unit)	Main inductance.
97.05	SIGMAL USER	FW block: None
	<p>Defines the leakage inductance σL_S.</p> <p>Note: This parameter is valid only for asynchronous motors.</p>	
	0...1 p.u. (per unit)	Leakage inductance.
97.06	LD USER	FW block: None
	<p>Defines the direct axis (synchronous) inductance.</p> <p>Note: This parameter is valid only for permanent magnet motors.</p>	
	0...10 p.u. (per unit)	Direct axis (synchronous) inductance.

97.07	LQ USER	FW block: None
	Defines the quadrature axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors.	
	0...10 p.u. (per unit)	Quadrature axis (synchronous) inductance.
97.08	PM FLUX USER	FW block: None
	Defines the permanent magnet flux. Note: This parameter is valid only for permanent magnet motors.	
	0...2 p.u. (per unit)	Permanent magnet flux.
97.09	RS USER SI	FW block: None
	Defines the stator resistance R_S of the motor model.	
	0.00000...100.00000 ohm	Stator resistance.
97.10	RR USER SI	FW block: None
	Defines the rotor resistance R_R of the motor model. Note: This parameter is valid only for asynchronous motors.	
	0.00000...100.00000 ohm	Rotor resistance.
97.11	LM USER SI	FW block: None
	Defines the main inductance L_M of the motor model. Note: This parameter is valid only for asynchronous motors.	
	0.00...100000.00 mH	Main inductance.
97.12	SIGL USER SI	FW block: None
	Defines the leakage inductance σL_S . Note: This parameter is valid only for asynchronous motors.	
	0.00...100000.00 mH	Leakage inductance.
97.13	LD USER SI	FW block: None
	Defines the direct axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors.	
	0.00...100000.00 mH	Direct axis (synchronous) inductance.
97.14	LQ USER SI	FW block: None
	Defines the quadrature axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors.	
	0.00...100000.00 mH	Quadrature axis (synchronous) inductance.

97.18	SIGNAL INJECTION	FW block: None
	<p>Enables signal injection. A high frequency alternating signal is injected to the motor at the low speed region to improve the stability of torque control. Signal injection can be enabled with different amplitude levels.</p> <p>Note: Use as low a level as possible that gives satisfactory performance. Signal injection cannot be applied to asynchronous motors.</p>	
	(0) Disabled	Signal injection is disabled.
	(1) Enabled5%	Signal injection is enabled with an amplitude level of 5%.
	(2) Enabled10%	Signal injection is enabled with an amplitude level of 10%.
	(3) Enabled15%	Signal injection is enabled with an amplitude level of 15%.
	(4) Enabled20%	Signal injection is enabled with an amplitude level of 20%.
97.20	POS OFFSET USER	FW block: None
	<p>Defines an angle offset between the zero position of the synchronous motor and the zero position of the position sensor.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The value is in electrical degrees. The electrical angle equals the mechanical angle multiplied by the number of motor pole pairs. • This parameter is valid only for permanent magnet motors. 	
	0...360°	Angle offset.

Group 98 MOTOR CALC VALUES

Calculated motor values.

98.01	TORQ NOM SCALE	FW block: None
	Nominal torque in N•m which corresponds to 100%. Note: This parameter is copied from parameter 99.12 MOT NOM TORQUE if given. Otherwise the value is calculated.	
	0...2147483 Nm	Nominal torque.
98.02	POLEPAIRS	FW block: None
	Calculated number of motor pole pairs. Note: This parameter cannot be set by the user.	
	0...1000	Calculated number of motor pole pairs.

Group 99 START-UP DATA

Start-up settings such as language, motor data and motor control mode.

The nominal motor values must be set before the drive is started; for detailed instructions, see chapter [Start-up](#) on page 17.


With DTC motor control mode, parameters 99.06...99.10 must be set; better control accuracy is achieved by also setting parameters 99.11 and 99.12.


With scalar control, parameters 99.06...99.09 must be set.


99.01	LANGUAGE	FW block: None
	Selects the language. Note: Not all languages listed below are necessarily supported.	
	(0809h) ENGLISH	English.
	(0407h) DEUTSCH	German.
	(0410h) ITALIANO	Italian.
	(040Ah) ESPAÑOL	Spanish.
	(041Dh) SVENSKA	Swedish.
	(041Fh) TÜRKÇE	Turkish.
99.04	MOTOR TYPE	FW block: None
	Selects the motor type. Note: This parameter cannot be changed while the drive is running.	
	(0) AM	Asynchronous motor. Three phase AC voltage supplied induction motor with squirrel cage rotor.
	(1) PMSM	Permanent magnet motor. Three phase AC voltage supplied synchronous motor with permanent magnet rotor and sinusoidal BackEMF voltage.

99.05	MOTOR CTRL MODE	FW block: None
	<p>Selects the motor control mode.</p> <p>DTC (Direct torque control) mode is suitable for most applications.</p> <p>Scalar control is suitable for special cases where DTC cannot be applied. In Scalar Control, the drive is controlled with a frequency reference. The outstanding motor control accuracy of DTC cannot be achieved in scalar control. There are some standard features that are disabled in the scalar control mode, for example motor identification run (99.13), torque limits in parameter group 20, DC hold and DC magnetising (11.04...11.06, 11.01).</p> <p>Note: Correct motor run requires that the magnetising current of the motor does not exceed 90 percent of the nominal current of the inverter.</p> <p>Note: Scalar control mode must be used</p> <ul style="list-style-type: none"> • with multimotor applications 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification, • if the nominal current of the motor is less than 1/6 of the nominal output current of the drive, or • if the drive is used with no motor connected (eg, for test purposes). 	
	(0) DTC	Direct torque control mode.
	(1) Scalar	Scalar control mode.
99.06	MOT NOM CURRENT	FW block: None
	<p>Defines the nominal motor current. Must be equal to the value on the motor rating plate. If several motors are connected to the inverter, enter the total current of the motors.</p> <p>Note: Correct motor run requires that the magnetising current of the motor does not exceed 90 percent of the nominal current of the inverter.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	0...32767 A	<p>Nominal motor current.</p> <p>Note: The allowed range is $1/6...2 \times I_{2N}$ of drive for direct control mode (parameter 99.05 MOTOR CTRL MODE = (0) DTC). For scalar control mode (parameter 99.05 MOTOR CTRL MODE = (1) Scalar), the allowed range is $0...2 \times I_{2N}$ of drive.</p>
99.07	MOT NOM VOLTAGE	FW block: None
	<p>Defines the nominal motor voltage. Nominal voltage is a fundamental phase to phase rms voltage, which is supplied to the motor at the nominal operating point. This parameter value must be equal to the value on the asynchronous motor name plate.</p> <p>Note: Make sure the motor is connected correctly (star or delta) in accordance to the rating plate.</p> <p>Note: With permanent magnet motors, the nominal voltage is the BackEMF voltage (at motor nominal speed). If the voltage is given as voltage per rpm, eg, 60 V per 1000 rpm, the voltage for 3000 rpm nominal speed is $3 \times 60 \text{ V} = 180 \text{ V}$. Note that the nominal voltage is not equal to the equivalent DC motor voltage (E.D.C.M.) value given by some motor manufactures. The nominal voltage can be calculated by dividing the E.D.C.M. voltage by 1.7 (= square root of 3).</p> <p>Note: The stress on the motor insulations is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than the rating of the drive and the supply of the drive.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	
	0...32767 V	<p>Nominal motor voltage.</p> <p>Note: The allowed range is $1/6...2 \times U_N$ of drive.</p>

99.08	MOT NOM FREQ	FW block: None
	Defines the nominal motor frequency. Note: This parameter cannot be changed while the drive is running.	
	5...500 Hz	Nominal motor frequency.
99.09	MOT NOM SPEED	FW block: None
	Defines the nominal motor speed. Must be equal to the value on the motor rating plate. When parameter value is changed, check the speed limits in parameter group 20 . Note: This parameter cannot be changed while the drive is running. Note: For safety reasons, after motor ID run, the maximum and minimum speed limits (parameters 20.01 and 20.02) are automatically set to a 1.2 times bigger value than the nominal motor speed.	
	0...30000 rpm	Nominal motor speed.
99.10	MOT NOM POWER	FW block: None
	Defines the nominal motor power. Must be equal to the value on the motor rating plate. If several motors are connected to the inverter, enter the total power of the motors. Set also parameter 99.11 MOT NOM COSFII . Note: This parameter cannot be changed while the drive is running.	
	0...10000 kW	Nominal motor power.
99.11	MOT NOM COSFII	FW block: None
	Defines the cosphi (not applicable to permanent magnet motors) for a more accurate motor model. Not obligatory; if set, should be equal to the value on the motor rating plate. Note: This parameter cannot be changed while the drive is running.	
	0...1	Cosphi (0 = parameter disabled).
99.12	MOT NOM TORQUE	FW block: None
	Defines the nominal motor shaft torque for a more accurate motor model. Not obligatory. Note: This parameter cannot be changed while the drive is running.	
	0...2147483 Nm	Nominal motor shaft torque.

99.13	IDRUN MODE	FW block: None
	<p>Selects the type of the motor identification performed at the next start of the drive in DTC mode. During the identification, the drive will identify the characteristics of the motor for optimum motor control. After the motor ID run, the drive is stopped. Note: This parameter cannot be changed while the drive is running.</p> <p>Once the motor ID run is activated, it can be cancelled by stopping the drive: If motor ID run has already been performed once, parameter is automatically set to (0) No. If no motor ID run has been performed yet, parameter is automatically set to (3) Standstill. In this case, the motor ID run must be performed.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Motor ID run can only be performed in local control (ie, when drive is controlled via PC tool or control panel). • Motor ID run cannot be performed if parameter 99.05 MOTOR CTRL MODE is set to (1) Scalar. • Motor ID run must be performed every time any of the motor parameters (99.04, 99.06...99.12) have been changed. Parameter is automatically set to STANDSTILL after the motor parameters have been set. • With permanent magnet motor, the motor shaft must NOT be locked and the load torque must be < 10% during the motor ID run (Normal/Reduced/Standstill). • Mechanical brake (if present) is not opened during the motor ID run. • Ensure that possible Safe Torque Off and emergency stop circuits are closed during motor ID run. 	
	(0) No	<p>No motor ID run is requested. This mode can be selected only if the motor ID run (Normal/Reduced/Standstill) has already been performed once.</p>
	(1) Normal	<p>Guarantees the best possible control accuracy. The motor ID run takes about 90 seconds. This mode should be selected whenever it is possible.</p> <p>Note: The driven machinery must be de-coupled from the motor with Normal ID run:</p> <ul style="list-style-type: none"> • if the load torque is higher than 20%. • if the machinery is not able to withstand the nominal torque transient during the motor ID run. <p>Note: Check the direction of rotation of the motor before starting the motor ID run. During the run, the motor will rotate in the forward direction.</p> <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the motor ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE MOTOR ID RUN!</p>

	(2) Reduced	<p>Reduced ID run. This mode should be selected instead of the Normal ID run</p> <ul style="list-style-type: none"> • if mechanical losses are higher than 20% (ie, the motor cannot be de-coupled from the driven equipment), or • if flux reduction is not allowed while the motor is running (ie, in case of a motor with an integrated brake supplied from the motor terminals), or • if large speed vibrations are detected during the Normal ID run. <p>With Reduced ID run, the control in the field weakening area or at high torques is not necessarily as accurate as with the Normal ID run. Reduced ID run is completed faster than the Normal ID run (< 90 seconds).</p> <p>Note: Check the direction of rotation of the motor before starting the motor ID run. During the run, the motor will rotate in the forward direction.</p> <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the motor ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE MOTOR ID RUN!</p>
	(3) Standstill	<p>Standstill ID run. The motor is injected with DC current. With asynchronous motor, the motor shaft is not rotating (with permanent magnet motor the shaft can rotate < 0.5 revolution).</p> <p>Note: This mode should be selected only if the Normal or Reduced ID run is not possible due to the restrictions caused by the connected mechanics (eg, with lift or crane applications).</p>
	(4) Autophasing	<p>During autophasing, the start angle of the motor is determined. Note that other motor model values are not updated. See also parameter 11.07 AUTOPHASING MODE, and section Autophasing on page 44.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Autophasing can only be selected after the Normal/Reduced/Standstill ID run has been performed once. Autophasing is used when an absolute encoder, a resolver or an encoder with commutation signals has been added/changed to a permanent magnet motor and there is no need to perform the Normal/Reduced/Standstill ID run again. • During Autophasing the motor shaft must NOT be locked and the load torque must be < 5%.
	(5) Cur meas cal	<p>Current offset and gain measurement calibration. The calibration will be performed at next start.</p>

	<p>(6) Advanced</p>	<p>Advanced ID run. Guarantees the best possible control accuracy. The motor ID run can take a couple of minutes. This mode should be selected when top performance is needed in the whole operating area.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The driven machinery must be de-coupled from the motor because of high torque and speed transients that are applied. • During the run, the motor may rotate both in the forward and reverse direction. <p> WARNING! The motor may run at up to the maximum (positive) and minimum (negative) allowed speed during the motor ID run. Several accelerations and decelerations are done. The maximum torque, current and speed allowed by the limit parameters may be utilized. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE MOTOR ID RUN!</p>
	<p>(7) Adv standstill</p>	<p>Advanced standstill ID run. This mode is recommended with asynchronous motors up to 75 kW instead of the Standstill ID run if:</p> <ul style="list-style-type: none"> • the actual nominal ratings of the motor is not known • the control performance of the motor is not satisfactory after a Standstill ID run. <p>Note: The performance of this mode depends on the motor size. With small motors, the ID run completes in 5 minutes. With bigger motors, the ID run takes up to 60 minutes.</p>
<p>99.16</p>	<p>PHASE INVERSION</p>	<p>FW block: None</p>
	<p>Switches the rotation direction of the motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical.</p> <p>Note: After changing this parameter, the sign of encoder feedback (if any) must be checked. This can be done by comparing the sign of parameter 1.14 SPEED ESTIMATED to that of 1.08 ENCODER 1 SPEED (or 1.10 ENCODER 2 SPEED). If the signs are in conflict, the encoder wiring must be corrected.</p>	
	<p>(0) No</p>	<p>Normal.</p>
	<p>(1) Yes</p>	<p>Reversed rotation direction.</p>

Parameter data

What this chapter contains

This chapter lists the parameters of the drive with some additional data. For the parameter descriptions, see chapter [Parameters and firmware blocks](#).

Terms

Term	Definition
Actual signal	Signal measured or calculated by the drive. Can be monitored by the user. No user setting is possible.
Def	Default value
enum	Enumerated list, ie, selection list
FbEq	Fieldbus equivalent: The scaling between the value shown on the panel and the integer used in serial communication.
Page no.	Page number for more information
INT32	32-bit integer value (31 bits + sign)
Bit pointer	Bit pointer. A bit pointer points to a single bit in the value of another parameter.
Val pointer	Value pointer. A value pointer points to the value of another parameter.
Parameter	An operation instruction of the drive that is often user-adjustable. Parameters that are signals measured or calculated by the drive are called actual signals.
Pb	Packed boolean
PT	Parameter protection type. See WP, WPD and WP0.
REAL	$\underbrace{\quad}_{16\text{-bit value}} \underbrace{\quad}_{16\text{-bit value}} (31 \text{ bits} + \text{sign})$ = integer value = fractional value
REAL24	$\underbrace{\quad}_{8\text{-bit value}} \underbrace{\quad}_{24\text{-bit value}} (31 \text{ bits} + \text{sign})$ = integer value = fractional value
Save PF	Parameter setting is protected against power failure.
Type	Data type. See enum, INT32, Bit pointer, Val pointer, Pb, REAL, REAL24, UINT32.
UINT32	32-bit unsigned integer value
WP	Write protected parameter (ie, read only)
WPD	Write protected parameter while drive is running
WP0	Parameter can only be set to zero.

Fieldbus equivalent

Serial communication data between fieldbus adapter and drive is transferred in integer format. Thus the drive actual and reference signal values must be scaled to 16/32-bit integer values. Fieldbus equivalent defines the scaling between the signal value and the integer used in serial communication.

All the read and sent values are limited to 16/32 bits.

Example: If [32.04 MAXIMUM TORQ REF](#) is set from external control system, an integer value of 10 corresponds to 1%.

Pointer parameter format in fieldbus communication

Value and bit pointer parameters are transferred between the fieldbus adapter and drive as 32-bit integer values.

32-bit integer value pointers

When a value pointer parameter is connected to the value of another parameter, the format is as follows:

	Bit			
	30...31	16...29	8...15	0...7
Name	Source type	Not in use	Group	Index
Value	1	-	1...255	1...255
Description	Value pointer is connected to parameter/signal.	-	Group of source parameter	Index of source parameter

For example, the value that should be written into parameter [33.02 SUPERV1 ACT](#) to change its value to [1.07 DC-VOLTAGE](#) is
 0100 0000 0000 0000 0000 0001 0000 0111 = 1073742087 (32-bit integer).

When a value pointer parameter is connected to an application program, the format is as follows:

	Bit		
	30...31	24...29	0...23
Name	Source type	Not in use	Address
Value	2	-	0 ... 2 ²⁴ -1
Description	Value pointer is connected to application program.	-	Relative address of application program variable

Note: Value pointer parameters which are connected to an application program cannot be set via fieldbus (ie, read access only).

32-bit integer bit pointers

When a bit pointer parameter is connected to value 0 or 1, the format is as follows:

	Bit			
	30...31	16...29	1...15	0
Name	Source type	Not in use	Not in use	Value
Value	0	-	-	0...1
Description	Bit pointer is connected to 0/1.	-	-	0 = False, 1 = True

When a bit pointer is connected to a bit value of another parameter, the format is as follows:

	Bit				
	30...31	24...29	16...23	8...15	0...7
Name	Source type	Not in use	Bit sel	Group	Index
Value	1	-	0...31	2...255	1...255
Description	Bit pointer is connected to signal bit value.	-	Bit selection	Group of source parameter	Index of source parameter

When a bit pointer parameter is connected to an application program, the format is as follows:

	Bit		
	30...31	24...29	0...23
Name	Source type	Bit sel	Address
Value	2	0...31	0 ... $2^{24}-1$
Description	Bit pointer is connected to application program.	Bit selection	Relative address of application program variable

Note: Bit pointer parameters which are connected to an application program cannot be set via fieldbus (ie, read access only).

Actual signals (Parameter groups 1...9)

Index	Name	Type	Range	Unit	FbEq	Update time	Data length	PT	Save PF	Page no.
01	ACTUAL VALUES									
1.01	SPEED ACT	REAL	-30000...30000	rpm	1 = 100	250 µs	32	WP		93
1.02	SPEED ACT PERC	REAL	-1000...1000	%	1 = 100	2 ms	32	WP		93
1.03	FREQUENCY	REAL	-30000...30000	Hz	1 = 100	2 ms	32	WP		93
1.04	CURRENT	REAL	0...30000	A	1 = 100	10 ms	32	WP		93
1.05	CURRENT PERC	REAL	0...1000	%	1 = 10	2 ms	16	WP		93
1.06	TORQUE	REAL	-1600...1600	%	1 = 10	2 ms	16	WP		93
1.07	DC-VOLTAGE	REAL	-	V	1 = 100	2 ms	32	WP		93
1.08	ENCODER 1 SPEED	REAL	-	rpm	1 = 100	250 µs	32	WP		93
1.09	ENCODER 1 POS	REAL24	-	rev	1=100000000	250 µs	32	WP		93
1.10	ENCODER 2 SPEED	REAL	-	rpm	1 = 100	250 µs	32	WP		94
1.11	ENCODER 2 POS	REAL24	-	rev	1=100000000	250 µs	32	WP		94
1.12	POS ACT	REAL	-32768...32767	*	See 60.09	250 µs	32	WP		94
1.13	POS 2ND ENC	REAL	-32768...32767	revs	1 = 1	250 µs	32	WP		94
1.14	SPEED ESTIMATED	REAL	-30000...30000	rpm	1 = 100	2 ms	32	WP		94
1.15	TEMP INVERTER	REAL24	-40...160	°C	1 = 10	2 ms	16	WP		94
1.16	TEMP BC	REAL24	-40...160	°C	1 = 10	2 ms	16	WP		94
1.17	MOTOR TEMP	REAL	-10...250	°C	1 = 10	10 ms	16	WP		94
1.18	MOTOR TEMP EST	INT32	-60...1000	°C	1 = 1	10 ms	16	WP	x	94
1.19	USED SUPPLY VOLT	REAL	0...1000	V	1 = 10	10 ms	16	WP		94
1.20	BRAKE RES LOAD	REAL24	0...1000	%	1 = 1	50 ms	16	WP		94
1.21	CPU USAGE	UINT32	0...100	%	1 = 1	100 ms	16	WP		94
1.22	INVERTER POWER	REAL	$-2^{31}...2^{31} - 1$	kW	1 = 100	10 ms	32	WP		94
1.26	ON TIME COUNTER	INT32	0...35791394.1	h	1 = 100	10 ms	32	WP0	x	94
1.27	RUN TIME COUNTER	INT32	0...35791394.1	h	1 = 100	10 ms	32	WP0	x	95
1.28	FAN ON-TIME	INT32	0...35791394.1	h	1 = 100	10 ms	32	WP0	x	95
1.31	MECH TIME CONST	REAL	0...32767	s	1 = 1000	10 ms	32	WP	x	95
1.38	TEMP INT BOARD	REAL24	-40...160	°C	1 = 10	2 ms	16	WP		95
1.39	OUTPUT VOLTAGE	REAL	0...1000	V	1 = 1	10 ms	16	WP		95
1.42	FAN START COUNT	INT32	0...2147483647	-	1 = 1	10 ms	32	WP	x	95
02	I/O VALUES									
2.01	DI STATUS	Pb	0...0x3F	-	1 = 1	2 ms	16	WP		96
2.02	RO STATUS	Pb	-	-	1 = 1	2 ms	16	WP		96
2.03	DIO STATUS	Pb	-	-	1 = 1	2 ms	16	WP		96
2.04	AI1	REAL	-	V or mA	1 = 1000	2 ms	16	WP		96
2.05	AI1 SCALED	REAL	-	-	1 = 1000	250 µs	32	WP		96
2.06	AI2	REAL	-	V or mA	1 = 1000	2 ms	16	WP		96
2.07	AI2 SCALED	REAL	-	-	1 = 1000	250 µs	32	WP		96
2.08	AO1	REAL	-	mA	1 = 1000	2 ms	16	WP		96
2.09	AO2	REAL	-	V	1 = 1000	2 ms	16	WP		96
2.10	DIO2 FREQ IN	REAL	-32768...32768	-	1 = 1000	2 ms	32	WP		96
2.11	DIO3 FREQ OUT	REAL	-32768...32768	Hz	1 = 1000	2 ms	32	WP		96

Index	Name	Type	Range	Unit	FbEq	Update time	Data length	PT	Save PF	Page no.
2.12	FBA MAIN CW	Pb	0 ... 0xFFFFFFFF	-	1 = 1	500 µs	32	WP		97
2.13	FBA MAIN SW	Pb	0 ... 0xFFFFFFFF	-	1 = 1	500 µs	32	WP		100
2.14	FBA MAIN REF1	INT32	$-2^{31} \dots 2^{31} - 1$	-	1 = 1	500 µs	32	WP		101
2.15	FBA MAIN REF2	INT32	$-2^{31} \dots 2^{31} - 1$	-	1 = 1	500 µs	32	WP		101
2.16	FEN DI STATUS	Pb	0...0x33	-	1 = 1	500 µs	16	WP		101
2.17	D2D MAIN CW	Pb	0...0xFFFF	-	1 = 1	500 µs	16	WP		102
2.18	D2D FOLLOWER CW	Pb	0...0xFFFF	-	1 = 1	2 ms	16	WP		102
2.19	D2D REF1	REAL	$-2^{31} \dots 2^{31} - 1$	-	1 = 1	500 µs	32	WP		102
2.20	D2D REF2	REAL	$-2^{31} \dots 2^{31} - 1$	-	1 = 1	2 ms	32	WP		102
03	CONTROL VALUES									
3.01	SPEED REF1	REAL	-30000...30000	rpm	1 = 100	500 µs	32	WP		103
3.02	SPEED REF2	REAL	-30000...30000	rpm	1 = 100	500 µs	32	WP		103
3.03	SPEEDREF RAMP IN	REAL	-30000...30000	rpm	1 = 100	500 µs	32	WP		103
3.04	SPEEDREF RAMPED	REAL	-30000...30000	rpm	1 = 100	500 µs	32	WP		103
3.05	SPEEDREF USED	REAL	-30000...30000	rpm	1 = 100	250 µs	32	WP		103
3.06	SPEED ERROR FILT	REAL	-30000...30000	rpm	1 = 100	250 µs	32	WP		103
3.07	ACC COMP TORQ	REAL	-1600...1600	%	1 = 10	250 µs	16	WP		103
3.08	TORQ REF SP CTRL	REAL	-1600...1600	%	1 = 10	250 µs	16	WP		103
3.09	TORQ REF1	REAL	-1000...1000	%	1 = 10	500 µs	16	WP		103
3.10	TORQ REF RAMPED	REAL	-1000...1000	%	1 = 10	500 µs	16	WP		103
3.11	TORQ REF RUSHLIM	REAL	-1000...1000	%	1 = 10	250 µs	16	WP		103
3.12	TORQUE REF ADD	REAL	-1000...1000	%	1 = 10	250 µs	16	WP		103
3.13	TORQ REF TO TC	REAL	-1600...1600	%	1 = 10	250 µs	16	WP		103
3.14	BRAKE TORQ MEM	REAL	-1000...1000	%	1 = 10	2 ms	16	WP	x	103
3.15	BRAKE COMMAND	enum	0...1	-	1 = 1	2 ms	16	WP		104
3.16	FLUX REF USED	REAL24	0...200	%	1 = 1	2 ms	16	WP		104
3.17	TORQUE REF USED	REAL	-1600...1600	%	1 = 10	250 µs	32	WP		104
3.20	MAX SPEED REF	REAL	0...30000	rpm	1 = 100	2 ms	16	WP		104
3.21	MIN SPEED REF	REAL	-30000...0	rpm	1 = 100	2 ms	16	WP		104
4	POS CTRL VALUES									
4.01	SPEED REF POS	REAL	-32768...32768	rpm	1 = 100	250 µs	32	WP		105
4.02	SPEED ACT LOAD	REAL	-32768...32768	**	See 60.10	500 µs	32	WP		105
4.03	PROBE1 POS MEAS	REAL	-32768...32768	*	See 60.09	2 ms	32	WP		105
4.04	PROBE2 POS MEAS	REAL	-32768...32768	*	See 60.09	2 ms	32	WP		105
4.05	CYCLIC POS ERR	REAL	-32768...32768	*	See 60.09	2 ms	32	WP		105
4.06	POS REF	REAL	-32768...32768	*	See 60.09	500 µs	32	WP		105
4.07	PROF SPEED	REAL	-32768...32768	**	See 60.10	500 µs	32	WP		105
4.08	PROF ACC	REAL	0...32768	**	See 60.10	500 µs	32	WP		105
4.09	PROF DEC	REAL	-32768...0	**	See 60.10	500 µs	32	WP		105
4.10	PROF FILT TIME	REAL	0...1000	ms	1 = 1	500 µs	16	WP		105
4.11	POS STYLE	Pb	0...0x1FF	-	1 = 1	500 µs	16	WP		105
4.12	POS END SPEED	REAL	0...32768	**	See 60.10	500 µs	32	WP		106
4.13	POS REF IPO	REAL	-32768...32768	*	See 60.09	500 µs	32	WP		106

Index	Name	Type	Range	Unit	FbEq	Update time	Data length	PT	Save PF	Page no.
4.14	DIST TGT	REAL	-32768...32768	*	See 60.09	500 µs	32	WP		106
4.15	SYNC REF UNGEAR	REAL	-32768...32768	*	See 60.09	500 µs	32	WP		106
4.16	SYNC REF GEARED	REAL	-32768...32768	*	See 60.09	500 µs	32	WP		106
4.17	POS REF LIMITED	REAL	-32768...32768	*	See 60.09	250 µs	32	WP		106
4.18	SYNC ERROR	REAL	-32768...32768	*	See 60.09	250 µs	32	WP		106
4.19	POS ERROR	REAL	-32768...32768	*	See 60.09	250 µs	32	WP		106
4.20	SPEED FEED FWD	REAL	-32768...32768	rpm	1 = 100	250 µs	32	WP		106
4.21	SYNC REF IN	REAL	-32768...32768	*	See 60.09	500 µs	32	WP		106
06	DRIVE STATUS									
6.01	STATUS WORD 1	Pb	0...65535	-	1 = 1	2 ms	16	WP		107
6.02	STATUS WORD 2	Pb	0...65535	-	1 = 1	2 ms	16	WP		108
6.03	SPEED CTRL STAT	Pb	0...31	-	1 = 1	250 µs	16	WP		109
6.05	LIMIT WORD 1	Pb	0...255	-	1 = 1	250 µs	16	WP		109
6.07	TORQ LIM STATUS	Pb	0...65535	-	1 = 1	250 µs	16	WP		110
6.09	POS CTRL STATUS	Pb	0...65535	-	1 = 1	2 ms	16	WP		111
6.10	POS CTRL STATUS2	Pb	0...65535	-	1 = 1	2 ms	16	WP		112
6.11	POS CORR STATUS	Pb	0...65535	-	1 = 1	2 ms	16	WP		113
6.12	OP MODE ACK	enum	0...11	-	1 = 1	2 ms	16	WP		114
6.14	SUPERV STATUS	Pb	0...65535	-	1 = 1	2 ms	16	WP		114
6.17	BIT INVERTER SW	Pb	0b000000... 0b111111	-	1 = 1	2 ms	16	WP		114
08	ALARMS & FAULTS									
8.01	ACTIVE FAULT	enum	0...65535	-	1 = 1	-	16	WP		115
8.02	LAST FAULT	enum	0...65535	-	1 = 1	-	16	WP		115
8.03	FAULT TIME HI	INT32	-2 ³¹ ...2 ³¹ - 1	days	1 = 1	-	32	WP		115
8.04	FAULT TIME LO	INT32	-2 ³¹ ...2 ³¹ - 1	time	1 = 1	-	32	WP		115
8.05	ALARM LOGGER 1	UINT32	-	-	1 = 1	2 ms	16	WP0		115
8.06	ALARM LOGGER 2	UINT32	-	-	1 = 1	2 ms	16	WP0		116
8.07	ALARM LOGGER 3	UINT32	-	-	1 = 1	2 ms	16	WP0		116
8.08	ALARM LOGGER 4	UINT32	-	-	1 = 1	2 ms	16	WP0		117
8.09	ALARM LOGGER 5	UINT32	-	-	1 = 1	2 ms	16	WP0		117
8.10	ALARM LOGGER 6	UINT32	-	-	1 = 1	2 ms	16	WP0		117
8.15	ALARM WORD 1	UINT32	-	-	1 = 1	2 ms	16	WP0		118
8.16	ALARM WORD 2	UINT32	-	-	1 = 1	2 ms	16	WP0		118
8.17	ALARM WORD 3	UINT32	-	-	1 = 1	2 ms	16	WP0		119
8.18	ALARM WORD 4	UINT32	-	-	1 = 1	2 ms	16	WP0		119
09	SYSTEM INFO									
9.01	DRIVE TYPE	INT32	0...65535	-	1 = 1	-	16	WP		120
9.02	DRIVE RATING ID	INT32	0...65535	-	1 = 1	-	16	WP		120
9.03	FIRMWARE ID	Pb	-	-	1 = 1	-	16	WP		120
9.04	FIRMWARE VER	Pb	-	-	1 = 1	-	16	WP		120
9.05	FIRMWARE PATCH	Pb	-	-	1 = 1	-	16	WP		120
9.10	INT LOGIC VER	Pb	-	-	1 = 1	-	32	WP		120
9.11	SLOT 1 VIE NAME	INT32	0x0000...0xFFFF	-	1 = 1	-	16	WP		120

Index	Name	Type	Range	Unit	FbEq	Update time	Data length	PT	Save PF	Page no.
9.12	SLOT 1 VIE VER	INT32	0x0000...0xFFFF	-	1 = 1	-	16	WP		120
9.13	SLOT 2 VIE NAME	INT32	0x0000...0xFFFF	-	1 = 1	-	16	WP		120
9.14	SLOT 2 VIE VER	INT32	0x0000...0xFFFF	-	1 = 1	-	16	WP		120
9.20	OPTION SLOT 1	INT32	0...18	-	1 = 1	-	16	WP		121
9.21	OPTION SLOT 2	INT32	0...18	-	1 = 1	-	16	WP		121
9.22	OPTION SLOT 3	INT32	0...18	-	1 = 1	-	16	WP		121

Parameter groups 10...99

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
10	START/STOP										
10.01	EXT1 START FUNC	enum	0...6	-	-	2 ms	16	1	WPD		123
10.02	EXT1 START IN1	Bit pointer		-		2 ms	32	P.02.01.00	WPD		124
10.03	EXT1 START IN2	Bit pointer		-		2 ms	32	C.False	WPD		124
10.04	EXT2 START FUNC	enum	0...6	-	-	2 ms	16	1	WPD		124
10.05	EXT2 START IN1	Bit pointer		-		2 ms	32	P.02.01.00	WPD		125
10.06	EXT2 START IN2	Bit pointer		-		2 ms	32	C.False	WPD		125
10.07	JOG1 START	Bit pointer		-		2 ms	32	C.False	WPD		125
10.08	FAULT RESET SEL	Bit pointer		-		2 ms	32	P.02.01.02			125
10.09	RUN ENABLE	Bit pointer		-		2 ms	32	C.True	WPD		125
10.10	EM STOP OFF3	Bit pointer		-		2 ms	32	C.True	WPD		125
10.11	EM STOP OFF1	Bit pointer		-		2 ms	32	C.True	WPD		126
10.12	START INHIBIT	enum	0...1	-	1 = 1	2 ms	16	0			126
10.13	FB CW USED	Val pointer		-		2 ms	32	P.02.12	WPD		126
10.14	JOG2 START	Bit pointer		-		2 ms	32	C.False	WPD		126
10.15	JOG ENABLE	Bit pointer		-		2 ms	32	C.False	WPD		126
10.16	D2D CW USED	Val pointer		-		2 ms	32	P.02.17	WPD		127
10.17	START ENABLE	Bit pointer		-		2 ms	32	C.True	WPD		127
11	START/STOP MODE										
11.01	START MODE	enum	0...2	-	1 = 1	-	16	1	WPD		128
11.02	DC MAGN TIME	UINT32	0...10000	ms	1 = 1	-	16	500	WPD		129
11.03	STOP MODE	enum	1...2	-	1 = 1	2 ms	16	2			129
11.04	DC HOLD SPEED	REAL	0...1000	rpm	1 = 10	2 ms	16	5			129
11.05	DC HOLD CUR REF	UINT32	0...100	%	1 = 1	2 ms	16	30			129
11.06	DC HOLD	Bit pointer	0...1	-	1 = 1	2 ms	16	0			130
11.07	AUTOPHASING MODE	enum	0...2	-	1 = 1	-	16	0			130
12	DIGITAL IO										
12.01	DIO1 CONF	enum	0...1	-	1 = 1	10 ms	16	0			131
12.02	DIO2 CONF	enum	0...2	-	1 = 1	10 ms	16	0			132
12.03	DIO3 CONF	enum	0...3	-	1 = 1	10 ms	16	0			132
12.04	DIO1 OUT PTR	Bit pointer		-		10 ms	32	P.06.02.02			132
12.05	DIO2 OUT PTR	Bit pointer		-		10 ms	32	P.06.02.03			132
12.06	DIO3 OUT PTR	Bit pointer		-		10 ms	32	P.06.01.10			132
12.07	DIO3 F OUT PTR	Val pointer		-		10 ms	32	P.01.01			132
12.08	DIO3 F MAX	REAL	3...32768	Hz	1 = 1	10 ms	16	1000			132
12.09	DIO3 F MIN	REAL	3...32768	Hz	1 = 1	10 ms	16	3			132
12.10	DIO3 F MAX SCALE	REAL	0...32768	-	1 = 1	10 ms	16	1500			133
12.11	DIO3 F MIN SCALE	REAL	0...32768	-	1 = 1	10 ms	16	0			133
12.12	RO1 OUT PTR	Bit pointer		-		10 ms	32	P.03.15.00			133
12.13	DI INVERT MASK	UINT32	0...63	-	1 = 1	10 ms	16	0			134
12.14	DIO2 F MAX	REAL	3...32768	Hz	1 = 1	10 ms	16	1000			134
12.15	DIO2 F MIN	REAL	3...32768	Hz	1 = 1	10 ms	16	3			134

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
12.16	DIO2 F MAX SCALE	REAL	-32768... 32768	-	1 = 1	10 ms	16	1500			134
12.17	DIO2 F MIN SCALE	REAL	-32768... 32768	-	1 = 1	10 ms	16	0			134
13	ANALOGUE INPUTS										
13.01	AI1 FILT TIME	REAL	0...30	s	1 = 1000	10 ms	16	0			135
13.02	AI1 MAX	REAL	-11...11/ -22...22	V or mA	1 = 1000	10 ms	16	10			135
13.03	AI1 MIN	REAL	-11...11/ -22...22	V or mA	1 = 1000	10 ms	16	-10			136
13.04	AI1 MAX SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	1500			136
13.05	AI1 MIN SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	-1500			136
13.06	AI2 FILT TIME	REAL	0...30	s	1 = 1000	10 ms	16	0			136
13.07	AI2 MAX	REAL	-11...11/ -22...22	V or mA	1 = 1000	10 ms	16	10			137
13.08	AI2 MIN	REAL	-11...11/ -22...22	V or mA	1 = 1000	10 ms	16	-10			137
13.09	AI2 MAX SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	100			137
13.10	AI2 MIN SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	-100			137
13.11	AITUNE	enum	0...4	-	1 = 1	10 ms	16	0			137
13.12	AI SUPERVISION	enum	0...3	-	1 = 1	2 ms	16	0			138
13.13	AI SUPERVIS ACT	UINT32	0000... 1111	-	1 = 1	2 ms	32	0			138
15	ANALOGUE OUTPUTS										
15.01	AO1 PTR	Val pointer		-		-	32	P.01.05			139
15.02	AO1 FILT TIME	REAL	0...30	s	1 = 1000	10 ms	16	0.1			139
15.03	AO1 MAX	REAL	0...22.7	mA	1 = 1000	10 ms	16	20			139
15.04	AO1 MIN	REAL	0...22.7	mA	1 = 1000	10 ms	16	4			140
15.05	AO1 MAX SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	100			140
15.06	AO1 MIN SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	0			140
15.07	AO2 PTR	Val pointer		-		-	32	P.01.02			140
15.08	AO2 FILT TIME	REAL	0...30	s	1 = 1000	10 ms	16	0.1			140
15.09	AO2 MAX	REAL	-10...10	V	1 = 1000	10 ms	16	10			141
15.10	AO2 MIN	REAL	-10...10	V	1 = 1000	10 ms	16	-10			141
15.11	AO2 MAX SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	100			141
15.12	AO2 MIN SCALE	REAL	-32768... 32767	-	1 = 1000	10 ms	32	-100			141
16	SYSTEM										
16.01	LOCAL LOCK	Bit pointer		-		2 ms	32	C.False			142
16.02	PARAMETER LOCK	enum	0...2	-	1 = 1	2 ms	16	1			142

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
16.03	PASS CODE	INT32	0...2 ³¹ -1	-	1 = 1	-	32	0			142
16.04	PARAM RESTORE	enum	0...2	-	1 = 1	-	16	0	WPD		142
16.07	PARAM SAVE	enum	0...1	-	1 = 1	-	16	0			142
16.09	USER SET SEL	enum	1...10	-	1 = 1	-	32	1	WPD		143
16.10	USER SET LOG	Pb	0...0x7FF	-	1 = 1	-	32	0	WP		143
16.11	USER IO SET LO	Bit pointer		-		-	32	C.False			144
16.12	USER IO SET HI	Bit pointer		-		-	32	C.False			144
16.13	TIME SOURCE PRIO	enum	0...8	-	1 = 1	-	16	0			144
16.20	DRIVE BOOT	enum	0...1	-	1 = 1	-	32	0	WPD		144
17	PANEL DISPLAY										
17.01	SIGNAL1 PARAM	INT32	00.00... 255.255	-	1 = 1	-	16	01.03			145
17.02	SIGNAL2 PARAM	INT32	00.00... 255.255	-	1 = 1	-	16	01.04			145
17.03	SIGNAL3 PARAM	INT32	00.00... 255.255	-	1 = 1	-	16	01.06			145
17.04	SIGNAL1 MODE	INT32	-1...3	-	1 = 1	-	16	0			145
17.05	SIGNAL2 MODE	INT32	1...3	-	1 = 1	-	16	0			145
17.06	SIGNAL3 MODE	INT32	1...3	-	1 = 1	-	16	0			146
20	LIMITS										
20.01	MAXIMUM SPEED	REAL	0...30000	rpm	1 = 1	2 ms	32	1500			147
20.02	MINIMUM SPEED	REAL	-30000...0	rpm	1 = 1	2 ms	32	-1500			147
20.03	POS SPEED ENA	Bit pointer		-		2 ms	32	C.True			148
20.04	NEG SPEED ENA	Bit pointer		-		2 ms	32	C.True			148
20.05	MAXIMUM CURRENT	REAL	0...30000	A	1 = 100	10 ms	32	$\frac{2\sqrt{2}}{3} \times$ [99.06]			148
20.06	MAXIMUM TORQUE	REAL	0...1600	%	1 = 10	2 ms	16	300			148
20.07	MINIMUM TORQUE	REAL	-1600...0	%	1 = 10	2 ms	16	-300			148
20.08	THERM CURR LIM	enum	0...1	-	1 = 1	-	16	1			149
22	SPEED FEEDBACK										
22.01	SPEED FB SEL	enum	0...2	-	1 = 1	10 ms	16	0	WPD		151
22.02	SPEED ACT FTIME	REAL	0...10000	ms	1 = 1000	10 ms	32	3			151
22.03	MOTOR GEAR MUL	INT32	-2 ³¹ ...2 ³¹ -1	-	1 = 1	10 ms	32	1			152
22.04	MOTOR GEAR DIV	UINT32	1...2 ³¹ -1	-	1 = 1	10 ms	32	1			152
22.05	ZERO SPEED LIMIT	REAL	0...30000	rpm	1 = 100	2 ms	32	30			152
22.06	ZERO SPEED DELAY	UINT32	0...30000	ms	1 = 1	2 ms	16	0			153
22.07	ABOVE SPEED LIM	REAL	0...30000	rpm	1 = 1	2 ms	16	0			153
22.08	SPEED TRIPMARGIN	REAL	0...10000	rpm	1 = 10	2 ms	32	500			154
22.09	SPEED FB FAULT	enum	0...2	-	1 = 1	10 ms	16	0			154
22.10	SPD SUPERV EST	REAL	0...30000	rpm	1 = 1	250 μ s	32	450			155
22.11	SPD SUPERV ENC	REAL	0...30000	rpm	1 = 1	250 μ s	32	15			155
22.12	SPD SUPERV FILT	REAL	0...10000	ms	1 = 1	250 μ s	32	15			155
24	SPEED REF MOD										
24.01	SPEED REF1 SEL	enum	0...8	-	1 = 1	10 ms	16	1			157
24.02	SPEED REF2 SEL	enum	0...8	-	1 = 1	10 ms	16	0			158

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
24.03	SPEED REF1 IN	Val pointer		-		10 ms	32	P.03.01			158
24.04	SPEED REF2 IN	Val pointer		-		10 ms	32	P.03.02			158
24.05	SPEED REF 1/2SEL	Bit pointer		-		2 ms	32	C.False			158
24.06	SPEED SHARE	REAL	-8...8	-	1 = 1000	2 ms	16	1			158
24.07	SPEEDREF NEG ENA	Bit pointer		-		2 ms	32	C.False			159
24.08	CONST SPEED	REAL	-30000.... 30000	rpm	1 = 1	2 ms	16	0			159
24.09	CONST SPEED ENA	Bit pointer		-		2 ms	32	C.False			159
24.10	SPEED REF JOG1	REAL	-30000.... 30000	rpm	1 = 1	2 ms	16	0			159
24.11	SPEED REF JOG2	REAL	-30000.... 30000	rpm	1 = 1	2 ms	16	0			159
24.12	SPEED REFMIN ABS	REAL	0...30000	rpm	1 = 1	2 ms	16	0			159
25	SPEED REF RAMP										
25.01	SPEED RAMP IN	Val pointer		-		10 ms	32	P.03.03	WP		161
25.02	SPEED SCALING	REAL	0...30000	rpm	1 = 1	10 ms	16	1500			161
25.03	ACC TIME	REAL	0...1800	s	1 = 1000	10 ms	32	1			161
25.04	DEC TIME	REAL	0...1800	s	1 = 1000	10 ms	32	1			162
25.05	SHAPE TIME ACC1	REAL	0...1000	s	1 = 1000	10 ms	32	0			162
25.06	SHAPE TIME ACC2	REAL	0...1000	s	1 = 1000	10 ms	32	0			162
25.07	SHAPE TIME DEC1	REAL	0...1000	s	1 = 1000	10 ms	32	0			162
25.08	SHAPE TIME DEC2	REAL	0...1000	s	1 = 1000	10 ms	32	0			163
25.09	ACC TIME JOGGING	REAL	0...1800	s	1 = 1000	10 ms	32	0			163
25.10	DEC TIME JOGGING	REAL	0...1800	s	1 = 1000	10 ms	32	0			163
25.11	EM STOP TIME	REAL	0...1800	s	1 = 1000	10 ms	32	1			163
25.12	SPEEDREF BAL	REAL	-30000... 30000	rpm	1 = 1000	2 ms	32	0			163
25.13	SPEEDREF BAL ENA	Bit pointer		-		2 ms	32	C.False			163
26	SPEED ERROR										
26.01	SPEED ACT NCTRL	Val pointer		-		2 ms	32	P.01.01	WP		165
26.02	SPEED REF NCTRL	Val pointer		-		2 ms	32	P.03.04	WP		165
26.03	SPEED REF PCTRL	Val pointer		-		2 ms	32	P.04.01			165
26.04	SPEED FEED PCTRL	Val pointer		-		2 ms	32	P.04.20			165
26.05	SPEED STEP	REAL	-30000... 30000	rpm	1 = 100	2 ms	32	0			166
26.06	SPD ERR FTIME	REAL	0...1000	ms	1 = 10	2 ms	16	0			166
26.07	SPEED WINDOW	REAL	0...30000	rpm	1 = 1	250 µs	16	100			166
26.08	ACC COMP DERTIME	REAL	0...600	s	1 = 100	2 ms	32	0			167
26.09	ACC COMP FTIME	REAL	0...1000	ms	1 = 10	2 ms	16	8			167
26.10	SPEED WIN FUNC	UINT32	0...2	-	1 = 1	250 µs	16	0			167
26.11	SPEED WIN HI	REAL	0...3000	rpm	1 = 1	250 µs	16	0		x	168
26.12	SPEED WIN LO	REAL	0...3000	rpm	1 = 1	250 µs	16	0		x	168
28	SPEED CONTROL										
28.01	SPEED ERR NCTRL	Val pointer		-		2 ms	32	P.03.06	WP		170

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
28.02	PROPORT GAIN	REAL	0...200	-	1 = 100	2 ms	16	10			170
28.03	INTEGRATION TIME	REAL	0...600	s	1 = 1000	2 ms	32	0.5			171
28.04	DERIVATION TIME	REAL	0...10	s	1 = 1000	2 ms	16	0			172
28.05	DERIV FILT TIME	REAL	0...1000	ms	1 = 10	2 ms	16	8			172
28.06	ACC COMPENSATION	Val pointer		-		2 ms	32	P.03.07	WP		172
28.07	DROOPING RATE	REAL	0...100	%	1 = 100	2 ms	16	0			173
28.08	BAL REFERENCE	REAL	-1600... 1600	%	1 = 10	2 ms	16	0			173
28.09	SPEEDCTRL BAL EN	Bit pointer		-		2 ms	32	C.False			173
28.10	MIN TORQ SP CTRL	REAL	-1600... 1600	%	1 = 10	2 ms	16	-300			173
28.11	MAX TORQ SP CTRL	REAL	-1600... 1600	%	1 = 10	2 ms	16	300			173
28.12	PI ADAPT MAX SPD	REAL	0...30000	rpm	1 = 1	10 ms	16	0			174
28.13	PI ADAPT MIN SPD	REAL	0...30000	rpm	1 = 1	10 ms	16	0			174
28.14	P GAIN ADPT COEF	REAL	0...10	-	1 = 1000	10 ms	16	0			174
28.15	I TIME ADPT COEF	REAL	0...10	-	1 = 1000	10 ms	16	0			174
28.16	PI TUNE MODE	enum	0...4	-	1 = 1		16	0			175
28.17	TUNE BANDWIDTH	REAL	0...2000	Hz	1 = 100		16	100			175
28.18	TUNE DAMPING	REAL	0...200	-	1 = 10		16	0.5			175
32	TORQUE REFERENCE										
32.01	TORQ REF1 SEL	enum	0...4	-	1 = 1	10 ms	16	2			177
32.02	TORQ REF ADD SEL	enum	0...4	-	1 = 1	10 ms	16	0			177
32.03	TORQ REF IN	Val pointer		-		250 µs	32	P.03.09			178
32.04	MAXIMUM TORQ REF	REAL	0...1000	%	1 = 10	250 µs	16	300			178
32.05	MINIMUM TORQ REF	REAL	-1000...0	%	1 = 10	250 µs	16	-300			178
32.06	LOAD SHARE	REAL	-8...8	-	1 = 1000	250 µs	16	1			178
32.07	TORQ RAMP UP	UINT32	0...60	s	1 = 1000	10 ms	32	0			178
32.08	TORQ RAMP DOWN	UINT32	0...60	s	1 = 1000	10 ms	32	0			179
32.09	RUSH CTRL GAIN	REAL	1...10000	-	1 = 10	10 ms	32	1000			179
32.10	RUSH CTRL TI	REAL	0.1...10	s	1 = 10	10 ms	32	2			179
32.11	TORQ START ABS	REAL	15...300	%	1 = 10	2 ms	16	100			179
32.12	TORQ START TIME1	UINT32	0...60	s	1 = 1	2 ms	32	0			179
32.13	TORQ START TIME2	UINT32	0...60	s	1 = 1	2 ms	32	0			179
33	SUPERVISION										
33.01	SUPERV1 FUNC	UINT32	0...4	-	1 = 1	2 ms	16	0			180
33.02	SUPERV1 ACT	Val pointer		-		2 ms	32	P.01.01			180
33.03	SUPERV1 LIM HI	REAL	-32768... 32768	-	1 = 100	2 ms	32	0			181
33.04	SUPERV1 LIM LO	REAL	-32768... 32768	-	1 = 100	2 ms	32	0			181
33.05	SUPERV2 FUNC	UINT32	0...4	-	1 = 1	2 ms	16	0			181
33.06	SUPERV2 ACT	Val pointer		-		2 ms	32	P.01.04			181

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
33.07	SUPERV2 LIM HI	REAL	-32768... 32768	-	1 = 100	2 ms	32	0			181
33.08	SUPERV2 LIM LO	REAL	-32768... 32768	-	1 = 100	2 ms	32	0			181
33.09	SUPERV3 FUNC	UINT32	0...4	-	1 = 1	2 ms	16	0			182
33.10	SUPERV3 ACT	Val pointer		-		2 ms	32	P.01.06			182
33.11	SUPERV3 LIM HI	REAL	-32768... 32768	-	1 = 100	2 ms	32	0			182
33.12	SUPERV3 LIM LO	REAL	-32768... 32768	-	1 = 100	2 ms	32	0			182
33.17	BIT0 INVERT SRC	Bit pointer	-	-	-	2 ms	32	DI1			182
33.18	BIT1 INVERT SRC	Bit pointer	-	-	-	2 ms	32	DI2			183
33.19	BIT2 INVERT SRC	Bit pointer	-	-	-	2 ms	32	DI3			183
33.20	BIT3 INVERT SRC	Bit pointer	-	-	-	2 ms	32	DI4			183
33.21	BIT4 INVERT SRC	Bit pointer	-	-	-	2 ms	32	DI5			183
33.22	BIT5 INVERT SRC	Bit pointer	-	-	-	2 ms	32	DI6			183
34	REFERENCE CTRL										
34.01	EXT1/EXT2 SEL	Bit pointer		-		2 ms	32	P.02.01.01			185
34.02	EXT1 MODE 1/2SEL	Bit pointer		-		2 ms	32	C.False (P.02.01.05 for pos. appl.)			185
34.03	EXT1 CTRL MODE1	enum	1...5 (1...9 for pos. appl.)	-	1 = 1	2 ms	16	1			185
34.04	EXT1 CTRL MODE2	enum	1...5 (1...9 for pos. appl.)	-	1 = 1	2 ms	16	2 (8 for pos. appl.)			186
34.05	EXT2 CTRL MODE1	enum	1...5 (1...9 for pos. appl.)	-	1 = 1	2 ms	16	2 (6 for pos. appl.)			186
34.07	LOCAL CTRL MODE	enum	1...2 (1...6 for pos. appl.)	-	1 = 1	2 ms	16	1	WPD		187
34.08	TREF SPEED SRC	Val pointer		-		250 µs	32	P.03.08	WP		187
34.09	TREF TORQ SRC	Val pointer		-		250 µs	32	P.03.11	WP		187
34.10	TORQ REF ADD SRC	Val pointer		-		250 µs	32	P.03.12	WP		187
35	MECH BRAKE CTRL										
35.01	BRAKE CONTROL	enum	0...2	-	1 = 1	2 ms	16	0	WPD		188
35.02	BRAKE ACKNOWL	Bit pointer		-		2 ms	32	C.False	WPD		188
35.03	BRAKE OPEN DELAY	UINT32	0...5	s	1 = 100	2 ms	16	0			189
35.04	BRAKE CLOSE DLY	UINT32	0...60	s	1 = 100	2 ms	16	0			189
35.05	BRAKE CLOSE SPD	REAL	0...1000	rpm	1 = 10	2 ms	16	100			189
35.06	BRAKE OPEN TORQ	REAL	0...1000	%	1 = 10	2 ms	16	0			189
35.07	BRAKE CLOSE REQ	Bit pointer		-		2 ms	32	C.False	WPD		189
35.08	BRAKE OPEN HOLD	Bit pointer		-		2 ms	32	C.False	WPD		189
35.09	BRAKE FAULT FUNC	enum	0...2	-	1 = 1	2 ms	16	0			190

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
40	MOTOR CONTROL										
40.01	FLUX REF	REAL	0...200	%	1 = 1	10 ms	16	100			191
40.02	SF REF	enum	0...16	kHz	1 = 1	-	16	4			191
40.03	SLIP GAIN	REAL	0...200	%	1 = 1	-		100			192
40.04	VOLTAGE RESERVE	REAL		V/%	1 = 1	-		-			192
40.05	FLUX OPT	enum	0...1	-	1 = 1	-		-			192
40.06	FORCE OPEN LOOP	enum	0...1	-	1 = 1	250 µs	16	0			192
40.07	IR COMPENSATION	REAL24	0...50	%	1 = 100	2 ms	32	0			193
40.10	FLUX BRAKING	enum	0...2	-	1 = 1	-	16	0			193
45	MOT THERM PROT										
45.01	MOT TEMP PROT	enum	0...2	-	1 = 1	10 ms	16	2			194
45.02	MOT TEMP SOURCE	enum	0...14	-	1 = 1	10 ms	16	0			194
45.03	MOT TEMP ALM LIM	INT32	0...200	°C	1 = 1	-	16	90			195
45.04	MOT TEMP FLT LIM	INT32	0...200	°C	1 = 1	-	16	110			195
45.05	AMBIENT TEMP	INT32	-60...100	°C	1 = 1	-	16	20			196
45.06	MOT LOAD CURVE	INT32	50...150	%	1 = 1	-	16	100			196
45.07	ZERO SPEED LOAD	INT32	50...150	%	1 = 1	-	16	100			196
45.08	BREAK POINT	INT32	0.01...500	Hz	1 = 100	-	16	45			196
45.09	MOTNOM TEMP RISE	INT32	0...300	°C	1 = 1	-	16	80			197
45.10	MOT THERM TIME	INT32	100...10000	s	1 = 1	-	16	256			197
46	FAULT FUNCTIONS										
46.01	EXTERNAL FAULT	Bit pointer		-		2 ms	32	C.True			199
46.02	SPEED REF SAFE	REAL	-30000...30000	rpm	1 = 1	2 ms	16	0			199
46.03	LOCAL CTRL LOSS	enum	0...3	-	1 = 1	-	16	1			199
46.04	MOT PHASE LOSS	enum	0...1	-	1 = 1	2 ms	16	1			199
46.05	EARTH FAULT	enum	0...2	-	1 = 1	-	16	2			199
46.06	SUPPL PHS LOSS	enum	0...1	-	1 = 1	2 ms	16	1			200
46.07	STO DIAGNOSTIC	enum	1...4	-	1 = 1	10 ms	16	1			200
46.08	CROSS CONNECTION	enum	0...1	-	1 = 1	-	16	1			200
46.09	STALL FUNCTION	Pb	0b000...0b111	-	1 = 1	10 ms	16	0b111			201
46.10	STALL CURR LIM	REAL	0...1600	%	1 = 10	10 ms	16	200			201
46.11	STALL FREQ HI	REAL	0.5...1000	Hz	1 = 10	10 ms	16	15			201
46.12	STALL TIME	UINT32	0...3600	s	1 = 1	10 ms	16	20			201
46.13	FAN CTRL MODE	enum	0...3	-	1 = 1	-	16	0			201
46.14	FAULT STOP MODE	enum	0...1	-	1 = 1	-	16	0			202
46.15	FAST STALL TIME	UINT32	0...3600	ms	1 = 1	10 ms	16	0			202
47	VOLTAGE CTRL										
47.01	OVERVOLTAGE CTRL	enum	0...1	-	1 = 1	10 ms	16	1			203
47.02	UNDERVOLT CTRL	enum	0...1	-	1 = 1	10 ms	16	1			203
47.03	SUPPLVOLTAUTO-ID	enum	0...1	-	1 = 1	10 ms	16	1			204

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
47.04	SUPPLY VOLTAGE	REAL	0...1000	V	1 = 10	2 ms	16	400			204
47.05	LOW VOLT MOD ENA	Bit pointer		-			32	C.False			204
47.06	LOW VOLT DC MIN	REAL	250...450	V	1 = 1	10 ms	16	250			204
47.07	LOW VOLT DC MAX	REAL	350...810	V	1 = 1	10 ms	16	810			204
47.08	EXT PU SUPPLY	Bit pointer		-			32	C.False			204
48	BRAKE CHOPPER										
48.01	BC ENABLE	enum	0...2	-	1 = 1	-	16	0			205
48.02	BC RUN-TIME ENA	Bit pointer		-		2 ms	32	P.06.01.03			205
48.03	BR THERM TIMECONST	REAL24	0...10000	s	1 = 1	-	32	0			205
48.04	BR POWER MAX CNT	REAL24	0...10000	kW	1 = 10000	-	32	0			205
48.05	R BR	REAL24	0.1...1000	ohm	1 = 10000	-	32	-			206
48.06	BR TEMP FAULTLIM	REAL24	0...150	%	1 = 1	-	16	105			206
48.07	BR TEMP ALARMLIM	REAL24	0...150	%	1 = 1	-	16	95			206
50	FIELD BUS										
50.01	FBA ENABLE	enum	0...1	-	1 = 1	-	16	0			207
50.02	COMM LOSS FUNC	enum	0...3	-	1 = 1	-	16	0			207
50.03	COMM LOSS T OUT	UINT32	0.3...6553.5	s	1 = 10	-	16	0.3			208
50.04	FBA REF1 MODESEL	enum	0...2 (0...4 for pos. appl.)	-	1 = 1	10 ms	16	2			208
50.05	FBA REF2 MODESEL	enum	0...2 (0...4 for pos. appl.)	-	1 = 1	10 ms	16	3			208
50.06	FBA ACT1 TR SRC	Val pointer		-		10 ms	32	P.01.01			209
50.07	FBA ACT2 TR SRC	Val pointer		-		10 ms	32	P.01.06			209
50.08	FBA SW B12 SRC	Bit pointer		-		500 µs	32	C.False			209
50.09	FBA SW B13 SRC	Bit pointer		-		500 µs	32	C.False			209
50.10	FBA SW B14 SRC	Bit pointer		-		500 µs	32	C.False			209
50.11	FBA SW B15 SRC	Bit pointer		-		500 µs	32	C.False			209
50.12	FBA CYCLE TIME	enum	0...2	-	1 = 1	10 ms	16	2			210
50.20	FB MAIN SW FUNC	Pb	0b000... 0b111	-	1 = 1	10 ms	16	0b011			210
51	FBA SETTINGS										
51.01	FBA TYPE	UINT32	0...65536	-	1 = 1		16	0			211
51.02	FBA PAR2	UINT32	0...65536	-	1 = 1		16	0		x	211
...			
51.26	FBA PAR26	UINT32	0...65536	-	1 = 1		16	0		x	211
51.27	FBA PAR REFRESH	UINT32	0...1	-	1 = 1		16	0	WPD	x	211
51.28	PAR TABLE VER	UINT32	0...65536	-	1 = 1		16	0		x	211
51.29	DRIVE TYPE CODE	UINT32	0...65536	-	1 = 1		16	0		x	211
51.30	MAPPING FILE VER	UINT32	0...65536	-	1 = 1		16	0		x	212
51.31	D2FBA COMM STA	UINT32	0...6	-	1 = 1		16	0		x	212
51.32	FBA COMM SW VER	UINT32	0...65536	-	1 = 1		16	0		x	212
51.33	FBA APPL SW VER	UINT32	0...65536	-	1 = 1		16	0		x	212

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
52	FBA DATA IN										
52.01	FBA DATA IN1	UINT32	0...9999	-	1 = 1		16	0		x	213
...			-
52.12	FBA DATA IN12	UINT32	0...9999	-	1 = 1		16	0		x	213
53	FBA DATA OUT										
53.01	FBA DATA OUT1	UINT32	0...9999	-	1 = 1		16	0		x	214
...			
53.12	FBA DATA OUT12	UINT32	0...9999	-	1 = 1		16	0		x	214
55	COMMUNICATION TOOL										
55.01	MDB STATION ID	UINT32	1...247	-	1 = 1		16	1			215
55.02	MDB BAUD RATE	UINT32	0...4	-	1 = 1		16	0			215
55.03	MDB PARITY	UINT32	0...3	-	1 = 1		16	0			215
57	D2D COMMUNICATION										
57.01	LINK MODE	UINT32	0...2	-	1 = 1	10 ms	16	0			216
57.02	COMM LOSS FUNC	UINT32	0...2	-	1 = 1	10 ms	16	1			216
57.03	NODE ADDRESS	UINT32	1...62	-	1 = 1	10 ms	16	1	WPD		217
57.04	FOLLOWER MASK 1	UINT32	0...2 ³¹	-	1 = 1	10 ms	32	0	WPD		217
57.05	FOLLOWER MASK 2	UINT32	0...2 ³¹	-	1 = 1	10 ms	32	0	WPD		217
57.06	REF 1 SRC	Val pointer		-		10 ms	32	P.03.04			217
57.07	REF 2 SRC	Val pointer		-		10 ms	32	P.03.13			217
57.08	FOLLOWER CW SRC	Val pointer		-		10 ms	32	P.02.18			217
57.09	KERNEL SYNC MODE	enum	0...3	-	1 = 1	10 ms	16	0	WPD		218
57.10	KERNEL SYNC OFFS	REAL	-4999... 5000	ms	1 = 1	10 ms	16	0	WPD		218
57.11	REF 1 MSG TYPE	UINT32	0...1	-	1 = 1	10 ms	16	0			218
57.12	REF1 MC GROUP	UINT32	0...62	-	1 = 1	10 ms	16	0			219
57.13	NEXT REF1 MC GRP	UINT32	0...62	-	1 = 1	10 ms	16	0			219
57.14	NR REF1 MC GRPS	UINT32	1...62	-	1 = 1	10 ms	16	1			219
57.15	D2D COMM PORT	enum	0...3	-	1 = 1		16	0	WPD		219
60	POS FEEDBACK										
60.01	POS ACT SEL	enum	0...2	-	1 = 1	10 ms	16	0			221
60.02	POS AXIS MODE	enum	0...1	-	1 = 1	2 ms	16	0			221
60.03	LOAD GEAR MUL	INT32	-2 ³¹ ...2 ³¹ - 1	-	1 = 1	2 ms	32	1			222
60.04	LOAD GEAR DIV	UINT32	1...2 ³¹ - 1	-	1 = 1	2 ms	32	1			222
60.05	POS UNIT	enum	0...4	-	1 = 1	10 ms	16	0	WPD		222
60.06	FEED CONST MUL	UINT32	1...2 ³¹ - 1	-	1 = 1	10 ms	32	1	WPD		222
60.07	FEED CONST DEN	UINT32	1...2 ³¹ - 1	-	1 = 1	10 ms	32	1	WPD		223
60.08	POS2INT SCALE	enum	1...1000000	-	1 = 1	10 ms	32	1000	WPD		223
60.09	POS RESOLUTION	enum	10...24	-	1 = 1	10 ms	16	16	WPD		223
60.10	POS SPEED UNIT	enum	0...2	-	1 = 1	10 ms	16	0	WPD		223
60.11	POS SPEED2INT	enum	1...1000000	-	1 = 1	10 ms	32	1000	WPD		223

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
60.12	POS SPEED SCALE	REAL	0...32768	-	1 = 10000	10 ms	32	1	WPD		224
60.13	MAXIMUM POS	REAL	-32768... 32768	*	See 60.09	2 ms	32	32768			224
60.14	MINIMUM POS	REAL	-32768... 32768	*	See 60.09	2 ms	32	-32768			224
60.15	POS THRESHOLD	REAL	-32768... 32768	*	See 60.09	2 ms	32	0			224
62	POS CORRECTION										
62.01	HOMING METHOD	UINT32	0...35	-	1 = 1	10 ms	16	0			226
62.02	HOMING STARTFUNC	enum	0...1	-	1 = 1	10 ms	16	0			226
62.03	HOMING START	Bit pointer	-	-		10 ms	32	P.02.01.05			226
62.04	HOME SWITCH TRIG	enum	0...4	-	1 = 1	10 ms	16	0			226
62.05	NEG LIMIT SWITCH	Bit pointer	-	-		10 ms	32	C.False			226
62.06	POS LIMIT SWITCH	Bit pointer	-	-		10 ms	32	C.False			227
62.07	HOMING SPEEDREF1	REAL	0...32768	**	See 60.10	10 ms	32	1			227
62.08	HOMING SPEEDREF2	REAL	0...32768	**	See 60.10	10 ms	32	0.25			227
62.09	HOME POSITION	REAL	-32768... 32768	*	See 60.09	10 ms	32	0			227
62.10	HOME POS OFFSET	REAL	-32768... 32768	*	See 60.09	10 ms	32	0			227
62.11	PRESET MODE	enum	0...3	-	1 = 1	10 ms	16	0			228
62.12	PRESET TRIG	enum	0...14	-	1 = 1	10 ms	16	0			228
62.13	PRESET POSITION	REAL	-32768... 32768	*	See 60.09	10 ms	32	0			229
62.14	CYCLIC CORR MODE	enum	0...5	-	1 = 1	10 ms	16	0			229
62.15	TRIG PROBE1	enum	0...30	-	1 = 1	10 ms	16	0			229
62.16	PROBE1 POS	REAL	-32768... 32768	*	See 60.09	10 ms	32	0			231
62.17	TRIG PROBE2	enum	0...30	-	1 = 1	10 ms	16	0			231
62.18	PROBE2 POS	REAL	-32768... 32768	*	See 60.09	10 ms	32	0			231
62.19	MAX CORRECTION	REAL	0...32768	*	See 60.09	10 ms	32	50			231
62.20	POS ACT OFFSET	REAL	-32768... 32768	*	See 60.09	10 ms	32	0			231
62.21	POS COR MODE	enum	0...1	-	1 = 1	10 ms	16	0			232
62.22	TRIG PROBE1 SW	Bit pointer	-	-		10 ms	32	C.False			232
62.23	TRIG PROBE2 SW	Bit pointer	-	-		10 ms	32	C.False			232
62.25	Z-PULSE SOURCE 1	enum	0...3	-	1 = 1		16	0			232
62.26	Z-PULSE SOURCE 2	enum	0...3	-	1 = 1		16	0			233
62.27	HOMING ACC	REAL	0...32768	u/s^2	See 60.10	2 ms	32	10			233
62.28	HOMING DEC	REAL	-32768...0	u/s^2	See 60.10	2 ms	32	-10			233
62.30	PROBE TRIG FILT	enum	0...3	-	1 = 1		16	2			234
62.31	CYCLIC COR STYLE	enum	0...1	-	1 = 1	-	16	0			234

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
62.32	MAX COR MODE	enum	0...2	-	1=1	2 ms	16	0			235
65	PROFILE REFERENCE										
65.01	POS REFSOURCE	enum	0...2	-	1 = 1	2 ms	16	0			237
65.02	PROF SET SEL	Bit pointer	-	-	-	2 ms	32	P.02.01.04			238
65.03	POS START 1	Bit pointer	-	-	-	2 ms	32	P.02.01.03			238
65.04	POS REF 1 SEL	enum	0...8	-	1 = 1	2 ms	16	7			238
65.05	POS SPEED 1	REAL	0...32768	**	See 60.10	2 ms	32	5			238
65.06	PROF ACC 1	REAL	0...32768	**	See 60.10	2 ms	32	10			238
65.07	PROF DEC 1	REAL	-32768...0	**	See 60.10	2 ms	32	-10			238
65.08	PROF FILT TIME 1	REAL	0...1000	ms	1 = 1	2 ms	16	0			238
65.09	POS STYLE 1	UINT32	0...0xFFFF	-	1 = 1	2 ms	16	20			239
65.10	POS END SPEED 1	REAL	-32768... 32768	**	See 60.10	2 ms	32	0			241
65.11	POS START 2	Bit pointer	-	-	-	2 ms	32	P.02.01.03			241
65.12	POS REF 2 SEL	enum	0...8	-	1 = 1	2 ms	32	8			241
65.13	POS SPEED 2	REAL	0...32768	**	See 60.10	2 ms	32	5			241
65.14	PROF ACC 2	REAL	0...32768	**	See 60.10	2 ms	32	10			241
65.15	PROF DEC 2	REAL	-32768...0	**	See 60.10	2 ms	32	-10			241
65.16	PROF FILT TIME 2	REAL	0...1000	ms	1 = 1	2 ms	16	0			241
65.17	POS STYLE 2	UINT32	0...0xFFFF	-	1 = 1	2 ms	16	20			241
65.18	POS END SPEED 2	REAL	-32768... 32768	**	See 60.10	2 ms	32	0			242
65.19	POS REF 1	REAL	-32760... 32760	*	See 60.09	2 ms	32	0			242
65.20	POS REF 2	REAL	-32760... 32760	*	See 60.09	2 ms	32	0			242
65.21	POS REF ADD SEL	enum	0...8	-	1 = 1	2 ms	16	0			242
65.22	PROF VEL REF SEL	enum	0...7	-	1 = 1	2 ms	16	7			243
65.23	PROF VEL REF1	REAL	-32768... 32768	**	See 60.10	500 µs	32	0			243
65.24	POS START MODE	enum	0...1	-	1 = 1	2 ms	16	0			243
66	PROFILE GENERATOR										
66.01	PROF GENERAT IN	Val pointer	-	-	-	10 ms	32	P.04.06	WP		245
66.02	PROF SPEED MUL	REAL	0...1	-	1 = 1000	500 µs	32	1			245
66.03	PROF ACC WEAK SP	REAL	0...32768	**	See 60.10	10 ms	32	32768			246
66.04	POS WIN	REAL	0...32768	*	See 60.09	500 µs	32	0.1			246
66.05	POS ENABLE	Bit pointer	-	-	-	500 µs	32	C.True			246
67	SYNC REF SEL										
67.01	SYNC REF SEL	enum	0...9	-	1 = 1	10 ms	16	8			248
67.02	VIRT MAS REF SEL	enum	0...9	-	1 = 1	10 ms	16	0			248
67.03	INTERPOLAT MODE	enum	0...1	-	1 = 1	10 ms	16	0			249
67.04	INTERPOLAT CYCLE	UINT32	1...10000	ms	1 = 1	10 ms	16	1			249
67.10	VIRT MAS SPD REF	REAL	-30000... 30000	rpm	1 = 1	10 ms	16	0			249

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
68	SYNC REF MOD										
68.01	SYNC GEAR IN	Val pointer	-	-	-	10 ms	32	P.04.15			250
68.02	SYNC GEAR MUL	INT32	$-2^{31} \dots 2^{31} - 1$	-	1 = 1	10 ms	32	1	WPD		251
68.03	SYNC GEAR DIV	UINT32	$1 \dots 2^{31} - 1$	-	1 = 1	10 ms	32	1	WPD		251
68.04	SYNC GEAR ADD	REAL	-30...30	-	1 = 1000	500 μ s	32	1			251
68.05	SYNC REF FTIME	REAL	0...1000	ms	1 = 1	10 ms	16	0	WPD		251
68.06	SYNCFILT DLY LIM	REAL	0...120	*	See 60.09	10 ms	32	0			251
68.07	SYNCHRON MODE	enum	0...1	-	1 = 1	2 ms	16	1			251
70	POS REF LIMIT										
70.01	POS REF PROFILE	Val pointer	-	-	-	500 μ s	32	P.04.13			253
70.02	POS REF SYNC	Val pointer	-	-	-	500 μ s	32	P.04.16			253
70.03	POS REF ENA	Bit pointer	-	-	-	500 μ s	32	C.True			253
70.04	POS SPEED LIM	REAL	0...32768	**	See 60.10	2 ms	32	32768			253
70.05	POS ACCEL LIM	REAL	0...32768	**	See 60.10	2 ms	32	32768			254
70.06	POS DECEL LIM	REAL	-32768...0	**	See 60.10	2 ms	32	-32768			254
70.07	SYNC ERR LIM	REAL	0...32768	*	See 60.09	500 μ s	32	0			254
70.08	SYNC VEL WINDOW	REAL	0...32768	**	See 60.10	2 ms	32	2			254
71	POSITION CTRL										
71.01	POS ACT IN	Val pointer	-	-	-	500 μ s	32	P.01.12	WP		256
71.02	POS CTRL REF IN	Val pointer	-	-	-	500 μ s	32	P.04.17			256
71.03	POS CTRL GAIN	REAL	0...10000	1/s	1 = 100	500 μ s	32	10			256
71.04	P CTRL FEED GAIN	REAL	0...10	-	1 = 100	500 μ s	16	1			257
71.05	POS CTRL DELAY	UINT32	0...15	-	1 = 1	2 ms	16	0			257
71.06	POS ERR LIM	REAL	0...32768	*	See 60.09	500 μ s	32	32768			257
71.07	GEAR RATIO MUL	INT32	$-2^{31} \dots 2^{31} - 1$	-	1 = 1	10 ms	32	1			257
71.08	GEAR RATIO DIV	UINT32	$1 \dots 2^{31} - 1$	-	1 = 1	10 ms	32	1			257
71.09	FOLLOW ERR WIN	REAL	0...32768	*	See 60.09	500 μ s	32	32768			257
90	ENC MODULE SEL										
90.01	ENCODER 1 SEL	enum	0...6	-	1 = 1		16	0			259
90.02	ENCODER 2 SEL	enum	0...6	-	1 = 1		16	0			260
90.03	EMUL MODE SEL	enum	0...9	-	1 = 1		16	0			260
90.04	TTL ECHO SEL	enum	0...4	-	1 = 1		16	0			261
90.05	ENC CABLE FAULT	UINT32	0...2	-	1 = 1		16	1			262
90.06	INVERT ENC SIG	enum	0...3	-	1 = 1		16	0			262
90.10	ENC PAR REFRESH	UINT32	0...1	-	1 = 1		16	0	WPD		262
91	ABSOL ENC CONF										
91.01	SINE COSINE NR	UINT32	0...65535	-	1 = 1		16	0			264
91.02	ABS ENC INTERF	enum	0...5	-	1 = 1		16	0			264
91.03	REV COUNT BITS	UINT32	0...32	-	1 = 1		16	0			264
91.04	POS DATA BITS	UINT32	0...32	-	1 = 1		16	0			264
91.05	REFMARK ENA	UINT32	0...1	-	1 = 1		16	0			264
91.06	ABS POS TRACKING	UINT32	0...1	-	1 = 1		16	0			265
91.10	HIPERFACE PARITY	UINT32	0...1	-	1 = 1		16	0			265

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
91.11	HIPERF BAUDRATE	UINT32	0...3	-	1 = 1		16	1			265
91.12	HIPERF NODE ADDR	UINT32	0...255	-	1 = 1		16	64			265
91.20	SSI CLOCK CYCLES	UINT32	2...127	-	1 = 1		16	2			265
91.21	SSI POSITION MSB	UINT32	1...126	-	1 = 1		16	1			266
91.22	SSI REVOL MSB	UINT32	1...126	-	1 = 1		16	1			266
91.23	SSI DATA FORMAT	UINT32	0...1	-	1 = 1		16	0			266
91.24	SSI BAUD RATE	UINT32	0...7	-	1 = 1		16	2			266
91.25	SSI MODE	UINT32	0...3	-	1 = 1		16	0			266
91.26	SSI TRANSMIT CYC	UINT32	0...5	-	1 = 1		16	1			267
91.27	SSI ZERO PHASE	UINT32	0...3	-	1 = 1		16	0			267
91.30	ENDAT MODE	UINT32	0...3	-	1 = 1		16	0			267
91.31	ENDAT MAX CALC	UINT32	0...3	-	1 = 1		16	3			267
91.32	ENDAT CLOCK FREQ	enum	0...3	-	1 = 1		16	2			268
92	RESOLVER CONF										
92.01	RESOLV POLEPAIRS	UINT32	1...32	-	1 = 1		16	1			269
92.02	EXC SIGNAL AMPL	UINT32	4...12	Vrms	1 = 10		16	4			269
92.03	EXC SIGNAL FREQ	UINT32	1...20	KHz	1 = 1		16	1			269
93	PULSE ENC CONF										
93.01	ENC1 PULSE NR	UINT32	0...65535	-	1 = 1		16	0			270
93.02	ENC1 TYPE	enum	0...1	-	1 = 1		16	0			270
93.03	ENC1 SP CALCMODE	enum	0...5	-	1 = 1		16	4			270
93.04	ENC1 POS EST ENA	enum	0...1	-	1 = 1		16	1			271
93.05	ENC1 SP EST ENA	enum	0...1	-	1 = 1		16	0			271
93.06	ENC1 OSC LIM	enum	0...3	-	1 = 1		16	0			271
93.07	ENC1 PULSE FILT	UINT32	0...2	-	1 = 1		16	0			272
93.11	ENC2 PULSE NR	UINT32	0...65535	-	1 = 1		16	0			272
93.12	ENC2 TYPE	enum	0...1	-	1 = 1		16	0			272
93.13	ENC2 SP CALCMODE	enum	0...5	-	1 = 1		16	4			272
93.14	ENC2 POS EST ENA	enum	0...1	-	1 = 1		16	1			272
93.15	ENC2 SP EST ENA	enum	0...1	-	1 = 1		16	0			272
93.16	ENC2 OSC LIM	enum	0...3	-	1 = 1		16	0			272
93.17	ENC2 PULSE FILT	UINT32	0...2	-	1 = 1		16	0			273
93.21	EMUL PULSE NR	UINT32	0...65535	-	1 = 1		16	0			273
93.22	EMUL POS REF	Val pointer		-			32	P.01.12 (P.04.17 for pos. appl.)			273
93.23	EMUL POS OFFSET	REAL	0 ... 0.99998	rev	1 = 100000		32	0			273
95	HW CONFIGURATION										
95.01	CTRL UNIT SUPPLY	enum	0...1	-	1 = 1		16	0			274
95.02	EXTERNAL CHOKE	enum	0...1	-	1 = 1		16	0			274

Index	Parameter	Type	Range	Unit	FbEq	Update time	Data length	Def	PT	Save PF	Page no.
97	USER MOTOR PAR										
97.01	USE GIVEN PARAMS	enum	0...3	-	1 = 1		16	0	WPD		275
97.02	RS USER	REAL24	0...0.5	p.u.	1 = 100000		32	0			275
97.03	RR USER	REAL24	0...0.5	p.u.	1 = 100000		32	0			275
97.04	LM USER	REAL24	0...10	p.u.	1 = 100000		32	0			275
97.05	SIGMAL USER	REAL24	0...1	p.u.	1 = 100000		32	0			275
97.06	LD USER	REAL24	0...10	p.u.	1 = 100000		32	0			275
97.07	LQ USER	REAL24	0...10	p.u.	1 = 100000		32	0			276
97.08	PM FLUX USER	REAL24	0...2	p.u.	1 = 100000		32	0			276
97.09	RS USER SI	REAL24	0...100	ohm	1 = 100000		32	0			276
97.10	RR USER SI	REAL24	0...100	ohm	1 = 100000		32	0			276
97.11	LM USER SI	REAL24	0...100000	mH	1 = 100000		32	0			276
97.12	SIGL USER SI	REAL24	0...100000	mH	1 = 100000		32	0			276
97.13	LD USER SI	REAL24	0...100000	mH	1 = 100000		32	0			276
97.14	LQ USER SI	REAL24	0...100000	mH	1 = 100000		32	0			276
97.18	SIGNAL INJECTION	UINT32	0...4	-	1 = 1		16	0			277
97.20	POS OFFSET USER	REAL	0...360	° (el.)	1 = 1		32	0			277
98	MOTOR CALC VALUES										
98.01	TORQ NOM SCALE	UINT32	0...2147483	Nm	1 = 1000		32	0	WP		278
98.02	POLEPAIRS	UINT32	0...1000	-	1 = 1		16	0	WP		278
99	START-UP DATA										
99.01	LANGUAGE	enum		-	1 = 1		16				279
99.04	MOTOR TYPE	enum	0...1	-	1 = 1		16	0	WPD		279
99.05	MOTOR CTRL MODE	enum	0...1	-	1 = 1		16	0			280
99.06	MOT NOM CURRENT	REAL	0...6400	A	1 = 10		32	0	WPD		280
99.07	MOT NOM VOLTAGE	REAL	80...960	V	1 = 10		32	0	WPD		280
99.08	MOT NOM FREQ	REAL	0...500	Hz	1 = 10		32	0	WPD		281
99.09	MOT NOM SPEED	REAL	0...30000	rpm	1 = 1		32	0	WPD		281
99.10	MOT NOM POWER	REAL	0...10000	kW	1 = 100		32	0	WPD		281
99.11	MOT NOM COSFII	REAL24	0...1	-	1 = 100		32	0	WPD		281
99.12	MOT NOM TORQUE	INT32	0...2147483	Nm	1 = 1000		32	0	WPD		281
99.13	IDRUN MODE	enum	0...7	-	1 = 1		16	0	WPD		282
99.16	PHASE INVERSION	UINT32	0...1	-	1 = 1		32	0	WPD		284

* The unit depends on parameter 60.05 POS UNIT selection.

** The unit depends on parameter 60.05 POS UNIT and 60.10 POS SPEED UNIT selections.

Fault tracing

What this chapter contains

The chapter lists all alarm and fault messages including the possible cause and corrective actions.

Safety



WARNING! Only qualified electricians are allowed to maintain the drive. The *Safety Instructions* on the first pages of the appropriate hardware manual must be read before you start working with the drive.

Alarm and fault indications


The alarm/fault code is displayed on the control panel of the drive, as well as the DriveStudio PC tool. An alarm or a fault message indicates abnormal drive status. Most alarm and fault causes can be identified and corrected using this information. If not, an ABB representative should be contacted.

The four-digit code number in brackets after the message is for the fieldbus communication.

The alarm/fault code is displayed on the 7-segment display of the drive. The following table describes the indications given by the 7-segment display.

Display	Meaning
"E-" followed by error code	System error. 9001...9002 = Control unit hardware failure. 9003 = No memory unit connected. 9004 = Memory unit failure. 9007...9008 = Loading of firmware from memory unit failed. 9009...9018 = Internal error. Contact an ABB representative. 9019 = Contents of memory unit corrupted. 9020 = Internal error. Contact an ABB representative. 9021 = Program versions of memory unit and drive incompatible. 9022...9026 = Internal error. Contact an ABB representative. 9027 = Memory unit of out memory. 9102...9106 = Internal error. Contact an ABB representative. 9107...9108 = Application initialization fault. 9109...9111 = Internal error. Contact an ABB representative. 9112 = Problem with ACSM1 variant data (Speed / Motion).
"A-" followed by error code	Alarm. See section Alarm messages generated by the drive on page 309.
"F-" followed by error code	Fault. See section Fault messages generated by the drive on page 318.

How to reset

The drive can be reset either by pressing the reset key on the PC tool () or control panel (**RESET**) or switching the supply voltage off for a while. When the fault has been removed, the motor can be restarted.

A fault can also be reset from an external source by parameter [10.08 FAULT RESET SEL](#).

Fault history

When a fault is detected, it is stored in the fault logger with a time stamp. The fault history stores information on the 16 latest faults of the drive. Three of the latest faults are stored at the beginning of a power switch off.

Signals [8.01 ACTIVE FAULT](#) and [8.02 LAST FAULT](#) store the fault codes of the most recent faults.

Alarms can be monitored via bit words [8.05 ALARM LOGGER 1](#)...[8.10 ALARM LOGGER 6](#) and [8.15 ALARM WORD 1](#)...[8.18 ALARM WORD 4](#). Alarm information is lost at power switch off or fault reset.

Alarm messages generated by the drive

Code	Alarm (fieldbus code)	Cause	What to do
2000	BRAKE START TORQUE (0x7185) Programmable fault: 35.09 BRAKE FAULT FUNC	Mechanical brake alarm. Alarm is activated if required motor starting torque, 35.06 BRAKE OPEN TORQ , is not achieved.	Check brake open torque setting, parameter 35.06 . Check drive torque and current limits. See firmware block LIMITS on page 147 .
2001	BRAKE NOT CLOSED (0x7186) Programmable fault: 35.09 BRAKE FAULT FUNC	Mechanical brake control alarm. Alarm is activated, eg, if brake acknowledgement is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings, parameters 35.01...35.09 . To determine whether problem is with acknowledgement signal or brake: Check if brake is closed or open.
2002	BRAKE NOT OPEN (0x7187) Programmable fault: 35.09 BRAKE FAULT FUNC	Mechanical brake control alarm. Alarm is activated, eg, if brake acknowledgement is not as expected during brake opening.	Check mechanical brake connection. Check mechanical brake settings, parameters 35.01...35.08 . To determine whether problem is with acknowledgement signal or brake: Check if brake is closed or open.
2003	SAFE TORQUE OFF (0xFF7A) Programmable fault: 46.07 STO DIAGNOSTIC	Safe Torque Off function is active, ie, safety circuit signal(s) connected to connector X6 is lost while drive is stopped and parameter 46.07 STO DIAGNOSTIC is set to (2) Alarm.	Check safety circuit connections. For more information, see appropriate drive hardware manual and <i>Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives</i> (3AFE68929814 [English]).
2005	MOTOR TEMPERATURE (0x4310) Programmable fault: 45.01 MOT TEMP PROT	Estimated motor temperature (based on motor thermal model) has exceeded alarm limit defined by parameter 45.03 MOT TEMP ALM LIM .	Check motor ratings and load. Let motor cool down. Ensure proper motor cooling: Check cooling fan, clean cooling surfaces, etc. Check value of alarm limit. Check motor thermal model settings, parameters 45.06...45.08 and 45.10 MOT THERM TIME .
		Measured motor temperature has exceeded alarm limit defined by parameter 45.03 MOT TEMP ALM LIM .	Check that actual number of sensors corresponds to value set by parameter 45.02 MOT TEMP SOURCE . Check motor ratings and load. Let motor cool down. Ensure proper motor cooling: Check cooling fan, clean cooling surfaces, etc. Check value of alarm limit.
2006	EMERGENCY OFF (0xF083)	Drive has received emergency OFF2 command.	To restart drive, activate RUN ENABLE signal (source selected by parameter 10.09 RUN ENABLE) and start drive.

Code	Alarm (fieldbus code)	Cause	What to do
2007	RUN ENABLE (0xFF54)	No Run enable signal is received.	Check setting of parameter 10.09 RUN ENABLE . Switch signal on (eg, in the fieldbus Control Word) or check wiring of selected source.
2008	ID-RUN (0xFF84)	Motor identification run is on.	This alarm belongs to normal start-up procedure. Wait until drive indicates that motor identification is completed.
		Motor identification is required.	This alarm belongs to normal start-up procedure. Select how motor identification should be performed, parameter 99.13 IDRUN MODE . Start identification routines by pressing Start key.
2009	EMERGENCY STOP (0xF081)	Drive has received emergency stop command (OFF1/OFF3).	Check that it is safe to continue operation. Return emergency stop push button to normal position (or adjust the fieldbus Control Word accordingly). Restart drive.
2010	POSITION SCALING (0x8584)	Overflow or underflow in position calculation (caused by used position scaling).	Check position scaling parameter settings: 60.06 FEED CONST NUM... 60.09 POS RESOLUTION . Check speed scaling parameter settings: 60.11 POS SPEED2INT and 60.12 POS SPEED SCALE .
2011	BR OVERHEAT (0x7112)	Braking resistor temperature has exceeded alarm limit defined by parameter 48.07 BR TEMP ALARMLIM .	Stop drive. Let resistor cool down. Check resistor overload protection function settings, parameters 48.01... 48.05 . Check alarm limit setting, parameter 48.07 . Check that braking cycle meets allowed limits.
2012	BC OVERHEAT (0x7181)	Braking chopper IGBT temperature has exceeded internal alarm limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings, parameters 48.01... 48.05 . Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.

Code	Alarm (fieldbus code)	Cause	What to do
2013	DEVICE OVERTEMP (0x4210)	Measured drive temperature has exceeded internal alarm limit.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against unit power.
2014	INTBOARD OVERTEMP (0x7182)	Interface board (between power unit and control unit) temperature has exceeded internal alarm limit.	Let drive cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet.
2015	BC MOD OVERTEMP (0x7183)	Input bridge or braking chopper temperature has exceeded internal alarm limit.	Let drive cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet.
2016	IGBT OVERTEMP (0x7184)	Drive temperature based on thermal model has exceeded internal alarm limit.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against unit power.
2017	FIELDBUS COMM (0x7510) Programmable fault: 50.02 COMM LOSS FUNC	Cyclical communication between drive and fieldbus adapter module or between PLC and fieldbus adapter module is lost.	Check status of fieldbus communication. See appropriate User's Manual of fieldbus adapter module. Check fieldbus parameter settings. See parameter group 50 on page 207 . Check cable connections. Check if communication master can communicate.
2018	LOCAL CTRL LOSS (0x5300) Programmable fault: 46.03 LOCAL CTRL LOSS	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Replace control panel in mounting platform.
2019	AI SUPERVISION (0x8110) Programmable fault: 13.12 AI SUPERVISION	Analogue input AI1 or AI2 signal has reached limit defined by parameter 13.13 AI SUPERVIS ACT .	Check analogue input AI1/2 source and connections. Check analogue input AI1/2 minimum and maximum limit settings, parameters 13.02 and 13.03 / 13.07 and 13.08 .
2020	FB PAR CONF (0x6320)	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check fieldbus parameter settings. See parameter group 50 on page 207 .

Code	Alarm (fieldbus code)	Cause	What to do
2021	NO MOTOR DATA (0x6381)	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set. Note: It is normal for this alarm to appear during the start-up until the motor data is entered.
2022	ENCODER 1 FAILURE (0x7301)	Encoder 1 has been activated by parameter but the encoder interface (FEN-xx) cannot be found.	Check parameter 90.01 ENCODER 1 SEL setting corresponds to encoder interface 1 (FEN-xx) installed in drive Slot 1/2 (signal 9.20 OPTION SLOT 1 / 9.21 OPTION SLOT 2). Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.
2023	ENCODER 2 FAILURE (0x7381)	Encoder 2 has been activated by parameter but the encoder interface (FEN-xx) cannot be found.	Check parameter 90.02 ENCODER 2 SEL setting corresponds to encoder interface 2 (FEN-xx) installed in drive Slot 1/2 (signal 9.20 OPTION SLOT 1 / 9.21 OPTION SLOT 2). Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.
		EnDat or SSI encoder is used in continuous mode as encoder 2. [i.e. 90.02 ENCODER 2 SEL = (3) FEN-11 ABS and 91.02 ABS ENC INTERF = (2) EnDat or (4) SSI) and 91.30 ENDAT MODE = (1) Continuous (or 91.25 SSI MODE = (1) Continuous).]	If possible, use single position transfer instead of continuous position transfer (i.e. if encoder has incremental sin/cos signals): - Change parameter 91.25 SSI MODE / 91.30 ENDAT MODE to value (0) Initial pos.. Otherwise use EnDat/SSI encoder as encoder 1: - Change parameter 90.01 ENCODER 1 SEL to value (3) FEN-11 ABS and parameter 90.02 ENCODER 2 SEL to value (0) None. Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.

Code	Alarm (fieldbus code)	Cause	What to do
2024	LATCH POS 1 FAILURE (0x7382)	Position latch 1 from encoder 1 or 2 has failed.	<p>Check latch source parameter settings: 62.04 HOME SWITCH TRIG, 62.12 PRESET TRIG, 62.15 TRIG PROBE1 and 62.17 TRIG PROBE2. Note that zero pulse is not always supported. *</p> <p>Check that appropriate encoder interface 1/2 is activated by parameter 90.10 ENCODER 1 SEL / 90.02 ENCODER 2 SEL.</p> <p>Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.</p> <p>* - Zero pulse is supported when TTL input of encoder interface module is selected (i.e. par. 90.01/90.02 = (1) FEN-01 TTL+, (2) FEN-01 TTL, (4) FEN-11 TTL or (6) FEN-21 TTL.</p> <p>- Zero pulse is supported when absolute encoder input of encoder interface module is selected and zero pulse is enabled (i.e. 90.01/90.02 = (3) FEN-11 ABS and 91.02 = (0) None / (1) Commut sig and 91.05 = (1) TRUE).</p> <p>- Zero pulse is not supported when resolver input is selected (i.e. 90.01/90.02 = (5) FEN-21 RES).</p>
2025	LATCH POS 2 FAILURE (0x7383)	Position latch 2 from encoder 1 or 2 has failed.	See alarm LATCH POS 1 FAILURE.
2026	ENC EMULATION FAILURE (0x7384)	Encoder emulation error	<p>If position value used in emulation is measured by encoder:</p> <p>- Check that FEN-xx encoder used in emulation (90.03 EMUL MODE SEL) corresponds to FEN-xx encoder interface 1 or (and) 2 activated by parameter 90.01 ENCODER 1 SEL / 90.02 ENCODER 2 SEL. (Parameter 90.01/90.02 activates the position calculation of the used FEN-xx input).</p> <p>If position value used in emulation is determined by drive software:</p> <p>- Check that FEN-xx encoder used in emulation (90.03 EMUL MODE SEL) corresponds to FEN-xx encoder interface 1 or (and) 2 activated by parameter 90.01 ENCODER 1 SEL / 90.02 ENCODER 2 SEL (because position data used in emulation is written to FEN-xx during encoder data request). Encoder interface 2 is recommended.</p> <p>Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.</p>

Code	Alarm (fieldbus code)	Cause	What to do
2027	FEN TEMP MEAS FAILURE (0x7385)	Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used.	<p>Check that parameter 45.02 MOT TEMP SOURCE setting corresponds to encoder interface installation (9.20 OPTION SLOT 1 / 9.21 OPTION SLOT 2):</p> <p>If one FEN-xx module is used:</p> <ul style="list-style-type: none"> - Parameter 45.02 MOT TEMP SOURCE setting must be either (2) KTY 1st FEN or (5) PTC 1st FEN. FEN-xx module can be in either Slot 1 or Slot 2. <p>If two FEN-xx modules are used:</p> <ul style="list-style-type: none"> - When parameter 45.02 MOT TEMP SOURCE setting is (2) KTY 1st FEN or (5) PTC 1st FEN, the encoder installed in drive Slot 1 is used. - When parameter 45.02 MOT TEMP SOURCE setting is (3) KTY 2nd FEN or (6) PTC 2nd FEN, the encoder installed in drive Slot 2 is used.
		Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used.	FEN-01 does not support temperature measurement with KTY sensor. Use PTC sensor or other encoder interface module.
2028	ENC EMUL MAX FREQ (0x7386)	TTL pulse frequency used in encoder emulation exceeds maximum allowed limit (500 kHz).	<p>Decrease parameter 93.21 EMUL PULSE NR value.</p> <p>Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.</p>
2029	ENC EMUL REF ERROR (0x7387)	Encoder emulation has failed due to failure in writing new (position) reference for emulation.	Contact your local ABB representative.
2030	RESOLVER AUTOTUNE ERR (0x7388)	Resolver autotuning routines, which are automatically started when resolver input is activated for the first time, have failed.	<p>Check cable between resolver and resolver interface module (FEN-21) and order of connector signal wires at both ends of cable.</p> <p>Check resolver parameter settings.</p> <p>For resolver parameters and information, see parameter group 92 on page 269.</p> <p>Note: Resolver autotuning routines should always be performed after resolver cable connection has been modified. Autotuning routines can be activated by setting parameter 92.02 EXC SIGNAL AMPL or 92.03 EXC SIGNAL FREQ, and then setting parameter 90.10 ENC PAR REFRESH to (1) Configure.</p>

Code	Alarm (fieldbus code)	Cause	What to do
2031	ENCODER 1 CABLE (0x7389)	Encoder 1 cable fault detected.	Check cable between FEN-xx interface and encoder 1. After any modifications in cabling, re-configure interface by switching drive power off and on, or by activating parameter 90.10 ENC PAR REFRESH .
2032	ENCODER 2 CABLE (0x738A)	Encoder 2 cable fault detected.	Check cable between FEN-xx interface and encoder 2. After any modifications in cabling, re-configure interface by switching drive power off and on, or by activating parameter 90.10 ENC PAR REFRESH .
2033	D2D COMMUNICATION (0x7520) Programmable fault: 57.02 COMM LOSS FUNC	On the master drive: The drive has not been replied to by an activated follower for five consecutive polling cycles.	Check that all drives that are polled (parameters 57.04 and 57.05) on the drive-to-drive link are powered, properly connected to the link, and have the correct node address. Check the drive-to-drive link wiring.
		On a follower drive: The drive has not received new reference 1 and/or 2 for five consecutive reference handling cycles.	Check the settings of parameters 57.06 and 57.07 on the master drive. Check the drive-to-drive link wiring.
2034	D2D BUFFER OVERLOAD (0x7520) Programmable fault: 57.02 COMM LOSS FUNC	Transmission of drive-to-drive references failed because of message buffer overflow.	Contact your local ABB representative.
2035	PS COMM (0x5480)	Communication errors detected between the JCU Control Unit and the power unit of the drive.	Check the connections between the JCU Control Unit and the power unit. If the JCU is powered from an external supply, ensure that parameter 95.01 CTRL UNIT SUPPLY is set to (1) External 24V .
2036	RESTORE (0x630D)	Restoration of backed-up parameters failed.	Contact your local ABB representative.
2037	CUR MEAS CALIBRATION (0x2280)	Current measurement calibration will occur at next start.	Informative alarm.
2038	AUTOPHASING (0x3187)	Autophasing will occur at next start.	Informative alarm.
2039	EARTH FAULT (0x2330) Programmable fault: 46.05 EARTH FAULT	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check that there are no power factor correction capacitors or surge absorbers in motor cable. Check that there is no earth fault in motor or motor cables: - measure insulation resistances of motor and motor cable. If no earth fault can be detected, contact your local ABB representative.

Code	Alarm (fieldbus code)	Cause	What to do
2041	MOTOR NOM VALUE (0x6383)	The motor configuration parameters are set incorrectly.	Check the settings of the motor configuration parameters in group 99 .
		The drive is not dimensioned correctly.	Check that the drive is sized correctly for the motor.
2042	D2D CONFIG (0x7583)	The settings of drive-to-drive link configuration parameters (group 57) are incompatible.	Check the settings of the parameters in group 57 .
2043	STALL (0x7121) Programmable fault: 46.09 STALL FUNCTION	Motor is operating in stall region because of, eg, excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
2047	SPEED FEEDBACK (0x8480)	No speed feedback is received.	Check the settings of the parameters in group 22 . Check encoder installation. See the description of fault 0039 (ENCODER1) for more information. Check encoder cabling. See the descriptions of alarms 2031 (ENCODER 1 CABLE) and 2032 (ENCODER 2 CABLE) for more information.
2048	OPTION COMM LOSS (0x7000)	Communication between drive and option module (FEN-xx and/or FIO-xx) is lost.	Check that option modules are properly connected to Slot 1 and (or) Slot 2. Check that option modules or Slot 1/2 connectors are not damaged. To determine whether module or connector is damaged: Test each module individually in Slot 1 and Slot 2.
2072	DC NOT CHARGED (0x3250)	The voltage of the intermediate DC circuit has not yet risen to operating level.	Wait for the DC voltage to rise.
2073	SPEED CTRL TUNE FAIL (0x8481)	Speed controller autotune routine did not finish successfully.	See parameter 28.16 PI TUNE MODE .
2075	LOW VOLT MODE CONFIG (0xC015)	Low voltage mode has been activated but the parameter settings are outside allowable limits.	Check the Low voltage mode parameters in group 47 . See also section Low voltage mode on page 50 .
2079	ENC 1 PULSE FREQUENCY (0x738B)	Encoder 1 is receiving too high data flow (pulse frequency).	Check encoder settings. Change parameters 93.03 ENC1 SP CALCMODE and 93.13 ENC2 SP CALCMODE to use only one channel pulses/edges.

Code	Alarm (fieldbus code)	Cause	What to do
2080	ENC 2 PULSE FREQUENCY (0x738C)	Encoder 2 is receiving too high data flow (pulse frequency).	Check encoder settings. Change parameters 93.03 ENC1 SP CALCMODE and 93.13 ENC2 SP CALCMODE to use only one channel pulses/ edges.
2082	BR DATA (0x7113)	Brake chopper is configured wrong.	Check the brake chopper configuration in parameter group 48 .

Fault messages generated by the drive

Code	Fault (fieldbus code)	Cause	What to do
0001	OVERCURRENT (0x2310)	Output current has exceeded internal fault limit.	<p>Check motor load.</p> <p>Check acceleration time. See parameter group 25 on page 161.</p> <p>Check motor and motor cable (including phasing and delta/star connection).</p> <p>Check that the start-up data in parameter group 99 corresponds to the motor rating plate.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check encoder cable (including phasing).</p>
0002	DC OVERVOLTAGE (0x3210)	Excessive intermediate circuit DC voltage.	<p>Check that overvoltage controller is on, parameter 47.01 OVERVOLTAGE CTRL.</p> <p>Check mains for static or transient overvoltage.</p> <p>Check braking chopper and resistor (if used).</p> <p>Check deceleration time.</p> <p>Use coast-to-stop function (if applicable).</p> <p>Retrofit frequency converter with braking chopper and braking resistor.</p>
0003	DEVICE OVERTEMP (0x4210)	Measured drive temperature has exceeded internal fault limit.	<p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against unit power.</p>
0004	SHORT CIRCUIT (0x2340)	Short-circuit in motor cable(s) or motor.	<p>Check motor and motor cable.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check the braking chopper cabling.</p>
	Extension: 1	Short-circuit in the upper transistor of the U-phase.	Contact your local ABB representative.
	Extension: 2	Short-circuit in the lower transistor of the U-phase.	Contact your local ABB representative.
	Extension: 4	Short-circuit in the upper transistor of the V-phase.	Contact your local ABB representative.
	Extension: 8	Short-circuit in the lower transistor of the V-phase.	Contact your local ABB representative.
	Extension: 16	Short-circuit in the upper transistor of the W-phase.	Contact your local ABB representative.
	Extension: 32	Short-circuit in the lower transistor of the W-phase.	Contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0005	DC UNDERVOLTAGE (0x3220)	Intermediate circuit DC voltage is not sufficient due to missing mains phase, blown fuse or rectifier bridge internal fault.	Check mains supply and fuses.
0006	EARTH FAULT (0x2330) Programmable fault: 46.05 EARTH FAULT	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check that there are no power factor correction capacitors or surge absorbers in motor cable. Check that there is no earth fault in motor or motor cables: - measure insulation resistances of motor and motor cable. If no earth fault can be detected, contact your local ABB representative.
0007	FAN FAULT (0xFF83)	Fan is not able to rotate freely or fan is disconnected. Fan operation is monitored by measuring fan current.	Check fan operation and connection.
0008	IGBT OVERTEMP (0x7184)	Drive temperature based on thermal model has exceeded internal fault limit.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against unit power.
0009	BC WIRING (0x7111)	Braking resistor is missing, damaged or there is a problem in the resistor cabling. Short circuit in the braking chopper IGBT.	Ensure that the braking resistor is connected and not damaged. Replace the braking chopper.
0010	BC SHORT CIRCUIT (0x7113)	Short circuit in the braking chopper IGBT.	Ensure that the braking resistor is connected and not damaged. Replace the braking chopper.
0011	BC OVERHEAT (0x7181)	Braking chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings, parameters 48.03...48.05 . Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.

Code	Fault (fieldbus code)	Cause	What to do
0012	BR OVERHEAT (0x7112)	Braking resistor temperature has exceeded fault limit defined by parameter 48.06 BR TEMP FAULTLIM .	Stop drive. Let resistor cool down. Check resistor overload protection function settings, parameters 48.01...48.05 . Check fault limit setting, parameter 48.06 . Check that braking cycle meets allowed limits.
0013	CURR MEAS GAIN (0x3183)	Difference between output phase U2 and W2 current measurement gain is too great.	Contact your local ABB representative.
0014	CABLE CROSS CON (0x3181) Programmable fault: 46.08 CROSS CONNECTION	Incorrect input power and motor cable connection (ie, input power cable is connected to drive motor connection).	Check input power connections. This fault can be disabled after the drive has been commissioned until the input power cable or motor cable are disconnected again.
0015	SUPPLY PHASE (0x3130) Programmable fault: 46.06 SUPPL PHS LOSS	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse.	Check input power line fuses. Check for input power supply imbalance.
0016	MOTOR PHASE (0x3182) Programmable fault: 46.04 MOT PHASE LOSS	Motor circuit fault due to missing motor connection (all three phases are not connected).	Connect motor cable.

Code	Fault (fieldbus code)	Cause	What to do
0017	ID-RUN FAULT (0xFF84)	Motor ID run is not completed successfully.	Check the fault logger for a fault code extension. See appropriate actions for each extension below.
	Extension: 1	The motor ID run cannot be completed because the maximum current setting and/or the internal current limit of the drive is too low.	Check setting of parameters 99.06 MOT NOM CURRENT and 20.05 MAXIMUM CURRENT . Make sure that 20.05 MAXIMUM CURRENT > 99.06 MOT NOM CURRENT . Check that the drive is dimensioned correctly according to the motor.
	Extension: 2	The motor ID run cannot be completed because the maximum speed setting and/or calculated field weakening point is too low.	Check setting of parameters 99.07 MOT NOM VOLTAGE , 99.08 MOT NOM FREQ , 99.09 MOT NOM SPEED , 20.01 MAXIMUM SPEED and 20.02 MINIMUM SPEED . Make sure that <ul style="list-style-type: none"> • 20.01 MAXIMUM SPEED > (0.55 × 99.09 MOT NOM SPEED) > (0.50 × synchronous speed), • 20.02 MINIMUM SPEED ≤ 0, and • supply voltage ≥ (0.66 × 99.07 MOT NOM VOLTAGE).
	Extension: 3	The motor ID run cannot be completed because the maximum torque setting is too low.	Check setting of parameters 99.12 MOT NOM TORQUE and 20.06 MAXIMUM TORQUE . Make sure that 20.06 MAXIMUM TORQUE > 100%.
	Extension: 5...8	Internal error.	Contact your local ABB representative.
	Extension: 9	Asynchronous motors only: Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	Extension: 10	Asynchronous motors only: Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	Extension: 11	Asynchronous motors only: Speed dropped to zero during motor ID run.	Contact your local ABB representative.
	Extension: 12	Permanent magnet motors only: First acceleration did not finish within reasonable time.	Contact your local ABB representative.
	Extension: 13	Permanent magnet motors only: Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	Extension: 14...16	Internal error.	Contact your local ABB representative.
0018	CURR U2 MEAS (0x3184)	Measured offset error of U2 output phase current measurement is too great. (Offset value is updated during current calibration.)	Contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0019	CURR V2 MEAS (0x3185)	Measured offset error of V2 output phase current measurement is too great. (Offset value is updated during current calibration.)	Contact your local ABB representative.
0020	CURR W2 MEAS (0x3186)	Measured offset error of W2 output phase current measurement is too great. (Offset value is updated during current calibration.)	Contact your local ABB representative.
0021	STO1 LOST (0x8182)	Safe Torque Off function is active, i.e. safety circuit signal 1 connected between X6:1 and X6:3 is lost while drive is at stopped state and parameter 46.07 STO DIAGNOSTIC setting is (2) Alarm or (3) No.	Check safety circuit connections. For more information, see the appropriate drive hardware manual and <i>Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives</i> (3AFE68929814 [English]).
0022	STO2 LOST (0x8183)	Safe Torque Off function is active, i.e. safety circuit signal 2 connected between X6:2 and X6:4 is lost while drive is at stopped state and parameter 46.07 STO DIAGNOSTIC setting is (2) Alarm or (3) No.	Check safety circuit connections. For more information, see the appropriate drive hardware manual and <i>Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives</i> (3AFE68929814 [English]).
0024	INTBOARD OVERTEMP (0x7182)	Interface board (between power unit and control unit) temperature has exceeded internal fault limit.	Let drive cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet.
0025	BC MOD OVERTEMP (0x7183)	Input bridge or braking chopper temperature has exceeded internal fault limit.	Let drive cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet.

Code	Fault (fieldbus code)	Cause	What to do
0026	AUTOPHASING (0x3187)	Autophasing routine failed because the estimated angle of the rotor differs too much from the measured angle of the rotor. All other reasons for the autophasing fault are explained in section <i>Autophasing</i> on page 44.	Try other autophasing modes (see parameter 11.07 AUTOPHASING MODE) if possible. In addition, repeat autophasing multiple times and check the value in parameter 97.20 POS OFFSET USER between separate runs (see section <i>Autophasing</i>). The value should not change between consecutive autophasing runs. Check that there is no slip in the encoder connection to the motor axle. Because of the slip the estimated and measured drive speed may differ during fast accelerations/ decelerations.
0027	PU LOST (0x5400)	Connection between the JCU Control Unit and the power unit of the drive is lost.	Check the connections between the JCU Control Unit and the power unit. If the JCU is powered from an external supply, ensure that parameter 95.01 CTRL UNIT SUPPLY is set to (1) <i>External 24V</i> .
0028	PS COMM (0x5480)	Communication errors detected between the JCU Control Unit and the power unit of the drive.	Check the connections between the JCU Control Unit and the power unit. If the JCU is powered from an external supply, ensure that parameter 95.01 CTRL UNIT SUPPLY is set to (1) <i>External 24V</i> .
0029	IN CHOKE TEMP (0xFF81)	Temperature of internal AC choke excessive.	Check cooling fan.
0030	EXTERNAL (0x9000)	Fault in external device. (This information is configured through one of programmable digital inputs.)	Check external devices for faults. Check setting of parameter 46.01 EXTERNAL FAULT .
0031	SAFE TORQUE OFF (0xFF7A) Programmable fault: 46.07 STO DIAGNOSTIC	Safe Torque Off function is active, i.e. safety circuit signal(s) connected to connector X6 is lost - during drive start or drive run or - while drive is stopped and parameter 46.07 STO DIAGNOSTIC setting is (1) <i>Fault</i> .	Check safety circuit connections. For more information, see the appropriate drive hardware manual and <i>Application guide - Safe torque off function for ACSM1, ACS850 and ACQ810 drives</i> (3AFE68929814 [English]).
0032	OVERSPEED (0x7310)	Motor is turning faster than highest allowed speed due to incorrectly set minimum/ maximum speed, insufficient braking torque or changes in load when using torque reference.	Check minimum/maximum speed settings, parameters 20.01 MAXIMUM SPEED and 20.02 MINIMUM SPEED . Check adequacy of motor braking torque. Check applicability of torque control. Check need for braking chopper and resistor(s).

Code	Fault (fieldbus code)	Cause	What to do
0033	BRAKE START TORQUE (0x7185) Programmable fault: 35.09 BRAKE FAULT FUNC	Mechanical brake fault. Fault is activated if required motor starting torque, 35.06 BRAKE OPEN TORQ , is not achieved.	Check brake open torque setting, parameter 35.06 . Check drive torque and current limits. See parameter group 20 on page 147 .
0034	BRAKE NOT CLOSED (0x7186) Programmable fault: 35.09 BRAKE FAULT FUNC	Mechanical brake control fault. Fault is activated if brake acknowledgement is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings, parameters 35.01...35.09 . To determine whether problem is with acknowledgement signal or brake: Check if brake is closed or open.
0035	BRAKE NOT OPEN (0x7187) Programmable fault: 35.09 BRAKE FAULT FUNC	Mechanical brake control fault. Fault is activated if brake acknowledgement is not as expected during brake opening.	Check mechanical brake connection. Check mechanical brake settings, parameters 35.01...35.08 . To determine whether problem is with acknowledgement signal or brake: Check if brake is closed or open.
0036	LOCAL CTRL LOSS (0x5300) Programmable fault: 46.03 LOCAL CTRL LOSS	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Replace control panel in mounting platform.
0037	NVMEMCORRUPTED (0x6320)	Drive internal fault Note: This fault cannot be reset.	Check the fault logger for a fault code extension. See appropriate actions for each extension below.
	Fault code extension: 2051	Total number of parameters (including unused space between parameters) exceeds firmware maximum.	Move parameters from the firmware groups to the application groups. Reduce the number of parameters.
	Fault code extension: Other	Drive internal fault.	Contact your local ABB representative.
0038	OPTION COMM LOSS (0x7000)	Communication between drive and option module (FEN-xx and/or FIO-xx) is lost.	Check that option modules are properly connected to Slot 1 and (or) Slot 2. Check that option modules or Slot 1/2 connectors are not damaged. To determine whether module or connector is damaged: Test each module individually in Slot 1 and Slot 2.
		Speed feedback (22.01 SPEED FB SEL) has been selected from an encoder which does not supply a speed feedback. SSI and EnDat type absolute encoders do not supply speed feedback when in the 'Continuous' mode (91.25 SSI MODE , 91.30 ENDAT MODE).	In this case, either the estimated speed value must be used, or another encoder mode must be selected. Check parameters 22.01 SPEED FB SEL and 91.25 SSI MODE/91.30 ENDAT MODE .

Code	Fault (fieldbus code)	Cause	What to do
0039	ENCODER1 (0x7301)	Encoder 1 feedback fault	<p>If fault appears during first start-up before encoder feedback is used:</p> <ul style="list-style-type: none"> - Check cable between encoder and encoder interface module (FEN-xx) and order of connector signal wires at both ends of cable. <p>If absolute encoder, EnDat/Hiperface/SSI, with incremental sin/cos pulses is used, incorrect wiring can be located as follows: Disable serial link (zero position) by setting parameter 91.02 ABS ENC INTERF to (0) None and test encoder operation:</p> <ul style="list-style-type: none"> - If encoder fault is not activated, check serial link data wiring. Note that zero position is not taken into account when serial link is disabled. - If encoder fault is activated, check serial link and sin/cos signal wiring. <p>Note: Because only zero position is requested through serial link and during run, position is updated according to sin/cos pulses.</p> <ul style="list-style-type: none"> - Check encoder parameter settings. <p>If fault appears after encoder feedback has already been used or during drive run:</p> <ul style="list-style-type: none"> - Check that encoder connection wiring or encoder is not damaged. - Check that encoder interface module (FEN-xx) connection or module is not damaged. - Check earthings (when disturbances are detected in communication between encoder interface module and encoder). <p>Note: The new settings (or fixed wiring) will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.</p> <p>For more information on encoders, see parameter groups 90 (page 259), 91 (page 263), 92 (page 269) and 93 (page 270).</p>

Code	Fault (fieldbus code)	Cause	What to do
0040	ENCODER2 (0x7381)	Encoder 2 feedback fault	See fault ENCODER1.
		EnDat or SSI encoder is used in continuous mode as encoder 2. [i.e. 90.02 ENCODER 2 SEL = (3) FEN-11 ABS and 91.02 ABS ENC INTERF = (2) EnDat or (4) SSI and 91.30 ENDAT MODE = (1) Continuous (or 91.25 SSI MODE = (1) Continuous).]	If possible, use single position transfer instead of continuous position transfer (i.e. if encoder has incremental sin/cos signals): - Change parameter 91.25 SSI MODE / 91.30 ENDAT MODE to value (0) Initial pos.. Otherwise use Endat/SSI encoder as encoder 1: - Change parameter 90.01 ENCODER 1 SEL to value (3) FEN-11 ABS and parameter 90.02 ENCODER 2 SEL to value (0) None. Note: The new setting will only take effect after parameter 90.10 ENC PAR REFRESH is used or after the JCU control unit is powered up the next time.
0041	POSITION ERROR (0x8500)	Calculated position error, 4.19 POS ERROR , exceeds defined position error supervision window. Motor is stalled.	Check supervision window setting, parameter 71.06 POS ERR LIM . Check that no torque limit is exceeded during positioning.
0043	POSITION ERROR MIN (0x8582)	Actual position value exceeds defined minimum position value. Limit can be exceeded because no homing (or preset function) has been performed.	Check minimum position setting, parameter 60.14 MINIMUM POS . Perform homing (or preset function).
0044	POSITION ERROR MAX (0x8583)	Actual position value exceeds defined maximum position value. Limit can be exceeded because no homing (or preset function) has been performed.	Check maximum position setting, parameter 60.13 MAXIMUM POS . Perform homing (or preset function).
0045	FIELD BUS COMM (0x7510) Programmable fault: 50.02 COMM LOSS FUNC	Cyclical communication between drive and fieldbus adapter module or between PLC and fieldbus adapter module is lost.	Check status of fieldbus communication. See appropriate User's Manual of fieldbus adapter module. Check fieldbus parameter settings. See parameter group 50 on page 207 . Check cable connections. Check if communication master can communicate.
0046	FB MAPPING FILE (0x6306)	Drive internal fault	Contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0047	MOTOR OVERTEMP (0x4310) Programmable fault: 45.01 MOT TEMP PROT	Estimated motor temperature (based on motor thermal model) has exceeded fault limit defined by parameter 45.04 MOT TEMP FLT LIM .	Check motor ratings and load. Let motor cool down. Ensure proper motor cooling: Check cooling fan, clean cooling surfaces, etc. Check value of fault limit. Check motor thermal model settings, parameters 45.06...45.08 and 45.10 MOT THERM TIME .
		Measured motor temperature has exceeded fault limit defined by parameter 45.04 MOT TEMP FLT LIM .	Check that actual number of sensors corresponds to value set by parameter 45.02 MOT TEMP SOURCE . Check motor ratings and load. Let motor cool down. Ensure proper motor cooling: Check cooling fan, clean cooling surfaces, etc. Check value of fault limit.
		Broken wire in the temperature sensor.	Check the temperature sensor connection.
0048	POS ACT MEASURE (0x8584)	Selected operation mode requires position feedback data (actual position), but no feedback data is available.	Check actual position source setting, 60.01 POS ACT SEL . Check encoder installation. See ENCODER1 fault description for more information. (The used operation mode is indicated by signal 6.12 OP MODE ACK .)
0049	AI SUPERVISION (0x8110) Programmable fault: 13.12 AI SUPERVISION	Analogue input AI1 or AI2 signal has reached limit defined by parameter 13.13 AI SUPERVIS ACT .	Check analogue input AI1/2 source and connections. Check analogue input AI1/2 minimum and maximum limit settings, parameters 13.02 and 13.03 / 13.07 and 13.08 .
0050	ENCODER 1 CABLE (0x7389) Programmable fault: 90.05 ENC CABLE FAULT	Encoder 1 cable fault detected.	Check cable between FEN-xx interface and encoder 1. After any modifications in cabling, re-configure interface by switching drive power off and on, or by activating parameter 90.10 ENC PAR REFRESH .
0051	ENCODER 2 CABLE (0x738A) Programmable fault: 90.05 ENC CABLE FAULT	Encoder 2 cable fault detected.	Check cable between FEN-xx interface and encoder 2. After any modifications in cabling, re-configure interface by switching drive power off and on, or by activating parameter 90.10 ENC PAR REFRESH .
0052	D2D CONFIG (0x7583)	Configuration of the drive-to-drive link has failed for a reason other than those indicated by alarm 2042 , for example start inhibition is requested but not granted.	Contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0053	D2D COMM (0x7520) Programmable fault: 57.02 COMM LOSS FUNC	On the master drive: The drive has not been replied to by an activated follower for five consecutive polling cycles.	Check that all drives that are polled (parameters 57.04 FOLLOWER MASK 1 and 57.05 FOLLOWER MASK 2) on the drive-to-drive link are powered, properly connected to the link, and have the correct node address. Check the drive-to-drive link wiring.
		On a follower drive: The drive has not received new reference 1 and/or 2 for five consecutive reference handling cycles.	Check the settings of parameters 57.06 REF 1 SRC and 57.07 REF 2 SRC on the master drive. Check the drive-to-drive link wiring.
0054	D2D BUF OVLOAD (0x7520) Programmable fault: 57.02 COMM LOSS FUNC	Transmission of drive-to-drive references failed because of message buffer overflow.	Contact your local ABB representative.
0055	TECH LIB (0x6382)	Resettable fault generated by a technology library.	Refer to the documentation of the technology library.
0056	TECH LIB CRITICAL (0x6382)	Permanent fault generated by a technology library.	Refer to the documentation of the technology library.
0057	FORCED TRIP (0xFF90)	Generic Drive Communication Profile trip command.	Check PLC status.
0058	FIELD BUS PAR ERROR (0x6320)	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check fieldbus parameter settings. See parameter group 50 on page 207 .
0059	STALL (0x7121) Programmable fault: 46.09 STALL FUNCTION	Motor is operating in stall region because of, eg, excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
0061	SPEED FEEDBACK (0x8480)	No speed feedback is received.	Check the settings of the parameters in group 22 . Check encoder installation. See the description of fault 0039 (ENCODER1) for more information. Check encoder cabling. See the descriptions of faults 0050 (ENCODER1) and 0051 (ENCODER2) for more information.
0062	D2D SLOT COMM (0x7584)	Drive-to-drive link is set to use an FMBA module for communication, but no module is detected in specified slot.	Check the settings of parameters 57.01 LINK MODE and 57.15 D2D COMM PORT . Ensure that the FMBA module has been detected by checking parameters 9.20...9.22 . Check that the FMBA module is correctly wired. Try installing the FMBA module into another slot. If the problem persists, contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0067	FPGA ERROR1 (0x5401)	Drive internal fault	Contact your local ABB representative.
0068	FPGA ERROR2 (0x5402)	Drive internal fault	Contact your local ABB representative.
0069	ADC ERROR (0x5403)	Drive internal fault	Contact your local ABB representative.
0073	ENC 1 PULSE FREQUENCY (0x738B)	Encoder 1 is receiving too high data flow (pulse frequency).	Check encoder settings. Change parameters 93.03 ENC1 SP CALCMODE and 93.13 ENC2 SP CALCMODE to use only one channel pulses/edges.
0074	ENC 2 PULSE FREQUENCY (0x738C)	Encoder 2 is receiving too high data flow (pulse frequency).	Check encoder settings. Change parameters 93.03 ENC1 SP CALCMODE and 93.13 ENC2 SP CALCMODE to use only one channel pulses/edges.
0075	MOT OVERFREQUENCY (0x7390)	Inverter output (motor) frequency has exceeded the frequency limit 599 Hz.	Reduce the motor rotation speed.
0201	T2 OVERLOAD (0x0201)	Firmware time level 2 overload Note: This fault cannot be reset.	Contact your local ABB representative.
0202	T3 OVERLOAD (0x6100)	Firmware time level 3 overload Note: This fault cannot be reset.	Contact your local ABB representative.
0203	T4 OVERLOAD (0x6100)	Firmware time level 4 overload Note: This fault cannot be reset.	Contact your local ABB representative.
0204	T5 OVERLOAD (0x6100)	Firmware time level 5 overload Note: This fault cannot be reset.	Contact your local ABB representative.
0205	A1 OVERLOAD (0x6100)	Application time level 1 fault Note: This fault cannot be reset.	Contact your local ABB representative.
0206	A2 OVERLOAD (0x6100)	Application time level 2 fault Note: This fault cannot be reset.	Contact your local ABB representative.
0207	A1 INIT FAULT (0x6100)	Application task creation fault Note: This fault cannot be reset.	Contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0208	A2 INIT FAULT (0x6100)	Application task creation fault Note: This fault cannot be reset.	Contact your local ABB representative.
0209	STACK ERROR (0x6100)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0210	JMU MISSING (0xFF61)	JMU Memory Unit is missing or broken.	Check that the JMU is properly installed. If the problem persists, replace the JMU.
0301	UFF FILE READ (0x6300)	File read error Note: This fault cannot be reset.	Contact your local ABB representative.
0302	APPL DIR CREATION (0x6100)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0303	FPGA CONFIG DIR (0x6100)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0304	PU RATING ID (0x5483)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0305	RATING DATABASE (0x6100)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0306	LICENSING (0x6100)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0307	DEFAULT FILE (0x6100)	Drive internal fault Note: This fault cannot be reset.	Contact your local ABB representative.
0308	APPL FILE PAR CONF (0x6300)	Corrupted application file Note: This fault cannot be reset.	Reload application. If fault is still active, contact your local ABB representative.

Code	Fault (fieldbus code)	Cause	What to do
0309	APPL LOADING (0x6300)	Application file incompatible or corrupted. Note: This fault cannot be reset.	Check the fault logger for a fault code extension. See appropriate actions for each extension below.
	Fault code extension: 8	Template used in the application incompatible with drive firmware.	Change the template of the application in DriveSPC.
	Fault code extension: 10	Parameters defined in the application conflict with existing drive parameters.	Check the application for conflicting parameters.
	Fault code extension: 35	Application memory full.	Reduce the application size and reload the application.
	Fault code extension: 38	Too many powerfail parameters	Reduce the powerfail parameters from the application.
	Fault code extension: 39	Memory unit full	Reduce the application size and reload the application.
	Fault code extension: Other	Corrupted application file	Reload application. If fault is still active, contact your local ABB representative.
0310	USERSET LOAD (0xFF69)	Loading of user set is not successfully completed because: - requested user set does not exist - user set is not compatible with drive program - drive has been switched off during loading.	Reload.
0311	USERSET SAVE (0xFF69)	User set is not saved because of memory corruption.	Check the setting of parameter 95.01 CTRL UNIT SUPPLY . If the fault still occurs, contact your local ABB representative.
0312	UFF OVERSIZE (0x6300)	UFF file is too big.	Contact your local ABB representative.
0313	UFF EOF (0x6300)	UFF file structure failure	Contact your local ABB representative.
0314	TECH LIB INTERFACE (0x6100)	Incompatible firmware interface Note: This fault cannot be reset.	Contact your local ABB representative.
0315	RESTORE FILE (0x630D)	Restoration of backed-up parameters failed.	Contact your local ABB representative. The fault is reset after a successful restoration via the control panel or DriveStudio.

Code	Fault (fieldbus code)	Cause	What to do
0316	DAPS MISMATCH (0x5484)	Mismatch between firmware version (in JMU) and power unit logic versions.	Contact your local ABB representative.
0317	SOLUTION FAULT (0x6200)	Fault generated by function block SOLUTION_FAULT in the application program.	Check the usage of the SOLUTION_FAULT block in the application program.
0319	APPL LICENCE (0x6300)	Drive power unit (JPU) lacks the correct application licence required to use the downloaded application program.	Assign the correct application licence to the drive power unit using the DriveSPC PC tool or remove the protection from the application used. For more information, see section Application program licensing and protection on page 34.

Standard function blocks

What this chapter contains

This chapter describes the standard function blocks. The blocks are grouped according to the grouping in the DriveSPC tool.

The number in brackets in the standard block heading is the block number.

Note: The given execution times may vary depending on the drive application used. The block execution time describes how much CPU load ([1.21 CPU USAGE](#)) the block reserves. For example, if a block with the execution time of 2.33 μ s is set to a 1 ms time level, the increase in the CPU load will be 0.23%.

Terms

Data type	Description	Range
Boolean	Boolean	0 or 1
DINT	32-bit integer value (31 bits + sign)	-2147483648...2147483647
INT	16-bit integer value (15 bits + sign)	-32768...32767
PB	Packed Boolean	0 or 1 for each individual bit
REAL	$\underbrace{\hspace{1.5cm}}_{16\text{-bit value}}$ $\underbrace{\hspace{1.5cm}}_{16\text{-bit value}}$ (31 bits + sign) = integer value = fractional value	-32768,99998...32767,9998
REAL24	$\underbrace{\hspace{1.5cm}}_{8\text{-bit value}}$ $\underbrace{\hspace{1.5cm}}_{24\text{-bit value}}$ (31 bits + sign) = integer value = fractional value	-128,0...127,999

Alphabetical index


ABS	335	EXPT	336	OR	340
ADD	335	FILT1	396	PARRD	397
AND	339	FIO_01_slot1	375	PARRDINTR	398
BGET	344	FIO_01_slot2	376	PARRDPTR	398
BITAND	344	FIO_11_AI_slot1	377	PARWR	399
BITOR	345	FIO_11_AI_slot2	379	PID	390
BOOL_TO_DINT	356	FIO_11_AO_slot1	381	RAMP	392
BOOL_TO_INT	357	FIO_11_AO_slot2	382	REAL_TO_REAL24	362
BOP	400	FIO_11_DIO_slot1	384	REAL24_TO_REAL	363
BSET	345	FIO_11_DIO_slot2	385	REALn_TO_DINT	363
CTD	365	FTRIG	372	REALn_TO_DINT_SIMP	364
CTD_DINT	366	FUNG-1V	387	REG	346
CTU	366	GE	353	REG-G	393
CTU_DINT	367	GetBitPtr	397	ROL	340
CTUD	368	GetValPtr	397	ROR	341
CTUD_DINT	370	GT	354	RS	372
CYCLET	386	IF	402	RTRIG	373
D2D_Conf	348	INT	388	SEL	404
D2D_McastToken	349	INT_TO_BOOL	361	SHL	341
D2D_SendMessage	349	INT_TO_DINT	362	SHR	342
DATA_CONTAINER	386	LE	354	SOLUTION_FAULT	395
DEMUX-I	405	LIMIT	403	SQRT	338
DEMUX-MI	405	LT	355	SR	374
DINT_TO_BOOL	358	MAX	403	SR-D	347
DINT_TO_INT	359	MIN	403	SUB	338
DINT_TO_REALn	359	MOD	336	SWITCH	406
DINT_TO_REALn_SIMP	360	MONO	408	SWITCHC	407
DIV	335	MOTPOT	389	TOF	409
DS_ReadLocal	351	MOVE	337	TON	409
DS_WriteLocal	352	MUL	337	TP	410
ELSE	400	MULDIV	337	XOR	343
ELSEIF	401	MUX	404		
ENDIF	401	NE	355		
EQ	353	NOT	339		

Arithmetic

ABS

(10001)

Illustration



Execution time 0.53 μ s

Operation The output (OUT) is the absolute value of the input (IN).
 $OUT = | IN |$


Inputs The input data type is selected by the user.
 Input (IN): DINT, INT, REAL or REAL24

Outputs Output (OUT): DINT, INT, REAL or REAL24

ADD

(10000)

Illustration



Execution time 3.36 μ s (when two inputs are used) + 0.52 μ s (for every additional input). When all inputs are used, the execution time is 18.87 μ s.

Operation The output (OUT) is the sum of the inputs (IN1...IN32).
 $OUT = IN1 + IN2 + \dots + IN32$
 The output value is limited to the maximum and minimum values defined by the selected data type range.


Inputs The input data type and the number of the inputs (2...32) are selected by the user.
 Input (IN1...IN32): DINT, INT, REAL or REAL24

Outputs Output (OUT): DINT, INT, REAL or REAL24

DIV

(10002)

Illustration




Execution time 2.55 μ s

- Operation** The output (OUT) is input IN1 divided by input IN2.
 $OUT = IN1/IN2$
 The output value is limited to the maximum and minimum values defined by the selected data type range.
 If the divider (IN2) is 0, the output is 0.
- Inputs** The input data type is selected by the user.
 Input (IN1, IN2): INT, DINT, REAL, REAL24
- Outputs** Output (OUT): INT, DINT, REAL, REAL24

EXPT
(10003)


Illustration



- Execution time** 81.90 μ s
- Operation** The output (OUT) is input IN1 raised to the power of the input IN2:
 $OUT = IN1^{IN2}$
 If input IN1 is 0, the output is 0.
 The output value is limited to the maximum value defined by the selected data type range.
Note: The execution of the EXPT function is slow.
- Inputs** The input data type is selected by the user.
 Input (IN1): REAL, REAL24
 Input (IN2): REAL
- Outputs** Output (OUT): REAL, REAL24

MOD
(10004)

Illustration




- Execution time** 1.67 μ s
- Operation** The output (OUT) is the remainder of the division of the inputs IN1 and IN2.
 $OUT = \text{remainder of } IN1/IN2$
 If input IN2 is zero, the output is zero.
- Inputs** The input data type is selected by the user.
 Input (IN1, IN2): INT, DINT
- Outputs** Output (OUT): INT, DINT

MOVE

(10005)

Illustration



Execution time 2.10 μs (when two inputs are used) + 0.42 μs (for every additional input). When all inputs are used, the execution time is 14.55 μs .

Operation Copies the input values (IN1...32) to the corresponding outputs (OUT1...32).

Inputs The input data type and number of inputs (2...32) are selected by the user.


Input (IN1...IN32): INT, DINT, REAL, REAL24, Boolean

Outputs Output (OUT1...OUT32): INT, DINT, REAL, REAL24, Boolean

MUL

(10006)

Illustration



Execution time 3.47 μs (when two inputs are used) + 2.28 μs (for every additional input). When all inputs are used, the execution time is 71.73 μs .

Operation The output (OUT) is the product of the inputs (IN).

$$O = IN1 \times IN2 \times \dots \times IN32$$

The output value is limited to the maximum and minimum values defined by the selected data type range.

Inputs The input data type and the number of inputs (2...32) are selected by the user.


Input (IN1...IN32): INT, DINT, REAL, REAL24

Outputs Output (OUT): INT, DINT, REAL, REAL24

MULDIV

(10007)

Illustration



Execution time 7.10 μs


Operation The output (O) is the product of input IN and input MUL divided by input DIV.
 $Output = (I \times MUL) / DIV$
 O = whole value. REM = remainder value.
 Example: I = 2, MUL = 16 and DIV = 10:
 $(2 \times 16) / 10 = 3.2$, i.e. O = 3 and REM = 2
 The output value is limited to the maximum and minimum values defined by the data type range.

Inputs Input (I): DINT
 Multiplier input (MUL): DINT
 Divider input (DIV): DINT

Outputs Output (O): DINT
 Remainder output (REM): DINT

SQRT
(10008)

Illustration



Execution time 2.09 μ s


Operation Output (OUT) is the square root of the input (IN).
 $OUT = \text{sqrt}(IN)$
 Output is 0 if the input value is negative.

Inputs The input data type is selected by the user.
 Input (IN): REAL, REAL24

Outputs Output (OUT): REAL, REAL24

SUB -
(10009)

Illustration



Execution time 2.33 μ s

Operation Output (OUT) is the difference between the input signals (IN):
 $OUT = IN1 - IN2$
 The output value is limited to the maximum and minimum values defined by the selected data type range.

Inputs The input data type is selected by the user.
 Input (IN1, IN2): INT, DINT, REAL, REAL24


Outputs Output (OUT): INT, DINT, REAL, REAL24

Bitstring

AND

(10010)

Illustration



Execution time 1.55 μs (when two inputs are used) + 0.60 μs (for every additional input). When all inputs are used, the execution time is 19.55 μs .

Operation The output (OUT) is 1 if all the connected inputs (IN1...IN32) are 1. Otherwise the output is 0.

Truth table:

IN1	IN2	OUT
0	0	0
0	1	0
1	0	0
1	1	1

The inputs can be inverted.

Inputs The number of inputs is selected by the user.


Input (IN1...IN32): Boolean

Outputs Output (OUT): Boolean

NOT

(10011)

Illustration



Execution time 0.32 μs

Operation The output (O) is 1 if the input (I) is 0. The output is 0 if the input is 1.


Inputs Input (I): Boolean

Outputs Output (O): Boolean

OR

(10012)

Illustration



Execution time 1.55 μ s (when two inputs are used) + 0.60 μ s (for every additional input). When all inputs are used, the execution time is 19.55 μ s.

Operation The output (OUT) is 0, if all connected inputs (IN) are 0. Otherwise the output is 1.
Truth table:

IN1	IN2	OUT
0	0	0
0	1	1
1	0	1
1	1	1

The inputs can be inverted.

Inputs The number of inputs (2...32) is selected by the user.


Input (IN1...IN32): Boolean

Outputs Output (OUT): Boolean

ROL

(10013)


Illustration



Execution time 1.28 μ s

Operation Input bits (I) are rotated to the left by the number (N) of bits defined by BITCNT. The N most significant bits (MSB) of the input are stored as the N least significant bits (LSB) of the output.

Example: If BITCNT = 3



Inputs The input data type is selected by the user.


Number of bits input (BITCNT): INT, DINT

Input (I): INT, DINT

ROR (10014)

Outputs Output (O): INT, DINT


Illustration



Execution time 1.28 μ s

Operation Input bits (I) are rotated to the right by the number (N) of bits defined by BITCNT. The N least significant bits (LSB) of the input are stored as the N most significant bits (MSB) of the output.

Example: If BITCNT = 3




Inputs The input data type is selected by the user.
 Number of bits input (BITCNT): INT, DINT
 Input (I): INT, DINT

Outputs Output (O): INT, DINT

SHL (10015)


Illustration



Execution time 0.80 μ s

Operation Input bits (I) are rotated to the left by the number (N) of bits defined by BITCNT. The N most significant bits (MSB) of the input are lost and the N least significant bits (LSB) of the output are set to 0.

Example: If BITCNT = 3



Inputs The input data type is selected by the user.


Number of bits (BITCNT): INT; DINT

Input (I): INT, DINT

Outputs Output (O): INT; DINT

SHR
(10016)


Illustration



Execution time 0.80 μ s

Operation Input bits (I) are rotated to the right by the number (N) of bits defined by BITCNT. The N least significant bits (LSB) of the input are lost and the N most significant bits (MSB) of the output are set to 0.

Example: If BITCNT = 3



Inputs The input data type is selected by the user.

Number of bits (BITCNT): INT; DINT


Input (I): INT, DINT

Outputs Output (O): INT; DINT

XOR

(10017)

Illustration



Execution time 1.24 μs (when two inputs are used) + 0.72 μs (for every additional input). When all inputs are used, the execution time is 22.85 μs .

Operation The output (OUT) is 1 if one of the connected inputs (IN1...IN32) is 1. Output is zero if all the inputs have the same value.

Example:

IN1	IN2	OUT
0	0	0
0	1	1
1	0	1
1	1	0

The inputs can be inverted.

Inputs The number of inputs (2...32) is selected by the user.
Input (IN1...IN32): Boolean


Outputs Output (OUT): Boolean

Bitwise

BGET

(10034)

Illustration



Execution time 0.88 μ s

Operation The output (O) is the value of the selected bit (BITNR) of the input (I).
 BITNR: Bit number (0 = bit number 0, 31 = bit number 31)
 If bit number is not in the range of 0...31 (for DINT) or 0...15 (for INT), the output is 0.


Inputs The input data type is selected by the user.
 Number of the bit (BITNR): DINT
 Input (I): DINT, INT

Outputs Output (O): Boolean

BITAND

(10035)

Illustration



Execution time 0.32 μ s

Operation The output (O) bit value is 1 if the corresponding bit values of the inputs (I1 and I2) are 1. Otherwise the output bit value is 0.
 Example:

I1	1 1 1 0 0 0 0 0 1 1 1 0 0 1 0 1 1 1 0 1 0 0 1 1 0 0 1 1 0 0 1
I2	0 0 0 0 0 1 1 1 0 0 1 0 1 1 1 0 1 0 0 1 1 0 0 1 1 0 1 0 1 1 1 1
O	0 0 0 0 0 0 0 0 0 0 0 1 0 0 1 0 0 1 0 0 1 0 0 0 1 0 0 1 0 0 1 0 1


Inputs Input (I1, I2): DINT

Outputs Output (O): DINT

BITOR

(10036)

Illustration



Execution time 0.32 μ s

Operation The output (O) bit value is 1 if the corresponding bit value of any of the inputs (I1 or I2) is 1. Otherwise the output bit value is 0.

Example:

I1	1 1 1 0 0 0 0 0 1 1 1 0 0 1 0 1 1 1 0 1 0 0 1 1 0 0 1 1 0 0 1 1 0 1 0 1
I2	0 0 0 0 0 1 1 1 1 0 0 1 0 1 1 1 0 1 0 0 1 1 0 0 1 1 0 1 0 1 1 1 1 1
O	1 1 1 0 0 1 1 1 1 1 1 0 1 1 1 1 1 1 1 0 1 1 0 1 1 1 1 0 1 1 1 1 1 1 1


Input Input (I1, I2): DINT

Output Output (O): DINT

BSET

(10037)

Illustration



Execution time 1.36 μ s

Operation The value of a selected bit (BITNR) of the input (I) is set as defined by the bit value input (BIT). The function must be enabled by the enable input (EN).

BITNR: Bit number (0 = bit number 0, 31 = bit number 31)

If BITNR is not in the range of 0...31 (for DINT) or 0...15 (for INT) or if EN is reset to zero, the input value is stored to the output as it is (i.e. no bit setting occurs).

Example:

EN = 1, BITNR = 3, BIT = 0

IN = 0000 0000 1111 1111

O = 0000 0000 1111 0111

Inputs The input data type is selected by the user.

Enable input (EN): Boolean

Number of the bit (BITNR): DINT


Bit value input (BIT): Boolean

Input (I): INT, DINT

Outputs Output (O): INT, DINT

REG (10038)

Illustration



Execution time 2.27 μs (when two inputs are used) + 1.02 μs (for every additional input). When all inputs are used, the execution time is 32.87 μs.

Operation The input (I1...I32) value is stored to the corresponding output (O1...O32) if the load input (L) is set to 1 or the set input (S) is 1. When the load input is set to 1, the input value is stored to the output only once. When the set input is 1, the input value is stored to the output every time the block is executed. The set input overrides the load input. If the reset input (R) is 1, all connected outputs are 0.

Example:

S	R	L	I	O1 _{previous}	O1
0	0	0	10	15	15
0	0	0->1	20	15	20
0	1	0	30	20	0
0	1	0->1	40	0	0
1	0	0	50	0	50
1	0	0->1	60	50	60
1	1	0	70	60	0
1	1	0->1	80	0	0

O1_{previous} is the previous cycle output value.

Inputs The input data type and number of inputs (1...32) are selected by the user.

Set input (S): Boolean

Load input (L): Boolean

Reset input (R): Boolean


Input (I1...I32): Boolean, INT, DINT, REAL, REAL24

Outputs Output (O1...O32): Boolean, INT, DINT, REAL, REAL24

SR-D

(10039)

Illustration



Execution time 1.04 μ s

Operation

When clock input (C) is set to 1, the data input (D) value is stored to the output (O).
When reset input (R) is set to 1, the output is set to 0.

If only set (S) and reset (R) inputs are used, SR-D block acts as an [SR](#) block:

The output is 1 if the set input (S) is 1. The output will retain the previous output state if the set input (S) and reset input (R) are 0. The output is 0 if the set input is 0 and the reset input is 1.

Truth table:

S	R	D	C	O _{previous}	O
0	0	0	0	0	0 (= Previous output value)
0	0	0	0 -> 1	0	0 (= Data input value)
0	0	1	0	0	0 (= Previous output value)
0	0	1	0 -> 1	0	1 (= Data input value)
0	1	0	0	1	0 (Reset)
0	1	0	0 -> 1	0	0 (Reset)
0	1	1	0	0	0 (Reset)
0	1	1	0 -> 1	0	0 (Reset)
1	0	0	0	0	1 (= Set value)
1	0	0	0 -> 1	1	0 (= Data input value) for one execution cycle, then changes to 1 according to the set input (S = 1).
1	0	1	0	1	1 (= Set value)
1	0	1	0 -> 1	1	1 (= Data input value)
1	1	0	0	1	0 (Reset)
1	1	0	0 -> 1	0	0 (Reset)
1	1	1	0	0	0 (Reset)
1	1	1	0 -> 1	0	0 (Reset)

O_{previous} is the previous cycle output value.

Inputs

Set input (S): Boolean
Data input (D): Boolean
Clock input (C): Boolean
Reset input (R): Boolean

Outputs


Output (O): Boolean

Communication

See also [Appendix B – Drive-to-drive link](#) (page 435).

D2D_Conf (10092)

Illustration



Execution time -

Operation Defines handling interval for drive-to-drive references 1 and 2, and the address (group number) for standard (non-chained) multicast messages.

The values of the Ref1/2 Cycle Sel inputs correspond to the following intervals:

Value	Handling interval
0	Default (500 µs for reference 1; 2 ms for reference 2)
1	250 µs
2	500 µs
3	2 ms

Note: Negative value of Ref2 Cycle Sel disables the handling of Ref2 (if disabled in the master, it must be disabled in all follower drives as well).

Allowable values for the Std Mcast Group input are 0 (= multicasting not used) and 1...62 (multicast group).

An unconnected input, or an input in an error state, is interpreted as having the value 0. The error codes indicated by the Error output are as follows:

Bit	Description
0	REF1_CYCLE_ERR: Value of input Ref1 Cycle Sel out of range
1	REF2_CYCLE_ERR: Value of input Ref2 Cycle Sel out of range
2	STD_MCAST_ERR: Value of input Std Mcast Group out of range

See also section [Examples of using standard function blocks in drive-to-drive communication](#) starting on page 443.


Inputs Drive-to-drive reference 1 handling interval (Ref1 Cycle Sel): INT
 Drive-to-drive reference 2 handling interval (Ref2 Cycle Sel): INT
 Standard multicast address (Std Mcast Group): INT

Outputs Error output (Error): PB

D2D_McastToken

(10096)

Illustration



Execution time -

Operation

Configures the transmission of token messages sent to a follower. Each token authorizes the follower to send one message to another follower or group of followers. For the message types, see the block [D2D_SendMessage](#).

Note: This block is only supported in the master.

The Target Node input defines the node address the master sends the tokens to; the range is 1...62.

The Mcast Cycle specifies the interval between token messages in the range of 2...1000 milliseconds. Setting this input to 0 disables the sending of tokens.

The error codes indicated by the Error output are as follows:

Bit	Description
0	D2D_MODE_ERR: Drive is not master
5	TOO_SHORT_CYCLE: Token interval is too short, causing overloading
6	INVALID_INPUT_VAL: An input value is out of range
7	GENERAL_D2D_ERR: Drive-to-drive communication driver failed to initialize message

See also section [Examples of using standard function blocks in drive-to-drive communication](#) starting on page 443.


Inputs Token recipient (Target Node): INT
Token interval (Mcast Cycle): INT

Outputs Error output (Error): DINT

D2D_SendMessage

(10095)

Illustration



Execution time -

Operation

Configures the transmission between the dataset tables of drives.

The Msg Type input defines the message type as follows:

Value	Message type
0	Disabled
1	<p>Master P2P:</p> <p>The master sends the contents of a local dataset (specified by LocalDsNr input) to the dataset table (dataset number specified by RemoteDsNr input) of a follower (specified by Target Node/Grp input).</p> <p>The follower replies by sending the next dataset (RemoteDsNr + 1) to the master (LocalDsNr + 1).</p> <p>The node number of a drive is defined by parameter 57.03.</p> <p>Note: Only supported in the master drive.</p>
2	<p>Read Remote:</p> <p>The master reads a dataset (specified by RemoteDsNr input) from a follower (specified by Target Node/Grp input) and stores it into local dataset table (dataset number specified by LocalDsNr input).</p> <p>The node number of a drive is defined by parameter 57.03.</p> <p>Note: Only supported in the master drive.</p>
3	<p>Follower P2P:</p> <p>The follower sends the contents of a local dataset (specified by LocalDsNr input) to the dataset table (dataset number specified by RemoteDsNr input) of another follower (specified by Target Node/Grp input).</p> <p>The node number of a drive is defined by parameter 57.03.</p> <p>Note: Only supported in a follower drive. A token from the master drive is required for the follower to be able to send the message. See the block D2D_McastToken.</p>
4	<p>Standard Multicast:</p> <p>The drive sends the contents of a local dataset (specified by LocalDsNr input) to the dataset table (dataset number specified by RemoteDsNr input) of a group of followers (specified by Target Node/Grp input).</p> <p>Which multicast group a drive belongs to is defined by the Std Mcast Group input of the D2D_Conf block.</p> <p>A token from the master drive is required for a follower to be able to send the message. See the block D2D_McastToken.</p>
5	<p>Broadcast:</p> <p>The drive sends the contents of a local dataset (specified by LocalDsNr input) to the dataset table (dataset number specified by RemoteDsNr input) of all followers.</p> <p>A token from the master drive is required for a follower to be able to send the message. See the block D2D_McastToken.</p> <p>Note: With this message type, the Target Node/Grp input must be connected in DriveSPC even if not used.</p>

See also section [Examples of using standard function blocks in drive-to-drive communication](#) starting on page 443.

The Target Node/Grp input specifies the target drive or multicast group of drives depending on message type. See the message type explanations above.

Note: The input must be connected in DriveSPC even if not used.

The LocalDsNr input specifies the number of the local dataset used as the source or the target of the message.

The RemoteDsNr input specifies the number of the remote dataset used as the target or the source of the message.

The Sent msg count output is a wrap-around counter of successfully sent messages.


The error codes indicated by the Error output are as follows:

Bit	Description
0	D2D_MODE_ERR: Drive-to-drive communication not activated, or message type not supported in current drive-to-drive mode (master/follower)
1	LOCAL_DS_ERR: LocalDsNr input out of range (16...199)
2	TARGET_NODE_ERR: Target Node/Grp input out of range (1...62)
3	REMOTE_DS_ERR: Remote dataset number out of range (16...199)
4	MSG_TYPE_ERR: Msg Type input out of range (0...5)
5...6	Reserved
7	GENERAL_D2D_ERR: Unspecified error in D2D driver
8	RESPONSE_ERR: Syntax error in received response
9	TRA_PENDING: Message has not yet been sent
10	REC_PENDING: Response has not yet been received
11	REC_TIMEOUT: No response received
12	REC_ERROR: Frame error in received message
13	REJECTED: Message has been removed from transmit buffer
14	BUFFER_FULL: Transmit buffer full

Inputs	Message type (Msg Type): INT Target node or multicast group (Target Node/Grp): INT Local dataset number (LocalDsNr): INT Remote dataset number (RemoteDsNr): INT
Outputs	Successfully sent messages counter (Sent msg count): DINT Error output (Error): PB

DS_ReadLocal (10094)

Illustration



Execution time -

Operation Reads the dataset defined by the LocalDsNr input from the local dataset table. One dataset contains one 16-bit and one 32-bit word which are directed to the Data1 16B and Data2 32B outputs respectively.
 The LocalDsNr input defines the number of the dataset to be read.
 The error codes indicated by the Error output are as follows:


Bit	Description
1	LOCAL_DS_ERR: LocalDsNr out of range (16...199)

See also section [Examples of using standard function blocks in drive-to-drive communication](#) starting on page 443.

Inputs Local dataset number (LocalDsNr): INT
Outputs Contents of dataset (Data1 16B): INT
 Contents of dataset (Data2 32B): DINT
 Error output (Error): DINT

DS_WriteLocal (10093)

Illustration



Execution time -

Operation Writes data into the local dataset table. Each dataset contains 48 bits; the data is input through the Data1 16B (16 bits) and Data2 32B (32 bits) inputs. The dataset number is defined by the LocalDsNr input.
 The error codes indicated by the Error output are as follows:

Bit	Description
1	LOCAL_DS_ERR: LocalDsNr out of range (16...199)

See also section [Examples of using standard function blocks in drive-to-drive communication](#) starting on page 443.


Inputs Local dataset number (LocalDsNr): INT
 Contents of dataset (Data1 16B): INT
 Contents of dataset (Data2 32B): DINT
Outputs Error output (Error): DINT

Comparison

EQ

(10040)

Illustration



Execution time 0.89 μs (when two inputs are used) + 0.43 μs (for every additional input). When all inputs are used, the execution time is 13.87 μs .

Operation The output (OUT) is 1 if all the connected input values are equal ($\text{IN1} = \text{IN2} = \dots = \text{IN32}$). Otherwise the output is 0.

Inputs The input data type and the number of inputs (2...32) are selected by the user.
Input (IN1...IN32): INT, DINT, REAL, REAL24


Outputs Output (OUT): Boolean

GE

>=

(10041)

Illustration



Execution time 0.89 μs (when two inputs are used) + 0.43 μs (for every additional input). When all inputs are used, the execution time is 13.87 μs .


Operation The output (OUT) is 1 if ($\text{IN1} \geq \text{IN2}$) & ($\text{IN2} \geq \text{IN3}$) & ... & ($\text{IN31} \geq \text{IN32}$). Otherwise the output is 0.

Inputs The input data type and the number of inputs (2...32) are selected by the user.
Input (IN1...IN32): INT, DINT, REAL, REAL24

Outputs Output (OUT): Boolean

GT >
(10042)

Illustration



Execution time 0.89 μs (when two inputs are used) + 0.43 μs (for every additional input). When all inputs are used, the execution time is 13.87 μs.


Operation The output (OUT) is 1 if (IN1 > IN2) & (IN2 > IN3) & ... & (IN31 > IN32). Otherwise the output is 0.

Inputs The input data type and the number of inputs (2...32) are selected by the user.
Input (IN1...IN32): INT, DINT, REAL, REAL24

Outputs Output (OUT): Boolean

LE <=
(10043)

Illustration




Execution time 0.89 μs (when two inputs are used) + 0.43 μs (for every additional input). When all inputs are used, the execution time is 13.87 μs.

Operation Output (OUT) is 1 if (IN1 ≤ IN2) & (IN2 ≤ IN3) & ... & (IN31 ≤ IN32). Otherwise the output is 0.

Inputs The input data type and the number of inputs (2...32) are selected by the user.
Input (IN1...IN32): INT, DINT, REAL, REAL24

Outputs Output (OUT): Boolean


LT <**(10044)****Illustration**

Execution time 0.89 μ s (when two inputs are used) + 0.43 μ s (for every additional input). When all inputs are used, the execution time is 13.87 μ s.

Operation Output (OUT) is 1 if (IN1 < IN2) & (IN2 < IN3) & ... & (IN31 < IN32). Otherwise the output is 0.

Inputs The input data type and the number of inputs (2...32) are selected by the user.
Input (IN1...IN32): INT, DINT, REAL, REAL24

Outputs Output (OUT): Boolean

NE <>**(10045)****Illustration**

Execution time 0.44 μ s

Operation The output (O) is 1 if I1 <> I2. Otherwise the output is 0.


Inputs The input data type is selected by the user.
Input (I1, I2): INT, DINT, REAL, REAL24

Outputs Output (O): Boolean

Conversion

BOOL_TO_DINT (10018)

Illustration



Execution time 13.47 μ s

Operation The output (OUT) value is a 32-bit integer value formed from the boolean input (IN1...IN31 and SIGN) values. IN1 = bit 0 and IN31 = bit 30.

Example:

IN1 = 1, IN2 = 0, IN3...IN31 = 1, SIGN = 1


OUT = 1111 1111 1111 1111 1111 1111 1111 1101
 SIGN IN31...IN1

Input Sign input (SIGN): Boolean
 Input (IN1...IN31): Boolean

Output Output (OUT): DINT (31 bits + sign)

BOOL_TO_INT (10019)

Illustration



Execution time 5.00 µs

Operation The output (OUT) value is a 16-bit integer value formed from the boolean input (IN1...IN15 and SIGN) values. IN1 = bit 0 and IN15 = bit 14.

Example:

IN1...IN15 = 1, SIGN = 0


OUT = 0111 1111 1111 1111
 SIGN IN15...IN1

Inputs Input (IN1...IN15): Boolean
 Sign input (SIGN): Boolean

Outputs Output (OUT): DINT (15 bits + sign)

DINT_TO_BOOL (10020)

Illustration



Execution time 11.98 μ s

Operation The boolean output (OUT1...OUT32) values are formed from the 32-bit integer input (IN) value.

Example:

IN = 0 111 1111 1111 1111 1111 1111 1111 1100
 └───┬──────────────────┘
 SIGN OUT32...OUT1


Inputs Input (IN): DINT

Outputs Output (OUT1...OUT32): Boolean
 Sign output (SIGN): Boolean

DINT_TO_INT

(10021)

Illustration



Execution time 0.53 μ s

Operation The output (O) value is a 16-bit integer value of the 32-bit integer input (I) value.
Examples:

I (31 bits + sign)	O (15 bits + sign)
2147483647	32767
-2147483648	-32767
0	0


Inputs Input (I): DINT

Outputs Output (O): INT

DINT_TO_REALn

(10023)

Illustration



Execution time 7.25 μ s

Operation The output (OUT) is the REAL/REAL24 equivalent of the input (IN). Input IN1 is the integer value and input IN2 is the fractional value.

If one (or both) of the input values is negative, the output value is negative.

Example (from DINT to REAL):

When IN1 = 2 and IN2 = 3276, OUT = 2.04999.

The output value is limited to the maximum value of the selected data type range.


Inputs Input (IN1, IN2): DINT

Outputs The output data type is selected by the user.
Output (OUT): REAL, REAL24

DINT_TO_REALn_SIMP

(10022)

Illustration



Execution time 6.53 μs

Operation The output (O) is the REAL/REAL24 equivalent of the input (I) divided by the scale input (SCALE).

Error codes indicated at the error output (ERRC) are as follows:

Error code	Description
0	No error
1001	The calculated REAL/REAL24 value exceeds the minimum value of the selected data type range. The output is set to the minimum value.
1002	The calculated REAL/REAL24 value exceeds the maximum value of the selected data type range. The output is set to the maximum value.
1003	The SCALE input is 0. The output is set to 0.
1004	Incorrect SCALE input, i.e. the scale input is < 0 or is not a factor of 10.

Example (from DINT to REAL24):

When I = 205 and SCALE = 100, I/SCALE = 205 /100 = 2.05 and O = 2.04999.

Inputs Input (I): DINT

Scale input (SCALE): DINT

Outputs The output data type is selected by the user.


Output (O): REAL, REAL24

Error output (ERRC): DINT

INT_TO_BOOL

(10024)

Illustration



Execution time 4.31 μ s

Operation The boolean output (OUT1...OUT16) values are formed from the 16-bit integer input (IN) value.

Example:

IN = 0111 1111 1111 1111
 └──┬──┘
 SIGN OUT16...OUT1


Inputs Input (IN): INT

Outputs Output (OUT1...OUT16): Boolean
 Sign output (SIGN): Boolean

INT_TO_DINT

(10025)

Illustration



Execution time 0.33 μs

Operation The output (O) value is a 32-bit integer value of the 16-bit integer input (I) value.

I	O
32767	32767
-32767	-32767
0	0


Inputs Input (I): INT

Outputs Output (O): DINT

REAL_TO_REAL24

(10026)

Illustration



Execution time 1.35 μs

Operation Output (O) is the REAL24 equivalent of the REAL input (I).
The output value is limited to the maximum value of the data type.

Example:

$$\begin{aligned}
 I &= \underbrace{0000\ 0000\ 0010\ 0110}_{\text{Integer value}}\ \underbrace{1111\ 1111\ 1111\ 1111}_{\text{Fractional value}} \\
 O &= \underbrace{0010\ 0110}_{\text{Integer value}}\ \underbrace{1111\ 1111\ 1111\ 1111\ 0000\ 0000}_{\text{Fractional value}}
 \end{aligned}$$


Inputs Input (I): REAL

Outputs Output (O): REAL24

REAL24_TO_REAL

(10027)

Illustration



Execution time 1.20 μ s

Operation Output (O) is the REAL equivalent of the REAL24 input (I).
The output value is limited to the maximum value of the data type range.

Example:

I = 0010 0110 1111 1111 1111 1111 0000 0000
 Integer value Fractional value

O = 0000 0000 0010 0110 1111 1111 1111 1111
 Integer value Fractional value


Inputs Input (I): REAL24

Outputs Output (O): REAL

REALn_TO_DINT

(10029)

Illustration



Execution time 6.45 μ s

Operation Output (O) is the 32-bit integer equivalent of the REAL/REAL24 input (I). Output O1 is the integer value and output O2 is the fractional value.

The output value is limited to the maximum value of the data type range.

Example (from REAL to DINT):

When I = 2.04998779297, O1 = 2 and O2 = 3276.

Inputs The input data type is selected by the user.


Input (I): REAL, REAL24

Outputs Output (O1, O2): DINT

REALn_TO_DINT_SIMP

(10028)

Illustration



Execution time 5.54 μ s

Operation Output (O) is the 32-bit integer equivalent of the REAL/REAL24 input (I) multiplied by the scale input (SCALE).

Error codes are indicated by the error output (ERRC) as follows:

Error code	Description
0	No error
1001	The calculated integer value exceeds the minimum value. The output is set to the minimum value.
1002	The calculated integer value exceeds the maximum value. The output is set to the maximum value.
1003	Scale input is 0. The output is set to 0.
1004	Incorrect scale input, i.e. scale input is < 0 or is not a factor of 10.

Example (from REAL to DINT):

When I = 2.04998779297 and SCALE = 100, O = 204.

Inputs The input data type is selected by the user.

Input (I): REAL, REAL24

Scale input (SCALE): DINT

Outputs Output (O): DINT


Error output (ERRC): DINT

Counters

CTD

(10047)

Illustration



Execution time 0.92 μ s

Operation

The counter output (CV) value is decreased by 1 if the counter input (CD) value changes from 0 -> 1 and the load input (LD) value is 0. If the load input value is 1, the preset input (PV) value is stored as the counter output (CV) value. If the counter output has reached its minimum value -32768, the counter output remains unchanged.

The status output (Q) is 1 if the counter output (CV) value ≤ 0 .

Example:

LD	CD	PV	Q	CV _{prev}	CV
0	1 -> 0	10	0	5	5
0	0 -> 1	10	0	5	5 - 1 = 4
1	1 -> 0	-2	1	4	-2
1	0 -> 1	1	0	-2	1
0	0 -> 1	5	1	1	1 - 1 = 0
1	1 -> 0	-32768	1	0	-32768
0	0 -> 1	10	1	-32768	-32768

CV_{prev} is the previous cycle counter output value.

Inputs

Load input (LD): Boolean
 Counter input (CD): Boolean
 Preset input (PV): INT


Outputs

Counter output (CV): INT
 Status output (Q): Boolean

CTD_DINT

(10046)

Illustration



Execution time 0.92 µs

Operation

The counter output (CV) value is decreased by 1 if the counter input (CD) value changes from 0 -> 1 and the load input (LD) value is 0. If the load input (LD) value is 1, the preset input (PV) value is stored as the counter output (CV) value. If the counter output has reached its minimum value -2147483648, the counter output remains unchanged.

The status output (Q) is 1 if the counter output (CV) value ≤ 0 .

Example:

LD	CD	PV	Q	CV _{prev}	CV
0	1 -> 0	10	0	5	5
0	0 -> 1	10	0	5	5 - 1 = 4
1	1 -> 0	-2	1	4	-2
1	0 -> 1	1	0	-2	1
0	0 -> 1	5	1	1	1 - 1 = 0
1	1 -> 0	-2147483648	1	0	-2147483648
0	0 -> 1	10	1	-2147483648	-2147483648

CV_{prev} is the previous cycle counter output value.

Inputs

Load input (LD): Boolean
 Counter input (CD): Boolean
 Preset input (PV): DINT


Outputs

Counter output (CV): DINT
 Status output (Q): Boolean

CTU

(10049)

Illustration



Execution time 0.92 µs

Operation The counter output (CV) value is increased by 1 if the counter input (CU) value changes from 0 -> 1 and the reset input (R) value is 0. If the counter output has reached its maximum value 32767, the counter output remains unchanged.

The counter output (CV) is reset to 0 if the reset input (R) is 1.

The status output (Q) is 1 if the counter output (CV) value \geq preset input (PV) value.

Example:

R	CU	PV	Q	CV _{prev}	CV
0	1 -> 0	20	0	10	10
0	0 -> 1	11	1	10	10 + 1 = 11
1	1 -> 0	20	0	11	0
1	0 -> 1	5	0	0	0
0	0 -> 1	20	0	0	0 + 1 = 1
0	0 -> 1	30	1	32767	32767

CV_{prev} is the previous cycle counter output value.

Inputs Counter input (CU): Boolean

Reset input (R): Boolean

Preset input (PV): INT


Outputs Counter output (CV): INT

Status output (Q): Boolean

CTU_DINT

(10048)

Illustration



Execution time 0.92 μ s

Operation The counter output (CV) value is increased by 1 if the counter input (CU) value changes from 0 -> 1 and the reset input (R) value is 0. If the counter output has reached its maximum value 2147483647, the counter output remains unchanged.

The counter output (CV) is reset to 0 if the reset input (R) is 1.

The status output (Q) is 1 if the counter output (CV) value \geq preset input (PV) value.

Example:

R	CU	PV	Q	CV _{prev}	CV
0	1 -> 0	20	0	10	10
0	0 -> 1	11	1	10	10 + 1 = 11
1	1 -> 0	20	0	11	0
1	0 -> 1	5	0	0	0
0	0 -> 1	20	0	0	0 + 1 = 1
0	0 -> 1	30	1	2147483647	2147483647


CV_{prev} is the previous cycle counter output value.

Inputs Counter input (CU): Boolean
 Reset input (R): Boolean
 Preset input (PV): DINT

Outputs Counter output (CV): DINT
 Status output (Q): Boolean

**CTUD
 (10051)**

Illustration



Execution time 1.40 µs

Operation

The counter output (CV) value is increased by 1 if the counter input (CU) value changes from 0 -> 1 and the reset input (R) is 0 and the load input (LD) is 0.

The counter output (CV) value is decreased by 1 if the counter input (CD) changes from 0 -> 1 and the load input (LD) is 0 and the reset input (R) is 0.

If the load input (LD) is 1, the preset input (PV) value is stored as the counter output (CV) value.

The counter output (CV) is reset to 0 if the reset input (R) is 1.

If the counter output has reached its minimum or maximum value, -32768 or +32767, the counter output remains unchanged until it is reset (R) or until the load input (LD) is set to 1.

The up counter status output (QU) is 1 if the counter output (CV) value \geq preset input (PV) value.

The down counter status output (QD) is 1 if the counter output (CV) value \leq 0.

Example:

CU	CD	R	LD	PV	QU	QD	CV _{prev}	CV
0 -> 0	0 -> 0	0	0	2	0	1	0	0
0 -> 0	0 -> 0	0	1	2	1	0	0	2
0 -> 0	0 -> 0	1	0	2	0	1	2	0
0 -> 0	0 -> 0	1	1	2	0	1	0	0
0 -> 0	0 -> 1	0	0	2	0	1	0	0 - 1 = -1
0 -> 0	1 -> 1	0	1	2	1	0	-1	2
0 -> 0	1 -> 1	1	0	2	0	1	2	0
0 -> 0	1 -> 1	1	1	2	0	1	0	0
0 -> 1	1 -> 0	0	0	2	0	0	0	0 + 1 = 1
1 -> 1	0 -> 0	0	1	2	1	0	1	2
1 -> 1	0 -> 0	1	0	2	0	1	2	0
1 -> 1	0 -> 0	1	1	2	0	1	0	0
1 -> 1	0 -> 1	0	0	2	0	1	0	0 - 1 = -1
1 -> 1	1 -> 1	0	1	2	1	0	-1	2
1 -> 1	1 -> 1	1	0	2	0	1	2	0
1 -> 1	1 -> 1	1	1	2	0	1	0	0

CV_{prev} is the previous cycle counter output value.

Inputs

Up counter input (CU): Boolean

Down counter input (CD): Boolean

Reset input (R): Boolean

Load input (LD): Boolean

Preset input (PV): INT

Outputs

Counter output (CV): INT


Up counter status output (QU): Boolean

Down counter status output (QD): Boolean

CTUD_DINT

(10050)

Illustration



Execution time 1.40 μs

Operation

The counter output (CV) value is increased by 1 if the counter input (CU) changes from 0 -> 1 and the reset input (R) is 0 and the load input (LD) is 0.

The counter output (CV) value is decreased by 1 if the counter input (CD) changes from 0 -> 1 and the load input (LD) is 0 and the reset input (R) is 0.

If the counter output has reached its minimum or maximum value, -2147483648 or +2147483647, the counter output remains unchanged until it is reset (R) or until the load input (LD) is set to 1.

If the load input (LD) value is 1, the preset input (PV) value is stored as the counter output (CV) value.

The counter output (CV) is reset to 0 if the reset input (R) is 1.

The up counter status output (QU) is 1 if the counter output (CV) value ≥ preset input (PV) value.

The down counter status output (QD) is 1 if the counter output (CV) value ≤ 0.

Example:

CU	CD	R	LD	PV	QU	QD	CV _{prev}	CV
0 -> 0	0 -> 0	0	0	2	0	1	0	0
0 -> 0	0 -> 0	0	1	2	1	0	0	2
0 -> 0	0 -> 0	1	0	2	0	1	2	0
0 -> 0	0 -> 0	1	1	2	0	1	0	0
0 -> 0	0 -> 1	0	0	2	0	1	0	0 - 1 = -1
0 -> 0	1 -> 1	0	1	2	1	0	-1	2
0 -> 0	1 -> 1	1	0	2	0	1	2	0
0 -> 0	1 -> 1	1	1	2	0	1	0	0
0 -> 1	1 -> 0	0	0	2	0	0	0	0 + 1 = 1
1 -> 1	0 -> 0	0	1	2	1	0	1	2
1 -> 1	0 -> 0	1	0	2	0	1	2	0
1 -> 1	0 -> 0	1	1	2	0	1	0	0
1 -> 1	0 -> 1	0	0	2	0	1	0	0 - 1 = -1
1 -> 1	1 -> 1	0	1	2	1	0	-1	2
1 -> 1	1 -> 1	1	0	2	0	1	2	0
1 -> 1	1 -> 1	1	1	2	0	1	0	0

CV_{prev} is the previous cycle counter output value.


Inputs	Up counter input (CU): Boolean
	Down counter input (CD): Boolean
	Reset input (R): Boolean
	Load input (LD): Boolean
	Preset input (PV): DINT
Outputs	Counter output (CV): DINT
	Up counter status output (QU): Boolean
	Down counter status output (QD): Boolean

Edge & bistable

FTRIG

(10030)

Illustration



Execution time 0.38 μ s

Operation

The output (Q) is set to 1 when the clock input (CLK) changes from 1 to 0. The output is set back to 0 with the next execution of the block. Otherwise the output is 0.

CLK _{previous}	CLK	Q
0	0	0
0	1	0
1	0	1 (for one execution cycle time, returns to 0 at the next execution)
1	1	0

CLK_{previous} is the previous cycle output value.

Inputs

Clock input (CLK): Boolean


Outputs

Output (Q): Boolean

RS

(10032)

Illustration



Execution time 0.38 μ s

Operation The output (Q1) is 1 if the set input (S) is 1 and the reset input (R1) is 0. The output will retain the previous output state if the set input (S) and the reset input (R1) are 0. The output is 0 if the reset input is 1.

Truth table:

S	R1	Q1 _{previous}	Q1
0	0	0	0
0	0	1	1
0	1	0	0
0	1	1	0
1	0	0	1
1	0	1	1
1	1	0	0
1	1	1	0

Q_{previous} is the previous cycle output value.


Inputs Set input (S): Boolean

Reset input (R1): Boolean

Outputs Output (Q1): Boolean

RTRIG (10031)

Illustration



Execution time 0.38 μ s

Operation The output (Q) is set to 1 when the clock input (CLK) changes from 0 to 1. The output is set back to 0 with the next execution of the block. Otherwise the output is 0.

CLK _{previous}	CLK	Q
0	0	0
0	1	1
1	0	0
1	1	0

CLK_{previous} is the previous cycle output value.

Note: The output (Q) is 1 after the first execution of the block after cold restart when the clock input (CLK) is 1. Otherwise the output is always 0 when the clock input is 1.


Inputs Clock input (CLK): Boolean

Outputs Output (Q): Boolean

SR

(10033)

Illustration



Execution time 0.38 μ s

Operation The output (Q1) is 1 if the set input (S1) is 1. The output will retain the previous output state if the set input (S1) and the reset input (R) are 0. The output is 0 if the set input is 0 and the reset input is 1.

Truth table:

S1	R	Q1 _{previous}	Q1
0	0	0	0
0	0	1	1
0	1	0	0
0	1	1	0
1	0	0	1
1	0	1	1
1	1	0	1
1	1	1	1

Q1_{previous} is the previous cycle output value.

Inputs Set input (S1): Boolean
Reset input (R): Boolean


Outputs Output (Q1): Boolean

Extensions

FIO_01_slot1

(10084)

Illustration



Execution time 8.6 μ s

Operation The block controls the four digital inputs/outputs (DIO1...DIO4) and two relay outputs (RO1, RO2) of a FIO-01 Digital I/O Extension mounted on slot 1 of the drive control unit. The state of a DIOx conf input of the block determines whether the corresponding DIO on the FIO-01 is an input or an output (0 = input, 1 = output). If the DIO is an output, the DOx input of the block defines its state. The RO1 and RO2 inputs define the state of the relay outputs of the FIO-01 (0 = not energised, 1 = energised). The DIx outputs show the state of the DIOs.


Inputs Digital input/output mode selection (DIO1 conf ... DIO4 conf): Boolean
 Digital output state selection (DO1...DO4): Boolean
 Relay output state selection (RO1, RO2): Boolean

Outputs Digital input/output state (DI1...DI4): Boolean
 Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_01_slot2

(10085)

Illustration



Execution time 8.6 μ s

Operation The block controls the four digital inputs/outputs (DIO1...DIO4) and two relay outputs (RO1, RO2) of a FIO-01 Digital I/O Extension mounted on slot 2 of the drive control unit.

The state of a DIOx conf input of the block determines whether the corresponding DIO on the FIO-01 is an input or an output (0 = input, 1 = output). If the DIO is an output, the DOx input of the block defines its state.

The RO1 and RO2 inputs define the state of the relay outputs of the FIO-01 (0 = not energised, 1 = energised).

The DIx outputs show the state of the DIOs.

Inputs Digital input/output mode selection (DIO1 conf ... DIO4 conf): Boolean

Digital output state selection (DO1...DO4): Boolean


Relay output state selection (RO1, RO2): Boolean

Outputs Digital input/output state (DI1...DI4): Boolean

Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_11_AI_slot1 (10088)


Illustration




Execution time 11.1 μs

Operation The block controls the three analogue inputs (AI1...AI3) of a FIO-11 Analog I/O Extension mounted on slot 1 of the drive control unit.
 The block outputs both the unscaled (AIx) and scaled (AIx scaled) actual values of each analogue input. The scaling is based on the relationship between the ranges AIx min ... AIx max and AIx min scale ... AIx max scale.
 AIx Min must be smaller than AIx Max; AIx Max Scale can be greater or smaller than AIx Min Scale.

AIx Min Scale < AIx Max Scale



Alx Min Scale > Alx Max Scale



The Alx filt gain inputs determine a filtering time for each input as follows:

Alx filt gain	Filtering time	Notes
0	No filtering	
1	125 μ s	Recommended setting
2	250 μ s	
3	500 μ s	
4	1 ms	
5	2 ms	
6	4 ms	
7	7.9375 ms	

The Alx mode outputs show whether the corresponding input is voltage (0) or current (1). The voltage/current selection is made using the hardware switches on the FIO-11.

Inputs


Analogue input filter gain selection (AI1 filt gain ... AI3 filt gain): INT
 Minimum value of input signal (AI1 Min ... AI3 Min): REAL (\geq -11 V or -22 mA)
 Maximum value of input signal (AI1 Max ... AI3 Max): REAL (\leq 11 V or 22 mA)
 Minimum value of scaled output signal (AI1 Min scale ... AI3 Min scale): REAL
 Maximum value of scaled output signal (AI1 Max scale ... AI3 Max scale): REAL

Outputs

Analogue input mode (voltage or current) (AI1 mode ... AI3 mode): Boolean
 Value of analogue input (AI1 ... AI3): REAL
 Scaled value of analogue input (AI1 scaled ... AI3 scaled): REAL
 Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_11_AI_slot2 (10089)

Illustration



Execution time 11.1 μs


Operation

The block controls the three analogue inputs (AI1...AI3) of a FIO-11 Analog I/O Extension mounted on slot 2 of the drive control unit.


The block outputs both the unscaled (AIx) and scaled (AIx scaled) actual values of each analogue input. The scaling is based on the relationship between the ranges AIx min ... AIx max and AIx min scale ... AIx max scale.

AIx Min must be smaller than AIx Max; AIx Max Scale can be greater or smaller than AIx Min Scale.

AIx Min Scale < AIx Max Scale



Alx Min Scale > Alx Max Scale



The Alx filt gain inputs determine a filtering time for each input as follows:

Alx filt gain	Filtering time	Notes
0	No filtering	
1	125 μ s	Recommended setting
2	250 μ s	
3	500 μ s	
4	1 ms	
5	2 ms	
6	4 ms	
7	7.9375 ms	

The Alx mode outputs show whether the corresponding input is voltage (0) or current (1). The voltage/current selection is made using the hardware switches on the FIO-11.

Inputs


Analogue input filter gain selection (AI1 filt gain ... AI3 filt gain): INT
 Minimum value of input signal (AI1 Min ... AI3 Min): REAL (\geq -11 V or -22 mA)
 Maximum value of input signal (AI1 Max ... AI3 Max): REAL (\leq 11 V or 22 mA)
 Minimum value of scaled output signal (AI1 Min scale ... AI3 Min scale): REAL
 Maximum value of scaled output signal (AI1 Max scale ... AI3 Max scale): REAL

Outputs

Analogue input mode (voltage or current) (AI1 mode ... AI3 mode): Boolean
 Value of analogue input (AI1 ... AI3): REAL
 Scaled value of analogue input (AI1 scaled ... AI3 scaled): REAL
 Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_11_AO_slot1 (10090)

Illustration



Execution time 4.9 μ s


Operation

The block controls the analogue output (AO1) of a FIO-11 Analog I/O Extension mounted on slot 1 of the drive control unit.


The block converts the input signal (AO scaled) to a 0...20 mA signal (AO) that drives the analogue output; the input range AO Min Scale ... AO Max Scale corresponds to the current signal range of AO Min ... AO Max.

AO Min Scale must be smaller than AO Max Scale; AO Max can be greater or smaller than AO Min.

AO Min < AO Max




AO Min > AO Max



- Inputs**
- Minimum current signal (AO Min): REAL (0...20 mA)
 - Maximum current signal (AO Max): REAL (0...20 mA)
 - Minimum input signal (AO Min Scale): REAL
 - Maximum input signal (AO Max Scale): REAL
 - Input signal (AO scaled): REAL
- Outputs**
- Analogue output current value (AO): REAL
 - Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_11_AO_slot2 (10091)

Illustration



Execution time 4.9 μ s


Operation

The block controls the analogue output (AO1) of a FIO-11 Analog I/O Extension mounted on slot 2 of the drive control unit.


The block converts the input signal (AO scaled) to a 0...20 mA signal (AO) that drives the analogue output; the input range AO Min Scale ... AO Max Scale corresponds to the current signal range of AO Min ... AO Max.

AO Min Scale must be smaller than AO Max Scale; AO Max can be greater or smaller than AO Min.

AO Min < AO Max



AO Min > AO Max

**Inputs**

Minimum current signal (AO Min): REAL (0...20 mA)
 Maximum current signal (AO Max): REAL (0...20 mA)
 Minimum input signal (AO Min Scale): REAL
 Maximum input signal (AO Max Scale): REAL
 Input signal (AO scaled): REAL


Outputs

Analogue output current value (AO): REAL
 Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_11_DIO_slot1

(10086)

Illustration



Execution time 6.0 μs

Operation The block controls the two digital inputs/outputs (DIO1, DIO2) of a FIO-11 Digital I/O Extension mounted on slot 1 of the drive control unit.
 The state of a DIOx conf input of the block determines whether the corresponding DIO on the FIO-11 is an input or an output (0 = input, 1 = output). If the DIO is an output, the DOx input of the block defines its state.

The DIx outputs show the state of the DIOs.

The DIx filt gain inputs determine a filtering time for each input as follows:

Dix filt gain	Filtering time
0	7.5 μs
1	195 μs
2	780 μs
3	4.680 ms


Inputs Digital input/output mode selection (DIO1 conf, DIO2 conf): Boolean
 Digital output state selection (DO1, DO2): Boolean
 Digital input filter gain selection (DI1 filt gain, DI2 filt gain): INT

Outputs Digital input/output state (DI1, DI2): Boolean
 Error output (Error): DINT (0 = No error; 1 = Application program memory full)

FIO_11_DIO_slot2

(10087)

Illustration



Execution time 6.0 μ s

Operation

The block controls the two digital inputs/outputs (DIO1, DIO2) of a FIO-11 Digital I/O Extension mounted on slot 2 of the drive control unit.

The state of a DIOx conf input of the block determines whether the corresponding DIO on the FIO-11 is an input or an output (0 = input, 1 = output). If the DIO is an output, the DOx input of the block defines its state.

The Dlx outputs show the state of the DIOs.

The Dlx filt gain inputs determine a filtering time for each input as follows:

Dlx filt gain	Filtering time
0	7.5 μ s
1	195 μ s
2	780 μ s
3	4.680 ms

Inputs

Digital input/output mode selection (DIO1 conf, DIO2 conf): Boolean

Digital output state selection (DO1, DO2): Boolean

Digital input filter gain selection (D11 filt gain, D12 filt gain): INT

Outputs

Digital input/output state (D11, D12): Boolean


Error output (Error): DINT (0 = No error; 1 = Application program memory full)

Feedback & algorithms

CYCLET

(10074)

Illustration



Execution time 0.00 μ s

Operation Output (OUT) is the time level of the CYCLET function block.


Inputs -

Outputs Output (OUT): DINT. 1 = 1 μ s

DATA CONTAINER

(10073)



Illustration



Execution time 0.00 μ s

Operation Output (OUT) is an array of data with values 1...99. The array can be used by the XTAB and YTAB tables in the block [FUNG-1V](#) (page 387). The array is defined by selecting "Define Pin Array Data" on the output pin in DriveSPC. Each value in the array must be on a separate row. Data can also be read from an *.arr file.

Example:




Inputs -

Outputs The output data type and the number of coordinate pairs are selected by the user.
Output (OUT): DINT, INT, REAL or REAL24

FUNG-1V

(10072)

Illustration



Execution time 9.29 μ s


Operation

The output (Y) at the value of the input (X) is calculated with linear interpolation from a piecewise linear function.

$$Y = Y_k + (X - X_k)(Y_{k+1} - Y_k) / (X_{k+1} - X_k)$$

The piecewise linear function is defined by the X and Y vector tables (XTAB and YTAB). For each X-value in the XTAB table, there is a corresponding Y-value in the YTAB table. The values in XTAB and YTAB must be in ascending order (i.e. from low to high).

XTAB and YTAB values are defined with the DriveSPC tool.



The balancing function (BAL) permits the output signal to track an external reference and gives a smooth return to the normal operation. If BAL is set to 1, output Y is set to the value of the balance reference input (BALREF). The X value which corresponds to this Y value is calculated with linear interpolation and it is indicated by the balance reference output (BALREFO).

If the X input is outside the range defined by the XTAB table, the output Y is set to the highest or lowest value in the YTAB table.

If BALREF is outside the range defined by the YTAB table when balancing is activated (BAL: 0 -> 1), the output Y is set to the value of the BALREF input and the BALREFO output is set to the highest or lowest value in the XTAB table.

The ERROR output is set to 1 when the number of the XTAB and YTAB inputs are different. When ERROR is 1, the FUNG-1V block will not function. XTAB and YTAB tables can be defined in the [DATA CONTAINER](#) block (page 386) or the [REG-G](#) block (page 393).

Inputs

The input data type is selected by the user.

Balance input (BAL): Boolean

Balance reference input (BALREF): DINT, INT, REAL, REAL24.

X value input (X): DINT, INT, REAL, REAL24

X table input (XTAB): DINT, INT, REAL, REAL24


Y table input (YTAB): DINT, INT, REAL, REAL24

Outputs Y value output (Y): DINT, INT, REAL, REAL24
 Balance reference output (BALREFO): DINT, INT, REAL, REAL24
 Error output (ERROR): Boolean

INT

(10065)

Illustration



Execution time 4.73 μs


Operation The output (O) is the integrated value of the input (I):
 $O(t) = K/TI \int I(t) dt$
 Where TI is the integration time constant and K is the integration gain.
 The step response for the integration is:
 $O(t) = K \times I(t) \times t/TI$
 The transfer function for the integration is:
 $G(s) = K \ 1/sTI$
 The output value is limited according to the defined minimum and maximum limits (OLL and OHL). If the value is below the minimum value, output O = LL is set to 1. If the value exceeds the maximum value, output O = HL is set to 1. The output (O) retains its value when the input signal I(t) = 0.
 The integration time constant is limited to value 2147483 ms. If the time constant is negative, zero time constant is used.
 If the ratio between the cycle time and the integration time constant $Ts/TI < 1$, Ts/TI is set to 1.
 The integrator is cleared when the reset input (RINT) is set to 1.
 If BAL is set to 1, output O is set to the value of the input BALREF. When BAL is set back to 0, normal integration operation continues.

Inputs Input (I): REAL
 Gain input (K): REAL
 Integration time constant input (TI): DINT, 0...2147483 ms
 Integrator reset input (RINT): Boolean
 Balance input (BAL): Boolean
 Balance reference input (BALREF): REAL
 Output high limit input (OHL): REAL
 Output low limit input (OLL): REAL

Outputs Output (O): REAL
 High limit output (O=HL): Boolean
 Low limit output (O=LL): Boolean

MOTPOT (10067)

Illustration



Execution time 2.92 μ s

Operation The motor potentiometer function controls the rate of change of the output from the minimum to the maximum value and vice versa.
 The function is enabled by setting the ENABLE input to 1. If the up input (UP) is 1, the output reference (OUTPUT) is increased to the maximum value (MAXVAL) with the defined ramp time (RAMPTIME). If the down input (DOWN) is 1, the output value is decreased to the minimum value (MINVAL) with the defined ramp time. If the up and down inputs are activated/deactivated simultaneously, the output value is not increased/decreased.

If the RESET input is 1, the output will be reset to the value defined by the reset value input (RESETVAL) or to the value defined by the minimum input (MINVAL), whichever is higher.

If the ENABLE input is 0, the output is zero.

Digital inputs are normally used as up and down inputs.


Inputs Function enable input (ENABLE): Boolean
 Up input (UP): Boolean
 Down input (DOWN): Boolean
 Ramp time input (RAMPTIME): REAL (seconds) (i.e. the time required for the output to change from the minimum to the maximum value or from the maximum to the minimum value)
 Maximum reference input (MAXVAL): REAL
 Minimum reference input (MINVAL): REAL
 Reset value input (RESETVAL): REAL
 Reset input (RESET): Boolean

Outputs Output (OUTPUT) REAL

PID

(10075)

Illustration



Execution time 15.75 μs

Operation

The PID controller can be used for closed-loop control systems. The controller includes anti-windup correction and output limitation.

The PID controller output (Out) before limitation is the sum of the proportional (U_P), integral (U_I) and derivative (U_D) terms:

$$\text{Out}_{\text{unlimited}}(t) = U_P(t) + U_I(t) + U_D(t)$$

$$U_P(t) = P \times \text{Dev}(t)$$

$$U_I(t) = P/tI \times \left[\int \text{Dev}(\tau) d\tau + tC \times (\text{Out}(t) - \text{Out}_{\text{unlimited}}(t)) \right]$$

$$U_D(t) = P \times tD \times d(\text{Dev}(t))/dt$$

Integrator:

The integral term can be cleared by setting I_reset to 1. Note that the anti-windup correction is simultaneously disabled. When I_reset is 1, the controller acts as a PD controller.

If integration time constant tI is 0, the integral term will not be updated.

Smooth return to normal operation is guaranteed after errors or abrupt input value changes. This is achieved by adjusting the integral term so that the output will retain its previous value during these situations.

Limitation:

The output is limited by the defined minimum and maximum values, OLL and OHL:

If the actual value of the output reaches the specified minimum limit, output $O=LL$ is set to 1.

If the actual value of the output reaches the specified maximum limit, output $O=HL$ is set to 1.

Smooth return to normal operation after limitation is requested if and only if the anti-windup correction is not used, i.e. when $tI = 0$ or $tC = 0$.

Error codes:

Error codes are indicated by the error output (ERROR) as follows

Error code	Description
1	The minimum limit (OLL) exceeds the maximum limit (OHL).
2	Overflow with U_p , U_i , or U_d calculation

Balancing:

The balancing function (BAL) permits the output signal to track an external reference and gives a smooth return to the normal operation. If BAL is set to 1, the output (Out) is set to the value of the balance reference input (BAL_ref). Balance reference is limited by the defined minimum and maximum limits (OLL and OHL).


Anti-windup:

Anti-windup correction time constant is defined by input tC , which defines the time after which the difference between the unlimited and limited outputs is subtracted from the I-term during limitation. If $tC = 0$ or $tI = 0$, anti-windup correction is disabled.

- Inputs**
- Actual input (IN_act): REAL
 - Reference input (IN_ref): REAL
 - Proportional gain input (P): REAL
 - Integration time constant input (tI): REAL. 1 = 1 ms
 - Derivation time constant input (tD): REAL. 1 = 1 ms
 - Antiwind-up correction time constant input (tC): IQ6. 1 = 1 ms
 - Integrator reset input (I_reset): Boolean
 - Balance input (BAL): Boolean
 - Balance reference input (BAL_ref): REAL
 - Output high limit input (OHL): REAL
 - Output low limit input (OLL): REAL
- Outputs**
- Output (Out): REAL
 - Deviation output (Dev): REAL (= actual -reference = IN_act - IN_ref)
 - High limit output (O=HL): Boolean
 - Low limit output (O=LL): Boolean
 - Error code output (ERROR): INT32

RAMP (10066)

Illustration



Execution time 4.23 µs

Operation

Limits the rate of the change of the signal.

The input signal (IN) is connected directly to the output (O) if the input signal does not exceed the defined step change limits (STEP+ and STEP-). If the input signal change exceeds these limits, the output signal change is limited by the maximum step change (STEP+/STEP- depending on the direction of rotation). After this, the output signal is accelerated/decelerated by the defined ramp value (SLOPE+/SLOPE-) per second until the input and output signal values are equal.


The output is limited by the defined minimum and maximum values (OLL and OHL). If the actual value of the output falls below the specified minimum limit (OLL), output O=LL is set to 1. If the actual value of the output exceeds the specified maximum limit (OHL), output O=HL is set to 1.

If the balancing input (BAL) is set to 1, the output (O) is set to the value of the balance reference input (BAL_ref). Balancing reference is also limited by the minimum and maximum values (OLL and OHL).

- Inputs**
- Input (IN): REAL
 - Maximum positive step change input (STEP+): REAL
 - Maximum negative step change input (STEP-): REAL
 - Ramp-up value per second input (SLOPE+): REAL
 - Ramp-down value per second input (SLOPE-): REAL
 - Balance input (BAL): Boolean
 - Balance reference input (BALREF): REAL
 - Output high limit input (OHL): REAL
 - Output low limit input (OLL): REAL
- Outputs**
- Output (O): REAL
 - High limit output (O=HL): Boolean
 - Low limit output (O=LL): Boolean

REG-G
(10102)

Illustration



Execution time -

Operation

Combines the array (group of variables) (if any) on the EXP input with the values of the I1...I32 pins to produce an output array. The data type of the arrays can be INT, DINT, REAL16, REAL24 or Boolean. The output array consists of the data from the EXP input and the values of the I1...In (in this order).

When input S is 1, data is continuously assembled into the output array. The element acts as a latch when input S is 0; the latest data assembled then remains at the output.


If S is 0 and L changes state from 0 to 1, the array from the EXP input and the values of the I1...In inputs are copied to output O during this program cycle. If S or R is 1, L has no effect.

WR and AWR are used to change individual cells of the output array. AWR indicates the input whose value is moved to the output array. If AWR is 0, only the array from input EXP is moved to the output. If AWR is not 0, the corresponding I input is moved to the output. This is performed when WR goes from 0 to 1.

When input R is 1, the output array is cleared and all further data entry is prevented. R overrides both S and L. If WR is 1, the address at AWR is checked and if it is illegal (negative or greater than the number of inputs), the error output (ERR) is set to 2. Otherwise ERR is 0.

Whenever an error is detected, ERR is set within one cycle. No place in the register is affected when an error occurs.

Example:



In the diagram, the DATA CONTAINER block includes an array with values [1,2,3,4]. At start, the output array is [0,0,0,0,0,0,0,0]. When WR changes to 1 and returns to 0, the AWR value of 0 means that only EXP is moved into the output array, which now reads [1,2,3,4,0,0,0,0]. After this, AWR is changed to 3, meaning that inputs EXP and I3 are moved to the output. After a WR switch, the output array is [1,2,3,4,0,0,7,0].

Inputs

- Set (S): Boolean, INT, DINT, REAL, REAL24
- Load (L): Boolean, INT, DINT, REAL, REAL24
- Write (WR): Boolean, INT, DINT, REAL, REAL24
- Write address (AWR): INT
- Reset (R): Boolean
- Expander (EXP): IArray
- Data input (I1...I32): Boolean, INT, DINT, REAL, REAL24


Outputs

- Error (ERR): INT
- Array data output (O): OC1

SOLUTION_FAULT

(10097)

Illustration



Execution time -

Operation When the block is enabled (by setting the Enable input to 1), a fault (F-0317 SOLUTION FAULT) is generated by the drive. The value of the Flt code ext input is recorded by the fault logger.

Inputs Fault code extension (Flt code ext): DINT
Generate fault (Enable): Boolean


Outputs -

Filters

FILT1

(10069)

Illustration



Execution time 7.59 μ s

Operation The output (O) is the filtered value of the input (I) value and the previous output value (O_{prev}). The FILT1 block acts as 1st order low pass filter.

Note: Filter time constant (T1) must be selected so that $T1/Ts < 32767$. If the ratio exceeds 32767, it is considered as 32767. Ts is the cycle time of the program in ms.

If $T1 < Ts$, the output value is the input value.

The step response for a single pole low pass filter is:

$$O(t) = I(t) \times (1 - e^{-t/T1})$$

The transfer function for a single pole low pass filter is:

$$G(s) = 1 / (1 + sT1)$$

Inputs Input (I): REAL

Filter time constant input (T1): DINT, 1 = 1 ms


Outputs Output (O): REAL

Parameters

GetBitPtr

(10099)

Illustration



Execution time -

Operation Reads the status of one bit within a parameter value cyclically. The Bit ptr input specifies the parameter group, index and bit to be read. The output (Out) provides the value of the bit.


Inputs Parameter group, index and bit (Bit ptr): DINT

Outputs Bit status (Out): DINT

GetValPtr

(10098)

Illustration



Execution time -

Operation Reads the value of a parameter cyclically. The Par ptr input specifies the parameter group and index to be read. The output (Out) provides the value of the parameter.


Inputs Parameter group and index (Par ptr): DINT

Outputs Parameter value (Out): DINT

PARRD

(10082)

Illustration



Execution time 6.00 μ s

Operation Reads the scaled value of a parameter (specified by the Group and Index inputs). If the parameter is a pointer parameter, the Output pin provides the number of the source parameter instead of its value.

Error codes are indicated by the error output (Error) as follows:

Error code	Description
0	No error
<> 0	Error

See also blocks [PARRDINTR](#) and [PARRDPTR](#).

Inputs Parameter group input (Group): DINT

Parameter index input (Index): DINT


Outputs Output (Output): DINT

Error output (Error): DINT

PARRDINTR

(10101)

Illustration



Execution time -

Operation Reads the internal (non-scaled) value of a parameter (specified by the Group and Index inputs). The value is provided by the Output pin.

Error codes are indicated by the error output (Error) as follows:

Error code	Description
0	No error or busy
<> 0	Error

Note: Using this block may cause incompatibility issues when upgrading the application to another firmware version.

Inputs Parameter group (Group): DINT

Parameter index (Index): DINT


Outputs Output (Output): Boolean, INT, DINT, REAL, REAL24

Error output (Error): DINT

PARRDPTR

(10100)

Illustration



Execution time -

Operation Reads the internal (non-scaled) value of the source of a pointer parameter. The pointer parameter is specified using the Group and Index inputs.

The value of the source selected by the pointer parameter is provided by the Output pin. Error codes are indicated by the error output (Error) as follows:

Error code	Description
0	No error or busy
<> 0	Error

Inputs Parameter group (Group): DINT

Parameter index (Index): DINT


Outputs Output (Output): Boolean, INT, DINT, REAL, REAL24

Error output (Error): DINT

PARWR

(10080)

Illustration



Execution time 14.50 μ s

Operation The input value (IN) is written to the defined parameter (Group and Index).

The new parameter value is stored to the flash memory if the store input (Store) is 1.

Note: Cyclic parameter value storing can damage the memory unit. Parameter values should be stored only when necessary.

Error codes are indicated by the error output (Error) as follows:

Error code	Description
0	No error
<> 0	Error

Inputs Input (IN): DINT

Parameter group input (Group): DINT

Parameter index input (Index): DINT

Store input (Store): Boolean


Outputs Error output (Error): DINT

Program structure

BOP

(10105)

Illustration



Execution time -

Operation The BOP (Bundle OutPut) block collects the outputs of several different sources. The sources are connected to the B_Output pins. The B_Output pin that changed last is relayed to the Output pin.


The block is intended for use with conditional IF-ENDIF structures. See the example under the IF block.

Inputs Values from different conditional branches (B_Output1...B_OutputN): INT, DINT, Boolean, REAL, REAL24

Outputs Output from currently active branch of a IF-ELSEIF structure or latest updated input value (Output): INT, DINT, Boolean, REAL, REAL24

ELSE

Illustration



Execution time -


Operation See description of IF block.

Inputs -

Outputs -

ELSEIF

Illustration



Execution time -


Operation See description of IF block.

Inputs Input (COND): Boolean

Outputs -

ENDIF

Illustration



Execution time -


Operation See description of IF block.

Inputs -

Outputs -

IF (10103)

Illustration



Execution time -


Operation

The IF, ELSE, ELSEIF and ENDIF blocks define, by Boolean logic, which parts of the application program are executed. If the condition input (COND) is true, the blocks between the IF block and the next ELSEIF, ELSE or ENDIF block (in execution order) are run. If the condition input (COND) is false, the blocks between the IF block and the next ELSEIF, ELSE or ENDIF block are skipped.

The outputs of the “branches” are collected and selected by using the BOP block.

Example:

Bit 4 of 2.01 DI STATUS (digital input DI5) controls the branching of the application program. If the input is 0, the blocks between the IF and ELSE blocks are skipped but the blocks between ELSE and ENDIF are run. If the input is 1, the blocks between IF and ELSE are run. The program execution then jumps to the block that follows ENDIF, which is a BOP. The BOP block outputs the value from the branch that was executed. If the digital input is 0, the BOP block output is 2; if the digital input is 1, the BOP block output is 1.



Inputs

Input (COND): Boolean

Outputs


-

Selection

LIMIT

(10052)

Illustration



Execution time 0.53 μ s

Operation The output (OUT) is the limited input (IN) value. Input is limited according to the minimum (MN) and maximum (MX) values.


Inputs The input data type is selected by the user.
 Minimum input limit (MN): INT, DINT, REAL, REAL24
 Input (IN): INT, DINT, REAL, REAL24
 Maximum input limit (MX): INT, DINT, REAL, REAL24

Outputs Output (OUT): INT, DINT, REAL, REAL24

MAX

(10053)

Illustration



Execution time 0.81 μ s (when two inputs are used) + 0.53 μ s (for every additional input). When all inputs are used, the execution time is 16.73 μ s.

Operation The output (OUT) is the highest input value (IN).


Inputs The input data type and the number of inputs (2...32) are selected by the user.
 Input (IN1...IN32): INT, DINT, REAL, REAL24

Outputs Output (OUT): INT, DINT, REAL, REAL24

MIN

(10054)

Illustration




Execution time 0.81 μ s (when two inputs are used) + 0.52 μ s (for every additional input). When all inputs are used, the execution time is 16.50 μ s.

- Operation** The output (OUT) is the lowest input value (IN).
- Inputs** The input data type and the number of inputs (2...32) are selected by the user.
Input (IN1...IN32): INT, DINT, REAL, REAL24
- Outputs** Output (OUT): INT, DINT, REAL, REAL24

MUX

(10055)

Illustration




- Execution time** 0.70 μ s
- Operation** The value of an input (IN) selected by the address input (K) is stored to the output (OUT).
If the address input is 0, negative or exceeds the number of the inputs, the output is 0.
- Inputs** The input data type and number of inputs (2...32) are selected by the user.
Address input (K): DINT
Input (IN1...IN32): INT, DINT, REAL, REAL24
- Outputs** Output (OUT): INT, DINT, REAL, REAL24

SEL

(10056)

Illustration




- Execution time** 1.53 μ s
- Operation** The output (OUT) is the value of the input (IN) selected by the selection input (G).
If G = 0: OUT = IN A.
If G = 1: OUT = IN B.
- Inputs** The input data type is selected by the user.
Selection input (G): Boolean
Input (IN A, IN B): Boolean, INT, DINT, REAL, REAL24
- Outputs** Output (OUT): Boolean, INT, DINT, REAL, REAL24

Switch & Demux

DEMUX-I

(10061)

Illustration



Execution time 1.38 μs (when two outputs are used) + 0.30 μs (for every additional output). When all outputs are used, the execution time is 10.38 μs .

Operation Input (I) value is stored to the output (OA1...OA32) selected by the address input (A). All other outputs are 0.
If the address input is 0, negative or exceeds the number of the outputs, all outputs are 0.


Inputs The input data type is selected by the user.
Address input (A): DINT
Input (I): INT, DINT, Boolean, REAL, REAL24

Outputs The number of the output channels (1...32) is selected by the user.
Output (OA1...OA32): INT, DINT, REAL, REAL24, Boolean

DEMUX-MI

(10062)

Illustration



Execution time 0.99 μs (when two outputs are used) + 0.25 μs (for every additional output). When all outputs are used, the execution time is 8.4 μs .

Operation The input (I) value is stored to the output (OA1...OA32) selected by the address input (A) if the load input (L) or the set input (S) is 1. When the load input is set to 1, the input (I) value is stored to the output only once. When the set input is set to 1, the input (I) value is stored to the output every time the block is executed. The set input overrides the load input.

If the reset input (R) is 1, all connected outputs are 0.

If the address input is 0, negative or exceeds the number of the outputs, all outputs are 0.

Example:

S	L	R	A	I	OA1	OA2	OA3	OA4
1	0	0	2	150	0	150	0	0
0	0	0	2	120	0	150	0	0
0	1	0	3	100	0	150	100	0
1	0	0	1	200	200	150	100	0
1	1	0	4	250	200	150	100	250
1	1	1	2	300	0	0	0	0

Inputs The input data type is selected by the user.

Address input (A): DINT

Reset input (R): Boolean

Load input (L): Boolean

Set input (S): Boolean

Input (I): DINT, INT, REAL, REAL24, Boolean


Outputs The number of the output channels (1...32) is selected by the user.

Output (OA1...OA32): DINT, INT, REAL, REAL24, Boolean

SWITCH

(10063)

Illustration



Execution time 0.68 μs (when two inputs are used) + 0.50 μs (for every additional input). When all inputs are used, the execution time is 15.80 μs.

Operation The output (OUT) is equal to the corresponding input (IN) if the activate input (ACT) is 1. Otherwise the output is 0.

Inputs The input data type and the number of inputs (1...32) are selected by the user.

Activate input (ACT): Boolean


Input (IN1...IN32): INT, DINT, REAL, REAL24, Boolean

Outputs Output (OUT1...OUT32): INT, DINT, REAL, REAL24, Boolean

SWITCHC

(10064)

Illustration



Execution time 1.53 μ s (when two inputs are used) + 0.73 μ s (for every additional input). When all inputs are used, the execution time is 23.31 μ s.

Operation The output (OUT) is equal to the corresponding channel A input (CH A1...32) if the activate input (ACT) is 0. The output is equal to the corresponding channel B input (CH B1...32) if the activate input (ACT) is 1.

Inputs The input data type and the number of inputs (1...32) are selected by the user.
 Activate input (ACT): Boolean
 Input (CH A1...CH A32, CH B1...CH B32): INT, DINT, REAL, REAL24, Boolean


Outputs Output (OUT1...OUT32): INT, DINT, REAL, REAL24, Boolean

Timers

MONO

(10057)

Illustration




Execution time 1.46 μ s


Operation

The output (O) is set to 1 and the timer is started, if the input (I) is set to 1. The output is reset to 0 when the time defined by the time pulse input (TP) has elapsed. Elapsed time (TE) count starts when the output is set to 1 and stops when the output is set to 0. If RTG is 0, a new input pulse during the time defined by TP has no effect on the function. The function can be restarted only after the time defined by TP has elapsed. If RTG is 1, a new input pulse during the time defined by TP restarts the timer and sets the elapsed time (TE) to 0.

Example 1: MONO is not re-triggable, i.e. RTG = 0.




Example 2: MONO is re-triggable, i.e. RTG = 1.



- Inputs**
 - Re-trigger input (RTG): Boolean
 - Time pulse input (TP): DINT (1 = μ s)
 - Input (I): Boolean
- Outputs**
 - Output (O): Boolean
 - Time elapsed output (TE): DINT (1 = 1 μ s)

TOF (10058)

Illustration




Execution time 1.10 μ s

Operation

The output (Q) is set to 1, when the input (IN) is set to 1. The output is reset to zero when the input has been 0 for a time defined by the pulse time input (PT).

Elapsed time count (ET) starts when the input is set to 0 and stops when the input is set to 1.

Example:



Inputs

Input (IN): Boolean

Pulse time input (PT): DINT (1 = 1 μ s)


Outputs

Elapsed time output (ET): DINT (1 = 1 μ s)

Output (Q): Boolean

TON (10059)

Illustration




Execution time 1.22 μ s

Operation The output (Q) is set to 1 when the input (IN) has been 1 for a time defined by the pulse time input (PT). The output is set to 0, when the input is set to 0.

Elapsed time count (ET) starts when the input is set to 1 and stops when the input is set to 0.

Example:




Inputs Input (IN): Boolean
Pulse time input (PT): DINT (1 = 1 μ s)

Outputs Elapsed time output (ET): DINT (1 = 1 μ s)
Output (Q): Boolean

TP (10060)


Illustration



Execution time 1.46 μ s

Operation The output (Q) is set to 1 when the input (IN) is set to 1. The output is set to 0, when it has been 1 for a time defined by the pulse time input (PT).

Elapsed time count (ET) starts when the input is set to 1 and stops when the input is set to 0.



Inputs Pulse time input (PT): DINT (1 = 1 μ s)
Input (IN): Boolean

Outputs Output (Q): Boolean
Elapsed time output (ET): DINT (1 = 1 μ s)

Application program template


What this chapter contains


This chapter presents the application program template as displayed by the DriveSPC tool after empty template upload (Drive - Upload Template from Drive).

ACTUAL VALUES		14
TUF10 2 msec	(1)	
1.02 SPEED ACT PERC	↑	
1.03 FREQUENCY	↑	
1.04 CURRENT	↑	
1.05 CURRENT PERC	↑	
1.06 TORQUE	↑	
1.07 DC-VOLTAGE		
1.14 SPEED ESTIMATED		
1.15 TEMP INVERTER		
1.16 TEMP BC		
1.20 BRAKE RES LOAD		
1.22 INVERTER POWER		
1.26 ON TIME COUNTER		
1.27 RUN TIME COUNTER		
1.28 FAN ON-TIME		
1.31 MECH TIME CONST		
1.38 TEMP INT BOARD		

Exp. 1. Sample	Based on	Prepared	Title	Doc. des.
1.0000000000000000	Commer	Commer		Resp./dpt.
Firmware Library ID = 1, Ver = 1.0	Cur. Doc. No.	Project Name	ABB	Doc. No.
Standard Library ID = 10000, Ver = 1.1	DWG			








BRAKE CHOPPER	
TFUF10	2 ms (1)
(Drive value)	48.01 BC ENABLE
(Drive value)	< 48.02 BC RUN-TIME EMA
(Drive value)	48.03 BRTHERM/TIMECONST
(Drive value)	48.04 BR POWER MAX CNT
(Drive value)	48.05 R BR
(Drive value)	48.06 BR TEMP FAULT LIM
(Drive value)	48.07 BR TEMP ALARM LIM

VOLTAGE CTRL	
TFUF11	10 ms (1)
(Drive value)	1.19 USED SUPPLY VOLT
(Drive value)	47.01 OVERVOLTAGE CTRL
(Drive value)	47.02 UNDERVOLT CTRL
(Drive value)	47.03 SUPPLYVOLT/AUTO-ID
(Drive value)	47.04 SUPPLY VOLTAGE
(Drive value)	< 47.05 LOW VOLT MOD ENA
(Drive value)	47.06 LOW VOLT DC MIN
(Drive value)	47.07 LOW VOLT DC MAX
(Drive value)	< 47.08 EXT PU SUPPLY

Exp. 5_DrvsControl	38	Doc. des.	
Project Name	ABB	Resp. dpt.	
Firmware Library ID = 1, ver = 1.0		Doc. No.	
Standard Library ID = 10000, ver = 1.1			
Based on			
Committer			
Ctrl. Doc. No.			
DAW			
Prepared			
Project Name			
Title			










Fig. 7 - Speed Control Parameters	TLER 250	Standard Library ID = 10000, ver = 1.1
Based on	Customer	Date
Prepared	Product name	
Title		Doc. des.
Author		Resp. des.
Curt. Doc. No.		Doc. No.
Part No.		



Doc. title	ABS
Doc. No.	
Doc. date	
Doc. disp.	
Doc. No.	
Doc. title	ABS
Doc. No.	
Doc. date	
Doc. disp.	
Doc. No.	
Doc. title	ABS
Doc. No.	
Doc. date	
Doc. disp.	
Doc. No.	








Page: 11 Position Ctrl
 File compatibility level = 1.79
 Standard Library ID = 10000, Ver = 1.1

Based on
 Customer
 Date


Prepared
 Approved
 Project name

Title
AMB

Doc. des.
 Descr. diff.
 Doc. No.



Page 31 - Motor Ctrl	Based on	Prepared	Title	Doc. des.
Standard Library ID = 1.0	Customer	Project Name		Res.P.#/P.#
Standard Library ID = 1.0, ver = 1.0	Cur. Doc. No.		ABB	Doc. No.
Standard Library ID = 10000, ver = 1.1	Rev			




Appendix A – Fieldbus control

What this chapter contains

The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.

System overview

The drive can be connected to an external control system via a fieldbus adapter module. The adapter module is installed into drive Slot 3.



The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the fieldbus interface and other available sources, for example, digital and analogue inputs.

Fieldbus adapters are available for various serial communication protocols, for example:

- PROFIBUS DP (FPBA-xx adapter)
- CANopen (FCAN-xx adapter)
- DeviceNet™ (FDNA-xx adapter)
- Modbus/RTU (FSCA-xx adapter)
- Modbus/TCP, EtherNet/IP™, PROFINET IO (FENA-xx adapter)

- EtherCAT® (FECA-xx adapter)
- MACRO (FMAC-xx adapter)
- ControlNet™ (FCNA-xx adapter)
- EthernetPOWERLINK (FEPL-xx adapter)
- Sercos II (FSEA-xx adapter).

Setting up communication through a fieldbus adapter module

Before configuring the drive for fieldbus control, the adapter module must be mechanically and electrically installed according to the instructions given in the *User's Manual* of the appropriate fieldbus adapter module.

The communication between the drive and the fieldbus adapter module is activated by setting parameter **50.01 FBA ENABLE** to **(1) Enable**. The adapter-specific parameters must also be set. See the table below.

Parameter	Setting for fieldbus control	Function/Information
COMMUNICATION INITIALISATION AND SUPERVISION		
50.01 FBA ENABLE	(1) Enable	Initialises communication between drive and fieldbus adapter module.
50.02 COMM LOSS FUNC	(0) No (1) Fault (2) Spd ref Safe (3) Last speed	Selects how the drive reacts upon a fieldbus communication break.
50.03 COMM LOSS T OUT	0.3...6553.5 s	Defines the time between communication break detection and the action selected with parameter 50.02 COMM LOSS FUNC .
50.04 FBA REF1 MODESEL and 50.05 FBA REF2 MODESEL	(0) Raw data (1) Torque (2) Speed (3) Position (4) Velocity (5) Auto	Defines the fieldbus reference scaling. When (0) Raw data is selected, see also parameters 50.06...50.11 . When both parameters are set to (5) Auto , the scalings for fieldbus references are set automatically according to parameter 34.03 EXT1 CTRL MODE1 as follows: 34.03 = (1) Speed, (2) Torque, (3) Min, (4) Max or (5) Add: FBA REF1 = Speed, FBA REF2 = Torque 34.03 = (6) Position, (7) Synchron, (8) Homing, (9) Prof Vel: FBA REF1 = Position, FBA REF2 = Velocity
ADAPTER MODULE CONFIGURATION		
51.01 FBA TYPE	–	Displays the type of the fieldbus adapter module.
51.02 FBA PAR2 ••• 51.26 FBA PAR26	These parameters are adapter module-specific. For more information, see the <i>User's Manual</i> of the fieldbus adapter module. Note that not all of these parameters are necessarily used.	
51.27 FBA PAR REFRESH	(0) DONE (1) REFRESH	Validates any changed adapter module configuration parameter settings.
51.28 PAR TABLE VER	–	Displays the parameter table revision of the fieldbus adapter module mapping file stored in the memory of the drive.
51.29 DRIVE TYPE CODE	–	Displays the drive type code of the fieldbus adapter module mapping file stored in the memory of the drive.

Parameter	Setting for fieldbus control	Function/Information
51.30 MAPPING FILE VER	–	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive.
51.31 D2FBA COMM STA	–	Displays the status of the fieldbus adapter module communication.
51.32 FBA COMM SW VER	–	Displays the common program revision of the adapter module.
51.33 FBA APPL SW VER	–	Displays the application program revision of the adapter module.
Note: In the <i>User's Manual</i> of the fieldbus adapter module, the parameter group number is 1 or A for parameters 51.01...51.26 .		
TRANSMITTED DATA SELECTION		
52.01 FBA DATA IN1 ... 52.12 FBA DATA IN12	0 4...6 14...16 101...9999	Defines the data transmitted from drive to fieldbus controller. Note: If the selected data is 32 bits long, two parameters are reserved for the transmission.
53.01 FBA DATA OUT1 ... 53.12 FBA DATA OUT12	0 1...3 11...13 1001...9999	Defines the data transmitted from fieldbus controller to drive. Note: If the selected data is 32 bits long, two parameters are reserved for the transmission.
Note: In the <i>User's Manual</i> of the fieldbus adapter module, the parameter group number is 2 or B for parameters 52.01...52.12 and 3 or C for parameters 53.01...53.12 .		

After the module configuration parameters have been set, the drive control parameters (see section [Setting the drive control parameters](#) below) must be checked and adjusted when necessary.

The new settings will take effect when the drive is powered up the next time, or when parameter [51.27 FBA PAR REFRESH](#) is activated.

Setting the drive control parameters


The **Setting for fieldbus control** column gives the value to use when the fieldbus interface is the desired source or destination for that particular signal. The **Function/Information** column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information
CONTROL COMMAND SOURCE SELECTION		
10.01 EXT1 START FUNC	(3) FBA	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.
10.04 EXT2 START FUNC	(3) FBA	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.
24.01 SPEED REF1 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as speed reference 1.
24.02 SPEED REF2 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as speed reference 2.
32.01 TORQ REF1 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as torque reference 1.
32.02 TORQ REF ADD SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used for torque reference addition.
65.04 POS REF 1 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as positioning reference when position reference set 1 is used.
65.12 POS REF 2 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as positioning reference when position reference set 2 is used.
65.21 POS REF ADD SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as additional position reference.
65.22 PROF VEL REF SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as speed reference in profile velocity mode.
67.01 SYNC REF SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as position reference in synchron control.
67.02 VIRT MAS REF SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as virtual master speed reference.
SYSTEM CONTROL INPUTS		
16.07 PARAM SAVE	(0) Done (1) Save	Saves parameter value changes (including those made through fieldbus control) to permanent memory.

Basics of the fieldbus adapter interface

The cyclic communication between a fieldbus system and the drive consists of 16/32-bit input and output data words. The drive supports at the maximum the use of 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters [52.01 FBA DATA IN1](#)...[52.12 FBA DATA IN12](#) and data transmitted from the fieldbus controller to the drive is defined by parameters [53.01 FBA DATA OUT1](#)...[53.12 FBA DATA OUT12](#).



Control Word and Status Word

The Control Word (CW) is the principal means of controlling the drive from a fieldbus system. The Control Word is sent by the fieldbus controller to the drive. The drive

switches between its states according to the bit-coded instructions of the Control Word.

The Status Word (SW) is a word containing status information, sent by the drive to the fieldbus controller.

Actual values

Actual values (ACT) are 16/32-bit words containing information on selected operations of the drive.

FBA communication profile

The FBA communication profile is a state machine model which describes the general states and state transitions of the drive. The [State diagram](#) on page 433 presents the most important states (including the FBA profile state names). The FBA Control Word ([2.12 FBA MAIN CW](#), page 97) commands the transitions between these states and the FBA Status Word ([2.13 FBA MAIN SW](#), page 100) indicates the status of the drive.

Fieldbus adapter module profile (selected by adapter module parameter) defines how the control word and status word are transmitted in a system which consists of fieldbus controller, fieldbus adapter module and drive. With transparent modes, control word and status word are transmitted without any conversion between the fieldbus controller and the drive. With other profiles (eg, PROFIdrive for FPBA-01, AC/DC drive for FDNA-01, DS-402 for FCAN-01 and ABB Drives profile for all fieldbus adapter modules) fieldbus adapter module converts the fieldbus-specific control word to the FBA communication profile and status word from FBA communication profile to the fieldbus-specific status word.

For descriptions of other profiles, see the *User's Manual* of the appropriate fieldbus adapter module.

Fieldbus references


References (FBA REF) are 16/32-bit signed integers. A negative reference is formed by calculating the two's complement from the corresponding positive reference value. The contents of each reference word can be used as speed, torque, position, synchron or profile velocity reference.

When torque or speed reference scaling is selected (by parameter [50.04 FBA REF1 MODESEL](#) / [50.05 FBA REF2 MODESEL](#)), the fieldbus references are 32-bit integers. The value consists of a 16-bit integer value and a 16-bit fractional value. The speed/torque reference scaling is as follows:

Reference	Scaling	Notes
Torque reference	FBA REF / 65536 (value in %)	Final reference is limited by parameters 20.06 MAXIMUM TORQUE and 20.07 MINIMUM TORQUE .
Speed reference	FBA REF / 65536 (value in rpm)	Final reference is limited by parameters 20.01 MAXIMUM SPEED , 20.02 MINIMUM SPEED and 24.12 SPEED REFMIN ABS .
Position reference	See parameter group 60 (page 221)	
Velocity reference		

State diagram

The following presents the state diagram for the FBA communication profile. For other profiles, see the *User's Manual* of the appropriate fieldbus adapter module.



Appendix B – Drive-to-drive link

What this chapter contains

This chapter describes the wiring of, and available communication methods on the drive-to-drive link. Examples of using standard function blocks in the communication are also given starting on page [443](#).

General

The drive-to-drive link is a daisy-chained RS-485 transmission line, constructed by connecting the X5 terminal blocks of the JCU Control Units of several drives. It is also possible to use an FMBA Modbus extension module installed into an option slot on the JCU. The firmware supports up to 63 nodes on the link.

The link has one master drive; the rest of the drives are followers. By default, the master broadcasts control commands as well as speed and torque references for all followers. The master can also be configured to send a position reference as either target position or synchronization reference. The master can send 8 messages per millisecond at 100/150-microsecond intervals. Sending one message takes approximately 15 microseconds, which results in a theoretical link capacity of roughly 6 messages per 100 microseconds.

Multicasting the control data and reference 1 to a pre-defined group of drives is possible, as is chained multicast messaging. Reference 2 is always broadcast by the master to all followers. See parameters [57.11...57.14](#).

Wiring

Shielded twisted-pair cable (~100 ohm, eg, PROFIBUS-compatible cable) must be used for the wiring. The maximum length of the link is 50 metres (164 ft).


The JCU Control Unit has a jumper (J3, "T") next to the X5 terminal block for bus termination. Termination must be ON on the drives at the ends of the drive-to-drive link; on intermediate drives, termination must be OFF.

Instead of the X5 connector, an FMBA Modbus extension module can be used.

For best immunity, high quality cable is recommended. The cable should be kept as short as possible. Unnecessary loops and running the cable near power cables (such as motor cables) must be avoided.

Note: The cable shields are to be grounded to the control cable clamp plate on the drive. Follow the instructions given in the *Hardware Manual* of the drive.

The following diagram shows the wiring of the drive-to-drive link.



Datasets

Drive-to-drive communication uses DDCS (Distributed Drives Communication System) messages and dataset tables for data transfer. Each drive has a dataset table of 256 datasets, numbered 0...255. Each dataset contains 48 data bits.

By default, datasets 0...15 and 200...255 are reserved for the drive firmware; datasets 16...199 are available for the user application program.

The contents of the two firmware communication datasets can be configured freely with pointer parameters and/or application programming with the DriveSPC tool. The 16-bit control word and 32-bit drive-to-drive reference 1 are transmitted from one dataset on a 500-microsecond (by default) time level; drive-to-drive reference 2 (32 bits) is transmitted from the other dataset on a 2-millisecond (by default) time level. Depending on the drive control mode, the followers can be configured to use the drive-to-drive commands and references with the following parameters:

Control data	Parameter	Setting for drive-to-drive communication
Start/Stop commands	10.01 EXT1 START FUNC 10.04 EXT2 START FUNC	(4) D2D
Speed reference	24.01 SPEED REF1 SEL 24.02 SPEED REF2 SEL	(5) D2D REF1 or (6) D2D REF2
Torque reference	32.01 TORQ REF1 SEL 32.02 TORQ REF ADD SEL	(5) D2D REF1 or (6) D2D REF2
Position reference	65.04 POS REF 1 SEL 65.12 POS REF 2 SEL	(5) D2D REF1 or (6) D2D REF2
Position reference in synchron control operating mode	67.01 SYNC REF SEL 67.02 VIRT MAS REF SEL	(5) D2D REF1 or (6) D2D REF2

The communication status of the followers can be supervised by a periodic supervision message from the master to the individual followers (see parameters [57.04 FOLLOWER MASK 1](#) and [57.05 FOLLOWER MASK 2](#)).

Drive-to-drive function blocks can be used in the DriveSPC tool to enable additional communication methods (such as follower-to-follower messaging) and to modify the use of datasets between the drives. See the function blocks under [Communication](#) (page [348](#)).

Types of messaging

Each drive on the link has a unique node address allowing point-to-point communication between two drives. The node address 0 is automatically assigned to the master drive; on other drives, the node address is defined by parameter [57.03 NODE ADDRESS](#).

Multicast addressing is supported, allowing the composition of groups of drives. Data sent to a multicast address is received by all drives that have that address. A multicast group can consist of 1...62 drives.

In broadcast messaging, data can be sent to all drives (actually, all followers) on the link.

Both master-to-follower(s) and follower-to-follower(s) communication is supported. A follower can send one message to another follower (or a group of followers) after receiving a token message from the master.


Type of messaging		Note
Point-to-point	Master point-to-point	Supported only at master
	Read remote	Supported only at master
	Follower point-to-point	Supported only at followers
Standard multicast		For both master and followers
Broadcast		For both master and followers
Token message for follower-to-follower communication		–
Chained multicast		Supported only for drive-to-drive reference 1 and control word

Master point-to-point messaging

In this type of messaging, the master sends one dataset (LocalDsNr) from its own dataset table to the follower's. TargetNode stands for the node address of the follower; RemoteDsNr specifies the target dataset number.

The follower responds by returning the contents of the next dataset. The response is stored into dataset LocalDsNr+1 in the master.


Note: Master point-to-point messaging is only supported at the master because the response is always sent to node address 0 (the master).



Read remote messaging

The master can read a dataset (RemoteDsNr) from a follower specified by TargetNode. The follower returns the contents of the requested dataset to the master. The response is stored at dataset LocalDsNr in the master.


Note: Read remote messaging is only supported at the master because the response is always sent to node address 0 (the master).



Follower point-to-point messaging

This type of messaging is for point-to-point communication between followers. After receiving a token from the master, a follower can send one dataset to another follower with a follower point-to-point message. The target drive is specified using the node address.

Note: The data is not sent to the master.




Standard multicast messaging

In standard multicast messaging, one dataset can be sent to a group of drives having the same standard multicast group address. The target group is defined by the [D2D_Conf](#) standard function block (see page 348).


The sending drive can either be the master, or a follower after receiving a token from the master.

Note: The master does not receive the sent data even if it is a member of the target multicast group.

Master-to-follower(s) multicasting



Follower-to-follower(s) multicasting




Broadcast messaging

In broadcasting, the master sends one dataset to all followers, or a follower sends one dataset to all other followers (after receiving a token from the master).


The target (**Target Grp**) is automatically set to 255 denoting all followers.

Note: The master does not receive any data broadcast by the followers.

Master-to-follower(s) broadcasting



Follower-to-follower(s) broadcasting




Chained multicast messaging

Chained multicasting is supported only for drive-to-drive reference 1 by the firmware.

The message chain is always started by the master. The target group is defined by parameter [57.13 NEXT REF1 MC GRP](#). The message is received by all followers that have parameter [57.12 REF1 MC GROUP](#) set to the same value as parameter [57.13 NEXT REF1 MC GRP](#) in the master.

If a follower has parameters [57.03 NODE ADDRESS](#) and [57.12 REF1 MC GROUP](#) set to the same value, it becomes a submaster. Immediately after a submaster receives the multicast message, it sends its own message to the next multicast group defined by parameter [57.13 NEXT REF1 MC GRP](#).

The duration of the entire message chain is approximately 15 microseconds multiplied by the number of links in the chain (defined by parameter [57.14 NR REF1 MC GRPS](#) in the master).



* Acknowledgement from last follower to master can be prevented by setting parameter 57.11 REF 1 MSG TYPE to (0) Broadcast (required because parameters 57.03 NODE ADDRESS and 57.12 REF1 MC GROUP are set to the same value). Alternatively, node/group addresses (parameters 57.03 NODE ADDRESS and 57.12 REF1 MC GROUP) could be set to non-equal values.


Examples of using standard function blocks in drive-to-drive communication

See also the descriptions of the drive-to-drive function blocks starting on page 348.

Example of master point-to-point messaging

Master


Follower (node 1)




1. The master sends a constant (1) and the value of the message counter into follower dataset 20. Data is prepared to and sent from dataset 16.
2. The follower sends the received counter value and a constant (21) as a reply to the master.
3. The master calculates the difference of the latest message number and received data.

Example of read remote messaging

Master




Follower (node 1)



1. The master reads the contents of the follower dataset 22 into its own dataset 18. Data is accessed using the **DS_ReadLocal** block.
2. In the follower, constant data is prepared into dataset 22.

Releasing tokens for follower-to-follower communication

Master




1. This drive-to-drive link consists of three drives (master and two followers).
2. The master operates as a “chairman”. Follower 1 (node 1) is allowed to send one message every 3 milliseconds. Follower 2 (node 2) is allowed to send one message every 6 milliseconds.

Example of follower point-to-point messaging

Follower 1 (node 1)


Follower 2 (node 2)




1. Follower 1 writes local dataset 24 to follower 2 dataset 30 (3 ms interval).
2. Follower 2 writes local dataset 33 to follower 1 dataset 28 (6 ms interval).
3. In addition, both followers read received data from local datasets.

Example of standard master-to-follower(s) multicast messaging

Master



Follower(s) in Std Mcast Group 10




1. The master sends a constant (9876) and the value of the message counter to all followers in standard multicast group 10. The data is prepared into and sent from master dataset 19 to follower dataset 23.
2. Received data is read from dataset 23 of the receiving followers.


Note: The example application shown for Master above also applies to the sending follower in standard follower-to-follower multicasting.

Example of broadcast messaging

Master



Follower(s)



1. The master sends a constant (9876) and the value of the message counter to all followers. The data is prepared into and sent from master dataset 19 to follower dataset 23.
2. Received data is read from dataset 23 of the followers.

Note: The example application shown for Master above also applies to the sending follower in follower-to-follower broadcasting.


Appendix C – Homing methods

What this chapter contains

This chapter describes homing methods 1...35.


Negative direction means that the movement is to the left and positive direction means that the movement is to the right.

The following picture presents an example of a homing application:



Homing method 1


The status of the home switch at start is insignificant.



1	Start in the negative direction (left) by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Change direction by the rising edge of the signal selected by par. 62.05 NEG LIMIT SWITCH .
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2 , by the falling edge of the signal selected by par. 62.05 NEG LIMIT SWITCH .
4	Stop by the next index pulse.


Homing method 2

The status of the home switch at start is insignificant.




1	Start in the positive direction (right) by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Change direction by the rising edge of the signal selected by par. 62.06 POS LIMIT SWITCH .
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2 , by the falling edge of the signal selected by par. 62.06 POS LIMIT SWITCH .
4	Stop by the next index pulse.

Homing method 3




1	If the home switch signal is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the home switch signal is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.

Homing method 4




1	If the home switch signal is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.




1	If the home switch signal is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.

Homing method 5




1	If the home switch signal is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the home switch signal is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction) by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.

Homing method 6




1	If the home switch signal is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1. With homing method 4, the start direction is positive (right). With homing method 6, the start direction is negative (left).
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.




1	If the home switch signal is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.


Homing method 7



1	If the home switch signal is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the home switch signal is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the home switch signal is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.


Homing method 8



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH.
3	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
5	Stop by the next index pulse.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.


Homing method 9



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.


Homing method 10



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH.
3	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
5	Stop by the next index pulse.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.

Homing method 11




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.

Homing method 11




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.


Homing method 12



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
5	Stop by the next index pulse.

Homing method 13




1	If the state of the home switch is 0: Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG .
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2 , by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG .
4	Stop by the next index pulse.




1	If the state of the home switch is 0: Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH .
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2 , by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG .
4	Stop by the next index pulse.

Homing method 13




1	If the state of the home switch is 1: Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the next index pulse.


Homing method 14



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the next index pulse.



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Change to homing speed 2, par. 62.08 HOMING SPEEDREF2, by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
5	Stop by the next index pulse.




Homing methods 15 and 16

Reserved

Homing method 17


The status of the home switch at start is insignificant.



1	Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH .
3	Stop by the falling edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH .


Homing method 18

The status of the home switch at start is insignificant.




1	Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH .
3	Stop by the falling edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH .

Homing method 19




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.

Homing method 20




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.

Homing method 21




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.

Homing method 22






1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.



1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.


Homing method 23






1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.


Homing method 24



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH.
3	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.


Homing method 25



1	If the state of the home switch is 0: (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 0: (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the positive limit switch signal selected by par. 62.06 POS LIMIT SWITCH.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1: (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.


Homing method 26




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1: (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




Homing method 27



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.


Homing method 28



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG. Note: Stop is only possible after a falling edge of the home switch has been detected.




1	If the state of the home switch is 1: (par. 62.04 HOME SWITCH TRIG): Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.


Homing method 29



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG. Note: Stop is only possible after a falling edge of the home switch has been detected.




1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
3	Stop by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG. Note: Stop is only possible after a falling edge of the home switch has been detected.


Homing method 30



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.



1	If the state of the home switch is 0 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Change direction by the rising edge of the negative limit switch signal selected by par. 62.05 NEG LIMIT SWITCH.
3	Change direction by the rising edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.
4	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.




1	If the state of the home switch is 1 (par. 62.04 HOME SWITCH TRIG): Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1.
2	Stop by the falling edge of the home switch signal selected by par. 62.04 HOME SWITCH TRIG.

Homing methods 31 and 32

Reserved

Homing method 33


The status of the home switch at start is insignificant.



1	Start in the negative (left) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Stop by the next index pulse.

Homing method 34

The status of the home switch at start is insignificant.



1	Start in the positive (right) direction by the rising edge of the signal selected by par. 62.03 HOMING START with homing speed 1, par. 62.07 HOMING SPEEDREF1 .
2	Stop by the next index pulse.

Homing method 35

In method 35 the current position is used as home position.


Appendix D – Application examples

What this chapter contains

This chapter contains the following application examples:

- Position system commissioning
- Absolute linear positioning
- Relative linear positioning
- Synchronisation through drive-to-drive link
- Synchronisation through drive-to-drive link with synchron gear
- Cam synchronisation
- Homing.

Basic motion control configuration



The PLC controls the ACSM1 drive through a PROFIBUS DP bus using the PROFIdrive positioning mode. The drive is position-controlled and uses an absolute encoder (4096/EnDat) installed on the motor. The mechanical gear ratio (1:20) and pitch (6 mm / 1 rev) of the lead screw are taken into the drive's position control loop. Limit switches and a home switch are used to determine the initial position of the machine.

The jog input (DI2) is used to move the load manually close to the machine. If the STO circuit is opened, the drive is not able to move the load at all.

Basic parameter settings

Index	Parameter	Value
10.01	EXT1 START FUNC	(3) FBA
10.07	JOG1 START	P.02.01.01 (2.01 DI STATUS, b1) = DI2
10.08	FAULT RESET SEL	P.02.12.08 (2.12 FBA MAIN CW, b8)
10.15	JOG ENABLE	P.02.01.01 (2.01 DI STATUS, b1) = DI2
22.01	SPEED FB SEL	(1) Enc1 speed
22.03	MOTOR GEAR MUL	1
22.04	MOTOR GEAR DIV	1
34.01	EXT1/EXT2 SEL	P.02.12.15 (2.12 FBA MAIN CW, b15)
34.02	EXT1 MODE 1/2SEL	P.02.12.26 (2.12 FBA MAIN CW, b26)
34.03	EXT1 CTRL MODE1	(6) Position / (7) Synchron

34.04	EXT1 CTRL MODE2	(8) Homing
34.05	EXT2 CTRL MODE1	(9) Prof Vel
50.01	FBA ENABLE	(1) Enable
50.04	FBA REF1 MODESEL	(3) Position
50.05	FBA REF2 MODESEL	(4) Velocity
51.05	PROFILE	(4) PROFdrive positioning mode
57.01	LINK MODE	(2) Master / (1) Follower
57.03	NODE ADDRESS	(User setting)
57.06	REF 1 SRC	P.01.12 (1.12 POS ACT)
57.08	FOLLOWER CW SRC	P.02.18 (2.18 D2D FOLLOWER CW)
57.09	KERNEL SYNC MODE	(1) D2DSync
60.01	POS ACT SEL	(0) ENC1
60.02	POS AXIS MODE	(0) Linear
60.03	LOAD GEAR MUL	1
60.04	LOAD GEAR DIV	20
60.05	POS UNIT	(2) Meter
60.06	FEED CONST NUM	6
60.07	FEED CONST DEN	1
60.08	POS2INT SCALE	1000
60.10	POS SPEED UNIT	(0) u/s
62.01	HOMING METHOD	(23) CAN Method23
62.03	HOMING START	P.02.12.26 (2.12 FBA MAIN CW, b26)
62.04	HOME SWITCH TRIG	(0) ENC1_DI1
62.05	NEG LIMIT SWITCH	P.02.01.03 (2.01 DI STATUS, b3) = DI4
62.06	POS LIMIT SWITCH	P.02.01.04 (2.01 DI STATUS, b4) = DI5
62.07	HOMING SPEEDREF1	(User setting)
62.09	HOME POSITION	0
65.01	POS REFSOURCE	(2) Fieldbus
65.03	POS START 1	P.02.12.25 (2.12 FBA MAIN CW, b25)
65.04	POS REF 1 SEL	(3) FBA REF1
65.06	PROF ACC 1	20 u/s ²
65.07	PROF DEC 1	-20 u/s ²
65.09	POS STYLE 1	0b010100 (absolute) / 0b000100 (relative) / 0b010001 (synchron follower)
65.22	PROF VEL REF SEL	(4) FBA REF2
67.01	SYNC REF SEL	(5) D2D REF1
68.02	SYNC GEAR MUL	1
68.03	SYNC GEAR DIV	1 / 2
68.07	SYNCHRON MODE	(0) Absolute
71.07	GEAR RATIO MUL	20
71.08	GEAR RATIO DIV	1
80.01	CAM Enable	(User setting)
80.02	CAM Start	(User setting)
80.03	CAM Selector	(User setting)
90.01	ENCODER 1 SEL	(3) FEN-11 ABS
91.01	SINE COSINE NR	4096
91.02	ABS ENC INTERF	(2) EnDat
91.03	REV COUNT BITS	12
91.04	POS DATA BITS	13


Example – Position system commissioning

In order to commission the position system properly, you must check and configure the settings of the following position parameters. Upon the start of the commissioning procedure, these parameters must be at their default values.

Commissioning procedure

1. Parameter [60.09 POS RESOLUTION](#)
2. Parameters in groups [90...93](#) for encoder configuration
3. Parameter [90.10 ENC PAR REFRESH](#)
4. Parameter [91.06 ABS POS TRACKING](#)
5. The rest of the parameters in group [60](#), except for the load encoder gear function parameters (See the next step.)
6. Parameters [60.02 LOAD GEAR MUL](#), [60.03 LOAD GEAR DIV](#), [71.07 GEAR RATIO MUL](#) and [71.08 GEAR RATIO DIV](#) for load encoder gear function
7. The rest of the positioning parameters in groups [60...71](#)
8. Parameter [90.10 ENC PAR REFRESH](#)
9. Last, execute the homing procedure, if needed.

Example – Absolute linear positioning




In this example, the drive uses absolute positioning in linear mode. Five references are given: 75 mm, 150 mm, 275 mm, 400 mm and 0 mm.

Parameter settings

Index	Parameter	Value
22.03	MOTOR GEAR MUL	1
22.04	MOTOR GEAR DIV	1
34.03	EXT1 CTRL MODE1	(6) Position
50.04	FBA REF1 MODESEL	(3) Position
50.05	FBA REF2 MODESEL	(4) Velocity
60.01	POS ACT SEL	(0) ENC1
60.02	POS AXIS MODE	(0) Linear
60.03	LOAD GEAR MUL	1
60.04	LOAD GEAR DIV	20
60.05	POS UNIT	(2) Meter
60.06	FEED CONST NUM	6
60.07	FEED CONST DEN	1
60.08	POS2INT SCALE	1000
60.10	POS SPEED UNIT	(0) u/s
65.01	POS REFSOURCE	(2) Fieldbus
65.03	POS START 1	P.02.12.20 (2.12 FBA MAIN CW, b20)
65.04	POS REF 1 SEL	(3) FBA REF1
65.06	PROF ACC 1	20 u/s ²
65.07	PROF DEC 1	-20 u/s ²
65.09	POS STYLE 1	0b010100 (absolute)
71.07	GEAR RATIO MUL	20
71.08	GEAR RATIO DIV	1

Example – Relative linear positioning




In this example, the drive uses relative positioning in linear mode. Five references are given: 75 mm, 75 mm, 125 mm, 125 mm and -400 mm.

Parameter settings

Index	Parameter	Value
22.03	MOTOR GEAR MUL	1
22.04	MOTOR GEAR DIV	1
34.03	EXT1 CTRL MODE1	(6) Position
50.04	FBA REF1 MODESEL	(3) Position
50.05	FBA REF2 MODESEL	(4) Velocity
60.01	POS ACT SEL	(0) ENC1
60.02	POS AXIS MODE	(0) Linear
60.03	LOAD GEAR MUL	1
60.04	LOAD GEAR DIV	20
60.05	POS UNIT	(2) Meter
60.06	FEED CONST NUM	6
60.07	FEED CONST DEN	1
60.08	POS2INT SCALE	1000
60.10	POS SPEED UNIT	(0) u/s
65.01	POS REFSOURCE	(2) Fieldbus
65.03	POS START 1	P.02.12.20 (2.12 FBA MAIN CW, b20)
65.04	POS REF 1 SEL	(3) FBA REF1
65.06	PROF ACC 1	20 u/s ²
65.07	PROF DEC 1	-20 u/s ²
65.09	POS STYLE 1	0b000100 (relative)
71.07	GEAR RATIO MUL	20
71.08	GEAR RATIO DIV	1

Example – Synchronisation through drive-to-drive link




In this example, there are two drives, the first of which is position-controlled and uses absolute positioning in linear mode. The second drive is synchronised with the first one via the drive-to-drive link.

Five references are given to the first drive: 75 mm, 75 mm, 125 mm, 125 mm and -400 mm. The second drive will move to the same positions at the same speed.

Parameter settings

Index	Parameter	Value
22.03	MOTOR GEAR MUL	1
22.04	MOTOR GEAR DIV	1
34.03	EXT1 CTRL MODE1	(6) Position / (7) Synchron
57.01	LINK MODE	(2) Master / (1) Follower
57.03	NODE ADDRESS	(User setting)
57.06	REF 1 SRC	P.01.12 (1.12 POS ACT)
57.08	FOLLOWER CW SRC	P.02.18 (2.18 D2D FOLLOWER CW)
57.09	KERNEL SYNC MODE	(1) D2DSync
60.03	LOAD GEAR MUL	1
60.04	LOAD GEAR DIV	20
60.06	FEED CONST NUM	6
60.07	FEED CONST DEN	1
65.09	POS STYLE 1	0b010001 (synchron follower)
67.01	SYNC REF SEL	(5) D2D REF1
68.02	SYNC GEAR MUL	1
68.03	SYNC GEAR DIV	1
68.07	SYNCHRON MODE	(0) Absolute
71.07	GEAR RATIO MUL	20
71.08	GEAR RATIO DIV	1

Example – Synchronisation through drive-to-drive link with synchron gear




This example is similar to [Example – Synchronisation through drive-to-drive link](#); however, the follower here is synchronised to the master but with half the speed and half the target position.

The target positions given to the first drive are 150 mm, 400 mm and 0 mm, so the second drive will move to the positions 75 mm, 200 mm and 0 mm (at half speed compared to the first drive).

Parameter settings

Index	Parameter	Value
22.03	MOTOR GEAR MUL	1
22.04	MOTOR GEAR DIV	1
34.03	EXT1 CTRL MODE1	(6) Position / (7) Synchron
57.01	LINK MODE	(2) Master / (1) Follower
57.03	NODE ADDRESS	(User setting)
57.06	REF 1 SRC	P.01.12 (1.12 POS ACT)
57.08	FOLLOWER CW SRC	P.02.18 (2.18 D2D FOLLOWER CW)
57.09	KERNEL SYNC MODE	(1) D2DSync
60.03	LOAD GEAR MUL	1
60.04	LOAD GEAR DIV	20
60.06	FEED CONST NUM	6
60.07	FEED CONST DEN	1
65.09	POS STYLE 1	0b010001 (synchron follower)
67.01	SYNC REF SEL	(5) D2D REF1
68.02	SYNC GEAR MUL	1
68.03	SYNC GEAR DIV	2
68.07	SYNCHRON MODE	(0) Absolute
71.07	GEAR RATIO MUL	20
71.08	GEAR RATIO DIV	1

Example – Cam synchronisation




This example is similar to [Example – Synchronisation through drive-to-drive link](#); however, the follower here is cam synchronised to the master.

The master is given two position references in an automatic sequence (400 mm and 0 mm) while the follower runs in sync with it. The follower performs a traverse cam profile.

Parameter settings

Index	Parameter	Value
22.03	MOTOR GEAR MUL	1
22.04	MOTOR GEAR DIV	1
34.03	EXT1 CTRL MODE1	(6) Position / (7) Synchron
57.01	LINK MODE	(2) Master / (1) Follower
57.03	NODE ADDRESS	(User setting)
57.06	REF 1 SRC	P.01.12 (1.12 POS ACT)
57.08	FOLLOWER CW SRC	P.02.18 (2.18 D2D FOLLOWER CW)
57.09	KERNEL SYNC MODE	(1) D2DSync
60.03	LOAD GEAR MUL	1
60.04	LOAD GEAR DIV	20
60.06	FEED CONST NUM	6
60.07	FEED CONST DEN	1
65.09	POS STYLE 1	0b010001 (synchron follower)
67.01	SYNC REF SEL	(5) D2D REF1
68.02	SYNC GEAR MUL	1
68.03	SYNC GEAR DIV	1
68.07	SYNCHRON MODE	(0) Absolute
71.07	GEAR RATIO MUL	20
71.08	GEAR RATIO DIV	1
80.01	CAM Enable	(User setting)
80.02	CAM Start	(User setting)
80.03	CAM Selector	(User setting)

Example – Homing



In this example, the drive performs a homing using Homing method 23.

When homing is started, the home switch is not active, so the machine is moved in the positive (right) direction. The direction is changed by the rising edge of the positive limit switch.

The load is moved in the negative direction until the falling edge of the home switch signal is received.

Parameter settings


Index	Parameter	Value
34.02	EXT1 MODE 1/2SEL	P.02.12.26 (2.12 FBA MAIN CW, b26)
34.04	EXT1 CTRL MODE2	(8) Homing
62.01	HOMING METHOD	(23) CAN Method23
62.03	HOMING START	P.02.12.26 (2.12 FBA MAIN CW, b26)
62.04	HOME SWITCH TRIG	(0) ENC1_DI1
62.05	NEG LIMIT SWITCH	P.02.01.03 (2.01 DI STATUS, b3) = DI4
62.06	POS LIMIT SWITCH	P.02.01.04 (2.01 DI STATUS, b4) = DI5
62.07	HOMING SPEEDREF1	(User setting)
62.09	HOME POSITION	0

Appendix E – Control chain and drive logic diagrams


What this chapter contains

This chapter presents the drive control chain and logic.


Speed control chain




Torque control chain




Position control chain




Drive logic 1



Drive logic 2 (Fieldbus interface)



DTC motor control



Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com/drives