Smarter. Greener. Together.

# **Industrial Automation Headquarters**

Delta Electronics, Inc.

Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District,

Taoyuan City 33068, Taiwan

TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code : 201209

TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996

Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Tokvo Office

Industrial Automation Sales Department

2-1-14 Shibadaimon, Minato-ku

Tokyo, Japan 105-0012 TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

Delta Electronics (Korea), Inc.

1511, 219, Gasan Digital 1-Ro., Geumcheon-gu,

Seoul, 08501 South Korea

TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon,

PIN 122001, Haryana, India

TEL: 91-124-4874900 / FAX: 91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z),

Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand

TEL: 66-2709-2800 / FAX: 662-709-2827

Delta Energy Systems (Australia) Pty Ltd.

Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia

TEL: 61-3-9543-3720

#### Americas

Delta Electronics (Americas) Ltd.

P.O. Box 12173, 5101 Davis Drive,

Research Triangle Park, NC 27709, U.S.A.

TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Greentech (Brasil) S/A

São Paulo Office

Rua Itapeva, 26 – 3° Andar - Bela Vista

CEP: 01332-000 - São Paulo - SP - Brasil

TEL: 55-11-3530-8642 / 55-11-3530-8640

Delta Electronics International Mexico S.A. de C.V.

Vía Dr. Gustavo Baz No. 2160, Colonia La Loma, 54060 Tlalnepantla Estado de Mexico

TEL: 52-55-2628-3015 #3050/3052

Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com

Marketing: Marketing.IA.EMEA@deltaww.com

Technical Support: iatechnicalsupport@deltaww.com

Customer Support: Customer-Support@deltaww.com

Service: Service.IA.emea@deltaww.com

TEL: +31(0)40 800 3800

BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20, 5652 AG Eindhoven, The Netherlands Mail: Sales.IA.Benelux@deltaww.com

TEL: +31(0)40 800 3800

DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany

Mail: Sales.IA.DACH@deltaww.com

TEL: +49(0)2921 987 0

France: Delta Electronics (France) S.A.

ZI du bois Challand 2, 15 rue des Pyrénées,

Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com

TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed.

Hormigueras – P.I. de Vallecas 28031 Madrid

TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain Mail: Sales.IA.Iberia@deltaww.com

Italy: Delta Electronics (Italy) S.r.I. Ufficio di Milano Via Senigallia 18/2 20161 Milano (MI)

Piazza Grazioli 18 00186 Roma Italy

Mail: Sales.IA.Italy@deltaww.com

TEL: +39 02 64672538

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str. 17 121357 Moscow Russia

Mail: Sales.IA.RU@deltaww.com

TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A

34775 Ümraniye - İstanbul

Mail: Sales.IA.Turkey@deltaww.com

TEL: + 90 216 499 9910

GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre

Dubai, United Arab Emirates

Mail: Sales.IA.MEA@deltaww.com

TEL: +971(0)4 2690148

Egypt + North Africa: Delta Electronics

511 Cairo Business Plaza, North 90 street,

New Cairo, Cairo, Egypt

Mail: Sales.IA.MEA@deltaww.com





**Delta Fan/Pump Vector Control Drive CP2000 Series User Manual** 



### Copyright notice

©Delta Electronics, Inc. All rights reserved.

All information contained in this user manual is the exclusive property of Delta Electronics Inc. (hereinafter referred to as "Delta") and is protected by copyright law and all other laws. Delta retains the exclusive rights of this user manual in accordance with the copyright law and all other laws. No parts in this manual may be reproduced, transmitted, transcribed, translated or used in any other ways without the prior consent of Delta.

#### **Limitation of Liability**

The contents of this user manual are only for the use of the AC motor drives manufactured by Delta. Except as defined in special mandatory laws, Delta provides this user manual "as is" and does not offer any kind of warranty through this user manual for using the product, either express or implied, including but not limited to the following: (i) this product will meet your needs or expectations; (ii) the information contained in the product is current and correct; (iii) the product does not infringe any rights of any other person. You shall bear your own risk to use this product.

In no event shall Delta, its subsidiaries, affiliates, managers, employees, agents, partners and licensors be liable for any direct, incidental, special, derivative or consequential damages (including but not limited to the damages for loss of profits, goodwill, use or other intangible losses) unless the laws contains special mandatory provisions to the contrary.

Delta reserves the right to make changes to the user manual and the products described in the user manual without prior notice and afterwards.

#### PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- ☑ Disconnect AC input power before connecting any wiring to the AC motor drive.
- ☑ Even if the power has been turned off, a charge may still remain in the DC-link capacitors with hazardous voltages before the POWER LED is OFF. Do NOT touch the internal circuits and components.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Take anti-static measure before touching these components or the circuit boards.
- ☑ Never modify the internal components or wiring.
- ☑ Ground the AC motor drive by using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ Do NOT install the AC motor drive in a location with high temperature, direct sunlight or inflammable materials or gases.



- ☑ Never connect the AC motor drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.
- ☑ After finishing the wiring of the AC motor drive, check if U/T1, V/T2, and W/T3 are short-circuited to ground with a multimeter. Do NOT power the drive if short circuits occur. Eliminate the short circuits before the drive is powered.
- ☑ The rated voltage of power system to install motor drives is listed below. Ensure that the installation voltage is in the correct range when installing a motor drive.
  - 1. For 230V models, the range is between 170-264V.
  - 2. For 460V models, the range is between 323-528V.
  - 3. For 575V models, the range is between 446-660V.
  - 4. For 690V models, the range is between 446–759V.

☑ Refer to the table below for short circuit rating:

Model (Power)	Short circuit rating
230V / 460V	100 kA
575V (2-20HP)	5 kA
690V (25-50HP)	5 kA
690V (60-175HP)	10 kA
690V (215-335HP)	18 kA
690V (425-600HP)	30 kA
690V (745-850HP)	42 kA

- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.
- ☑ Even if the three-phase AC motor is stopped, a charge with hazardous voltages may still remain in the main circuit terminals of the AC motor drive.
- ☑ The performance of electrolytic capacitor will degrade if it is not charged for a long time. It is recommended to charge the drive which is stored in no charge condition every 2 years for 3–4 hours to restore the performance of electrolytic capacitor in the motor drive. Note: When power up the motor drive, use adjustable AC power source (ex. AC autotransformer) to charge the drive at 70%–80% of rated voltage for 30 minutes (do not run the motor drive). Then charge the drive at 100% of rated voltage for an hour (do not run the motor drive). By doing these, restore the performance of electrolytic capacitor before starting to run the motor drive. Do NOT run the motor drive at 100% rated voltage right away.
- ☑ Pay attention to the following precautions when transporting and installing this package (including wooden crate and wood stave)
  - 1. If you need to deworm the wooden crate, do NOT use fumigation or you will damage the drive. Any damage to the drive caused by using fumigation voids the warranty.

- 2. Use other methods, such as heat treatment or any other non-fumigation treatment, to deworm the wood packaging material.
- 3. If you use heat treatment to deworm, leave the packaging materials in an environment of over 56°C for a minimum of thirty minutes.
- ☑ Connect the drive to a three-phase three-wire or three-phase four-wire Wye system to comply with UL standards.
- ☑ If the motor drive generates leakage current over AC 3.5 mA or over DC 10 mA on a grounding conductor, compliance with local grounding regulations or IEC61800-5-1 standard is the minimum requirement for grounding.



The content of this manual may be revised without prior notice. Please consult our distributors or download the latest version at <a href="http://www.deltaww.com/iadownload">http://www.deltaww.com/iadownload</a> acmotordrive

# **Table of Contents**

CHAPTER 1 INTRODUCTION	1-1
1-1 Nameplate Information	1-2
1-2 Model Name	1-3
1-3 Serial Number	1-3
1-4 Apply After Service by Mobile Device	1-4
1-5 RFI Jumper	1-5
1-6 Dimensions	1-8
CHAPTER 2 INSTALLATION	2-1
2-1 Mounting Clearance	2-2
2-2 Air Flow and Power Dissipation	2-5
CHAPTER 3 UNPACKING	3-1
3-1 Unpacking	3-2
3-2 The Lifting Hook	
CHAPTER 4 WIRING	4-1
4-1 System Wiring Diagram	4-3
4-2 Wiring	4-4
CHAPTER 5 MAIN CIRCUIT TERMINALS	5-1
5-1 Main Circuit Diagram	5-4
5-2 Specifications of Main Circuit Terminals	5-7
CHPATER 6 CONTROL TERMINALS	6-1
6-1 Remove the Cover for Wiring	6-4
6-2 Specifications of Control Terminal	6-8
6-3 Remove the Terminal Block	6-11
CHAPTER 7 OPTIONAL ACCESSORIES	7-1
7-1 All Brake Resistors and Brake Units Used in AC Motor Drive	es7-2
7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circui	t Breaker7-8
7-3 Fuse Specification Chart	7-13
7-4 AC / DC Reactor	7-15
7-5 Zero Phase Reactor	7-63
7-6 EMC Filter	7-66

7-7 Panel Mounting	7-79
7-8 Conduit Box Kit	7-81
7-9 Fan Kit	7-96
7-10 Flange Mounting Kit	7-114
7-11 Power Terminal Kit	7-129
7-12 USB/RS-485 Communication Interface IFD6530	7-131
CHAPTER 8 OPTION CARDS	8-1
8-1 Option Card Installation	8-2
8-2 EMC-D42A Extension card for 4-point digital input / 2-point digital input	8-11
8-3 EMC-D611A Extension card for 6-point digital input (110V <sub>AC</sub> input voltage)	8-11
8-4 EMC-R6AA Relay output extension card (6-point N.O. output contact)	8-11
8-5 EMC-BPS01 +24V power card	8-12
8-6 EMC-A22A Extension card for 2-point analog input/ 2-point analog output	8-13
8-7 CMC-PD01 Communication card, PROFIBUS DP	8-15
8-8 CMC-DN01 Communication card, DeviceNet	8-17
8-9 CMC-EIP01 Communication card, EtherNet/IP	8-20
8-10 CMC-PN01 Communication card, PROFINET	8-24
8-11 eZVFD-CC Communication card, BACnet Ethernet/BACnet IP	8-28
8-12 EMC-COP01 Communication card, CANopen	8-32
8-13 Delta Standard Fieldbus Cables	8-33
CHAPTER 9 SPECIFICATION	9-1
9-1 230V Models	9-2
9-2 460V Models	9-3
9-3 575V Models	9-5
9-4 690V Models	9-6
9-5 Environment for Operation, Storage and Transportation	9-9
9-6 Specification for Operation Temperature and Protection Level	9-10
9-7 Derating Curve for Ambient Temperature, Altitude and Carrier Frequency	9-11
9-8 Efficiency Curve	9-18
CHAPTER 10 DIGITAL KEYPAD	10-1
10-1 Descriptions of Digital Keypad	10-2
10-2 Function of Digital Keypad KPC-CC01	
10-3 TPEditor Installation Instruction	
10-4 Fault Code Description of Digital Keypad KPC-CC01	
10-5 Unsupported Functions when using TPEditor on KPC-CC01 Keypad	
CHADTED 11 SLIMMARY OF DADAMETERS	11_1

CHAPTER 12 DESCRIPTION OF PARAMETER SETTINGS	12-1
12-1 Description of Parameter Settings	12.1-00-1
00 Drive Parameters	12.1-00-1
01 Basic Parameters	12.1-01-1
02 Digital Input / Output Parameters	12.1-02-1
03 Analog Input / Output Parameters	12.1-03-1
04 Multi-stage Speed Parameters	12.1-04-1
05 Motor Parameters	12.1-05-1
06 Protection Parameters	12.1-06-1
07 Special Parameters	12.1-07-1
08 High-function PID Parameters	12.1-08-1
09 Communication Parameters	12.1-09-1
10 Feedback Control Parameters	12.1-10-1
11 Advanced Parameters	12.1-11-1
12 Pump Parameters	12.1-12-1
13 Application Parameters by Industry	12.1-13-1
14 Extension Card Parameter	12.1-14-1
12-2 Adjustment & Application	12.2-1
CHAPTER 13 WARNING CODES	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS	14-1
CHAPTER 14 FAULT CODES AND DESCRIPTIONS CHAPTER 15 CANOPEN OVERVIEW	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS	<b>15-1</b> 15-3
CHAPTER 14 FAULT CODES AND DESCRIPTIONS  CHAPTER 15 CANOPEN OVERVIEW	1 <b>5-1</b> 15-3
CHAPTER 14 FAULT CODES AND DESCRIPTIONS.  CHAPTER 15 CANOPEN OVERVIEW.  15-1 CANopen Overview.  15-2 Wiring for CANopen.	15-1 15-3 15-6 15-7
CHAPTER 14 FAULT CODES AND DESCRIPTIONS  CHAPTER 15 CANOPEN OVERVIEW  15-1 CANopen Overview  15-2 Wiring for CANopen  15-3 CANopen Communication Interface Description	15-115-315-615-7
CHAPTER 14 FAULT CODES AND DESCRIPTIONS  CHAPTER 15 CANOPEN OVERVIEW  15-1 CANopen Overview  15-2 Wiring for CANopen  15-3 CANopen Communication Interface Description  15-4 CANopen Supporting Index	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS  CHAPTER 15 CANOPEN OVERVIEW  15-1 CANopen Overview  15-2 Wiring for CANopen  15-3 CANopen Communication Interface Description  15-4 CANopen Supporting Index  15-5 CANopen Fault Codes	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS  CHAPTER 15 CANOPEN OVERVIEW  15-1 CANopen Overview.  15-2 Wiring for CANopen.  15-3 CANopen Communication Interface Description.  15-4 CANopen Supporting Index  15-5 CANopen Fault Codes  15-6 CANopen LED Function.  CHAPTER 16 PLC FUNCTION APPLICATIONS	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS  CHAPTER 15 CANOPEN OVERVIEW  15-1 CANopen Overview  15-2 Wiring for CANopen  15-3 CANopen Communication Interface Description  15-4 CANopen Supporting Index  15-5 CANopen Fault Codes  15-6 CANopen LED Function  CHAPTER 16 PLC FUNCTION APPLICATIONS  16-1 PLC Summary	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS	
CHAPTER 14 FAULT CODES AND DESCRIPTIONS	

16-8 CANopen Master Control Applications	16-131
16-9 Explanation Of Various PLC Mode Controls (speed, torque, homing, and position)	16-143
16-10 Internal Communications Main Node Control	16-145
16-11 Modbus Remote IO Control Applications (use MODRW)	16-149
16-12 Calendar Function	16-156
APTER 17 INTRODUCTION TO BACnet	17-1
APTER 18 SAFE TORQUE OFF FUNCTION	18-1
18-1 The Drive Safety Function Failure Rate	18-2
18-2 Safe Torque Off Terminal Function Description	18-2
18-3 Wiring Diagram	18-3
18-4 Parameters	18-5
18-5 Operating Sequence Description	18-6
18-6 New Error Code for STO Function	18-8
PENDIX A. REVISION HISTORY	A-1
	16-8 CANopen Master Control Applications

Issued Edition: 01

Firmware Version: V2.07

(Refer to Parameter 00-06 on the product to get the firmware version.)

**Issued Date: 2020/09** 

# Chapter 1 Introduction

- 1-1 Nameplate Information
- 1-2 Model Name
- 1-3 Serial Number
- 1-4 Apply After Service by Mobile Device
- 1-5 RFI Jumper
- 1-6 Dimensions

# **Receiving and Inspection**

After receiving the AC motor drive, check for the following:

- 1. Inspect the unit after unpacking to ensure that it was not damaged during shipment. Make sure that the part number printed on the package matches the part number indicated on the nameplate.
- 2. Make sure that the mains voltage is within the range indicated on the nameplate. Install the AC motor drive according to the instructions in this manual.
- 3. Before applying power, make sure that all devices, including mains power, motor, control board and digital keypad, are connected correctly.
- 4. When wiring the AC motor drive, make sure that the wiring of input terminals "R/L1, S/L2, T/L3" and output terminals "U/T1, V/T2, W/T3" are correct to prevent damage to the drive.
- 5. When power is applied, use the digital keypad (KPC-CC01) to select the language and set parameters. When executing a trial run, begin with a low speed and then gradually increase the speed to the desired speed.

# 1-1 Nameplate Information:






Figure 1-1

### 1-2 Model Name:



# 1-3 Serial Number:



# 1-4 Apply After Service by Mobile Device

#### 1-4-1 Location of Service Link Label

#### Frame A-H

Service link label (Service Label) is pasted on the area as the drawing below shows:




Figure 1-2

#### 1-4-2 Service Link Label



### Scan QR Code to apply

- 1. Find the QR code sticker (as shown above).
- 2. Use a smartphone to run a QR Code reader APP.
- 3. Point your camera at the QR Code. Hold your camera steady until the QR code comes into focus.
- 4. Access the Delta After Service website.
- 5. Fill your information into the column marked with an orange star.
- 6. Enter the CAPTCHA and click "Submit" to complete the application.

#### Cannot find the QR Code?

- 1. Open a web browser on your computer or smart phone.
- 2. Enter <a href="https://service.deltaww.com/ia/repair">https://service.deltaww.com/ia/repair</a> in browser address bar and press the Enter key.
- 3. Fill your information into the columns marked with an orange star.
- 4. Enter the CAPTCHA and click "Submit" to complete the application.

# 1-5 RFI Jumper

- (1) The driver contains Varistor / MOVs that are connected from phase-to-phase and from phase-to-ground to prevent the drive from unexpected stop or damage caused by mains surges or voltage spikes. Because the Varistors / MOVs from phase-to-ground are connected to ground with the RFI jumper, removing the RFI jumper disables the protection.
- (2) In the models with a built-in EMC filter, the RFI jumper connects the filter capacitors to ground to form a return path for high frequency noise in order to isolate the noise from contaminating the mains power. Removing the RFI jumper strongly reduces the effect of the built-in EMC filter. Although a single drive complies with the international standards for leakage current, an installation with several drives with built-in EMC filter can trigger the RCD. Removing the RFI jumper helps, but the EMC performance of each drive would be no longer guaranteed.

#### Frame A-C

Screw Torque: 8-10 kg-cm / [6.9-8.7 lb -in.] / [0.8-1.0 Nm]

Loosen the screw and remove the MOV-PLATE. Fasten the screws back to the original position after MOV-PLATE is removed.




Figure 1-4 Figure 1-5

#### Frame D0-H

Remove the MOV-PLATE by hands, no screws need to be loosen





Figure 1-6

#### Isolating main power from ground:

When the power distribution system for the drive is a floating ground system (IT Systems) or an asymmetric ground system (Corner Grounded TN Systems), you must remove the RFI jumper. Removing the RFI Jumper disconnects the internal capacitors from ground to avoid damaging the internal circuits and to reduce the ground leakage current.

Important points regarding ground connection

- ☑ To ensure the safety of personnel, proper operation, and to reduce electromagnetic radiation, you must properly ground the motor and drive during installation.
- ☑ The diameter of the grounding cables must comply with the local safety regulations.
- ☑ You must connect the shielded cable to the motor drive's ground to meet safety regulations.
- ☑ Only use the shielded cables as the ground for equipment when the aforementioned points are met.
- ☑ When installing multiple drives, do not connect the grounds of the drives in series but connect each drive to ground. The following pictures show the correct and wrong ways to connect the grounds.



Pay particular attention to the following points:

- ☑ Do not remove the RFI jumper while the power is on.
- ☑ Removing the RFI jumper also cuts the capacitor conductivily of the surge absorber to ground and the built-in EMC filter capacitors. Compliance with the EMC specifications is no longer guaranteed.
- ☑ Do not remove the RFI jumper if the mains power is a symmetrical grounded power system in order to maintain the efficiency for EMC circuit.
- ☑ Remove the RFI jumper when conducting high voltage tests. When conducting a high voltage test to the entire facility, disconnect the mains power and the motor if the leakage current is too high.

#### Floating Ground System (IT Systems)

A floating ground system is also called an IT system, an ungrounded system, or a high impedance / resistance (greater than 30  $\Omega$ ) grounded system.


- ☑ Remove the RFI jumper to disconnect the ground cable from the internal filter capacitor and surge absorber.
- ☑ In situations where EMC is required, check for excess electromagnetic radiation affecting nearby low-voltage circuits. In some situations, the adapter and cable naturally provide enough suppression. If in doubt, install an extra electrostatic shielded cable on the power supply side between the main circuit and the control terminals to increase shielding.
- ☑ Do not install an external RFI / EMC filter. The external EMC filter passes through a filter capacitor and connects power input to the ground. This is very dangerous and damages the motor drive.


#### Asymmetric Ground System (Corner Grounded TN Systems)

Figure 1-11

Caution: Do not remove the RFI jumper while power to the input terminal of the drive is ON.

In the following four situations, you must remove the RFI jumper. This is to prevent the system from grounding through the RFI and filter capacitors and damaging the drive.





### 1-6 Dimensions

#### Frame A

VFD007CP23A-21; VFD015CP23A-21; VFD022CP23A-21; VFD037CP23A-21; VFD055CP23A-21; VFD007CP43A-21; VFD015CP43B-21; VFD022CP43B-21; VFD037CP43B-21; VFD040CP43A-21; VFD055CP43B-21; VFD075CP43B-21; VFD007CP4EA-21; VFD015CP4EB-21; VFD022CP4EB-21; VFD037CP4EB-21; VFD040CP4EA-21; VFD055CP4EB-21; VFD075CP4EB-21; VFD015CP53A-21; VFD022CP53A-21; VFD037CP53A-21






Figure 1-14


Frame         W         H         D         W1         H1         D1*         S1         Φ1         Φ2           130.0         250.0         170.0         116.0         236.0         45.8         6.2         22.2         34.0	mm [incn]
130.0   250.0   170.0   116.0   236.0   45.8   6.2   22.2   34.0	Ф3
	28.0
A [5.12] [9.84] [6.69] [4.57] [9.29] [1.80] [0.24] [0.87] [1.34]	[1.10]

#### Frame B

VFD075CP23A-21; VFD110CP23A-21; VFD150CP23A-21; VFD110CP43B-21; VFD150CP43B-21; VFD185CP43B-21; VFD110CP4EB-21; VFD150CP4EB-21; VFD185CP4EB-21; VFD055CP53A-21; VFD075CP53A-21; VFD150CP53A-21










Detail A (Mounting Hole)




Detail B (Mounting Hole)


Figure 1-15


									Unit:	mm [inch]
Frame	W	Н	D	W1	H1	D1*	S1	Ф1	Ф2	Ф3
В	190.0	320.0	190.0	173.0	303.0	77.9	8.5	22.2	34.0	43.8
В	[7.48]	[12.60]	[7.48]	[6.81]	[11.93]	[3.07]	[0.33]	[0.87]	[1.34]	[1.72]

#### Frame C

VFD185CP23A-21; VFD220CP23A-21; VFD300CP23A-21; VFD220CP43A-21; VFD300CP43B-21; VFD370CP43B-21; VFD370CP4EB-21; VFD370CP4EB-21; VFD370CP4EB-21; VFD370CP63A-21; VFD370CP63A-21; VFD370CP63A-21









Detail A (Mounting Hole)





Detail B (Mounting Hole)

Figure 1-16

									Unit:	: mm [inch]
Frame	W	Η	D	W1	H1	D1*	S1	Ф1	Ф2	Ф3
	250.0	400.0	210.0	231.0	381.0	92.9	8.5	22.2	34.0	50.0
	[9.84]	[15.75]	[8.27]	[9.09]	[15.00]	[3.66]	[0.33]	[0.87]	[1.34]	[1.97]

# D0-1: VFD450CP43S-00; VFD550CP43S-00








Figure 1-17

Unit: mm [inch]

									Offit.	
Frame	W	H1	D	W1	H2	H3	D1*	D2	S1	S2
D0 1	280.0	500.0	255.0	235.0	475.0	442.0	94.2	16.0	11.0	18.0
D0-1	[11.02]	[19.69]	[10.04]	[9.25]	[18.70]	[17.40]	[3.71]	[0.63]	[0.43]	[0.71]

# D0-2: VFD450CP43S-21; VFD550CP43S-21






Figure 1-18

													Unit: mr	m [inch]
Frame	W	Н	D	W1	H1	H2	Н3	D1*	D2	S1	S2	Ф1	Ф2	Ф3
D0-2			255.0				442.0		16.0	11.0	18.0	62.7	34.0	22.0
D0-2	[11.02]	[24.19]	[10.04]	[9.25]	[19.69]	[18.70]	[17.40]	[3.71]	[0.63]	[0.43]	[0.71]	[2.47]	[1.34]	[0.87]

D1: VFD370CP23A-00; VFD450CP23A-00; VFD750CP43B-00; VFD900CP43A-00; VFD450CP63A-00; VFD550CP63A-00








Figure 1-19

Unit: mm [inch] Frame W Н D W1 H1 H2 Н3 D1\* D2 S1 S2 Ф1 Ф2 Ф3 330.0 275.0 550.0 525.0 492.0 107.2 285.0 16.0 11.0 18.0 D1 12.99] [10.83] [11.22] [21.65] [20.67] [19.37] [4.22] [0.63][0.43][0.71]

D2: VFD370CP23A-21; VFD450CP23A-21; VFD750CP43B-21; VFD900CP43A-21; VFD450CP63A-21; VFD550CP63A-21





Figure 1-20

													Unit: mr	n [inch]
Frame	W	Ι	D	W1	H1	H2	Н3	D1*	D2	S1	S2	Ф1	Ф2	Ф3
D2	330.0	688.3	275.0	285.0	550.0	525.0	492.0	107.2	16.0	11.0	18.0	76.2	34.0	22.0
D2	[12.99]	[27.10]	[10.83]	[11.22]	[21.65]	[20.67]	[19.37]	[4.22]	[0.63]	[0.43]	[0.71]	[3.00]	[1.34]	[0.87]
													_:	

#### Frame E

E1: VFD550CP23A-00; VFD750CP23A-00; VFD900CP23A-00; VFD1100CP43A-00; VFD1320CP43B-00; VFD750CP63A-00; VFD900CP63A-00; VFD1100CP63A-00; VFD1320CP63A-00






Figure 1-21

Unit: mm [inch] Frame W W1 H2 Н3 D1\* D2 S1/S2 S3 Ф1 Φ2 Ф3 370.0 300.0 589.0 560.0 528.0 143.0 335.0 18.0 13.0 18.0 E1 14.57] [11.81]|[13.19]|[23.19]|[22.05]|[20.80]| [5.63] [0.71] [0.51][0.71]

#### Frame E

E2: VFD550CP23A-21; VFD750CP23A-21; VFD900CP23A-21; VFD1100CP43A-21; VFD1320CP43B-21; VFD750CP63A-21; VFD900CP63A-21; VFD1100CP63A-21; VFD1320CP63A-21




Figure 1-22

													Unit: mi	m [inch]
Frame	W	Н	D	W1	H1	H2	Н3	D1*	D2	S1, S2	S3	Ф1	Ф2	Ф3
ГЭ	370.0	715.8	300.0	335.0	589.0	560.0	528.0	143.0	18.0	13.0	18.0	22.0	34.0	92.0
E2	[14.57]	[28.18]	[11.81]	[13.19	[23.19]	[22.05]	[20.80]	[5.63]	[0.71]	[0.51]	[0.71]	[0.87]	[1.34]	[3.62]
												D1*: F	Flange n	nounting

### Frame F

# F1: VFD1600CP43A-00; VFD1850CP43B-00; VFD1600CP63A-00; VFD2000CP63A-00





Figure 1-23

											Unit: n	nm [inch]
Frame	W	Ι	D	W1	H1	H2	H3	D1*	D2	S1	S2	S3
E1	420.0		300.0	380.0	800.0	770.0	717.0	124.0	18.0	13.0	25.0	18.0
F1	[16.54]	-	[11.81]	[14.96]	[31.50]	[30.32]	[28.23]	[4.88]	[0.71]	[0.51]	[0.98]	[0.71]
Frame	Ф1	Ф2	Ф3									
F1	-	-	-									

#### Frame F

# F2: VFD1600CP43A-21; VFD1850CP43B-21; VFD1600CP63A-21; VFD2000CP63A-21



Detail B (Mounting Hole)

		Unit: n	nm [inch]
D2	S1	S2	S3
18.0	13.0	25.0	18.0
[0.71]	[0.51]	[0.98]	[0.71]

Г	[16.54]	[37.00]	[11.81]
Frame	Ф1	Ф2	Ф3
F2	92.0	35.0	22.0
	[3.62]	[1.38]	[0.87]

420.0 940.0 300.0

Frame

W1

380.0

[14.96]

H1

800.0

[31.50]

D1\*: Flange mounting

H2

770.0

[30.32]

НЗ

717.0

[28.23]


D1\*

124.0

[4.88]

### Frame G


G1: VFD2000CP43A-00; VFD2200CP43A-00; VFD2500CP43A-00; VFD2800CP43A-00; VFD2500CP63A-00; VFD3150CP63A-00



												Unit: m	ım [inch]
Frame	W	Н	D	W1	H1	H2	Н3	S1	S2	S3	Ф1	Ф2	Ф3
G1	500.0		397.0	440.0	1000.0	963.0	913.6	13.0	26.5	27.0			
Gi	[19.69]	-	[15.63]	[217.32]	[39.37]	[37.91]	[35.97]	[0.51]	[1.04]	[1.06]	-	_	-

#### Frame G

G2: VFD2000CP43A-21; VFD2200CP43A-21; VFD2500CP43A-21; VFD2500CP43A-21; VFD2500CP63A-21; VFD3150CP63A-21









Figure 1-26

												Unit: m	m [inch]
Frame	W	Н	D	W1	H1	H2	Н3	S1	S2	S3	Ф1	Ф2	Ф3
G2	500.0	1240.2	397.0	440.0	1000.0	963.0	913.6	13.0	26.5	27.0	22.0	34.0	117.5
G2	[19.69]	[48.83]	[15.63]	[217.32]	[39.37]	[37.91]	[35.97]	[0.51]	[1.04]	[1.06]	[0.87]	[1.34]	[4.63]

H1: VFD3150CP43A-00; VFD3550CP43A-00; VFD4000CP43A-00; VFD5000CP43A-00; VFD5600CP43A-00; VFD6300CP43A-00










Detail B (Mounting Hole)

Figure 1-27

Unit: mm [inch] Frame W Н D W1 W2 W3 W4 W5 W6 H2 H4 H1 Н3 398.0 630.0 700.0 1435.0 290.0 1403.0 1346.6 H1 [55.24] [53.02] [27.56][56.5] [15.67] [24.8] [11.42]D5 S1 S2 Ф2 Frame H5 D1 D2 D3 D4 D6 S3 Ф1 Ф3 45.0 13.0 26.5 25.0 H1 [1.77][0.51][1.04][0.98]

H2: VFD3150CP43C-00; VFD3550CP43C-00; VFD4000CP43C-00; VFD5000CP43C-00







Figure 1-28

												Unit: m	m [inch]
Frame	W	I	D	W1	W2	W3	W4	W5	W6	H1	H2	Н3	H4
H2	700.0	1745.0	404.0	630.0	500.0	630.0	760.0	800.0		1729.0	1701.6		
ПZ	[27.56]	[68.70]	[15.90]	[24.8]	[19.69]-	[24.80]	[29.92]	[31.5]	-	[68.07]	[66.99]	-	-
Frame	H5	D1	D2	D3	D4	D5	D6	S1	S2	S3	Ф1	Ф2	Ф3
H2		51.0	38.0	65.0	204.0	68.0	137.0	13.0	26.5	25.0			
112	-	[2.00]	[1.50]	[2.56]	[8.03]	[2.68]	[5.40]	[0.51]	[1.04]	[0.98]	-	-	-

H3: VFD3150CP43C-21; VFD3550CP43C-21; VFD4000CP43C-21; VFD5000CP43C-21; VFD5600CP43C-21; VFD6300CP43C-21






Figure 1-29

Unit: mm [inch]

Frame	W	Н	D	W1	W2	W3	W4	W5	W6	H1	H2	Н3	H4
НЗ	700.0	1745.0	404.0	630.0	500.0	630.0	760.0	800.0		1729.0	1701.6		
пэ	[27.56]	[68.70]	[15.91]	[24.80]	[19.69]	[24.80]	[29.92]	[31.5]	-	[68.07]	[66.99]	-	-
Frame	H5	D1	D2	D3	D4	D5	D6	S1	S2	S3	Ф1	Ф2	Ф3
НЗ		51.0	38.0	65.0	204.0	68.0	137.0	13.0	26.5	25.0	22.0	34.0	117.5
ПЗ	-	[2.00]	[1.50]	[2.56]	[8.03]	[2.68]	[5.40]	[0.51]	[1.04]	[0.98]	[0.87]	[1.34]	[4.63]

H1: VFD4000CP63A-00; VFD4500CP63A-00; VFD5600CP63A-00; VFD6300CP63A-00




Figure 1-30

											l	Jnit: mn	n [inch]
Frame	W	W1	W2	Н	H1	H2	H3	D	D1	S1	S2	S3	S4
Ш4	700.0	630.0	290.0	1435.0	1389.0	1346.6	1375.0	398.0	45.0	26.5	13.0	14.0	25.0
"	[27 56]	124 801	[11 42]	[56 50]	154 681	153 021	[54 13]	[15 67]	[1 77]	[1 04]	[0.51]	[0.55]	[89.01

H2: VFD4000CP63A-21; VFD4500CP63A-21; VFD5600CP63A-21; VFD6300CP63A-21




Figure 1-31

												Unit: m	m [inch]
Frame	W	W1	W2	W3	W4	W5	Н	H1	H2	H3	D	D1	D2
H2	700.0	630.0	800.0	500.0	630.0	760.0	1745.0	1715.0	74.5	137.0	404.0	51.0	68.0
ПZ	[27.56]	[24.80]	[31.50]	[19.69]	[24.80]	[29.92]	[68.70]	[67.52]	[2.93]	[5.39]	[15.91]	[2.01]	[2.68]
Frame	D3	D4	D5	S1	S2	S3	S4	S5	Ф1	Ф2	Ф3		
H2	137.0	103.0	204.0	26.5	13.0	14.0	25.0	13.0	22.0	34.0	117.50		
112	[5.39]	[4.06]	[8.03]	[1.04]	[0.51]	[0.55]	[0.98]	[0.51]	[0.87]	[1.34]	[4.63]		

# **Digital Keypad**

KPC-CC01




Figure 1-32


# Chapter 2 Installation

- 2-1 Mounting Clearance
- 2-2 Airflow and Power Dissipation

### 2-1 Mounting Clearance

- ☑ Prevent fiber particles, scraps of paper, shredded wood, sawdust, metal particles, etc. from adhering to the heat sink.
- ☑ Install the AC motor drive in a metal cabinet. When installing one drive below another one, use a metal separator between the AC motor drives to prevent mutual heating and to prevent the risk of fire accident.
- ☑ Install the AC motor drive in Pollution Degree 2 environments only: Normally only nonconductive pollution occurs and temporary conductivity caused by condensation is expected.

The appearances shown in the following figures are for reference only. The actual motor drives may look different.



Multiple drives side-by-side vertical installation

#### Ta: Frame A–G Ta\*: Frame H

When installing one AC motor drive below another one (top-bottom installation), use a metal separator between the drives to prevent mutual heating. The temperature measured at the fan's inflow side must be lower than the temperature measured at the operation side. If the fan's inflow temperature is higher, use a thicker or larger size of metal separator. Operation temperature is the temperature measured at 50 mm away from the fan's inflow side (as shown in the figure below).

(Frame A-C)




Figure 2-5

#### (Frame D0-G)

Install metal separator between the drives.




Figure 2-6

#### Minimum mounting clearance

Frame	A [mm]	B [mm]	C [mm]	D [mm]
A–C	60	30	10	0
D0-F	100	50	-	0
G	200	100	-	0
Н	350	0	0	200 (Ta = Ta* = 50°C)
Н	350	0	0	100 (Ta = Ta* = 40°C)

Table 2-1



The minimum mounting clearances A–D stated in the table above apply to AC motor drives installation. Failing to follow the minimum mounting clearances may cause the fan to malfunction and heat dissipation problems.

	NEDOSTOPOSA OL NEDOSTOPIONI/EN OL NEDOSTOPOSA OL NEDOSTOPIONI/ED OL
	VFD007CP23A-21; VFD007CP43A/4EA-21; VFD015CP23A-21; VFD015CP43B/4EB-21; VFD023CP23A-21; VFD023
Frama A	VFD022CP23A-21; VFD022CP43B/4EB-21; VFD037CP23A-21; VFD037CP43B/4EB-21;
	VFD040CP43A/4EA-21; VFD055CP23A-21; VFD055CP43B/4EB-21; VFD075CP43B/4EB-21;
	VFD015CP53A-21; VFD022CP53A-21; VFD037CP53A-21
	VFD075CP23A-21; VFD110CP23A-21; VFD110CP43B/4EB -21; VFD150CP23A-21;
Frame B	VFD150CP43B/4EB-21; VFD185CP43B/4EB-21; VFD055CP53A-21; VFD075CP53A-21;
	VFD110CP53A-21; VFD150CP53A-21
	VFD185CP23A-21; VFD220CP23A-21; VFD220CP43A/4EA -21; VFD300CP23A-21;
Frame C	VFD300CP43B/4EB-21; VFD370CP43B/4EB-21; VFD185CP63A-21; VFD220CP63A-21;
	VFD300CP63A-21; VFD370CP63A-21
Frame D0	VFD450CP43S-00; VFD550CP43S-00; VFD450CP43S-21; VFD550CP43S-21
Гиана В	VFD370CP23A-00/23A-21; VFD450CP23A-00/23A-21; VFD750CP43B-00/43B-21;
Frame D	VFD900CP43A-00/43A-21; VFD450CP63A-00/63A-21; VFD550CP63A-00/63A-21
	VFD550CP23A-00/23A-21; VFD750CP23A-00/23A-21; VFD900CP23A-00/23A-21;
Frame E	VFD1100CP43A-00/43A-21; VFD1320CP43B-00/43B-21; VFD750CP63A-00/63A-21;
	VFD900CP63A-00/63A-21; VFD1100CP63A-00/63A-21; VFD1320CP63A-00/63A-21
Гиана г	VFD1600CP43A-00/43A-21; VFD1850CP43B-00/43B-21; VFD1600CP63A-00/63A-21;
Frame F	VFD2000CP63A-00/63A-21
Frame G	VFD2000CP43A-00/43A-21; VFD2200CP43A-00/43A-21; VFD2500CP43A-00/43A-21;
Frame G	VFD2800CP43A-00/43A-21; VFD2500CP63A-00/63A-21; VFD3150CP63A-00/63A-21
	VFD3150CP43A-00/43C-00/43C-21; VFD3550CP43A-00/43C-00/43C-21;
Frame U	VFD4000CP43A-00/43C-00/43C-21; VFD5000CP43A-00/43C-00/43C-21;
Frame H	VFD5600CP43A-00/43C-21; VFD6300CP43A-00/43C-21; VFD4000CP63A-00/63A-21;
	VFD4500CP63A-00/63A-21; VFD5600CP63A-00/63A-21; VFD6300CP63A-00/63A-21

Table 2-2




Figure 2-7

# NOTE

- \*\* The mounting clearance stated in the figure is for installing the drive in an open area. To install the drive in a confined space (such as cabinet or electric box), follow the following rules: (1) Keep the minimum mounting clearances. (2) Install a ventilation equipment or an air conditioner to keep surrounding temperature lower than operation temperature. (3) Refer to parameter setting and set up Pr.00-16, Pr.00-17, and Pr.06-55.
- The table below shows the heat dissipation and the required air volume when installing a single drive in a confined space. When installing multiple drives, the required air volume shall be multiplied by the number of the drives.
- Refer to the table below (Airflow Rate for Cooling) for ventilation equipment design and selection.
- Refer to the table below (Power Dissipation for AC Motor Drive) for air conditioner design and selection.
- Different control mode affects the derating. See Pr.06-55 for more information.
- Ambient temperature derating curve shows the derating status in different temperature in relation to different protection level.
- Refer to Section 9-7 for ambient temperature derating curve and derating curves under different control modes.
- If UL Type 1 models need side-by-side installation, remove the top cover for Frame A–C. Do NOT install the conduit box for Frame D and above.

# 2-2 Airflow and Power Dissipation

	Airflow Rate for Cooling						Power Dissipation for AC Motor Drive			
Model No.	Flow	Rate (Unit	:: cfm)	Flow Rate (Unit: m³/hr)			Power Dissipation (Unit: watt)			
meder ive.		Internal	Total	External	Internal	Total	Loss External (Heat Sink)	Internal	Total	
VFD007CP23A-21	-	-	-	-	-	-	40	31	71	
VFD015CP23A-21	-	-		-	-	-	61	39	100	
VFD022CP23A-21	14	-	14	24	-	24	81	45	126	
VFD037CP23A-21	14	-	14	24	-	24	127	57	184	
VFD055CP23A-21	10	-	10	17	-	17	158	93	251	
VFD075CP23A-21	40	14	54	68	24	92	291	101	392	
VFD110CP23A-21	66	14	80	112	24	136	403	162	565	
VFD150CP23A-21	58	14	73	99	24	124	570	157	727	
VFD185CP23A-21	166	12	178	282	20	302	622	218	840	
VFD220CP23A-21	166	12	178	282	20	302	777	197	974	
VFD300CP23A-21	146	12	158	248	20	268	878	222	1100	
VFD370CP23A-00/	179	30	209	304	51	355	1271	311	1582	
VFD370CP23A-21	179	30	209	304	51	333	1271	311	1302	
VFD450CP23A-00/ VFD450CP23A-21	179	30	209	304	51	355	1550	335	1885	
VFD550CP23A-00/ VFD550CP23A-21	228	73	301	387	124	511	1762	489	2251	
VFD750CP23A-00/ VFD750CP23A-21	228	73	301	387	124	511	2020	574	2594	
VFD900CP23A-00/ VFD900CP23A-21	246	73	319	418	124	542	2442	584	3026	
VFD007CP43A/ VFD007CP4EA-21	-	-	-	-	-	-	35	32	67	
VFD015CP43B/ VFD015CP4EB-21	-	-	-	-	-	-	48	39	87	
VFD022CP43B/ VFD022CP4EB-21	-	-	-	-	-	-	64	52	116	
VFD037CP43B/ VFD037CP4EB-21	14	-	14	24	-	24	103	77	180	
VFD040CP43A/ VFD040CP4EA-21	10	-	10	17	ı	17	124	81	205	
VFD055CP43B/ VFD055CP4EB-21	10	-	10	17	-	17	142	116	258	
VFD075CP43B/ VFD075CP4EB-21	10	-	10	17	-	17	205	129	334	
VFD110CP43B/ VFD110CP4EB-21	40	14	54	68	24	92	291	175	466	
VFD150CP43B/ VFD150CP4EB-21	66	14	80	112	24	136	376	190	566	
VFD185CP43B/ VFD185CP4EB-21	58	14	73	99	24	124	396	210	606	
VFD220CP43A/ VFD220CP4EA-21	99	21	120	168	36	204	455	358	813	
VFD300CP43B/ VFD300CP4EB-21	99	21	120	168	36	204	586	410	996	
VFD370CP43B/ VFD370CP4EB-21	126	21	147	214	36	250	778	422	1200	
VFD450CP43S-00/ VFD450CP43S-21	179	30	209	304	51	355	1056	459	1515	
VFD550CP43S-00/ VFD550CP43S-21	179	30	209	304	51	355	1163	669	1832	
VFD750CP43B-00/ VFD750CP43B-21	179	30	209	304	51	355	1407	712	2119	
VFD900CP43A-00/ VFD900CP43A-21	186	30	216	316	51	367	1787	955	2742	
VFD1100CP43A-00/ VFD1100CP43A-21	257	73	330	437	124	561	2112	1084	3196	
VFD1320CP43B-00/ VFD1320CP43B-21	223	73	296	379	124	503	2597	1220	3817	

#### Chapter 2 Installation | CP2000

	Airflow Rate for Cooling						Power Dissipation for AC Motor Drive		
Model No.	Flow Rate (Unit: cfm			m) Flow Rate (Unit: m³/hr)			Power Dissipation (Unit: watt)		
	External	Internal	Total	External	Internal	Total	Loss External (Heat Sink)	Internal	Total
VFD1600CP43A-00/ VFD1600CP43A-21	224	112	336	381	190	571	3269	1235	4504
VFD1850CP43B-00/ VFD1850CP43B-21	289	112	401	491	190	681	3814	1570	5384
VFD2000CP43A-00/ VFD2000CP43A-21			454			771			5741
VFD2200CP43A-00/ VFD2200CP43A-21			454			771			6358
VFD2500CP43A-00/ VFD2500CP43A-21			454			771			6662
VFD2800CP43A-00/ VFD2800CP43A-21			454			771			7325
VFD3150CP43A-00/ VFD3150CP43C-00/ VFD3150CP43C-21			769			1307			8513
VFD3550CP43A-00/ VFD3550CP43C-00/ VFD3550CP43C-21			769			1307			9440
VFD4000CP43A-00/ VFD4000CP43C-00/ VFD4000CP43C-21			769			1307			10642
VFD5000CP43A-00/ VFD5000CP43C-00/ VFD5000CP43C-21			769			1307			13364
VFD5600CP43A-00/ VFD5600CP43C-21			952.9			1618.9			14350
VFD6300CP43A-00/ VFD6300CP43C-21			952.9			1618.9			16150
VFD015CP53A-21	_	_	-	_	_	_	39.5	13.0	53
VFD022CP53A-21	-	-	-	-	-	-	55.0	22.0	77
VFD037CP53A-21	0.006	-	0.006	13.6	_	13.6	86.8	42.7	130
VFD055CP53A-21	0.019	0.007	0.026	40.0	14.5	54.5	124.6	67.9	193
VFD075CP53A-21	0.019	0.007	0.026	40.0	14.5	54.5	143.5	119.0	263
VFD110CP53A-21	0.019	0.007	0.026	40.0	14.5	54.5	222.2	162.8	385
VFD150CP53A-21	0.019	0.007	0.026	40.0	14.5	54.5	308.5	216.5	525
VFD185CP63A-21	90.0	21.3	111.4	153.0	36.2	189.2	317.5	145.0	462.5
VFD220CP63A-21	90.0	21.3	111.4	153.0	36.2	189.2	408.2	141.8	550.0
VFD300CP63A-21	90.0	21.3	111.4	153.0	36.2	189.2	492.7	257.3	750.0
VFD370CP63A-21	89.0	21.3	110.3	151.2	36.2	187.5	641.6	283.4	925.0
VFD450CP63A-00/21	175.9	36.4	212.3	298.8	61.8	360.6	718.2	406.8	1125.0
VFD550CP63A-00/21	175.9	36.4	212.3	298.8	61.8	360.6	890.1	484.9	1375.0
VFD750CP63A-00/21	264.6	90.6	355.2	449.6	153.9	603.5	1356.0	519.0	1875.0
VFD900CP63A-00/21	264.6	90.6	355.2	449.6	153.9	603.5	1652.8	597.2	2250.0
VFD1100CP63A-00/21	264.6	90.6	355.2	449.6	153.9	603.5	1960.3	789.7	2750.0
VFD1320CP63A-00/21			355.2	449.6		603.5	2230.8	1069.2	
	264.6	90.6			153.9				3300.0
VFD1600CP63A-00/21	248.1	135.3	383.4	421.6	229.9	651.4	2627.3	1372.7	4000.0
VFD2000CP63A-00/21	248.1	135.3	383.4	421.6	229.9	651.4	3415.0	1585.0	5000.0
VFD2500CP63A-00/21	1		409.7			696.0	4751.7	1498.3	6250.0
VFD3150CP63A-00/21	<b>.</b>		409.7			696.0	5695.4	2179.6	7875.0
VFD4000CP63A-00/21	<b>.</b>		563.0			956.4	6796.2	3203.8	10000.0
VFD4500CP63A-00/21	]		952.9	]		1618.9	7313.6	3936.4	11250.0
VFD5600CP63A-00/21			952.9			1618.9	9553.4	4446.6	14000.0
VFD6300CP63A-00/21			952.9			1618.9	11042.4	4707.6	15750.0

## Chapter 2 Installation | CP2000

	Airflow Rate for Cooling						Power Dissipation for AC Motor Drive			
Model No.	Flow Rate (Unit: cfm)			Flow Rate (Unit: m³/hr)			Power Dissipation (Unit: watt)			
	External	Internal	Total	External	Internal	Total	Loss External (Heat Sink)	Internal	Total	
<ul> <li>The required airflow confined space.</li> <li>When installing mult required air volume for the confined a</li></ul>	iple drive	s, the requ	uired air v	olume sho	ould be the		the table is drive in a co  When insta volume of h should be th single drive drives.  Heat dissipate is calculated	ssipation sho for installing onfined space lling multiple eat dissipation he heat dissipation the number the number ation for each d by rated vous default carri	single e. drives, on pated for er of the n model oltage,	

Table 2-3

[The page intentionally left blank]


# Chapter 3 Unpacking


- 3-1 Unpacking
- 3-2 The Lifting Hook

The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time.

# 3-1 Unpacking

Follow these steps to unpack the AC motor drive:





#### Frame D (crate version)

#### Unpacking 1 (VFDXXXCPXXX-00)

Loosen the 12 screws to open the top cover of the crate.





Figure 3-7

#### Unpacking 2 (VFDXXXCPXXX-21)

Loosen the 16 screws at the four corners of the crate, and then remove the iron plates.



Take out the EPEs and the manual.





Figure 3-8

Remove the top cover, take out the EPEs, rubber and the manual.



Loosen the eight screws fasten the drive on the pallet, and then remove the wood plate.





Figure 3-9


Lift the drive by hooking the lifting hole. It is now ready for installation.

Figure 3-10

Loosen the ten screws fasten the drive on the pallet, and then remove the wood plate.



Lift the drive by hooking the lifting hole. It is now ready for installation.



#### Frame E

#### Unpacking 1 (VFDXXXCPXXX-00)

Loosen the 16 screws at the four corners of the crate, and then remove the iron plates.




Figure 3-15

## Unpacking 2 (VFDXXXCPXXX-21)

Loosen the 16 screws at the four corners of the crate, and then remove the iron plates.




Figure 3-19

Remove the top cover, take out the EPEs and the manual.




Figure 3-16

Remove the top cover, take out the EPEs, rubber and the manual.




Figure 3-20

Loosen the eight screws fasten the drive on the pallet, and then remove the wood plate.






Figure 3-17

Loosen the ten screws fasten the drive on the pallet, and then remove the wood plates and the conduit box.





#### Frame F

#### Unpacking 1 (VFDXXXCPXXX-00)

Remove the six buckles fixed on the crate with a flat-head screwdriver, see the figure below.




Figure 3-23

Unpacking 2 (VFDXXXCPXXX-21)

Remove the six buckles fixed on the crate with a flat-head screwdriver, see the figure below.




Figure 3-27

Remove the top cover, take out the EPEs and the manual.






Figure 3-24


Remove the top cover, take out the EPEs, rubber and the manual.




Loosen the five screws fasten the drive on the pallet, see the figure below.



Loosen the five screws fasten the drive on the pallet, and then remove the wood plates and the conduit box.





#### Frame G

#### Unpacking 1 (VFDXXXXCPXXA-00)

Remove the six buckles fixed on the crate with a flat-head screwdriver, see the figure below.





Figure 3-31

Unpacking 2 (VFDXXXXCPXXA-21)

Remove the six buckles fixed on the crate with a flat-head screwdriver, see the figure below.



Remove the top cover, take out the EPEs and the manual.




Figure 3-32

Remove the top cover, take out the EPEs, rubber and the manual.







Figure 3-36

Loosen the five screws fasten the drive on the pallet, see the figure below.



Loosen the 12 screws fasten the drive on the pallet, and then remove the wood plates and the conduit box.





#### Frame H

#### Unpacking 1 (VFDXXXXCPXXA-00)

Remove the eight buckles fixed on the crate with a flat-head screwdriver, see the figure below.




Figure 3-39

#### Unpacking 2 (VFDXXXXCPXXC-00)

Remove the eight buckles fixed on the crate with a flat-head screwdriver, see the figure below.






Figure 3-43


Remove the top cover, take out the EPEs and the manual.




Loosen the six screws fasten the drive on the pallet, and then remove six metal washers and six




Remove the top cover, take out the EPEs and the manual.




Loosen the six screws fasten the drive on the pallet, and then remove six metal washers and six plastic washers. See the figure below.



Lift the drive by hooking the lifting hole. It is now ready for installation.




Loosen the six M6 screws and the iron plates (see the figure below). You can use the removed screws and iron plates to fix the drive from outside.




This description is how to fix the drive from the outside. You can skip to the next step if it is not necessary.

Loosen the eight M8 screws, and then use these eight M8 screws to fix the iron plates (removed at the last step) to the drive, see the figure below.

Torque: 150–180 kg-cm / [130.20–156.24 lb-in.] / [14.7–17.6 Nm]



Lift the drive by hooking the lifting hole. It is now ready for installation.



#### Frame H

#### Unpacking 3 (VFDXXXXCPXXC-21)

Remove the eight buckles fixed on the crate with a flat-head screwdriver, see the figure below.




Figure 3-49

Remove the top cover, take out the EPEs and the manual.




Figure 3-50

Loosen the six screws fasten the drive on the pallet, and then remove six metal washers and six plastic washers. See the figure below.




Figure 3-51

Loosen the six M6 screws and the iron plates (see the figure below). You can use the removed screws and iron plates to fix the drive from the outside.




Figure 3-52

#### Fix the drive from the inside

Loosen the 18 M6 screws and remove the covers (see the figure 3-54). After fixing the drive and the cover for cables (see the figure 3-53), fasten the other covers back (see the figure 3-54)

Torque: 35–45 kg-cm / [30.38–39.06 lb-in.] / [3.4–4.4 Nm]





Figure 3-53


Cover for cables (use M12 screws)




#### Fix the drive from the outside

Loosen the eight M8 screws, and then use these eight M8 screws to fix the iron plates (removed at the last step) to the drive, see the figure below.

Torque: 150–180 kg-cm / [130.20–156.24 lb-in.] / [14.7–17.6 Nm]





# 690V Frame H

# Unpacking 1 (VFDXXXXCP63A-00)

Remove the eight buckles fixed on the crate with a flat-head screwdriver, see the figure below.




Figure 3-59

Remove the top cover, take out the EPEs and the manual.




Figure 3-60

Loosen the six screws fasten the drive on the pallet, and then remove six metal washers and six plastic washers. See the figure below.





Figure 3-61

# Chapter 3 Unpacking | CP2000



## 690V Frame H

#### Unpacking 2 (VFDXXXXCP63A-21)

Remove the eight buckles fixed on the crate with a flat-head screwdriver, see the figure below.




Figure 3-63

Remove the top cover, take out the EPEs and the manual.




Figure 3-64

Loosen the six screws fasten the drive on the pallet, and then remove six metal washers and six plastic washers. See the figure below.




Figure 3-65

Loosen the six M6 screws and the iron plates (see the figure below). You can use the removed screws and iron plates to fix the drive from the outside.





Figure 3-66


#### Fix the drive from the inside.

Loosen the 18 M6 screws and remove the covers (see the figure 3-68). After fixing the drive and the cover for cables (see the figure 3-67), fasten the other covers back (see the figure 3-68)

Torque: 35–45 kg-cm / [30.38–39.06 lb-in.] / [3.4–4.4 Nm]



Cover for cables (use M12 screws)



#### Fix the drive from the outside.

Loosen the eight M8 screws, and then use these eight M8 screws to fix the iron plates (removed at the last step) to the drive, see the figure below.

Torque: 150–180 kg-cm / [130.20–156.24 lb-in.] / [14.7–17.6 Nm]






Figure 3-70



# Frame H: Fix the drive


#### H1: VFDXXXXCPXXA-00



Screw M12\*6 Torque: 340–420 kg-cm / [295.1–364.6 lb-in.] / [33.3–41.2 Nm]

Figure 3-73


#### H2: VFDXXXXCPXXC-00



Fix the drive from the inside Screw M12\*8 Torque: 340–420 kg-cm / [295.1–364.6 lb-in.] / [33.3–41.2 Nm]

Figure 3-74

#### H3: VFDXXXXCPXXC-21



Fix the drive from the outside Screw M12\*8 Torque: 340–420 kg-cm / [295.1–364.6 lb-in.] / [33.3–41.2 Nm]

Figure 3-75


#### H1: VFDXXXXCP63A-00



Screw M12\*6 Torque: 340-420 kg-cm / [295.1-364.6 lb-in.] / [33.3-41.2 Nm]

Figure 3-76

#### H2: VFDXXXXCP63A-21




Fix the drive from the outside

Fix the drive from the outside Screw M12\*8 Torque: 340–420 kg-cm / [295.1–364.6 lb-in.] / [33.3–41.2 Nm]

Figure 3-77

# 3-2 The Lifting Hook

The arrows indicate the location of the lifting holes of frame D to H, as shown in figure below:



# Frame F F Applicable models: VFD1600CP43A-00; VFD1850CP43B-00; VFD1600CP63A-00; VFD2000CP63A-00; VFD1600CP43A-21; VFD1850CP43B-21; VFD1600CP63A-21; VFD2000CP63A-21 Figure 3-81 Frame G G Applicable models: VFD2000CP43A-00; VFD2200CP43A-00; VFD2500CP43A-00; VFD2800CP43A-00; VFD2500CP63A-00; VFD3150CP63A-00; VFD2000CP43A-21; VFD2200CP43A-21; VFD2500CP43A-21; VFD2800CP43A-21; VFD2500CP63A-21; VFD3150CP63A-21 Figure 3-82 Frame H Н Applicable models: VFD3150CP43A-00; VFD3550CP43A-00; VFD4000CP43A-00; VFD5000CP43A-00; VFD5600CP43A-00; VFD6300CP43A-00; VFD3150CP43C-00; VFD3550CP43C-00; VFD4000CP43C-00; VFD5000CP43C-00; VFD3150CP43C-21; VFD3550CP43C-21; VFD4000CP43C-21; VFD5000CP43C-21; VFD5600CP43C-21; VFD6300CP43C-21; VFD4000CP63A-00; VFD4500CP63A-00; VFD5600CP63A-00; VFD6300CP63A-00 Figure 3-83

# 690V Frame H2 Applicable models: VFD4000CP63A-21; VFD4500CP63A-21; VFD5600CP63A-21; VFD6300CP63A-21 Figure 3-84

Ensure the lifting hook properly goes through the lifting hole, as shown in the following diagram.

#### Applicable to Frame D0-E




Figure 3-85

#### Applicable to Frame F-H




Figure 3-86

Ensure the angle between the lifting holes and the lifting device is within the specification, as shown in the following figure.

#### Applicable to Frame D0-E







Figure 3-87

Applicable to Frame F–H, 690V Frame H3 Following drawing is only for demonstration, it may be slightly different with the machine you have.



#### Weight





# Chapter 4 Wiring

- 4-1 System Wiring Diagram
- 4-2 Wiring

#### Chapter 4 Wiring | CP2000

After removing the front cover, please check if the power and control terminals are clearly noted. Please read following precautions to avoid wiring mistakes.




- ☑ It is crucial to cut off the AC motor drive power before any wiring installation are made. A charge may still remain in the DC BUS capacitors with hazardous voltages even if the power has been turned off. Therefore, it is suggested for users to measure the remaining voltage by DC voltage meter before wiring. For your personnel safety, please do not perform any wiring before the voltage drops to a safe level < 25 V<sub>DC</sub>. Wiring installation with remaining voltage condition may cause sparks and short circuit.
- ☑ Only qualified personnel familiar with AC motor drives is allowed to perform installation, wiring and commissioning. Make sure the power is turned off before wiring to prevent electric shock.
- ☑ Make sure that power is only applied to the R/L1, S/L2, and T/L3 terminals. Failure
  to comply may result in damage to the equipment. The voltage and current should
  lie within the range as indicated on the nameplate (Chapter 1-1 Nameplate
  Information).
- ☑ All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock.
- ☑ Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.



- ☑ When wiring, please choose the wires with specification that complies with local regulation for your personnel safety.
- ☑ Check following items after finishing the wiring:
  - 1. Are all connections correct?
  - 2. Any loosen wires?
  - 3. Any short-circuits between the terminals or to ground?

# 4-1 System Wiring Diagram



NOTE Please refer to Chapter 4-2 Wiring Diagram for detailed wiring information.

Table 4-1

# 4-2 Wiring




Figure 4-2




Figure 4-3

<sup>\*1</sup> Please refer to Chapter 7-1 for brake units and resistors selection

## Wiring Diagram for Frame G-H Input: 3-phase power \*1 Braking resistor (optional) Braking module +1/DC -/DC U/T1 Motor DQ+ R/L11 V/T2 DC reactor 3~ S/L21 W/T3 T/L31 R/L12 S/L22 DC-T/L32 Power -→ Transformer → Inverter

Figure 4-4

- \*1 Please refer to Chapter 7-1 for brake units and resistors selection
- NOTE When wiring for 12 Pulse Input, please strictly follow above wiring diagram.

#### Wiring Diagram for Frame A-H

Input: 3-phase power





Figure 4-5

# 4-2-1 SINK (NPN) / SOURCE (PNP) Mode



[This page intentionally left bank.]

# Chapter 5 Main Circuit Terminals

- 5-1 Main Circuit Diagram
- 5-2 Specifications of Main Circuit Terminals



- ☑ Tighten the screws in the main circuit terminal to prevent sparks caused by screws loosened due to vibration.
- ☑ If necessary, use an inductive filter only at the motor output terminals U/T1, V/T2, W/T3 of the AC motor drive. Do NOT use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta.
- ☑ DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- ☑ DO NOT connect brake resistors directly to [+1, -], [+2, -], [+1/DC+, -/DC-] to prevent damage to the drive or to the brake resistors.
- ☑ Ensure proper insulation of the main circuit wiring in accordance with the relevant safety regulations.




#### Main input power terminals

- ☑ Do not connect three-phase model to one-phase power. R/L1, S/L2 and T/L3 have no phase-sequence requirement; they can be connected in any sequence.
- Add a magnetic contactor (MC) to the power input wiring to cut off power quickly and reduce malfunctions when the AC motor drive protection function activates. Both ends of the MC should have an R-C surge absorber.
- ☑ Use voltage and current within the specification in Chapter 09. Refer to Chapter 09 Specifications for details.
- When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200 mA or above, and its operation time should not be less than 0.1 second to avoid nuisance tripping.
- ☑ Use shield wire or conduit for the power wiring and ground the two ends of the shielding or tube.
- ☑ Do NOT run and stop the AC motor drives by turning the power ON and OFF. Run and stop the AC motor drives by sending the RUN and STOP commands through the control terminals or the keypad. If you still need to run and stop the AC motor drives by turning the power ON and OFF, do so no more often than ONCE per hour.
- ☑ To comply with UL standards, connect the drive to a three-phase three-wire or three-phase four-wire Wye system type of mains power system.

#### Output terminals for the main circuit

- ☑ Use well-insulated motors to prevent any electric leakage from motors.
- When the AC drive output terminals U/T1, V/T2 and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3 respectively, the motor rotates counterclockwise (as viewed on the shaft end of the motor, refer to the pointed direction in the figure below) when a forward operation command is received. To permanently reverse the direction of motor rotation, exchange any two of the motor leads.



#### Terminals for connecting DC reactor, external brake resistor and DC circuit

☑ Use the terminals, as shown in Figure 5-2, to connect a DC reactor to improve the power factor. A jumper is connected to these terminals at the factory. Remove that jumper before connecting to a DC reactor.




Figure 5-2

☑ Install and external brake resistor for applications in frequent deceleration to stop, short deceleration time (such as high frequency operation and heavy load operation), too low braking torque, or increased braking torque.




Figure 5-3

- ☑ For Frame A, B and C, connect the external brake resistor to B1 and B2 terminals of the AC motor drives.
- For those models without built-in brake resistor, connect external brake unit and brake resistor (both of them are optional) to increase brake torque.
- ☑ When the terminals +1, +2 and are not used, leave the terminals open.
- ☑ When connecting DC+ and DC- in common DC bus applications, refer to Section 5-1
  (Main Circuit Terminal) for the wiring terminal specification and the wire gauge information.
- ☑ Refer to the VFDB manual for more information on wire gauge when installing the brake unit.

# 5-1 Main Circuit Diagram

#### Wiring Diagram for Frame A~C

Input: 3-phase power




Figure 5-4

## Wiring Diagram for Frame A~C




Figure 5-5

### Wiring Diagram for Frame D~F

Input: 3-phase power




Figure 5-6

<sup>\*1</sup> Refer to Section 7-1 for brake units and resistors selection




Figure 5-7

\*1 Refer to Section 7-1 for brake units and resistors selection

Note: When wiring for 12 Pulse Input, strictly follow the wiring diagram above.

# NOTE

- If the wiring between motor drive and motor is over 75 meters, please refer to Section 7-4 Specifications of limits for motor cable length.
- Remove the short circuit plate of Frame G and H if 12 pulse is implemented. Before implementing 12 pulse, consult Delta for more detail.




Figure 5-8

# Chapter 5 Main Circuit Terminals | CP2000

Terminals	Descriptions				
R/L1, S/L2, T/L3	AC line input terminals 3-phase				
U/T1, V/T2, W/T3	AC drive output terminals for connecting 3-phase induction motor				
	Applicable to frame A–C				
+1, +2	Connections for DC reactor to improve the power factor. It needs to remove the				
	jumper for installation.				
	Connections for brake module (VFDB series)				
	(for 230V models: ≤ 22 kW, built-in brake module)				
+1/DC+, -/DC-	(for 460V models: ≤ 30 kW, built-in brake module)				
	(for 690V models: ≤ 37 kW, built-in brake module)				
	Common DC bus				
B1, B2	Connections for brake resistor (optional)				
	Earth connection, please comply with local regulations.				

# **5-2 Specifications of Main Circuit Terminals**

- Use the specified ring lug for main circuit terminal wiring.
   See figure 5-9 and figure 5-10 for ring lug specifications. For other types of wiring, use the wires that comply with the local regulations.
- After crimping the wire to the ring lug (must be UL and CSA approved R/C (YDPU2)), install heat shrink tubing rated at a minimum of 600V<sub>AC</sub> insulation over the live part. Refer to figure 5-10 below.




Figure 5-9

Figure 5-10

# **Dimensions of Ring Lug**

The part number of the ring lugs (produced by K.S. Terminals Inc.) in the table below are for reference only. You can buy other ring lugs of your choice to match with different frame sizes.

Frame	AWG	Kit P/N	A (MAX)	B (MAX)	C (MIN)	D (MAX)	d2 (MIN)	E (MIN)	F (MIN)	W (MAX)	t (MAX)
	16	RNBL2-4									
	14	TUIDLE									
Α	12	RNBL5-4	20	5	5.5	9	4.3	8	5.5	10	1.5
	10										
	8	RNBS8-4									
_	8	RNBM8-5	00.0	7.0	<b>7</b> -	44.0	<b>5</b> 0	40.0	12.0	440	4 5
В	6 4	RNB14-5	28.0	7.0	7.5	14.0	5.2	13.0		14.0	1.5
	6	RNBS22-5 RNB14-8									
	4	RNB22-8								24	
С	2	RNBS38-8	40	12	12.5	22	8.3	13	12.5		2.5
	1/0	RNB60-8									
	4	RNB22-8									
	2	RNBS38-8	44.0	13.0	10.0	15.0	8.3	13.0	17.0	26.0	3.0
D0	1/0	SQNBS60-8	40.0	44.0	40.0		0.0	40.0	44.04	0.4.0	4.5
	2/0	SQNBS80-8	40.0	11.0	10.0	23.0	8.3	13.0	14.0*	24.0	
	4	RNB22-8								28.0	
	2	RNBS38-8				27.0	8.3	13.0			
	1/0	RNB60-8									
D	2/0	RNB70-8	50.0	16.0	10.0				14.0		6.0
	3/0	RNB80-8	30.0	10.0	10.0	21.0	0.5	13.0	14.0	20.0	0.0
	4/0	SQNBS100-8									
	250MCM	SQNBS150-8									
	300MCM	SQNBS150-8									
	4/0	RNB100-8									
Е	3/0	RNB80-8	53.0	16.0	17.0	26.5	8.4	13.0	17.0	31.0	5.0
_	2/0	RNB70-8									
	1/0	RNB60-8									
_	3/0	RNB80-8	EE O	15.0	10.0	27.0	0.2	12.0	17.5	24.0	6.0
	F 4/0	SQNBS100-8	55.0	15.0	10.0	27.0	8.3	13.0	17.5	31.0	6.0
	300MCM	SQNBS150-8									


# Chapter 5 Main Circuit Terminals | CP2000

Frame	AWG	Kit P/N	A (MAX)	B (MAX)	C (MIN)	D (MAX)	d2 (MIN)	E (MIN)	F (MIN)	W (MAX)	t (MAX)
	1/0	SQNB60-6									
	2/0	SQNBS80-8									
	3/0	3QND300-0	54	15.5	18	26.5	8.2	13	18	31	3.5
G 4/0 250MCM 300MCM	4/0	SQNBS100-8									
	250MCM	SQNBS150-8									
	300MCM	SQNBS180-12	70	21	27	32.7	12.2	13	27	42	4.0
	400MCM	SQNBS200-12									
	500MCM	3QND3200-12									
	3/0	SQNBS80-8									
	4/0	SQNBS100-8									
	250MCM		54	15.5	18	26.5	8.2	13	18	31	3.5
Н	300MCM	SQNBS150-8									
11	350MCM										
- - -	400MCM	SQNBS200-12						13.0			
	500MCM	SQNBS200-12	70.0	21.0	27.0	32.7	12.2		27.0	42.0	4.5
	600MCM	SQNBS325-12									

<sup>\*</sup>F (MAX.) = 16.5

<sup>\*</sup>AWG: Refer to the table below for the wire size specification for models in each frame.


#### Frame A



- If you install at Ta 50°C environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.

	R/L1, S/L2	lain Circuit Termina 2, T/L3, U/T1, V/T2, -/DC-, +2/DC+, +1/I	W/T3, B1,	Terminal 🖶			
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	
VFD007CP23A-21		2.5 mm <sup>2</sup> [14 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD015CP23A-21		4.0 mm <sup>2</sup> [12 AWG]		4.0 mm <sup>2</sup> [12 AWG]	4.0 mm <sup>2</sup> [12 AWG]		
VFD022CP23A-21		6.0 mm <sup>2</sup> [10 AWG]		6.0 mm <sup>2</sup> [10 AWG]	6.0 mm <sup>2</sup> [10 AWG]		
VFD037CP23A-21		10.0 mm <sup>2</sup> [8 AWG]		10.0 mm <sup>2</sup> [8 AWG]	10.0 mm <sup>2</sup> [8 AWG]		
VFD055CP23A-21		10.0 mm <sup>2</sup> [8 AWG]		10.0 mm <sup>2</sup> [8 AWG]	10.0 mm <sup>2</sup> [8 AWG]		
VFD007CP43A-21		1.5 mm <sup>2</sup> [16 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD015CP43B-21		1.5 mm <sup>2</sup> [16 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD022CP43B-21		2.5 mm <sup>2</sup> [14 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD037CP43B-21		6.0 mm <sup>2</sup> [10 AWG]		6.0 mm <sup>2</sup> [10 AWG]	6.0 mm <sup>2</sup> [10 AWG]		
VFD040CP43A-21		6.0 mm <sup>2</sup> [10 AWG]	M4	6.0 mm <sup>2</sup> [10 AWG]	6.0 mm <sup>2</sup> [10 AWG]	M4	
VFD055CP43B-21	10 mm <sup>2</sup>	10.0 mm <sup>2</sup> [8 AWG]	20kg-cm	10.0 mm <sup>2</sup> [8 AWG]	10.0 mm <sup>2</sup> [8 AWG]	20kg-cm	
VFD075CP43B-21	[8 AWG]	10.0 mm <sup>2</sup> [8 AWG]	[17.4lb-in.]	10.0 mm <sup>2</sup> [8 AWG]	10.0 mm <sup>2</sup> [8 AWG]	[17.4lb-in.]	
VFD007CP4EA-21		1.5 mm <sup>2</sup> [16 AWG]	[1.96Nm]	2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]	[1.96Nm]	
VFD015CP4EB-21		1.5 mm <sup>2</sup> [16 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD022CP4EB-21		2.5 mm <sup>2</sup> [14 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD037CP4EB-21		6.0 mm <sup>2</sup> [10 AWG]		6.0 mm <sup>2</sup> [10 AWG]	6.0 mm <sup>2</sup> [10 AWG]		
VFD040CP4EA-21		6.0 mm <sup>2</sup> [10 AWG]		6.0 mm <sup>2</sup> [10 AWG]	6.0 mm <sup>2</sup> [10 AWG]		
VFD055CP4EB-21		10.0 mm <sup>2</sup> [8 AWG]		10.0 mm <sup>2</sup> [8 AWG]	10.0 mm <sup>2</sup> [8 AWG]		
VFD075CP4EB-21		10.0 mm <sup>2</sup> [8 AWG]		10.0 mm <sup>2</sup> [8 AWG]	10.0 mm <sup>2</sup> [8 AWG]		
VFD015CP53A-21		2.5 mm <sup>2</sup> [14 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD022CP53A-21		2.5 mm <sup>2</sup> [14 AWG]		2.5 mm <sup>2</sup> [14 AWG]	2.5 mm <sup>2</sup> [14 AWG]		
VFD037CP53A-21		4.0 mm <sup>2</sup> [12 AWG]		4.0 mm <sup>2</sup> [12 AWG]	4.0 mm <sup>2</sup> [12 AWG]		


#### Frame B



- If you install at Ta 50°C environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD150CP23A-21 model: If you install at Ta 30°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.
- Wire fix to pole +2/DC+ and +1/DC+: 45 kg-cm / [39.0 lb-in] / [4.42 Nm] (±10%)

	R/L1, S/L2	lain Circuit Termina 2, T/L3, U/T1, V/T2, -/DC-, +2/DC+, +1/l	W/T3, B1,	Terminal 🕀			
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	
VFD075CP23A-21		16 mm <sup>2</sup> [6 AWG]		16 mm <sup>2</sup> [6 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD110CP23A-21		25 mm <sup>2</sup> [4 AWG]		25 mm <sup>2</sup> [4 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD150CP23A-21		25 mm <sup>2</sup> [4 AWG]		25 mm <sup>2</sup> [4 AWG]	16 mm <sup>2</sup> [6 AWG]	M5	
VFD110CP43B-21		10 mm <sup>2</sup> [8 AWG]		10 mm <sup>2</sup> [8 AWG]	10 mm <sup>2</sup> [8 AWG]		
VFD150CP43B-21		16 mm <sup>2</sup> [6 AWG]		16 mm <sup>2</sup> [6 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD185CP43B-21	OF2	25 mm <sup>2</sup> [4 AWG]	M5	25 mm <sup>2</sup> [4 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD110CP4EB-21	25 mm <sup>2</sup>	10 mm <sup>2</sup> [8 AWG]	35kg-cm	10 mm <sup>2</sup> [8 AWG]	10 mm <sup>2</sup> [8 AWG]	35kg-cm	
VFD150CP4EB-21	[4 AWG]	16 mm <sup>2</sup> [6 AWG]	[30.4lb-in.] [3.43Nm]	16 mm <sup>2</sup> [6 AWG]	16 mm <sup>2</sup> [6 AWG]	[30.4lb-in.] [3.43Nm]	
VFD185CP4EB-21		25 mm <sup>2</sup> [4 AWG]	[3.43[4]]]	25 mm <sup>2</sup> [4 AWG]	25 mm <sup>2</sup> [4 AWG]	[3.43[1]]	
VFD055CP53A-21		6 mm <sup>2</sup> [10 AWG]		6 mm <sup>2</sup> [10 AWG]	6 mm <sup>2</sup> [10 AWG]		
VFD075CP53A-21		6 mm <sup>2</sup> [10 AWG]		6 mm <sup>2</sup> [10 AWG]	6 mm <sup>2</sup> [10 AWG]		
VFD110CP53A-21		10 mm <sup>2</sup> [8 AWG]		10 mm <sup>2</sup> [8 AWG]	10 mm <sup>2</sup> [8 AWG]		
VFD150CP53A-21		10 mm <sup>2</sup> [8 AWG]		10 mm <sup>2</sup> [8 AWG]	10 mm <sup>2</sup> [8 AWG]		


#### Frame C



- If you install at Ta 50°C environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD220CP23A-21 model, if you install at Ta 40°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD300CP23A-21 model, if you install at Ta 30°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.
- Wire fix to pole +2/DC+ and +1/DC+: 90 kg-cm / [78.2 lb-in] / [8.83 Nm] (±10%)

		Main Circuit Tarmine	ale.				
		Main Circuit Termina			<u> </u>		
		2, T/L3, U/T1, V/T2		Terminal 🖶			
Model Name	B2,	-/DC-, +2/DC+, +1/			T		
	Max. Wire	14: 14: 0	Screw Spec.	14 14" 0		Screw Spec.	
	Gauge	Min. Wire Gauge	and Torque	Max. Wire Gauge	Min. Wire Gauge	and Torque	
			(±10%)			(±10%)	
VFD185CP23A -21		50 mm <sup>2</sup> [1/0 AWG]		50 mm <sup>2</sup> [1/0 AWG]	25 mm <sup>2</sup> [4 AWG]		
VFD220CP23A-21		50 mm <sup>2</sup> [1/0 AWG]		50 mm <sup>2</sup> [1/0 AWG]	25 mm <sup>2</sup> [4 AWG]	ļ	
VFD300CP23A-21		50 mm <sup>2</sup> [1/0 AWG]		50 mm <sup>2</sup> [1/0 AWG]	25 mm <sup>2</sup> [4 AWG]		
VFD220CP43A-21		25 mm <sup>2</sup> [4 AWG]		25 mm <sup>2</sup> [4 AWG]	16 mm <sup>2</sup> [6 AWG]	M8	
VFD300CP43B-21		35 mm <sup>2</sup> [2 AWG]		35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD370CP43B-21	E0 mm <sup>2</sup>	50 mm <sup>2</sup> [1/0 AWG]	M8	50 mm <sup>2</sup> [1/0 AWG]	25 mm <sup>2</sup> [4 AWG]		
VFD220CP4EA-21	50 mm <sup>2</sup> [1/0 AWG]	25 mm <sup>2</sup> [4 AWG]	80kg-cm [69.4lb-in.]	25 mm <sup>2</sup> [4 AWG]	16 mm <sup>2</sup> [6 AWG]	80kg-cm	
VFD300CP4EB-21	[1/0 AVVG]	35 mm <sup>2</sup> [2 AWG]	[7.84Nm]	35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]	[69.4lb-in.] [7.84Nm]	
VFD370CP4EB-21		50 mm <sup>2</sup> [1/0 AWG]	[7.04[1]]	50 mm <sup>2</sup> [1/0 AWG]	25 mm <sup>2</sup> [4 AWG]	[7.04[4]]]	
VFD185CP63A-21		10 mm <sup>2</sup> [8 AWG]		10 mm <sup>2</sup> [8 AWG]	10 mm <sup>2</sup> [8 AWG]		
VFD220CP63A-21		16 mm <sup>2</sup> [6 AWG]		16 mm <sup>2</sup> [6 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD300CP63A-21		25 mm <sup>2</sup> [4 AWG]		25 mm <sup>2</sup> [4 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD370CP63A-21		35 mm <sup>2</sup> [2 AWG]		35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]		


#### Frame D0



- If you install at Ta 50°C (for 460V model names with last digit -00) / 40°C (for 460V model names with last digit -21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C (for 460V model names with last digit -00) / 40°C (for 460V model names with last digit -21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD550CP43S-00 model: If you install at Ta 45°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.

Model Name		Main Circuit Termina 2, T/L3, U/T1, V/T2, +1/DC+		Terminal 🕀			
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	
VFD450CP43S-00		70 mm <sup>2</sup> [2/0 AWG]	M8			M8	
VFD550CP43S-00	70 mm <sup>2</sup>	70 mm <sup>2</sup> [2/0 AWG]	80kg-cm	35mm <sup>2</sup>	25mm <sup>2</sup>	80kg-cm	
VFD450CP43S-21	[2/0 AWG]	50 mm <sup>2</sup> [1 AWG]	[69.4lb-in.]	[2AWG]	[4AWG]	[69.4lb-in.]	
VFD550CP43S-21		70 mm <sup>2</sup> [2/0 AWG]	[7.84Nm]			[7.84Nm]	

#### Frame D




- If you install at Ta 50°C (for 230V / 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 230V / 460V model names with last digit -21; for 690V model names end with 63A-21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C (for 230V / 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 230V / 460V model names with last digit -21; for 690V model names end with 63A-21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD450CP23A-00 and VFD900CP43A-00 models: If you install at Ta 45°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD450CP23A-21 and VFD900CP43A-21 models: If you install at Ta 30°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.

  Do not reduce the wire gauge when using higher-temperature resistant wire.

						1	
		Main Circuit Termina 2, T/L3, U/T1, V/T2, DC+/+1, +2/B1, B2	W/T3, DC-,	Terminal⊕			
Model Name	Max. Wire Gauge		Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	
VFD370CP23A-00		120 mm <sup>2</sup> [250 MCM]		120 mm <sup>2</sup> [250 MCM]	70 mm <sup>2</sup> [2/0 AWG]		
VFD450CP23A-00	150 mm <sup>2</sup>	150 mm <sup>2</sup> [300 MCM]		150 mm <sup>2</sup> [300 MCM]	95 mm <sup>2</sup> [3/0 AWG]		
VFD750CP43B-00	[300 MCM]	120 mm <sup>2</sup> [250 MCM]		120 mm <sup>2</sup> [250 MCM]	70 mm <sup>2</sup> [2/0 AWG]		
VFD900CP43A-00		150 mm <sup>2</sup> [300 MCM]		150 mm <sup>2</sup> [300 MCM]	95 mm <sup>2</sup> [3/0 AWG]		
VFD370CP23A-21		120 mm <sup>2</sup> [4/0 AWG]	M8	120 mm <sup>2</sup> [4/0 AWG]	70 mm <sup>2</sup> [2/0 AWG]	M8	
VFD450CP23A-21	120 mm <sup>2</sup>	120 mm <sup>2</sup> [4/0 AWG]	180kg-cm	120 mm <sup>2</sup> [4/0 AWG]	70 mm <sup>2</sup> [2/0 AWG]	180kg-cm	
VFD750CP43B-21	[4/0 AWG]	120 mm <sup>2</sup> [4/0 AWG]	[156.2lb-in.]	120 mm <sup>2</sup> [4/0 AWG]	70 mm <sup>2</sup> [2/0 AWG]	[156.2lb-in.]	
VFD900CP43A-21		120 mm <sup>2</sup> [4/0 AWG]	[17.65Nm]	120 mm <sup>2</sup> [4/0 AWG]	70 mm <sup>2</sup> [2/0 AWG]	[17.65Nm]	
VFD450CP63A-00		35 mm <sup>2</sup> [2 AWG]		35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD550CP63A-00	150 mm <sup>2</sup>	35 mm <sup>2</sup> [2 AWG]		35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD450CP63A-21	[300 MCM]	35 mm <sup>2</sup> [2 AWG]		35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]		
VFD550CP63A-21		35 mm <sup>2</sup> [2 AWG]		35 mm <sup>2</sup> [2 AWG]	16 mm <sup>2</sup> [6 AWG]		


#### Frame E



- If you install at Ta 50°C (for 230V / 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 230V / 460V model names with last digit -21; for 690V model names end with 63A-21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C (for 230V / 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 230V / 460V model names with last digit -21; for 690V model names end with 63A-21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD900CP23A-00 model: If you install at Ta 40°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.

	R/L1, S/L2	Main Circuit Terminals 2, T/L3, U/T1, V/T2, W/T3 -/DC-	3, +1/DC+,	Terminal 🕀			
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	
VFD550CP23A-00		95mm <sup>2</sup> *2 [3/0 AWG*2]		95 mm <sup>2</sup> *2 [3/0 AWG*2]	95mm <sup>2</sup> *1 [3/0 AWG*1]		
VFD750CP23A-00		120mm <sup>2</sup> *2 [4/0 AWG*2]		120mm <sup>2</sup> *2 [4/0 AWG*2]	120 mm <sup>2</sup> *1 [4/0 AWG*1]		
VFD900CP23A-00		120mm <sup>2</sup> *2 [4/0AWG*2]		120 mm <sup>2</sup> *2 [4/0AWG*2]	120 mm <sup>2</sup> *1 [4/0AWG*1]		
VFD1100CP43A-00		95mm <sup>2</sup> *2 [3/0 AWG*2]		95 mm <sup>2</sup> *2 [3/0 AWG*2]	95 mm <sup>2</sup> *1 [3/0 AWG*1]		
VFD1320CP43A-00		120mm <sup>2</sup> *2 [4/0 AWG*2]		120mm <sup>2</sup> *2 [4/0 AWG*2]	120 mm <sup>2</sup> *1 [4/0 AWG*1]		
VFD550CP23A-21		70mm <sup>2</sup> *2 [2/0 AWG*2]		70 mm <sup>2</sup> *2 [2/0 AWG*2]	70 mm <sup>2</sup> *1 [2/0 AWG*1]		
VFD750CP43A-21		95mm <sup>2</sup> *2 [3/0 AWG*2]		95 mm <sup>2</sup> *2 [3/0 AWG*2]	95 mm <sup>2</sup> *1 [3/0 AWG*1]		
VFD900CP43A-21		120mm <sup>2</sup> *2 [4/0AWG*2]	M8	120 mm <sup>2</sup> *2 [4/0AWG*2]	120 mm <sup>2</sup> *1 [4/0AWG*1]	M8	
VFD1100CP23A-21	120 mm <sup>2</sup> *2	70mm <sup>2</sup> *2 [2/0 AWG*2]	180kg-cm	70 mm <sup>2</sup> *2 [2/0 AWG*2]	70 mm <sup>2</sup> *1 [2/0 AWG*1]	180kg-cm	
VFD1320CP43A-21	[4/0 AWG*2]	95mm <sup>2</sup> *2 [3/0 AWG*2]	[156.2lb-in.]	95 mm <sup>2</sup> *2 [3/0 AWG*2]	95 mm <sup>2</sup> *1 [3/0 AWG*1]	[156.2lb-in.]	
VFD750CP63A-00		25mm <sup>2</sup> *2 [4 AWG*2]	[17.65Nm]	25 mm <sup>2</sup> *2 [4 AWG*2]	25 mm <sup>2</sup> *1 [4 AWG*1]	[17.76Nm]	
VFD900CP63A-00		35mm <sup>2</sup> *2 [2 AWG*2]		35 mm <sup>2</sup> *2 [2 AWG*2]	35 mm <sup>2</sup> *1 [2 AWG*1]		
VFD1100CP63A-00		35mm <sup>2</sup> *2 [2 AWG*2]		35 mm <sup>2</sup> *2 [2 AWG*2]	35 mm <sup>2</sup> *1 [2 AWG*1]		
VFD1320CP63A-00		50mm <sup>2</sup> *2 [1/0 AWG*2]		50 mm <sup>2</sup> *2 [1/0 AWG*2]	50 mm <sup>2</sup> *1 [1/0 AWG*1]		
VFD750CP63A-21		25mm <sup>2</sup> *2 [4 AWG*2]		25 mm <sup>2</sup> *2 [4 AWG*2]	25 mm <sup>2</sup> *1 [4 AWG*1]		
VFD900CP63A-21		35mm <sup>2</sup> *2 [2 AWG*2]		35 mm <sup>2</sup> *2 [2 AWG*2]	35 mm <sup>2</sup> *1 [2 AWG*1]		
VFD1100CP63A-21		35mm <sup>2</sup> *2 [2 AWG*2]		35 mm <sup>2</sup> *2 [2 AWG*2]	35 mm <sup>2</sup> *1 [2 AWG*1]		
VFD1320CP63A-21		50mm <sup>2</sup> *2 [1/0 AWG*2]		50 mm <sup>2</sup> *2 [1/0 AWG*2]	50 mm <sup>2</sup> *1 [1/0 AWG*1]		


#### Frame F



- If you install at Ta 50°C (for 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 460V model names with last digit -21; for 690V model names end with 63A-21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C (for 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 460V model names with last digit -21; for 690V model names end with 63A-21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD1850CP43B-21 model: If you install at Ta 45°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD1850CP43B-21 model: If you install at Ta 30°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.

		Main Circuit Terminals , T/L3, U/T1, V/T2, W/T +1/DC+	Г3, -/DC-,	Terminal ⊕			
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	
VFD1600CP43A-00	150mm <sup>2</sup> *2	150mm <sup>2</sup> *2 [300 MCM*2]	50mm <sup>2</sup> *2 [300 MCM*2]	150mm <sup>2</sup> *2 [300 MCM*2]	150mm <sup>2</sup> *1 [300 MCM*1]		
VFD1850CP43B-00	[300MCM*2]	150mm <sup>2</sup> *2 [300 MCM*2]		150mm <sup>2</sup> *2 [300MCM*2]	150mm <sup>2</sup> *1 [300MCM*1]		
VFD1600CP43A-21	120mm <sup>2</sup> *2	120mm <sup>2</sup> *2 [4/0 AWG*2]		120mm <sup>2</sup> *2 [4/0AWG*2]	120mm <sup>2</sup> *1 [4/0AWG*1]		
VFD1850CP43B-21	[4/0AWG*2]	120mm <sup>2</sup> *2 [4/0 AWG*2]	M8 180kg-cm	120mm <sup>2</sup> *2 [4/0AWG*2]	120mm <sup>2</sup> *1 [4/0AWG*1]	M8 180kg-cm	
VFD1600CP63A-00		70mm <sup>2</sup> *2 [2/0 AWG*2]	[156.2lb-in.] [17.65Nm]	70mm <sup>2</sup> *2 [2/0 AWG*2]	70mm <sup>2</sup> *1 [2/0 AWG*1]	[156.2lb-in.] [17.76Nm]	
VFD2000CP63A-00	150mm <sup>2*</sup> 2 [300MCM*2]	95mm <sup>2</sup> *2 [3/0 AWG*2]	[]	95mm <sup>2</sup> *2 [3/0 AWG*2]	95mm <sup>2</sup> *1 [3/0 AWG*1]	[]	
VFD1600CP63A-21		70mm <sup>2</sup> *2 [2/0 AWG*2]		70mm <sup>2</sup> *2 [2/0 AWG*2]	70mm <sup>2</sup> *1[2/0 AWG*1]		
VFD2000CP63A-21		95mm <sup>2</sup> *2 [3/0 AWG*2]		95mm <sup>2</sup> *2 [3/0 AWG*2]	95mm <sup>2</sup> *1 [3/0 AWG*1]		

#### Frame G




- If you install at Ta 50°C (for 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 460V model names with last digit -21; for 690V model names end with 63A-21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C (for 460V model names with last digit -00; for 690V model names end with 63A-00) / 40°C (for 460V model names with last digit -21; for 690V model names end with 63A-21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD2200CP43A-00 and VFD2500CP43A-00 models (Terminals U/T1, V/T2, W/T3, -/DC- and +1/DC+): If you install at Ta 45°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD2800CP43A-00 model (Terminals U/T1, V/T2, W/T3, -/DC- and +1/DC+): If you install at Ta 40
   °C above environment, use copper wires that have a voltage rating 600V and are temperature resistant
   to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.

		lain Circuit Terminals		Т	erminal 🕀	
	R/LTT, R/L	12, S/L21, S/L22, T/L		<u> </u>		
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)
VFD2000CP43A-00		70mm <sup>2</sup> *4 [2/0AWG*4]		70mm <sup>2</sup> *4 [2/0AWG*4]	70mm <sup>2</sup> *2 [2/0AWG*2]	
VFD2200CP43A-00		95mm <sup>2</sup> *4 [3/0AWG*4]		95mm <sup>2</sup> *4 [3/0AWG*4]	95mm <sup>2</sup> *2 [3/0AWG*2]	
VFD2500CP43A-00		120mm <sup>2</sup> *4 [4/0AWG*4]		120mm <sup>2</sup> *4 [4/0AWG*4]	120mm <sup>2</sup> *2 [4/0AWG*2]	
VFD2800CP43A-00	120mm <sup>2</sup> *4	120mm <sup>2</sup> *4 [4/0AWG*4]		120mm <sup>2</sup> *4 [4/0AWG*4]	120mm <sup>2</sup> *2 [4/0AWG*2]	
VFD2000CP43A-21	[250MCM*4]	50mm <sup>2</sup> *4 [1/0AWG*4]	M8	50mm <sup>2</sup> *4 [1/0AWG*4]	50mm <sup>2</sup> *2 [1/0AWG*2]	M8
VFD2200CP43A-21		70mm <sup>2</sup> *4 [2/0AWG*4]	180kg-cm	70mm <sup>2</sup> *4 [2/0AWG*4]	70mm <sup>2</sup> *2 [2/0AWG*2]	180kg-cm
VFD2500CP43A-21		70mm <sup>2</sup> *4 [2/0AWG*4]	[156.2lb-in.]	70mm <sup>2</sup> *4 [2/0AWG*4]	70mm <sup>2</sup> *2 [2/0AWG*2]	[156.2lb-in.]
VFD2800CP43A-21		95mm <sup>2</sup> *4 [3/0AWG*4]	[17.65Nm]	95mm <sup>2</sup> *4 [3/0AWG*4]	95mm <sup>2</sup> *2 [3/0AWG*2]	[17.65Nm]
VFD2500CP63A-00		50mm <sup>2</sup> *4 [1/0AWG*4]		50mm <sup>2</sup> *4 [1/0AWG*4]	50mm <sup>2</sup> *2 [1/0AWG*2]	
VFD3150CP63A-00	150mm <sup>2</sup> *4	50mm <sup>2</sup> *4 [1/0AWG*4]		50mm <sup>2</sup> *4 [1/0AWG*4]	50mm <sup>2</sup> *2 [1/0AWG*2]	
VFD2500CP63A-21	[300MCM*4]	50mm <sup>2</sup> *4 [1/0AWG*4]		50mm <sup>2</sup> *4 [1/0AWG*4]	50mm <sup>2</sup> *2 [1/0AWG*2]	
VFD3150CP63A-21		50mm <sup>2</sup> *4 [1/0AWG*4]		50mm <sup>2</sup> *4 [1/0AWG*4]	50mm <sup>2</sup> *2 [1/0AWG*2]	

# Chapter 5 Main Circuit Terminals | CP2000

		Main Circuit Terminals V/T2, W/T3, +1/DC+,	-/DC-		Terminal 🖶	
Model Name	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)
VFD2000CP43A-00		240mm <sup>2</sup> *2 [400MCM*2]		240mm <sup>2</sup> *2 [400MCM*2]	240mm <sup>2</sup> *1 [400MCM*1]	
VFD2200CP43A-00		240mm <sup>2</sup> *2 [500MCM*2]	M12	240mm <sup>2</sup> *2 [500MCM*2]	240mm <sup>2</sup> *1 [500MCM*1]	
VFD2500CP43A-00		240mm <sup>2</sup> *2 [500MCM*2]		240mm <sup>2</sup> *2 [500MCM*2]	240mm <sup>2</sup> *1 [500MCM*1]	
VFD2800CP43A-00		240mm <sup>2</sup> *2 [500MCM*2]		240mm <sup>2</sup> *2 [500MCM*2]	240mm <sup>2</sup> *1 [500MCM*1]	
VFD2000CP43A-21		150mm <sup>2</sup> *2 [300MCM*2]		150mm <sup>2</sup> *2 [300MCM*2]	150mm <sup>2</sup> *1 [300MCM*1]	M8
VFD2200CP43A-21	240mm <sup>2</sup> *2	240mm <sup>2</sup> *2 [400MCM*2]		240mm <sup>2</sup> *2 [400MCM*2]	240mm <sup>2</sup> *1 [400MCM*1]	180kg-cm
VFD2500CP43A-21	[500MCM*2]	240mm <sup>2</sup> *2 [500MCM*2]	[354.1lb-in.] [39.98Nm]	240mm <sup>2</sup> *2 [500MCM*2]	240mm <sup>2</sup> *1 [500MCM*1]	[156.2lb-in.] [17.65Nm]
VFD2800CP43A-21		240mm <sup>2</sup> *2 [500MCM*2]		240mm <sup>2</sup> *2 [500MCM*2]	240mm <sup>2</sup> *1 [500MCM*1]	[17.05INIII]
VFD2500CP63A-00		120mm <sup>2</sup> *2 [250MCM*2]		120mm <sup>2</sup> *2 [250MCM*2]	120mm <sup>2</sup> *1 [250MCM*1]	
VFD3150CP63A-00	-	150mm <sup>2</sup> *2 [350MCM*2]	1	150mm <sup>2</sup> *2 [350MCM*2]	150mm <sup>2</sup> *1 [350MCM*1]	
VFD2500CP63A-21		120mm <sup>2</sup> *2 [250MCM*2]		120mm <sup>2</sup> *2 [250MCM*2]	120mm <sup>2</sup> *1 [250MCM*1]	
VFD3150CP63A-21		150mm <sup>2</sup> *2 [350MCM*2]		150mm <sup>2</sup> *2 [350MCM*2]	150mm <sup>2</sup> *1 [350MCM*1]	


#### Frame H




- If you install at Ta 50°C (for 460V model names with last digit A-00 / C-00; for 690V model names end with 63A-00) / 40°C (for 460V model names with last digit C-21; for 690V model names end with 63A-21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 75°C or 90°C.
- If you install at Ta 50°C (for 460V model names with last digit A-00 / C-00; for 690V model names end with 63A-00) / 40°C (for 460V model names with last digit C-21; for 690V model names end with 63A-21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- For VFD4000CP43A-00 and VFD4000CP43C-00 models: If you install at Ta 40 °C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90° C or above.
- For VFD5000CP43A-00, VFD5000CP43C-00 and VFD5000CP43C-21 models: If you install at Ta 30
   °C above environment, use copper wires that have a voltage rating 600V and are temperature
   resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations.
   Do not reduce the wire gauge when using higher-temperature resistant wire.

Model Name	Main Circuit Terminals R/L11, R/L12, S/L21, S/L22, T/L31, T/L32, U/T1, V/T2, W/T3, +1/DC+, -/DC-			Terminal 🖶		
	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)
VFD3150CP43A-00	185mm <sup>2</sup> *4	150mm <sup>2</sup> *4 [300MCM*4]	M8 180kg-cm [156.2lb-in.] [17.65Nm]	150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	M8 180kg-cm [156.2lb-in.] [17.65Nm]
VFD3550CP43A-00		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	
VFD4000CP43A-00		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	
VFD5000CP43A-00		185mm <sup>2</sup> *4 [350MCM*4]		185mm <sup>2</sup> *4 [350MCM*4]	185mm <sup>2</sup> *2 [350MCM*2]	
VFD3150CP43C-00		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	
VFD3550CP43C-00		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	
VFD4000CP43C-00		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	
VFD5000CP43C-00		185mm <sup>2</sup> *4 [350MCM*4]		185mm <sup>2</sup> *4 [350MCM*4]	185mm <sup>2</sup> *2 [350MCM*2]	
VFD3150CP43C-21		120mm <sup>2</sup> *4 [4/0AWG*4]		120mm <sup>2</sup> *4 [4/0AWG*4]	120mm <sup>2</sup> *2 [4/0AWG*2]	
VFD3550CP43C-21		120mm <sup>2</sup> *4 [250MCM*4]		120mm <sup>2</sup> *4 [250MCM*4]	120mm <sup>2</sup> *2 [250MCM*2]	
VFD4000CP43C-21		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm <sup>2</sup> *2 [300MCM*2]	
VFD5000CP43C-21		185mm <sup>2</sup> *4 [350MCM*4]		185mm <sup>2</sup> *4 [350MCM*4]		
VFD4000CP63A-00		95mm <sup>2</sup> *4 [3/0AWG*4]		95mm <sup>2</sup> *4 [3/0AWG*4]	95mm <sup>2</sup> *2 [3/0AWG*2]	
VFD4500CP63A-00		95mm <sup>2</sup> *4 [3/0AWG*4]		95mm <sup>2</sup> *4 [3/0AWG*4]	95mm <sup>2</sup> *2 [3/0AWG*2]	
VFD5600CP63A-00		120mm <sup>2</sup> *4 [250MCM*4]			120mm <sup>2</sup> *2 [250MCM*2]	
VFD6300CP63A-00		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]		
VFD4000CP63A-21		95mm <sup>2</sup> *4 [3/0AWG*4]		95mm <sup>2</sup> *4 [3/0AWG*4]	95mm <sup>2</sup> *2 [3/0AWG*2]	
VFD4500CP63A-21		95mm <sup>2</sup> *4 [3/0AWG*4]		95mm <sup>2</sup> *4 [3/0AWG*4]	95mm <sup>2</sup> *2 [3/0AWG*2]	
VFD5600CP63A-21		120mm <sup>2</sup> *4 [250MCM*4]		120mm <sup>2</sup> *4 [250MCM*4]	120mm <sup>2</sup> *2 [250MCM*2]	
VFD6300CP63A-21		150mm <sup>2</sup> *4 [300MCM*4]		150mm <sup>2</sup> *4 [300MCM*4]	150mm²*2 [300MCM*2]	

#### Frame H





- If you install at Ta 50°C (model names with last digit A-00) / 40°C (models names with last digit C-21) environment, use copper wires that have a voltage rating 600V and are temperature resistant to 70°C or 90°C.
- If you install at Ta 50°C (model names with last digit A-00) / 40°C (models names with last digit C-21) above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- If you install at Ta 30°C above environment, use copper wires that have a voltage rating 600V and are temperature resistant to 90°C or above.
- To be UL installation compliant, you must use copper wires when installing. The wire gauge is based on a temperature resistant of 75°C, in accordance with UL requirements and recommendations. Do not reduce the wire gauge when using higher-temperature resistant wire.

Model Name	Main Circuit Terminals R/L11, R/L12, S/L21, S/L22, T/L31, T/L32, U/T1, V/T2, W/T3, +1/DC+, -/DC-			Terminal 🕀		
	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)	Max. Wire Gauge	Min. Wire Gauge	Screw Spec. and Torque (±10%)
VFD5600CP43A-00	300mm <sup>2</sup> *4	240mm <sup>2</sup> *4 [500MCM*4]		240mm <sup>2</sup> *4 [500MCM*4]	240mm <sup>2</sup> *2 [500MCM*2]	M8 180kg-cm [156.2lb-in.] [17.65Nm]
VFD6300CP43A-00	[600MCM*4]	300mm <sup>2</sup> *4 [600MCM*4]	M12 408kg-cm	300mm <sup>2</sup> *4 [600MCM*4]	300mm <sup>2</sup> *2 [600MCM*2]	
VFD5600CP43C-21	240mm <sup>2</sup> *4	240mm <sup>2</sup> *4 [500MCM*4]	[354.1lb-in.] [39.98Nm]	240mm <sup>2</sup> *4 [500MCM*4]	240mm <sup>2</sup> *2 [500MCM*2]	
VFD6300CP43C-21		240mm <sup>2</sup> *4 [500MCM*4]		240mm <sup>2</sup> *4 [500MCM*4]	240mm <sup>2</sup> *2 [500MCM*2]	

[This page intentionally left blank]


# Chapter 6 Control Terminals

- 6-1 Remove the Cover for Wiring
- 6-2 Specifications of Control Terminal
- 6-3 Remove the Terminal Block




## Analog input terminals (AVI1, AVI2, ACI, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (< 20 m) with proper grounding. If the noise is inductive, connecting the shield to the ACM terminal can reduce interference.
- ☑ Use twisted-pair wire for weak analog signals.
- ☑ If the analog input signals are affected by noise from the AC motor drive, connect a capacitor and a ferrite core as shown in Figure 6-1.



## Contact input terminals (FWD, REV, MI1-MI8, COM)

☑ The "COM" terminal is a common terminal of the photo-coupler in all the wiring methods.



☑ When the photo coupler uses the internal power supply, the switch connection for Sink and Source modes shows as Figure 6-2 and Figure 6-3:

MI-DCM: Sink mode MI-+24V: Source mode

☑ When the photo coupler uses the external power supply, remove the short-circuit cable between +24V and COM terminals. The switch connection for Sink and Source modes shows as Figure 6-4 and Figure 6-5:

The "+" of 24V connecting to "COM: Sink mode The "-" of 24V connecting to COM: Source mode

# 6-1 Remove the Cover for Wiring

Remove the top cover before wiring the multi-function input and output terminals,

The drive appearances shown in the figures are for reference only, a real drive may look different.

#### Frame A & B

### Applicable models:

VFD007CP23A-21; VFD015CP23A-21; VFD022CP23A-21; VFD037CP23A-21; VFD055CP23A-21; VFD007CP43A-21; VFD015CP43B-21; VFD022CP43B-21; VFD037CP43B-21; VFD040CP43A-21; VFD055CP43B-21; VFD075CP43B-21; VFD075CP4EB-21; VFD015CP4EB-21; VFD037CP4EB-21; VFD040CP4EB-21; VFD055CP4EB-21; VFD075CP4EB-21; VFD015CP53A-21; VFD022CP53A-21; VFD037CP53A-21; VFD037CP53A-21; VFD037CP53A-21; VFD110CP23A-21; VFD150CP23A-21; VFD110CP43B-21; VFD150CP4BB-21; VFD185CP43B-21; VFD110CP53A-21; VFD150CP53A-21; VFD185CP4EB-21; VFD150CP53A-21

Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm] Loosen the screw and press the tabs on both sides to remove the cover.




Figure 6-6

#### Frame C

#### Applicable models:

VFD185CP23A-21; VFD220CP23A-21; VFD300CP23A-21; VFD220CP43A-21; VFD300CP43B-21; VFD370CP43B-21; VFD220CP4EA-21; VFD300CP4EB-21; VFD370CP4EB-21; VFD185CP63A-21; VFD220CP63A-21; VFD370CP63A-21

Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]

Loosen the screws and press the tabs on both sides to remove the cover.




Figure 6-7

#### Frame D0 & D

# Applicable models:

VFD450CP43S-00; VFD550CP43S-00; VFD450CP43S-21; VFD550CP43S-21; VFD370CP23A-00/-21;

VFD450CP23A-00/-21; VFD750CP43B-00/-21; VFD900CP43A-00/-21; VFD450CP63A-00/-21;

VFD550CP63A-00/-21

Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]

To remove the cover, lift it slightly and pull outward.

Loosen the screws and press the tabs on both sides to remove the cover.




Figure 6-8

### Frame E

#### Applicable models:

VFD550CP23A-00/-21; VFD750CP23A-00/-21; VFD900CP23A-00/-21; VFD1100CP43A-00/-21; VFD1320CP43B-00/-21; VFD750CP63A-00/-21; VFD900CP63A-00/-21; VFD1100CP63A-00/-21; VFD1320CP63B-21

Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm] To remove the cover, lift it slightly and pull outward.




Figure 6-9


#### Frame F


Applicable models:

VFD1600CP43A-00/-21; VFD1850CP43B-00/-21; VFD1600CP63A-00/-21; VFD2000CP63A-00/-21

Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]

To remove the cover, lift it slightly and pull outward








Figure 6-10

Frame G


Applicable models:


VFD2000CP43A-00/-21; VFD2200CP43A-00/-21; VFD2500CP43A-00/-21; VFD2800CP43A-00/-21;

VFD2500CP63A-00/-21; VFD3150CP63A-00/-21

Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]

To remove the cover, lift it slightly and pull outward








Figure 6-11

#### Frame H

Applicable models:


VFD3150CP43A-00; VFD3550CP43A-00; VFD4000CP43A-00; VFD5000CP43A-00; VFD5600CP43A-00;

VFD6300CP43A-00; VFD3150CP43C-00/-21; VFD3550CP43C-00/-21; VFD4000CP43C-00/-21;

VFD5000CP43C-00/-21; VFD5600CP43C-21; VFD6300CP43C-21

Screw torque: 14–16 kg-cm / [12.15–13.89 lb-in.] / [1.4–1.6 Nm]

To remove the cover, lift it slightly and pull outward






Figure 6-12


#### 690V Frame H

Applicable models:

VFD4000CP63A-00/-21; VFD4500CP63A-00/-21; VFD5600CP63A-00/-21; VFD6300CP63A-00/-21

Screw torque: 14-16 kg-cm / [12.15-13.89 lb-in.] / [1.4-1.6 Nm]

To remove the cover, lift it slightly and pull outward







Figure 6-13

#### **6-2 Specifications of Control Terminal**



Terminal Function	Group	Conductor	Stripping Length [mm]	Maximum Wire Gauge	Minimum Wire Gauge	Torque (±10%)
Relay	A	Solid	4–5			5 kg-cm [4.3 lb-in]
,	O	Strand				[0.49 Nm]
Control	B	Solid		1.5 mm <sup>2</sup> [16 AWG]	0.2 mm <sup>2</sup> [26 AWG]	8 kg-cm [6.9 lb-in]
board		Strand	6–7			[0.78 Nm]
Control board		Solid	0-7			2 kg-cm
	©	Strand				[1.7 lb-in] [0.20 Nm]

#### Wiring precautions:

- In the figure above, the default for STO1, STO2, +24V and SCM1, SCM2, DCM are short circuit. The +24V from section © of above figure is for STO only, and cannot be used for other purposes. The default for +24V-COM is short circuit and SINK mode (NPN); please refer to Section 4 Wiring for more detail.
- Tighten the wiring with slotted screwdriver:
  - (A) (B) is 3.5 mm (wide) x 0.6 mm (thick); (C) is 2.5 mm (wide) x 0.4 mm (thick)
- When wiring bare wires, ensure that they are perfectly arranged to go through the wiring holes.

Terminals	Terminal Function	Default (NPN mode)		
+24V	Digital control signal common	+24V + 5% 200mA		
T24V	(Source)	124V ± 570 200HIA		
COM	Digital control signal common (Sink)	Common for multi-function input terminals		
		FWD-DCM:		
FWD	Forward-Stop command	ON→ forward running		
		OFF→ deceleration to stop		
		REV-DCM:		
REV	Reverse-Stop command	ON→ reverse running		
		OFF→ deceleration to stop		

Terminals	Terminal Function	Default (NPN mode)
MI1   MI8	Multi-function input 1–8	Refer to Pr.02-01–02-08 to program the multi-function inputs MI1–MI8. Source Mode ON: activation voltage $\geq$ 11 V <sub>DC</sub> OFF: cut-off voltage $\leq$ 5 V <sub>DC</sub> Sink Mode ON: the activation voltage $\leq$ 13 V <sub>DC</sub> OFF: cut-off current voltage $\geq$ 19 V <sub>DC</sub> The internal resistance is 3.6 k $\Omega$ .
DCM	Digital frequency signal common	Digital frequency signal common
RA1	Multi-function relay output 1 (N.O.) a	Resistive Load: 3 A (N.O.) / 3 A (N.C.) 250 V <sub>AC</sub>
RB1	Multi-function relay output 1 (N.C.) b	5 A (N.O.) / 3 A (N.C.) 30 V <sub>DC</sub> Inductive Load (COS 0.4): 1.2 A (N.O) / 1.2 A (N.C.) 250 V <sub>AC</sub>
RC1	Multi-function relay common	Various kinds of monitor signals output, e.g. operation, frequency reached, overload indication, etc.
RA2	Multi-function relay output 2 (N.O.) a	Resistive Load: 3 A (N.O.) / 250 V <sub>AC</sub>
RC2	Multi-function relay common	5 A (N.O.) / 30 V <sub>DC</sub>
RA3	Multi-function relay output 3 (N.O.) a	
RC3	Multi-function relay common	Various kinds of monitor signals output, e.g. operation, frequency reached, overload indication, etc.
+10V	Potentiometer power supply	Analog frequency setting: +10 V <sub>DC</sub> 20 mA
AVI1	Analog voltage input  AVI1 circuit  +10V  AVI1  ACM  Internal circuit  Figure 6-16	Impedance: 20 kΩ Range: 0–20 mA / 4–20 mA / 0–10 V = 0–Max. Output Frequency (Pr.01-00) AVI1 switch, default is 0–10 V
ACI	Analog current input  ACI ACI circuit  ACM Internal circuit  Figure 6-17	Impedance: 250 Ω Range: 0–20 mA / 4–20 mA / 0–10 V = 0–Max. Output Frequency (Pr.01-00) ACI Switch, default is 4–20 mA

Terminals	Terminal Function	Default (NPN mode)
AVI2	Auxiliary analog voltage input  AVI2 circuit  AVI2  AVI2  ACM  Internal circuit  Figure 6-18	Impedance: 20 kΩ Range: 0–10 V <sub>DC</sub> = 0–Max. Output Frequency (Pr.01-00)
AFM1	Multi-function analog voltage output  AFM1  ACM	0–10 V Max. output current 2 mA, Max. load 5 k $\Omega$ 0–20 mA Max. load 500 $\Omega$ Output current: 20 mA max
AFM2	AFM2  E D  Figure 6-19	Resolution: 0–10 V corresponds to Max. operation frequency Range: 0–10 V → 4–20 mA AFM1/ AFM2 Switch, default is 0–10 V
ACM	Analog Signal Common	Common for analog terminals
STO1	Default setting is shorted	
SCM1	Power removal safety function for EN	N ISO 13849 and IEC 61508
STO2		activated, the voltage of STO1–SCM1 / STO2–SCM2 must be
SCM2	≥ 11 V <sub>DC</sub> , the internal resistance for S Note: Refer to Section 18 Safe Torqu	STO1–SCM1 / STO2–SCM2 is 3.6 k $\Omega$ ue Off Function.
SG+	Modbus RS-485	
SG-	Note: Refer to Section 12 DESCRIP	TION OF PARAMETER SETTINGS group 09
SGND	Communication Parameters for	r more information.
RJ45	, , ,	N 3, 6: SGND N 5: SG+

NOTE: Wire size of analog control signals: 0.75  $\mathrm{mm^2}\,[\mathrm{18}\,\mathrm{AWG}]$  with shielded wire

#### 6-3 Remove the Terminal Block

1. Loosen the screws by screwdriver. (As shown in figure below). Screw torque: 6–8 kg-cm / [5.2–6.9 lb-in] / [0.59–0.78 Nm]




Figure 6-19

2. Remove the control board by pulling it out for a distance 6–8 cm (as 1 in the figure) then lift the control board upward (as 2 in the figure).




Figure 6-20

[This page intentionally left blank]

- 7-1 Brake Resistors and Brake Units Used in AC Motor Drive
- 7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit
  Breaker
- 7-3 Fuse Specification Chart
- 7-4 AC / DC Reactor
- 7-5 Zero Phase Reactor
- 7-6 EMC Filter
- 7-7 Panel Mounting (MKC-KPPK)
- 7-8 Conduit Box Kit
- 7-9 Fan Kit
- 7-10 Flange Mounting Kit
- 7-11 Power Terminal Kit
- 7-12 USB/RS-485 Communication Interface IF6530

The optional accessories listed in this chapter are available upon request. Installing additional accessories to your drive can substantially improve the drive's performance. Select accessories according to your needs or contact your local distributor for suggestions.

#### 7-1 Brake Resistors and Brake Units Used in AC Motor Drives

#### 230V Model

Applio Mo				125% Brak	ing To	orque 10%	DED *1		Max.	Braking Torqu	ıe *2
HP	kW	Braking Torque [kg-m]	Brake Unit VFDB *4		r for E nit *3 Q'ty		Resistor Value Spec. for Each AC Motor Drive	Total Braking Current [A]	Min. Resistor Value [Ω]	Max. Total Braking Current [A]	Peak Power [kW]
1	0.7	0.5	-	BR080W200	1	-	80W 200Ω	1.9	63.3	6	2.3
2	1.5	0.5	-	BR080W200	1	-	80W 200Ω	1.9	63.3	6	2.3
3	2.2	1.0	-	BR200W091	1	-	200W 91Ω	4.2	47.5	8	3.0
5	3.7	1.5	-	BR300W070	1	-	300W 70Ω	5.4	38.0	10	3.8
7.5	5.5	2.5	-	BR400W040	1	-	400W 40Ω	9.5	19.0	20	7.6
10	7.5	3.7	-	BR1K0W020	1	-	1000W 20Ω	19	14.6	26	9.9
15	11	5.1	-	BR1K0W020	1	-	1000W 20Ω	19	14.6	26	9.9
20	15	7.4	-	BR1K5W013	1	-	1500W 13Ω	29	12.6	29	11.0
25	18	10.2	-	BR1K0W4P3	2	2 in series	2000W 8.6Ω	44	8.3	46	17.5
30	22	12.2	-	BR1K0W4P3	2	2 in series	2000W 8.6Ω	44	8.3	46	17.5
40	30	14.9	-	BR1K5W3P3	2	2 in series	3000W 6.6Ω	58	5.8	66	25.1
50	37	20.3	2015*2	BR1K0W5P1	2	2 in series	4000W 5.1Ω	75	4.8	80	30.4
60	45	25	2022*2	BR1K2W3P9	2	2 in series	4800W 3.9Ω	97	3.2	120	45.6
75	55	30.5	2022*2	BR1K5W3P3	2	2 in series	6000W 3.3Ω	118	3.2	120	45.6
100	75	37.2	2022*3	BR1K2W3P9	2	2 in series	7200W 2.6Ω	145	2.1	180	68.4
125	90	50.8	2022*4	BR1K2W3P9	2	2 in series	9600W 2Ω	190	1.6	240	91.2
								<del></del>			Table 7-1

#### 460V Model

+001	Wodel										
	icable otor			125%Bra	king T	orque 10%l	ED *1		Max.	Braking Torqu	ıe *2
HP	kW	Braking Torque	Brake Unit		nit *3	1	Spec. for Each	Total Braking	Min. Resistor	Max. Total Braking	Peak Power
		[kg-m]	VFDB *4		Q'ty	Usage	AC Motor Drive	Current [A]	Value [Ω]	Current [A]	[kW]
1	0.7	0.5	-	BR080W750	1	-	80W 750Ω	1	190.0	4	3.0
2	1.5	0.5	-	BR080W750	1	-	80W 750Ω	1	190.0	4	3.0
3	2.2	1.0	-	BR200W360	1	-	200W 360Ω	2.1	126.7	6	4.6
5	3.7	1.5	-	BR300W250	1	_	300W 250Ω	3	108.6	7	5.3
5.5	4.0	2.5	-	BR400W150	1	-	400W 150Ω	5.1	84.4	9	6.8
7.5	5.5	2.7	-	BR1K0W075	1	-	1000W 75Ω	10.2	54.3	14	10.6
10	7.5	3.7	-	BR1K0W075	1	-	1000W 75Ω	10.2	54.3	14	10.6
15	11	5.1	-	BR1K0W075	1	-	1000W 75Ω	10.2	47.5	16	12.2
20	15	7.4	-	BR1K5W043	1	_	1500W 43Ω	17.6	42.2	18	13.7
25	18	10.2	-	BR1K0W016	2	2 in series	2000W 32Ω	24	26.2	29	22.0
30	22	12.2	-	BR1K0W016	2	2 in series	2000W 32Ω	24	23.0	33	25.1
40	30	14.9	-	BR1K5W013	2	2 in series	3000W 26Ω	29	23.0	33	25.1
50	37	20.3	-	BR1K0W016	4	2 parallel, 2 in series	4000W 16Ω	47.5	14.1	54	41.0
60	45	25	4045*1	BR1K2W015	4	2 parallel, 2 in series	4800W 15Ω	50	12.7	60	45.6
75	55	30.5	4045*1	BR1K5W013	4	2 parallel, 2 in series	6000W 13Ω	59	12.7	60	45.6
100	75	37.2	4030*2	BR1K0W5P1	4	4 series	8000W 10.2Ω	76	9.5	80	60.8
125	90	50.8	4045*2	BR1K2W015	4	2 parallel, 2 in series	9600W 7.5Ω	100	6.3	120	91.2
150	110	60.9	4045*2	BR1K5W013	4	2 parallel, 2 in series	12000W 6.5Ω	117	6.3	120	91.2
175	132	74.5	4110*1	BR1K2W015	10	5 parallel, 2 in series	12000W 6Ω	126	6.0	126	95.8
215	160	89.4	4160*1	BR1K5W012	12	6 parallel, 2 in series	18000W 4Ω	190	4.0	190	144.4

	cable otor			125%Bra	king T	orque 10%	ED *1		Max. Braking Torque *2		
HP	kW	Braking Torque	Brake Unit	Brake Resistor for Each Brake Unit *3			Resistor Value Spec. for Each	Total Braking	Min. Resistor	Max. Total Braking	Peak Power
		[kg-m]	VFDB *4	P/N	Q'ty	Usage	AC Motor Drive	Current [A]	Value [Ω]	Current [A]	[kW]
250	185	108.3	4160*1	BR1K5W012	12	6 parallel, 2 in series	18000W 4Ω	190	4.0	190	144.4
270	200	108.3	4185*1	BR1K5W012	12	6 parallel, 2 in series	18000W 4Ω	190	4.0	190	144.4
300	220	125.2	4185*1	BR1K5W012	14	7 parallel, 2 in series	21000W 3.4Ω	225	3.4	225	172.0
340	250	135.4	4110*2	BR1K2W015	10	5 parallel, 2 in series	24000W 3Ω	252	3.0	252	191.5
375	280	148.9	4110*2	BR1K2W015	10	5 parallel, 2 in series	24000W 3Ω	252	3.0	252	191.5
425	315	189.6	4160*2	BR1K5W012	12	6 parallel, 2 in series	36000W 2Ω	380	2.0	380	288.8
475	355	213.3	4160*2	BR1K5W012	12	6 parallel, 2 in series	36000W 2Ω	380	2.0	380	288.8
536	400	240.3	4185*2	BR1K5W012	14	7 parallel, 2 in series	42000W 1.7Ω	450	1.7	450	344.2
675	500	304.7	4185*3	BR1K5W012	12	6 parallel, 2 in series	54000W 1.3Ω	600	1.1	675	513.0
745	560	379.1	4185*3	BR1K5W012	14	7 parallel, 2 in series	63000W 1.1Ω	675	1.1	675	513.0
850	630	426.5	4160*4	BR1K5W012	12	6 parallel, 2 in series	72000W 1.0Ω	760	1.0	760	577.6

Table 7-2

#### 575V Model

	cable r [kW]			125%Brak	ing Tor	que 10%	ED *1		Max. Braking Torque *2			
ND	Braking Brake LD Torque Unit		Brake Resistor Ur	r for Ea nit *3	ach Brake	Resistor Value Spec. for Each	Total Braking	Min. Resistor	Max. Total Braking	Peak Power		
ND	LD	[kg-m]	VFDB *4	P/N	Q'ty	Usage	AC Motor Drive	Current [A]	Value [Ω]	Current [A]	[kW]	
0.75	1.5	0.5	-	BR080W750	1	-	80W 750Ω	1.2	280.0	4	4.5	
1.5	2.2	1	-	BR200W360	1	-	200W 360Ω	2.6	186.7	6	6.7	
2.2	3.7	1.5	-	BR300W400	1	-	300W 400Ω	2.3	160.0	7	7.8	
3.7	5.5	2.5	-	BR500W100	1	-	500W 100Ω	9.2	93.3	12	13.4	
5.5	7.5	3.7	-	BR750W140	1	-	750W 140Ω	6.6	80.0	14	15.7	
7.5	11	5.1	-	BR1K0W075	1	-	1000W 75Ω	12.3	70.0	16	17.9	
11	15	7.4	-	BR1K1W091	1	-	1100W 91Ω	10.1	62.2	18	20.2	

Table 7-3

### 690V Model

0301	090 V IVIOGEI											
	cable r [kW]			125%Brak	ing To	rque 10%	ED *1		Max. Braking Torque*2			
LD	ND	Braking Torque	Brake Unit	Unit *3			Resistor Value Spec. for Each	Total Braking	Min. Resistor	Max. Total Braking	Peak Power	
		[kg-m]	VFDB*4	P/N	Q'ty	Usage	AC Motor Drive	Current [A]	Value [Ω]	Current [A]	[kW]	
18.5	15	10.2	-	BR1K0W039	2	2 in series	2000W 78Ω	14.4	58.9	19	21.3	
22	18.5	12.5	-	BR1K2W033	2	2 in series	2400W 66Ω	17.0	58.9	19	21.3	
30	22	14.9	-	BR1K5W027	2	2 in series	3000W 54Ω	20.7	43.1	26	29.1	
37	30	20.3	-	BR1K2W015	3	3 in series	3600W 45Ω	24.9	43.1	26	29.1	
45	37	25	6055*1	BR1K2W033	4	2 parallel, 2 in series	4800W 33Ω	33.9	24.3	46	51.5	
55	45	30.5	6055*1	BR1K5W027	4	2 parallel, 2 in series	6000W 27Ω	41.5	24.3	46	51.5	
75	55	37.2	6110*1	BR1K2W033	6	3 parallel, 2 in series	7200W 22Ω	50.9	12.2	92	103.0	
90	75	50.8	6110*1	BR1K5W027	6	3 parallel, 2 in series	9000W 18Ω	62.2	12.2	92	103.0	


	cable r [kW]			125%Brak	ing To	rque 10%	ED *1		Max. Braking Torque*2			
LD	ND	Braking Torque	Brake Unit			ach Brake	Resistor Value Spec. for Each	Total Braking	Min. Resistor	Max. Total Braking	Peak Power	
		[kg-m]	VFDB*4	P/N	Q'ty	Usage	AC Motor Drive	Current [A]	Value [Ω]	Current [A]	[kW]	
110	90	60.9	6110*1	BR1K5W027	8	4 parallel, 2 in series	12000W 13.5Ω	83.0	12.2	92	103.0	
132	110	74.5	6160*1	BR1K2W015	12	4 parallel, 3 in series	14400W 11.3Ω	99.6	8.2	136	152.3	
160	132	89.4	6160*1	BR1K5W027	10	5 parallel, 2 in series	15000W 10.8Ω	103.7	8.2	136	152.3	
200	160	108.3	6200*1	BR1K5W027	12	6 parallel, 2 in series	18000W 9.0Ω	124.4	6.9	162	181.4	
250	200	135.4	6110*2	BR1K5W027	8	4 parallel, 2 in series	24000W 6.8Ω	165.9	6.1	184	206.1	
315	250	169.3	6160*2	BR1K5W027	10	5 parallel, 2 in series	30000W 5.4Ω	207.4	4.1	272	304.6	
400	315	213.3	6200*2	BR1K5W027	12	6 parallel, 2 in series	36000W 4.5Ω	248.9	3.5	324	362.9	
450	355	240.3	6200*2	BR1K5W027	14	7 parallel, 2 in series	42000W 3.9Ω	290.4	3.5	324	362.9	
560	450	304.7	6200*3	BR1K5W027	12	6 parallel, 2 in series	54000W 3.0Ω	373.3	2.3	486	544.3	
630	630	426.5	6200*4	BR1K5W027	12	6 parallel, 2 in series	72000W 2.3Ω	497.8	1.7	648	725.8	

Table 7-4

- \*1 Calculation for 125% braking toque: (kW) × 125% × 0.8; where 0.8 is motor efficiency.
  Because of the limited resistor power, the longest operation time for 10%ED is 10 seconds (ON: 10 sec. / OFF: 90 sec.).
- \*2 Refer to Chapter 7 "Brake Module and Brake Resistors" in the application manual for "Operation Duration & ED" vs. "Braking Current".
- For heat dissipation, a resistors of 400 W or lower should be fixed to the frame and maintain the surface temperature below 250°C; a resistor of 1000 W and above should maintain the surface temperature below 350°C. (If the surface temperature is higher than the temperature limit, install extra cooling or increase the size of the resistor.)
- \*4 The calculation of the brake resistor is based on a four-pole motor (1800 rpm). Refer to VFDB series Braking Module Instruction for more details on brake resistor.

#### NOTE

- 1. Specification and Appearance of Brake Resistors
  - 1-1 Wire wound resistors: For 1000 W and above, refer to the following appearance of wire wound resistor (Figure 7-1) and its model and specification comparison table (Table 7-5) for details.




Models and Specifications Comparison Table of Wire Wound Resistors:

ioueis and c	phecilics	ilions C	onipans	oui iabi	5 OI VVII	ie wo	unu ix	cololol	э.		Ur	nit: mm
MODEL	Α	В	С	D	Е	F	G	Н	ØΙ	ØJ	K	L
BR1K0W4P3												
BR1K0W5P1												
BR1K0W016												
BR1K0W020												
BR1K0W075												
BR1K2W3P9	470±10	445±5	48±0.2	9.1±0.1	390±3	98±5	47±5	15±1	55±5	8.1±0.1	21±0.2	8±1
BR1K2W015												
BR1K5W3P3												
BR1K5W012												
BR1K5W013												
BR1K5W043												

Table 7-5

1-2 Aluminum housed resistors: For below 1000 W, refer to the following appearance of aluminum-housed resistor (Figure 7-2) and its model and specification comparison table (Table 7-6) for details.



							Unit: mm
MODEL	L1	L2	L3	W	Н	Α	L
BR080W200	140+2	125±2	100±1	40±0.5	20± 0.5		
BR080W750	140±2	123±2	100±1	40±0.5	20±0.5		
BR200W091	165±2	150±2	125±1				
BR200W360	165±2	150±2	123±1			50105	000   00
BR300W070	215±2	200±2	175±1	60± 0.5	30± 0.5	$5.3\pm0.5$	200±20
BR300W250	Z13±Z	200±2	173±1	00±0.5	30±0.5		
BR400W040	005   0	250   2	225   4				
BR400W150	265±2	250±2	225±1				

Table 7-6

2. Select the resistance value, power and brake usage (ED %) according to Delta rules.

# Brake Time T1 Cycle Time T0

Definition for Brake Usage ED%


 $ED\% = T1 / T0 \times 100(\%)$ 

Explanation:


Brake usage ED (%) is the amount of time needed for the brake unit and brake resistor to dissipate heat generated by braking. When the brake resistor heats up, the resistance increases with temperature, and braking torque decreases accordingly.

Figure 7-3

For safety, install a thermal overload relay (O.L) between the brake unit and the brake resistor in conjunction with the magnetic contactor (MC) before the drive for additional protection. The thermal overload relay protects the brake resistor from damage due to frequent or continuous braking. Under such circumstances, turn off the power to prevent damage to the brake resistor, brake unit and drive. NOTE: Never use it to disconnect the brake resistor.



- When AC Drive is equipped with a DC reactor, please read user manual for the correct wiring for the brake unit input circuit +(P).
- DO NOT connect input circuit -(N) to the neutral point of the power system.
- 3. Any damage to the drive or other equipment caused by using brake resistors and brake modules that are not provided by Delta voids the warranty.
- 4. Consider environmental safety factors when installing the brake resistors. If you use the minimum resistance value, consult local dealers for the power calculation.
- 5. When using more than two brake units, the equivalent resistor value of the parallel brake unit cannot be less than the value in the column "Min. Resistor Value ( $\Omega$ )". Read the wiring information in the brake unit instruction sheet thoroughly prior to operation. Visit the following links to get the instruction sheets for the wiring in the brake unit:
  - VFDB2015 / 2022 / 4030 / 4045 / 5055 Braking Modules Instruction Sheet
     http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA\_IA-MDS\_VFDB\_I\_EN\_20070719.pdf
  - VFDB4110 / 4160 / 4185 Braking Modules Instruction Sheet
     <a href="http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA\_IA-MDS\_VFDB4110-4160-4185\_I\_EN\_20101011.pdf">http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA\_IA-MDS\_VFDB4110-4160-4185\_I\_EN\_20101011.pdf</a>
  - VFDB6055 / 6110 / 6160 / 6200 Braking Modules Instruction Sheet
     <a href="http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA\_IA-MDS\_VFDB6055-6110-6160-6200\_ITSE\_20121030.pdf">http://www.deltaww.com/filecenter/Products/download/06/060101/Option/DELTA\_IA-MDS\_VFDB6055-6110-6160-6200\_ITSE\_20121030.pdf</a>
- 6. The selection tables are for normal usage. If the AC motor drive requires frequent braking, increase the Watts by two to three times.
- 7. Thermal Overload Relay (TOR), for 230V / 460V / 690V models:
  - Thermal overload relay selection is based on its overload capacity. A standard braking capacity of the CP2000 is 10% ED (Tripping time = 10 s). As shown in the figure below, a 460V, 110 kw CP2000 requires the thermal relay to take 260% overload capacity for 10 seconds (hot starting) and the braking current is 126 A. In this case, select a thermal overload relay rated at 50 A. The property of each thermal relay may vary among different manufacturers. Carefully read the specification before using it.



Multiple of current setting

In (x) Figure 7-5

# 7-2 Magnetic Contactor / Air Circuit Breaker and Non-fuse Circuit Breaker

#### Magnetic Contactor (MC) and Air Circuit Breaker (ACB)

It is recommended the surrounding temperature for MC should be  $\geq 60^{\circ}$ C and that for ACB should be  $\geq 50^{\circ}$ C. In the meanwhile, consider temperature derating for components with ON/OFF switch in accordance with the ambient temperature of the on-site distribution panel.

#### 230V Model

Frame	Model	Light Duty Output Current [A]	Light Duty Input Current [A]	MC/ACB Selection [A]
	VFD007CP23A-21	5	6.4	11
	VFD015CP23A-21	7.5	9.6	18
А	VFD022CP23A-21	10	15	22
	VFD037CP23A-21	15	22	40
	VFD055CP23A-21	21	25	40
	VFD075CP23A-21	31	34	55
В	VFD110CP23A-21	46	51	85
	VFD150CP23A-21	61	67	105
	VFD185CP23A-21	75	83	130
С	VFD220CP23A-21	90	99	150
	VFD300CP23A-21	105	116	185
D	VFD370CP23A-00/21	146	146	225
	VFD450CP23A-00/21	180	180	265
	VFD550CP23A-00/21	215	215	330
E	VFD750CP23A-00/21	276	276	400
	VFD900CP23A-00/21	322	322	500

Table 7-7

#### 460V Model

Frame	Model	Light Duty Output Current [A]	Light Duty Input Current [A]	MC/ACB Selection [A]
	VFD007CP43A-21	3.0	4.3	7
	VFD015CP43B-21	4.2	6.0	9
	VFD022CP43B-21	5.5	8.1	12
Α	VFD037CP43B-21	8.5	12.4	22
	VFD040CP43A-21	10.5	16	32
	VFD055CP43B-21	13	20	32
	VFD075CP43B-21	18	22	40
	VFD110CP43B-21	24	26	40
В	VFD150CP43B-21	32	35	55
	VFD185CP43B-21	38	42	65
	VFD220CP43A-21	45	50	75
С	VFD300CP43B-21	60	66	105
	VFD370CP43B-21	73	80	130

Frame	Model	Light Duty Output Current [A]	Light Duty Input Current [A]	MC/ACB Selection [A]
D0	VFD450CP43S-21	91	91	150
DU	VFD550CP43S-21	110	110	185
D	VFD750CP43B-00/21	150	150	265
U	VFD900CP43A-00/21	180	180	265
Е	VFD1100CP43A-00/21	220	220	330
	VFD1320CP43B-00/21	260	260	400
F	VFD1600CP43A-00/21	310	310	500
F	VFD1850CP43B-00/21	370	370	630
	VFD2000CP43A-00/21	395	395	800
	VFD2200CP43A-00/21	460	460	800
G	VFD2500CP43A-00/21	481	481	800
	VFD2800CP43A-00/21	530	530	800
	VFD3150CP43A-00/C-00/C-21	616	616	1000
	VFD3550CP43A-00/C-00/C-21	683	683	1000
	VFD4000CP43A-00/C-00/C-21	770	770	1250
Н	VFD5000CP43A-00/C-00/C-21	930	930	1600
	VFD5600CP43A-00/C-21	1094	1094	2000
	VFD6300CP43A-00/C-21	1212	1212	2000

Table7-8

#### 575V Model

Frame	Model	Light Duty Output Current [A]	Light Duty Input Current [A]	MC/ACB Selection [A]
	VFD015CP53A-21	3	3.8	9
Α	VFD022CP53A-21	4.3	5.4	12
	VFD037CP53A-21	6.7	10.4	18
	VFD055CP53A-21	9.9	14.9	32
В	VFD075CP53A-21	12.1	16.9	32
Ь	VFD110CP53A-21	18.7	21.3	40
	VFD150CP53A-21	24.2	26.3	50

Table 7-9

#### 690V Model

Frame	Model	Light Duty Output Current [A]	Light Duty Input Current [A]	MC/ACB Selection [A]
	VFD185CP63A-21	24	29	50
С	VFD220CP63A-21	30	36	65
C	VFD300CP63A-21	36	43	75
	VFD370CP63A-21	45	54	100
D	VFD450CP63A-00/A-21	54	65	130
D	VFD550CP63A-00/A-21	67	81	150
	VFD750CP63A-00/A-21	86	84	150
E	VFD900CP63A-00/A-21	104	102	185
	VFD1100CP63A-00/A-21	125	122	225

Frame	Model	Light Duty Output Current [A]	Light Duty Input Current [A]	MC/ACB Selection [A]	
E	VFD1320CP63A-00/A-21	150	147	265	
F	VFD1600CP63A-00/A-21	180	178	330	
F	VFD2000CP63A-00/A-21	220	217	400	
G	VFD2500CP63A-00/A-21	290	292	630	
	VFD3150CP63A-00/A-21	350	353	630	
	VFD4000CP63A-00/A-21	430	454	800	
	VFD4500CP63A-00/A-21	465	469	800	
Н	VFD5600CP63A-00/A-21	590	595	1000	
	VFD6300CP63A-00/A-21	675	681	1250	

Table 7-10

#### Non-fuse Circuit Breaker

Comply with the UL standard: Per UL 508, paragraph 45.8.4, part a,

The rated current of the non-fuse circuit breaker should be 1.6–2.6 times (575V / 690V models: 2–4 times) the drive's rated input current.

230V / Three-phase				
Model	Breaker Rated Input Recommended Current [A]			
VFD007CP23A-21	15			
VFD015CP23A-21	20			
VFD022CP23A-21	30			
VFD037CP23A-21	40			
VFD055CP23A-21	50			
VFD075CP23A-21	60			
VFD110CP23A-21	100			
VFD150CP23A-21	125			
VFD185CP23A-21	150			
VFD220CP23A-21	200			
VFD300CP23A-21	225			
VFD370CP23A-00/23A-21	250			
VFD450CP23A-00/23A-21	300			
VFD550CP23A-00/23A-21	400			
VFD750CP23A-00/23A-21	450			
VFD900CP23A-00/23A-21	600			

Table 7-11

Model	Breaker Rated Input Recommended Current [A]
VFD007CP43A-21/4EA-21	10
VFD015CP43B-21/4EB-21	10
VFD022CP43B-21/4EB-21	15
VFD040CP43A-21/4EA-21	25
VFD037CP43B-21/4EB-21	30
VFD055CP43B-21/4EB-21	40
VFD075CP43B-21/4EB-21	40
VFD110CP43B-21/4EB-21	50
VFD150CP43B-21/4EB-21	60
VFD185CP43B-21/4EB-21	75
VFD220CP43A-21/4EA-21	100
VFD300CP43B-21/4EB-21	125
VFD370CP43B-21/4EB-21	150
VFD450CP43S-00/43S-21	175
VFD550CP43S-00/43S-21	250
VFD750CP43B-00/43B-21	300
VFD900CP43A-00/43A-21	300
VFD1100CP43A-00/43A-21	400
VFD1320CP43B-00/43B-21	500
VFD1600CP43A-00/43A-21	600
VFD1850CP43B-00/43B-21	600
VFD2000CP43A-0043A/-21	800
VFD2200CP43A-00/43A-21	800
VFD2500CP43A-00/43A-21	1000
VFD2800CP43A-00/43A-21	1000
VFD3150CP43A-00/43C-00/43C-21	1200
VFD3550CP43A-00/43C-00/43C-21	1350
VFD4000CP43A-00/43C-00/43C-21	1500
VFD5000CP43A-00/43C-00/43C-21	2000
VFD5600CP43A-00/43C-21	2000
VFD6300CP43A-00/43C-21	2000

460V / Three-phase

Table 7-12

575V / Three-phase				
Model	Breaker Rated Input Recommended Current [A]			
VFD015CP53A-21	7			
VFD022CP53A-21	10			
VFD037CP53A-21	15			
VFD055CP53A-21	25			
VFD075CP53A-21	32			
VFD110CP53A-21	50			
VFD150CP53A-21	63			

Table 7-13

690V / Three-phase				
Model	Breaker Rated Input Recommended Current [A]			
VFD185CP63A-21	60			
VFD220CP63A-21	70			
VFD300CP63A-21	80			
VFD370CP63A-21	100			
VFD450CP63A-00/-21	100			
VFD550CP63A-00/-21	125			
VFD750CP63A-00/-21	175			
VFD900CP63A-00/-21	200			
VFD1100CP63A-00/-21	250			
VFD1320CP63A-00/-21	300			
VFD1600CP63A-00/-21	350			
VFD2000CP63A-00/-21	400			
VFD2500CP63A-00/-21	450			
VFD3150CP63A-00/-21	500			
VFD4000CP63A-00/-21	700			
VFD4500CP63A-00/-21	800			
VFD5600CP63A-00/-21	1250			
VFD6300CP63A-00/-21	1400			

Table 7-14

## 7-3 Fuse Specification Chart

- ☑ Fuse specifications lower than the table below are allowed.
- For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code (NEC) and any applicable local codes. Use UL classified fuses to fulfill this requirement.

For installation in Canada, branch circuit protection must be provided in accordance with Canadian Electrical Code and any applicable provincial codes. Use UL classified fuses to fulfill this requirement.

230V Model	Input Current I [A]		Line Fuse	
230 V WOUGH	Normal Duty	Light Duty	l [A]	Bussmann P/N
VFD007CP23A-21	3.9	6.4	15	JJN-15
VFD015CP23A-21	6.4	9.6	20	JJN-20
VFD022CP23A-21	12	15	30	JJN-30
VFD037CP23A-21	16	22	40	JJN-40
VFD055CP23A-21	20	25	50	JJN-50
VFD075CP23A-21	28	35	60	JJN-60
VFD110CP23A-21	36	50	100	JJN-100
VFD150CP23A-21	52	65	125	JJN-125
VFD185CP23A-21	72	83	150	JJN-150
VFD220CP23A-21	83	100	200	JJN-200
VFD300CP23A-21	99	116	225	JJN-225
VFD370CP23A-00/23A-21	124	146	250	JJN-250
VFD450CP23A-00/23A-21	143	180	300	JJN-300
VFD550CP23A-00/23A-21	171	215	400	JJN-400
VFD750CP23A-00/23A-21	206	276	450	JJN-450
VFD900CP23A-00/23A-21	245	322	600	JJN-600

Table 7-15

460V/Model	Input Curi	rent I[A]	Line	Line Fuse	
460V Model	Normal Duty	Light Duty	I [A]	Bussmann P/N	
VFD007CP43A-21/4EA-21	3.5	4.3	10	JJS-10	
VFD015CP43B-21/4EB-21	4.3	6.0	10	JJS-10	
VFD022CP43B-21/4EB-21	5.9	8.1	15	JJS-15	
VFD040CP43A-21/4EA-21	8.7	12.4	25	JJS-20	
VFD037CP43B-21/4EB-21	14	16	30	JJS-20	
VFD055CP43B-21/4EB-21	15.5	20	40	JJS-30	
VFD075CP43B-21/4EB-21	17	22	40	JJS-40	
VFD110CP43B-21/4EB-21	20	26	50	JJS-50	
VFD150CP43B-21/4EB-21	26	35	60	JJS-60	
VFD185CP43B-21/4EB-21	35	42	75	JJS-75	
VFD220CP43A-21/4EA-21	40	50	100	JJS-100	
VFD300CP43B-21/4EB-21	47	66	125	JJS-125	
VFD370CP43B-21/4EB-21	63	80	150	JJS-150	
VFD450CP43S-00/43S-21	74	91	175	JJS-175	
VFD550CP43S-00/43S-21	101	110	250	JJS-250	
VFD750CP43B-00/43B-21	114	150	300	JJS-300	
VFD900CP43A-00/43-21	157	180	300	JJS-300	
VFD1100CP43A-00/43A-21	167	220	400	JJS-400	
VFD1320CP43B-00/43B-21	207	260	500	JJS-500	
VFD1600CP43A-00/43A-21	240	310	600	JJS-600	
VFD1850CP43B-00/43B-21	300	370	600	JJS-600	
VFD2000CP43A-00/43A-21	300	395	800	JJS-800	
VFD2200CP43A-00/43A-21	380	460	800	JJS-800	
VFD2500CP43A-00/43A-21	390	481	1000	KTU-1000	
VFD2800CP43A-00/43A-21	400	530	1000	KTU-1000	
VFD3150CP43A-00/43C-00/43C-21	494	616	1200	KTU-1200	
VFD3550CP43A-00/43C-00/43C-21	555	683	1350	KTU-1350	
VFD4000CP43A-00/43C-00/43C-21	625	770	1500	KTU-1500	
VFD5000CP43A-00/43C-00/43C-21 *	866	930	1600	170M6019	
VFD5600CP43A-00/43C-21	930	1094	2000	170M6021	
VFD6300CP43A-00/43C-21	1094	1212	2000	170C6021	

<sup>\*</sup>VFD5000CP43A-00/43C-00/43C-21 models are not UL certified.

Table 7-16

F75\/ M l . l	Input Curi	rent I [A]	Line Fuse				
575V Model	Normal Duty	Light Duty	I [A]	Bussmann P/N	Vendor		
VFD015CP53A-21	3.1	3.8	7	KLKD007.T	Littelfuse		
VFD022CP53A-21	4.5	5.4	10	KLKD010.T	Littelfuse		
VFD037CP53A-21	7.2	10.2	15	KLKD015.T	Littelfuse		
VFD055CP53A-21	12.3	14.9	25	25ET	Bussmann		
VFD075CP53A-21	15	16.9	32	32ET	Bussmann		
VFD110CP53A-21	18	21.3	50	50FE	Bussmann		
VFD150CP53A-21	22.8	26.3	63	63FE	Bussmann		

Table 7-17

690V Model	Input Curi	rent I [A]	Line	Fuse
090 V Wodel	Normal Duty	Light Duty	I [A]	Bussmann P/N
VFD185CP63A-21	24	29	60	JJS-60
VFD220CP63A-21	29	36	70	JJS-70
VFD300CP63A-21	36	43	80	JJS-80
VFD370CP63A-21	43	54	100	JJS-100
VFD450CP63A-00/-21	54	65	100	JJS-100
VFD550CP63A-00/-21	65	81	125	JJS-125
VFD750CP63A-00/-21	66	84	175	JJS-175
VFD900CP63A-00/-21	84	102	200	JJS-200
VFD1100CP63A-00/-21	102	122	250	JJS-250
VFD1320CP63A-00/-21	122	147	300	JJS-300
VFD1600CP63A-00/-21	148	178	350	JJS-350
VFD2000CP63A-00/-21	178	217	400	JJS-400
VFD2500CP63A-00/-21	222	292	450	170M4063
VFD3150CP63A-00/-21	292	353	500	170M6058
VFD4000CP63A-00/-21	353	454	700	170M6061
VFD4500CP63A-00/-21	388	469	800	170M6062
VFD5600CP63A-00/-21	504	595	1250	170M6066
VFD6300CP63A-00/-21	681	681	1400	170M6067

Table 7-18


#### 7-4 AC / DC Reactor

#### **AC Input Reactor**

Installing an AC reactor on the input side of an AC motor drive can increase line impedance, improve the power factor, reduce input current, increase system capacity, and reduce interference generated from the motor drive. It also reduces momentary voltage surges or abnormal current spikes from the mains power, further protecting the drive. For example, when the main power capacity is higher than 500 kVA, or when using a phase-compensation capacitor, momentary voltage and current spikes may damage the AC motor drive's internal circuit. An AC reactor on the input side of the AC motor drive protects it by suppressing surges.

#### Installation

Install an AC input reactor in series between the main power and the three input phases R S T, as shown in the figure below:



Following table shows the standard AC reactors specification of Delta CP2000

200V-230V, 50 / 60 Hz, Light Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD007CP23A-21	0.75	1	5	6	2.536	4.227	No	DR005A0254	21
VFD015CP23A-21	1.5	2	7.5	9	1.585	2.642	No	DR008A0159	37
VFD022CP23A-21	2.2	3	10	12	1.152	1.92	No	DR011A0115	38
VFD037CP23A-21	3.7	5	15	18	0.746	1.243	No	DR017AP746	40
VFD055CP23A-21	5.5	7.5	21	25.2	0.507	0.845	No	DR025AP507	61
VFD075CP23A-21	7.5	10	31	37.2	0.38	0.633	No	DR033AP320	60
VFD110CP23A-21	11	15	46	55.2	0.26	0.433	No	DR049AP215	70
VFD150CP23A-21	15	20	61	73.2	0.196	0.327	No	DR065AP162	83
VFD185CP23A-21	18.5	25	75	90	0.169	0.282	No	DR075AP170	150
VFD220CP23A-21	22	30	90	108	0.141	0.235	No	DR090AP141	120
VFD300CP23A-21	30	40	105	126	0.12	0.2	No	DR105AP106	150
VFD370CP23A-00 VFD370CP23A-21	37	50	146	175.2	0.087	0.145	Yes	DR146AP087	110
VFD450CP23A-00 VFD450CP23A-21	45	60	180	216	0.07	0.117	Yes	DR180AP070	120
VFD550CP23A-00 VFD550CP23A-21	55	75	215	258	0.059	0.098	Yes	DR215AP059	150

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD750CP23A-00 VFD750CP23A-21	75	100	276	331.2	0.049	0.082	Yes	DR276AP049	200
VFD900CP23A-00 VFD900CP23A-21	90	125	322	386.4	0.037	0.062	Yes	DR346AP037	240

Note: The above heat dissipation is calculated based on AC reactor's rated current, the actual dissipation varies with the operation current.

Table 7-19

#### 200V-230V, 50 / 60 Hz, Normal Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD007CP23A-21	0.75	1	4.6	7.36	2.536	4.227	No	DR005A0254	21
VFD015CP23A-21	1.5	2	5	8	2.536	4.227	No	DR005A0254	21
VFD022CP23A-21	2.2	3	8	12.8	1.585	2.642	No	DR008A0159	37
VFD037CP23A-21	3.7	5	11	17.6	1.152	1.92	No	DR011A0115	38
VFD055CP23A-21	5.5	7.5	17	27.2	0.746	1.243	No	DR017AP746	40
VFD075CP23A-21	7.5	10	25	40	0.507	0.845	No	DR025AP507	61
VFD110CP23A-21	11	15	33	52.8	0.38	0.633	No	DR033AP320	60
VFD150CP23A-21	15	20	49	78.4	0.26	0.433	No	DR049AP215	70
VFD185CP23A-21	18.5	25	65	104	0.196	0.327	No	DR065AP162	83
VFD220CP23A-21	22	30	75	120	0.169	0.282	No	DR075AP170	150
VFD300CP23A-21	30	40	90	144	0.141	0.235	No	DR090AP141	120
VFD370CP23A-00 VFD370CP23A-21	37	50	120	192	0.12	0.2	Yes	DR105AP106	150
VFD450CP23A-00 VFD450CP23A-21	45	60	146	233.6	0.087	0.145	Yes	DR146AP087	110
VFD550CP23A-00 VFD550CP23A-21	55	75	180	288	0.07	0.117	Yes	DR180AP070	120
VFD750CP23A-00 VFD750CP23A-21	75	100	215	344	0.059	0.098	Yes	DR215AP059	150
VFD900CP23A-00 VFD900CP23A-21	90	125	255	408	0.049	0.082	Yes	DR276AP049	200

Note: The above heat dissipation is calculated based on AC reactor's rated current, the actual dissipation varies with the operation current.

Table 7-20

#### 380V-460V, 50 / 60 Hz, Light Duty

			<u>,                                      </u>						
Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD007CP43A-21 VFD007CP4EA-21	0.75	1	3	3.6	8.102	13.503	No	DR003A0810	20
VFD015CP43B-21 VFD015CP4EB-21	1.5	2	4.2	5.04	6.077	10.128	No	DR004A0607	21
VFD022CP43B-21 VFD022CP4EB-21	2.2	3	5.5	6.6	4.05	6.75	No	DR006A0405	31
VFD037CP43B-21 VFD037CP4EB-21	3.7	5	8.5	10.2	2.7	4.5	No	DR009A0270	40
VFD040CP43A-21 VFD040CP4EA-21	4	5	10.5	12.6	2.315	3.858	No	DR010A0231	50

			Datad	Catumatian	20/	F0/	Duilt in		Heat
Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD055CP43B-21 VFD055CP4EB-21	5.5	7.5	13	15.6	2.025	3.375	No	DR012A0202	50
VFD075CP43B-21 VFD075CP4EB-21	7.5	10	18	21.6	1.35	2.25	No	DR018A0117	54
VFD110CP43B-21 VFD110CP4EB-21	11	15	24	28.8	1.01	1.683	No	DR024AP881	60
VFD150CP43B-21 VFD150CP4EB-21	15	20	32	38.4	0.76	1.267	No	DR032AP660	80
VFD185CP43B-21 VFD185CP4EB-21	18.5	25	38	45.6	0.639	1.065	No	DR038AP639	85
VFD220CP43A-21 VFD220CP4EA-21	22	30	45	54	0.541	0.902	No	DR045AP541	95
VFD300CP43B-21 VFD300CP4EB-21	30	40	60	72	0.405	0.675	No	DR060AP405	100
VFD370CP43B-21 VFD370CP4EB-21	37	50	73	87.6	0.334	0.557	No	DR073AP334	115
VFD450CP43S-00 VFD450CP43S-21	45	60	91	109.2	0.267	0.445	Yes	DR091AP267	130
VFD550CP43S-00 VFD550CP43S-21	55	75	110	132	0.221	0.368	Yes	DR110AP221	150
VFD750CP43B-00 VFD750CP43B-21	75	100	150	180	0.162	0.27	Yes	DR150AP162	170
VFD900CP43A-00 VFD900CP43A-21	90	125	180	216	0.135	0.225	Yes	DR180AP135	190
VFD1100CP43A-00 VFD1100CP43A-21	110	150	220	264	0.11	0.183	Yes	DR220AP110	230
VFD1320CP43B-00 VFD1320CP43B-21	132	175	260	312	0.098	0.163	Yes	DR260AP098	280
VFD1600CP43A-00 VFD1600CP43A-21	160	215	310	372	0.078	0.13	Yes	DR310AP078	300
VFD1850CP43B-00 VFD1850CP43B-21	185	250	370	444	0.066	0.11	Yes	DR370AP066	340
VFD2000CP43A-00 VFD2000CP43A-21	200	270	395	474	0.061	0.1	Yes	DR460AP054*1	400
VFD2200CP43A-00 VFD2200CP43A-21	220	300	460	552	0.054	0.09	Yes	DR460AP054	400
VFD2500CP43A-00 VFD2500CP43A-21	250	340	481	578	0.052	0.086	Yes	DR550AP044*1	430
VFD2800CP43A-00 VFD2800CP43A-21	280	375	530	636	0.044	0.073	Yes	DR550AP044	430
VFD3150CP43A-00 VFD3150CP43C-00 VFD3150CP43C-21	315	420	616	739.2	0.039	0.065	Yes	DR616AP039	450
VFD3550CP43A-00 VFD3550CP43C-00 VFD3550CP43C-21	355	475	683	819.6	0.036	0.06	Yes	DR683AP036	480
VFD4000CP43A-00 VFD4000CP43C-00 VFD4000CP43C-21	400	530	770	924	0.028	0.047	Yes	DR866AP028	610

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD5000CP43A-00 VFD5000CP43C-00	500	930	912	1094.4	0.028	0.043	Yes	DR866AP028	610
VFD5000CP43C-21	000	000	0.12	100 1.1	0.020	0.010	100	D110007 11 020	010
VFD5600CP43A-00 VFD5600CP43C-21	560	750	1094	1318.2	0.022	0.037	Yes		
VFD6300CP43A-00	000	050	4040	4454.4	0.000	0.000	.,	Contact D	elta
VFD6300CP43C-21	630	850	1212	1454.4	0.020	0.033	Yes		

<sup>\*</sup>Note 1: The inductance value for the above applications of Delta's reactors will be closer, but less than 3%.

Note 2: The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

Table 7-21

#### 380V-460V, 50 / 60 Hz, Normal Duty

380V-460V, 50 / 60			Rated	Saturation	3%	5%	Built-in	Innut AC Deseter	Heat
Model	kW	HP	Current (Arms)	Current (Arms)	Reactor (mH)	Reactor (mH)	DC Reactor	Input AC Reactor Delta Part #	Dissipation (W)
VFD007CP43A-21 VFD007CP4EA-21	0.75	1	2.8	4.48	9.058	15.097	No	DR003A0810*1	20
VFD015CP43B-21 VFD015CP4EB-21	1.5	2	3	4.8	8.102	13.503	No	DR003A0810	20
VFD022CP43B-21 VFD022CP4EB-21	2.2	3	4	6.4	6.077	10.128	No	DR004A0607	21
VFD037CP43B-21 VFD037CP4EB-21	3.7	5	6	9.6	4.05	6.75	No	DR006A0405	31
VFD040CP43A-21 VFD040CP4EA-21	4	5	9	14.4	2.7	4.5	No	DR009A0270	40
VFD055CP43B-21 VFD055CP4EB-21	5.5	7.5	10.5	16.8	2.315	3.858	No	DR010A0231	50
VFD075CP43B-21 VFD075CP4EB-21	7.5	10	12	19.2	2.025	3.375	No	DR012A0202	50
VFD110CP43B-21 VFD110CP4EB-21	11	15	18	28.8	1.35	2.25	No	DR018A0117	54
VFD150CP43B-21 VFD150CP4EB-21	15	20	24	38.4	1.01	1.683	No	DR024AP881	60
VFD185CP43B-21 VFD185CP4EB-21	18.5	25	32	51.2	0.76	1.267	No	DR032AP660	80
VFD220CP43A-21 VFD220CP4EA-21	22	30	38	60.8	0.639	1.065	No	DR038AP639	85
VFD300CP43B-21 VFD300CP4EB-21	30	40	45	72	0.541	0.902	No	DR045AP541	95
VFD370CP43B-21 VFD370CP4EB-21	37	50	60	96	0.405	0.675	No	DR060AP405	100
VFD450CP43S-00 VFD450CP43S-21	45	60	73	116.8	0.334	0.557	Yes	DR073AP334	115
VFD550CP43S-00 VFD550CP43S-21	55	75	91	145.6	0.267	0.445	Yes	DR091AP267	130
VFD750CP43B-00 VFD750CP43B-21	75	100	110	176	0.221	0.368	Yes	DR110AP221	150
VFD900CP43A-00 VFD900CP43A-21	90	125	150	240	0.162	0.27	Yes	DR150AP162	170

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Input AC Reactor Delta Part #	Heat Dissipation (W)
VFD1100CP43A-00 VFD1100CP43A-21	110	150	180	288	0.135	0.225	Yes	DR180AP135	190
VFD1320CP43B-00 VFD1320CP43B-21	132	175	220	352	0.11	0.183	Yes	DR220AP110	230
VFD1600CP43A-00 VFD1600CP43A-21	160	215	260	416	0.098	0.163	Yes	DR260AP098	280
VFD1850CP43B-00 VFD1850CP43B-21	185	250	310	496	0.078	0.13	Yes	DR310AP078	300
VFD2000CP43A-00 VFD2000CP43A-21	200	270	335	536	0.072	0.12	Yes	DR370AP066*1	340
VFD2200CP43A-00 VFD2200CP43A-21	220	300	370	592	0.066	0.11	Yes	DR370AP066	340
VFD2500CP43A-00 VFD2500CP43A-21	250	340	415	664	0.058	0.10	Yes	DR460AP054*1	400
VFD2800CP43A-00 VFD2800CP43A-21	280	375	460	736	0.054	0.09	Yes	DR460AP054	400
VFD3150CP43A-00 VFD3150CP43C-00 VFD3150CP43C-21	315	420	550	880	0.044	0.073	Yes	DR550AP044	430
VFD3550CP43A-00 VFD3550CP43C-00 VFD3550CP43C-21	355	475	616	985.6	0.039	0.065	Yes	DR616AP039	450
VFD4000CP43A-00 VFD4000CP43C-00 VFD4000CP43C-21	400	530	683	1092.8	0.036	0.06	Yes	DR683AP036	480
VFD5000CP43A-00 VFD5000CP43C-00 VFD5000CP43C-21	500	930	866	1385.6	0.028	0.047	Yes	DR866AP028	610
VFD5600CP43A-00 VFD5600CP43C-21	560	750	930	1488	0.026	0.043	Yes	Contact	Nolta
VFD6300CP43A-00 VFD6300CP43C-21	630	850	1094	1750.4	0.022	0.037	Yes	Contact D	<i>ਾ</i> ਦਾਪਿ

<sup>\*</sup>Note 1: The inductance value for the above applications of Delta's reactors will be closer, but less than 3%.

Table 7-22

#### 575 V, 50 / 60 Hz, Three-phase

			Rated Curre	ent (Arms)	Saturation	3% React	or (mH)	5% React	or (mH)
Model	kW	HP	Normal Duty	Light Duty	Current (Arms)	Normal Duty	Light Duty	Normal Duty	Light Duty
VFD015CP53A-21	1.5	2	2.5	3	4.2	10.567	8.806	17.612	14.677
VFD022CP53A-21	2.2	3	3.6	4.3	5.9	7.338	6.144	12.230	10.239
VFD037CP53A-21	3.7	5	5.5	6.7	9.1	4.803	3.943	8.005	6.572
VFD055CP53A-21	5.5	7.5	8.2	9.9	13.7	3.222	2.668	5.369	4.447
VFD075CP53A-21	7.5	10	10	12.1	16.5	2.642	2.183	4.403	3.639
VFD110CP53A-21	11	15	15.5	18.7	25.7	1.704	1.413	2.841	2.355
VFD150CP53A-21	15	20	20	24.2	33.3	1.321	1.092	2.201	1.819

Table 7-23


Note 2: The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

690V, 50 / 60 Hz, Three-phase


			Rated (Arı	Current ms)	Saturation (Arr	n Current ms)	3% Imp (m		5% Imp (m	
Model	kW	HP	Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty
VFD185CP63A-21	18.5	25	20	24	30.0	28.8	1.902	1.585	3.170	2.642
VFD220CP63A-21	22	30	24	30	36.0	36.0	1.585	1.268	2.642	2.113
VFD300CP63A-21	30	40	30	36	45.0	43.2	1.268	1.057	2.113	1.761
VFD370CP63A-21	37	50	36	45	54.0	54.0	1.057	0.845	1.761	1.409
VFD450CP63A-00/-21	45	60	45	54	67.5	64.8	0.845	0.704	1.409	1.174
VFD550CP63A-00/-21	55	75	54	67	81.0	80.4	0.704	0.568	1.174	0.946
VFD750CP63A-00/-21	75	100	67	86	100.5	103.2	0.568	0.442	0.946	0.737
VFD900CP63A-00/-21	90	125	86	104	129.0	124.8	0.442	0.366	0.737	0.610
VFD1100CP63A-00/-21	110	150	104	125	156.0	150.0	0.366	0.304	0.610	0.507
VFD1320CP63A-00/-21	132	175	125	150	187.5	180.0	0.304	0.254	0.507	0.423
VFD1600CP63A-00/-21	160	215	150	180	225.0	216.0	0.254	0.211	0.423	0.352
VFD2000CP63A-00/-21	200	270	180	220	270.0	264.0	0.211	0.173	0.352	0.288
VFD2500CP63A-00/-21	250	335	220	290	330.0	348.0	0.173	0.131	0.288	0.219
VFD3150CP63A-00/-21	315	425	290	350	435.0	420.0	0.131	0.109	0.219	0.181
VFD4000CP63A-00/-21	400	530	350	430	525.0	516.0	0.109	0.088	0.181	0.147
VFD4500CP63A-00/-21	450	600	385	465	577.5	558.0	0.099	0.082	0.165	0.136
VFD5600CP63A-00/-21	560	745	465	590	697.5	708.0	0.082	0.064	0.136	0.107
VFD6300CP63A-00/-21	630	850	675	675	1012.5	810.0	0.056	0.056	0.094	0.094


Table 7-24

#### AC input reactor dimension and specification:



Tightening torque: 6.1-8.2 kg-cm / [5.3-7.1 lb-in.] / [0.6-0.8 Nm]





Tightening torque: F Nm




Figure 7-7

Unit: mm

Input AC reactor Delta part #	А	В	С	D1*D2	E	G1	G2	PE D
DR005A0254	100	115	65	6*9	45	60	40	M4
DR008A0159	100	115	65	6*9	45	60	40	M4
DR011A0115	130	135	95	6*12	60	80.5	60	M4
DR017AP746	130	135	100	6*12	65	80.5	60	M4

Table 7-25




Figure 7-8

Input AC reactor Delta part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR025AP215	130	195	100	6*12	65	80.5	60	M4
DR033AP163	130	195	100	6*12	65	80.5	60	M4
DR049AP163	160	200	125	6*12	90	107	75	M4

Table 7-26




Figure 7-9

Input AC reactor Delta part #	Dimensions
DR065AP162	Refer to the diagram above

Table 7-27




Figure 7-10

Input AC reactor Delta part #	Dimensions
DR075AP170	Refer to the diagram above

Table 7-28




Figure 7-11

Input AC reactor Delta part #	Dimensions
DR090AP141	Refer to the diagram above

Table 7-29





Figure 7-12

Input AC reactor Delta part #	Dimensions
DR105AP106	Refer to the diagram above

Table 7-30



Input AC reactor Delta part #	Dimensions
DR146AP087	Refer to the diagram above

Table 7-31




Figure 7-14

Input AC reactor Delta part #	Dimensions
DR180AP070	Refer to the diagram above

Table 7-32




Figure 7-15

Input AC reactor Delta part #	Dimensions	
DR215AP059	Refer to the diagram above	

Table 7-33




Figure 7-16

Input AC reactor Delta part #	Dimensions
DR215AP059	Refer to the diagram above

Table 7-34




Figure 7-17

Input AC reactor Delta part #	Dimensions
DR346AP037	Refer to the diagram above

Table 7-35




Figure 7-18

Input AC reactor Delta part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003A0810	100	125	65	6*9	43	60	40	M4
DR004A0607	100	125	65	6*9	43	60	40	M4
DR006A0405	130	15	95	6*12	60	80.5	60	M4
DR009A0270	160	160	105	6*12	75	107	75	M4
DR010A0231	160	160	115	6*12	90	107	75	M4
DR012A0202	160	160	115	6*12	90	107	75	M4
DR018A0117	160	160	115	6*12	90	107	75	M4

Table 7-36




Figure 7-19 Unit: mm

Input AC reactor Delta part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR024AP881	160	175	115	6*12	90	107	75	M4
DR032AP660	195	200	145	6*12	115	122	85	M6
DR038AP639	190	200	145	6*12	115	122	85	M6
DR045AP541	190	200	145	6*12	115	122	85	M6

Table 7-37




Figure 7-20

Input AC reactor Delta part #	Dimensions
DR060AP405	Refer to the diagram above

Table 7-38




Figure 7-21

Input AC reactor Delta part #	Α	A1	В	B1	B2	С	D	D1*D2	E	C1	G1	G2	Н
DR073AP334	228	240	215	40	170	133	8.5	7*13	152	75	176	200	97
DR091AP267	228	240	245	40	195	133	8.8	7*13	152	90	176	200	97
DR110AP221	228	240	245	40	195	138	8.5	7*13	152	75	176	200	102

Table 7-39




Figure 7-22

Input AC reactor Delta part #	А	A1	В	B1	B2	С	C1	D	D1*D2	F	G1	G2	Н	M*T
DR150AP162	240	250	245	40	200	151	105	9	11*18	160	190	220	125	20*3
DR180AP135	240	250	245	40	200	151	105	9	11*18	160	190	220	125	20*3
DR220AP110	264	270	275	50	230	151	105	9	10*18	176	200	230	106	30*3
DR260AP098	264	270	285	50	240	151	105	9	10*18	176	200	230	106	30*3
DR310AP078	300	300	345	55	295	153	105	9	10*18	200	224	260	113	30*3
DR370AP066	300	300	345	55	295	158	120	9	10*18	200	224	260	118	50*4

Table 7-40




Figure 7-23


												O.	
Input AC reactor Delta part #	А	A1	В	B1	B2	С	C1	D1*D2	Е	G1	G2	Н	M*T
DR460AP054	300	300	425	95	355	220	170	11*21	200	240	300	190	50*4
DR550AP044	300	300	445	95	375	220	170	11*21	200	240	300	190	50*4
DR616AP039	360	360	465	105	385	252	190	11*21	240	246	316	220	50*5
DR683AP036	360	360	465	105	385	252	195	11*21	240	246	316	220	50*5
DR866AP028	360	360	520	105	435	272	200	11*21	240	246	316	240	60*6

#### **DC** Reactor

A DC reactor can also increase line impedance, improve the power factor, reduce input current, increase system power, and reduce interference generated from the motor drive. A DC reactor stabilizes the DC bus voltage. Compared with an AC input reactor, a DC reactor is in smaller size, lower price, and lower voltage drop (lower power dissipation)

#### Installation

Install a DC reactor between terminals +2/DC+ and +1/DC+. Remove the jumper, as shown in the figure below, before installing a DC reactor.



Specifications of DC reactors (standard item)

The following table shows the specifications of DC reactors (standard items) for Delta CP2000 series products.

200V-230V, 50 / 60 Hz

Model	kW	HP	Rated (		Satur Curi (Arı		DC Re		DC Reactor Delta Part #		
			Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty	
VFD007CP23A-21	0.75	1	4.6	5	7.36	6	6.366	5.857	DR005D0585*	DR005D0585	
VFD015CP23A-21	1.5	2	5	7.5	8	9	5.857	3.66	DR005D0585	DR008D0366	
VFD022CP23A-21	2.2	3	8	10	12.8	12	3.66	2.662	DR008D0366	DR011D0266	
VFD037CP23A-21	3.7	5	11	15	17.6	18	2.662	1.722	DR011D0266	DR017D0172	
VFD055CP23A-21	5.5	7.5	17	21	27.2	25.2	1.722	1.172	DR017D0172	DR025D0117	
VFD075CP23A-21	7.5	10	25	31	40	37.2	1.172	0.851	DR025D0117	DR033DP851	
VFD110CP23A-21	11	15	33	46	52.8	55.2	0.851	0.574	DR033DP851	DR049DP574	
VFD150CP23A-21	15	20	49	61	78.4	73.2	0.574	0.432	DR049DP574	DR065DP432	
VFD185CP23A-21	18.5	25	65	75	104	90	0.432	0.391	DR065DP432	DR075DP391	
VFD220CP23A-21	22	30	75	90	120	108	0.391	0.325	DR075DP391	DR090DP325	
VFD300CP23A-21	30	40	90	105	144	126	0.325	0.244	DR090DP325	Contact Delta	
*Note 1: Use with DR005D05	Note 1: Use with DR005D0585, but the inductance value will be 3% short.										

Table 7-42

# 380V-460V, 50 / 60 Hz

Model	kW	kW	kW	HP	Rated (	Current ms)	Satur Curi (Arr	rent		eactor H)	DC Re	
			Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty		
VFD007CP43A-21/4EA-21	0.75	1	2.8	3	4.48	3.6	20.918	18.709	DR003D1870*	DR003D1870		
VFD015CP43B-21/4EB-21	1.5	2	3	4.2	4.8	5.04	18.709	14.031	DR003D1870	DR004D1403		
VFD022CP43B-21/4EB-21	2.2	3	4	5.5	6.4	6.6	14.031	9.355	DR004D1403	DR006D0935		
VFD037CP43B-21/4EB-21	3.7	5	6	8.5	9.6	10.2	9.355	6.236	DR006D0935	DR009D0623		
VFD040CP43A-21/4EA-21	4	5	9	10.5	14.4	12.6	6.236	5.345	DR009D0623	DR010D0534		
VFD055CP43B-21/4EB-21	5.5	7.5	10.5	13	16.8	15.6	5.345	4.677	DR010D0534	DR012D0467		
VFD075CP43B-21/4EB-21	7.5	10	12	18	19.2	21.6	4.677	3.119	DR012D0467	DR018D0311		
VFD110CP43B-21/4EB-21	11	15	18	24	28.8	28.8	3.119	2.338	DR018D0311	DR024D0233		
VFD150CP43B-21/4EB-21	15	20	24	32	38.4	38.4	2.338	1.754	DR024D0233	DR032D0175		
VFD185CP43B-21/4EB-21	18.5	25	32	38	51.2	45.6	1.754	1.477	DR032D0175	DR038D0147		
VFD220CP43A-21/4EA-21	22	30	38	45	60.8	54	1.477	1.247	DR038D0147	DR045D0124		
VFD300CP43B-21/4EB-21	30	40	45	60	72	72	1.247	0.935	DR045D0124	DR060DP935		
VFD370CP43B-21/4EB-21	37	50	60	73	96	87.6	0.935	0.768	DR060DP935	Contact Delta		

\*Note 1: Use with DR003D1870, but the inductance value will be 3% short.

Table 7-43

# 575 V, 50 / 60 Hz, Three-phase

			Rated Curr	ent (Arms)	Saturation	DC Reactor (mH)	
Model	kW	HP	Normal Duty	Light Duty	Current (Arms)	Normal Duty	Light Duty
VFD015CP53A-21	1.5	2	2.5	3	4.2	29.284	24.404
VFD022CP53A-21	2.2	3	3.6	4.3	5.9	20.336	17.027
VFD037CP53A-21	3.7	5	5.5	6.7	9.1	13.310	10.927
VFD055CP53A-21	5.5	7.5	8.2	9.9	13.7	8.929	7.394
VFD075CP53A-21	7.5	10	10	12.1	16.5	7.322	6.050
VFD110CP53A-21	11	15	15.5	18.7	25.7	4.722	3.916
VFD150CP53A-21	15	20	20	24.2	33.3	3.661	3.026

Table 7-44

#### 690V. 50 / 60 Hz. Three-phase

			Rated Curr	ent (Arms)	Saturation Co	urrent (Arms)	DC Read	tor (mH)
Model	kW	HP	Normal	Light	Normal	Light	Normal	Light
			Duty	Duty	Duty	Duty	Duty	Duty
VFD185CP63A-21	18.5	25	20	24	30.0	28.8	4.392	3.660
VFD220CP63A-21	22	30	24	30	36.0	36.0	3.660	2.928
VFD300CP63A-21	30	40	30	36	45.0	43.2	2.928	2.441
VFD370CP63A-21	37	50	36	45	54.0	54.0	2.441	1.951
VFD450CP63A-00/-21	45	60	45	54	67.5	64.8	1.951	1.626
VFD550CP63A-00/-21	55	75	54	67	81.0	80.4	1.626	1.312
VFD750CP63A-00/-21	75	100	67	86	100.5	103.2	1.312	1.021
VFD900CP63A-00/-21	90	125	86	104	129.0	124.8	1.021	0.845
VFD1100CP63A-00/-21	110	150	104	125	156.0	150.0	0.845	0.702
VFD1320CP63A-00/-21	132	175	125	150	187.5	180.0	0.702	0.587
VFD1600CP63A-00/-21	160	215	150	180	225.0	216.0	0.587	0.487

## Chapter 7 Optional Accessories | CP2000

			Rated Curr	rent (Arms)	Saturation Co	urrent (Arms)	DC Read	ctor (mH)
Model	kW	HP	Normal	Light	Normal	Light	Normal	Light
			Duty	Duty	Duty	Duty	Duty	Duty
VFD2000CP63A-00/-21	200	270	180	220	270.0	264.0	0.487	0.400
VFD2500CP63A-00/-21	250	335	220	290	330.0	348.0	0.400	0.303
VFD3150CP63A-00/-21	315	425	290	350	435.0	420.0	0.303	0.252
VFD4000CP63A-00/-21	400	530	350	430	525.0	516.0	0.252	0.203
VFD4500CP63A-00/-21	450	600	385	465	577.5	558.0	0.229	0.189
VFD5600CP63A-00/-21	560	745	465	590	697.5	708.0	0.189	0.148
VFD6300CP63A-00/-21	630	850	675	675	1012.5	810.0	0.129	0.129

Table 7-45

# DC reactor dimension and specification:




Figure 7-25

DC reactor	Α .	В	С	D	E	Dimensions [mm]
Delta part #	[mm)	[mm]	[mm]	[mm]	[mm]	Billionelene [min]
DR005D0585	79	78	112	64 ± 2	56 ± 2	9.5*5.5
DR008D0366	79	78	112	64 ± 2	56 ± 2	9.5*5.5
DR011D0266	79	92	112	64 ± 2	69.5 ± 2	9.5*5.5
DR017D0172	79	112	112	64 ± 2	89.5 ± 2	9.5*5.5
DR025D0117	99	105	128	79 ± 2	82.5 ± 2	9.5*5.5
DR033DP851	117	110	156	95 ± 2	87 ± 2	10*6.5
DR049DP574	117	120	157	95 ± 2	97 ± 2	10*6.5
DR065DP432	117	140	157	95 ± 2	116.5 ± 2	10*6.5
DR075DP391	136	135	178	111 ± 2	112 ± 2	10*6.5
DR090DP325	136	135	179	111 ± 2	112 ± 2	10*6.5
DR003D1870	79	78	112	64 ± 2	56 ± 2	9.5*5.5
DR004D1403	79	92	112	64 ± 2	69.5 ± 2	9.5*5.5
DR006D0935	79	92	112	64 ± 2	69.5 ± 2	9.5*5.5
DR009D0623	79	112	112	64 ± 2	89.5 ± 2	9.5*5.5
DR010D0534	99	93	128	79 ± 2	70 ± 2	9.5*5.5
DR012D0467	99	105	128	79 ± 2	82.5 ± 2	9.5*5.5
DR018D0311	117	110	144	95 ± 2	87 ± 2	10*6.5
DR024D0233	117	120	144	95 ± 2	97 ± 2	10*6.5
DR032D0175	117	140	157	95 ± 2	116.5 ± 2	10*6.5
DR038D0147	136	135	172	111 ± 2	112 ± 2	10*6.5
DR045D0124	136	135	173	111 ± 2	112 ± 2	10*6.5
DR060DP935	136	150	173	111 ± 2	127 ± 2	10*6.5

Table 7-46

The table below shows the THDi specification when using Delta's drives to work with AC/DC reactors:

	M	odels without B	Built-in DC Read	ctor	Model	ls with Built-in D	C Reactor					
Current Harmonic	No AC/DC Reactor	3% Input AC Reactor	5% Input AC Reactor	4% DC Reactor	No Input AC Reactor	3% Input AC Reactor	5% Input AC Reactor					
5 <sup>th</sup>	73.3%	38.5%	30.8%	25.5%	31.16%	27.01%	25.5%					
7 <sup>th</sup>	52.74%	15.3%	9.4%	18.6%	23.18%	9.54%	8.75%					
11 <sup>th</sup>	7.28%	7.1%	6.13%	7.14%	8.6%	4.5%	4.2%					
13 <sup>th</sup>	0.4%	3.75%	3.15%	0.48%	7.9%	0.22%	0.17%					
THDi	91%	43.6%	34.33%	38.2%	42.28%	30.5%	28.4%					
Note	•	The THDi specification listed here may be slightly different from the actual THDi, depending on the installation and environmental conditions (wires, motors).										

**Table 7-47** 


# **AC Output Reactor**

When using drives in long wiring output application, ground fault (GFF), over-current (oc) and motor over-voltage (ov) often occur. GFF and OC cause errors due to the drive's self-protective mechanism; over-voltage damages motor insulation.

The excessive length of the output wires makes the grounded stray capacitance too large, increase the three-phase output common mode current, and the reflected wave of the long wires makes the motor dv / dt and the motor terminal voltage too high. Thus, installing a reactor on the drive's output side can increase the high-frequency impedance to reduce the dv / dt and terminal voltage to protect the motor.

#### Installation

Install an AC output reactor in series between the three output phases U V W and the motor, as shown in the figure below:



Wiring of AC output reactor

Figure 7-26

Specifications of AC output reactors (standard item)

Following tables show the standard AC output reactors specification of Delta CP2000:

200V-230V, 50 / 60 Hz, Light Duty

			Rated	Saturation	3%	5%	Built-in	Output AC	Heat
Model	kW	HP	Current	Current	Reactor	Reactor	DC Reactor	Reactor Delta	Dissipation
			(Arms)	(Arms)	(mH)	(mH)	DC Reactor	Part #	(W)
VFD007CP23A-21	0.75	1	5	6	2.536	4.227	No	DR005L0254	15
VFD015CP23A-21	1.5	2	7.5	9	1.585	2.642	No	DR008L0159	30
VFD022CP23A-21	2.2	3	10	12	1.152	1.92	No	DR011L0115	33
VFD037CP23A-21	3.7	5	15	18	0.746	1.243	No	DR017LP746	34
VFD055CP23A-21	5.5	7.5	21	25.2	0.507	0.845	No	DR025LP507	50
VFD075CP23A-21	7.5	10	31	37.2	0.38	0.633	No	DR033LP320	50
VFD110CP23A-21	11	15	46	55.2	0.26	0.433	No	DR049LP215	62
VFD150CP23A-21	15	20	61	73.2	0.196	0.327	No	DR065LP162	70
VFD185CP23A-21	18.5	25	75	90	0.169	0.282	No	DR075LP170	80
VFD220CP23A-21	22	30	90	108	0.141	0.235	No	DR090LP141	80
VFD300CP23A-21	30	40	105	126	0.12	0.2	No	DR105LP106	95
VFD370CP23A-00	37	50	146	175.2	0.087	0.145	Yes	DR146LP087	110
VFD370CP23A-21	31	50	140	175.2	0.067	0.145	168	DK 140LF001	110
VFD450CP23A-00	45	60	180	216	0.07	0.117	Yes	DR180LP070	125
VFD450CP23A-21	43	00	100	210	0.07	0.117	165	DICTOOLFUTO	123
VFD550CP23A-00	55	75	215	258	0.059	0.098	Yes	DR215LP059	150
VFD550CP23A-21	33	73	210	230	0.009	0.090	163	DIV2 13L1 039	150
VFD750CP23A-00	75	100	276	331.2	0.049	0.082	Yes	DR276LP049	210
VFD750CP23A-21	73	100	210	301.2	0.048	0.002	162	DIX210LF049	210
VFD900CP23A-00	90	125	322	386.4	0.037	0.062	Yes	DR346LP037	220
VFD900CP23A-21	30	120	522	300.4	0.001	0.002	165	DINO-OLI 001	220

Table 7-48

## 200V-230V, 50 / 60 Hz, Normal Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Heat Dissipation (W)
VFD007CP23A-21	0.75	1	4.6	7.36	2.536	4.227	No	DR005L0254	15
VFD015CP23A-21	1.5	2	5	8	2.536	4.227	No	DR005L0254	15
VFD022CP23A-21	2.2	3	8	12.8	1.585	2.642	No	DR008L0159	30
VFD037CP23A-21	3.7	5	11	17.6	1.152	1.92	No	DR011L0115	33
VFD055CP23A-21	5.5	7.5	17	27.2	0.746	1.243	No	DR017LP746	34
VFD075CP23A-21	7.5	10	25	40	0.507	0.845	No	DR025LP507	50
VFD110CP23A-21	11	15	33	52.8	0.38	0.633	No	DR033LP320	50
VFD150CP23A-21	15	20	49	78.4	0.26	0.433	No	DR049LP215	62
VFD185CP23A-21	18.5	25	65	104	0.196	0.327	No	DR065LP162	70
VFD220CP23A-21	22	30	75	120	0.169	0.282	No	DR075LP170	80
VFD300CP23A-21	30	40	90	144	0.141	0.235	No	DR090LP141	80
VFD370CP23A-00 VFD370CP23A-21	37	50	120	192	0.12	0.2	Yes	DR105LP106	95
VFD450CP23A-00 VFD450CP23A-21	45	60	146	233.6	0.087	0.145	Yes	DR146LP087	110
VFD550CP23A-00 VFD550CP23A-21	55	75	180	288	0.07	0.117	Yes	DR180LP070	125
VFD750CP23A-00 VFD750CP23A-21	75	100	215	344	0.059	0.098	Yes	DR215LP059	150
VFD900CP23A-00 VFD900CP23A-21	90	125	255	408	0.049	0.082	Yes	DR276LP049	210

380V-460V, 50 / 60 Hz, Light Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Heat Dissipation (W)
VFD007CP43A-21 VFD007CP4EA-21	0.75	1	3	3.6	8.102	13.503	No	DR003L0810	13
VFD015CP43B-21 VFD015CP4EB-21	1.5	2	4.2	5.04	6.077	10.128	No	DR004L0607	18
VFD022CP43B-21 VFD022CP4EB-21	2.2	3	5.5	6.6	4.050	6.75	No	DR006L0405	22
VFD037CP43B-21 VFD037CP4EB-21	3.7	5	8.5	10.2	2.700	4.5	No	DR009L0270	35
VFD040CP43A-21 VFD040CP4EA-21	4	5	10.5	12.6	2.315	3.858	No	DR010L0231	40
VFD055CP43B-21 VFD055CP4EB-21	5.5	7.5	13	15.6	2.025	3.375	No	DR012L0202	45
VFD075CP43B-21 VFD075CP4EB-21	7.5	10	18	21.6	1.35	2.25	No	DR018L0117	48
VFD110CP43B-21 VFD110CP4EB-21	11	15	24	28.8	1.01	1.683	No	DR024LP881	52
VFD150CP43B-21 VFD150CP4EB-21	15	20	32	38.4	0.76	1.267	No	DR032LP660	66
VFD185CP43B-21 VFD185CP4EB-21	18.5	25	38	45.6	0.639	1.065	No	DR038LP639	70
VFD220CP43A-21 VFD220CP4EA-21	22	30	45	54	0.541	0.902	No	DR045LP541	85
VFD300CP43B-21 VFD300CP4EB-21	30	40	60	72	0.405	0.675	No	DR060LP405	85
VFD370CP43B-21 VFD370CP4EB-21	37	50	73	87.6	0.334	0.557	No	DR073LP334	110
VFD450CP43S-00 VFD450CP43S-21	45	60	91	109.2	0.267	0.445	Yes	DR091LP267	130
VFD550CP43S-00 VFD550CP43S-21	55	75	110	132	0.221	0.368	Yes	DR110LP221	150
VFD750CP43B-00 VFD750CP43B-21	75	100	150	180	0.162	0.27	Yes	DR150LP162	175
VFD900CP43A-00 VFD900CP43A-21	90	125	180	216	0.135	0.225	Yes	DR180LP135	195
VFD1100CP43A-00 VFD1100CP43A-21	110	150	220	264	0.110	0.183	Yes	DR220LP110	235
VFD1320CP43B-00 VFD1320CP43B-21	132	175	260	312	0.098	0.163	Yes	DR260LP098	285
VFD1600CP43A-00 VFD1600CP43A-21	160	215	310	372	0.078	0.13	Yes	DR310LP078	300
VFD1850CP43B-00 VFD1850CP43B-21	185	250	370	444	0.066	0.11	Yes	DR370LP066	345
VFD2000CP43A-00 VFD2000CP43A-21	200	270	395	474	0.061	0.1	Yes	DR370LP066*1	410
VFD2200CP43A-00 VFD2200CP43A-21	220	300	460	552	0.054	0.09	Yes	DR460LP054	410
VFD2500CP43A-00 VFD2500CP43A-21	250	340	481	578	0.052	0.086	Yes	DR460LP054*1	440

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Heat Dissipation (W)
VFD2800CP43A-00 VFD2800CP43A-21	280	375	530	636	0.044	0.073	Yes	DR550LP044	440
VFD3150CP43A-00 VFD3150CP43C-00 VFD3150CP43C-21	315	420	616	739.2	0.039	0.065	Yes	DR616LP039	465
VFD3550CP43A-00 VFD3550CP43C-00 VFD3550CP43C-21	355	475	683	819.6	0.036	0.06	Yes	DR683LP036	495
VFD4000CP43A-00 VFD4000CP43C-00 VFD4000CP43C-21	400	530	770	924	0.028	0.047	Yes	DR866LP028	600
VFD5000CP43A-00 VFD5000CP43C-00 VFD5000CP43C-21	500	675	912	1094.4	0.028	0.047	Yes	DR866LP028	600
VFD5600CP43A-00 VFD5600CP43C-21	560	650	1094	1318.2	0.022	0.037	Yes	0	N = 14 =
VFD6300CP43A-00 VFD6300CP43C-21	630	760	1212	1454.4	0.020	0.033	Yes	Contact D	Jeita

<sup>\*</sup>Note 1: The inductance value for the above applications of Delta's reactors will be closer, but less than 3%.

Table 7-50

# 380V-460V, 50 / 60 Hz, Normal Duty

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Heat Dissipation (W)
VFD007CP43A-21 VFD007CP4EA-21	0.75	1	2.8	4.48	9.058	15.097	No	DR003L0810*1	13
VFD015CP43B-21 VFD015CP4EB-21	1.5	2	3	4.8	8.102	13.503	No	DR003L0810	13
VFD022CP43B-21 VFD022CP4EB-21	2.2	3	4	6.4	6.077	10.128	No	DR004L0607	18
VFD037CP43B-21 VFD037CP4EB-21	3.7	5	6	9.6	4.050	6.75	No	DR006L0405	22
VFD040CP43A-21 VFD040CP4EA-21	4	5	9	14.4	2.700	4.5	No	DR009L0270	35
VFD055CP43B-21 VFD055CP4EB-21	5.5	7.5	10.5	16.8	2.315	3.858	No	DR010L0231	40
VFD075CP43B-21 VFD075CP4EB-21	7.5	10	12	19.2	2.025	3.375	No	DR012L0202	45
VFD110CP43B-21 VFD110CP4EB-21	11	15	18	28.8	1.35	2.25	No	DR018L0117	48
VFD150CP43B-21 VFD150CP4EB-21	15	20	24	38.4	1.01	1.683	No	DR024LP881	52
VFD185CP43B-21 VFD185CP4EB-21	18.5	25	32	51.2	0.76	1.267	No	DR032LP660	66
VFD220CP43A-21 VFD220CP4EA-21	22	30	38	60.8	0.639	1.065	No	DR038LP639	70
VFD300CP43B-21 VFD300CP4EB-21	30	40	45	72	0.541	0.902	No	DR045LP541	85

Note 2: The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

#### Chapter 7 Optional Accessories | CP2000

Model	kW	HP	Rated Current (Arms)	Saturation Current (Arms)	3% Reactor (mH)	5% Reactor (mH)	Built-in DC Reactor	Output AC Reactor Delta Part #	Heat Dissipation (W)
VFD370CP43B-21 VFD370CP4EB-21	37	50	60	96	0.405	0.675	No	DR060LP405	85
VFD450CP43S-00 VFD450CP43S-21	45	60	73	116.8	0.334	0.557	Yes	DR073LP334	110
VFD550CP43S-00 VFD550CP43S-21	55	75	91	145.6	0.267	0.445	Yes	DR091LP267	130
VFD750CP43B-00 VFD750CP43B-21	75	100	110	176	0.221	0.368	Yes	DR110LP221	150
VFD900CP43A-00 VFD900CP43A-21	90	125	150	240	0.162	0.27	Yes	DR150LP162	175
VFD1100CP43A-00 VFD1100CP43A-21	110	150	180	288	0.135	0.225	Yes	DR180LP135	195
VFD1320CP43B-00 VFD1320CP43B-21	132	175	220	352	0.110	0.183	Yes	DR220LP110	235
VFD1600CP43A-00 VFD1600CP43A-21	160	215	260	416	0.098	0.163	Yes	DR260LP098	285
VFD1850CP43B-00 VFD1850CP43B-21	185	250	310	496	0.078	0.13	Yes	DR310LP078	300
VFD2000CP43A-00 VFD2000CP43A-21	200	270	335	536	0.072	0.12	Yes	DR370LP066*1	345
VFD2200CP43A-00 VFD2200CP43A-21	220	300	370	592	0.066	0.11	Yes	DR370LP066	345
VFD2500CP43A-00 VFD2500CP43A-21	250	340	415	664	0.058	0.10	Yes	DR460LP054*1	410
VFD2800CP43A-00 VFD2800CP43A-21	280	375	460	736	0.054	0.09	Yes	DR460LP054	410
VFD3150CP43A-00 VFD3150CP43C-00 VFD3150CP43C-21	315	420	550	880	0.044	0.073	Yes	DR550LP044	440
VFD3550CP43A-00 VFD3550CP43C-00 VFD3550CP43C-21	355	475	616	985.6	0.039	0.065	Yes	DR616LP039	465
VFD4000CP43A-00 VFD4000CP43C-00 VFD4000CP43C-21	400	530	683	1092.8	0.036	0.06	Yes	DR683LP036	495
VFD5000CP43A-00 VFD5000CP43C-00 VFD5000CP43C-21	500	675	866	1385.6	0.028	0.047	Yes	DR866LP028	600
VFD5600CP43A-00 VFD5600CP43C-21	560	650	930	1488	0.026	0.043	Yes	0	) alta
VFD6300CP43A-00 VFD6300CP43C-21	630	760	1094	1750.4	0.022	0.037	Yes	Contact D	репа

<sup>\*</sup>Note 1: The inductance value for the above applications of Delta's reactors will be closer, but less than 3%.

Note 2: The above heat dissipation is calculated based on AC reactor's rated current; the actual dissipation varies with the operation current.

575V, 50 / 60 Hz, Three-phase


			Rated Curi	rent (Arms)	Saturation	3% Read	ctor (mH)	5% Reactor (mH)		
Model	kW	HP	Normal Duty	Light Duty	Current (Arms)	Normal Duty	Light Duty	Normal Duty	Light Duty	
VFD015CP53A-21	1.5	2	2.5	3	4.2	10.567	8.806	17.612	14.677	
VFD022CP53A-21	2.2	3	3.6	4.3	5.9	7.338	6.144	12.230	10.239	
VFD037CP53A-21	3.7	5	5.5	6.7	9.1	4.803	3.943	8.005	6.572	
VFD055CP53A-21	5.5	7.5	8.2	9.9	13.7	3.222	2.668	5.369	4.447	
VFD075CP53A-21	7.5	10	10	12.1	16.5	2.642	2.183	4.403	3.639	
VFD110CP53A-21	11	15	15.5	18.7	25.7	1.704	1.413	2.841	2.355	
VFD150CP53A-21	15	20	20	24.2	33.3	1.321	1.092	2.201	1.819	

Table 7-52

# 690V, 50 / 60 Hz, Three-phase


Model	kW HP			Rated Current (Arms)		n Current ms)	• • • • • • • • • • • • • • • • • • • •	eactor ıH)	5% Reactor (mH)	
Wodel	KVV		Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty	Normal Duty	Light Duty
VFD185CP63A-21	18.5	25	20	24	30.0	28.8	1.902	1.585	3.170	2.642
VFD220CP63A-21	22	30	24	30	36.0	36.0	1.585	1.268	2.642	2.113
VFD300CP63A-21	30	40	30	36	45.0	43.2	1.268	1.057	2.113	1.761
VFD370CP63A-21	37	50	36	45	54.0	54.0	1.057	0.845	1.761	1.409
VFD450CP63A-00/-21	45	60	45	54	67.5	64.8	0.845	0.704	1.409	1.174
VFD550CP63A-00/-21	55	75	54	67	81.0	80.4	0.704	0.568	1.174	0.946
VFD750CP63A-00/-21	75	100	67	86	100.5	103.2	0.568	0.442	0.946	0.737
VFD900CP63A-00/-21	90	125	86	104	129.0	124.8	0.442	0.366	0.737	0.610
VFD1100CP63A-00/-21	110	150	104	125	156.0	150.0	0.366	0.304	0.610	0.507
VFD1320CP63A-00/-21	132	175	125	150	187.5	180.0	0.304	0.254	0.507	0.423
VFD1600CP63A-00/-21	160	215	150	180	225.0	216.0	0.254	0.211	0.423	0.352
VFD2000CP63A-00/-21	200	270	180	220	270.0	264.0	0.211	0.173	0.352	0.288
VFD2500CP63A-00/-21	250	335	220	290	330.0	348.0	0.173	0.131	0.288	0.219
VFD3150CP63A-00/-21	315	425	290	350	435.0	420.0	0.131	0.109	0.219	0.181
VFD4000CP63A-00/-21	400	530	350	430	525.0	516.0	0.109	0.088	0.181	0.147
VFD4500CP63A-00/-21	450	600	385	465	577.5	558.0	0.099	0.082	0.165	0.136
VFD5600CP63A-00/-21	560	745	465	590	697.5	708.0	0.082	0.064	0.136	0.107
VFD6300CP63A-00/-21	630	850	675	675	1012.5	810.0	0.056	0.056	0.094	0.094

AC output reactor dimensions and specification:



Torque: 6.1-8.2 kg-cm / [5.3-7.1 lb-in] / [0.6-0.8 Nm]

0



В






Figure 7-27


Output AC Reactor Delta Part #	А	В	С	D1*D2	E	G1	G2	PE D
DR005L0254	96	110	70	6*9	42	60	40	M4
DR008L0159	120	135	96	6*12	60	80.5	60	M4
DR011L0115	120	135	96	6*12	60	80.5	60	M4
DR017LP746	120	135	105	6*12	65	80.5	60	M4
DR025LP507	150	160	120	6*12	88	107	75	M4
DR033LP320	150	160	120	6*12	88	107	75	M4


Table 7-54





Terminals: 16 mm<sup>2</sup> Tightening torque: 1.2–1.4 Nm





Output AC Reactor Delta Part #	А	В	С	D1*D2	Н	G	G1	Q	М	PE D
DR049LP215	180	205	175	6*12	115	85	122	16	1.2–1.4	M4
DR065LP162	180	215	185	6*12	115	85	122	35	2.5–3.0	M4

Table 7-55





Figure 7-29 Unit: mm

Output AC Reactor Delta Part #	А	A1	В	B1	B2	С	C1	D1*D2	Е	G1	Н	M*T
DR075LP170	240	228	215	44	170	151	100	7*13	152	176	85	20*3
DR090LP141	240	228	215	44	170	151	100	7*13	152	176	85	20*3
DR105LP106	240	228	215	44	170	165	110	7*13	152	176	97	20*3
DR146LP087	240	228	240	45	202	165	110	7*13	152	176	97	30*3
DR180LP070	250	240	250	46	205	175	110	11*18	160	190	124	30*5
DR215LP059	250	240	275	51	226	180	120	11*18	160	190	124	30*5



**E±**5

**M±**0.5






Figure 7-30


Output AC Reactor Delta Part #	Α	A1	В	B1	B2	С	C1	D1*D2	Е	Н	M*T
DR276LP049	270	260	320	50	265	200	140	10*18	176	106	30*5
DR346LP037	270	265	340	50	285	200	140	10*18	176	106	30*5

Table 7-57



Torque: 6.1–8.2 kg-cm / [5.3–7.1 lb-in] / [0.6–0.8 Nm]










Figure 7-31 Unit: mm


								<u> </u>
Output AC Reactor Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR003L0810	96	115	65	6*9	42	60	40	M4
DR004L0607	120	135	95	6*12	60	80.5	60	M4
DR006L0405	120	135	95	6*12	60	80.5	60	M4
DR009L0270	150	160	100	6*12	74	107	75	M4
DR010L0231	150	160	115	6*12	88	107	75	M4
DR012L0202	150	160	115	6*12	88	107	75	M4
DR018L0117	150	160	115	6*12	88	107	75	M4
DR024LP881	150	160	115	6*12	88	107	75	M4
DR032LP660	180	190	145	6*12	114	122	85	M6

Table 7-58





Terminals: 16 mm<sup>2</sup>
Tightening torque: 1.2–1.4 Nm






Figure 7-32

Output AC Reactor  Delta Part #	А	В	С	D1*D2	Н	G1	G2	PE D
DR038LP639	180	205	170	6*12	115	85	122	M4
DR045LP541	235	245	155	7*13	85	1	176	M6

Table 7-59




Figure 7-33

Output AC Reactor Delta Part #	А	A1	В	B1	B2	С	C1	D1*D2	Е	G1	Н	M*T
DR060LP405	240	228	215	44	170	163	110	7*13	152	176	97	20*3
DR073LP334	250	235	235	44	186	174	115	11*18	160	190	124	20*3
DR091LP267	250	240	235	44	186	174	115	11*18	160	190	124	20*3
DR110LP221	270	260	245	50	192	175	115	10*18	176	200	106	20*3

Table 7-60




Figure 7-34

	1	1	1		1	1	1						
Output AC Reactor Delta Part #	Α	A1	В	B1	B2	С	C1	D1*D2	Е	G1	G2	Η	M*T
DR150LP162	270	264	265	51	208	192	125	10*18	176	200	/	118	30*3
DR180LP135	300	295	310	55	246	195	125	11*22	200	230	190	142	30*3
DR220LP110	300	298	310	57	248	210	140	11*22	200	230	190	142	30*5
DR260LP098	300	295	330	56	270	227	140	11*22	200	230	190	160	30*5
DR310LP078	300	298	350	54	288	233	145	11*22	200	230	190	160	30*5
DR370LP066	300	298	350	54	289	268	170	11*22	200	230	190	185	40*5

Table 7-61

## Chapter 7 Optional Accessories | CP2000




Figure 7-35

Output AC Reactor	Α	A1	В	B1	B2	С	C1	D1*D2	E	G1	Н	M*T
Delta Part #	A	Αı	ם	ы	DZ	C	Ci	שלו וע		Gi	П	IVI I
DR460LP054	360	355	510	106	401	346	215	12*20	240	240	240	50*5
DR550LP044	360	355	510	106	401	358	220	12*20	240	240	250	50*5
DR616LP039	360	355	510	110	401	376	230	12*20	240	240	270	50*8
DR683LP036	360	355	510	110	401	396	240	12*20	240	240	290	50*8
DR866LP028	410	418	570	120	464	402	245	12*20	280	280	290	50*8

Table 7-62

#### **Motor Cable Length**

#### Consequence of leakage current on the motor

If the cable length is too long, the stray capacitance between cables increases an may cause leakage current. In this case, it activates the over-current protection, increases leakage current, or may affect the current display. The worst case is that it may damage the AC motor drive. If more than one motor is connected to one AC motor drive, the total wiring length should be the sum of the wiring length from AC motor drive to each motor.

For the 460V models AC motor drives, when you install an overload thermal relay between the drive and the motor to protect the motor from overheating, the connecting cable must be shorter than 50m, however, an overload thermal relay malfunction may still occur. To prevent the malfunction, install an output reactor (optional) to the drive or lower the carrier frequency setting (see Pr.00-17 Carrier Frequency).

## 2. Consequence of the surge voltage on the motor

When a motor is driven by a PWM-type AC motor drive, the motor terminals experience surge voltages (dv/dt) due to power transistor conversion of AC motor drive. When the motor cable is very long (especially for the 460V models), surge voltages (dv/dt) may damage the motor insulation and bearing. To prevent this, follow these rules:

- a. Use a motor with enhanced insulation.
- b. Reduce the cable length between the AC motor drive and motor to suggested values.
- c. Connect an output reactor (optional) to the output terminals of the AC motor drive.

Refer to the following tables for the suggested motor shielded cable length. For drive models < 490V, use a motor with a rated voltage  $\leq$  500 V<sub>AC</sub> and an insulation level  $\geq$  1.35 kV in accordance with IEC 60034-17.

2201			Rated (	Current ms)		an AC Output eactor	With an AC Output Reactor		
230V Model	kW	HP	Normal Duty (ND)	Light Duty (LD)	Shielded Cable [meter]	Non-shielded Cable [meter]	Shielded Cable [meter]	Non-shielded Cable [meter]	
VFD007CP23A-21	0.75	1	4.6	5	50	75	75	115	
VFD015CP23A-21	1.5	2	5	7.5	50	75	75	115	
VFD022CP23A-21	2.2	3	8	10	50	75	75	115	
VFD037CP23A-21	3.7	5	11	15	50	75	75	115	
VFD055CP23A-21	5.5	7.5	17	21	100	150	150	225	
VFD075CP23A-21	7.5	10	25	31	100	150	150	225	
VFD110CP23A-21	11	15	33	46	100	150	150	225	
VFD150CP23A-21	15	20	49	61	100	150	150	225	
VFD185CP23A-21	18.5	25	65	75	100	150	150	225	
VFD220CP23A-21	22	30	75	90	100	150	150	225	
VFD300CP23A-21	30	40	90	120	100	150	150	225	
VFD370CP23A-00/-21	37	50	120	146	100	150	150	225	
VFD450CP23A-00/-21	45	60	146	180	150	225	225	325	
VFD550CP23A-00/-21	55	75	180	215	150	225	225	325	
VFD750CP23A-00/-21	75	100	215	276	150	225	225	325	
VFD900CP23A-00/-21	90	125	255	322	150	225	225	325	

## Chapter 7 Optional Accessories | CP2000

460V			Rated (	_		an AC Output eactor	With an AC	Output Reactor
Model	kW	HP	Normal Duty (ND)	Light Duty (LD)	Shielded Cable [meter]	Non-shielded Cable [meter]	Shielded Cable [meter]	Non-shielded Cable [meter]
VFD007CP43A-21/4EA-21	0.75	1	1.7	3	50	75	75	115
VFD015CP43B-21/4EB-21	1.5	2	3	4.2	50	75	75	115
VFD022CP43B-21/4EB-21	2.2	3	4	5.5	50	75	75	115
VFD037CP43B-21/4EB-21	3.7	5	6	8.5	50	75	75	115
VFD040CP43A-21/4EA-21	4	5	9	10.5	50	75	75	115
VFD055CP43B-21/4EB-21	5.5	7.5	10.5	13	50	75	75	115
VFD075CP43B-21/4EB-21	7.5	10	12	18	100	150	150	225
VFD110CP43B-21/4EB-21	11	15	18	24	100	150	150	225
VFD150CP43B-21/4EB-21	15	20	24	32	100	150	150	225
VFD185CP43B-21/4EB-21	18.5	25	32	38	100	150	150	225
VFD220CP43A-21/4EA-21	22	30	38	45	100	150	150	225
VFD300CP43B-21/4EB-21	30	40	45	60	100	150	150	225
VFD370CP43B-21/4EB-21	37	50	60	73	100	150	150	225
VFD450CP43S-00/43S-21	45	60	73	91	150	225	225	325
VFD550CP43S-00/43S-21	55	75	91	110	150	225	225	325
VFD750CP43B-00/43B-21	75	100	110	150	150	225	225	325
VFD900CP43A-00/43A-21	90	125	150	180	150	225	225	325
VFD1100CP43A-00/43A-21	110	150	180	220	150	225	225	325
VFD1320CP43B-00/43B-21	132	175	220	260	150	225	225	325
VFD1600CP43A-00/43A-21	160	215	260	310	150	225	225	325
VFD1850CP43B-00/43B-21	185	250	310	370	150	225	225	325
VFD2000CP43A-00/43A-21	200	270	335	395	150	225	225	325
VFD2200CP43A-00/43A-21	220	300	370	460	150	225	225	325
VFD2500CP43A-00/43A-21	250	340	415	481	150	225	225	325
VFD2800CP43A-00/43A-21	280	375	460	530	150	225	225	325
VFD3150CP43A-00/ VFD3150CP43C-00/-21	315	420	550	616	150	225	225	325
VFD3550CP43A-00/ VFD3550CP43C-00/-21	355	475	616	683	150	225	225	325
VFD4000CP43A-00/ VFD4000CP43C-00/-21	400	536	683	770	150	225	225	325
VFD5000CP43A-00/ VFD5000CP43C-00/-21	500	675	866	912	150	225	225	325
VFD5600CP43A-00/43C-21	560	650	930	1094	150	225	225	325
VFD6300CP43A-00/43C-21	630	750	1094	1212	150	225	225	325

Table 7-64


575\/	575V LW LIB		Rated current	Without an AC	Output Reactor	With an AC Output Reactor		
Model	kW	HP	(Arms) Normal Duty	Shielded Cable [meter]	Non-shielded cable [meter]	Shielded Cable [meter]	Non-shielded cable [meter]	
VFD015CP53A-21	0.75	1	2.5	35	30	45	20	
VFD022CP53A-21	1.5	2	3.6	35	30	45	20	
VFD037CP53A-21	2.2	3	5.5	35	30	45	20	
VFD055CP53A-21	3.7	5	8.2	35	30	45	20	
VFD075CP53A-21	5.5	7.5	10	35	30	45	20	
VFD110CP53A-21	7.5	10	15.5	35	30	45	20	
VFD150CP53A-21	11	15	20	35	30	45	20	

			Rated current	Without an AC	output reactor	With an AC o	output reactor
690V Model	kW	HP	(Arms)	Shielded Cable			Non-shielded
			Normal Duty	[meter]	cable [meter]	Cable [meter]	cable [meter]
VFD185CP63A-21	18.5	25	20	20	35	30	45
VFD220CP63A-21	22	30	24	20	35	30	45
VFD300CP63A-21	30	40	30	20	35	45	60
VFD370CP63A-21	37	50	36	20	45	60	75
VFD450CP63A-00/21	45	60	45	20	45	60	75
VFD550CP63A-00/21	55	75	54	20	45	60	100
VFD750CP63A-00/21	75	100	67	20	45	60	100
VFD900CP63A-00/21	90	125	86	20	45	75	100
VFD1100CP63A-00/21	110	150	104	20	45	75	100
VFD1320CP63A-00/21	132	175	125	20	45	75	100
VFD1600CP63A-00/21	160	215	150	20	45	90	100
VFD2000CP63A-00/21	200	270	180	20	45	90	100
VFD2500CP63A-00/21	250	335	220	20	45	90	100
VFD3150CP63A-00/21	315	425	290	20	45	90	100
VFD4000CP63A-00/21	400	530	350	20	45	90	100
VFD4500CP63A-00/21	450	600	385	20	45	90	100
VFD5600CP63A-00/21	560	745	465	20	45	75	90
VFD6300CP63A-00/21	630	850	675	20	45	75	90

 $<sup>\,\%\,</sup>$  690V output motor cable length needs to comply with IEC 60034-25.

#### Table 7-66

## Requirements on insulation level of Curve B motor



#### Key

A Without filters for motors up to 500 V a.c.

B Without filters for motors up to 690 V a.c.

 $^{\star}$  Examples of measured results at 415 V supply, for different lengths of steel armoured cable

Figure 7-36

#### The t<sub>r</sub> is defined as:




Figure 7-37


## Sine-wave filter

When there is longer cable length connected between the motor drive and the motor, the damping leads to high frequency resonator, and makes impedance matching poor to enlarge the voltage reflection. This phenomenon will generate twice-input voltage in the motor side, which will easily make motor voltage overshoot to damage insulation.


To prevent this, installing sine-wave filter can transform PWM output voltage to smooth and low-ripple sin wave, and motor cable length can be longer than 1000 meters.

#### Installation

Sine-wave filter is serially connected between motor drive UVW output side and motor, which is shown as below:



Wiring of non-shielded cable Figure 7-39



Wiring of shielded cable Figure 7-40

# Following table shows the sine-wave filter specification of Delta CP2000 200V–230V, 50 / 60 Hz

230V	kW	HP	Rated (		Suggested Sine-wave	Output Cable Length
Model	IXVV		Normal Duty	Light Duty	Filter Part #	(Shielded or Non-shielded)
VFD007CP23A-21	0.75	1	4.6	5	B84143V0006R227	1000
VFD015CP23A21	1.5	2	5	7.5	B84143V0011R227	1000
VFD022CP23A-21	2.2	3	8	10	B84143V0011R227	1000
VFD037CP23A-21	3.7	5	11	15	B84143V0025R227	1000
VFD055CP23A-21	5.5	7.5	17	21	B84143V0025R227	1000
VFD075CP23A-21	7.5	10	25	31	B84143V0033R227	1000
VFD110CP23A-21	11	15	33	46	B84143V0050R227	1000
VFD150CP23A-21	15	20	49	61	B84143V0066R227	1000
VFD185CP23A-21	18.5	25	65	75	B84143V0075R227	1000
VFD220CP23A-21	22	30	75	90	B84143V0095R227	1000
VFD300CP23A-21	30	40	90	105	B84143V0132R227	1000
VFD370CP23A-00/-21	37	50	120	146	B84143V0180R227	1000
VFD450CP23A-00/-21	45	60	146	180	B84143V0180R227	1000
VFD550CP23A-00/-21	55	75	180	215	B84143V0250R227	1000
VFD750CP23A-00/-21	75	100	215	276	B84143V0320R227	1000
VFD900CP23A-00/-21	90	125	255	322	Non-available	1000

Table 7-67

#### 380V-460V 50 / 60 Hz

380V–460V, 50 / 60 Hz			Rated	Current		
460V	14147	ЦΒ		ms)	Suggested Sine-wave	Output Cable Length (Shielded or
Model	kW	HP	Normal Duty	Light Duty	Filter Part #	Non-shielded)
VFD007CP43A-021/4EA-21	0.75	1	2.8	3	B84143V0004R227	1000
VFD015CP43B-21/4EB-21	1.5	2	3	4.2	B84143V0006R227	1000
VFD022CP43B-21/4EB-21	2.2	3	4	5.5	B84143V0006R227	1000
VFD037CP43B-21/4EB-21	3.7	5	6	8.5	B84143V0011R227	1000
VFD040CP43A-21/4EA-21	4	5	9	10.5	B84143V0011R227	1000
VFD055CP43B-21/4EB-21	5.5	7.5	10.5	13	B84143V0016R227	1000
VFD075CP43B-21/4EB-21	7.5	10	12	18	B84143V0025R227	1000
VFD110CP43B-21/4EB-21	11	15	18	24	B84143V0025R227	1000
VFD150CP43B-21/4EB-21	15	20	24	32	B84143V0033R227	1000
VFD185CP43B-21/4EB-21	18.5	25	32	38	B84143V0050R227	1000
VFD220CP43A-21/4EA-21	22	30	38	45	B84143V0050R227	1000
VFD300CP43B-21/4EB-21	30	40	45	60	B84143V0066R227	1000
VFD370CP43B-21/4EB-21	37	50	60	73	B84143V0075R227	1000
VFD450CP43S-00/43S-21	45	60	73	91	B84143V0095R227	1000
VFD550CP43S-00/43S-21	55	75	91	110	B84143V0132R227	1000
VFD750CP43B-00/43B-21	75	100	110	150	B84143V0180R227	1000
VFD900CP43A-00/43A-21	90	125	150	180	B84143V0180R227	1000

## Chapter 7 Optional Accessories | CP2000

460V Model	kW	HP		Current ms) Light Duty	Suggested Sine-wave Filter Part #	Output Cable Length (Shielded or Non-shielded)	
VFD1100CP43A-00/43A-21	110	150	180	220	B84143V0250R227	1000	
VFD1320CP43B-00/43B-21	132	175	220	260	B84143V0320R227	1000	
VFD1600CP43A-00/43A-21	160	215	260	310	B84143V0320R227	1000	
VFD1850CP43B-00/43B-21	185	250	310	370	Non-av	ailable	
VFD2000CP43A-00/43A-21	200	270	335	395	Non-av	ailable	
VFD2200CP43A-00/43A-21	220	300	370	460	Non-available		
VFD2500CP43A-00/43A-21	250	340	415	481	Non-available		
VFD2800CP43A-00/43A-21	280	375	460	530	Non-av	ailable	
VFD3150CP43A-00/ VFD3150CP43C-00/-21	315	420	550	616	Non-av	ailable	
VFD3550CP43A-00/ VFD3550CP43C-00/-21	355	475	616	683	Non-av	ailable	
VFD4000CP43A-00/ VFD4000CP43C-00/-21	400	536	683	770	Non-available		
VFD5000CP43A-00/ VFD5000CP43C-00/-21	500	675	866	912	Non-available		
VFD5600CP43A-00/43C-21	560	650	930	1294	Non-available		
VFD6300CP43A-00/43C-21	630	750	1094	1212	Non-available		

Table 7-68

Sine-wave output filters	Click on this URL for more information http://en.tdk.eu/inf/30/db/emc 2014/B84143V R227.pdf
B84143V0004R227	I <sub>R</sub> :4A, Sine-wave output filters for 3-phase systems
B84143V0006R227	I <sub>R</sub> :6A, Sine-wave output filters for 3-phase systems
B84143V0011R227	I <sub>R</sub> :11A, Sine-wave output filters for 3-phase systems
B84143V0016R227	I <sub>R</sub> :16A, Sine-wave output filters for 3-phase systems
B84143V0025R227	I <sub>R</sub> :25A, Sine-wave output filters for 3-phase systems
B84143V0033R227	I <sub>R</sub> :33A, Sine-wave output filters for 3-phase systems
B84143V0050R227	I <sub>R</sub> :50A, Sine-wave output filters for 3-phase systems
B84143V0066R227	I <sub>R</sub> :66A, Sine-wave output filters for 3-phase systems
B84143V0075R227	I <sub>R</sub> :75A, Sine-wave output filters for 3-phase systems
B84143V0095R227	I <sub>R</sub> :95A, Sine-wave output filters for 3-phase systems
B84143V0132R227	I <sub>R</sub> :132A, Sine-wave output filters for 3-phase systems
B84143V0180R227	I <sub>R</sub> :180A, Sine-wave output filters for 3-phase systems
B84143V0250R227	I <sub>R</sub> :250A, Sine-wave output filters for 3-phase systems
B84143V0320R227	I <sub>R</sub> :320A, Sine-wave output filters for 3-phase systems


Table 7-69


# 7-5 Zero Phase Reactors


Reactor model (Note)	Recommen	ded Wire Size	Wiring Method	Qty	Corresponding motor drives
RF008X00A or RF008X00N	≤8 AWG	≤ 8.37 mm <sup>2</sup>	Diagram A	1	VFD007CP23A-21; VFD007CP43A/4EA-21; VFD015CP23A-21; VFD015CP43B/4EB-21; VFD022CP23A-21; VFD022CP43B/4EB-21; VFD037CP23A-21; VFD037CP43B/4EB-21; VFD040CP43A/4EA-21; VFD055CP23A-21; VFD055CP43B/4EB-21; VFD075CP43B/4EB-21; VFD022CP53A-21; VFD037CP53A-21
RF004X00A or RF004X00N	≤ 4 AWG	≤ 21.15 mm <sup>2</sup>	Diagram A	1	VFD075CP23A-21; VFD110CP23A-21; VFD110CP43B/4EB-21; VFD150CP23A-21; VFD150CP43B/4EB-21; VFD185CP43B/4EB-21; VFD055CP53A-21; VFD075CP53A-21; VFD110CP53A-21; VFD150CP53A-21
RF002X00A or RF410X00N	≤2AWG	≤ 33.62 mm <sup>2</sup>	Diagram A	1	VFD185CP23A-21; VFD220CP23A-21; VFD220CP43A/4EA-21; VFD300CP23A-21; VFD300CP43B/4EB-21; VFD370CP43B/4EB-21; VFD185CP63A-21; VFD220CP63A-21; VFD300CP63A-21; VFD370CP63A-21; VFD370CP23A-00/23A-21; VFD450CP23A-00/23A-21; VFD750CP43B-00/43B-21; VFD900CP43A-00/43A-21; VFD450CP63A-00; VFD550CP63A-00; VFD450CP63A-21; VFD550CP63A-21
RF300X00A or RF300X00N	≤ 300 MCM	≤ 152 mm <sup>2</sup>	Diagram A	1	VFD450CP43S-00; VFD550CP43S-00; VFD450CP43S-21; VFD550CP43S-21; VFD550CP23A-00/23A-21; VFD750CP23A-00/23A-21; VFD900CP23A-00/23A-21; VFD1100CP43A-00/43A-21; VFD1320CP43B-00/43B-21; VFD750CP63A-00; VFD1320CP63A-00; VFD1100CP63A-21; VFD900CP63A-00; VFD1320CP63A-21; VFD900CP63A-21; VFD1320CP63A-21; VFD1100CP63A-21; VFD1100CP63A-21; VFD1850CP43B-00/43B-21; VFD1600CP63A-00; VFD2000CP63A-00; VFD1600CP63A-21; VFD2000CP63A-21; VFD2000CP63A-21; VFD2000CP43A-00/43A-21; VFD2200CP43A-00/43A-21; VFD2500CP43A-00/43A-21; VFD2500CP43A-00/43A-21; VFD2500CP63A-00; VFD3150CP63A-00; VFD3150CP63A-21; VFD3550CP43A-00/43C-00/43C-21; VFD3550CP43A-00/43C-00/43C-21; VFD4000CP63A-00; VFD4500CP63A-00; VFD5600CP63A-00; VFD4500CP63A-00; VFD5600CP63A-00; VFD4500CP63A-00; VFD5600CP63A-21; VFD4500CP63A-21; VFD5600CP63A-21; VFD

\*575V insulated power cable

## Chapter 7 Optional Accessories | CP2000










Unit: mm [inch]

Model	Α	В	С	D	E	F	G[Ø]	Torque
RF008X00A	98 [3.858]	73 [2.874]	36.5 [1.437]	29 [1.142]	56.5 [2.224]	86 [3.386]	5.5 [0.217]	< 10 kgf/cm <sup>2</sup>
RF004X00A	110 [4.331]	87.5 [3.445]	43.5 [1.713]	36 [1.417]	53 [2.087]	96 [3.780]	5.5 [0.217]	< 10 kgf/cm <sup>2</sup>

Table 7-71








Unit: mm [inch]

Model	Α	В	С	D	Е	F	G[Ø]	Н	Torque
RF002X00A	200 [7.874]	172.5 [6.791]	90 [3.543]	78 [3.071]	55.5 [2.185]	184 [7.244]	5.5 [0.217]	22 [0.866]	<45 kgf/cm <sup>2</sup>

Table 7-72



Unit: mm [inch]

Model	Α	В	С	D	Е	F	G[Ø]	Н	I
RF300X00A	241	217[	114	155	42	220	6.5	7.0	20
	[9.488]	8.543]	[4.488]	[6.102]	[1.654]	[8.661]	[0.256]	[0.276]	[0.787]

Table 7-73




Figure 7-43


Model	Α	В	С	Application
RF008X00N	22.5	43.1	18.5	Motor cable
RF004X00N	36.3	53.5	23.4	Motor cable
RF410X00N	108.1	70	30.3	Motor cable
RF300X00N	166.9	123.9	30.5	Motor cable
RF026X00N	10.7	17.8	8.0	Signal cable
RF020X00N	17.5	27.3	12.3	Signal cable

Table 7-74

#### Diagram A

Put all wires through at least one core without winding.

Zero Phase Reactor



**Note 1:** The table above gives approximate wire size for the zero phase reactors, but the selection is ultimately governed by the type and diameter of cable fitted i.e. the cable must fit through the center hole of zero phase reactors.

- Note 2: Only the phase conductors should pass through, not the earth core or screen.
- **Note 3:** When using long motor output cables, an output zero phase reactor may be required to reduce radiated emissions from the cable.

#### 7-6 EMC Filter

Following table is the external EMC filter of CP2000 series. User can choose corresponding zero phase reactor and suitable shielded cable length in accord to required noise emission and electromagnetic interference level to achieve the best configuration to suppress the electromagnetic interference. When the application does not consider RE interference and only needs CE to comply with C2 or C1, there is no need to install zero phase reactor on the input side.

230V / 460V Model

	400 V IVIOGEI			Zoro Dhoo	e* Reactor		CE	Cable	Radiation	
	Mandal	Input	Applicable EMC	Zero Phas	e Reactor	Carrier	Length		Emission	
Frame	Model	Current [A]	Filter	Input Side	Output Side	Frequency	default carrier frequency			
		[^]		(R/S/T)	(U/V/W)		C1	C2	EN61800-3	
	VFD007CP23A	6.4								
	VFD015CP23A	9.6	EMF021A23A							
Α	VFD022CP23A	15	EIVIFUZ IAZSA	RF008X00A	RF008X00A					
	VFD037CP23A	22				≤8 kHz				
	VFD055CP23A	25				⊒ 0 Ki iZ				
	VFD075CP23A	35	EMF056A23A							
В	VFD110CP23A	50		RF004X00A	RF004X00A					
	VFD150CP23A	65								
_	VFD185CP23A	83	KMF3100A							
С	VFD220CP23A	100								
	VFD300CP23A	116	B84143D0150R127	N/A	RF002X00A	≤ 6 kHz				
D	VFD370CP23A	146								
	VFD450CP23A	180	B84143B0250S020							
_	VFD550CP23A	215		NI/A	DE300Y004	~ A 1:11=		100 m	C2	
E	VFD750CP23A	276	B84143B0400S020	N/A	RF300X00A	≤ 4 kHz	50 m			
	VFD900CP23A	322								
	VFD015CD43A	4.3								
	VFD015CP43B VFD022CP43B	6 8.1	EMF014A43A							
Α	VFD022CF43B VFD037CP43B	12.4		RF008X00A	RF008X00A	≤ 8 kHz				
_ A	VFD037CF43B VFD040CP43A	16		NI UUUNUUA	KFUUOAUUA					
	VFD040CF43A VFD055CP43B	20								
	VFD035CF43B VFD075CP43B	22	EMEU307137							
	VFD110CP43B	26	EMF039A43A			1				
В	VFD150CP43B	35		RF004X00A	RF004X00A	≤ 8 kHz	-			
	VFD185CP43B	42		141 00 1740074	111 00-170071					
	VFD220CP43A	50	KMF370A							
С	VFD300CP43B	66				≤ 6 kHz				
	VFD370CP43B	80		N/A	RF002X00A					
D0	VFD450CP43S	91	B84143D0150R127							
D0	VFD550CP43S	110	D04440D0450D407			4 C L.L.				
	VFD750CP43B	150	B84143D0150R127	N/A	RF002X00A	≤ 6 kHz				
D	VFD900CP43A	180	D04442D0200D427				1			
Е	VFD1100CP43A	220	B84143D0200R127							
	VFD1320CP43B	260								
F	VFD1600CP43A	310	MIF3400B							
'	VFD1850CP43B	370	WIII 3400B							
	VFD2000CP43A	395					50 m	100 m	Pass	
G	VFD2200CP43A	460		N/A	RF300X00A	≤ 4 kHz				
	VFD2500CP43A	481		14/7 (	111 000710071					
	VFD2800CP43A	530	MIF3800							
	VFD3150CP43A 616	5555								
	VFD3550CP43A									
	VFD4000CP43A	770	D04440D4000000							
Н	VFD5000CP43A	930	B84143B1000S020							
	VFD5600CP43A-00	1094	-							
	VFD5600CP43C-21	1094	B84143B1600S020		Contact Delta	a for more in	format	ion		
	VFD6300CP43A-00	1212	}	Senter Delization Internation						
	VFD6300CP43C-21	1212							Table 7 75	

## 460V Model

	CP2000			Zero Phase	Reactor		Conducted Emission	Radiation Emission
Frame	Model	Rated Input Current [A]	Applicable EMC Filter	Input Side (R/S/T)	Output Side (U/V/W)	Carrier Freq.	Output Shielded Cable Length EN618000-3 C2	EN61800-3
D0	VFD450CP43S	91	B84143B0120R110		N/A			*C2
D0	VFD550CP43S	110	B64143B0120K110		IN/A	≤ 6 kHz	25 m	C2
D	VFD750CP43B	150	B84143B0180S020	N/A				*C3
	VFD900CP43A	180	D04143D01003020					- 03
E	VFD1100CP43A	220	B84143B0250S020					
	VFD1320CP43B	260	B84143B0320S020	B64290L0084X830		≤ 4 kHz	4 kHz	
F	VFD1600CP43A	310				= 7 KHZ		C2
	VFD1850CP43B	370	B84143B0400S020					
	VFD2000CP43A	395			RF300X00A or			
G	VFD2200CP43A	460			RF300X00N		13 m	
	VFD2500CP43A	481	B84143B0600S020					
	VFD2800CP43A	530						
	VFD3150CP43A	616				≤ 2 kHz		
	VFD3550CP43A	683	B84143B1000S020					*C3
	VFD4000CP43A	770	000140010000020					03
	VFD5000CP43A	930						
н	VFD5600CP43A-0 0	1094						
	VFD4500CP43C-2 1	1094	D04442D4600C020		Contact Dolt	a for more	for more information	
	VFD6300CP43A-0 0	1212	1430 10003020	S84143B1600S020 Contact Delta for more		iiioiiiatioii		
	VFD6300CP43C-2 1	1212						

<sup>\*</sup>For radiated emission, the drive needs to be placed inside a cabinet.

Table 7-76

	CP2000			Zero Phase	Reactor		Conducted Emission	Radiation Emission
Frame	Model	Rated Input	Applicable EMC Filter	Input Side	Output Side	Carrier Freq.	Output Shielded Cable Length	EN61800-3
Tanic	Model	Current [A]		(R/S/T)	(U/V/W)		EN618000-3 C3	LINO 1000-3
D0	VFD450CP43S	91	B84143A0120R105					C3
DU	VFD550CP43S	110	D04 143AU 12UR 103			≤6 kHz		C3
D	VFD750CP43B	150	B84143B0180S080					*C3
D	VFD900CP43A	180	B04 143B0 1603060					Co
Е	VFD1100CP43A	220	B84143B0250S080				150 m	C3
L	VFD1320CP43B	260	B84143B0320S080				130 111	
F	VFD1600CP43A	310	B84143B0400S080	N/A	N/A			
Г	VFD1850CP43B	370	B04143B04003000	IN/A	IN/A			
G	VFD2200CP43A	460	B84143B0600S080			≤4 kHz		
G	VFD2800CP43A	530	B64 143B00003000					03
	VFD3150CP43A	616						
	VFD3550CP43A	683	B84143B1000S080				100 m	
	VFD4000CP43A	770	B64 143B 10003000				100 m	
Н	VFD5000CP43A	930						
''	VFD5600CP43A-00	1094						
	VFD4500CP43C-21	1094	B84143B1600S080		Contact Del	ta for mor	e information	
	VFD6300CP43A-00		1430 10003000		Contact Dei	ta 101 11101	e iiiioiiiialioii	
	VFD6300CP43C-21	1212						

<sup>\*</sup>For radiated emission, the drive needs to be placed inside a cabinet.

## Chapter 7 Optional Accessories | CP2000

## 575V / 690V Model

		Input	Zero Phase*		CE Cabl	e Length	Radiation Emission	
Frame	Model	Current	Applicable EMC Filter	Reactor	d	efault carrie	r frequency	
		[A]		redotor	C1	C2	EN61800-3	
	VFD022CP53A-21	5.4	EMF008A63A					
Α	VFD037CP53A-21	10.4	EMF014A63A					
	VFD055CP53A-21	14.9		DE000\/004				
_	VFD075CP53A-21	16.9		RF008X00A				
В	VFD110CP53A-21	21.3	EMF027A63A					
	VFD150CP53A-21	26.3						
	VFD185CP63A-21	29						
	VFD220CP63A-21	36						
С	VFD300CP63A-21	43						
	VFD370CP63A-21	54	B84143A0050R021	RF002X00A				
	VFD450CP63A-00	54			50 m	100 m	C2	
D	VFD450CP63A-21 VFD550CP63A-00	0CP63A-21						
	VFD550CP63A-21	67						
	VFD750CP63A-00 VFD750CP63A-21	84	B84143A0120R021 B84143B0150S021					
E	VFD900CP63A-00 VFD900CP63A-21	102						
_	VFD1100CP63A-00 VFD1100CP63A-21	122						
	VFD1320CP63A-00	147		RF300X00A				
	VFD1320CP63A-21 VFD1600CP63A-00							
F	VFD1600CP63A-21	178	B84143B0250S021					
	VFD2000CP63A-00 VFD2000CP63A-21	217						
	VFD2500CP63A-00 VFD2500CP63A-21	292	B84143B0400S021					
G	VFD3150CP63A-00	353						
	VFD3150CP63A-21 VFD4000CP63A-00		B84143B0600S021					
Н	VFD4000CP63A-21	3A-21 454		RF300X00A	50 m	100 m	C2	
''	VFD4500CP63A-00 VFD4500CP63A-21	469			NI OOOAOOA	55 111	100 111	
	VFD5600CP63A-00 VFD5600CP63A-21	595						
Н	VFD6300CP63A-00 VFD6300CP63A-21	681	B84143B1000S021					


<sup>\*</sup> For Frame A–C: On both input and output side, a zero phase reactor is required to be wired to the motor drive. Table 7-78

There should be in total 2 zero phase reactors.


For Frame D–H: Only one zero phase reactor is required to be wired on the output side of the motor drive.

**EMC Filter Dimension** 


EMC filter model name: EMF021A23A; EMF014A43A




EMC filter model name: EMF018A43A





## EMC filter model name: EMF056A23A; EMF039A43A



EMC filter model name: KMF370A; KMF3100A












Figure 7-48


## EMC filter model name: B84143D0150R127




EMC filter model name: B84143D0200R127




EMC filter model name: B84143B0250S020




EMC filter model name: B84143B0400S020



EMC filter model name: B84143B1000S020



## EMC filter model name: B84143B1600S020



The table below is the suggested shielded cable length for drive models with built-in EMC filters. You can choose the corresponding shielded cable length according to the required noise emission and electromagnetic interference level.

EMC built-in model		Rated current	Class C3		3) Comply with EMC (IEC 61800-3 Class C2	
Frame	Model	(ND)	Shielded cable length	Fc	Shielded cable length	Fc
	VFD007CP4EA-21	3.5				
	VFD015CP4EB-21	4.3				
	VFD022CP4EB-21	5.9				
Α	VFD037CP4EB-21	8.7		≤ 8 kHz		≤8 kHz
	VFD040CP4EA-21	14				
	VFD055CP4EB-21	15.5				
	VFD075CP4EB-21	17	30 m		10 m	
	VFD110CP4EB -21	20				
В	VFD150CP4EB -21	26				
	VFD185CP4EB -21	35				
	VFD220CP4EA -21	40		≤ 6 kHz		≤ 6 kHz
С	VFD300CP4EB -21	47		≥ 0 KHZ		≥ U K⊓Z
	VFD370CP4EB-21	63				

Tahle 7-70

### **EMC Filter Installation**

All electrical equipment (including AC motor drives) generate high or low frequency noise that interferes with peripheral equipment by radiation or conduction when during operation. Correctly install an EMC filter can eliminate much interference. It is recommended to use DELTA EMC filter to have the best interference elimination performance.

We assure that it can comply with the following rules when the AC motor drive and EMC filter are both installed and wired according to user manual:

- EN61000-6-4
- EN61800-3: 1996
- EN55011 (1991) Class A Group 1 (1st Environment, restricted distribution)

### General precaution

To ensure the EMC filter maximizes the effect of suppressing the interference of AC motor drive, the installation and wiring of AC motor drive should follow the user manual. In addition, be sure to observe the following precautions:

- 1. Install the EMC filter and AC motor drive on the same metal plate.
- 2. Install the AC motor drive on footprint EMC filter or install the EMC filter as close as possible to the AC motor drive.
- 3. Wire as short as possible.
- 4. Ground the metal plate.
- 5. The cover of EMC filter and AC motor drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

<sup>\*</sup> To prevent increment of wires parasitic capacitance and leakage current due to excessive cable length, which causes overheating of the built-in EMC filters, the shielded cable length for Frame A should not be longer than 30 m, and that for Frame B, C should not be longer than 50 m.

## Choose suitable motor cable and precautions

Improper installation and choice of motor cable affects the performance of EMC filter. Be sure to observe the following precautions when selecting motor cable.

- 1. Use the cable with shielding (double shielding is the best).
- 2. The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
- 3. Remove any paint on metal saddle for good ground contact with the plate and shielding.

Remove any paint on metal saddle for good ground contact with the plate and shielding.




Figure 1






Figure 2

## 7-7 Panel Mounting (MKC-KPPK)

For MKC-KPPK model, you can choose wall mounting or embedded mounting, the protection level is IP66. Applicable to the digital keypads (KPC-CC01).



Chapter 7 Optional Accessories | CP2000



## 7-8 Conduit Box Kit

### Appearance

Conduit box kit is optional For VFDXXXCPXXA-XX (Frame D and above) and VFDXXXCP43S-XX, the protection level is IP20 / NEMA1 / UL TYPE1 after installation.


### Frame D0

### Applicable models:

VFD450CP43S-00, VFD550CP43S-00, VFD450CP43S-21, VFD550CP43S-21

### Model number MKC-D0N1CB

ITEM	Description	Qty.
1	Screw M5*0.8*10L	4
2	Bushing Rubber 28	2
3	Bushing Rubber 44	2
4	Bushing Rubber 73	2
5	Conduit box cover	1
6	Conduit box base	1



**Table 7-82** 

### Frame D


### Applicable models:

VFD370CP23A-00, VFD450CP23A-00, VFD750CP43B-00, VFD900CP43A-00, VFD370CP23A-21, VFD450CP23A-21, VFD750CP43B-21, VFD900CP43A-21, VFD450CP63A-00, VFD550CP63A-00, VFD450CP63A-21, VFD550CP63A-21

## Model number MKC-DN1CB J

ITEM	Description	Qty.
1	Screw M5*0.8*10L	4
2	Bushing Rubber 28	2
3	Bushing Rubber 44	2
4	Bushing Rubber 88	2
5	Conduit box cover	1
6	Conduit box base	1

Table 7-83



## Frame E


### Applicable models:

VFD550CP23A-00, VFD750CP23A-00, VFD900CP23A-00, VFD1100CP43A-00, VFD1320CP43B-00, VFD550CP23A-21, VFD750CP23A-21, VFD900CP23A-21, VFD1100CP43A-21, VFD1320CP43B-21, VFD750CP63A-00, VFD900CP63A-00, VFD1100CP63A-00, VFD1320CP63A-00, VFD750CP63A-21, VFD900CP63A-21, VFD1100CP63A-21, VFD1320CP63A-21

### Model number MKC-EN1CB

ITEM	Description	Qty.
1	Screw M5*0.8*10L	6
2	Bushing Rubber 28	2
3	Bushing Rubber 44	4
4	Bushing Rubber 100	2
5	Conduit box cover	1
6	Conduit box base	1

Table 7-84



### Frame F


### Applicable models:

VFD1600CP43A-00, VFD1850CP43B-00, VFD1600CP43A-21, VFD1850CP43B-21, VFD1600CP63A-00, VFD2000CP63A-00, VFD1600CP63A-21, VFD2000CP63A-21

## Model number 『MKC-FN1CB』

ITEM	Description	Qty.
1	Screw M5*0.8*10L	8
2	Bushing Rubber 28	2
3	Bushing Rubber 44	4
4	Bushing Rubber 100	2
5	Conduit box cover	1
6	Conduit box base	1

Table 7-85



### Frame G


## Applicable models:

VFD2000CP43A-00, VFD2200CP43A-00, VFD2500CP43A-00, VFD2800CP43A-00, VFD2000CP43A-21, VFD2200CP43A-21, VFD2500CP43A-21, VFD2500CP43A-21, VFD2500CP63A-00, VFD3150CP63A-00, VFD2500CP63A-21, VFD3150CP63A-21

### 型號『MKC-GN1CB』

ITEM	Description	Qty.
1	Screw M5*0.8*10L	12
2	Bushing Rubber 28	2
3	Bushing Rubber 44	2
4	Bushing Rubber 130	3
5	Conduit box cover	1
6	Conduit box base	1

Table 7-86



### Frame H


### Applicable models:

VFD3150CP43A-00, VFD3550CP43A-00, VFD4000CP43A-00, VFD5000CP43A-00, VFD5600CP43A-00, VFD6300CP43A-00, VFD3150CP43C-00, VFD3550CP43C-00, VFD4000CP43C-00, VFD5000CP43C-00, VFD3150CP43C-21, VFD3550CP43C-21, VFD4000CP43C-21, VFD5000CP43C-21, VFD5600CP43C-21, VFD5600CP43C-21, VFD6300CP43C-21, VFD4000CP63A-00, VFD4500CP63A-00, VFD4500CP63A-21, VFD4500CP63A-21, VFD4500CP63A-21, VFD5600CP63A-21

## Model number MKC-HN1CB I

ITEM	Description	Qty.
1	Screw M6*1.0*25L	8
2	Screw M8*1.25*30L	3
3	NUT M8	4
4	NUT M10	4
5	Bushing Rubber 28	4
6	Bushing Rubber 44	2
7	Bushing Rubber 130	4
8	Conduit box cover 1	1
9	Conduit box cover 2	2
10	Conduit box cover 3	2
11	Conduit box cover 4	2
12	Conduit box base	1
13	Accessories 1	2
14	Accessories 2	1


**Table 7-87** 




### Conduit Box Installation

### Frame D0


1. Loosen the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]




 Remove the 5 screws shown in the following figure. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]



3. Install the conduit box by fasten the 5 screws shown in the following figure. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




4. Fasten the 2 screws shown in the following figure. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]




### Frame D


1. Loosen the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]




2. Remove the 5 screws shown in the following figure. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]



3. Install the conduit box by fasten the 5 screws shown in the following figure. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




4. Fasten the 2 screws shown in the following figure. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]




## Frame E


1. Loosen the 4 cover screws and lift the cover; Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]



2. Fasten the 6 screws shown in the following figure and place the cover back to the original position. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




3. Fasten the 4 screws shown in the following figure. Screw torque: 12-15 kg-cm / [10.4-13 lb-in.] / [1.2-1.5 Nm]




### Frame F


1. Loosen the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]



2. Install the conduit box by fastens the 4 screws, as shown in the following figure. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




3. Install the conduit box by fasten all the screws shown in the following figure Screw 9–12 torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm] Screw 13–16 torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]



### Chapter 7 Optional Accessories | CP2000


### Frame G

- 1. On the conduit box, loosen 7 of the cover screws and remove the cover. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm].
- 2. On the drive, loosen 4 of the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]




3 Remove the top cover and loosen the screws.


M5 Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm] M8 Screw torque: 100–120 kg-cm / [86.7–104.1 lb-in.] / [9.8–11.8 Nm]




4 Install the conduit box by fastening all the screws shown in the following figure. M5 Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in] / [2.4–2.5 Nm] M8 Screw torque: 100–120 kg-cm / [86.7–104.1 lb-in] / [9.8–11.8 Nm]



5. Fasten all the screws. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




6. Place the cover back to the top and fasten the screws (as shown in the figure). Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]




## Frame H

## Assembly for Frame H3 (Conduit Box Kit)


1. Loosen the screws and remove the cover of conduit box H3 as preparation.




2. Loosen the screws as below figure shown.



3. Fasten the M6 screws to locations shown in below figure. Screw torque: 35–45 kg-cm / [30.3–39 lb-in.] / [3.4–4.4 Nm]




4. Install the conduit box by fasten all the screws shown in the following figure Screw 1–6: M6 screw torque: 55–65 kg-cm / [47.7–56.4 lb-in] / [5.4–6.4 Nm] Screw 7–9: M8 screw torque: 100–110 kg-cm / [86.7–95.4 lb-in] / [9.8–10.8 Nm] Screw 10–13: M10 screw torque: 250–300 kg-cm / [216.9–260.3 lb-in] / [24.5–29.4 Nm] Screw 14–17: M8 screw torque: 100–110 kg-cm / [86.7–95.4 lb-in] / [9.8–10.8 Nm]




## Chapter 7 Optional Accessories | CP2000

5. Fasten the 3 covers and screws, which are loosen from step1, to the original location. Screw torque: 35–45 kg-cm / [30.3–39 lb-in.] / [3.4–4.4 Nm]




6. Installation complete.




## Assembly for Frame H2 (Straight Stand)


1. Loosen the 3 screws and remove the cover of conduit box.



2. Remove the 4 covers of conduit box, and fasten the loosen screws back to the original location. Screw torque: 100–110 kg-cm / [86.7–95.4 lb-in] / [9.8–10.8 Nm]




3. Remove the parts and screws as below figure shown.




### Chapter 7 Optional Accessories | CP2000


4. Fasten the M6 screws to locations shown in below figure. Screw torque: 35–45 kg-cm / [30.3–39 lb-in.] / [3.4–4.4 Nm]



5. Install conduit box and accessories by fasten all the screws shown in the following figure. Screws 1–6: M6 screw torque: 55–65 kg-cm / [47.7–56.4 lb-in] / [5.4–6.4 Nm] Screws 7–9: M8 screw torque: 100–110 kg-cm / [86.7–95.4 lb-in] / [9.8–10.8 Nm] Screws 10–13: M10 screw torque: 250–300 kg-cm / [216.9–260.3 lb-in] / [24.5–29.4 Nm] Screws 14–17: M8 screw torque: 100–110 kg-cm / [86.7–95.4 lb-in] / [9.8–10.8 Nm]



## 6. Installation complete.



## 7-9 Fan Kit

## Appearance of the fan kit

NOTE: The fan does not support hot swap function. For re-	eplacement, turn the power off before replacing the fan.
Frame A	Heat sink Fan Model 『MKC-AFKM』
Applicable Model  VFD022CP23A-21; VFD037CP23A-21; VFD055CP23A-21; VFD022CP43B-21; VFD022CP4EB-21; VFD037CP43B-21; VFD037CP4EB-21; VFD040CP43A-21; VFD040CP4EA-21; VFD055CP43B-21; VFD055CP4EB-21; VFD015CP53A-21; VFD022CP53A-21; VFD037CP53A-21	
Frame A	Heat sink Fan Model 『MKCB-AFKM2』
Applicable Model VFD075CP43B-21; VFD075CP4EB-21	
Frame B	Heat sink Fan Model 『MKC-BFKM1』
Applicable Model  VFD075CP23A-21; VFD110CP43B-21;  VFD110CP4EB-21; VFD055CP53A-21;  VFD075CP53A-21; VFD110CP53A-21;  VFD150CP53A-21	
Frame B	Heat sink Fan Model 『MKC-BFKM2』『MKC-BFKM3』
Applicable Model	
MKC-BFKM2: VFD110CP23A-21; VFD150CP43B-21; VFD150CP4EB-21; VFD185CP43B-21; VFD185CP4EB-21  MKC-BFKM3: VFD150CP23A-21	
(The MKC-BFKM2 and MKC-BFKM 3 have the same shape)	

## Frame B

## Applicable Model

VFD075CP23A-21; VFD110CP23A-21; VFD110CP43B-21; VFD110CP4EB-21;


VFD150CP23A-21; VFD150CP43B-21;

VFD150CF25A-21; VFD150CF43B-21; VFD150CP4B-21;

VFD185CP4EB-21; VFD055CP53A-21;

VFD075CP53A-21; VFD110CP53A-21;

VFD150CP53A-21



### Frame C

### Applicable Model


VFD185CP23A-21; VFD220CP23A-21;

VFD300CP23A-21; VFD185CP63A-21;

VFD220CP63A-21; VFD300CP63A-21;

VFD370CP63A-21






### Frame C

#### Applicable Model

VFD220CP43A-21; VFD220CP4EA-21; VFD300CP43B-21; VFD300CP4EB-21;

VFD370CP43B-21; VFD370CP4EB-21

### Capacitor Fan Model 『MKC-CFKB2』



## Frame C

Following Models use one set of MKC-CFKM:

VFD220CP43A-21; VFD220CP4EA-21;

VFD300CP43B-21; VFD300CP4EB-21;


VFD370CP43B-21

Following Models use two sets of MKC-CFKM:

VFD185CP23A-21; VFD220CP23A-21;

VFD300CP23A-21; VFD370CP4EB-21

Heat sink Fan 『MKC-CFKM』




# Frame C Heat sink Fan Model Capacitor Fan Model 『MKC-CFKM1』 <sup>ḟ</sup>MKC-CFKB3 』 Applicable Model VFD185CP63A-21; VFD220CP63A-21; VFD300CP63A-21; VFD370CP63A-21 Frame D0 Heat sink Fan Model Capacitor Fan Model 『MKC-DFKB』 『MKC-D0FKM』 Applicable Model VFD450CP43S-00; VFD450CP43S-21; VFD550CP43S-00; VFD550CP43S-21 Heat sink Fan Model Capacitor Fan Model Frame D MKC-DFKB 『MKC-DFKM』 Applicable Model VFD370CP23A-00; VFD370CP23A-21; VFD450CP23A-00; VFD450CP23A-21; VFD750CP43B-00; VFD750CP43B-21; VFD900CP43A-00; VFD900CP43A-21; VFD450CP63A-00; VFD450CP63A-21; VFD550CP63A-00; VFD550CP63A-21 Frame E Heat sink Fan Model 『MKC-EFKM1』 Applicable Model VFD550CP23A-00; VFD550CP23A-21; VFD750CP23A-00; VFD750CP23A-21

#### Frame E

### Applicable Model

VFD900CP23A-00; VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43B-00; VFD1320CP43B-21




#### Frame E

### Applicable Model

VFD750CP63A-00; VFD750CP63A-21; VFD900CP63A-00; VFD900CP63A-21; VFD1100CP63A-00; VFD1100CP63A-21; VFD1320CP63A-00; VFD1320CP63A-21

Fan Model 『MKC-EFKM3』




## Frame E

### Applicable Model

VFD550CP23A-00; VFD550CP23A-21; VFD750CP23A-00; VFD750CP23A-21; VFD900CP23A-00; VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43B-00; VFD1320CP43B-21; VFD900CP63A-00; VFD900CP63A-21; VFD1100CP63A-00; VFD1100CP63A-21; VFD1320CP63A-00; VFD1320CP63A-21

Capacitor Fan Model 『MKC-EFKB』




### Frame F

## Applicable Model

VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43B-00; VFD1850CP43B-21; VFD1600CP63A-00; VFD1600CP63A-21; VFD2000CP63A-00; VFD2000CP63A-21

Heat sink Fan Model 『MKC-FFKM』



# Chapter 7 Optional Accessories | CP2000 Frame F Capacitor Fan Model 『MKC-FFKB』 Applicable Model VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43B-00; VFD1850CP43B-21; VFD1600CP63A-00; VFD1600CP63A-21; VFD2000CP63A-00; VFD2000CP63A-21 Frame G Heat sink Fan Model 『MKC-GFKM』 Applicable Model VFD2000CP43A-00; VFD2000CP43A-21; VFD2200CP43A-00; VFD2200CP43A-21; VFD2500CP43A-00; VFD2500CP43A-21; VFD2800CP43A-00; VFD2800CP43A-21; VFD2500CP63A-00; VFD2500CP63A-21; VFD3150CP63A-00; VFD3150CP63A-21 Frame H Heat sink Fan Model MKC-HFKM Applicable Model Following models use two sets of MKC-HFKM: VFD3150CP43A-00; VFD3150CP43C-00; VFD3150CP43C-21; VFD3550CP43A-00; VFD3550CP43C-00; VFD3550CP43C-21; VFD4000CP43A-00; VFD4000CP43C-00; VFD4000CP43C-21 Heat sink Fan Model 『MKCHS-HFKM』 Frame H Applicable Model Following models use three sets of MKCHS-HFKM: VFD5000CP43A-00; VFD5000CP43C-00; VFD5000CP43C-21; VFD5600CP43A-00; VFD5600CP43C-21; VFD6300CP43A-00;

VFD6300CP43C-21

Frame H Heat sink Fan Model 『MKC-HFKM1』

Applicable Model

Following models use two sets of MKC-HFKM1:


VFD4000CP63A-00; VFD4000CP63A-21

Following models use three sets of MKC-HFKM1:

VFD4500CP63A-00; VFD4500CP63A-21;

VFD5600CP63A-00; VFD5600CP63A-21;

VFD6300CP63A-00; VFD6300CP63A-21



### Fan Removal

### Frame A

Model『MKC-AFKM』: Heat Sink Fan

Applicable model

VFD022CP23A-21; VFD037CP23A-21; VFD055CP23A-21; VFD022CP43B-21; VFD022CP4EB-21;

VFD037CP43B-21; VFD037CP4EB-21; VFD040CP43A-21; VFD040CP4EA-21; VFD055CP43B-21;

VFD055CP4EB-21; VFD015CP53A-21; VFD022CP53A-21; VFD037CP53A-21

## Model『MKCB-AFKM2』: Heat Sink Fan

Applicable model

VFD075CP43B-21; VFD075CP4EB-21

1. Refer to Figure 1, press the tabs on both side of the 2. Disconnect the power terminal before removing the fan to successfully remove the fan. fan. (As shown below.)




Figure 1




Figure 2

#### Frame B

### Model 『MKC-BFKM1』 Heat Sink Fan

Applicable model

VFD075CP23A-21; VFD110CP43B-21; VFD110CP4EB-21; VFD055CP53A-21; VFD075CP53A-21;

VFD110CP53A-21; VFD150CP53A-21

## Model『MKC-BFKM2』Heat Sink Fan

Applicable model


VFD110CP23A-21; VFD150CP43B-21; VFD150CP4EB-21; VFD185CP43B-21; VFD185CP4EB-21

### Model『MKC-BFKM3』Heat Sink Fan

Applicable model

VFD150CP23A-21

fan to successfully remove the fan.






Figure 1




Figure 2

#### Frame B


## Model 『MKC-BFKB』 Capacitor Fan

### Applicable model

VFD075CP23A-21; VFD110CP23A-21; VFD110CP43B-21; VFD110CP4EB-21; VFD150CP23A-21; VFD150CP43B-21; VFD150CP4EB-21; VFD185CP4BB-21; VFD185CP4EB-21; VFD055CP53A-21;

VFD075CP53A-21; VFD110CP53A-21; VFD150CP53A-21

Disconnect fan power and pull out the fan by using flathead screwdriver. (As shown in the larger picture)



#### Frame C

### Model『MKC-CFKM』Heat Sink Fan

### Applicable model

Single fan kit applicable models (only fan kit 1 is required to be installed):

VFD220CP43A-21; VFD220CP4EA-21; VFD300CP43B-21; VFD300CP4EB-21; VFD370CP43B-21;

Dual fan kit applicable models (both fan kit 1 and 2 are required to be installed):


VFD185CP23A-21; VFD220CP23A-21; VFD300CP23A-21; VFD370CP4EB-21

### Model『MKC-CFKM1』Heat Sink Fan

### Applicable model

VFD185CP63A-21; VFD220CP63A-21; VFD300CP63A-21; VFD370CP63A-21

1. (As shown Figure 1) Before removing the fan, remove the cover by using a slotted screwdriver.



(As shown in Figure 2), remove the power connector, loosen the screw and remove the fan kit. When installing
the fan kit, have the label on the fan kit facing inside of the motor drive.

Screw's torque: 10–12 kg-cm / [8.7–10.4 lb-in.] / [1.0–1.2 Nm]




Figure 2

#### Frame C

Model『MKC-CFKB1』Capacitor Fan

Applicable model

VFD185CP23A-21; VFD220CP23A-21; VFD300CP23A-21; VFD185CP63A-21; VFD220CP63A-21;

VFD300CP63A-21; VFD370CP63A-21

# Model『MKC-CFKB2』Capacitor Fan

Applicable model

VFD220CP43A-21; VFD220CP4EA-21; VFD300CP43B-21; VFD300CP4EB-21; VFD370CP43B-21;


VFD370CP4EB-21

# Model『MKC-CFKB3』Capacitor Fan

Applicable model

VFD185CP63A-21; VFD220CP63A-21; VFD300CP63A-21; VFD370CP63A-21

Disconnect fan power and pull out the fan by using flathead screwdriver. (As shown in the larger picture)




#### Frame D0

# Model『MKC-DFKB』Capacitor Fan

#### Applicable model

VFD450CP43S-00; VFD450CP43S-21; VFD550CP43S-00; VFD550CP43S-21

right and left to remove the cover, follow the direction the arrows indicate. Press on top of digital keypad to properly remove it. Screw 1, 2 Torque: 12-15 kg-cm / [10.4-13 lb-in.] / [1.2-1.5 Nm]






Figure 1




Figure 2

3. Loosen screw 4 (figure 3) and disconnect fan power and pull out the fan. (As shown in the enlarged picture 3) Screw 4 Torque: 10–12 kg-cm / [8.7–10.4 lb-in.] / [1.0–1.2 Nm]




Figure 3

#### Frame D0

# Model 『MKC-D0FKM』 Heat Sink Fan

## Applicable model

VFD450CP43S-00; VFD450CP43S-21; VFD550CP43S-00; VFD550CP43S-21

- 1. Loosen the screw and remove the fan kit. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in. / [2.4–2.5 Nm]
- 2. (As shown Figure 1) Before removing the fan, remove the cover by using a slotted screwdriver.




Figure 1

#### Frame D


#### Model 『MKC-DFKB』Capacitor Fan

Applicable model

VFD370CP23A-00; VFD370CP23A-21; VFD450CP23A-00; VFD450CP23A-21; VFD750CP43B-00; VFD750CP43B-21; VFD900CP43A-00; VFD900CP43A-21; VFD450CP63A-00; VFD450CP63A-21;

VFD550CP63A-00; VFD550CP63A-21

Loosen screw 1 and screw 2, press the tab on the 2. right and the left to remove the cover, follow the direction the arrows indicate. Press on top of digital keypad to properly remove it. Screw 1, 2 Torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]






Figure 1




Figure 2

3. Loosen screw 5 (figure 3) and disconnect fan power and pull out the fan. (As shown in the enlarged picture 3) Screw 5 Torque: 10–12 kg-cm / [8.6–10.4 lb-in.] / [1.0–1.2 Nm]




Figure 3


#### Frame D

#### Model 『MKC-DFKM』 Heat Sink Fan

Applicable model

VFD370CP23A-00; VFD370CP23A-21; VFD450CP23A-00; VFD450CP23A-21; VFD750CP43B-00; VFD750CP43B-21; VFD900CP43A-00; VFD900CP43A-21; VFD450CP63A-00; VFD450CP63A-21; VFD550CP63A-00; VFD550CP63A-21

- 1. Loosen the screw and remove the fan kit. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]
- 2. (As shown Figure 1) Before removing the fan, remove the cover by using a slotted screwdriver.



#### Frame E

Applicable models for MKC-EFKM1:

VFD550CP23A-00; VFD550CP23A-21; VFD750CP23-00; VFD750CP23A-21

Applicable models for MKC-EFKM2:

VFD900CP23A-00; VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43B-00;

VFD1320CP43B-21

Applicable models for MKC-EFKM3:

VFD750CP63A-00; VFD750CP63A-21; VFD900CP63A-00; VFD900CP63A-21; VFD1100CP63A-00;

VFD1100CP63A-21; VFD1320CP63A-00; VFD1320CP63A-21

Applicable models for MKC-EFKB:

VFD550CP23A-00; VFD550CP23A-21; VFD750CP23A-00; VFD750CP23A-21; VFD900CP23A-00;

VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43B-00; VFD1320CP43B-21;

VFD900CP63A-00; VFD900CP63A-21; VFD1100CP63A-00; VFD1100CP63A-21; VFD1320CP63A-00;

VFD1320CP63A-21

## Model『MKC-EFKM1』Heat Sink Fan

 Loosen screw 1–4 (figure 1) and disconnect fan power and pull out the fan. (As shown in the enlarged picture 1) Screw1–4 Torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




Figure 1

# Model 『MKC-EFKM2 / MKC-EFKM3』Heat Sink Fan

. Loosen screw 1–4 (figure 2) and disconnect fan power and pull out the fan. (As shown in the enlarged picture 2) Screw1–4 Torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




Figure 2

# Model MKC-EFKB : Heat Sink Fan

1. Loosen screw 1–2 and disconnect fan power and pull out the fan. (As shown in the enlarged picture 3) Screw1–2 Torque: 24–26 kg-cm / [20.8–22.6 lb-in] / [2.4–2.5 Nm]




Figure 3

# Frame F

Applicable model

VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43B-00; VFD1850CP43B-21; VFD1600CP63A-00;

VFD1600CP63A-21; VFD2000CP63A-00; VFD2000CP63A-21

Fan model『MKC-FFKM』Heat Sink Fan

1. Loosen the screws and plug out the power of fan before removing it (figure 1). Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]





Figure 1

# Fan model 『MKC-FFKB』Capacitor Fan

 Loosen the screw (figure 1) and remove the cover. Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]



2. Loosen the screw (figure 2) and remove the cover. Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]





Figure 1

Figure 2

3. Loosen the screws and remove the fan. (figure 3 and figure 4) Screw torque: 12–15 kg-cm / [10.4–13 lb-in.] / [1.2–1.5 Nm]



#### Frame G

# Fan model『MKC-GFKM』Heat Sink Fan

Applicable model

VFD2000CP43A-00; VFD2000CP43A-21; VFD2200CP43A-00; VFD2200CP43A-21; VFD2500CP43A-00; VFD2500CP43A-21; VFD2800CP43A-00; VFD2800CP43A-21; VFD2500CP63A-00; VFD2500CP63A-21; VFD3150CP63A-00; VFD3150CP63A-21

1. Loosen the screw (figure 1) and remove the cover. Screw torque: 12–15 kg-cm / [10.4–13.1 lb-in.] / [1.2–1.5 Nm]




Figure 1

- 2. For 1–8 shown in the figure 2: Loosen the screws Screw M6 torque: 35–40 kg-cm / [30.4–34.7 lb-in.] / [3.4–3.9 Nm]
- 3. For 9–10 shown in the figure 2: Loosen the screws and remove the cover. Screw M4 torque: 14–16 kg-cm / [12.2–13.9 lb-in.] / [1.4–1.6 Nm]




Figure 2

Loosen screw 1–3 and remove the protective ring (as 5. Lift the fan by putting your finger through the protective shown in figure 3) Screw torque: 14–16 kg-cm / holes, as indicates in 1 and 2 on the figure 4. [12.2–13.9 lb-in.] / [1.4–1.6 Nm]




Figure 3

If you are switching new fan on old AC motor drive, follow the steps below:

Loosen screws 1–5, remove the cover (as shown in figure below). M4 screw torque: 14–16 kg-cm / [12.2–13.9 lb-in] / [1.4–1.6 Nm]




Figure 5




Figure 4

6. Add cable model 3864483201 to connect the power board and fan connector. (The cable 3864483201 goes with the fan as accessory.)




Figure 6

#### Frame H

# Fan model『MKC-HFKM』Heat Sink Fan

#### Applicable model


VFD3150CP43A-00; VFD3150CP43C-00; VFD3150CP43C-21; VFD3550CP43A-00; VFD3550CP43C-00;

VFD3550CP43C-21; VFD4000CP43A-00; VFD4000CP43C-00; VFD4000CP43C-21; VFD5000CP43A-00;


VFD5000CP43C-00; VFD5000CP43C-21; VFD5600CP43A-00; VFD5600CP43C-21; VFD6300CP43A-00;

#### VFD6300CP43C-21


1. Loosen the screw 1–4 and remove the top cover (figure 1). Screw torque: 14-16 kg-cm / [12.2-13.9 lb-in] / [1.4-1.6 Nm]




2. Loosen the screw 5–12 and remove the top cover (figure 2). Screw torque: 24-26 kg-cm / [20.8-22.6 lb-in] / [2.4-2.5 Nm]



3. Press the latch to disconnect fan power (as shown in 4. Loosen the screw 13–18 and remove the fan. the enlarged picture of figure 3).





# Frame H

# Fan model『MKCHS-HFKM』Heat Sink Fan

## Applicable model

Following models use three sets of MKCHS-HFKM:

VFD5000CP43A-00; VFD5000CP43C-00; VFD5000CP43C-21; VFD5600CP43A-00; VFD5600CP43C-21;

VFD6300CP43A-00; VFD6300CP43C-21

 Loosen the screw 1–4 and remove the top cover (figure 1) Screw torque: 14–16 kg-cm / [12.2–13.9 Ib-in.] / [1.4–1.6 Nm]




Figure 1

 Loosen the screw 5–12 and remove the top cover (figure 2). Screw torque: 24–26kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




Figure 2

3. Press the latch to disconnect fan power, and cut the cable tie





Figure 3

4. Loosen the screw 13-24 and remove the fan.




# Fan model『MKC-HFKM1』Heat Sink Fan

Applicable model

Following models use two sets of MKC-HFKM1:

VFD4000CP63A-00; VFD4000CP63A-21

1. Loosen the screw 1–4 and remove the top cover 2. (figure 1) Screw torque: 14–16 kg-cm / [12.2–13.9 lb-in.] / [1.4–1.6 Nm]



Loosen the screw and remove the top cover (figure 2). Screw torque: 24–26kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]





Figure 2

3. Disconnect the fan (figure 3).



4. Loosen the screw 1–4 (as shown below) and remove the fan. Make sure fan power is disconnected before removal. Screw torque: 24–26kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




Figure 4


# Fan model『MKC-HFKM1』Heat Sink Fan

#### Applicable model

Following models use three sets of MKC-HFKM1:

VFD4500CP63A-00; VFD4500CP63A-21; VFD5600CP63A-00; VFD5600CP63A-21; VFD6300CP63A-00; VFD6300CP63A-21

Loosen the screw 1-4 and remove the top cover 2. Loosen the screw and remove the top cover (figure (figure 1) Screw torque: 14-16 kg-cm / [12.2-13.9



2). Screw torque: 24-26kg-cm / [20.8-22.6 lb-in.] / [2.4-2.5 Nm]





Figure 2

3. Disconnect the fan (figure 3).



4. Loosen the screw 1–6 (as shown below) and remove the fan. Make sure fan power is disconnected before removal. Screw torque: 24-26kg-cm / [20.8-22.6 Ib-in.] / [2.4-2.5 Nm]




Figure 4

# 7-10 Flange Mounting Kit

Applicable Models, Frame A-F


#### Frame A

『MKC-AFM1』

Applicable model

VFD022CP23A-21; VFD022CP43B-21; VFD022CP4EB-21; VFD037CP23A-21; VFD015CP53A-21;

VFD022CP53A-21; VFD037CP53A-21



<sup>『</sup>MKC-AFM』


Applicable model

VFD007CP4EA-21; VFD015CP23A-21; VFD015CP43B-21; VFD015CP4EB-21; VFD022CP23A-21;

VFD037CP43B-21; VFD037CP4EB-21; VFD055CP23A-21; VFD040CP43A-21; VFD040CP4EA-21;

VFD055CP43B-21; VFD055CP4EB-21; VFD075CP43B-21; VFD075CP4EB-21





Install accessory 1 by fastening 4 of the screw 1(M3) (figure 1). Screw torque: 6–8 kg-cm / [5.21–6.94 lb-in.] / [0.6–0.8 Nm]




Figure 1

 Install accessory 2&3 by fastening 2 of the screw 2 (M6) (figure 2). Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm]




Figure 2

 Install accessory 2&3 by fastening 2 of the screw 2(M6) (figure 3). Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm]




Figure 3

 Plate installation, place 4 of the screw 2 (M6) (figure 4) through accessory 2&3 and the plate then fasten the screws. Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm]




Figure 4

# 『MKC-AFM』 Installation

1. Install accessory 2 & 3 by fastening 2 of the screw 2 (M6). Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm] (figure 1)




Figure 1

2. Install accessory 2 & 3 by fastening 2 of the screw 2 (M6). Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm] (figure 2)





Figure 2

3. Plate installation, place 4 of the screw \*4 (M6) through accessory 2&3 and the plate, then fasten the screws. Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm] (figure 3)



# $^{\mathbb{F}}\mathsf{MKC}\text{-BFM}\,_{\mathbb{Z}}$


# Applicable model


VFD075CP23A-21; VFD110CP23A-21; VFD110CP43B-21; VFD110CP4EB-21; VFD150CP23A-21;

VFD150CP43B-21; VFD150CP4EB-21; VFD185CP43B-21; VFD185CP4EB-21; VFD055CP53A-21;

VFD075CP53A-21; VFD110CP53A-21; VFD150CP53A-21







<sup>®</sup>MKC-BFM』Installation Install accessory 1& 2 by fastening 4 of the screw 1 (M8). Screw torque: 40-45 kg-cm / [34.7-39.0 lb-in.] / [3.9–4.4 Nm] (As shown in the following figure) SCREW 1 ACCESSORIES 1





Plate installation, place 6 of the screw 2 (M6) through accessory 1&2 and the plate, then fasten the screws. Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm] (As shown in the following figure)



# Frame C

『MKC-CFM』


Applicable model


VFD185CP23A-21; VFD220CP23A-21; VFD220CP43A-21; VFD220CP4EA-21; VFD300CP23A-21;

VFD300CP43B-21; VFD300CP4EB-21; VFD370CP43B-21; VFD370CP4EB-21; VFD185CP63A-21;

VFD220CP63A-21; VFD300CP63A-21; VFD370CP63A-21







『MKC-CFM』 Installation 1. Install accessory 1 & 2 by fastening 4 of the screw 1 (M8). Screw torque: 50-55 kg-cm / [43.4-47.7 lb-in.] / [4.9–5.4 Nm] (As shown in the following figure)






Plate installation, place 8 of the screw 2 (M6) through Accessory 1&2 and the plate, then fasten the screws. Screw torque: 25–30 kg-cm / [21.7–26 lb-in.] / [2.5–2.9 Nm] (As shown in the following figure)



Applicable model

VFD450CP43S-00; VFD450CP43S-21; VFD550CP43S-00; VFD550CP43S-21




# Frame D

Applicable model

VFD370CP23A-00; VFD370CP23A-21; VFD450CP23A-00; VFD450CP23A-21; VFD750CP43B-00;

VFD750CP43B-21; VFD900CP43A-00; VFD900CP43A-21; VFD450CP63A-00; VFD450CP63A-21;

VFD550CP63A-00; VFD550CP63A-21



# Frame E


# Applicable model

VFD550CP23A-00; VFD550CP23A-21; VFD750CP23A-00; VFD750CP23A-21; VFD900CP23A-00;

VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43B-00; VFD1320CP43B-21;


VFD750CP63A-00; VFD750CP63A-21; VFD900CP63A-00; VFD900CP63A-21; VFD1100CP63A-00;

VFD1100CP63A-21; VFD1320CP63A-00




# Frame D0 & D & E Installation


Loosen 8 screws and remove Fixture 2 (as shown in the following figure).




3. Fasten 4 screws (as shown in the following figure). Screw torque: 30–32 kg-cm / [26.0–27.8 lb-in.] / [2.9–3.1 Nm]




5. Fasten 4 screws (as shown in the following figure). Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




2. Loosen 10 screws and remove Fixture 1 (as shown in the following figure).



4. Fasten 5 screws (as shown in the following figure). Screw torque: 30–32 kg-cm / [26.0–27.8 lb-in.] / [2.9–3.1 Nm]




6. Fasten 5 screws (as shown in the following figure). Screw torque: 24–26 kg-cm / [20.8–22.6 lb-in.] / [2.4–2.5 Nm]




7. Place 4 screws (M10) through Fixture 1&2 and the plate then fasten the screws. (as shown in the following figure)


Frame D0/D M10\*4 Screw torque: 200–240 kg-cm / [173.6–208.3 lb-in.] / [19.6–23.5 Nm] Frame E M12\*4 Screw torque: 300–400 kg-cm / [260–347 lb-in.] / [29.4–39.2 Nm]



# Applicable model

VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43B-00; VFD1850CP43B-21; VFD1600CP63A-00; VFD1600CP63A-21; VFD2000CP63A-00; VFD2000CP63A-21





# 7-11 Power Terminal Kit

# <sup>®</sup> MKC-PTCG 』 (Applicable for Frame G models-VFDXXXCPXXA)


Applicable model

VFD2000CP43A-00/-21; VFD2200CP43A-00/-21; VFD2500CP43A-00/-21; VFD2800CP43A-00/-21; VFD2500CP63A-00/-21; VFD2500CP

VFD3150CP63A-00/-21

(The MKC-PTCG is optional for the above models, after installation, the 12 pulse will be 6 pulse.)


	Accessories			
Item Descrip		Description	Q'ty	
1		Copper Assy.	3	
	1.1	Copper	3	
	1.2	Screw M12*25L	6	
	1.3	Spring	6	
1.4		Washer	6	
	1.5	Nuts	6	






# 


1. Loosen the 4 screws on the cover, as shown in the following figure. Screw Torque: 12–15 kg-cm / [10.4–13 lb-in] / [1.2–1.5 Nm]



2. Remove the 5 screws from the FR4 board, as shown in the following figure. (The FR4 board is not needed after the installation of the power terminal kit). Screw Torque: 12–15 kg-cm / [10.4–13 lb-in] / [1.2–1.5 Nm]





3. Loosen the upper M8 nuts (1–6) with a sleeve wrench (12mm of the sleeve). M8 Torque: 90 kg / [78.1 lb-in] / [8.8 Nm]




4. Install the 3pcs copper assy., as shown in the following figure 1. Fasten the upper M8 nuts (1–6) with a sleeve wrench (12 mm of the sleeve), as shown in the figure 2 below.

M8 Torque: 180 kg-cm / [156.2 lb-in] / [17.65 Nm]





5. Put the cover back and fasten the screws as shown in the figure below. Screw Torque: 12–15 kg-cm / [10.4–13 lb-in] / [1.2–1.5 Nm]



# 7-12 USB/RS-485 Communication Interface IFD6530

# Warning


- ✓ Please thoroughly read this instruction sheet before installation and putting it into use.
- ✓ The content of this instruction sheet and the driver file may be revised without prior notice. Please consult our distributors or <u>download</u> the most updated instruction/driver version.

## Introduction

IFD6530 is a convenient RS-485-to-USB converter, which does not require external power-supply and complex setting process. It supports baud rate from 75 to 115.2 kbps and auto switching direction of data transmission. In addition, it adopts RJ45 in RS-485 connector for users to wire conveniently. And its tiny dimension, handy use of plug-and-play and hot-swap provide more conveniences for connecting all DELTA IABG products to your PC.

Applicable Models: All DELTA IABG products.

# (Application & Dimension)



# **Specifications**

Power supply	No external power is needed
Power consumption	1.5 W
Isolated voltage	2,500 V <sub>DC</sub>
Baud rate	75 Kbps, 150 Kbps, 300 Kbps, 600 Kbps, 1,200 Kbps, 2,400 Kbps, 4,800 Kbps, 9,600 Kbps, 19,200 Kbps, 38,400 Kbps, 57,600 Kbps, 115,200 Kbps
RS-485 connector	RJ45
USB connector	A type (plug)
Compatibility	Full compliance with USB V2.0 specification
Max. cable length	RS-485 Communication Port: 100 m
Support RS-485 half-duplex transmission	

Figure 7-88

#### RJ45



PIN	Description
1	Reserved
2	Reserved
3	GND
4	SG-


PIN	Description
5	SG+
6	GND
7	Reserved
8	+9V

# **Preparations before Driver Installation**


Extract the driver file (IFD6530\_Drivers.exe) by following steps. Download the driver file (IFD6530\_Drivers.exe) at www.deltaww.com/iadownload acmotordrive/IFD6530 Drivers.

NOTE DO NOT connect IFD6530 to PC before extracting the driver file.

#### STEP 1



#### STEP 2



#### STEP 3



STEP 4



#### STEP 5


You should have a folder marked SiLabs under drive C. c:\ SiLabs

# **Driver Installation**

After connecting IFD6530 to PC, please install driver by following steps.

×	
L	

# Chapter 7 Optional Accessories | CP2000



STEP 5
Repeat Step 1 to Step 4 to complete COM PORT setting.

# **LED Display**

- 1. Steady Green LED ON: power is ON.
- 2. Blinking orange LED: data is transmitting.

# **Revision Record**

If you need to contact the technical engineer of this product, please let them know the version of this user manual and firmware

Issue Edition: V02

Firmware Version: V2.03

Issue date:

Date	Page	Adding Content
2017/07/14	7-52	Table of Descriptions of LED Functions:
		Operation Direction LED under Torque Model
2017/07/14	7-67	Table of Appearance of the fan kit:
		Frame E_MKC-EFKM3 drawing and applicable model

Date	Page	Modify Content
2017/07/14	7-2	<ol> <li>Modify the Min. Resistor Value and Max. Total Braking Current in 230V Brake Resistors and Brake Units Selection Chart</li> <li>Adjust table format of the chart of 460V</li> </ol>
2017/07/14	7-3	Modify unit presentation of the selection chart
2017/07/14	7-4	Modify Note 3 of 690V selection chart:
		Change the surface temperature of 400W resistor from 50°C to 250°C
2017/07/14	7-6	Modify contents of point 2: Thermal Relay
2017/07/14	7-8	Complete the model number of 3-phase 690V chart
2017/07/14	7-9	<ul> <li>Modify contents of the table:</li> <li>460V Model number: from VFD450CP43S-00/S-21 to VFD450CP43S-00/43S-21</li> <li>Bussmann P/N of 460V Model VFD550CP43S-00/43S-21 (from JJS-225 to JJS-250)</li> </ul>
2017/07/14	7-11~13, 25, 27, 29~31, 33~34, 36~37, 51~52, 55~58, 63~66, 69~81, 83, 86, 90, 91, 93 & 94	Adjust table format     Modify contents in the table
2017/07/14	7-18	Modify content of Column G1-DR006A0405: from 805mm to 80.5mm
2017/07/14	7-41	EMC Filter: change the Applicable EMC Filter of Model VFD6300CP63A-00 / VFD6300CP63A-21 (from B84143B0600S021 to B84143B1000S021)
2017/07/14	7-71	Update Fan Kit drawing of Frame B&C
	7-11~12	Chapter 7-4: 1. Update diagram of AC input reactor installation 2. Update 3% & 5% reactor spec. of 200V~230V and 380V~460V models. 3. Add notes in above spec. chart.
2017/7/28	7-23~24	Update the DC reactor spec. of 200V~230V and 380C~460V models Add notes in above spec. chart.
	7-26	Remove column "Built-in DC reactor, and without adding input AC/DC reactor" from chart of Spec. of THDi
	7-27~28	AC output reactor: Update the reactor spec. and corresponded Delta part number of 200V~230V & 380V~460V models
2017/8/17	7-2~7-3	Update resistor spec. of 230V and 460V models
0047/0/04	7-65	Revise fan kit model for Frame A, applicable model VFD075CP43B/4EB-21, from MKC-AFKM2 to MKCB-AFKM2
2017/8/24	7-69	Revise fan kit model for Frame A, applicable model VFD075CP43B/4EB-21, from MKC-AFKM2 to MKCB-AFKM2

# Chapter 7 Optional Accessories | CP2000

	7-2	Update the Brake Resistors and Brake Units Selection Chart
	7-4	Update note 3 and note 4
	7-6	Update diagram of Thermal Relay
2017/8/31	7-23	DC reactor, update installation terminal: change from "terminal +1 and +2" to "terminal +2/DC+ and +1/DC+" Update diagram of "Wiring of DC reactor"
	7-32	Update diagram of "tr definition"
	7-40	Update the EMC filter spec. chart.
	7-29	Remove heavy load from 575V/690V spec.
	7-67	Update fan drawing of Frame A MKC-AFKM Add new column for Frame A MKC-AFKM2, add new fan drawing Adjust format of Frame B
	7-68	Update applicable model for Frame D, change VFD750CP43A-00/21 to VFD750CP43B-00/21
2017/9/5	7-69	Update applicable model for Frame E, add VFD550CP23A-00/21 and VFD750CP23A-00/21
	7-70	Add explanation for applicable models of Frame H: Below models use two MKC-HFKM fans
	7-82	Update drawing of Frame A
	7-86	Update drawing of Frame B
	7-88	Update/add drawing of Frame C
2017/9/7	7-31	Suggested motor shielding cable length, model 007, normal load of rated current, change the cable length from 2.8 to 1.7
2017/9/10	7-10	Add note 3: Short-circuit current rating (SCCR): Per UL508C, the drive is suitable for use on a circuit capable of delivering not more than 100kA symmetrical amperes (rms) when protected by fuses given in the fuse table.
2017/11/23	7-67~72	Add installation description to the Frame H conduit box.

Issue Edition: V03 Firmware Version: V2.06

Firmware Version: V2.06		
日期	頁碼	修正資訊
2010/6/5	7-3	註記*2 工作時間與 ED vs.煞車電流之關係,改成參考 "台達官網應用
2019/6/5		手冊"制動模組與制動電阻"章節。";煞車電流改為制動電流
		註記*3 與*4 順序對調·原*4 中 1000W 以上之電阻·表面溫度需低於
		600°C 改為 350°C
	7-5	更新圖 7-5(調整 XY 軸單位字型及位置)
	7-6	說明"無熔絲開關的電流額定必須介於 1.6~2.6 倍"後面加註
		(575V/690V 機種為 2~4 倍)
	7-8	刪除說明"短路電流額定值(SCCR):依據 UL508C,搭配保險絲適用於
		短路容量 100kA 以下之電源系統。"
	7-10	更新輸入 AC 電抗器安裝示意圖(圖 7-6)
	7-xx	刪除章節 7-7 數位操作器
	7-49	適用於數位操作器(KPC-CC01 與 KPC-CE01)· 刪除 KPC-CE01
		更新平盤安裝示意圖(刪除 KPC-CE01)
	7-50	更新凸盤安裝及平盤安裝示意圖(刪除 KPC-CE01)
	7-53	框號 H 適用機種增加 VFD5600CP43A-00; VFD6300CP43A-00;
		VFD5600CP43C-21; VFD6300CP43C-21
	7-70	框號 C 風扇增加"散熱片風扇型號 MKC-CFKM1"、"電容風扇型號

<b>21</b> 為 三顆風
為
為
為
三顆風
OC .
調整章
 21 之無
21 之保
21 之
 <b>21</b> 之
及資訊

日期	真碼	修正資訊
	7-13~29	更新 AC 輸入電抗器外觀圖示與規格(宗男 2019/4/19 提供)
	7-31	更新 DC 電抗器外觀圖示與規格(宗男 2019/4/19 提供)
	7-33	THDi 規格表增加"無加裝輸入 AC 電抗器"欄位
		更新 AC 輸出電抗器安裝方式示意圖
	7-35	新增 460V 560, 630kW 機種之 AC 輸出電抗器型號及規格(宗男
		2019/4/19 提供)
	7-37~45	新增 AC 輸出電抗器外觀圖示及規格(宗男 2019/4/19 提供)
	7-47	新增 460V 560, 630kW 機種之馬達配線長度(宗男 2019/4/29 提供)
	7-51	新增 460V 560, 630kW 機種之正弦波濾波器建議規格( 宗男 2019/4/29
		提供)
	7-56	新增 460V EMC 濾波器評價表格(紀宏 2019/4/26 提供)
	7-xx	調整圖片及表格編碼
	7-2	補上新增 560, 630kW 機種對應之制動電阻規格
	7-6~7	新增電磁接觸器/空氣斷路器選型表
0040/0/00	7.0.7.7	230V 系列新增框號 A~C 的 MC/ACB 選型; 460V 系列新增框號 A~D0
2019/6/20	7-6~7-7	的 MC/ACB 選型
	7-10~11	調整表格欄寬
2019/6/24	7-37	更新 AC 輸出電抗器之說明(Ref. mail C2000 使用手冊_章節 7-4_AC
2019/0/24	7-37	/ DC 電抗器 Aly 20190401)
2019/06/25	7-35~36	新增 575V/690V DC 電抗器規格表
2019/6/26	7-122	新增下載驅動程式之超連結,並刪除原本所列網址
	7-123	將驅動程式安裝說明中的"隨機所附 CD"改為官網下載短網址
	7-5	加上 Braking Modules Instruction Sheet 下載連結
	7-80	更新框號 E 管線盒拆裝示意圖 (移除通風孔)
	7-82~83	更新框號 G 管線盒拆裝示意圖 (移除通風孔)
2019/7/11	7-101	更新框號 E 風扇拆裝示意圖 (移除通風孔)
2019/1/11	7-102	更新風扇 MKC-FFKM 拆裝步驟 1 螺絲扭力值
		更新風扇 MKC-FFKB 拆裝步驟 3 螺絲扭力值
	7-103	更新框號 G 風扇拆裝示意圖 (移除通風孔)
2020/7/14	7-12	保險絲規格 KYU-1000 改為 KTU-1000 ( mail: 【手冊校稿】CP2000_V2.07_
2020/1/17	1-12	手冊 V01_Mario_20200713)
2020/7/23	7-43~46	輸出電抗器規格表中,電抗器料號欄位名稱 "Input AC reactor" 更正為 "Output AC reactor"
	7-63~65	更新零相電抗器型號(mail: 【手冊校稿】CP2000_V2.07_手冊
2020/7/29		V01_20200729 )
		J

# Chapter 8 Option Cards


- 8-1 Option Card Installation
- 8-2 EMC-D42A -- Extension card for 4-point digital input / 2-point digital input
- 8-3 EMC-D611A -- Extension card for 6-point digital input (110V<sub>AC</sub> input voltage)
- 8-4 EMC-R6AA -- Relay output extension card (6-point N.O. output contact)
- 8-5 EMC-BPS01 -- +24V power card
- 8-6 EMC-A22A -- Extension card for 2-point analog input / 2-point analog output
- 8-7 CMC-PD01 -- Communication card, PROFIBUS DP
- 8-8 CMC-DN01 -- Communication card, DeviceNet
- 8-9 CMC-EIP01 -- Communication card, EtherNet/IP
- 8-10 CMC-PN01 -- Communication card, PROFINET
- 8-11 eZVFD-CC -- Communication card, BACnet Ethernet / BACnet IP
- 8-12 EMC-COP01 -- Communication card, CANopen
- 8-13 Delta Standard Fieldbus Cables


#### Chapter 8 Option Cards | CP2000


- Select applicable option cards for your drive or contact local distributor for suggestion.
- To prevent damage to the drive during installation, remove the digital keypad and the cover before wiring. Refer to the following instruction.
- The option card does not support hot swap function. Turn the power off before installing or removing the option card.

# 8-1 Option Card Installation


## 8-1-1 Remove the top cover







# 8-1-2 Option Card Installation Location




- 1 RJ45 (Socket) for digital keypad KPC-CC01 Refer to Section 10 for more details on digital keypad. Refer to Section 10 for more details on optional accessory RJ45 extension cable.
- 2 Communication extension card (Slot 1)
  CMC-PD01; CMC-DN01; CMC-EIP01; EMC-COP01;
  CMC-PN01
- 3 I/O & Relay extension card (Slot 3)
  EMC-D42A; EMC-D611A; EMC-A22A; EMC-R6AA;
  EMC-BPS01
- 4 PG Card (Slot 2) \*\*CP2000 do not support PG card.


# Screws Specification for optional card terminals:

EMC-D42A; EMC-D611A; EMC-BPS01	Wire gauge	0.2–0.5 mm <sup>2</sup> [26–20 AWG ]
ENIC-D42A, ENIC-D011A, ENIC-BF301	Torque	5 kg-cm / [4.4 lb-in.] / [0.5 Nm]
EMC-R6AA	Wire gauge	0.2–0.5 mm <sup>2</sup> [26–20 AWG ]
EIVIC-ROAA	Torque	8 kg-cm / [7 lb-in.] / [0.8 Nm]
EMC ASSA	Wire gauge	0.2–4 mm <sup>2</sup> [24–12 AWG]
EMC-A22A	Torque	5 kg-cm / [4.4 lb-in] / [0.5 Nm]

# Communication extension card (Slot 1)




# I/O / Relay extension card & 24V Power extension card (Slot 3)




## 8-1-3 Install and Uninstall of Extension Cards

## 8-1-3-1 Installation


Communication card: EMC-COP01, CMC-EIP01, CMC-DN01, CMC-PD01, CMC-PN01





As shown in the figure on the left. Put the isolation sheet into the positioning pin. Aim the two holes at the positioning pin. Press the pin to clip the holes with the PCB.



As shown in the figure on the left. Fasten the screws after the PCB is clipped with the holes.











As shown in the figure on the left, installation is completed.

## I/O & Relay Card: EMC-D42A, EMC-D611A, EMC-R6AA, EMC-BPS01, EMC-A22A











As shown in the figure on the left, installation is completed.


## 8-1-3-2 Disconnect the extension card

Communication Card: EMC-COP01, CMC-EIP01, CMC-DN01, CMC-PD01, CMC-PN01






As shown in the figure on the left. Twist to open the clip. Insert a slot type screwdriver into the hollow to prize the PCB off the clip.




Twist to open the other clip to remove the PCB.

## Chapter 8 Option Cards | CP2000


## I/O & Relay Card: EMC-D42A, EMC-D611A, EMC-R6AA, EMC-BPS01, EMC-A22A



Remove the two screws as shown in the figure on the left.



As shown in the figure on the left.
Twist to open the clip.
Insert a slot type screwdriver into the hollow to prize the PCB off the clip.



Twist to open the other clip to remove the PCB, as shown in the figure on the left.

# 8-2 EMC-D42A -- Extension card for 4-point digital input / 2-point digital input

	Terminals	Descriptions
	СОМ	Common for Multi-function input terminals
		Select SINK (NPN) / SOURCE (PNP) in J1 jumper / external power
		supply
		Refer to Pr.02-26–Pr.02-29 to program the multi-function inputs
		MI10–MI13.
		Internal power is applied from terminal E24: +24 V <sub>DC</sub> ± 5% 200 mA,
	MI10-MI13	5 W
		External power +24 V <sub>DC</sub> : max. voltage 30 V <sub>DC</sub> , min. voltage 19 V <sub>DC</sub>
		ON: the activation current is 6.0 mA
		OFF: leakage current tolerance is 10 μA
I/O Extension	MO10-MO11	Multi-function output terminals (photocoupler)
Card		The AC motor drive releases various monitor signals, such as drive
		in operation, frequency attained and overload indication, via
		transistor (open collector).
		MO10
		MO11
		□ MXM
	MXM	Common for multi-function output terminals MO10, MO11 (photo
		coupler)
		Max 48 V <sub>DC</sub> 50 mA

# **8-3 EMC-D611A** -- Extension card for 6-point digital input (110V<sub>AC</sub> input voltage)

2 2 1112 2 2 1111 Extension said for a point alguer input (110 vita input votage)			
	Terminals	Descriptions	
	AC	AC power Common for multi-function input terminal (Neutral)	
		Refer to Pr.02-26–Pr.02-31 for multi-function input selection	
I/O Extension		Input voltage: 100–130 V <sub>AC</sub>	
I/O Extension Card		Input frequency: 47–63 Hz	
		Input impedance: 27 kΩ	
		Terminal response time:	
		ON: 10 ms	
		OFF: 20 ms	

# 8-4 EMC-R6AA


	Terminals	Descriptions
Relay Extension Card	RA10-RA15 RC10-RC15	Refer to Pr.02-36–Pr.02-41 for multi-function relay selection Resistive load: $3 \text{ A (N.O.) / } 250 \text{ V}_{AC}$ $5 \text{ A (N.O.) / } 30 \text{ V}_{DC}$ Inductive load (COS 0.4) $1.2 \text{ A (N.O.) / } 250 \text{ V}_{AC}$ $2.0 \text{ A (N.O.) / } 30 \text{ V}_{DC}$ It is used to output each monitor signal, such as drive is in operation, frequency attained or overload indication.

# **8-5 EMC-BPS01** -- +24V power card

	Terminals	Descriptions
		Input power: 24 V ± 5%
		Maximum input current: 0.5 A
		Note:
		Do not connect drive control terminal GND directly to the
		EMC-BPS01 input terminal GND.
		Function: When the drive is only powered by EMC-BPS01, the
External Power		communication can be assured and support all communication
Supply	24V	cards and following functions:
Supply	GND	Parameters read and write
		Keypad can be displayed
		Keypad button can be operated (except RUN)
		Analog input is effective
		Multi-input (FWD, REV, MI1–MI8) needs external power supply to
		operate
		Following functions are not supported :
		Relay output (including extension card), PG card, PLC function

# **8-6 EMC-A22A** -- Extension card for 2-point analog input / 2-point analog output

# 8-6-1 Product File



- 1. Screw fixing hole
- 2. Positioning hole
- 3. POWER indicator
- 4. Switch
- 5. Fool-proof groove
- 6. Terminal block
- 7. AC motor drive connection port

## 8-6-2 Terminal Specification

8-6-2 Terminal S	Terminals	Descriptions	
	Terrilliais	Refer to Pr.14-00–Pr.14-01 for function selection (input), and	
		Pr.14-18—Pr.14-19 for mode selection.	
		There are two sets of AI port, SSW3 (AI10) and SSW4 (AI11), which can be	
		switched to Voltage or Current mode.	
		Voltage mode: Input 0–10 V	
		Current mode: Input 0–20 mA / 4–20 mA	
		Analog voltage frequency	
		command Impedance: 20 kΩ	
		Range: 0–10 V = 0–Max. Output Frequency	
	Al10, Al11	+10V +10V (Pr.01-00)	
		h   AVI1   ]	
Analog I/O		Switch: Al10 / Al11 Switch, default 0–10 V	
Extension Card		Internal circuit	
		Analog current frequency	
		command Impedance: 250 Ω	
		ACI ACI circuit Range: 0–20 mA / 4–20 mA = 0–Max. Output	
		Frequency (Pr.01-00)	
		Switch: AI10 / AI11 Switch, default 0–10 V	
		ACM Internal circuit	
		Refer to Pr.14-12–Pr.14-13 for function selection (output), and	
		Pr.14-36–Pr.14-37 for mode selection.	
	AO10, AO11	There are two sets of AO port, SSW1 (AO10) and SSW2 (AO11), which can	
		be switched to Voltage or Current mode.	
		Voltage mode: Output 0–10 V	
		Current mode: Output 0-20 mA / 4-20 mA	

# Chapter 8 Option Cards | CP2000


	Multi-function analog	AVO:
	output	0–10 V Max. output current 2 mA, Max. load 5 kΩ
	N 1010 a .	Output current: 2 mA max
	AO10	Resolution: 0–10 V corresponds to Max.
	ACM	operation frequency
	1 1 1 1 1	Switch: AO10 / AO11 Switch, default 0–10 V
	AO11	ACO:
	<b>⊕</b> E <b>O</b> ─	0–20 mA Max. Load 500 Ω
		Output current: 20 mA max
		Resolution: 0–20 mA / 4–20 mA corresponds to
		Max. operation frequency
		Switch: AO10 / AO11 Switch, default 0–10 V
ACM	Analog Signal Common	Common for analog terminals

# 8-7 CMC-PD01 -- Communication card, PROFIBUS DP

# 8-7-1 Features

- 1. Supports PZD control data exchange.
- 2. Supports PKW polling AC motor drive parameters.
- 3. Supports user diagnosis function.
- 4. Auto-detects baud rates; supports Max. 12 Mbps.

## 8-7-2 Product Profile



- 1. NET indicator
- 2. POWER indicator
- 3. Positioning hole
- 4. AC motor drive connection port
- 5. PROFIBUS DP connection port
- 6. Screw fixing hole
- 7. Fool-proof groove

# 8-7-3 Specifications

## PROFIBUS DP Connector

Interface	DB9 connector
Transmission method	High-speed RS-485
Transmission cable	Shielded twisted pair cable
Electrical isolation	500 V <sub>DC</sub>

## Communication

Message type	Cyclic data exchange
Module name	CMC-PD01
GSD document	DELA08DB.GSD
Company ID	08DB (HEX)
Serial transmission speed supported	9.6 Kbps; 19.2 Kbps; 93.75 Kbps; 187.5 Kbps; 500 Kbps; 1.5 Mbps; 3 Mbps;
(auto-detection)	6 Mbps; 12 Mbps (bit /per second)

## **Electrical Specification**

Power supply voltage	5 V <sub>DC</sub> (supplied by AC motor drive)
Insulation voltage	500 V <sub>DC</sub>
Power consumption	1 W
Weight	28 g


## Environment

Noise immunity	ESD (IEC 61800-5-1, IEC 61000-4-2)  EFT (IEC 61800-5-1, IEC 61000-4-4)  Surge Teat (IEC 61800-5-1, IEC 61000-4-5)  Conducted Susceptibility Test (IEC 61800-5-1, IEC 61000-4-6)
Operation /storage	Operation: -10°C–50°C (temperature), 90% (humidity) Storage: -25°C–70°C (temperature), 95% (humidity)
Shock / vibration resistance	International standards: IEC61131-2, IEC60068-2-6 (TEST Fc) / IEC61131-2 & IEC60068-2-27 (TEST Ea)

## 8-7-4 Installation

## PROFIBUS DP Connector

PIN	PIN name	Definition
1	-	Not defined
2	-	Not defined
3	Rxd/Txd-P	Sending/receiving data P(B)
4	-	Not defined
5	DGND	Data reference ground
6	VP	Power voltage – positive
7	-	Not defined
8	Rxd/Txd-N	Sending/receiving data N(A)
9	-	Not defined



# 8-7-5 LED Indicator & Troubleshooting

There are 2 LED indicators on CMC-PD01: POWER LED and NET LED. POWER LED displays the status of the working power. NET LED displays the connection status of the communication.

## POWER LED

. 01121122			
	LED status	Indication	How to correct it
	Green light ON	Power supply in normal status.	
	OFF	No power	Check if the connection between CMC-PD01 and AC motor drive is normal.

## **NET LED**


LED status	Indication	How to correct it
Green light ON	Normal status	
Red light ON	CMC-PD01 is not connected to PROFIBUS DP bus.	Connect CMC-PD01 to PROFIBUS DP bus.
Red light flashes	Invalid PROFIBUS communication address	Set the PROFIBUS address of CMC-PD01 between 1–125 (decimal)
Orange light flashes	CMC-PD01 fails to communicate with AC motor drive.	Switch off the power and check whether CMC-PD01 is correctly and normally connected to AC motor drive.

# 8-8 CMC-DN01 -- Communication card, DeviceNet

## 8-8-1 Functions

- 1. Based on the high-speed communication interface of Delta HSSP protocol, able to conduct immediate control to AC motor drive.
- 2. Supports Group 2 only connection and polling I/O data exchange.
- 3. For I/O mapping, supports Max. 32 words of input and 32 words of output.
- 4. Supports EDS file configuration in DeviceNet configuration software.
- 5. Supports all baud rates on DeviceNet bus: 125 Kbps, 250 Kbps, 500 Kbps and extendable serial transmission speed mode.
- 6. Node address and serial transmission speed can be set up on AC motor drive.
- 7. Power supplied from AC motor drive.

## 8-8-2 Product Profile



1. NS indicator
2. MS indicator
3. POWER indicator
4. Positioning hole

- 5. DeviceNet connection port
- 6. Screw fixing hole
- 7. Fool-proof groove
- 8. AC motor drive connection port

## 8-8-3 Specifications

#### **DeviceNet Connector**

Interface	5-PIN open removable connector of 5.08 mm PIN interval
Transmission method	CAN
Transmission cable	Shielded twisted pair cable (with 2 power cables)
Transmission speed	125 Kbps, 250 Kbps, 500 Kbps and extendable serial transmission speed mode
Network protocol	DeviceNet protocol

#### **AC Motor Drive Connection Port**

Interface	50 PIN communication terminal
Transmission method	SPI communication
Terminal function	Communicating with AC motor drive     Transmitting power supply from AC motor drive
Communication protocol	Delta HSSP protocol

## **Electrical Specification**

Power supply voltage	5 V <sub>DC</sub> (supplied by AC motor drive)
Insulation voltage	500 V <sub>DC</sub>
Communication wire power consumption	0.85 W
Power consumption	1 W
Weight	23 g


## Environment

	ESD (IEC 61800-5-1,IEC 61000-4-2)	
Noise immunity	EFT (IEC 61800-5-1,IEC 61000-4-4)	
Noise immunity	Surge Test (IEC 61800-5-1,IEC 61000-4-5)	
	Conducted Susceptibility Test (IEC 61800-5-1,IEC 61000-4-6)	
Operation /storage	Operation: -10°C–50°C (temperature), 90% (humidity)	
Operation /storage	Storage: -25°C–70°C (temperature), 95% (humidity)	
Shock / vibration resistance	International standards: IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-27	

## 8-8-4 Installation

## **DeviceNet Connector**

PIN	Signal	Color	Definition
1	V+	Red	DC24V
2	Н	White	Signal+
3	S	-	Earth
4	L	Blue	Signal-
5	V-	Black	0V



# 8-8-5 LED Indicator & Troubleshooting

There are 3 LED indicators on CMC-DN01: POWER LED, MS LED and NS LED. POWER LED displays the status of power supply. MS LED and NS LED are dual-color LED, displaying the connection status of the communication and error messages.

## **POWER LED**

LED status	Indication	How to correct it
OFF	Power supply in abnormal status.	Check the power supply of CMC-DN01.
Green light ON Power supply in normal status		

# **NS LED**

LED status	Indication	How to correct it	
OFF	No power supply or CMC-DN01 has not completed MAC ID test yet.	<ol> <li>Check the power of CMC-DN01 and see if the connection is normal.</li> <li>Make sure at least one or more nodes are on the bus.</li> <li>Check if the serial transmission speed of CMC-DN01 is the same as that of other nodes.</li> </ol>	
Green light flashes	CMC-DN01 is on-line but has not established connection to the master.	<ol> <li>Configure CMC-DN01 to the scan list of the master.</li> <li>Re-download the configured data to the master.</li> </ol>	
Green light ON	CMC-DN01 is on-line and is normally connected to the master		
Red light flashes	CMC-DN01 is on-line, but I/O connection is timed-out.	<ol> <li>Check if the network connection is normal.</li> <li>Check if the master operates normally.</li> </ol>	
Red light ON	<ol> <li>The communication is down.</li> <li>MAC ID test failure.</li> <li>No network power supply.</li> <li>CMC-DN01 is off-line.</li> </ol>	<ol> <li>Make sure all the MAC IDs on the network are not repeated.</li> <li>Check if the network installation is normal.</li> <li>Check if the baud rate of CMC-DN01 is consistent with that of other nodes.</li> <li>Check if the node address of CMC-DN01 is illegal.</li> <li>Check if the network power supply is normal.</li> </ol>	

# MS LED


LED status	Indication	How to correct it	
OFF	No power supply or being off-line	Check the power supply of CMC-DN01 and see if the connection is normal.	
Green light flashes	Waiting for I/O data	Switch the master PLC to RUN status	
Green light ON	I/O data are normal		
Red light flashes	Mapping error	Reconfigure CMC-DN01     Re-power AC motor drive	
Red light ON	Hardware error	<ol> <li>See the error code displayed on AC motor drive.</li> <li>Send back to the factory for repair if necessary.</li> </ol>	
Orange light flashes	CMC-DN01 is establishing connection with AC motor drive.	If the flashing lasts for a long time, turn off the power and check if CMC-DN01 and AC motor drive are correctly installed and normally connected to each other.	

# 8-9 CMC-EIP01 -- Communication card, EtherNet/IP

## 8-9-1 Features

- 1. Supports Ethernet/IP and Modbus TCP protocol
- 2. User-defined corresponding parameters (EIP V1.06 and above)
- 3. Simple firewall function for IP Filter
- 4. MDI/MDI-X auto-detect
- 5. Baud rate: 10/100 Mbps auto-detect mail alarm

## 8-9-2 Product Profile



# [Figure1]

- 1. Screw fixing hole
- 2. Positioning hole
- 3. AC motor drive connection port
- 4. LINK indicator
- 5. RJ45 connection port
- 6. POWER indicator
- 7. Fool-proof groove

# 8-9-3 Specifications

## **Network Interface**

Interface	RJ45 with Auto MDI/MDIX
Number of ports	1 Port
Transmission method	IEEE 802.3, IEEE 802.3u
Transmission cable	Category 5e shielding 100M
Transmission speed	10/100 Mbps Auto-Detect
Network protocol	ICMP, IP, TCP, UDP, DHCP, BOOTP, SMTP, EtherNet/IP, Modbus TCP

## **Electrical Specification**

Weight	25 g
Insulation voltage	500 V <sub>DC</sub>
Power consumption	0.8 W
Power supply voltage	5 V <sub>DC</sub>


#### **Environment**

	ESD (IEC 61800-5-1, IEC 61000-4-2)
Noise immunity	EFT (IEC 61800-5-1, IEC 61000-4-4)
Noise infillulity	Surge Test (IEC 61800-5-1, IEC 61000-4-5)
	Conducted Susceptibility Test (IEC 61800-5-1, IEC 61000-4-6)
Operation/storage	Operation: -10°C–50°C (temperature), 90% (humidity)
Operation/storage	Storage: -25°C–70°C (temperature), 95% (humidity)
Vibration/shock immunity	International standard: IEC 61800-5-1, IEC 60068-2-6/IEC 61800-5-1, IEC 60068-2-27

## 8-9-4 Installation

Connecting CMC-EIP01 to Network

- 1. Turn off the power of AC motor drive.
- 2. Open the cover of AC motor drive.
- Connect CAT-5e network cable to RJ45 port on CMC-EIP01 (See the figure on the right).



#### **RJ45 PIN Definition**

PIN	Signal	Definition
1	Tx+	Positive pole for data transmission
2	Tx-	Negative pole for data transmission
3	Rx+	Positive pole for data receiving
4		N/C

PIN	Signal	Definition
5		N/C
6	Rx-	Negative pole for data receiving
7	-	N/C
8		N/C



# 8-9-5 Communication Parameters for CP2000 Connected to Ethernet

When the CP2000 is connected to an Ethernet network, set up the communication parameters for it according to the table below. The Ethernet master is only able to read/write the frequency word and control word of CP2000 after the communication parameters are set.

Parameter	Function	Set value (Dec)	Explanation
Pr.00-20	Source of frequency command setting	8	The frequency command is controlled by communication card.
Pr.00-21	Source of operation command setting	5	The operation command is controlled by communication card.
Pr.09-30	Decoding method for communication	0	The decoding method for Delta AC motor drive
Pr.09-75	IP setting	0	Static IP(0) / Dynamic distribution IP(1)
Pr.09-76	IP address -1	192	IP address 192.168.1.5
Pr.09-77	IP address -2	168	IP address 192.168.1.5
Pr.09-78	IP address -3	1	IP address 192.168.1.5
Pr.09-79	IP address -4	5	IP address 192.168.1.5

## Chapter 8 Option Cards | CP2000

Parameter	Function	Set value (Dec)	Explanation
Pr.09-80	Netmask -1	255	Netmask 255.255.255.0
Pr.09-81	Netmask -2	255	Netmask 255.255.255.0
Pr.09-82	Netmask -3	255	Netmask 255.255.255.0
Pr.09-83	Netmask -4	0	Netmask 255.255.255.0
Pr.09-84	Default gateway -1	192	Default gateway 192.168.1.1
Pr.09-85	Default gateway -2	168	Default gateway 192.168.1.1
Pr.09-86	Default gateway -3	1	Default gateway 192.168.1.1
Pr.09-87	Default gateway -4	1	Default gateway 192.168.1.1

# 8-9-6 LED Indicator & Troubleshooting

There are 2 LED indicators on CMC-EIP01: POWER LED and LINK LED. The POWER LED displays the status of power supply, and the LINK LED displays the connection status of the communication.

## **LED Indicators**

LED	Status		Indication	How to correct it
POWER	Green	ON	Power supply in normal status	
POWER	Green	OFF	No power supply	Check the power supply.
	ON	Network connection in normal status		
LINK	Green	Flashes	Network in operation	
	OFF	Network not connected	Check if the network cable is connected.	

# Troubleshooting

Abnormality	Cause	How to correct it
DOWER LED OFF	AC motor drive not powered	Check if AC motor drive is powered, and if the power supply is normal.
POWER LED OFF	CMC-EIP01 not connected to AC motor drive	Make sure CMC-EIP01 is connected to AC motor drive.
LINIK LED OFF	CMC-EIP01 not connected to network	Make sure the network cable is correctly connected to network.
LINK LED OFF	Poor contact to RJ45 connector	Make sure RJ45 connector is connected to Ethernet port.
	CMC-EIP01 not connected to network	Make sure CMC-EIP01 is connected to network.
No communication card found	PC and CMC-EIP01 in different networks and blocked by network firewall.	Search by IP or set up relevant settings by AC motor drive keypad.
	CMC-EIP01 not connected to network	Make sure CMC-EIP01 is connected to the network.
Fail to open CMC-EIP01 setup page	Incorrect communication setting in DCISoft	Make sure the communication setting in DCISoft is set to Ethernet.
	PC and CMC-EIP01 in different networks and blocked by network firewall.	Conduct the setup by AC motor drive keypad.

# Chapter 8 Option Cards | CP2000

Abnormality	Cause	How to correct it
Able to open CMC-EIP01 setup page but fail to utilize webpage monitoring	Incorrect network setting in CMC-EIP01	Check if the network setting for CMC-EIP01 is correct. For the Intranet setting in your company, consult your IT staff. For the Internet setting in your home, refer to the network setting instruction provided by your ISP.
	Incorrect network setting in CMC-EIP01	Check if the network setting for CMC-EIP01 is correct.
Fail to send e-mail	Incorrect mail server setting	Confirm the IP address for SMTP-Server.

## 8-10 CMC-PN01 - Communication card, PROFINET


#### 8-10-1 Features


CMC-PN01 connects CP2000 to PROFINET, so the drive is able to exchange data with the upper unit. It is a simple NET solution, which can reduce the cost and time of connection/ installing factory automation, also provide compatibility of similar components from multiple suppliers.

Connect CMC-PN01 to CP2000 via PROFINET device:

- 1. Control the AC motor drive via PROFINET
- 2. Change the drive parameters via PROFINET
- 3. Monitor the drive status via PROFINET

#### 8-10-2 Product Profile





1. Screw fixing hole
2. Positioning hole
Ready out indicator
4. MT out indicator
5. SD indicator
6. BF out indicator
7. ACT PHY2 indicator
8. Link PHY2 indicator
9. ACT PHY1 indicator
10. Link PHY1 indicator
11. Switch
12.Fool-proof groove
13. RJ45 connection port
(Port 2)
<ol><li>14. RJ45 connection port</li></ol>
(Port 1)
15. Connection port of

control board

MAC Address label definition

5503092600 MAC1: 0018233C0043 MAC2: 0018233C0044 MAC3: 0018233C0045 ACRNAR000189

Def.	Explanation
MAC1	Port 1 MAC Address
MAC2	Port 2 MAC Address
MAC3	Interface MAC Address

# 8-10-3 Specifications

# **Network Interface**

Interface	RJ45
Number of ports	2 ports
Transmission method	IEEE 802.3
Transmission cable	Category 5e shielding 100 M
Transmission speed	10/100 Mbps auto-negotiate
Network protocol	PROFINET

# **Electrical Specification**

Power supply voltage	5 V <sub>DC</sub>
Power consumption	0.8 W
Insulation voltage	500 V <sub>DC</sub>
Weight (g)	27

# Environment

Noise immunity	ESD (IEC 61800-5-1, IEC 61000-4-2) EFT (IEC 61800-5-1, IEC 61000-4-4) Surge Test (IEC 61800-5-1, IEC 61000-4-5) Conducted Susceptibility Test (IEC 61800-5-1, IEC 61000-4-6)
Operation	-10°C–50°C (temperature), 90% (humidity)
Storage	-25°C-70°C (temperature), 95% (humidity)
Vibration / Shock immunity	International standard: IEC 61800-5-1, IEC 60068-2-6 / IEC 61800-5-1, IEC 60068-2-27

# 8-10-4 RJ45 PIN Definition

RJ45	PIN No.	Signal	Definition
	1	Tx+	Positive pole for data transmission
	2	Tx-	Negative pole for data transmission
12345678	3	Rx+	Positive pole for data receiving
	4		N/C
	5		N/C
	6	Rx-	Negative pole for data receiving
	7		N/C
	8		N/C

# 8-10-5 Communication Parameters for CP2000 Conneted to PROFINET

When operating CP2000 via CMC-PN01, set the control and operation command as controlled by communication card. When CP2000 is connected to PROFINET network, set up the communication parameters according to the table below.


Parameter	Set value (Dec)	Explanation			
Pr.00-20	8	The frequency command is controlled by communication card.			
Pr.00-21	5	The operation command is controlled by communication card.			
Pr.09-30	1	Set Pr.09-30 to 60xx or 20xx as the decoding method.			
Pr.09-60	12	Identification: when CMC-PN01 is connected, Pr.09-60 will show value 12.			

## 8-10-6 LED Indicator

LED	Status		Indication
		ON	PN Stack operates in normal status
Ready out	Yellow	Flashes	PN Stack operates in normal status, and waiting to sync with MCU
		OFF	PN Stack operates with error
MT out	Green	-	-
SD	Red	-	-
		ON	Connection with PROFINET Controller breaks off
BF out	Red	Flashes	Connection is normal, but an error occurs to the communication with PROFINET Controller
		OFF	Connection with PROFINET Controller is normal
		ON	Online, exchanging data with the master
ACT PHY1	Orange	Flashes	Off line, but handshaking data with the master
		OFF	Initial status
		ON	Network connection is normal
LINK PHY1	Green	OFF	Network is not connected
		ON	On line, exchanging data with the master
ACT PHY2	Orange	Flashes	Off line, but handshaking data with the master
		OFF	Initial status
LINK PHY2	Green	ON	Network connection is normal
LIIVIN PH 12	Green	OFF	Network is not connected

## 8-10-7 Network Connection

Wiring of CMC-PN01 is as following:



When the hardware is installed and power on, the current set value of Pr.09-60 will be 12, and shows "PROFINET" on the display. If the above information does not show on the display, check the version of CP2000 and the connection of the card.




# 8-11 eZVFD-CC - Communication card, BACnet Ethernet/BACnet IP

#### 8-11-1 Features

The eZVFD-CC Integration Module provides BACnet/IP and BACnet over Ethernet communication to BACnet compliant devices. When used with a Delta Controls system, you can use the module's GCL+ programs and Delta Controls internal control loops to directly control pumps and fan motors. Quickly configure and save drive parameters in enteliWEB and load the saved configuration onto other CP2000 AC motor drives over the BACnet network. Features include:

- Native BACnet firmware
- BACnet/IP, BACnet over Ethernet communication protocols
- Fully programmable in GCL+ (Delta Controls General Control Language)
- Dual port ethernet to support daisy-chaining multiple CP2000 devices
- Monitor and utilize CP2000 AC motor drive I/O terminals as BACnet I/O
- Set up and configure using enteliWEB. Use enteliWEB to read, write, save and load CP2000 AC motor drive parameters.

#### 8-11-2 Product Profile



1. Screw fixing hole 1
2. Screw fixing hole 2
3. Positioning hole
4. Status and Power LED
5. Fool-proof groove

- 6. RJ45 Ethernet Port 1 7. RJ45 Ethernet Port 2
- AC motor drive connection port

MAC address is displayed in the IPS object in entelliWEB.

## 8-11-3 Specifications

#### **Network Interface**

Interface	RJ45
Number of ports	2 ports
Daisy chaining	Up to 30 devices (daisy chain is discontinued if drive is not powered)
Transmission method	IEEE 802.3
Transmission cable	10/100BaseT CAT5E/CAT6
Maximum length	100m (port-to-port)
Transmission speed	10/100 Mbps auto-negotiate
Network protocol	BACnet/IP or BACnet/Ethernet

# **Electrical Specification**

Power supply voltage	5 V <sub>DC</sub> (supplied by AC Motor Drive)		
Power consumption	< 2 W		
Insulation voltage	500 V <sub>DC</sub>		
Weight (g)	2.6g		
Technology	32-bit CPU, field upgradeable firmware, real-time clock with supercapacitor backup		

## Environment

Compliance	CE IEC 61800-3, EMC Standard for Variable Speed Drives LVD IEC 61800-5-1 Safety Requirements for Electrical Power Drive Sys	
Operation	0°C to 55°C (temperature), 10% to 95% RH (non-condensing)	
Storage	-25°C-70°C (temperature), 95% RH	

# 8-11-4 RJ45 PIN Definition

RJ45	PIN No.	Signal	Definition
	1	Tx+	Positive pole for data transmission
	2	Tx-	Negative pole for data transmission
12345678	3	Rx+	Positive pole for data receiving
	4		N/C
	5		N/C
	6	Rx-	Negative pole for data receiving
	7		N/C
	8		N/C

# 8-11-5 Communication Parameters for CP2000 Connected to eZVFD-CC BACnet Controller

When operating the CP2000 using the eZVFD-CC card you must set the parameters according to the table below:

Parameter	Function	Set value (Dec)	Explanation
Pr.00-20	Source of frequency command setting	8	The frequency command is controlled by communication card.
Pr.00-21	Source of operation command setting	5	The operation command is controlled by communication card.
Pr.09-30	Decoding method for communication	1	Decoding method 2 (Refer to address: 6000h – 60FFh)
Pr.09-60	Identification for Communication Card	Read-only	When eZVFD-CC is connected, Pr.09-60 will show value 8 (BACnet IP)

# Chapter 8 Option Cards | CP2000

The following parameters should be set according to your desired network configuration. The table below shows default values:

Parameter	Function	Default value (Dec)	Explanation
Pr.04-50	UDP port number	47808	UDP/IP communication port
Pr.04-51	BACnet network number	BACnet/Ethernet: 19999 BACnet/IP: 49999	Depends on setting of Pr.09-91
Pr.09-52	BACnet device address, low word (range 0-65535)	4100000 + (last 4 hex in MAC address in decimal)	This value is added to the value of Pr.09-53 * 65536
Pr.09-53	BACnet device address, high word (range 0-63)	-	This value is multiplied by 65536 and added to the value of Pr.09-52
Pr.09-75	IP setting	0	0: Static IP 1: Dynamic Distribution IP (DHCP)
Pr.09-91	BACnet IP or Ethernet	1	0: BACnet/ Ethernet 1: BACnet/IP

If static IP is chosen (Pr.09-75 = 0), then the following parameters must be set according to your local network configuration:


Parameter	Function	Set value (Dec)	Explanation
Pr.09-76	IP address -1	192	IP address 192.168.1.5
Pr.09-77	IP address -2	168	IP address 192.168.1.5
Pr.09-78	IP address -3	1	IP address 192.168.1.5
Pr.09-79	IP address -4	5	IP address 192.168.1.5
Pr.09-80	Netmask -1	255	Netmask 255.255.255.0
Pr.09-81	Netmask -2	255	Netmask 255.255.255.0
Pr.09-82	Netmask -3	255	Netmask 255.255.255.0
Pr.09-83	Netmask -4	0	Netmask 255.255.255.0
Pr.09-84	Default gateway -1	192	Default gateway 192.168.1.1
Pr.09-85	Default gateway -2	168	Default gateway 192.168.1.1
Pr.09-86	Default gateway -3	1	Default gateway 192.168.1.1
Pr.09-87	Default gateway -4	1	Default gateway 192.168.1.1


# 8-11-6 LED Indicator

Color	LED Pattern	Indication				
Red	On	Hardware startup before system is running				
Red	Blinks in a regular repeating pattern	Hardware failure				
Red	1 second on, 1 second off.					
Croon	Blinks in a regular repeating pattern	OK				
Green	1 second on, 1 second off.	OK				
Amber	Blinks at approx. 100 Hz	Flash loading Main from Boot				
Amber	On	Database saving or restoring from Flash				

# 8-12 EMC-COP01 -- Communication card, CANopen

# 8-12-1 Terminal Resistor Position





# 8-12-2 RJ45 PIN Definition



RS-485 socket

Pin	Pin name	Definition
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground/0V/V-
7	CAN_GND	Ground/0V/V-

# 8-12-3 Specifications

Interface	RJ45
Number of ports	1 Port
Transmission method	CAN
Transmission cable	CAN standard cable
Transmission speed	1 Mbps, 500 Kbps, 250 Kbps, 125 Kbps, 100 Kbps, 50 Kbps
Communication protocol	CANopen

# 8-13 Delta Standard Fieldbus Cables

Delta Cables	Part Number	Description	Length
	UC-CMC003-01A	CANopen Cable, RJ45 Connector	0.3 m
	UC-CMC005-01A	CANopen Cable, RJ45 Connector	0.5 m
	UC-CMC010-01A	CANopen Cable, RJ45 Connector	1 m
	UC-CMC015-01A	CANopen Cable, RJ45 Connector	1.5 m
CANopen Cable	UC-CMC020-01A	CANopen Cable, RJ45 Connector	2 m
	UC-CMC030-01A	CANopen Cable, RJ45 Connector	3 m
	UC-CMC050-01A	CANopen Cable, RJ45 Connector	5 m
	UC-CMC100-01A	CANopen Cable, RJ45 Connector	10 m
	UC-CMC200-01A	CANopen Cable, RJ45 Connector	20 m
DeviceNet Cable	UC-DN01Z-01A	DeviceNet Cable	305 m
Devicemet Cable	UC-DN01Z-02A	DeviceNet Cable	305 m
	UC-EMC003-02A	Ethernet/EtherCAT cable, Shielding	0.3 m
	UC-EMC005-02A	Ethernet/EtherCAT cable, Shielding	0.5 m
	UC-EMC010-02A	Ethernet/EtherCAT cable, Shielding	1 m
Ethernet / EtherCAT	UC-EMC020-02A	Ethernet/EtherCAT cable, Shielding	2 m
Cable	UC-EMC050-02A	Ethernet/EtherCAT cable, Shielding	5 m
	UC-EMC100-02A	Ethernet/EtherCAT cable, Shielding	10 m
	UC-EMC200-02A	Ethernet/EtherCAT cable, Shielding	20 m
	TAP-CN01	1 in 2 out, built-in 121Ω terminal resistor	1 in 2 out
CANopen / DeviceNet	TAP-CN02	1 in 4 out, built-in 121Ω terminal resistor	1 in 4 out
IAF	TAP-CN03	1 in 4 out, RJ45 connector, built-in 121Ω terminal resistor	1 in 4 out
PROFIBUS Cable	UC-PF01Z-01A	PROFIBUS DP Cable	305 m

[This page intentionally left blank]

# Chapter 9 Specifications

- 9-1 230V Models
- 9-2 460V Models
- 9-3 575V Models
- 9-4 690V Models
- 9-5 Environment for Operation, Storage and Transportation
- 9-6 Specification for Operation Temperature and Protection Level
- 9-7 Derating Curve for Ambient Temperature, Altitude and Carrier Frequency
- 9-8 Efficiency Curve

## 9-1 230V Models

		Frame	9	A					В			С		D		E			
Model: VFDCP23			007	015	022	037	055	075	110	150	185	220	300	370	450	550	750	900	
		Rate	d output hity [kVA]	2	3	4	6	8.4	12	18	24	30	36	42	58	72	86	110	128
		Rate	d output ent [A]	5	7.5	10	15	21	31	46	61	75	90	105	146	180	215	276	322
	uty	outp	ible motor ut [kW]	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90
	ight Duty	outp	ble motor ut [HP]	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100	125
	Ť		d tolerance		120% of rated current for 1 minute during every 5 minutes														
		freque	output ency [Hz]		599.00													400.00	
ating		Carrier frequency [kHz]				2	–15 (D	efault: 8	3)				2–10	(Defa	ult: 6)		(D	2–9 efault:	4)
*Output Rating		capac	d output sity [kVA]	1.2	2	3.2	4.4	6.8	10	13	20	26	30	36	48	58	72	86	102
*Out			Rated output current [A]		5	8	11	17	25	33	49	65	75	90	120	146	180	215	255
	ıty	Applicable motor output [kW]		0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	19	22	30	37	45	55	75
	Normal Duty	Applicable motor output [HP]		0.5	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100
	Norn	Overload	d tolerance		120% of rated current for 1 minute during every 5 minutes; 160% of rated current for 3 seconds during every 25 seconds														
		Max. output frequency [Hz]			599.00												400.00		
	•	Carrier frequency [kHz]			2–15 ( Default: 8) 2–10							(Defa	ult: 6)		2–9 (Default: 4)				
		Input	Light duty	6.4	9.6	15	22	25	35	50	65	83	100	116	146	180	215	276	322
ting	cu	rrent [A]	Normal duty	3.9	6.4	12	16	20	28	36	52	72	83	99	124	143	171	206	245
Input Rating		Rated vo		3 phase, 200–240 V <sub>AC</sub> [-15%– +10%], 50/60 Hz															
lubí		Operating ran	•	170–264 V <sub>AC</sub>															
	F	requency									47–6	3 Hz							
		Efficiency							97	'.8		. 00					98	3.2	
Power Factor Weight [Kg]				2	2.6 ± 0.3	3			5.4 ± 1	> 0		9.8 ± 1.	5	38.5	± 1.5	6	4.8 ± 1.	.5	
	(	Cooling m			ural ling				1			•	ooling						
	Е	Braking ch			····ʊ	l .		Frame /									above:		
		DC cho					F	rame A	, B, C:	Option					Fra	me D a	above: I	3uilt-in	3%
EMC Filter										Opti	ional								

NOTE

Table 9-1

- The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Chapter 9-7 Derating Curve of Ambient Temperature.
- Select the AC motor drive with capacity one grade larger for the impact load application.
- Refer to Chapter 9-6 Specification for Operation Temperature and Protection Level for the protection level of each model.
- \*The default setting is Light Duty, you can select Normal Duty and Light Duty by setting Pr.00-16.

# 9-2 460V Models

Frame			A								В			С			D0	
Mo Mo	odel odel	VFD(	CP43 CP4E	007	015	022	037	040	055	075	110	150	185	220	300	370	450	550
		Rated output capacity [kVA]		2.4	3.3	4.4	6.8	8.4	10.4	14.3	19	25	30	36	48	58	73	88
			tput current [A]	3	4.2*2	5.5*2	8.5*2	10.5	13 <sup>*2</sup>	18 <sup>*2</sup>	24*2	32*2	38*2	45	60*2	73*²	91	110
	uty	outp	ble motor ut [kW]	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45	55
	Light duty	Applicable motor output [HP] Overload tolerance		1	2	3	5	5	7.5	10	15	20	25	30	40	50	60	75
	긔			120% of rated current for 1 minute during every 5 minutes														
		freque	output ncy [Hz]		599.00													
rating		Carrier frequency [kHz]			ı		2	2–15 (D	efault: 8	)	ı	ı	ı		2–10	) (Defau	ılt: 6)	ı
*1 Output rating		Rated output capacity [kVA]		2.2	2.4	3.2	4.8	7.2	8.4	10.4	14.3	19	25	30	36	48	58	73
, O		Rated output current [A]		1.7	3.0	4.0	6.0	9.0	10.5	12	18	24	32	38	45	60	73	91
	uty	Applicable motor output [kW]		0.4	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37	45
	Normal duty	Applicable motor output [HP]		0.5	1	2	3	5	5	7.5	10	15	20	25	30	40	53	60
	Nor		d tolerance	120% of rated current for 1 minute during every 5 minutes; 160% of rated current for 3 seconds during every 25 seconds														
		Max. freque		599.00														
		Carrier t		2–15 (Default: 8)									2-10 (Default: 6)					
		Input	Light duty	4.3	6	8.1	12.4	16	20	22	26	35	42	50	66	80	91	110
nput rating	CL	irrent [A]	Normal duty	3.5	4.3	5.9	8.7	14	15.5	17	20	26	35	40	47	63	74	101
out ra		Rated vo	ency	3 phase, 380–480 V <sub>AC</sub> [-15%– +10%), 50/60 Hz														
ü			Itage range								3–528 \							
	F	requency									17–63 H	Z						
		Efficiency									97.8							
		Power fa					20.00				> 0.98	<i></i>			20.47	_	0.7	
	Weight [Kg]			Nat	ural	4	2.6 ± 0.3	)				5.4 ± 1			9.8 ± 1.5	)	27	I I
		Cooling me		coo	ling					Frame	A, B, C:	an coolii Built-in:	U					
		Braking ch	• •						F	rame D	0 above . B. C: 0	: Option	al					
		DC cho	ke					_	Fra	ame D0	above:	Built-in :	3%					
	EMC Filter						Frame Frame	ne A, B, e A, B, C	of VFD	(	CP43A	: no b	ilt-in; uilt-in;					
			Frame D0 above: Optional															

NOTE

Table 9-2

- The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Chapter 9-7 Derating Curve of Ambient Temperature.
- Select the AC motor drive with capacity one grade larger for the impact load application.

  Refer to Chapter 9-6 Specification for Operation Temperature and Protection Level for the protection level of each model.
- \*1 The default setting is Light Duty, you can select Normal Duty and Light Duty by setting Pr.00-16.
- \*2 It means the rated output current is for the models of Version B. (e.g. VFD015CP43**B**-21)

## **460V Models**

	F	rame	D		E		F	=	G				Н					
	Model VFD_	CP43	750	900	1100	1320	1600	1850	2000	2200	2500	2800	3150	3550	4000	5000	5600	6300
		Rated output capacity [kVA]	120	143	175	207	247	295	315	367	383	422	491	544	613	741	872	966
		Rated output current [A]	150*2	180	220	260*2	310	370*2	395	460	481	530	616	683	770	930	1094	1212
	ıty	Applicable motor output [kW]	75	90	110	132	160	185	200	220	250	280	315	355	400	500	560	630
	Light duty	Applicable motor output [HP]	100	125	150	175	215	250	270	300	340	375	425	475	530	675	750	850
	Ĕ	Overload capacity		120% of rated output current: 1 minute for every 5 minutes														
		Max. output frequency [Hz]	599.00								400.00	)						
*1Output rating	İ	Carrier Frequency [kHz]	2–10 (Default: 6)		2–9 (Default: 4)													
Outpu		Rated output capacity [kVA]	88	120	143	175	207	247	247	295	315	367	438	491	544	690	741	872
*		Rated output current [A]	110	150	180	220	260	310	310	370	395	460	550	616	683	866	930	1094
	luty	Applicable motor output [kW]	55	75	90	110	132	160	160	185	200	220	280	315	355	450	500	560
	Normal duty	Applicable motor output [HP]	75	100	125	150	175	215	215	250	270	300	375	425	475	600	675	850
		Overload capacity				120% of												
		Max. output frequency [Hz]	599	99 400														
		Carrier frequency [kHz]	2–10 (Default: 6)		2–9 (Default: 4)													
	Input	Light duty	150	180	220	260	310	370	395	460	481	530	616	683	770	930	1094	1212
ling	current [A]	Normal duty	114	157	167	207	240	300	300	380	390	400	494	555	625	866	930	1094
Input rating	Rated vo	ltage / frequency				3	3-phas	e 380-	480 V	<sub>AC</sub> [-15	%– +1	0%], 5	0/60 H	lz				
lubi	Operatin	ng voltage range							32	3–528	V <sub>AC</sub>							
	Freque	ency tolerance		47–63 Hz														
	Effici	iency [%]	97.8								98.2							
	Pow	er factor								> 0.98	3							
	Drive v	weight [Kg]	38.5 ±	£ 1.5	(	64.8 ±	1.5	86.5	± 1.5		134 ±	: 4			2	28		
	Coolir	ng method			•		•		Fa	n cool	ing							
	Brakin	ng chopper	Frame D–H: Optional															
	DC	choke		Frame D–H: Built-in 3%														
	EM	1C filter						F	rame	D–H: (	Option	al						

NOTE

- The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Chapter 9-7 Derating Curve of Ambient Temperature.
- Select the AC motor drive with capacity one grade larger for the impact load application.
- Refer to Chapter 9-6 Specification for Operation Temperature and Protection Level for the protection level of each model.
- \*1 The default setting is Light Duty, you can select Normal Duty and Light Duty by setting Pr.00-16.
- \*2 It means the rated output current is for the models of Version B. (e.g. VFD015CP43**B-**21)
- Model VFD5000CP43A-xx is not UL certified.

## 9-3 575V Models

		Fram	е		Α			E	3			
	Мо	del VFD	_CP53A-21	015	022	037	055	075	110	150		
		Rated outp	out capacity [kVA]	3	4.3	6.7	9.9	12.1	18.6	24.1		
	luty	Rated ou	tput current [A]	3	4.3	6.7	9.9	12.1	18.7	24.2		
	Light duty	Applicable motor output [kW]		1.5	2.2	3.7	5.5	7.5	11	15		
ting	ij	Applicable	motor output [HP]	2	3	5	7.5	10	15	20		
ıtra	_	Rated outp	out capacity [kVA]	2.5	3.6	5.5	8.2	10	15.4	19.9		
*Output rating	Normal duty	Rated ou	tput current [A]	2.5	3.6	5.5	8.2	10	15.4	20		
0	mal	Applicable motor output [kW]		0.75	1.5	2.2	3.7	5.5	7.5	11		
	Nor	Applicable motor output [HP]		1	2	3	5	7.5	10	15		
	Carrier frequency [kHz]		2–15 (Default: 4)									
			Light duty	3.8	5.4	10.4	14.9	16.9	21.3	26.3		
βL	Inpu	t current [A]	Normal duty	3.1	4.5	7.2	12.3	15	18	22.8		
Input rating	Rated voltage / Frequency		3-phase, 525–600 V <sub>AC</sub> [-15%– +10%] · 50/60 Hz									
put		Operating v	oltage range	446–660 V <sub>AC</sub>								
		Frequency	/ tolerance	47–63 Hz								
		Efficienc	y [%]		97			9	8			
		Power fa	actor				> 0.98					
	Weight [Kg]				3 ± 0.3		4.8 ± 1					
		Cooling m	nethod	Natural	cooling		•	Fan cooling				
		Braking ch		Frame A–B: Built-in								
		DC cho	oke	Frame A–B: Optional								

NOTE

- The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Chapter 9-7 Derating Curve of Ambient Temperature.
- Select the AC motor drive with capacity one grade larger for the impact load application.
- Refer to Chapter 9-6 Specification for Operation Temperature and Protection Level for the protection level of each model.
- \* The default setting is Light Duty, you can select Normal Duty and Light Duty by setting Pr.00-16.

### 9-4 690V Models

	Frame				(	2		[	D		E	<u> </u>	
N	Лode	el VFD	_CP63A	185	220	300	370	450	550	750	900	1100	1320
			utput capacity [kVA]	29	36	43	54	65	80	103	124	149	179
		• • •	e motor output 0V [kW]	18.5	22	30	37	45	55	75	90	110	132
	duty		e motor output 0V [HP]	25	30	40	50	60	75	100	125	150	175
	Light duty		e motor output 5V [HP]	20	25	30	40	50	60	75	100	125	150
		Rated out	tput current [A]	24	30	36	45	54	67	86	104	125	150
		Overload tolerance				120%	of rated cur	rent for 1 m	ninute durin	g every 5 n	ninutes		
ing		Max.output frequency [Hz]						599	9.00				
*Output rating		Rated output capacity [kVA]		24	29	36	43	54	65	80	103	124	149
"On		Applicable motor output 690V [kW]		15	18.5	22	30	37	45	55	75	90	110
	duty		e motor output 0V [HP]	20	25	30	40	50	60	75	100	125	150
	Normal duty		utput capacity 5V [HP]	15	20	25	30	40	50	60	75	100	125
		Rated out	tput current [A]	20	24	30	36	45	54	67	86	104	125
		Overload tolerance		120% of rated current for 1 minute during every 5 minutes; 160% of rated current for 3 seconds during every 25 seconds									
		Max.out	out frequency [Hz]	599.00									
		Carrier freq	uency [kHz]					2–9 (De	efault: 4)				
	Inp	out current	Light duty	29	36	43	54	65	81	84	102	122	147
ng		[A]	Normal duty	24	29	36	43	54	65	66	84	102	122
Input rating	R	ated voltage	e / Frequency			3-	phase, 525		-15%- +10	%), 50/60 F	łz		
put	(	Operating v	oltage range						59 V <sub>AC</sub>				
_=	Frequency tolerance								3 Hz				
		Efficienc	y [%]						)7				
		Power fa						> 0	).98				
		Weight			10 ±	: 1.5		_	39 ± 1.5			61 ± 1.5	
		Cooling m			F. 1	N. D. dit i		Fan c	ooling	F 5 :	- 0-1: :		
<u> </u>		Braking cl				: Built-in				Frame D-6	E: Optional -E: Built-in		
1	DC choke				⊦rame C	Optional		<u> </u>		riaine D-	-∟. Dullt-in		

NOTE

- The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Chapter 9-7 Derating Curve of Ambient Temperature.
- Select the AC motor drive with capacity one grade larger for the impact load application.
- Refer to Chapter 9-6 Specification for Operation Temperature and Protection Level for the protection level of each model.
- \* The default setting is Light Duty, you can select Normal Duty and Light Duty by setting Pr.00-16.

## 690V Models

	Frame			F	(	<u> </u>		ŀ	1			
М	lode	el VFD CP63A-	1600	2000	2500	3150	4000	4500	5600	6300		
		Rated output capacity [kVA]	215	263	347	418	494.5	534.7	678.5	776		
		Applicable motor output 690V [kW]	160	200	250	315	400	450	560	630		
	duty	Applicable motor output 690V [HP]	215	270	335	425	530	600	750	850		
	Light duty	Applicable motor output 575V [HP]	150	200	250	350	400	450	500	750		
		Rated output current [A]	180	220	290	350	430	465	590	675		
		Overload tolerance		1	20% of rated	current for 1 m	ninute during e	every 5 minute	s			
ng		Max.output frequency [Hz]		599.00								
*Output rating		Rated output capacity [kVA]	179	215	239	347	402.5	442.7	534.7	776		
*Out		Applicable motor output 690V [kW]	132	160	200	250	315	355	450	630		
	duty	Applicable motor output 690V [HP]	175	215	270	335	425	475	600	850		
	Normal duty	Rated output capacity 575V [HP]	150	150	200	250	350	400	450	750		
		Rated output current [A]	150	180	220	290	350	385	465	675		
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes; 160% of rated current for 3 seconds during every 25 seconds									
		Max.output frequency [Hz]		599.00								
		Carrier frequency [kHz]				2–9 (Default: 4			T	2-9 (Default: 3)		
0		nput current [A] Light duty	178	217	292	353	454	469	595	681		
nput rating		out current [A] Normal duty	148	178	222	292	353	388	504	681		
nt ra	R	Rated voltage / Frequency			3-phase,	525–690 V <sub>AC</sub> (		, 50/60 Hz				
du	(	Operating voltage range				446–7						
		Frequency tolerance			1	47–6						
		Efficiency [%]	9	97				8				
		Power factor			T	> 0	.98					
		Weight [Kg]	88 :	± 1.5	135	± 4		243	± 5			
		Cooling method				Fan c						
		Braking chopper				Frame F-H						
		DC choke				Frame F-	H: Built-in			T-51- 0 0		

Table 9-6

■ The carrier frequency is default. Increasing the carrier frequency requires a reduction in current. Refer to Chapter 9-7 Derating Curve of Ambient Temperature.

■ Select the AC motor drive with capacity one grade larger for the impact load application.

Refer to Chapter 9-6 Specification for Operation Temperature and Protection Level for the protection level of each model.

\* The default setting is Light Duty, you can select Normal Duty and Light Duty by setting Pr.00-16.

## **General Specifications**

	Control Mode	Pulse-Width Modulation (PWM)
	Control Method	1: V/F, 2: SVC, 3: PM Sensorless, 4: SynRM Sensorless
	Starting Torque	Reach up to 150% above at 0.5 Hz.
	V/F Curve	4 point adjustable V/F curve and square curve
	Speed Response Ability	5 Hz (vector control can reach up to 40 Hz)
	·	Light duty: max. 130% torque current
	Torque Limit	Normal duty: max. 160% torque current
	Torque Accuracy	±5%
		230V models: 599.00 Hz (55 kW and above: 400.00 Hz)
	Max. output frequency (Hz)	460V models: 599.00 Hz (90 kW and above: 400.00 Hz)
S		575/690V models: 599.00 Hz
stic	Frequency Output Accuracy	Digital command: ± 0.01%, -10°C– +40°C, Analog command: ± 0.1%, 25 ± 10°C
teri	Output Frequency	Digital command: 0.01 Hz
arac	Resolution	Analog command: 0.03 × max. output frequency/60 Hz (± 11 bit)
Che		Light duty: 120% of rated current can endure for 1 minute
Irol	Overload Tolerance	Normal duty: 120% of rated current can endure for 1 minute; 160% of rated current can endure for 3 sec.
Control Characteristics	Frequency Setting Signal	0-+10 V, 4-20 mA, 0-20 mA
	Accel./Decel. Time	0.00-600.00/0.0-6000.0 seconds
		Momentary power loss ride thru, Speed search, Over-torque detection, Torque limit, 16-step speed (max),
		Accel./Decel. time switch, S-curve accel./decel., 3-wire sequence, Auto-Tuning, Dwell,-Slip compensation,
	Main control function	Torque compensation, JOG frequency, Frequency upper/lower limit settings, DC injection braking at
		start/stop, High slip braking, Energy saving control, Modbus communication (RS-485 RJ45, max. 5.2
		Kbps)
		230V models: Models above VFD185CP23 (including VFD185CP23) are PWM control
		Models below VFD150CP23 (including VFD150CP23) are ON/OFF switch control.
	Fan Control	460V models: Models above VFD220CP43/4E (including VFD220CP43/4E) are PWM control
		Models below VFD185CP43/4E (including VFD185CP43/4E) are ON/OFF switch control.
		575V / 690V models: PWM control
	Motor Protection	Electronic thermal relay protection
		For drive model 230V/460V:
		Over-current protection: 185% rated current for light duty; 240% rated current for normal duty
	Over-current Protection	Current clamp: Light duty: 130–135% a; Normal duty: 170–175% a
		For drive model 575/690V:
		Over-current protection: 225% rated current for normal duty  Current clamp: 『Light duty: 128–141%』; 『Normal duty: 170–175%』
stics		230V models: drive will stop when DC bus voltage exceeds 410 V
risti		460V models: drive will stop when DC bus voltage exceeds 820 V
acte	Over-voltage Protection	575V models: drive will stop when DC bus voltage exceeds 1016 V
Jara		690V models: drive will stop when DC bus voltage exceeds 1189 V
C	Over-temperature	The state of the s
ction	Protection	Built-in temperature sensor
Protection Characteri	Stall Prevention	Stall prevention during acceleration, deceleration and running independently
Ь	Restart After Instantaneous	
	Power Failure	Parameter setting up to 20 seconds
	Grounding Leakage Current Protection	Leakage current is higher than 50% of rated current of the AC motor drive
	Short-circuit Current Rating	Per UL508C, the drive is suitable for use on a circuit capable of delivering not more than 100 kA
	(SCCR)	symmetrical amperes (rms) when protected by fuses given in the fuse table.
	Certifications	CERTIFIED EHL & SEMI F47, GB/T12668.3
	Certifications	SEMI F47, GB/T12668.3

## NOTE

- \* The setting range of max. output frequency changes as carrier wave and control modes changes. Refer to Pr.01-00 for more information.
- Only 230V/460V models are complied with EAC certification. 575V/690V models are not yet for certified.
- Model VFD5000CP43A-xx is not UL certified.

# 9-5 Environment for Operation, Storage and Transportation

Do NOT expose t	he AC motor drive	in the bad environme	ent, such as dust, direct sunlight, corrosive/inflammable gasses, humidity, liquid and						
vibration environr	nent. The salt in the	e air must be less th	an 0.01mg/cm² every year.						
	Installation location	IEC60364-1/IEC606	664-1 Pollution degree 2, Indoor use only						
	Surrounding	Storage	-25- +70						
	Temperature	Transportation	-25- +70						
	(°C)	Non-condensation	ı, non-frozen						
		Operation	Max. 95%						
	Rated Humidity	Storage/	Max. 95%						
	Traced Fidinidity	Transportation							
		No condense water	lo condense water						
	Air Pressure (kPa)	Operation/ Storage	86–106						
Environment	(KFa)	Transportation	70–106						
		IEC60721-3-3							
		Operation	Class 3C3; Class 3S2						
	Pollution Level	Storage	Class 1C2; Class 1S2						
	Poliution Level	Transportation	Class 2C2; Class 2S2						
			If the AC motor drive is to be used under harsh environment with high level of contamination (e.g. dew,						
		water, dust), make	sure it is installed in an environment qualified for IP54 such as in a cabinet.						
	Altitude	Operation	If AC motor drive is installed at altitude 0–1000 m, follow normal operation restriction. If it is install at altitude 1000–2000 m, decrease 1% of rated current or lower 0.5°C of temperature for every 100 m increase in altitude. Maximum altitude for Corner Grounded is 2000 m.Contact Delta for more information, if you need to use this motor drive at an altitude of 2000m or higher.						
Package Drop	Storage Transportation	ISTA procedure 1/	A (according to weight) IEC60068-2-31						
) (!la a 4! a	1.0mm, peak to pe	eak value range fron	n 2 Hz to 13.2 Hz; 0.7G–1.0G range from 13.2 Hz to 55 Hz; 1.0G range from 55 Hz to						
Vibration		vith IEC 60068-2-6							
Impact	IEC/EN 60068-2-2								
Operation Position  Max. allowed offset angle ±10° (under normal installation position)  10° 10° 10° 10°									

# 9-6 Specification for Operation Temperature and Protection Level

Model	Frame Top cover Conduit box Protection level		Operation temperature		
	Frame A-C 230V: 0.75-30 kW 460V: 0.75-37 kW	Top cover removed	Standard	IP20/UL Open Type	230V&460V: -10°C-50°C *1 575V&690V: -10°C~50°C
VFDxxxxCP23x-21 VFDxxxxCP43x-21 VFDxxxxCP4Ex-21	575V: 1.5–15 kW 690V: 18.5–37 kW	Standard with top cover	conduit plate	IP20/ UL Type1/ NEMA1	-10-40°C
VFDxxxxCP53x-21 VFDxxxxCP63x-xx	Frame D–H 230V: 37 kW and above 460V: 45 kW and above 690V: 45 kW and above	N/A	With conduit box	IP20/UL Type1/NEMA1	-10-40°C
VFDxxxxCP23x-00 VFDxxxxCP43x-00 VFDxxxxCP63x-xx	Frame D–H 230V: 37 kW and above 460V: 45 kW and above 690V: 45 kW and above	N/A		IP00 IP20/UL Open Type  The circled area: IP00 Other than the circled area: IP20  Figure 9-1	230V&460V: -10°C–50°C * <sup>1</sup> 690V: -10°C–50°C

<sup>\*1</sup> When the carrier wave for light duty is 2 kHz, the maximum operation temperature can reach up to 50°C.

## 9-7 Derating Curve for Ambient Temperature, Altitude and Carrier Frequency

- ☑ For more information on calculation for derating curve, refer to Pr.06-55.
- ☑ When choosing the correct model, consider factors such as ambient temperature, altitude, carrier frequency, control mode, and so on. That is,

Actual rated current for application (A) = Rated output current (A) × Ambient temp. rated derating (%) x Altitude rated derating (%) × [Normal / Advanced control] carrier frequency rated derating (%)

Protection Level	Operating Environment
UL Type I / IP20	If the AC motor drive operates at the rated current, the ambient temperature needs to be between -10–40°C. If the temperature is above 40°C, decrease 2% of the rated current for every 1°C increase in temperature. The maximum allowable temperature is 60°C.
UL Open Type / IP20	If the AC motor drive operates at the rated current, the ambient temperature needs to be between -10–50°C. If the temperature is above 50°C, decrease 2% of the rated current for every 1°C increase in temperature. The maximum allowable temperature is 60°C.

Table 9-10

## Ambient Temperature Derating Curve

#### 230V / 460V




Figure 9-2

#### UL Open Type:

The rated output current derating (%) in normal duty / light duty when carrier frequency is 2 kHz:

Ambient Temp. / 100% Load Fc (kHz)	30°C	50°C	60°C
2	100	100	80

#### UL Open Type Side by Side or UL Type 1:

Table 9-11

The rated output current derating (%) in normal duty / light duty when carrier frequency is the default value:

Ambient Temp. / 100% Load Fc (kHz)	30°C	40°C	60°C
Default Value	100	100	60

#### 575V / 690V




Figure 9-3

## UL Open Type:

The rated output current derating (%) in normal duty / light duty when carrier frequency is the default value:

Ambient Temp. / 100% Load Fc (kHz)	30°C	50°C	60°C
Default Value	100	100	75

Table 9-13

### UL Open Type Side by Side or UL Type 1:

The rated output current derating (%) in normal duty / light duty when carrier frequency is the default value:

Ambient Temp. / 100% Load Fc (kHz)	30°C	40°C	60°C
Default Value	100	100	50

## **Altitude Derating Curve**

Condition	Operating Environment
High Altitude	If the AC motor drive is installed at an altitude of 0–1000 m, follow normal operation restrictions. For altitudes of 1000–2000 m, decrease the drive's rated current by 1% or lower the temperature by 0.5°C for every 100 m increase in altitude. The maximum altitude for corner grounding is 2000 m. If installing at an altitude higher than 2000 m is required, contact Delta for more information.

Table 9-15




Figure 9-4

The rated output current derating (%) for different altitudes above sea level:

Altitude above Sea Level (Meter)	0	1000	1500	2000
Output Current / Rated	100	100	95	90
Current (%)	100	100	90	90

Table 9-16

## Carrier Frequency Derating Curve

230V / 460V Normal Control

$$Pr.00-11 = 0 (IMVF)$$

$$= 2 (IM SVC, Pr.05-33 = 0)$$




Figure 9-5

The rated output current derating (%) of 230V models in normal control mode for different carrier frequencies:

Fc (kHz) Model No.	4	5	6	7	8	9	10	11	12	13	14	15
VFD007-150CP23A/E	100	100	100	100	100	97	94	91	88	85	83	80
VFD185-450CP23A/E	100	100	100	96	93	90	87	1	1	-	-	ı
VFD550-900CP23A/E	100	97	93	90	87	84	-	-	-	-	-	-

Table 9-17




Figure 9-6

The rated output current derating (%) of 460V models in normal control mode for different carrier frequencies:

neque	JIIOICS.												
Mode	Fc (kHz)	4	5	6	7	8	9	10	11	12	13	14	15
VFD	007-185CP43A/E	100	100	100	100	100	96	92	88	84	80	76	72
VFD	220-750CP43A/E	100	100	100	95	89	84	79	-	-	-	-	-
VFD9	900-6300CP43A/E	100	94	88	82	76	71	-	-	-	-	-	-

Table 9-18

#### 230V / 460V Advanced Control

Pr.00-11 = 2 (PM SVC, Pr.05-33 = 1, 2)




Figure 9-7

The rated output current derating (%) of 230V models in advanced control mode for different carrier frequencies:

noquonoloo.														
Fc (kHz) Model No.	2	3	4	5	6	7	8	9	10	11	12	13	14	15
VFD007-150CP23A/E	100	100	100	100	96	92	88	83	79	75	71	67	63	59
VFD185-450CP23A/E	100	100	100	94	90	85	81	76	72	-	-	-	-	-
VFD550-900CP23A/E	100	96	91	87	82	78	73	69	-	-	-	-	-	-

Table 9-19




Figure 9-8

The rated output current derating (%) of 460V models in advanced control mode for different carrier frequencies:

Fc (kHz) Model No.	2	3	4	5	6	7	8	9	10	11	12	13	14	15
VFD007-185CP43A/E	100	100	100	100	94	88	82	76	71	65	59	53	47	41
VFD220-750CP43A/E	100	100	100	92	84	76	68	60	52	-	-	-	-	-
VFD900-6300CP43A/E	100	92	83	75	67	58	50	42	ı	ı	1	1	1	-

Table 9-20

#### Chapter 09 Specifications | CP2000

• 575V / 690V

Pr.00-16 = 2, light duty:

Pr.00-11 = 0 (IMVF)

= 2 (IM SVC, Pr.05-33 = 0)




Figure 9-9

The rated output current derating (%) of 575V / 690V models in light duty for different carrier frequencies:

Fc (kHz) Model No.	2	3	4	5	6	7	8	9
VFD015-150CP53A-21	100	100	100	100	100	90	82	75
VFD185–550CP63A-xx	100	100	100	100	100	90	02	73
VFD750-2000CP63A-xx	100	100	100	100	95	85	75	65
VFD2500-6300CP63A-xx	100	100	100	100	95	80	65	55

Table 9-21

Pr.00-16 = 0, normal duty:

Pr.00-11 = 0 (IMVF)

= 2 (IM SVC, Pr.05-33 = 0)




Figure 9-10

The rated output current derating (%) of 575V / 690V models in normal duty for different carrier frequencies:

Fc (kHz) Model No.	2	3	4	5	6	7	8	9
VFD015-150CP53A-21	100	100	100	100	100	90	82	75
VFD185-550CP63A-xx	100	100	100	100	100	90	02	75
VFD750-2000CP63A-xx	100	100	100	100	95	85	75	65
VFD2500-6300CP63A-xx	100	100	100	100	95	80	65	55
VFD6300CP63A-xx	100	100	100	86	73	63	55	48

Table 9-22

## 9-8 Efficiency Curve

 Models: VFD007C23A-VFD370C23A VFD007C43A-VFD750C43A




Figure 9-11

Efficiency (%) under different loads:

<u> </u>	annoronic rodado.			
Speed (%) Load (%)	16.7	50	66.7	100
100% Load	90.6	96.2	97.0	97.8
75% Load	90.4	96.1	96.9	97.8
50% Load	89.5	95.7	96.6	97.6
25% Load	82.5	92.3	93.8	95.5

Table 9-23

#### Models: VFD450C23A-VFD900C23A VFD900C43A-VFD4500C43A




Figure 9-12

Efficiency (%) under different loads:

Speed (%) Load (%)	16.7	50	66.7	100
100% Load	93.2	97.2	97.7	98.2
75% Load	93.4	97.3	97.8	98.3
50% Load	92.6	97.1	97.7	98.2
25% Load	90.1	92.6	93.2	93.2

Table 9-24

# Chapter 10 Digital Keypad

- 10-1 Descriptions of Digital Keypad
- 10-2 Function of Digital Keypad KPC-CC01
- 10-3 TPEditor Installation Instruction
- 10-4 Fault Code Description of Digital Keypad KPC-CC01
- 10-5 Unsupported Functions when using TPEditor on

KPC-CC01 Keypad

## 10-1 Descriptions of Digital Keypad

#### KPC-CC01



Communication Interface RJ45 (socket), RS-485 interface

Communication protocol:

RTU19200, 8, N, 2

#### Installation Method

- 1. The embedded type can be installed on the surface of the control box. The front cover is waterproof.
- 2. Buy a MKC-KPPK model for wall mounting or embedded mounting. Its protection level is IP66.
- 3. The maximum RJ45 extension lead is 5 m (16ft).
- 4. This keypad can only be used on Delta's motor drive C2000 series, CH2000 and CP2000 series.


## **Keypad Functions Description**

<b>J</b> .	lons Description							
Key	Descriptions							
RUN	ort Operation Key Only valid when the source of operation command is the keypad. Operates the AC motor drive by the function setting. The RUN LED will be ON. Can be pressed repeatedly at the stop process.							
STOP	This key has the highest priority when the command is from the keypad.  When it receives the STOP command, regardless of whether the AC motor drive is in operation or stop status, the AC motor drive executes the "STOP" command.  Use the RESET key to reset the drive after a fault occurs.  If you cannot reset after the error:  a. The condition which triggers the fault is not cleared. After you clear the condition, you can then reset the fault.  b. The drive is in fault status when powered on. After you clear the condition, restart and then you can reset the fault.							
FWD REV	Operation Direction Key  1. Only controls the operation direction, NOT the drive activation. FWD: forward, REV: reverse.  2. Refer to the LED descriptions for more details.							
ENTER	ENTER Key Goes to the next menu level. If at the last level, press ENTER to execute the command.							
ESC	ESC Key Leaves the current menu and returns to the previous menu; also functions as a return key or cancel key in a sub-menu.							
MENU	Returns to the main menu.  Menu commands:  1. Parameter Setup  2. Quick Start  3. Application Selection List  4. Changed List  5. Copy Parameter  6. Fault Record  7. Language Setup  13. Start-up Menu  14. Main Page  15. PC Link  16. Start Wizard  16. Start Wizard							


Key	Descriptions
< > ^ V	Direction: Left / Right / Up / Down  1. In the numeric value setting mode, moves the cursor and changes the numeric value.  2. In the menu / text selection mode, selects an item.
F1 F2 F3 F4	<ol> <li>Function Key</li> <li>The functions keys have defaults and can also be user-defined. The defaults for F1 and F4 work with the function list below. For example, F1 is the JOG function, and F4 is a speed setting key for adding / deleting user-defined parameters.</li> <li>Other functions must be defined using TPEditor.         Download TPEditor software at Delta website. Select TPEditor version 1.60 or above. Refer to the installation instruction for TPEditor in Section 10-3.     </li> </ol>
HAND	<ol> <li>HAND Key</li> <li>Use this key to select HAND mode. In this mode, the drive's parameter settings for frequency command source is Pr.00-30, and that for operation command source is Pr.00-31.</li> <li>Press the HAND key at STOP, then the setting switches to the HAND frequency source and HAND operation source.</li> <li>Press HAND key at RUN, and it stops the AC motor drive first (displays AHSP warning), and switches to HAND frequency source and HAND operation source.</li> <li>Successful mode switching for the KPC-CC01 displays HAND mode on the screen.</li> </ol>
	<ol> <li>AUTO Key</li> <li>The default of the drive is AUTO mode.</li> <li>Use this key to select AUTO mode. In this mode, the drive's parameter settings for frequency command source is Pr.00-20, and that for operation command is Pr.00-21.</li> <li>Press the AUTO key at STOP, then the setting switches to the AUTO frequency source and AUTO operation source.</li> <li>Press AUTO key at RUN, and it stops the AC motor drive first (displays AHSP warning), and switches to AUTO frequency source and AUTO operation source.</li> <li>Successful mode switching for the KPC-CC01 displays AUTO mode on the screen.</li> <li>defaults for the frequency command and operation command source of HAND / AUTO mode are from the keypad.</li> </ol>

## **LED Functions Descriptions**

LED	Descriptions
STOP RESET	Steady ON: STOP indicator for the AC motor drive. Blinking: the drive is in standby. Steady OFF: the drive does not execute the "STOP" command.
FWD REV	Operation Direction LED  1. Green light: the drive is running forward. 2. Red light: the drive is running backward. 3. Flashing light: the drive is changing direction.  Operation Direction LED under Torque Mode
	<ol> <li>Green light: when the torque command ≥ 0, and the motor is running forward.</li> <li>Red light: when the torque command &lt; 0, and the motor is running backward.</li> <li>Flashing light: when the torque command &lt; 0, and the motor is running forward.</li> </ol>




## 10-2 Function of Digital Keypad KPC-CC01






- 1. Start-up screen can only display pictures, not animation.
- 2. When powered ON, it displays the start-up screen then the main screen. The main screen displays Delta's default setting F/H/A/U. You can set the display order with Pr.00-03 (Start-up display). When you selected the U screen, use the left / right keys to switch between the items, and set the display order for the U screen with Pr.00-04 (User display).

## **Display Icon**





- : present setting
- ▼ : Scroll down the page for more options

Press for more options

► : show complete sentence Press (<) > for complete information

## Display item



#### MENU

1: Parameter Setup 6 2: Quick Start 7 3: Application Selection List 8

4: Changed List
5: Copy Parameter


6: Fault Record 7: Language Setup 8: Time Setup 9: Keypad Locked 10: PLC Function

13: Start-up Menu 14: Main Page 15: PC Link 16: Start Wizard


11: Copy PLC

12: Display Setup

#### 1. Parameter Setup



#### Quick Start



20.	Output frequency lower limit
	(Pr.01-11)

- 21. Acceleration time 1 (Pr.01-12)
- 22. Deceleration time 1 (Pr.01-13)
- 23. Over-voltage stall prevention (Pr.06-01)
- 24. Derating protection (Pr.06-55)
- 25. Software brake chopper action level (Pr.07-00)
- 26. Speed tracking during start-up (Pr.07-12)
- 27. Emergency stop (EF) & force to stop selection (Pr.07-20)
- 28. Torque command filter time (Pr.07-24)
- 29. Slip compensation filter time (Pr.07-25)
- 30. Torque compensation gain (Pr.07-26)
- 31. Slip Compensation Gain (Pr.07-27)

#### 2. SVC Mode

## \$VC Mode :P00-07 \$01:Password De 02:Password Inp 03:Control Meth

01: Password Decoder




#### Items

- Parameter protection password input (Pr.00-07)
- Parameter protection password setting (Pr.00-08)
- Speed control mode (Pr.00-11)
- 4. Load selection (Pr.00-16)
- 5. Carrier frequency (Pr.00-17)
- Master frequency command source (AUTO) / Source selection of the PID target (Pr.00-20)
- 7. Operation command source (AUTO) (Pr.00-21)
- 8. Stop method (Pr.00-22)
- Digital keypad STOP function (Pr.00-32)
- 10. Max. operation frequency (Pr.01-00)
- Output frequency of motor 1 (Pr.01-01)
- Output voltage of motor 1 (Pr.01-02)
- Min. output frequency of motor 1 (Pr.01-07)
- Min. output voltage of motor 1 (Pr.01-08)
- 15. Output frequency upper limit (Pr.01-10)
- 16. Output frequency lower limit (Pr.01-11)
- 17. Acceleration time 1 (Pr.01-12)
- 18. Deceleration time 1 (Pr.01-13)
- Full-load current for induction motor 1 (Pr.05-01)
- 20. Rated power for induction motor 1 (Pr.05-02)
- 21. Rated speed for induction motor 1 (Pr.05-03)
- 22. Number of poles for induction motor 1 (Pr.05-04)
- 23. No-load current for induction motor 1 (Pr.05-05)
- 24. Over-voltage stall prevention (Pr.06-01)
- 25. Over-current stall prevention during acceleration (Pr.06-03)
- 26. Derating protection (Pr.06-55)

- 27. Software brake chopper action level (Pr.07-00)
- 28. Emergency stop (EF) & Force to stop selection (Pr.07-20)
- 29. Torque command filter time (Pr.07-24)
- 30. Slip compensation filter time (Pr.07-25)
- 31. Slip compensation gain (Pr.07-27)

#### My Mode



Press F4 in parameter setting screen to save the parameter to My Mode. To delete or correct the parameter, select this parameter and press F4 for DEL in the bottom right corner.

#### **Items**


It can save 1-32 sets of parameters (Pr).

#### Setup process

Go to Parameter Setup function.
 Press ENTER to select the parameter to
 use. There is an ADD on the bottom right
 corner of the screen. Press F4 to add this
 parameter to My Mode.




 The parameter (Pr) displays in My mode if it is properly saved.
 To correct or to delete this parameter, press F4 for DEL.




 To delete a parameter, go to My Mode and select the parameter to delete. Press ENTER to enter the parameter setting screen. DEL appears in the bottom left corner of the screen. Press F4 to delete this parameter from My Mode.







#### 3. **Application Selection List**




#### 4. Changed List




#### 5. Copy Parameter







#### Fault Record



#### Language Setup




#### 8. Time Setup



Use the Left / Right keys to Time Setup select Year, Month, Day, Hour, 2014/01/01 Minute or Second to change. Press the Up / Down keys to set the Month 00:00:00 Time Setup 2014/01/01 Press the Up / Down keys to set the Day 00:00:00 Time Setup 2014/01/01 Press the Up / Down keys to set the Hour 21:00:00 Time Setup 2014/01/01 Press the Up / Down keys to set the Minute 21:12:00 Time Setup 2014/01/01 Press the Up / Down keys to set the Second 21:12:14 Time Setup **END** Press ENTER to confirm the Time Setup. NOTE

## 9. Keypad Locked



Limitation: The charging process for the keypad super capacitor finishes in about 6 minutes. When the digital keypad is removed, the time setting is


saved for 7 days. After 7 days, you must reset the time.

♦F 60.00Hz H 0.00Hz u 540.0Vdc JOG 14:35:58

Press ESC for 3 seconds to unlock the keypad; the keypad returns to this screen. All keys on the keypad is functional.

All keys on the keypad is functional. Turning the power off and on does not lock the keypad.

#### 10. PLC Function



Press the Up/Down keys to select a PLC's function, and then press ENTER.

When activating and stopping the PLC function (choosing 2: PLC Run or 3: PLC Stop), the PLC status displays on main screen (Delta default setting).



Choose option 2: PLC Run to enable the PLC function.

The default on the main screen displays the PLC / RUN status message.


Choose option 3: PLC Stop to disable the PLC function.

The default on the main screen displays the PLC / STOP status message.

If the PLC program is not available in the control board, the PLFF warning displays when you choose option 2 or 3.

In this case, choose option 1: Disable to clear PLFF warning.

## 11. Copy PLC



Four groups of parameters are available to copy.

The steps are shown in the example below.


Example: PLC program saved in the motor drive.



34%

- 1. Go to Copy PLC
- 2. Select the PLC program to copy and press ENTER.
- 1. Select 1: Keypad→VFD
- Press ENTER to go to the "Keypad→VFD" screen.

Begin copying the PLC program until it is done.




Begin copying the PLC program until it is done.


VFD->Keypad


12%

#### Chapter 10 Digital Keypad | CP2000




#### 12. Display setup







#### 13. Start-up




#### 14. ain page



#### 15. PC Link






Press ENTER to go to Waiting to connect to

PC screen.

2.

PC Link 1: Waiting

0%



#### 16. Start Wizard (applicable for CP2000 firmware V2.06 and above)

#### 16.1 New drive start-up setting process

When a new drive is powered on, it directly enters the Start Wizard. There are three modes in the start-up setting process: Start Wizard, Exit Wizard and Test Mode.

#### (1) Start Wizard:

- In Start Wizard, you can set drive's parameters such as Calendar, Maximum operation frequency and Maximum voltage...; refer to Table 1 for setting items and orders.
- The drive exits Start Wizard when you finish the complete setting process, and will not enter this process when rebooting the power.

#### (2) Exit Wizard:

 Exit the Start Wizard mode. The drive does not go to Start Wizard when rebooting the power.


#### (3) Test Mode:

- This function is hidden to avoid misuse. Refer to the following flow chart to enter Test Mode.
- When the drive is in Test mode, it temporarily disables the Start Wizard and Exit Wizard mode.
- The Test Mode is designed for distributors / suppliers / clients to manage and operate the drive before shipping it out.
- If you enter Test Mode without exiting the Start Wizard process, the drive will begin with the new drive start-up process upon next power on.


Setting Order	Description	Parameter
1	Calendar	N/A
2	Output frequency of motor 1	01-01
3	Output voltage of motor 1	01-02
4	Full-load current for induction motor 1 (A)	05-01
5	Number of poles for induction motor 1	05-04
6	Rated speed for induction motor 1 (rpm)	05-03
7	Minimum output frequency of motor 1	01-07
8	Maximum operation frequency	01-00
9	Master frequency command source (AUTO) / Source selection of the PID target	00-20
10	Operation command source (AUTO)	00-21
11	V/F curve selection	01-43
12	Acceleration time 1	01-12
13	Deceleration time 1	01-13

Table 1: Start Wizard setting items

Flow chart for the above setting process:



#### 16.2 Re-start Start Wizard




Refer to item 16.1 "New drive start-up setting" for further setting procedure

NOTE: The "16: Start Wizard" on the menu is to set whether the screen shows start wizard when powering on the drive.

## Other displays

When a fault occurs, the screen display shows the fault or warning:





- 1. Press the STOP / RESET key to reset the fault code. If there is no response, contact your local distributor or return the unit to the factory. To view the fault DC bus voltage, output current and output voltage, press MENU and then choose 6: Fault Record.
- 2. After resetting, if the screen returns to the main page and shows no fault after you press ESC, the fault is cleared
- 3. When the fault or warning message appears, the LED backlight blinks until you clear the fault or warning.

## Optional accessory: RJ45 Extension Lead for Digital Keypad

Part No.	Description
CBC-K3FT	RJ45 extension lead, 3 feet (approximately 0.9 m)
CBC-K5FT	RJ45 extension lead, 5 feet (approximately 1.5 m)
CBC-K7FT	RJ45 extension lead, 7 feet (approximately 2.1 m)
CBC-K10FT	RJ45 extension lead, 10 feet (approximately 3 m)
CBC-K16FT	RJ45 extension lead, 16 feet (approximately 4.9 m)

Note: When you need to buy communication cables, buy non-shielded, 24 AWG, four-wire twisted pair, 100 ohms communication cables.


#### 10-3 TPEditor Installation Instruction

TPEditor can edit up to 256 HMI (Human-Machine Interface) pages with a total storage capacity of 256 KB. Each page can include 50 normal objects and 10 communication objects.


- 1) TPEditor: Setup & Basic Functions
  - 1. Run TPEditor version 1.60 or above by double-clicking the program icon.



 On the File menu, click New. In the New project dialog box, for Set Device Type, select DELTA VFD-C Inverter. For TP Type, select VFD-C KeyPad. For File Name, enter TPE0 and then click OK.




3. The editor displays the Design window. On the **Edit** menu, click **Add** a **New Page**. You can also right-click on the TP page in the upper right corner of the Design window and click **Add** to add one more page(s) to edit.




4. Edit the start-up screen

5. Add static text. Open a blank page (step 3), then on the toolbar click . Double-click the blank page to display the **Static Text Setting** dialog box, and then enter the static text.




6. Add a static bitmap. Open a blank page (step 3), then on the toolbar, click . Double-click the blank page to display the **Static Bitmap Setting** dialog box where you can choose the bitmap.



You can only use images in the BMP format. Click the image and then click Open to show the image in the page.

- 7. Add a geometric bitmap. There are 11 kinds of geometric bitmaps to choose. Open a new blank page (step
  - 3), then on the toolbar click the geometric bitmap icon that you need


    In the page, drag the geometric bitmap and enlarge it to the size that you need.
- 8. When you finish editing the start-up screen, on the **Communication** menu, click **Input User Defined Keypad Starting Screen.**




- 9. Download the new setting: On the **Tool** menu, click **Communication**. Set up the communication port and speed for the IFD6530. There are three speeds available: 9600 bps, 19200 bps, and 38400 bps.
- 10. On the Communication menu, click Input User Defined Keypad Starting Screen.



11. The Editor displays a message asking you to confirm the new setting. Before you click **OK**, on the keypad, go to MENU, select PC LINK, press ENTER and then wait for few seconds. Then click **YES** in the confirmation dialog box to start downloading.



- 2) Edit the Main Page and Download to the Keypad
  - In the Editor, add a page to edit. On the Edit menu, click Add a New Page. You can also right-click on the
    TP page in the upper right corner of the Design window and click Add to add one more pages to edit.
    This keypad currently supports up to 256 pages.




2. In the bottom right-hand corner of the Editor, click the page number to edit, or on the View menu, click HMI Page to start editing the main page. As shown in the picture above, the following objects are available. From left to right they are: Static Text, ASCII Display, Static Bitmap, Scale, Bar Graph, Button, Clock Display, Multi-state bit map, Units, Numeric Input, the 11 geometric bitmaps, and lines of different widths. Use the same steps to add Static Text, Static Bitmap, and geometric bitmaps as for the start-up page.




3. Add a numeric/ASCII display. On the toolbar, click the **Numeric/ASCII** button. In the page, double-click the object to specify the **Refer Device**, **Frame Setting**, **Font Setting** and **Alignment**.



Click [...]. In the **Refer Device** dialog box, choose the VFD communication port that you need. If you want to read the output frequency (H), set the **Absolute Addr.** to 2202. For other values, refer to the ACMD Modbus Comm Address List (see Pr.09-04 in Chapter 12 Group 09 Communication Parameters).




4. Scale Setting. On the toolbar, click to add a scale. You can also edit the Scale Setting in the Property Window on the right-hand side of your computer screen.




- a. **Scale Position**: specifies where to place the scale.
- b. **Scale Side**: specifies whether the scale is numbered from smaller numbers to larger numbers or from larger to smaller.
- c. Font Setting: specifies the font.
- d. Value Length: specifies 16 bits or 32 bits.
- e. **Main Scale & Sub-Scale**: divides the whole scale into equal parts; enter the numbers for the main scale and sub-scale.
- f. **Max Value & Min Value**: specifies the numbers on the two ends of the scale. They can be negative numbers, but the maximum and minimum values are limited by the **Value Length** setting. For example, when **Value Length** is **hexadecimal** (**16 bits**), the maximum and the minimum value cannot be entered as -40000.


Clicking **OK** creates a scale as in the picture below.



5. Bar Graph setting. On the toolbar, click to add a bar graph.



- a. Refer Device: specifies the VFD communication port.
- b. **Direction Setting**: specifies the direction: **From Bottom to Top**, **From Top to Bottom**, **From Left to Right** or **From Right to Left**.
- c. **Max Value** and **Min Value**: specifies the maximum value and minimum value. A value smaller than or equal to the minimum value causes the bar graph to be blank (0). A value is bigger or equal to the maximum value causes the bar graph is full (100%). A value between the minimum and maximum values causes the bar graph to be filled proportionally.
- 6. Button some the toolbar, click . Currently this function only allows the keypad to switch pages; other functions are not yet available (including text input and insert image). In the blank page, double-click to open the Button Setting dialog box.




**Button Type**: specifies the button's functions.

**Page Jump** and **Constant Setting** are the only functions currently supported.

#### A. Page Jump Setting


- Page Jump Setting: in the Button Type list, choose Page Jump to show the Page Jump Setting.
- Function Key: specifies the functions for the following keys on the KPC-CC01 keypad: F1, F2, F3, F4, Up, Down, Left and Right. Note that the Up and Down keys are locked by TPEditor. You cannot program these two keys. If you want to program Up and Down keys, on the Tool menu, click Function Key Setting, and then click Re-Define Up/Down Key.



Button Text: specifies the text that appears on a button. For example, when you enter Next Page
for the button text, that text appears on the button.

#### **B.** Constant setting

This function specifies the memory address' values for the VFD or PLC. When you press the **Function Key**, it writes a value to the memory address specified by the value for **Constant Setting**. You can use this function to initialize a variable.




7. Clock Display Setting: on the toolbar, click You can display the time, day, or date on the keypad.

Open a new page and click once in that window to add a clock display.

Choose to display Time, Day, or Date on the keypad. To adjust time, go to #8 on the keypad's menu. You can also specify the Frame Setting, Font Setting, and Alignment.



8. Multi-state bitmap: on the toolbar, click . Open a new page and click once in that window to add a Multi-state bitmap. This object reads a bit's property value from the PLC. It defines the image or text that appears when this bit is 0 or 1. Set the initial status (**Current State**) to be 0 or 1 to define the displayed image or text.




9. Unit Measurement: on the toolbar, click
Open a new blank page, and double-click on that window to display the **Units Setting** dialog box.
Choose the Metrology Type and the Unit Name. For Metrology, the choices are Length, Square Measure, Volume/Solid Measure, Weight, Speed, Time, and Temperature. The unit name changes automatically when you change metrology type.



10. Numeric Input Setting: on the toolbar, click



This object enables you to provide parameters or communication ports (0x22xx) and to input numbers. Open a new file and double click on that window to display the **Numeric Input Setting** dialog box.




- a. **Refer Device**: specifies the **Write** and the **Read** values. Enter the numbers to display and the corresponding parameter and communication port numbers. For example, enter 012C to Read and Write Parameter Pr.01-44.
- OutLine Setting: specifies the Frame Setting, Font Setting, Hori. Alignment, and Vert.
   Alignment for the outline.
- c. **Function Key**: specifies the function key to program on the keypad in the **Function Key** box. The corresponding key on the keypad starts to blink. Press ENTER to confirm the setting.
- d. Value Type and Value Length: specify the range of the Min Value and Max Value for the Limit Setting. Note that the corresponding supporting values for MS300 must be 16 bits. 32-bit values are not supported.
- e. Value Setting: automatically set by the keypad itself.
- f. **Limit Setting**: specifies the range for the numeric input here.


For example, if you set **Function Key** to **F1**, **Min Value** to 0 and **Max Value** to 4, when you press F1 on the keypad, then you can press Up/Down on the keypad to increase or decrease the value. Press ENTER on the keypad to confirm your setting. You can also view the parameter table 01-44 to verify if you correctly entered the value.


11. Download TP Page: Press Up / Down on the keypad to select #13 PC Link.


Then press ENTER on the keypad. The screen displays "Waiting". In TPEditor, choose a page that you have created, and then on the **Communication** menu click **Write to TP** to start downloading the page to the keypad.

When you see "Completed" on the keypad screen, the download is finished. You can then press ESC on the keypad to go back to the menu screen.










## 10-4 Fault Code Description of Digital Keypad KPC-CC01



#### **Fault Codes**

LCD Display *	Fault Name	Description	Corrective Actions
Fault FrEr kpd Flash Read Er	Flash memory read error (FrEr)	Keypad flash memory read error	Error in the keypad's flash memory.  1. Press RESET to clear the errors.  2. Check for any problem on Flash IC.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FsEr kpd Flash Save Er	Flash memory save error (FsEr)	Keypad flash memory save error	Error in the keypad's flash memory.  1. Press RESET to clear the errors.  2. Check for any problem on Flash IC.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.
Fault FPEr kpd Flash Pr Er	Flash memory parameter error (FPEr)	Keypad flash memory parameter error	Error in the default parameters. It might be caused by a firmware update.  1. Press RESET to clear the errors.  2. Check for any problem on Flash IC.  3. Shut down the system, wait for ten minutes, and then restart the system. If none of the above solutions works, contact your authorized local dealer for assistance.
Fault VFDr Read VFD Info Er	Reading AC motor drive data error (VFDr)	Keypad error when reading AC motor drive data	<ul> <li>Keypad cannot read any data sent from the VFD.</li> <li>1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.</li> <li>2. Press RESET to clear the errors.</li> <li>3. Shut down the system, wait for ten minutes, and then restart the system.</li> <li>If none of the above solutions works, contact your authorized local dealer for assistance.</li> </ul>
Fault CPUEr CPU Error	CPU error (CPUEr)	Keypad CPU error	A serious error in the keypad's CPU.  1. Check for any problem on CPU clock.  2. Check for any problem on Flash IC.  3. Check for any problem on RTC IC.  4. Verify that the communication quality of the RS-485 cable is good.  5. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your authorized local dealer for assistance.

## **Warning Codes**


LCD Display *	Warning Name	Description	Corrective Actions
Warning CE1 Comm. Error 1	Commuication error 1 (CE1)		<ul> <li>Motor drive does not accept the communication command sent from the keypad.</li> <li>1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.</li> <li>2. Press RESET on the keypad to clear errors.</li> <li>If none of the above solutions works, contact your local authorized dealer for assistance.</li> </ul>
Warning CK1 Comm Command Er	Communication command error 1 (CK1)	illegal function code	<ul> <li>Keypad does not accept the motor drive's communication command.</li> <li>1. Remove the keypad and reconnect it.</li> <li>2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2</li> <li>3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45.</li> <li>If none of the above solution works, contact your local authorized dealer.</li> </ul>
Warning CE2 Comm. Error 2	Communication error 2 (CE2)	RS-485 Modbus illegal data address	<ul> <li>Motor drive does not accept the keypad's communication address.</li> <li>1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.</li> <li>2. Press RESET to clear the errors.</li> <li>If none of the above solutions works, contact your local authorized dealer for assistance.</li> </ul>
Аито Warning CK2 Comm Address Er	Communication address error (CK2)	illegal data address	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45.  If none of the above solution works, contact your local authorized dealer.
Warning CE3 Comm. Error 3	Communication error 3 (CE3)	RS-485 Modbus illegal data value	<ul> <li>Motor drive does not accept the communication data sent from the keypad.</li> <li>1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.</li> <li>2. Press RESET to clear the errors.</li> <li>If none of the above solutions works, contact your local authorized dealer for assistance.</li> </ul>
маrning СКЗ Comm Data Error	Communication data error (CK3)	illegal data value	Format = RTU8, N, 2 3. Verify if the keypad is properly connected to the

LCD Display *	Warning Name	Description	Corrective Actions
Warning CE4 Comm. Error 4	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	<ul> <li>Motor drive cannot process the communication command sent from the keypad.</li> <li>1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.</li> <li>2. Press RESET to clear the errors.</li> <li>3. Shut down the system, wait for ten minutes, and then restart the system.</li> <li>If none of the above solutions works, contact your local authorized dealer for assistance.</li> </ul>
Аито Warning CK4 Comm Slave Error	Communication slave error (CK4)	Keypad communication data is written to read-only address (Keypad auto-detect this error and display it)	
Warning CE10 Comm. Error 10		RS-485 Modbus transmission time-Out	Motor drive does not respond to the communication command sent from the keypad.  1. Verify that the keypad is properly connected to the motor drive by a communication cable such as RJ45.  2. Press RESET to clear the errors.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your local authorized dealer for assistance.
АИТО Warning CK10 KpdComm Time Out		Keypad communication data, transmission time-out (Keypad auto-detect this error and display it).	Keypad does not accept the motor drive's communication command.  1. Remove the keypad and reconnect it.  2. Verify if the Baud rate = 19200 bps, and the Format = RTU8, N, 2  3. Verify if the keypad is properly connected to the motor drive on the communication contact by a communication cable such as RJ45.  If none of the above solution works, contact your local authorized dealer.
Warning TPNO TP No Object	Keypad communication time out (CK10)	Object not supported by TPEditor	<ol> <li>Keypad's TPEditor uses an unsupported object.</li> <li>Verify that the TPEditor is not using an unsupported object or setting. Delete unsupported objects and unsupported settings.</li> <li>Re-edit the object in the TPEditor, and then download it to the keypad.</li> <li>Verify that the motor drive supports the TP functions. If the drive does not support TP function, the main page displays Default.</li> <li>If none of the above solutions works, contact your local authorized dealer for assistance.</li> </ol>

The warning code CExx only occurs when the communication problem is between the drive and the keypad. It has nothing to do with the drive and other devices. Note the warning code description to find the cause of the error if CExx appears.

## **File Copy Setting Fault Description:**

These faults occur when KPC-CC01 cannot perform the command after clicking the ENTER key in the copy function.



LCD Display *	Fault Name	Description	Corrective Actions
ERR1 Read Only	Read only (ERR1)	Parameter and file are read-only	The parameter / file is read-only and cannot be written to.  1. Verify the specification in the user manual. If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR2  Write Fail	Write in error (ERR2)	Fail to write parameter and file	An error occurred while writing to a parameter / file.  1. Check for any problem on the Flash IC.  2. Shut down the system, wait for ten minutes, and then restart the system.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR3 VFD Running	Drive operating (ERR3)	AC motor drive is in operating status	A setting cannot be changed while the motor drive is in operation.  1. Verify that the drive is not in operation.  If this solution does not work, contact your local authorized dealer for assistance.
001> P00-00 ERR4 Pr Lock	Parameter locked (ERR4)	AC motor drive parameter is locked	A setting cannot be changed because a parameter is locked.  1. Check if the parameter is locked. If it is locked, unlock it and try to set the parameter again.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR5 Pr Changing	Parameter changing (ERR5)	AC motor drive parameter is changing	A setting cannot be changed because a parameter is being modified.  1. Check if the parameter is being modified. If it is not being modified, try to change that parameter again.  If this solution does not work, contact your local authorized dealer for assistance.
ERR6 Fault Code	Fault code (ERR6)	Fault code is not cleared	A setting cannot be changed because an error has occurred in the motor drive.  1. Check if any error occurred in the motor drive. If there is no error, try to change the setting again.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00 ERR7 Warning Code	Warning code (ERR7)	Warning code is not cleared	A setting cannot be changed because of a warning message given to the motor drive.  1. Check if there is a warning message given to the motor drive.  If this solution does not work, contact your local authorized dealer for assistance.

Chapter 10 Digital Keypad | CP2000

LCD Display *	Fault Name	Description	Corrective Actions
P00-00  ERR8  Type Mismatch	File type mismatch (ERR8)	File type mismatch	Data to be copied are not the correct type, so the setting cannot be changed.  1. Check if the products' serial numbers to be copied are in the same category. If they are in the same category, try to copy the setting again.  If this solution does not work, contact your local authorized dealer for assistance.
P00-00  ERR9  Password Lock	Password locked (ERR9)	File is locked with password	A setting cannot be changed because some data are locked.  1. Check if the data are unlocked or able to be unlocked. If the data are unlocked, try to change the setting again.  2. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your local authorized dealer for assistance.
P00-00  ERR10  Password Fail	Password fail (ERR10)	File password mismatch	A setting cannot be changed because the password is incorrect.  1. Check if the password is correct. If the password is correct, try to change the setting again.  2. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your local authorized dealer for assistance.
001> P00-00 ERR11 Version Fail	Version fail (ERR11)	File version mismatch	A setting cannot be changed because the version of the data is incorrect.  1. Check if the version of the data matches the motor drive. If it matches, try to change the setting again.  If none of the above solutions works, contact your local authorized dealer for assistance.
001> P00-00 ERR12 VFD Time Out	VFD Time out (ERR12)	AC motor drive copy function time-out	A setting cannot be changed because the data copying time-out expired.  1. Try copying the data again.  2. Check if copying data is authorized. If it is authorized, try to copy the data again.  3. Shut down the system, wait for ten minutes, and then restart the system.  If none of the above solutions works, contact your local authorized dealer for assistance.


<sup>\*</sup> The content in this section only applies to the KPC-CC01 keypad V1.01 and later versions.

## 10-5 Unsupported Functions when using TPEditor with the KPC-CC01


1. Local Page Setting and Global Setting functions are not supported.



2. In the Communication menu, Read from TP function is not supported.



3. In the RTC Display Setting, you cannot change the Refer Device.



[This page intentionally left blank]

# Chapter 11 Summary of Parameter Settings

This chapter provides a summary of parameter (Pr.) setting ranges and defaults. You can set, changed and reset parameters through the digital keypad.

#### NOTE

- 1)  $\mathcal{N}$ : You can set this parameter during operation
- 2) For more detail on parameters, refer to Ch12 Description of Parameter Settings.
- 3) The following are abbreviations for different types of motors:
  - IM: Induction motor
  - PM: Permanent magnet synchronous AC motor
  - IPM: Interior permanent magnet synchronous AC motor
  - SPM: Surface permanent magnet synchronous AC motor
  - SynRM: Synchronous reluctance motor

#### **00 Drive Parameters**

Pr.	Parameter Name	Settings Range	Default
		4: 230V, 0.75 kW	
		5: 460V, 0.75 kW	
		6: 230V, 1.50 kW	
		7: 460V, 1.50 kW	
		8: 230V, 2.20 kW	
		9: 460V, 2.20 kW	
		10: 230V, 3.70 kW	
		11: 460V, 3.70 kW	
		12: 230V, 5.50 kW	
		13: 460V, 5.50 kW	
		14: 230V, 7.50 kW	
		15: 460V, 7.50 kW	
		16: 230V, 11.0 kW	
		17: 460V, 11.0 kW	Read
00-00	AC motor drive identity code	18: 230V, 15.0 kW	only
		19: 460V, 15.0 kW	<b>,</b>
		20: 230V, 18.5 kW	
		21: 460V, 18.5 kW	
		22: 230V, 22.0 kW	
		23: 460V, 22.0 kW	
		24: 230V, 30.0 kW	
		25: 460V, 30.0 kW	
		26: 230V, 37.0 kW	
		27: 460V, 37.0 kW	
		28: 230V, 45.0 kW	
		29: 460V, 45.0 kW	
		30: 230V, 55.0 kW	
		31: 460V, 55.0 kW	
		32: 230V, 75.0 kW	

Pr.	Parameter Name	Settings Range	Default
		33: 460V, 75.0 kW	
		34: 230V, 90.0 kW	
		35: 460V, 90.0 kW	
		37: 460V, 110.0 kW	
		39: 460V, 132.0 kW	
		41: 460V, 160.0 kW	
		43: 460V, 185.0 kW	
		45: 460V, 220.0 kW	
		47: 460V, 280.0 kW	
		49: 460V, 315.0 kW	
		51: 460V, 355.0 kW	
		53: 460V, 400.0 kW	
		55: 460V, 450.0 kW	
		57: 460V, 500.0 kW	
		59: 460V, 560.0 kW	
		61: 460V, 630.0 kW	
		90: 230V, 3.00 kW	
		91: 460V, 3.00 kW	
		92: 230V, 4.00 kW	
		93: 460V, 4.00 kW	
		486: 460V, 200 kW	
		487: 460V, 250 kW	
		505: 575V, 1.5 kW	
		506: 575V, 2.2 kW	
		507: 575V, 3.7 kW	
		508: 575V, 5.5 kW	
		509: 575V, 7.5 kW	
		510: 575V, 11 kW	
		511: 575V, 15 kW	
		612: 690V, 18.5 kW	
		613: 690V, 22 kW	
		614: 690V, 30 kW	
		615: 690V, 37 kW	
		616: 690V, 45 kW	
		617: 690V, 55 kW	
		618: 690V, 75 kW	
		619: 690V, 90 kW	
		620: 690V, 110 kW	
		621: 690V, 132 kW	
		622: 690V, 160 kW	
		626: 690V, 315 kW	
		628: 690V, 400 kW	
		629: 690V, 450 kW	
		631: 690V, 560 kW	
		632: 690V, 630 kW	
		686: 690V, 200 kW	
		687: 690V, 250 kW	
00-01	AC motor drive rated current display	Display by models	Read
		. , ,	only

	Pr.	Parameter Name	Settings Range	Default
			0: No function	
			1: Write protection for parameters	
			5: Return kWh displays to 0	
			6: Reset PLC (including CANopen Master Index)	
	00-02	Parameter reset	7: Reset CANopen Slave index	0
			9: Reset all parameters to defaults	
			(base frequency is 50 Hz)	
			10: Reset all parameters to defaults	
			(base frequency is 60 Hz)	
			0: F (frequency command)	
~	00-03	Start-up display	1: H (output frequency)	0
,,	00 00	carr up diopiay	2: U (user-defined, see Pr.00-04)	J
			3: A (output current)	
			0: Display output current (A) (Unit: Amp)	
			1: Display counter value (c) (Unit: CNT)	
			2: Display the motor's actual output frequency (H.)	
			(Unit: Hz)	
			3: Display the drive's DC bus voltage (v) (Unit: V <sub>DC</sub> )	
			4: Display the drive's output voltage (E) (Unit: V <sub>AC</sub> )	
			5: Display the drive's output power angle (n)	
			(Unit: deg)	
			6: Display the drive's output power (P) (Unit: kW)	
			7: Display the motor speed rpm (r) (Unit: rpm)	
			10: Display PID feedback (b) (Unit: %)	
			11: Display AVI1 analog input terminal signal (1.) (Unit: %)	
			12: Display ACI analog input terminal signal (2.)	
			(Unit: %)	
		Content of multi-function display (user-defined)	13: Display AVI2 analog input terminal signal (3.) (Unit: %)	
×	00-04		14: Display the drive's IGBT temperature (i.) (Unit: °C)	3
			15: Display the drive's capacitance temperature (c.)	
			(Unit: °C)	
			16: The digital input status (ON / OFF) (i)	
			17: The digital output status (ON / OFF) (o)	
			18: Display multi-step speed (S)	
			19: The corresponding CPU digital input pin status	
			(d)	
			20: The corresponding CPU digital output pin status	
			(0.)	
			26: Ground fault GFF (G.) (Unit: %)	
			27: DC bus voltage ripple (r.) (Unit: V <sub>DC</sub> )	
			28: Display PLC register D1043 data (C)	
			30: Display the output of User-defined (U)	
			31: Display Pr.00-05 user gain (K)	
			34: Operation speed of fan (F.) (Unit: %)	
			36: Present operating carrier frequency of the drive	
			(J.) (Unit: Hz)	

	Pr.	Parameter Name	Settings Range	Default
			38: Display the drive status (6.)	
			41: kWh display (J) (Unit: kWh)	
			42: PID target value (h.) (Unit: %)	
			43: PID compensation (o.) (Unit: %)	
			44: PID output frequency (b.) (Unit: Hz)	
			45: Hardware ID	
			51: PMSVC torque offset	
			52: AI10%	
			53: AI11%	
			68: STO version	
			69: STO checksum-high word (d) 70: STO checksum-low word (d)	
		Coefficient gain in actual output	70. STO Checksum-low word (d)	
*	00-05	frequency	0.00–160.00	1.00
	00-06	Firmware version	Read only	Read only
N	00-07	Parameter protection password	0–65535	0
,		input	0–4: the number of password attempts allowed	_
			0–65535	
×	80-00	Parameter protection password	0: No password protection or password entered	0
		setting	correctly (Pr.00-07)	
			1: Parameter has been set	
			0: IMVF (IM V/F control)	
			2: IM / PM SVC (IM / PM Space vector control)     6: PM Sensorless (PM filed-oriented sensorless	
	00-11	Speed control mode	vector control) (applied to 230V / 460V models)	0
			8: SynRM Sensorless control (applied to 230V /	
			460V models)	
			0: Light duty	
	00-16	Load selection	1: Normal duty	0
			230V / 460V models	
			Light duty	
			Control mode VE SVC PMEOC SRMFOC*	
			VED007_150CP23A/E	8
			VFD007-185CP43A/E 2-15 4-10 4-8	
			VFD185-450CP23A/E VFD220-750CP43A/E 2-10 4-10 4-8	6
			VFD550-1100CP23A/E         2-9         4-9         4-8	4
			*The default is 4 kHz in SRMFOC mode.	
	00-17	Carrier Frequency (kHz)	Normal duty	
			Control mode VE SVC PMEOC SPMEOC*	
			Model         VF, 3VC         FIMILOC         SKWIFOC           VFD007-150CP23A/E         2-15         4-10         4-8	8
			VFD185-450CP23A/E	6
			VFD550-1100CP23A/E 2_9 4_9 4_8	
			VFD900-6300CP43A/E	4
			*The default is 4 kHz in SRMFOC mode.	
			· I	

	Pr.	Parameter Name	Set	ttings Range	Default
			575V / 690V models		
			Light duty		
			Control mode	VF, SVC	
			Model VFD015–150CP53A	2–9	4
			VFD185–5600CP63A	2–9	4
			VFD6300CP63A	2–9	3
			Normal duty		
			Control mode Model	VF, SVC	
			VFD015-150CP53A	2–9	4
			VFD185-5600CP63A	2–9	4
			VFD6300CP63A	2–9	3
	00-19	PLC command mask		d is forced by PLC control	Read
ļ				nand is forced by PLC control	only
			0: Digital keypad	-41 in-m-4	
			1: RS-485 communica	•	
		Master frequency command		out (Refer to Pr.03-00–03-02) /N terminal (multi-function input	
	00-20	source (AUTO) / Source selection	terminals)	n terriinai (muti-iunction input	0
		of the PID target	6: CANopen commun	ication card	
			•	rd (does not include CANopen	
			card)	(	
			0: Digital keypad		
			1: External terminals		
	00-21	Operation command source	2: RS-485 communication	ation input	0
	00 21	(AUTO)	3: CANopen commun		Ü
				rd (does not include CANopen	
-			card)		
1	00-22	Stop method	0: Ramp to stop 1: Coast to stop		0
ŀ			0: Enable forward / re	everse	
/	00-23	Motor direction control	1: Disable reverse	· -	0
			2: Disable forward		
ĺ	00-24	Digital operator (keypad) frequency	Read only		Read
		command memory	•		only
			bit0–3: user-defined of 0000b: no decimal	•	
			0000b: no decimal	•	
			0010b: two decima	•	
			0011b: three decim	·	
1	00-25	User-defined characteristics	bit4–15: user-defined	·	0
			000xh: Hz		
			001xh: rpm		
			002xh: %		
			003xh: kg		

Pr.	Parameter Name	Settings Range	Default
		004xh: m/s	
		005xh: kW	
		006xh: HP	
		007xh: ppm	
		008xh: 1/m	
		009xh: kg/s	
		00Axh: kg/m	
		00Bxh: kg/h	
		00Cxh: lb/s	
		00Dxh: lb/m	
		00Exh: lb/h	
		00Fxh: ft/s	
		010xh: ft/m	
		011xh: m	
		012xh: ft	
		013xh: degC	
		014xh: degF	
		015xh: mbar	
		016xh: bar	
		017xh: Pa	
		018xh: kPa	
		019xh: mWG	
		01Axh: inWG	
		01Bxh: ftWG	
		01Cxh: psi	
		01Dxh: atm	
		01Exh: L/s	
		01Fxh: L/m	
		020xh: L/h	
		021xh: m3/s	
		022xh: m3/h	
		023xh: GPM	
		024xh: CFM	
		xxxxh: Hz	
		0: No function	
		0–65535 (when Pr.00-25 is set to no decimal place)	
		0.0–6553.5 (when Pr.00-25 is set to 1 decimal	
00.00	Mandana and an all firms I	place)	_
00-26	Maximum user-defined value	0.00–655.35 (when Pr.00-25 is set to 2 decimal	0
		places)	
		0.000–65.535 (when Pr.00-25 is set to 3 decimal	
		places)	
00-27	User-defined value	Read only	Read Only
		bit0: Sleep function control bit	J.11.y
		0: Cancel sleep function	
00-28	Switching from AUTO mode to	1: Sleep function and Auto mode are the same	
33 20	HAND mode	bit1: Control bit unit	
		0: Displaying unit in Hz	
	<u> </u>		

Pr.	Parameter Name	Settings Range	Default
		1: Same unit as the Auto mode	
		bit2: PID control bit	
		0: Cancel PID control	
		1: PID control and Auto mode are the same	
		bit3: Frequency source control bit	
		0: Frequency source set up by parameter, if the	
		multi-step speed is activated, then	
		multi-speed has the priority.	
		1: Frequency command set up by Pr.00-30,	
		regardless of whether the multi-step speed	
		is activated.	
		0: Standard HOA function	
		1: When switching between local and remote, the	
		drive stops	
		2: When switching between local and remote, the	
		drive runs with REMOTE settings for frequency	
	LOCAL / REMOTE selection	and operation status	0
00-29		3: When switching between local and remote, the	
00-29		drive runs with LOCAL settings for frequency and	
		operation status	
		4: When switching between local and remote, the	
		drive runs with LOCAL settings when switched to	
		Local and runs with REMOTE settings when	
		switched to Remote for frequency and operation	
		status.	
		0: Digital keypad	
	Master frequency command source	1: RS-485 communication input	
		2: External analog input (Refer to Pr.03-00–03-02)	
00-30	(HAND)	3: External UP / DOWN terminal	0
	()	6: CANopen communication card	
		8: Communication card (does not include CANopen	
		card)	
		0: Digital keypad	
	Operation command source	1: External terminals	
00-31	Operation command source (HAND)	RS-485 communication input     CANopen communication card	0
	(HAND)	5: Communication card (does not include CANopen	
		card)	
		0: STOP key disabled	
00-32	Digital keypad STOP function	1: STOP key enabled	0
00-37	Over-modulation gain	80–120	100
00-48	Display filter time (current)	0.001–65.535 sec.	0.100
00-49	Display filter time (keypad)	0.001–65.535 sec.	0.100
00.50			Read
00-50	Software version (Date)	Read only	only

## **01 Basic Parameters**

	Pr.	Parameter Name	Settings Range	Default
*	01-00	Maximum operation frequency of motor 1	50.00–599.00 Hz Setting range for/including 45 kW (60 HP) and above: 0.00–400 Hz	60.00 / 50.00
	01-01	Rated / base frequency of motor 1	0.00–599.00 Hz	60.00 / 50.00
	01-02	Rated / base voltage of motor 1	230V models: 0.0–255.0 V 460V models: 0.0–510.0 V 575V models: 0.0–637.0 V 690V models: 0.0–765.0 V	200.0 400.0 575.0 660.0
	01-03	Mid-point frequency 1 of motor 1	0.00–599.00 Hz	3.00 / 0.00
*	01-04	Mid-point voltage 1 of motor 1	230V models: 0.0–240.0 V 460V models: 0.0–480.0 V 575V models: 0.0–637.0 V 690V models: 0.0–720.0 V *690V, with 185 kW and above: 10.0	11.0 22.0 0.0 0.0
	01-05	Mid-point frequency 2 of motor 1	0.00-599.00 Hz	1.50
*	01-06	Mid-point voltage 2 of motor 1	230V models: 0.0–240.0 V 460V models: 0.0–480.0 V 575V models: 0.0–637.0 V 690V models: 0.0–720.0 V *690V, with 185 kW and above: 2.0	5.0 10.0 0.0 0.0
	01-07	Minimum output frequency of motor 1	0.00-599.00 Hz	1.50
*	01-08	Minimum output voltage of motor 1	230V models: 0.0–240.0 V 460V models: 0.0–480.0 V 575V models: 0.0–637.0 V 690V models: 0.0–720.0 V	1.0 2.0 0.0 0.0
	01-09	Start-up frequency	0.00–599.00 Hz	0.50
*	01-10	Output frequency upper limit	0.00–599.00 Hz	599.00
*	01-11	Output frequency lower limit	0.00-599.00 Hz	0.00
*	01-12	Acceleration time 1	Pr.01-45 = 0: 0.00–600.00 sec.  Pr.01-45 = 1: 0.0–6000.0 sec.  Motor drive with 230V/460V/690V, 22 kW and above:  60.00 / 60.0  Motor drive with 690V, 160 kW and above: 80.00 / 80.0	10.00
*	01-13	Deceleration time 1	Pr.01-45 = 0: 0.00–600.00 sec.  Pr.01-45 = 1: 0.0–6000.0 sec.  Motor drive with 230V/460V/690V, 22 kW and above:  60.00 / 60.0  Motor drive with 690V, 160 kW and above: 80.00 / 80.0	10.00
*	01-14	Acceleration time 2	Pr.01-45 = 0: 0.00–600.00 sec.  Pr.01-45 = 1: 0.0–6000.0 sec.  Motor drive with 230V/460V/690V, 22 kW and above:  60.00 / 60.0  Motor drive with 690V, 160 kW and above: 80.00 / 80.0	10.00

	Pr.	Parameter Name	Settings Range	Default
			Pr.01-45 = 0: 0.00–600.00 sec.	
	01-15		Pr.01-45 = 1: 0.0–6000.0 sec.	
×		Deceleration time 2	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
			60.00 / 60.0	
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
			Pr.01-45 = 1: 0.0–6000.0 sec.	
×	01-16	Acceleration time 3	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
			60.00 / 60.0	
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
			Pr.01-45 = 1: 0.0–6000.0 sec.	
×	01-17	Deceleration time 3	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
			60.00 / 60.0	
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
			Pr.01-45 = 1: 0.0–6000.0 sec.	
×	01-18	Acceleration time 4	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
			60.00 / 60.0	
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
	04.40	5 1 " " 4	Pr.01-45 = 1: 0.0–6000.0 sec.	40.00
~	01-19	Deceleration time 4	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
			60.00 / 60.0 Mater drive with 600 / 160 kW and shave 80.00 / 80.0	
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0  Pr.01-45 = 0: 0.00–600.00 sec.	
			Pr.01-45 = 1: 0.0–6000.00 sec.	
N	01-20	JOG acceleration time	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
ĺ	01-20	300 acceleration time	60.00 / 60.0	10.00
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0	
			Pr.01-45 = 0: 0.00–600.00 sec.	
			Pr.01-45 = 1: 0.0–6000.0 sec.	
×	01-21	JOG deceleration time	Motor drive with 230V/460V/690V, 22 kW and above:	10.00
			60.00 / 60.0	
			Motor drive with 690V, 160 kW and above: 80.00 / 80.0	
×	01-22	JOG frequency	0.00-599.00 Hz	6.00
×	01-23	Switch frequency between first and	0.00–599.00 Hz	0.00
		fourth Accel. / Decel.		
×	01-24	S-curve for acceleration begin time 1	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
			Pr.01.45 = 1: 0.0–250.0 sec.	
×	01-25	S-curve for acceleration arrival time 2	Pr.01-45 = 0: 0.00–25.00 sec.	0.20
			Pr.01-45 = 1: 0.0–250.0 sec. Pr.01-45 = 0: 0.00–25.00 sec.	
×	01-26	S-curve for deceleration begin time 1	Pr.01-45 = 1: 0.0–250.0 sec.	0.20
			Pr.01-45 = 0: 0.00–25.00 sec.	
×	01-27	S-curve for deceleration arrival time 2	Pr.01-45 = 1: 0.0–250.0 sec.	0.20
	01-28	Skip frequency 1 (upper limit)	0.00–599.00 Hz	0.00
	01-29	Skip frequency 1 (lower limit)	0.00–599.00 Hz	0.00
	0.20		5.55 000.00 TIE	5.55

	Pr.	Parameter Name	Settings Range	Default
	01-30	Skip frequency 2 (upper limit)	0.00–599.00 Hz	0.00
	01-31	Skip frequency 2 (lower limit)	0.00-599.00 Hz	0.00
	01-32	Skip frequency 3 (upper limit)	0.00-599.00 Hz	0.00
	01-33	Skip frequency 3 (lower limit)	0.00–599.00 Hz	0.00
	01-00		0: Output waiting	0.00
			1: Zero-speed operation	
	01-34	Zero-speed mode	2: Minimum frequency (Refer to Pr.01-07 and	0
			Pr.01-41)	
			,	60.00 /
	01-35	Rated / base frequency of motor 2	0.00–599.00 Hz	50.00
			230V models: 0.0–255.0 V	200.0
	01-36	Dated / base voltage of mater 2	460V models: 0.0–510.0 V	400.0
	01-30	Rated / base voltage of motor 2	575V models: 0.0–637.0 V	575.0
			690V models: 0.0–765.0 V	660.0
	01-37	Mid-point frequency 1 of motor 2	0.00–599.00 Hz	3.00
			230V models: 0.0–240.0 V	11.0
		Mid-point voltage 1 of motor 2	460V models: 0.0–480.0 V	22.0
/	01-38		575V models: 0.0–637.0 V	0.0
			690V models: 0.0–720.0 V	0.0
			Motor drive with 690V, 185 kW and above: 10.0	
	01-39	Mid-point frequency 2 of motor 2	0.00–599.00 Hz	1.50
			230V models: 0.0–240.0 V	5.0
		Mid-point voltage 2 of motor 2	460V models: 0.0–480.0 V	10.0
/	01-40		575V models: 0.0–637.0 V	0.0
			690V models: 0.0–720.0 V	0.0
			Motor drive with 690V, 185 kW and above: 2.0	
	01-41	Minimum output frequency of motor 2	0.00–599.00 Hz	0.50
			230V models: 0.0–240.0 V	1.0
,	01-42	Minimum output voltage of motor 2	460V models: 0.0–480.0 V	2.0
	01-42	williman output voltage of motor 2	575V models: 0.0–637.0 V	0.0
			690V models: 0.0–720.0 V	0.0
			0: V/F curve determined by Pr.01-00–01-08	
			1: V/F curve to the power of 1.5	
			2: V/F curve to the power of 2	
			3: 60 Hz, voltage saturation in 50 Hz	
			4: 72 Hz, voltage saturation in 60 Hz	
			5: 50 Hz, decrease gradually with cube	
			6: 50 Hz, decrease gradually with square	
	01-43	V/F curve selection	7: 60 Hz, decrease gradually with cube	0
			8: 60 Hz, decrease gradually with square	
			9: 50 Hz, medium starting torque	
			10: 50 Hz, high starting torque	
			11: 60 Hz, medium starting torque	
			12: 60 Hz, high starting torque 13: 90 Hz, voltage saturation in 60 Hz	
			13. 90 Hz, voltage saturation in 60 Hz	
			15: 180 Hz, voltage saturation in 60 Hz	
			10. 100 Hz, voltage saturation in 00 Hz	

## Chapter 11 Summary of Parameter Settings | CP2000

	Pr.	Parameter Name	Settings Range	Default
			0: Linear acceleration and deceleration	
			1: Auto-acceleration and linear deceleration	
~	01-44	Auto-acceleration and	2: Linear acceleration and auto-deceleration	0
,	01-44	auto-deceleration setting	3: Auto-acceleration and auto-deceleration	0
			4: Stall prevention by auto-acceleration and	
			auto-deceleration (limited by Pr.01-12–01-21)	
	01-45	Time unit for acceleration /	0: Unit: 0.01 sec.	0
	01-43	deceleration and S-curve	1: Unit: 0.1 sec.	0
~	01-46	01-46 CANopen quick stop time	Pr.01-45 = 0: 0.00–600.00 sec.	1.00
,			Pr.01-45 = 1: 0.0–6000.0 sec.	1.0
			0: Normal deceleration	
	01-49	Deceleration method selection	1: Over-voltage energy restriction	0
	01-49	Deceleration method selection	2: Traction energy control (TEC)	0
			3: Electromagnetic energy traction control	
×	01-50	Electromagnetic traction energy consumption coefficient	0.00-5.00 Hz	0.50
		Flux-weakening overload stall		
×	01-51	prevention time (applied to 230V /	0.00-600.00 sec.	1.00
		460V models)		

# **02 Digital Input / Output Parameters**

Pr.	Parameter Name	Setting Range	Default
		0: Two-wire mode 1, power on for operation control	
02-00	Two-wire / three-wire operation	1: Two-wire mode 2, power on for operation control	0
	control	2: Three-wire, power on for operation control	
02-01	Multi-function input command 1 (MI1)	0: No function	1
02-02	Multi-function input command 2 (MI2)	1: Multi-step speed command 1	2
02-03	Multi-function input command 3 (MI3)	2: Multi-step speed command 2	3
02-04	Multi-function input command 4 (MI4)	3: Multi-step speed command 3	4
02-05	Multi-function input command 5 (MI5)	4: Multi-step speed command 4	0
02-06	Multi-function input command 6 (MI6)	5: Reset	0
02-07	Multi-function input command 7 (MI7)	6: JOG operation (By KPC-CC01 or external	0
02-08	Multi-function input command 8 (MI8)	control)	0
00.00	Input terminal of I/O extension card	7: Acceleration / deceleration speed inhibit	•
02-26	(MI10)	8: 1st and 2nd acceleration / deceleration time	0
00.07	Input terminal of I/O extension card	selection	•
02-27	(MI11)	9: 3 <sup>rd</sup> and 4 <sup>th</sup> acceleration / deceleration time	0
00.00	Input terminal of I/O extension card	selection	•
02-28	(MI12)	10: External Fault (EF) input (Pr.07-20)	0
00.00	Input terminal of I/O extension card	11: Base Block (B.B) input from external	0
02-29	(MI13)	12: Output stop	0
00.00	Input terminal of I/O extension card	13: Cancel the setting of auto-acceleration /	0
02-30	(MI14)	auto-deceleration time	0
00.04	Input terminal of I/O extension card	14: Switch between motor 1 and motor 2	0
02-31	(MI15)	15: Rotating speed command from AVI1	0
		16: Rotating speed command from ACI	
		17: Rotating speed command from AVI2	
		18: Forced to stop (Pr.07-20)	
		19: Frequency up command	
		20: Frequency down command	
		21: PID function disabled	
		22: Clear the counter	
		23: Input the counter value (MI6)	
		24: FWD JOG command	
		25: REV JOG command	
		28: Emergency stop (EF1)	
		29: Signal confirmation for Y-connection	
		30: Signal confirmation for ∆-connection	
		38: Disable write EEPROM function	
		40: Force coasting to stop	
		41: HAND switch	
		42: AUTO switch	
		49: Enable drive	
		50: Slave dEb action to execute	
		51: Selection for PLC mode bit0	
		52: Selection for PLC mode bit1	
		53: Trigger CANopen quick stop	

	Pr.	Parameter Name	Setting Range	Default
			54: UVW output electromagnetic valve switch	
			55: Brake release	
			56: Local / Remote selection	
			58: Enable fire mode (with RUN command)	
			59: Enable fire mode (without RUN command)	
			60: Disable all the motors	
			61: Disable Motor 1	
			62: Disable Motor 2	
			63: Disable Motor 3	
			64: Disable Motor 4	
			65: Disable Motor 5	
			66: Disable Motor 6	
			67: Disable Motor 7	
			68: Disable Motor 8	
			69: Preheating command	
		/	0: UP / DOWN by the acceleration / deceleration	
×	02-09	UP / DOWN key mode	time	0
			1: UP / DOWN constant speed (Pr.02-10)	
		Constant speed, acceleration /		
×	02-10	deceleration speed of the UP /	0.001–1.000 Hz / ms	0.001
		DOWN key		
×	02-11	Multi-function input response time	0.000-30.000 sec.	0.005
×	02-12	Multi-function input mode selection	0000h–FFFFh (0: N.O.; 1: N.C.)	0000h
×	02-13	Multi-function output 1 RLY1	0: No function	11
×	02-14	Multi-function output 2 RLY2	1: Indication during RUN	1
×	02-15	Multi-function output 3 RLY3	2: Operation speed reached	66
		Output terminal of I/O extension card	3: Desired frequency reached 1 (Pr.02-22)	
*	02-36	(MO10) or (RA10)	4: Desired frequency reached 2 (Pr.02-24)	0
		Output terminal of I/O extension card	5: Zero speed (Frequency command)	_
×	02-37	(MO11) or (RA11)	6: Zero speed including STOP (Frequency	0
		Output terminal of I/O extension card-	command)	
×	02-38	(RA12)	7: Over-torque 1 (Pr.06-06-08)	0
		Output terminal of I/O extension card	8: Over-torque 2 (Pr.06-09–06-11)	
×	02-39	(RA13)	9: Drive is ready	0
		Output terminal of I/O extension card	10: Low voltage warning (Lv) (Pr.06-00)	
×	02-40	(RA14)	11: Malfunction indication	0
		Output terminal of I/O extension card	12: Mechanical brake release (Pr.02-32)	
×	02-41	(RA15)	13: Overheat warning (Pr.06-15)	0
		Output terminal of I/O extension card	14: Software brake signal indication (Pr.07-00)	
×	02-42	(MO16 virtual terminal)	15: PID feedback error (Pr.08-13, Pr.08-14)	0
		,	` ·	
×	02-43	Output terminal of I/O extension card (MO17 virtual terminal)	16: Slip error (oSL) 17: Count value reached, does not return to 0	0
		,		
×	02-44	Output terminal of I/O extension card	(Pr.02-20)	0
ŀ		(MO18 virtual terminal)	18: Count value reached, returns to 0	
N	02-45	Output terminal of I/O extension card	(Pr.02-19)	0
	-	(MO19 virtual terminal)	19: External interrupt B.B. input (Base Block)	
,,	02-46	Output terminal of I/O extension card	20: Warning output	0
7*	0 <u>2</u> -70	(MO20 virtual terminal)	21: Over-voltage	

y) utput
•
•
•
•
•
•
•
•
71–06-73)
switch
terface
ards
0000h
0
0
60.00 / 50.00
2.00
t

#### Chapter 11 Summary of Parameter Settings | CP2000

	Pr.	Parameter Name	Setting Range	Default
*	02-24	Desired frequency reached 2	0.00–599.00 Hz	60.00 / 50.00
*	02-25	The width of the desired frequency reached 2	0.00–599.00 Hz	2.00
	02-32	Brake delay time	0.000-65.000 sec.	0.000
*	02-33	Output current level setting for multi-function output terminal	0–150%	0
*	02-34	Output frequency setting for multi-function output terminal	0.00–599.00 Hz	3.00
*	02-35	External operation control selection after reset and reboot	Disable     The Run command remains after reset or reboot	0
	02-50	Display the status of multi-function input terminal	Monitor the status of multi-function input terminals	Read only
	02-51	Display the status of multi-function output terminal	Monitor the status of multi-function output terminals	Read only
	02-52	Display the external multi-function input terminals used by PLC	Monitor the status of PLC input terminals	Read only
	02-53	Display the external multi-function output terminals used by PLC	Monitor the status of PLC output terminals	Read only
	02-54	Display the frequency command executed by external terminal	0.00–599.00 Hz (Read only)	Read only
	02-70	IO card types	1: EMC-BPS01 4: EMC-D611A 5: EMC-D42A 6: EMC-R6AA 11: EMC-A22A	Read only
×	02-72	Preheating output current level	0–100%	0
N	02-73	Preheating output cycle	0–100%	0

## 03 Analog Input / Output Parameters

	Pr.	Parameter Name	Setting Range	Default
~	03-00	AVI1 analog input selection	0: No function	1
~	03-01	ACI analog input selection	1: Frequency command (speed limit under torque	0
~	03-02	AVI2 analog input selection	control mode)	0
Ī			4: PID target value	
			5: PID feedback signal	
			6: Thermistor (PTC) input value	
			11: PT100 thermistor input value	
			13: PID compensation value	
~	03-03	AVI1 analog input bias		
×	03-04	ACI analog input bias	100 0 100 00/	0.0
	00.05	AVI2 analog positive voltage	-100.0–100.0%	0.0
*	03-05	input bias		
	00.07	AVI1 positive / negative bias	0: No bias	
	03-07	mode	1: Lower than or equal to bias	
	02.00	ACI positive / negative bias	2: Greater than or equal to bias	0
	03-08	mode	3: The absolute value of the bias voltage while serving	0
	02.00	AVI2 positive / negative bias	as the center	
	03-09	mode	4: Bias serves as the center	
*	03-10	Reverse setting when analog signal input is negative frequency	<ul> <li>0: Negative frequency input is not allowed. The digital keypad or external terminal controls the forward and reverse direction.</li> <li>1: Negative frequency is allowed. Positive frequency = run in a forward direction; negative frequency = run in a reverse direction. The digital keypad or external terminal control cannot change the running direction.</li> </ul>	0
~	03-11	AVI1 analog input gain	carmot change the running an ection.	
~	03-12	ACI analog input gain		
×	03-13	AVI2 analog positive input gain	-500.0–500.0%	100.0
~	03-14	AVI2 analog negative input gain		
~	03-15	AVI1 analog input filter time		
×	03-16	ACI analog input filter time	0.00-20.00 sec.	0.01
×	03-17	AVI2 analog input filter time		
*	03-18	Analog input addition function	0: Disable (AVI1, ACI, AVI2) 1: Enable	0
	03-19	Signal loss selection for the analog input 4–20 mA	Disable     Continue operation at the last frequency     Decelerate to 0 Hz     Stop immediately and display ACE	0
×	03-20	AFM1 analog output selection	0: Output frequency (Hz)	0
×	03-23	AFM2 analog output selection	1: Frequency command (Hz)	0
			2: Motor speed (Hz)	
			3: Output current (rms)	
			4: Output voltage	
			5: DC bus voltage	

	Pr.	Parameter Name	Setting Range	Default
			6: Power factor	
			7: Power	
			9: AVI1%	
			10: ACI%	
			11: AVI2%	
			20: CANopen analog output	
			21: RS-485 analog output	
			22: Communication card analog output	
			23: Constant voltage output	
~	03-21	AFM1 analog output gain	0.0–500.0%	100.0
		AEN44 analag autaut DEV	0: Absolute value in output voltage	
×	03-22	AFM1 analog output REV	1: Reverse output 0 V; forward output 0–10 V	0
		direction	2: Reverse output 5–0 V; forward output 5–10 V	
×	03-24	AFM2 analog output gain	0.0–500.0%	100.0
		45140	0: Absolute value in output voltage	
×	03-25	AFM2 analog output REV	1: Reverse output 0 V; forward output 0–10 V	0
		direction	2: Reverse output 5–0 V; forward output 5–10 V	
×	03-27	AFM2 output bias	-100.00–100.00%	0.00
			0: 0–10 V	
×	03-28	AVI1 terminal input selection	1: 0–20 mA	0
		•	2: 4–20 mA	
			0: 4–20 mA	
×	03-29	ACI terminal input selection	1: 0–10 V	0
		·	2: 0–20 mA	
	03-30	PLC analog output terminal status	Monitor the status of the PLC analog output terminals	Read only
	22.24		0: 0–20 mA output	
~	03-31	AFM2 output selection	1: 4–20 mA output	0
×	03-32	AFM1 DC output setting level	0.00 400 0004	0.00
×	03-33	AFM2 DC output setting level	0.00–100.00%	0.00
	22.24		0: 0–20 mA output	
	03-34	AFM1 output selection	1: 4–20 mA output	0
×	03-35	AFM1 output filter time	0.00.00	0.04
×	03-36	AFM2 output filter time	0.00–20.00 sec.	0.01
			0: AVI1	
×	03-44	Multi-function output (MO) by AI	1: ACI	0
		level source	2: AVI2	
×	03-45	Al upper level	-100.00–100.00%	50.00
×	03-46	Al lower level	-100.00–100.00%	10.00
			0: Normal curve	
			1: Three-point curve of AVI1	
			2: Three-point curve of ACI	
	00.55		3: Three-point curve of AVI1 & ACI	_
×	03-50	Analog input curve selection	4: Three-point curve of AVI2	7
			5: Three-point curve of AVI1 & AVI2	
			6: Three-point curve of ACI & AVI2	
			7: Three-point curve of AVI1 & ACI & AVI2	

Chapter 11 Summary of Parameter Settings | CP2000

	Pr.	Parameter Name	Setting Range	Default
			Pr.03-28 = 0, 0.00–10.00 V	0.00
×	03-51	AVI1 lowest point	Pr.03-28 = 1, 0.00–20.00 mA	0.00
			Pr.03-28 = 2, 0.00–20.00 mA	4.00
×	03-52	AVI1 proportional lowest point	-100.00–100.00%	0.00
			Pr.03-28 = 0, 0.00–10.00 V	5.00
×	03-53	AVI1 mid-point	Pr.03-28 = 1, 0.00–20.00 mA	10.00
			Pr.03-28 = 2, 0.00–20.00 mA	12.00
×	03-54	AVI1 proportional mid-point	-100.00–100.00%	50.00
			Pr.03-28 = 0, 0.00–10.00 V	10.00
×	03-55	AVI1 highest point	Pr.03-28 = 1, 0.00–20.00 mA	20.00
			Pr.03-28 = 2, 0.00–20.00 mA	20.00
×	03-56	AVI1 proportional highest point	-100.00–100.00%	100.00
×			Pr.03-29 = 0, 0.00–20.00 mA	4.00
	03-57	ACI lowest point	Pr.03-29 = 1, 0.00–10.00 V	0.00
			Pr.03-29 = 2, 0.00–20.00 mA	0.00
×	03-58	ACI proportional lowest point	-100.00–100.00%	0.00
			Pr.03-29 = 0, 0.00–20.00 mA	12.00
×	03-59	ACI mid-point	Pr.03-29 = 1, 0.00–10.00 V	5.00
			Pr.03-29 = 2, 0.00–20.00 mA	10.00
×	03-60	ACI proportional mid-point	-100.00–100.00%	50.00
			Pr.03-29 = 0, 0.00–20.00 mA	20.00
×	03-61	ACI high point	Pr.03-29 = 1, 0.00–10.00 V	10.00
			Pr.03-29 = 2, 0.00–20.00 mA	20.00
×	03-62	ACI proportional highest point	-100.00–100.00%	100.00
*	03-63	Positive AVI2 voltage lowest point	0.00–10.00 V	0.00
*	03-64	Positive AVI2 voltage proportional lowest point	-100.00–100.00%	0.00
~	03-65	Positive AVI2 voltage mid-point	0.00–10.00 V	5.00
~	03-66	Positive AVI2 voltage proportional mid-point	-100.00–100.00%	50.00
*	03-67	Positive AVI2 voltage highest point	0.00–10.00 V	10.00
*	03-68	Positive AVI2 voltage proportional highest point	-100.00–100.00%	100.00

# 04 Multi-step Speed Parameters

	Pr.	Parameter Name	Setting Range	Default
N	04-00	1 <sup>st</sup> step speed frequency	0.00-599.00 Hz	0.00
×	04-01	2 <sup>nd</sup> step speed frequency	0.00-599.00 Hz	0.00
×	04-02	3 <sup>rd</sup> step speed frequency	0.00-599.00 Hz	0.00
×	04-03	4 <sup>th</sup> step speed frequency	0.00-599.00 Hz	0.00
N	04-04	5 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-05	6 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-06	7 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
N	04-07	8 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-08	9 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-09	10 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
N	04-10	11 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-11	12 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-12	13 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-13	14 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-14	15 <sup>th</sup> step speed frequency	0.00–599.00 Hz	0.00
×	04-50	PLC buffer 0	0–65535	0
×	04-51	PLC buffer 1	0–65535	0
×	04-52	PLC buffer 2	0–65535	0
×	04-53	PLC buffer 3	0–65535	0
×	04-54	PLC buffer 4	0–65535	0
×	04-55	PLC buffer 5	0–65535	0
×	04-56	PLC buffer 6	0–65535	0
×	04-57	PLC buffer 7	0–65535	0
×	04-58	PLC buffer 8	0–65535	0
×	04-59	PLC buffer 9	0–65535	0
×	04-60	PLC buffer 10	0–65535	0
×	04-61	PLC buffer 11	0–65535	0
×	04-62	PLC buffer 12	0–65535	0
×	04-63	PLC buffer 13	0–65535	0
×	04-64	PLC buffer 14	0–65535	0
×	04-65	PLC buffer 15	0–65535	0
×	04-66	PLC buffer 16	0–65535	0
×	04-67	PLC buffer 17	0–65535	0
×	04-68	PLC buffer 18	0–65535	0
×	04-69	PLC buffer 19	0–65535	0
×	04-70	PLC Application parameter 0	0–65535	0
×	04-71	PLC Application parameter 1	0–65535	0
×	04-72	PLC Application parameter 2	0–65535	0
×	04-73	PLC Application parameter 3	0–65535	0
×	04-74	PLC Application parameter 4	0–65535	0
×	04-75	PLC Application parameter 5	0–65535	0
×	04-76	PLC Application parameter 6	0–65535	0
×	04-77	PLC Application parameter 7	0–65535	0
N	04-78	PLC Application parameter 8	0–65535	0
×	04-79	PLC Application parameter 9	0–65535	0

Chapter 11 Summary of Parameter Settings | CP2000

	Pr.	Parameter Name	Setting Range	Default
×	04-80	PLC Application parameter 10	0–65535	0
×	04-81	PLC Application parameter 11	0–65535	0
×	04-82	PLC Application parameter 12	0–65535	0
×	04-83	PLC Application parameter 13	0–65535	0
×	04-84	PLC Application parameter 14	0–65535	0
×	04-85	PLC Application parameter 15	0–65535	0
×	04-86	PLC Application parameter 16	0–65535	0
×	04-87	PLC Application parameter 17	0–65535	0
×	04-88	PLC Application parameter 18	0–65535	0
×	04-89	PLC Application parameter 19	0–65535	0
×	04-90	PLC Application parameter 20	0–65535	0
×	04-91	PLC Application parameter 21	0–65535	0
×	04-92	PLC Application parameter 22	0–65535	0
×	04-93	PLC Application parameter 23	0–65535	0
×	04-94	PLC Application parameter 24	0–65535	0
×	04-95	PLC Application parameter 25	0–65535	0
×	04-96	PLC Application parameter 26	0–65535	0
×	04-97	PLC Application parameter 27	0–65535	0
×	04-98	PLC Application parameter 28	0–65535	0
×	04-99	PLC Application parameter 29	0–65535	0

## **05 Motor Parameters**

	Pr.	Parameter Name	Setting Range	Default
	05-00	Motor parameter auto-tuning	0: No function 1: Simple rolling auto-tuning for induction motor (IM) 2: Static auto-tuning for induction motor (IM) 5: Rolling auto-tuning for PM (IPM / SPM) 11: SynRM parameter auto-tuning (applied to 230V / 460V models) 13: Static auto-tuning for PM (IPM / SPM)	0
	05-01	Full-load current for induction motor 1 (A)	Depending on the model power	Depending on the model power
*	05-02	Rated power for induction motor 1 (kW)	0.00–655.35 kW	Depending on the model power
*	05-03	Rated speed for induction motor 1 (rpm)	0–xxxx rpm (Depending on the motor's number of poles) 1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	Depending on the motor's number of poles
	05-04	Number of poles for induction motor 1	2–64	4
	05-05	No-load current for induction motor 1 (A)	0.00-Pr.05-01 default	Depending on the model power
	05-06	Stator resistance (Rs) for induction motor 1	0.000–65.535 Ω	Depending on the model power
	05-07	Rotor resistance (Rr) for induction motor 1	0.000–65.535 Ω	0.000
	05-08	Magnetizing inductance (Lm) for induction motor 1	0.0–6553.5 mH	0.0
	05-09	Stator inductance (Lx) for induction motor 1	0.0–6553.5 mH	0.0
	05-13	Full-load current for induction motor 2 (A)	Depending on the model power	Depending on the model power
*	05-14	Rated power for induction motor 2 (kW)	0.00–655.35 kW	Depending on the model power
*	05-15	Rated speed for induction motor 2 (rpm)	0–xxxx rpm (Depending on the motor's number of poles) 1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)	Depending on the motor's number of poles
	05-16	Number of poles for induction motor 2	2–64	4
	05-17	No-load current for induction motor 2 (A)	0.00-Pr.05-13 default	Depending on the model power
	05-18	Stator resistance (Rs) for induction motor 2	0.000–65.535 Ω	Depending on the model power

	Pr.	Parameter Name	Setting Range	Default
	05-19	Rotor resistance (Rr) for induction motor 2	0.000–65.535 Ω	0.000
	05-20	Magnetizing inductance (Lm) for induction motor 2	0.0–6553.5 mH	0.0
	05-21	Stator inductance (Lx) for induction motor 2	0.0–6553.5 mH	0.0
	05-22	Induction motor 1 / 2 selection	1: Motor 1 2: Motor 2	1
*	05-23	Frequency for Y-connection / Δ-connection switch for an induction motor	0.00–599.00 Hz	60.00
	05-24	Y-connection / Δ-connection switch for an induction motor	0: Disable 1: Enable	0
*	05-25	Delay time for Y-connection / Δ-connection switch for an induction motor	0.000-60.000 sec.	0.200
	05-28	Accumulated Watt-hour for a motor (W-hour)	0.0-6553.5	Read only
	05-29	Accumulated Watt-hour for a motor in low word (kW-hour)	0.0-6553.5	Read only
	05-30	Accumulated Watt-hour for a motor in high word (MW-hour)	0–65535	Read only
	05-31	Accumulated motor operation time (minutes)	0–1439	0
	05-32	Accumulated motor operation time (days)	0–65535	0
	05-33	Induction motor (IM) or permanent magnet synchronous AC motor (PM) selection	0: IM 1: SPM 2: IPM 3: SynRM (applied to 230V / 460V models)	0
	05-34	Full-load current for a permanent magnet synchronous AC motor / reluctance motor	Depending on the model power	Depending on the model power
*	05-35	Rated power for a permanent magnet synchronous AC motor / reluctance motor	0.00–655.35 kW	Depending on the motor power
*	05-36	Rated speed for a permanent magnet synchronous AC motor / reluctance motor	0–65535 rpm	2000
	05-37	Number of poles for a permanent magnet synchronous AC motor / reluctance motor	0–65535	10
	05-38	System inertia for a permanent magnet synchronous AC motor / reluctance motor	0.0–6553.5 kg-cm <sup>2</sup>	Depending on the motor power
	05-39	Stator resistance for a permanent magnet synchronous AC motor / reluctance motor	$0.000-65.535~\Omega$	0.000

Pr.	Parameter Name	Setting Range	Default
05-40	Permanent magnet synchronous	0.00–655.35 mH	0.00
03-40	AC motor / reluctance motor Ld	0.00-033.33 1111	0.00
05.44	Permanent magnet synchronous	0.00-655.35 mH	0.00
05-41	AC motor / reluctance motor Lq		
05.40	Ke parameter for a permanent	0.05505 (1. 11. ) (1. 11. )	0
05-43	magnet synchronous AC motor	0–65535 (Unit: V / krpm)	0

# **06 Protection Parameters**

	Pr.	Parameter Name	Setting Range	Default
			230V models:	
		Low voltage level	Frame A–D: 150.0–220.0 V <sub>DC</sub>	180.0
			Frame E and above : 190.0–220.0 V <sub>DC</sub>	200.0
.,	06-00		460V models:	
^	00-00	Low voltage level	Frame A-D: 300.0-440.0 V <sub>DC</sub>	360.0
			Frame E and above : 380.0–440.0 V <sub>DC</sub>	400.0
			575V models: 420.0–520.0 V <sub>DC</sub>	470.0
			690V models: 450.0–660.0 V <sub>DC</sub>	480.0
			0: Disabled	
			230V models: 0.0–450.0 V <sub>DC</sub>	380.0
×	06-01	Over-voltage stall prevention	460V models: 0.0–900.0 V <sub>DC</sub>	760.0
			575V models: 0.0–1116.0 V <sub>DC</sub>	920.0
			690V models: 0.0–1318.0 V <sub>DC</sub>	1087.0
			0: Traditional over-voltage and traditional over-current	
			stall prevention	
			Smart over-voltage and traditional over-current stall prevention	
×	06-02	Selection for stall prevention	Traditional over-voltage and smart over-current stall	0
			prevention	
			3: Smart over-voltage and smart over-current stall	
			prevention	
	06-03		230V / 460V models	
			Light duty: 0–130% (100% corresponds to the rated	120
			current of the drive )	
			Normal duty: 0–160% (100% corresponds to the rated	120
		Over-current stall prevention	current of the drive)	
^	00-03	during acceleration	575V / 690V models	
			Light duty: 0–125% (100% corresponds to the rated	120
			current of the drive)	
			Normal duty: 0–150% (100% corresponds to the rated	120
			current of the drive)	
			230V / 460V models	400
			Light duty: 0–130% (100% corresponds to the rated	120
			current of the drive ) Normal duty: 0–160% (100% corresponds to the rated	120
		Over-current stall prevention	current of the drive)	120
×	06-04	during operation	575V / 690V models	
		daming operation	Light duty: 0–125% (100% corresponds to the rated	120
			current of the drive)	-20
			Normal duty: 0–150% (100% corresponds to the rated	120
			current of the drive)	
			0: By current acceleration / deceleration time	
		Acceleration / deceleration time	1: By the first acceleration / deceleration time	
×	06-05	selection for stall prevention at	2: By the second acceleration / deceleration time	0
		constant speed	3: By the third acceleration / deceleration time	
			4: By the fourth acceleration / deceleration time	

	Pr.	Parameter Name	Setting Range	Default
			5: By auto-acceleration / auto-deceleration	
			0: No function	
			1: Continue operation after over-torque detection	
			during constant speed operation	
,	00.00	Over-torque detection selection	2: Stop after over-torque detection during constant	0
~	06-06	(OT1)	speed operation	0
			3: Continue operation after over-torque detection	
			during RUN	
			4: Stop after over-torque detection during RUN	
~	06-07	Over-torque detection level (OT1)	10–200% (100% corresponds to the drive's light-duty	120
^	00-07	Over-torque detection level (OTT)	rated current)	120
×	06-08	Over-torque detection time (OT1)	0.0-60.0 sec.	0.1
			0: No function	
			1: Continue operation after over-torque detection	
			during constant speed operation	
~	06-09	Over-torque detection selection	2: Stop after over-torque detection during constant	0
,		(OT2)	speed operation	
			3: Continue operation after over-torque detection	
			during RUN	
			4: Stop after over-torque detection during RUN	
×	06-10	Over-torque detection level (OT2)	10–200% (100% corresponds to the light-load rated	120
,	00.44	O	current of the drive)	0.4
<b>X</b>	06-11	Over-torque detection time (OT2)	0.0–60.0 sec.	0.1
*	06-12	Current limit	0–200%	150
	06-13	Electronic thermal relay selection	O: Inverter motor (with external forced cooling)     Standard motor (motor with fan on the shaft)	2
^	00-13	1 (Motor 1)	2: Disable	2
		Electronic thermal relay action	Z. Disable	
×	06-14	time 1 (Motor 1)	30.0–600.0 sec.	60.0
		Temperature level overheat (OH)		
×	06-15	warning	0.0–110.0°C	105.0
		Stall prevention limit level		
N	06-16	(Weak magnetic field current stall	0–100% (Pr.06-03)	50
		prevention level)	,	
	06-17	Fault record 1	0: No fault record	0
	06-18	Fault record 2	1: Over-current during acceleration (ocA)	0
	06-19	Fault record 3	2: Over-current during deceleration (ocd)	0
	06-20	Fault record 4	3: Over-current during steady speed (ocn)	0
	06-21	Fault record 5	4: Ground fault (GFF)	0
	06-22	Fault record 6	5: IGBT short-circuit between upper bridge and lower	0
			bridge (occ)	
			6: Over-current at stop (ocS)	
			7: Over-voltage during acceleration (ovA)	
			8: Over-voltage during deceleration (ovd)	
			9: Over-voltage at constant speed (ovn)	
			10: Over-voltage at stop (ovS)	
			11: Low-voltage during acceleration (LvA)	
			12: Low-voltage during deceleration (Lvd)	

Pr.	Parameter Name	Setting Range	Default
		13: Low-voltage at constant speed (Lvn)	
		14: Low-voltage at stop (LvS)	
		15: Phase loss protection (OrP)	
		16: IGBT overheating (oH1)	
		17: Heatsink overheating (oH2)	
		18: IGBT temperature detection failure (tH1o)	
		19: Capacitor hardware error (tH2o)	
		21: Over load (oL)	
		22: Electronic thermal relay 1 protection (EoL1)	
		23: Electronic thermal relay 2 protection (EoL2)	
		24: Motor overheating (oH3) (PTC / PT100)	
		26: Over torque 1 (ot1)	
		27: Over torque 2 (ot2)	
		28: Under current (uC)	
		30: EEPROM write error (cF1)	
		31: EEPROM read error (cF2)	
		33: U-phase error (cd1)	
		34: V-phase error (cd2)	
		35: W-phase error (cd3)	
		36: cc (current clamp) hardware error (Hd0)	
		37: oc (over-current) hardware error (Hd1)	
		38: ov (over-voltage) hardware error (Hd2)	
		39: occ hardware error (Hd3)	
		40: Auto-tuning error (AUE)	
		41: PID loss ACI (AFE)	
		48: ACI loss (ACE)	
		49: External fault (EF)	
		50: Emergency stop (EF1)	
		51: External base block (bb)	
		52: Enter wrong password three times and locked	
		(Pcod)	
		53: Firmware version error (ccod)	
		54: Illegal command (CE1)	
		55: Illegal data address (CE2)	
		56: Illegal data value (CE3)	
		57: Data is written to read-only address (CE4)	
		58: Modbus transmission time-out (CE10)	
		60: Brake transistor error (bF)	
		61: Y-connection / Δ-connection switch error (ydc)	
		62: Deceleration energy backup error (dEb)	
		63: Over slip error (oSL)	
		64: Electric valve switch error (ryF)	
		68: Reverse direction of the speed feedback (SdRv)	
		69: Over speed rotation feedback (SdOr)	
		70: Large deviation of speed feedback (SdDe)	
		71: Watchdog (WDTT)	
		72: STO loss 1 (STL1)	
		73: Emergency stop for external safety (S1)	
		74: FIRE mode output (Fire)	

11-26

	Pr.	Parameter Name	Setting Range	Default
			76: Safe torque off (STO)	
			77: STO loss 2 (STL2)	
			78: STO loss 3 (STL3)	
			82: Output phase loss U phase (OPHL)	
			83: Output phase loss V phase (OPHL)	
			84: Output phase loss W phase (OPHL)	
			89: Rotor position detection error (RoPd)	
			90: Forced to stop (FStp)	
			101: CANopen guarding error (CGdE)	
			102: CANopen heartbeat error (ChbE)	
			104: CANopen bus off error (CbFE)	
			105: CANopen index error (CidE)	
			106: CANopen station address error (CadE)	
			107: CANopen memory error (CfrE)	
			111: InrCOM time-out error (ictE)	
			142: Auto-tuning error 1 (no feedback current error)	
			(AUE1)	
			143: Auto-tuning error 2 (motor phase loss error)	
			(AUE2)	
			144: Auto-tuning error 3 (no-load current l₀ measuring	
			error) (AUE3)	
			148: Auto-tuning error 4 (leakage inductance Lsigma	
			measuring error) (AUE4)	
×	06-23	Fault output option 1		
N	06-24	Fault output option 2	0.05505 (2.50.4. 13.4.11. 5.2.5.11	0
N	06-25	Fault output option 3	0–65535 (refer to bit table for fault code)	0
×	06-26	Fault output option 4		
		Electronic thermal relay selection	0: Inverter motor (with external forced cooling)	
×	06-27	-	1: Standard motor (motor with fan on the shaft)	2
		2 (motor 2)	2: Disable	
,	00.00	Electronic thermal relay action	20.0.000.0	60.0
×	06-28	time 2 (motor 2)	30.0–600.0 sec.	60.0
			0: Warn and continue operation	
.,	06-29	PTC detection selection / PT100	1: Fault and ramp to stop	0
×	00-29	motion	2: Fault and coast to stop	U
			3: No warning	
N	06-30	PTC level	0.0–100.0%	50.0
	00.04	Frequency command at	0.00 500 00 11-	Read
	06-31	malfunction	0.00–599.00 Hz	only
	00.00	0 + 15	0.00 500 00 11	Read
	06-32	Output frequency at malfunction	0.00–599.00 Hz	only
				Read
	06-33	Output voltage at malfunction	0.0–6553.5 V	only
				Read
	06-34	DC bus voltage at malfunction	0.0–6553.5 V	only
				Read
	06-35	Output current at malfunction	0.0–6553.5 Amp	only
				5.119

Chapter 11 Summary of Parameter Settings | CP2000

	Pr.	Parameter Name	Setting Range	Default
	06-36	IGBT temperature at malfunction	-3276.7–3276.7°C	Read
			527 6.17 627 6.17 C	only
	06-37	Capacitance temperature at	-3276.7–3276.7°C	Read
		malfunction		only
	06-38	Motor speed at malfunction	-32767–32767 rpm	Read
,		Status of the multi-function input		only Read
	06-40	terminal at malfunction	0000h-FFFFh	only
		Status of the multi-function output		Read
	06-41	terminal at malfunction	0000h-FFFFh	only
				Read
	06-42	Drive status at malfunction	0000h-FFFFh	only
			0: STO latch	
×	06-44	STO latch selection	1: STO no latch	0
			0: Warn and continue operation	
		Output phase loss detection	1: Fault and ramp to stop	
×	06-45	action (OPHL)	2: Fault and coast to stop	3
		,	3: No warning	
		Detection time for output phase		
×	06-46	loss	0.000–65.535 sec.	0.500
	00.47	Current detection level for output	0.00 400 0004	4.00
×	06-47	phase loss	0.00-100.00%	1.00
	00.40	DC brake time for output phase	0.000 05 505	0.000
~	06-48	loss	0.000–65.535 sec.	0.000
	00.40	L. W. coda accept	0: Disable	0
~	06-49	LvX auto-reset	1: Enable	0
	00.50	Time for input phase loss	0.00,000,00,	0.00
^	06-50	detection	0.00-600.00 sec.	0.20
			230V models: 0.0–100.0 V <sub>DC</sub>	30.0
.,	06-52	50 Dinale of innut about less	460V models: 0.0–200.0 V <sub>DC</sub>	60.0
	00-32	Ripple of input phase loss	575V models: 0.0–400.0 V <sub>DC</sub>	75.0
			690V models: 0.0–480.0 V <sub>DC</sub>	90.0
,	06-53	Input phase loss detection action	0: Fault and ramp to stop	0
′	00 00	(OrP)	1: Fault and coast to stop	
			0: Auto-decrease carrier frequency and limit output	
N	06-55	Derating protection	current	0
,			Constant carrier frequency and limit output current	
			2: Auto-decrease carrier frequency	
×	06-56	PT100 voltage level 1	0.000–10.000 V	5.000
×	06-57	PT100 voltage level 2	0.000–10.000 V	7.000
*	06-58	PT100 level 1 frequency protection	0.00–599.00 Hz	0.00
*	06-59	PT100 activation level 1 protection frequency delay time	0–6000 sec.	60
~	06-60	Software detection GFF current	0.0–6553.5% (100% corresponds to the light-duty	60.0
	06.64	level	rated current of the drive)	0.40
×	06-61	Software detection GFF filter time	0.00-655.35 sec.	0.10

	Pr.	Parameter Name	Setting Range	Default
	00.00	Operation time of fault record 1	0.05505	Read
	06-63	(Days)	0–65535 days	only
	00.04	Operation time of fault record 1	0.4400	Read
	06-64	(Minutes)	0–1439 min.	only
		Operation time of fault record 2		Read
	06-65	(Days)	0–65535 days	only
		Operation time of fault record 2		Read
	06-66	(Minutes)	0–1439 min.	only
		Operation time of fault record 3		Read
	06-67	(Days)	0–65535 days	only
		Operation time of fault record 3		Read
	06-68	(Minutes)	0–1439 min.	only
		Operation time of fault record 4		Read
	06-69	(Days)	0–65535 days	only
		Operation time of fault record 4		Read
	06-70	(Minutes)	0–1439 min.	only
			0.0–100.0% (100% corresponds to the light-duty rated	_
×	06-71	Low current setting level	current of the drive)	0.0
<b>~</b>	06-72	Low current detection time	0.00–360.00 sec.	0.00
^	00-12	Low current detection time	0: No function	0.00
			1: Fault and coast to stop	
./	06-73	Low current action	2: Fault and ramp to stop by the second deceleration	0
~	00-73	Low current action	time	0
			3: Warn and continue operation	
			230V models: 0.0–200.0 V <sub>DC</sub>	20.0
			460V models: 0.0–200.0 V <sub>DC</sub>	40.0
N	06-76	dEb motion offset	575V models: 0.0–200.0 V <sub>DC</sub>	50.0
			690V models: 0.0–200.0 V <sub>DC</sub>	60.0
			0: Disable	00.0
	06-80	Fire mode		0
	06-60	File filode	1: Forward (counterclockwise) operation	0
			2: Reverse (clockwise) operation	
N	06-81	Operating frequency when	0.00-599.00 Hz	60.00
		running fire mode	Or Disable hypers	
×	06-82	Enable bypass on fire mode	0: Disable bypass	0
	00.00	Dimensional delications are for an extension	1: Enable bypass	0.0
×	06-83	Bypass delay time on fire mode	0.0–6550.0 sec.	0.0
×	06-84	Number of times of reset in fire mode	0–10	0
×	06-85	Length of time of reset in fire mode	0.0-6000.0 sec.	60.0
			bit0: 0 = Open Loop; 1 = Close Loop (PID control)	
			bit1: 0 = Manual reset fire mode; 1 = Auto reset fire	
			mode	
	06-86	Fire mode motion	0: Open loop control and manual reset fire mode	0
			1: Close loop control and manual reset fire mode	
			2: Open loop control and auto reset fire mode	
			3: Close loop control and auto reset fire mode	
N	06-87	Fire mode PID set point	0.00–100.00%	0.00
/.	55 51	5 out point	100.0070	5.55

# **07 Special Parameters**

	Pr.	Parameter Name	Setting Range	Default
			230V models: 350.0–450.0 V <sub>DC</sub>	370.0
×	07-00	Software brake chopper action level	460V models: 700.0–900.0 V <sub>DC</sub> 575V models: 850.0–1116.0 V <sub>DC</sub>	740.0 895.0
		levei	690V models: 939.0–1318.0 V <sub>DC</sub>	1057.0
×	07-01	DC brake current level	0–100%	0
×	07-02	DC brake time at start-up	0.0-60.0 sec.	0.0
×	07-03	DC brake time at STOP	0.0-60.0 sec.	0.0
×	07-04	DC brake frequency at STOP	0.00-599.00 Hz	0.00
×	07-05	Voltage increasing gain	1–200%	100
*	07-06	Restart after momentary power loss	0: Stop operation 1: Speed tracking by the speed before the power loss 2: Speed tracking by the minimum output frequency	0
×	07-07	Allowed power loss duration	0.0–20.0 sec.	2.0
*	07-08	Base block time	0.0–5.0 sec. (Depending on the model power)	Depending on the model power
×	07-09	Current limit of speed tracking	20–200% (100% corresponds to the light-duty rated current of the drive)	100
*	07-10	Restart after fault action	0: Stop operation 1: Speed tracking by current speed 2: Speed tracking by minimum output frequency	0
*	07-11	Number of times of restart after fault	0–10	0
*	07-12	Speed tracking during start-up	O: Disable  1: Speed tracking by the maximum output frequency  2: Speed tracking by the motor frequency at start-up  3: Speed tracking by the minimum output frequency	0
*	07-13	dEb function selection	O: Disable  1: dEb with auto-acceleration / auto-deceleration, the drive does not output the frequency after the power is restored.  2: dEb with auto-acceleration / auto-deceleration, the drive outputs the frequency after the power is restored.	0
×	07-15	Dwell time at acceleration	0.00-600.00 sec.	0.00
×	07-16	Dwell frequency at acceleration	0.00-599.00 Hz	0.00
×	07-17	Dwell time at deceleration	0.00-600.00 sec.	0.00
×	07-18	Dwell frequency at deceleration	0.00–599.00 Hz	0.00
*	07-19	Fan cooling control	0: Fan always ON 1: Fan is OFF after the AC motor drive stops for one minute 2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops	0

	Pr.	Parameter Name	Setting Range	Default
			3: Fan turns ON when temperature (IGBT) reaches	
			around 60°C.	
			4: Fan always OFF	
			0: Coast to stop	
			1: Stop by the first deceleration time	
	07-20	Emergency stop (EF) & force to	2: Stop by the second deceleration time	
×		stop selection	3: Stop by the third deceleration time	0
		- COOP	4: Stop by the fourth deceleration time	
			5: System deceleration	
			6: Automatic deceleration	
	/	Automatic energy-saving	0: Disable	
*	07-21	selection	1: Power factor energy-saving improvement	0
			2: Automatic energy-saving optimization	
*	07-22	Energy-saving gain	10–1000%	100
	o= oo	Automatic voltage regulation	0: Enable AVR	
~	07-23	(AVR) function	1: Disable AVR	0
		T	2: Disable AVR during deceleration	
*	07-24	Torque command filter time (V/F and SVC control mode)	0.001-10.000 sec.	0.500
~	07-25	Slip compensation filter time	0.001–10.000 sec.	0.100
		(V/F and SVC control mode)		
×	07-26	Torque compensation gain	IM: 0–10 (when Pr.05-33 = 0)	0
			PM: 0–5000 (when Pr.05-33 = 1 or 2)	0.00
				0.00 (Default
*	07-27	Slip compensation gain	0.00–10.00	value is
				1.00 in SVC mode)
×	07.20	Slip deviation level	0.0–100.0%	0.0
	07-29	Slip deviation level	0 : No detection	0.0
*	07-30	Over-slip deviation detection time	0.0–10.0 sec.	1.0
			0: Warn and continue operation	
,	07-31	Over-slip deviation treatment	1: Fault and ramp to stop	0
<i>,</i> ·	01-01	Over-siip deviation treatment	2: Fault and coast to stop	
			3: No warning	
*	07-32	Motor oscillation compensation	0–10000	1000
		factor	0: Disable	
*	07-33	Auto-restart interval of fault	0.0-6000.0 sec.	60.0
*	07-38	PMSVC voltage feed forward gain	0.00-2.00	1.00
*	07-41	Minimum frequency for AES	0.00–40.00 Hz	10.00
	07-42	Delay time for AES	0–600 sec.	5
*	07-43	Targeted power factor angle for AES	0.00–65.00°	40.00
×	07-44	Maximum voltage drop for AES	0.00–70.00%	60.00
×	07-45	AES coefficient	0–10000%	100
×	07-50	PWM fan speed	60–100%	60

# **08 High-function PID Parameters**

	Pr.	Parameter Name	Setting Range	Default
*	08-00	Terminal selection of PID feedback	O: No function  1: Negative PID feedback: by analog input (Pr.03-00–03-02)  4: Positive PID feedback: by analog input (Pr.03-00–03-02)	0
*	08-01	Proportional gain (P)	0.0–100.0	1.0
*	08-02	Integral time (I)	0.00–100.00 sec. 0.00: No integral	1.00
*	08-03	Differential time (D)	0.00-1.00 sec.	0.00
*	08-04	Upper limit of integral control	0.0–100.0%	100.0
*	08-05	PID output command limit	0.0–110.0%	100.0
*	08-06	PID feedback value display	-200.00–200.00%	Read only
×	08-07	Delay time	0.0–35.0 sec.	0.0
*	80-80	Feedback signal detection time	0.0-3600.0 sec.	0.0
*	08-09	Feedback signal fault treatment	0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: Warn and operate at last frequency	0
*	08-10	Sleep level	0.00–599.00 Hz or 0–200.00%	0.00
*	08-11	Wake-up level	0.00-599.00 Hz or 0-200.00%	0.00
*	08-12	Sleep delay time	0.0-6000.0 sec.	0.0
*	08-13	PID feedback signal error deviation level	1.0-50.0%	10.0
*	08-14	PID feedback signal error deviation detection time	0.1–300.0 sec.	5.0
*	08-16	PID compensation selection	0: Parameter setting (Pr.08-17) 1: Analog input	0
*	08-17	PID compensation	-100.0–100.0%	0.0
	08-18	Sleep mode function setting	Refer to PID output command     Refer to PID feedback signal	0
×	08-19	Wake-up integral limit	0.0–200.0%	50.0
	08-20	PID mode selection	Serial connection     Parallel connection	0
	08-21	Enable PID to change the operation direction	O: Operation direction cannot be changed     Coperation direction can be changed	0
×	08-22	Wake-up delay time	0.00-600.00 sec.	0.00

# **09 Communication Parameters**

	Pr.	Parameter Name	Setting Range	Default
N	09-00	Communication address	1–254	1
~	09-01	COM1 transmission speed	4.8–115.2 Kbps	9.6
,		1	0: Warn and continue operation	
			1: Fault and ramp to stop	
×	09-02	COM1 transmission fault treatment	2: Fault and coast to stop	3
			3: No warning, no fault and continue operation	
×	09-03	COM1 time-out detection	0.0–100.0 sec.	0.0
			1: 7, N, 2 (ASCII)	
			2: 7, E, 1 (ASCII)	
			3: 7, O, 1 (ASCII)	
			4: 7, E, 2 (ASCII)	
			5: 7, O, 2 (ASCII)	
			6: 8, N, 1 (ASCII)	
			7: 8, N, 2 (ASCII)	
			8: 8, E, 1 (ASCII)	
×	09-04	COM1 communication protocol	9: 8, O, 1 (ASCII)	1
			10: 8, E, 2 (ASCII)	
			11: 8, O, 2 (ASCII)	
			12: 8, N, 1 (RTU)	
			13: 8, N, 2 (RTU)	
			14: 8, E, 1 (RTU)	
			15: 8, O, 1 (RTU)	
			16: 8, E, 2 (RTU)	
			17: 8, O, 2 (RTU)	
×	09-09	Communication response delay time	0.0–200.0 ms	2.0
	09-10	Communication main frequency	0.00–599.00 Hz	60.00
×	09-11	Block transfer 1	0000–FFFFh	0000h
×	09-12	Block transfer 2	0000–FFFFh	0000h
×	09-13	Block transfer 3	0000-FFFFh	0000h
×	09-14	Block transfer 4	0000–FFFFh	0000h
×	09-15	Block transfer 5	0000–FFFFh	0000h
*	09-16	Block transfer 6	0000_FFFFh	0000h
*	09-17	Block transfer 7	0000–FFFFh	0000h
×	09-18	Block transfer 8	0000–FFFFh	0000h
×	09-19	Block transfer 9	0000_FFFFh	0000h
×	09-20	Block transfer 10	0000_FFFFh	0000h
×	09-21	Block transfer 11	0000–FFFFh	0000h
×	09-22	Block transfer 12	0000–FFFFh	0000h
×	09-23	Block transfer 13	0000–FFFFh	0000h
×	09-24	Block transfer 14	0000–FFFFh	0000h
×	09-25	Block transfer 15	0000–FFFFh	0000h
×	09-26	Block transfer 16	0000–FFFFh	0000h
	09-30	Communication decoding method	0: Decoding method 1 (20xx)	1
			1: Decoding method 2 (60xx)	

	Pr.	Parameter Name	Setting Range	Default
			1: BACnet	
			0: Modbus 485	
			-1: Internal communication slave 1	
			-2: Internal communication slave 2	
	22.24		-3: Internal communication slave 3	
		latamata and a second and a second and a	-4: Internal communication slave 4	0
	09-31	Internal communication protocol	-5: Internal communication slave 5	0
			-6: Internal communication slave 6	
			-7: Internal communication slave 7	
			-8: Internal communication slave 8	
			-10: Internal communication master	
			-12: Internal PLC control	
			bit0: Before PLC scans, set up PLC target	_
✓	09-33	PLC command force to 0	frequency = 0	0
	09-35	PLC address	1–254	2
			0: Disable	_
	09-36	CANopen slave address	1–127	0
			0: 1 Mbps	
			1: 500 Kbps	
		CANopen speed	2: 250 Kbps	
	09-37		3: 125 Kbps	0
			4: 100 Kbps (Delta only)	
			5: 50 Kbps	
			bit0: CANopen guarding time out	
			bit1: CANopen heartbeat time out	
			bit2: CANopen SYNC time out	
			bit3: CANopen SDO time out	
			bit4: CANopen SDO buffer overflow	
			bit5: Can Bus off	
	09-39	CANopen warning record	bit6: Error protocol of CANopen	Read only
		3	bit8: The setting values of CANopen indexes	· · · · · · · · · · · · · · · · · · ·
			are fail	
			bit9: The setting value of CANopen address	
			is fail	
			bit10: The checksum value of CANopen	
			indexes is fail	
			0: Disable (Delta-defined decoding method)	
	09-40	CANopen decoding method	1: Enable (CANopen standard DS402	1
		·	protocol)	
			0: Node reset state	
			1: Com reset state	
			2: Boot up state	
	09-41	CANopen communication status	3: Pre-operation state	Read only
			4: Operation state	
			5: Stop state	
			0: Not ready for use state	
	00.75		1: Inhibit start state	
	09-42	CANopen control status	2: Ready to switch on state	Read only
			3: Switched on state	
			1	i

Pr.	Parameter Name	Setting Range	Default
		4: Enable operation state	
		7: Quick stop active state	
		13: Error reaction activation state	
		14: Error state	
00.45		0: Disable	_
09-45	CANopen master function	1: Enable	0
09-46	CANopen master address	0–127	100
		0: Update Index 604F and 6050 to	
		Acceleration / Deceleration time 1	
		bit0 = 0: Enabled (default)	
		bit0 = 1: Disabled	
00.40		1: Distinguish the CANopen identity code by	00001
09-49	CANopen extension setting	models or by series	0002h
		bit1 = 0: Distinguish the CANopen identify	
		code by models	
		bit1 = 1: Distinguish the CANopen identify	
		code by series	
09-50	BACnet MS / TP node address	0–127	10
09-51	BACnet baud rate	9.6–76.8 Kbps	38.4
09-52	BACnet Device index L	0-65535	10
09-53	BACnet Device index H	0–63	0
09-55	BACnet Max Address	0–127	127
09-56	BACnet password	0–65535	0
		0: No communication card	
	Communication card identifications	1: DeviceNet slave	
		2: Profibus-DP slave	
		3: CANopen slave / master	
09-60		4: Modbus –TCP Slave	Read only
		5: EtherNet/IP Slave	
		6: EtherCAT	
		8: BACnet IP	
		12: PROFINET	
09-61	Firmware version of communication card	Read only	Read only
09-62	Product code	Read only	Read only
09-63	Fault code	Read only	Read only
09-70	Communication card address	DeviceNet: 0–63	1
09-70	(for DeviceNet or PROFIBUS)	Profibus-DP: 1–125	'
		Standard DeviceNet:	
		0: 100 Kbps	
		1: 125 Kbps	
		2: 250 Kbps	
	Communication card speed setting	3: 1 Mbps (Delta only)	
09-71	(for DeviceNet)	Non-standard DeviceNet: (Delta only)	2
		0: 10 Kbps	
		1: 20 Kbps	
		2: 50 Kbps	
		3: 100 Kbps	
		4: 125 Kbps	

Chapter 11 Summary of Parameter Settings | CP2000

	Pr.	Parameter Name	Setting Range	Default
			5: 250 Kbps	
			6: 500 Kbps	
			7: 800 Kbps	
			8: 1 Mbps	
			0: Standard DeviceNet	
<i>N</i>			In this mode, the baud rate can only be 100	
		Additional settings for communication	Kbps, 125 Kbps or 250 Kbps in standard	
×	09-72	card speed (for DeviceNet)	DeviceNet speed	0
		,	1: Non-standard DeviceNet	
			In this mode, DeviceNet baud rate can be	
			the same as that for CANopen (0–8).	
×	09-75	Communication card IP configuration	0: Static IP	0
		(for Modbus TCP)	1: Dynamic IP (DHCP)	
*	09-76	Communication card IP address 1 (for Modbus TCP)	0–65535	0
*	09-77	Communication card IP address 2 (for Modbus TCP)	0–65535	0
~	09-78	Communication card IP address 3 (for Modbus TCP)	0–65535	0
		Communication card IP address 4		
×	09-79	(for Modbus TCP)	0–65535	0
		Communication card address mask 1		
×	09-80	(for Modbus TCP)	0–65535	0
		Communication card address mask 2		
×	09-81	(for Modbus TCP)	0–65535	0
	09-82	Communication card address mask 3	0.65525	0
×	09-82	(for Modbus TCP)	0–65535	0
	09-83	Communication card address mask 4	0–65535	0
~	09-03	(for Modbus TCP)	0-0000	U
~	09-84	Communication card gateway address 1	0–65535	0
~	00-04	(for Modbus TCP)	0 00000	0
~	09-85	Communication card gateway address 2	0–65535	0
,		(for Modbus TCP)	0 00000	ŭ
~	09-86	Communication card gateway address 3	0–65535	0
, ·		(for Modbus TCP)		<u> </u>
×	09-87	Communication card gateway address 4	0–65535	0
,		(for Modbus TCP)		-
×	09-88	Communication card password	0–99	0
		(Low word) (for Modbus TCP)		
×	09-89	Communication card password	0–99	0
		(High word) (for Modbus TCP)	O. Disable	
×	09-90	Reset communication card	0: Disable	0
		(for Modbus TCP)	1: Reset to defaults	
			bit0: Enable IP filter	
	09-91	Additional settings for the communication	bit1: Enable internet parameters (1 bit).  When the IP address is set, this bit is	0
*	U3-31	card (for Modbus TCP)	•	U
			enabled. After updating the parameters	
			for the communication card, this bit	

Pr.	Parameter Name	Setting Range	Default
		changes to disabled.	
		bit2: Enable login password (1 bit).	
		When you enter the login password, this	
		bit is enabled. After updating the	
		parameters for the communication card,	
		this bit changes to disabled.	
		bit0: Enable password	
	Communication card status	When the communication card is set	
09-92	(for Modbus TCP)	with password; this bit is enabled.	0
		When the password is cleared; this bit is	
		disabled.	

# **10 Sensorless Motor Control Parameters**

	Pr.	Parameter Name	Setting Range	Default
*	10-08	Treatment for speed observer feedback fault	Warn and continue operation     Fault and ramp to stop     Fault and coast to stop	2
*	10-09	Detection time of speed observer feedback fault	0.0–10.0 sec. 0: Disable	1.0
*	10-10	Speed observer stall level	0–120% 0: No function	115
*	10-11	Detection time of speed observer stall	0.0–2.0 sec.	0.1
*	10-12	Speed observer stall action	O: Warn and continue operation  1: Fault and ramp to stop  2: Fault and coast to stop	2
×	10-13	Speed observer slip range	0–50% 0: No function	50
×	10-14	Detection time of speed observer slip	0.0-10.0 sec.	0.5
×	10-15	Speed observer stall and slip error action	Warn and continue operation     Fault and ramp to stop     Fault and coast to stop	2
×	10-31	I/F mode, current command	0–150% of motor rated current	40
×	10-32	PM FOC sensorless speed estimator bandwidth	0.00–600.00 Hz	5.00
*	10-33	PM FOC sensorless speed estimator bandwidth (low speed) (applied to 230V / 460V models)	0.00–600.00 Hz	1.00
×	10-34	PM sensorless speed estimator low-pass filter gain	0.00-655.35	1.00
×	10-35	AMR (Kp) gain (applied to 230V / 460V models)	0.00-3.00	1.00
×	10-36	AMR (Ki) gain (applied to 230V / 460V models)	0.00-3.00	1.00
×	10-39	Frequency to switch from I/F mode to PM sensorless mode	0.00–599.00 Hz	20.00
×	10-40	Frequency to switch from PM sensorless mode to I/F mode	0.00–599.00 Hz	20.00
×	10-41	I/F mode, Id current low-pass filter time	0.0-6.0 sec.	0.2
×	10-42	Initial angle detection pulse value	0.0–3.0	1.0
×	10-49	Zero voltage time during start-up	0.000-60.000 sec.	0.000
×	10-51	Injection frequency	0–1200 Hz	500
*	10-52	Injection magnitude	0.0–200.0 V 230V models: 0.0–100.0 V 460V models: 0.0–200.0 V 575V models: 0.0–200.0 V	15.0 30.0 30.0

	Pr.	Parameter Name	Setting Range	Default
			690V models: 0.0–200.0 V	30.0
			0: Disable	
		DM initial rater position	1: Using I/F current command (Pr.10-31) to attract the	
×	10-53	PM initial rotor position detection method	rotor to zero degrees	0
		detection method	2: High frequency injection	
			3: Pulse injection	
		Magnetic flux linkage estimate		
×	10-54	low-speed gain (applied to 230V	10–1000%	100
		/ 460V models)		
		Magnetic flux linkage estimate		
×	10-55	high-speed gain (applied to	10–1000%	100
		230V / 460V models)		
×	10-56	Kp of phase-locked loop	10–1000%	100
	10-30	(applied to 230V / 460V models)	10—1000 /0	100
×	10-57	Ki of phase-locked loop	10–1000%	100
	10-37	(applied to 230V / 460V models)	10-100070	100
		Mutual inductance gain		
×	10-58	compensation	0.00–655.35	1.00
		(applied to 230V / 460V models)		

# 11 Advanced Parameters (Applied to 230V / 460V models)

	Pr.	Parameter Name	Setting Range	Default
Î			bit0: Auto-tuning for ASR and APR	
	11-00	System control	bit6: 0 Hz linear-cross	0000h
			bit7: Saving or not saving the frequency	
	11-01	Per-unit of system inertia	1–65535 (256 = 1PU)	256
*	11-02	ASR1 / ASR2 switch frequency	0.00–599.00 Hz	7.00
*	11-03	ASR1 low-speed bandwidth	1-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-04	ASR2 high-speed bandwidth	1-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-05	Zero-speed bandwidth	1-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-06	ASR 1 gain	0-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-07	ASR 1 integral time	0.000-10.000 sec.	0.100
×	11-08	ASR 2 gain	0-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
×	11-09	ASR 2 integral time	0.000-10.000 sec.	0.100
*	11-10	ASR gain of zero speed	0-40 Hz (IM) / 1-100 Hz (PM) / 1-30 Hz (SynRM)	10
, [	11-11	ASR1 integral time of zero	0.000-10.000 sec.	0.100
*	11-11	speed	0.000-10.000 sec.	0.100
~	11-12	Gain for ASR speed feed	0–200%	0
	11-12	forward	0-20070	U
*	11-13	PDFF gain value	0–200%	30
*	11-14	ASR output low pass filter time	0.000-0.350 sec.	0.008
*	11-15	Notch filter depth	0–20 dB	0
*	11-16	Notch filter frequency	0.0–6000.0 Hz	0.0
*	11-17	Forward motor torque limit  Quadrant I	0–500%	500
*	11-18	Forward regenerative torque limit Quadrant II	0–500%	500
<i>N</i>	11-19	Reverse motor torque limit	0–500%	500
-		Quadrant III		
*	11-20	Reverse regenerative torque limit Quadrant IV	0–500%	500
*	11-21	Flux weakening curve for motor	0–200%	90
		1 gain value		
*	11-22	Flux weakening curve for motor 2 gain value	0–200%	90
*	11-23	Flux weakening area speed response	0–150%	65

## **12 PUMP Parameters**

	Pr.	Parameter Name	Setting Range	Default
			0: No operation	
			1: Fixed time circulation (by time)	
	40.00	Circulation Control	2: Fixed quantity circulation	0
	12-00	Circulation Control	3: Fixed quantity control	
			4: Fixed time circulation + fixed quantity circulation	
			5: Fixed time circulation + fixed quantity control	
	12-01	Number of Motors to be connected	1–8	1
	12-02	Operating time for each motor (minutes)	0–65500 min.	0
		Delay time due to the		
	12-03	acceleration (or the increment )	0.0-3600.0 sec.	1.0
		at motor switching (seconds)		-
		Delay time due to the		
	12-04	deceleration ( or the decrement)	0.0-3600.0 sec.	1.0
		at motor switching (seconds)	0.0 0000.0 000.	
		Delay time due to fixed quantity		
N	12-05	circulation at motor switching	0.0-3600.0 sec.	10.0
,	.2 00	(seconds)	0.0 0000.0 000.	10.0
		Frequency when switching		
N	12-06	motors at fixed quantity	0.00–599.00 Hz	60.0
,	12 00	circulation (Hz)	0.00 000.00 112	
			0: Turn off all output	
	12-07	Action when fixed 1uantity	1: Motors powered by mains electricity continues to	0
		circulation breaks down	operate	-
,		Frequency for stopping auxiliary		
×	12-08	motor (Hz)	0.00–599.00 Hz	0.00
		Fixed quantity circulation output		
	12-09	delay	1.0–3600.0 sec.	1.0
		Motor 1 operation record		Read
	12-10	(min./sec.)	Read only	Only
		•		Read
	12-11	Motor 1 operation record (hour)	Read only	Only
		Motor 2 operation record		Read
	12-12	(min./sec.)	Read only	Only
		,		Read
	12-13	Motor 2 operation record (hour)	Read only	Only
		Motor 3 operation record		Read
	12-14	(min./sec.)	Read only	Only
				Read
	12-15	Motor 3 operation record (hour)	Read only	Only
		Motor 4 operation record		Read
	12-16	(min./sec.)	Read only	Only
		(		Read
	12-17	Motor 4 operation record (hour)	Read only	Only
				Orny

Pr.	Parameter Name	Setting Range	Default
12-18	Motor 5 operation record	Pood only	Read
12-10	(min./sec.)	Read only	Only
12-19	Motor 5 operation record (hour)	Read only	Read
12-19	Motor 5 operation record (nodr)	Read only	Only
12-20	Motor 6 operation record	Read only	Read
12-20	(min./sec.)	Read only	Only
12-21	Motor 6 operation record (hour)	Read only	Read
12-21	Motor o operation record (nodr)	Read only	Only
12-22	Motor 7 operation record	Read only	Read
12-22	(min./sec.)	read only	Only
12-23	Motor 7 operation record (hour)	Read only	Read
12-20	Wotor / operation record (nodi)	redu only	Only
12-24	Motor 8 operation record	Read only	Read
12 27	(min./sec.)	Troud only	Only
12-25	Motor 8 operation record (hour)	Read only	Read
12 20	Motor o operation record (nodi)	Troud only	Only
		0: No function	
		1: Clear operation time for motor 1	
		2: Clear operation time for motor 2	
		3: Clear operation time for motor 3	
40.00		4: Clear operation time for motor 4	
12-26	Clear motor's operation time	5: Clear operation time for motor 5	0
		6: Clear operation time for motor 6	
		7: Clear operation time for motor 7	
		8: Clear operation time for motor 8	
		10: Clear operation time for all motors	
12-27	Priority for circulated operation	0: Terminal order	0
12-21	Priority for circulated operation	1: Minimum operation time	0

# 13 Application Parameters by Industry

Pr.	Parameter Name	Setting Range	Default
		0: Disable	
		1: User-defined Parameter	
13-00	Industry Parameters	2: Compressor (IM)	0
13-00	combination	3: Fan	0
		4: Pump	
		10: Air Handling Unit, AHU	
13-01			
	Industry Parameters 1–99	0.00–655.35	0.00
13-99			

# **14 Extension Card Parameter**

	Pr.	Parameter Name	Setting Range	Default
	14-00	Extension card Input terminal	0: Disable	0
	14-00	selection (Al10)	1: Frequency command	U
	14-01	Extension card Input terminal	4: PID target value	0
	14-01	selection (AI11)	5: PID feedback signal	U
			6: Thermistor (PTC) input value	
			11: PT100 thermistor input value	
			13: PID compensation amount	
*	14-08	Analog input filter time (AI10)	0.00-20.00 sec.	0.01
*	14-09	Analog input filter time (AI11)	0.00-20.00 sec.	0.01
	11 10	Analog input 4–20mA signal loss	0: Disable	0
	14-10	selection (Al10)	1: Continue operation at the last frequency	0
	4.4.44	Analog input 4–20mA signal loss	2: Decelerate to 0 Hz	0
	14-11	selection (Al11)	3: Stop immediately and display ACE	0
	44.40	Extension card output terminal	0: Output frequency (Hz)	•
*	14-12	selection (AO10)	1: Frequency command (Hz)	0
	44.40	Extension card output terminal	2: Motor speed (Hz)	•
*	14-13	selection (AO11)	3: Output current (rms)	0
			4: Output voltage	
			5: DC bus voltage	
			6: Power factor	
			7: Power	
			9: AVI1 proportional	
			10: ACI proportional	
			11: AVI2 proportional	
			20: CANopen analog output	
			21: RS-485 analog output	
			22: Communication card analog output	
			23: Constant voltage output	
	14-14	Analog output 1 gain output	0.0.500.0%	100.0
_	14-14	(AO10)	0.0–500.0%	100.0
	14-15	Analog output 1 gain output	0.0–500.0%	100.0
	14-15	(AO11)	0.0-300.076	100.0
	14 16	Analog output 1 in REV direction		0
~	14-16	(AO10)	0: Absolute value of output voltage	0
		Analog output 1 in REV direction	1: Reverse output 0 V; Forward output 0–10 V	_
*	14-17	(AO11)	2: Reverse output 5–0 V; Forward output 5–10 V	0
	1/1/10	Extension card input selection	0: 0–10 V (AVI10)	0
~	14-18	(AI10)	1: 0–20 mA (ACI10)	0

	Pr.	Parameter Name	Setting Range	Default
			2: 4–20 mA (ACI10)	
		Extension card input selection	0: 0–10 V (AVI11)	
×	14-19	(Al11)	1: 0–20 mA (ACI11)	0
		(AIII)	2: 4–20 mA (ACI11)	
	14-20	AO10 DC output setting level	0.00-100.00%	0.00
	14-21	AO11 DC output setting level	0.00-100.00%	0.00
×	14-22	AO10 filter output time	0.00-20.00 sec.	0.01
×	14-23	AO11 filter output time	0.00-20.00 sec.	0.01
*	14-36	AO10 output selection	0: 0–10 V	0
			1: 0–20 mA	_
×	14-37	AO11 output selection	2: 4–20 mA	0

[This page intentionally left blank]

# Chapter 12 Descriptions of Parameter Settings

# 12-1 Description of parameter settings 00 Drive Parameters

✓ You can set this parameter during operation.

AC Motor Drive Identity Code

Default: Read only

Settings Read Only

Graph Control of the Control of t

Default: Read only

Settings Read Only

Pr.00-00 displays the AC motor drive identity code. Using the following specification table to check if Pr.00-01 setting is the rated current of the AC motor drive. Pr.00-01 corresponds to the identity code of the AC motor drive (Pr.00-00).

☐ The default is the rated current for light duty. Set Pr.00-16 = 1 to display the rated current for normal duty.

	230V Models														
Frame			Α				В								
Power (kW)	0.75	1.5	2.2	3.7	5.5	7.5	11	15							
Power (HP)	1	2	3	5	7.5	10	15	20							
Identity code	4	6	8	10	12	14	16	18							
Rated current for light duty [A]	5	7.5	10	15	21	31	46	61							
Rated current for normal duty [A]	3	5	8	11	17	25	33	49							
Frame		С		Ι	)		E								
Power (kW)	18.5	22	30	37	45	55	75	90							
Power (HP)	25	30	40	50	60	75	100	125							
Identity code	20	22	24	26	28	30	32	34							
Rated current for light duty [A]	75	90	105	146	180	215	276	322							
Rated current for normal duty [A]	65	75	90	120	146	180	215	255							

	460V Models														
Frame				Α					В			С	D0		
Power (kW)	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11	15	18.5	22	30	37	45	55
Power (HP)	1	2	3	5	5	7.5	10	15	20	25	30	40	50	60	75
Identity code	5	7	9	11	93	13	15	17	19	21	23	25	27	29	31
Rated current for light load [A]	3	4.2	5.5	8.5	10.5	13	18	24	32	38	45	60	73	91	110
Rated current for normal load [A]	2.8	3.0	4.0	6.0	9.0	10.5	12	18	24	32	38	45	60	73	91

#### Chapter 12 Description of Parameter Settings | CP2000

	460V Models															
Frame	[	D		Ξ	F			(	3				ŀ	1		
Power (kW)	75	90	110	132	160	185	200	220	250	280	315	355	400	500	560	630
Power (HP)	100	125	150	175	215	250	270	300	340	375	425	475	530	675	750	850
Identity code	33	35	37	39	41	43	486	45	487	47	49	51	53	55	59	61
Rated current for light duty [A]	150	180	220	260	310	370	395	460	481	530	616	683	770	930	1094	1212
Rated current for normal duty [A]	110	150	180	220	260	310	310	370	395	460	550	616	683	866	930	1094

	575V Models														
Frame		Α		В											
Power (kW)	1.5	2.2	3.7	5.5	7.5	11	15								
Power (HP)	2	3	5	7.5	10	15	20								
Identity code	505	506	507	508	509	510	511								
Rated current for light duty [A]	3	4.3	6.7	9.9	12.1	18.7	24.2								
Rated current for normal duty [A]	2.5	3.6	5.5	8.2	10	15.5	20								

					690V	/ M	lodels						
Frame		(	0				[	)			ı	Ξ	
Power (kW)	18.5	22	22 30		37		45	55	75	9	0	110	132
Power (HP)	25	30	4	0	50		60	75	100	12	25	150	175
Identity code	612	613	61	4	615		616 617		618	61	19 620		621
Rated current for light duty [A]	24	30			6 45		54	67	86	10	04 125		150
Rated current for normal duty [A]	20	24	3	0	36		45	54	67	8	6	104	125
Frame		F		G		}				H	1		
kW	160	200	)	2	250		315	400	45	0	;	560	630
HP	215	270	)	(	335		425	530	60	0		750	850
Identity code	622	686	6	(	687		626	628	62	9	631		632
Rated current for light duty [A]	180	220	220		290		350	430	46	5		590	675
Rated current for normal duty [A]	150	180	180		220		290	350	50 385		465		675

# Parameter Reset

Default: 0

Settings 0: No Function

1: Write protection for parameters

5: Return kWh displays to 0

6: Reset PLC (including CANopen Master Index)

7: Reset CANopen Slave Index

9: Reset all parameters to defaults (base frequency at 50 Hz)

10: Reset all parameters to defaults (base frequency at 60 Hz)

1: All parameters are read only except Pr.00-02, Pr.00-07 and Pr.00-08. Set Pr.00-02 to 0 before changing other parameter settings. □ 5: You can return the kWh displayed value to 0 even during drive is operation. For example, you can set Pr.05-26-Pr.05-30 to 0. 6: Clear the internal PLC program (includes the related settings of PLC internal CANopen master) 2 7: Reset the related settings of CANopen slave. 9 or 10: Reset all parameters to defaults. If you have set a password (Pr.00-08), unlock the password (Pr.00-07) to clear the password you have set before you reset all parameters. For settings of 6, 7, 9 and 10, you must reboot the motor drive after you finish the setting. Default: 0 Settings 0: F (Frequency command) 1: H (Output frequency) 2: U (User-defined, see Pr.00-04) 3: A (Output current) Determines the start-up display page after power is applied to the drive. The user-defined contents display according to the Pr.00-04 settings. ✓ **## - # 4** Content of Multi-function Display Default: 3 Settings 0: Display output current (A) (Unit: Amp) 1: Display counter value (c) (Unit: CNT) 2: Display the motor's actual output frequency (H) (Unit: Hz) 3: Display the drive's DC bus voltage (v) (Unit: V<sub>DC</sub>) 4: Display the drive's output voltage (E) (Unit: V<sub>AC</sub>) 5: Display the drive's output power angle (n) (Unit: deg) 6: Display the drive's output power in kW (P) (Unit: kW) 7: Display the motor speed rpm (Unit: rpm) 10: Display PID feedback (b) (Unit: %) 11: Display AVI1 analog input terminal signal (1.) (Unit: %) 12: Display ACI analog input terminal signal (2.) (Unit: %) 13: Display AVI2 analog input terminal signal (3.) (Unit: %) 14: Display the drive's IGBT temperature (i.) (Unit: °C) 15: Display the drive's capacitance temperature (c.) (Unit: °C) 16: The digital input status (ON/OFF) (i) 17: The digital output status (ON/OFF) (o) 18: Display multi-step speed (S) 19: The corresponding CPU digital input pin status (d) 20: The corresponding CPU digital output pin status (0.) 26: Ground Fault GFF (G.) (Unit: %)

27: DC bus voltage ripple (r.) (Unit: V<sub>DC</sub>)

#### Chapter 12 Description of Parameter Settings | CP2000

- 28: Display PLC register D1043 data (C)
- 30: Display the output of User-defined (U)
- 31: Display Pr.00-05 user Gain (K)
- 34: Operation speed of fan (F.) (Unit: %)
- 36: Present operating carrier frequency of the drive (J.) (Unit: Hz)
- 38: Display the drive status (6.)
- 41: kWh display (J) (Unit: kWh)
- 42: PID target value (h) (Unit: %)
- 43: PID compensation (o.) (Unit: %)
- 44: PID output frequency (b.) (Unit: Hz)
- 45: Hardware ID
- 51: PMSVC torque offset
- 52: AI10%
- 53: AI11%
- 68: STO version (d)
- 69: STO checksum-high word (d)
- 70: STO checksum-low word (d)

#### Explanation 1

It can display negative values when setting analog input bias (Pr.03-03-03-10).

Example: Assume that AVI1 input voltage is 0 V, Pr.03-03 is 10.0% and Pr.03-07 is 4 (Bias serves as the center).

#### **Explanation 2**

Example: If REV, MI1 and MI6 are ON, the following table shows the status of the terminals.

Normally opened contact (N.O.), 0: OFF, 1: ON

Terminal	MI15	MI14	MI13	MI12	MI11	MI10	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
Status	0	0	0	0	0	0	0	0	1	0	0	0	0	1	1	0

NOTE MI10–MI15 are the terminals for extension cards (Pr.02-26–02-31).

- The value is 0000 0000 1000 0110 in binary and 0086h in HEX. When Pr.00-04 is set to 16 or 19, the u page on the keypad displays "0086h".
- The setting value 16 is ON / OFF status of digital input according to Pr.02-12 setting, and the setting value 19 is the corresponding CPU pin ON / OFF status of the digital input.
- You can set 16 to monitor the digital input ON / OFF status, and then set 19 to check if the circuit
  is normal.

#### **Explanation 3**

Assume that RY1: Pr.02-13 is set to 9 (Drive is ready). After the drive is powered on, if there is no other abnormal status, the contact is ON. The display status is shown as below.

Normally opened contact (N.O.):

Termina	MO20	MO19	MO18	MO17	MO16	MO15	MO14	MO13	MO12	MO11	MO10	Reserved	Reserved	RY3	RY2	RY1
Status	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1

 If Pr.00-04 is set to 17 or 20, it displays in hexadecimal "0001h" with LED u page is ON in the keypad.

- The setting value 17 is ON / OFF status of digital output according to Pr.02-18 setting, and the setting value 20 is the corresponding CPU pin ON / OFF status of the digital output.
- You can set 17 to monitor the digital output ON / OFF status, and then set 20 to check if the circuit is normal.

#### **Explanation 4**

Setting value 25: when displayed value reaches 100.00%, the drive shows "oL" as an overload warning.

#### Explanation 5

Setting value 38:

bit 0: The drive is running forward. bit 3: Errors occurred on the drive.

bit 1: The drive is running backward. bit 4: The drive is running.

bit 2: The drive is ready. bit 5: Warnings occurred on the drive.

## ★ Goefficient Gain in Actual Output Frequency

Default: 1.00

Settings 0.00-160.00

Sets the user-defined unit coefficient gain. Set Pr.00-04 = 31 to display the calculation result on the screen (calculation = output frequency × Pr.00-05).

### Firmware Version

Default: Read only

Settings Read only

## Parameter Protection Password Input

Default: 0

Settings 0-65535

Display 0–4 (the number of password attempts allowed)

- This parameter allows you to enter your password (which is set in Pr.00-08) to unlock the parameter protection and to make changes to the parameter.
- To avoid problems in the future, be sure to write down the password after you set this parameter.
- Pr.00-07 and Pr.00-08 are used to prevent personnel from setting other parameters by accident.
- If you forget the password, clear the password setting by input 9999 and press the ENTER key, then enter 9999 again and press ENTER within 10 seconds. After decoding, all the settings return to default.
- When setting is under password protection, all the parameters read 0, except Pr.00-08.

## ✓ ☐☐ - ☐☐ Parameter Protection Password Setting

Default: 0

Settings 0-65535

0: No password protection or password entered correctly (Pr.00-07)

1: Password has been set


This parameter sets the password protection. Password can be set directly the first time. After you set the password, the value of Pr.00-08 is 1, which means password protection is activated. At this time, if you want to change any of the parameter settings, you must enter the correct

#### Chapter 12 Description of Parameter Settings | CP2000

password in Pr.00-07 to deactivate the password temporarily, and this would make Pr.00-08 become 0. After you finish setting the parameters, reboot the motor drive and the password is activated again.

- Entering the correct password in Pr.00-07 only temporarily deactivates the password. To permanently deactivate password protection, set Pr.00-08 to 0 manually. Otherwise, password protection is always reactivated after you reboot the motor drive.
- The keypad copy function works only when the password protection is deactivated (temporarily or permanently), and password set in Pr.00-08 cannot be copied to the keypad. So when copying parameters from the keypad to the motor drive, set the password manually again in the motor drive to activate password protection.

#### Password Decode Flow Chart



# Speed Control Mode

Default: 0

Settings 0: IMVF (IM V/F control)


2: IM / PM SVC (IM / PM space vector control)

6: PM Sensorless (PM FOC sensorless) (applied to 230V / 460V models)


8: SynRM Sensorless Control (applied to 230V / 460V models)

- Determines the control method of the AC motor drive:
  - 0: IM V/F control, you can set the proportion of V/F as required and control multiple motors simultaneously.
  - 2: IM / PM space vector control, gets the optimal control by auto-tuning the motor parameters.
  - 6: PM FOC sensorless, PM filed oriented sensorless vector control
  - 8: SynRM Sensorless, SynRM filed oriented sensorless vector control


When you set Pr.00-11 to 0, the V/F control diagram is as follows:




When you set Pr.00-11 to 2, the space vector control diagram is as follows. Induction Motor Space Vector Control (IMSVC)




#### Permanent Magnetic Motor Space Vector Control (PMSVC)



When you set Pr.00-11 to 6, PM FOC Sensorless control diagram is as follows:



When you set Pr.00-11 to 8, SynRM Sensorless control diagram is as follows:



### Load Selection

Default: 0

Settings 0: Light duty

1: Normal duty

- Light load (230V / 460V models): over-load ability is 120% rated output current in 60 seconds. Refer to Pr.00-17 for the setting of carrier frequency. Refer to Chapter 09 Specifications or Pr.00-01 for the rated current.
- Normal load (230V / 460V models): over-load ability is 120% rated output current in 60 seconds (160% rated output current in 3 seconds). Refer to Pr.00-17 for the setting of carrier frequency. Refer to Chapter 09 Specifications or Pr.00-01 for the rated current.
- Pr.00-01 varies with the setting value for Pr.00-16. The default value and maximum setting value for Pr.06-03 and Pr.06-04 also vary with the setting value for Pr.00-16.

### Carrier Frequency

Default: Table below

Settings 2-15 kHz

- This parameter determinates the PWM carrier frequency for the AC motor drive.
- When you set Pr.00-11 = 8 (SynRM Sensorless control), the maximum setting value of carrier frequency is 8 kHz.

#### • 230V / 460V models:

Light duty						
Control mode	VF,	SVC	PMFOC		SRMFOC	
Model	Settings	Default	Settings	Default	Settings	Default
VFD007-150CP23A/E	2 15 14 17	–15 kHz 8 kHz	4–10 kHz	8 kHz	4–8 kHz	4 kHz
VFD007-185CP43A/E	2-15 KHZ					
VFD185-450CP23A/E	2–10 kHz	0.401415	4 40 1411-	6 kHz	4 0 1/1 1=	4 141 1=
VFD220-750CP43A/E	2-10 KHZ	6 kHz	4–10 kHz	O KHZ	4–8 kHz	4 kHz
VFD550-1100CP23A/E	2–9 kHz	4 kHz	4–9 kHz	4 kHz	4–8 kHz	4 kHz
VFD900-6300CP43A/E		4 KHZ	4-9 KHZ	4 KMZ	4-0 KHZ	4 KHZ

Normal duty						
Control mode	VF, SVC		PMFOC		SRMFOC	
Model	Settings	Default	Settings	Default	Settings	Default
VFD007-150CP23A/E	2 15 14 17	–15 kHz 8 kHz	4–10 kHz	8 kHz	4–8 kHz	4 kHz
VFD007-185CP43A/E	2-15 KHZ					
VFD185-450CP23A/E	2 10 1/11-	2–10 kHz 6 kHz	4–10 kHz 6 kH	e kH-	4–8 kHz	4 kHz
VFD220-750CP43A/E	2-10 KHZ			O KITZ		4 KHZ
VFD550-1100CP23A/E	0.0141-	0.011- 411-	4.0141-	4 1 1 1 -	4 0 1.11-	4 kHz
VFD900-6300CP43A/E	2–9 kHz	4 kHz	4–9 kHz	4 kHz	4–8 kHz	4 KHZ

#### 575V / 690V models:

	Light duty		Normal duty	
Control mode	VF, SVC		VF, SVC	
Model	Settings	Default	Settings	Default
VFD015-150CP53A	2–9 kHz	4 kHz	2–9 kHz	4 kHz
VFD185-5600CP63A	2–9 kHz	4 kHz	2–9 kHz	4 kHz
VFD6300CP63A	2–9 kHz	3 kHz	2–9 kHz	3 kHz*1

<sup>\*1.</sup> Light duty / Normal duty: the default for 690V, 630 kW [850 HP] model is 3 kHz in VF / SVC mode.

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
2kHz	Significant	Minimal	Minimal	<del></del>
8kHz	<b>1</b>	<b>1</b>	l T	
15kHz		<b>↓</b>	↓	-\\\\\ ↓
	Minimal	Significant	Significant	

From the table, you see that the PWM carrier frequency has significant influences on the electromagnetic noise, the AC motor drive heat dissipation, and the motor acoustic noise.

Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency to reduce the temperature rise. Although the motor has quiet operation in the higher carrier frequency, consider the entire wiring and interference.

When the carrier frequency is higher than the default, decrease the carrier frequency to protect the drive. Refer to Pr.06-55 for the related setting and details.

### PLC Command Mask

Default: Read Only

Settings bit0: Control command is forced by PLC control

bit1: Frequency command is forced by PLC control

Determines if the frequency command or control command is locked by PLC

Master Frequency Command Source (AUTO) / Source Selection of the PID Target

Default: 0

Settings 0: Digital keypad

1: RS-485 communication input

2: External analog input (Refer to Pr.03-00–Pr.03-02)

3: External UP/DOWN terminal (multi-function input terminals)

6: CANopen communication card

8: Communication card (does not include CANopen card)

Set the master frequency source in AUTO mode.

Pr.00-20 and Pr.00-21 are for settings the frequency source and operation source in AUTO mode. Pr.00-30 and Pr.00-31 are for settings the frequency source and operation source in HAND mode. You can switch the AUTO/HAND mode with the keypad KPC-CC01 or the multi-function input terminal (MI).

The default for the frequency source or operation source is AUTO mode. It returns to AUTO mode whenever you cycle the power. If you use a multi-function input terminal to switch between AUTO and HAND mode, the highest priority is the multi-function input terminal. When the external terminal is OFF, the drive does not accept any operation signal and cannot execute JOG.

### Operation Command (AUTO) Source

Default: 0

Settings 0: Digital keypad

1: External terminals

2: RS-485 communication input

3: CANopen communication card

5: Communication card (does not include CANopen card)

Determines the operation frequency source in the AUTO mode.

When you control the operation command by the keypad KPC-CC01, keys RUN, STOP and JOG (F1) are valid.


✓ GG - 22 Stop Method

Default: 0

Settings 0: Ramp to stop

1: Coast to stop

Determines how the motor is stopped when the drive receives the STOP command.



Ramp to Stop and Coast to Stop

- 1. **Ramp to stop:** the AC motor drive decelerates to 0 or the minimum output frequency (Pr.01-07) according to the set deceleration time, and then to stop.
- 2. **Coast to stop:** the AC motor drive stops output immediately, and the motor coasts to stop according to the load inertia.
  - Use "ramp to stop" for the safety of personnel, or to prevent material from being wasted in applications where the motor must stop immediately after the drive stops. You must set the deceleration time accordingly.
  - If idling is allowed, or the load inertia is large, use "coast to stop". For example, blowers, punching machines and pumps

Default: 0

Settings 0: Enable forward / reverse

1: Disable reverse

2: Disable forward

Enables the motor to run in the forward and reverse direction. You can use it to prevent a motor from running in a direction that would cause injure or damage to the equipment, especially when only on running direction is allowed for the motor load.

Digital Operator (Keypad) Frequency Command Memory

Default: Read only

Settings Read only

If the keypad is the frequency command source, when Lv or Fault occurs, this parameter stores the current frequency command.

## **GG-25** User-Defined Characteristics

Default: 0

Settings bit0-3: user-defined decimal place

0000b: no decimal place

0001b: one decimal place

0010b: two decimal places

0011b: three decimal places

bit4-15: user-defined unit

000xh: Hz

001xh: rpm

002xh: %

003xh: kg

004xh: m/s

005xh: kW

006xh: HP

007xh: ppm

008xh: 1/m

009xh: kg/s

00Axh: kg/m

00Bxh: kg/h

00Cxh: lb/s

00Dxh: lb/m

00Exh: lb/h

00Fxh: ft/s

010xh: ft/m

011xh: m

012xh: ft

013xh: degC

014xh: degF

015xh: mbar

016xh: bar

017xh: Pa

019xh: mWG

01Axh: inWG

01Bxh: ftWG

01Cxh: psi

01Cxh: psi

01Dxh: atm


01Exh: L/s

01Fxh: L/m

020xh: L/h

021xh: m3/s 022xh: m3/h 023xh: GPM 024xh: CFM xxxxh: Hz

- □ bit0–3: the displayed units for the control frequency F page and user-defined (Pr.00-04 = d10, PID feedback) and the displayed number of decimal places for Pr.00-26 (supports up to three decimal places).
- bit4–15: the displayed units for the control frequency F page, user-defined (Pr.00-04 = d10, PID feedback) and Pr.00-26.



You must convert the setting value to decimal when using the keypad to set parameters.

Example: Assume that the user-defined unit is inWG and user-defined decimal place is the third decimal point. According to the information above, the corresponding unit to inWG is 01Axh (x is the set decimal point), and the corresponding unit to the third decimal place is 0003h, then inWG and the third decimal point displayed in hexadecimal is 01A3h, that is 419 in decimal value. Thus, set Pr.00-25 = 419 to complete the setting.

### ## - 25 Maximum User-Defined Value

Default: 0

Settings 0: Disable

0-65535 (when Pr.00-25 is set to no decimal place)

0.0-6553.5 (when Pr.00-25 is set to one decimal place)

0.00–655.35 (when Pr.00-25 is set to two decimal places)

0.000–65.535 (when Pr.00-25 is set to three decimal places)

When Pr.00-26 is NOT set to 0, the user-defined value is enabled. After selecting the displayed unit and number of decimal places with Pr.00-25, the setting value of Pr.00-26 corresponds to Pr.01-00 (drive's maximum operating frequency).

Example: When the frequency set in Pr.01-00 = 60.00 Hz, the maximum user-defined value for Pr.00-26 is 100.0%. This also means that Pr.00-25 is set as 0021h.

Set Pr.00-25 before using Pr.00-26. After you finish setting, when Pr.00-26 is not 0, the displayed unit on the keypad shows correctly according to Pr.00-25 settings.

# User-Defined Value Default: Read only Settings Read only Pr.00-27 displays the user-defined value when Pr.00-26 is not set to 0.

The user-defined value is valid only when Pr.00-20 (frequency source) is set to the digital keypad

or to RS-485 communication.

### Switching from AUTO Mode to HAND Mode

Default: 0

Settings bit0: Sleep function control bit

0: Cancel sleep function

1: Sleep function and AUTO mode are the same

bit1: Control bit unit

0: Displaying unit in Hz

1: Same unit as the AUTO mode

bit2: PID control bit

0: Cancel PID control

1: PID control and AUTO mode are the same.

bit3: Frequency source control bit

0: Frequency source set up by parameter, if the multi-step speed is activated, then multi-step speed has the priority.

1: Frequency command set up by Pr.00-30, regardless of whether the multi-step speed is activated.

### ## - P LOCAL / REMOTE Selection

Default: 0

Settings 0: Standard HOA function

1: When switching between local and remote, the drive stops

- 2: When switching between local and remote, the drive runs with REMOTE settings for frequency and operating status
- 3: When switching between local and remote, the drive runs with LOCAL setting for frequency and operating status
- 4: When switching between local and remote, the drive runs with LOCAL settings when switched to Local and runs with REMOTE settings when switched to Remote for frequency and operation status.
- The default for Pr.00-29 is 0, that is, the standard HOA (Hand-Off-Auto) function. Set the AUTO and HAND frequency and operation source with Pr.00-20, Pr.00-21 and Pr.00-30, Pr.00-31. Use digital keypad (KPC-CC01) or multi-function input terminal to set MIx = 41 and 42 (AUTO / HAND mode).
- When you set the external terminal (MI) to 41 and 42 (AUTO / HAND mode), Pr.00-29 = 1, 2, 3, 4 are disabled. The external terminal has the highest command priority, and Pr.00-29 functions in standard HOA mode.

- If Pr.00-29 is not set to 0, the Local / Remote function is enabled, and the top right corner of digital keypad (firmware version 1.021 and above) displays "LOC" or "REM". Set the REMOTE frequency and operation source with Pr.00-20 and Pr.00-21. Set the LOCAL frequency and operation source with Pr.00-30 and Pr.00-31. Select or switch Local / Remote mode with the digital keypad or set the multi-function input terminal MIx = 56. The AUTO key of the digital keypad is for the REMOTE function, and HAND key is for the LOCAL function.
- When you set the external terminal (MI) to 56 for LOC / REM mode selection, if you set Pr.00-29 to 0, then the external terminal function is disabled.
- When you set the external terminal (MI) to 56 for LOC / REM mode selection, if Pr.00-29 is not set to 0, then AUTO / HAND key is disabled, and the external terminal has the highest command priority.
- The comparison between the setting of each mode and the PLC address:

PLC address /	HOA mode		LOC / REM mode		HOA mode
Mode	HAND-ON	AUTO-ON	LOC-ON	REM-ON	OFF
M1090 =	0	0	0	0	1
M1091 =	1	0	0	0	0
M1092 =	0	1	0	0	0
M1100 =	0	0	1	0	0
M1101 =	0	0	0	1	0

### 

Default: 0

Settings 0: Digital keypad

1: RS-485 communication input

2: External analog input (refer to Pr.03-00–Pr.03-02)

3: External UP/DOWN terminal

6: CANopen communication card

8: Communication card (does not include CANopen card)

Determines the master frequency source in HAND mode.

### GG - 3 ( Operation Command Source (HAND)

Default: 0

Settings 0: Digital keypad

1: External terminals

2: RS-485 serial communication input

3: CANopen communication card

5: Communication card (does not include CANopen card)

- Sets the operation frequency source in HAND mode.
- Use Pr.00-20 and Pr.00-21 to set the frequency source and the operation source in AUTO mode, and use Pr.00-30 and Pr.00-31 to set the frequency source and operation source in HAND mode. Select or switch AUTO / HAND mode by using the digital keypad KPC-CC01 or setting the multi-function input terminal (MI).
- The default for the frequency source or operation source is AUTO mode. It returns to AUTO

mode whenever you cycle the power. If you use a multi-function input terminal to switch AUTO / HAND mode, the multi-function input terminal has the highest priority. When the external terminal is OFF, the drive does not accept any operation signal and cannot execute JOG.

Default: 0

Settings 0: STOP key disabled

1: STOP key enabled

Valid when the operation command source is note the digital keypad (Pr.00-21 ≠ 0). When Pr.00-21 = 0, the STOP key on the digital keypad is not affected by this parameter.

### ✓ ☐☐ - ☐☐ Over-modulation Gain

Default: 100

Settings 80–120

- When the motor operates in the flux-weakening region or voltage saturation region it can be that a higher voltage output is required. Increase Pr.00-37 to increase the output RMS voltage. Increasing the over-modulation gain reduces the output current and enhances the motor efficiency. However, note that low-frequency harmonics created by the six-step square-wave modulation may occur if the gain is too large.
- How to use Pr.00-37:
  Gradually increase Pr.00-37 setting value to check if the output current reduces and the operation performance improves for an optimal over-modulation gain value.

### ✓ ☐☐ - Ч☐ Display Filter Time (Current)

Default: 0.100

Settings: 0.001-65.535 sec.

Minimizes the current fluctuation displayed by the digital keypad.

### ✓ ☐☐ - Ч ☐ Display Filter Time (Keypad)

Default: 0.100

Settings: 0.001-65.535 sec

Minimizes the value fluctuation displayed by the digital keypad.

### ☐☐ - ☐☐ Software Version (date)

Default: Read only

Settings: Read only

Displays the current drive software version by date.

### 01 Basic Parameters

✓ You can set this parameter during operation.

Maximum Operation Frequency

Default: 60.00 / 50.00

Settings 50.00-599.00 Hz

230V models: setting range for / including 55 kW: 0.00-400.00 Hz 460V models: setting range for / including 90 kW: 0.00-400.00 Hz

575V / 690V models: 599.00 Hz

Determines the AC motor drive's maximum operation frequency range. All the AC motor drive frequency command sources (analog inputs 0-10 V, 4-20 mA, 0-20 mA, ±10 V) are scaled to correspond to the output frequency range.

Minimum Carrier Frequency Requirement	Maximum Operation Frequency (IM VF/ IM SVC)
2k	200 Hz
3k	300 Hz
4k	400 Hz
5k	500 Hz
6k	599 Hz

230V models 55 kW and above: the maximum operation frequency is 400 Hz (the carrier frequency should be set at least 4k)

460V models 90 kW and above: the maximum operation frequency is 400 Hz (the carrier frequency should be set at least 4k)

575V / 690V models: maximum operation frequency is 599 Hz

Rated / Base Frequency of Motor 1

- 35 Rated / Base Frequency of Motor 2

Default: 60.00 / 50.00

Settings 0.00-599.00 Hz

Set this parameter according to the motor's rated frequency on the motor nameplate. If the motor's rated frequency is 60 Hz, set this parameter to 60. If the motor's rated frequency is 50 Hz, set this parameter to 50.

Rated / Base Voltage of Motor 1

Rated / Base Voltage of Motor 2

Default: 220.0/400.0/

575.0/660.0

Settings 230V models: 0.0-255.0 V

460V models: 0.0-510.0 V 575V models: 0.0-637.0 V 690V models: 0.0-765.0 V

- Set this parameter according to the rated voltage on the motor nameplate. If the motor's rated voltage is 220 V, set this parameter to 220.0. If the motor's rated voltage is 200 V, set this parameter to 200.0.
- There are many motor types in the market and the power system for each country is also different. The economical and convenient solution is to install an AC motor drive. Then there is no problem using the motor with different voltage and frequency inputs, and the motor drive can improve the original motor characteristics and useful life.

	0:1-03	Mid-point	Frequency 1 of Motor 1	
				Default: 3.00 / 3.00 /
				0.0 / 0.0
		Settings	230V models: 0.00-599.00 Hz	
			460V models: 0.00-599.00 Hz	
			575V models: 0.00-599.00 Hz	
			690V models: 0.00-599.00 Hz	
×	01-04	Mid-point	Voltage 1 of Motor 1	
				Default: 11.0 / 22.0 /
				0.0 / 0.0
		Settings	230V models: 0.0-240.0 V	
			460V models: 0.0-480.0 V	
			575V models: 0.0-637.0 V	
			690V models: 0.0-720.0 V	
				690V, 185 kW and above models: 10.0
	0:1-37	Mid-point	Frequency 1 of Motor 2	
				Default: 3.00
		Settings	0.00–599.00 Hz	
×	0:-38	Mid-point	Voltage 1 of Motor 2	
				Default: 11.0 / 22.0 /
				0.0 / 0.0
		Settings	230V models: 0.0–240.0 V	
			460V models: 0.0–480.0 V	
			575V models: 0.0–637.0 V	
			690V models: 0.0–720.0 V	
				690V, 185 kW and above models: 10.0
	0:1-05	Mid-point	Frequency 2 of Motor 1	
				Default: 1.50
			0.00–599.00 Hz	
<b>/</b>	0 1-08	Mid-point	Voltage 2 of Motor 1	
				Default: 5.0 / 10.0 /
				0.0 / 0.0
		Settings	230V models: 0.0–240.0 V	
			460V models: 0.0–480.0 V	
			575V models: 0.0–637.0 V	
			690V models: 0.0–720.0 V	2001/ 405
	0 . 20	B 41 1	5 0 (11)	690V, 185 kW and above models: 2.0
	0:-39	Mid-point	Frequency 2 of Motor 2	
		0 11:	0.00 500 00 11	Default: 1.50
		Settings	0.00–599.00 Hz	

## Holding 


### Hid-point Voltage 2 of Motor 2 Default: 5.0 / 10.0 / 0.0 / 0.0Settings 230V models: 0.0–240.0 V 460V models: 0.0-480.0 V 575V models: 0.0-637.0 V 690V models: 0.0-720.0 V 690V, 185 kW and above models: 2.0 Minimum Output Frequency of Motor 1 Default: 1.50 Settings 0.00-599.00 Hz Minimum Output Voltage of Motor 1 Default: 1.0 / 2.0 / 0.0 / 0.0 Settings 230V models: 0.0-240.0 V 460V models: 0.0-480.0 V 575V models: 0.0-637.0 V 690V models: 0.0-720.0 V Minimum Output Frequency of Motor 2 Default: 0.50 0.00-599.00 Hz Settings Minimum Output Voltage of Motor 2 Default: 1.0 / 2.0 / 0.0 / 0.0 Settings 230V models: 0.0–240.0 V 460V models: 0.0-480.0 V 575V models: 0.0-637.0 V 690V models: 0.0-720.0 V In You usually set the V/F curve according to the motor's allowable loading characteristics. Pay special attention to the motor's heat dissipation, dynamic balance, and bearing lubrication when the loading characteristics exceed the loading limit of the motor. There is no limit for the voltage setting, but a high voltage at a low frequency may cause motor damage, overheating, and trigger the stall prevention or the over-current protection; therefore, use low voltage at low frequency to prevent motor damage or drive error.

second V/F curve.

2.

Pr.01-35 to Pr.01-42 is the V/F curve for motor 2. When setting the multi-function input terminals [Pr.02-01–02-08 and Pr.02-26–Pr.02-31 (extension card)] to 14, the AC motor drive acts with the


The diagram below shows the V/F curve for motor 1. You can use the same V/F curve for motor




V/F Curve and The Related Parameters

### Common settings of the V/F curve:


#### (1) General purpose






Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03	1.30
01-05	1.30
01-04	10.0
01-06	10.0
01-07	1.30
01-08	10.0

### (2) For fan and hydraulic machinery




Pr.	Setting
01-00	60.0
01-01	60.0
01-02	220.0
01-03	30.0
01-05	50.0
01-04	50.0
01-06	50.0
01-07	1.50
01-08	10.0
	01-00 01-01 01-02 01-03 01-05 01-04 01-06 01-07




Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03 01-05	25.0
01-04 01-06	50.0
01-07	1.30
01-08	10.0

#### (3) High starting torque



Pr.	Setting
01-00	60.0
01-01	60.0
01-02	220.0
01-03	3.00
01-05	3.00
01-04	00.0
01-06	23.0
01-07	1.50
01-08	18.0



Pr.	Setting
01-00	50.0
01-01	50.0
01-02	220.0
01-03 01-05	2.20
01-04 01-06	23.0
01-07	1.30
01-08	14.0

# ☐ : - ☐ ☐ Start-Up Frequency

Default: 0.50

#### Settings 0.00-599.00 Hz

When the starting frequency is larger than the Minimum Output Frequency, the drives' frequency output starts when the starting frequency reaches the F command. Refer to the following diagram for details.


Fcmd: frequency command

Fstart: start-up frequency (Pr.01-09)

fstart: actual start-up frequency of the drive

Fmin: 4<sup>th</sup> output frequency setting (Pr.01-07 / Pr.01-41)

Flow: output frequency lower limit (Pr.01-11)



When Fcmd > Fmin and Fcmd < Fstart:

If Flow < Fcmd, the drive runs directly by Fcmd.

If Flow ≥ Fcmd, the drive runs with Fcmd, and then rises to Flow according to acceleration time.

The drive's output frequency goes directly to 0 when decelerating to Fmin.




Output Frequency Lower Limit

Default: 0.00

Settings 0.00-599.00 Hz

- If the output frequency setting is higher than the upper limit (Pr.01-10), the drive runs with the upper limit frequency. If the output frequency setting is lower than the lower limit (Pr.01-11) but higher than the minimum output frequency (Pr.01-07), the drive runs with the lower limit frequency. Set the upper limit frequency > the lower limit frequency (Pr.01-10 setting value must be > Pr.01-11 setting value).
- If the slip compensation function (Pr.07-27) is enabled for the drive, the drive's output frequency may exceed the Frequency command.




- When the drive starts, it operates according to the V/F curve and accelerates from the minimum output frequency (Pr.01-07) to the setting frequency. It is not limited by the lower output frequency settings.
- Use the frequency upper and lower limit settings to prevent operator misuse, overheating caused by the motor's operating at a too low frequency, or mechanical wear due to a too high operation frequency.
- ☐ If the frequency upper limit setting is 50 Hz and the frequency setting is 60 Hz, the maximum operation frequency is 50 Hz.
- If the frequency lower limit setting is 10 Hz and the minimum operation frequency setting (Pr.01-07) is 1.5 Hz, then the drive operates at 10 Hz when the Frequency command is higher than Pr.01-07 but lower than 10 Hz. If the Frequency command is lower than Pr.01-07, the drive is in ready status without output.

N	B	1- 12	Accelerat	ion Time 1			
N	$\Box$	!- !3	Decelerat	tion Time 1			
N	B	1- 14	Accelerat	ion Time 2			
N	B	1- 15	Decelerat	tion Time 2			
N	B	1- 18	Accelerat	ion Time 3			
N	B	! - ! ]	Decelerat	tion Time 3			
N	8	!- !8	Accelerat	ion Time 4			
N	B	1- 19	Decelerat	tion Time 4			
N	G	1-20	JOG Acce	eleration Time			
N	$\overline{g}$	1-21	JOG Dec	eleration Time			
		_				Default: 10.00	
						Default: 60.00 / 60.0 (22 kW model	s and above)
						Default: 80.00 / 80.0 (160 kW mode	els and above)
			Settings	Pr.01-45 = 0: 0	0.00–600.00	seconds	
				Pr.01-45 = 1: 0	0.0–6000.0 s	econds	
		The acc	eleration ti	ime determines	the time red	uired for the AC motor drive to ramp	from 0.00 Hz
		to the n	naximum	operation frequ	ency (Pr.01	-00). The deceleration time determ	nines the time
		required	for the A0	C motor drive to	decelerate	from the maximum operation freque	ncy (Pr.01-00)
		down to	0.00 Hz.				
		The acc	eleration a	and deceleratio	n time are i	nvalid when using Pr.01-44 Auto-ac	celeration and
		Auto-de	celeration	Setting			
		Select t	he Accele	ration / Decele	ration time	1, 2, 3, 4 with the multi-function i	nput terminals
		settings.	The defa	ults are Accelera	ation Time 1	and Deceleration Time 1.	
		With the	e enabled	torque limits	and stall p	revention functions, the actual acc	celeration and
		decelera	ation time a	are longer than	the above a	ction time.	
		Note th	at setting	the acceleration	on and dec	eleration time too short may trigg	er the drive's
		protection	on function	n (Pr.06-03 Ov	er-current	Stall Prevention during Acceleratio	n or Pr.06-01
		Over-vo	Itage Stall	Prevention), an	d the actual	acceleration and deceleration time a	are longer than
		this setti	ing.				
		Note that	at setting	the deceleration	n time too	short may cause motor damage o	r trigger drive
		protection	on due to c	over-current dur	ing the drive	's deceleration or over-voltage.	
		Use suit	table brak	e resistor (refer	to Section	07 Optional Accessories) to decele	rate in a short
		time and	d prevent c	over-voltage.			

☐ When you enable Pr.01-24–Pr.01-27 (S-curve acceleration and deceleration begin and arrival

time), the actual acceleration and deceleration time are longer than the setting.



Acceleration / Deceleration Time

## ✓ ☐ ! - ? ? JOG Frequency

Settings 0.00-599.00 Hz

Default: 6.00

You can use both the external terminal JOG and F1 key on the optional keypad KPC-CC01 to set the JOG function. When the JOG command is ON, the AC motor drive accelerates from 0 Hz to the JOG frequency (Pr.01-22). When the JOG command is OFF, the AC motor drive decelerates from the JOG frequency to stop. The JOG acceleration and deceleration time (Pr.01-20, Pr.01-21) are the time to accelerate from 0.0 Hz to JOG frequency (Pr.01-22).

You cannot execute the JOG command when the AC motor drive is running. When the JOG command is executing, other operation commands are invalid.

### ★ 3 ! - 2 3 Switch Frequency between First and Fourth Accel. / Decel.

Default: 0.00


#### Settings 0.00-599.00 Hz

- This function does not require the external terminal switching function; it switches the acceleration and deceleration time automatically according to the Pr.01-23 setting. If you set the external terminal, the external terminal has priority over Pr.01-23.
- Use this parameter to set the switch frequency between acceleration and deceleration slope. The First / Fourth Accel. / Decel. slope is calculated by the Max. Operation Frequency (Pr.01-00) / acceleration / deceleration time.

Example: When the Max. Operation Frequency (Pr.01-00) = 80 Hz, and Switch Frequency between First and Fourth Accel. / Decel. (Pr.01-23) = 40 Hz:

- a. If Acceleration Time 1 (Pr.01-02) = 10 sec., Acceleration Time 4 (Pr.01-18) = 6 sec., then the acceleration time is 3 sec. for 0–40 Hz and 5 sec. for 40–80 Hz.
- b. If Deceleration Time 1 (Pr.01-13) = 8 sec., Deceleration Time 4 (Pr.01-19) = 2 sec., then the deceleration time is 4 sec. for 80–40 Hz and 1 sec. for 40–0 Hz.

Default: 0.20



1st/4th Acceleration/Deceleration Frequency Switching

N	01-54	S-curve for Acceleration Begin Time 1
×	01-25	S-curve for Acceleration Arrival Time 2
×	85-18	S-curve for Deceleration Begin Time 1
N	$\Omega : -2.7$	S-curve for Deceleration Arrival Time 2

Settings Pr.01-45 = 0: 0.00–25.00 seconds Pr.01-45 = 1: 0.0–250.0 seconds


deceleration time.

Using an S-curve gives the smoothest transition between speed changes. The acceleration and deceleration curve adjusts the acceleration and deceleration S-curve. When enabled, the drive produces a different acceleration and deceleration curve according to the acceleration and

The S-curve function is invalid when you set the acceleration and deceleration time to 0.

When Pr.01-12, Pr.01-14, Pr.01-16, Pr.01-18 ≥ Pr.01-24 and Pr.01-25, the actual acceleration time = Pr.01-12, Pr.01-14, Pr.01-16, Pr.01-18 + (Pr.01-24 + Pr.01-25) / 2

When Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 ≥ Pr.01-26 and Pr.01-27, the actual deceleration time = Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 + (Pr.01-26 + Pr.01-27) / 2 Frequency






Default: 0.00

Settings 0.00-599.00 Hz

- Sets the AC motor drive's skip frequency. The drive's frequency setting skips these frequency ranges. However, the frequency output is continuous. There are no limits for these six parameters and you can combine them. Pr.01-28 does not need to be greater than Pr.01-29; Pr.01-30 does not need to be greater than Pr.01-31; Pr.01-32 does not need to be greater than Pr.01-33. You can set Pr.01-28–01-33 as you required. There is no size distinction among these six parameters.
- These parameters set the skip frequency ranges for the AC motor drive. You can use this function to avoid frequencies that cause mechanical resonance. The skip frequencies are useful when a motor has resonance vibration at a specific frequency bandwidth. Skipping this frequency avoids the vibration. There are three frequency skip zones available.
- You can set the frequency command (F) within the range of skip frequencies. Then the output frequency (H) is limited to the lower limit of skip frequency ranges.
- During acceleration and deceleration, the output frequency still passes through the skip frequency ranges.



### 


Default: 0

Settings 0: Output waiting

1: Zero-speed operation

2: Minimum frequency (Refer to Pr.01-07 and Pr.01-41)

- When the drive's Frequency command is lower than Fmin (Pr.01-07 or Pr.01-41), the drive operates according to this parameter.
- 0: the AC motor drive is in waiting mode without voltage output from terminals U, V, W.
- 1: the drive executes the DC brake by Vmin (Pr.01-08 and Pr.01-42) in V/F and SVC modes.
- 2: the AC motor drive runs using Fmin (Pr.01-07, Pr.01-41) and Vmin (Pr.01-08, Pr.01-42) in V/F and SVC modes.
- In V/F and SVC modes



Default: 0

Settings 0: V/F curve determined by Pr.01-00-01-08

1: V/F curve to the power of 1.5

2: V/F curve to the power of 2

3: 60 Hz, voltage saturation in 50 Hz

4: 72 Hz, voltage saturation in 60 Hz

5: 50 Hz, decrease gradually with cube

6: 50 Hz, decrease gradually with square

7: 60 Hz, decrease gradually with cube

8: 60 Hz, decrease gradually with square

9: 60 Hz, medium starting torque

10: 60 Hz, high starting torque

11: 60 Hz, medium starting torque


12: 60 Hz, high starting torque

13: 90 Hz, voltage saturation in 60 Hz

14: 120 Hz, voltage saturation in 60 Hz

15: 180 Hz, voltage saturation in 60 Hz

- When setting to 0, refer to Pr.01-01-08 for the motor 1 V/F curve. For motor 2, refer to Pr.01-35-01-42.
- When setting to 1 or 2, the second and third voltage frequency setting are invalid.
- If the load of the motor is a variable torque load (torque is in direct proportion to the rotating speed, such as the load of a fan or a pump), the load torque is low at low rotating speed. You can decrease the input voltage appropriately to make the magnetic field of the input current smaller and reduce flux loss and iron loss for the motor to increase efficiency.
- When you set the V/F curve to high power, it has lower torque at low frequency, and the drive is not suitable for rapid acceleration and deceleration. Do NOT use this parameter for rapid acceleration and deceleration.






Auto-acceleration and Auto-deceleration Setting

Default: 0

Settings

- 0: Linear acceleration and deceleration
- 1: Auto-acceleration and linear deceleration
- 2: Linear acceleration and auto-deceleration
- 3: Auto-acceleration and auto-deceleration
- 4: Stall prevention by auto-acceleration and auto-deceleration (limited by Pr.01-12–Pr.01-21)
- 0 (linear acceleration and linear deceleration): the drive accelerates and decelerates according to the setting for Pr.01-12–01-19.
- 1 or 2 (auto / linear acceleration and auto / linear deceleration): the drive auto-tunes the acceleration and deceleration to effectively reduce the mechanical vibration during the load start-up and stop and make the auto-tuning process more easier. It does not stall during acceleration and does not need a brake resistor during deceleration to stop. It can also improve operation efficiency and save energy.
- 3 (auto-acceleration and auto-deceleration-decelerating by the actual load): the drive auto-detects the load torque and automatically accelerates from the fastest acceleration time and smoothest start-up current to the setting frequency. During deceleration, the drive automatically determines the loaded regenerative energy to steadily and smoothly stop the motor in the fastest deceleration time.
- 4 (stall prevention by auto-acceleration and deceleration—reference to the acceleration and deceleration time settings): if the acceleration and deceleration time are within a reasonable range, the actual acceleration and deceleration time refer to Pr.01-12–01-19 settings. If the acceleration and deceleration time are too short, the actual acceleration and deceleration time are greater than the acceleration and deceleration time settings.



Acceleration / Deceleration Time

- Optimize the acceleration / deceleration time when Pr.01-44 is set to 0.
- 2 Optimize the acceleration / deceleration time which load needs actually when Pr.01-44 is set to 3.

Time Unit for Acceleration and Deceleration and S Curve

Default: 0

Settings 0: Unit 0.01 sec.

1: Unit 0.1 sec.

CANopen Quick Stop Time

Default: 1.00

Settings Pr.01-45 = 0: 0.00-600.00 sec.

Pr.01-45 = 1: 0.0-6000.0 sec.

Sets the time required to decelerate from the maximum operation frequency (Pr.01-00) to 0.00 Hz through the CANopen control.

☐ - 목록 Deceleration Method Selection

Default: 0

Settings 0: Normal deceleration

1: Over voltage energy restriction

2: Traction energy control (TEC)


3: Electromagnetic energy traction control

Different control modes for Pr.01-49:

Setting / Control mode	Induction Motor (IM)		Permanent Magnet Synchronous Motor (PM)			Synchronous Reluctance Motor (SynRM)
	VF	SVC	PMSVC	PMFOC	HFI	FOC
0: Normal deceleration	<b>√</b>	✓	✓	✓	✓	✓
1: Over-voltage energy restriction	✓					
2: Traction energy control (TEC)	✓					
3: Electromagnetic energy traction control	<b>√</b>					

- © The drive decelerates or stops based on the original deceleration time settings. Use this setting when brake resistors are used.
- 1: During deceleration, the drive controls the motor according to Pr.06-01 (Over-voltage Stall Prevention) setting and the regenerative DC bus voltage. When the regenerative DC bus voltage reaches 95% of Pr.06-01, the controller is enabled. If Pr.06-01 = 0, the drive controls on the basis of the working voltage and regenerative DC bus voltage instead. When using this method, the drive decelerates according to the deceleration time setting. However, the actual deceleration time is equal to or larger than the deceleration setting time.
- 2: During deceleration, the drive controls the motor according Pr.06-01 (Over-voltage Stall Prevention) setting and the regenerative DC bus voltage. When the regenerative DC bus voltage reaches 95% of Pr.06-01, the drive dynamically adjusts the output frequency and output voltage to consume the regenerative energy. Use this method when the deceleration time that is set to fulfill the system requirement for application triggers over-voltage.
- 3: During operation (acceleration / steady speed / deceleration), the drive adjusts the output voltage according to the amount of regenerative energy and consumes the regenerative energy

- timely to reduce the risk of over-voltage. Moreover, you can also use Pr.01-50 (Electromagnetic Traction Energy Consumption Coefficient) to adjust the drive's output voltage strength.
- If you use the electromagnetic energy traction control (Pr.01-49 = 3) during linear deceleration (no triggering of over-voltage stall prevention), you can enhance the output current by increasing the output voltage (V<sub>out</sub>) to further suppress the regenerative DC bus voltage that is prompt to rise. Using this function with Pr.06-02 = 1 (Smart Over-voltage Stall Prevention) can achieve a smoother and faster deceleration.



- Electromagnetic energy traction control activates in the following three conditions:
  - 1. Activates when DC bus is larger than the over-voltage stall prevention level (Pr.06-01) during acceleration and deactivates once Pr.06-01 is disabled.
  - 2. Activates when DC bus is larger than the over-voltage stall prevention level (Pr.06-01) during steady operation and deactivates once Pr.06-01 is disabled.
  - Activates during deceleration (including stop) and deactivates once acceleration occurs or deceleration is stopped.
- When Pr.01-49 = 3, Pr.06-02 = 1 (Smart Over-voltage Stall Prevention) is automatically set to increase the stability during deceleration.

## ✓ ☐ ! - 5 ☐ Electromagnetic Traction Energy Consumption Coefficient

Default: 0.50

Settings 0.00-5.00

- During acceleration / steady speed / deceleration, the drive will dynamically adjust the output voltage based on the DC bus voltage level in order to prevent the drive from tripping on over-voltage. The output voltage is adjusted based on this parameter setting.
- The drive's output current and the efficiency of regenerative energy consumption increase when Pr.01-50 is increased. When Pr.01-50 is decreased, also the drive's output current and the

- efficiency of regenerative energy consumption will decrease.
- When setting Pr.01-50, pay attention to the drive's output current. The drive's output current must be lower than 80% of the motor's rated current to prevent the motor from overheating.
- Flux-weakening Overload Stall Prevention Time (applied to 230V / 460V models)

Default: 1.00

Settings 0.00–600.00 sec.

- This parameter is only valid when Pr.00-11 = 8 (SynRM Sensorless Control Mode).
- When the drive operates in flux-weakening zone, and the motor decelerates due to its sudden loading increment, adjust the setting for this parameter.

## 02 Digital Input / Output Parameter

✓ You can set this parameter during operation.

## Two-wire / Three-wire Operation Control

Default: 0

Settings 0: Two-wire mode 1, power on for operation control

1: Two-wire mode 2, power on for operation control

2: Three-wire, power on for operation control

This parameter sets the configuration of the terminals (Pr.00-21 = 1 or Pr.00-31 = 1) which control the operation. There are three different control modes listed in the following table.

Pr.02-00	Control Circuits of the External Terminal
Setting value: 0 Two-wire operation control FWD/STOP REV/STOP	FWD/STOP  REV/STOP  OO  REV ("OPEN": STOP)  ("CLOSE": FWD)  REV ("OPEN": STOP)  ("CLOSE": REV)  DCM  CP2000
Setting value: 1 Two-wire operation control RUN/STOP REV/FWD	RUN/STOP FWD ("OPEN": STOP) ("CLOSE": RUN) REV ("OPEN": FWD) ("CLOSE": REV) DCM CP2000
Setting value: 2 Three-wire operation control	FWD ("CLOSE": RUN)  STOP RUN  MI1 ("OPEN": STOP)  REV/FWD ("OPEN": FWD)  ("CLOSE": REV)  DCM  CP2000

☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: 1
☐ 2 - ☐ 2 Multi-function Input Command 2 (MI2)	
	Default: 2
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: 3
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: 4
### Multi-function Input Command 5 (MI5)	
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
## Multi-function Input Command 7 (MI7)	
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
## Input terminal of I/O extension card (MI10)	

☐ 2 - 2 7 Input terminal of I/O extension card (MI11)	
☐ 2 - 2 ☐ Input terminal of I/O extension card (MI12)	
☐ 2 - 2 3 Input terminal of I/O extension card (MI13)	
☐ 2 - 3 ☐ Input terminal of I/O extension card (MI14)	
☐ 2 - 3 ☐ Input terminal of I/O extension card (MI15)	

Default: 0

#### Settings

- 0: No function
- 1: Multi-step speed command 1
- 2: Multi-step speed command 2
- 3: Multi-step speed command 3
- 4: Multi-step speed command 4
- 5: Reset
- 6: JOG operation [by external control or KPC-CC01 (optional)]
- 7: Acceleration / deceleration speed inhibit
- 8: 1st and 2nd acceleration / deceleration time selection
- 9: 3<sup>rd</sup> and 4<sup>th</sup> acceleration / deceleration time selection
- 10: External Fault (EF) input (Pr.07-20)
- 11: Base Block (B.B.) input from external
- 12: Output stop
- 13: Cancel the setting of auto-acceleration / auto-deceleration time
- 14: Switch between motor 1 and motor 2
- 15: Rotating speed command from AVI1
- 16: Rotating speed command from ACI
- 17: Rotating speed command from AVI2
- 18: Forced to stop (Pr.07-20)
- 19: Frequency up command
- 20: Frequency down command
- 21: PID function disabled
- 22: Clear the counter
- 23: Input the counter value (MI6)
- 24: FWD JOG command
- 25: REV JOG command
- 28: Emergency stop (EF1)
- 29: Signal confirmation for Y-connection
- 30: Signal confirmation for  $\Delta$ -connection
- 38: Disable write EEPROM function
- 40: Force coasting to stop
- 41: HAND switch
- 42: AUTO switch
- 49: Enable drive

- 50: Slave dEb action to execute
- 51: Selection for PLC mode bit0
- 52: Selection for PLC mode bit1
- 53: Trigger CANopen quick stop
- 54: UVW output electromagnetic valve switch
- 55: Brake release
- 56: Local / Remote Selection
- 58: Enable fire mode with RUN command
- 59: Enable fire mode without RUN command
- 60: Disable all the motors
- 61: Disable Motor 1
- 62: Disable Motor 2
- 63: Disable Motor 3
- 64: Disable Motor 4
- 65: Disable Motor 5
- 66: Disable Motor 6
- 67: Disable Motor 7
- 68: Disable Motor 8
- 69: Preheating command
- This parameter selects the functions for each multi-function terminal.
- Pr.02-26–Pr.02-31 are entity input terminals only when extension cards are installed; otherwise, there are virtual terminals. For example, when using the multi-function extension card EMC-D42A, Pr.02-26–Pr.02-29 are defined as the corresponded parameters for MI10–MI13. In this case, Pr.02-30–Pr.02-31 are virtual terminals.
- When Pr.02-12 is defined as virtual terminal, use digital keypad KPC-CC01 or communication method to change its status (0: ON; 1: OFF) of bit8–15.
- If Pr.02-00 is set to three-wire operation control, terminal MI1 is for the STOP contact. The function set previously for this terminal is automatically invalid.

#### Summary of function settings

Take the normally opened contact (N.O.) for example, ON: contact is closed, OFF: contact is open

Settings	Functions	Descriptions
0	No Function	
1	Multi-step speed	
ı	command 1	You can set 15 steps of speed or 15 positions with the digital status
2	Multi-step speed	of these four terminals. You can use 16-steps of speed if you
	command 2	include the master speed when setting as 15 steps of speed (refer
2	Multi-step speed	to Parameter Group 04 Multi-step Speed Parameters.)
3	command 3	

Settings	Functions	Descriptions	
4	Multi-step speed		
4	command 4		
5	Reset	Use this terminal to reset the drive after clearing a drive fault.	
6	JOG operation [by external control or KPC-CC01 (optional)]	This function is valid when the source of the operation command is the external terminals.  The JOG operation executes when the drive stops completely. While running, you can still change the operation direction, and the STOP key on the keypad* and the STOP command from communications are valid. Once the external terminal receives the OFF command, the motor stops in the JOG deceleration time. Refer to Pr.01-20–01-22 for details.  *: This function is valid when Pr.00-32 is set to 1.  Pr.01-22  JOG frequency  ON  OFF  Mix-GND  ON  OFF	
7	Acceleration / deceleration speed inhibit	When you enable this function, the drive stops acceleration of deceleration immediately. After you disable this function, the AC motor drive starts to accelerate or decelerate from the inhibit point.  Frequency  Setting frequency  Accel. inhibit area  Actual operation frequency  Decel. inhibit area  Actual operation frequency  Decel. inhibit area  Actual operation frequency  Decel. inhibit area  ON  Operation Command  ON  OFF	
8	1 <sup>st</sup> and 2 <sup>nd</sup> acceleration / deceleration time selection	You can select the acceleration and deceleration time of the drive with this function, or from the digital status of the terminals; there are four acceleration and deceleration selection.	

Settings	Functions			Descr	riptions	
			MIx=9	MIx=8	Accel./Decel.	
	3 <sup>rd</sup> and 4 <sup>th</sup> acceleration /		OFF	OFF	1st Accel./Decel.	
9	deceleration time		OFF	ON	2 <sup>nd</sup> Accel./Decel.	
	selection		ON	OFF	3 <sup>rd</sup> Accel./Decel.	
			ON	ON	4 <sup>th</sup> Accel./Decel.	
10	External Fault (EF) Input	Pr.07-20 setti record when a	ng, and tan externa	he keypa Il fault occ	ive decelerates acc d shows "EF" (It shows). The drive keep us restored) after RE	nows the fault s running until
11	Base block (B.B.) input from external	ON: the outpu	ut of the d	rive stops	immediately. The m B.B. signal. Refer t	notor is in free
	mom oxtornal	details.				
		free run status	s. The dri <sup>,</sup> FF, and th	ve is in ou	s immediately and the status und the status under the starts and runs	ntil the switch
12	Output Stop	Voltage Freq Setting frequency MIx-GND Operation command	uency	ON	OFF ON	Time
	Cancel the setting of	Set Pr.01-44	to one of	the 01-0	4 setting modes bef	ore using this
13					nabled, OFF is for a	•
	auto-deceleration time	ON is for linea			·	
	Switch between motor 1	ON: use para	meters for	motor 2.		
14	and motor 2	OFF: use para	ameters fo	or motor 1		
15	Rotating speed command from AVI1		d comma	nds are s	ve's frequency to be set to AVI1, ACI and ACI > AVI2)	•
16	Rotating speed command form ACI		d comma	nds are s	ve's frequency to b set to AVI1, ACI and ACI > AVI2)	`
17	Rotating speed command form AVI2		d comma	nds are s	ve's frequency to be set to AVI1, ACI and ACI > AVI2)	•
18	F (D-07.00)	ON: the drive	rampe to	eton acco	rding to the Pr.07-20	) actting

Settings	Functions	Descriptions
		ON: the frequency of the drive increases or decreases by one unit.
19	Frequency Up command	If this function remains ON continuously, the frequency increases
		or decreases according to Pr.02-09 / Pr.02-10.
	F 5	The Frequency command returns to zero when the drive stops, and
20	Frequency Down	the displayed frequency is 0.0 Hz. If you select Pr.11-00, bit7 = 1,
	command	the frequency is not saved.
21	PID function disabled	ON: the PID function is disabled.
22	Clear the counter	ON: the current counter value is cleared and displays "0". The drive
22	Clear the Counter	counts up when this function is disabled.
23	Input the counter value	ON: the counter value increases by one. Use the function with
25	input the counter value	Pr.02-19.
24	FWD JOG command	This function is valid when the source of the operation command is
24	1 VVD 000 confinance	external terminal. ON: the drive executes forward JOG.
25	REV JOG command	This function is valid when the source of the operation command is
20	1.L v 000 command	external terminal. ON: the drive executes reverse JOG.
		ON: the output of the drive stops immediately, displays "EF1" on the
	Emergency stop (EF1)	keypad, and the motor is in the free run status. The drive keeps
		running until the fault is cleared after you press RESET on the
		keypad (EF: External Fault).
		Voltage
		Frequency
		Setting / / / / / / / / / / / / / / / / / / /
28		
		_
		ON OFF ON
		MIX-GND OFF
		Reset Operation ON ON
		command
	Signal confirmation for	When the control mode is V/F, ON: the drive operates by the first
29	Y-connection	V/F.
25	Signal confirmation for	When the control mode is V/F, ON: the drive operates by the
30	∆-connection	second V/F.
	Disable writing EEPROM	ONL unition to EEDDOM is disabled. Oher and a consistence of
38	function (parameters	ON: writing to EEPROM is disabled. Changed parameters are not
	memory disable)	saved after power off
40	Force coasting to stop	ON: during operation, the motor coasts to stop.

Settings	Functions	Descriptions
41	HAND switch	<ol> <li>When the MI terminal switches to OFF, it executes a STOP command. Therefore, if the MI terminal switches to OFF during operation, the drive stops.</li> <li>Use the optional keypad KPC-CC01 to switch between HAND and AUTO. The drive stops first, and then switches to HAND or AUTO status.</li> </ol>
42	AUTO switch	3. The optional digital keypad KPC-CC01 displays the current status of the drive (HAND/OFF/AUTO).
49	Enable drive	When the drive is enabled, the RUN command is valid.  When the drive is disabled, the RUN command is invalid.  When drive is operating, the motor coasts to stop.  This function varies with MOx = 45.
50	Slave dEb action to execute	Enter the message setting in this parameter when the master triggers dEb. This ensures that the slave also triggers dEb, then the master and slave stop simultaneously.
51	Selection for PLC mode (bit0)	PLC status bit1 bit0 Disable PLC function (PLC 0) 0 0
52	Selection for PLC mode (bit1)	Trigger PLC to operation (PLC 1) 0 1 Trigger PLC to stop (PLC 2) 1 0 No function 1 1
53	Trigger CANopen quick stop	When this function is enabled under CANopen control, it changes to Quick Stop. Refer to Section 15 CANopen Overview for more details.
	UVW output electromagnetic valve switch	This function allows receiving confirmation signals when the output is controlled through the UVW magnetic switch.
55	Brake release	When Pr.02-56 ≠ 0, connect the brake release signal to multi-function input terminals. When the brake is opened, and the drive does not receive its confirming signal, the Brk error occurs.
56	LOCAL / REMOTE Selection	Use Pr.00-29 to select LOCAL / REMOTE mode (refer to Pr.00-29).  When Pr.00-29 is not set to 0, the digital keypad KPC-CC01  displays the LOC / REM status. (KPC-CC01 firmware version 1.021 and above).

Settings	Functions	Descriptions
58	Enable fire mode with	Enable this function under fire mode to force the drive to run (while
56	RUN Command	there <b>is</b> RUN command).
59	Enable fire mode	Enable this function under fire mode to force the drive to run (while
39	without RUN Command	there <b>is not</b> a RUN command).
60	Disable all the motors	ON: when the multi-motor circulative control is enable, all motors
00	Disable all the motors	coast to stop.
61	Disable Motor 1	
62	Disable Motor 2	
63	Disable Motor 3	These functions work with multi-motor circulative control, motor 1 to
64	Disable Motor 4	8 can be set to coast to stop. If any of Auxiliary Motor 1 to Motor 8 is
65	Disable Motor 5	out of order or under maintenance, enable this terminal to bypass
66	Disable Motor 6	that motor.
67	Disable Motor 7	
68	Disable Motor 8	
		ON: if the preheating function is open and drive is in STOP status,
60	Droboating Command	the preheating function is executed; until the contact status
69	Preheating Command	changes to OFF, or the drive status turns to RUN and stops the
		preheating function. Refer to Pr.02-72-02-73 for detail.

### ✓ ☐ 2 - ☐ 3 UP/DOWN Key Mode

Default: 0

Settings 0: Up / Down by the acceleration or deceleration time

1: Up / Down constant speed (Pr.02-10)


✓ ☐ Constant speed, Acceleration or Deceleration Speed of the UP/DOWN Key

Default: 0.001

Settings 0.001-1.000 Hz/ms


- Use when the multi-function input terminals are set to 19, 20 (Frequency UP / DOWN command). The frequency increases or decreases according to Pr.02-09 and Pr.02-10.
- ☐ When Pr.02-09 is set to 0:

The increasing or decreasing Frequency command (F) operates according to the setting for acceleration or deceleration time (refer to Pr.01-12–Pr.01-19)



When Pr.02-09 is set to 1:

The increasing or decreasing Frequency command (F) operates according to the setting for Pr.02-10 (0.01–1.00 Hz/ms).



### 

Default: 0.005

Settings 0.000-30.000 sec.

- Use this parameter to set the response time of the digital input terminals FWD, REV and MI1–MI8.
- This function is to delay and confirm the digital input terminal signal. The time for delay is also the time for confirmation. The confirmation prevents interference that could cause error in the input to the digital terminals. But in the meanwhile, it delays the response time though confirmation improves accuracy.

### 

Default: 0000h

Settings 0000h-FFFFh (0: N.O.; 1: N.C.)

- The parameter setting is in hexadecimal.
- This parameter sets the status of the multi-function input signal (0: normally open; 1: normally closed) and it is not affected by the status of SINK / SOURCE.
- bit2-bit15 correspond to MI1-MI14.
- The default for bit0 is FWD terminal, and the default for bit1 is REV terminal. You cannot use this parameter to change the input mode.
- You can change the terminal ON / OFF status through communications.

For example, MI1 is set to 1 (multi-step speed command 1) and MI2 is set to 2 (multi-step speed command 2). Then the forward + second step speed command =  $1001_2 = 9_{10}$ . As long as Pr.02-12 = 9 is set through communications, there is no need to wire any multi-function terminal to run forward with the second step speed.

bit1	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MI1	MI14	MI13	MI12	MI11	MI10	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD

81 - 50	Multi-function Output 1 (Relay1)	
		Default: 11
82-14	Multi-function Output 2 (Relay2)	
		Default: 1
82 - 15	Multi-function Output 3 (Relay3)	
		Default: 66
88-58	Output Terminal of I/O Extension Card (MO10) or (RA10)	
02-37	Output Terminal of I/O Extension Card (MO11) or (RA11)	
88 - 50	Output Terminal of I/O Extension Card (RA12)	
02-39	Output Terminal of I/O Extension Card (RA13)	
82-48	Output Terminal of I/O Extension Card (RA14)	
02-41	Output Terminal of I/O Extension Card (RA15)	
82-42	Output Terminal of I/O Extension Card (MO16 Virtual Terminal)	
02-43	Output Terminal of I/O Extension Card (MO17 Virtual Terminal)	
85-44	Output Terminal of I/O Extension Card (MO18 Virtual Terminal)	
02-45	Output Terminal of I/O Extension Card (MO19 Virtual Terminal)	
82-48	Output Terminal of I/O Extension Card (MO20 Virtual Terminal)	
		Default: 0

#### Settings

- 0: No function
- 1: Indication during RUN
- 2: Operation speed reached
- 3: Desired frequency reached 1 (Pr.02-22)
- 4: Desired frequency reached 2 (Pr.02-24)
- 5: Zero speed (Frequency command)
- 6: Zero speed including STOP (Frequency command)
- 7: Over-torque 1 (Pr.06-06-06)
- 8: Over-torque 2 (Pr.06-09-06-11)
- 9: Drive is ready
- 10: Low voltage warning (Lv) (Pr.06-00)
- 11: Malfunction indication
- 12: Mechanical brake release (Pr.02-32)
- 13: Overheat warning (Pr.06-15)
- 14: Software brake signal indication (Pr.07-00)
- 15: PID feedback error (Pr.08-13, Pr.08-14)
- 16: Slip error (oSL)
- 17: Count value reached, does not return to 0 (Pr.02-20)
- 18: Count value reached, returns to 0 (Pr.02-19)
- 19: External interrupt B.B. input (Base Block)
- 20: Warning output
- 21: Over-voltage

22: Over-current stall prevention 23: Over-voltage stall prevention 24: Operation mode 25: Forward command 26: Reverse command 27: Output when current ≥ Pr.02-33 28: Output when current < Pr.02-33 29: Output when frequency ≥ Pr.02-34 30: Output when frequency < Pr.02-34 31: Y-connection for the motor coil 32: △ -connection for the motor coil 33: Zero speed (actual output frequency) 34: Zero speed including stop (actual output frequency) 35: Error output selection 1 (Pr.06-23) 36: Error output selection 2 (Pr.06-24) 37: Error output selection 3 (Pr.06-25) 38: Error output selection 4 (Pr.06-26) 40: Speed reached (including stop) 44: Low current output (use with Pr.06-71–Pr.06-73) 45: UVW output electromagnetic valve switch 46: Master dEb output 50: Output control for CANopen 51: Analog output control for RS-485 interface (InnerCOM / Modbus) 52: Output control for communication cards 53: Fire mode indication 54: Bypass fire mode indication 55: Motor 1 output 56: Motor 2 output 57: Motor 3 output 58: Motor 4 output 59: Motor 5 output 60: Motor 6 output 61: Motor 7 output 62: Motor 8 output 66: SO output logic A 67: Analog input level reached 68: SO output logic B 69: Preheating output indication Use this parameter to set the function of the multi-function terminals. Pr.02-36-Pr.02-41 requires additional extension cards to display the parameters, the choices of optional cards are EMC-D42A and EMC-R6AA. The optional card EMC-D42A provides two output terminals, use with Pr.02-36–Pr.02-37.

- The optional card EMC-R6AA provides six output terminals, use with Pr.02-36–Pr.02-41.
- MO16–MO20 are virtual terminals, set the status of bit11–15 of Pr.02-18 to control these virtual terminals.

Summary of function settings

Take the normally open contact (N.O.) for example, ON: contact is closed, OFF: contact is open

Settings	Functions	Descriptions						
0	No function							
1	Indication during RUN	Active when the drive is not in STOP.						
2	Operation speed reached	Active when output frequency of the drive reaches the setting frequency.						
3	Desired frequency reached 1 (Pr.02-22)	Active when the desired frequency (Pr.02-22) reached.						
4	Desired frequency reached 2 (Pr.02-24)	Active when the desired frequency (Pr.02-24) reached.						
5	Zero Speed (frequency command)	Active when frequency command = 0 (the drive must be in RUN status)						
6	Zero Speed, includes Stop (frequency command)	Active when frequency command = 0 or stopped.						
7	Over-torque 1	Active when the drive detects over-torque. Pr.06-07 sets the over-torque detection level, and Pr.06-08 sets the over-torque detection time. Refer to Pr.06-06—Pr.06-08.						
8	Over-torque 2	Active when the drive detects over-torque. Pr.06-10 sets the over-torque detection level, and Pr.06-11 sets the over-torque detection time. Refer to Pr.06-09–06-11.						
9	Drive is ready	Active when the drive is ON with no error detected.						
10	Low voltage warning (Lv)	Active when the DC bus voltage is too low (refer to Pr.06-00 Low Voltage Level).						
11	Malfunction indication	Active when fault occurs (except Lv stop).						
12	Mechanical brake release (Pr.02-32)	Active when the drive runs after the set delayed time for Pr.02-32. This function must be used with DC brake function.						
13	Overheat warning	Active when IGBT or heat sink overheats, to prevent the drive from shutting down due to overheating (refer to Pr.06-15).						
14	Software brake signal indication	Active when the soft brake function is ON (refer to Pr.07-00).						
15	PID feedback error	Active when the PID feedback signal error is detected.						
16	Slip Error (oSL)	Active when the slip error is detected.						
17	Count value reached, does not return to 0 (Pr.02-20)	When the drive executes external counter, this contact is active if the count value is equal to the setting value for Pr.02-20. This contact is not active when the setting value for Pr.02-20 > Pr.02-19.						
18	Counter value reached, returns to 0 (Pr.02-19)	When the drive executes the external counter, this contact is active if the count value is equal to the setting value for Pr.02-19.						
19	External interrupt B.B. input (Base Block)	Active when external interrupt (B.B.) stop output occurs in the drive.						
20	Warning output	Active when a warning is detected.						
21	Over-voltage	Active when over-voltage is detected. (Refer to over-voltage descriptions in Chapter 14 Fault Codes for action levels.)						
22	Over-current stall prevention	Active when over-current stall prevention is detected.						
23	Over-voltage stall prevention	Active when over-voltage stall prevention is detected.						

Settings	Functions	Descriptions			
	Operation mode	Active when the operation command is not controlled by external			
24	indication	terminal. (Pr.00-21 ≠ 0)			
25	Forward command	Active when the operation direction is forward.			
26	Reverse command	Active when the operation direction is reverse.			
27	Output when current ≥ Pr.02-33	Active when the current is ≥ Pr.02-33.			
28	Output when current < Pr.02-33	Active when the current is < Pr.02-33			
29	Output when frequency ≥ Pr.02-34	Active when the frequency is ≥ Pr.02-34.			
30	Output when frequency < Pr.02-34	Active when the frequency is < Pr.02-34.			
31	Y-connection for the motor coil	Active when Pr.05-24 = 1, the frequency output is lower than Pr.05-23 minus 2 Hz, and the time is longer than Pr.05-25.			
32	Δ-connection for the motor coil	Active when Pr.05-24 = 1, the frequency output is higher than Pr.05-23 plus 2 Hz, and the time is longer than Pr.05-25.			
33	Zero speed (actual output frequency)	Active when the actual output frequency is 0 (the drive is in RUN mode).			
34	Zero speed including stop (actual output frequency)	Active when the actual output frequency is 0 or stopped.			
35	Error output selection 1 (Pr.06-23)	Active when Pr.06-23 is ON.			
36	Error output selection 2 (Pr.06-24)	Active when Pr.06-24 is ON.			
37	Error output selection 3 (Pr.06-25)	Active when Pr.06-25 is ON.			
38	Error output selection 4 (Pr.06-26)	Active when Pr.06-26 is ON.			
40	Speed reached (including STOP)	Active when the output frequency reaches the setting frequency or stopped.			
44	Low current output	This function needs to be used with Pr.06-71–Pr.06-73			
45	UVW output electromagnetic valve switch	Use this function with external terminal input = 49 (drive enabled) and external terminal output = 45 (electromagnetic valve enabled), and then the electromagnetic valve is ON or OFF according to the status of the drive.  Enable ON ON MC  AC Driver MC  Motor IM  Motor IM  MOx=45			

Settings	Functions		Desc	riptions					
		When dEb rises		•	signal to the slave.				
46	Master dEb output	Output the message when the master triggers dEb. This ensures that							
40	Iviaster dEb output	the slave also triggers dEb. Then slave follows the deceleration time							
		of the master to	stop simultaneous	sly with the	e master.				
		Control the mul	ti-function output te	erminals th	nrough CANopen.				
			set Pr.02-14 = 50.		g				
		· ·			nown in the following table:				
		Physical	Setting of related						
		terminal	parameters	Attribute	Corresponding Index				
		RY1	Pr.02-13 = 50	RW	The bit0 at 2026-41				
	Output control for	RY2	Pr.02-14 = 50	RW	The bit1 at 2026-41				
50	Output control for CANopen	RY3	Pr.02-15 = 50	RW	The bit2 at 2026-41				
	CANOPEN	MO10/RY10	Pr.02-36 = 50	RW	The bit5 at 2026-41				
		MO11/RY11	Pr.02-37 = 50	RW	The bit6 at 2026-41				
		RY12	Pr.02-38 = 50	RW	The bit7 at 2026-41				
		RY13	Pr.02-39 = 50	RW	The bit8 at 2026-41				
		RY14	Pr.02-40 = 50	RW	The bit9 at 2026-41				
		RY15	Pr.02-41 = 50	RW	The bit10 at 2026-41				
		Refer to Section	n 15-3-5 for more i	nformatior	1.				
		For RS-485 int	erface (InnerCOM	l / Modbu	s) communication control				
		output.	•		,				
		Physical	Setting of related	A 44!	O a mara an an alina ar lar da co				
		terminal	parameters	Attribute	Corresponding Index				
	Analog output control for RS-485 interface	RY1	Pr.02-13 = 51	RW	The bit0 at 2640h				
		RY2	Pr.02-14 = 51	RW	The bit1 at 2640h				
51		MO1	Pr.02-16 = 51	RW	The bit3 at 2640h				
51		MO2	Pr.02-17 = 51	RW	The bit 4 at 2640h				
		MO10/RA10	Pr.02-36 = 51	RW	The bit5 at 2640h				
		MO11/RA11	Pr.02-37 = 51	RW	The bit6 at 2640h				
		RY12	Pr.02-38 = 51	RW	The bit7 at 2640h				
		RY13	Pr.02-39 = 51	RW	The bit8 at 2640h				
		RY14	Pr.02-40 = 51	RW	The bit9 at 2640h				
		RY15	Pr.02-41 = 51	RW	The bit10 at 2640h				
		Control the outr	out through commu	ınication c	ards (CMC-EIP01,				
		CMC-PN01 and	-		ardo (omo zir o i,				
		Physical	Setting of related						
		terminal	parameters	Attribute	Corresponding Index				
		RY1	Pr.02-13 = 52	RW	The bit0 at 2640				
		RY2	Pr.02-14 = 52	RW	The bit1 at 2640				
52	Output control for	RY3	Pr.02-15 = 52	RW	The bit2 at 2640				
	communication cards	MO10/RY10	Pr.02-36 = 52	RW	The bit5 at 2640				
		MO11/RY11	Pr.02-37 = 52	RW	The bit6 at 2640				
		RY12	Pr.02-38 = 52	RW	The bit7 at 2640				
		RY13	Pr.02-39 = 52	RW	The bit8 at 2640				
		RY14	Pr.02-40 = 52	RW	The bit9 at 2640				
		RY15	Pr.02-41 = 52	RW	The bit10 at 2640				
53	Fire mode indication	This function is	enabled when sett	ing 58 or	59 is enabled.				
54	Bypass fire mode indication	The contact wo	rks when bypass fu	unction is	enabled in the fire mode.				
55	Motor 1 output	When setting m	ulti motor oirculati	ue function	the multi function output				
56	Motor 2 output	_			n, the multi-function output -Pr.02-15  and  Pr.02-36–				
57	Motor 3 output		ordance with the se						
58	Motor 4 output	1.02 40 111 4000	oracioo will lile st	g 101 1					

Settings	Functions			Descriptions			
59	Motor 5 output						
60	Motor 6 output						
61	Motor 7 output						
62	Motor 8 output						
			Otatus of duice	Status of sa	afety output		
66	SO output logic A (N.O.)	ווי	Status of drive	N.O. (MOx = 66)	N.C. (MOx = 68)		
		-	Normal	Broken circuit (Open)	Short circuit (Close)		
68	SO output logic B (N.C.)	Ш	STO	Short circuit (Close)	Broken circuit (Open)		
	OG output logic B (14.0.)		STL1-STL3	Short circuit (Close)	Broken circuit (Open)		
		The multi-function output terminals operate when the analog input					
				high level and the low le			
		Pr.03-44: Select one of the analog signal channels (AVI1, ACI, and					
	Analog input level	AVI2) to be compared.					
67	reached	Pr.03-45: The high level for the analog input, default is 50.00%					
	reaction	Pr.03-46: The low level for the analog input, default is 10.00%.					
		If analog input > Pr.03-45, the multi-function output terminal operates.					
		If analog input < Pr.03-46, the multi-function output terminal stops					
	output.						
69	Preheating output indication		•	neating is detected.			

Add Remote IO function to directly control the drive's AO / DO and read current AI / DI status through the standard Modbus, the corresponding indexes of 26xx is as following:

	bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
2600h	MI15	MI14	MI13	MI12	MI11	MI10	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
2640h	1	-	-	-	1	MO15	MO14	MO13	MO12	MO11	MO10	•	-	RY3	RY2	RY1
2660h	A۱	/I1	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2661h	A	CI	-	-	-	-	-	-	-	-	-	ı	1	-	-	-
2662h	A۱	/12	-	-	-	-	-	-	-		-	-	-	-	-	-
266Ah	Al	10	-	-	-	-	-	-	-	-	-	-	-	-	-	-
266Bh	Al	11	-	-	-	-	-	-	-	-	-	-	-	-	-	-
26A0h		AFM1		-	-	-	-	-	-	-	-	1	-	-	-	-
26A1h		AFM2		-	-	-	-	-	-	-	-	ı	1	-	-	-
26AAh		AO10		-	-	-	-	-	-	-	-	-	-	-	-	-
26ABh		AO11		-	-	-	-	-	-	-	-	-	-	-	-	-

In addition, the AI and DI values can be read directly, while DO and AO must be controlled by Modbus under corresponding parameter function. The related parameter definition is as following:

#### DO

Terminal	Pr. Setting	Direct control the index corresponded to Modbus
RY1	Pr.02-13 = 51	bit0 of 2640h
RY2	Pr.02-14 = 51	bit1 of 2640h
RY3	Pr.02-15 = 51	bit2 of 2640h
MO10 / RY10	Pr.02-36 = 51	bit5 of 2640h
MO11 / RY11	Pr.02-37 = 51	bit6 of 2640h
RY12	Pr.02-38 = 51	bit7 of 2640h
RY13	Pr.02-39 = 51	bit8 of 2640h
RY14	Pr.02-40 = 51	bit9 of 2640h
RY15	Pr.02-41 = 51	bit10 of 2640h

#### ΑO

Terminal	Pr. Setting	Direct control the index corresponded to Modbus
AFM1	Pr.03-20 = 21	The value of 26A0h
AFM2	Pr.03-23 = 21	The value of 26A1h

Terminal	Pr. Setting	Direct control the index corresponded to Modbus
AFM10	Pr.14-12 = 21	The value of 26AAh
AFM11	Pr.14-13 = 21	The value of 26ABh

# ★ ## Multi-function Output Direction

Default: 0000h

Settings 0000h-FFFFh (0: N.O.; 1: N.C.)

- This parameter is in hexadecimal.
- This parameter is set by a bit. If a bit is 1, the corresponding multi-function output acts in an opposite way.

Example: Assume Pr.02-13 = 1 (indication when the drive is operating). If the output is positive, the bit is set to 0, and then Relay is ON when the drive runs and is OFF when the drive stops. On the contrary, if the output is negative, and the bit is set to 1, then the Relay is OFF when the drive runs and is ON when the drive stops.

bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MO20	MO19	MO18	MO17	MO16	MO15	MO14	MO13	MO12	MO11	MO10	Rese	erved	RY3	RY2	RY1

# ★ ☐ 2 - 19 Terminal Counting Value Reached (return to 0)

Default: 0

Settings 0-65500

You can set the input point for the counter using the multi-function terminal MI6 as a trigger terminal (set Pr.02-06 to 23). When counting is completed, the specified multi-function output terminal is activated (Pr.02-13, Pr.02-14, Pr.02-36, Pr.02-37 are set to 18), and Pr.02-19 cannot be set to 0 at this time.


Example: When the displayed value is c5555, the drive count is 5,555 times. If the displayed value is c5555•, the actual count value is 55,550–55,559.

# Preliminary Counting Value Reached (does not return to 0)

Default: 0

Settings 0-65500

When the count value counts from 1 to reach this value, the corresponding multi-function output terminal is activated (Pr. 02-13, Pr.02-14, Pr.02-36, Pr.02-37 are set to 17). You can use this parameter as the end of counting to make the drive run from the low speed to stop.



Desired Frequency Reached 1

Desired Frequency Reached 2

Default: 60.00 / 50.00

Settings 0.00-599.00 Hz


The Width of the Desired Frequency Reached 1

The Width of the Desired Frequency Reached 2

Default: 2.00

Settings 0.00-599.00 Hz

Once the output speed (frequency) reaches the desired speed (frequency), if the corresponding multi-function output terminal is set to 3–4 (Pr.02-13, Pr.02-14, Pr.02-36, and Pr.02-37), this multi-function output terminal is "closed".




Brake Delay Time


Default: 0.000

Settings 0.000-65.000 sec.

When the AC motor drive runs after the setting delay time of Pr.02-32, the corresponding multi-function output terminal (12: mechanical brake release) is "closed". The function must be used with DC brake.



This parameter is invalid if it is used without DC brake. Refer to the following operation timing.



# 

Default: 0

Settings 0-150%

- When the drive outputs current higher than or equal to Pr.02-33 (≥ Pr.02-33), the multi-function output parameters active (Pr.02-13, Pr.02-14, and Pr.02-15 are set to 27).
- When the drive outputs current lower than Pr.02-33 (< Pr.02-33), the multi-function output parameters active (Pr.02-13, Pr.02-14, and Pr.02-15 are set to 28).

# Output Frequency Setting for Multi-function Output Terminals

Default: 3.00

Settings 0.00-599.00 Hz

- When the drive outputs frequency higher than or equal to Pr.02-34 (actual output frequency H ≥ Pr.02-34), the multi-function terminals active (Pr.02-13, Pr.02-14 and Pr.02-15 are set to 29).
- When the drive outputs frequency lower than Pr.02-34 (actual output frequency H < Pr.02-34), the multi-function terminals active (Pr.02-13, Pr.02-14 and Pr.02-15 are set to 30).

# ★ 32 - 35 External Operation Control Selection after Reset and Activate

Default: 0

Settings 0: Disable


1: Drive runs if the RUN command remains after reset or re-boot

- Setting 1: The drive automatically executes the RUN command under the following circumstances, pay extra attention on this.
  - Status 1: After the drive is powered on and the external terminal for RUN stays ON, the drive runs.
  - Status 2: After clearing a fault once a fault is detected and the external terminal for RUN stays
     ON, you can run the drive by pressing the RESET key.

# P - 5 !! Display the Status of Multi-function Input Terminal


Default: Read only

#### Settings Monitoring status of multi-function input terminal



#### Example:


When Pr.02-50 displays 0034h (hex), (that is, the value is 110100 (binary), it means that MI1, MI3 and MI4 are ON.



# Display the Status of Multi-function Output Terminal


Default: Read only

#### Settings Monitoring status of multi-function output terminal



#### Example:

When Pr.02-51 displays 0023h (hex) (that is, the value is 100011 (binary)), it means that RY1, RY2 and MO10 are ON.




# P-5P Display the External Multi-function Input Terminals Used by PLC

Default: Read only


#### Settings Monitoring status of PLC external output terminal

Pr.02-52 displays the external multi-function input terminals that used by PLC.



#### Example:

When Pr.02-52 displays 0034h (hex) (that is, the value is 110100 (binary)), it means that MI1, MI3 and MI4 are used by PLC.




# R2-53 Display the External Multi-function Output Terminals Used by PLC

Default: Read only


Settings Monitoring status of PLC external multi-function output terminal

Pr.02-53 displays the external multi-function output terminal that used by PLC.



Example:

When Pr.02-53 displays 0003h (hex) (that is, the value is 0011 (binary)), it means that RY1 and RY2 are used by PLC.



# B 2 - 5 4 Display the Frequency Command Executed by External Terminal

Default: Read only

Settings 0.00–599.00 Hz (Read only)

When you set the source of the Frequency command as the external terminal, if Lv or Fault occurs, the external terminal Frequency command is saved in this parameter.

# 

Default: Read only

Settings 1: EMC-BPS01

4: EMC-D611A

5: EMC-D42A

6: EMC-R6AA

11: EMC-A22A

# 

Default: 0

#### Settings 0-100%

- When a motor drive is not in operation (STOP) and is placed in a cold and humid environment, enabling the preheating function to output DC current to heat up the motor drive can prevent the invasion of humidity into the motor drive, which creates condensation affects the normal function of the motor drive.
- Sets the output current level from the motor drive to the motor after enabling the preheating. The percentage of the preheating DC current is 100% of the rated current of the motor drive (Pr.05-01, Pr.05-13 and Pr.05-34). When setting this parameter, slowly increase the percentage to reach the sufficient preheating temperature.


# Preheating Output Cycle

Default: 0

#### Settings 0-100%

- Sets the output current cycle of preheating. 0–100% corresponds to 0–10 seconds. When set to 0%, there is no output current. When set to 100%, there is a continuous output. For example, when set to 50%, a cycle of preheating goes from OFF (5 seconds) to ON (5 seconds), and vice versa.
- Related Parameters of Preheating

Parameter	Description	Setting Range	Explanation
Pr.02-72	Output current level of preheating	0–100% (rated current of the motor) 0% No output	Output current level of preheating
Pr.02-73	Output cycle of preheating	0-100% (0-10 sec.) 0% No output 100% Continuous output	Output cycle of preheating
Pr.02-01-08 Pr.02-26-31	Multi-input function commands (MFI)	69 Preheating command	Enable or disable the preheating
Pr.02-13-15 Pr.02-36-46	Multi-output function commands (MFO)	69 Output command of preheating	Indication of the preheating




#### Chapter 12 Description of Parameter Settings | CP2000

- Enable preheating: When Pr.02-72 and Pr.02-73 are NOT set to zero.
- Preheating function A: If Pr.07-72 and Pr.07-23 are set before the motor drive stops operation (STOP), preheating is enabled right after the motor drive stops. However, if Pr.07-72 and Pr.07-73 are set after the motor drives stops operation, preheating is not enabled. Preheating is enabled only when the motor drive stops again or restarts.
- Preheating function B: When the motor drive is in operation (RUN) or stops operating (STOP), set Pr.02-72 and Pr.02-73 between 1–100% and set MIx = 69 and MIx = ON. Preheating is enabled whenever the motor drive stops; no matter the motor drive is in operation (RUN) or stops operating (STOP).
- Preheating priority: if preheating function A and B are both enabled, function B takes priority.


## **Sequential Diagram of the Preheating Function:**

1. Setting parameters to enable preheating (Function A)
Set Pr.02-72 and Pr.02-73 not equal to zero (50% in the diagram) and stop running the motor drive, then preheating is enabled to output DC current. At the same time, MOx (Output Command of Preheating) is ON (MOx = 69). Once the drive is rebooted, the preheating function is enabled right away. The sequence of preheating goes from OFF (5 seconds) to ON (5 seconds). When the motor is in operation (RUN), the preheating function is OFF even it is enabled. Meanwhile, MOx is OFF (MOx = 69) and the preheating is enabled when the motor




#### 2. Enable preheating via multi-input terminals (Function B)

Set Pr.02-72 and Pr.02-73 (50% in the diagram) not equal to zero and set MIx = 69, and MIx = ON, then Function B takes priority to enable / disable preheating on the motor drive. At the same time, enabling preheating by parameters is automatically invalid. If, at this moment, the motor drive is already STOP, the preheating function is enabled to output DC current and the MOx (Output Command of Preheating) is ON (MOx = 69). The sequence of preheating goes from OFF (5 seconds) to ON (5 seconds). When the motor is in operation (RUN), the preheating function is OFF even it is enabled. Meanwhile, MOx is OFF (MOx = 69) and the preheating is enabled when the motor drive stops.



#### 3. Enable DC brake function


DC brake and preheating are enabled at the same time. The motor drive operates with the same logic described above for preheating. The only difference is that no matter the motor drive is in operation (RUN) or stops operating (STOP), DC brake enables first. When the motor drive stops, preheating is activated.



# 03 Analog Input / Output Parameter

3 7	4	✓ You can see	et this param	neter during operation.
	alog Input Selection		·	
				Default: 1
✓  ☐ ☐ → ACI Ana	log Input Selection			
				Default: 0
✓ 3 - 3 ≥ AVI2 An	alog Input Selection			
				Default: 0
Settings				
0: No fu				
·	uency command			
	arget value			
	eedback signal			
	nistor (PTC) input value			
	00 thermistor input value			
	compensation value	) reference target	input you n	aust set Pr.00 20 to 2
(external analog	analog input as the PID	reference larger	iriput, you ii	iust set F1.00-20 to 2
,	1: Pr.03-00–03-02 set 1 a	s PID reference tar	raet innut	
•	ue 1 and setting value 4 e		•	nout has highest priority
•	ID reference target input		10, 110, 111	ipat nao mgnoot phonty
	nalog input as the PID cor		ou must set l	Pr.08-16 to 1 (source of
•	on value is analog input).	•		`
·	Frequency command, th		-	
maximum output	frequency (Pr.01-00).			
If the settings for	Pr.03-00-Pr.03-02 are th	e same, the AVI1 ir	nput has high	est priority.
	alog Input Bias			
				Default: 0.0
Settings	-100.0–100.0%			
Sets the correspond	onding AVI1 voltage for th	e external analog i	nput 0.	
✓   ☐   ☐   ☐   ☐   ☐   ☐   ☐   ☐   ☐	alog Input Bias			
	9			Default: 0.0
Settings	<b>-1</b> 00.0–100.0%			
	onding ACI current for the	external analog in	put 0.	
	alog Voltage Input Bias	3		
AVIZ AII	alog vollage iliput bias			Default: 0.0
Settings	s -100.0–100.0%			Delault. U.U
	onding AVI2 voltage for th	e external analog i	nnut 0	
•	ng external input voltage	•	•	uency is 0–10 V (4–20
- The conception	.g ontomai impat voltage	, sansin digital dik	oot noq	35.10, 10 0 10 V (7 20

mA) corresponds to 0-maximum frequency (Pr.01-00).



AVI2 Positive / Negative Bias Mode


Default: 0

Settings 0: No bias

- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center
- Using negative bias to set the frequency greatly reduces the noise interference. In a noisy environment, do NOT use signals less than 1 V to set the drive's operation frequency.

### In the diagram below: Black line: Curve with no bias. Gray line: curve with bias

#### Diagram 1



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

#### 1: Lower than or equal to bias


- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

#### Diagram 2



Pr.03-03=10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0. No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

V Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11Analog Input Gain (AVI1)=100%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

### Diagram 4



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 5



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias


1: Lower than or equal to bias

- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11Analog Input Gain (AVI1)= 100%

## Diagram 7



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 8



Pr.03-03=10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

2: Greater than or equal to bias

3: The absolute value of the bias voltage while serving as the center

4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.

 Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

#### Diagram 10



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

2: Greater than or equal to bias

3: The absolute value of the bias voltage while serving as the center

4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.

1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

#### Diagram 11



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

2: Greater than or equal to bias

3: The absolute value of the bias voltage while serving as the center


4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.

1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 13



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias


- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%

#### Diagram 14



Pr.03-03=-10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 100%



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
  Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 16



Pr.03-03=-10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 100%

#### Diagram 17



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias


- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)= 111.1%

10/9=111.1%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

#### 2: Greater than or equal to bias


- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1)=111.1% 10/9=111.1%

## Diagram 19



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

2: Greater than or equal to bias

3: The absolute value of the bias voltage while serving as the center


4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1% 10/9 = 111.1%

#### Diagram 20



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

1: Lower than or equal to bias

2: Greater than or equal to bias

3: The absolute value of the bias voltage while serving as the center


4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

0: Negative frequency is not valid.
Forward and reverse run is controlled
by digital keypad or external terminal.

1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1% 10/9 = 111.1%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

0: No bias

#### 1: Lower than or equal to bias


- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11Analog Input Gain (AVI1) = 111.1% 10/9 = 111.1%

## Diagram 22



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias

#### 2: Greater than or equal to bias


- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid.
  Forward and reverse run is controlled
  by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1% 10/9 = 111.1%

#### Diagram 23



Pr.03-03=10%


Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1% 10/9 = 111.1%



Pr.03-03=10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center

4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- Negative frequency is not valid.
   Forward and reverse run is controlled by digital keypad or external terminal.
- by digital keypad or external terminal.

  1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Pr.03-11 Analog Input Gain (AVI1) = 111.1% 10/9 = 111.1%

## Diagram 25



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.


Calculate the bias:

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-x\text{V})} \quad x\text{V} = \frac{10}{-9} = -1.11\text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

=-11.1%

Calculate the gain:  $03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$ 

# Diagram 26



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

=-11.1%

Calculate the gain: 03-11=  $\frac{10V}{11.1}$ V×100%=90.0%



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:  $03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$ 

## Diagram 28



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- n. No hige
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain:  $03-11 = \frac{10V}{11.1V} \times 100\% = 90.0\%$ 

# Diagram 29



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- 1: Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control.

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = 1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 03-11=  $\frac{10 \text{ V}}{11.1 \text{ V}} \times 100\% = 90.0\%$ 



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias

#### 2: Greater than or equal to bias

- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control

Calculate the bias:

$$\frac{60-6Hz}{10V} = \frac{6-0Hz}{(0-xV)} \quad xV = \frac{10}{-9} = -1.11V \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 03-11= 
$$\frac{10V}{11.1V} \times 100\% = 90.0\%$$
 = -11.1%

## Diagram 31



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
  4: Serve bias as the center

Pr.03-10 (Analog Frequency Command for Reverse Run)


- 0: Negative frequency is not valid. Forward and reverse run is controlled by digital keypad or external terminal.
- Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control

Calculate the bias:

$$\frac{60-6\text{Hz}}{10\text{V}} = \frac{6-0\text{Hz}}{(0-x\text{V})} \quad x\text{V} = \frac{10}{-9} = 1.11\text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 03-11= 
$$\frac{10 \text{ V}}{11.1 \text{ V}} \times 100\% = 90.0\%$$

## Diagram 32



Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- Serve bias as the center


Pr.03-10 (Analog Frequency Command for Reverse Run)

- 0: Negative frequency is not valid. Forward and reverse run is controlled
- by digital keypad or external terminal. Neagtive frequency is valid. Positive frequency = forward run; negative frequency = reverse run. Direction can not be switched by digital keypad or external teriminal control

Calculate the bias:

$$\frac{60-6 \text{Hz}}{10 \text{V}} = \frac{6-0 \text{Hz}}{(0-x \text{V})} \quad x \text{V} = \frac{10}{-9} = 1.11 \text{V} \quad \therefore 03-03 = \frac{-1.11}{10} \times 100\%$$

Calculate the gain: 03-11=  $\frac{10 \text{ V}}{11.1 \text{ V}} \times 100\% = 90.0\%$ 




Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%

## Diagram 34




Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%

#### Diagram 35




Pr.00-21=0 (Digital keypad control and run in FWD direction)
Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%
Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage
- while serving as the center 4: Serve bias as the center

4. Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%




Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10% Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 100%

#### Diagram 37




Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10% Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 111.1%  $(10/9) \times 100\% = 111.1\%$ 

Pr.03-14 Analog Positive Input Gain (AVI2) = 100%


#### Diagram 38



Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10% Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 100% Pr.03-14 Analog Positive Input Gain (AVI2) = 90.0%  $(10/11) \times 100\% = 90.9\%$ 



Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)


- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- 4: Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 111.1%  $(10/9) \times 100\% = 111.1\%$ 

Pr.03-14 Analog Positive Input Gain (AVI2) = 90.9%

 $(10/11) \times 100\% = 90.9\%$ 

#### Diagram 40



Pr.00-21=0 (Digital keypad control and run in FWD direction) Pr.03-05 Analog Positive Voltage Input Bias (AVI2) = 10%

Pr.03-07-03-09 (Positive/Negative Bias Mode)

- 0: No bias
- 1: Lower than or equal to bias
- 2: Greater than or equal to bias
- 3: The absolute value of the bias voltage while serving as the center
- : Serve bias as the center

Pr.03-13 Analog Positive Input Gain (AVI2) = 111.1%  $(10/9) \times 100\% = 111.1\%$ 

Pr.03-14 Analog Positive Input Gain (AVI2) = 90.9%

 $(10/11) \times 100\% = 90.9\%$ 

# Reverse Setting when Analog Signal Input is Negative Frequency

Default: 0

- Settings 0: Negative frequency is not allowed. The digital keypad or external terminal controls the forward and reverse direction.
  - 1: Negative frequency is allowed. Positive frequency = run in forward direction; negative frequency = run in reverse direction. The digital keypad or external terminal control cannot switch the running direction.
- ☐ Use this parameter only for AVI1 or ACI analog input.
- Requirements for negative frequency (reverse running):
  - 1. Pr.03-10 = 1
  - 2. Bias mode = Bias serve as the center
  - 3. Corresponded analog input gain < 0 (negative); this makes the input frequency negative.
- In using the additional analog input function (Pr.03-18 = 1), when the analog signal is negative after the addition, you can set this parameter to allow or not allow the reverse running. The result after adding depends on the "Requirements for negative frequency (reverse running)."

#### Chapter 12 Description of Parameter Settings | CP2000

AVI1 Analog Input Gain	
ACI Analog Input Gain	
AVI2 Analog Positive Input Gain	
AVI2 Analog Negative Input Gain	
	Default: 100.0

Settings -500.0-500.0%

Use Pr.03-03–Pr.03-14 are used when the Frequency command source is the analog voltage or current signal.

AVI1 Analog Input Filter Time	
ACI Analog Input Filter Time	
✓ <a> <b>/</b></a>	

Settings 0.00-20.00 sec.

Analog signals, such as those entering AVI1, ACI and AVI2, are commonly affected by interference that affects the stability of the analog control. Use the Input Noise Filter to create a more stable system.

When the time constant setting is too large, the control is stable but the control response is slow. When the time constant setting is too small, the control response is be faster but the control may be unstable. For optimal setting, adjust the setting based on the control stability or the control response.

# ★ B - B Analog Input Addition Function

Default: 0

Default: 0.01

Settings 0: Disable (AVI1, ACI, AVI2) 1: Enable

When Pr.03-18 = 1:


Example 1: Pr.03-00 = Pr.03-01 = 1, Frequency command = AVI1 + ACI

Example 2: Pr.03-00 = Pr.03-01 = Pr.03-02 = 1, Frequency command = AVI1 + ACI + AVI2

Example 3: Pr.03-00 = Pr.03-02 = 1, Frequency command = AVI1 + AVI2

Example 4: Pr.03-01 = Pr.03-02 = 1, Frequency command = ACI + AVI2

When Pr.03-18 = 0 and the analog input selection settings (Pr.03-00, Pr.03-01 and Pr.03-02) are the same, AVI1 has priority over ACI and AVI2 (AVI1 > ACI > AVI2).



Fcmd=[(ay±bias)\*gain]\* Fmax(01-00) 10V or 16mA or 20mA Fcmd: the corresponding frequency of 10V or 20mA

ay: 0~10V, 4~20mA, 0~20mA bias: Pr.03-03, Pr. 03-04, Pr.03-05

gain: Pr.03-11, Pr.03-12, Pr.03-13, Pr.03-14

# Signal Loss Selection for the Analog Input 4–20 mA

Default: 0


Settings 0: Disable

1: Continue operation at the last frequency

2: Decelerate to 0 Hz

3: Stop immediately and display "ACE"

- Determines the treatment when the 4–20 mA signal is lost [AVIc (Pr.03-28 = 2) or ACIc (Pr.03-29 = 0)].
- When Pr.03-28 ≠ 2, the voltage input to AVI1 terminal is 0–10 V or 0–20 mA, and Pr.03-19 is invalid.
- When Pr.03-29  $\neq$  0, the voltage input to ACI terminal is 0–10 V, and the Pr.03-19 is invalid.
- When the setting is 1 or 2, the keypad displays the warning code "ANL". It keeps blinking until the ACI signal is recovered.
- When the setting is 3, and the ACI terminal is disconnected, the keypad displays "ACE" error. It keeps blinking until the connection is recovered and the error is reset.
- When the drive stops, the condition that causes the warning does not exist, so the warning automatically disappears.



Default: 0

Settings 0–23

#### **Function Chart**

Settings	Functions	Descriptions		
0	Output frequency (Hz)	Maximum frequency Pr.01-00 is processed as 100%.		
1	Frequency command (Hz)	Maximum frequency Pr.01-00 is processed as 100%.		
2	Motor speed (Hz)	Maximum frequency Pr.01-00 is processed as 100%		
3	Output current (rms) (2.5 × drive rated current) is processed as 100%		ent) is processed as 100%	
4	Output voltage	tput voltage (2 × motor rated voltage) is processed as 100%		
5	DC bus Voltage	450V (900V) = 100%		
6	Power factor	-1.000–1.000 = 100%		
7	Power	Drive rated power is processed as 100%		
9	AVI1 percentage	0–10 V / 0–20 mA / 4–20 mA = 0–100%		
10	ACI percentage	4–20 mA / 0–10 V / 0–20 mA = 0–100%		
11	AVI2 percentage	0–10 V = 0–100%		
		For CANopen communication analog output		
		Terminal	Corresponding address	
20	CANopen analog output	AFM1	2026-A1	
		AFM2	2026-A2	
		AO10	2026-AB	
		AO11	2026-AC	

Settings	Functions		Descriptions	
		For RS-485 (InnerCOM / Modbus) control analog output		
		Terminal	Corresponding address	
21	RS-485 analog output	AFM1	26A0H	
	3 1	AFM2	26A1H	
		AO10	26AAH	
		AO11	26ABH	
22	Communication card analog output	For communication an CMC-PN01, CMC-DN0 Terminal AFM1 AFM2 AO10 AO11	calog output (CMC-EIPO 01) Corresponding address 26A0H 26A1H 26AAH 26ABH	01,
23	Constant voltage output	0-100% of Pr.03-32 co	control the voltage out orresponds to 0–10 V o orresponds to 0–10 V o	f AFM1.

☐ 3 - 2 ☐ AFM1 Analog Output Gain

## AFM2 Analog Output Gain

Default: 100.0

Settings 0.0-500.0%

Adjusts the voltage level outputted to the analog meter from the analog signal (Pr.03-20) output terminal AFM of the drive.

★ ## AFM1 Analog Output REV Direction


★ ☐ 3 - 2 5 AFM2 Analog Output REV Direction

Default: 0

Settings 0: Absolute value in output voltage

1: Reverse output 0 V; forward output 0-10 V

2: Reverse output 5-0 V; forward output 5-10 V



Selections for the analog output direction

☐ - - - AFM2 Output Bias

Default: 0.00

Settings -100.00-100.00%

- Example 1, AFM2 0–10 V is set to the output frequency, the output equation is:  $10 \text{ V} \times (\text{output frequency} / \text{Pr.01-00}) \times \text{Pr.03-24} + 10 \text{ V} \times \text{Pr.03-27}$
- Example 2, AFM2 0–20 mA is set to the output frequency, the output equation is: 20 mA × (output frequency / Pr.01-00) × Pr.03-24 + 20 mA × Pr.03-27
- Example 3, AFM2 4–20 mA is set to the output frequency, the output equation is: 4 mA + 16 mA × (output frequency / Pr.01-00) × Pr.03-24 + 16 mA × Pr.03-27
- This parameter sets the corresponding voltage of the analog output 0.

# ✓ ☐ 3 - 2 ☐ AVI1 Terminal Input Selection

Default: 0

Settings 0: 0-10 V

1: 0-20 mA

2: 4-20 mA

# ★ 3 - 23 ACI Terminal Input Selection

Default: 0

Settings 0: 4-20 mA

1: 0-10 V

2: 0-20 mA


- When you change the input mode, verify that the external terminal switch (SW3, SW4) corresponds to the setting for Pr.03-28–Pr.03-29.
- When you change the setting, proportion to the corresponding ACI and ACI will change to default.

# PLC Analog Output Terminal Status

Default: Read only


Settings Monitor the status of the PLC analog output terminals

Pr.03-30 displays the external multi-function output terminal that used by PLC.



#### ☐ For Example:

When Pr.03-30 displays 0002h (hex), it means that AFM2 is used by PLC.



## Chapter 12 Description of Parameter Settings | CP2000

×	83-31	AFM2 Output Selection		
×	03-34	AFM1 Ou	tput Selection	
				Default: 0
		Settings	0: 0–20 mA output	
			1: 4-20 mA output	
×			Output Setting Level	
×	03-33	AFM2 DC	Output Setting Level	
				Default: 0.00
		Settings	0.00-100.00%	
	Pair wit	h multi-fun	ction output: 23, Pr.03-32 and Pr.03-33 outputs constar	nt AFM voltage.
	Set Pr.0	03-32 betw	een 0-100.00% to correspond to 0-10 V of AFM1.	
	Set Pr.0	03-33 betw	een 0-100.00% to correspond to 0-10 V of AFM2.	
N	00.00	VENTA EII	ter Output Time	
×	63-36	AFM2 Filt	ter Output Time	
				Default: 0.01
		Settings	0.00–20.00 sec.	
N	# - 44	Multi-func	ction MO Output by Al Level Source	
				Default: 0
		Settings	0: AVI1	
		Settings	0: AVI1 1: ACI	
			1: ACI 2: AVI2	
~	03-45		1: ACI 2: AVI2	
×	03-45		1: ACI 2: AVI2	Default: 50.00
N	03-45		1: ACI 2: AVI2	Default: 50.00
*	03-45	Al Upper Settings	1: ACI 2: AVI2 Level -100.00–100.00%	Default: 50.00
*		Al Upper Settings	1: ACI 2: AVI2 Level -100.00–100.00%	Default: 50.00  Default: 10.00
×		Al Upper Settings	1: ACI 2: AVI2 Level -100.00–100.00%	
*	03-48	Al Upper Settings Al Lower Settings	1: ACI 2: AVI2 Level -100.00–100.00% Level	Default: 10.00
N	<ul><li>○ 3 - 48</li><li>□ Use this</li></ul>	Al Upper  Settings  Al Lower  Settings  function (	1: ACI 2: AVI2 Level -100.00–100.00% Level -100.00–100.00%	Default: 10.00 og input level reached).
N	Use this	Al Upper  Settings  Al Lower  Settings  function (	1: ACI 2: AVI2 Level -100.00–100.00% Level -100.00–100.00% Pr.03-44) with the multi-function output setting 67 (anal	Default: 10.00 og input level reached).
N	Use this The MC the AI in	Al Upper  Settings  Al Lower  Settings  function (in active value) is active value.	1: ACI 2: AVI2  Level  -100.00-100.00%  Level  -100.00-100.00%  Pr.03-44) with the multi-function output setting 67 (analwhen the AI input level is higher than the Pr.03-45. The	Default: 10.00  og input level reached). e MO is disabled when
N N	Use this The MC the Al in When so	Al Upper  Settings Al Lower  Settings function (i) is active viput is lower etting level	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analwhen the AI input level is higher than the Pr.03-45. Ther than the Pr.03-46.  Is, Pr.03-45 AI upper level must be higher than Pr.03-46.	Default: 10.00  og input level reached). e MO is disabled when
<i>N</i>	Use this The MC the Al in When so	Al Upper  Settings Al Lower  Settings function (i) is active viput is lower etting level	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analywhen the AI input level is higher than the Pr.03-45. The trian the Pr.03-46.	Default: 10.00  og input level reached). e MO is disabled when Al lower level.
N N	Use this The MC the Al in When so	Al Upper  Settings  Al Lower  Settings  function (in active value) is active value active value.  Analog In	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analymen the AI input level is higher than the Pr.03-45. The transport than the Pr.03-46.  Is, Pr.03-45 AI upper level must be higher than Pr.03-46.  Is apput Curve Selection	Default: 10.00  og input level reached). e MO is disabled when
N	Use this The MC the Al in When so	Al Upper  Settings Al Lower  Settings function (i) is active viput is lower etting level	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analwhen the AI input level is higher than the Pr.03-45. The than the Pr.03-46.  Is, Pr.03-45 AI upper level must be higher than Pr.03-46.  Is put Curve Selection  0: Normal Curve	Default: 10.00  og input level reached). e MO is disabled when Al lower level.
N	Use this The MC the Al in When so	Al Upper  Settings  Al Lower  Settings  function (in active value) is active value active value.  Analog In	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analywhen the AI input level is higher than the Pr.03-45. The than the Pr.03-46.  Is, Pr.03-45 AI upper level must be higher than Pr.03-46.  Iput Curve Selection  0: Normal Curve 1: Three-point curve of AVI1	Default: 10.00  og input level reached). e MO is disabled when Al lower level.
N N	Use this The MC the Al in When so	Al Upper  Settings  Al Lower  Settings  function (in active value) is active value active value.  Analog In	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analymenthe Al input level is higher than the Pr.03-45. The than the Pr.03-46.  Is, Pr.03-45 Al upper level must be higher than Pr.03-46.  Is put Curve Selection  0: Normal Curve 1: Three-point curve of AVI1 2: Three-point curve of ACI	Default: 10.00  og input level reached). e MO is disabled when Al lower level.
N N	Use this The MC the Al in When so	Al Upper  Settings  Al Lower  Settings  function (in active value) is active value active value.  Analog In	1: ACI 2: AVI2  Level  -100.00–100.00%  Level  -100.00–100.00%  Pr.03-44) with the multi-function output setting 67 (analywhen the AI input level is higher than the Pr.03-45. The than the Pr.03-46.  Is, Pr.03-45 AI upper level must be higher than Pr.03-46.  Iput Curve Selection  0: Normal Curve 1: Three-point curve of AVI1	Default: 10.00  og input level reached). e MO is disabled when  Al lower level.

		J. Three-point curve of Avi Ta Aviz				
		6: Three-point curve of ACI & AVI2				
7: Three-point curve of AVI1 & ACI & AVI2						
Sets the	ne calculation method for analog input.					
When P	r.03-50 = 0, all analog input signal is calculated by bias and gain.					
When P	Pr.03-50 = 1, AVI1 calculates by frequency and voltage / current (Pr.03-51–Pr.03-56), other					
analog i	input signal calculates by bias and gain.					
	Pr.03-50 = 2, ACI calculates by frequency and voltage / current (Pr.03-57–Pr.03-62), other					
analog i	input signal calculates by bias and gain.					
	/hen Pr.03-50 = 3, AVI1 and ACI calculate by frequency and voltage / current					
(Pr.03-5	Pr.03-51–Pr.03-62), other analog input signal calculate by bias and gain.					
	When Pr.03-50 = 4, AVI2 calculates by frequency and voltage (Pr.03-63–Pr.03-68), other analog					
input sig	input signal calculates by bias and gain.					
When P	☐ When Pr.03-50 = 5, AVI1 and AVI2 calculate by frequency and voltage / current					
(Pr.03-5	1–Pr.03-50	6 and Pr.03-63–Pr.03-68), other analog input signal cal	culate by bias and gain.			
	When Pr.03-50 = 6, ACI and AVI2 calculate by frequency and voltage / current					
•		8), other analog input signal calculates by bias and gain				
		<ol> <li>all analog input signal calculate by frequency and voltage</li> </ol>	age / current (Pr.03-51–			
Pr.03-68	3).					
83-5 :	AVI1 Low	rest Point				
			Default:			
			0.00 / 0.00 / 4.00			
	Settings	Pr.03-28 = 0, 0.00–10.00 V				
		Pr.03-28 = 1, 0.00–20.00 mA				
		Pr.03-28 = 2, 0.00–20.00 mA				
03-52	AVI1 Prop	portional Lowest Point				
			Default: 0.00			
	Settings	-100.00–100.00%				
03-53	AVI1 Mid-	-Point				
			Default:			
			5.00 / 10.00 / 12.00			
	Settings	Pr.03-28 = 0, 0.00–10.00 V				
		Pr.03-28 = 1, 0.00–20.00 mA				
		Pr.03-28 = 2, 0.00–20.00 mA				
83-54	AVI1 Proportional Mid-Point					
			Default: 50.00			
	Settings	-100.00–100.00%				

5: Three-point curve of AVI 1& AVI2

## AVI1 Highest Point

Default:

10.00 / 20.00 / 20.00

Settings Pr.03-28 = 0, 0.00-10.00 VPr.03-28 = 1, 0.00-20.00 mA


Pr.03-28 = 2, 0.00-20.00 mA


R 3 - 5 AVI1 Proportional Highest Point


Default: 100.00


Settings -100.00-100.00%

- When Pr.03-28 = 0, the AVI1 setting is 0-10 V and the unit is in voltage (V). When Pr.03-28  $\neq$  0, the AVI1 setting is 0–20 mA or 4–20 mA and the unit is in current (mA).
- When you set the analog input AVI1 to frequency command, 100% corresponds to Fmax (Pr.01-00 Maximum Operation Frequency).
- ☐ The requirement for these there parameters (Pr.03-51, Pr.03-53 and Pr.03-55) is Pr.03-51 < Pr.03-53 < Pr.03-55. The values for three proportional points (Pr.03-52, Pr.03-54 and Pr.03-56) have no limits. Values between two points are calculated by a linear equation. The ACI and AVI2 are the same as AVI1.
- The output percentage is 0% when the AVI1 input value is lower than the lowest point setting. Example: Pr.03-51 = 1 V, Pr.03-52 = 10%. The output is 0% when AVI1 input is lower than 1 V. If the AVI1 input varies between 1 V and 1.1 V, the drive's output frequency is between 0% and 10%.












 $\begin{array}{l} Pr.03-51=1V\,;\, Pr.03-52=10\,\%\\ Pr.03-53=5V\,;\, Pr.03-54=50\,\%\\ Pr.03-55=10V\,;\, Pr.03-56=100\,\% \end{array}$ 


Pr.03-51=1V; Pr.03-52=10% Pr.03-53=5V; Pr.03-54=50% Pr.03-55=9V; Pr.03-56=100%







Pr.03-51=1V; Pr.03-52=0% Pr.03-53=5V; Pr.03-54=50% Pr.03-55=10V; Pr.03-56=100%



★ ## ACI Lowest Point

Default:

4.00 / 0.00 / 0.00

Settings Pr.03-29 = 0, 0.00–20.0 mA Pr.03-29 = 1, 0.00–10.00 V Pr.03-29 = 2, 0.00–20.00 mA

★ B 3 - 5 B ACI Proportional Low Point

Default: 0.00

Settings -100.00-100.00%

ACI Mid-Point

Default:

12.00 / 5.00 / 10.00

Settings Pr.03-29 = 0, 0.00–20.00 mA Pr.03-29 = 1, 0.00–10.00 V Pr.03-29 = 2, 0.00–20.00 mA

ACI Proportional Mid-Point

Default: 50.00

Settings -100.00-100.00%

Default:

20.00 / 10.00 / 20.00

Settings Pr.03-29 = 0, 0.00–20.00 mA Pr.03-29 = 1, 0.00–10.00 V Pr.03-29 = 2, 0.00–20.00 mA

ACI Proportional Highest Point

Default: 100.00

Settings -100.00-100.00%

When Pr.03-29 = 1, the ACI setting is 0–10 V and the unit is in voltage (V).

When Pr.03-29  $\neq$  1, the ACI setting is 0–20 mA or 4–20 mA and the unit is in current (mA).

When you set the analog input ACI to the Frequency command, 100% corresponds to Fmax (Pr.01-00 Maximum Operation Frequency).


### Chapter 12 Description of Parameter Settings | CP2000

			•	·	•	3-59 and Pr.03-61) is Pr.03-57 < (Pr.03-58, Pr.03-60 and Pr.03-62)
					tion between two points	
	m				•	s. lue is lower than the lowest point
	لعظ	setting.	tput perce	mage becomes 0 % v	viien tile ACI iliput va	ide is lower than the lowest point
		Exampl	۵.			
		•		Pr 03-58 = 10% then	the output becomes 0°	% when the AVI1 input is ≤ 2 mA. If
					·	utput frequency oscillates between
		0% and	•	g-		
×	Ü	<u> </u>	Positive A	VI2 Voltage Lowest F	oint	
						Default: 0.00
				0.00–10.00 V		
N		<u> 3-64</u>	Positive A	VI2 Voltage Proportio	nal Lowest Point	
						Default: 0.00
				-100.00–100.00%		
×	0	<u> 3-65</u>	Positive A	VI2 Voltage Mid-Poin	t	
						Default: 5.00
			Settings	0.00–10.00 V		
×	0	<u> 3-66</u>	Positive A	VI2 Voltage Proportio	nal Mid-Point	
						Default: 50.00
			Settings	-100.00–100.00%		
×	0	<u> 3 - 6 7</u>	Positive A	VI2 Voltage Highest F	oint	
						Default: 10.00
			Settings	0.00-10.00 V		
N	$\theta$	<u>3-68</u>	Positive A	VI2 Voltage Proportio	nal Highest Point	
						Default: 100.00
			Settings	-100.00–100.00%		
		When yo	ou set the	positive voltage AVI2	to the Frequency com	mand, 100% corresponds to Fmax
		(Pr.01-0	0 Maximur	n Operation Frequenc	cy) and the motor runs	in the forward direction.
		The req	uirement	or these three paran	neters (Pr.03-63, Pr.0	3-65 and Pr.03-67) is Pr.03-63 <
		Pr.03-65	5 < Pr.03-6	37. The values for thre	ee proportional points	(Pr.03-64, Pr.03-66 and Pr.03-68)
		have no	limits. The	re is a linear calculati	ion between two points	
		The out	put percen	tage becomes 0% wh	en the positive voltage	AVI2 input value is lower than the
		lowest p	oint setting	<b>j</b> .		
		For exa	mple:			
		If Pr.03-	63 = 1 V; F	Pr.03-64 = 10%, then	the output becomes 0%	% when the input is lower than 1 V.
		If the AV	/I input swi	ngs between 1 V and	1.1 V, the drive's outpu	it frequency oscillates between 0%
		and 10%	6.			

must be 0.00-10.00 or 0.00-20.00.

When AVI1 Selection (Pr.03-28) is 0–10 V, the setting ranges for Pr.03-51, Pr.03-53, and Pr.03-55

- When ACI Selection (Pr.03-29) is 0–10 V, the setting ranges for Pr.03-57, Pr.03-59 and Pr.03-61 must be 0.00–10.00 or 0.00–20.00.
- Use Pr.03-51–Pr.03-68 to set the open circuit corresponding function of analog input value and maximum operation frequency (Pr.01-00), as shown in the figure below:



### **04 Multi-Step Speed Parameters**

✓ This parameter can be set during operation.

			7.	 paramon	or oarr	DO COL GUII	ng opola	
N	84-88	1 <sup>st</sup> Step Speed Frequency						
N	84-81	2 <sup>nd</sup> Step Speed Frequency						
×	84-88	3 <sup>rd</sup> Step Speed Frequency						
×	04-03	4 <sup>th</sup> Step Speed Frequency						
×	84-84	5 <sup>th</sup> Step Speed Frequency						
×	84-85	6 <sup>th</sup> Step Speed Frequency						
N	89-88	7 <sup>th</sup> Step Speed Frequency						
×	84-87	8 <sup>th</sup> Step Speed Frequency						
×	80-20	9 <sup>th</sup> Step Speed Frequency						
×	84-89	10 <sup>th</sup> Step Speed Frequency						
×	84-18	11th Step Speed Frequency						
N	84-11	12 <sup>th</sup> Step Speed Frequency						
×	84 - 18	13 <sup>th</sup> Step Speed Frequency						
×	84-13	14 <sup>th</sup> Step Speed Frequency						
×	84-14	15 <sup>th</sup> Step Speed Frequency						
						Default:	0.00	

Settings 0.00-599.00 Hz

- Use the multi-function input terminals (refer to setting 1–4 of Pr.02-01–Pr.02-08 and Pr.02-26–Pr.02-31 Multi-function Input Command) to select the multi-step speed command (the maximum is 15<sup>th</sup> step speed). Pr.04-00 to Pr.04-14 set the multi-step speed frequency as shown in the following diagram.
- The external terminal/digital keypad/communication controls the RUN and STOP commands with Pr.00-21.
- You can set each multi-step speed between 0.00–599.00 Hz during operation.
- $\hfill \Box$  Explanation for the timing diagram of the multi-step speed and external terminals.

The related parameter settings are:

- 1. Pr.04-00–04-14: sets the 1st to 15th multi-step speed (to set the frequency of each step speed)
- 2. Pr.02-01–02-08 and Pr.02-26–02-31: sets the multi-function input terminals (multi-step speed command 1–4)
  - Related parameters:


Pr.01-22 JOG Frequency

Pr.02-01 Multi-function Input Command 1 (MI1)

Pr.02-02 Multi-function Input Command 2 (MI2)

Pr.02-03 Multi-function Input Command 3 (MI3)

Pr.02-04 Multi-function Input Command 4 (MI4)



Multi-speed via External Terminals

M	04-50	PLC Buffer 0	
M	84-51	PLC Buffer 1	
×	04-52	PLC Buffer 2	
×	04-53	PLC Buffer 3	
×	84-54	PLC Buffer 4	
×	04-55	PLC Buffer 5	
×	04-58	PLC Buffer 6	
×	04-57	PLC Buffer 7	
×	04-58	PLC Buffer 8	
		PLC Buffer 9	
×	04-80	PLC Buffer 10	
×		PLC Buffer 11	
×	88-88	PLC Buffer 12	
×	84-83	PLC Buffer 13	
×	84-84	PLC Buffer 14	
×	84-85	PLC Buffer 15	
×	88-28	PLC Buffer 16	
×	84-88	PLC Buffer 17	
×	83-20	PLC Buffer 18	
×	84-69	PLC Buffer 19	
			Default: 0

You can combine the PLC buffer with the built-in PLC function for a variety of applications.

Settings 0-65535

### Chapter 12 Description of Parameter Settings | CP2000

×	84-38	PLC Application Parameter 0
×	84-31	PLC Application Parameter 1
×	84-32	PLC Application Parameter 2
×	84-73	PLC Application Parameter 3
×	84-34	PLC Application Parameter 4
×	84-75	PLC Application Parameter 5
×	84-78	PLC Application Parameter 6
×	84-33	PLC Application Parameter 7
×	87-78	PLC Application Parameter 8
×	84-79	PLC Application Parameter 9
×	04-80	PLC Application Parameter 10
×	8-20	PLC Application Parameter 11
×	84-85	PLC Application Parameter 12
×	84-83	PLC Application Parameter 13
×	84-84	PLC Application Parameter 14
	84-85	PLC Application Parameter 15
	88-20	PLC Application Parameter 16
	84-87	PLC Application Parameter 17
		PLC Application Parameter 18
		PLC Application Parameter 19
		PLC Application Parameter 20
		PLC Application Parameter 21
		PLC Application Parameter 22
		PLC Application Parameter 23
		PLC Application Parameter 24
		PLC Application Parameter 25
		PLC Application Parameter 26
		PLC Application Parameter 27
		PLC Application Parameter 28
	04-99	PLC Application Parameter 29

Default: 0

### Settings 0-65535

Pr.04-70–Pr.04-99 are user-defined parameters. You can combine these 30 PLC Application Parameters with the PLC programming for a variety of applications.

### 05 Motor Parameters

✓ You can set this parameter during operation.

The following are abbreviations for different types of motors:

IM: Induction motor

- SPM: Surface permanent magnet synchronous AC motor
- PM: Permanent magnet synchronous AC motor
- SynRM: Synchronous reluctance motor
- IPM: Interior permanent magnet synchronous AC motor

## **## 5 - ## Motor Parameter Auto-Tuning**

Default: 0

Settings 0: No function

1: Simple rolling auto-tuning for induction motor(IM)

2: Static auto-tuning for induction motor

5: Rolling auto-tuning for PM (IPM / SPM)

11: SynRM parameter auto-tuning (applied to 230V / 460V models)

13: Static auto-tuning for PM (IPM / SPM)

Refer to Section 12-2 "Adjustment and Application" for more details of motor adjustment process.

## **G** 5 - **G** Full-load Current for Induction Motor 1 (A)

Default: Depending on

the model power

Settings Depending on the model power

- Sets this value according to the rated current of the motor as indicated on the motor nameplate.
- The default is 90% of the drive's rated current.

Example: The rated current for a 7.5 HP (5.5 kW) is 25 A. The default is 22.5 A.

The setting range is between 2.5–30 A.  $(25 \times 10\% = 2.5 \text{ A})$  and  $25 \times 120\% = 30 \text{ A}$ 

## ★ Rated Power for Induction Motor 1(kW)

Default: Depending on

the model power

Settings 0.00–655.35 kW

Sets the rated power for motor 1. The default is the drive's power value.

## 

Default: Depending on the motor's number of

poles

Settings 0–xxxx rpm (Depending on the motor's number of poles)

1710 (60 Hz 4 poles); 1410 (50 Hz 4 poles)

- Sets the rated speed for the motor as indicated on the motor nameplate.
- Pr.01-01 and Pr.05-04 determine the maximum rotor speed for IM.

For example: Pr.01-01 = 20 Hz, Pr.05-04 = 2, according to the equation  $120 \times 20 \text{ Hz} / 2 = 1200$ 

### **Chapter 12 Description of Parameter Settings | CP2000**

rpm and take integers. Due to the slip of the IM, the maximum setting value for Pr.05-03 is 1199 rpm (1200 rpm - 1).

R5-R4 Number of Poles for Induction Motor 1	
	Default: 4
Settings 2-64	
Sets the number poles for the motor (must be an even number).  Set up Pr.01-01 and Pr.05-03 before setting up Pr.05-04 to make normally. Pr.01-01 and Pr.05-03 determine the maximum set up number For example: Pr.01-01 = 20 Hz and Pr.05-03 = 39 rpm, according to the rpm = 61.5 and take even number, the number of poles is 60. Therefore the maximum of 60 poles.	r poles for the IM. equation 120 x 20 Hz / 39
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
Sottings 0.0 Dr.05 04 default	Default: Depending on the model power
Settings 0.0–Pr.05-01 default  The default is 10–40% of motor rated current.	
For model with 110 kW and above, default setting is 20% of motor rated	d current.
☐ 5 - ☐ 6 Stator Resistance (Rs) for Induction Motor 1	
	Default: Depending on the model power
Settings $0.000-65.535 \Omega$	
Rotor Resistance (Rr) for Induction Motor 1	
Settings $0.000-65.535 \Omega$	Default: 0.000
☐ 5 - ☐ ☐ Magnetizing Inductance (Lm) for Induction Motor 1	
Stator Inductance (Lx) for Induction Motor 1	
	Default: 0.0
Settings 0.0–6553.5 mH	
Full-load Current for Induction Motor 2 (A)	
	Default: Depending on the model power
Settings Depending on the model power	
Set this value according to the rated current of the motor as indicated The default is 90% of the drive's rated current.  Example: The rated current for a 7.5 HP (5.5 kW) motor is 25 A. The de The setting range is between 2.5–30 A. (25 × 10% = 2.5 A and 25 × 120)	fault is 22.5 A.

ng on
ng on
ng on
per of
perates
poratos
Hz / 39
e set to
ng on
ding on
ding on
•
•
•
•
•
•
•

115 - 22 Induction Motor 1 / 2 Selection

Default: 1

Settings 1: Motor 1

Sets the motor currently operated by the AC motor drive.

2: Motor 2

★ 35 - 23 Frequency for Y-connection / Δ-connection Switch for an Induction Motor

Default: 60.00

Settings 0.00-599.00 Hz

# Y-connection / Δ-connection Switch for Induction Motor

Default: 0

Settings 0: Disable


1: Enable

 $\checkmark$  35 - 25 Delay Time for Y-connection /  $\triangle$ -connection Switch for an Induction Motor

Default: 0.200

Settings 0.000-60.000 sec.


- You can apply Pr.05-23–Pr.05-25 in a wide range of motors, and the motor coil executes the Y-connection /  $\Delta$ -connection switch as required. The wide range motors are related to the motor design. In general, the motor has higher torque with low speed Y-connection, and has higher speed with high speed  $\Delta$ -connection).
- $\square$  Pr.05-24 enables and disables the switch of Y-connection /  $\triangle$ -connection.
- When you set Pr.05-24 as 1, the drive uses the Pr.05-23 setting and current motor frequency, and switches the current motor to Y-connection or Δ-connection. You can switch the relevant motor parameter settings simultaneously.
- $\square$  Pr.05-25 sets the switch delay time of Y-connection /  $\triangle$ -connection.
- When the output frequency reaches Y-connection / Δ-connection switch frequency, the drive delays according to Pr.05-25 before activating the multi-function output terminals.




Y-Δ connection switch: can be used for wide range motor

Y-connection for low speed: higher torque can be used for rigid tapping

Δ-connection for high speed: higher torque can be used for high-speed drilling





# RS-28 Accumulated Watt-hour for a Motor (W-hour)

Default: Read only

Settings 0.0-6553.5

Accumulated Watt-hour for a Motor in Low Word (kW-hour)

Default: Read only

Settings 0.0–6553.5

Default: Read only

Settings 0-65535

- Pr.05-28–05-30 record the amount of power consumed by the motors. The accumulation begins when the drive is activated and the record is saved when the drive stops or turns OFF. The amount of consumed watts continues to accumulate when the drive is activated again. To clear the accumulation, set Pr.00-02 as 5 to return the accumulation record to 0.
- The accumulated total watts of the motor per hour = Pr.05-30 x 1000000 + Pr.05-29 x 1000 + Pr.05-28 Wh

#### Chapter 12 Description of Parameter Settings | CP2000

Example: When Pr.05-30 = 76 MWh and Pr.05-29 = 150 kWh, Pr.05-28 = 400 Wh (or 0.4 kWh), the accumulated total kilowatts of the motor per hour =  $76 \times 1000000 + 150 \times 1000 + 40 = 76150400$ Wh = 76150.4 kWh

Accumulated Motor Operation Time (Minutes) Default: 0 Settings 0-1439 Accumulated Motor Operation Time (Days) Default: 0 Settings 0-65535 Use Pr.05-31 and Pr.05-32 to record the motor operation time. To clear the operation time, set Pr.05-31 and Pr.05-32 as 00. An operation time shorter than 60 seconds is not recorded. Induction Motor (IM) or Permanent Magnet Synchronous AC Motor Selection Default: 0 Settings 0: IM 1: SPM 2: IPM 3: SynRM (applied to 230V / 460V models) Full-load Current for a Permanent Magnet Synchronous AC Motor / Reluctance Motor Default: Depending on the model power

Settings Depending on the model power

Sets the full-load current for the motor according to motor's nameplate. The default is 90% of the drive's rated current.

For example: The rated current of a 7.5 HP (5.5 kW) is 25 A. The default is 22.5 A. The setting range is between 2.5-30 A.  $(25 \times 10\% = 2.5 \text{ A})$  and  $25 \times 120\% = 30 \text{ A})$ 

Rated Power for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: Depending on the motor power

Settings 0.00-655.35 kW

Sets the rated power for the permanent magnet synchronous motor. The default is the drive's power value.

Rated Speed for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: 2000

Settings 0-65535 rpm

☐ 5 - 3 7 Pole Number for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: 10

Settings 0-65535

RS - R System Inertia for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: Depending on

the motor power

Settings 0.0–6553.5 kg-cm<sup>2</sup>

Default values are as below:

Rated Power [kW]	0.4	0.75	1.5	2.2	3.7	5.5	7.5	9.3	11
Rotor Inertia [kg-cm <sup>2</sup> ]	1.2	3.0	6.6	15.8	25.7	49.6	82.0	121.6	177.0

Rated Power [kW]	14.1	18.2	27	33	40	46	54	54 and above
Rotor Inertia [kg-cm <sup>2</sup> ]	211.0	265.0	308.0	527.0	866.0	1082.0	1267.6	1515.0

# 5 - 3 Stator Resistance for a Permanent Magnet Synchronous AC Motor / Reluctance Motor

Default: 0.000

Settings  $0.000-65.535 \Omega$ 

Permanent Magnet Synchronous AC Motor / Reluctance Motor Ld

Default: 0.00

0.00-655.35 mH Settings

Permanent Magnet Synchronous AC Motor / Reluctance Motor Lq

Default: 0.00

Settings 0.00-655.35 mH

**#5 - 43** Ke parameter for a Permanent Magnet Synchronous AC Motor

Default: 0

Settings 0-65535 V/krpm

- Permanent magnet motor parameter Ke (V<sub>phase, rms</sub> / krpm).
- When Pr.05-00 = 5, parameter Ke is calculated according to the motor's actual operation.
- When Pr.05-00 = 13, parameter Ke is automatically calculated according to the motor power, current and rotor speed.

### **06 Protection Parameters**


✓ You can set this parameter during operation.

# ★ BB - BB Low Voltage Level

		Default:
Settings	230V models:	
	Frame A–D: 150.0–220.0 V <sub>DC</sub>	180.0
	Frame E and above: 190.0–220.0 $V_{\text{DC}}$	200.0
	460V models:	
	Frame A–D: 300.0–440.0 V <sub>DC</sub>	360.0
	Frame E and above: 380.0–440.0 $V_{\text{DC}}$	400.0
	575V models: 420.0–520.0 V <sub>DC</sub>	470.0
	690V models: 450.0–660.0 V <sub>DC</sub>	480.0

- Sets the Low Voltage (Lv) level. When the DC bus voltage is lower than Pr.06-00, a Lv fault is triggered, and the drive stops output and the motor coasts to stop.
- If the Lv fault is triggered during operation, the drive stops output and the motor coasts to stop. There are three Lv faults: LvA (Lv during acceleration), Lvd (Lv during deceleration), and Lvn (Lv in constant speed) that are triggered according to the status of acceleration or deceleration. You must press RESET to clear the Lv fault. The drive automatically restarts if you set to restart after momentary power loss (refer to Pr.07-06 Restart after Momentary Power Loss and Pr.07-07 Allowed Power Loss Duration for details).
- If the Lv fault is triggered when the drive is in STOP status, the drive displays LvS (Lv during stop), which is not recorded, and the drive restarts automatically when the input voltage is higher than Pr.06-00 + Lv return level (as listed below).

Lv Return Level	230V	460V	575V	690V
Frame A–D	30 V <sub>DC</sub>	60 V <sub>DC</sub>	100 V <sub>DC</sub>	100 V <sub>DC</sub>
Frame E-H	40 V <sub>DC</sub>	80 V <sub>DC</sub>	N/A	120 V <sub>DC</sub>



# 

		Default:
Settings	0: Disabled	
	230V models: 0.0-450.0 V <sub>DC</sub>	380.0
	460V models: 0.0-900.0 V <sub>DC</sub>	760.0
	575V models: 0.0-1116.0 V <sub>DC</sub>	920.0
	690V models: 0.0-1318.0 V <sub>DC</sub>	1087.0

Dafault.

- Setting Pr.06-01 to 0.0 disables the over-voltage stall prevention function (connected with braking unit or brake resistor). Use this setting when braking units or brake resistors are connected to the drive.
- Setting Pr.06-01 to a value > 0.0 enables the over-voltage stall prevention. This setting refers to the power supply system and loading. If the setting is too low, then over-voltage stall prevention is easily activated, which may increase the deceleration time.
- Related parameters:
  - Pr.01-13, Pr.01-15, Pr.01-17, Pr.01-19 Deceleration Time 1–4
  - Pr.02-13–Pr.02-15 Multiple-function Output (Relay1–3)
  - Pr.06-02 Selection for Over-voltage Stall Prevention.

## ★ \$\frac{1}{25} - \frac{1}{2}\$ Selection for Stall Prevention

Default: 0

Settings 0: Traditional over-voltage and traditional over-current stall prevention

1: Smart over-voltage and traditional over-current stall prevention

2: Traditional over-voltage and smart over-current stall prevention

3: Smart over-voltage and smart over-current stall prevention

A comparison between traditional stall prevention and smart stall prevention:

Tuno	0	ver-voltage		Over-current			
Туре	Description	Action	Parameter	Description	Action	Parameter	
Traditiona	Frequency maintains during	Deceleration stops	Pr.06-01	Frequency maintains during acceleration	Acceleration stops	Pr.06-03	
Traditiona	deceleration		P1.06-01	Frequency decreases at constant speed	Frequency gradually decreases	Pr.06-04	
Smart	Frequency increases during acceleration /	Frequency gradually	Pr.06-01	Frequency decreases during acceleration / deceleration	Frequency gradually decreases	Pr.06-03	
	deceleration / constant speed	increases		Frequency decreases at constant speed	Frequency gradually decreases	Pr.06-04	

- Pr.06-02 (Selection for stall prevention) can be used with Pr.01-49 (Regenerative energy restriction control method), but Pr.06-02 cannot work with Pr.01-44 (Auto-acceleration and auto-deceleration setting).
- When Pr.06-02 or Pr.01-49 is enabled (setting value > 0), Pr.01-44 (Auto-acceleration and auto-deceleration setting) automatically disables (setting value = 0) and cannot be set; when Pr.01-44 is enabled (setting value > 0), Pr.06-02 and Pr.01-49 automatically disable and cannot be set.
- If you use smart over-voltage or smart over-current stall prevention for industries that require fast response, you can decrease the deceleration time when needed.
- When using smart over-voltage stall prevention, the drive decelerates to stop with the fastest deceleration time according to different working condition, rather than the first to fourth deceleration time (Pr.01-13–01-19).


#### Chapter 12 Description of Parameter Settings | CP2000

- For 220V / 440V 160 kW models and above, the default for Pr.06-02 is automatically set to 1 (Smart over-voltage and traditional over-current stall prevention). If you need to set the deceleration time with Pr.01-13–01-19, set Pr.06-02 = 0.
- Related parameters:

Pr.06-01 Over-voltage stall prevention, Pr.06-03 Over-current stall prevention during acceleration, Pr.06-04 Over-current stall prevention during operation, Pr.06-05 Acceleration / deceleration time selection for stall prevention at constant speed, Pr.01-12-01-19 Acceleration / Deceleration time 1-4, and Pr.02-13-02-15 Multi-function output (Relay 1-3).


#### Traditional over-voltage stall prevention

- Used for uncertain load inertia. When it stops under normal load, the over-voltage does not occur during deceleration and fulfills the deceleration time setting. However, load regenerative inertia may occasionally increase and does not trip due to over-voltage when decelerating to stop. In this case, the drive automatically increases the deceleration time until it stops.
- Because of the motor load inertia, the motor may exceed the synchronous speed when the drive decelerates; in this case, the motor becomes generator. If the motor load inertia is larger, or the setting for drive's decelerating time is too small, the motor regenerates energy to the drive, and makes the DC bus voltage increase to the maximum allowable value. Thus, when traditional over-voltage stall prevention is enabled, the drive does not decelerate further and maintains the output frequency until the voltage drops below the setting value again.
- When the over-voltage stall prevention is enabled, the drive deceleration time is larger than the setting time.
- When there is a problem with the deceleration time, this function is disabled. See below for solution:
  - 1. Increase the deceleration time properly.
  - 2. Install a brake resistor (refer to Section 7-1 Brake Resistors and Brake Units Selection Chart for details) to dissipate the heat, that is, the electrical energy regenerating from the motor.



#### Smart over-voltage stall prevention

Adopts closed-loop control and takes the setting for Pr.06-01 over-voltage stall prevention as target command during acceleration, deceleration and constant speed. When the DC bus voltage is higher than the stall prevention level, the controller increases the output frequency gradually according to closed-loop response until the DC bus voltage drops below the stall prevention level, and returns to target frequency based on the previous setting for deceleration time when the DC bus voltage is lower than the stall prevention level. If the DC bus voltage is still higher than the stall prevention level during the adjustment, the output frequency increases to the maximum operation frequency (Pr.01-00).




#### Traditional over-current stall prevention

- When the output current exceeds the over-current stall prevention level (Pr.06-03) during acceleration, the output frequency stops accelerating. The output frequency continues to accelerate when the output current drops below the stall prevention level to protect the drive.
- When the output current exceeds the over-current stall prevention during operation (Pr.06-04), the output frequency decreases according to the setting for acceleration / deceleration time selection for over-current stall prevention at constant speed (Pr.06-05). When the output current drops below the stall prevention level, the output frequency accelerates to the target frequency according to its previous set acceleration time.

#### **Smart over-current stall prevention**

Adopts closed-loop control. It takes the setting for Pr.06-03 over-current stall prevention during acceleration as target command during acceleration and deceleration, and takes Pr.06-04 over-current stall prevention during operation as target command at constant speed. When the output current exceeds the stall prevention level, the controller decreases the output frequency gradually according to the closed-loop response until the current drops below the stall prevention level, and returns to target frequency based on the previous setting when the current is lower than the stall prevention level. If the output current is still higher than the stall prevention level during the adjustment, the output frequency decreases to the minimum output frequency at 0.5 Hz.



# ✓ ☐ ☐ ☐ ☐ ☐ Over-current Stall Prevention during Acceleration

Default: 120

Settings 230V / 460V models

Light duty: 0–130% (100%: drive's rated current)


Normal duty: 0–160% (100%: drive's rated current)

575V / 690V models


Light duty: 0–125% (100%: drive's rated current)

Normal duty: 0–150% (100%: drive's rated current)

- ☐ This parameter only works in VF and SVC control modes.
- If the motor load is too large or the drive's acceleration time is too short, the output current of the drive may be too high during acceleration, and it may cause motor damage or trigger the drive's protection functions (oL or oc). Use this parameter to prevent these situations.
- During acceleration, the output current of the drive may increase abruptly and exceed the setting value of Pr.06-03. In this case, the drive stops accelerating and keeps the output frequency constant, and then continues to accelerate until the output current decreases.



Refer to Pr.06-16 for more details of stall level in flux weakening region. The protection curve is as following:



- When you enable the over-current stall prevention, the drive's acceleration time is longer than the setting.
- When the over-current stall prevention occurs because the motor capacity is too small or operates in the default, decrease the Pr.06-03 setting value.
- If you encounter any problem with the acceleration time, refer to the following guides for troubleshooting:
  - 1. Increase the acceleration time to a proper value.
  - 2. Setting Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting to 1, 3 or 4 (auto-acceleration).
- Related parameters:
  - Pr.01-12, Pr.01-14, Pr.01-16, Pr.01-18 Acceleration Time 1–4
  - Pr.01-44 Auto-Acceleration and Auto-Deceleration Setting
  - Pr.02-13-02-15 Multi-function Output Relay1-3.

## ✓ 日子 Over-current Stall Prevention during Operation

Default: 120

Settings 230V / 460V models


Light duty: 0-130% (100%: drive's rated current)

Normal duty: 0–160% (100%: drive's rated current)

575V / 690V models

Light duty: 0–125% (100%: drive's rated current)
Normal duty: 0–150% (100%: drive's rated current)

- This parameter only works in VF and SVC control modes.
- This is a protection for the drive to decrease output frequency automatically when the motor over-loads abruptly during constant motor operation.
- If the output current exceeds the setting value for Pr.06-04 when the drive is operating, the drive decelerates according to the Pr.06-05 setting to prevent the motor from stalling. The lower limit for the over-current stall prevention is determined by the maximum value among 0.5 Hz, Pr.01-07 and Pr.01-11.
- If the output current is lower than the setting value for Pr.06-04, the drive accelerates (according to Pr.06-05) again to the setting frequency.



Over-current stall prevention during operation

## Acceleration / Deceleration Time Selection for Stall Prevention at Constant Speed

Default: 0

Settings 0: By current acceleration / deceleration time

1: By the first acceleration / deceleration time

2: By the second acceleration / deceleration time

3: By the third acceleration / deceleration time

4: By the fourth acceleration / deceleration time

5: By auto-acceleration / auto-deceleration

Sets the acceleration / deceleration time selection when stall prevention occurs at constant speed.

## ✓ ☐ ☐ ☐ ☐ ☐ Over-torque Detection Selection (OT1)

Default: 0

Settings 0: No function

1: Continue operation after over-torque detection during constant speed operation

2: Stop after over-torque detection during constant speed operation

3: Continue operation after over-torque detection during RUN

4: Stop after over-torque detection during RUN

## ✓ ☐ ☐ ☐ ☐ ☐ ☐ Over-torque Detection Selection (OT2)

Default: 0

Settings 0: No function

1: Continue operation after over-torque detection during constant speed operation

2: Stop after over-torque detection during constant speed operation

3: Continue operation after over-torque detection during RUN

4: Stop after over-torque detection during RUN

- When you set Pr.06-06 and Pr.06-09 to 1 or 3, a warning message displays, but there is no error record.
- When you set Pr.06-06 and Pr.06-09 to 2 or 4, an error message displays and there is an error record.

Default: 120

Settings 10–200% (100% corresponds to the light-duty rated current of the drive)

✓ ☐ 6 - ☐ 6 Over-torque Detection Level (OT1)

Default: 0.1

Settings 0.0-60.0 sec.

✓ ☐ ☐ - ☐ Over-torque Detection Level (OT2)


Default: 120

Settings 10–200% (100% corresponds to the light-duty rated current of the drive)


Default: 0.1


Settings 0.0-60.0 sec.

- When the output current exceeds the over-torque detection level (Pr.06-07 or Pr.06-10) and exceeds the over-torque detection time (Pr.06-08 or Pr.06-11), the over-torque detection follows the setting of Pr.06-06 and Pr.06-09.
- When you set Pr.06-06 or Pr.06-09 to 1 or 3, an ot1 / ot2 warning displays while the drive keeps running after over-torque detection. The warning remains on until the output current is smaller than 5% of the over-torque detection level.




When you set Pr.06-06 or Pr.06-09 to 2 or 4, an ot1 / ot2 warning displays and the drive stops running after over-torque detection. The drive does not run until you manually reset it.






the operation time to prevent motor from overheating.

characteristic curve of electronic thermal relay, the output frequency and current of the drive, and





Default: 105.0

Motor cooling curve with independent fan

- The action of electronic thermal relay depends on the setting for Pr.06-13 and Pr.06-27.
  - 1. Pr.06-13 or Pr.06-27 is set to 0 (using inverter motor):


When the output current of motor drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with independent fan), motor drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or 06-28.

2. Pr.06-13 or Pr.06-27 is set to 1 (using standard motor):

When the output current of the drive is higher than 150% of the motor rated current (refer to the motor rated current % corresponded to the motor rated frequency in the motor cooling curve with shaft-fixed fan), the drive starts to count the time. The electronic thermal relay acts when the accumulated time exceeds Pr.06-14 or 06-28

- 3. If the motor's rated current (Pr.05-01) is not set, set 90% of the drive's rated current (Pr.00-01) as the default for this parameter.
- 🕮 The actual electronic thermal relay action time adjusts according to the drive output current (shown as the motor loading rate %). The action time is short when the current is high, and the action time is long when the current is low. Refer to following diagram: (The motor cooling curve with shaft-fixed fan and motor cooling curve with independent fan F = 50 Hz are the same one.)

Operation time





Temperature Level Overheat (oH) Warning

Settings 0.0-110.0°C

🕮 If Pr.06-15 is set to 110°C, when the temperature reaches 110°C, the drive stops with an IGBT overheat fault.

For Frame C and above, when IGBT temperature is above Pr.06-15 minus 15°C, the cooling fan enhances performance to 100%; however, when IGBT temperature is below 35°C of Pr.06-15 and the temperature of capacitance is below 10°C of oH2 over-heat warning (Pr.06-51), the cooling fan resets. The temperature 35°C is the criterion if Pr.06-15 is set below to 35°C.

★ 35 - 15 Stall Prevention Limit Level (Weak Magnetic Area Current Stall Prevention Level)

Settings 0–100% (Refer to Pr.06-03)

Sets the over-current stall prevention level when the motor's operation frequency is larger than Pr.01-01 (base frequency). This parameter only works during acceleration.

Default: 50

- Example: Pr.06-03 = 150%, Pr.06-04 = 100% and Pr.06-16 = 80%, when the operation frequency is larger than Pr.01-01, the lowest over-current stall prevention level during acceleration is:
  - $Pr.06-03 \times Pr.06-16 = 150 \times 80\% = 120\%$ . (Refer to Pr.06-03 diagram for the protection curve)
- Pr.06-16 is invalid when the over-current stall prevention activates according to Pr.06-04 at constant speed.

	Fault Record 1
	Fault Record 2
	Fault Record 3
	Fault Record 4
	Fault Record 5
85-88	Fault Record 6

#### Settings

- 0: No fault record
- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during steady speed (ocn)
- 4: Ground fault (GFF)
- 5: IGBT short-circuit between upper bridge and lower bridge (occ)
- 6: Over-current at stop (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage at constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)
- 13: Low-voltage at constant speed (Lvn)
- 14: Low-voltage at stop (LvS)
- 15: Phase loss protection (OrP)
- 16: IGBT overheating (oH1)
- 17: Heatsink overheating (oH2)
- 18: IGBT temperature detection failure (tH1o)

- 19: Capacitor hardware error (tH2o)
- 21: Over load (oL)
- 22: Electronic thermal relay 1 protection (EoL1)
- 23: Electronic thermal relay 2 protection (EoL2)
- 24: Motor overheating (oH3) (PTC / PT100)
- 26: Over torque 1 (ot1)
- 27: Over torque 2 (ot2)
- 28: Under current (uC)
- 30: EEPROM write error (cF1)
- 31: EEPROM read error (cF2)
- 33: U-phase error (cd1)
- 34: V-phase error (cd2)
- 35: W-phase error (cd3)
- 36: cc (current clamp) hardware error (Hd0)
- 37: oc (over-current) hardware error (Hd1)
- 38: ov (over-voltage) hardware error (Hd2)
- 39: occ hardware error (Hd3)
- 40: Auto-tuning error (AUE)
- 41: PID loss ACI (AFE)
- 48: ACI loss (ACE)
- 49: External fault (EF)
- 50: Emergency stop (EF1)
- 51: External base block (bb)
- 52: Enter wrong password three times and locked (Pcod)
- 53: Firmware version error (ccod)
- 54: Illegal command (CE1)
- 55: Illegal data address (CE2)
- 56: Illegal data value (CE3)
- 57: Data is written to read-only address (CE4)
- 58: Modbus transmission time-out (CE10)
- 60: Brake transistor error (bF)
- 61: Y-connection /  $\Delta$ -connection switch error (ydc)
- 62: Deceleration energy backup error (dEb)
- 63: Over slip error (oSL)
- 64: Electric valve switch error (ryF)
- 68: Reverse direction of the speed feedback (SdRv)
- 69: Over speed rotation feedback (SdOr)
- 70: Large deviation of speed feedback (SdDe)
- 71: Watchdog (WDTT)
- 72: STO loss 1 (STL1)
- 73: Emergency stop for external safety (S1)
- 74: FIRE mode output (Fire)

76: Safety Torque Off (STO) 77: STO loss 2 (STL2) 78: STO loss 3 (STL3) 82: Output phase loss U phase (OPHL) 83: Output phase loss V phase (OPHL) 84: Output phase loss W phase (OPHL) 89: Rotor position detection error (RoPd) 90: Forced to stop (FStp) 101: CANopen guarding error (CGdE) 102: CANopen heartbeat error (CHbE) 104: CANopen bus off error (CbFE) 105: CANopen index error (CidE) 106: CANopen station address error (CAdE) 107: CANopen memory error (CFrE) 111: InrCOM time-out error (ictE) 142: Auto-tuning error 1 (no feedback current error) (AUE1) 143: Auto-tuning error 2 (motor phase loss error) (AUE2) 144: Auto-tuning error 3 (no-load current I<sub>0</sub> measuring error) (AUE3) 148: Auto-tuning error (leakage inductance Lsigma measuring error) (AUE4) The parameters record when the fault occurs and forces a stop. When low-voltage at stop fault (LvS) occurs, the fault is not recorded. When low-voltage during operation faults (LvA, Lvd, Lvn) occur, the faults are recorded. When dEb function is valid and enabled, the drive executes dEb and records fault code 62 to Pr.06-17-Pr.06-22 simultaneously. ✓ ☐ Fault Output Option 1

Fault Output Option 1

Fault Output Option 2

Fault Output Option 3

Fault Output Option 4

Default: 0

### Settings 0–65535 (Refer to bit table for fault code)

Use these parameters with multi-function output terminal (set Pr.06-23–Pr.06-26 to 35–38) for the specific requirement. When the fault occurs, the corresponding terminals are activated. Convert the binary value to decimal value before you enter the value for Pr.06-23–Pr.06-26).

Fault Code		bit1	bit2	bit3	bit4	bit5	bit6
		Volt.	OL	SYS	FBK	EXI	CE
0: No fault							
1: Over-current during acceleration (ocA)	•						
2: Over-current during deceleration (ocd)	•						
3: Over-current during steady speed (ocn)	•						
4: Ground fault (GFF)	•						

Fault Code	bit0	bit1	bit2	bit3	bit4	bit5	bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
5: IGBT short-circuit between upper bridge and	•						
lower bridge (occ)							
6: Over-current at stop (ocS)	•						
7: Over-voltage during acceleration (ovA)		•					
8: Over-voltage during deceleration (ovd)		•					
9: Over-voltage at constant speed (ovn)		•					
10: Over-voltage at stop (ovS)		•					
11: Low-voltage during acceleration (LvA)		•					
12: Low-voltage during deceleration (Lvd)		•					
13: Low-voltage at constant speed (Lvn)		•					
14: Low-voltage at stop (LvS )		•					
15: Phase loss protection (OrP)		•					
16: IGBT overheating (oH1)			•				
17: Heatsink overheating (oH2)			•				
18: IGBT temperature detection failure (tH1o)			•				
19: Capacitor hardware error (tH2o)			•				
21: Over load (oL)			•				
22: Electronic thermal relay 1 protection (EoL1)			•				
23: Electronic thermal relay 2 protection (EoL2)			•				
24: Motor overheating (oH3) (PTC / PT100)			•				
26: Over torque 1 (ot1)			•				
27: Over torque 2 (ot2)			•				
28: Under current (uC)	•						
30: EEPROM write error (cF1)				•			
31: EEPROM read error (cF2)				•			
33: U-phase error (cd1)				•			
34: V-phase error (cd2)				•			
35: W-phase error (cd3)				•			
36: cc (current clamp) hardware error (Hd0)				•			
37: oc (over-current) hardware error (Hd1)				•			
38: ov (over-voltage) hardware error (Hd2)				•			
39: occ hardware error (Hd3)				•			
40: Auto-tuning error (AUE)				•			
41: PID loss ACI (AFE)					•		
48: ACI loss (ACE)					•		
49: External fault (EF)						•	
50: Emergency stop (EF1)						•	
51: External base block (bb)						•	
52: Enter wrong password three times and							
locked (Pcod)				•			
53: Firmware version error (ccod)				_			
Jos. I IIIIWale version end (CCOU)				•	<u> </u>		

Foult Codo	bit0	bit1	bit2	bit3	bit4	bit5	bit6
Fault Code		Volt.	OL	SYS	FBK	EXI	CE
54: Illegal command (CE1)							•
55: Illegal data address (CE2)							•
56: Illegal data value (CE3)							•
57: Data is written to read-only address (CE4)							•
58: Modbus transmission time-out (CE10)							•
60: Brake transistor error (bF)						•	
61: Y-connection/∆-connection switch error (ydc)						•	
62: Deceleration energy backup error (dEb)		•					
63: Over slip error (oSL)						•	
64: Electric valve switch error (ryF)						•	
68: Reverse direction of the speed feedback							
(SdRv)					•		
69: Over speed rotation feedback (SdOr)					•		
70: Large deviation of speed feedback (SdDe)					•		
71: Watchdog (WDTT)				•			
72: STO loss 1 (STL1)				•			
73: Emergency stop for external safety (S1)				•			
74: FIRE mode output (Fire)						•	
76: Safety Torque Off (STO)				•			
77: STO loss 2 (STL2)				•			
78: STO loss 3 (STL3)				•			
82: Output phase loss U phase (OPHL)	•						
83: Output phase loss V phase (OPHL)	•						
84: Output phase loss W phase (OPHL)	•						
89: Rotor position detection error (RoPd)				•			
90: Forced to stop (FStp)				•			
101: CANopen guarding error (CGdE)							•
102: CANopen heartbeat error (CHbE)							•
104: CANopen bus off error (CbFE)							•
105: CANopen index error (CldE)							•
106: CANopen station address error (CAdE)							•
107: CANopen memory error (CFrE)							•
111: InrCOM time-out error (ictE)							•
142: Auto-tuning error 1 (no feedback current							
error) (AUE1)	•						
143: Auto-tuning error 2 (motor phase loss error)		· · · · · · · · · · · · · · · · · · ·	· · · · · ·	_	· · · · · ·		
(AUE2)				•			
144: Auto-tuning error 3 (no-load current I <sub>0</sub>							
measuring error) (AUE3)	•						
148: Auto-tuning error 4 (leakage inductance							
Lsigma measuring error) (AUE4)							

N	08-29	PTC Dete	ection Selection / PT100 Motion	
				Default: 0
		Settings	0: Warn and continue operation	
			1: Fault and ramp to stop	
			2: Fault and coast to stop	
			3: No warning	
	Sets the	operation	mode of a drive after detecting PTC / PT100 / KTY84 d	etection.
×	06-30	PTC Leve	el	
				Default: 50.0
		Settings	0.0–100.0%	
	Sets AV	11 / ACI / A	VI2 analog input function Pr.03-00–03-02 to 6 [Thermist	or (PTC) input value].
	Use this	to set the	e PTC level, the corresponding value for 100% is the	analog input maximum
	value.			
	88-31	Frequenc	y Command at Malfunction	
				Default: Read only
		Settings	0.00–599.00 Hz	
	☐ When a	malfuncti	ion occurs, check the current frequency command.	If it happens again, it
	overwrit	es the prev	vious record.	
	08-32	Output Er	equency at Malfunction	
	טט שנ	Output i i	equency at Manufiction	Default: Read only
		Settings	0.00–599.00 Hz	Delault. Read Only
	₩ When a		on occurs, check the current output frequency. If it happe	ens again it overwrites
		ious record		ono agam, n overwines
	00-33	Output vo	oltage at Malfunction	Defectity Dead and
		Cottings	0.0 6552.5.V	Default: Read only
	∭ When e		0.0–6553.5 V on occurs, check the current output voltage. If it happens	again it avaruritas tha
	previous		in occurs, check the current output voltage. If it happens	again, it overwrites the
	<i>86-3</i> 4	DC bus V	oltage at Malfunction	
				Default: Read only
	~~		0.0–6553.5 V	
			on occurs, check the current DC bus voltage. If it happe	ens again, it overwrites
	the prev	ious record	d.	
	88-35	Output Cu	urrent at Malfunction	
				Default: Read only
		Settings	0.0–6553.5 Amp	
	When a	malfunctio	n occurs, check the current output current. If it happens	again, it overwrites the

previous record.

66-96	IGBT Temperature at Malfunction	
		Default: Read only
	Settings -3276.7-3276.7°C	
When a	a malfunction occurs, check the current IGBT temperature. If	it happens again, it
overwrit	es the previous record.	
06 22	O '' T ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	
00-3 i	Capacitance Temperature at Malfunction	
		Default: Read only
	Settings -3276.7-3276.7°C	
	malfunction occurs, check the current capacitance temperature.	If it happens again, it
overwrit	es the previous record.	
00.00	Motor Speed in rpm at Malfunction	
00 10	Motor opecu in thin at Manufetton	Default: Read only
	Cattings 22767 22767 rpm	Delault. Nead Only
<b>○</b> \ <b>\ \ \ \ \ \ \ \ \ </b>	Settings -32767–32767 rpm	£ (4 )
	a malfunction occurs, check the current motor speed in rpm. I	t it nappens again, it
overwrit	es the previous record.	
88-48	Status of Multi-function Input Terminal at Malfunction	
	· ·	Default: Read only
	Settings 0000h-FFFFh	,
06-41	Status of Multi-function Output Terminal at Malfunction	
	Status of Manufaction Surpar Forminal at Manufaction	Default: Read only
	Settings 0000h–FFFFh	Deladit. Nead only
M Whon o	malfunction occurs, check the current status of multi-function input	t / output torminals. If it
	•	t / Output terminais. If it
nappens	s again, it overwrites the previous record.	
88-42	Drive Status at Malfunction	
		Default: Read only
	Settings 0000h-FFFFh	•
	malfunction occurs, check the current drive status (communicatio	n address 2101H). If it
	s again, it overwrites the previous record.	,
	·	
86-44	STO Latch Selection	
		Default: 0
	Settings 0: STO Latch	
	1: STO No latch	
Pr.06-44	4 = 0: STO Alarm Latch. After you clear the cause of the STO	) Alarm, use a Reset
commar	nd to clear the STO Alarm.	
Pr.06-44	4 = 1: STO Alarm no Latch. After you clear the cause of the STO	Alarm, the STO Alarm
	utomatically.	
	ΓL1–STL3 errors are "Alarm Latch" mode (in STL1–STL3 mode, t	he Pr.06-44 function is

not available).

Output Phase Loss Detection Action (OPHL)

Default: 3

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: No warning

The OPHL protection is enabled when Pr.06-45 is not set to 3.

Detection Time of Output Phase Loss

Default: 0.500

Settings 0.000–65.535 sec.

Current Detection Level for Output Phase Loss

Default: 1.00

Settings 0.00-100.00%


DC Brake Time of Output Phase Loss

Default: 0.000


Settings 0.000-65.535 sec.

- There are two situations for the output phase loss detection: "detect when the drive is in operation" and "detect before operation". Setting Pr.06-48 to 0 disables the OPHL detection function before operation.
- The status of output phase loss detection are as following:
  - Status 1: The drive is in operation

When any phase is less than the Pr.06-47 setting, and exceeds Pr.06-46 setting time, the drive executes according to the Pr.06-45 setting.




Status 2: The drive is in STOP; Pr.06-48 = 0; Pr.07-02 ≠ 0
After the drive starts, the DC brake operates according to Pr.07-01 and Pr.07-02. During this period, OPHL detection is not active. After the DC brake action is completed, the drive starts to run, and enables the OPHL protection as mentioned above for status 1.




Status 3: The drive is in STOP; Pr.06-48≠0; Pr.07-02≠0
When the drive starts, it executes Pr.06-48 first, and then executes Pr.07-02 (DC brake).
The DC brake current level in this state includes two parts: one is 20 times the Pr.06-47 setting value in Pr.06-48 setting time; the other is the Pr.07-02 setting value in Pr.07-01 setting time. The total DC brake time is T = Pr.06-48 + Pr.07-02.

Status 3-1: Pr.06-48  $\neq$  0, Pr.07-02  $\neq$  0 (No OPHL detected before operation)





Status 3-2: Pr.06-48  $\neq$  0, Pr.07-20  $\neq$  0 (OPHL detected before operation)

In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.




Status 4: The drive is in STOP; Pr.06-48 ≠ 0; Pr.07-02 = 0
 When the drive starts, it executes Pr.06-48 as the DC brake. The DC brake current level is 20 times the Pr.06-47 setting value.





Status 4-2: Pr.06-48 ≠ 0, Pr.07-02 = 0 (OPHL detected before operation)

In this period, if an OPHL occurs within the time for Pr.06-48, the drive executes the Pr.06-45 setting after the drive starts counting for half the time of Pr.06-48.



✓ ☐ ☐ - Ч ☐ LvX Auto-Reset

Default: 0

Settings 0: Disable

1: Enable

Default: 0.20

Settings 0.00-600.00 sec.

Sets the time for input phase loss detection; setting 0.20 seconds means to check every 0.20 sec.

Default:

30.0/60.0/75.0/90.0

Settings 230V models: 0.0–100.0 V<sub>DC</sub>

460V models:  $0.0-200.0\ V_{DC}$ 575V models:  $0.0-400.0\ V_{DC}$ 690V models:  $0.0-480.0\ V_{DC}$ 

- When the drive detects the DC bus ripple is higher than the setting for Pr.06-52, and lasts for the time of Pr.06-50 plus 30 seconds, the drive executes the input phase loss protection according to Pr.06-53.
- In the period of Pr.06-50 setting plus 30 seconds, if the DC bus ripple is lower than the setting for Pr.06-52, the OrP protection recalculates.

## ✓ ☐ 6 - 5 3 Input Phase Loss Detection Action (OrP)

Default: 0

Settings 0: Fault and ramp to stop

1: Fault and coast to stop

- When the DC bus ripple voltage lasts for Pr.06-50 ripple time, the drive activates the Input Phase Loss protection according to the Pr.06-53 settings:
  - DC bus ripple frequency ≤ 166 Hz
  - The amplitude is higher than Pr.06-52 setting [default 30 V (230V models), 60 V (460V models)]. It starts to count time after 20 consecutive times.
  - When the counting lasts for the following time conditions, an ORP occurs.

(I)% is rated current percentage

(I)%	Actual seconds
50	432
75	225
120	60

When any of the above conditions is not met, the ORP protection recalculates.

# 

Default: 0

Settings 0: Auto-decrease carrier frequency and limit output current

1: Constant carrier frequency and limit output current

2:Auto-decrease carrier frequency

- Refer to Pr.00-01 (Maximum Operation Frequency) for allowable maximum output frequency in each control mode.
- The corresponded carrier frequency lower limit under each control mode:
  - VF, SVC: 599 Hz, 6K
  - FOC sensorless (IM): 300 Hz, 6K
  - FOC sensorless (PM): 500 Hz, 10K
- Refer to the Section 9-7 Derating for Ambient Temperature, Altitude and Carrier Frequency for the derating ratio.
- Setting 0:
  - Actual over-current stall prevention level = derating ratio × over-current stall prevention level (Pr.06-03 and Pr.06-04).
  - Rated current derating level: derating ratio × rated current (Pr.00-01).
  - When the operating point is greater than the derating curve, the carrier frequency (Fc)
    output by the drive decreases automatically according to the ambient temperature, overload
    output current and time.
  - Applicable conditions: If overloads are not frequent, and the concern is only about the carrier frequency operating with the rated current for a long time, and changes to the carrier wave due to short overload are acceptable, set to 0.
  - Take VFD007CP43A Normal Duty for example: ambient temperature 50°C, UL Open Type, and independent installation. When the carrier frequency is set to 15 kHz, it corresponds to

72% of the derating ratio. When the output current is higher than the value, it automatically decreases the carrier frequency according to the ambient temperature, output current and overload time (for example: set Pr.06-03 to 200%). At this time, the over-current stall prevention level is 144% ( =  $72\% \times 200\%$ ) of the rated current (Pr.00-01).

### Setting 1:

- When the operating point is greater than the derating curve 1, the carrier frequency (Fc) output by the drive is fixed to the default value.
- Applicable conditions: Select this mode if the change of carrier frequency and motor noise caused by ambient temperature and frequent overload are not acceptable. Refer to Pr.00-17.
- Take VFD007CP43A Normal Duty for example: ambient temperature 50°C, UL Open Type, and independent installation. When the carrier frequency maintains at 15 kHz, it corresponds to 72% of the derating ratio. The oL protection executes when the current is 120% × 72% = 86% for one minute; therefore, it must operate by the curve to keep the carrier frequency.

#### Setting 2:

- The protection method and action are set to 0, but this disables the current limit when output current is the derating ratio x 160% of output current in normal load, and derating ratio x 130% of output current in light load.
- The advantage is that it can provide a higher starting output current (Pr.06-55 = 0) when the carrier frequency (Pr.00-17) setting is higher than the default value. The disadvantage is that the carrier frequency derates easily when it overloads.

For example: when Pr.06-55 = 0 or 1, the over-current stall prevention level = Ratio × Pr.06-03. When Pr.06-55 = 2, the over-current stall prevention level = Pr.06-03.

Use with the settings for Pr.00-16 and Pr.00-17.

× 88 - 58 I	PT100 Voltage Level 1	
00 00		
		Default: 5.000
;	Settings 0.000–10.000 V	
× 88-57	PT100 Voltage Level 2	
		Default: 7.000
:	Settings 0.000-10.000 V	
Condition	on settings: PT100 voltage level Pr.06-57 > Pr.06-56.	
<b>~</b> 08-58	PT100 Level 1 Frequency Protection	

Default: 0.00

Settings 0.00-599.00 Hz


PT100 Activation Level 1 Protection Frequency Delay Time

Default: 60

Settings 0-6000 sec.

- PT100 operation instructions:
  - (1) Use voltage type analog input (AVI1, AVI2 and ACI voltage 0–10 V) and select PT100 mode.
  - (2) Select one of the voltage type analog inputs below:

- (a) AVI1 (Pr.03-00 = 11)
- (b) AVI2 (Pr.03-02 = 11)
- (c) ACI (Pr.03-01 = 11 and Pr.03-29 = 1).
- (3) When selecting Pr.03-01 = 11 and Pr.03-29 = 1, you must switch SW4 to 0–10 V for the external I/O board.
- (4) The AFM2 outputs constant voltage or current, then Pr.03-23 = 23. You must switch AFM2 SW2 to 0–20 mA for the external I/O board, and set AFM2 output level to 45% (Pr.03-33 = 45%) of 20 mA = 9 mA.
- (5) Use Pr.03-33 to adjust the constant voltage or constant current of the AFM2 output; the setting range is 0–100.00%.
- (6) There are two types of action levels for PT100. The diagram below shows the PT100 protecting action:



(7) PT100 wiring diagram:




Figure 1

When Pr.06-58 = 0.00 Hz, PT100 function is disabled.

#### Case:

When using PT100, if the motor temperature is higher than 135°C (275°F), the drive starts to count the delay time for auto-deceleration (Pr.06-59). The drive decreases the motor frequency to the setting for Pr.06-58 when it reaches the delay time count value. The drive operates at the frequency set for Pr.06-58 until the motor temperature is lower than 135°C (275°F). If the motor temperature is higher than 150°C (302°F), the drive automatically decelerates to STOP and displays the warning "oH3".

#### Set up process:

- 1. Switch AFM2 to 0–20 mA on the I/O control terminal block. (Refer to Figure 1, PT100 wiring diagram)
- 2. Wiring (Refer to Figure 1, PT100 wiring diagram):

Connect external terminal AFM2 to "+"

Connect external terminal ACM to "-"

Connect external terminals AFM2 and AVI1 to "short circuit"

- 3. Set Pr.03-00 = 11 or Pr.03-23 = 23 or Pr.03-33 = 45% (9 mA).
- 4. Refer to the RTD temperature and resistance comparison table

Temperature = 135°C, resistance = 151.71  $\Omega$ ; input current: 9 mA, voltage: about 1.37 V<sub>DC</sub> Temperature = 150°C, resistance = 157.33  $\Omega$ ; input current: 9 mA, voltage: about 1.42 V<sub>DC</sub>

- 5. When the RTD temperature > 135°C, the drive decelerates to the specified operation frequency automatically. Then, Pr.06-56 = 1.37 V and Pr.06-58 = 10 Hz. (When Pr.06-58 = 0, it disables the specified operation frequency.)
- 6. When the RTD temperature > 150°C, the drive outputs a fault, decelerates to STOP, and displays the warning "oH3". Then, Pr.06-57 = 1.42 V and Pr.06-29 = 1 (fault and ramp to stop).
- ★ ☐ 6 6 ☐ Software Detection GFF Current Level

Default: 60.0

Settings 0.0–6553.5% (100% corresponds to the light-load rated current of the drive)

Software Detection GFF Filter Time

Default: 0.10

Settings 0.00–655.35 sec.

When the drive detects that the unbalanced three-phase output current is higher than the setting for Pr.06-60, GFF protection activates. The drive then stops output.

Operation Time of Fault Record 1 (Day)

Operation Time of Fault Record 2 (Day)

Operation Time of Fault Record 3 (Day)

Operation Time of Fault Record 4 (Day)

Default: Read only

Settings 0–65535 days

요 - 등 및 Operation Time of Fault Record 1 (Min)	
## G - S S Operation Time of Fault Record 2 (Min)	
## Operation Time of Fault Record 3 (Min)	
☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐	
	Default: Read only

Settings 0-1439 min.

If there is any malfunctions when the drive operates, Pr.06-17–Pr.06-22 record the malfunctions, and Pr.06-63–Pr.06-70 record the operation time for four sequential malfunctions. Check if there is any problem with the drive according to the interval of the recorded fault.

#### Example:

The first error: ocA occurs after motor drive operates for 1000 minutes.

The second error: ocd occurs after another 1000 minutes. The third error: ocn occurs after another 1000 minutes.

The fourth error: ocA occurs after another 1000 minutes.

The fifth error: ocd occurs after another 1000 minutes.

The sixth error: ocn occurs after 1000 minutes.

Then Pr.06-17–Pr.06-22 and Pr.06-63–Pr.06-70 are recorded as follows:

	1 <sup>st</sup> fault	2 <sup>nd</sup> fault	3 <sup>rd</sup> fault	4 <sup>th</sup> fault	5 <sup>th</sup> fault	6 <sup>th</sup> fault
Pr.06-17	ocA	ocd	ocn	ocA	ocd	ocn
Pr.06-18	0	ocA	ocd	ocn	ocA	ocd
Pr.06-19	0	0	ocA	ocd	ocn	ocA
Pr.06-20	0	0	0	ocA	ocd	ocn
Pr.06-21	0	0	0	0	ocA	ocd
Pr.06-22	0	0	0	0	0	ocA
Pr.06-63	0	1	2	2	3	4
Pr.06-64	1000	560	120	1120	680	240
Pr.06-65	0	0	1	2	2	3
Pr.06-66	0	1000	560	120	1120	680
Pr.06-67	0	0	0	1	2	2
Pr.06-68	0	0	1000	560	120	1120
Pr.06-69	0	0	0	0	1	2
Pr.06-70	0	0	0	1000	560	120

<sup>※</sup> By examining the time record, you can see that the last fault (Pr.06-17) happened after the
drive ran for 4 days and 240 minutes.

Default: 0.0

Settings 0.0–100.0% (100% corresponds to the light-load rated current of the drive)

Default: 0.00

Settings 0.00–360.00 sec.

12.1-06-26

# Default: 0 Settings 0: No function 1: Fault and coast to stop 2: Fault and ramp to stop by the 2<sup>nd</sup> deceleration time 3: Warn and operation continue The drive operates according to the setting for Pr.06-73 when the output current is lower than the setting for Pr.06-71, and when the time of the low current exceeds the detection time for Pr.06-72. Use this parameter with the multi-function output terminal = 44 (low current output). The low current detection function does not execute when the drive is in sleep or standby status. Sets Pr.06-71 low current level according to the drive's rated current, the equation is Pr.00-01 (drive's rated current) × Pr.06-71 (low current setting level)% = low current detection level (A). The drive changes the setting for Pr.00-01 (rated current) according to the setting for Pr.00-16 (load selection). ✓ ☐ 5 - ☐ 5 dEb Motion Offset Default: 20.0/40.0/50.0/60.0 Settings 230V models: 0.0-200.0 V<sub>DC</sub> 460V models: 0.0-200.0 V<sub>DC</sub> 575V models: 0.0-200.0 V<sub>DC</sub> 690V models: 0.0-200.0 V<sub>DC</sub> Fire Mode Default: 0.00 Settings 0: Disable 1: Forward (counter clockwise) operation 2: Reverse (clockwise) operation

Use this parameter with multi-function input terminal setting 58 or 59, and multi-function output terminal setting 53 or 54.

- 0: Fire detection is invalid.
- 1: The motor operates in a counterclockwise direction (U, V, W).
- 2: The motor operates in a clockwise direction (U, W, V).

## ✓ ☐ 6 - 8 | Operating Frequency in Fire Mode

Default: 60.00

Settings 0.00-599.00 Hz

Enables fire mode (Pr.06-80 = 1 or 2) and sets the operation frequency in fire mode (Pr.06-81). The drive operates with operation frequency in fire mode when the fire mode is enabled. Refer to Pr.06-86 Fire mode operating sequence for details.

# ★ \$\frac{1}{2} \frac{1}{2} \frac\frac{1}{2} \frac{1}{2} \frac{1}{2} \frac{1}{2} \frac{1}{2} \frac

Default: 0

Settings 0: Disable Bypass 1: Enable Bypass

- The Bypass function only enables in Fire mode.
- When the Bypass function enables and the fault listed in Table 1 occurs, the drive automatically switches to mains power for the motor's operation.

## 

Default: 0.0

Settings 0.0-6550.0 sec.

- $\square$  Conditions to enable the Bypass function (Pr.06-82 = 1):
  - (1) When a fault that can enable the Bypass function (as shown in Table 1) occurs in Fire mode, and the fire alarm lasts for Pr.06-83 setting time, the Bypass function enables and the Bypass fire mode indication (MOx = 54) is ON.
  - (2) When a fault that can be reset (as shown in Table 1) occurs in Fire mode, the automatic reset time is zero, and the fire alarm lasts for Pr.06-83 setting time, then the Bypass function enables and the Bypass fire mode indication (MOx = 54) is ON. If the fault is successfully reset (no fault) before the Bypass function enabled, the counter of bypass delay time returns to zero and waits for the next trigger.




Table 1: Fault detection under Normal mode, Fire mode and Bypass function in Fire mode. (V means detectable)

Code	Fault name	Normal mode	Fire Mode	Enable bypass function
1	Over-current during acceleration (ocA)	V(RS)	V(able to auto-reset)	V
2	Over-current during deceleration (ocd)	V(RS)	V(able to auto-reset)	V
3	Over-current during steady speed (ocn)	V(RS)	V(able to auto-reset)	V
4	Ground Fault (GFF)	V	V(able to auto-reset)	V
5	IGBT short-circuit between upper bridge and lower bridge (occ)	V(RS)	V(able to auto-reset)	V
6	Over-current at stop (ocS)	V(RS)	V(able to auto-reset)	V
7	Over-voltage during acceleration (ovA)	V(RS)	V(able to auto-reset)	V
8	Over-voltage during deceleration (ovd)	V(RS)	V(able to auto-reset)	V
9	Over-voltage at constant speed (ovn)	V(RS)	V(able to auto-reset)	V

Code	Fault name	Normal mode	Fire Mode	Enable bypass function
10	Over-voltage at stop (ovS)	V(RS)	V(able to auto-reset)	V
11	Low-voltage during acceleration (LvA)	V	Not-detectable	Not-detectable
12	Low-voltage during deceleration (Lvd)	V	Not-detectable	Not-detectable
13	Low-voltage at constant speed (Lvn)	V	Not-detectable	Not-detectable
14	Low-voltage at Stop (LvS)	V	Not-detectable	Not-detectable
15	Phase loss protection (OrP)	V	V(able to auto-reset)	V
16	IGBT overheating (oH1)	V	V(able to auto-reset)	V
17	Heatsink overheating (oH2)	V	V(able to auto-reset)	V
18	IGBT temperature detection failure (tH1o)	V	V(able to auto-reset)	V
19	Capacitor hardware error (tH2o)	V	V(able to auto-reset)	V
21	Over load (oL) (150% 1Min, Inverter)	V	Not-detectable	Not-detectable
22	Electronic thermal relay 1 protection (EoL1)	٧	Not-detectable	Not-detectable
23	Electronic thermal relay 2 protection (EoL2)	V	Not-detectable	Not-detectable
24	Motor overheating (oH3) (PTC / PT100)	V	V(able to auto-reset)	V
26	Over torque 1 (ot1)	V	Not-detectable	Not-detectable
27	Over torque 2 (ot2)	V	Not-detectable	Not-detectable
28	Under current (uC)	V	Not-detectable	Not-detectable
30	EEPROM write error (cF1)	V	Not-detectable	Not-detectable
31	EEPROM read error (cF2)	V	V	Not-detectable
33	U-phase error (cd1)	V	V	Not-detectable
34	V-phase error (cd2)	V	V	Not-detectable
35	W-phase error (cd3)	V	V	Not-detectable
36	cc (current clamp) hardware error (Hd0)	V	V	Not-detectable
37	oc (over-current) hardware error (Hd1)	V	V	Not-detectable
38	ov (over-voltage) hardware error (Hd2)	V	V	Not-detectable
39	occ hardware error (Hd3)	V	V	Not-detectable
40	Auto-tuning error (AUE)	V	Not-detectable	Not-detectable
41	PID loss ACI (AFE)	V	Not-detectable	Not-detectable
48	ACI loss (ACE)	V	Not-detectable	Not-detectable
49	External fault (EF)	V	Not-detectable	Not-detectable
50	Emergency stop (EF1)	V	Not-detectable	Not-detectable
51	External base block (bb)	V	Not-detectable	Not-detectable
52	Enter wrong password three times and locked (Pcod)	V	Not-detectable	Not-detectable
53	Firmware version error (ccod)	V	V	Not-detectable
54	Illegal command (CE1)	V	Not-detectable	Not-detectable
55	Illegal data address (CE2)	V	Not-detectable	Not-detectable
56	Illegal data value (CE3)	V	Not-detectable	Not-detectable
57	Data is written to read-only address (CE4)	V	Not-detectable	Not-detectable
58	Modbus transmission time-out (CE10)	V	Not-detectable	Not-detectable
60	Braking transistor error (bF)	V	Not-detectable	Not-detectable
61	Y-connection / Δ-connection switch error (ydc)	V	Not-detectable	Not-detectable
62	Deceleration energy backup error (dEb)	V	Not-detectable	Not-detectable
63	Over slip error (oSL)	V	Not-detectable	Not-detectable

Code	Fault name	Normal mode	Fire Mode	Enable bypass function
64	Electric valve switch error (ryF)	V	Not-detectable	Not-detectable
68	Reverse direction of the speed feedback (SdRv)	V	Not-detectable	Not-detectable
69	Over speed rotation feedback (SdOr)	V	Not-detectable	Not-detectable
70	Large deviation of speed feedback (SdDe)	V	Not-detectable	Not-detectable
71	Watchdog (WDTT)	Not detectable	Not-detectable	Not-detectable
72	STO loss 1 (STL1)	V	V	Not-detectable
73	Emergency stop for external safety (S1)	V	V	Not-detectable
74	Fire mode output (Fire)	V	V (keeps operating)	V (keeps operating)
76	Safety Torque Off (STO)	V	V	Not-detectable
77	STO loss 2 (STL2)	V	V	Not-detectable
78	STO loss 3 (STL3)	V	V	Not-detectable
82	Output phase loss U-phase (OPHL)	V	V(able to auto-reset)	V
83	Output phase loss V-phase (OPHL)	V	V(able to auto-reset)	V
84	Output phase loss W-phase (OPHL)	V	V(able to auto-reset)	V
89	Rotor position detection error (RoPd)	V	V	V
90	Forced to stop (FStp)	V	Not-detectable	Not-detectable
101	CANopen guarding error (CGdE)	V	Not-detectable	Not-detectable
102	CANopen heartbeat error (CHbE)	V	Not-detectable	Not-detectable
104	CANopen bus off error (CbFE)	V	Not-detectable	Not-detectable
105	CANopen index error (CidE)	V	Not-detectable	Not-detectable
106	CANopen station address error (CAdE)	V	Not-detectable	Not-detectable
107	CANopen memory error (CFrE)	V	Not-detectable	Not-detectable
111	InrCOM time-out error (ictE)	V	Not-detectable	Not-detectable
142	Auto-tuning error 1 (no feedback current error) (AUE1)	Not detectable	Not-detectable	Not-detectable
143	Auto-tuning error 2 (motor phase loss error) (AUE2)	Not detectable	Not-detectable	Not-detectable
144	Auto-tuning error 3 (no-load current I <sub>0</sub> measuring error) (AUE3)	Not detectable	Not-detectable	Not-detectable
148	Auto-tuning error 4 (leakage inductance Lsigma measuring error) (AUE4)	Not detectable	Not-detectable	Not-detectable

# እ ያያ - 8 ዓ Number of Times of Reset in Fire Mode

Default: 0

#### Settings 0–10

- When a fault occurs in fire mode, the drive attempts resetting the fault to prevent entering bypass mode. Use Pr.06-84 and Pr.06-85 to set this function.
- When this function is disabled (Pr.06-84 = 0) and a fault that listed in Table 1 occurs, the drive enters bypass mode (Pr.06-82 = 1, bypass function is enabled).

Example: If Pr.06-83 = 3, the drive attempts to reset the fault for three times at most. When the fourth fault occurs in the setting time for Pr.06-85, the drive will no longer attempt to reset the fault, and directly goes into Bypass mode after the setting delay time for Pr.06-83.

**~** 88-85 Ler

#### Length of Time of Reset in Fire Mode

Default: 60.0

Settings 0.0-6000.0 sec.

The settings for Pr.06-82 to Pr.06-85 determine whether to switch the motor operation to mains power in fire mode.

### **85-85** Fire Mode Motion

Default: 0

Settings bit0: 0 = Open Loop; 1 = Close Loop (PID control)

bit1: 0 = Manual reset fire mode; 1 = Auto reset fire mode


0: Open loop control and manual reset fire mode

1: Close loop control and manual reset fire mode

2: Open loop control and auto reset fire mode

3: Close loop control and auto reset fire mode

The sequence of Fire mode operation is as the diagram below. Choose the operation mode [open-loop control or close-loop control (PID control)] according to the setting for Pr.06-86.



- The Fire mode operating procedure:
  - Pr.06-86 bit0 = 0:

When setting Pr.06-80 = 1 or 2, and the multi-functional input terminals MIx = 58 is ON, the drive enables the fire mode operation. The drive accelerates to the setting frequency for Pr.06-81, and the keypad KPC-CC01 displays a "Fire" warning. The drive outputs a RUN command for the fire mode when the multi-function output terminal MOx is set to 53. If you set Pr.06-82 = 1 to enable the Bypass function and the condition is established, the MOx = 54 Bypass fire mode indicates action and switches the motor power to the mains power, then the drive stops.

Pr.06-86 bit0 = 1:

When setting the Pr.06-80 = 1 or 2, and the multi-functional input terminals MIx = 58 is ON, the drive enables the fire mode operation. The drive runs PID control with Pr.06-87 as PID set point, and the keypad KPC-CC01 displays a "Fire" warning. The drive outputs a RUN command for the fire mode when the multi-function output terminal MOx is set to 53. If you set Pr.06-82 = 1 to enable the Bypass function and the condition is established, the MOx = 54 Bypass fire mode indicates action and switches the motor power to the mains power, then the drive stops.

• If an error occurs to the PID feedback signal, the drive switches to the open-loop control and runs according to the setting frequency for Pr.06-81.

## 


Default: 0.00

Settings 0.00-100.00%

Sets the PID target value in Fire mode.


The Fire mode reset procedure:

When the terminal MIx = 58 changes from ON to OFF, the drive starts to run "fire mode reset procedure", and determines whether to "Manual reset" or "Auto reset" fire mode according to the selection of Pr.06-86 bit1.



#### Wiring Diagram:

- 1. When AC power is ON, RB1 and RC1 are ON, and RA1 and RC1 are OFF.
- 2. When operating in fire mode and bypass indication function is disabled, RB1 and RC1 are ON, and the motor is driven by the drive.
- 3. When operating in fire mode and bypass indication function is enabled, RA1 and RC1 are ON, and the motor runs under mains electricity.



- When in fire mode, the running direction of the drive is based on Pr.06-80 = 1 (Forward / Counter clockwise operation) or Pr.06-80 = 2 (Reverse / Clockwise operation). Other running direction commands are invalid and Pr.00-23 Motor Operating Direction is not available when in fire mode.
- When in fire mode, all keypad command are ignored, including RUN, STOP, JOG and direction commands.
- When in fire mode, all RS-485 communication commands are ignored, including RUN, STOP, JOG and direction commands.
- When in fire mode, B.B. and EF are not activated, including external terminal B.B, communication B.B, external terminal EF, communication EF and external terminal EF1). Any activated B.B. is automatically invalid, including external terminal B.B. and communication B.B., and the drive executes speed tracking.
- When in fire mode, activated EF and EF1 are automatically invalid, including external terminals EF & EF1 and communication EF).
- When in fire mode, the JOG command is not available (JOG command source: keypad, external terminals and communications). Any operating JOG command is automatically invalid.
- When in fire mode, the Acceleration / Deceleration Speed Inhibit function is not available. Any activated acceleration / deceleration speed inhibition is automatically invalid.
- When in fire mode, If you set Pr.06-86 to bit0 = 0 (open-loop control), the drive does not execute parameter group 08 PID function. Any operating PID function is automatically invalid.
- When in fire mode, the Hand-Off-Auto function is not available, including multi-function output terminals.

	When in fire mode, the drive does not execute the circulative control function, and all circulating
	control function parameters are cleared. The circulative control function is automatically invalid
	when in fire mode.
	When in fire mode, the drive does not execute the sleep function.
	When in fire mode, the drive does not execute the DC brake function. Any operating DC brake is
	automatically invalid when in fire mode.
	When in fire mode, the drive does not execute over-current stall prevention function. Any operating over-current stall prevention is automatically invalid when in fire mode.
	When in fire mode, over-torque detection function is not available.
	When in fire mode, oL1/oL2 detection function is not available.
	When in fire mode, abnormal communication (CE10, CE1, CE2, CE3 and CE4) detection is not
اعظ	available.
	The cd1, cd2, cd3 and Hd0, Hd1, Hd2, Hd3 are boot check and cannot be cleared. The above
	errors cannot be cleared when in fire mode. The drive does not operate when in fire mode.
	Lv protection is not activated when in fire mode, so the drive keeps running or runs until the
	power is lost. If the Lv error occurs before the fire mode warning, clear the Lv error to operate the
	drive.
	If bypass fire mode indication ( $MOx = 54$ ) is activated, reboot the drive and deactivate the fire
	mode to turn off this terminal output.
	When in fire mode, the output stop function is not available.
	When in fire mode, the skip frequency function is not available.
	When in fire mode, the operating frequency for Pr.06-81 cannot be larger than Pr.01-00
	Maximum Output Frequency. If Pr.06-81 > Pr.01-00, the maximum frequency is automatically set
	to Pr.01-00.

### **07 Special Parameters**

✓ You can set this parameter during operation.

The following are abbreviations for different types of motors:

IM: Induction motor

- SPM: Surface permanent magnet synchronous AC motor
- PM: Permanent magnet synchronous AC motor
- SynRM: Synchronous reluctance motor
- IPM: Interior permanent magnet synchronous AC motor

### Software Brake Chopper Action Level

Default:

380.0/740.0/895.0/1057.0

Settings 230V models: 350.0-450.0 V<sub>DC</sub>

460V models:  $700.0-900.0 \text{ V}_{DC}$  575V models:  $850.0-1116.0 \text{ V}_{DC}$  690V models:  $939.0-1318.0 \text{ V}_{DC}$ 

- Sets the DC bus voltage at which the brake chopper is activated. Choose a suitable brake resistor to achieve the best deceleration. Refer to Chapter 7 Optional Accessories for information about brake resistors.
- This parameter is only valid for the models below 22 kW of 230V models and 30 kW of 460V models.

### 

Default: 0

Settings 0–100%

- 100% corresponds to the rated current of the drive (Pr.00-01).
- Sets the level of the DC brake current output to the motor at start-up and stop. It is recommended that you start with a low DC brake current level and then increase until you reach the proper holding torque. However, the DC brake current cannot exceed the motor's rated current to prevent the motor from burnout. Do NOT use the DC brake for mechanical retention, otherwise, injury or accident may occur.
- The PM has the magnetic field itself, using the DC brake may possibly cause the motor run in a reverse direction, therefore, it is not recommended to use DC brake for PM.

## ✓ ☐ 7 - ☐ 2 DC Brake Time at Start-up

Default: 0.0

Settings 0.0-60.0 sec.

The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. If you use the drive with the motor rotating, it may cause motor damage or trigger drive protection due to over-current. This parameter outputs DC current, generating torque to force the motor to stop to get a stable start before more operation. This parameter determines the duration of the DC brake current output to the motor when the drive starts up. Setting this parameter to 0.0 disables the DC brake at start-up.

The PM has the magnetic field itself, using the DC brake may possibly cause the motor run in a reverse direction, therefore, it is not recommended to use DC brake for PM. Use Pr.10-49 zero voltage command to force the motor decelerate or to stop.

## 

Default: 0.0

Settings 0.0-60.0 sec.


- The motor may continue rotating after the drive stops output due to external forces or the inertia of the motor itself. This parameter outputs DC current, generating torque to force the drive stop after the drive stops output to make sure that the motor stops.
- This parameter determines the duration of the DC brake current output to the motor when braking. To enable the DC brake at STOP, you must set Pr.00-22 (Stop Method) to 0 (ramp to stop). Set this parameter to 0.0 to disable the DC brake at stop.
- Related parameters: Pr.00-22 Stop Method, Pr.07-04 DC Brake Frequency at STOP.

### 

Default: 0.00

Settings 0.00-599.00 Hz

Determines the start frequency of the DC brake before the drive ramps to stop. When this setting is less than Pr.01-09 (Start-up Frequency), the start frequency for the DC brake begins at the minimum frequency.



DC Brake Output Timing Diagram

- Use the DC brake before running the motor when the load is movable at stop, such as with fans and pumps. The motor is in free running status and in unknown rotation direction before the drive starts up. Execute the DC brake before you start the motor.
- Use the DC brake at STOP when you need to brake the motor quickly or to control the positioning, such as with cranes or cutting machines.

## ✓ ☐ 7 - ☐ 5 Voltage Increasing Gain

Default: 100

Settings 1–200%

When using speed tracking, adjust Pr.07-05 to slow down the increasing voltage gain if there are errors such as oL or oc; however, the speed tracking time will be longer.

N	8	- 🖁 🖁 Restart after Momentary Power Loss
		Default: 0
		Settings 0: Stop operation
		1: Speed tracking by speed before the power loss
		2: Speed tracking by minimum output frequency
		Determines the operation mode when the drive restarts from a momentary power loss.
		The power system connected to the drive may power off momentarily due to many reasons. This
		function allows the drive to keep outputting voltages after the drive is repowered and does not
		cause the drive to stop.
		1: Frequency tracking begins before momentary power loss and accelerates to the master
		Frequency command after the drive output frequency and motor rotator speed are synchronous.
		Use this setting when there is a lot of inertia with little resistance on the motor load. For example
		in equipment with a large inertia flywheel, there is NO need to wait until the flywheel stops
		completely after a restart to execute the operation command; therefore, it saves time.
		2: Frequency tracking starts from the minimum output frequency and accelerates to the master
		Frequency command after the drive output frequency and motor rotator speed are synchronous.
		Use this setting when there is little inertia and large resistance.
		This function is only valid when the RUN command is enabled.
N	8	Allowed Power Loss Duration
		Default: 2.0
		Settings 0.0–20.0 sec.
		Determines the maximum time of allowable power loss. If the duration of a power loss exceeds
		this parameter setting, the AC motor drive stops output after the power recovers.
		Pr.07-06 is valid when the maximum allowable power loss time is ≤ 20 seconds and the AC
		motor drive displays "Lv". If the AC motor drive is powered off due to overload, even if the
		maximum allowable power loss time is ≤ 20 seconds, Pr.07-06 is invalid after the power
		recovers.
N	8	- 🖁 🖁 Base Block Time
		Default: Depending on the
		model power
		Settings 0.0–5.0 sec. (Depending on the model power)
		When momentary power loss is detected, the AC motor drive blocks its output and then waits for
		a specified period of time (determined by Pr.07-08, called Base Block Time) before resuming
		operation. Set this parameter to the time that allows the residual voltage at the output side to
		decrease to 0 V before activating the drive again.
		This parameter is not only for the B.B. time, but also is the re-start delay time after free run.
		The RUN command during a free run operation is memorized, and runs or stops with the last
		frequency command after the delay time.
		This delay time is only applicable in "Re-start after coast to stop" status, and does not limit ramp


to stop. The coast to stop can be caused by various control command source, or by errors.

Following table is the recommended setting for re-start delay time of each model power. You must set Pr.07-08 according to this table (the default of each model power is also based on this table).


kW	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11.0	15.0	18.5	22.0
HP	1	2	3	5	5.5	7.5	10	15	20	25	30
Delay time (sec.)	0.3	0.4	0.5	0.6	0.7	0.7	8.0	0.9	1	1.1	1.2

kW	30.0	37.0	45.0	55.0	75.0	90.0	110.0	132.0	160.0	185.0	200.0
HP	40	50	60	75	100	125	150	175	215	250	270
Delay time (sec.)	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2.0	2.1	2.2	2.3


kW	220.0	250.0	280.0	315.0	355.0	400.0	500.0	560.0	630.0
HP	300	340	375	425	475	530	675	750	850
Delay time (sec.)	2.3	2.4	2.5	2.6	2.7	2.8	2.9	3.2	3.4



B.B. Search with last output frequency downward timing chart



B.B. Search with minimum output frequency upward timing chart



B.B. Search with minimum output frequency upward timing chart

## ✓ ☐ 7 - ☐ ☐ Current Limit for Speed Tracking

Default: 100

Settings 20–200% (100% corresponds to the light-duty rated current of the drive)

- The AC motor drive executes speed tracking only when the output current is greater than the value set in Pr.07-09.
- The maximum current for speed tracking affects the synchronous time. The larger the parameter setting is, the faster the synchronization occurs. However, if the parameter setting is too large, the overload protection function may be activated.

### 

Default: 0

Settings 0: Stop operation

1: Speed tracking by current speed

2: Speed tracking by minimum output frequency

Faults include: bb, oc, ov, and occ. To restart after oc, ov and occ, you cannot set Pr.07-11 to 0.

### Number of Times of Restart after Fault

Default: 0

Settings 0-10

- After fault (oc, ov, and occ) occurs, the AC motor drive can reset and restart automatically up to 10 times. If Pr. 07-11 is set to 0, the drive resets or restarts automatically after faults occur. The drive starts according to the Pr.07-10 setting after restarting after fault.
- If the number of faults exceeds the Pr.07-11 setting, the drive does not restart and reset until you press RESET manually and execute the operation command again.

## ★ ☐ 7 - 12 Speed Tracking during Start-up

Default: 0

Settings 0: Disable

1: Speed tracking by the maximum output frequency

2: Speed tracking by the motor frequency start-up


3: Speed tracking by the minimum output frequency

	Speed tracking is suitable for punch, fans and other large inertia loads. For example, a mechanical punch usually has a large inertia flywheel, and the general stop method is coast to stop. If it needs to be restarted again, the flywheel may take 2–5 minutes or longer to stop. This parameter setting allows you to start the flywheel operating again without waiting until the flywheel stops completely.							
	flywheel stops completely.							
	When using PM, $Pr.07-12 \neq 0$ , the speed tracking function is enabled. When $Pr.07-12 = 1$ , the output frequency converts to the actual rotor speed from zero-speed.	2 or 3,						
	When using SynRM control mode, only Pr.07-12 = 3 (speed tracking by the minimum	output						
	frequency) is enabled.	output						
$\Omega$	dEb Function Selection							
_	Default: 0							
	Settings 0: Disable							
	1: dEb with auto-acceleration / auto-deceleration, the drive does not out the frequency after the power is restored.	ıtput						
	2: dEb with auto-acceleration / auto-deceleration, the drive outputs the							
	frequency after the power is restored							
	dEb (Deceleration Energy Backup) lets the motor decelerates to stop when momentary	power						
	loss occurs. When the power loss is instantaneous, use this function to let the motor dece	elerate						
	to zero speed. If the power recovers at this time, the drive restarts the motor after the dEb	return						
	time.							
	Lv return level: Default value depends on the drive power model							
	Models for frame A, B, C, D = Pr.06-00 + 60V/30V (230V models)							
	Models for frame E and above = Pr.06-00 + 80V/40V (230V models)							
	Lv level: Default = Pr.06-00							
	During dEb operation, other protection such as ryF, ov, oc, occ and EF may interrupt these error codes are recorded.	it, and						
	The STOP (RESET) command does not work during the dEb auto-deceleration, and the	e drive						
	continues decelerating to stop. To make the drive coast to stop immediately, use a							
	function (EF) instead.							
	The B.B. function does not work when executing dEb. The B.B. function is enabled after the	ne dEb						
	function finishes.							
	Even though the Lv warning does not display during dEb operation, if the DC bus vol	tage is						
	lower than the Lv level, MOx = 10 (Low voltage warning) still operates.							
	The following explains the dEb action:							
	When the DC voltage drops below the dEb setting level, the dEb function starts to wor	k (soft						
	start relay remains closed), and the drive executes auto-deceleration.	-						

 Situation 1: Momentary power loss, or too low and unstable power voltage, or power supply sliding down because of sudden heavy load.


Pr.07-13 = 1, "dEb active, DC bus voltage returns, output frequency does not return" and power recovers.

When the power recovers and DC bus voltage exceeds the dEb return level, the drive linearly decelerates to 0 Hz and stops. The keypad displays the "dEb" warning until you manually reset it, so you can see the reason for the stop.



 Situation 2: Momentary power loss or too low and unstable power voltage, or power supply sliding down because of sudden heavy load.


Pr.07-13 = 2 "dEb active, DC bus voltage returns, output frequency returns" and power recovers. During the dEb deceleration (includes 0 Hz run), if the power recovers to a voltage higher than dEb return level, the drive maintains the frequency for the set time of Pr.07-14 (default = 3 sec.) and then accelerates again. The "dEb" warning on the keypad is automatically cleared.



Situation 3: Unexpected power shut down or power loss

Pr.07-13 = 1 "dEb active, DC bus voltage returns, the output frequency does not return" and the power does not recover.

The keypad displays the "dEb" warning and the drive stops after decelerating to the lowest operating frequency. When the DC bus voltage is lower than the Lv level, the drive disconnects the soft start relay until the power completely runs out.



#### Situation 4:

Pr.07-13 = 2 "dEb active, DC bus voltage returns, the output frequency returns" and power does not recover.

The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft-start relay. The keypad displays "dEb" warning until the drive completely runs out of power.

#### Situation 5:

Pr.07-13 = 2 "dEb low voltage control, when the speed is lower than 1/4 rated motor speed, DC bus voltage rises to 350  $V_{DC}$  / 700  $V_{DC}$ , the drive ramps to stop .

The drive decelerates to 0 Hz. The DC bus voltage continues to decrease until the voltage is lower than the Lv level, and then the drive disconnects the soft-start relay. The soft-start relay closes again after the power recovers and the DC bus voltage is higher than the Lv return level. When the DC bus voltage is higher than the dEb return level, the drive maintains the frequency for the set time of Pr.07-14 (default = 3 sec.) and starts to accelerate linearly, and the dEb warning on the keypad is automatically cleared.


#### Situation 6:

Pr.07-13 = 4, dEb high-voltage control


When dEb occurs, the DC bus voltage control level rises to 350 V<sub>DC</sub> / 700 V<sub>DC</sub> to ramp to stop.

Even though the power recovers and the frequency does not return, dEb activates until the motor decelerates to 0 Hz.

- (1) When dEb activates, it sends dEb warning. When the output frequency reaches 0 Hz, the operation status is STOP and disables the dEb function, the dEb warning continues.
- (2) If power does not recover, the DC bus voltage drops until reaches the Lv level, the drive LvS error occurs (keypad displays LvS error that covers the dEb display), the Soft Start Relay will be OFF.



- In the heavy load situation, Dwell can make stable output frequency temporarily.
- For heavy load applications, use Pr.07-15–Pr.07-18 to avoid ov or oc protection.



Dwell at acceleration / deceleration

## ★ # T - # Fan Cooling Control

Default: 0

Settings 0: Fan is always ON

- 1: Fan is OFF after AC motor drive stops for one minute
- 2: Fan is ON when the AC motor drive runs; fan is OFF when the AC motor drive stops
- 3: Fan turns ON when temperature (IGBT) reaches around 60°C
- 4: Fan is always OFF
- Use this parameter to control the fan.
- ©: Fan runs immediately when the drive power is turned ON.

- 1: Fan runs when the AC motor drive runs. One minute after the AC motor drives stops, the fan is OFF.
- 2: Fan runs when the AC motor drive runs and stops immediately when AC motor drive stops.
- 3: Fan is ON when IGBT or capacitance temperature is > 60°C

  Fan is OFF when IGBT and capacitance temperature are both < 40°C, and the drive stops running
- Setting 4: Fan is always OFF
- The control parameter for the applicable fan of each frame are as below:

Frame	Heat Sink Fan	Capacitor Fan
Α	Pr.07-19	No capacitor fan
В	Pr.07-19	Pr.07-19
•	D= 07.40	Pr.07-19
С	Pr.07-19	230V models: always ON
D0	Pr.07-19	Pr.07-19
D	Pr.07-19	ON
E	Pr.07-19	Pr.07-19
F	Pr.07-19	Pr.07-19
G	Pr.07-19	No capacitor fan
Н	Pr.07-19	No capacitor fan

## ★ ☐ 7 - 2 ☐ Emergency Stop (EF) & Force to Stop Selection

Default: 0

Settings 0: Coast to stop

1: Stop by the first deceleration time

2: Stop by the second deceleration time


3: Stop by the third deceleration time


4: Stop by the fourth deceleration time

5: System deceleration

6: Automatic deceleration

When the multi-function input terminal setting is set to 10 (EF input) or 18 (force to stop) and the terminal contact is ON, the drive stops according to the setting of this parameter.





## Automatic Energy-saving (AES) Selection

Default: 0

Settings 0: Disabled

1: Power factor energy-saving improvement (for VF and SVC control modes)


2: Automatic energy-saving optimization (for VF and SVC control modes)

#### Different control modes for Pr.07-21:


Settings / Control mode	Induction Motor (IM)		Permanent Magnet Synchronous Motor (PM)		Synchronous Reluctance Motor (SynRM)
mode	VF	SVC	PMSVC	PMFOC	FOC
1: Power factor energy-saving improvement	✓	<b>√</b>			
2: Automatic energy-saving optimization	✓	<b>√</b>			

- Power factor energy-saving improvement (Pr.07-21 = 1):
  - When the automatic energy-saving function is enabled, the drive runs with full-voltage during acceleration and deceleration, and runs with the optimal voltage that is automatically calculated by the load power during constant operation. It is not recommended to use this function for applications that require frequent load changes or when the load is close to full-load during operation.
  - The prerequisites for valid power factor energy-saving improvement (Pr.07-21 = 1) are:
    - A. Power factor angle is larger than Pr.07-43 (Targeted Power Factor Angle for AES)
    - B. Output frequency is larger than Pr.07-41 (Minimum Frequency for AES)
    - C. The drive is in a steady-state output frequency status
    - D. Time for steady-state output frequency is larger than Pr.07-42 (Delay Time for AES)
    - E. Output current is smaller than or equal to 90% of the drive's rated current

- The prerequisites for invalid power factor energy-saving improvement (Pr.07-21 = 1) are:
  - 1. A changing output frequency
  - 2. Output current is lager than 90% of the drive's rated current




- Automatic energy-saving optimization (Pr.07-21 = 2):
  - Controls the output voltage to minimize the motor's losses for optimal energy-saving. The motor's losses are calculated by motor parameter auto-tuning and energy-saving coefficient.
  - Automatic energy-saving optimization control is according to the block diagram below:



- Pr.07-21 Auto Energy-saving (AES) Selection Pr.07-41 Minimum Frequency for AES
- Pr.07-42 Delay Time for AES
- The prerequisites for valid automatic energy-saving optimization (Pr.07-21 = 2) are:
  - Output frequency is larger than Pr.07-41 (Miminum Frequency for AES) A.
  - B. The drive is in a steady-state output frequency status
  - C. Time for steady-state output frequency is larger than Pr.07-42 (Delay Time for AES)

- The prerequisites for invalid automatic energy-saving optimization (Pr.07-21 = 2) are:
  - 1. A changing output frequency
  - The loss model automatically determines the voltage drops when the drive is in normal and heavy duty. If there is no more voltage that can be adjusted, that is, the voltage drop is already optimized, AES is invalid.



The energy-saving function is invalid during the drive's acceleration and deceleration. To make it valid, the prerequisites need to be verified again.

## 

Default: 100

Settings 10-1000%

- When Pr.07-21 is set to 1, use this parameter to adjust the energy-saving gain. The default is 100%. If the result is not satisfactory, adjust it by decreasing the setting value. If the motor oscillates, then increase the setting value.
- In certain applications such as high speed spindles, the temperature rise in the motor is a major concern. When the motor is not in working state, reduce the motor current to a lower level. Reduce this parameter setting to meet this requirement.

## ★ 3 - 2 3 Automatic Voltage Regulation (AVR) Function

Default: 0

Settings 0: Enable AVR

1: Disable AVR

2: Disable AVR during deceleration

The rated voltage of the motor is usually 200–240 V<sub>AC</sub> (380–480 V<sub>AC</sub>), 60 Hz / 50 Hz and the input voltage of the AC motor drive may vary between 170–264 V<sub>AC</sub> (323–528 V<sub>AC</sub>), 50 Hz / 60 Hz. Therefore, when the AC motor drive is used without AVR function, the output voltage is the same as the input voltage. When the motor runs at the voltage exceeding 12–20% of the rated voltage, it causes higher temperature, damaged insulation, and unstable torque output, which

	result in losses due to shorter motor lifetime.
	The AVR function automatically regulates the output voltage of the AC motor drive to the motor's
	rated voltage when the input voltage exceeds the motor's rated voltage. For example, if the V/F
	curve is set at 200 $V_{AC}$ / 50 Hz and the input voltage is at 200-264 $V_{AC}$ , then the drive
	automatically reduces the output voltage to the motor to a maximum of 200 $V_{AC}$ / 50 Hz. If the
	input voltage is at 170–200 V <sub>AC</sub> , the output voltage to motor is in direct proportion to the input
	voltage.
	0: When the AVR function is enabled, the drive calculates the output voltage according to the
	actual DC bus voltage. The output voltage does NOT change when the DC bus voltage
	changes.
	1: When the AVR function is disabled, the drive calculates the output voltage according to the
	actual DC bus voltage. The output voltage changes with the DC bus voltage, and may cause
	insufficient current, over-current or oscillation.
	2: The drive disables the AVR function only during deceleration to stop, and at this time, you can
	accelerate the braking to achieve the same result.
	When the motor ramps to stop, disable the AVR function to shorten the deceleration time. Then,
	use with the auto-acceleration and auto-deceleration functions to make the motor's deceleration
	more stable and quicker.
0	- ፫ ሣ Torque Command Filter Time (V/F and SVC Control Mode)
	Default: 0.500
	Settings 0.001–10.000 sec.
	When the time constant setting is too large, the control is stable but the control response is slow.
	When the time constant setting is too small, the control response is faster but the control may be
	unstable. For optimal setting, adjust the setting based on the control stability or the control
	response.
0.5	Slip Compensation Filter Time (V/F and SVC Control Mode)
<i>'</i> '	Default: 0.100
	Settings 0.001–10.000 sec.
	Change the compensation response time with Pr.07-24 and Pr.07-25.
	If you set Pr.07-24 and Pr.07-25 to 10 seconds, the compensation response time is the slowest;
	however, the system may be unstable if you set the time too short.
	7 - 2 5 Torque Compensation Gain
	Default: 0
	Settings IM: 0–10 (when Pr.05-33 = 0)
	PM: 0–5000 (when Pr.05-33 = 1 or 2)
	Only applicable in IMVF and PMSVC control modes.
	With a large motor load, a part of the drive output voltage is absorbed by the stator winding
	resistor; therefore, the air gap magnetic field is insufficient. This causes insufficient voltage at
	motor induction and results in excessive output current but insufficient output torque.

Auto-torque compensation can automatically adjust the output voltage according to the load and

#### Chapter 12 Description of Parameter Settings | CP2000

		keep the air gap magnetic fields stable to get the optimal operation.  In the V/F control, the voltage decreases in direct proportion when decreasing frequency. The orque decreases at low speed because of a decreasing AC resistor and an unchanged DC esistor. The auto-torque compensation function increases the output voltage at low frequence of get a higher starting torque.  When the compensation gain is set too large, it may cause motor over-flux and result in a total arge output current of the drive, motor overheating or trigger the drive's protection function.
1	87	Slip Compensation Gain
		Default: 0.00 (1.00 in SVC mode) Settings 0.00–10.00
		Only applicable in IMVF and IMSVC control modes.
		The induction motor needs constant slip to produce electromagnetic torque. It can be ignored an injury higher motor speed, such as rated speed or 2–3% of slip.
		However, during the drive operation, the slip and the synchronous frequency are in reverse proportion to produce the same electromagnetic torque. The slip is larger with the reduction of synchronous frequency. Moreover, the motor may stop when the synchronous frequence decreases to a specific value. Therefore, the slip seriously affects the motor speed accuracy above speed.
		n another situation, when you use an induction motor with the drive, the slip increases when the pad increases. It also affects the motor speed accuracy.
		Use this parameter to set the compensation frequency, and reduce the slip to maintain the synchronous speed when the motor runs at the rated current in order to improve the accuracy of the drive. When the drive output current is higher than Pr.05-05 (No-load Current for Induction Motor 1 (A)), the drive compensates the frequency according to this parameter.
		This parameter is set to 1.00 automatically when Pr.00-11 (Speed Control Mode) is changed rom V/F mode to vector mode. Otherwise, it is automatically set to 0.00. Apply the slip compensation after load and acceleration. Increase the compensation value from small to large gradually; add the output frequency to the [motor rated slip × Pr.07-27 (Slip Compensation Gain when the motor is at the rated load. If the actual speed ratio is slower than expected, increase the parameter setting value; otherwise, decrease the setting value.
/		Slip Deviation Level
		Default: 0.0 Settings 0.0–100.0% 0: No detection
/	07	Over-slip Deviation Detection Time
		Default:1.0 Settings 0.0–10.0 sec.

*	07	- }  Over-slip	Deviation Treatment	
			Def	fault: 0
		Settings	0: Warn and continue operation	
			1: Fault and ramp to stop	
			2: Fault and coast to stop	
			3: No warning	
[		Pr.07-29 to Pr.07-	31 set the allowable slip level / time and the over-slip to	reatment when the drive
		is running.		
×	87	- 32 Motor Osc	cillation Compensation Factor	
			Def	fault: 1000
		Settings	0–10000	
			0: Disable	
[		If there are curre	nt wave motions which cause severe motor oscillation	n in some specific area,
		setting this param	neter can effectively improve this situation. (When runn	ing with high frequency,
		set this paramete	r to 0. When the current wave motion occurs in low fre	quency and high power,
		increase the value	e for Pr.07-32.)	
~	$\overline{\Omega}$	- 3 3 Auto-resta	art Interval of Fault	
				fault: 60.0
		Settings	0.0-6000.0 sec.	
[		When a reset / res	start occurs after a fault, the drive uses Pr.07-33 as a ti	imer and starts counting
		the numbers of fa	rults within this time period. Within this period, if the nu	umber of faults does not
		exceed the setting	g for Pr.07-11, the counting clears and starts from 0 wh	en the next fault occurs.
×	07	- 38 PMSVC V	oltage Feed Forward Gain	
				Default: 1.00
		Settings	0.00-2.00	
I		Adjusts the PMS	VC voltage feedback forward gain, and to meet the de	mand of rapid feedback
		application.		
		Pr.07-38 = 1.00 n	neans forward feedback = Ke × motor rotor speed	
[		Refer to Section	12-2 "PMSVC adjustment" for details.	
×		- 4   Minimum	Frequency for AES	
-				Default: 10.00
		Settings	0.00–40.00 Hz	
[		The drive's output	t frequency must be larger than Pr.07-41 to make the o	drive determine whether
		to run in a steady	-state output frequency.	
[		In general, larger	power and voltage can give more energy-savings; lo	ower power and voltage
			ergy-savings. However, too low power and voltag	_
		low-speed operat	ion because it needs a larger starting current. Pr.07-4	11 is the parameter that
			m frequency when AES is enabled (Pr.07-41 to Pr.	•

range – from minimum to maximum – that you can use for the AES function).

## ✓ ☐ ☐ ☐ ☐ Delay Time for AES

Default: 5

Settings 0–600 sec.

When the drive runs in a steady-state output frequency, and exceeds Pr.07-42 setting time, the drive enters the energy-saving mode.

## ✓ ☐ 7 - 4 3 Targeted Power Factor Angle for AES

Default: 40.00

Settings 0.00-65.00°

- Use this function when Pr.07-21 = 1. If the power factor angle is larger than Pr.07-43, the drive continuously adjusts the energy-saving until it is smaller than Pr.07-43.
- Pr.07-43 is the angle  $\varphi$  between active power and reactive power. The smaller COS $\varphi$ , the lower the reactive power, and the lower the loss.

### 


Default: 60.00

Settings 0.00-70.00%

- Defines the maximum allowed voltage drop when the drive is in energy-saving mode.
- The drive has bigger energy-saving efficiency when running in no-load or light-load. But the output voltage drop is not unlimited. Use Pr.07-44 to limit the maximum ratio (%) of the output voltage drop.

#### Example:


- (1) If Pr.01-01 = 60 Hz, Pr.01-02 = 380  $V_{AC}$ , the frequency command is 60 Hz and the actual voltage output is 371.2  $V_{AC}$ , and Pr.07-44 = 60%, then the maximum voltage drop = 380V (the voltage command corresponding to the frequency command in the VF table: 60 Hz corresponds to 380V) × 60% = 228  $V_{AC}$ .
- (2) If the frequency command is 30 Hz, the corresponding voltage is 200  $V_{AC}$  in the VF table, and Pr.07-44 = 60%, then the maximum voltage drop = 200V × 60% = 120  $V_{AC}$ .




Default: 100

#### Settings 0-10000%

- Defines the motor power loss constant. Default 100% corresponds to the drive's iron loss constant that is calculated by motor parameter auto-tuning or motor nameplate information.
- Pr.07-45 affects the final steady-state output voltage value for the energy-saving control. The larger the Pr.07-45 setting value, the higher the steady-state output voltage (smaller voltage drop). The smaller the Pr.07-45 setting value, the lower the steady-state output voltage (larger voltage drop).
- See below for the flowchart of AES adjustment with motor parameter auto-tuning (recommended):



See below for the flowchart of AES adjustment without motor parameter auto-tuning (not recommended):



# PWM Fan Speed

Default: 60

Settings 60–100%

For different application and environment, adjust the fan speed to expedite the heat dissipation of the drive.

Default for 460V models (45 kW, 55 kW, 75 kW, 90 kW and 110 kW) is 80%; default for other models are 60%.

230V models: 18.5 kW and above models are controlled by PWM fan speed control, and Pr.07-50 is available.

460V models: 22kW and above models are controlled by PWM fan speed control, and Pr.07-50 is available.

575V / 690V models are all controlled by PWM, and Pr.07-50 is available.

### **08 High-function PID Parameters** You can set this parameter during operation.

## 

Default: 0

Settings 0: No function

1: Negative PID feedback: by analog input (Pr.03-00-03-02)

4: Positive PID feedback: by analog input (Pr.03-00-03-02)

- $\square$  Pr.08-00  $\neq$  0 enables the PID function.
- Negative feedback:

Error = +Target value (set point) – Feedback. Use negative feedback when the detection value increases if the output frequency increases.


Positive feedback:

Error = -Target value (set point) + Feedback. Use positive feedback when the detection value decreases if the output frequency increases.

- When Pr.08-00  $\neq$  7 or  $\neq$  8, the input value is disabled. The setting value does not remain when the drive is powered off.
- When  $Pr.08-00 \neq 0$ , the related applicable parameters include:
  - Pr.00-20 (Master frequency command source (AUTO) / Source selection of the PID target)
  - Pr.03-00-03-02

When Pr.00-20 = 2 (External analog input), set Pr.03-00-03-02 = 4 (PID tartget value) When Pr.08-00 = 2 or 4, set Pr.03-00-03-02 = 5 (PID feedback signal)

Refer to the following description for details.



### □□ - □□ Master Frequency Command Source (AUTO) / Source Selection of the PID Target

Default: 0

Settings 0: Digital keypad

1: RS-485 communication input

2: External analog input (Refer to Pr.03-00)

3: External UP/DOWN terminal

6: CANopen communication card

8: Communication card (does not include CANopen card)


#### Chapter 12 Description of Parameter Settings | CP2000

×	83-88	Analog In	put Selection (AVI1)	
				Default: 1
×	03-01	Analog In	put Selection (ACI)	
				Default: 0
×	03-02	Analog In	put Selection (AVI2)	
				Default: 0
		Settings	4: PID target value	
			5: PID feedback signal	

#### Common applications for PID control

- 1. Flow control: Use a flow sensor to feedback the flow data and perform accurate flow control.
- 2. Pressure control: Use a pressure sensor to feedback the pressure data and perform precise pressure control.
- 3. Air volume control: Use an air volume sensor to feedback the air volume data to achieve excellent air volume regulation.
- 4. Temperature control: Use a thermocouple or thermistor to feedback temperature data for comfortable temperature control.
- 5. Speed control: Use a speed sensor feedback motor shaft speed or input another machine speed as a target value for synchronous control.

#### PID control loop:



K<sub>P</sub> Proportional Gain (P), T<sub>i</sub> Integral Time (I), T<sub>d</sub> Differential Time (D), S Calculation

#### Concept of PID control

Proportional gain (P):

The output is proportional to input. With only proportional gain control, there is always a steady-state error.

Adjustment: Turn off the Ti and Td, or remain Ti and Td in constant value, then adjust the proportional gain (P).

Increase: Faster status feedback, but excessive adjustment increases the overshoot.

Decrease: Smaller overshoot, but excessive adjustment slows down the transient response.

#### Integral time(I):

The controller output is proportional to the integral of the controller input. When an automatic control system is in a steady state and a steady-state error occurs, the system is called a System with Steady-state Error. To eliminate the steady-state error, add an "integral part" to the controller. The integral time controls the relation between integral part and the error. The integral part increases over time even if the error is small. It gradually increases the controller output to eliminate the error until it is zero. This stabilizes the system without a steady-state error by using proportional gain control and integral time control.

Adjustment: The integral time (I) accumulates from the time difference, if the vibration cycle is longer than the setting for integral time, the integration enhances. Increase the integral time (I) to reduce the vibration.

Increase: Reduce the overshoot, excessive adjustment causes worse transient response.

Decrease: Faster transient response, but the transient time will be longer, and takes more time to achieve the steady state. Excessive adjustment causes larger overshoot.


#### Differential control (D):

The controller output is proportional to the differential of the controller input. During elimination of the error, oscillation or instability may occur. Use the differential control to suppress these effects by acting before the error. That is, when the error is near zero, the differential control should be zero. Use proportional gain (P) and differential control (D) to improve the system state during PID adjustment.

Adjustment: When the vibration cycle is shorter and continuous, it means that the differential time setting is too large, and causes excessive output. Decrease the setting of D gain to reduce the vibration. If the D gain is set to 0, adjust the PID control again.

#### Using PID control in a constant pressure pump feedback application:

Set the application's constant pressure value (bar) to be the set point of PID control. The pressure sensor sends the actual value as the PID feedback value. After comparing the PID set point and PID feedback, an error displays. The PID controller calculates the output by using proportional gain (P), integral time (I) and differential time (D) to control the pump. It controls the drive to use a different pump speed and achieves constant pressure control by using a 4–20 mA signal corresponding to 0–10 bar as feedback to the drive.



- Pr.00-04 = 10 (Display PID feedback (b) (%))
- Pr.01-12 Acceleration Time is set according to actual conditions.
- Pr.01-13 Deceleration Time is set according to actual conditions.
- Pr.00-21 = 0, operate through the digital keypad
- Pr.00-20 = 0, the digital keypad controls the set point.
- Pr.08-00 = 1 (Negative PID feedback from analog input)
- ACI analog input Pr.03-01 = 5, PID feedback signal.
- Pr.08-01–08-03 is set according to actual conditions:

  If there is no oscillation in the system, increase Pr.08-01 (Proportional Gain (P))

  If there is no oscillation in the system, reduce Pr.08-02 (Integral Time (I))

  If there is no oscillation in the system, increase Pr.08-03 (Differential Time (D))
- Refer to Pr.08-00–08-21 for PID parameter settings.

## 

Default: 1.0

Settings 0.0-100.0


- 1.0: Kp gain is 100%; if the setting is 0.5, Kp gain is 50%.
- Sets the proportional gain to determine the deviation response speed. The higher the proportional gain, the faster the response speed. Eliminates the system deviation; usually used to decrease the deviation and get faster response speed, it also reduces the steady-state error. If you set the value too high, overshoot occurs and it may cause system oscillation and instability.

		If you set the other two gains (I and D) to zero, proportional control is the only effective parameter.
N	88	
		Default: 1.00
		Settings 0.00–100.00 sec.
		0.00: No integral
		Use the integral controller to eliminate the deviation during stable system operation. The integral
		control does not stop working until the deviation is zero. The integral is affected by the integral
		time. The smaller the integral time, the stronger integral action. It is helpful to reduce overshoot
		and oscillation for a stable system. Accordingly, the speed to lower the steady-state deviation
		decreases. The integral control is often used with the other two controls for the PI controller of PID controller.
		Sets the integral time of the I controller. When the integral time is long, there is a small
		controller gain, with slower response and slow external control. When the integral time is short,
		there is a large gain of I controller gain, with faster response and rapid external control.
		When the integral time is too short, it may cause overshoot or oscillation for the output
	·	frequency and system.
		Set Integral Time to 0.00 to disable the I controller.
N	88	B - 🕃 B Differential Time (D)
		Default: 0.00
	·	Settings 0.00–1.00 sec.
		Use the differential controller to show the system deviation change, as well as to preview the change in the deviation. You can use the differential controller to eliminate the deviation in order
		to improve the system state. Using a suitable differential time can reduce overshoot and shorten
		adjustment time; however, the differential operation increases noise interference. Note that a too
		large differential causes more noise interference. In addition, the differential shows the change
		and the output is 0 when there is no change. Note that you cannot use the differential control
		independently. You must use it with the other two controllers for the PD controller or PID
		controller.
		Sets the D controller gain to determine the deviation change response. Using a suitable
		differential time reduces the P and I controllers overshoot to decrease the oscillation for a stable
		system. A differential time that is too long may cause system oscillation.  The differential controller acts on the change in the deviation and cannot reduce the interference
		Do not use this function when there is significant interference.
		<u> </u>
~	Ыb	Upper limit of Integral Control
		Default: 100.0
		Settings 0.0–100.0%
		Defines an upper bound for the integral gain (I) and therefore limits the master frequency. The
	<b>I</b>	formula is: Integral upper bound = Maximum Output Frequency (Pr.01-00) x Pr.08-04 %.
		An excessive integral value causes a slow response due to sudden load changes and may
		cause motor stall or machine damage. If so, decrease it to a proper value.


N	88	8-05	PID Output Command Limit				
						Default: 100.0	
			Settings	0.0-110.0%			
		Defines	s the perc	entage of the output command	limit during the PID of	control. The formula is	
		Output	Command	Limit = Maximum Operation Fr	equency (Pr.01-00 x Pr.	08-05 %).	
N	88	8-08	PID Feed	oack Value Display			
						Default: Read only	
			Settings	-200.00–200.00%	_		
	0.5						
×	ដូច	{ - []	PID Delay	Time			
			0 44	0.0.05.0		Default: 0.0	
	0.0	ם כ		0.0–35.0 sec.			
	ÜÜ	i-cu	PID Mode	Selection		Default: 0	
			Settings	0: Serial connection		Delault. 0	
			Settings	1: Parallel connection			
		0: Seria	al connecti	on, use conventional PID contro	 ol structure.	_	
				tion, the proportional gain, inte		gain are independent.	
				nize the P, I and D value to fit yo			
		Pr.08-2	20 determir	es the primary low pass filter	time when in PID contro	ol. Setting a large time	
		consta	nt may slo	v down the drive's response spe	eed.		
		PID control output frequency is filtered with a primary low pass function. This function can filter				his function can filter a	
		mix frequencies. A long primary low pass time means the filter degree is high and a short					
		•	•	time means the filter degree is l			
			•	y time setting may cause syste	m oscillation.		
		PI Con		, the D action as the deviction	a account he entirely alic	minated in several to	
			•	y the P action, so the deviation	•	_	
		eliminate residual deviations, use the P + I control. When you use the PI control, it eliminates the deviation caused by the targeted value changes and the constant external interferences					
				ction is too powerful, it delays t			
				on by itself to control the loadin	·	•	
		PD Co	ntrol:				
		When	deviation o	ccurs, the system immediately g	generates an operation l	oad that is greater than	
		the loa	d generate	d only by the D action to restr	ain the deviation increm	nent. If the deviation is	
				veness of the P action decr		•	
				integral component loads, v		•	
				integral component is functioning			
				ol to reduce the P action's oscill		system. In other words,	
		PID Co		ul with no brake function's load	ing over the processes.		
				o eliminate the deviation and th	e D action to reduce os	cillation; then combine	

this with the P action for the PID control. Use the PID method for a control process with no deviations, high accuracies and a stable system.

#### Serial connection



#### **Parallel connection**



## ★ ☐ ☐ ☐ ☐ ☐ ☐ Feedback Signal Detection Time

Default: 0.0

Settings 0.0-3600.0 sec.

- □ Valid only when the feedback signal is ACI (4–20 mA).
- This parameter sets the detection time for abnormal PID signal feedback. You can also use it when the system feedback signal response is extremely slow. (Setting the detection time to 0.0 disables the detection function.)

### 

Default: 0

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: Warn and operate at last frequency

- □ Valid only when the feedback signal is ACI (4–20 mA).
- Sets the treatments when the PID feedback signal is abnormal.


N	$\Omega S$	R - IR Sleep Level	
	~ ~	Default: 0.0	00
		Settings 0.00–599.00 Hz or 0–200.00%	-
		Determines the sleep level, and if the sleep time and the wake-up level are enabled o	r disabled.
		When Pr.08-10 = 0: Disabled; when Pr.08-10 ≠ 0: Enabled.	
N	88	🖁 - 🚶 Wake-up Level	
		Default: 0.0	00
		Settings 0.00–599.00 Hz or 0–200.00%	
		When Pr.08-18 = 0, the unit for Pr.08-10 and that for Pr.08-11 switch to frequency. The	ne settings
		become 0.00-599.00 Hz.	
		When Pr.08-18 = 1, the unit for Pr.08-10 and that for Pr.08-11 switch to percentage. The are between 0–200.00%.	ne settings
		The percentage is based on the current command value, not the maximum value. For	example, if
		the maximum value is 100 kg, and the current command value is 30 kg, then if Pr.08-	11 = 40%,
		the value is 12 kg.	
		Pr.08-10 uses the same logic for calculation.	
N	$\Omega S$	R - 12 Sleep Delay Time	
,	00	Default: 0.0	)
		Settings 0.0–6000.0 sec.	
		When the frequency command is smaller than the sleep frequency and less than the s	sleep time,
		the frequency command is equal to the sleep frequency. However, the frequency	<u>-</u>
		remains at 0.00 Hz until the frequency command becomes equal to or larger than the	e wake-up
		frequency.	
	$\cap i$	8 - 13 PID Feedback Signal Error Deviation Level	
~	U	Default: 10.	0
		Settings 1.0–50.0%	.0
<b>₩</b>	$\cap$ (	PID Feedback Signal Error Deviation Detection Time	
,	U	Default: 5.0	)
		Settings 0.1–300.0 sec.	,
			od of time
		that is close to the target value.	
		•	rol, if IPID
		reference target value – detection value  > Pr.08-13 PID Feedback Signal Error Devia	•
		and exceeds Pr.08-14 setting, it is regarded as a PID control fault, and the multi-func	tion output
		terminal setting 15 (PID feedback error) activates.	
/	0.0	O. I.C. DID Common anastian Calcution	
×	ÜÜ	PID Compensation Selection	
		Default: 0	
		Settings 0: Parameter setting (Pr.08-17)	
		1: Analog input	

		1: Set	the analog	Pr.08-17 gives the PID compensation value. g input (Pr.03-00–Pr.03-02) to 13, then the PID comper I on Pr.08-17. At this time, Pr.08-17 is read only.	nsation value of analog
<b>~</b>	88	! - ! ]	PID Com	pensation	
					Default: 0.0
			Settings	-100.0–100.0%	
			•	nsation value = maximum PID target value × Pr.08-1	•
			•	ion frequency Pr.01-00 = 60.00 Hz, Pr.08-17 = 10.0%,	·
		value ir	ncreases t	he output frequency 6.00 Hz. 60.00 Hz × 100.00% × 10	.0% = 6.00 Hz
	88	1- 18	Sleep Mo	de Function Setting	
					Default: 0
			Settings	0: Refer to PID output command	
				1: Refer to PID feedback signal	
				Pr.08-10 and that for Pr.08-11 switch to frequency. The	e settings are between
	~~		99.00 Hz.		
				r.08-10 and that for Pr.08-11 switch to percentage. The	e settings are between
		0–200.	00%.		
<b>V</b>	88	!- :9	Wake-up	Integral Limit	
					Default: 50.0
			Settings	0.0–200.0%	
			•	egral limit for the drive prevents suddenly running at high	·
			•	es the wake-up integral frequency limit = (Pr.01-00 × Pr.0	08-19%)
		Reduce	es the read	ction time from sleep to wake-up.	
	88	! - 2	Enable P	ID to Change the Operation Direction	
					Default: 0
			Settings	0: Operation direction cannot be changed	
				1: Operation direction can be changed	
<b>V</b>	88	1-22	Wake-up	Delay Time	
					Default: 0.00
			Settings	0.00-600.00 sec.	
		Refer to	o Pr.08-18	for more information.	

There are three scenarios for the sleep and wake-up frequency. Refer to following explanations:

### 1. Frequency Command (PID is not in use, Pr.08-00 = 0. Works only in VF mode)


When the output frequency ≤ the sleep frequency, and the drive reaches the preset sleep time, then the drive is in sleep mode (0 Hz). When the Frequency command reaches the wake-up frequency, the drive starts to count the wake-up delay time. When the drive reaches the wake-up delay time, it starts to catch up to reach the Frequency command value by the acceleration time.



### 2. Internal PID Calculation Frequency Command (PID is in use, Pr.08-00 ≠ 0 and Pr.08-18 = 0)

When the PID calculation Frequency command reaches the sleep frequency, the drive starts to count the sleep time and the output frequency starts to decrease. If the drive exceeds the preset sleep time, then the drive is in sleep mode (0 Hz). If the drive does not reach the preset sleep time, it remains at the lower frequency limit (if there is a preset of lower limit), or it remains at the minimum output frequency set at Pr.01-07 and waits until it reaches the sleep time before it going into sleep mode (0 Hz). When the PID calculated Frequency command reaches the wake-up frequency, the drive starts to count the wake-up delay time. Once it reaches the wake-up delay time, the drive starts to catch up to reach the PID Frequency command value by the acceleration time.

### Internal PID Calculation Frequency Command



### 3. PID Feedback Value Rate Percentage (PID is in use, Pr.08-00 ≠ 0 and Pr.08-18 = 1)

When the PID feedback value reaches the sleep level percentage, the drive starts to count the sleep time and the output frequency starts to decrease. If the drive exceeds the preset sleep time, then the drive is in sleep mode (0 Hz). If the drive does not reach the preset sleep time, it remains at the lower frequency limit (if there is a preset of lower limit.), or it remains at the minimum output frequency set for Pr.01-07 and waits until it reaches the sleep time before going into sleep mode (0 Hz).

When the PID feedback value reaches the wake-up percentage, the drive starts to count the wake-up delay time. Once it reaches the wake-up delay time, the drive starts to catch up to reach the PID Frequency command value by the acceleration time.

### Example 01: PID negative feedback

- Pr.08-10 must > Pr.08-11
- 30 kg is the reference
- Set the parameter:

Pr.03-00 = 5 (AVI1 is PID feedback)

Pr.08-00 = 1 (PID negative feedback: AVI1

simulation input function select)

Pr.08-10 = 40% (Sleep reference:

 $12 \text{ kg} = 40\% \times 30 \text{ kg}$ 


Pr.08-11 = 20% (Wake-up reference:

 $6 \text{ kg} = 20\% \times 30 \text{ kg}$ 

Case 01: If feedback > 12 kg, frequency decreases.

Case 02: If feedback < 6 kg, frequency increases.

Area	PID		
Area	Physical quantity		
Cloop	> 12 kg, the drive goes		
Sleep	into sleep, the motor		
area	goes into sleep		
Excessive	between 6 kg and 12		
	kg, the drive remains in		
area	current state		
Make up	< 6 kg, the drive		
Wake-up	wakes-up, the motor		
area	wakes-up		



Example 02: PID positive feedback

- Pr.08-10 must < Pr.08-11</li>
- 30 kg is the reference
- Set the parameter:

Pr.03-00 = 5 (AVI1 is PID feedback)

Pr.08-00 = 4 (PID positive feedback: AVI1

simulation input function select)

Pr.08-10 = 110% (Sleep reference:

 $33 \text{ kg} = 110\% \times 30 \text{ kg}$ 


Pr.08-11 = 120% (Wake-up reference:

 $36 \text{ kg} = 120\% \times 30 \text{ kg}$ 

Case 01: If feedback < 33 kg, frequency decreases.

Case 02: If feedback > 36 kg, frequency increases.

Area	PID		
Alea	Physical quantity		
Sleep	> 36 kg, the drive goes		
•	into sleep, the motor		
area	goes into sleep		
Funnaius	between 33 kg and 36		
Excessive	kg, the drive remains in		
area	the current state		
Wake-up	< 33 kg, the drive		
area	wakes-up		



### **09 Communication Parameters**

✓ You can set this parameter during the operation.

When using the communication interface, the diagram on the right shows the communication port pin definitions. We recommend that you connect the AC motor drive to your PC by using Delta IFD6530 orIFD6500 as a communication converter.



Modbus RS-485 Pin 1, 2, 6: Reserved Pin 3, 7: SGND

Pin 4: SG-Pin 5: SG+

Pin 8: +10VS

✓ ☐ G - ☐ ☐ Communication Address

Default: 1

Settings 1-254

Sets the communication address for the drive if the AC motor drive is controlled through RS-485 serial communication. The communication address for each AC motor drive must be unique.

✓ ☐ ☐ ☐ COM1 Transmission Speed

Default: 9.6

Settings 4.8–115.2 Kbps

Sets the transmission speed between the computer and the AC motor drive.

Options are 4.8 Kbps, 9.6 Kbps, 19.2 Kbps, 38.4 Kbps, 57.6 Kbps or 115.2 Kbps; otherwise, the transmission speed is set to the default 9.6 Kbps.

✓ ☐ ☐ ☐ COM1 Transmission Fault Treatment

Default: 3

Settings 0: Warn and continue operation

1: Fault and ramp to stop

2: Fault and coast to stop

3: No warning, no fault and continue operation

Determines the treatment when an error is detected that the host controller does not continuously transmit data to the AC motor drive during Modbus communication. The detection time is based on the Pr.09-03 setting.

COM1 Time-out Detection

Default: 0.0

Settings 0.0-100.0 sec.

Sets the communication transmission time-out value.

✓ 🔐 🖁 - 🖁 🖁 COM1 Communication Protocol

Default: 1

Settings 1: 7, N, 2 (ASCII)

2: 7, E, 1 (ASCII)

3: 7, O, 1 (ASCII)

4: 7, E, 2 (ASCII)

5: 7, O, 2 (ASCII)

6: 8, N, 1 (ASCII)

7: 8, N, 2 (ASCII)

8: 8, E, 1 (ASCII)

9: 8, O, 1 (ASCII)

10: 8, E, 2 (ASCII)

11: 8, O, 2 (ASCII)

12: 8, N, 1 (RTU)

13: 8, N, 2 (RTU)

14: 8, E, 1 (RTU)

15: 8, O, 1 (RTU)

16: 8, E, 2 (RTU)

17: 8, O, 2 (RTU)

### Control by PC (Computer Link)

When using the RS-485 serial communication interface, you must specify each drive's communication address in Pr.09-00. The computer then implements control using the drives' individual addresses.

Modbus ASCII (American Standard Code for Information Interchange): Each byte of data is the combination of two ASCII characters. For example, one byte of data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

### 1. Code Description

The communication protocol is in hexadecimal, ASCII: "0"..."9", "A"..."F", every hexadecimal value represents an ASCII code. The following table shows some examples:


Character	'0'	'1'	'2'	'3'	<b>'4'</b>	'5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H

Character	'8'	'9'	'A'	'B'	,C,	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H


#### 2. Data Format

10-bit character frame (For ASCII):


(7, N, 2)



(7, E, 1)




(7, O, 1)




11-bit character frame (For RTU):














### 3. Communication Protocol

### 3.1 Communication Data Frame:

### **ASCII** mode

STX	Start character = ':' (3AH)
Address High	Communication address:
Address Low	one 8-bit address consists of 2 ASCII codes
Function High	Command code:
Function Low	one 8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
	n × 8-bit data consist of 2n ASCII codes
DATA 0	n ≤ 16, maximum of 32 ASCII codes
LRC Check High	LRC checksum:
LRC Check Low	one 8-bit checksum consists of 2 ASCII codes
END High	End characters:
END Low	END1 = CR (0DH), END0 = LF(0AH)

### **RTU** mode

START	Defined by a silent interval of larger than / equal to 10 ms
Address	Communication address: 8-bit binary address
Function	Command code: 8-bit binary command
DATA (n-1)	Contents of data:
	n × 8-bit data, n ≤ 16
DATA 0	11 ^ 0-bit data, 11 ≥ 10
CRC Check Low	CRC checksum:
CRC Check High	one 16-bit CRC checksum consists of 2 8-bit binary
	characters
END	Defined by a silent interval of larger than / equal to 10 ms

### 3.2 Communication Address ( Address )

00H: broadcast to all AC motor drives

01H: AC motor drive of address 01 0FH: AC motor drive of address 15

10H: AC motor drive of address 16

:

FEH: AC motor drive of address 254

### 3.3 Function (Function code) and DATA (data characters)

03H: read data from register

06H: write single register

10H: write continuous multiple data

Example: Reading two continuous data from register address 2102H, AMD address is 01H.

#### **ASCII** mode:

Command Message:

STX	· . ·	STX	( , ) -
Address	'0'	Address	<b>'</b> 0'
Addless	'1'	Address	<b>'1'</b>
Function	'0'	Function	<b>'</b> 0'
FullCuon	<b>'3'</b>	Function	<b>'3'</b>
	'2'	Number of register	<b>'</b> 0'
Starting register	'1'	(count by byte)	<b>'4'</b>
Starting register	<b>'</b> 0'	Content of starting register 2102H	<b>'1'</b>
	'2'		<b>'7'</b>
	<b>'</b> 0'		<b>'7'</b>
Number of register	<b>'</b> 0'		<b>'</b> 0'
(count by word)	<b>'</b> 0'		<b>'</b> 0'
	<b>'2'</b>	Content of register	<b>'</b> 0'
LRC Check	'D'	2103H	<b>'</b> 0'
LRC Check	<b>'7'</b>		<b>'</b> 0'
END	CR	LRC Check	<b>'7'</b>
END	LF	LRC Check	<b>'1'</b>
		END	CR

### RTU mode:

Command Message:

Response Message

Command Meccago:			
01H			
03H			
21H			
02H			
00H			
02H			
6FH			
F7H			

Address	01H
Function	03H
Number of register (count by byte)	04H
Content of register	17H
address 2102H	70H
Content of register	00H
address 2103H	00H
CRC Check Low	FEH
CRC Check High	5CH

06H: single write, write single data to register.

Example: Writing data 6000 (1770H) to register 0100H. AMD address is 01H.

#### **ASCII** mode:

Command Message:

Response Message

Command	Message:	Response Message	
STX	(.) -	STX	( . ;
Address	·0'	Address	'0'
Address	<b>'1'</b>	Address	<b>'1'</b>
Function	<b>'</b> 0'	Function	<b>'</b> 0'
Function	<b>'6'</b>	FullCuon	<b>'</b> 6'
	'0'		<b>'</b> 0'
Torget register	<b>'1'</b>	Torget register	<b>'1'</b>
Target register	'0'	Target register	<b>'</b> 0'
	<b>'</b> 0'		<b>'</b> 0'
	'1'		<b>'1'</b>
Register content	'7'	Degister centent	<b>'</b> 7'
Register content	'7'	Register content	<b>'</b> 7'
	<b>'</b> 0'		<b>'</b> 0'
LRC Check	'7'	LRC Check	<b>'</b> 7'
LRC Check	<b>'1'</b>	LIC CHECK	<b>'1'</b>
END	CR	END	CR
LIND	LF	LIND	LF

### RTU mode:

Command Message:

Response Message

	3			
Address	01H	Address	01H	
Function	06H	Function	06H	
Target register	01H	Torget register	01H	
Target register	00H	Target register	00H	
Dogistor content	17H	Degister centent	17H	
Register content	70H	Register content	70H	
CRC Check Low	86H	CRC Check Low	86H	
CRC Check High	22H	CRC Check High	22H	

10H: write multiple registers (can write at most 20 sets of data simultaneously).

Example: Set the multi-step speed of an AC motor drive (address is 01H),

Pr.04-00 = 50.00 (1388H), Pr.04-01 = 40.00 (0FA0H).

#### **ASCII** Mode

STX ADR 1

ADR 0

CMD 1 CMD 0

Target register

Number of register

(count by word)

Number of register (count by byte)

The first data content

The second data content

LRC Check

**END** 

Command Message:

'0' '1'

<u>'1'</u>

'0' '0' '4'

'0' '0'

'0'

'0' '2' '0'

'4' '1' '3'

'8' '8' '0' 'F'

'A' '0'

<u>'B'</u> CR

LF

Response Message

STX	.,
ADR 1	'0'
ADR 0	<b>'1'</b>
CMD 1	<b>'1'</b>
CMD 0	'0'
	'0'
Torget register	<b>'4'</b>
Target register	'0'
	'0'
	'0'
Number of register	'0'
(count by word)	'0'
	'2'
LRC Check	'E'
LKC Clieck	<b>'</b> 9'
END	CR
EIND	LF

#### RTU mode:

Command Message:

ADR	01H
CMD	10H
Target register	04H
Target register	00H
Number of register	00H
(Count by word)	02H
Quantity of data (byte)	04
The first data content	13H
The instituata content	88H
The second data	0FH
content	A0H
CRC Check Low	<b>'9'</b>
CRC Check High	'A'

Response Message:

ADR	01H
CMD 1	10H
Target register	04H
rarget register	00H
Number of register	00H
(Count by word)	02H
CRC Check Low	40H
CRC Check High	F8H

### 3.4 Checksum

### (1) ASCII mode (LRC Check):

LRC (Longitudinal Redundancy Check) is calculated by summing up the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example,

01H+03H+21H+02H+00H+02H=29H, the 2's-complement negation of 29H is D7H.

### (2) RTU mode (CRC Check):

- CRC (Cyclical Redundancy Check) is calculated by the following steps:
- Step 1: Load a 16-bit register (called CRC register) with FFFFh.
- **Step 2:** Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.
- Step 3: Examine the LSB of CRC register.
- **Step 4:** If the LSB of CRC register is 0, shift the CRC register one bit to the right, fill MSB with zero, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right, fill MSB with zero, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.
- **Step 5:** Repeat step 3 and 4 until you perform eight shifts. This processes a complete 8-bit byte.
- **Step 6:** Repeat step 2 through 5 for the next 8-bit byte of the command message. Continue doing this until all bytes are processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, that is, the lower order byte is transmitted first.

The following is an example of CRC generation using C language.

The function takes two arguments:

Unsigned char\* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer.

```
Unsigned int crc_chk(unsigned char* data, unsigned char length) {
```

## 4. Address list

AC motor drive parameters (GGxx)

Modbus address	Function
GGnnH	GG is the parameter group, nn is the parameter number; for example, the address of
GGIIIII	Pr.04-10 is 040AH.

### Control command (20xx)

Modbus address	R/W		Function
			00B: No function
		L:44 O	01B: Stop
		bit1–0	10B: Run
			11B: JOG + RUN
		bit3-2	Reserved
			00B: No function
		hitE 1	01B: FWD
		bit5–4	10B: REV
			11B: Change direction
			00B: 1st acceleration / deceleration
		h:+7 C	01B: 2 <sup>nd</sup> acceleration / deceleration
		bit7–6	10B: 3 <sup>rd</sup> acceleration / deceleration
			11B: 4 <sup>th</sup> acceleration / deceleration
			0000B: Master speed
		,	0001B: 1st Step speed frequency
2000H	RW		0010B: 2 <sup>nd</sup> Step speed frequency
			0011B: 3 <sup>rd</sup> Step speed frequency
			0100B: 4 <sup>th</sup> Step speed frequency
			0101B: 5 <sup>th</sup> Step speed frequency
			0110B: 6 <sup>th</sup> Step speed frequency
		P:+11 0	0111B: 7 <sup>th</sup> Step speed frequency
		bit11–8	1000B: 8 <sup>th</sup> Step speed frequency
			1001B: 9th Step speed frequency
			1010B: 10 <sup>th</sup> Step speed frequency
			1011B: 11 <sup>th</sup> Step speed frequency
			1100B: 12 <sup>th</sup> Step speed frequency
			1101B: 13 <sup>th</sup> Step speed frequency
			1110B: 14 <sup>th</sup> Step speed frequency
			1111B: 15 <sup>th</sup> Step speed frequency
		bit12	1: Enable bit06–11 function
		bit15	Reserved
2001H	RW	Frequency	command (XXX.XX Hz)

Modbus address	R/W	Function	
		bit0	1: E.F. ON
200211 DW	bit1	1: Reset	
2002H	RW	bit2	1: Base block (B.B) ON
		bit15-3	Reserved

# Status monitor read only (21xx)

Modbus address	R/W		Function	
240011	D	High byte: Warn Code		
2100H	R	Low Byte:	Error Code	
			AC motor drive operation status	
		bit1-0	00B: Drive stops	
			01B: Drive decelerating	
			10B: Drive standby	
			11B: Drive operating	
		bit2	1: JOG Command	
			Operation Direction	
		bit4-3	00B: FWD run	
			01B: From REV run to FWD run	
2101H	R		10B: From FWD run to REV run	
			11B: REV run	
		bit8	1: Master frequency controlled by communication interface	
		bit9	1: Master frequency controlled by analog/external signal	
		bit10	1: Operation command controlled by communication interface	
		bit11	1: Parameter locked	
		bit12	1: Enable to copy parameters from keypad	
		bit15-13	Reserved	
2102H	R	Frequency	Frequency command (XXX.XX Hz)	
2103H	R	Output free	quency (XXX.XX Hz)	
2104		Output cur	Output current (XX.XX A). When current is higher than 655.35, it shifts the	
2104H	R	decimal as (XXX.X A). The decimal can refer to High byte of 211F.		
2105H	R	DC bus Vo	DC bus Voltage (XXX.X V)	
2106H	R	Output vol	Output voltage (XXX.X V)	
2107H	R	Current step number of multi-step speed operation		
2108H	R	Reserved		
2109H	R	Counter va	alue	
210AH	R	Power fact	Power factor angle (XXX.X)	
210CH	R	Actual mo	Actual motor speed (XXXXX rpm)	
210DH	R	Reserved		

### Chapter 12 Description of Parameter Settings | CP2000

Modbus address	R/W	Function
210EH	R	Reserved
210FH	R	Power output (X.XXX kW)
2116H	R	Multi-function display (Pr.00-04)
		Maximum Operation Frequency (Pr.01-00) or Maximum User-defined Value
		(Pr.00-26)
		When Pr.00-26 is 0, this value is equal to Pr.01-00 setting
211BH	R	When Pr.00-26 is not 0, and the command source is keypad, this value =
		Pr.00-24 × Pr.00-26 / Pr.01-00
		When Pr.00-26 is not 0, and the command source is 485, this value =
	Pr.09-10 × Pr.00-26 / Pr.01-00	
211FH	R	High byte: decimal of current value (display)

## Status monitor read only (22xx)

Modbus address	RW	Function
2200H	220011	Display output current (A). When current is higher than 655.35, it shifts the
220011	R	decimal as (XXX.X A). The decimal can refer to High byte of 211F.
2201H	R	Display counter value ©
2202H	R	Actual output frequency (XXXXX Hz)
2203H	R	DC bus voltage (XXX.X V)
2204H	R	Output voltage (XXX.X V)
2205H	R	Power angle (XXX.X)
2206H	R	Display actual motor speed kW of U, V, W (XXXX.X kW)
22074	D	Display motor speed in rpm estimated by the drive or encoder feedback
2207H	R	(XXXXX rpm)
2208H	R	Display positive/negative output torque in %, estimated by the drive (XXX.X
220011	220011	%)
2209H	R	Reserved
220AH	R	PID feedback value after enabling PID function (XXX.XX %)
220BH	20BH R	Display signal of AVI1 analog input terminal, 0-10 V corresponds to
220011		0.00-100.00% (1.) (see NOTE 2 in Pr.00-04)
220CH	R	Display signal of ACI analog input terminal, 4–20 mA / 0–10 V corresponds
220011	1	to 0.00-100.00% (2.) (see NOTE 2 in Pr.00-04)
220DH	R	Display signal of AVI2 analog input terminal, -10 V-10 V corresponds to
220011	220DH	-100.00-100% (3.) (see NOTE 2 in Pr.00-04)
220EH	R	IGBT temperature of drive power module (XXX.X°C)
220FH	R	The temperature of capacitance (XXX.X°C)
2210H	R	The status of digital input (ON/OFF), refer to Pr.02-12
221011	IX.	(see NOTE 3 in Pr.00-04)

Modbus address	RW		Function	
2211H	R	The status of digital output (ON/OFF), refer to Pr.02-18 (see NOTE 4 in Pr.00-04)		
2211П	K			
2212H	R	The multi-s	step speed that is executing (S)	
2213H	R		sponding CPU pin status of digital input (d.) E 3 in Pr.00-04)	
2214H	R		sponding CPU pin status of digital output (O.) E 4 in Pr.00-04)	
2215H	R	Reserved		
2216H	R	Reserved		
2217H	R	Reserved		
2218H	R	Reserved		
2219H	R	Display tim	nes of counter overload (XXX.XX %)	
221AH	R	GFF (XXX	.XX %)	
221BH	R	DC bus vo	Itage ripples (XXX.X V)	
221CH	R	PLC regist	er D1043 data (C)	
221DH	R	Reserved		
221EH	R	User page	displays the value in physical measure	
221FH	R	Output Value of Pr.00-05 (XXX.XX Hz)		
000011	R	Number of	f motor turns when drive operates (saves when drive stops, and	
2220H		resets to z	ero when operating)	
2221H	R		Operating position of the motor (saves when drive stops, and resets to zero when operating)	
2222H	R	•	of the drive (XXX %)	
2223H	R	•	ode of the drive 0: speed mode	
2224H	R		quency of the drive (XXXX kHz)	
2225H	R	Reserved	44	
		Drive status bit1–0	00b: No direction 01b: Forward 10b: Reverse	
2226H	R	bit3-2	01b: Drive ready 10b: Error	
		bit4	0b: Motor drive did not output 1b: Motor drive did output	
		bit5	0b: No alarm 1b: Alarm	
2228H	R	Reserve	1	
2229H	R	kWh displa	ay (XXXX.X)	
222AH	R	Reserve		

Modbus address	RW	Function
222BH	R	Reserve
222CH	R	Reserve
222DH	R	Reserve
222EH	R	PID reference (XXX.XX %)
222FH	R	PID offset (XXX.XX %)
2230H	R	PID output frequency (XXX.XX Hz)
2231H	R	Hardware ID

## Remote IO (26xx)

,			
Modbus address	RW	Function	
2600H	R	Each bit corresponds to different terminal input contact	
2640H	RW	Each bit corresponds to different terminal output contact	
2660H	R	AVI1 proportional value	
2661H	R	ACI proportional value	
2662H	R	AVI2 proportional value	
266AH	R	Extension card AI10, 0.0–100.0% (EMC-A22A)	
266BH	R	Extension card Al11, 0.0–100.0% (EMC-A22A)	
26A0H	RW	AFM1 output proportional value	
26A1H	RW	AFM2 output proportional value	
26AAH	RW	Extension card AO10, 0.0–100.0% (EMC-A22A)	
26ABH	RW	Extension card AO11, 0.0–100.0% (EMC-A22A)	

### 5. Exception response:

When the drive is using the communication connection, if an error occurs, the drive responds to the error code and sets the highest bit (bit7) of the command code to 1 (function code AND 80H), then responds to the control system to signal that an error occurred.

If the keypad displays "CE-XX" as a warning message, "XX" is the error code at that time. Refer to the table of error codes for communication error for reference.

### Example:

### ASCII mode:

#### RTU mode:

Accii	moue.	KTO IIIOGE.		
STX	1.1	Address	01H	
Address	'0'	Function	86H	
Address	<b>'1'</b>	Exception code	02H	
Function	'8'	CRC Check Low	C3H	
Function	'6'	CRC Check High	A1H	
Evention code	'0'			
Exception code	'2'			
LRC Check	'7'			
LING CHECK	<b>'7'</b>			
END	CR			
LIND	LF			

The explanation of exception codes:


Exception code	Explanation
1	Function code is not supported or unrecognized.
2	Address is not supported or unrecognized.
3	Data is not correct or unrecognized.
4	Failure to execute this function code
10	Transformation for over-time duration

# ✓ ☐ ☐ ☐ ☐ ☐ Communication Response Delay Time

Default: 2.0

## Settings 0.0-200.0 ms

If the host controller does not finish the transmitting / receiving process, you can use this parameter to set the response delay time after the AC motor drive receives communication command as shown in the following picture.



# ☐ ☐ ☐ Communication Main Frequency

Default: 60.00

### Settings 0.00-599.00 Hz

When you set Pr.00-20 to 1 (RS-485 serial communication input), the AC motor drive saves the last Frequency command into Pr.09-10 when there is abnormal power off or momentary power loss. When power is restored, the AC motor drive operates with the frequency in Pr.09-10 if no new Frequency command input. When a Frequency command of RS-485 changes (the frequency command source must be set as Modbus), this parameter also changes.

×	89-11	Block Transfer 1
×	09 - 12	Block Transfer 2
×	09-13	Block Transfer 3
×	09-14	Block Transfer 4
×	09-15	Block Transfer 5
×	09-18	Block Transfer 6
×	89- ; ;	Block Transfer 7
×	81 - 20	Block Transfer 8
×	09-19	Block Transfer 9
×	09-20	Block Transfer 10
×	09-21	Block Transfer 11
×	09-22	Block Transfer 12
×	09-23	Block Transfer 13
×	09-24	Block Transfer 14
×	89-25	Block Transfer 15
×	89-28	Block Transfer 16

Default: 0000

#### Chapter 12 Description of Parameter Settings | CP2000

There is a group of block transfer parameters available in the AC motor drive (Pr.09-11-
Pr.09-26). Using communication code 03H, you can store the parameters (Pr.09-11-Pr.09-26)
that you want to read.

For example: according to the Address List (as shown in the table below), Pr.01-42 is shown as 012A. Set Pr.09-11 to 012Ah (the minimum voltage of Pr.01-42 M2 is 2.0 V), and use Pr.09-11 (communication address 090B) to read the communication parameter, the read value is 2.0.

AC motor drive	GGnnH	GG is the parameter group, nn is the parameter number; for
parameters	GGIIII	example, the address of Pr.04-10 is 040AH.

Mind if the transfer parameters are read only. If the data is written to read-only paraemters from the upper unit, a communication error may occur.

# G 9 - 3 € Communication Decoding Method

Default: 1

Settings 0: Decoding Method 1 (20xx) 1: Decoding Method 2 (60xx)

The EtherCAT communication card only supports Decoding Method 2 (60xx).

		Decoding Method 1	Decoding Method 2	
	Digital Keypad	Digital keypad controls the drive action regardless of decoding method 1 or 2.		
Source of	External Terminal	External terminal controls the drive action regardless of decoding method 1 or 2.		
Source of	RS-485	Refer to address: 2000h–20FFh	Refer to address: 6000h–60FFh	
Operation Control	CANopen	Refer to index: 2020-01h-2020-FFh	Refer to index: 2060-01h-2060-FFh	
	Communication Card	Refer to address: 2000h–20FFh Refer to address: 6000h–60FFh		
	PLC	PLC commands controls the drive action regardless of decoding method 1 or 2.		

# 

Default: 0

Settings 1: BACnet

0: Modbus 485

-1: Internal Communication Slave 1

-2: Internal Communication Slave 2

-3: Internal Communication Slave 3

-4: Internal Communication Slave 4

-5: Internal Communication Slave 5

-6: Internal Communication Slave 6

-7: Internal Communication Slave 7

-8: Internal Communication Slave 8

-10: Internal Communication Master

-12: Internal PLC Control

When it is defined as internal communication, refer to Section 16-10 for Main Control Terminal of Internal Communication.

When it is defined as internal PLC control, refer to Section 16-12 for Remote IO Control Application (using MODRW).

		Chapter 12 Description of Par	ameter Settings   CP2000
× 89-33	PLC Com	mand Force to 0	
02 22			Default: 0000
	Setting	bit0: Before PLC scans, set the PLC target frequency =	= 0
Defines		e Frequency command or the Speed command must be	
		rts the next scan.	
09-35	PLC Addr	ess	
			Default: 2
	Settings		_
09-38	CANopen	Slave Address	
			Default: 0
	Settings	0: Disable	
		0–127	
89-37	CANopen	Speed	
			Default 0
	Settings	0: 1 Mbps	
		1: 500 Kbps	
		2: 250 Kbps	
		3: 125 Kbps	
		4: 100 Kbps (Delta only)	
		5: 50 Kbps	
89-39	CANopen	Warning Record	
			Default: Ready only
	Settings	bit0: CANopen Guarding Time-out	
		bit1: CANopen Heartbeat Time-out	
		bit2: CANopen SYNC Time-out	
		bit3: CANopen SDO Time-out	
		bit4: CANopen SDO Buffer Overflow	
		bit5: CANopen hardware disconnection warning (Can E	Bus Off)
		bit6: Error protocol of CANopen	
		bit8: The setting values of CANopen indexes are fail	
		bit9: The setting value of CANopen address is fail	
		bit10: The checksum value of CANopen indexes is fail	
09-40	CANopen	Decoding Method	
			Default: 1
	Settings	0: Disable (Delta-defined decoding method)	
		1: Enable (CANopen DS402 Standard protocol)	

CANopen Communication Status

Default: Read Only

Settings 0: Node Reset State

1: Com Reset State

2: Boot up State

#### Chapter 12 Description of Parameter Settings | CP2000

- 3: Pre-operation State
- 4: Operation State
- 5: Stop State

## CANopen Control Status

Default: Read Only

Settings 0: Not ready for use state

- 1: Inhibit start state
- 2: Ready to switch on state
- 3: Switched on state
- 4: Enable operation state
- 7: Quick stop active state
- 13: Error reaction activation state
- 14: Error state

# **GS-45** CANopen Master Function

Default: 0

Settings 0: Disable

1: Enable

# CANopen Master Address

Default: 100

Settings 0-127

## CANopen Extension Setting

Default: 0002h

Settings bit0: Update Index 604F and 6050 to Acceleration / Deceleration time 1

bit0 = 0: Enabled (default)

bit0 = 1: Disabled

bit1: Distinguish the CANopen identity code by models or by series

bit1 = 0: Distinguish the CANopen identity code by models

bit1 = 1: Distinguish the CANopen identity code by series

- bit0 = 0, the drive directly controls Acceleration time 1 (Pr.01-12) and Deceleration time 1 (Pr.01-13).
- bit1 = 0: each model of different series of drives has its own EDS file, this setting is more complicated to use.

bit1 = 1: distinguish the CANopen identity code by the drive's serie, which requires only one EDS file.

# BACnet MS / TP Node Address

Default: 10

Settings 0-127

# BACnet Baud Rate

Default: 38.4

Settings 9.6–76.8 Kbps

09-52	BACnet [	Device ID L	
			Default: 10
	Settings	0–65535	
00 -63	DAO:-+5	Davisa ID II	
09-53	BACnet L	Device ID H	
			Default: 0
	Settings		
09-55	BACnet N	Max Address	
			Default: 127
	Settings	0–127	
09-58	BACnet F	Password	
			Default: 0
	Settings	0–65535	
09-80	Identification	tions for Communication Card	
			Default: Read only
	Settings	0: No communication card	
		1: DeviceNet Slave	
		2: Profibus-DP Slave	
		3: CANopen Slave / Master	
		4: Modbus-TCP Slave	
		5: EtherNet / IP Slave	
		8: BACnet IP	
		12: PROFINET	
09-61	Firmware	Version of Communication Card	
			Default: Read only
	Settings	Read only	
09-62	Product C	Code	
			Default: Read only
	Settings	Read only	-
89-83	Error Cod	le	
			Default: Read only
	Settings	Read only	•
		•	
89-78	Communi	cation Card Address (for DeviceNet or PROFIBUS)	
			Default: 1
	Settings	DeviceNet: 0-63	
		Profibus-DP: 1–125	

× 89-71	Communication Card Speed Setting (for DeviceNet)	
	-	Default: 2
	Settings Standard DeviceNet:	
	0: 125 Kbps	
	1: 250 Kbps	
	2: 500 Kbps	
	3: 1 Mbps (Delta only)	
	Non standard DeviceNet : (Delta only)	
	0: 10 Kbps	
	1: 20 Kbps	
	2: 50 Kbps	
	3: 100 Kbps	
	4: 125 Kbps	
	5: 250 Kbps	
	6: 500 Kbps	
	7: 800 Kbps	
	8: 1 Mbps	
× 89-72	Additional Settings for Communication Card Speed (for DeviceN	et)
		Default: 0
	Settings 0: Standard DeviceNet	
	In this mode, the baud rate can only be 125 Kbps, 2	250 Kbps, and 500 Kbps
	in standard DeviceNet speed.	
	1: Non-standard DeviceNet	no so that far CANianan
	In this mode, the DeviceNet baud rate can be san (0–8).	ne as that for CANopen
Use the second of the secon	his parameter with Pr.09-71.	
🚇 0: The	e baud rate can only be set to 125 Kbps, 250 Kbps and 500 Kbps a	s a standard DeviceNet
speed		
🕮 1: The	e DeviceNet communication rate can be the same as that for CAN	open (setting 0-8).
× 89-75	Communication Card IP Configuration (for Modbus TCP)	
		Default: 0
	Settings 0: Static IP	
	1: DynamicIP (DHCP)	
	t the IP address manually. address is dynamically set by the host controller.	
× 89-78	•	
	` '	
/ US- 11	Communication Card IP Address 2 (for Modbus TCP)	
× 99-78	, ,	
× 89-79	Communication Card IP Address 4 (for Modbus TCP)	D ( II 0
	Sottings 0 SEESE	Default: 0
<b>™ U</b> ¬	Settings 0–65535	
■ Use P	Pr.09-76–09-79 with a communication card.	

				go   01 2000			
×	88-88	Communi	ication Card Address Mask 1 (for Modbus TCP)				
×	03-8 :	Communication Card Address Mask 2 (for Modbus TCP)					
×	09-82	Commun	ication Card Address Mask 3 (for Modbus TCP)				
×	09-83	Commun	ication Card Address Mask 4 (for Modbus TCP)				
				Default: 0			
		Settings	0–65535				
×	09-84	Communi	ication Card Gateway Address 1 (for Modbus TCP)				
×	09-85	Communi	ication Card Gateway Address 2 (for Modbus TCP)				
×	09-88	Communi	ication Card Gateway Address 3 (for Modbus TCP)				
×	89-87	Communi	ication Card Gateway Address 4 (for Modbus TCP)				
				Default: 0			
		Settings	0–65535				
×	09-88	Commun	ication Card Password (Low word) (for Modbus TCP)				
×	09-89	Commun	ication Card Password (High word) (for Modbus TCP)				
				Default: 0			
		Settings	0–99				
×	09-90	Reset Co	mmunication Card (for Modbus TCP)				
				Default: 0			
		Settings	0: Disable				
			1: Reset to defaults				
N	89-91	Additiona	I Setting for the Communication Card (for Modbus TCP)	)			
				Default: 1			
		Settings	bit0: Enable IP Filter				
			bit1: Enable internet parameters (1bit)				
			When the IP address is set, this bit is enable	ed. After updating the			
			parameters for the communication card, this bit c	hanges to disabled.			
			bit2: Enable login password (1bit)				
			When you enter the login password, this bit is ena	abled. After updating the			
			communication card parameters, this bit changes	to disable.			
	09-92	Commun	ication Card Status (for Modbus TCP)				
				Default: 0			
		Settings	bit0: Enable password				
			When the communication card is set with a passv	word, this bit is enabled.			
			When the password is cleared, this bit is disabled	<del>1</del>			

# **10 Sensorless Motor Control Parameters**

			✓ You can set thi	s parameter during operation.
× H	} - ₩₩ Trea	atmen	t for Speed Observer Feedback Fault	o paramotor dannig operation.
			-	Default: 2
	Sett	tings	0: Warn and continue operation	
		J	1: Fault and ramp to stop	
			2: Fault and coast to stop	
× H	} - {}	ection	Time of Speed Observer Feedback Fault	
				Default: 1.0
	Sett	tings	0.0-10.0 sec.	
			0: Disable	
	When speed	d obse	erver outputs an abnormal signal, or the rotation	direction is different with the
	detected dire	ection	from speed observer, and the fault time exceed	s the detection time of speed
	observer fee	edback	fault (Pr.10-09), a reverse direction of the speed	feedback (SdRv) fault occurs.
	Refer to Cha	apter 1	4 for solutions.	
× H	- III Spe	ed Ob	server Stall Level	
				Default: 115
	Sett	tings	0–120%	
		J	0: Disable	
	Determines	the fa	ult level of feedback signal. The maximum opera	ation frequency for Pr.01-00 =
M H	-     Det	ection	Time of Speed Observer Stall	
			·	Default: 0.1
	Sett	tings	0.0-2.0 sec.	
× H	] -	ed Ob	server Stall Action	
				Default: 2
	Sett	tings	0: Warn and continue operation	
			1: Fault and ramp to stop	
			2: Fault and coast to stop	
	When the d	rive o	utput frequency exceeds the speed observer st	tall level (Pr.10-10), the drive
	starts to cou	unt the	e time. When the error time exceeds the speed	observer stall detection time
	(Pr.10-11), a solutions.	an ov	er speed rotation feedback (SdOr) fault occu	rs. Refer to Chapter 14 for
w <b>1</b> 1	solutions.			rs. Refer to Chapter 14 for
× 11	solutions.		er speed rotation feedback (SdOr) fault occu	
× 11	solutions.	ed Ob	oserver Slip Range	rs. Refer to Chapter 14 for  Default: 50
× ::	solutions.			

N	!!!	- :4	Detection	Time of Speed	Observer SI	ip			
						·		Default: 0.5	
			Settings	0.0–10.0 sec.				2 3 3 3 3 3 3	
~	!!!	- !5		server Stall and	Slip Error A	Action			
,	''	' _'	opood ox		. op	1011011		Default: 2	
			Settings	0: Warn and c	ontinue oper	ation		Boladii. 2	
			oougo	1: Fault and ra	•	auon			
				2: Fault and co	•				
	Ω,	When th	 ne value of		•	guency) exc	eeds the Pr	10-13 setting, and the	
				•		• • ,		ne detection time exce	
								fer to Chapter 14 for	,000
		solution	_		ou rooubuok	(Cabo) ladi	t ooddio. Ito	ior to Oriaptor 14 for	
,				0 10					
×	ΙÜ	i - ქ i	I/F Mode,	Current Comm	and			D 6 11 40	
			0 "	0.4500/ 1.1				Default: 40	
	~~	<b>.</b>	Settings	0–150% rated					
						<u>-</u>	, .	area: frequency comr	
			,				-	ward / reverse with	
			•		If the inrus	h current is	s too high a	and causes oc stall,	then
	~		•	ameter value.					
				` •		,	_	value for I/F mode Cu	rrent
					n for this pa	rameter exte	ends to high-	speed zone and	
	~		eakening z						
						•		s in flux-weakening zo	
		=			ot accelerate	e, even caus	ses the obse	rver lost control, adjus	st the
		setting	for Pr.10-	31.					
×	- 10	1-32	PM FOC	Sensorless Spe	ed Estimato	r Bandwidth			
								Default: 5.00	
			Settings	0.00-600.00 H	z				
		Sets tl	ne speed	estimator band	width. Adjus	st the parar	neter to cha	ange the stability and	the t
		accura	cy of the n	notor speed.					
		If there	e is low free	quency vibration	the wavefo	orm is simila	r to the sine	wave) during the prod	cess,
		then in	crease the	e bandwidth. If t	here is high	frequency v	ribration (the	waveform shows ext	reme
		vibratio	on and is li	ke a spur), then	decrease th	ne bandwidtl	า.		
N	15	}-33	PM FOC	Sensorless Spe	ed Estimato	or Bandwidth	ı (Low Speed	d)	
				to 230V/460V m	odels)				
								Default: 1.00	
			Settings	0.00–600.00 H	Ηz				
		Works	only when	Speed mode is	set as IPM	sensorless	/ SRM senso	orless (Pr.00-11 = 7 or	8).
			•	-				ng start-up and low-s	,

operation.

# **Chapter 12 Description of Parameter Settings | CP2000** When the motor speed during start-up or operation is lower than the frequency to switch from I/F mode to PM sensorless mode (Pr.10-39), and the motor speed oscillates, adjust the setting for this parameter. When Pr.05-33 is set to 3 (SynRM), the unit changes to Pu, the setting upper and lower limit for Pr.10-33 change to 3.00-0.01 and the default is 1.0. PM Sensorless Speed Estimator Low-pass Filter Gain Default: 1.00 Settings 0.00–655.35 Changes the response speed of the speed estimator. If there is low frequency vibration (the waveform is similar to the sine wave) during the process, then increase the gain. If there is high frequency vibration (the waveform shows extreme vibration and is like a spur), then decrease the gain. When Pr.05-33 is set to 3 (SynRM), the setting upper limit is 10.00. AMR (Kp) Gain (applied to 230V / 460V models) Default: 1.00 Settings 0.00–3.00 When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 0.40. AMR (Ki) Gain (applied to 230V / 460V models) Default: 0.20 Settings 0.00–3.00 When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 2.00. AMR is the abbreviation for Active Magnetic Regulator (Kp / Ki), it affects the response of magnetic regulation in flux-weakening zone. If the input voltage or DC bus plummets in the flux-weakening zone (for example, a sudden insufficient voltage due to unstable power net, or DC bus plummets because of a sudden loading), causes the ACR diverges and oc fault occurs, then increase the gain. If the Id value of a spur generates large noise in high frequency output current, decrease the gain to reduce the noise. But decreasing the gain will slow down the response speed. ## - 3 4 Frequency to Switch from I/F Mode to PM Sensorless Mode Default: 20.00 Settings 0.00–599.00 Hz The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency). Sets the frequency for switching from low frequency to high frequency, and sets the switch point for high and low frequencies of the speed observer. If the switch frequency is too low, the motor does not generate enough back-EMF to let the speed observer measure the right position and speed of the rotor, causing stall and oc when running at the switch frequency. If the switch frequency is too high, the active range of I/F is too wide, which generates a larger current without energy saving. (If the current value for Pr.10-31 is too high, the high switch

frequency makes the drive continue to output with Pr.10-31 setting value.)

When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 10.00 Hz.

~	iù	Frequency to Switch from PM Sensoness Mode to I/F Mode
		Default: 20.00
	~	Settings 0.00–599.00 Hz
		The setting upper limit is the same as that for Pr.01-00 (Maximum operation frequency).
		Sets the frequency for switching from high frequency to low frequency, and sets the switch point
		for high and low frequencies of the speed observer.
	Ш	If the switch frequency is too low, the motor does not generate enough back-EMF to let the
		speed observer measure the right position and speed of the rotor when running at the switch
		frequency.
	Ш	If the switch frequency is too high, the active range of I/F is too wide, which generates a larger
		current without energy saving. (If the current value for Pr.10-31 is too high, the high switch
		frequency makes the drive continue to output with Pr.10-31 setting value.)
×	+0	- 😽 🕻 I/F Mode, Id Current Low-Pass Filter Time
		Default: 0.2
		Settings 0.0–6.0 sec.
		Sets the filter time for Pr.10-31. Smoothly increases the magnetic field to the current command
		setting value under the I/F mode.
		If you want to slowly increase the size of Id, increase the filter time to avoid a Step phenomenon
		occurs when starting current output. When decrease the filter time (minimum value is 0), the
		current rises faster, then a Step phenomenon occurs.
×	10	Initial Angle Detection Pulse Value
		Default: 1.0
		Settings 0.0–3.0 times rated current of the motor
		The angle detection is fixed to Pr.10-53 = 2 (High frequency injection) or 3 (Pulse injection).
		The parameter influences the value of the pulse during the angle detection. The larger the pulse
		the higher the accuracy of rotator's position. A larger pulse might cause oc.
		Increase the parameter when the running direction and the command are opposite during
		start-up. If oc occurs at start-up, then decrease the parameter.
	Ш	Refer to Section 12-2 Adjustment & Application for detailed motor adjustment procedure.
×	-10	Zero Voltage Time during Start-up
		Default: 0.000
		Settings 0.000–60.000 sec.
		This parameter is valid only when the setting for Pr.07-12 (Speed Tracking during Start-up) = 0.
		When the motor is in static status at start-up, this increases the accuracy when estimating
		angles. In order to put the motor in static state, set the three-phase drive output to 0 V to the
		motor. The Pr.10-49 setting time is the length of time when three-phase output at 0 V.
		It is possible that even when you apply this parameter, the motor cannot go into the static state
		because of inertia or some external force. If the motor does not go into the static state in 0.2
		seconds, increase the setting value appropriately.
		If Pr.10-49 is too high, the start-up time is longer. If it is too low, the braking performance is

weak.

# Injection Frequency Default: 500 Settings 0–1200 Hz This parameter is a high frequency injection command in PM SVC control mode and usually you do not need to adjust it. If a motor's rated frequency (for example, 400 Hz) is too close to the frequency setting for this parameter (that is, the Default of 500 Hz), it affects the accuracy of the angle detection. Refer to the setting for Pr.01-01 before you adjust this parameter. If the setting value for Pr.00-17 is lower than Pr.10-51 × 10, then increase the frequency of the carrier wave. $\square$ Pr.10-51 is valid only when Pr.10-53 = 2. When Pr.00-11 is set to 8 (SynRM), the default for this parameter is 400. Injection Magnitude Default: 15.0/ 30.0/ 30.0/ 30.0 Settings 0.0–200.0 V 230V models: 0.0-100.0 V 460V models: 0.0-200.0 V 575V models: 0.0-200.0 V 690V models: 0.0-200.0 V The parameter is the magnitude command for the high frequency injection signal in IPM Sensorless control mode. Increasing the parameter can increase the accuracy of the angle estimation, but the electromagnetic noise might be louder if the setting value is too high. The system uses this parameter when the motor's parameter is "Auto". This parameter influences the angle estimation accuracy. When the ratio of the salient pole (Lq/Ld) is lower, increase Pr.10-52 to make the angle detection more accurate. $\square$ Pr.10-52 is valid only when Pr.10-53 = 2. When Pr.05-33 is set to 3 (SynRM), the unit is percentage (%); the setting upper limit and lower limit is 50-10%, and the default is 30%. PM Initial Rotor Position Detection Method Default: 0 Settings 0: Disable

1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees

2: High frequency injection

3: Pulse injection

- When the Speed mode is set to PMSVC (Pr.00-11 = 2) or PM Sensorless (Pr.00-11 = 6):
  - For IPM application, set Pr.10-53 = 2.
  - For SPM application, set Pr.10-53 = 3.
  - If the above settings cause problems, then set this parameter to 1.
- When the Speed mode is set to SynRM Sensorless (Pr.00-11 = 8), you do not need to set this parameter.

N	10	) - 54	Magnetic	Flux Linkage	e Estimate	Low-spee	ed Gain (app	olied to 2	30V / 460\	/models)	
									Default	: 100	
			Settings	10–1000%							
		•	arameter i -11 = 6).	is valid only	when the	speed m	node is set	to PM	Sensorlss	control mo	de
		Increas	se this para	ameter to enl	nance the l	oading ca	pacity durin	ıg start-u <sub>l</sub>	p.		
		Low-sp	eed zone	means moto	r speed un	der 1/5 of	motor's rate	ed speed	; high-spe	ed zone	
		means	speed be	yond 1/5 of n	notor's rate	ed speed.					
M	10	7-55	Magnetic	Flux Linkage	e Estimate	High-spe	ed Gain (ap	plied to 2			
			Settings	10–1000%					Default	: 100	
		This pa		valid only w	hen the spe	eed mode	is set to Pl	M Sensor	less (Pr.00	)-11 = 6) /	
		•		ess control mo	•				(		
		Increas	se this para	ameter to enl	nance the l	oading pe	rformance i	in high-sp	eed zone	and improv	е
		the res	sponse.								
		Decrea	ase this pa	rameter whei	n there is a	speed os	scillation in t	the flux-w	eakening	zone.	
				set to 3 (Syr	nRM), the u	ınit is Pu;	the setting (	upper an	d lower lim	its are 3.0–	0.1
		and the	e default is	s 1.0.							
N	+{	7-56	Kp of Pha	ase-locked Lo	oop (applie	d to 230V	/ 460V mod	dels)			
									Default	t: 100	
			Settings	10–1000%							
		Increas	se this para	ameter to enl	nance the l	oading pe	rformance i	in high-sp	peed zone	and improv	е
		the res	sponse.								
			-	rameter whei	n there is a	high freq	uency vibra	ition in th	e speed ou	utput	
	m	freque	•	ant to 2 (C)	-DM\ tha.	unit in 1 leu	the eatting		ما امیدم انس	oita ara EO	_
			e default is	s set to 3 (Syr s 30.	irivi), the t	unii is mz;	the setting	upper an	d lower lift	ills are 50-	5
<b>N</b>	11	7-57	Ki of Pha	se-locked Lo	op (applied	d to 230V	/ 460V mod	lels)			
									Default	t: 100	
			Settings	10–1000%							
		Increas	se this para	ameter to inc	rease the s	speed resp	ponse durin	g accelei	ration and	deceleratio	n.
✓	+0	-58	Mutual Ind	ductance Gai	n Compens	sation (ap	plied to 230	)V / 460V	models)		
									Default	t: 100	
			Settings	0.00-655.35	5						
	Ш.	This par	ameter is	valid only wh	en the spe	ed mode i	s set to Syr	nRM sens	sorlss cont	rol mode	
		(Pr.00-1	1 = 8).								
				ding perforn		•	-		•		
		•	•	from I/F mod		sensorles	s mode (Pr	:10-39),	adjust this	parameter	to
	j	improve	the loadin	g performan	ce.						

# 11 Advanced Parameters (applied to 230V / 460V models)

✓ You can set this parameter during operation.

In this parameter group, ASR stands for Adjust Speed Regulator

System Control

Default: 0000h


Settings bit0: Auto-tuning for ASR and APR

bit6: 0 Hz linear-cross

bit7: Save or do not save the frequency

bit0 = 0: Manual adjustment for ASR and APR gain, Pr.11-06–Pr.11-11 are valid and Pr.11-03–Pr.11-05 are invalid.


bit0 = 1: Auto-adjustment for ASR and APR gain, the system automatically generates an ASR setting, Pr.11-06–Pr.11-11 are invalid and Pr.11-03–Pr.11-05 are valid.



When the drive needs to keep a certain torque at zero-speed, or it needs a steady frequency output at extreme low speed, increase Pr.11-05 zero-speed bandwidth appropriately. If there is serious output current vibration that cause the drive vibrates in high-speed area, then decrease the high-speed bandwidth.

For example:


Manual gain	Response:
Manual gain	[Pr.11-10, Pr.11-11] > [Pr.11-06, Pr.11-07] > [Pr.11-08, Pr.11-09]
Auto gain	Pr.11-05 = 15 Hz, Pr.11-03 = 10 Hz, Pr.11-04 = 8 Hz



ASR adjustment- manual gain

ASR adjustment- auto gain

- bit6 0 Hz linear-cross function: keeps the S-Curve in linear-cross the 0 Hz point when the S-curves for acceleration / deceleration time (Pr.01-24–Pr.01-27) are set, and the forward / reverse run cross 0 Hz.
  - bit6 = 1: The S-curves for acceleration / deceleration time (Pr.01-24–Pr.01-27) do NOT affect the drive starts and stops. Forward / reverse rotation crosses the zero point in linear.
  - bit6 = 0: The S-curves for acceleration / deceleration time (Pr.01-24–Pr.01-27) affect the drive starts and stops. Forward / reverse rotation crosses the zero point after the S-Curve.



- bit 7 = 0: Save the frequency before power is OFF. The keypad displays the saved frequency after cycle the power.
  - bit7 = 1: Do not save the frequency before power is OFF. The keypad displays 0.00 Hz after cycle the power.

# 

Default: 256

Settings 1–65535 (256 = 1PU)

When Pr.11-01 = 256, it is 1PU. So if you use a 2 HP motor, the 2 HP motor inertia is 6.6 kg-cm<sup>2</sup> according to the rotor inertia table in Pr.05-38. If Pr.11-01 = 10000 after tuning, the system inertia is (10000 / 256) x 6.6 kg-cm<sup>2</sup>.

	If the Iq current command from ASR has high-frequency glitch, response time of sudden loading is too slow, then increase the s	•
× 1	ASR1 / ASR2 Switch Frequency	
		Default: 7.00
	Settings 5.00-599.00 Hz	
	Sets the low-speed and high-speed ASR switching point in the	FOC area. Provides flexibility to
	meet two needs: in the high-speed region of the estimator swit	ch point it has a high response,
	and in the low-speed region of the estimator switch point	it has a lower response. The
	recommended switching point is higher than Pr.10-39.	
	A low setting does not cover Pr.10-39. If the setting is too high, t	he high-speed range is too
	narrow.	
	When Pr.00-11 is set to 8 (SynRM), the default for this parameter	er is 10.00 Hz.
<i>N</i>	- [] ∃ ASR1 Low-speed Bandwidth	
		Default: 10
	Settings 1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (Syl	nRM)
<i>N</i>	I - ☐ H     ASR2 High-speed Bandwidth	,
	3 1	Default: 10
	Settings 1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (Sy	
w !	Zero-speed Bandwidth	,
		Default: 10
	Settings 1–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (Syl	
		,
	Pr.11-04 and Pr.11-05 separately by speed response. The larger	•
	response. Pr.11-02 is the switch frequency between the low-spe	_
		•
لعظ	when F1.00-11 – 8 (Synkivi), the setting upper limit is 50, and the	le deladit is 3.
<b>*</b>	<b>╎- ∁</b>	
		Default: 10
	Settings 0–40 Hz (IM) / 1–100 Hz (PM) / 1–30 Hz (Sy	nRM)
<i>N</i>	- ☐ ↑ ASR 1 Integral Time	
		Default: 0.100
	Settings 0.000-10.000 sec.	
N I	! - () 8 ASR 2 Gain	
		Default: 10
	Settings 0–40 Hz (IM) / 0–100 Hz (PM) / 1–30 Hz (Sy	
w <b>1</b>	- 33 ASR 2 Integral Time	,
	, to the integral time	Default: 0.100
	Settings 0.000–10.000 sec.	Dolault. 0.100
<b>√</b> 1		
/ <u> </u>	AGIT Gaill of Zelo Speed	Dofoult: 10
	Settings 0.40 H= (IM) / 0.400 H= (DM) / 4.20 H= (0.11	Default: 10
	Settings 0–40 Hz (IM) / 0–100 Hz (PM) / 1–30 Hz (Sy	HINNI)

ASR Integral Time of Zero Speed

Default: 0.100


Settings 0.000-10.000 sec.

ASR Speed Feed Forward Gain

Default: 0

Settings 0–150%

- $\square$  This function enables when Pr.11-00 bit0 = 1.
- Increase the setting for Pr.11-12 to reduce the command tracking difference, and improve the speed response. Use this function for speed tracking applications.
- Set Pr.11-01 correctly to get excellent improvement of the speed response.





# 

Default: 30

Settings 0–200%

- $\square$  This parameter is invalid when Pr.05-24 = 1.
- $\square$  This parameter is valid only when Pr.11-00 bit0 = 1.
- After you estimate and set Pr.11-00 bit0 = 1 (auto-tuning), use Pr.11-13 to reduce overshoot. However, a shift of the curve may occur earlier. In this case, you can set Pr.11-13 = 0 first, and then increase the setting value to "a condition with best acceleration and without overshoot" when the acceleration time meets your application but overshoot occurs.
- ☐ Increasing Pr.11-13 improves the overshoot of speed tracking, but an excessive value may reduce the transient response.
- Increasing Pr.11-13 enhances the system stiffness in high-speed steady state, and reduce the speed transient fluctuation at a sudden loading.
- Ensure that you set Pr.11-01 system inertia correctly to get excellent improvement of the speed response.





Settings 0-500%

VF and SVC mode:


Pr.11-17–Pr.11-20 limit the output current, the percentage base value is the drive's rated current (not the motor's rated current). The minimum value between Pr.11-17–11-20 and Pr.06-12 becomes the current output limit. In acceleration and steady state operation, when the output current reaches the limit, the ocA (over-current during acceleration) protection or over-current stall prevention under steady-state operation acts. The output frequency drops, and recovers when the output current is lower than the limit value.

Default: 500


Calculation equation for the motor rated torque:

Motor rated torque = 
$$T(N.M) = \frac{P(W)}{\omega(rad/s)}$$
; P(W) value = Pr.05-02 (Pr.05-14);

ω(rad/s) value = Pr.05-03 (Pr.05-15); 
$$\frac{RPM \times 2\pi}{60} = rad/s$$




- All control mode is based on 100% of the motor rated current except for these four modes: IM: VF, SVC and PM: PMSVC modes.
- When Pr.00-11 = 8 (SynRM), the default for Pr.11-17–Pr.11-20 is 200.



- Adjusts the output voltage for the flux-weakening curve.
- For the spindle application, use this adjustment method:
  - 1. Run the motor to the highest frequency.
  - 2. Observe the output voltage.
  - 3. Adjust the Pr.11-21 (motor 1) or Pr.11-22 (motor 2) setting to make the output voltage reach the motor rated voltage.
  - 4. The larger the setting value, the greater the output voltage.

### **Chapter 12 Description of Parameter Settings | CP2000**



# Flux Weakening Area Speed Response

Default: 65

Settings 0: Disable 0–150%

Controls the speed in the flux weakening area. The larger the value, the faster the acceleration/ deceleration. In normal condition, you do not need to adjust this parameter.

# 12 Pump Parameters

✓ You can set this parameter during operation.

Circulation Control

Default: 0

Settings 0: No operation

1: Fixed Time Circulation (by time)

2: Fixed Quantity Circulation

3: Fixed Quantity Control

4: Fixed Time Circulation + Fixed Quantity Circulation

5: Fixed Time Circulation + Fixed Quantity Control

In this mode, the CP2000 can control up to eight motors at a time. The total number of motors is determined by Pr.12-01. In accordance with the Fixed Time Circulation (Pr.12-02), you can adjust the switching time between Start and Stop for each motor. When an operating motor reaches the time setting for Pr.12-02, the CP2000 stops that motor according to the setting for Pr.00-22 (Stop method). After the delay time setting for Pr.12-03, next motor starts operating. See diagram below.




Diagram 12-1: Sequential Diagram of Fixed Time Free Runs Circulation (by time)

#### Disable Motors' Output

Setting the multi-function input commands as Disable Motors' Output can stop the corresponding motors. The following table lists the settings:

Pr.02-01–Pr.02-06 =	60	61	62	63	64	65	66	67	68
Disable Motors' Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor coasts to stop.

Wiring: Fixed Time Circulation (by time) can control up to eight motors. Diagram 12-2 shows an example of controlling four motors at the same time.




Diagram 12-2: Wiring

# **├ ?** - **{ ; ;** Number of Motors to be Connected

Default: 1

Settings 1-8

Number of Motors: maximum of eight motors. After setting the number of connected motors, the multi-function output terminals automatically follow the setting as shown in the table below.

Pr.12-01	01	02	03	04	05	06	07	08
Pr.02-13	55	55	55	55	55	55	55	55
Pr.02-14		56	56	56	56	56	56	56
Pr.02-15			57	57	57	57	57	57
Pr.02-36				58	58	58	58	58
Pr.02-37					59	59	59	59
Pr.02-38						60	60	60
Pr.02-39							61	61
Pr.02-40								62

Table 1: Setting of Multi-function Output Terminal for Circulating Motors

# **; ? - ; ?** Operating Time of Each Motor (minutes)

Default: 0

Settings 0-65500 minutes

Sets the fixed time for circulation. If Pr.12-02 = 0, stop the timing. The currently running motors continue operating until a Stop command is given.

Delay Time due to the Acceleration (or the Increment ) at Motor Switching (seconds)

Default: 1.0

Settings 0.0-3600.0 seconds

Sets the delay time when switching motors. When the currently running motors reach the time setting for Pr.12-02, the CP2000 uses the delay time setting for Pr.12-03 and then switches to run the next motors.

Default: 1.0

Settings 0.0-3600.0 seconds

Sets the delay time of motor switching during the deceleration, the unit is second.

Default: 10.0

Settings 0.0-3600.0 seconds

Sets the fixed quantity circulation with PID

Sequential Diagram

In this mode, the CP2000 can control up to four motors to increase flow quantity and pressure range control. When controlling the flow quantity, the motors are in parallel connection. When

controlling the pressure range, the motors are in series connection.

To increase the flow quantity or pressure range, the CP2000 increases the first motor's pressure from 0 Hz to the largest operating frequency. If the output frequency reaches the frequency setting for Pr.12-06 and delay time for Pr.12-05, the CP2000 delays the time setting for Pr.12-03. CP2000 then switches to the next motor to use mains electricity and delays the time setting for Pr.12-03 to run the next motor. If necessary, other motors are activated in sequence. See sequential diagram of 12-3 and 12-4.




Diagram 12-3: Sequence of Fixed quantity circulation with PID – Increasing Demand




Diagram 12-4: Sequence of switching motors at Fixed Quantity Circulation with PID

— Increasing Demands

However, if the decreasing demands for flow quantity and pressure are too big, the CP2000 stops the current operating motors and waits for the delay time setting for Pr.12-04. It continues doing this until the last motor stops using mains electricity. See sequential diagram 12-5 and 12-6 below.




Diagram 12-5: Sequence of Fixed Quantity Circulation with PID – Decreasing Demands




Diagram 12-6: Sequence of switching motors at Fixed Quantity Circulation with PID

— Decreasing Demands

## Parameter Setting

Parameter setting	Description									
Pr.12-00=2	Choose Fixed Quantity Circulation with PID									
	Number of Motors: maximum four motors. After you set the number of motors to be connected at the same time, the multi-function output terminals automatically follow the setting as shown in the table below.									
	Pr.12-01 01	01	02	02	03	03	04	04	Material Inc. Drives	
	Pr.02-13 55 Pr.02-14	55 56	55 56	55 56	55 56	55 56	55 56	55 56	Motor 1 by Drive  Motor 1 by Mains	
Pr.12-01=X	2-01=X Pr.02-15 57 57 57 57 57 Motor 2 by Drive								<u> </u>	
									Motor 2 by Mains	
	Pr.02-37				59	59	59	59	Motor 3 by Drive	
	Pr.02-38					60	60	60	Motor 3 by Mains	
	Pr.02-39						61	61	Motor 4 by Drive	
	Pr.02-40							62	Motor 4 by Mains	
	Table 2: Setting	g of M	ulti-fu	ınctio	n Ou	tput <sup>-</sup>	Геrmi	nal o	n Circulating Motors	
Pr.12-03 = X	Delay Time du	e to th	e Acc	celera	ation	(or th	e Inc	reme	ent) at Motor Switching (unit: sec.)	
Pr.12-04 = X	Delay Time du	e to th	e De	celera	ation	(or th	ne De	crem	nent) at Motor Switching (unit: sec.)	
Pr.12-05 = X	Delay time while Fixed Quantity Circulation at Motor Switching with PID (unit: sec.)									
Pr.12-06 = X	Frequency when switching motors at Fixed Quantity Circulation (Hz)									
Pr.12-09 = X	Delay time for	he ne	xt mo	otor o	utput	whe	n the	dem	and increases.	

Disable Motor Output

Set the multi-function input commands to Disable Motors' Output can stop corresponding motors. The settings are:

Pr.02-01-Pr.02-06=	60	61	62	63	64	65	66	67	68
Disable Motor's Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor coasts to stop.

Fixed Quantity Circulation with PID can control up to four motors. Diagram 12-7 below shows an example of controlling 4 motors.




Diagram 12-7

Frequency when Switching Motors at Fixed Quantity Circulation (Hz)

Default: 60.00

Settings 0.0–599.00 Hz

Sets the drive's output frequency at which the system prepares to switch motors.

Action when Fixed Quantity Circulation Breaks Down

Default: 0

Settings 0: Turn off all output

1: Motors powered by mains electricity continues to operate

Frequency for Stopping Auxiliary Motor (Hz)

Default: 0

Settings 0.00-599.00 Hz

- When the output frequency is smaller than the Pr.12-08 and remains at the time setting for Pr.12-04, the CP2000 shuts down the motors one by one.
- Fixed Quantity Control with PID
  In this mode, the CP2000 can control up to eight motors to increase flow quantity and pressure range control.

The CP2000 connects directly to a main motor while the rest of the motors use mains electricity and are controlled by a relay. When controlling flow quantity, the motors are in parallel connection. When controlling pressure range, the motors are in series connection.

To increase the flow quantity or pressure range, the CP2000 increases the main motor's pressure from 0 Hz to the largest operating frequency. If necessary, the CP2000 switches the motors to use mains electricity in sequence. See sequential diagram 12-8 and 12-9.




Diagram 12-8: Sequence of Fixed Quantity Control with PID - Increasing Demand




Diagram 12-9: Sequence of switching motors at Fixed Quantity Control with PID

— Increasing Demand

However, if the flow quantity or pressure is too large, the CP2000 stops, one by one, the motors use mains electricity until the CP2000 decreases the main motor's frequency to 0 Hz. See Diagram 12-10 and Diagram 12-11.




Diagram 12-10: Sequence of Fixed Quantity Control with PID – Decreasing Demand




Diagram 12-11: Sequence of switching motors at Fixed Quantity Control with PID

— Decreasing Demand

### Parameter setting:

Parameter Setting	Description									
Pr.12-00 = 3	Choose Fixed Quantity Control									
	Number of	Number of Motors: maximum of eight motors. After you set the number of connected								
	motors, the	motors, the multi-function output terminals automatically follow the setting as shown in the								
	table below	<i>1</i> .								
	Pr.12-01	01	02	03	04	05	06	07	80	
	Pr.02-13	55	55	55	55	55	55	55	55	Motor 1 by Mains
	Pr.02-14		56	56	56	56	56	56	56	Motor 2 by Mains
Pr.12-01 = X	2-01 = X Pr.02-15 57 57 57 57 57 Motor 3 by Mains								Motor 3 by Mains	
	Pr.02-36				58	58	58	58	58	Motor 4 by Mains
	Pr.02-37					59	59	59	59	Motor 5 by Mains
	Pr.02-38						60	60	60	Motor 6 by Mains
	Pr.02-39							61	61	Motor 7 by Mains
	Pr.02-40								62	Motor 8 by Mains
	Table 2: Se	etting	of M	ulti-fu	ınctio	n Ou	tput 7	Termi	nal o	n Circulating Motors
Pr.12-05 = X	Delay time for Fixed Quantity Circulation at Motor Switching (seconds)									
Pr.12-06 = X	Frequency	for s	witch	ing m	notors	at F	ixed	Quar	ntity C	Circulation (Hz)

Disable Motor's Output

Set the multi-function input commands to Disable Motors' Output can stop the corresponding motors.

The settings are:

Pr.02-01-Pr.02-06=	60	61	62	63	64	65	66	67	68
Disable Motor's Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor coasts to stop.

Wiring: Fixed Quantity Control can control up to eight motors. Diagram 12-12 is an example of controlling four motors at the same time.




Diagram 12-12

☐ Fixed Time circulation and Fixed quantity circulation with PID

This mode combines Fixed Time Circulation and Fixed Quantity Circulation with PID. This is to prevent motors from becoming rusty if they are not in use for a long period. If some motors are not activated, set the fixed time circulation to run the motors one by one to make sure each of them is running.

If all the motors are running and the water pressure is sufficient, the fixed time circulation is not enabled. If motor 1 and motor 2 run to reach a balance in water pressure and the time reaches the setting for Pr.12-02, motor 1 runs without using mains electricity (runs by the motor drive) and motor 2 decelerates to stop.

When the motor 2 reaches the frequency setting at Pr.12-06 and the time setting for Pr.12-05, it separates from the motor drive (runs on mains electricity). When time reaches the setting for Pr.12-03, motor 2 runs using the mains electricity. Then when the time exceeds the setting for Pr.12-03, motor 3 is enabled by the motor drive. The time sequence Diagram 12-13 is shown as below.




Diagram 12-13 Fixed Time Circulation and Fixed Quantity Control with PID

Fixed Time Circulation and Fixed Quantity Control with PID

This mode combines Fixed Time Circulation and Fixed Quantity Control with PID. This is to prevent motors from becoming rusty if they are not in use for a long period. If some motors are not activated, set the fixed time circulation to run the motors one by one to make sure each of them is running.

When all the motors are running and water pressure is sufficient, the fixed time circulation is not enabled. If motor 1 and motor 2 run to reach a balance in water pressure and when the time reaches the setting for Pr.12-02, motor 1 runs without using mains electricity (run by the motor drive). When the time reaches the setting for Pr.12-03, motor 3 runs using mains electricity, and the operating time of each motor resets. Once it reaches the time setting for Pr.12-02 again, motor 2 runs without using mains electricity. Then when time reaches the setting for Pr.12-03, motor 4 runs using mains electricity. The time sequence Diagram 12-14 is as shown below




Diagram 12-14: Fixed Time Circulation under Fixed Amount Control Balance

# Fixed Quantity Circulation Output Delay

Default: 1.0

Default: Read only

Settings 1.0-3600.0 sec.

Under Fixed Quantity Circulation (Increment) mode, the first motor of the drive switches to the supply mains through the setting time for Pr.12-03, then switches to the second motor through the setting delay time for Pr.12-09.




Diagram 12-15: Sequence of output delay for fixed quantity circulation

<b>;</b> ∂ - <b>;</b> ∂ Motor 1 Operation Record (min. /sec.)
<b>;</b> ∂ - <b>;</b> ∂ Motor 2 Operation Record (min. /sec.)
<b>;</b> ∂ - <b>;</b> ∀ Motor 3 Operation Record (min. /sec.)
#2 - #5 Motor 4 Operation Record (min. /sec.)
<b>;</b> ∂ - <b>;</b> B Motor 5 Operation Record (min. /sec.)
<b>;</b> ∂ - ∂ <b>!</b> Motor 6 Operation Record (min. /sec.)
#2 - 2 ₽ Motor 7 Operation Record (min. /sec.)
<b>12 - 2 4</b> Motor 8 Operation Record (min. /sec.)

Settings Read only

#### Chapter 12 Description of Parameter Settings | CP2000

Motor 1 Operation Record (hour)	
<b>;</b> ∂ − <b>;</b> ∂ Motor 2 Operation Record (hour)	
#2 - #5 Motor 3 Operation Record (hour)	
Motor 4 Operation Record (hour)	
Motor 5 Operation Record (hour)	
<b>; ∂ − ∂ ;</b> Motor 6 Operation Record (hour)	
#2 - 2 3 Motor 7 Operation Record (hour)	
12 - 25 Motor 8 Operation Record (hour)	
	Default: Read only

### Settings Read only

- These parameters record the operation time for Motor 1 to Motor 8. For examples, Pr.12-10 and Pr.12-11 both record the operation time for Motor 1. Pr.12-10 records the operation time in minutes and seconds, whereas Pr.12-11 records the operation time in hours. When Pr.12-10 displays 5959, it means the motor has operated for 59 minutes and 59 seconds. When the motor operates for an hour, Pr.12-11 displays 1 and Pr.12-10 displays 0.
- When circulation control Pr.12-00 = 1–5, the output frequency is > 0 Hz and output current is > 0 A, the motor operation time is recorded.
- When the record reaches the upper limit 65535 hours 59 minutes and 59 seconds, clear the motor operation time manually to keep tracking the operation status of each motor, and the service life of the motor.

Motor No. /	Harris	Mire /Coo	Clear
Motor Operation Time	Hour	Min./Sec.	Motor Operation Time
	Pr.12-11 = 65535	Pr.12-10 = 5959	
Motor 1	$\downarrow$	$\downarrow$	Pr.12-26 = 1
	65535 hour	59 min.: 59 sec.	
Motor 2	Pr.12-13	Pr.12-12	Pr.12-26 = 2
Motor 3	Pr.12-15	Pr.12-14	Pr.12-26 = 3
Motor 4	Pr.12-17	Pr.12-16	Pr.12-26 = 4
Motor 5	Pr.12-19	Pr.12-18	Pr.12-26 = 5
Motor 6	Pr.12-21	Pr.12-20	Pr.12-26 = 6
Motor 7	Pr.12-23	Pr.12-22	Pr.12-26 = 7
Motor 8	Pr.12-25	Pr.12-24	Pr.12-26 = 8
All motors	N/A	N/A	Pr.12-26 = 10

Default: 0

# ₹₽-₽₽ Clear Motor's Operation Time

Settings 0: No function

- 1: Clear operation time for motor 1
- 2: Clear operation time for motor 2
- 3: Clear operation time for motor 3
- 4: Clear operation time for motor 4
- 5: Clear operation time for motor 5
- 6: Clear operation time for motor 6
- 7: Clear operation time for motor 7
- 8: Clear operation time for motor 8
- 10: Clear operation time for all motors
- Clear the operation time for single motor or all motors as needed.
- 1: The operation time for Motor 1 returns to zero, including operation records in Pr.12-11 (hour) and Pr.12-10 (min. /sec.).
- 10: The operation time for Motor 1–8 (Pr.12-10–Pr.12-25) all return to zero.

# ₹2 - 2 ? Priority for Circulated Operation

Default: 0

Settings 0: Terminal order

1: Minimum operation time

- Terminal order: the multi-function output terminals corresponded to each circulation control mode (Pr.12-00 = 1–5).
- Minimum operation time: starts in the order from the motor with the minimum operating hours among all running motors.
- The minimum operation time is only applicable for operation time record under fixed time circulation mode (Pr.12-00 = 1), as listed in the circulation mode comparison table below.
- A comparison for each circulation mode

Function / Circulation Control Mode	Pr.12-00 = 1	Pr.12-00 = 2–5
Motor operation time record	V	V
Terminal order	V	V
Minimum operation time	V*	Х

- \* When the drive resumes and starts running after stopping (or turning off) after operating for a period, the motor operates according to the minimum operation time. However, the first operating motor after resuming is the previous running motor before stop or turn-off. If you need to start the motors according to the minimum operation time in sequence immediately after resuming, close the minimum operation time (Pr.12-27 = 0) first and start (Pr.12-27 = 1) again.
- When Pr.12-00 = 1–5, the terminal order (Pr.12-27 = 0) is applicable for the operation time record under all the circulated control modes.
- When Pr.12-00 = 1–5, the terminal order (Pr.12-27 = 0) is the only available selection, and the minimum operation time (Pr.12-27 = 1) is invalid.

#### Chapter 12 Description of Parameter Settings | CP2000

When the minimum operation time (Pr.12-27 = 1) is enabled, the drive sorts the operation hours according to the amount of running motors at the moment, and then choose the motor that has the minimum operation hour to start after RUN command.

As Example 1 below shows, the drive starts Motor 2, which having a minimum operation time among all eight motors.

As Example 2 below shows, Motor 8 does not start though it has the minimum operation time, because only Motor 1 to Motor 5 are started. Moreover, if more than one motors have the same minimum operation hour, the number of the motor takes the priority. Therefore, Motor 3 starts rather than Motor 5.

### Motor operation time-Example 1

Motor No. / Motor Status	Status	Operating Hour	Operating Min./ Sec.
Motor 1	ON	0	59 59
Motor 2	ON	0	12 12
Motor 3	ON	2	00 00
Motor 4	ON	0	43 11
Motor 5	ON	1	33 00
Motor 6	ON	3	50 05
Motor 7	ON	1	05 22
Motor 8	ON	10	20 21

### Motor operation time-Example 2

Motor No. / Motor status	Status	Operating Hour	Operating Min./ Sec.
Motor 1	ON	0	59 59
Motor 2	ON	5	12 12
Motor 3	ON	0	33 00
Motor 4	ON	0	43 11
Motor 5	ON	0	33 00
Motor 6	OFF	3	50 05
Motor 7	OFF	1	05 22
Motor 8	OFF	0	00 01

# 13 Application Parameters by Industry

★ This parameter can be set during operation.

**∤** ∃ - **₽ ₽** Application Selection

Default: 0

Settings 0: Disabled

1: User-defined Parameter

2: Compressor IM

3: Fan

4: Pump

10: Air Handling Unit, AHU

- After you select the macro, some of the default values adjust automatically according to the application selection.
- Each setting varies with different application selection, and its value is different as well.
- Refer to Section 10-2 for more operation details.
- Group settings: 2: Compressor IM

The following table lists the relevant compressor application parameters.

Pr.	Explanation	Settings
00-11	Speed control mode	0: VF (IM V/F control)
00-16	Load selection	0: Light load
00-17	Carrier frequency	Default setting
00-20	Master frequency command source (AUTO)	2: External analog input
00-20	/ Source selection of the PID target	2. External analog input
00-21	Operation command source (AUTO)	1: External terminals.
00-22	Stop method	0: Ramp to stop
00-23	Control of motor direction	1: Disable reverse
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1 Default setting	
01-03	Mid-point frequency 1 of motor 1 Default setting	
01-04	Mid-point voltage 1 of motor 1 Default setting	
01-05	Mid-point frequency 2 of motor 1	Default setting
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1	Default setting
01-11	Output frequency lower limit	20 (Hz)
01-12	Acceleration time 1	20 (s)
01-13	Deceleration time 1 20 (s)	
03-00	Analog input selection (AVI1) 0: No function	
03-01	Analog input selection (ACI)	1: Frequency command
05-01	Full-load current for induction motor 1(A)	Default setting

Pr.	Explanation	Settings
05-03	Rated speed for induction motor 1 (rpm)	Default setting
05-04 Number of poles for induction motor 1 Default setting		Default setting

## Group setting 03: Fan

The following table lists the relevant fan setting application parameters.

Pr.	Explanation Settings		
00-11	Speed control mode	0 (V/F control)	
00-16	Load selection	0: Light load	
00-17	Carrier frequency	Default setting	
00-20	Master frequency command source (AUTO)	2: External analog input	
00-20	/ Source selection of the PID target	2: External analog input	
00-21	Operation command source (AUTO)	1: External terminals.	
00-22	Stop method	1: Coast to stop	
00-23	Control of Motor Direction	1: Disable reverse	
00-30	Master frequency command (HAND) source	0: Digital keypad	
00-31	Operation command (HAND) source	0: Digital keypad	
01-00	Maximum operation frequency	Default setting	
01-01	Output frequency of motor 1	Default setting	
01-02	Output voltage of motor 1	Default setting	
01-03	1-03 Mid-point frequency 1 of motor 1 Default setting		
01-04	1-04 Mid-point voltage 1 of motor 1 Default setting		
01-05	Mid-point frequency 2 of motor 1	Default setting	
01-06	Mid-point voltage 2 of motor 1	Default setting	
01-07	Minimum output frequency of motor 1	Default setting	
01-08	Minimum output voltage of motor 1 Default setting		
01-10	Output frequency upper limit 50 (Hz)		
01-11	11 Output frequency lower limit 35 (Hz		
01-12	Acceleration time 1	15 (s)	
01-13	Deceleration time 1	15 (s)	
01-43	V/F curve selection	2: 2 <sup>nd</sup> V/F curve	
02-05	Multi-function input command 5 (MI5)	16: Rotating speed command from ACI	
03-00	Analog input selection (AVI1)	1: Frequency command	
03-01	Analog input selection (ACI)	1: Frequency command	
03-28	AVI1 terminal input selection	0 (0–10 V)	
03-29	ACI terminal input selection 1 (0–10 V)		
03-31	AFM output selection	0 (0–10 V)	
03-50	Analog input curve selection	1: three-point curve of AVI1	
07-06	Restart after momentary power loss	Speed tracking by minimum output frequency	
07-11	Number of times of restart after fault	5 (times)	
07-33	Auto-restart interval of fault	60 (s)	

## Group setting 04: Pump

The following table lists the relevant pump setting application parameters.

Pr.	Explanation	Settings
00-11	Speed control mode 0 (V/F mode)	
00-16	Load selection	0: Light load
00-20	Master frequency command source (AUTO) / Source selection of the PID target	2: External analog input
00-21	Operation command source (AUTO)	1: External terminals.
00-23	Control of motor direction	1: Disable reverse
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1	Default setting
01-03	Mid-point frequency 1 of motor 1 Default setting	
01-04	Mid-point voltage 1 of motor 1 Default setting	
01-05	Mid-point frequency 2 of motor 1 Default setting	
01-06	Mid-point voltage 2 of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-08	Minimum output voltage of motor 1 Default setting	
01-10	Output frequency upper limit 50 (Hz)	
01-11	Output frequency lower limit	35 (Hz)
01-12	Acceleration time 1	15 (s)
01-13	Deceleration time 1	15 (s)
01-43	V/F curve selection	2: 2 <sup>nd</sup> V/F curve
07-06	Restart after momentary power loss	2: Speed tracking by minimum output frequency
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (s)

## Group setting 10: Air Handling Unit, AHU

The following table lists the relevant AHU setting application parameters.

Pr.	Explanation	Settings
00-04	Content of multi-function display	2
00-11	Speed control mode	0 (V/F control)
00-16	Load selection	0: Light load
00-20	Master frequency command source (AUTO)	2 or 0 (External analog input)
00-20	/ Source selection of the PID target	2 or 0 (External analog input)
00-21	Operation command source (AUTO) 1 or 0 (External terminals)	
00-22	Stop method 1: Coast to stop	
00-23	Control of motor direction 1: Disable reverse	
00-30	Master frequency command (HAND) source 0: Digital keypad	
00-31	Operation command (HAND) source 0: Digital keypad	

## Chapter 12 Description of Parameter Settings | CP2000

Pr.	Explanation	Settings
01-00	Maximum operation frequency	Default setting
01-01	Output frequency of motor 1	Default setting
01-02	Output voltage of motor 1	Default setting
01-07	Minimum output frequency of motor 1	Default setting
01-10	Output frequency upper limit	50
01-11	Output frequency lower limit	35
01-34	Zero-speed mode	2
01-43	V/F curve selection	2
02-05	Multi-function input command 5 (MI5)	16 or 17
02-13	Multi-function output 1 RLY1	11
02-14	Multi-function output 2 RLY2	1
03-00	Analog input selection (AVI1)	1
03-01	Analog input selection (ACI)	1
03-02	Analog input selection (AVI2)	1
03-28	AVI1 terminal input selection	0
03-29	ACI terminal input selection	1
03-20	Multi-function output 1 (AFM1)	0
03-23	Multi-function output 2 (AFM2)	0
03-31	AFM1 current selection	0 or 1
03-34	AFM2 current selection	0 or 1
03-50	Analog input curve selection	4
07.06	Destant offer means to the control of the control o	2 (Speed tracking by minimum output
07-06	Restart after momentary power loss	frequency)
07-11	Number of times of restart after fault	5 (times)
07-33	Auto-restart interval of fault	60 (s)



Application Parameter 1-99

Default: 0.00

Settings 0.00-655.35

## 14 Extension Card Parameter

✓ This parameter can be set during operation. Extension Card Input Terminal Selection (Al10) Extension Card Input Terminal Selection (AI11) Default: 0 Settings 0: Disable 1: Frequency command 4: PID target value 5: PID feedback signal 6: Thermistor (PTC) input value 11: PT100 thermistor input value 13: PID compensation amount When the setting for Pr.14-00 and Pr.14-01 are the same, the Al10 is selected first. Analog Input Filter Time (AI10) Analog Input Filter Time (AI11) Default: 0.01 Settings 0.00-20.00 sec. The input analog signal of terminal AI1 and AI2 often includes interferences, which will affect the stability of the control. Use these input delays to filter a noisy analog signal. When the setting for the time constant is too large, the control is stable but the control response is slow. When the setting for time constant is too small, the control response is faster but the control may be unstable. For optimal setting, adjust the setting according to the control stability or the control response. Analog Input 4–20 mA Signal Loss Selection (AI10) Analog Input 4–20 mA Signal Loss Selection (AI11) Default: 0

Settings 0: Disable

1: Continue operation at the last frequency

2: Decelerate to 0 Hz

3: Stop immediately and display ACE

- This parameter determines the treatment when the 4–20 mA signal is lost, when Pr.14-18 = 2, Pr.14-19 = 2.
- When the setting for Pr.14-18 or Pr.14-19 are 0 or 1, the voltage input to AVI and ACI terminal is 0–10 V or 4–20 mA. At this moment, Pr.14-10 and Pr.14-11 are invalid.
- Setting 1 or 2: Displays the warning code "ANL" on the keypad. It continues blinking until the lost ACI signal is recovered.
- When the motor drive stops, the warning condition does not continue to exist, so the warning disappears.



Default: 0

## Settings 0-23

Refer to the function chart below for details setting.

### **Function Chart**

Settings	Functions		Descriptions
0	Output frequency (Hz)	Maximum frequency Pr.01-00 is processed as 100%.	
1	Frequency command (Hz)	Maximum frequency Pr.01-00 is processed as 100%.	
2	Motor speed (Hz)	Maximum frequency P	r.01-00 is processed as 100%.
3	Output current (rms)	(2.5 × rated current) is	processed as 100%
4	Output voltage	(2 × rated voltage) is p	rocessed as 100%
5	DC bus voltage	450V (900V)=100%	
6	Power factor	-1.000-1.000=100%	
7	Power	(2 × rated power) is pro	ocessed as 100%
9	AVI1	0-10 V = 0-100%	
10	ACI	4–20 mA = 0–100%	
11	AVI2	-10-10 V = 0-100%	
		For CANopen commur	nication analog output
		Terminal	Corresponding address
20	CANopen analog output	AFM1	2026-A1
		AFM2	2026-A2
		AO10	2026-AB
		AO11	2026-AC
		For RS-485 (InnerCON	/l / Modbus) analog output
	RS-485 analog output	Terminal	Corresponding
21		AFM1	address 26A0H
	l 400 dilalog odtpat	AFM2	26A1H
		AO10	26AAH
		AO11	26ABH
	For communication analog output (CMC-EIP01, CMC-PN01, CMC-DN01)		
22	Communication card	Terminal	Corresponding address
	analog output	AFM1	26A0H
		AFM2	26A1H
		AO10	26AAH
		AO11	26ABH
23	Constant voltage output	0-100% of Pr.14-20 co	control voltage output level orresponds to 0–10 V of AO10. orresponds to 0–10 V of AO11.

	Chapter 12 Description of Barameter Settings   CB2000
	Chapter 12 Description of Parameter Settings   CP2000
✓ ╎┤ - ╎┤ Analog Output 1 Gain (AO10)	
✓	
	Default: 100.0
Settings 0.0-500.0%	
Adjusts the voltage level outputted to the	e analog meter from the analog signal (Pr.14-12,
Pr.14-13) output terminal AFM of the drive.	
Analog Output 1 in REV Direction (A	O10)
Analog Output 1 in REV Direction (A	.011)
	Default: 0
Settings 0: Absolute output voltage	value
1: Reverse output 0 V; for	ward output 0–10 V
2: Reverse output 5–0 V; f	forward output 5–10 V
Determines the voltage reverse output when	n AO10 and AO11 are set as 0–10 V (Pr.14-36 = 0,
Pr.14-37 = 0).	
↑10V(20mA) ↑1	10V(20mA) ↑ 10V(20mA)
	Freq. Freq.
0V	V 5V (12mA)
(UIIIA)	(12111A)
Pr. 14-16=0 Pr. 14-1	
Pr. 14-17=0 Pr. 14-1	
Analog Outpu      Y -     Extension Card Input Selection (Al10)	
Extension Gard input Selection (Arro	
Settings 0: 0–10 V (AVI10)	Default: 0
1: 0–20 mA (ACI10)	
2: 4–20 mA (ACI10)	
Extension Card Input Selection (AI11	()
	Default: 0
Settings 0: 0–10 V (AVI11)	Boldan. 0
1: 0–20 mA (ACI11)	

2: 4-20 mA (ACI11)

When you change the input mode, verify that the switch position of external terminal (Al10, Al11) is correct.

AO10 DC Output Setting Level

AO11 DC Output Setting Level

Default: 0.00

Settings 0.00-100.00%

## Chapter 12 Description of Parameter Settings | CP2000

✓	Iter Output Time	
	Iter Output Time	
		Default: 0.01
Settings	0.00-20.00 sec.	
	utput Selection	
	utput Selection	
		Default: 0
Settings	0: 0–10 V	
	1: 0–20 mA	
	2: 4–20 mA	

# 12-2 Adjustment & Application

The followings are abbreviations for different types of motors:


• IM: Induction motor

- SPM: Surface permanent magnet synchronous AC motor
- ▶ PM: Permanent magnet synchronous AC motor
   ▶ SynRM: Synchronous reluctance motor
- IPM: Interior permanent magnet synchronous AC motor


## 12-2-1 Permanent Magnet Motor Space Vector Control (PM SVC) Pr.00-11 = 2

1. Control Diagram

PM SVC control diagram



- 2. PM SVC Adjustment Procedure (\* the number marked on the procedure corresponds to the number of following adjustment explanations)
  - I. PM SVC motor parameters adjustment



#### Chapter 12 Description of Parameter Settings | CP2000

- Basic Motor Parameters Adjustment
  - 1. Parameter reset:

Reset Pr.00-02 = 10 (60 Hz) to the default value.

2. Select PM motor type:

Pr.05-33 = 1 (SPM) or 2 (IPM)

3. Motor nameplate parameter setting:

Parameter	Description
Pr.01-01	Rated frequency (Hz)
Pr.01-02	Rated voltage (V <sub>AC</sub> )
Pr.05-34	Rated current (A)
Pr.05-35	Rated power (kW)
Pr.05-36	Rated rotor speed (rpm)
Pr.05-37	Number of poles for the motor (poles)

- 4. PM parameter auto-tuning:
- 5. Set Pr.05-00 = 5 (Rolling auto-tuning for PM) or 13 (Static auto-tuning for PM) and press "RUN" key to finish motor auto-tuning, then you will get the following parameters:

Parameter	Description
Pr.05-39	Stator resistance for a permanent magnet motor (Ω)
Pr.05-40	Permanent magnet motor Ld (mH)
Pr.05-41	Permanent magnet motor Lq (mH)
Pr.05-43	Ke parameter of a permanent magnet motor (V <sub>phase rms</sub> / krpm) (When Pr.05-00 = 5, the Ke parameter is measured based on the actual motor rotation.) (When Pr.05-00 = 13, the Ke parameter is automatically calculated based on the motor power, current and rotor speed.)

If an auto-tuning error (AUE) occurs, refer to Section 14 "Fault Codes and Descriptions" for further treatment.

AUE Error (code)	Description
AUE (40)	Auto-tuning error
AUE1 (142)	Auto-tuning error 1 (No feedback current error)
AUE2 (143)	Auto-tuning error 2 (Motor phase loss error)

6. Set control mode

Control mode for the motor: Pr.00-11 = 2: PM SVC mode


7. Measure the initial magnetic pole angle of PM

Set Pr.10-53 PM initial rotor position detection method

- 0: Disable
- 1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees
- 2: High frequency injection
- 3: Pulse injection

(Set to 2 for IPM; set to 3 for SPM. If these settings cause problems, then set the parameter to 1.)

### II. PMSVC Adjustment for Operation without Load / with Light-load




- Adjustment for Operation with Light-load
  - 8. Start the motor with no-load / light-load, and operates to 1/2 of the rated rotor speed A1. Start operation direction:
    - a. If the start operation direction is wrong
       SPM: increase the current proportion for Pr.10-42 (Initial angle detection pulse value) to improve the accuracy of the angle detection.
       IPM: Increase the voltage for Pr.10-52 (Injection magnitude) to improve the accuracy of the angle detection.
    - b. If an ocA error occurs when pressing RUN to start the motor, decrease the current proportion for Pr.10-42 (Initial angle detection pulse value). An excessive pulse current may cause ocA error easily.
    - A2. Operates the motor in 1/2 of the rated rotor speed, adjust the no-load operating current lf the no-load operating current exceeds 20% of the rated current, increase Pr.07-26 (Torque compensation gain) and observe the no-load operating current.
    - A3. Accelerate to rated frequency and observe if the motor operates stably.
      - a. If the motor output rotor speed presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.10-32 (PM FOC sensorless speed estimator bandwidth).
      - b. If the output frequency reflects high frequency vibration, decrease Pr.10-34 or decrease Pr.10-32.
    - A4. Accelerate the motor to the maximum rotor speed, and observe if it operates stably.

      If the motor stalls when accelerating to the maximum rotor speed, then increase Pr.10-34

      PM Sensorless Speed Estimator Low-pass Filter Gain, or increase Pr.00-17 Carrier

      Frequency (you must set the carrier frequency larger than 10 times of the maximum output frequency)

### III. PM SVC Carrier Start-up Adjustment



- Heavy Load Operation Adjustment
  - 9. Load operating test
    - B1. Low-frequency loading performance is below 1/10 of rated frequency:
      - a. If the low-frequency loading performance is insufficient, or the rotor speed is not smooth, increase Pr.10-31 (Current command of I/F mode).
      - b. If the low-frequency current is large, decrease Pr.10-31 (Current command of I/F mode).
    - B2. Test the with-load accelerating performance:
      - When the motor operates in 1/10 of rotor speed and above, if the speed cannot follow the acceleration time during accelerating, or the current stalls, increase Pr.07-38 (PMSVC voltage feedback forward gain).
  - 10. Stability test at constant speed operation: if the motor operates stably at constant speed
    - a. If the motor output rotor speed presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or increase Pr.10-32 (PM FOC sensorless speed estimator bandwidth).
    - b. If the output frequency reflects high frequency vibration, decrease Pr.10-34 or decrease Pr.10-32.

#### 12-2-2-1 PMSVC Related Parameters


Refer to Section 12-1 Description of Parameter Settings for more details.

Parameter	Description	Unit	Default	Setting Range
Pr.07-24	Torque command filter time	sec.	0.5	0.001–10
Pr.07-26	Torque compensation gain	N/A	0	0–5000
Pr.07-38	PMSVC voltage feedback forward gain	N/A	1.0	0.5–2.0
Pr.10-31	I/F mode, current command	%	40	0–150
Pr.10-32	PM FOC sensorless speed estimator bandwidth	Hz	5.00	0.00-600.00
Pr.10-34	PM sensorless speed estimator low-pass filter gain	N/A	1.00	0.00-655.35
Pr.10-39	Frequency point to switch from I/F mode to PM sensorless mode	Hz	20.00	0.00-599.00
Pr.10-40	Frequency point to switch from PM sensorless mode to V/F mode	Hz	20.00	0.00–599.00
Initial Angle Estimating Parameters				
Pr.10-42	Initial angle detection pulse value	N/A	1.0	0.0–3.0
Pr.10-51	Injection frequency	Hz	500	0–1200
Pr.10-52	Injection magnitude	V	15.0 / 30.0	0.0–200.0
Pr.10-53	PM initial rotor position detection method 0: Disable 1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees 2: High frequency injection 3: Pulse injection	N/A	0	0–3

#### 12-2-2 PM Sensorless Adjustment (Pr.00-11 = 6)


#### 1. Control Diagram

PM Sensorless FOC mode (applicable for CP2000 V2.07 and above)



PM Sensorless FOC control is the control method dedicated for PM; it uses the high salient pole characteristic of PM to detect positions of NS magnetic poles. By doing this, it calculates the motor's rotor position at low-speed frequency.

- 2. PM Sensorless FOC Control Adjustment (\* the number marked on the procedure corresponds the number of following explanations)
  - I. Adjustment for PM Sensorless FOC Mode Motor Parameters



#### Motor Parameters Adjustment

1. Parameter reset:

Pr.00-02 = 10, reset parameter to the default value.

2. Select motor type:

Pr.05-33 = 1 or 2 (SPM or IPM)

3. Motor nameplate parameter setting:

Parameter	Description		
Pr.01-01	Rated frequency (Hz)		
Pr.01-02	Rated voltage (V <sub>AC</sub> )		
Pr.05-34	Rated current (A)		
Pr.05-35	Rated power (kW)		
Pr.05-36	Rated rotor speed (rpm)		
Pr.05-37	Number of motor poles (poles)		
Pr.05-38	System inertia for PM (kg-cm²)		

#### 4. PM parameter auto-tuning:

Set Pr.05-00 = 5 [Rolling auto-tuning for PM (without load)] or 13 (Static auto-tuning for PM), and press "RUN" key to finish motor auto-tuning, then you get the following parameters:

Parameter	Description		
Pr.05-39	Stator resistance for a permanent magnet motor ( $\Omega$ )		
Pr.05-40	Permanent magnet motor Ld (mH)		
Pr.05-41	Permanent magnet motor Lq (mH)		
Pr.05-43	Ke parameter of a permanent magnet motor (V <sub>phase · rms</sub> / krpm) (When Pr.05-00 = 5, the Ke parameter is measured based on the actual motor rotation.) (When Pr.05-00 = 13, the Ke parameter is automatically calculated based on the motor power, current and rotor speed.)		

If an auto-tuning error (AUE) occurs, refer to Section 14 "Error Codes and Descriptions" for further treatment.

AUE Fault code	Description	
AUE (40)	Auto-tuning error	
AUE 1 (142)	Auto-tuning error 1 (no feedback current error)	
AUE 2 (143)	Auto-tuning error 2 (motor phase loss error)	

#### 5. Set control mode

Set Pr.00-11 = 6 PM Sensorless FOC control mode


- 6. After auto-tuning, cycle the power.
- 7. Measure the initial magnetic pole angle of PM

Set Pr.10-53 PM initial rotor position detection method:


- 0: Disable
- 1: Using I/F current command (Pr.10-31) to attract the rotor to zero degrees
- 2: High frequency injection
- 3: Pulse injection

(Set "2" for IPM; set "3" for SPM; set "1" when setting "2" and "3" are not enough)

#### II. PM Sensorless FOC Mode - No load / Light-load Adjustment




- No-load / Light-load Operation Adjustment
  - 8. Start the motor without load
    - (a) Set Pr.11-00 = 1 Auto-tuning for ASR and APR
    - (b) Start the motor without load, and operates the motor to 1/2 of rated rotor speed
    - A1. If the start direction is wrong or starting rotation is not smooth (ocA), adjust Pr.11-01 (System inertia). When the Ke parameter (Pr.05-43) is < 25 V, increase Pr.10-31 (I/F mode, current command) or Pr.10-39, Pr.10-40 (Switch the frequency from I/F mode to PM Sensorless mode).
    - A2. If the motor starts up with a reverse direction, but operates with a correct direction, adjust Pr.10-52 (Injection magnitude) when using High frequency injection to detect the PM initial rotor position (Pr.10-53 = 2); increase Pr.10-42 (Initial angle detection pulse value) to improve the accuracy of angle detection when using Pulse injection to detect the PM initial rotor position (Pr.10-53 = 3).
  - 9. Acceleration test with no-load / light-load
    - A3. Accelerate the motor to the rated frequency, and check if it operates stably.
      - a. If the motor output frequency presents steady state speed wave, increase Pr.11-04 (ASR2 high-speed bandwidth) or Pr.11-01 (Per-unit of system inertia).
      - b. If the motor output frequency presents large fluctuations or diverges, increase Pr.10-55 (Magnetic flux linkage estimate high-speed gain) or decrease Pr.10-56 (Kp of phase-locked loop).
    - A4. Accelerate the motor to the maximum frequency, and check if it operates stably. If the motor stalls at the maximum operation speed, increase Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.00-17 (Carrier frequency), or decrease Pr.10-56 (Kp of phase-locked loop).
    - \* Setting curve for speed regulator (ASR) and related parameters:



ASR adjustment- auto gain

Parameter	Description	Default
Pr.11-00	System control	0
Pr.11-01	Per-unit of system inertia	256
Pr.11-02	ASR1 / ASR2 switch frequency	7
	(set the switch frequency > Pr.10-39)	7 Hz
Pr.11-03	ASR1 low-speed bandwidth	10 Hz
Pr.11-04	ASR2 high-speed bandwidth	10 Hz
Pr.11-05 Zero-speed bandwidth		10 Hz

#### III. PM Sensorless FOC Mode - Load Starting Adjustment



- Load Operation Adjustment and Steady State Adjustment at Constant Speed
  - 11. Load operation test
    - B1. Low-frequency carrier capacity test (the output frequency is < 20% of rated speed):
      - a. If the frequency switch from I/F mode to PM Sensorless is zero (Pr.10-39 = 0 Hz), increase Pr.10-54 (Magnetic flux linkage estimate low-speed gain).
      - b. If the output frequency is less than Pr.10-39 (Frequency to switch from I/F mode to PM Sensorless), increase Pr.10-31 (I/F mode, current command).
    - B2. Carrier capacity test during acceleration
      In heavy load operation, accelerate the motor to rated speed according to the acceleration time:
      - a. If the motor responds too slowly or an over current occurs during the acceleration, increase Pr.10-57 (Ki phase-locked loop).
  - 12. Steady state test at constant speed, check if the motor operates stably at constant speed.
    - a. If the motor's output frequency presents periodic low-frequency wave, increase Pr.10-34 (PM sensorless speed estimator low-pass filter gain), or adjust the ASR parameters.
    - b. If the motor's output frequency presents extreme vibration, decrease Pr.10-34 (PM sensorless speed estimator low-pass filter gain) or Pr.10-56 (Kp phase-locked loop).

## PM Sensorless FOC Mode Adjustment Parameters

Refer to Section 12-1 Description of Parameter Settings for more details.

Parameter	Description		Default	Settings
Pr.10-31	I/F mode, current command		40	150
Pr.10-34	PM sensorless speed estimator low-pass filter gain	NA	1.00	0.00-655.35
Pr.10-39	Frequency to switch from I/F mode to PM sensorless mode	Hz	20.0	0.0–599.0
Pr.10-40	Frequency to switch from PM sensorless mode to I/F mode	Hz	20.0	0.0–599.0
Pr.10-54	Magnetic flux linkage estimate low-speed gain (applied to 230V / 460V models)	%	100	10–1000
Pr.10-55	Magnetic flux linkage estimate high-speed gain (applied to 230V / 460V models)	%	100	10–1000
Pr.10-56	Kp of phase-locked loop (applied to 230V / 460V models)	%	100	10–1000
Pr.10-57	Ki of phase-locked loop (applied to 230V / 460V models)		100	10–1000
	Initial Angle Estimating Paramete	ers		
Pr.10-42	Initial angle detection pulse value	NA	0.5	0.0–3.0
Pr.10-51	Injection frequency (applicable when Pr.10-53 = 2)	Hz	500	0–1200
Pr.10-52	Injection magnitude (applicable when Pr.10-53 = 2)	٧	15.0/30.0	0.0–200.0
Pr.10-53	PM initial rotor position detection method 0: Disable 1: Force attracting the rotor to zero degrees 2: High frequency injection 3: Pulse injection	NA	0	0–3
Motor Performance Control Parameters				
Pr.11-00	System control	bit	0	0–8


# Chapter 12 Description of Parameter Settings | CP2000

Parameter	Description		Default	Settings
Pr.11-02	ASR1 / ASR2 switch frequency		7.0	5.0-599.0
Pr.11-03	03 ASR1 low-speed bandwidth		10	1–100 (PM) 1–40 (IM)
Pr.11-04 ASR2 high-speed bandwidth		Hz	10	1–100 (PM) 1–40 (IM)
Pr.11-05	Zero-speed bandwidth	Hz	10	1–100 (PM) 1–40 (IM)

## 12-2-3 SynRM FOC Sensorless Vector Control Mode (SynRM Sensorless) Pr.00-11 = 8

## 1. Control diagram


SynRM Sensorless (applied to CP2000 V2.07 and above)



#### 2. SynRM Sensorless Adjustment Procedure

(\* the number marked on the procedure corresponds the number of following explanations)

I. Adjustment for SynRM Sensorless Parameters



#### Motor Parameters Adjustment

1. Parameter reset:

Pr.00-02 = 9 (50 Hz) or 10 (60 Hz), reset parameter to the default value

2. Select motor type:

Pr.05-33 = 3 (SynRM)

3. Motor nameplate parameter setting:

Parameter	Description		
Pr.01-01	Rated frequency (Hz)		
Pr.01-02	Rated voltage (V <sub>AC</sub> )		
Pr.05-34	Rated current (A)		
Pr.05-35	Rated power (kW)		
Pr.05-36	Rated rotor speed (rpm)		
Pr.05-37	Number of motor poles (poles)		

4. Motor parameter auto-tuning:

Set Pr.05-00 = 11 [SynRM parameter auto-tuning (without load)] and press "RUN" key to finish motor auto-tuning, then you get the following parameters:


Parameter	Description	
Pr.05-39	Stator resistance for a permanent magnet motor (Ω)	
Pr.05-40	Permanent magnet motor Ld (mH)	
Pr.05-41	Permanent magnet motor Lq (mH)	

5. Set control mode:

Set Pr.00-11 = 8 (SynRM Sensorless)


6. After auto-tuning, cycle the power.

#### II. SynRM Sensorless No-load Adjustment Procedure



#### No-load Operation Adjustment

- 7. Start the motor without load
  - A1. Start the motor without load, refer to the following adjustment before the operation frequency reaches 1/5 or motor's rated frequency:
    - a. If the motor starts in a wrong direction, the starting rotation is not smooth (ocA) or there is motor shaft lock, adjust Pr.10-31 (I/F mode, current command) and Pr.10-33 (PM FOC sensorless low-speed estimator bandwidth).
    - b. When there is an extreme vibration of the motor speed, adjust Pr.11-01 (Per-unit of system inertia) and Pr.11-03 (ASR1 low-speed bandwidth) depending on whether the motor departs from the load.
    - Setting curve for speed regulator (ASR) and related parameters:




ASR adjustment- auto gain

Parameter	Description	Default
Pr.11-00	System control	0
Pr.11-01	Per-unit of system inertia	256
	ASR1 / ASR2 switch frequency	
Pr.11-02	(set the switch frequency > 1/5 of	7 Hz
	motor's rated frequency)	
Pr.11-03 ASR1 low-speed bandwidth		10 Hz
Pr.11-04	Pr.11-04 ASR2 high-speed bandwidth	
Pr.11-05	Zero-speed bandwidth	10 Hz

- A2. The operation frequency exceeds the switch frequency for Pr.10-39
  - a. If there is an extreme vibration of speed and current when switching frequency, or a fault occurs during the switching process, adjust Pr.10-56 (Kp of phase-locked loop).
  - Both of adjustments for Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.10-56 (Kp of phase-locked loop) affect the performance of the speed estimator.
     Adjust only Pr.10-56 in no-load operation.
  - c. When there is a low-frequency vibration of speed during motor's operation, adjust Pr.11-01 (Per-unit of system inertia) and Pr.11-04 (ASR2 high-speed bandwidth) depending on whether the motor departs from the load.
- A3. Observe whether the motor operates stably when accelerates to the maximum frequency If the motor stalls at the maximum operation speed, decrease Pr.10-56 (Kp phase-locked loop)

#### III. SynRM Sensorless Start-up with Load Adjustment



#### Load Operation Adjustment

#### 8. Operation test with load

- B1. Low-frequency loading capacity test
  - a. If the low-frequency loading performance is low, increase Pr.10-31 (I/F mode, current command) and Pr.10-58 (mutual inductance compensation gain).
- b. If the low-frequency loading speed presents large plummet, or the output frequency presents low-frequency vibration, adjust Pr.11-03 (ASR1 low-speed bandwidth) and Pr.10-33 (PM FOC sensorless speed estimator bandwidth). Increase the setting to improve the response when the speed drops too much at transient load. Decrease the setting if the frequency presents an extreme vibration at stable load.

#### B2. High frequency loading capacity test

- a. If the high frequency loading performance is insufficient, increase Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.10-56 (Kp of phase-locked loop).
- b. If there is large plummet of loading speed, or the output frequency vibrates, adjust Pr.11-04 (ASR2 high-speed bandwidth), Pr.10-55 (Magnetic flux linkage estimate high-speed gain) and Pr.10-56 (Kp of phase-locked loop). Increase the setting to improve the response when the speed drops too much at transient load. Decrease the setting if the frequency presents an extreme vibration at stable load.

#### B3. Operation frequency exceeds the rated frequency

a. When there is a waveform of speed and current in the flux-weakening zone, and an oc or ov fault occurs during the deceleration, adjust Pr.01-51 (Flux-weakening overload stall prevention time) and Pr.10-31 (I/F mode current command).

#### SynRM Sensorless Mode Adjustment Parameters

Refer to Section 12-1 Description of Parameter Settings for more details.

Parameter	Description	Unit	Default	Settings
00-11	Speed control mode		0	0–8
00-17	Carrier frequency	kHz	4	4–8
01-51	Flux-weakening overload stall prevention time	sec.	1.00	0.00-600.00
05-00	Motor parameter auto-tuning		0	0–13
05-33	Induction motor or permanent magnet synchronous AC motor selection		3	0–3
05-34	Full-load current for a permanent magnet synchronous AC motor / reluctance motor		NA	NA
05-35	Rated power for a permanent magnet synchronous AC motor / reluctance motor		NA	0–655.35
05-36	Rated speed for a permanent magnet synchronous AC motor / reluctance motor		NA	0–65535
05-37	Number of poles for a permanent magnet synchronous AC motor / reluctance motor		NA	0–65535
05-38	System inertia for a permanent magnet synchronous AC motor / reluctance motor		NA	0.0–6553.5
05-39	Stator resistance for a permanent magnet synchronous AC motor / reluctance motor		0.000	0.000–65.535
05-40	Permanent magnet synchronous AC motor / reluctance motor Ld	mH	0.00	0.00-655.35

## Chapter 12 Description of Parameter Settings | CP2000

Parameter	Description	Unit	Default	Settings
05-41	Permanent magnet synchronous AC motor / reluctance motor Lq		0.00	0.00-655.35
07-12	Speed tracking during start-up		0	0–3
10-08	Treatment for speed observer feedback fault		2	0–2
10-09	Detection time of speed observer feedback fault	sec.	1.0	0.0–10.0
10-10	Speed observer stall level	%	115	0–120
10-11	Detection time of speed observer stall	sec.	0.1	0.0-2.0
10-12	Speed observer stall action		2	0–2
10-13	Speed observer slip range	%	50	0–0
10-14	Detection time of speed observer slip	sec.	0.5	0.0–10.0
10-15	Speed observer stall and slip error action		2	0–2
10-31	I/F mode, current command	%	15	0–150
10-33	PM FOC sensorless speed estimator bandwidth (low speed)		1.00	0.01–3.00
10-34	PM sensorless speed estimator low-pass filter gain		1.00	0.00-10.00
10-35	AMR (Kp) gain		0.4	0.00-3.00
10-36	AMR (Ki) gain		2.00	0.00-3.00
10-39	Frequency to switch from I/F mode to PM sensorless mode	Hz	10.00	0.0–599.00
10-51	Injection frequency		400	0–1200
10-52	Injection magnitude	%	30	10–50
10-55	PM initial rotor position detection method		1.0	0.1–3.0
10-56	Kp of phase-locked loop	Hz	10	5–50
10-58	Mutual inductance gain compensation		1.00	0.00-655.35
11-00	System control		0x201h	0–65535
11-01	Per-unit of system inertia	pu	256	0–65535
11-02	ASR1 / ASR2 switch frequency	Hz	10.00	5.00-599.00
11-03	ASR1 low-speed bandwidth	Hz	5	1–30
11-04	ASR2 high-speed bandwidth		5	1–30
11-05	Zero-speed bandwidth	Hz	5	1–30
11-17	Forward motor torque limit Quadrant I	%	200	0–500
11-18	Forward regenerative torque limit Quadrant II	%	200	0–500
11-19	Reverse motor torque limit Quadrant III	%	200	0–500
11-20	Reverse regenerative torque limit Quadrant IV	%	200	0–500



- ① Display error signal
- 2 Abbreviate error code
- 3 Display error description

ID No.	Display on LCD Keypad	Warning Name	Description	
1	Warning CE1 Comm. Error 1	Communication error 1 (CE1)	RS-485 Modbus illegal function code	
		Action and	d Reset	
	Action condition	When the function code	e is not 03, 06, 10 and 63	
	Action time	Immediately act		
War	ning setting parameter	N/A		
Reset method		"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct function code.		
Reset condition		Immediately reset		
	Record	N/A		
	Cause		Corrective Actions	
	t communication nd from upper unit	Check if the communication command is correct.		
Malfunct	Verify the wiring and grounding of the communication circuit. It is recommon to separate the communication circuit from the main circuit, or wire in 90 defor effective anti-interference performance.			
	communication setting upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconnection or bad connection of the cable and replace it			place it if necessary.	

Display on LCD Keypad	Warning Name	Description	
	Warning Name	Description	
Warning CK1 Comm Command Er	Communication command error 1 (CK1)	Keypad communication data, illegal function code (Keypad auto-detects this error and displays it.)	
	Action and	d Reset	
Action condition	When the function code	e is not 03, 06, 10 and 63	
Action time	Immediately act		
Warning setting parameter	N/A	N/A	
Reset method	Remove the keypad and	d then reconnect it to the motor drive.	
Reset condition	Immediately reset		
Record	N/A		
Cause		Corrective Actions	
Incorrect communication	Keypad and the motor of	drive don't communicate properly. It is recommended to	
command from keypad	remove the keypad and	then reconnect it to the motor drive.	
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.		
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.		

ID No.	Display on LCD Keypad	Warning Name	Description	
2	Warning CE2 Comm. Error 2	Communication error 2 (CE2)	RS-485 Modbus illegal data address	
		Action and	d Reset	
	Action condition	When the input data ad-	dress is incorrect	
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct data address.		
Reset condition Imm		Immediately reset		
Record N/A		N/A		
Cause			Corrective Actions	
	t communication ad from upper unit	Check if the communication command is correct.		
Malfunct	iion caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	communication setting upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconnor of the ca	ection or bad connection ble	Check the cable and replace it if necessary.		

Display on LCD Keypad	Warning Name	Description		
Warning CK2 Comm Address Er	Communication address error (CK2)	Keypad communication data, illegal data address (Keypad auto-detects this error and displays it.)		
	Action and			
Action condition	When the input data add	dress is incorrect		
Action time	Immediately act			
Warning setting parameter	N/A			
Reset method	Remove the keypad and then reconnect it to the motor drive.			
Reset condition	Immediately reset			
Record	N/A	N/A		
Cause		Corrective Actions		
Incorrect communication command from keypad		drive don't communicate properly. It is recommended to then reconnect it to the motor drive.		
Verify the wiring and grounding of the communication circuit. It is recommunication caused by interference to separate the communication circuit from the main circuit, or wire in 90 for effective anti-interference performance.		nication circuit from the main circuit, or wire in 90 degree		
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.			
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.			

ID No.	Display on LCD Keypad	Warning Name	Description	
3	Warning CE3 Comm. Error 3	Communication error 3 (CE3)	RS-485 Modbus illegal data value	
		Action and	l Reset	
	Action condition	When the length of com	munication data is too long	
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct communication data value.		
Reset condition		Immediately reset		
Record N/A		N/A		
	Cause Corrective Actions		Corrective Actions	
	t communication ad from upper unit	Check if the communication command is correct.		
Malfunct		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different from upp	communication setting per unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconno of the ca	ection or bad connection able	Check the cable and replace it if necessary.		

Display on LCD Keypad	Warning Name	Description	
Warning CK3 Comm Data Error	Communication data error (CK3)	Keypad communication data, illegal data value (Keypad auto-detects this error and displays it.)	
	Action and		
Action condition		munication data is too long	
Action time	Immediately act		
Warning setting parameter	N/A		
Reset method	Remove the keypad and	d then reconnect it to the motor drive.	
Reset condition	Immediately reset		
Record	N/A		
Cause		Corrective Actions	
Incorrect communication	Keypad and the motor of	drive don't communicate properly. It is recommended to	
command from keypad	remove the keypad and	then reconnect it to the motor drive.	
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.		
Disconnection or bad connection of the cable	Check the cable and replace it if necessary.		

ID No.	Display on LCD Keypad	Warning Name	Description	
4	Warning CE4 Comm. Error 4	Communication error 4 (CE4)	RS-485 Modbus data is written to read-only address	
		Action and	d Reset	
	Action condition	When the data is writter	n to read-only address	
	Action time	Immediately act		
War	ning setting parameter	N/A		
	Reset method	"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the correct written address of communication data.		
Reset condition Immed		Immediately reset		
	Record N/A			
	Cause		Corrective Actions	
	t communication nd from upper unit	Check if the communication command is correct.		
Verify the wiring and grounding of the communication circuit. It is recommunication caused by interference to separate the communication circuit from the main circuit, or wire in 90 for effective anti-interference performance.		nication circuit from the main circuit, or wire in 90 degree		
from the	communication setting upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconnof the ca	ection or bad connection able	Check the cable and replace it if is necessary.		

Diamless and CD Keyman	Manair a Nara	Description	
Display on LCD Keypad	Warning Name	Description	
Warning CK4 Comm Slave Error	Communication slave error (CK4)	Keypad communication data is written to read-only address. (Keypad auto-detects this error and displays it.)	
	Action and	Reset	
Action condition	When the data is writter	n to read-only address	
Action time	Immediately act		
Warning setting parameter	N/A		
Reset method	Remove the keypad and then reconnect it to the motor drive.		
Reset condition	Immediately reset		
Record	N/A		
Cause		Corrective Actions	
Incorrect communication command from keypad	Keypad and the motor drive don't communicate properly. It is recommended to remove the keypad and then reconnect it to the motor drive. If the problem persists after reconnecting the keypad, pay attention to the motor drive status. For example: Motor drive might reset to default setting during operation or while enabling PLC function.		
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.		
Disconnection or bad connection of the cable	Check the cable and replace it if is necessary.		

ID No.	Display on LCD Keypad	Warning Name	Description	
5	Warning CE10 Comm. Error 10	Communication error 10 (CE10)	RS-485 Modbus transmission time-out	
		Action and	d Reset	
	Action condition	When the communication time-out	ation time exceeds the detection time of Pr.09-03 t	
	Action time	Setting for Pr.09-03		
War	ning setting parameter	N/A		
	Reset method	"Warning" occurs when Pr.09-02 = 0 and the motor drive keeps running. The drive resets automatically when receiving the next communication packet.		
Reset condition		Immediately reset		
	Record	N/A		
	Cause		Corrective Actions	
the com	r.09-03 setting time	Check if the upper unit transmits the communication command within the setting time for Pr.09-03.		
Malfunct	tion caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	t communication setting upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconnof the ca	ection or bad connection able	Check the cable and replace it if necessary.		

Display on LCD Keypad	Warning Name	Description
Warning CK10 KpdComm Time Out	Keypad communication time out (CK10)	Keypad communication data, transmission time-out (Keypad auto-detects this error and displays it.)
	Action and	d Reset
Action condition	When the communication communication time-out	on time exceeds the detection time of Pr.09-03 t
Action time	Setting for Pr.09-03	
Warning setting parameter	N/A	
Reset method	Remove the keypad and	d then reconnect it to the motor drive.
Reset condition	Immediately reset	
Record	N/A	
Cause		Corrective Actions
Incorrect communication	Keypad and the motor	drive don't communicate properly. It is recommended to
command from keypad	remove the keypad and	then reconnect it to the motor drive.
Malfunction caused by interference	Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.	
Different communication setting from keypad	Check if the Baud rate = 19200 bps. Format = RTU8, N, 2.	
Disconnection or bad connection of the cable	Check the cable and re	place it if necessary.

ID No.	Display on LCD Keypad	Warning Name	Description	
7	Warning SE1 Save Error 1	Save error 1 (SE1)	Keypad COPY error 1: Keypad copy time-out	
		Action and	Reset	
"SE1" warning occurs when the keypad does not transmit the COPY of to the drive, and does not transmit any data to the drive again in 10 in time you copy the parameters to the drive.		not transmit any data to the drive again in 10 ms at the		
Action time 10 ms				
War	ning setting parameter	N/A		
Reset method		Manual reset		
Reset condition		Immediately reset		
Record N/A				
	Cause		Corrective Actions	
Commu	nication connection error	SE1: The causes of error are mostly communication problems between the keypad and control board. Potential causes include communication signal		
Keypad	error	interference and the unacceptable communication command to the Slave.  Check if the error occurs randomly, or only occurs when copying certain parameters (the error displays on the upper right corner of the copy page). If you cannot clear the error, please contact Delta.		
Control	board error			

ID No.	Display on LCD Keypad	Warning Name	Description
8	Warning SE2 Save Error 2	Save error 2 (SE2)	Keypad COPY error 2: parameter writing error
		Action and	d Reset
	Action condition	copy parameters to the	when writing the parameters incorrectly at the time you drive. For example, you copy the new firmware version to the drive with old firmware version.
	Action time	N/A	
War	ning setting parameter	N/A	
Reset method		Manual reset	
Reset condition		Immediately reset	
Record		N/A	
Cause			Corrective Actions
	v parameters to the new e version.	SE2: In this stage, the copied data has been transmitted to the Slave.  The Slave compares and processes the copied data, and then saves the data the Data ROM. During the process, the data error (should be attribution en may occur, or the data cannot be saved to EEPROM. At this time, the warn occurs.  It is suggested to check the status of Data ROM and remove the error caus first.  If you cannot clear the error, please contact Delta.	
Malfunction caused by interference Ve			grounding of the main circuit, control circuit and the ti-interference performance.

ID No.	Display on LCD Keypad	Warning Name	Description	
9	Warning  oH1  Over heat 1 warn	IGBT over-heating warning (oH1)	The AC motor drive detects over-heating of IGBT, and over the protection level of oH1 warning. (When Pr.06-15 is higher than the IGBT over-heating level, the drive shows oH1 error without displaying oH1 warning.)	
		Action and	Reset	
	Action condition	Pr.06-15		
	Action time	"oH1" warning occurs value.	when IGBT temperature is higher than Pr.06-15 setting	
War	ning setting parameter	N/A		
	Reset method	Auto-reset		
	D 1 177	The drive auto-resets v	vhen IGBT temperature is lower than oH1 warning level	
	Reset condition	minus (–) 5°C		
	Record	N/A		
	Cause		Corrective Actions	
or tempe is too hig	ph, or if there is obstruction			
	there is any obstruction on sink or if the fan is running			
Insufficie	ent ventilation space	Increase ventilation space of the drive.		
	the drive matches the ended loading	<ol> <li>Decrease loading.</li> <li>Decrease the carrier.</li> <li>Replace with a drive with larger capacity.</li> </ol>		
	e has run 100% or more of I output for a long time			

	5: 1 10514	14/ 1 11	5	
ID No.	Display on LCD Keypad	Warning Name	Description	
10	Warning oH2 Over heat 2 warn	Board-level component overheating warning (oH2)	The drive has detected over heat of the board-level component	
		Action and	d Reset	
	Action condition	oH2 error level minus (-	-) 5°C	
	Action time	The oH2 warning occur than oH2 warning level	s when the board-level component temperature is higher	
War	ning setting parameter	N/A		
	Reset method	Auto-reset		
		The drive auto-resets when the board-level component temperature is lower		
	Reset condition	than oH2 error level minus (–) 10°C		
Record		N/A		
Cause			Corrective Actions	
Check if the ambient temperature or temperature inside the cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.		<ul><li>3. Change the installer resistors, in the surface of the s</li></ul>	ne ventilation hole of the control cabinet.  ed place if there are heating objects, such as braking roundings.  fan or air conditioner to lower the temperature inside the	
Check if there is any obstruction on the heat sink or if the fan is running		Remove the obstruction or replace the cooling fan.		
Insufficie	sufficient ventilation space Increase ventilation space of the drive.		ce of the drive.	
Check if the drive matches the corresponded loading  1. Decrease loading. 2. Decrease the carrier. 3. Replace with a drive with larger capacitation.				

The drive has run 100% or more of the rated output for a long time	Replace with a drive with larger capacity.
Unstable power	Install reactor(s).
The load changes frequently	Reduce the changes of the load.

oH1/ oH2 warning level

oH1/ oH2 warning level	T	T	
Model	oH1	oH2	oH warning oH1 warning = (Pr. 06-15)
VFD007CP23A-21			, ,
VFD015CP23A-21			
VFD022CP23A-21			
VFD037CP23A-21			
VFD055CP23A-21			
VFD075CP23A-21		110	
VFD110CP23A-21			
VFD150CP23A-21	110		oH1 Warning = oH1 – 5
VFD185CP23A-21			oH2 Warning = oH2 – 5
VFD220CP23A-21			j i
VFD300CP23A-21			
VFD370CP23A-00/-21			
VFD450CP23A-00/-21			
VFD550CP23A-00/-21		90	
VFD750CP23A-00/-21			
VFD900CP23A-00/-21			
VFD007CP43A/4EA-21			
VFD015CP43B/4EB-21	440	440	oH1 Warning = oH1 – 5
VFD022CP43B/4EB-21	110	110	oH2 Warning = oH2 – 5
VFD037CP43B/4EB-21			-
VFD040CP43A/4EA-21			
VFD055CP43B/4EB-21			
VFD075CP43B/4EB-21			
VFD110CP43B/4EB-21		110	
VFD150CP43B/4EB-21		110	
VFD185CP43B/4EB-21			
VFD220CP43A/4EA-21			
VFD370CP43B/4EB-21			
VFD450CP43S-00/-21			
VFD550CP43S-00/-21			
VFD750CP43B-00/-21			
VFD900CP43A-00/-21			
VFD1100CP43A-00/-21			
VFD1320CP43B-00/-21	110		oH1 Warning = oH1 – 5
VFD1600CP43A-00/-21	110		oH2 Warning = oH2 – 5
VFD1850CP43B-00/-21			
VFD2000CP43A-00/-21		90	
VFD2200CP43A-00/-21			
VFD2500CP43A-00/-21			
VFD2800CP43A-00/-21			
VFD3150CP43A-00			
VFD3150CP43C-00/-21			
VFD3550CP43A-00			
VFD3550CP43C-00/-21			
VFD4000CP43A-00			
VFD4000CP43C-00/-21			
VFD5000CP43A-00		85	
VFD5000CP43C-00/-21			
VFD5600CP43A-00		Contact D	elta for more information
VFD5600CP43C-21			
VFD6300CP43A-00		Contact D	elta for more information
VFD6300CP43C-21	400	0.5	-114 M
VFD015CP53A-21	100	85	oH1 Warning = oH1 – 5

Model	oH1	oH2	oH warning oH1 warning = (Pr. 06-15)
VFD022CP53A-21			oH2 Warning = (F1. 00-13)
VFD022CF33A-21			Oriz Warning – Oriz – 3
VFD057CF35A-21			
VFD033CF33A-21			
VFD073CF33A-21		70	
VFD110CF33A-21			
VFD185CP63A-21			
VFD165CP65A-21			
VFD300CP63A-21	90	85	
VFD370CP63A-21			
VFD450CP63A-00/-21	100		
VFD550CP63A-00/-21			
VFD750CP63A-00/-21			
VFD900CP63A-00/-21		65	
VFD1100CP63A-00/-21			oH1 Warning = oH1 – 5
VFD1320CP63A-00/-21			oH2 Warning = oH2 – 5
VFD1600CP63A-00/-21			
VFD2000CP63A-00/-21	110		
VFD2500CP63A-00/-21	110		
VFD3150CP63A-00/-21			
VFD4000CP63A-00/-21		70	
VFD4500CP63A-00/-21			
VFD5600CP63A-00/-21			
VFD6300CP63A-00/-21			

ID No.	Display on LCD Keypad	Warning Name	Description	
11	Warning PID PID FBK Error	PID feedback error (PID)	PID feedback loss (warning for analog feedback signal; works only when PID enables)	
		Action and	Reset	
	Action condition	When the analog input mA)	is lower than 4 mA (only detects analog input of 4-20	
	Action time	Pr.08-08		
Warning setting parameter		Pr.08-09 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: Warn and operate at last frequency		
	Reset method	clears when the	surs when Pr.08-09 = 0 or 3. The "Warning" automatically ne feedback signal is larger than 4mA.  when Pr.08-09 = 1 or 2. You must reset manually.	
	Reset condition	Immediately reset		
	Record	Records when Pr.08-09 Does not record when F	= 1 or 2 ("Error"). Pr.08-09 = 3 ("Warning").	
Cause Corrective Actions		Corrective Actions		
Loose or broken PID feedback wiring Tighten the terminals again.  Replace with a new cable.				
Feedbad	edback device malfunction Replace with a new feedback device.			
Hardwar	e error	If the PID error still occ repair.	urs after checking all the wiring, return to the factory for	

ID No.	Display on LCD Keypad	Warning Name	Description	
12	Warning ANL Analog loss		Analog input current loss (including all analog 4–20 mA signals)	
		Action and	Reset	
	Action condition	When the analog input i	s lower than 4 mA (only detects analog input 4–20 mA)	
	Action time	Immediately act		
Warning setting parameter		Pr.03-19 0: Disable 1: Continue operation at the last frequency (warning, keypad displays ANL) 2: Decelerate to 0 Hz (warning, keypad displays ANL) 3: Stop immediately and display ACE		
	Reset method	clears when the	ours when Pr.03-19 = 1 or 2. The "Warning automatically ne analog input signal is larger than 4mA.  when Pr.03-19 = 3. You must reset manually.	
	Reset condition	Immediately reset	,	
	Record	Does not record when Pr.03-19 = 1 or 2 ("Warning").		
	Cause	Corrective Actions (		
Loose or broken ACI wiring  Tighten the terminals again. Replace with a new cable.				
External device error Replace new device.				
Hardwa	re error	If the AnL error still occ repair.	urs after checking all the wiring, return to the factory for	

ID No.	Display on LCD Keypad	Warni	ng Name	Description	
13	Warning  uC  Under Current	Unde	er current (uC)	Low current	
			Action and	Reset	
	Action condition	Pr.06-71			
	Action time	Pr.06-72			
Warning setting parameter		Pr.06-73 0: No function 1: Fault and coast to stop 2: Fault and ramp to stop by 2 <sup>nd</sup> deceleration time 3: Warn and operation continue			
Reset method		Auto "Warning" occurs when Pr.06-73 = 3. The "Warning" automatically clears when the output current is > (Pr.06-71 + 0.1 A).  Manual "Error" occurs when Pr.06-73 = 1 and 2. You must reset manually.			
	Reset condition	Immediately reset			
	Record	Does not record when Pr.06-73 = 3 and uC displays "Warning".			
	Cause		Corrective Actions		
Broken motor cable		Exclude the connection issue of the motor and its load.			
Improper setting for the low current protection Set the proper settings for Pr.06-71, Pr.06-72 and Pr.06-73.		for Pr.06-71, Pr.06-72 and Pr.06-73.			
Low load	Low load		Check the loading status. Make sure the loading matches the motor capacity.		

ID No.	Display on LCD Keypad	Warning Name	Description		
17	Warning oSPD Over Speed Warn	Over speed warning (oSPd)	Over speed warning		
		Action and	d Reset		
	Action condition	The encoder feedback	speed > Pr.10-10		
	Action time	Pr.10-11			
\Mar	ning setting parameter	Pr.10-12 = 0			
vvai	Tillig Setting parameter	0: Warn and keep operation			
Reset method		"Warning" automatically	clears when the drive stops		
Reset condition		"Warning" automatically	clears when the drive stops		
Record		N/A			
Cause			Corrective Actions		
Improper setting for Pr.10-25 FOC bandwidth of speed observer		Decrease setting value	for Pr.10-25.		
Improper bandwidth setting for ASR speed controller		Increase the bandwidth setting for ASR speed controller.			
Incorrect motor parameter setting Reset m		'	and run parameter tuning.		
Malfunction caused by interference		Verify wiring of the cor prevent interference.	ntrol circuit, and wiring/grounding of the main circuit to		

ID No.	Display on LCD Keypad	Warning Name	Description		
18	Warning  dAvE  Deviation Warn	Deviation Warning (dAvE)	Over speed deviation warning		
		Action and	Reset		
	Action condition	Pr.10-13			
	Action time	Pr.10-14			
\Mar	ning setting parameter	Pr.10-15 = 0			
vvaii		0: Warn and keep opera			
	Reset method		clears when the drive stops		
	Reset condition	After the drive stops			
	Record	N/A			
Cause			Corrective Actions		
Improper parameter setting for the slip error		Reset proper value for Pr.10-13 and Pr.10-14.			
Improper setting for ASR parameter and acceleration/ deceleration		Reset ASR parameters. Set proper accel./ decel. time.			
Accel./ D	Decel. time is too short	Reset proper accel./ decel. time.			
Motor locked		Remove the causes of motor locked.			
Mechanical brake is not released		Check the active timing of the system.			
Incorrect parameter setting of torque limit Adjust to proper setting value.  (Pr.06-12, Pr.11-17–20)		value.			
Malfunction caused by interference		Verify wiring of the corprevent interference.	ntrol circuit, and wiring/grounding of the main circuit to		

ID No.	Display on LCD Keypad	Warning Name	Description	
19	Warning PHL Phase Loss	Phase loss (PHL)	Input phase loss warning	
		Action and	Reset	
	Action condition	One of the phases outp	uts less than Pr.06-47	
	Action time	Pr.06-46		
War	ning setting parameter	Pr.06-45 = 0 0: Warn and keep opera	ation	
	Reset method	"Warning" automatically	clears when the drive stops	
	Reset condition	After the drive stops		
	Record	N/A		
	Cause	Corrective Actions		
Phase loss of the input power		Verify wiring of the main circuit.		
Single phase power input on a three-phase model		Use the model with voltage that matches the power.		
The power voltage has changed		broken.	rcuit works well, check if the MC of the main circuit is erifying the power is normal. If PHL still occurs, return to	
Loose wiring terminal of input power		Tighten the terminal screws with the torque listed in the user manual.		
Check if the input cable of 3-phase power is broken		Make sure the wiring is correct. Replace the broken part of the cable.		
The volt	age of input power has	Check setting for Pr.06-50 (Time for Input Phase Loss Detection) and Pr.06-52 (Ripple of Input Phase Loss).		
Unbalance three-phase of the input power		Check the status of three-phase power.		

ID No.	Display on LCD Keypad	Warning Name	Description		
20	Warning ot1 Over Torque 1	Over-torque 1 (ot1)	Over-torque 1 warning		
		Action and	Reset		
	Action condition	Pr.06-07			
	Action time	Pr.06-08			
Warning setting parameter		Pr.06-06 = 1 or 3 0: No function 1: Continue operation after over-torque detection during constant speed operation 2: Stop after over-torque detection during constant speed operation 3: Continue operation after over-torque detection during RUN 4: Stop after over-torque detection during RUN			
	Reset method		Pr.06-07 – 5%), the Ot1 warning automatically clears		
	Reset condition		Pr.06-07 – 5%), the Ot1 warning automatically clears		
	Record	N/A	•		
	Cause	Corrective Actions			
Incorrec	t parameter setting	Configure the settings for Pr.06-07 and Pr.06-08 again.			
	ical error (e.g. mechanical to over-torque)	Remove the causes of malfunction.			
The load	d is too large	Decrease the loading. Replace with a motor with larger capacity.			
Accel./ Decel. time and working cycle is too short Increase the setting values for Pr.01-12–01-19 (accel./ decel. time			ues for Pr.01-12–01-19 (accel./ decel. time)		
V/F voltage is too high			Pr.01-01-01-08 (V/F curve), especially the setting value ge (if the mid-point voltage is set too small, the load ow-speed).		

The motor capacity is too small	Replace with a motor with larger capacity.
Over-load during low-speed operation	Decrease the loading during low-speed operation. Increase the motor capacity.
The torque compensation is too large	Adjust the torque compensation value (Pr.07-26 torque compensation gain) until the output current decreases and the motor does not stall.
Improper parameter settings for the speed tracking function (including restart after momentary power loss and restart after fault)	Correct the parameter settings for speed tracking. Start the speed tracking function. Adjust the maximum current for Pr.07-09 speed tracking.

ID No.	Display on LCD Keypad	Warning Name	Description	
21	Warning ot2 Over Torque 2	Over-torque (ot2)	Over-torque 2 warning	
		Action and	nd Reset	
	Action condition	Pr.06-10		
	Action time	Pr.06-11		
Warı	ning setting parameter	operation 2: Stop after over-torque 3: Continue operation a	after over-torque detection during constant speed ue detection during constant speed operation after over-torque detection during RUN ue detection during RUN	
	Reset method		(Pr.06-10 – 5%), the Ot2 warning automatically clears	
	Reset condition	When output current <	(Pr.06-10 – 5%), the Ot2 warning automatically clears	
	Record	N/A		
	Cause		Corrective Actions	
Incorrect	t parameter setting	Configure the settings f	for Pr.06-10 and Pr.06-11	
Mechanical error (e.g. mechanical lock due to over-torque)		Remove the causes of malfunction.		
	l is too large	Decrease the loading. Replace with a motor w	with larger capacity.	
Accel./ D	Decel. time and working too short		alues for Pr.01-12–01-19 (accel./ decel. time)	
V/F volta	nge is too high	Adjust the V/F curve (Motor 2, Pr.01-35–01-42), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity decreases at low-speed).		
The moto	or capacity is too small	Replace with a motor w	with larger capacity.	
operation		Decrease the loading during low-speed operation. Increase the motor capacity.		
The torq	ue compensation is too		pensation value (Pr.07-26 torque compensation gain) until reases and the motor does not stall.	
Improper the spee (including	r parameter settings for ed tracking function g restart after momentary ss and restart after fault)	the output current decreases and the motor does not stall.  Correct the parameter settings for speed tracking.  Start speed tracking function.  Adjust the maximum current for Pr.07-09 speed tracking.		

ID No. Display on LCD Keypad	Warning Name	Description	
AUTO	<u> </u>	·	
Warning	Motor over-heating	Motor over-heating warning.	
22_1 oH3	(oH3) PTC	The AC motor drive detects the temperature inside the motor is too high	
Motor Over Heat		moter is too mgm	
	Action and		
Action condition	Pr.03-00 = 6 (PTC), PTC input level > Pr.06-30 (default = 50%)		
Action time	Immediately act	0	
	Error treatment: Pr.06-2 0: Warn and keep opera		
	1: Fault and ramp to stop		
	2: Fault and coast to sto		
Warning setting parameter	3: No warning	· F	
		d when the temperature is ≤ Pr.06-30 level, the oH3	
	warning automatically c		
	When Pr.06-29 = 0 ("Wa	arning"), it automatically resets.	
Reset method		pH3 displays "Warning". When the temperature is ≤ warning automatically clears.	
Reset condition		s ≤ Pr.06-30 level, the oH3 warning automatically clears.	
Record	N/A		
Cause	Corrective Actions		
Motor locked	Clear the motor lock status.		
The load is too large	Decrease the loading.  Replace with a motor with larger capacity.		
Ambien temperature is too high	Change the installed place if there are heating devices in the surroundings. Install/ add cooling fan or air conditioner to lower the ambient temperature.		
Motor cooling system error	Check the cooling system to make it work normally.		
Motor fan error	Replace the fan.		
	Decrease low-speed operation time.		
Operates at low-speed too long	Change to dedicated motor for the drive.		
Appl / Dood, time and working	Increase the motor capa	acity.	
Accel./ Decel. time and working cycle is too short		for Pr.01-12–01-19 (accel./ decel. time).	
V/F voltage is too high	Adjust settings for Pr.01-01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too small, the load capacity		
V/F voltage is too nigh	decreases at low-speed		
Check if the motor rated current			
matches the motor nameplate	Configure the correct ra	ted current value of the motor again.	
Check if the PTC is properly set and wired	Check the connection b	etween PTC thermistor resistor and the heat protection.	
Check if the setting for stall prevention is correct	Set the stall prevention	to the proper value.	
abalance three-phase pedance of the motor.  Replace the motor.			
impedance of the motor	-		

ID No. Display on LCD Keypad	Warning Name	Description		
Warning OH3 Motor Over Heat	Motor over-heating (oH3) PT100	Motor over-heating warning. The AC motor drive detects the temperature inside the motor is too high.		
	Action and			
Action condition		PT100 input level > Pr.06-57 (default = 7 V)		
Action time  Warning setting parameter	warning automatically of	when the temperature is < Pr.06-56 level, the oH3		
	according to the operat	petween Pr.06-56 and Pr.06-57, the frequency outputs ing frequency setting for Pr.06-58.  3 displays "Warning". When the temperature is <		
Reset method		warning automatically clears.		
Reset condition		is < Pr.06-56 level, the oH3 warning automatically clears.		
Record	N/A			
Cause	Corrective Actions			
Motor locked	Clear the motor lock sta	atus.		
The load is too large	Decrease loading. Replace with a motor w	Replace with a motor with larger capacity.		
Ambien temperature is too high	Change the installed place if there are heating devices in the surroundings.  Install/ add cooling fan or air conditioner to lower the ambient temperature.			
Motor cooling system error	Check the cooling syste	em to make it work normally.		
Motor fan error	Replace the fan.			
Operates at low-speed too long	Decrease low-speed op Change to dedicated m Increase the motor cap	otor for the drive.		
Accel./ Decel. time and working cycle is too short	Increase the setting val	ues for Pr.01-12–01-19 (accel./ decel. time).		
V/F voltage is too high		Pr.01-01-01-08 (V/F curve), especially the setting value ge (if the mid-point voltage is set too small, the load ow-speed).		
Check if the motor rated current matches the motor nameplate	Configure the correct ra	ated current value of the motor again.		
Check if the PT100 is properly set and wired	Check the connection protection.	n between PT100 thermistor resistor and the heat		
Check if the setting for stall prevention is correct	Set the stall prevention	Set the stall prevention to the proper value.		
Unbalance three-phase impedance of the motor	Replace the motor.			
Harmonics is too high	Use remedies to reduce	e harmonics.		

ID No.	Display on LCD Keypad	Warning Name	Description
24	Warning  oSL  Over Slip Warn	Over slip warning (oSL)	Over slip warning. By using the maximum slip (Pr.10-29) as the base, when the drive outputs at constant speed, and the F>H or F <h 100%="" and="" exceeds="" level="" pr.07-29="Pr.10-29.&lt;/td" pr.07-30="" setting="" time,=""></h>
		Action and	
	Action condition	When the drive outputs at constant speed, and F > H or F < H exceeds the Pr.07-29 level	
	Action time	Pr.07-30	
Warning setting parameter		Pr.07-31 = 0 Warning 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning	
Reset method		F < H no longer exce clears.	when the drive outputs at constant speed, and F > H or eds the Pr.07-29 level, the oSL warning automatically
	Reset condition	N/A	
	Record	N/A	
	Cause		Corrective Actions
Check if the motor parameter is correct		Check the motor parameter.	
The load is too large Decrease the loa		Decrease the loading.	
Check if the settings for Pr.07-29, Pr.07-30 and Pr.10-29 are properly set		Check the parameter se	ettings for oSL protection.

ID No.	Display on LCD Keypad	Warning Name	Description	
25	Warning tUn Auto tuning	Auto tuning (tUn)	Parameter auto-tuning is processing. When running auto-tuning, the keypad displays "tUn".	
		Action and	d Reset	
	Action condition	When running Pr.05-00 motor parameter auto-tuning, the keypad displays "tUn".		
Action time		N/A		
Warning setting parameter		N/A		
Reset method		When auto-tuning is finclears.	nished and no error occurs, the warning automatically	
	Reset condition	When auto-tuning is finished and no error occurs.		
Record		N/A		
Cause			Corrective Actions	
The motor parameter is running auto-tuning		When the auto-tuning is	s finished, the warning automatically clears.	

ID No.	Display on LCD Keypad	Warning Name	Description	
28	Warning OPHL Output PHL Warn	Output phase loss (OPHL)	Output phase loss	
		Action and	Reset	
	Action condition	Pr.06-47		
	Action time	N/A		
Warning setting parameter		Pr.06-45 0: Warn and keep operating 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
Reset method		If Pr.06-45 is set to 0, the OPHL warning automatically clears after the drive stops.		
	Reset condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
	Unbalanced three-phase mpedance of the motor Replace the motor.			
Check if	the wiring is incorrect	Check the cable. Replace the cable.		
	the motor is a hase motor	Choose a three-phase motor.		
Check if broken	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the error still occurs, return to the factory for repair.  Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL error still shows on the display, return to the factory for repair.		
If capaci than the	ity of the drive is larger motor	Choose the matches ca	pacity of the drive and motor.	

ID No.	Display on LCD Keypad	Warning Name	Description	
30	Warning SE3 Copy Model Err 3	Copy model error 3 (SE3)	Keypad COPY error 3: copy model error	
		Action and	d Reset	
Action condition		"SE3" warning occurs when different drive identity codes are found during copying parameters.		
	Action time	Immediately act when the error is detected		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	N/A		
Record		N/A		
Cause			Corrective Actions	
Keypad copy between different power range drives		It is mainly to prevent p	arameter copies between different HP/models.	

ID No.	Display on LCD Keypad	Warning Name	Description
36	Warning CGdn Guarding T-out	CANopen guarding time-out (CGdn)	CANopen guarding time-out 1
		Action and	d Reset
		When CANopen Node	Guarding detects that one of the slaves does not
	Action condition	response, the CGdn err	
		The upper unit sets fact	or and time during configuration.
	Action time	The time that upper unit sets during configuration	
Warning setting parameter		N/A	
Reset method		Manual reset	
	Reset condition	The upper unit sends a	reset package to clear this fault.
	Record	N/A	
	Cause		Corrective Actions
The guarding time is too short, or less detection times		Increase the guarding ti	me (Index 100C) and detection times.
Malfunc	tion caused by interference	recommended to so or wire in 90 degree 2. Make sure the com	and grounding of the communication circuit. It is eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series. e or add terminating resistance.

ID No.	Display on LCD Keypad	Warning Name	Description	
37	Warning  CHbn  Heartbeat T-out	CANopen heartbeat error (CHbn)	CANopen heartbeat error	
		Action and		
Action condition		CHbn error shows.	eat detects that one of the slaves does not response, the ne confirming time of producer and consumer during	
	Action time	The upper unit sets the confirming time of producer and consumer during configuration.		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition		reset package to clear this fault	
	Record	When Pr.00-21 ≠ 3, CH	bn is a "Warning", and the warning is not recorded	
	Cause		Corrective Actions	
The hea	rtbeat time is too short	Increase heartbeat time	(Index 1016)	
1. Verify the wiring and grounding of the communication circuit recommended to separate the communication circuit from the ma or wire in 90 degree for effective anti-interference performance.  2. Make sure the communication circuit is wired in series.  3. Use CANopen cable or add terminating resistance.		eparate the communication circuit from the main circuit, e for effective anti-interference performance. munication circuit is wired in series.		
Commu bad con	nication cable is broken or nected	Check or replace the co	ommunication cable.	

ID No.	Display on LCD Keypad	Warning Name	Description	
39	Warning CbFn Can Bus Off	CANopen bus off error (CbFn)	CANopen BUS off error	
		Action and	Reset	
		Hardware When CANo	pen card is not installed, CbFn fault will occur.	
Action condition		Software fault will occ Too much in When the C		
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	Manual Reset		
	Reset condition	Cycle the power		
	Record	When Pr.00-21≠3, CbFn is a "Warning", and the warning is not recorded		
	Cause		Corrective Actions	
Check if installed	the CANopen card is	Make sure the CANope	n card is installed.	
Check if correct	the CANopen speed is	Reset CANopen speed (Pr.09-37)		
1. Verify the wiring and grounding of the communication circuit recommended to separate the communication circuit from the main or wire in 90 degree for effective anti-interference performance.  2. Make sure the communication circuit is wired in series.  3. Use CANopen cable or add terminating resistance.		eparate the communication circuit from the main circuit, for effective anti-interference performance. munication circuit is wired in series.		
Commulbad con	nication cable is broken or nected	Check or replace the co	ommunication cable.	

ID No.	Display on LCD Keypad	Warning Name	Description	
40	Warning Cldn CAN/S ldx exceed	CANopen index error (Cldn)	CANopen Index error	
Action and Reset			Reset	
	Action condition	CANopen communication Index error		
	Action time	Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	Manual Reset		
	Reset condition	Upper unit sends a reset package to clear this fault		
	Record	When Pr.00-21 ≠ 3, Cldn is a "Warning", and the warning is not recorded		
Cause		Corrective Actions		
Incorrect setting of CANopen index		Reset CANopen Index	(Pr.00-02 = 7)	

ID No.	Display on LCD Keypad	Warning Name	Description	
41	Warning CAdn CAN/S Addres set	CANopen station address error (CAdn)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action condition	CANopen station address error		
Action time		Immediately act when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	Manual Reset		
	Reset condition	Pr.00-02 = 7		
Record		When Pr.00-21 ≠ 3, CAdn is a "Warning", and the warning is not recorded		
Cause		Corrective Actions		
Incorrect setting of CANopen station address		<ol> <li>Disable CANopen (Pr.09-36 = 0)</li> <li>Reset CANopen (Pr.00-02 = 7)</li> <li>Reset CANopen station address (Pr.09-36)</li> </ol>		

ID No.	Display on LCD Keypad	Warning Name	Description
42	Warning  CFrn  CAN/S FRAM fail	CANopen memory error (CFrn)	CANopen memory error
Action and Reset			
Action condition		When the user update firmware version of the control board, the FRAM internal data will not be changed, then CFrn fault will occur.	
Action time		Immediately act when the fault is detected	
Warning setting parameter		N/A	
Reset method		Manual Reset	
Reset condition		Pr.00-02 = 7	
Record		When Pr.00-21 ≠ 3, CFrn is a "Warning", and the warning is not recorded	
Cause		Corrective Actions	
CANopen internal memory error		<ol> <li>Disable CANopen (Pr.09-36 = 0)</li> <li>Reset CANopen (Pr.00-20 = 7)</li> <li>Reset CANopen station address (Pr.09-36)</li> </ol>	

ID No.	Display on LCD Keypad	Warning Name	Description	
43	Warning CSdn SDO T-out	CANopen SDO time-out (CSdn)	SDO transmission time-out (only shows on master station)	
		Action and	d Reset	
	Action condition	When the CANopen ma "time-out", CSdn warnin	aster transmits SDO command, and the Slave response ag will occur.	
	Action time	Immediately act when the	ne fault is detected	
War	ning setting parameter	N/A		
	Racai mainnn	When the master resends a SDO command and receives the response, the warning automatically clears.		
	Reset condition	N/A		
Record		N/A		
	Cause		Corrective Actions	
Slave is	not connected	Connect slave and CAN	lopen BUS.	
The syn	chronize cycle is set too	Increase the synchronization time (Index 1006)		
		<ol> <li>Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
	ection or bad connection ommunication cable	Check the status of the	cable, or replace the cable.	

ID No.	Display on LCD Keypad	Warning Name	Description
44	Warning CSbn Buf Overflow	CANopen SDO receives register overflow (CSbn)	CANopen SDO receives register overflow
		Action and	Reset
Action condition		The upper unit sends too much SDO and causes buffer overflow	
Action time		Immediately act when the	he fault is detected
War	ning setting parameter	N/A	
	Reset method	The upper unit sends a reset package to clear the warning.	
	Reset condition	N/A	
Record		N/A	
Cause		Corrective Actions	
Too much SDO from the upper unit		Check if the master se sends SDO command a	ends too much SDO command. Make sure the master according to the command format.

ID No.	Display on LCD Keypad	Warning Name	Description	
46	Warning CPtn Error Protocol	CANopen format error (CPtn)	CANopen protocol format error	
		Action and	d Reset	
Action condition		The slave detects that data from the upper unit cannot be recognized, and then shows CPtn warning		
Action time		Immediately displays when the fault is detected		
Warning setting parameter		N/A		
	Reset method	The upper unit sends a reset packet to clear the warning		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
The upper unit sends incorrect communication packet		Make sure the master command format.	sends the packet based on CANopen DS301 standard	

ID No.	Display on LCD Keypad	Warning Name	Description	
47	Warning PLrA RTC Adjust	RTC adjust (PLrA)	PLC (RTC) is not adjusted	
		Action and	d Reset	
	Action condition	When using RTC functions RTC time, PLrA warning	tion for PLC program, and PLC detects unreasonable g displays.	
	Action time	Immediately displays when the second	nen the fault is detected	
War	ning setting parameter	N/A		
	Reset method	Auto Stops the PLC and runs again, the warning automatically clears		
		Manual Manual reset to clear this warning		
	Reset condition	Cycle the power		
Record		N/A		
Cause		Corrective Actions		
		Stop the PLC progra	am and restart it. e and cycle the power.	
KPC-CC01 does not adjust the RTC time and cycle the power.  Adjust the RTC time and cycle the power.		d cycle the power.		
PLC det time	ects unreasonable RTC	Stop the PLC program and restart it.     Cycle the power.		
Replace with a new KPC-CC01		<ol> <li>Stop the PLC progra</li> <li>Cycle the power.</li> </ol>	am and restart it.	

ID No.	Display on LCD Keypad	Warning Name	Description	
48	Warning PLiC InnerCOM error	InnerCOM error (PLiC)	InnerCOM error	
		Action and	d Reset	
	Action condition	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	N/A		
	Reset condition	When InnerCOM is back to normal condition, the warning automatically clears		
Record		N/A		
	Cause		Corrective Actions	
Commu	Communication cable is loose Check the connection of the communication cable		f the communication cable	
Verify the wiring and grounding of the communication circuit. It is recommunication caused by interference for effective anti-interference performance.  It recommended to install terminal resistor(s) on the first and the last uncommunication circuit.		nication circuit from the main circuit, or wire in 90 degree ence performance.		

ID No.	Display on LCD Keypad	Warning Name	Description	
49	Warning PIrt Keypad RTC T-out	Keypad RTC time-out (PLrt)	·	
		Action and	d Reset	
	Action condition	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	N/A		
	Reset condition	Cycle the power		
	Record	N/A		
Cause		Corrective Actions		
KPC-CC01 is not connected to the control board while using the RTC function		Do not remove the KPC-CC01 keypad while using RTC function.		

ID No.	Display on LCD Keypad	Warning Name	Description	
50	Warning PLod Opposite Defect	PLC opposite defect (PLod)	PLC download error warning	
		Action and	d Reset	
Action condition		During PLC downloading, the program source code detects incorrect address (e.g. the address exceeds the range), then the PLod warning shows.		
Action time		Immediately displays when the fault is detected		
Warning setting parameter		N/A		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
Incorrect component number is found when downloading the PLC program		Use the correct compor	nent number.	

ID No.	Display on LCD Keypad	Warning Name	Description	
51	Warning PLSv Save mem defect	PLC save memory error (PLSv)	Data error during PLC operation	
		Action and	d Reset	
Action condition		The program detects incorrect written address (e.g. the address has exceeded the range) during PLC operation, then the PLSv warning shows.		
Action time		Immediately displays when the fault is detected		
War	ning setting parameter	N/A		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
An incorrect written address is detected during PLC operation		Make sure the write-in address is correct and re-download the program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
52	Warning PLdA Data defect	Data defect (PLdA)	Data error during PLC operation	
		Action and	d Reset	
	Action condition	T. The program detects incorrect write-in address when decoding the program source code and downloading the PLC program (e.g. the address has exceeded the range), then PLdA warning acts.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	N/A		
	Reset method	Check if the program is not exist, the warning a	correct and re-download the program. If the fault does utomatically clears.	
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
During PLC operation, the external Modbus has written/read incorrect data to internal PLC program			transmits the correct command	

ID No.	Display on LCD Keypad	Warning Name	Description	
53	Warning PLFn Function defect	Function defect (PLFn)	PLC download function code error	
Action and Reset				
Action condition		The program detects incorrect command (unsupported command) during PLC downloading, then PLFn warning acts.		
Action time		Immediately displays w	hen the fault is detected	
War	ning setting parameter	N/A		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
Unsupported command has used while downloading the program		Check if the firmware of	f the drive is the old version. If yes, contact Delta.	

ID No.	Display on LCD Keypad	Warning Name	Description	
54	Warning PLor Buf overflow	PLC buffer overflow (PLor)	PLC register overflow	
		Action and	d Reset	
Action condition		When PLC runs the last command and the command exceeds the maximum capacity of the program, the PLor warning shows.		
Action time		Immediately displays when the fault is detected		
Warning setting parameter		N/A		
	Reset method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
1. Disable PLC The program detects source code error during PLC operation 2. Delete PLC program (Pr.00-02 = 6) 3. Enable PLC 4. Re-download PLC program			,	

ID No.	Display on LCD Keypad	Warning Name	Description	
55	Warning PLFF Function defect	Function defect (PLFF)	Function code error during PLC operation	
		Action and	d Reset	
Action condition		The program detects incorrect command (unsupported command) during PLC operation, then PLFF warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	NA		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
The PLC runs an incorrect command during operation		When starting the PLC function and there is no program in the PLC, the PLFF warning shows. This is a normal warning, please download the program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
56	Warning PLSn Check sum error	Checksum error (PLSn)	PLC checksum error	
		Action and	d Reset	
	Action condition	PLC checksum error is	detected after power on, then PLSn warning shows	
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	NA		
	Reset method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
The program detects checksum error during PLC operation		<ol> <li>Disable PLC</li> <li>Remove PLC progr</li> <li>Enable PLC</li> <li>Re-download PLC progress</li> </ol>	,	

ID No.	Display on LCD Keypad	Warning Name	Description	
57	Warning PLEd No end command	No end command (PLEd)	PLC end command is missing	
		Action and	Reset	
Action condition		The "End" command is missing until the last command is executed, the PLEd warning shows		
	Action time	Immediately displays when the fault is detected		
Warning setting parameter		NA		
	Reset method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A	·	
	Record	N/A		
Cause		Corrective Actions		
There is no "END" command during PLC operation		<ol> <li>Disable PLC</li> <li>Remove PLC progr</li> <li>Enable PLC</li> <li>Re-download PLC progress</li> </ol>	,	

ID No.	Display on LCD Keypad	Warning Name	Description	
58	Warning PLCr PLC MCR error	PLC MCR error (PLCr)	PLC MCR command error	
		Action and	d Reset	
Action condition		The MC command is detected during PLC operation, but there is no corresponded MCR command, then the PLCr warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	NA		
Reset method		Check if the program is not exist, the warning a	correct and re-download the program. If the fault does utomatically clears.	
	Reset condition	N/A		
Record		N/A		
Cause			Corrective Actions	
The MC command is continuously used for more than 9 times		The MC command cann program, then re-downless	not be used continuously for 9 times. Check and reset the oad the program.	

ID No.	Display on LCD Keypad	Warning Name	Description	
59	Warning PLdF Download fail	PLC download fail (PLdF)	PLC download fail	
		Action and		
Action condition		PLC download fail due to momentary power loss during the downloading, when power is ON again, PLdF warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	NA		
Reset method		Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
PLC download is forced to stop, so the program write-in is incompleted		Check if there is any er	ror in the program and re-download the PLC program	

ID No.	Display on LCD Keypad	Warning Name	Description	
60	Warning PLSF Scan time fail	PLC scan time fail (PLSF)	PLC scan time exceeds the maximum allowable time	
		Action and	d Reset	
	Action condition	When the PLC scan time exceeds the maximum allowable time (400 ms), PLSF warning shows.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	NA		
Reset method		Check if the program is not exist, the warning a	s correct and re-download the program. If the fault does utomatically clears.	
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
The PLC scan time exceeds the maximum allowable time (400ms)		Check if the source cod	e is correct and re-download the program	

ID No.	Display on LCD Keypad	Warning Name	Description	
61	Warning PCGd CAN/M Guard err	CAN/M guarding error (PCGd)	CANopen Master guarding error	
		Action and	Reset	
	Action condition	When CANopen Master response, the PCGd was	r Node Guarding detects that one of the Slaves does not arning will display	
	Action time	Immediately displays w	hen the fault is detected	
War	ning setting parameter	NA		
	Reset method	Check if the program is correct and re-download the program. If the fault does not exist, the warning automatically clears.		
Reset condition		N/A	•	
Record		N/A		
	Cause		Corrective Actions	
Slave is not connected or CANopen BUS cable is not connected		Connect the Slave and	CANopen BUS	
Malfunct	<ol> <li>Verify wiring/grounding of the communication circuit. It is recommended separate the communication circuit from the main circuit, or wire in degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		nunication circuit from the main circuit, or wire in 90 anti-interference performance. munication circuit is wired in series.	
Communication cable is broken or bad connected		Check or replace the communication cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
62	Warning PCbF CAN/M bus off	CAN/M BUS off (PCbF)	CANopen Master BUS off	
		Action and	Reset	
Action condition		off detection, or when displays.	ster detects error packets more than 255 during the BUS the CANopen card is not installed, the PCbF warning connected, the drive will not receive issues packet, and ot display.	
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	NA		
	Reset method	Cycle the power		
	Reset condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
Malfunction caused by interference		separate the commodegree for effective  2. Make sure the commodern the c	ding of the communication circuit. It is recommended to nunication circuit from the main circuit, or wire in 90 anti-interference performance. munication circuit is wired in series. e or add terminating resistance.	
Commulbad con	nication cable is broken or nected	Check or replace the co	ommunication cable.	

ID No.	Display on LCD Keypad	Warning Name	Description	
63	Warning PCnL CAN/M Node Lack	CAN/M node lack (PCnL)	CANopen Master node error	
		Action and	d Reset	
	Action condition	When the CANopen master configures different setting nodes from the actual nodes, the PCnL warning displays.		
Action time		Immediately displays when the fault is detected		
Warning setting parameter		N/A		
Reset method		When connect BUS to the original slave, or change the configured node numbers to meet the actual node quantity, the warning automatically clears.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
The configured node quantity is different from the actual nodes meet the actual node quantity  Connect BUS to the original slave, or change the configured node number of the actual node quantity.				
Communication cable is broken or bad connected		Check or replace the communication cable.		

ID No.	Display on LCD Keypad	Warning Name	Description	
64	Warning PCCt CAN/M Cycle Time	CAN/M cycle time-out (PCCt)	CANopen Master cycle time-out	
		Action and	Reset	
	Action condition	When the transmitted packet from CANopen master exceeds the maximum allowable quantity in a certain time, the PCCt warning displays.		
	Action time	Immediately displays when the fault is detected		
War	ning setting parameter	N/A		
Reset method		The warning automatically clears when changing the configuration and re-executing the program.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
CANope	e transmitted packet from en master exceeds the m allowable quantity in a ime			

ID No.	Display on LCD Keypad	Warning Name	Description	
65	Warning PCSF CAN/M SDO over	CAN/M SDO over (PCSF)	CANopen Master SDO overflow	
		Action and	d Reset	
	Action condition	When the CANopen	master transmits too much SDO that causes buffer	
	Action condition	overflow, the PCSF warning displays		
	Action time	Immediately displays w	hen the fault is detected	
War	ning setting parameter	N/A		
	Reset method	Cycle the power, or stop the PLC and run the PLC again		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
Internal PLC transmits too much		The PLC program needs to confirm receiving the SDO feedback data before		
SDO at once		sending another SDO command.		

ID No.	Display on LCD Keypad	Warning Name	Description	
66	Warning PCSd CAN/M Sdo Tout	CAN/M SDO time-out (PCSd)	CANopen Master SDO time-out	
		Action and		
Action condition		When the CANopen master sends a SDO command, and the BUS is too busy to transmit the command, PCSd warning displays.		
Action time		Immediately displays when the fault is detected		
Warning setting parameter		N/A		
	Reset method	The warning automatically clears when the SDO transmits normally.		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
When the CANopen master transmits a SDO command, and does not receive feedback from the Slave within 1 sec.		Check if the Slave resp	onds within 1 second.	

ID No.	Display on LCD Keypad	Warning Name	Description	
67	Warning PCAd CAN/M Addres set	CAN/M address error (PCAd)	CANopen Master station address error	
		Action and	d Reset	
Action condition		When the CANopen master detects an incorrect or repeated station address from the Slave, the PCAd warning displays.		
Action time		Immediately displays when the fault is detected		
Warning setting parameter		N/A		
Reset method		The warning automatically clears when reset the station address and run the program again.		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
When the CANopen master detects an incorrect or repeated station address from the Slave		Set the correct slave sta	ation address.	

ID No.	Display on LCD Keypad	Warning Name	Description	
68	Warning PCTo CAN/MT-Out	CAN/M time-out (PCTo)	When the drive receives an incorrect packet, it means that there is interference or the command from the upper unit does not meet the CANopen command format.	
		Action and	d Reset	
	Action condition	N/A		
	Action time	Immediately acts when	receiving the command	
War	ning setting parameter	N/A		
	Reset method	The warning automatically clears after receives another normal packet		
	Reset condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
Malfunction caused by interference		<ol> <li>Verify wiring/grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
The command from the upper unit does not meet the CANopen Contact format		Contact Delta for further	r confirmation.	

ID No.	Display on LCD Keypad	Warning Name	Description	
70	Warning  ECid  ExCom ID failed	ExCom ID fail (ECid)	Duplicate MAC ID error Node address setting error	
		Action and	d Reset	
	Action condition	Duplicate setting of MAC ID Node address setting error		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Correct the setting and cycle the power		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
The setting address exceeds the range (0–63)		Check the address setting of the communication card (Pr.09-70)		
The spec	ed setting exceeds the	Standard: 0–2, non-standard: 0–7		
	ress is duplicated with des on the BUS	Reset the address		

ID No.	Display on LCD Keypad	Warning Name	Description	
71	Warning  ECLv  ExCom pwr loss	ExCom power loss (ECLv)	Low voltage of communication card	
		Action and	d Reset	
	Action condition	The 5V power that drive	provides to communication card is to low	
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Re-power		
	Reset condition	N/A		
	Record	N/A		
	Cause		Corrective Actions	
The 5V power that drive provides to communication card is to low		<ol> <li>Switch the communication card to other CP2000 drives and observe if there is ECLv warning shown. If yes, replace with a new communication card; if not, replace the drive.</li> <li>Use another communication card to test if the ECLv warning has shown as well. If not, replace the card; if yes, replace the drive.</li> </ol>		
The card	d is loose	Make sure the commun	ication card is well inserted.	

ID No.	Display on LCD Keypad	Warning Name	Description	
72	Warning  ECtt  ExCom Test Mode	ExCom test mode (ECtt)	Communication card is in the test mode	
Action and Reset				
	Action condition	Communication card is in the test mode		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Cycle the power and enter the normal mode		
	Reset condition	N/A		
	Record	N/A		
Cause			Corrective Actions	
Communication command error		Cycle the power		

ID No.	Display on LCD Keypad	Warning Name	Description	
73	Warning  ECbF  ExCom Bus off	ExCom Bus off (ECbF)	The communication card detects too much errors in the BUS, then enters the BUS-OFF status and stop communicating	
		Action and	d Reset	
	Action condition	When the drive detects BUS-off (for DeviceNet)		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Cycle the power		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
Poor connection of the cable		Re-connect the cable		
Bad quality of the cable		Replace the cable		

ID No.	Display on LCD Keypad	Warning Name	Description	
74	Warning ECnP ExCom No power	ExCom no power (ECnP)	There is no power supply on the DeviceNet	
		Action and	d Reset	
	Action condition	There is no power supply on the DeviceNet		
Action time		Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Re-power		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
The drive detects that DeviceNet has no power		Check if the cable and p	power is normal. If yes, return to the factory for repair.	

ID No.	Display on LCD Keypad	Warning Name	Description	
75	Warning  ECFF ExCom Facty def	ExCom factory defect (ECFF)	Factory default setting error	
		Action and	d Reset	
	Action condition	Factory default setting error		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Cycle the power		
	Reset condition	N/A		
Record		N/A		
Cause		Corrective Actions		
Factory default setting error		Use DCISoft to reset to the default value.		

ID No.	Display on LCD Keypad	Warning Name	Description	
76	Warning  ECiF  ExCom Inner err	ExCom inner error (ECiF)	Serious internal error	
		Action and	d Reset	
	Action condition	Internal memory saving	error	
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Cycle the power		
	Reset condition	N/A		
	Record	N/A		
	Cause	Corrective Actions		
Noise interference		Verify wiring of the control circuit, and wiring/grounding of the main circuit to prevent interference.  Cycle the power.		
The memory is broken		Reset to the default value and check if the error still exists. If yes, replace the communication card.		

ID No.	Display on LCD Keypad	Warning Name	Description	
77	Warning  ECio  ExCom IONet brk	ExCom IO Net break (ECio)	IO connection break off	
		Action and	d Reset	
	Action condition	IO connection between the communication card and the master is broken off		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	N/A		
Cause		Corrective Actions		
The cable is loose		Re-install the cable		
Incorrect parameter setting for master communication		Check the setting for m	aster communication parameter	

ID No.	Display on LCD Keypad	Warning Name	Description	
78	Warning  ECPP  ExCom Pr data	ExCom Parameter data error (ECPP)	Profibus parameter data error	
		Action and	d Reset	
	Action condition	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
The GSD file is incorrect		Get the correct GSD file from the software		

ID No.	Display on LCD Keypad	Warning Name	Description	
79	Warning  ECPi  ExCom Conf data	ExCom configuration data error (ECPi)	Profibus configuration data error	
		Action and	Reset	
	Action condition	N/A		
	Action time	N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		N/A		
Cause		Corrective Actions		
The GSD file is incorrect		Get the correct GSD file from the software		

ID No.	Display on LCD Keypad	Warning Name	Description	
80	Warning  ECEF  ExCom Link fail	Ethernet link fail (ECEF)	Ethernet cable is not connected	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	N/A		
	Record	N/A		
Cause			Corrective Actions	
Ethernet	t cable is loose	Re-connect the cable		
Bad quality of Ethernet cable		Replace the cable		

ID No.	Display on LCD Keypad	Warning Name	Description	
81	Warning  ECto  ExCom Inr T-out	Communication time-out (ECto)	Communication time-out for communication card and the upper unit	
		Action and	d Reset	
	Action condition	N/A		
Action time		N/A		
Warning setting parameter		N/A		
	Reset method	N/A		
Reset condition		CMC-EC01: auto resets when the communication with the upper unit is back to normal		
	Record	N/A		
·	Cause	Corrective Actions		
Communication card is not connected with the upper unit		Check if the connection of the communication cable is correct		
Communication error of the upper unit		Check if the communication of the upper unit is normal		

ID No.	Display on LCD Keypad	Warning Name	Description	
82	Warning  ECCS  ExCom Inr CRC	Checksum error (ECCS)	Checksum error for communication card and the drive	
Action a			d Reset	
Action condition		Software detection		
Action time		N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately resets		
	Record	N/A		
Cause		Corrective Actions		
Noise interference		Verify wiring of the corprevent interference.	ntrol circuit, and wiring/grounding of the main circuit to	

ID No.	Display on LCD Keypad	Warning Name	Description	
83	Warning  ECrF  ExCom Rtn def	Return defect (ECrF)	Communication card returns to the default setting	
		Action and	d Reset	
Action condition		Communication card returns to the default setting		
Action time		N/A		
Warning setting parameter		N/A		
Reset method		Manual reset		
	Reset condition	Immediately resets		
Record		N/A		
Cause			Corrective Actions	
Communication card is returning to default setting		No actions.		

ID No.	Display on LCD Keypad	Warning Name	Description	
84	Warning  ECo0  ExCom MTCP over	Modbus TCP over (Eco0)	Modbus TCP exceeds maximum communication value	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately resets		
Record		N/A		
	Cause		Corrective Actions	
The Master communication value is more than the allowable quantity of the communication card		Reduce Master commu	nication value	
The upper unit is online without communicating, and does not break off the Modbus TCP link, causes occupy connection		Revise program of upper not used for a long time	er unit, the communication should be break off when it is	
		Revise program of upp connected to the same	per unit: use the same Modbus TCP connection when communication card	

ID No.	Display on LCD Keypad	Warning Name	Description	
85	Warning ECo1 ExCom EIP over	EtherNet/IP over (ECo1)	Ethernet/IP exceeds maximum communication value	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Immediately acts		
War	rning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately resets		
Record		N/A		
Cause			Corrective Actions	
The Master communication value is more than the allowable quantity of the communication card		Reduce Master commu	nication value	
		Revise program of upponot used for a long time	er unit, the communication should be break off when it is	
A new M built eve unit is co commur	Modbus TCP connection is ery time when the upper connected to the nication card, which occupy connection	Revise program of upper unit: use the same Modbus TCP connection whe connected to the same communication card		

ID No.	Display on LCD Keypad	Warning Name	Description	
86	Warning  ECIP  ExCom IP fail	IP fail (ECiP)	IP setting error	
		Action and	d Reset	
Action condition		Software detection		
Action time		Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediate reset		
	Record	N/A		
Cause		Corrective Actions		
IP conflict		Reset IP		
DHCP IP configuration error		MIS check if DHCP Server works normally		

ID No.	Display on LCD Keypad	Warning Name	Description	
87	Warning  EC3F  ExCom Mail fail		Mail warning: Alarm mail will be sent when the communication card establishes alarm conditions	
		Action and	d Reset	
Action condition		Communication card establishes alarm conditions		
Action time		Immediately acts		
Warning setting parameter		N/A		
	Reset method	Manual reset		
	Reset condition	Immediately resets		
Record		N/A		
Cause			Corrective Actions	
Communication card establishes alarm conditions		No actions		

ID No.	Display on LCD Keypad	Warning Name	Description	
88	Warning  Ecby  ExCom Busy	ExCom busy (ECbY)	Communication card busy: too much packets are received	
		Action and	d Reset	
	Action condition	Software detection		
Action time		N/A		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	N/A		
	Record	N/A		
Cause		Corrective Actions		
Communication packets are too much for the communication card to process		Reduce communication	ı packets	

ID No.	Display on LCD Keypad	Warning Name	Description
89	Warning  ECCb  ExCom Card break	ExCom card break (ECCb)	Communication card break off warning
		Action and	d Reset
	Action condition	Communication card broad	eak off
Action time		The time between communication card break off and ECCb displays:  1. EtherNet/IP: 3 sec.  2. Modbus TCP: 3 sec.  3. DeviceNet: 1 sec.  4. PROFIBUS: 1 sec.  5. EtherCAT: 0.1 sec.	
War	ning setting parameter	N/A	
	Reset method	Auto resets after communication card is re-installed	
	Reset condition	Immediately resets	
Record N/A		N/A	
Cause		Corrective Actions	
Communication card break off Re-install communication card			on card

ID No.	Display on LCD Keypad	Warning Name	Description
90	Warning  CPLP  Copy PLC Pass Wd	Copy PLC: password error (CPLP)	Copy PLC password error. When KPC-CC01 is processing PLC copy and the PLC password is incorrect, the CPLP warning shows.
Ac			d Reset
Action condition		PLC password is incorre	ect
Action time		Immediately acts	
War	ning setting parameter	N/A	
	Reset method	Manual reset	
	Reset condition	Directly resets	
Record		N/A	
Cause			Corrective Actions
PLC password is incorrect		Reset and enter correct PLC password	

ID No.	Display on LCD Keypad	Warning Name	Description	
91	Warning CPL0 Copy PLC Mode Rd	Copy PLC: Read mode error (CPL0)	Copy PLC Read mode error	
		Action and	l Reset	
Action condition		When copy PLC read mode with incorrect process		
Action time		Immediately acts		
Warning setting parameter		N/A		
	Reset method	Manual reset		
Reset condition		Directly resets		
Record		N/A		
Cause		Corrective Actions		
When copy PLC read mode and the process is incorrect		Cycle the power and copy PLC read mode again		

ID No.	Display on LCD Keypad	Warning Name	Description	
92	АИТО	<u> </u>	Copy PLC write mode error	
Action and Reset				
Action condition		Copy PLC write mode with incorrect process		
Action time		Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Directly resets		
Record		N/A		
Cause		Corrective Actions		
When copy PLC write mode and the process is incorrect		Cycle the power and co	py PLC read mode again	

ID No.	Display on LCD Keypad	Warning Name	Description	
93	Warning CPLv Copy PLC Version	Copy PLC: version error (CPLv)	Copy PLC version error. When non-CP2000 built-in PLC is copied to CP2000 drive, the CPLv warning shows	
		Action and	Reset	
Action condition		Software detection		
Action time		Immediately acts		
War	rning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Directly resets		
Record		N/A		
Cause		Corrective Actions		
Non-CP2000 PLC program is		Check if the copied PLC program is for CP2000.		
copied t	o CP2000	Use the correct CP2000 PLC program.		

ID No.	Display on LCD Keypad	Warning Name	Description	
94	Warning CPLS Copy PLC Size	Copy PLC: size error (CPLS)	Copy PLC Capacity size error	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Directly resets		
Record		N/A		
Cause		Corrective Actions		
The PLC copied to CP2000		Check if the copied PLC program is for CP2000		
exceeds	the allowable capacity	Use CP2000 PLC program with correct capacity		

ID No.	Display on LCD Keypad	Warning Name	Description	
95	Warning  CPLF Copy PLC Func		KPC-CC01 Copy PLC function should be executed when PLC is off	
		Action and	d Reset	
	Action condition	Software detection		
Action time		Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
PLC function is enabled when KPC-CC01 is running copy PLC		Disable PLC function fir	st, then run the PLC copy function again	

ID No.	Display on LCD Keypad	Warning Name	Description	
96	Warning  CPLt  Copy PLC Time Out	Copy PLC: time-out (CPLt)	Copy PLC time out	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately acts		
War	ning setting parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Directly resets		
	Record	N/A		
Cause		Corrective Actions		
KPC-CC01 is removed while copying PLC program		The KPC-CC01 cannot	be removed during the PLC copy process	

ID No.	Display on LCD Keypad	Warning Name	Description	
101	Warning ictn InrCOM Time Out	_	Internal communication time-out	
		Action and		
	Action condition		(-10) (no -9) and the internal communication between normal, the ictn warning shows.	
	Action time	Immediately acts		
War	ning setting parameter	N/A		
Reset method		Auto-reset		
Reset condition		The warning automatically clears when the communication is back to normal condition		
	Record	N/A		
	Cause	Corrective Actions		
Malfunction caused by interference		Verify wiring/grounding of the communication circuit. It is recommended to esparate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication conditions with the upper unit  Check if the setting for Pr.09-02 is the same as the setting for Pr.09-02 is the setting for Pr.09-02 is the same as the setting for Pr.09-02 is the setting for Pr.09-02		Pr.09-02 is the same as the setting for upper unit		
Communication cable break off or		Check the cable status or replace the cable		

ID No.	Display on LCD Keypad	Warning Name	Description	
105	Warning SpdR Est-Speed REV	Estimated speed reverse (SpdR)	Estimated speed is in a reverse direction with motor actual running direction	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Pr.10-09		
Warning setting parameter		Pr.10-08 0: Warn and keep operation 1: Fault and coast to stop 2: Fault and ramp to stop		
Reset method		Manual reset		
	Reset condition	Immediately resets		
	Record	N/A		
	Cause		Corrective Actions	
The motor runs in reverse direction at start		Check if the motor is ho	ld when started, or start the motor with speed source.	
The difference between motor		Normally the Rr value of IM is Rs × 0.7. If there is much difference of the		
parameter measured Rr and Rs		measured value (e.g. Rr = Rs × 0.3), proceed the motor parameter auto-tuning		
	too large	again.		
Insufficient output torque is				
,		Increase the current lim	it of Pr.06-12, so as to increase the output torque.	
the load				

ID No.	Display on LCD Keypad	Warning Name	Description	
123	Warning  dEb  Dec. Energy backup	Deceleration energy backup (dEb)	Deceleration energy backup	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	N/A		
Warning setting parameter		<ul> <li>0: Disable</li> <li>1: dEb with auto accel./decel., the output frequency will note return after power reply.</li> <li>2: dEb with auto accel./decel., the output frequency will return after power reply.</li> <li>3: dEb low-voltage control, then increase to 350 V<sub>DC</sub> / 700 V<sub>DC</sub> and decelerate to stop.</li> <li>4: dEb high-voltage control of 350 V<sub>DC</sub> / 700 V<sub>DC</sub> and decelerate to stop</li> </ul>		
	Reset method	Manual reset		
	Reset condition	Immediately resets		
	Record	N/A		
Cause		Corrective Actions		
Instantaneous power off or low voltage and unstable/ sudden heavy load of the power that cause the voltage drop		Check the power consumption		
		Check the power consu	mption	

# Chapter 14 Fault Codes and Descriptions

① Warning

OcA

3 Oc at accel

① Display error signal

AUTO

- Abbreviate error code
- 3 Display error description

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
1	Fault ocA Oc at accel	Over-current during acceleration (ocA)	Output current exceeds 2.4 times of rated current during acceleration.  When ocA occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ocA error.	
		Action and	d Reset	
	Action condition	240% of rated current		
	Action time	Immediately act		
Fau	t treatment parameter	N/A		
	Reset method	Manual reset	foult is also and	
	Reset condition	Reset in 5 sec. after the Yes	e fault is cleared	
	Record Cause	res	Corrective Actions	
	Cause	Increase the accele		
Accelera	tion time is too short	<ol> <li>Increase the acceleration</li> <li>Set auto-acceleration</li> <li>Set over-current state</li> </ol>	eration time eration time of S curve on and auto-deceleration parameter (Pr.01-44) all prevention function (Pr.06-03) with a larger capacity model.	
Short cir	cuit at motor output due to		and remove causes of the short circuits, or replace the	
	ulation wiring	cable before turning on		
	or possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging ins	sulation of the motor	insulation is poor.		
The load	l is too large.	Check if the output current during the whole working process exceeds the AC motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.		
Impulsive change of the load		Reduce the load or incr	ease the capacity of AC motor drive.	
	cial motor or motor with pacity than the drive	Check the motor capacity (the rated current on the motor's nameplate should $\leq$ the rated current of the drive)		
electrom	OFF controller of an agnetic contactor at the J/V/W) of the drive	Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.		
	e setting error	Adjust V/F curve setting and frequency/voltage. When the fault occurs, and the frequency voltage is too high, reduce the voltage.		
Torque c	ompensation is too large	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain) until the output current reduces and the motor does not stall.		
Malfunction caused by interference		Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		
	or starts when in free run	Enable the speed track	ing during start-up of Pr.07-12.	
the spee (including	r parameter settings for d tracking function g restart after momentary ss and restart after fault)	<ol> <li>Start the speed trace</li> <li>Adjust the maximur</li> </ol>	m current for Pr.07-09 speed tracking.	
Incorrect combination of control mode and used motor  Check the settings for Pr.00-11 control mode:  1. For IM, Pr.00-11 = 0, 1, 2, 3, 5  2. For PM, Pr.00-11 = 4, 6, or 7		0, 1, 2, 3, 5 4, 6, or 7		
The leng long	th of motor cable is too	Increase AC motor drive Install AC reactor(s) on	e's capacity. the output side (U/V/W).	

#### Chapter 14 Fault Codes and Descriptions | CP2000

Hardware failure	The ocA occurs due to short circuit or ground fault at the output side of the drive. Check for possible short circuits between terminals with the electric meter:  B1 corresponds to U, V and W; DC- corresponds to U, V and W; © corresponds to U, V and W.  If short circuit occur, return to the factory for repair.	
Check if the setting for stall prevention is correct  Set the stall prevention to the proper value.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
2	Fault ocd Oc at decel	Over-current during deceleration (ocd)	Output current exceeds 2.4 times of rated current during deceleration.  When ocd occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ocd error.	
		Action and	d Reset	
	Action condition	240% of rated current		
	Action time	Immediately act		
Fault	treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in 5 sec. after the	e fault is cleared	
	Record	Yes	0 " 1 "	
	Cause	4 1 1 1	Corrective Actions	
Decelerat	tion time too short	<ol> <li>Set auto-acceleration</li> <li>Set over-current state</li> </ol>	eration time eration time of S-curve on and auto-deceleration parameter (Pr.01-44) all prevention function (Pr.06-03) with a larger capacity model	
Check if t	he mechanical brake of	'	• • •	
_	activates too early	Check the action timing	of the mechanical brake	
		Check the motor cable and remove causes of the short circuits, or replace the		
	lation wiring	cable before turning on the power.		
	possible burnout or	Check the motor insulation value with megger. Replace the motor if the		
aging insu	ulation of the motor	insulation is poor.		
The load	is too large	Check if the output current during the whole working process exceeds the AC motor drive's rated current. If yes, replace the AC motor drive with a larger capacity model.		
	change of the load		ease the capacity of AC motor drive.	
larger cap	ial motor or motor with pacity than the drive	Check the motor capacity (the rated current on the motor's nameplate should ≤ the rated current of the drive)		
electroma	OFF controller of an agnetic contactor at the /V/W) of the drive	Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.		
V/F curve	setting error	Adjust V/F curve settings and frequency/voltage. When the fault occurs, and the frequency voltage is too high, reduce the voltage.		
Torque co	ompensation is too large	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain) until the output current reduces and the motor does not stall.		
Malfunction caused by interference Ve		Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		
The length of motor cable is too Increase AC motor drive's capacity		e's capacity		
long Install AC reactor(s) on the output side (U/V/W)		the output side (U/V/W)		
Hardware error  B1 correspond		Check for possible shor B1 corresponds to U corresponds to U, V and	short circuit or ground fault at the output side of the drive. It circuits between terminals with the electric meter:  , V and W; DC- corresponds to U, V and W;   d W.  eturn to the factory for repair.	
	he setting of stall	Set the stall prevention		
preventio	n is correct	protoniuon	b. sha. ranae.	

ID Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault ocn Oc at normal SPD	Over-current during steady operation (ocn)	Output current exceeds 2.4 times of the rated current during constant speed. When ocn occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ocn error.	
	Action and	d Reset	
Action condition	240% of rated current		
Action time	Immediately act		
Fault treatment parameter	N/A		
Reset method	Manual reset		
Reset condition	Reset in 5 sec. after the	e fault is cleared	
Record	Yes		
Cause		Corrective Actions	
		and remove causes of the short circuits, or replace the	
poor insulation wiring	cable before turning on		
Check for possible shaft lock,	Troubleshoot the motor		
burnout or aging insulation of the	Check the motor insulation value with megger. Replace the motor if the		
motor	insulation is poor.		
Impulsive change of the load	Reduce the load or increase the capacity of AC motor drive.		
Use special motor or motor with larger capacity than the drive	Check motor capacity (the rated current on the motor's nameplate should ≤ the rated current of the drive)		
Use ON/OFF controller of an electromagnetic contactor at the output (U/V/W) of the drive	Check the action timing of the contactor and make sure it is not turned ON/OFF when the drive outputs the voltage.		
V/F curve setting error	Adjust V/F curve settings and frequency/voltage. When the fault occurs, and the frequency voltage is too high, reduce the voltage.		
Over-torque offset value too high		et value (Refer to Pr.07-26 torque compensation gain), is reduced and not motor stall.	
Torque compensation is too large.	Adjust the torque compensation (refer to Pr.07-26 torque compensation		
Malfunction caused by interference Verify the wiring of the control circuit and wiring/grounding of the mair prevent interference.			
The length of motor cable is too Increase the AC motor drive's capacity.		drive's capacity.	
long	Install AC reactor(s) on	the output side (U/V/W).	
Hardware failure	Check for possible shor	short circuit or ground fault at the output side of the drive. t circuit between terminals with the electric meter: , V and W; DC- corresponds to U, V, and W;	
	If short circuits occur, return to the factory for repair.		

### Chapter 14 Fault Codes and Descriptions | CP2000

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
4	Fault  GFF  Ground fault	Ground fault (GFF)	When (one of) the output terminal(s) is grounded, short circuit current is larger than Pr.06-60 setting value, and the detection time is longer than Pr.06-61 time setting, GFF occurs.  NOTE: the short circuit protection is provided for AC motor drive protection, not to protect the user.	
		Action and		
	Action condition	Pr.06-60 (Default = 60%	b)	
	Action time	Pr.06-61 (Default = 0.10	sec.)	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in 5 sec. after the fault is cleared		
	Record	Yes		
Cause			Corrective Actions	
Motor burnout or aging insulation occurred		Check the motor insulation is poor.	lation value with megger. Replace the motor if the	
Short circuit due to broken cable		Troubleshoot the short of Replace the cable.	circuit.	
Larger s	tray capacitance of the	If the motor cable lengt	h exceeds 100 m, decrease the setting value for carrier	
_	nd terminal	frequency. Take remedies to reduce stray capacitance.		
Malfunct	tion caused by interference	to separate the commun	d wiring of the communication circuit. It is recommended nication circuit from the main circuit, or wire in 90 degree nti-interference performance.	
Hardwar	re failure	Cycle the power after of GFF still exists, return to	checking the status of motor, cable and cable length. If the factory for repair.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
5	Fault occ Short Circuit	IGBT short circuit between upper bridge and lower bridge (occ)	Short-circuit is detected between upper bridge and lower bridge of the IGBT module	
		Action and	d Reset	
	Action condition	Hardware protection		
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset in 5 sec. after the fault is cleared		
Record		Yes		
Cause		Corrective Actions		
IGBT error		Check the motor wiring.		
Short-circuit detecting circuit error		Cycle the power, if occ still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
6	Fault ocS Oc at stop	Over-current at stop (ocS)	Over-current or hardware failure in current detection at stop. Cycle the power after ocS occurs. If the hardware failure occurs, the display shows cd1, cd2 or cd3.	
		Action and	d Reset	
	Action condition	240% of rated current		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
Reset method		Manual reset		
	Reset condition	Reset in 5 sec. after the fault is cleared		
	Record	Yes		
	Cause	Corrective Actions		
Malfunction caused by interference		Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		
Hardwai		Check if other error coor return to the factory for	de such as cd1–cd3 occur after cycling the power. If yes, repair.	

ID Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault ovA Ov at accel	Over-voltage during acceleration (ovA)	DC bus over-voltage during acceleration. When ovA occurs, the drive closes the gate of the output, the motor runs freely, and the display shows an ovA error.	
	Action and	d Reset	
Action condition	230V models: 410 V <sub>DC</sub> 460V models: 820 V <sub>DC</sub> 575V models: 1116 V <sub>DC</sub> 690V models: 1318 V <sub>DC</sub>	>	
Action time	-	OC bus voltage is higher than the level	
Fault treatment parameter	N/A		
Reset method	Manual reset		
Reset condition	-	is voltage is lower than 90% of the over-voltage level	
Record	Yes	Compositive Actions	
Cause	Decrease the secoloret	Corrective Actions	
Acceleration is too slow (e.g. hen lifting load decreases acceleration time)	Decrease the acceleration time Use brake unit or DC bus Replace the drive with a larger capacity model.		
The setting for stall prevention level is smaller than no-load current	The setting for stall prevention level should be larger than no-load current		
Power voltage is too high	Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
ON/OFF switch action of phase-in capacitor in the same power system	system, the input voltage may surge abnormally in a short time. In this case, install an AC reactor.		
Regenerative voltage of motor inertia	Use over-voltage stall prevention function (Pr.06-01) Use auto-acceleration and auto-deceleration setting (Pr.01-44) Use a brake unit or DC bus		
Check if the over-voltage warning occurs after acceleration stops.  When the warning occurs, do the following:  1. Increase the acceleration time  2. Set Pr.06-01 over-voltage stall prevention  3. Increase setting value for Pr.01-25 S-curve acceleration arrival time 2		eration time voltage stall prevention	
Motor ground fault	The ground short circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals.  Troubleshoot the ground fault.		
Incorrect wiring of brake resistor o brake unit			
Malfunction caused by interference	Verify the wiring of the prevent interference.	control circuit and wiring/grounding of the main circuit to	

## Chapter 14 Fault Codes and Descriptions | CP2000

ID Display on LCD Keypad	Fault Name	Fault Descriptions
Fault ovd Ov at decel	Over-voltage during deceleration (ovd)	DC bus over-voltage during deceleration. When ovd occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovd error.
	Action and	d Reset
Action condition	230V models: 410 V <sub>DC</sub> 460V models: 820 V <sub>DC</sub> 575V models: 1116 V <sub>DC</sub> 690V models: 1318 V <sub>DC</sub>	
Action time		OC bus voltage is higher than the level
Fault treatment parameter	N/A	
Reset method	Manual reset	
Reset condition		us voltage is lower than 90% of the over-voltage level
Record	Yes	O
Cause	4	Corrective Actions
Deceleration time is too short, causing too large regenerative energy of the load	(deceleration time) 2. Connect brake resis 3. Reduce the brake f 4. Replace the drive w 5. Use S-curve accele 6. Use over-voltage st 7. Use auto-acceleration	vith a larger capacity model.
The setting for stall prevention level is smaller than no-load current	on , , , , , , , , , , , , , , , , , , ,	
Power voltage is too high	and check for possible	
ON/OFF switch action of phase-in capacitor in the same power system		
Motor ground fault	The ground short circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals.  Troubleshoot the ground fault.	
Incorrect wiring of brake resistor or brake unit		
Malfunction caused by interference	Verify the wiring of the prevent interference.	control circuit and wiring/grounding of the main circuit to

ID Display on LCD Keypad	Fault Name	Fault Descriptions	
Fault ovn Ov at normal SPD	Over-voltage at constant speed (ovn)	DC bus over-voltage at constant speed. When ovn occurs, the drive closes the gate of the output immediately, the motor runs freely, and the display shows an ovn error.	
	Action and	Reset	
Action condition	230V models: 410 V <sub>DC</sub> 460V models: 820 V <sub>DC</sub> 575V models: 1116 V <sub>DC</sub> 690V models: 1318 V <sub>DC</sub>		
Action time	·	OC bus voltage is higher than the level	
	N/A		
Reset method	Manual reset		
		is voltage is lower than 90% of over-voltage level	
Record	Yes		
Cause	Corrective Actions		
impulsive change of the load	<ol> <li>Reduce the load.</li> <li>Replace to drive with</li> </ol>	stor, brake unit or DC bus to the drive. th a larger capacity model. I (Pr.07-01 or bolt position of the brake unit).	
The setting for stall prevention level is smaller than no-load current	The setting of stall prev	ention level should be larger than no-load current	
Regenerative voltage of motor inertia	Use over-voltage stall p Use a brake unit or DC	revention function (Pr.06-01) bus	
	and check for possible		
capacitor in the same power	system, the input volta install an AC reactor.	or or active power supply unit acts in the same power ge may surge abnormally in a short time. In this case,	
Motor ground fault	The ground short-circuit current charges the capacitor in the main circuit through the power. Check if there is ground fault on the motor cable, wiring box and its internal terminals.  Troubleshoot the ground fault.		
Incorrect wiring of brake resistor or brake unit		ke resistor or brake unit.	
Malfunction caused by interference	Verify the wiring of the prevent interference.	control circuit and wiring/grounding of the main circuit to	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
10	Fault ovS Ov at stop	Over-voltage at stop (ovS)	Over-voltage at stop	
		Action and	Reset	
	Action condition	230V models: 410 $V_{DC}$ 460V models: 820 $V_{DC}$ 575V models: 1116 $V_{DC}$ 690V models: 1318 $V_{DC}$		
	Action time	Immediately act when D	OC bus voltage is higher than the level	
Fau	lt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when DC bus voltage is lower than 90% of over-voltage level		
	Record	Yes		
	Cause		Corrective Actions	
Power voltage is too high		Check if the input voltage is within the rated AC motor drive input voltage range, and check for possible voltage spikes.		
ON/OFF switch action of phase-in		If the phase-in capacitor	r or active power supply unit activates in the same power	
capacito system	or in the same power	system, the input voltage may surge abnormally in a short time. In this case, install an AC reactor.		
Incorrect wiring of brake registor or		Check the wiring of brake resistor or brake unit.		
Malfunction caused by interference Verify the wiring of the control circuit and wiring/grounding of the management of the prevent interference.		control circuit and wiring/grounding of the main circuit to		
Hardware failure in voltage Check if other error code such as		le such as cd1–cd3 occur after cycling the power. If yes,		
detection	· · · · · · · · · · · · · · · · · · ·			
Motor gr	round fault		current charges the capacitor in the main circuit through re is ground fault on the motor cable, wiring box and its d fault.	

	_			
ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
11	Fault LvA Lv at accel	Low-voltage during acceleration (LvA)	DC bus voltage is lower than Pr.06-00 setting value during acceleration	
		Action and	- 1 10001	
	Action condition	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset when DC bus voltage is higher than Pr.06-00 + 30 V (Frame A–D) / 40 V (Frame E and below)		
Record		Yes		
Cause			Corrective Actions	
Power-off		Improve power supply of	condition.	
Power voltage changes		Adjust voltage to the power range of the drive		
Start up	the motor with large	Check the power system.		
capacity	1	Increase the capacity of power equipment.		
		Reduce the load.		
The load	d is too large	Increase the drive capacity.		
		Increase the acceleration time.		
DC bus		Install DC reactor(s).		
			ate or DC reactor between terminal +1 and +2. eturn to the factory for repair.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
12	Fault Lvd Lv at decel	Low-voltage during deceleration (Lvd)	DC bus voltage is lower than Pr.06-00 setting value during deceleration	
		Action and		
	Action condition	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Fau	It treatment parameter	NA		
	Reset method	Manual reset		
Reset condition		Reset when DC bus voltage is higher than Pr.06-00 + 30 V (Frame A–D) / 40 V (Frame E and above)		
Record		Yes		
	Cause	Corrective Actions		
Power-o	off	Improve power supply of	condition.	
Power v	oltage changes	Adjust voltage to the power range of the drive.		
Start up the motor with large		Check the power system.		
capacity		Increase the capacity of power equipment.		
Cuddon	load	Reduce the load.		
Sudden	loau	Increase the drive capacity.		
DC bus		Install DC reactor(s).		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
13	Fault Lvn Lv at normal SPD	Low-voltage at constant speed (Lvn)	DC bus voltage is lower than Pr.06-00 setting value at constant speed	
		Action and	Reset	
	Action condition	Pr.06-00 (Default = dep	ending on the model)	
	Action time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Fau	It treatment parameter	NA		
	Reset method	Manual reset		
	Reset condition	Reset when DC bus voltage is higher than Pr.06-00 + 30 V (Frame A–D) / 40 V (Frame E and above)		
Record		Yes		
	Cause	Corrective Actions		
Power-o	ff	Improve power supply condition.		
Power v	oltage changes	Adjust voltage to the power range of the drive		
Start up the motor with large		Check the power system.		
capacity		Increase the capacity of power equipment.		
Sudden	load	Reduce the load.		
Sudden	loau	Increase the drive capacity.		
DC bus		Install DC reactor(s).		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
14	Fault LvS Lv at stop	Low-voltage at stop (LvS)	DC bus voltage is lower than Pr.06-00 setting value at stop     Hardware failure in voltage detection	
		Action and	Reset	
	Action condition	Pr.06-00 (Default = depending on the model)		
	Action time	Immediately act when D	OC bus voltage is lower than Pr.06-00	
Fau	ılt treatment parameter	N/A		
		Manual / auto:		
		230V models:		
		Frame A–D = Lv leve	I + 30 V <sub>DC</sub> + 500 ms	
		Frame E and above = Lv level + 40 V <sub>DC</sub> + 500 ms		
		460V models:		
		Frame A–D = Lv level + 60 V <sub>DC</sub> + 500 ms		
	Reset method	Frame E and above = Lv level + 80 V <sub>DC</sub> + 500 ms		
		575V models:		
		Frame A–D = Pr.06-00 + 100.0 V <sub>DC</sub>		
		Frame E and above = Pr.06-00 + 120 V <sub>DC</sub>		
		690V models:		
		Frame A–D = $Pr.06-00 + 100.0 V_{DC}$		
		Frame E and above = $Pr.06-00 + 100.0 V_{DC}$		
	Reset condition	500 ms		
	Record	Yes		
	Cause	Corrective Actions		
Power-c		Improve power supply condition.		
Incorrect drive models Check if the power specification matches the drive.				
Power v	oltage changes	Adjust voltage to the power range of the drive.  Cycle the power after checking the power. If LvS error still exists, return to the factory for repair.		
Start up	the motor with large	Check the power syster	n.	
capacity	_	Increase the capacity of		
DC bus		Install DC reactor(s).		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
15	Fault OrP Phase lacked	Phase loss protection (OrP)	Phase loss of power input	
		Action and	d Reset	
	Action condition	DC bus is lower than Pr	:.07-00, and DC bus ripple is higher than Pr.06-52	
	Action time	N/A		
Fau	lt treatment parameter	Pr.06-53		
	Reset method	Manual reset		
	Reset condition	Immediately reset when	DC bus is higher than Pr.07-00	
	Record	Yes		
	Cause		Corrective Actions	
Phase loss of input power		Correctly install the wiri	ng of the main circuit power.	
Single phase power input to three-phase model		Choose the model whose power matches the voltage.		
Power voltage changes			works normally, verify the main circuit. Checking the power, if OrP error still exists, return to the	
Loose wiring terminal of input power		Tighten the terminal screws according to the torque described in the user manual.		
The inpu	ut cable of three-phase	Wire correctly.		
power is		Replace the cut off cable.		
	wer voltage changes too	Verify the setting value for Pr.06-50 Time for Input Phase Loss Detection and		
much		Pr.06-52 Ripple of Input Phase Loss		
Unbalan power	nced three-phase of input	Check the power three-	phase status.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
16	Fault oH1	IGBT overheating (oH1)	IGBT temperature exceeds the protection level	
		Action and	Reset	
	Action condition	occurs instead of oH1 w		
	Action time	IGBT temperature exce occurs.	eds the protection level for more than 100ms, oH1 error	
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset only when IGBT temperature is lower than oH1 error level minus (-) 10°C		
	Record	Yes		
	Cause	Corrective Actions		
Check if the ambient temperature or temperature inside the control cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.		<ol> <li>Change the installer resistors, in the sure</li> </ol>	ne ventilation hole of the control cabinet.  ed place if there are heating objects, such as braking	
	if there is any obstruction on Remove the obstruction or replace the cooling fan.		or replace the cooling fan.	
Insufficient ventilation space Inc		Increase ventilation space of the drive.		
_	the drive matches the onding load	<ol> <li>Reduce the load</li> <li>Reduce the carrier</li> <li>Replace the drive w</li> </ol>	vith a larger capacity model.	
	e has run 100% or more 0% of the rated output for a e	Replace the drive with a	a larger capacity model.	

ID Display on LCD Keypad	Fault Name	Fault Descriptions		
Fault oH2 Heat Sink oH		Board-level component temperature exceeds the protection level		
Action and Reset				
Action condition	Refer to the table below for oH2 level of each models			
Action time	When board-level component temperature exceeds the protection level for more than 100 ms, oH2 error occurs			
Fault treatment parameter	N/A			
Reset method	Manual reset			
Reset condition	Reset when board-level component temperature is lower than oH2 error level minus (-) 10°C			
Record	Yes			
Cause	Corrective Actions			
Check if the ambient temperature or temperature inside the control cabinet is too high, or if there is obstruction in the ventilation hole of the control cabinet.	<ol> <li>Check ambient temperature.</li> <li>Regularly inspect the ventilation hole of the control cabinet.</li> <li>Change the installed place if there are heating objects, such as braking resistors, in the surroundings.</li> <li>Install / add cooling fan or air conditioner to lower the temperature inside the cabinet.</li> </ol>			
Check if there is any obstruction or the heat sink or if the fan is running.	Remove the obstruction or replace the cooling fan.			
Insufficient ventilation space	Increase ventilation spa	ce of the drive.		
Check if the drive matches the corresponding load	<ol> <li>Reduce the load</li> <li>Reduce the carrier</li> <li>Replace the drive with a larger capacity model.</li> </ol>			
long time	Replace the drive with a larger capacity model.			
Unstable power	Install reactor(s)			
Load changes frequently	Reduce load changes			

### oH1/ oH2 warning level

Model	oH1	oH2	oH warning oH1 warning = (Pr.06-15)
VFD007CP23A-21			<u> </u>
VFD015CP23A-21			
VFD022CP23A-21			
VFD037CP23A-21	110	110	oH1 Warning = oH1 – 5 oH2 Warning = oH2 – 5
VFD055CP23A-21			
VFD075CP23A-21			
VFD110CP23A-21			
VFD150CP23A-21			
VFD185CP23A-21			
VFD220CP23A-21			
VFD300CP23A-21			
VFD370CP23A-00/-21			
VFD450CP23A-00/-21			
VFD550CP23A-00/-21		90	
VFD750CP23A-00/-21			
VFD900CP23A-00/-21			
VFD007CP43A/4EA-21	110	110	oH1 Warning = oH1 – 5 oH2 Warning = oH2 – 5
VFD015CP43B/4EB-21			
VFD022CP43B/4EB-21			
VFD037CP43B/4EB-21			
VFD040CP43A/4EA-21			
VFD055CP43B/4EB-21			
VFD075CP43B/4EB-21			
VFD110CP43B/4EB-21			

Model	oH1	oH2	oH warning
	OTT	OI IZ	oH1 warning = (Pr.06-15)
VFD150CP43B/4EB-21			
VFD185CP43B/4EB-21			
VFD220CP43A/4EA-21		110	
VFD370CP43B/4EB-21			
VFD450CP43S-00/-21			
VFD550CP43S-00/-21			
VFD750CP43B-00/-21			
VFD900CP43A-00/-21			
VFD1100CP43A-00/-21			
VFD1320CP43B-00/-21			
VFD1600CP43A-00/-21			
VFD1850CP43B-00/-21			
VFD2000CP43A-00/-21		90	oH1 Warning = oH1 – 5
VFD2200CP43A-00/-21	110		oH2 Warning = oH2 – 5
VFD2500CP43A-00/-21			
VFD2800CP43A-00/-21			
VFD3150CP43A-00			
VFD3150CP43C-00/-21			
VFD3550CP43A-00			
VFD3550CP43C-00/-21 VFD4000CP43A-00			
VFD4000CP43A-00 VFD4000CP43C-00/-21			
VFD5000CP43A-00			
VFD5000CP43A-00 VFD5000CP43C-00/-21		85	
VFD5600CP43A-00			
VFD5600CP43A-00		Contact D	elta for more information
VFD6300CP43A-00			
VFD6300CP43C-21		Contact D	elta for more information
VFD015CP53A-21			
VFD022CP53A-21		85	
VFD037CP53A-21		00	
VFD055CP53A-21	100		oH1 Warning = oH1 – 5
VFD075CP53A-21	100		oH2 Warning = oH2 – 5
VFD110CP53A-21		70	
VFD150CP53A-21			
VFD185CP63A-21			
VFD220CP63A-21	2.2	<u> </u>	
VFD300CP63A-21	90	85	
VFD370CP63A-21			
VFD450CP63A-00/-21	400		
VFD550CP63A-00/-21	100		
VFD750CP63A-00/-21			
VFD900CP63A-00/-21		65	
VFD1100CP63A-00/-21			oH1 Warning = oH1 – 5
VFD1320CP63A-00/-21			oH2 Warning = oH2 – 5
VFD1600CP63A-00/-21			
VFD2000CP63A-00/-21	440		
VFD2500CP63A-00/-21	110		
VFD3150CP63A-00/-21			
VFD4000CP63A-00/-21		70	
VFD4500CP63A-00/-21			
VFD5600CP63A-00/-21			
VFD6300CP63A-00/-21			

ID	Display on LCD Keypad	Fault Name	Fault Descriptions
18	Fault tH1o Thermo 1 open	IGBT temperature detection failure (tH1o)	IGBT hardware failure in temperature detection
		Action and	d Reset
	Action condition	NTC broken or wiring failure	
		When the IGBT temperature is higher than the protection level, and detection time exceeds 100 ms, the tH1o protection activates.	
Fault treatment parameter N/A			
	Reset method	Manual reset	
	Reset condition	Immediately reset	
	Record	Yes	
	Cause	Corrective Actions	
Hardwa	Hardware failure  Wait for 10 minutes, and then cycle the power. Check if tH1o proexists. If yes, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
19	Fault tH2o Thermo 2 open	Capacitor hardware error (tH2o)	Hardware failure in capacitor temperature detection	
		Action and	d Reset	
Action condition NTC broken or wiring failure		ailure		
		When the IGBT temperature is higher than the protection level, and detection time exceeds 100 ms, the tH2o protection activates.		
Fault treatment parameter N/A		·		
	Reset method	Manual reset		
	Reset condition Immediately reset			
Record Yes				
	Cause	Corrective Actions		
Hardwai	re failure	Wait for 10 minutes, and then cycle the power. Check if tH2o protection sexists. If yes, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions
21	Fault oL Over load	Over load (oL)	The AC motor drive detects excessive drive output current. The overload capacity sustains for 1 minute when the drive outputs 150% of the drive's rated output current.
Action and Reset			d Reset
	Action condition	Based on over load cur	ve and derating curve.
	Action time	When the load is higher the oL protection activation	er than the protection level and exceeds allowable time, tes.
Fau	It treatment parameter	N/A	
	Reset method	Manual reset	
	Reset condition	Reset in 5 sec. after the	e fault is cleared
	Record	Yes	
	Cause		Corrective Actions
	l is too large	Reduce the load	
	ecel. time or the working e too short	Increase the setting value for Pr.01-12–01-19 (accel./decel time)	
V/F volta	age is too high	Adjust the settings for Pr.01-01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).  Refer to the V/F curve selection of Pr.01-43.	
The capa	acity of the drive is too	Replace the drive with a larger capacity model.	
Overload operation	d during low-speed n	Reduce the load during low-speed operation. Increase the drive capacity. Decrease the carrier frequency of Pr.00-17.	
_	compensation is too large		pensation (refer to Pr.07-26 Torque Compensation Gain) reduces and the motor does not stall.
	the setting for stall on is correct.	Set the stall prevention to the proper value.	
Output p	hase loss	Check the status of three-phase motor. Check if the cable is broken or the screws are loose.	
the spee (includin	r parameter settings for ed tracking function g restart after momentary ess and restart after fault)	Correct the parameter settings for speed tracking.  1. Start the speed tracking function.  2. Adjust the maximum current for Pr.07-09 speed tracking.	

ID Display on LCD Keypad	Fault Name	Fault Descriptions		
Fault EoL1 Thermal relay 1	Electronic thermal relay 1 protection (EoL1)	Electronics thermal relay 1 protection. The drive coasts to stop once it activates.		
	Action and	d Reset		
Action condition	Start counting when out	Start counting when output current > 105% of motor 1 rated current		
Action time	Pr.06-14 (if the output current is larger than 105% of motor 1 rated current again within 60 sec., the counting time reduces and is less than Pr.06-14)			
Fault treatment parameter	N/A			
Reset method	Manual reset			
Reset condition	Reset in 5 sec. after the	e fault is cleared		
Record	Yes			
Cause		Corrective Actions		
The load is too large	Reduce the load.			
Accel./Decel. time or the working cycle is too short	_	ues for Pr.01-12–01-19 (Accel./Decel. time)		
V/F voltage is too high	Adjust the settings for Pr.01-01-08 (V/F curve), especially the setting for the mid-point voltage (if the mid-point voltage is set too low, the load decreases at low speed).  Refer to the V/F curve selection of Pr.01-43.			
Overload during low-speed operation.  When using a general motor, even it operates below rated current, an overload may still occur during low-speed operation.  Decrease low-speed operation time. Replace the drive with a dedicated to VFD model. Increase the motor capacity.		a dedicated to VFD model.		
When using VFD dedicated motors, Pr.06-13=0 (electronic thermal relay selection motor 1 = inverter motor)	Pr.06-13 = 1 electronic with fan on the shaft).	thermal relay selection motor 1 = standard motor (motor		
Incorrect value of electronic thermal relay	Reset to the correct mo	otor rated current.		
The maximum motor frequency is set too low	Reset to the correct mo	tor rated frequency.		
One drive to multiple motors	Set Dr 06 13 = 2 electronic thermal relay selection motor 1= disable, an			
Check if the setting for stall prevention is correct.	setting for stall  Set the stall prevention to the proper value			
Torque compensation is too large		pensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.		
Motor fan error	Check the status of the fan, or replace the fan.			
Unbalanced three-phase impedance of the motor	nase Replace the motor			

ID Display on LCD Keypad	Fault Name	Fault Descriptions		
Fault EoL2 Thermal relay 2	Electronic thermal relay 2 protection (EoL2)	Electronic thermal relay 2 protection. The drive coasts to stop once it activates.		
	d Reset			
Action condition	Start counting when out	tput current > 105% of motor 2 rated current		
Action time	within 60 sec., the cour	Pr.06-28 (If the output current is larger than 105% of motor 2 rated current again within 60 sec., the counting time reduces and is less than Pr.06-28)		
Fault treatment parameter	N/A			
Reset method	Manual reset			
Reset condition	Reset in 5 sec. after the	e fault is cleared		
Record	Yes			
Cause		Corrective Actions		
The load is too large	Reduce the load			
Accel./Decel. time or the working cycle are too short	_	ues for Pr.01-12–01-19 (accel./decel. time)		
V/F voltage is too high	Adjust the settings for Pr.01-01-08 (V/F curve), especially the setting for the mid-point voltage is set too low, the load codecreases at low speed).  Refer to the V/F curve selection setting of Pr.01-43.			
Overload during low-speed operation. When using general motor, even it operates below rated current, an overload may still occur during low-speed operation.	Overload during low-speed peration.  When using general motor, even it perates below rated current, an verload may still occur during  Decrease low-speed operation time.  Replace the drive with a dedicated to VFD model.  Increase the motor capacity.			
When using VFD dedicated motors, Pr.06-27 = 0 (electronic thermal relay selection motor 2 = standard motor thermal relay selection motor 2 = 0 with fan on the shaft).		thermal relay selection motor 2 = standard motor (motor		
Incorrect value of electronic thermal relay	Reset to the correct mo	otor rated current.		
The maximum motor frequency is set too low	The maximum motor frequency is			
One drive to multiple motors  Set Pr.06-27 = 2 Electronic thermal relay selection motor 2 = disable, and thermal relay on each motor.				
Check if the setting for stall prevention is correct.	ck if the setting for stall			
Torque compensation is too large	until the current reduce	pensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.		
Motor fan error	Check the status of the	fan, or replace the fan.		
Unbalanced three-phase impedance of the motor	alanced three-phase Penlace the motor			

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
24_1	Fault  oH3  Motor over heat	Motor overheating (oH3) PTC	Motor overheating (PTC) (Pr.03-00–Pr.03-02 = 6 PTC), when PTC input > Pr.06-30, the fault treatment acts according to Pr.06-29.	
Action and Reset				
	Action condition	PTC input value > Pr.06-30 setting (Default = 50%)		
	Action time	Immediately act		
Fau	lt treatment parameter	Pr.06-29 0: Warn and keep opera 1: Fault and ramp to sto 2: Fault and coast to sto 3: No warning	рр	
	Reset method		3 is a "Warning". The "Warning" is automatically cleared. , oH3 is a "Fault". You must reset manually.	
	Reset condition	Immediately reset		
	Record	When Pr.06-29 = 1 or 2	, oH3 is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
Motor sh	naft lock	Remove the shaft lock.		
The load	d is too large	Reduce the load. Increase the motor cap		
Ambient	temperature is too high	Change the installed place if there are heating devices in the surroundings.  Install/ add cooling fan or air conditioner to lower the ambient temperature.		
Motor co	poling system error	Check the cooling syste	em to make it work normally.	
Motor fa	n error	Replace the fan.		
Operate	at low-speed too long.	Decrease low-speed operation time. Replace the motor with a dedicated to VFD model. Increase the motor capacity.		
	ecel. time and working e too short	Increase the setting val	ues for Pr.01-12–01-19 (accel./decel. time)	
	age is too high	Adjust settings for Pr.01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).		
_	the motor rated current that on the motor ate.	Reset to the correct motor rated current.		
and wire		Check the connection between PTC thermistor and the heat protection.		
preventi	the setting for stall on is correct.	Set the stall prevention to the proper value.		
	iced three-phase nce of the motor	Replace the motor.		
	ics are too high.	Use remedies to reduce harmonics.		

ID Display on LCD Keypad	Fault Name	Fault Descriptions
Fault oH3 Motor over heat	Motor overheating (oH3) PT100	Motor overheating (PT100) (Pr.03-00–Pr.03-02 = 11 PT100). When PT100 input > Pr.06-57 (default = 7 V), the fault treatment acts according to Pr.06-29.
Action and Reset		
Action condition	PT100 input value > Pr.	06-57 setting (default = 7 V)
Action time	Immediately act	
Fault treatment parameter	Pr.06-29 0: Warn and keep opera 1: Fault and ramp to sto 2: Fault and coast to sto 3: No warning	рр
Reset method	When Pr.06-29 = 0 and cleared.	the temperature < Pr.06-56, oH3 is automatically , oH3 is a "Fault". You must reset manually.
Reset condition	Immediately reset	
Record	When Pr.06-29 = 1 or 2	, oH3 is a "Fault", and the fault is recorded.
Cause		Corrective Actions
Motor shaft lock	Remove the shaft lock.	
The load is too large	Reduce the load. Increase the motor capacity.	
Ambient temperature is too high	Change the installed place If there are heating devices in the surroundings. Install/ add cooling fan or air conditioner to lower the ambient temperature.	
Motor cooling system error	Check the cooling system to make it work normally.	
Motor fan error	Replace the fan.	
Operate at low-speed too long	Decrease low-speed op Replace the motor with Increase the motor capa	a dedicated to VFD model.
Accel./Decel. time and working cycle are too short	Increase the setting val	ues for Pr.01-12–Pr.01-19 (accel./decel. time)
V/F voltage is too high	Adjust settings for Pr.01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).	
Check if the motor rated current matches that on the motor nameplate.	Reset to the correct motor rated current.	
Check if the PT100 is properly set and wired.	Check connection of PT100 thermistor.	
Check if the setting for stall prevention is correct.	Set the stall prevention to the proper value.	
Unbalanced three-phase impedance of the motor	Replace the motor.	
Harmonics are too high	Use remedies to reduce	e harmonics.

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
26	Fault ot1 Over torque 1	Over torque 1 (ot1)	When output current exceeds the over-torque detection level (Pr.06-07) and exceeds over-torque detection time (Pr.06-08), and when Pr.06-06 or Pr.06-09 is set to 2 or 4, the ot1 error displays.	
Action and Reset			Reset	
	Action condition	Pr.06-07		
	Action time	Pr.06-08		
Faul	t treatment parameter	Pr.06-06 0: No function 1: Continue operation after Over-torque detection during constant speed operation 2: Stop after Over-torque detection during constant speed operation 3: Continue operation after Over-torque detection during RUN 4: Stop after Over-torque detection during RUN		
	Reset method Reset condition	Auto automatically	06 = 1 or 3, ot1 is a "Warning". The warning is cleared when the output current < (Pr.06-07 – 5%) 6 = 2 or 4, ot1 is a "Fault". You must reset manually.	
	Record	Immediately reset	o zor i, otrio a riadit i roa maotropot manadily.	
	Active level		, ot1 is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
	parameter setting	Reset Pr.06-07 and Pr.0	06-08	
	cal failure (e.g. <sub>l</sub> ue, mechanical lock)	Remove the causes of malfunction.		
	is too large	Reduce the load. Replace the motor with	a larger capacity model.	
	ecel. time and working too short	· ·	ues for Pr.01-12–Pr.01-19 (accel./decel. time)	
V/F volta	ge is too high	Adjust settings for Pr.01-01-08 (V/F curve), especially the setting value for the mid-point voltage (if the mid-point voltage is set too low, the load capacity decreases at low speed).		
	or capacity is too small	Replace the motor with a larger capacity model.		
	d during low-speed	Decrease low-speed op		
operation	1	Increase the motor capacity.		
·	ompensation is too large	Adjust the torque compensation (refer to Pr.07-26 torque compensation gain) until the current reduces and the motor does no stall.		
speed tra	r parameter settings for acking function (including fter momentary power loss art after fault)	<ol> <li>Start the speed tra</li> </ol>	settings for speed tracking. acking function. am current for Pr.07-09 speed tracking.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
27	Fault ot2 Over torque 2	Over torque 2 (ot2)	When output current exceeds the over-torque detection level (Pr.06-10) and exceeds over-torque detection time (Pr.06-11), and when Pr.06-09 is set to 2 or 4, the ot2 error displays.	
		Action and	d Reset	
	Action condition	Pr.06-10		
	Action time	Pr.06-11		
Fau	It treatment parameter	operation 2: Stop after Over-torqu 3: Continue operation a	after Over-torque detection during constant speed ue detection during constant speed operation ufter Over-torque detection during RUN ue detection during RUN	
	Reset method Reset condition	Auto  When Pr.06-09 = 1 or 3, ot2 is a "Warning". The warning is automatically cleared when the output current < (Pr.06-10 – 5%).  Manual When Pr.06-09 = 2 or 4, ot2 is a "Fault". You must reset manually.		
	Record	Immediately reset		
	Active level	When Pr.06-09 = 2 or 4, ot2 is a "Fault", and the fault is recorded.		
	Cause		Corrective Actions	
	t parameter setting	Reset Pr.06-07 and Pr.0	06-08	
	ical failure (e.g. que, mechanical lock)	Remove the causes of	malfunction.	
	d is too large.	Reduce the load. Replace the motor with a larger capacity model.		
	ecel. time and working e too short	Increase the setting val	ues for Pr.01-12–01-19 (accel./decel. time).	
V/F volta	age is too high		Pr.01-01-01-08 (V/F curve), especially the setting value e (if the mid-point voltage is set too low, the load capacity d).	
	or capacity is too small	Replace the motor with a larger capacity model.		
	d during low-speed	Decrease low-speed op		
operatio	n	Increase the motor cap		
•	compensation is too large		pensation (refer to Pr.07-26 torque compensation gain) s and the motor does no stall.	
speed tra	r parameter settings for acking function (including t momentary power loss art after fault)	<ol> <li>Start the speed tra</li> </ol>	settings for speed tracking. acking function. um current for Pr.07-09 speed tracking.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
28	Fault uC Under current	Under current (uC)	Low current detection	
		Action and	Reset	
	Action condition	Pr.06-71		
	Action time	Pr.06-72		
Fau	ult treatment parameter	Pr.06-73 0: No function 1: Fault and coast to stop 2: Fault and ramp to stop by 2 <sup>nd</sup> deceleration time 3: Warn and operation continue		
	Reset method Reset condition	Auto When Pr.06-73 = 3, uC is a "Warning". The warning is automatically cleared when the output current > (Pr.06-71+0.1A).  Manual When Pr.06-73 = 1 or 2, uC is a "Fault". You must reset manually.		
	Record	Immediately reset		
	Active level	When Pr.06-71 = 1 or 2, uC is a "Fault", and the fault is recorded.		
	Cause	Corrective Actions		
	able disconnection	Troubleshoot the connection between the motor and the load.		
Imprope protection	er setting of low-current on	Reset Pr.06-71, Pr.06-72 and Pr.06-73 to proper settings.		
The load	d is too low	Check the load status. Check if the motor capa	city matches the load.	

in.	D: 1 10D 1/	F 1( ) 1	5 "D ' "
ID	Display on LCD Keypad	Fault Name	Fault Descriptions
29	Fault LiT Limit Error	Limit Error (LiT)	When MIx = 45 (forward run limit) or MIx = 44 (backward run limit) act during operation, LiT error shows. (This error does not show on the CP2000 drive.)
		Action and	d Reset
	Action condition	MIx = 44 (backward run	limit) or MIx = 45(forward run limit)
	Action time	Immediately act	
Fau	Ilt treatment parameter	N/A	
	Reset method	Manual reset	
	Reset condition	Immediately reset	
	Record	Yes	
	Cause Corrective Actions		Corrective Actions
	t ON/OFF switch is on t position	Install the limit ON/OFF switch to correct position.	
Decelera	ation time is too long,	Reduce deceleration tin	ne.
causing limited p	the motor cannot stop at position	Adjust setting values for brake level (Pr.07-01 or the insert position on the brake unit).	
	tor cannot stop due to tage stall prevention	Reset the over-voltage stall prevention.	
Malfunct	tion caused by interference	Verify wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
30	Fault cF1 EEPROM write err	EEPROM write error (cF1)	Internal EEPROM cannot be programmed	
		Action and	d Reset	
	Action condition	Firmware internal detection		
	Action time	cF1 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Internal EEPROM cannot be programmed		Press "RESET" key or reset the parameter to the default setting, if cF1 still exists, return to the factory for repair.  Cycle the power, if cF1 still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
31	Fault cF2 EEPROM read err	EEPROM read error (cF2)	Internal EEPROM cannot be read	
		Action and	d Reset	
	Action condition	Firmware internal detection		
	Action time	cF2 acts immediately when the drive detects the fault		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
		Press "RESET" key or reset the parameter to the default setting, if cF2 still exists, return to the factory for repair.  Cycle the power, if cF2 error still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
33	Fault cd1 las sensor err	U-phase error (cd1)	U-phase current detection error when power is ON	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	cd1 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
		Cycle the power. If cd1 still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
34	Fault cd2	V-phase error (cd2)	V-phase current detection error when power ON	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	cd2 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
Record		Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power.  If cd2 still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
35	Fault cd3	W-phase error (cd3)	W-phase current detection error when power ON	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	cd3 acts immediately when the drive detects the fault		
Fau	Ilt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause			Corrective Actions	
Hardware failure		Cycle the power. If cd3 still exists, return	to the factory for repair.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
36	Fault Hd0 cc HW error	cc hardware failure (Hd0)	cc (current clamp) hardware protection error when power is ON	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Hd0 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
		Cycle the power.  If Hd0 still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
37	Fault Hd1 Oc HW error	oc hardware error (Hd1)	oc hardware protection error when power is ON	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	Hd1 acts immediately when the drive detects the fault		
Fau	ılt treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power.  If Hd1 still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
38	Fault Hd2 Ov HW error	ov hardware error (Hd2)	ov hardware protection error when power is ON	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Hd2 acts immediately when the drive detects the fault		
Fau	It treatment parameter	N/A		
	Reset method	Power-off		
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware failure		Cycle the power.  If Hd2 still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions		
39	Fault Hd3 occ HW error	occ hardware error (Hd3)	Protection error of occ IGBT short-circuit detection when power is ON		
	Action and Reset				
	Action condition	Hardware detection			
	Action time	Hd3 acts immediately when the drive detects the fault			
Fau	ılt treatment parameter	N/A			
	Reset method	Power-off			
	Reset condition	N/A			
	Record	Yes			
Cause		Corrective Actions			
Hardware failure		Cycle the power. If Hd3 still exists, return	to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
40	Fault AUE Auto tuning error	Auto-tuning error (AUE)	Motor auto-tuning error	
		Action and	l Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause				
	0 0.0.0		Corrective Actions	
Press "S auto-tun	STOP" key during	Re-execute auto-tuning		
auto-tun Incorrec	TOP" key during ing t motor capacity (too large	Check motor capacity a	nd related parameters. ers, that is Pr.01-01–Pr.01-02.	
auto-tun Incorrec or too sr	TOP" key during ing t motor capacity (too large	Check motor capacity a Set the correct paramet	nd related parameters. ers, that is Pr.01-01–Pr.01-02.	
auto-tun Incorrec or too sr	TOP" key during ing t motor capacity (too large nall) and parameter setting t motor wiring	Check motor capacity a Set the correct paramet Set Pr.01-00 larger thar	nd related parameters. ers, that is Pr.01-01–Pr.01-02. motor rated frequency.	
Incorrect or too sr Incorrect Motor sh The elect	TOP" key during ing t motor capacity (too large nall) and parameter setting t motor wiring naft lock	Check motor capacity a Set the correct paramet Set Pr.01-00 larger than Check the wiring.	nd related parameters. ers, that is Pr.01-01–Pr.01-02. motor rated frequency. otor shaft lock.	
Incorrect Motor shall be a control of the election of the elec	t motor capacity (too large nall) and parameter setting t motor wiring naft lock ctromagnetic contactor is utput side (U/V/W) of the	Check motor capacity a Set the correct paramet Set Pr.01-00 larger than Check the wiring. Remove the cause of make sure the electrom	nd related parameters. ers, that is Pr.01-01–Pr.01-02. motor rated frequency. otor shaft lock.	

ID	Diaplay on LCD Kaynad	Foult Name	Fault Descriptions	
טו	Display on LCD Keypad	Fault Name	Fault Descriptions	
41	Fault  AFE PID Fbk error	PID loss ACI (AFE)	PID feedback loss (analog feedback signal is only valid when the PID function is enabled)	
		Action and	d Reset	
	Action condition	When the analog input	< 4 mA (only detects 4–20 mA analog input)	
	Action time	Pr.08-08		
		Pr.08-09		
		0: Warn and keep operation		
Fau	ılt treatment parameter	1: Fault and ramp to stop		
		2: Fault and coast to stop		
		3: Warn and operate at last frequency		
	Reset method	Auto When Pr.08-09 = 3 or 4, AFE is a "Warning". When the feedback signal is > 4 mA, the "Warning" is automatically cleared.		
		Manual   When Pr.08-09 = 1 or 2, AFE is a "Fault". You must reset manually.		
	Reset condition	Immediately reset		
	Record	When Pr.08-09 = 1 or 2, AFE is a "Fault", and the fault is recorded; when		
	Necolu	Pr.08-09 = 3 or 4, AFE is a "Warning", and the warning is not recorded.		
Cause		Corrective Actions		
PID feed	dback cable is loose or cut			
off Replace the cable with a new one.				
Feedba	ck device failure	Replace the device with a new one.		
Hardwa	re failure	Check all the wiring. If AFE fault still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
42	Fault PGF1 PG Fbk error	PG feedback error (PGF1)	The motor runs in a reverse direction to the frequency command direction. (This error does not show on the CP2000 drive.)	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Pr.10-09		
Fau	lt treatment parameter	Pr.10-08 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop		
Reset method Manual reset				
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Incorrect encoder	t parameter setting of	Reset encoder parameter (Pr.10-02).		
Check wiring of the encoder Re-wire the encoder.				
PG card	or PG encoder failure	Replace PG card or encoder with a new one.		
Malfunction caused by interference Verify wiring of the control circuit and wiring/grounding of the main circuit and wiring	ntrol circuit and wiring/grounding of the main circuit to			

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
43	Fault PGF2 PG Fbk loss	PG feedback loss (PGF2)	Pr.10-00 and Pr.10-02 is not set in the PG control mode. When press "RUN" key, PGF2 fault occurs. (This error does not show on the CP2000 drive.)	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
·	Record	Yes		
·	Cause	Corrective Actions		
Incorrect setting of encoder parameter		Reset encoder parameters (Pr.10-00 and Pr.10-02)		
Incorrect selection of the control mode		Choose the correct control mode.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
44	Fault PGF3 PG Fbk over SPD	PG feedback stall (PGF3)	Under PG mode, when the motor frequency exceeds the encoder observer stall level (Pr.10-10) and starts to count, the fault time is longer than the detection time of encoder observer stall (Pr.10-11), then PGF3 fault occurs. (This error does not show on the CP2000 drive.)	
		Action and	d Reset	
	Action condition	Pr.10-10		
	Action time	Pr.10-11		
Fault treatment parameter		Pr.10-12 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Incorrect setting of encoder parameter		Reset encoder parameter (Pr.10-01)		
Pr. 01-00 is set too small		Set proper value for Pr.01-00.		
		Reset ASR parameters.	j	
parameters and accel./decel. time   Set correct accel./decel			. time.	
Incorrect stall	t setting for PG feedback	Reset proper values for	Pr.10-10 and Pr.10-11	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
45	Fault PGF4 PG Fbk deviate	PG slip error (PGF4)	Under PG mode, when the motor frequency exceeds encoder observer slip range (Pr.10-13) and starts to count, the fault time is longer than the detection time of encoder observer slip (Pr.10-14), PGF4 fault occurs. (This error does not show on the CP2000 drive.)	
		Action and	Reset	
	Action condition	Pr.10-13		
	Action time	Pr.10-14		
Fault treatment parameter		Pr.10-15 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop		
Reset method		When Pr.10-15 = 0, PGF4 is a "Warning", when the deviation between output frequency and motor frequency is smaller than the encoder observer slip range, the warning is automatically cleared.  Manual When Pr.10-15 = 1 or 2, PGF4 is a "Fault". You must reset manually.		
Reset condition		Immediately reset	5 - 1 of 2, F of 4 is a T ault . Tou must reset manually.	
	Record		, PGF4 is a "Fault", and the fault is recorded.	
	Cause	7711011711110 10 1 01 2	Corrective Actions	
Incorrec paramet	et settings for PG feedback ters	Reset correct values for	r Pr.10-13 and Pr.10-14.	
	t settings for ASR	Reset ASR parameters.		
	ters and accel./decel. time	Set correct accel./decel time.		
Incorrect paramet	et settings of encoder ters	Reset encoder parameters (Pr.10-01).		
Accel./Decel. time is too short		Reset proper accel./decel. time.		
paramet Pr.11-17	/	Reset proper setting values for Pr.06-12 and Pr.11-17–Pr. 17-20.		
Motor sh		Remove causes of motor shaft lock.		
Mechanical brake is not released Check the action sequence of the system.		ence of the system.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
48	Fault ACE ACI loss	ACI loss (ACE)	Analog input loss (including all the 4–20 mA analog signal)	
		Action and	d Reset	
	Action condition	When the analog in con	ditionput is < 4 mA (only detects 4–20 mA analog input)	
	Action time	Immediately act		
Fault treatment parameter		<ul> <li>Pr.03-19</li> <li>0: Disable</li> <li>1: Continue operation at the last frequency (warning, ANL is displayed on the keypad)</li> <li>2: Decelerate to stop (warning, ANL is displayed on the keypad)</li> <li>3: Stop immediately and display ACE</li> </ul>		
Reset method		is > 4 mA, the	9 = 1 or 2, ACE is a "Warning". When analog input signal warning is automatically cleared. 9 = 3, ACE is a "Fault". You must reset manually.	
	Reset condition	Immediately reset		
	Record	When Pr.03-19 = 3, AC	E is a "Fault", and the fault is recorded.	
	Cause	cause Corrective Actions		
TAUL CANIE IS INNSE NECHT ATT		Tighten the terminal. Replace the cable with a new one.		
External	device failure	Replace the device with a new one.		
Hardwar	re failure	Check all the wiring. If ACE still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
49	Fault  EF  External fault	External fault (EF)	External fault. When the drive decelerates based on the setting of Pr.07-20, the EF fault displays on the keypad.	
		Action and	d Reset	
	Action condition	MIx = EF and the MI ter	rminal is ON	
	Action time	Immediately act		
Fault treatment parameter		Pr.07-20 0: Coast to stop 1: Stop by the 1 <sup>st</sup> decele 2: Stop by the 2 <sup>nd</sup> decele 3: Stop by the 3 <sup>rd</sup> decele 4: Stop by the 4 <sup>th</sup> decele 5: System deceleration 6: Automatic deceleration	eration time eration time eration time	
	Reset method	Manual reset		
	Reset condition			
	Record	Yes		
	Cause	Corrective Actions		
External fault		Press RESET key after the fault is cleared.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
50	Fault  EF1  Emergency stop	Emergency stop (EF1)	When the contact of MIx = EF1 is ON, the output stops immediately and displays EF1 on the keypad. The motor is in free running.	
		Action and	d Reset	
	Action condition	MIx = EF1 and the MI terminal is ON		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Manual reset only after the external fault is cleared (terminal status is recovered)		
Record		Yes		
Cause		Corrective Actions		
When MIx = EF1 activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
51	Fault bb Base block	External base block (bb)	When the contact of MIx = bb is ON, the output stops immediately and displays bb on the keypad. The motor is in free running.	
		Action and	d Reset	
	Action condition	MIx = bb and the MI terminal is ON		
Action time		Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	The display "bb" is automatically cleared after the fault is cleared.		
	Reset condition	N/A		
Record		No		
Cause		Corrective Actions		
When MIx=bb activates		Verify if the system is back to normal condition, and then press "RESET" key to go back to the default.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
52	Fault Pcod Password error	Password is locked (Pcod)	Entering the wrong password three consecutive times	
		Action and	d Reset	
	Action condition	Entering the wrong pass	sword three consecutive times	
	Action time	Immediately act		
Fau	ult treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Power-off		
	Record	Yes		
	Cause		Corrective Actions	
Incorrect password input through Pr.00-07		2. If you forget the pas Step 1: Input 9999 a Step 2: Repeat step (You need to finish the two steps in 10	ssword after rebooting the motor drive. ssword, do the following steps: and press ENTER. o 1. Input 9999 and press ENTER. step 1 and step 2 within 10 seconds. If you don't finish seconds, try again.) ings return to the default when the "Input 9999" process	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
54	Fault CE1 PC err command	Illegal command (CE1)	Communication command is illegal	
		Action and	Reset	
	Action condition	When the function code	is not 03, 06, 10, or 63.	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
Incorrect communication command from the upper unit		Check if the communication	ation command is correct.	
Verify the wiring and grounding of the communication circuit. It is recommunication caused by interference to separate the communication circuit from the main circuit, or wire in 90 for effective anti-interference performance.		nication circuit from the main circuit, or wire in 90 degree		
from the	upper unit	Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconn of the ca	ection or bad connection able	Check the cable and re	place it if necessary.	

ID	Diaplay on LCD Kaynad	Foult Name	Fault Descriptions	
ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
55	Fault CE2 PC err address	Illegal data address (CE2)	Data address is illegal	
		Action and	d Reset	
	Action condition	When the data address	is correct.	
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
	t communication nd from the upper unit	Check if the communication	ation command is correct.	
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	Check if the setting for Pr.09-02 is the same as the setting for the upper unit		Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable  Check the cable and replace it if necessary.		place it if necessary.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
56	Fault CE3 PC err data	Illegal data value (CE3)	Data value is illegal	
		Action and	Reset	
	Action condition	When the data length is	too long	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
	et communication and from the upper unit	Check if the communication command is correct.		
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from the upper unit  Check if the setting for Pr.09-02 is the same as the setting for the upper unit			Pr.09-02 is the same as the setting for the upper unit.	
Disconn of the ca	ection or bad connection able	Check the cable and replace it if necessary.		

ID	Display on LCD Kaynad	Fault Name	Foult Descriptions	
טו	Display on LCD Keypad	Fault Name	Fault Descriptions	
57	Fault CE4 PC slave fault	Data is written to read-only address (CE4)	Data is written to read-only address	
		Action and	d Reset	
	Action condition	When the data is writter	n to read-only address.	
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	No		
	Cause		Corrective Actions	
	et communication and from the upper unit	Check if the communication	ation command is correct.	
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
Different communication setting from the upper unit		Check if the setting for Pr.09-02 is the same as the setting for the upper unit.		
Disconn of the ca	nection or bad connection able	Check the cable and replace it if necessary.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
58	Fault CE10 PC time out	Modbus transmission time-out (CE10)	Modbus transmission time-out occurs	
		Action and	d Reset	
	Action condition	When the communication	on time exceeds the detection time for Pr.09-03 time-out.	
	Action time	Pr.09-03		
Fau	It treatment parameter	Pr.09-02 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning and continue operation		
		Manual reset	•	
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
the com		Check if the upper unit transmits the communication command within the setting time for Pr.09-03.		
Verify the wiring and grounding of the communication circuit. It is reco Malfunction caused by interference to separate the communication circuit from the main circuit, or wire in for effective anti-interference performance.			nication circuit from the main circuit, or wire in 90 degree	
Different communication setting from the upper unit  Check if the setting for Pr.09-02 is the same as the setting for the upper unit			Pr.09-02 is the same as the setting for the upper unit.	
Disconnection or bad connection of the cable  Check the cable and replace it if necessary.			place it if necessary.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
60	Fault  bF  Braking fault	Brake transistor error (bF)	The brake transistor of the motor drive is abnormal. (for the models with built-in brake transistor)	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Hardware error		<ol> <li>Press "RESET" key to go back to the default. If bF still exists, return to the factory for repair.</li> <li>Power off the motor drive since the internal circuit is abnormal. Use a meter to check if it is short-circuit between B2 to DC If short-circuit exists, return to the factory for repair.</li> </ol>		
Malfunction caused by interference		Verify wiring/grounding of the main circuit to prevent interference.		
Using the incorrect brake resistor		Check if the resistance value of the brake resistor matches to the drive.		
Incorrect wiring of the brake resistor		Refer to the optional accessories instruction in chapter 7, and verify the wiring.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
61	Fault ydc Y-delta connect	Y-connection / Δ-connection switch error (ydc)	An error occurs when Y-Δ switches	
		Action and	d Reset	
			e confirmation signals of Y-connection and $\Delta$ -connection	
	Action condition	are conducted at the		
			n signals is not conducted within Pr.05-25, ydc occurs.	
	Action time	Pr.05-25		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition		the confirmation signal of Y-connection is conducted if it n the confirmation signal of $\Delta$ -connection is conducted if	
	Record	Yes		
	Cause		Corrective Actions	
	ctromagnetic valve s incorrectly during Y-∆	Check if the electromagnetic valve works normally.  If not, replace it.		
Incorrec	rect parameter setting Check if related parameters are all set up and set correctly.			
The wiring of Y-Δ switch function is incorrect Check the wiring.				

ID	Display on LCD Keypad	Fau	ult Name	Fault Descriptions	
62	Fault dEb Dec. Energy back	bac	ration energy kup error (dEb)	When Pr.07-13 is not 0, and the power is suddenly off, causing the DC bus voltage lower than the dEb action level, the dEb function acts and the motor ramps to stop. Then dEb displays on the keypad.	
			Action and	Reset	
	Action condition	When Pr.	.07-13 is not 0,	and the DC bus voltage is lower than the level of dEb.	
	Action time	Immediat	tely act		
Fau	It treatment parameter	N/A			
Reset method		Auto	drive outputs automatically When Pr.07-1	<ul> <li>3 = 2 (dEb with auto-acceleration / auto-deceleration, the the frequency after the power is restored): dEb is cleared.</li> <li>3 = 1 (dEb with auto-acceleration / auto-deceleration, the toutput the frequency after the power is restored): The</li> </ul>	
				nen dEb acts and the rotation speed becomes 0 Hz, then be reset manually.	
	Reset condition			natically cleared. lecelerates to 0 Hz.	
	Record	Yes			
	Cause		Corrective Actions		
Unstable power source or the power is off Check the			e power syster		
	any other large load	Replace power system with a larger capacity.			
operates	s in the power system	2. Use a different power system from the large load system.			

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
63	Fault  oSL  Over slip error	Over slip error (oSL)	On the basis of the maximum slip limit set via Pr.10-29, the speed deviation is abnormal. When the motor drive outputs at constant speed, F > H or F < H exceeds the level set via Pr.07-29, and it exceeds the time set via Pr.07-30, oSL shows. oSL occurs in induction motors only.	
		Action and	d Reset	
	Action condition		maximum limit of the slip frequency (Pr.10-29)	
	Action time	Pr.07-30		
Fault treatment parameter		Pr.07-31 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
	Reset method	Auto Pr.07-31 = 0 is a warning. When the motor drive outputs at constant speed, and F > H or F < H does not exceed the level set via Pr.07-29 anymore, oSL warning will be cleared automatically.		
		Hand When Pr.07-31 = 1 or 2, oSL is an error, and it needs to reset manually.		
	Reset condition	Immediately reset		
	Record	Pr.07-31 = 1 or 2, oSL i	s "Fault", and will be recorded.	
	Cause		Corrective Actions	
	ne motor parameters in er group 5 may be t	Check the motor parameters		
Overload	d	Decrease the load		
	ne setting value of 9, 07-30, and 10-29 is r	Check the setting of oSL protection function related parameters		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
64	Fault ryF MC Fault	Electric valve switch error (ryF)	Electric valve switch error when executing Soft Start	
		Action and	d Reset	
	Action condition	Hardware detection (Frame D and above)		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
Reset method		Manual reset		
	Reset condition	Reset when the electric	valve switch is correctly closed	
	Record	Yes		
	Cause	Corrective Actions		
The input power is abnormal		Check if the power is shut down during the drive operation. Check if the three-phase input power is normal.		
Malfunction caused by interference		Verify the wiring/grounding of the main circuit to prevent interference.		
Hardware failure		Cycle the power after checking the power. If ryF error still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
65	Fault PGF5 PG hardware error	PG hardware error (PGF5)	PG card hardware error (This error does not show on the CP2000 drive.)	
		Action and	d Reset	
		powering on, Pr.00-	permanent magnetic motor with PG01U/ PG02U: When 04 = 29 < Magnetic Pole Segment> displays 0 or 7	
	Action condition	<ul> <li>(Wiring Error or No U,V, W Input Signal), then the keypad displays this fault code.</li> <li>2. The motor drive receives a <run> command when powering on, but PG card is not ready to work. Then the keypad displays this fault code.</run></li> </ul>		
A (; );		Immediately act		
Action time Fault treatment parameter		N/A		
Reset method		Manual reset		
	Reset condition	Cycle the power to rese	et this fault message	
	Record	Yes	•	
	Cause		Corrective Actions	
Wiring Error or No U,V, W Input Signal		Re-wire correctly.		
Encoder	error	Verify if it is a UVW signal encoder		
Incorrect paramet	t setting of encoder er	Reset correct values for Pr.10-00		
	Verify if the motor selecting switch on the PG card is on the right side verify if using a UVW signal encoder or a Delta wire-saving encoder.			
Wrong PG card Verify if using a wrong PG card then choose a right one.			PG card then choose a right one.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
68	Fault SdRv SpdFbk Dir Rev	Reverse direction of the speed feedback (SdRv)	Rotating direction is different from the commanding direction detected by the sensorless	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Pr.10-09		
Fault treatment parameter		Pr.10-08 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		When Pr.10-08 = 1 or 2, SdRv is a "Fault", and the fault is recorded.		
Cause			Corrective Actions	
The setting of Pr.10-25 FOC bandwidth of speed observer is improper		Decrease the setting of	Pr.10-25	
The sett incorrect	ing of motor parameter is t	Reset the motor parameter and execute parameter tuning		
The mot broken	or cable is abnormal or	Check if the cable is well functioned or replace the cable		
	e force is exerted, or the ns in a reverse direction at	at Start speed tracking function (Pr.07-12)		
Malfunction caused by interference		Verify the wiring of the prevent interference.	control circuit and wiring/grounding of the main circuit to	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
69	Fault SdOr SpdFbk over SPD	Over speed rotation feedback (SdOr)	Over speed rotation detected by sensorless	
		Action and	Reset	
	Action condition	Pr.10-10		
	Action time	Pr.10-11		
Fault treatment parameter		Pr.10-12 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop		
	Reset method	Manual reset	•	
	Reset condition	Immediately reset		
Record		When Pr.10-12 = 1 or 2	, SdOr is a "Fault", and the fault is recorded.	
Cause			Corrective Actions	
	•	Decrease the setting of	Pr.10-25	
	ing of ASR bandwidth of ontroller is improper	Increase the bandwidth of ASR speed controller		
The sett incorrec	ing of motor parameter is t	Reset motor parameter and execute parameter tuning		
Malfunc	tion caused by interference	Verify the wiring of the prevent interference.	control circuit and wiring/grounding of the main circuit to	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
70	Fault SdDe SpdFbk deviate	Large deviation of speed feedback (SdDe)	A large deviation between the rotating speed and the command detected by the sensorless	
		Action and	Reset	
	Action condition	Pr.10-13		
	Action time	Pr.10-14		
Fault treatment parameter		Pr.10-15 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
Record		When Pr.10-15 = 1 or 2	, SdDe is a "Fault", and the fault is recorded.	
Cause			Corrective Actions	
	r parameter setting for al rotating slip function	Reset proper setting for	Pr.10-13 and Pr.10-14	
	r parameter setting for	Reset ASR parameters		
ASR and	d acceleration/deceleration	Set proper acceleration/deceleration time		
The acco	eleration/deceleration time ort	Reset proper acceleration	on/deceleration time	
Motor sh	naft lock	Remove the cause of motor shaft lock		
The mechanical brake is not released Verify the system a			timeline	
Incorrect parameter setting for torque limit (Pr.06-12, Adjust the setting to proper value Pr.11-17–20)				
Malfunct	tion caused by interference	Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
71	Fault WDTT Watchdog	Watchdog(WDTT)	Watchdog error	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	N/A		
Fault treatment parameter		N/A		
	Reset method	Hardware failure, and c	annot reset. Cycle the power.	
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Hardware interference		Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.  If the WDTT fault still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
72	Fault STL1 STO Loss 1	STO Loss 1 (STL1)	STO1–SCM1 internal loop detection error	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Hardware failure, and cannot reset. Cycle the power.		
Reset condition		N/A		
Record		Yes		
	Cause		Corrective Actions	
STO1 ar	nd SCM1 short circuit lines connected	Connect the short circuit line		
Hardware failure		After you make sure all the wiring is correct, if STOL fault still exists after cycling the power, please return to the factory for repair.		
Bad con	nection of the IO card	Check if the PIN of IO card is broken. Check if the IO card connects to the control board correctly, and if the screws are tightened well.		
The IO card does not match the version of the control board  Contact local agent or Delta			Pelta	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
73	Fault S1-emergy stop	Emergency stop for external safety (S1)	Emergency stop for external safety	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
		Manual reset		
	Reset condition	Reset only after S1 error is cleared.		
	Record	Yes		
Cause			Corrective Actions	
The swit (OPEN)	ch action of S1 and SCM	Reset the switch and cycle the power.		
S1 and SCM short circuit lines are not connected		Re-connect the short circuit lines		
Malfunction caused by interference		Verify the wiring/grounding of the main circuit, control circuit and encoder to prevent interference.		
Hardware failure		If S1 fault still exists after cycling the power, please return to the factory for repair.		
	Check if the PIN of IO card is broken.  Check if the IO card connects to the control board correctly, and if the scr are tightened well.			
The IO card does not match the version of the control board  Contact local agent or Delta		Delta		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
75	Fault Brk EXT-Brake Error	External brake error (Brk)	External mechanical brake error The MO terminal is active when MOx = 12, 42, 47 or 63, but the MIx = 55 does not receive signal for mechanical brake action during the set time of Pr.02-56.	
		Action and	Reset	
	Action condition	MIx = 55  did not receive time of Pr.02-56.	re signal for the mechanical brake action during the set	
	Action time	Pr.02-56		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Mechan	ical brake error	Verify if the mechanical brake can work correctly. Replace mechanical brake.		
Incorrec	t parameter setting	If there is no brake-confirming signal to use, set Pr.02-56 = 0.		
Signal cable is loose or cut off		Tighten the screws. Replace the signal cable with a new one.		
The time short	e of Pr.02-56 is set too	Increase the time setting of Pr.02-56		
Malfunction caused by interference		Verify the wiring/grounding of the main circuit, control circuit and encoder to prevent interference.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
76	Fault STO	STO (STO)	Safety Torque Off function active	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
Reset method		Auto When Pr.06-44 = 1 and after STO error is cleared, it automatically resets.		
		Manual   When Pr.06-44 = 0 and after STO error is cleared, reset it manually.		
	Reset condition	Reset only after STO er	ror is cleared.	
	Record	Yes		
	Cause	Corrective Actions		
The switch action of STO1/SCM1 and STO2/SCM2 (OPEN)		Reset the switch (ON) and cycle the power		
Poor connection of the IO card  Check if the PIN of IO card is broken.  Check if the IO card connects to the contrare tightened well.		eard is broken.  onnects to the control board correctly, and if the screws		
	card does not match the of the control board	Contact local agent or Delta		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
77	Fault STL2 STO Loss 2	STO Loss 2 (STL2)	STO2–SCM2 internal loop detection error	
		Action and	Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Hardware failure, and cannot reset. Cycle the power.		
	Reset condition	N/A		
	Record	Yes		
	Cause		Corrective Actions	
	nd SCM2 short circuit lines connected	Connect the short circui	t lines	
Hardware failure		After you make sure all the wiring is correct, if STL2 fault still exists after cycling the power, please return to the factory for repair.		
Poor cor	nnection of the IO card	Check if the PIN of IO card is broken.  Check if the IO card connects to the control board correctly, and if the screws are tightened well.		
	card does not match the of the control board	Contact local agent or Delta		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
78	Fault STL3 STO Loss 3	STO Loss 3 (STL3)	STO1–SCM1 and STO2–SCM2 internal loop detection error	
		Action and	d Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Faul	It treatment parameter	N/A		
	Reset method	Hardware failure, and cannot reset. Cycle the power.		
	Reset condition	N/A		
	Record	Yes		
	Cause		Corrective Actions	
STO1 and SCM1, or STO2 and SCM2 short circuit lines are not connected		Re-connect the short ci	rcuit lines	
Hardware failure		After you make sure all the wiring is correct, if STL3 fault still exists after cycling the power, please return to the factory for repair.		
Check if the PIN of IO card is broken.  Check if the IO card connects to the control board correctly, and if the are tightened well.				
	eard does not match the of the control board	Contact local agent or Delta		

	· · · · · · · · · · · · · · · · · · ·			
ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
82	Fault OPHL U phase lacked	Output phase loss U phase (OPHL)	U phase output phase loss	
		Action and	Reset	
	Action condition	Pr.06-47		
	Action time		ng value of Pr.06-48 first if there is DC braking function, that of Pr.06-46.	
Fault treatment parameter		Pr.06-45 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
Reset method		Manual reset		
Reset condition		Immediately reset		
	Record	Pr.06-45=1 or 2 is "Faul	t", and will be recorded.	
	Cause	Corrective Actions		
	ee-phase impedance of unbalanced	Replace the motor.		
The mot	notor is wired incorrectly  Check the cable condition.  Replace the cable.		on.	
Using a single-phase motor Choose a three-phase motor		notor		
	rent sensor is damaged	Check the flat cable of the control board. Re-do the wiring and test again if the flat cable is loose. If the fault still exists, return the unit to the factory.  Verify that the three-phase current is balanced via a current clamp meter. If it is balanced and the OPHL fault still exists, return the unit to the factory		
	re capacity is much larger emotor capacity	Make sure the capacity	of the drive and motor match to each other.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
83	Fault OPHL V phase lacked	Output phase loss V phase (OPHL)	V phase output phase loss	
		Action and	Reset	
	Action condition	Pr.06-47		
	Action time	Pr.06-46 Pr.06-48: Use the settin use that of P	g value of Pr.06-48 first. If DC braking function activates, r.06-46.	
Fault treatment parameter		Pr.06-45 0: Warn and keep operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
Reset method		Manual reset		
	Reset condition	Immediately reset		
	Record	When Pr.06-45 = 1 or 2	, OPHL is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
	iced three-phase nce of the motor	Replace the motor.		
Check if	the wiring is incorrect	Check the cable and re	place it if necessary.	
	c if the motor is a -phase motor.  Choose a three-phase motor.		motor.	
Check if broken	the current sensor is	Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL fault still exists, return to the factory for repair		
	the drive capacity is larger motor capacity	Choose the drive that m	natches the motor capacity	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
84	Fault OPHL W phase lacked	Output phase loss W phase (OPHL)	W phase output phase loss	
		Action and	Reset	
	Action condition	Pr.06-47		
	Action time	Pr.06-46 Pr.06-48: Use the settin use that of Pr.0	g value of Pr.06-48 first. If DC braking function activates, 06-46.	
Fault treatment parameter		Pr.06-45 0: Warn and continue operation 1: Fault and ramp to stop 2: Fault and coast to stop 3: No warning		
Reset method		Manual reset		
	Reset condition	Immediately reset		
	Record	When Pr.06-45 = 1 or 2	, OPHL is a "Fault", and the fault is recorded.	
	Cause		Corrective Actions	
	nced three-phase nce of the motor	Replace the motor.		
Check if	the wiring is incorrect	Check the cable and replace it if necessary.		
	Check if the motor is a single-phase motor  Choose a three-phase motor.		notor.	
Check if broken	the current sensor is	Check if the control board cable is loose. If yes, reconnect the cable and run the drive to test. If the fault still exists, return to the factory for repair.  Check if the three-phase current is balanced with a current clamp meter. If the current is balanced and the OPHL fault still exists, return to the factory for repair.		
Check if the drive capacity is larger than the motor capacity  Choose the drive that matches the motor capacity		natches the motor capacity		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
85	Fault AboF PG ABZ loss	PG ABZ loss protection (AboF)	When using PG02U card, the protection for ABZ loss (This error does not show on the CP2000 drive.)	
		Action and	l Reset	
	Action condition	Hardware detection		
	Action time	Immediately act		
Faul	t treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Reset Immediately reset		
	Record	Yes		
Cause			Corrective Actions	
PG card signal cable is not wired or is broken				
PG card	screws are loose.	Tighten all PG card <i>screws</i> .		
Malfunction caused by interference		Verify the wiring of the control circuit and wiring/grounding of the main circuit to prevent interference.		
Hardwar	e failure	<ol> <li>Cycle the power. If the keypad still displays AboF, return to the factory for repair.</li> <li>The VP power on the PG card does not output power or has abnormal voltage level.</li> <li>Encoder is broken.</li> </ol>		
encoder too long	Using a cable between the encoder and the PG card that is too long causes a VP voltage drop that is too large.  1. Reduce the cable length 2. Use power from another source to supply power to the encoder.			

ID	Display on LCD Keypad	Fault Name	Fault Descriptions		
86	Fault UvoF PG UVW loss	PG UVW loss protection (UvoF)	When using PG02U card, the protection for UVW loss (This error does not show on the CP2000 drive.)		
		Action and	Reset		
	Action condition	Hardware detection			
	Action time	Immediately act			
Fau	It treatment parameter	N/A			
Reset method		Manual reset	Manual reset		
	Reset condition	Reset Immediately reset			
	Record	Yes			
Cause			Corrective Actions		
PG card or is bro	l signal cable is not wired ken	Re-wire the PG card			
PG card	screws are loose.	Tighten all PG card scre	ews.		
Malfunction caused by interference		prevent interference.			
Hardware failure		<ol> <li>Cycle the power. If the keypad still displays AboF, return to the factory for repair.</li> <li>The VP power on the PG card doesnot output power or has abnormal voltage level.</li> <li>Encoder is broken.</li> </ol>			
			ength e encoder from another power source		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
87	Fault oL3 Derating Error	Overload protection at low frequency (oL3)	Low frequency and high current protection	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
The drive operates at a frequency below 15 Hz, and output current is too large.  2. Lower 3. Decreation to large.  4. Change		<ol> <li>Lower the carrier free</li> <li>Decrease the voltage the V/F curve.</li> <li>Change Pr.00-11 to</li> </ol>	issipation capacity for the cabinet. equency (Pr.00-17). ge settings that correspond to frequency below 15 Hz in general control mode. vith a larger power model.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
89	яшто Fault RoPd Rotor Pos. Error	Rotor position detection error (RoPd)	Rotor position detection error protection	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Check if the motor cable is abnormal or broken		Check or replace the cable.		
Motor coil error		Replace the motor.		
Hardware failure		IGBT broken. Return to the factory for repair.		
Drive's current feedback line error		Cycle the power. If RoPd still occurs during operation, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
90	Fault Fstp Force Stop	Force to stop (FStp)	Keypad forces PLC to Stop	
Action and Reset				
Action condition		When Pr.00-32 = 1, STOP button on the keypad is valid. When giving the STOP command during the PLC operation, FStp fault will active.		
Action time		Immediately act		
Fault treatment parameter		N/A		
Reset method		Manual reset		
Reset condition		Immediately reset		
Record		Yes		
Cause		Corrective Actions		
Pr.00-32 = 1: keypad STOP button is valid		Check if it is necessary to set Pr.00-32 = 0, so the keypad STOP button is invalid.		
Press STOP button during PLC operation		Verify the timing of STOP function.		

			_ ,,_ ,,,,	
ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
93	Fault TRAP CPU Trap 0 error	CPU error 0 (TRAP)	CPU crash	
Action and Reset				
Action condition		Hardware detection		
Action time		Immediately act		
Fault treatment parameter		N/A		
Reset method		Cannot reset, power off.		
Reset condition		N/A		
Record		Yes		
Cause		Corrective Actions		
Hardware interference		Verify the wiring of control circuit, and the wiring/grounding of the main circuit to prevent interference.  If TRAP fault still exists, return to the factory for repair.		
Hardware failure		Return to the factory for repair.		
CPU is in an infinite loop		Cycle the power. If the TRAP fault still exists, return to the factory for repair.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
101	Fault  CGdE  Guarding T-out	CANopen guarding error (CGdE)	CANopen guarding error	
		Action and	Reset	
	Action condition	response, the CGdE fau	Guarding detects that one of the slaves does not ult will activate. or and time during configuration.	
	Action time	The time that upper unit sets during configuration		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a	reset package to clear this fault	
	Record	Yes		
	Cause		Corrective Actions	
The guarding time is too short, or less detection times		Increase the guarding ti	ime (Index 100C) and detection times	
Malfunc	tion caused by interference	<ol> <li>Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
Communication cable is broken or		Check or replace the co	ommunication cable.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
102	Fault CHbE Heartbeat T-out	CANopen heartbeat error (CHbE)	CANopen heartbeat error	
		Action and	Reset	
Action condition		response, the CHbE fau	peat detects that one of the slaves does not all will activate. The confirming time of producer and consumer during	
	Action time	The confirming time that upper unit sets for producer and consumer during configuration.		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	The upper unit sends a	reset package to clear this fault	
	Record	Yes	· •	
	Cause		Corrective Actions	
The hea	rtbeat time is too short	Increase heartbeat time	e (Index 100C)	
Malfunction caused by interference		<ol> <li>Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.</li> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
Communication cable is broken or bad connected  Check or replace the communication cable.		ommunication cable.		

# Chapter 14 Fault Codes and Descriptions | CP2000

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
104	Fault CbFE Can bus off	CANopen bus off error (CbFE)	CANopen bus off error	
		Action and	Reset	
			pen card is not installed, CbFE fault will occur.	
Action condition		Software fault will occi Too much in When the C		
	Action level	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Cycle the power		
	Record	Yes		
	Cause		Corrective Actions	
Check if installed	the CANopen card is	Make sure the CANope	n card is installed.	
Check if the CANopen speed is correct		Reset CANopen speed (Pr.09-37)		
	iion caused by interference	<ol> <li>Make sure the communication circuit is wired in series.</li> <li>Use CANopen cable or add terminating resistance.</li> </ol>		
Communication cable is broken or		Check or replace the co	mmunication cable.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
105	Fault CIdE Can bus Index Err	CANopen index error (CldE)	CANopen index error	
		Action and	Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Upper unit sends a reset package to clear this fault		
Record		Yes		
Cause		Corrective Actions		
Incorrect setting of CANopen index		Reset CANopen Index (Pr.00-02 = 7)		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
106	Fault CAdE Can bus Add. Err	CANopen station address error (CAdE)	CANopen station address error (only supports 1–127)	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset (Pr.00-02	= 7)	
	Reset condition	N/A		
	Record	Yes		
Cause		Corrective Actions		
Incorrect setting of CANopen station address		<ol> <li>Disable CANopen (Pr.09-36 = 0)</li> <li>Reset CANopen (Pr.00-02 = 7)</li> <li>Reset CANopen station address (Pr.09-36)</li> </ol>		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
107	Fault  CFrE  Can bus off	CANopen memory error (CFrE)	CANopen memory error	
		Action and	d Reset	
	Action condition	When the user update firmware version of the control board, the FRAM internal data will not be changed, and then CFrE fault will occur.		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Pr.00-02 = 7		
	Record	Pr.00-21 = 3, the fault is recorded		
Cause		Corrective Actions		
CANopen internal memory error		<ol> <li>Disable CANopen (Pr.09-36 = 0)</li> <li>Reset CANopen (Pr.00-02 = 7)</li> <li>Reset CANopen station address (Pr.09-36)</li> </ol>		

# Chapter 14 Fault Codes and Descriptions | CP2000

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
111	Fault ictE InrCom Time Out	InrCOM time-out error (ictE)	Internal communication time-out	
		Action and	d Reset	
	Action condition	Pr.09-31 = -1 – -10 (there is no -9), when the internal communication between Slave and Master is abnormal, lctE fault will occur.		
	Action time	Immediately act		
Fau	Ilt treatment parameter	N/A		
	Reset method	Automatically reset after the internal communication is normal		
	Reset condition	N/A		
	Record	Yes		
	Cause		Corrective Actions	
Malfunction caused by interference		Verify the wiring and grounding of the communication circuit. It is recommended to separate the communication circuit from the main circuit, or wire in 90 degree for effective anti-interference performance.		
	nmunication condition is with the upper unit	Verify the setting of Pr.09-02 is the same as the setting of upper unit.		
Communication cable is broken or bad connected  Check or replace the communication		ommunication cable.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
112	Fault SfLK PMLess Shaft Lock	PMLess shaft lock (SfLK)	The drive has RUN command with output frequency, but the permanent magnetic motor does not turn.	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	3 sec.		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause	Corrective Actions		
Improper setting of the speed observer bandwidth		Increase the setting value.		
Motor shaft lock		Remove causes of the motor shaft lock.		
Motor error (e.g. demagnetization)		Replace the motor with a new one.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
142	Fault AUE1 Auto tuning Err	Auto-tune error 1 (AUE1)	No feedback current error when motor parameter automatically detects	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	It treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
	Cause		Corrective Actions	
Motor is not wired		Wire the motor correctly		
The electromagnetic contactor is used as an open state on the output side of the drive (U/V/W).		Verify that the electroma	agnetic valve is closed.	

ID	Display on LCD Keypad	Fault Name	Fault Descriptions		
143	Fault AUE2 Auto tuning Err	Auto-tune error 2 (AUE2)	Motor phase loss error when motor parameter automatically detects		
		Action and	d Reset		
	Action condition	Software detection			
	Action time	Immediately act			
Fau	It treatment parameter	N/A			
	Reset method	Manual reset			
	Reset condition	Immediately reset			
	Record	Yes			
	Cause	Corrective Actions			
Incorrec	t motor wiring	Wire the motor correctly.			
Motor error		Check if the motor works normally.			
The electromagnetic contactor is					
used as an open state on the output side of the drive (U/V/W).		Verify that the three-pha	ases of the electromagnetic valve are all closed.		
Motor U/V/W wire error		Check if the wires are b	roken.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
144	Fault AUE3 Auto tuning Err	Auto-tune error 3 (AUE3)	No load current I <sub>0</sub> measurement error when motor parameter automatically detects.	
		Action and	d Reset	
	Action condition	Software detection		
Action time		Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Incorrect settings for the motor parameter (rated current)  Check the		Check the settings for F	Pr.05-01 / Pr.05-13 / Pr.05-34.	
Motor error		Check if the motor works normally.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions	
148	Рашто Fault AUE4 Auto tuning Err	Auto-tune error 4 (AUE4)	Leakage inductance Lsigma measurement error when motor parameter automatically detects.	
		Action and	d Reset	
	Action condition	Software detection		
	Action time	Immediately act		
Fau	ılt treatment parameter	N/A		
	Reset method	Manual reset		
	Reset condition	Immediately reset		
	Record	Yes		
Cause		Corrective Actions		
Motor error		Check if the motor works normally.		
Incorrect setting of motor parameters (base frequency)		Check the setting of Pr.01-01.		

ID	Display on LCD Keypad	Fault Name	Fault Descriptions				
170	Fault CBM C/B Mismatch	C/B mismatch (CBM)	Control board matching error (This error does not show on the CP2000 drive.)				
		Action and	Reset				
	Action condition	N/A					
	Action time	Acts when turning on the drive					
Fau	Ilt treatment parameter	N/A					
	Reset method	Cannot reset					
	Reset condition	Cannot reset					
	Record	Yes					
	Cause	Corrective Actions					
Incorrec	t control board	Replace with the correct control board. If the CBM still exists, contact Delta for further confirmation.					

# Chapter 15 CANopen Overview

- 15-1 CANopen Overview
- 15-2 Wiring for CANopen
- 15-3 CANopen Communication Interface Description
- 15-4 CANopen Supporting Index
- 15-5 CANopen Fault Codes
- 15-6 CANopen LED Function

The built-in CANopen function is a kind of remote control. You can control the AC motor drive using the CANopen protocol. CANopen is a CAN-based higher layer protocol that provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO), and special functions (Time Stamp, Sync message, and Emergency message). It also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to CiA website <a href="http://www.can-cia.org/">http://www.can-cia.org/</a> for details.

#### Delta CANopen supporting functions:

- Support CAN2.0A Protocol;
- Support CANopen DS301 V4.02;
- Support DSP-402 V2.0.

#### Delta CANopen supporting services:

- PDO (Process Data Objects): PDO1–PDO4
- SDO (Service Data Object):

Initiate SDO Download;

Initiate SDO Upload;

Abort SDO:

You can use the SDO message to configure the slave node and access the Object Dictionary in every node.

■ SOP (Special Object Protocol):

Support default COB-ID in Predefined Master/Slave Connection Set in DS301 V4.02;

Support SYNC service;

Support Emergency service.

NMT (Network Management):

Support NMT module control;

Support NMT Error control;

Support Boot-up.


#### Delta CANopen not supporting service:

■ Time Stamp service

# 15-1 CANopen Overview

# **CANopen Protocol**

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks such as handling systems. Version 4.02 of CANopen (CiA DS301) is standardized as EN50325-4. The CANopen specifications cover the application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA DS302), recommendations for cables and connectors (CiA DS303-1) and SI units and prefix representations (CiA DS303-2).



#### **RJ45 Pin Definition**




PIN	Signal	Description					
1	CAN_H	CAN_H bus line (dominant high)					
2	CAN_L	CAN_L bus line (dominant low)					
3	CAN_GND	Ground / 0V / V-					
6	CAN_GND	Ground / 0V / V-					

## **CANopen Communication Protocol** contains the following services:

- NMT (Network Management Object)
- SDO (Service Data Objects)
- PDO (Process Data Object)
- **EMCY** (Emergency Object)

# NMT (Network Management Object)

The Network Management (NMT) follows a Master/Slave structure for executing NMT service. A network has only one NMT master, and the other nodes are slaves. All CANopen nodes have a present NMT state, and the NMT master can control the state of the slave nodes. The following shows the state diagram of a node:



(1) After power is applied, start in the auto-initialization state

(2) Automatically enter the pre-operational state

(3) (6) Start remote node

(4) (7) Enter pre-operational state

(5) (8) Stop remote node

(9) (10) (11) Reset node

(12) (13) (14) Reset communication

(16) Automatically enter the reset communication state

(15) Automatically enter the reset application state

	<del>(1)</del>
	Initializing
	<b>↓</b> (15)
	Reset Application (9)
	(11)
	Reset Communication
(14)	Pre-Operation ABCD
(13)	(3) (4) (5) (7) Stopped AB
(12)	(6) (8) Operation ABCD

A: NMT

C: SDO

E: PDO

F: Boot-up

B: Node Guard

D: Emergency

	Initializing	Operational	Stopped	
PDO			0	
SDO		0	0	
SYNC		0	0	
Time Stamp		0	0	
EMCY		0	0	
Boot-up	0			
NMT		0	0	0

## SDO (Service Data Objects)

Use SDO to access the Object Dictionary in every CANopen node using the Client / Server model. One SDO has two COB-ID (request SDO and response SDO) to upload or download data between two nodes. There is no data limit for SDOs to transfer data, but it must transfer data by segment when the data exceeds four bytes with an end signal in the last segment.

The Object Dictionary (OD) is a group of objects in a CANopen node. Every node has an OD in the system, and OD contains all parameters describing the device and its network behavior. The access path in the OD is the index and sub-index; each object has a unique index in the OD, and has a sub-index if necessary.

# **PDO (Process Data Object)**

PDO communication can be described by the producer / consumer model. Each node of the network listens to the messages of the transmission node and distinguishes whether the message has to be processed or not after receiving the message. A PDO can be transmitted from one device to one another device or to many other devices. Every PDO has two PDO services: a TxPDO and an RxPDO. PDOs are transmitted in a non-confirmed mode. All transmission types are listed in the following table:

Type Number	PDO										
Type Number	Cyclic	Acyclic	Asynchronous	RTR only							
0		0	0								
1–240	0		0	0							
241–251			Reserved								
252			0		0						
253				0	0						
254				0							
255				0							

- Type number 0 indicates the synchronous aperiodic message between two PDO transmissions.
- Type number 1–240 indicates the number of SYNC message between two PDO transmissions.
- Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.
- Type number 253 indicates the data is updated immediately after receiving RTR.
- Type number 254 indicates that Delta CANopen does not support this transmission format.
- Type number 255 indicates the data is an asynchronous aperiodic transmission.


All PDO transmission data must be mapped to the index with Object Dictionary.

# **EMCY (Emergency Object)**

When errors occur inside the hardware, an emergency object is triggered. An emergency object is only sent when an error occurs. As long as there is nothing wrong with the hardware, there is no emergency object warning of an error message.

# 15-2 Wiring for CANopen

Use an external CANopen communication card EMC-COP01 for CANopen wiring to connect the CANopen to the CP2000 drive. The link uses an RJ45 cable. You must write the two farthest ends with 120  $\Omega$  terminating resistors as shown in the picture below.



# 15-3 CANopen Communication Interface Description

# 15-3-1 CANopen Control Mode Selection

There are two control modes for CANopen: the DS402 standard (Pr.09-40 = 1) is the default, and the Delta's standard setting (Pr.09-40 = 0). There are two control modes according to Delta's standard. One is the old control mode (Pr.09-30 = 0); this control mode can only control the motor drive under frequency control. The other mode is a new standard (Pr.09-30 = 1); this new control mode allows the motor drive to be controlled under all kinds of modes. The CP2000 currently only supports speed mode. The following table shows the control mode definitions:

CANopen Control	Control Mode					
Mode Selection	Spe	eed				
Mode Selection	Index	Description				
DS402 standard	6042-00	Target rotating speed (rpm)				
Pr.09-40 = 1						
Delta Standard (Old definition) Pr.09-40 = 0, Pr.09-30 = 0	2020-02	Target rotating speed (Hz)				
Delta Standard (New definition)	2060-03	Target rotating speed (Hz)				
Pr.09-40 = 0, Pr.09-30 = 1	2060-04	Torque Limit (%)				

CANopen Control Mode	Operation Control					
Selection	Index	Description				
DS402 standard	6040-00	Operation Command				
Pr.09-40 = 1						
Delta Standard (Old definition) Pr.09-40 = 0, Pr.09-30 = 0	2020-01	Operation Command				
Delta Standard (New definition)	2060-01	Operation Command				
Pr.09-40 = 0, Pr.09-30 = 1						

CANopen Control Mode	Otl	her
Selection	Index	Description
DS402 standard	605A-00	Quick stop processing method
Pr.09-40 = 1	605C-00	Disable operation processing method
Delta Standard (Old definition) Pr.09-40 = 1, Pr.09-30 = 0		
Delta Standard (New definition)		
Pr.09-40 = 0, Pr.09-30 = 1		

You can use some indices in either DS402 or Delta's standard.

### For example:

- 1. Index that are defined as RO attributes.
- 2. The corresponding index of available parameter groups: (2000-00–200B-XX)
- 3. Acceleration / Deceleration Index: 604F 6050
- 4. Control mode: Index: 6060

#### 15-3-2 DS402 Standard Control Mode

## 15-3-2-1 Related setting for an AC motor drive (following the DS402 standard)

If you want to use the DS402 standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen)
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. (Run/stop, forward/reverse run...etc.)
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set DS402 for the control mode: Pr.09-40 = 1
- 5. Set the CANopen station: set Pr.09-36, the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS Baud Rate: 1 Mbps(0), 500 Kbps(1), 250 Kbps (2), 125 Kbps (3), 100 Kbps (4) and 50 Kbps (5))
- 7. Set the multiple input functions to Quick Stop. You can also choose to enable or disable; the default setting is disabled. If it is necessary to enable the function, set MI terminal to 53 in one of the following parameter: Pr.02-01–Pr.02-08 or Pr.02-26–Pr.02-31. Note that this function is available in DS402 only.

#### 15-3-2-2 The status of the motor drive (by following DS402 standard)

According to the DS402 definition, the motor drive is divided into 3 blocks and 9 statuses as described below.

#### 3 blocks

- 1. Power Disable: without PWM output
- 2. Power Enable: with PWM output
- 3. Fault: one or more errors have occurred.

#### 9 status

- 1. Start: power ON
- 2. Not ready to switch on: the motor drive is initiating.
- 3. Switch ON Disable: occurs when the motor drive finishes initiating.
- 4. Ready to Switch On: warming up before running.
- 5. Switch ON: the motor drive has the PWM output, but the reference command is not effective.
- 6. Operation Enable: able to control normally.
- 7. Quick Stop Active: when there is a Quick Stop request, stop running the motor drive.
- 8. Fault Reaction Active: the motor drive detects conditions which might trigger error(s).
- 9. Fault: One or more errors have occurred in the motor drive.


When the motor drive turns on and finishes the initiation, it remains in Ready to Switch On status. To control the operation of the motor drive, change to Operation Enable status. To do this, set the control word's bit0-bit3 and bit7 of the Index 6040H and pair with Index Status Word (Status Word 0X6041). The control steps and index definition are described as below:

#### Index 6040

15–9	8	7	6–4	3	2	1	0
Reserved	Halt	Fault Reset	Operation	Enable operation	Quick Stop	Enable Voltage	Switch On

#### Index 6041

ſ	15-14	13–12	11	10	9	8	7	6	5	4	3	2	1	0
ı	Reserved	Operation	Internal limit active	Target reached	Remote	Reserved	Warning	Switch on disabled	Quick stop	Voltage enabled	Fault	Operation enable		Ready to switch on



Set command 6040 = 0xE, then set another command 6040 = 0xF. Then you can switch the motor drive to Operation Enable. The Index 605A determines the direction of the lines from Operation Enable when the control mode changes from Quick Stop Active. When the setting value is 1–3, both direction lines are active, but when the setting value of 605A is not 1–3, once the motor drive is switched to Quick Stop Active, it is not be able to switch back to Operation Enable.

#### Chapter 15 CANopen Overview | CP2000

Inde	ex	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	note
605/	Ah	0	Quick stop option code	2	RW	S16		No		Slow down on slow down ramp     Slow down on quick stop ramp     Slow down on the current limit     Slow down on slow down ramp and stay in Quick Stop     Slow down on quick stop ramp and stay in Quick Stop     Slow down on the current limit and stay in Quick Stop

When the control block switches from Power Enable to Power Disable, use 605C to define the stop method.

Index	Sub	Definition	Default	R/W	Size	Unit	PDO Map	Mode	note
605Ch	0	Disable operation option code	1	RW	S16		No		Disable drive function     Slow down with slow down ramp; disable of the drive function

15-3-2-3 Various mode control method (by following DS402 standard)

CP2000 currently only supports speed control which is described as below:

#### Speed mode

- 1. Set CP2000 to speed control mode: set Index6060 to 2.
- 2. Switch to Operation Enable mode: Set 6040 = 0xE, then set 6040 = 0xF.
- 3. Set the target frequency: Set target frequency for 6042, since the operation unit of 6042 is rpm, a conversion is required:

  n: rotation speed (rpm) (rounds/minute)


 $n = f \times \frac{120}{p}$  P: motor's pole number (Pole) f: rotation frequency (Hz)

For example:

Set 6042H = 1500 (rpm), if the number of poles for the drive is 4 (Pr.05-04 or Pr.05-16), then the motor drive's operation frequency is 1500 / (120/4) = 50 Hz. The 6042 is defined as a signed operation. The plus or minus sign means to rotate clockwise or counter-clockwise

- 4. To set acceleration and deceleration: Use 604F (Acceleration) and 6050 (Deceleration).
- 5. Trigger an ACK signal: in the speed control mode, control the bit6–4 of Index 6040. It is defined below:

		Index 6040		SUM		
Chand made	bit6	bit5	bit4	SUM		
Speed mode (Index 6060=2)	1	0	1	Locked at the current signal.		
(Index 6060-2)	1	1	1	Run to reach targeting signal.		
		Other	Decelerate to 0 Hz.			



NOTE 01: Read 6043 to get the current rotation speed. (Unit: rpm)

NOTE 02: Read bit10 of 6041 to check if the rotation speed has reached the targeting value. (0: Not reached; 1: Reached)

## 15-3-3 Using the Delta Standard (Old definition, only supports speed mode)


#### 15-3-3-1 Various mode control method (following the Delta old standard)

If you want to use the Delta old standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen)
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. (Run/stop, forward/ reverse run..., etc.)
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (Old definition, only supports speed mode) as the control mode: Pr.09-40 = 0 and Pr.09-30 = 0.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36 = 0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02=7 to reset.
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS Baud Rate: 1 Mbps(0), 500 Kbps(1), 250 Kbps(2), 125 Kbps(3), 100 Kbps(4) and 50 Kbps(5))

# 15-3-3-2 The control method under speed mode

- 1. Set the target frequency: set 2020-02, the unit is Hz, with 2 decimal places. For example, 1000 is 10.00 Hz.
- 2. Operation control: set 2020-01 = 0002H for running, and set 2020-01 = 0001H for stopping.



15-3-4 By Using Delta Standard (New Definition)

15-3-4-1 Related settings for an AC motor drive (following the Delta New Standard)


If you want to use the Delta new standard to control the motor drive, follow these steps:

- 1. Wire the hardware (refer to Section 15-2 Wiring for CANopen)
- 2. Set the operation source: set Pr.00-21 to 3 for CANopen communication card control. (Run/stop, forward/reverse run..., etc.)
- 3. Set the frequency source: set Pr.00-20 to 6. Choose the source for the Frequency command from the CANopen setting.
- 4. Set Delta Standard (New definition) as the control mode: Pr.09-40 = 0 and Pr.09-30 = 1.
- 5. Set the CANopen station: set Pr.09-36; the range is between 1–127. When Pr.09-36=0, the CANopen slave function is disabled. Note that if an error appears (station address error CAdE or CANopen memory error CFrE) when you finish the station setting, set Pr.00-02 = 7 to reset.)
- 6. Set the CANopen baud rate: set Pr.09-37 (CANBUS Baud Rate: 1 Mbps (0), 500 Kbps (1), 250 Kbps (2), 125 Kbps (3), 100 Kbps (4) and 50 Kbps(5)).

15-3-4-2 Various mode control method (Delta New Standard)

#### **Speed Mode**

- 1. Set CP2000 to speed control mode: set Index6060 = 2.
- 2. Set the target frequency: set 2060-03, unit is Hz, with 2 decimal places. For example, 1000 is 10.00Hz.
- 3. Operation control: set 2060-01 = 008H for Server on, and set 2060-01 = 0081H for running.



NOTE 1: Read 2061-05 to get the current position.

NOTE 2: Read bit0 of 2061 to find if the position has reached to the target position. (0: Not reached, 1: Reached).

# 15-3-5 DI/ DO/ AI/ AO are controlled via CANopen

To control the DO and AO of the motor drive through CANopen, follow these steps:

- 1. Define the DO to be controlled by CANopen. For example, set Pr.02-14 = 50 to control RY2.
- 2. Define the AO to be controlled by CANopen. For example, set Pr.03-23 = 20 to control AFM2.
- 3. Control the Index mapped by CANopen. To control DO, use control Index 2026-41. To control AO, use control 2026-AX. To set RY2 as ON, set bit1 of Index 2026-41 = 1, then RY2 outputs 1. To control AFM2 output = 50.00%, set Index 2026-A2 = 5000, then AFM2 outputs 50%.

The following table shows the mapping of CANopen DI/ DO/ AI/ AO:

#### DI:

Terminal	Related Parameters	R/W	Mapping Index
FWD	==	RO	2026-01 bit0
REV	==	RO	2026-01 bit1
MI 1	==	RO	2026-01 bit2
MI 2	==	RO	2026-01 bit3
MI 3	==	RO	2026-01 bit4
MI 4	==	RO	2026-01 bit5
MI 5	==	RO	2026-01 bit6
MI 6	==	RO	2026-01 bit7
MI 7	==	RO	2026-01 bit8
MI 8	==	RO	2026-01 bit9
MI 10	==	RO	2026-01 bit10
MI 11	==	RO	2026-01 bit11
MI 12	==	RO	2026-01 bit12
MI 13	==	RO	2026-01 bit13
MI 14	==	RO	2026-01 bit14
MI 15	==	RO	2026-01 bit15

# DO:

Terminal	Related Parameters	R/W	Mapping Index
RY1	Pr.02-13 = 51	RW	2026-41 bit0
RY2	Pr.02-14 = 51	RW	2026-41 bit1
RY3	Pr.02-15 = 51	RW	2026-41 bit2
MO10/RY10	Pr.02-36 = 51	RW	2026-41 bit5
MO11/RY11	Pr.02-37 = 51	RW	2026-41 bit6
RY12	Pr.02-38 = 51	RW	2026-41 bit7
RY13	Pr.02-39 = 51	RW	2026-41 bit8
RY14	Pr.02-40 = 51	RW	2026-41 bit9
RY15	Pr.02-41 = 51	RW	2026-41 bit10

# AI:

Terminal	Related Parameters	R/W	Mapping Index
AVI1	==	RO	Value of 2026-61
ACI	==	RO	Value of 2026-62
AVI2	==	RO	Value of 2026-63

## AO:

Terminal	Related Parameters	R/W	Mapping Index
AFM1	Pr.03-20 = 21	RW	Value of 26A0h
AFM2	Pr.03-23 = 21	RW	Value of 26A1h
AFM10	Pr.14-12 = 21	RW	Value of 26AAh
AFM11	Pr.14-13 = 21	RW	Value of 26ABh

# 15-4 CANopen Supporting Index

CP2000 Index:

The parameter index corresponds as following in this example:

Index sub-Index

2000H + Group member+1

For example:

Pr.10-15 (Encoder Slip Error Treatment)

**Group member** 10(0AH) - 15(0FH)

Index = 2000H + 0AH = 200A

Sub Index = 0FH + 1H = 10H

CP2000 Control Index:

# **Delta Standard Mode (Old definition)**

Index	Sub	Definition	Factory Setting	R/W	Size	Note
	0	Number	3	R	U8	
2020H	1	Control word	0	RW	U16	bit1–0  00B: disable 01B: stop 10B: disable 11B: JOG Enable  bit3–2  Reserved  bit5–4  00B: disable 01B: Direction forward 10B: Reverse 11B: Switch Direction  bit7–6  00B: 1st step Accel. /Decel. 01B: 2nd step Accel. /Decel. 10B: 3rd step Accel. /Decel. 11B: 4th step Accel. /Decel. 11B: 4th step Accel. /Decel.  bit11–8  0000B: Master speed 0010B: 2nd step speed 0010B: 2nd step speed 0010B: 3rd step speed 0100B: 4th step speed 0100B: 4th step speed 0110B: 5th step speed 0110B: 5th step speed 0110B: 7th step speed 1001B: 7th step speed 1001B: 10th step speed 1001B: 10th step speed 1011B: 11th step speed 1101B: 12th step speed 1101B: 13th step speed 1101B: 13th step speed 1110B: 14th step speed 1110B: 14th step speed 1111B: 15th step speed 1111B: 15th step speed 1111B: 15th step speed 1111B: 15th step speed
	2	Freq. command	0	RW	U16	
		(XXX.XX Hz)				
	3	Other trigger	0	RW	U16	bit0 1: E.F. ON

Index	Sub	Definition	Factory Setting	R/W	Size		Note
						bit1	1: Reset
						bit2	1: Base Block (B.B) ON
						bit15-3	Reserved
	0	Number	10	R	U8		
	1	Error code	0	R U			Warn code
		Lifer code		11	0.10	Low byte:	
							00B: stop
							01B: decelerate to stop
						bit1–0	10B: waiting for operation
							command
						1.110	11B: in operation
						bit2	1: JOG command
							00B: run forward
							01B: switch from run in reverse
						bit4-3	to run forward
							10B: switch from run forward to
							run in reverse 11B: run in reverse
						bit7–5	Reserved
	2	AC motor drive status	0	R	U16	טונז–ט	
						bit8	1: master frequency command controlled by communication
						Dito	interface
							1: master frequency command
						bit9	controlled by analog signal
						Dito	input
							1: operation command
						bit10	controlled by communication
2021H							interface
						bit11	1: Parameter lock
						bit12	1: Enable the digital keypad
							copy parameter function
						bit15–13	Reserved
	3	Freq. command (XXX.XX Hz)	0	R	U16		
	4	Output freq. (XXX.XX Hz)	0	R	U16		
	5	Output current (XX.X A)	0	R	U16		
	6	DC bus voltage (XXX.X V)	0	R	U16		
	7	Output voltage (XXX.X V)	0	R	U16		
		The current segment run by					
	8	the multi-segment speed	0	R	U16		
		command					
	9	Reserved	0	R	U16		
	Α	Display counter value (c)	0	R	U16		
]	В	Display output power angle (XX.X°)	0	R	U16		
]	_	Display output torque					
]	С	(XXX.X %)	0	R	U16		
]	D	Display actual motor speed	0	Ь	1116		
		(rpm)		R	U16		
	10	Power output (X.XXX kWh)	0	R	U16		
	17	Multi-function display	0	R	U16		
<del></del>	0	(Pr.00-04) Reserved	0	R	U16		
	1	Display output current	0	R	U16		
	2	Display counter value	0	R	U16		
2022H		Display actual output					
,	3	frequency (XXX.XX Hz)	0	R	U16		
]		Display DC bus voltage	^		1140		
	4	(XXX.X V)	0	R	U16		

Index	Sub	Definition	Factory Setting	R/W	Size	Note
	5	Display output voltage (XXX.X V)	0	R	U16	
	6	Display output power angle (XX.X°)	0	R	U16	
	7	Display output power in kW	0	R	U16	
	8	Display actual motor speed (rpm)	0	R	U16	
	9	Display estimate output torque (XXX.X%)	0	R	U16	
	В	Display PID feedback value after enabling PID function in % (To 2 decimal places)	0	R	U16	
	С	Display signal of AVI 1 analog input terminal, 0–10 V corresponds to 0–100% (To 2 decimal places)	0	R	U16	
	D	Display signal of ACI analog input terminal, 4–20 mA /0–10 V corresponds to 0–100% (To 2 decimal places)	0	R	U16	
	Е	Display signal of AVI 2 analog input terminal, -10 V–10 V corresponds to -100–100% (To 2 decimal places)	0	R	U16	
	F	Display the IGBT temperature of drive power module in °C	0	R	U16	
	10	Display the temperature of capacitance in °C	0	R	U16	
	11	The status of digital input (ON/OFF), refer to Pr.02-12	0	R	U16	
	12	The status of digital output (ON/OFF), refer to Pr.02-18	0	R	U16	
	13	Display the multi-step speed that is executing	0	R	U16	
	14	The corresponding CPU pin status of digital input	0	R	U16	
	15	The corresponding CPU pin status of digital output	0	R	U16	
	1A	Display times of counter overload (0.00–100.00%)	0	R	U16	
		Display GFF in % Display DC bus voltage	0	R	U16	
	1C	ripples (Unit: V <sub>DC</sub> ) Display PLC register D1043	0	R	U16	
	1D	data  Display Pole of Permanent	0	R	U16	
	1E	Magnet Motor User page displays the	0	R	U16	
	1F	value in physical measure	0	R	U16	
	20	Output Value of Pr.00-05  Number of motor turns	0	R R	U16	
	22	when drive operates Operation position of motor	0	R	U16	
		Fan speed of the drive	0	R	U16	
	24	Control mode of the drive 0: speed mode	0	R	U16	
	25	Carrier frequency of the drive	0	R	U16	
		Reserved				
	27	Motor status				

# Chapter 15 CANopen Overview | CP2000

Index	Sub	Definition	Factory Setting	R/W	Size	Note
	2A	kWh display				
	1 /11	Motor actual position low-word				
		Motor actual position high-word				
	2F	PID reference target				
	30	PID bias value				
	31	PID output frequency				

# CANopen Remote IO mapping

Index	Sub	R/W	Definition
	01h	R	Each bit corresponds to the different input terminals
	03h-40h	R	Reserved
	41h	RW	Each bit corresponds to the different output terminals
	42h-60h	R	Reserved
	61h	R	AVI1 (%)
	62h	R	ACI (%)
	63h	R	AVI2 (%)
2026H	64h–6Ah	R	Reserved
202011	6Bh	R	Extension card Al10, 0.0–100.0% (EMC-A22A)
	6Ch	R	Extension card Al11, 0.0–100.0% (EMC-A22A)
	6Dh-A0h	R	Reserved
	A1h	RW	AFM1 (%)
	A2h	RW	AFM2 (%)
	A3h–AAh	RW	Reserved
	ABh	RW	Extension card AO10, 0.0–100.0% (EMC-A22A)
	ACh	RW	Extension card AO11, 0.0–100.0% (EMC-A22A)

Index 2026-01	bit0	bit1	bit2	bit3	bit4	bit5	bit6	bit7	bit8	bit9	bit10	bit11	bit12	bit13	bit14	bit15
1	FWD	REV	MI1	MI2	MI3	MI4	MI5	MI6	MI7	MI8						
2											MI10	MI11	MI12	MI13	MI14	MI15
3											MI10	MI11	MI12	MI13		

1 : Control broad I/O (Standard)

2: Add external card, EMC-D611A

3 : Add external card, EMC-D42A

Index 2026-41	bit0	bit1	bit2	bit3	bit4	bit5	bit6	bit7	bit8	bit9	bit10	bit11	bit12	bit13	bit14	bit15
1	RY1	RY2		MO1	MO2											
2						MO10	MO11									
3						RY10	RY11	RY12	RY13	RY14	RY15					

1 : Control broad I/O (Standard)

2 : Add external card, EMC-D42A

3: Add external card, EMC-R6AA

# Delta Standard Mode (New definition)

		D.044	0:		Descriptions		
Index	sub	R/W	Size	bit	Definition	Priority	Speed Mode
	00h	R	U8				
				0	Ack	4	0: fcmd = 0 1: fcmd = Fset (Fpid)
				1	Dir	4	0: FWD run command 1: REV run command
				3	Halt		0: drive run till target speed is attained
							1: drive stop by deceleration setting     0: drive run till target speed is
	01h	RW	U16	4	Hold		attained 1: frequency stop at current frequency
	UIII	KVV	010	5	JOG		0: JOG OFF Pulse 1: JOG RUN
2060h				6	QStop		Quick Stop
200011				7	Power		0:Power OFF 1:Power ON
				8	Reserved		
				9	Ext Cmd2	4	0->1: Absolute position cleared
				10–14	Reserved		
				15	RST	4	Pulse 1: Fault code cleared
	02h	RW	U16		Mode Cmd		0: Speed mode
	03h	RW	U16				Speed command (unsigned decimal)
	04h	RW RW	U16 S32				
	05h 06h	RW	532				
	07h	RW	U16				
	08h	RW	U16				
				0	Arrive		Frequency attained
				1	Dir		0: Motor FWD run 1: Motor REV run
				2	Warn		Warning
	01h	R	U16	3	Error		Error detected
				4	100		100
				5 6	JOG QStop		JOG Quick stop
2061h				7	Power On		Switch ON
200111				15–8	1 01101 011		- Maria Gra
	02h	R					
	03h	R	U16				Actual output frequency
	04h	R					
	05h	R	S32				Actual position (absolute)
	06h	R	0.10				
	07h	R	S16				Actual torque


Mapping for CANopen built-in PLC register D (mapping from D900–D999 to 3000H–3063H )

Index	Sub	R/W	Definition
3000	0	RW	PLC D900
3001	0	RW	PLC D901
3002	0	RW	PLC D902
3063	0	RW	PLC D999

# DS402 Standard

Index	Sub	Definition	Factory Setting	R/W	Size	Unit	PDO Map	Mode	Note
6007h	0	Abort connection option code	2	RW	S16		Yes		No action     Disable Voltage     guick stop
603Fh	0	Error code	0	R0	U16		Yes		·
6040h	0	Control word	0	RW	U16		Yes		
6041h	0	Status word	0	R0	U16		Yes		
6042h	0	vl target velocity	0	RW	S16	rpm	Yes	vl	
6043h		vl velocity demand	0	RO	S16	rpm	Yes	vl	
6044h		vl control effort	0	RO	S16	rpm	Yes	vl	
604Fh	0	vl ramp function time	10000	RW	U32	1ms	Yes	vl	Unit must be: 100 ms, and
6050h	_	vl slow down time	10000	RW	U32	1ms	Yes	vl	check if the setting is 0.
6051h	0	vl quick stop time	1000	RW	U32	1ms	Yes	vl	_
605Ah	0	Quick stop option code	2	RW	S16		No		il disable drive function     il: slow down on slow down ramp     il: slow down on quick stop ramp     il: slow down on quick stop ramp     il: slow down on slow down ramp and stay in Quick Stop     il: slow down on quick stop ramp and stay in Quick Stop
605Ch	0	Disable operation option code	1	RW	S16		No		Disable drive function     Slow down with slow     down ramp; disable of the     drive function
6060h	0	Mode of operation	2	RW	S8		Yes		2: Velocity Mode
6061h	0	Mode of operation display	2	RO	S8		Yes		Same as above

# 15-5 CANopen Fault Codes



- ① Display error signal
- 2 Abbreviate error code
- 3 Display error description
- Refer to setting value of Pr.06-17–Pr.06-22.
- Refer to Chapter 14 Fault Codes for detailed descriptions.

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
1	Fault ocA Oc at accel	0001H	Over-current during acceleration (ocA)	1	2213H
2	Fault ocd Oc at decel	0002H	Over-current during deceleration (ocd)	1	2213H
3	Fault ocn Oc at normal SPD	0003H	Over-current during steady operation (ocn)	1	2214H
4	Fault  GFF  Ground fault	0004H	Ground fault (GFF)	1	2240H
5	Fault occ Short Circuit	0005H	IGBT short circuit between upper bridge and lower bridge (occ)	1	2250H
6	Fault ocS Oc at stop	0006H	Over-current at stop (ocS)	1	2314H
7	Fault ovA Ov at accel	0007H	Over-voltage during acceleration (ovA)	2	3210H
8	Fault ovd Ov at decel	0008H	Over-voltage during deceleration (ovd)	2	3210H

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
9	Fault ovn Ov at normal SPD	0009H	DC bus over-voltage at constant speed (ovn)	2	3210H
10	Fault ovS Ov at stop	000AH	Over-voltage at stop (ovS)	2	3210H
11	Fault LvA Lv at accel	000BH	Low-voltage during acceleration (LvA)	2	3220H
12	Auто Fault Lvd Lv at decel	000CH	Low-voltage during deceleration (Lvd)	2	3220H
13	Fault Lvn Lv at normal SPD	000DH	Low-voltage at constant speed (Lvn)	2	3220H
14	Fault LvS Lv at stop	000EH	Low-voltage at stop (LvS)	2	3220H
15	Раиlt OrP Phase lacked	000FH	Phase loss protection (OrP)	2	3130H
16	Fault oH1	0010H	IGBT overheating (oH1)	3	4310H
17	Fault oH2 Heat Sink oH	0011H	Heatsink overheating (oH2)	3	4310H
18	Fault tH1o Thermo 1 open	0012H	IGBT temperature detection failure (tH1o)	3	FF00H
19	Fault tH2o Thermo 2 open	0013H	Capacitor hardware error (tH2o)	3	FF01H

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
21	Fault  OL  Over load	0015H	Over load (oL)	1	2310H
22	Fault EoL1 Thermal relay 1	0016H	Electronic thermal relay 1 protection (EoL1)	1	2310H
23	Fault EoL2 Thermal relay 2	0017H	Electronic thermal relay 2 protection (EoL2)	1	2310H
24	Fault oH3 Motor over heat	0018H	Motor overheating (oH3)	3	FF20H
26	Fault ot1 Over torque 1	001AH	Over torque 1 (ot1)	3	8311H
27	Fault ot2 Over torque 2	001BH	Over torque 2 (ot2)	3	8311H
28	Fault uC Under current	001CH	Under current (uC)	1	8321H
30	Fault cF1 EEPROM write err	001EH	EEPROM write error (cF1)	5	5530H
31	Fault cF2 EEPROM read err	001FH	EEPROM read error (cF2)	5	5530H
33	Fault cd1 las sensor err	0021H	U-phase error (cd1)	1	FF04H
34	Fault cd2	0022H	V-phase error (cd2)	1	FF05H

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
35	Fault cd3	0023H	W-phase error (cd3)	1	FF06H
36	Fault Hd0 cc HW error	0024H	cc (current clamp) hardware error (Hd0)	5	FF07H
37	Fault Hd1 Oc HW error	0025H	oc hardware error (Hd1)	5	FF08H
38	Fault Hd2 Ov HW error	0026H	ov hardware error (Hd2)	5	FF09H
39	Fault Hd3 occ HW error	0027H	occ hardware error (Hd3)	5	FF0AH
40	Fault AUE Auto tuning error	0028H	Auto-tuning error (AUE)	1	FF21H
41	Fault  AFE PID Fbk error	0029H	PID loss ACI (AFE)	7	FF22H
48	Fault ACE ACHOSS	0030H	ACI loss (ACE)	1	FF25H
49	Fault  EF  External fault	0031H	External fault (EF)	5	9000H
50	Fault EF1 Emergency stop	0032H	Emergency stop (EF1)	5	9000H
51	Fault bb Base block	0033H	External base block (bb)	5	9000H

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
52	Fault Pcod Password error	0034H	Password is locked (Pcod)	5	FF26H
54	Fault CE1 PC err command	0036H	Illegal command (CE1)	4	7500H
55	Fault CE2 PC err address	0037H	Illegal data address (CE2)	4	7500H
56	Fault CE3 PC err data	0038H	Illegal data value (CE3)	4	7500H
57	Fault CE4 PC slave fault	0039H	Data is written to read-only address (CE4)	4	7500H
58	Fault CE10 PC time out	003AH	Modbus transmission time-out (CE10)	5	7500H
60	Раиlt bF Braking fault	003CH	Brake transistor error (bF)	4	7110H
61	Раши удс Y-delta connect	003DH	Y-connection / Δ-connection switch error (ydc)	2	3330H
62	Раши dEb Dec. Energy back	003EH	Deceleration energy backup error (dEb)	2	FF27H
63	Аито Fault oSL Over slip error	003FH	Over slip error (oSL)	7	FF28H
64	Fault ryF MC Fault	0040H	Electric valve switch error (ryF)	5	7110H

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
68	Fault SdRv SpdFbk Dir Rev	0044H	Reverse direction of the speed feedback (SdRv)	0	8400H
69	Fault SdOr SpdFbk over SPD	0045H	Over speed rotation feedback (SdOr)	0	8400H
70	Fault SdDe SpdFbk deviate	0046H	Large deviation of speed feedback (SdDe)	0	8400H
71	Fault WDTT Watchdog	0047H	Watchdog (WDTT)	1	6010H
72	Fault STL1	0048H	STO loss 1 (STL1)	5	FF30H
73	Fault S1 S1-emergy stop	0049H	Emergency stop for external safety (S1)	5	FF2AH
74	Fault Fire On Fire	004AH	Fire mode (Fire)	7	FF2FH
76	Fault STO	004CH	Safe torque off (STO)	5	FF31H
77	Fault STL2 STO Loss 2	004DH	STO loss 2 (STL2)	5	FF32H
78	Fault STL3	004EH	STO loss 3 (STL3)	5	FF33H
82	Раціто Fault OPHL U phase lacked	0052H	Output phase loss U phase (OPHL)	2	2331H

ID No.*	Display	Fault code	Description	CANopen fault register (bit0–7)	CANopen fault code
83	Fault OPHL V phase lacked	0053H	Output phase loss V phase (OPHL)	2	2332H
84	Fault OPHL W phase lacked	0054H	Output phase loss 3 W phase (OPHL)	2	2333H
90	Fault Fstp Force Stop	005AH	Force to stop (FStp)	7	FF2EH
101	Раиlt CGdE Guarding T-out	0065H	CANopen guarding error (CGdE)	4	8130H
102	Fault CHbE Heartbeat T-out	0066H	CANopen heartbeat error (CHbE)	4	8130H
104	Fault CbFE Can bus off	0068H	CANopen bus off error (CbFE)	4	8140H
105	Fault CldE Can bus Index Err	0069H	CANopen index error (CldE)	4	8100H
106	Fault CAdE Can bus Add. Err	006AH	CANopen station address error (CAdE)	4	8100H
107	Fault  CFrE  Can bus off	006BH	CANopen memory error (CFrE)	4	8100H
111	Fault ictE InrCom Time Out	006FH	InrCOM time-out error (ictE)	4	7500H
112	Fault SfLK PMLess Shaft Lock	0070H	PMLess shaft lock (SfLK)	7	8A00H

# Chapter 15 CANopen Overview | CP2000

ID No.*	Display	Fault code	Description	CANopen fault register (bit0-7)	CANopen fault code
142	Аито Fault AUE1 Auto tuning Err	008EH	Auto-tune error 1 (AUE1)	1	FF3DH
143	АUTO Fault AUE2 Auto tuning Err	008FH	Auto-tune error 2 (AUE2)	1	FF3EH
144	Auto Fault AUE3 Auto tuning Err	0090H	Auto-tune error 3 (AUE3)	1	FF3FH
148	Аито Fault AUE4 Auto tuning Err	0094H	Auto-tune error 4 (AUE4)	1	FF43H


# 15-6 CANopen LED Function

There are two CANopen flash signs: RUN and ERR.

# **RUN LED:**

LED status	Condition	CANopen State
OFF		Initial
Blinking	ON-200 ms ms	Pre-Operation
Single flash	ON 200 1000 ms ms of ms	Stopped
ON	ERR — CAN — RUN	Operation

# ERR LED:



[This page intentionally left blank]

# Chapter 16 PLC Function Applications

16-1	PLC Summary
16-2	Notes before PLC use
16-3	Turn on
16-4	Basic principles of PLC ladder diagrams
16-5	Various PLC device functions
16-6	Introduction to the Command Window
16-7	Error display and handling
16-8	CANopen Master control applications
16-9	Explanation of various PLC speed mode controls
16-10	Internal communications main node control
16-11	Modbus remote IO control applications (use MODRW
16-12	Calendar functions

# 16-1 PLC Summary

#### 16-1-1 Introduction

The commands provided by the CP2000's built-in PLC functions, including the ladder diagram editing tool WPLSoft, as well as the usage of basic commands and applications commands, chiefly retain the operating methods of Delta's PLC DVP series.

# 16-1-2 WPLSoft ladder diagram editing tool


WPLSoft is Delta's program editing software for the DVP and CP2000 programmable controllers in the Windows operating system environment. Apart from general PLC program design general Windows editing functions (such as cut, paste, copy, multiple windows, etc.), WPLSoft also provides many Chinese/English annotation editing and other convenience functions (such as registry editing, settings, file reading, saving, and contact graphic monitoring and settings, etc.).

The following basic requirements that need to install WPLSoft editing software:

Item	System requirements						
Operating system	Windows 95/98/2000/NT/ME/XP						
CPU	At least Pentium 90						
Memory	At least 16 MB (we recommend at least 32 MB)						
Hard drive	Hard drive capacity: at least 100MB free space						
Hard drive	One optical drive (for use in installing this software)						
Display	Resolution: 640 × 480, at least 16 colors; it is recommended that the screen						
Display	area be set at 800 × 600 pixels						
Mouse Ordinary mouse or Windows-compatible device							
Printer Printer with a Windows driver program							
RS-485 port	Must have at least an RS-485 port to link to the PLC						

## 16-2 Notes before PLC use

- 1. The PLC has a preset communications format of 7, N, 2, 9600, with node 2; the PLC node can be changed in Pr.09-35, but this address may not be the same as the drive's address setting of Pr.09-00.
- 2. The CP2000 provides two communications serial ports that can be used to download PLC programs (see figure below). Channel 1 has a fixed communications format of 19200, 8, N, 2 RTU.




- 3. The client can simultaneously access data from the converter and internal PLC, which is performed through identification of the node. For instance, if the converter node is 1 and the internal PLC node is 2, then the client command will be
  - 01 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in converter Pr.04-00.
  - 02 (node) 03 (read) 0400 (address) 0001 (1 data item), indicating that it must read the data in internal PLC X0
- 4. The PLC program will be disabled when uploading/ downloading programs.
- 5. Please note when using WPR commands to write in parameters, values may be modified up to a maximum of 10<sup>9</sup> times, otherwise a memory write error will occur. The calculation of modifications is based on whether the entered value has been changed. If the entered value is left unchanged, the modifications will not increase afterwards. But if the entered value is different from before, the number of modifications will increase by one. Those parameters listed below are exceptions, proceed to the next page for details:
  - Pr.00-11 Speed control mode
  - Pr.01-12-01-19 Acceleration / Deceleration time 1-4
  - Pr.02-12 Multi-function input mode selection
  - Pr.02-18 Multi-function output direction
  - Pr.04-50-04-59 PLC buffer 0-9
  - Pr.08-04 Upper limit of integral control
  - Pr.08-05 PID output command limit

6. When Pr.00-04 is set as 28, the displayed value is the value of PLC register D1043 (see figure below):

Keypad KPC-CC01

Can display 0-65535




- 7. In the PLC Run and PLC Stop mode, the content 9 and 10 of Pr.00-02 cannot be set nor be reset to the default value.
- 8. The PLC can be reset to the default value when Pr.00-02 is set as 6.
- 9. The corresponding MI function will be disabled when the PLC writes to input contact X.
- 10. When the PLC controls converter operation, control commands will be entirely controlled by the PLC and will not be affected by the setting of parameter 00-21.
- 11. When the PLC controls converter frequency commands (FREQ commands), frequency commands will be entirely controlled by the PLC, and will not be affected by the setting of Pr.00-20 or the Hand ON/OFF configuration.
- 12. When the PLC controls the drive's operation, if the keypad Stop setting is valid, this will trigger an FStP error and cause stoppage.

### 16-3 Turn on


# 16-3-1 Connect to PC

Start operation of PLC functions in accordance with the following four steps


1. After pressing the Menu key and selecting 4: PLC on the KPC-CC01 digital keypad, press the Enter key (see figure below).



2. Wiring: Connect the driver's RJ45 communications interface to a PC via the RS-485



3. PLC function usage



■ When the external multifunctional input terminals (MI1–MI8) are in PLC Mode select bit0 (51) or PLC Mode select bit1 (52), and the terminal contact is closed or open, it will compulsorily switch to the PLC mode, and keypad switching will be ineffective. Corresponding actions are as follows:

PLC mode	DLC Made calcat hit1(F2)	DLC Made calest hit0 (F1)
Using KPC-CC01	PLC Mode select bit1(52)	PLC Mode select bit0 (51)
Disable	OFF	OFF
PLC Run	OFF	ON
PLC Stop	ON	OFF
Maintain previous state	ON	ON

# NOTE

- When input/output terminals (FWD REV MI1–MI8, MI10–15, Relay1–3, RY10–RY15, MO10–MO11,) are included in the PLC program, these input/output terminals will only be used by the PLC. As an example, when the PLC program controls Y0 during PLC operation (PLC1 or PLC2), the corresponding output terminal relay (RA/RB/RC) will operate in accordance with the program. At this time, the multifunctional input/output terminal setting will be ineffective. Because these terminal functions are already being used by the PLC, the DI DO AO in use by the PLC can be determined by looking at Pr.02-52, Pr.02-53, and Pr.03-30.
- When the PLC's procedures use special register D1040, the corresponding AO contact AFM1 will be occupied, and AFM2 corresponding to special register D1045 will have the same situation.
- Pr.03-30 monitors the state of action of the PLC function analog output terminal; bit0 corresponds to the AFM1 action state, and bit1 corresponds to the AFM2 action state.

# 16-3-2 I/O device explanation

#### Input devices:

Serial No.	X0	X1	X2	Х3	X4	X5	X6	X7	X10	X11	X12	X13	X14	X15	X16	X17
1	FWD	REV	MI1	MI2	MI3	MI4	MI5	MI6	MI7	MI8						
2											MI10	MI11	MI12	MI13	MI14	MI15
3											MI10	MI11	MI12	MI13		

1: Control I/O

2: Extension card: EMC-D611A (D1022=4)3: Extension card: EMC-D42A (D1022=5)

#### Output devices:


Serial No.	Y0	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y10	Y11	Y12	Y13	Y14	Y15	Y16	Y17
1	RY1	RY2	RY3													
2						MO10	MO11									
3						RY10	RY11	RY12	RY13	RY14	RY15					

1: Control I/O

2: Extension card: EMC-D42A (D1022=5)3: Extension card: EMC-R6AA (D1022=6)

#### RY1 / RY2 / RY3

#### RY10 / RY11 / RY12 / RY13 / RY14 / RY15





#### 16-3-3 Installation WPLSoft

Download and install WPLSoft editing software in Delta's website:

After completing installation, the WPLSoft program will be installed in the designated subfolder "C: \Program Files\Delta Industrial Automation\WPLSoft x.xx".

# 16-3-4 Program writing

Step 1: Click on the WPLSoft icon to start the editing software. (See figure 16-1)






Figure 16-1 (Left: WPLSoft icon; Right: Start WPLSoft)

Step 2: The WPLSoft editing window appears (see figure 16-2 below). When running WPLSoft for the first time, before "New file" has been used, only the "File (F)," "Communications (C)," View (V)," "Options (O)," and "Help (H)" columns will appear on the function toolbar.




Figure 16-2

After running WPLSoft for the second time, the last file edited will open and be displayed in the editing window. The following figure 16-3 provides an explanation of the WPLSoft editing software window:




Figure 16-3

Step 3: Click on the icon on the toolbar: opens new file (Ctrl+N), see figure 16-4 below



Figure 16-4

NOTE You can also find "New file (N) (Ctrl+N)" in the "File (F)", as shown in figure 16-5 below.



Figure 16-5

Step 4: The "Device settings" window will appear after clicking, see figure 16-6 below. You can now enter the project title and filename, and select the device and communication settings to be used.




Figure 16-6

Communications settings: Perform settings in accordance with the desired communications method. See figure 16-7 below.




Figure 16-7

Step 5: Press Confirm after completing settings and begin program editing. There are two program editing methods; you can choose whether to perform editing in the command mode or the ladder diagram mode (see figure 16-8 below).




Figure 16-8

In ladder diagram mode, you can perform program editing using the buttons on the function icon row (see figure 16-9 below).




Figure 16-9

#### **Basic Operation-Example**

Input the ladder diagram as the figure below. The following steps can be operated through the mouse or function key (F1–F12) on the keyboard.

Figure 16-10

Step 1: The following screen will appear after a new file is established:




Figure 16-11

Step 2: Click on the always-open switch icon or press the function key F1. After the name of the input device and the comment dialog box have appeared, the device name (such as "M"), device number (such as "10"), and input comments (such as "auxiliary contact") can be selected; press the OK button when finished (see figure 16-12 and 16-13 below).




Figure 16-12



Figure 16-13

Step 3: Click on the output coil icon or press function key F7. After the name of the input device and the comment dialog box have appeared, the device name (such as "Y"), device number (such as "0"), and input comments (such as "output coil") can be selected; press the OK button when finished (see figure 16-14 and 16-15 below).




Figure 16-14



Figure 16-15

Step 4: Press "ENTER" button, when the "Input Instructions" window appears, key in "END" in the field and press the OK button (see figure 16-16 and 16-17 below).




Figure 16-16




Figure 16-17

Step 5: Click on the Ladder diagram => Code" icon, which will compile the edited ladder diagram as a command program. After compiling, the number of steps will appear on the left side of the busbar (see figure 16-18 below).





Figure 16-18

# 16-3-5 Program download

After inputting a program using WPLSoft, select compile . After completing compilation, select the to download a program. WPLSoft will perform program download with the online PLC in the communications format specified in communications settings.

# 16-3-6 Program monitoring


While confirming that the PLC is in the Run mode, after downloading a program, click on in the communications menu and select start ladder diagram control (see figure below)



# 16-4 Basic principles of PLC ladder diagrams

# 16-4-1 Schematic diagram of PLC ladder diagram program scanning

Output results are calculated on the basis of the ladder diagram configuration (internal devices will have real-time output before results are sent to an external output point)



Repeated implementation

# 16-4-2 Introduction to ladder diagrams

Ladder diagrams comprise a graphic language widely applied in automatic control, and employs common electrical control circuit symbols. After a ladder diagram editor has been used to create a ladder pattern, PLC program designed is completed. The use of a graphic format to control processes is very intuitive, and is readily accepted by personnel who are familiar with electrical control circuit technology. Many of the basic symbols and actions in a ladder diagram comprise commonly seen electrical devices in conventional automatic control power distribution panels, such as buttons, switches, relays, timers, and counters.

Internal PLC devices: The types and quantities of internal PLC devices vary in different brands of products. Although these internal devices use the same names as conventional electrical control circuit elements such as relays, coils, and contacts, a PLC does not actually contain these physical devices, and they instead correspond to basic elements in the PLC's internal memory (bits). For instance, if a bit is 1, this may indicate that a coil is electrified, and if that bit is 0, it will indicate that the coil is not electrified. An N.O. contact (Normal Open, or contact a) can be used to directly read the value of the corresponding bit, and an N.C. contact (Normal Close, or contact b) can be used to obtain the inverse of the bit's value. Multiple relays occupy multiple bits, and 8 bits comprise one byte; two bytes comprise one word, and two words comprise a double word. When multiple relays are processing at the same time (such as addition / subtraction or displacement, etc.), a byte, word, or double word can be used. Furthermore, a PLC contains two types of internal devices: a timer and a counter. It not only has a coil, but can count time and numerical values. Because of this, when it is necessary to process some numerical values, these values are usually in the form of bytes, words, or double words.

The various internal devices in a PLC all account for a certain quantity of storage units in the PLC's storage area. When these devices are used, the content of the corresponding storage area is red in the form of bits, bytes, or words.

Introduction to the basic internal devices in a PLC

Device type	Description of Function
Input Relay	An input relay constitutes the basic unit of storage in a PLC's internal memory corresponding to an external input point (which serves as a terminal connecting with an external input switch and receiving external input signals). It is driven by external input signals, to which it assigns values of 0 or 1. A program design method cannot change the input relay status, and therefore cannot rewrite the corresponding basic units of an input relay, and WPLSoft cannot be used to perform compulsory ON / OFF actions. A relay's contacts (contacts a and b) can be used an unlimited number of times. An input relay with no input signal must be left idle and cannot be used for some other purpose.
	☑ Device indicated as: X0, X1, X7, X10, X11, etc. This device is expressed with the symbol "X," and a device's order is indicated with an octal number. Input point numbers are indicated in Section 16-8 I/O devices explanation.
Output Relay	An output relay constitutes the basic unit of storage in a PLC's internal memory corresponding to an external output point (which connects with an external load). It may be driven by an input relay contact, a contact on another internal device, or its own contacts. It uses one N.O. contact to connect with external loads or other contacts, and, like input contacts, can use the contact an unlimited number of times. An output relay with no input signal will be idle, but may be used an internal relay if needed.
	☑ Device indicated as: Y0, Y1, Y7, Y10, Y11, etc. This device is expressed with the symbol "Y," and a device's order is indicated with an octal number. Output point numbers are indicated in Section 16-8 I/O devices explanation.
Internal Relay	Internal relays have no direct connection with the outside. These relays are auxiliary relays inside a PLC. Their function is the same as that of an auxiliary (central) relay in an electrical control circuit: Each auxiliary relay corresponding to a basic unit of internal storage; they can be driven by input relay contacts, output relay contacts, and the contacts of other internal devices. An internal auxiliary relay's contact can also be used an unlimited number of times. Internal relays have no outputs to outside, and must output via an output point.
	☑ Device indicated as: M0, M1 to M799, etc. This device is expressed as the symbol "M," expressed, and its order is expressed as a decimal number.
Counter	A counter is used to perform counting operations. A count setting value (such as the number of pulses to be counted) must be assigned when a counter is used. A counter contains a coil, contact, and a counting storage device. When the coil goes from OFF to ON, this indicates that the counter has an input pulse, and one is added to its count. There are 16 bits that can be employed by the user.
	☑ Device indicated as: C0, C1 to C79, etc. This device is expressed as the symbol "C," expressed, and its order is expressed as a decimal number.
Timer	A timer is used to complete control of timing. The timer contains a coil, contact, and a time value register. When the coil is electrified, if the preset time is reached, the contact will be actuated (contact a will close, contact b will open), and the timer's fixed value be given by the set value. Timer has a regulated clock cycle (timing units: 100 ms). As soon as power to the coil is cut off, the contact will no longer be actuated (contact a will open, contact b will close), and the original timing value will return to zero.

Device type	Description of Function
	☑ Device indicated as: T0, T1 to T159, etc. The device is expressed as the symbol "T," and its order is expressed as a decimal number.
Data register	When a PLC is used to perform various types of sequence control and set time value and count value control, it most commonly perform data processing and numerical operations, and data registers are used exclusively for storage of data and various parameters. Each data register contains 16 bits of binary data, which means that it can store one word. Two data registers with adjacent numbers can be used to process double words.  Device indicated as: D0, D1 to D399, etc. The device is expressed as the symbol "D," and its order is expressed as a decimal number.

# Ladder diagram images and their explanation

Ladder diagram structures	Explanation of commands	Command	Using Device	
	N.O. switch, contact a	LD	X、Y、M、T、C	
	N.C. switch, contact b	LDI	X、Y、M、T、C	
	Series N.O.	AND	X、Y、M、T、C	
	Series N.C.	ANI	$X \cdot Y \cdot M \cdot T \cdot C$	
	Parallel N.O.	OR	X、Y、M、T、C	
	Parallel N.C.	ORI	$X \cdot Y \cdot M \cdot T \cdot C$	
	Positive edge-triggered switch	LDP	X · Y · M · T · C	
	Negative edge-triggered switch	LDF	X、Y、M、T、C	
<b>├</b> ── <b>├</b> ── <b>│↑├</b> ──	Positive edge-triggered series	ANDP	X、Y、M、T、C	
	Negative edge-triggered series	ANDF	X、Y、M、T、C	
	Positive edge-triggered parallel	ORP	X、Y、M、T、C	
	Negative edge-triggered parallel	ORF	X、Y、M、T、C	
	Block series	Block series ANB		
	Block parallel	ORB	N/A	
	Multiple outputs	MPS MRD MPP	N/A	

Ladder diagram structures	Explanation of commands	Command	Using Device
	Coil driven output commands	OUT	Υ·M
	Some basic commands, applications commands	Some basic commands Applications commands	
	Inverted logic	INV	N/A


# 16-4-3 Overview of PLC ladder diagram editing

The program editing method begins from the left busbar and proceeds to the right busbar (the right busbar is omitted when editing using WPLSoft). Continue to the next row after completing each row; there is a maximum of 11 contacts on each row. If this is not sufficient, a continuous line will be will be generated to indicate the continued connection and more devices can be added. A continuous series of numbers will be generated automatically and identical input points can be used repeatedly. See figure below:

The ladder diagram programming method involves scanning from the upper left corner to the lower right corner. The coils and applications command computing box are handled in the output, and the ladder diagram is placed on the farthest right. Taking the figure below as an example, we can gradually analyze the procedural sequence of the ladder diagram. The number in the upper right corner gives the sequential order.


#### Explanation of command sequence






Explanation of basic structure of ladder diagrams

LD (LDI) command: An LD or LDI command is given at the start of a block.



LDP and LDF have this command structure, but there are differences in their action state. LDP, LDF only act at the rising or falling edge of a conducting contact. (see figure below):




**AND (ANI) command:** A series configuration in which a single device is connected with one device or a block.




ANDP, ANDF also have structures like this, but their action occurs at the rising and falling edge.

**OR (ORI) command:** A single device is connected with one device or a block.




ORP, ORF also have identical structures, but their action occurs at the rising and falling edge.

**ANB command:** A configuration in which one block is in series with one device or block.



**ORB command:** A configuration in which one block is in parallel with one device or block.




In the case of ANB and ORB operations, if a number of blocks are connected, they should be combined to form a block or network from the top down or from left to right.

MPS, MRD, MPP commands: Branching point memory for multiple outputs, enabling multiple, different outputs. The MPS command begins at a branching point, where the so-called branching point refers to the intersection of horizontal and vertical lines. We have to rely on the contact status along a single vertical line to determine whether the next contact can give a memory command. While each contact is basically able to give memory commands, in view of convenience and the PLC's capacity restrictions, this can be omitted from some places when converting a ladder diagram. The structure of the ladder diagram can be used to judge what kinds of contact memory commands are used.

MPS can be distinguished by use of the "T" symbol; this command can be used consecutively for up to 8 times. The MRD command is read from branching point memory; because logic states along any one vertical line must be the same, in order to continue analysis of other ladder diagrams, the original contact status must be read.

MRD can be distinguished by use of the "-" symbol. The MPP command is read from the starting state of the uppermost branching point, and it is read from the stack (pop); because it is the final command along a vertical line, it indicates that the state of the vertical line can be concluded. MPP can be distinguished by use of the "-L" symbol. Although there should basically be no errors when using the foregoing analytical approach, the compiling program may sometimes omit identical state output, as shown in the following figure:




# 16-4-4 Commonly-used basic program design examples

#### Start, stop, and protection

Some applications may require a brief close or brief break using the buttons to start and stop equipment. A protective circuit, therefore, must be designed to maintain continued operation in these situations; this protective circuit may employ one of the following methods:


#### Example 1: Priority stop protective circuit

When the start N.O. contact X1 = ON, and the stop N.C. contact X2 = OFF, Y1 = ON; if X2 = ON at this time, coil Y1 will no longer be electrified, and this is therefore referred to as priority stop.



#### Example 2: Priority start protective circuit

When start N.O. contact X1 = ON, and the stop N.C. contact X2 = OFF, Y1 = ON, and coil Y1 will be electrified and protected. At this time, if X2 = ON, coil Y1 will still protect the contact and continue to be electrified, and this is therefore priority start.




Example 3: Setting (SET) and reset (RST) command protective circuit

The following figure shows a protective circuit composed of RST and SET commands.


Priority stop occurs when the RST command is placed after the SET command. Because the PLC executes programs from the top down, at the end of the program, the state of Y1 will indicate whether coil Y1 is electrified. When X1 and X2 are both actuated, Y1 will lose power, and this is therefore priority stop.

Priority start occurs when the SET command is placed after the RST command. When X1 and X2 are both actuated, Y1 will be electrified, and this is therefore priority start.

Top priority of stop




Top priority of start



#### Commonly-used control circuits


#### Example 4: Conditional control

X1 and X3 respectively starts and stops Y1; X2 and X4 respectively starts and stops Y2. All of these have protective circuits. Because Y1's N.O. contact is series connected with Y2's circuit, it becomes an AND condition for the actuation of Y2. The action of Y1 is therefore a condition for the action of Y2, and Y1 must be actuated before Y2 can be actuated.




Example 5: Interlocking control

The figure below shows an interlocking control circuit. Depending on which of the start contacts X1, X2 is valid first, the corresponding output Y1 or Y2 will be actuated, and when one is actuated, the other will not be actuated. This implies that Y1 and Y2 cannot be actuated at the same time (interlocking effect). Even if both X1 and X2 are valid at the same time, because the ladder diagram program is scanned from the top down, it is impossible for Y1 and Y2 to be actuated at same time. This ladder diagram assigns priority only to Y1.



#### Example 6: Sequence control


If the N.C. contact of Y2 in the interlocking control configuration of example 5 is put in series with the Y1 circuit, so that it is an AND condition for actuation of Y1 (see figure below), not only is Y1 a condition for the actuation of Y2 in this circuit, the actuation of Y2 will also stop the actuation of Y1. This configuration confirms the actuation order of Y1 and Y2.



Example 7: Oscillating circuit


Oscillating circuit with a period of  $\Delta T + \Delta T$ 

The figure below shows a very simple ladder diagram. When starting to scan the Y1 N.C. contact, because the Y1 coil has lost power, the Y1 N.C. contact will be closed. When the Y1 coil is then scanned, it will be electrified, and the output will be 1. When the Y1 N.C. contact is scanned in the scanning cycle, because Y1 coil is electrified, the Y1 N.C. contact will be open, the Y1 coil will then lose power, and the output will be 0. Following repeated scanning, the output of Y1 coil will have an oscillating waveform with a period of  $\Delta T$  (On) + $\Delta T$  (Off).




#### Oscillating circuit with a period of nT+ΔT

The program of the ladder diagram shown below uses timer T0 to control coil Y1's electrified time. After Y1 is electrified, it causes timer T0 to close during the next scanning cycle, which will cause the output from Y1 to have the oscillating waveform shown in the figure below. Here n is the timer's decimal setting value, and T is the clock cycle of the timer.




#### Example 8: Flashing circuit

The following figure shows an oscillating circuit of a type commonly used to cause an indicator light to flash or buzzers to buzz. It uses two timers to control the ON and OFF time of Y1 coil. Here n1, n2 are the timing set values of T1 and T2, and T is the clock cycle of the timer.




Example 9: Triggering circuit

In the figure below, a command consisting of the differential of the rising edge of X0 causes coil M0 to generate a single pulse for  $\Delta T$  (length of one scanning cycle), and coil Y1 is electrified during this scanning cycle. Coil M0 loses power during the next scanning cycle, N.C. contact M0 and N.C. contact Y1 are both closed. This causes coil Y1 to stay in an electrified state until there is another rising edge in input X0, which again causes the electrification of coil M0 and the start of another scanning cycle, while also causing coil Y1 to lose power, etc. The sequence of these actions can be seen in the figure below. This type of circuit is commonly used to enable one input to perform two actions in alternation. It can be seen from the time sequence in the figure below that when input X0 is a square wave signal with a period of T, the output of coil Y1 will be a square wave signal with a period of 2T.




Example 10: Delay circuit

When input X0 is ON, the timer T10 is in no power status because the corresponding N.C. contact is OFF, and the output coil Y1 is electrified. T10 receives power and begins timing only after input X0 is OFF, and the output coil Y1 is delayed for 100 sec. (K1000  $\times$  0.1 sec. = 100 sec.) before losing power; refer to the sequence of actions in the figure below.




Example 11: The open / close delay circuit is composed of two timers; output Y4 has a delay whether the input X0 is ON or OFF.



Example 12: Extended timing circuit

In the circuit in the figure on the left, the total delay time from the moment input X0 closes to the time output Y1 is electrified is  $(n1 + n2) \times T$ , where T is the clock cycle. Timers: T11, T12; clock cycle: T.



# 16-5 Various PLC device functions

Item	Specifications	Notes
Algorithmic control	Program stored internally, alternating	
method	back-and-forth scanning method	
Input / output control method	When it starts again after ending (after execution to the END command), the input/output has an immediate refresh command	
Algorithmic processing speed	Basic commands (several μs);	Applications command (1-several tens of µs)
Programming language	Command + ladder diagram	
Program capacity	10000 steps	
Input / output terminal	Input (X): 10, output (Y): 3	This number of contacts constitutes CP2000 input / output contacts; other devices have different correspondences

Туре	Device	I	tem	Range		Function		
	Х	External input	relav	X0–X17, 16 points, octal	Total	Corresponds to		
		External input	lolay	number	32	external input point		
	Υ	External outpu	t relav	Y0-Y17, 16 points, octal	points	Corresponds to		
		'		number		external output point		
	М	Auxiliary	General Use	M0–M799, 800 points	Total 880	Contact can switch ON / OFF within the		
	IVI	Relay	Special purpose	M1000–M1079, 80 points	points	program		
						Timers referred to by		
Relay bit					Total	the TMR command;		
form	Т	Timer	100ms timer	T0-T159, 160 points	160	contact of the T with the		
				·	points	same number will go On when the time is		
						reached		
						Counter referred to by		
					Total	the CNT command;		
	С	Counter	16-bit counter, general use	C0–C79, 80 points	Total 80	contact of the C with		
	C			C0-C79, 80 points	points	the same number will		
					points	go ON when the count		
						is reached		
	Т	Current timer \	value.	TO T150 160 points		The contact will be ON when the time is		
			/alue	T0–T159, 160 points		reached		
						The counter contact will		
Register	С	Current counte	er value	C0-C79, 16-bit counter 80	come ON when the			
word data				·	count is reached			
Word data			Used to maintain	D0-D399, 400 points	<b>.</b>			
	6	Data	power OFF	D0-D399, 400 points	Total 1400	Used as data storage		
	D	Register	Special purpose	D1000-D1199, 200 points	points	memory area		
			opeciai purpose	D2000-D2799, 800 points	•			
	K	Decimal	Single-byte	Setting Range: K-32,768-k				
Constant		Boomia	Double-byte	Setting Range: K-2,147,48		(2,147,483,647		
00110101111	Н	Hexadecimal	Single-byte	Setting Range:H0000-HFF				
Serial communications port (program write/read)				Setting Range: H00000000—HFFFFFFF				
Serial col	mmunica	Input/output	gram write/read)	RS-485/keypad port Built-in three analog inputs and two analog outputs				
			Optional					
	•	sion module	Accessories	EMC-D42A; EMC-R6AA; EMC-D611A				
Comm		n Expansion	Optional	EMC-COP01 (CANopen)				
	Modu	ile	Accessories					


#### 16-5-1 Introduction to device functions

# Input/output contact functions

Input contact X functions: Input contact X is connected with an input device, and reads input signals entering the PLC. The number of times that contact a or b of input contact X used in the program is not subject to restrictions. The ON / OFF state of input contact X will change as the input device switches ON and OFF; a peripheral device (WPLSoft) cannot be used to force contact X On or Off.

## Output contact Y functions

The job of output contact Y is to send an ON / OFF signal to drive the load connected with output contact Y. Output contacts consist of two types: relays and transistors. While number of times that contact a or b of each output contact Y used in the program is not subject to restrictions, it is recommended that the number of output coil Y be used only once in a program, otherwise the right to determine the output state when the PLC performs program scanning will be assigned to the program's final output Y circuit.



The output of Y0 will be decided by circuit **2**, i.e. decided by On/Off of X10.

# Numerical value, constant [K]/ [H]

Constant	Single-byte	K	Decimal	K-32,768–K32,767
	Double-byte		Decimal	K-2,147,483,648-K2,147,483,647
	Single-byte	Н	Hexadecimal	H0000-HFFFF
	Double-byte			H00000000-HFFFFFFF


The PLC can use five types of numerical values to implement calculations based on its control tasks; the following is an explanation of the missions and functions of different numerical values.

#### Binary Number, BIN

The PLC's numerical operations and memory employ binary numbers. Binary nibbles and relevant terms are explained as follows:

bit	bits are the fundamental units of binary values, and have a state of either 1 or 0
Nibble	Comprised of a series of 4 bits (such as b3-b0); can be used to express a
Nibble	one-nibble decimal number 0–9 or hexadecimal number: 0–F.
Puto	Comprised of a series of two nibbles (i.e. 8 bits, b7–b0); can express a
Byte	hexadecimal number: 00–FF.
Word	Comprised of a series of two bytes (i.e. 16 bits, b15–b0); can express a
vvord	hexadecimal number with four nibbles: 0000–FFFF.
Double Word	Comprised of a series of two words (i.e. 32 bits, b31–b0); can express a
Double Word	hexadecimal number with eight nibbles: 00000000–FFFFFFF

Relationship between bits, digits, nibbles, words, and double words in a binary system (see figure below):



#### Octal Number, OCT

The external input and output terminals of a DVP-PLC are numbered using octal numbers

Example: External input: X0–X7, X10–X17... (Device number table);

External output: Y0–Y7, Y10–Y17... (Device number table)

#### Decimal Number, DEC

Decimal numbers are used for the following purposes in a PLC system:

- ☐ The setting values of timer T or counter C, such as TMR C0 K50. (K constant)
- ☑ The numbers of devices including M, T, C, or D, such as M10 or T30. (device number)
- ☑ Used as an operand in an application command, such as MOV K123 D0. (K constant)

#### Binary Code Decimal, BCD

Uses one nibble or 4 bits to express the data in a decimal number; a series of 16 bits can therefore express a decimal number with 4 nibbles. Chiefly used to read the input value of a fingerwheel numerical switch input or output a numerical value to a seven-segment display driver.

#### Hexadecimal Number, HEX

Applications of hexadecimal numbers in a PLC system: Used as operands in application commands, such as MOV H1A2B D0. (H constant)

#### Constant K

Decimal numbers are usually prefixed with a "K" in a PLC system, such as K100. This indicates that it is a decimal number with a numerical value of 100.

Exceptions: K can be combined with bit device X, Y, M, or S to produce data in the form of a nibble, byte, word, or double word, such as in the case of K2Y10 or K4M100. Here K1 represents a 4-bit combination, and K2-K4 variously represent 8-, 12-, and 16-bit combinations.

#### Constant H

Hexadecimal numbers are usually prefixed with the letter "H" in a PLC system, such as in the case of H100, which indicates a hexadecimal number with a numerical value of 100.

# Functions of auxiliary relays

Like an output relay Y, an auxiliary relay M has an output coil and contacts a and b, and the number of times they can be used in a program is unrestricted. Users can use an auxiliary relay M to configure the control circuit, but cannot use it to directly drive an external load. Auxiliary relays have the following two types of characteristics:

Ordinary auxiliary relays: Ordinary auxiliary relays will all revert to the OFF state if a power outage occurs while the PLC is running, and will remain in the OFF state if power is again turned down.

Special purpose auxiliary relays: Each special purpose auxiliary relay has its own specific use. Do not use any undefined special purpose auxiliary relays.

# Timer functions

Timers take 100 ms as their timing units. When the timing method is an upper time limit, when the current timer value = set value, power will be sent to the output coil. Timer setting values consist of decimal K values, and the data register D can also serve as a setting value.

Actual timer setting time = timing units × set value

#### Counter features

Item	16-bit counter
Type	General Type
CT Direction:	Score:
Setting	0–32,767
Designation of set value	Constant K or data register D
Change in current value	When the count reaches the set value, there is no longer a count
Output contact	When the count reaches the set value, the contact comes On and stays On
Reset	The current value reverts to 0 when an RST command is executed, and the contact reverts to Off
Contact actuation	All are actuated after the end of scanning

#### **Counter functions**


When a counter's counting pulse input signal goes OFF→ON, if the counter's current value is equal to the set value, the output coil will become ON. The setting value will be a decimal K values, and the data register D can also serve as a setting value.

#### 16-bit counter C0-C79:


- ☑ 16-bit counter setting range: K0–K32,767. (when K0 and K1 are identical, the output contact will immediately be ON during the first count.)
- ☐ The current counter value will be cleared from an ordinary counter when power is shut off to the PLC.
- ☑ If the MOV command or WPLSoft is used to transmit a value greater than the set value to the C0 current value register, when the next X1 goes from OFF→ON, the C0 counter contact will change to On, and the current value will change to the set value.
- A counter's setting value may be directly set using a constant K or indirectly set using the value in register D (not including special data registers D1000–D1199 or D2000–D2799).
- ☑ If the set value employs a constant K, it may only be a positive number; the set value may be either a positive or a negative number if the value in data register D is used. The current counter value will change from 32,767 to -32,768 as the count continues to accumulate.

#### Chapter 16 PLC Function Applications | CP2000

#### Example



- When X0 = ON and the RST command is executed, the current value of C0 will revert to 0, and the output contact will revert to OFF.
- When X1 changes from OFF→ON, the current value of the counter will execute an increase (add one).
- 3. When the count of counter C0 reaches the set value K5, the contact C0 will come ON, and the current value of C0 = set value = K5. Afterwards, signal C0 triggered by X1 cannot be received, and the current value of C0 will remain K5.



# 16-5-2 Introduction to special relay functions (special M)

R/W items: RO: read only function; RW: read and write function

Special M	Description of Function	R/W *
M1000	Operates monitor N.O. contact (contact a). N.O. while RUN, contact a. This contact is ON while in the RUN state.	RO
M1001	Operates monitor N.C. contact (contact b). N.C. while RUN, contact b. This contact is OFF while in the RUN state.	RO
M1002	Initiates a forward (the instant RUN is ON) pulse. Initial pulse, contact a. Produces a forward pulse the moment RUN begins; its width = scan cycle	RO
M1003	Initiates a reverse (the instant RUN is OFF) pulse. Initial pulse, contact a. Produces a reverse pulse the moment RUN ends; the pulse width = scan cycle	RO
M1004	Reserved	RO
M1005	Driver malfunction instructions	RO
M1006	Converter has no output	RO
M1007	Driver direction FWD(0)/REV(1)	RO
M1008		
M1010	40 1 1 5 001/5 055	
M1011	10 ms clock pulse, 5ms ON / 5ms OFF	RO
M1012	100 ms clock pulse, 50ms On / 50ms Off	RO
M1013	1 sec. clock pulse, 0.5s On / 0.5s Off	RO
M1014	1 min. clock pulse, 30s On / 30s Off	RO
M1015	Frequency attained (when used together with M1025)	RO
M1016	Parameter read/write error	RO
M1017	Parameter write successful	RO
M1018		
	Motor drive warning indicator	RO
	Zero flag	RO
M1021	Borrow flag	RO
	Carry flag	RO
	Divisor is 0	RO
M1024	(01)	
M1025	Driver frequency = set frequency (ON) Driver frequency = 0(OFF)	RW
M1026	Driver operating direction FWD(OFF) / REV(ON)	RW
M1027	Driver Reset	RW
M1028		
M1029		
M1030		
M1031	Compulsory setting of the current PID integral value equal to D1019 (0 change, 1 valid)	RW
M1032	Compulsory definition of FREQ command after PID control	RW
M1033		
M1034	Initiates CANopen real-time control	RW
M1035	Initiates internal communications control	RW
M1036	Ignore calendar error	RW
M1037	<b></b>	
M1038		
M1039		
M1040	Excitation (Servo ON)	RW
M1041		
M1042	Quick stop	RW
M1043		
M1044	Pause (Halt)	RW

# Chapter 16 PLC Function Applications | CP2000

Special	Description of Function	R/W *
M	·	
M1045		
   N44047	<del></del>	
M1047		
M1048	<del></del>	
M1049	<del></del>	
M1050	 	
M1051		
M1052	Lock frequency (lock, frequency locked at the current operating frequency)	RW
M1053		
M1054		
M1055		
M1056	Excitation ready (Servo ON Ready)	RO
M1057	<b></b>	
M1058	On Quick Stopping	RO
M1059	CANopen Master setting complete	RO
M1060	CANopen Currently initializing slave station	RO
M1061	CANopen Slave station initialization failure	RO
M1062		
M1063		
M1064		
M1065	Read/write CANOpen data time out	RO
M1066	Read/write CANopen data complete	RO
M1067	Read/write CANopen data successful	RO
M1068	Calendar calculation error	RO
M1069		
M1070		
M1071		
M1072		
1		
M1075		
M1076	Calendar time error or refresh time out	RO
M1077	485 Read/write complete	RO
	485 Read-write error	RO
M1079	485 Communications time out	RO
	OFF (refer to parameter descriptions for Pr.00-29)	RO
M1091	HAND (refer to parameter descriptions for Pr.00-29)	RO
M1092	AUTO (refer to parameter descriptions for Pr.00-29)	RO
M1100	LOCAL (refer to parameter descriptions for Pr.00-29)	RO
M1101	REMOTE (refer to parameter descriptions for Pr.00-29)	RO
M1168	SMOV BCD and BIN mode switch	RW
M1260	PLC PID1 Enable	RW
	PLC PID1 Positive integral value limit	RW
	PLC PID2 Enable	RW
M1272	PLC PID2 Positive integral value limit	RW
<b>– . –</b>	1	

# 16-5-3 Introduction to special register functions (special D)

Special	Description of Function	R/W *
D	Becomption of Function	10,00
D1000		
	Device system program version	RO
	Program capacity	RO
D1003	Total program memory content	RO
D1004		
D4000	<del></del>	
D1009	Ourse at a continue (our ite of a continue)	D0
	Current scan time (units: 0.1 ms)	RO
	Minimum scan time (units: 0.1 ms)	RO
D1012	Maximum scan time (units: 0.1 ms)	RO
D1013		
D1017	<del></del>	
	Current integral value	RO
	Current integral value Compulsory setting of PID I integral	RW
	Output frequency (0.00–600.00Hz)	RO
	Output frequency (0.00–600.00Hz) Output current (####.#A)	RO
D1021	Al AO DI DO Expansion card number	KO
	0: No extension card	
	4: AC input card ( 6 in ) (EMC-D611A)	
D1022	5: Digital I/O Card ( 4 in 2 out ) (EMC-D42A)	RO
	6: Relay card( 6 out ) (EMC-R6AA)	
	11: Analog I/O card (2 in 2 out) (EMC-A22A)	
	Communication expansion card number	
	0: No extension card	
	1: DeviceNet Slave (CMC-DN01)	
D4000	2: Profibus-DP Slave (CMC-PD01)	ПО
D1023	3: CANopen Slave (EMC-COP01)	RO
	4: Modbus-TCP Slave	
	5: EtherNet/IP Slave (CMC-EIP01)	
	12: PROFINET Slave (CMC-PN01)	
D1024		
	<b> </b>	
D1026		
	PID calculation frequency command (frequency command after PID calculation)	RO
	AVI1value (0.00–100.00%)	RO
	ACI value (0.0–100.00%)	RO
	AVI2 value (0.00–100.00%)	RO
D1031	C series: extension card Al10 (0.0–100.0%)	RO
D1032	C series: extension card AI11 (0.0–100.0%)	RO
D1033		
D1025	<del></del>	
D1035	Conve fault hit	DO.
	Servo fault bit	RO
	Driver output frequency	RO RO
	DC bus voltage Output voltage	RO
	Analog output value AFM1 (-100.00–100.00%)	RW
	C series: extension card AO10 (0.0–100.0%)	RW
D1041	C series: extension card AO10 (0.0–100.0%)  C series: extension card AO11 (0.0–100.0%)	RW
	Can be user-defined (will be displayed on panel when Pr.00-04 is set as 28;	RW
D1043	display method is C xxx)	1700
D1044		_
	Analog output value AFM2 (-100.00–100.00%)	RW
טדטו ט	p maiog carpar value / 1 mz (=100.00-100.00/0)	1 7 4 4


Special D	Description of Function	R/W *
D1046		
1040		
D1049		
	Actual Operation Mode	
D1050	0: Speed	RO
D1051		
D1051	<u></u>	
D1052	<u></u>	
D1053	<u></u>	
D1055		
D1056	<u></u>	
D1057		
D1057		
D1058		
D1039	Operation Mode setting	
D1060	0: Speed	RW
D1061	485 COM1 communications time out time (ms)	RW
	Torque command (torque limit in speed mode)	RW
	Year (Western calendar) (display range 2000-2099) (must use KPC-CC01)	RO
D1064	Week (display range 1-7) (must use KPC-CC01)	RO
D1065	Month (display range 1-12) (must use KPC-CC01)	RO
	Day (display range 1-31) (must use KPC-CC01)	RO
	Hour (display range 0-23) (must use KPC-CC01)	RO
D1068	Minute (display range 0-59) (must use KPC-CC01)	RO
D1069	Second (display range 0-59) (must use KPC-CC01)	RO
	Target frequency	RO
	Target frequency (must be operating)	RO
D1102	Reference frequency	RO
D1103	<del></del>	
D1104	<del></del>	
D1105	<del></del>	
D1106		
	π(Pi) Low word	RO
	π(Pi) High word	RO
D1109	Random number	RO
D1110	Internal node communications number (set number of slave stations to be controlled)	RW
D1111		
D1112		
D1113	<del></del>	
	Numbering of the operating motors:	
D1114	1: Motor 1	RO
	2: Motor 2	
	Internal node synchronizing cycle (ms)	RO
D1116	Internal node error (bit0 = Node 0, bit1 = Node 1,bit7 = Node 7)	RO
D1117	Internal node online correspondence (bit0 = Node 0, bit1 = Node 1,bit7 = Node 7)	RO
D1118	ļ	
D1119		
	Internal node 0 control command	RW
D1121	Internal node 0 mode	RW
D1122	Internal node 0 reference command L	RW
	Internal node 0 reference command H	RW
D1124		
D1125		
		•

Special		
D	Description of Function	R/W *
_	Internal node 0 status	RO
	Internal node 0 reference status L	RO
D1128	Internal node 0 reference status H	RO
D1129	<b></b>	
D1130	Internal node 1 control command	RW
D1131	Internal node 1 mode	RW
D1132	Internal node 1 reference command L	RW
D1133	Internal node 1 reference command H	RW
D1134		
D1135		
D1136	Internal node 1 status	RO
	Internal node 1 reference status L	RO
	Internal node 1 reference status H	RO
D1139		
	Internal node 2 control command	RW
	Internal node 2 mode	RW
	Internal node 2 reference command L	RW
	Internal node 2 reference command H	RW
D1144		
D1145		
	Internal node 2 status	RO
	Internal node 2 reference status L	RO
	Internal node 2 reference status H	RO
D1149	Internal made O control common d	
	Internal node 3 control command	RW
	Internal node 3 mode	RW
	Internal node 3 reference command L Internal node 3 reference command H	RW RW
D1153	Internal flode 3 reference confinant	KVV
D1154		
	Internal node 3 status	RO
	Internal node 3 reference status L	RO
	Internal node 3 reference status H	RO
D1159		
	Internal node 4 control command	RW
D1161	Internal node 4 mode	RW
	Internal node 4 reference command L	RW
D1163	Internal node 4 reference command H	RW
D1164		
D1165		
	Internal node 4 status	RO
D1167	Internal node 4 reference status L	RO
D1168	Internal node 4 reference status H	RO
D1169		
	Internal node 5 control command	RW
	Internal node 5 mode	RW
	Internal node 5 reference command L	RW
D1173	Internal node 5 reference command H	RW
D1174	<del></del>	RW
D1175	<del></del>	
	Internal node 5 status	
D1177	Internal node 5 reference status L	RO
D1178	Internal node 5 reference status H	RO
D1179		
D1180	Internal node 6 control command	RW

Special D	Description of Function	R/W *
D1181	Internal node 6 mode	RW
D1182	Internal node 6 reference command L	RW
D1183	Internal node 6 reference command H	RW
D1184		
D1185	<b></b>	
D1186	Internal node 6 status	RO
D1187	Internal node 6 reference status L	RO
D1188	Internal node 6 reference status H	RO
D1189	<b></b>	
D1190	Internal node 7 control command	RW
D1191	Internal node 7 mode	RW
D1192	Internal node 7 reference command L	RW
D1193	Internal node 7 reference command H	RW
D1194	<b></b>	
D1195		
D1196	Internal node 7 status	RO
D1197	Internal node 7 reference status L	RO
D1198	Internal node 7 reference status H	RO
D1199		
D1560	Motor drive warning code	RO

	violor drive warriing oode		110
Special D	Description of Function	Default	R/W*
D1200	PID1 mode:	0	DW
D 1200	0: Basic mode	0	RW
	PID1 target selection:		
	0: Refer to D1202		
D1201	1: AVI1	0	RW
	2: ACI		
	3: AVI2		
D1202	PID1 target value (0.00%–100.00%)	5000	RW
	PID1 feedback selection		
	0: Refer to D1204	_	
D1203	1: AVI1	1	RW
	2: ACI		
D4004	3: AVI2		DIA
D1204	PID1 feedback value (0.00%–100.00%)	0	RW
D1205	PID1 P value (decimal point 2)	10	RW
D1206	PID1 I value (decimal point 2)	1000	RW
D1207	PID1 D value (decimal point 2)	0	RW
D1209	Max. limit of PID1	10000	RW
D1215	Counting value of PID1 (decimal point 2)	0	RO
D1220	PID2 mode:	0	RW
D1220	0: Basic mode	0	IXVV
	PID2 target selection:		
	0: Refer to D1202		
D1221	1: AVI1	0	RW
	2: ACI		
	3: AVI2		
D1222	PID2 target value (0.00%–100.00%)	5000	RW
	PID2 feedback selection		
D1223	0: Refer to D1204		
	1: AVI1	1	RW
	2: ACI		
	3: AVI2		

Special D	Description of Function	Default	R/W*
D1224	PID2 feedback value (0.00%–100.00%)	0	RW
D1225	PID1 P value (decimal point 2)	10	RW
D1226	PID2 I value (decimal point 2)	1000	RW
D1227	PID2 D value (decimal point 2)	0	RW
D1229	Max. limit of PID2	10000	RW
D1235	Counting value of PID2 (decimal point 2)	0	RO



The following is CANopen Master's special D (can be written in only with PLC in Stop state)

CP2000 does not have torque and position mode. As CANopen master, however, CP2000 can issue torque and position commands to CANopen slaves.

n=0-7

Special D	Description of Function	PDO Map	Power off Memory	Default:	R/W
D1070	Channel opened by CANopen initialization (bit0=Machine code0)	NO	NO	0	R
D1071	Error channel occurring in CANopen initialization process (bit0=Machine code0)	NO	NO	0	R
D1072	Reserved	-	-		-
D1073	CANopen break channel (bit0=Machine code0)	NO	NO		R
D1074	Error code of master error 0: No error 1: Slave station setting error 2: Synchronizing cycle setting error (too small)	NO	NO	0	R
D1075	Reserved	-	-		-
D1076	SDO error message (main index value)	NO	NO		R
D1077	SDO error message (secondary index value)	NO	NO		R
D1078	SDO error message (error code)	NO	NO		R
D1079	SDO error message (error code)	NO	NO		R
D1080	Reserved	-	-		-
D1081   D1086	Reserved	-	-		-
D1087   D1089	Reserved	-	-		-
D1090	Synchronizing cycle setting	NO	YES	4	RW
D1091	Sets slave station On or Off (bit0-bit7 correspond to slave stations number 0-7)	NO	YES	FFFFH	RW
D1092	Delay before start of initialization	NO	YES	0	RW
D1093	Break time detection	NO	YES	1000ms	RW
D1094	Break number detection	NO	YES	3	RW
D1095   D1096	Reserved	-	-		-

### Chapter 16 PLC Function Applications | CP2000

Special D	Description of Function	PDO Map	Power off Memory	Default:	R/W
D1097	Corresponding real-time transmission type (PDO) Setting range: 1–240	NO	YES	1	RW
D1098	Corresponding real-time receiving type (PDO) Setting range: 1–240	NO	YES	1	RW
D1099	Initialization completion delay time Setting range: 1 to 60000 sec	NO	YES	15 sec.	RW
D2000+100*n	Station number n of slave station Setting range: 0–127 0: No CANopen function	NO	YES	0	RW

The CP2000 supports 8 slave stations under the CANopen protocol; each slave station occupies 100 special D locations; stations are numbered 1–8, total of 8 stations.

<b>Explanation of</b>	Slave station no. 1	D2000	Node ID
slave station		D2001	Slave station no. 1 torque restrictions
number			
nambo.		D2099	Address 4(H) corresponding to receiving
			channel 4
	Slave station no. 2	D2100	Node ID
		D2101	Slave station no. 2 torque restrictions
		1	I
		D2 <sup>1</sup> 99	Address 4(H) corresponding to receiving
		DZ 199	
			channel 4
	Slave station no. 3	D2200	Node ID
		D2201	Slave station no. 3 torque restrictions
			i i
		D2299	Address 4(H) corresponding to receiving
			channel 4
		Û	
	Slave station no. 8	D2700	Node ID
	Slave Station no. o		
		D2701	Slave station no. 8 torque restrictions
		D2799	Address 4(H) corresponding to receiving
			channel 4
			_

### 1. The range of n is 0–7

# 2. ●Indicates PDOTX, ▲Indicates PDORX; unmarked special D can be refreshed using the CANFLS command

Special D	Description of Function	Default:	R/W
D2000+100*n	Station number n of slave station Setting range: 0–127 0: No CANopen function	0	RW
D2002+100*n	Manufacturer code of slave station number n (L)	0	R
D2003+100*n	Manufacturer code of slave station number n (H)	0	R
D2004+100*n	Manufacturer's product code of slave station number n (L)	0	R
D2005+100*n	Manufacturer's product code of slave station number n (H)	0	R

### Basic definitions

Special D	Description of Function	Default:	PDO Mapping		2		ault: 4	R/W
D2006+100*n	Communications break handling method of slave station number n	0	6007H-0010H					RW
D2007+100*n	Error code of slave station number n error	0	603FH-0010H					R
D2008+100*n	Control word of slave station number n	0	6040H-0010H	•		•	•	RW
D2009+100*n	Status word of slave station number n	0	6041H-0010H	lack		lack	<b>A</b>	R
D2010+100*n	Control mode of slave station number n	2	6060H-0008H					RW
D2011+100*n	Actual mode of slave station number n	2	6061H-0008H					R

## Velocity Control

### Slave station number n=0-7

Chaoial D	Description of Function	Default:	PDO		PDO Default:				
Special D	Description of Function	Delault:	Mapping	1	2	3	4	R/W	
D2001+100*n	Torque restriction on slave station number n	0	6072H-0010H					RW	
D2012+100*n	Target speed of slave station number n	0	6042H-0010H	•				RW	
D2013+100*n	Actual speed of slave station number n	0	6043H-0010H	lack				R	
D2014+100*n	Error speed of slave station number n	0	6044H-0010H					R	
D2015+100*n	Acceleration time of slave station number n	1000	604FH-0020H					R	
D2016+100*n	Deceleration time of slave station number n	1000	6050H-0020H					RW	

## 20XXH correspondences: MI / MO / AI / AO

### Slave station number n=0-7

Special D	Description of Function	Default:	PDO	PE	00	Defa	ault:	R/W
Special D	Description of Function	Delault.	Mapping	1	2	3	4	FX/ V V
D2026+100*n	MI status of slave station number n	0	2026H-0110H		$\color{red} \blacksquare$			RW
D2027+100*n	MO setting of slave station number n	0	2026H-4110H		•			RW
D2028+100*n	Al1 status of slave station number n	0	2026H-6110H		$\color{red} \blacksquare$			RW
D2029+100*n	Al2 status of slave station number n	0	2026H-6210H		$\color{red}\blacktriangle$			RW
D2030+100*n	Al3 status of slave station number n	0	2026H-6310H		$\color{red} \blacksquare$			RW
D2031+100*n	AO1 status of slave station number n	0	2026H-A110H		•			RW
D2032+100*n	AO2 status of slave station number n	0	2026H-A210H		•			RW
D2033+100*n	AO3 status of slave station number n	0	2026H-A310H		•			RW

## PDO reflection length setting:

Special D	Description of Function	Default:	R/W
D2034+100*n	Real-time transmission setting of slave station number n	000AH	RW
D2067+100*n	Real-time reception setting of slave station number n	0000H	RW

## 16-5-4 PLC Communication address

Device	Range	Туре	Address (Hex)
Х	00-37 (Octal)	bit	0400-041F
Υ	00-37 (Octal)	bit	0500-051F
Т	00–159	bit/word	0600-069F
M	000–799	000–799 bit	
M	1000–1079	bit	0BE8-0C37
С	0–79	0–79 bit/word 0E00–	
D	00–399	word	1000–118F
D 1000–1198		word	13E8-144B
D	2000–2799	word	17D0-1AEF

#### Command code that can be used

Function Code	Description of Function	Function target
01	Coil status read	Y, M, T, C
02	Input status read	X,Y,M,T,C
03	Read single unit of data	T,C,D
05	Compulsory single coil status change	Y,M,T,C
06	Write single unit of data	T,C,D
0F	Compulsory multiple coil status change	Y,M,T,C
10	Write multiple units of data	T,C,D



When PLC functions have been activated, the CP2000 can match PLC and driver parameters; this method employs different addresses, drivers (default station number is 1, PLC sets station number as 2)

## 16-6 Introduction to the Command Window

## 16-6-1 Overview of basic commands

## Ordinary commands

Command code	Function	OPERAND	Execution speed (us)
LD	Load contact a	$X \cdot Y \cdot M \cdot T \cdot C$	8.0
LDI	Load contact b	$X \cdot Y \cdot M \cdot T \cdot C$	0.8
AND	Connect contact a in series	$X \cdot Y \cdot M \cdot T \cdot C$	0.8
ANI	Connect contact b in series	$X \cdot Y \cdot M \cdot T \cdot C$	0.8
OR	Connect contact a in parallel	$X \cdot Y \cdot M \cdot T \cdot C$	0.8
ORI	Connect contact b in parallel	$X \cdot Y \cdot M \cdot T \cdot C$	0.8
ANB	Series circuit block	N/A	0.3
ORB	Parallel circuit block	N/A	0.3
MPS	Save to stack	N/A	0.3
MRD	Stack read (pointer does not change)	N/A	0.3
MPP	Read stack	N/A	0.3

## Output command

Command code	Function	OPERAND	Execution speed (us)
OUT	Drive coil	Y · M	1
SET	Action continues (ON)	Y · M	1
RST	Clear contact or register	Y · M · T · C · D	1.2

## Timer, counter

Command code	Function	OPERAND	Execution speed (us)
TMR	16-bit timer	T-K or T-D commands	1.1
CNT	16-bit counter	C-K or C-D (16-bit)	0.5

### Main control command

Command code	Function	OPERAND	Execution speed (us)
MC	Common series contact connection	N0~N7	0.4
MCR	Common series contact release	N0~N7	0.4

## Contact rising edge/falling edge detection command

Command code	Function	OPERAND	Execution speed (us)
LDP	Start of forward edge detection action	$X \cdot Y \cdot M \cdot T \cdot C$	1.1
LDF	Start of reverse edge detection action	$X \cdot Y \cdot M \cdot T \cdot C$	1.1
ANDP	Forward edge detection series connection	$X \cdot Y \cdot M \cdot T \cdot C$	1.1
ANDF	Reverse edge detection series connection	$X \cdot Y \cdot M \cdot T \cdot C$	1.1
ORP	Forward edge detection parallel connection	$X \cdot Y \cdot M \cdot T \cdot C$	1.1
ORF	Reverse edge detection parallel connection	$X \cdot Y \cdot M \cdot T \cdot C$	1.1

## Upper/lower differential output commands

Command code	Function	OPERAND	Execution speed (us)
PLS	Upper differential output	Υ·M	1.2
PLF	Lower differential output	Υ·M	1.2

#### Stop command

Command code	Function	OPERAND	Execution speed (us)
END	Program conclusion	N/A	0.2


#### Other commands


Command code	Function	OPERAND	Execution speed (us)
NOP	No action	N/A	0.2
INV	Inverse of operation results	N/A	0.2
Р	Index	Р	0.3

## 16-6-2 Detailed explanation of basic commands

Command			Fund	ction		
LD	Load contact a	3				
0,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_

The LD command is used for contact a starting at the left busbar or contact a starting at a contact circuit block; its function is to save current content and save the acquired contact status in the cumulative register.






Command code: Description:

LD	X0	Load Contact a of X0
AND	X1	Create series connection to contact a of X1
OUT	Y1	Drive Y1 coil

Command	Function					
LDI	Load contact b	)				
0,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399
Operand	✓	✓	✓	✓	✓	_


The LDI command is used for contact b starting at the left busbar or contact b starting at a contact circuit block; its function is to save current content and save the acquired contact status in the cumulative register.

Example




Command code: Description:

LDI	X0	Load Contact b of X0
AND	X1	Create series connection to contact a of X1
OUT	Y1	Drive Y1 coil



current status of the designated series contact and logical operation results before contact in order to perform "AND" operation; saves results in cumulative register.





Comman	d code:	Description:
LDI	X1	Load Contact b of X1
AND	Х0	Create series connection to contact a of X0
OUT	Y1	Drive Y1 coil

Command	Function						
ANI	Connect conta	onnect contact b in series					
Onerend	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399	
Operand	✓	✓	✓	✓	✓	_	

Explanation

The ANI command is used to create a series connection to contact b; its function is to first read current status of the designated series contact and logical operation results before contact in order to perform "AND" operation; saves results in cumulative register.





Command code: Description:

LD X1 Load Contact a of X1 Create series ANI **X0** connection to contact b of X0

Drive Y1 coil OUT Y1


Command	Function						
OR	Connect conta	onnect contact a in parallel					
0	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399	
Operand	✓	✓	✓	✓	✓	_	

Explanation

The OR command is used to establish a parallel connection to contact a; its function is to first read current status of the designated series contact and logical operation results before contact in order to perform "OR" operation; saves results in cumulative register.

Command code:






LD	X0	Load Contact a of X0
OR	X1	Create series connection to contact a of X1
OUT	V1	Drive V1 coil

Description:

Command	Function						
ORI	Connect conta	connect contact b in parallel					
0	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399	
Operand	✓	✓	✓	✓	✓	_	

The ORI command is used to establish a parallel connection to contact b; its function is to first read current status of the designated series contact and logical operation results before contact in order to perform "OR" operation; saves results in cumulative register.





Comman	u coue.	Description.
LD	X0	Load Contact a of X0
ORI	X1	Create series connection to contact b of X1

Drive Y1 coil

Y1


Command	Function
ANB	Series circuit block
Operand	N/A

Explanation

ANB performs an "AND" operation on the previous saved logic results and the current cumulative register content.

OUT

Example




Command c	ode:	Description:
LD 2	X0	Load Contact a of X0
ORI 2	X2	Establish parallel connection to contact b of X2
LDI 2	X1	Load Contact b of X1
OR 2	X3	Establish parallel connection to contact a of X3
ANB		Series circuit block
OUT `	Y1	Drive Y1 coil

Command	Function
ORB	Parallel circuit block
Operand	N/A

Explanation

ORB performs an "OR" operation on the previous saved logic results and the current cumulative register content.

Example




Command	d code:	Description:
LD	X0	Load Contact a of X0
		Establish parallel
ANI	X1	connection to contact b of X1
LDI	X2	Load Contact b of X2
		Establish parallel
AND	Х3	connection to contact a of X3
ORB		Parallel circuit block
OUT	Y1	Drive Y1 coil


							оно , фр	
Command				Fund	ction			
MPS	Save to stack							
Operand	N/A							
Explanation	Save current content of cumulative register to the stack. (Add one to stack pointer)							
Command				Fund	ction			
MRD	Read stack (po	ointer does	not change)					
Operand				N/	Ά			
Explanation	Reads stack change)	content ar	nd saves to	cum	ulative reg	ister. (	Stack poi	nter does not
Command				Fund	ction			
MPP	Read stack							
Operand				N/	Ά			
Example	Retrieves resucumulative reg Ladder diagrar	ister. (Subt					Des Load Cont Save to st Create se to contact Drive Y1 c	scription: tact a of X0 ack ries connection a of X1 coil
	MPP		END		AND OUT MPP OUT END	X2 M0 Y2	Create se to contact Drive M0 o Read stac Drive Y2 o Program o	coil k coil
Command				Fund	ction			
OUT	Drive coil							
0	X0-X17	Y0-Y17	M0-M7	<b>'</b> 99	T0-159		C0-C79	D0-D399
Operand	_	✓	✓		_		_	_
Explanation	Outputs result o					the des	ignated ele	ment.
	Result:	Coil	Out cor A Contact a (N	ccess	Point:	(N.C.)		
	FALSE	OFF	Not conduc		Conduc			
	TRUE	ON	Conducti		Not condu			
Example	Ladder diagrar		— Y1		Command LD AND	I code: X0	Load Cor Establish	scription: ntact b of X0 parallel on to contact a
					OUT	V1	of X1	

OUT

**Y1** 

Drive Y1 coil





When the RST command is driven, the action of the designated element will be as follows:

Element	Mode
Y, M	Both coil and contact will be set as OFF.
	The current timing or count value will be set as 0, and both the coil and contact will be set as OFF.
D	The content value will be set as 0.

If the RST command has not been executed, the status of the designated element will remain unchanged.





Comman	d code:	De	escription:	
LD	X0	Load Co	ontact a of X	(0
RST	Y5	Clear register	contact	or


Command		Function					
TMR	16-bit timer						
Operand	T-K	T0-T159, K0-K32,767					
	T-D	T0-T159, D0-D399					


Explanation

When the TMR command is executed, the designated timer coil will be electrified, and the timer will begin timing. The contact's action will be as follows when the timing value reaches the designated set value (timing value ≥ set value):

N.O. (Normally Open) contact	Closed
N.C. (Normally Close) contact	Open

If the RST command has not been executed, the status of the designated element will remain unchanged.





#### Chapter 16 PLC Function Applications | CP2000


Command	Function							
CNT	16-bit counter	3-bit counter						
Operand	C-K	C0-C79, K0-K32,767						
	C-D	C0-C79, D0-D399						

Explanation

When the CNT command is executed from OFF $\rightarrow$ ON, this indicates that the designated counter coil goes from no power  $\rightarrow$  electrified, and 1 will be added to the counter's count value; when the count reaches the designated value (count value = set value), the contact will have the following action:

N.O. (Normally Open) contact	Closed	
N.C. (Normally Close) contact	Open	

After the count value has been reached, the contact and count value will both remain unchanged even if there is continued count pulse input. Use the RST command if you wish to restart or clear the count.



Command	Function				
MC/MCR	Connect/release a common series contact				
Operand	N0-N7				


MC is the main control initiation command, and any commands between MC and MCR will be executed normally. When the MC command is OFF, any commands between MC and MCR will act as follows:

Determination of commands	Description		
Ordinary timer	The timing value will revert to 0, the coil will lose power, and the contact will not operate		
Counter	The coil will lose power, and the count value and contact will stay in their current state		
Coil driven by OUT command	None receive power		
Elements driven by SET, RST commands	Will remain in their current state		
Applications commands	None are actuated		

MCR is the main control stop command, and is placed at the end of the main control program. There may not be any contact commands before the MCR command. The MC-MCR main control program commands support a nested program structure with a maximum only 8 levels; use in the order N0-N7, please refer to the following program:

Example

Ladder diagram:




Comm code		Description:
LD	X0	Load Contact a of X0
MC	N0	Connection of N0 common series contact
LD OUT	X1 Y0	Load Contact a of X1 Drive Y0 coil
: LD	X2	Load Contact a of X2
MC	N1	Connection of N1 common series contact
LD	X3	Load Contact a of X3
OUT :	Y1	Drive Y1 coil
MCR	N1	Release N1 common series contact
: MCR	N0	Release N0 common series contact
: LD	X10	Load Contact a of X10
MC	N0	Connection of N0 common series contact
LD OUT :	X11 Y10	Load Contact a of X11 Drive Y10 coil
MCR	N0	Release N0 common series contact

Command	Function						
LDP	Start of forwar	Start of forward edge detection action					
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399	
	✓	✓	✓	✓	✓	_	

The LDP command has the same usage as LD, but its action is different; its function is to save current content, while also saving the detected state of the rising edge of the contact to the cumulative register.

Example



Command code:

Description:

LDP X0 Start of X0 forward edge detection action

AND X1 Create series connection to contact a of X1

OUT Y1 Drive Y1 coil

Remark


Please refer to the function specifications table for each device in series for the scope of usage of each operand.

A rising edge contact will be TRUE after power is turned on if the rising edge contact is On before power is turned on to the PLC.

Command	Function						
LDF	Start of reverse edge detection action						
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399	
	✓	✓	✓	✓	✓	_	

Explanation

The LDF command has the same usage as LD, but its action is different; its function is to save current content while also saving the detected state of the falling edge of the contact to the cumulative register.




Command code: Description:

LDF	X0	Start of X0 reverse edge detection action
AND	X1	Create series connection to contact a of X1
OUT	Y1	Drive Y1 coil

Command	Function							
ANDP	Forward edge	Forward edge detection series connection						
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399		
	✓	✓	✓	✓	✓	_		

Explanation The ANDP command used for a contact rising edge detection series connection.



Command code:

LD X0 Load Contact a of X0

X1 Forward edge

ANDP X1 detection series

connection

OUT Y1 Drive Y1 coil

#### Chapter 16 PLC Function Applications | CP2000

Command	Function						
ANDF	Reverse edge detection series connection						
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399	
	✓	✓	✓	✓	✓	_	
Explanation The ANDF command is used for a contact falling edge detection series connection.							

Example Ladder diagram:

X0 X1

Y1

Command code:

LD X0 Load Contact a of X0

X1 Reverse edge


ANDF X1 detection series

connection

OUT Y1 Drive Y1 coil

Command	Function									
ORP	Forward edge	orward edge detection parallel connection								
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399				
Operand	✓	✓	✓	✓	✓	_				

Explanation The ORP command is used for a contact rising edge detection parallel connection.



Command code:

Description:

LD X0 Load Contact a of X0


X1 Forward edge

ORP X1 detection parallel connection

OUT Y1 Drive Y1 coil

Command		Function								
ORF	Reverse edge	everse edge detection parallel connection								
Operand	X0-X17	Y0-Y17	M0-M799	T0-159	C0-C79	D0-D399				
Operand	✓	✓	✓	✓	✓	_				


Explanation The ORF command is used for contact falling edge detection parallel connection.



		·
LD	X0	Load Contact a of X0
ORF	X1	X1 Reverse edge detection parallel connection
OUT	Y1	Drive Y1 coil


Description:

Command code:




Command	Function										
PLF	Lower differen	ower differential output									
Operand	X0-X17	(0–X17 Y0–Y17 M0–M799			C0-C79	D0-D399					
Operand	_										
Lower differential output command. When X0 = ON→OFF (negative edge-triggered),											


Lower differential output command. When X0 = ON→OFF (negative edge-triggered), the PLF command will be executed, and M0 will send one pulse, with pulse length consisting of one scanning period.




Command	Function
END	Program conclusion
Operand	N/A

An END command must be added to the end of a ladder diagram program or command program. The PLC will scan from address 0 to the END command, and will return to address 0 and begins scanning again after execution.







## 16-6-3 Overview of application commands

01 15 11		Comma	nd code	Р		STE	PS
Classification	API	16 bit	32 bit	command	Function	16bit	32bit
	01	CALL	_	✓	Call subprogram	3	_
Circuit control	02	SRET	_	_	Conclusion of subprogram	1	_
	06	FEND	_	_	Conclusion of main program	1	
	10	CMP	DCMP	✓	Compares set output	7	13
Send	11	ZCP	DZCP	✓	Range comparison	9	17
comparison	12	MOV	DMOV	✓	Data movement	5	9
oompanoon	13	SMOV	DSMOV	✓	Nibble movement	11	21
	15	BMOV		✓	Send all	7	
	18	BCD	DBCD	✓	BIN to BCD transformation	5	9
	19	BIN	DBIN	<b>√</b>	BCD to BIN transformation	5	9
	20	ADD	DADD	✓	BIN addition	7	13
Four logical	21	SUB	DSUB	✓	BIN subtraction	7	13
operations	22	MUL	DMUL	<b>√</b>	BIN multiplication	7	13
	23	DIV	DDIV	<b>√</b>	BIN division	7	13
	24	INC	DINC	<b>√</b>	BIN add one	3	5
D	25	DEC	DDEC	<b>√</b>	BIN subtract one	3	5
Rotational	30	ROR	DROR	✓ ✓	Right rotation	5 5	
displacement	31	ROL	DROL		Left rotation		_
	40	ZRST	_	✓	Clear range	5	-
	41	DECO	DDECO	✓	Decoder	7	13
	42	ENCO	DENCO	✓	Encoder	7	13
Data Process	43	SUM	DSUM	✓	ON bit number	5	9
	44	BON	DBON	✓	ON bit judgement	7	13
	49	-	DFLT		BIN whole number → binary floating point number transformation	-	9
	110	_	DECMP	<b>✓</b>	Comparison of binary floating point numbers	-	13
	111	_	DEZCP	Comparison of binary floating point number range		_	17
	116	_	DRAD	✓			9
	117	_	DDEG	<b>√</b>	Radian → Angle	_	9
	120	-	DEADD	<b>✓</b>	Binary floating point number addition	_	13
	121	_	DESUB	✓	Binary floating point number subtraction	_	13
	122	-	DEMUL	✓	Binary floating point number multiplication	_	13
Floating point	123	-	DEDIV	✓	Binary floating point number division	I	13
operation	124	_	DEXP	<b>✓</b>	Binary floating point number obtain exponent	-	9
	125	_	DLN	<b>✓</b>	Binary floating point number obtain logarithm	_	9
	127	_	DESQR	✓	Binary floating point number find square root	_	9
	129	INT	DINT	Binary floating point number  → BIN whole number  transformation		_	9
	130	_	DSIN	✓	Binary floating point number SIN operation	_	9
	131	_	DCOS	✓	Binary floating point number COS operation	_	9
	132		DTAN	✓	Binary floating point number TAN operation	_	9

		Commo	nd code	Р		STE	DC
Classification	API	16 bit		command	Function	16bit	32bit
	133	-	DASIN	√	Binary floating point number ASIN operation	-	9
	134	_	DACOS	✓	Binary floating point number ACOS operation	_	9
	135	_	DATAN	✓	Binary floating point number ATAN operation	_	9
	136	_	DSINH	✓	Binary floating point number SINH operation		9
Floating point operation	137	_	DCOSH	✓	Binary floating point number COSH operation	_	9
	138	_	DTANH	✓	Binary floating point number TANH operation	ı	9
Other	147	SWAP	DSWAP	✓	Exchange the up/down 8 bits	3	5
Communication	150	MODRW	_	✓	Modbus read/write	7	_
	160	TCMP	_	✓	Compare calendar data	11	_
	161	TZCP	_	✓	Compare calendar data range	9	_
Calendar	162	TADD	_	✓	Calendar data addition	7	_
<u>_</u>	163	TSUB	_	✓	Calendar data subtraction	7	_
	166	TRD	_	✓	Calendar data read	3	_
GRAY code	170	GRY	DGRY	✓	BIN→GRY code transformation	5	9
GNAT code	171	GBIN	DGBIN	✓	GRY code →BIN transformation	5	9
	215	LD&	DLD&	-	Contact form logical operation LD#	5	9
	216	LDI	DLD	_	Contact form logical operation LD#	5	9
	217	LD^	DLD^	-	Contact form logical operation LD#	5	9
	218	AND&	DAND&	-	Contact form logical operation AND#	5	9
Contact form logical operation	219	ANDI	DANDI	_	Contact form logical operation AND#	5	9
	220	AND^	DAND^	_	Contact form logical operation AND#	5	9
	221	OR&	DOR&	-	Contact form logical operation OR#	5	9
	222	ORI	DOR	Contact form logical operation OR#		5	9
	223	OR^	DOR^	_	Contact form logical operation OR#	5	9
	224	LD=	DLD=	_	Contact form compare LD*	5	9
	225	LD>	DLD>	_	Contact form compare LD*	5	9
	226	LD<	DLD<	_	Contact form compare LD*	5	9
	228	LD<>	DLD<>	_	Contact form compare LD*	5	9
	229	LD<=	DLD<=	-	Contact form compare LD*	5	9
	230	LD>=	DLD>=	_	Contact form compare LD*	5	9
	232	AND=	DAND=	_	Contact form compare AND*	5	9
	233	AND>	DAND>	_	Contact form compare AND*	5	9
Contact form	234	AND <	DAND <	_	Contact form compare AND *	5	9
compare					Contact form compare AND *		
command	236	AND<>	DAND <	_	-	5	9
	237	AND<=	DAND<=	-	Contact form compare AND	5	9
	238	AND>=	DAND>=	_	Contact form compare AND*	5	9
	240	OR=	DOR=	_	Contact form compare OR ×	5	9
	241	OR>	DOR>	-	Contact form compare OR ×	5	9
	242	OR<	DOR<	_	Contact form compare OR*	5	9
	244	OR<>	DOR<>	_	Contact form compare OR*	5	9
	245	OR<=	DOR<=	-	Contact form compare OR*	5	9
	246	OR>=	DOR>=	_	Contact form compare OR*	5	9
	-	ı	1	1			


Classification	۸DI	Comma	nd code	Р	Function	STE	EPS
Classification	API	16 bit	32 bit	command	Function	16bit	32bit
	275	_	FLD=	_	Floating point number contact form compare LD ×	_	9
Floating point contact form	276	_	FLD>	_	Floating point number contact form compare LD *	_	9
	277	_	FLD<	_	Floating point number contact form compare LD *	_	9
	278	_	FLD<>	_	Floating point number contact form compare LD ×	_	9
	279	_	FLD<=	_	Floating point number contact form compare LD ×	_	9
	280	_	FLD>=	_	Floating point number contact form compare LD ×	_	9
	281	_	FAND=	_	Floating point number contact form compare AND*	_	9
	282	_	FAND>	_	Floating point number contact form compare AND*	_	9
	283	_	FAND<	_	Floating point number contact form compare AND*	_	9
	284	<ul><li>FAND&lt;&gt;</li><li>Floating point number contact form compare AND*</li></ul>		_	9		
Compare command	285	_	FAND<=	_	Floating point number contact form compare AND*	_	9
	286	_	FAND>=	_	Floating point number contact form compare AND*	_	9
	287	_	FOR=	_	Floating point number contact form compare OR*	_	9
	288	_	FOR>	_	Floating point number contact form compare OR*	_	9
	289	_	FOR<	_	Floating point number contact form compare OR*	_	9
	290	_	FOR<>	_	Floating point number contact form compare OR*	_	9
	291	FOR Floating point number co		Floating point number contact form compare OR*	_	9	
	292	_	FOR>=	_	Floating point number contact form compare OR*	_	9
	139	RPR	_	✓	Read servo parameter	5	_
_	140	WPR	_	✓	Write servo parameter	5	_
<u> </u>	141	FPID	_	<b>√</b>	Driver PID control mode	9	_
	142	FREQ	_	<b>√</b>	Driver torque control mode	7	_
Driver special -	261	CANRX	_	<b>√</b>	Read CANopen slave station data	9	_
command	264	CANTX	_	<b>✓</b>	Write CANopen slave station data	9	_
	265	CANFLS	_	✓	Refresh special D corresponding to CANopen	3	_
<u> </u>	320	ICOMR	DICOMR	✓	Internal communications read	9	17
<u> </u>	321	ICOMW	DICOMW	✓	Internal communications write	9	17
	323	WPRA	_	_	RAM write in drive parameters	5	_

## 16-6-4 Detailed explanation of applications commands

API CALL P	S Call s	ubprogram
	ord device KnY   KnM   T   C   D	16-bit command (3 STEP)   CALL   Continuous   CALLP   Pulse   execution type   execution type   32-bit command
The S operand can designate P CP2000 series device: The S operand	d can designate P0-P63	Flag signal: none


Explanation

- **S**: Call subprogram pointer.
- Write the subprogram after the FEND command.
- The subprogram must end after the SRET command.
- Refer to the FEND command explanation and sample content for detailed command functions.




Explanation


- A contact-driven command is not needed. Automatically returns next command after CALL command
- Indicates end of subprogram. After end of subprogram, SRET returns to main program, and executes next command after the original call subprogram CALL command.
- Refer to the FEND command explanation and sample content for detailed command functions.



- This command indicates the end of the main program. It is the same as the END command when the PLC executes this command.
- The CALL command program must be written after the FEND command, and the SRET command added to the end of the subprogram.
- When using the FEND command, an END command is also needed. However, the END command must be placed at the end, after the main program and subprogram.

CALL command process





- S1: Compare value 1. S2: Compare value 2. D: Results of comparison.
- Compares the size of the content of operand S1 and S2; the results of comparison are expressed in D.
- Size comparison is performed algebraically. All data is compared in the form of numerical binary values. Because this is a 16-bit command, when b15 is 1, this indicates a negative number.


Example

- When the designated device is Y0, it automatically occupies Y0, Y1 and Y2.
- When X10 = ON, the CMP command executes, and Y0, Y1 or Y2 will be ON. When X10 = OFF, the CMP command will not execute, and the state of Y0, Y1 and Y2 will remain in the state prior to X10 = OFF.
- If ≥, ≤, or ≠ results are needed, they can be obtained via series/parallel connections of Y0-Y2.

```
X10
            CMP
                    K10
                           D10
                                  Y0
             - If K10>D10, Y0 = On
             - If K10=D10, Y1 = On
             - If K10<D10, Y2= On
```

To clear results of comparison, use the RST or ZRST command.

```
M0
                           ZRST
RST
                                   M0
                                         M2
RST
     M1
RST
     M2
```



- S1: Lower limit of range comparison. S2: Upper limit of range comparison.

  S: Comparative value. D: Results of comparison.
- When the comparative value sis compared with the lower limit sin and upper limit sin the results of comparison are expressed in sin the lower limit
- When lower limit S1 > upper limit S2, the command will use the lower limit to perform comparison with the upper and lower limit.
- Size comparison is performed algebraically. All data is compared in the form of numerical binary values. Because this is a 16-bit command, when b15 is 1, this indicates a negative number.

Example


- When the designated device is M0, it automatically occupies M0, M1 and M2.
- When X0 = ON, the ZCP command executes, and M0, M1 or M2 will be ON. When X0 = OFF, the ZCP command will not execute, and the state of M0, M1 or M2 will remain in the state prior to X0 = OFF.
- If  $\geq$ ,  $\leq$ , or  $\neq$  results are needed, they can be obtained via series/parallel connections of M0-M2.

■ To clear results of comparison, use the RST or ZRST command.

```
RST M1

RST M2

RST M2
```




- S: Data source. 

  D: Destination of data movement.
- When this command is executed, the content of S content will be directly moved to D. When the command is not executed, the content of D will not change.

Example

- When X0 = OFF, the content of D10 will not change; if X0 = ON, the value K10 will be sent to data register D10.
- When X1 = OFF, the content of D10 will not change; if X1 = ON, the current value of T0 will be sent to data register D10.




- $\overline{S}$ : Data source.  $\underline{m1}$ : The data source transfers starting bit number.
  - (m2): The data source transfers individual bit number. D: Transfer destination.
  - n Transferring starting bit number of the destination.
- BCD mode (M1168 = OFF):

SMOV enables and operates BCD under this mode, the operation is similar to the way SMOV operates decimal numbers. The command copies specific bit number of arithmetic element S (S is a 4-figure decimal number), and sends the bit number to arithmetic element D (D is also a 4-figure decimal number). The current data on the target register will be covered.

- m₁ range: 1–4
- m<sub>2</sub> range: 1-m<sub>1</sub> (m<sub>2</sub> cannot be larger than m<sub>1</sub>)
- $\blacksquare$  n range:  $m_2$ –4 (n cannot be smaller than  $m_2$ )


Example 1


■ When M1168 = OFF (BCD mode), X0 is ON, the instruction transfers two digits of the decimal number starting from the fourth digit of the decimal number (the digit in the thousands place of the decimal number) in D10 to the two digits of the decimal number starting from the third digit of the decimal number (the digit in the hundreds place of the decimal number) in D20. After the instruction is executed, the digits in the thousands place of the decimal number (10³) and the ones place of the decimal number (10¹) in D20 are unchanged.




Example 2


■ When M1168 is ON (BIN mode), and the SMOV command is executed, D10 and D20 do not change in BCD mode, but send 4 digits as a unit in BIN mode.







■ If D10 = 001E (Hex) = 0030 (Decimal), the executed result will be Y0–Y3=0000 (BIN).



AP 20		) 4	ADD	P		<b>(S1)</b>	(S2			В	IN ac	ldition
	Bit	dev	ice			٧	Vord	devic	е			16-bit command (7 STEP)
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ADD Continuous ADDP Pulse
S1				*	*	*	*	*	*	*	*	execution type execution type
S2				*	*	*	*	*	*	*	*	32-bit command (13 STEP)
D							*	*	*	*	*	DADD : Continuous : DADDP : Pulse
Note	es on	oper	and u	sage:	none							execution type execution type
												Flag signal: M1020 Zero flag
												M1021 Borrow flag
												M1022 Carry flag
												Please refer to the following
												supplementary explanation


- S1): Augend. S2): Addend. D: Sum.
- Using two data sources: The result of adding S1 and S2 using the BIN method will be stored in D.
- The highest bit of any data is symbolized as bit 0 indicating (positive) 1 indicating (negative), enabling the use of algebraic addition operations. (for instance: 3+(-9) = -6)
- Flag changes connected with the addition.
  - 1. When calculation results are 0, the zero flag M1020 will be ON.
  - 2. When calculation results are less than –32,768, the borrow flag M1021 will be ON.
  - 3. When calculation results are greater than 32,767, the carry flag M1022 will be ON.

Example


■ 16-bit BIN addition: When X0 = ON, the result of the content of addend D0 plus the content of augend D10 will exist in the content of D20.


Remark

Relationship between flag actions and negative/positive numbers: 16-bit:



32-bit:






- Using two data sources: The result of subtraction of (S1) and (S2) using the BIN method is stored in (D).
- The highest bit of any data is symbolized as bit 0 indicating (positive) 1 indicating (negative), enabling the use of algebraic subtraction operations.
- Flag changes connected with subtraction.
  - 1. When calculation results are 0, the zero flag M1020 will be ON.
  - 2. When calculation results are less than –32,768, the borrow flag M1021 will be ON
  - 3. When calculation results are greater than 32,767, the carry flag M1022 will be ON.


Example


16-bit BIN subtraction: When X0 = ON, the content of D10 is subtracted from the content of D0, and the difference is stored in D20.





- S1: Multiplicand. S2: Multiplier. D: Product.
- Using two data sources: When (S1) and (S2) are multiplied using the BIN method, the product is stored in (D).





b15 is a symbol bit b15 is a symbol bit b31 is a symbol bit (b15 of D+1)

Symbol bit = 0 refers to a positive value Symbol bit = 1 refers to a negative value


When D is a bit device, K1~K4 can be designated as a hexadecimal number, which will occupy 2 consecutive units.

Example

When 16-bit DO is multiplied by 16-bit D10, the result will be a 32-bit product; the upper 16 bits will be stored in D21, and the lower 16 bits will be stored in D20. Whether the bit at the farthest left is OFF or ON will indicate the sign of the result.


```
MUL D0 D10 D20

MUL D0 D10 K8M0
```



- S1: Dividend. S2: Divisor. D: Quotient and remainder.
- Using two data sources: The quotient and remainder will be stored in D when S1 and S2 are subjected to division using the BIN method. The sign bit for S1, S2 and D must be kept in mind when performing a 16-bit operation.

#### 16-bit BIN division:





If D is a bit device, K1–K4 can be designated 16 bits, which will occupy 2 consecutive units and yield the quotient and remainder.


Example


When X0 = ON, the quotient resulting from division of dividend D0 by divisor D10 will be placed in D20, and the remainder will be placed in D21. Whether the highest bit is OFF or ON will indicate the sign of the result.

```
DIV D0 D10 K4Y0
```









4C		Z	RST	P		(1	01)(	D2)		С	lear r	range	
	Bit	dev	ice			٧	Vord	devic	е			16-bit command (5 STEP)	
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ZRST Continuous ZRSTP Pulse	
D1		*	*						*	*	*	execution type execution typ	e :
D2		*	*						*	*	*		,
Note	s on	oper	and u	sage:								32-bit command	;
						≤ nun	nber o	f opera	and D	2			:
Ope	rands	5 D <sub>1</sub> ,	D <sub>2</sub> mı	ust de	signat	e the	same	type of	f devic	е			
Plea	se re	efer to	the	function of de	on sp	ecifica	tions t	able fo	or eac	h de	vice in	n Flag signal: none	

- **D**<sub>1</sub>: Clear range's initial device. **D**<sub>2</sub>: Clear range's final device.
- When the number of operand  $D_1$  > number of operand  $D_2$ , only the operand designated by  $D_2$  will be cleared.

Example

- When X0 is ON, auxiliary relays M300–M399 will be cleared and changed to Off.
- When X1 is ON, 16-bit counters C0–C127 will all be cleared. (Writes 0, and clears and changes contact and coil to OFF).
- When X10 is ON, timer T0–T127 will all be cleared. (Writes 0, and clears and changes contact and coil to OFF).
- When X3 is ON, the data in data registers D0–D100 will be cleared and set as 0.

```
X0
┨┠
                  ZRST
                           M300
                                     M399
X1
4 F
                  ZRST
                            C0
                                     C127
X10
┨┠
                  ZRST
                            T0
                                    T127
Х3
\exists \vdash
                  ZRST
                            D0
                                     D100
```

Remark

Devices can independently use the clear command (RST), such as bit device Y, M and word device T, C, D.

```
RST M0

RST T0

RST Y0
```

4	1 [	טט	ECC	P		( <u>s</u> )	D	) ( <u>n</u>		De	ecod	er
	Bit	dev	ice			٧	Vord	devic	е			16-bit command (7 STEP)
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	DECO Continuous DECOP Pulse
S	*	*	*	*	*				*	*	*	execution type execution type
D		*	*				*	*	*	*	*	32-bit command (13 STEP) DDECO: Continuous DDECOP: Pulse
n				*	*							execution type execution type
Not	es on	oper	and u	sage:	none							Flag signal: none


API

- S: Decoding source device. Device that saves the decoding result.


  n: Length of decoding bit.
- Decodes with the lower "n" bit, and saves the length of "2" bit in D.
- This command usually uses pulse execution type command (DECOP).
- When D is the bit device, n = 1-8, when D is the word device, n = 1-4.

Example 1

- When Dis the bit device, the valid range of n is 0 < n ≤ 8. If n = 0 or n > 8, a fault will occur.
- When n = 8, the maximum decoding will be  $2^8 = 256$  points.
- When M200 switches from Off to On, the content of X0–X2 is decoded to M100–M107.
- If S = 3, M103 (the third digit starting from M100) = ON.
- When the command is executed, M200 turns to OFF. The ones that are decoded and outputted act as usual.



- When D is word device, the valid range of n is  $0 < n \le 4$ . If n = 0 or n > 4, the fault occurs
- When n = 4, the maximum decoding will be  $2^4 = 16$  points.
- When M200 switches from OFF to ON, the content of D10 (b2–b0) is decoded to D20 (b7–b0). The unused digits (b15–b8) of D20 become 0.
- The lower 3 digits of D10 are decoded and saved in the lower 8 digits of D20, the upper 8 digits are 0.
- When the command is executed, M200 turns to OFF. The ones that are decoded and outputted act as usual.




AF 42		E	NCC	P		S	D	) (n	D	Er	ncod	er
	Bit	dev	ice			٧	Vord	devic	е			16-bit command (7 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ENCO Continuous ENCOP Pulse
s	*	*	*						*	*	*	execution type execution type
D							*	*	*	*	*	32-bit command (13 STEP) DENCO: Continuous DENCOP: Pulse
n				*	*							execution type execution type
Note	es on	oper	and u	sage:	none							Flag signal: none

- S: Encoding source device. D: Device that saves the encoding result.


  n: Length of encoding bit.
- Encodes the data of lower "2" bit length from encoding source device S, and saves the encoding result in D.
- If multiple digits of encoding source device are 1, the command will process the first digit starting from high digit.
- This command usually uses pulse execution type command (ENCOP).
- When S is the bit device, n = 1-8, when S is the word device, n = 1-4.


- When S is the bit device, the valid range of n is  $0 < n \le 8$ . If n = 0 or n > 8, a fault will occur.
- When n = 8, the maximum decoding will be  $2^8 = 256$  points.
- When X0 switches from OFF to ON, the content of 2³ digit (M0–M7) is encoded and saved in the lower 3 digits (b2–b0). The unused digits (b15–b3) in D0 become 0.
- When the command is executed, X0 turns to OFF. The data in D is unchanged.



Example 2

- When S is word device, the valid range of n is  $0 < n \le 4$ . If n = 0 or n > 4, the fault occurs.
- When n = 4, the maximum decoding will be  $2^4 = 16$  points.
- When X0 switches from OFF to ON, 2³ digit data of D10 (b0–b7) is encoded and saved in the lower 3 digits (b2–b0) of D20. The unused digits (b15–b3) of D20 become 0. (b8–b15 in D10 are invalid data)
- When the command is executed, X0 turns to OFF. The data in D is unchanged.






Explanation

- S: Source device. D: Destination of saving counter values.
- The total amount of all digits that is "1" in S will be saved in D.
- D will use 2 registers when use the 32-bit command.
- Arithmetic elements S and D use F device, and can only use 16-bit command.
- If there is no bit is ON, the flag signal M1020 will be ON.

Example

■ When M200 = ON, the total amount of content "1" digit in D0's 16-bit command will be saved in D2.



b15

1 0

0

0

0

AF 44		) E	BON	P	(	S	D		n	10	N bit	judgement
	Bit	dev	ice			٧	Vord	devic	е			16-bit command (7 STEP)
	Χ	Υ	M	K	Н	KnX	KnY	KnM	Т	С	D	BON : Continuous : BONP : Pulse :
S				*	*	*	*	*	*	*	*	execution type execution type
D		*	*						*	*	*	32-bit command (9 STEP)
n				*	*							DBON Continuous DBONP Pulse execution type execution type
	20.00	onor	ond u	ı .								- Oxocoulon typo
INOL	es on	oper	and u	sage:	none							Flag signal: none
	kplana Exam			jud Th Ari Th	lged e sta thme e val en Xi	digit ( tus o etic el id rar	(num f spe emer nge o N, if	bering cific on t S u f arith	g fron ligit fr ses F nmetio	n 0) om s dev c ele	sourd rice, men	etion of saving judging result. n:: assign the device is shown on target position. and can only use the 16-bit command. to n: n = 0–15 (16-bit), n = 0–31 (32-bit). is "1", M0 is ON. If it is "0", M0 is OFF. revious status.
				H	<u> </u>		В	ON		D0		M0 K15
			[	b15 0	0	0 1	0	0	1	0 D0	0	b0 0 0 0 0 1 0 0 M0=Off

0 0

D0


0

b0

M0=On

0 0


## Chapter 16 PLC Function Applications | CP2000



AF 11		) E	СМЕ	P		<b>S</b> 1	<u>\$2</u>	0	)	С	ompa	arison of binary floating point numbers
	Bit	dev	ice			٧	Vord	devic	е			16-bit command
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	
S1				*	*						*	[iii
S2				*	*						*	32-bit command (13 STEP)
D											*	DECMP : Continuous : DECMP : Pulse :
Note	es on	oper	and u	sage:								execution type P execution type
The	oper	and D	) occi	upies t	hree	conse	cutive	points				
Plea	ase re	efer to	the	function of de	on sp	ecifica	tions t	able fo	or ead	ch de	vice in	Flag signal: none

- **S**<sub>1</sub>: Comparison of binary floating point numbers value 1. **S**<sub>2</sub>: Comparison of binary floating point numbers value 2. **D**: Results of comparison, occupies 3 consecutive points.
- When binary floating point number 1 is compared with comparative binary floating point number 2, the result of comparison (>, =, <) will be expressed in **D**.
- If the source operand S₁ or S₂ designates a constant K or H, the command will transform the constant to a binary floating-point number for the purpose of comparison.


- When the designated device is M10, it will automatically occupy M10–M12.
- When X0 = ON, the DECMP command executes, and one of M10–M12 will be ON. When X0 = OFF, the DECMP command will not execute, and M10–M12 will remain in the X0 = OFF state.
- If results in the form of ≥, ≤, or ≠ are needed, they can be obtained by series and parallel connection of M10–M12.
- Please use the RST or ZRST command to clear the result.



- **S**<sub>1</sub>: Lower limit of binary floating point number in range comparison. **S**<sub>2</sub>: Upper limit of binary floating point number in range comparison. **S**: Comparison of binary floating point numerical values. **D**: Results of comparison, occupies 3 consecutive points.
- Comparison of binary floating point numerical value **S** with binary floating point number lower limit value **S**<sub>1</sub> and binary floating point number upper limit value **S**<sub>2</sub>; the results of comparison are expressed in **D**.
- If the source operand S₁ or S₂ designates a constant K or H, the command will transform the constant to a binary floating-point number for the purpose of comparison.
- When the lower limit binary floating point number  $S_1$  is greater than the upper limit binary floating point number  $S_2$ , a command will be issued to perform comparison with the upper and lower limits using the binary floating point number lower limit value  $S_1$ .

- When the designated device is M0, it will automatically occupy M0–M2.
- When X0 = ON, the DEZCP command will be executed, and one of M0–M2 will be ON. When X0 = OFF, the EZCP command will not execute, and M0–M2 will continue in the X0 = OFF state.
- Please use the RST or ZRST command to clear the result.


```
X0
DEZCP
D0
D10
D20
M0
M0
M1
D0
M1
D0
M2
M2
D0
M1
M2
D0
M2
D0
M1
D0
M2
D0
M2
D10
D20
M0
D20
M0
D20
M0
D20
M0
D20
M0
D21
D20
D20
D21
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
D20
```




- S: data source (angle). D: result of transformation (radian).
- Uses the following formula to convert angles to radians.
- Radian = Angle ×  $(\pi/180)$

Example

When X0 = ON, the angle of the designated binary floating point number (D1, D0) will be converted to radians and stored in (D11, D10), with the content consisting of a binary floating point number.







- **S**: data source (radian). **D**: results of transformation (angle).
- Uses the following formula to convert radians to an angle.
- Angle = Radian × (180/π)

Example

When X0 = ON, angle of the designated binary floating point number (D1, D0) in radians will be converted to an angle and stored in (D11, D10), with the content consisting of a binary floating point number.






- S<sub>1</sub>: augend. S<sub>2</sub>: addend. D: sum.
- When the content of the register designated by  $S_2$  is added to the content of the register designated by  $S_1$ , and the result is stored in the register designated by D. Addition is performed entirely using binary floating-point numbers.
- If the source operand S<sub>1</sub> or S<sub>2</sub> designates a constant K or H, the command will transform that constant into a binary floating point number for use in addition.
- In the situation when S₁ and S₂ designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is ON, the register will perform addition once during each scan. Pulse execution type commands (DEADDP) are generally used under ordinary circumstances.

Example

When X0 = ON, a binary floating point number (D1, D0) will be added to a binary floating point number (D3, D2), and the results stored in (D11, D10).

```
X0 DEADD D0 D2 D10
```

■ When X2 = ON, a binary floating point number (D11, D10) will be added to K1234 (which has been automatically converted to a binary floating-point number), and the results stored in (D21, D20).




- **S**₁: minuend. **S₂**: subtrahend. **D**: difference.
- When the content of the register designated by  $S_2$  is subtracted from the content of the register designated by  $S_1$ , the difference will be stored in the register designated by D; subtraction is performed entirely using binary floating-point numbers.
- If the source operand S<sub>1</sub> or S<sub>2</sub> designates a constant K or H, the command will transform that constant into a binary floating point number for use in subtraction.
- In the situation when S₁ and S₂ designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is ON, the register will perform addition once during each scan. Pulse execution type commands (DESUBP) are generally used under ordinary circumstances.

Example

When X0 = ON, a binary floating point number (D1, D0) will be subtracted to a binary floating point number (D3, D2), and the results stored in (D11, D10).

```
DESUB D0 D2 D10
```

■ When X2 = ON, the binary floating point number (D1, D0) will be subtracted from K1234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).



- S<sub>1</sub>: multiplicand. S<sub>2</sub>: multiplier. **D**: product.
- When the content of the register designated by  $S_1$  is multiplied by the content of the register designated by  $S_2$ , the product will be stored in the register designated by D; multiplication is performed entirely using binary floating-point numbers.
- If the source operand S<sub>1</sub> or S<sub>2</sub> designates a constant K or H, the command will transform that constant into a binary floating point number for use in multiplication.
- In the situation when S₁ and S₂ designate identical register numbers, if a "continuous execution" command is employed, when conditional contact is On, the register will perform multiplication once during each scan. Pulse execution type commands (DEMULP) are generally used under ordinary circumstances.


Example

When X1 = ON, the binary floating point number (D1, D0) will be multiplied by the binary floating point number (D11, D10), and the product will be stored in the register designated by (D21, D20).

```
DEMUL D0 D10 D20
```

■ When X2 = ON, the binary floating point number (D1, D0) will be multiplied from K1234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

```
X2 | DEMUL K1234 | D0 | D10
```



- S₁: dividend. S₂: divisor. D: quotient and remainder.
- When the content of the register designated by  $S_1$  is divided by the content of the register designated by  $S_2$ , the quotient will be stored in the register designated by D; division is performed entirely using binary floating-point numbers.
- If the source operand S₁ or S₂ designates a constant K or H, the command will transform that constant into a binary floating point number for use in division.


Example

When X1 = ON, the binary floating point number (D1, D0) will be divided by the binary floating point number (D11, D10), and the quotient stored in the register designated by (D21, D20).

```
DEDIV D0 D10 D20
```


■ When X2 = ON, the binary floating point number (D1, D0) will be divided by K1,234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

```
X2 | DEDIV | D0 | K1234 | D10
```




- S: operation source device. D: operation results device.
- Taking e = 2.71828 as a base, **S** is the exponent in the EXP operation.
- [D+1,D] = EXP[S+1,S]
- Valid regardless of whether the content of **S** has a positive or negative value. The designated register D must have a 32-bit data format. This operation is performed using floating-point numbers, and **S** must therefore be converted to a floating point number.
- Content of operand  $\mathbf{D} = e^{S}$ ; e = 2.71828, **S** is the designated source data

- When M0 is ON, the value of (D1, D0) will be converted to a binary floating point number, which will be stored in register (D11, D10).
- When M1 is ON, the EXP operation is performed on the exponent of (D11, D10); its value is a binary floating point number stored in register (D21, D20).



- **S**: operation source device. **D**: operation results device.
- Taking e = 2.71828 as a base, **S** is the exponent in the EXP operation.
- **■** [**D**+1,**D**] = EXP[**S**+1,**S**]
- Valid regardless of whether the content of **S** has a positive or negative value. The designated register D must have a 32-bit data format. This operation is performed using floating-point numbers, and **S** must therefore be converted to a floating point number.
- Content of operand  $\mathbf{D} = e^{S}$ ; e = 2.71828,  $\mathbf{S}$  is the designated source data

- When M0 is ON, the value of (D1, D0) will be converted to a binary floating point number, which will be stored in register (D11, D10).
- When M1 is ON, the EXP operation is performed on the exponent of (D11, D10); its value is a binary floating point number stored in register (D21, D20).



- **S**: source device for which square root is desired **D**: result of finding square root.
- When the square root is taken of the content of the register designated by **S**, the result is temporarily stored in the register designated by **D**. Taking square roots is performed entirely using binary floating-point numbers.
- If the source operand **S** refers to a constant K or H, the command will transform that constant into a binary floating point number for use in the operation.


Example

When X0 = ON, the square root is taken of the binary floating point number (D1, D0), and the result is stored in the register designated by (D11, D10).

DESQR D0 D10
$$\sqrt{(D1 \cdot D0)} \longrightarrow (D11 \cdot D10)$$
Binary floating point Binary floating point

■ When X2 = ON, the square root is taken of K1,234 (which has been automatically converted to a binary floating-point number), and the results stored in (D11, D10).

```
X2
DESQR K1234 D10
```




- **S**: the source device to be transformed. **D**: results of transformation.
- The content of the register designated by **S** is transformed from a binary floating point number format into a BIN whole number, and is temporarily stored in **D**. The BIN whole number floating point number will be discarded.
- The action of this command is the opposite of that of command API 49 (FLT).

Example


■ When X0 = ON, the binary floating point number (D1, D0) is transformed into a BIN whole number, and the result is stored in (D10); the BIN whole number floating point number will be discarded.

```
X0
DINT D0 D10
END
```




- **S**: the designated source value. **D**: the SIN value result.
- S is the designated source in radians.
- The value in radians (RAD) is equal to (angle  $\times$ π/180).
- The SIN obtained from the source value designated by **S** is stored in **D**.


The following figure displays the relationship between the arc and SIN results:



Example


When X0 = ON, the SIN value of the designated binary floating point number (D1, D0) in radians (RAD) will be stored in (D11, D10), with the content consisting of a binary floating point number.






- **S**: the designated source value. **D**: the COS value result.
- The source designated by S can be given as radians or an angle; this is decided by flag M1018.
- When M1018 = OFF, the operation is in radians mode, where the radians (RAD) value is equal to (angle  $\times$  π/180).
- When M1018 = ON, the operation is in the angle mode, where the angular range is  $0^{\circ} \le \text{angle} < 360^{\circ}$ .
- When calculation results yield 0, M1020 = ON.
- The COS obtained from the source value designated by **S** is stored in **D**.


The following figure displays the relationship between the arc and SIN results:



Example


When X0 = ON, the COS value of the designated binary floating point number (D1, D0) in radians will be stored in (D11, D10), with the content consisting of a binary floating point number.






- S: the designated source value. D: the TAN value result.
- The source designated by **S** can be given as radians or an angle; this is decided by flag M1018.
- When M1018 = OFF, the operation is in radians mode, where the radians (RAD) value is equal to (angle  $\times \pi/180$ ).
- When M1018 = ON, the operation is in the angle mode, where the angular range is  $0^{\circ} \le \text{angle} < 360^{\circ}$ .
- When calculation results yield 0, M1020 = ON.
- The TAN obtained from the source value designated by **S** is stored in **D**.


The following figure displays the relationship between the arc and SIN results:



Example


When X0 = ON, the TAN value of the designated binary floating point number (D1, D0) in radians (RAD) will be stored in (D11, D10), with the content consisting of a binary floating point number.





- **S**: the designated source (binary floating point number). **D**: the ASIN value result.
- ASIN value = sin<sup>-1</sup>

The figure below shows the relationship between input data and result:




Example

When X0 = ON, the ASIN value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.

```
DASIN D0 D10


S D1 D0 Binary floating point

ASIN value
Binary floating point
```




- **S**: the designated source (binary floating point number). **D**: the ACOS value result.
- ACOS value = cos<sup>-1</sup>


The figure below shows the relationship between input data and result:



Example


When X0 = ON, the ACOS value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.





- S: the designated source (binary floating point number). D: the ATAN value result.
- ATAN value = tan-1

The figure below shows the relationship between input data and result:




Example

■ When X0 = ON, the TAN value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.

```
DATAN D0 D10

S D1 D0 Binary floating point


ATAN value
Binary floating point
```




- **S**: the designated source (binary floating point number). **D**: the SINH value result.
- SINH value = (e<sup>s</sup>-e<sup>-s</sup>)/2

Example

When X0 = ON, the SINH value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.







- **S**: the designated source (binary floating point number). **D**: the COSH value result.
- COSH value = (e<sup>s</sup>+e<sup>-s</sup>)/2

Example

When X0 = ON, the COSH value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.







**S**: the designated source (binary floating point number). **D**: the TANH value result.

 $tanh value = (e^s-e^{-s})/(e^s+e^{-s})$ 

Example

When X0 = ON, the TANH value obtained from the designated binary floating point number (D1, D0) will be stored in (D11, D10), with the content consisting of a binary floating point number.





- S: The device that going to exchange its up/down 8 bits.
- When using 16-bit command, the upper 8-bit and lower 8-bit exchange.
- When using 32-bit command, the contents of upper 8-bit and lower 8-bit of the 2 registers exchange.
- This command usually uses pulse execution type (SWAPP, DSWAPP)

15		MC	DDR	WP	<u>S</u> 1	<u> </u>	2 (	<u>s</u> 3 (	3	n	Me	odbus data read/write
	Bit	dev	ice			V	Vord	devic	е			16-bit command (5 STEP)
	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MODRW: Continuous MODRW: Pulse
S1				*	*						*	execution type P execution type
S2				*	*						*	
S3				*	*						*	32-bit command_
S											*	Ţ <u></u>
n				*	*						*	Flag signal: M1077 M1078 M1079
												ag digital. Witorr Mitoro Witoro

- S1: online device address. S2: communications function code. S3: address of data to read/write. S: register for data to be read/written is stored. N: length of data to be read/written.
- COM1 must be defined as controlled by the PLC (set P9-31 = -12) before using this command, and the corresponding communications speed and format must also be set (set P09-01 and P09-04). S2: communications function code. Currently only supports the following function code; the remaining function code cannot be executed.

Function	Description
H 02	Input read
H 03	Read word
H 06	Write single word
H 0F	Write multiple coils
H10	Write single word

- After executing this command, M1077, M1078 and M1079 will be immediately changed to 0.
- As an example, when CP2000 must control another converter and PLC, if the converter has a station number of 10 and the PLC has a station number of 20, see the following example:


Control slave device converter


			MODF	RW comr	mand	
Seria I No.	Example	S1	S2	S3	S4	n
I NO.	·	Node ID	Function code	Address	Register	Length
1	Reads 4 sets of data comprising the converter slave device parameters P01-00 to P01-03, and saves the read data in D0 to D3	K10	Н3	H100	D0	K4
2	Reads 3 sets of data comprising the converter slave device addresses H2100 to H2102, and saves the read data in D5 to D7	K10	Н3	H2100	D5	К3
3	Reads 3 sets of data comprising the converter slave device parameters P05-00 to P05-03, and writes the values as D10 to D12	K10	H10	H500	D10	К3
4	Writes 2 sets of data comprising the converter slave device addresses H2000 to H2001, and writes the values as D15 to D16	K10	H10	H2000	D15	K2

PLC controlling slave device

PLC C	ontrolling slave device					
				RW com		
Serial	Example	S1	S2	S3	S4	n
No.		Node	Functio	Addres	Registe	Length:
		ID	n code	S	r	Lengui.
	Reads 4 sets of data comprising the					
1	PLC slave device's X0 to X3 state, and	K20	H2	H400	D0	K4
	saves the read data in bits 0 to 3 of D0					
	Reads 4 sets of data comprising the					
2	PLC slave device's Y0 to Y3 state, and	K20	H2	H500	D1	K4
	saves the read data in bits 0 to 3 of D1					
	Reads 4 sets of data comprising the					
3	PLC slave device's M0 to M3 state, and	K20	H2	H800	D2	K4
	saves the read data in bits 0 to 3 of D2					
	Reads 4 sets of data comprising the					
4	PLC slave device's T0 to T3 state, and	K20	H2	H600	D3	K4
	saves the read data in bits 0 to 3 of D3					
	Reads 4 sets of data comprising the					
5	PLC slave device's C0 to C3 state, and	K20	H2	HE00	D4	K4
	saves the read data in bits 0 to 3 of D4					
	Reads 4 sets of data comprising the					
6	PLC slave device's T0 to T3 count	K20	НЗ	H600	D10	K4
	value, and saves the read data of D10	1120	110	11000	D10	114
	to D13					
	Reads 4 sets of data comprising the					
7	PLC slave device's C0 to C3 count	K20	НЗ	HE00	D20	K4
<b>'</b>	value, and saves the read data of D20	1120	110	TILOU	D20	114
	to D23					
	Reads 4 sets of data comprising the					
8	PLC slave device's D0 to D3 count	K20	НЗ	H1000	D30	K4
	value, and saves the read data of D30	1120	110	111000	200	10.
	to D33					
	Writes 4 sets of the PLC slave device's					
9	Y0 to Y3 state, and writes the values as	K20	HF	H500	D1	K4
	bits 0 to 3 of D1					
	Writes 4 sets of the PLC slave device's					
10	M0 to M3 state, and writes the values	K20	HF	H800	D2	K4
	as bits 0 to 3 of D2					
	Writes 4 sets of the PLC slave device's	1400			5.0	1.4
11	T0 to T3 state, and writes the values as	K20	HF	H600	D3	K4
	bits 0 to 3 of D3					
40	Writes 4 sets of the PLC slave device's	1/00		11500	D.4	17.4
12	C0 to C3 state, and writes the values	K20	HF	HE00	D4	K4
	as bits 0 to 3 of D4					
40	Writes 4 sets of the PLC slave device's	1/00	1140	11000	D40	17.4
13	T0 to T3 state, and writes the values of	K20	H10	H600	D10	K4
	D10 to D13					
11	Writes 4 sets of the PLC slave device's	KOO	LIAO	ПЕОО	Dag	1/4
14	C0 to C3 state, and writes the values of	K20	H10	HE00	D20	K4
	D20 to D23					
15	Writes 4 sets of the PLC slave device's	KOO	LIAO	H1000	Dag	1//
15	D0 to D3 state, and writes the values of	K20	H10	H1000	D30	K4
	D30 to D33					

- Will trigger M0 ON when the PLC begins to operate, and sends instruction to execute one MODRW command.
- After receiving the slave device's response, if the command is correct, it will execute one ROL command, which will cause M1 to be ON.
- After receiving the slave device's response, will trigger M50 = 1 after a delay of 10 PLC scanning cycles, and then execute one MODRW command.
- After again receiving the slave device's response, if the command is correct, it will execute one ROL command, and M2 will change to ON at this time (and M2 can be defined as a repeat of M); K4M0 will change to K1, and only M0 will remain 1. Transmission can proceed in a continuous cycle. If you wish to add a command, merely add the desired command in the empty frame, and change repeat M to Mn+1.





- $S_1$ : Sets the hours of the comparison time, setting range is "K0–K23."  $S_2$ : Sets the minutes of the comparison time, setting range is "K0–K59."  $S_3$ : Sets the seconds of the comparison time, setting range is "K0–K59."  $S_3$ : current calendar time.  $D_3$ : Results of comparison.
- Compares the time in hours, minutes, and seconds set in  $S_1$ – $S_3$  with the current calendar time in hours, minutes, and seconds, with the results of comparison expressed in D.
- **S** The hour content of the current calendar time is "K0–K23." **S** +1 comprises the minutes of the current calendar time, and consists of "K0–K59." **S** +2 comprises the seconds of the current calendar time, and consists of "K0–K59."
- The current calendar time designated by **S** is usually compared using the TCMP command after using the TRD command to read the current calendar time. If the content value of **S** exceeds the range, this is considered an operating error, the command will not execute, and M1068 = ON.

- When X10 = ON, the command will execute, and the current calendar time in D20–D22 will be compared with the preset value of 12:20:45; the results will be displayed in M10–M12. When X10 ON→OFF, the command will not be executed, but the ON/OFF status prior to M10–M12 will be maintained.
- If results in the form of ≥, ≤, or ≠ are needed, they can be obtained by series and parallel connection of M10–M12.


```
X10
           TCMP
                      K12
                                K20
                                         K45
                                                   D20
                                                            M10
       M<sub>10</sub>
                                         D20 (hr)
                                         D21 (min)
                ON when 12:20:45 >
                                         D22 (sec)
       M11
                                         D20 (hr)
               ON when 12:20:45=
                                         D21 (min)
                                         D22 (sec)
       M12
                                         D20 (hr)
                ON when 12:20:45 <
                                         D21 (min)
                                         D22 (sec)
```


	Bit	dev	ice			V	Vord	devic	е			:16-bit command (9 STEP)
	Χ	Υ	M	K	Н	KnX	KnY	KnM	Τ	С	D	TZCP Continuous TZCPP Pulse
S1									*	*	*	execution type execution type
S2									*	*	*	,
S									*	*	*	32-bit command
D		*	*									<u> </u>
Not	e on	oner	and u	sage:								

- **S**<sub>1</sub>: Sets the lower limit of the comparison time. **S**<sub>2</sub>: Sets the upper limit of the comparison time. **S**: current calendar time. **D**: Results of comparison.
- Performs range comparison by comparing the hours, minutes, and seconds of the current calendar time designated by **S** with the lower limit of the comparison time set as **S**<sub>2</sub>, and expresses the results of comparison in **D**.
- **S**<sub>1</sub>  $\cdot$  **S**<sub>1</sub> +1  $\cdot$  **S**<sub>1</sub> +2: Sets the hours, minutes, and seconds of the lower limit of the comparison time.
- **S**<sub>2</sub>  $\cdot$  **S**<sub>2</sub> +1  $\cdot$  **S**<sub>2</sub> +2: Sets the hours, minutes, and seconds of the upper limit of the comparison time.
- S · S +1 · S +2: The hours, minutes, and seconds of the current calendar time
- The D0 designated by the **S** listed in this program is usually obtained by comparison using the TZCP command after using the TRD command in advance to read the current calendar time. If the value of **S**<sub>1</sub>, **S**<sub>2</sub>, or **S** exceeds the range, this is considered an operating error, the command will not execute, and M1068 = ON.
- When the current time **S** is less than the lower limit value **S**<sub>1</sub> and **S** is less than the upper limit value **S**<sub>2</sub>, **D** will be ON. When the current time **S** is greater than the lower limit value **S**<sub>1</sub> and **S** is greater than the upper limit value **S**<sub>2</sub>, **D** +2 will be ON; **D** +1 will be ON under other conditions.

Example

■ When X10 = ON, the TZCP command executes, and one of M10-M12 will be ON. When X10 = OFF, the TZCP command will not execute, and M10-M12 will remain in the X10 = OFF state.







- **S**<sub>1</sub>: time addend. **S**<sub>2</sub>: time augend. **D**: time sum.
- The calendar data in hours, minutes, and seconds designated by  $S_2$  is added to the calendar data in hours, minutes, and seconds designated by  $S_1$ , and the result is stored as hours, minutes, and seconds in the register designated by D.
- If the value of S<sub>1</sub> or S<sub>2</sub> exceeds the range, this is considered an operating error, the command will not execute, M1067, M1068 = ON, and D1067 will record the error code 0E1A (HEX).
- If the results of addition are greater than or equal to 24 hours, carry flag M1022 = ON, and **D** will display the results of addition minus 24 hours.
- If the results of addition are equal to 0 (0 hours, 0 minutes, 0 seconds), zero flag M1020 = ON.

Example

When X10 = ON, the TADD command will be executed, and the calendar data in hours, minutes, and seconds designated by D0 to D2 will be added to the calendar data in hours, minutes, and seconds designated by D10 to D12, and the results are stored as a total number of hours, minutes, and seconds in the registers designated by D20 to D22.







- **S**<sub>1</sub>: time minuend. **S**<sub>2</sub>: time augend. **D**: time sum.
- Subtracts the calendar data in hours, minutes, and seconds designated by S₂ from the calendar data in hours, minutes, and seconds designated by S₁, and the result is temporarily stored as hours, minutes, and seconds in the register designated by D.
- If the value of S₁ or S₂ exceeds the range, this is considered an operating error, the command will not execute, M1067, M1068 = ON, and D1067 will record the error code 0E1A (HEX).
- If subtraction results in a negative number, borrow flag M1021 = ON, and the result of that negative number plus 24 hours will be displayed in the register designated by **D**.
- If the results of subtraction are equal to 0 (0 hours, 0 minutes, 0 seconds), zero flag M1020 = ON.

Example

■ When X10 = ON, the TADD command will be executed, and the calendar data in hours, minutes, and seconds designated by D10 to D12 will be subtracted from the calendar data in hours, minutes, and seconds designated by D0 to D2, and the results are stored as a total number of hours, minutes, and seconds in the registers designated by D20 to D22.






- S<sub>1</sub>: time minuend. S<sub>2</sub>: time augend. D: time sum.
- **D**: device used to store the current calendar time after reading.
- The EH/EH2/SV/EH3/SV2/SA/SX/SC main units have a built-in calendar clock, and the clock provides seven sets of data comprising year, week, month, day, hour, minute, and second stored in D1063 to D1069. The TRD command function allows program designers to directly read the current calendar time into the designated seven registers.
- D1063 only reads the two right digits of the Western calendar year.

- When X0 = ON, the current calendar time is read into the designated registers D0 to D6.
- In D1064, 1 indicates Monday, 2 indicates Tuesday, and so on, with and 7 indicating Sunday.

Special D	Item	Content		General D	Item
D1063	Year (Western)	00–99	<b>→</b>	D0	Year (Western)
D1064	Weeks	1–7	<b>→</b>	D1	Weeks
D1065	Month	1–12	<b>→</b>	D2	Month
D1066	Day	1–31	<b>→</b>	D3	Day
D1067	Hour	0–23	<b>→</b>	D4	Hour
D1068	Minute	0–59	<b>→</b>	D5	Minute
D1069	Second	0–59	<b>→</b>	D6	Second




- S: source device. D: device storing GRAY code.
- Transforms the content value (BIN value) of the device designated by **S** to GRAY code, which is stored in the device designated by **D**.
- The valid range of **S** is as shown below; if this range is exceeded, it will be considered an error, and the command will not execute.


16-bit command: 0-32,767

■ 32-bit command: 0–2,147,483,647

Example

When X0 = ON, the constant K6513 will be transformed to GRAY code and stored in D0.







- **S**: source device used to store GRAY code. **D**: device used to store BIN value after transformation.
- The GRAY code corresponding to the value of the device designated by **S** is transformed into a BIN value, which is stored in the device designated by **D**.
- This command will transform the value of the absolute position encoder connected with the PLC's input and (this encoder usually has an output value in the form of GRAY code) into a BIN value, which is stored in the designated register.
- The valid range of **S** is as shown below; if this range is exceeded, it will be considered an error, and the command will not execute.
- 16-bit command: 0-32,767
- 32-bit command: 0–2,147,483,647

Example

When X20 = ON, the GRAY code of the absolute position encoder connected with input points X0 to X17 will be transformed into BIN value and stored in D10.







- S₁: data source device 1. S₂: data source device 2.
- This command performs comparison of the content of S₁ and S₂; when the result of comparison is not 0, this command will be activated, but this command will not be activated when the result of comparison is 0.
- The LD#This command can be used while directly connected with the busbar

API No.	16-bit commands	32-bit commands			ions for	or	Conditions for inactivation				
215	LD&	<b>D</b> LD&	S <sub>1</sub>	&	S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	&	S <sub>2</sub>	=0	
216	LD	<b>D</b> LD	S <sub>1</sub>		S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>		S <sub>2</sub>	=0	
217	LD^	<b>D</b> LD^	S <sub>1</sub>	٨	S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	۸	S <sub>2</sub>	=0	

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When the content of C0 and C10 is subjected to the logical AND operation, and the result is not equal to 0, Y10 = ON.
- When the content of D200 and D300 is subjected to the logical OR operation, and the result is not equal to 0, and X1 = ON, Y11 = ON and remains in that state.







- **S**<sub>1</sub>: data source device 1. **S**<sub>2</sub>: data source device 2.
- This command performs comparison of the content of S₁ and S₂; when the result of comparison is not 0, this command will be activated, but this command will not be activated when the result of comparison is 0.
- The AND# command is an operation command in series with the contact.

AF	PI No.	16-bit commands	32-bit commands			ions for	or	Conditions for inactivation			
2	218	AND&	<b>D</b> AND&	S <sub>1</sub>	&	S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	&	S <sub>2</sub>	=0
2	219	AND	<b>D</b> AND	S <sub>1</sub>		S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	- 1	S <sub>2</sub>	=0
	220	AND^	<b>D</b> AND^	S <sub>1</sub>	٨	S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	٨	S <sub>2</sub>	=0

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When X0 = ON and the content of C0 and C10 is subjected to the logical AND operation, and the result is not equal to 0, Y10 = ON.
- When X1 = OFF and D10 and D0 is subjected to the logical OR operation, and the result is not equal to 0, Y11 = ON and remains in that state.
- When X2 = ON and the content of the 32-bit register D200 (D201) and 32-bit register D100 (D101) is subjected to the logical XOR operation, and the result is not equal to 0 or M3 = ON, M50 = ON.







- S<sub>1</sub>: data source device 1. S<sub>2</sub>: data source device 2.
- This command performs comparison of the content of  $S_1$  and  $S_2$ ; when the result of comparison is not 0, this command will be activated, but this command will not be activated when the result of comparison is 0.
- The OR# command is an operation command in series with the contact.

API No.	16-bit commands	32-bit commands	C	Conditions for activation				ions fo	or inact	ivation
221	OR&	DOR&	S <sub>1</sub>	&	S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	&	S <sub>2</sub>	=0
222	OR	<b>D</b> OR	S <sub>1</sub>		S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>		S <sub>2</sub>	=0
223	OR^	<b>D</b> OR^	S₁	٨	S <sub>2</sub>	<b>≠</b> 0	S <sub>1</sub>	٨	S <sub>2</sub>	=0

- &: logical AND operation.
- |: logical OR operation.
- ^: logical XOR operation.

- When X1 = ON or the content of C0 and C10 is subjected to the logical AND operation, and the result is not equal to 0, Y0 = ON.
- When X2 and M30 are both equal to On, or the content of 32-bit register D10 (D11) and 32-bit register D20 (D21) is subjected to the logical OR operation, and the result is not equal to 0, or the content of the 32-bit counter C235 and the 32-bit register D200 (D201) is subjected to the logical XOR operation, and the result is not equal to 0, M60 = ON.







- S₁: data source device 1. S₂: data source device 2.
- This command compares the content of S₁ and S₂. Taking API 224 (LD=) as an example, this command will be activated when the result of comparison is "equal," and will not be activated when the result is "unequal."
- The LD\* can be used while directly connected with the busbar

API No.	16-bit commands	32-bit commands	Conditions for activation	Conditions for inactivation
224	LD=	<b>D</b> LD=	$\boldsymbol{S_1} =  \boldsymbol{S_2}$	$S_1 \neq S_2$
225	LD>	<b>D</b> LD>	$S_1 > S_2$	$\bm{S_1} \leq \; \bm{S_2}$
226	LD<	<b>D</b> LD<	$S_1 < S_2$	$\textbf{S_1} \geq \ \textbf{S_2}$
228	LD<>	<b>D</b> LD<>	$S_1 \neq S_2$	$S_1 = S_2$
229	LD<=	$\mathbf{D}$ LD $<=$	$S_1 \leq S_2$	$S_1 > S_2$
230	LD>=	$\mathbf{D}$ LD>=	$\textbf{S}_1 \geq \ \textbf{S}_2$	$\textbf{S}_{\textbf{1}} <  \textbf{S}_{\textbf{2}}$

- When the content of C10 is equal to K200, Y10 = ON.
- When the content of D200 is greater than K-30, and X1 = ON, Y11 = ON and remains in that state.







- S₁: data source device 1. S₂: data source device 2.
- This command compares the content of S₁ and S₂. Taking API 232 (AND=) as an example, when the result of comparison is equal, this command will be activated; when the result of comparison is unequal, this command will not be activated.
- The AND\* command is a comparison command in series with a contact.

API No.	16-bit commands	32-bit commands	Conditions for activation	Conditions for inactivation
232	AND=	<b>D</b> AND=	$\bm{S_1}=\bm{S_2}$	$S_1 \neq S_2$
233	AND>	<b>D</b> AND>	$S_1 > S_2$	$\textbf{S}_{\textbf{1}} \leq \ \textbf{S}_{\textbf{2}}$
234	AND<	<b>D</b> AND<	$S_1 < S_2$	$\textbf{S_1} \geq \ \textbf{S_2}$
236	AND <>	<b>D</b> AND<>	$S_1 \neq S_2$	$S_1 = S_2$
237	AND < =	$\mathbf{D}$ and $<=$	$\bm{S_1} \leq \; \bm{S_2}$	$S_1 > S_2$
238	AND>=	$\mathbf{D}$ AND>=	$\bm{S_1} \geq \; \bm{S_2}$	$\textbf{S}_{\textbf{1}} <  \textbf{S}_{\textbf{2}}$

- When X0 = ON and the current value of C10 is also equal to K200, Y10 = ON.
- When X1 = OFF and the content of register D0 is not equal to K-10, Y11 = ON and remains in that state.
- When X2 = ON and the content of the 32-bit register D0 (D11) is less than 678,493, or M3 = ON, M50 = ON.







- S₁: data source device 1. S₂: data source device 2.
- This command compares the content of S₁ and S₂. Taking API 240 (OR=) as an example, when the result of comparison is equal, this command will be activated; when the result of comparison is unequal, this command will not be activated.
- The OR\* command is a compare command in parallel with a contact.

API No.	16-bit commands	32-bit commands	Conditions for activation	Conditions for inactivation
240	OR=	<b>D</b> OR=	$S_1 = S_2$	<b>S</b> <sub>1</sub> ≠ <b>S</b> <sub>2</sub>
241	OR>	<b>D</b> OR>	$S_1 > S_2$	$S_1 \leq S_2$
242	OR<	<b>D</b> OR<	$S_1 < S_2$	$S_1 \geq S_2$
244	OR<>	<b>D</b> OR<>	$S_1 \neq S_2$	$S_1 = S_2$
245	OR<=	<b>D</b> OR<=	$S_1 \leq S_2$	$S_1 > S_2$
246	OR>=	DOR>=	$S_1 \geq S_2$	$S_1 < S_2$

- When X0 = ON and the current value of C10 is also equal to K200, Y10 = ON.
- When X1 = OFF and the content of register D0 is not equal to K-10, Y11 = ON and remains in that state.
- When X2 = ON and the content of the 32-bit register D0 (D11) is less than 678,493, or M3 = ON, M50 = ON.






- S₁: data source device 1. S₂: data source device 2.
- This command compares the content of S₁ and S₂. Taking "FLD=" as an example, if the result of comparison is "equal," this command will be activated; but it will not be activated when the result is "unequal."
- The FLD\* command can directly input floating point numerical values (for instance: F1.2) to the S₁, S₂ operands, or store floating-point numbers in register D for use in operations.
- This command can be used while directly connected with the busbar

API No.	32-bit commands	Conditions for activation	Conditions for inactivation
275	FLD=	$S_1 = S_2$	S <sub>1</sub> ≠ S <sub>2</sub>
276	FLD>	$S_1 > S_2$	$S_1 \leq S_2$
277	FLD<	$S_1 < S_2$	$S_1 \geq S_2$
278	FLD<>	$S_1 \neq S_2$	$S_1 = S_2$
279	FLD<=	$S_1 \leq S_2$	$S_1 > S_2$
280	FLD>=	$S_1 \geq S_2$	$S_1 < S_2$

Example

When the floating point number of register D200 (D201) is less than or equal to F1.2, and X1 activated, contact Y21 will be activated and remain in that state.

```
FLD<= D200 F1.2 SET Y21
```




- S₁: data source device 1. S₂: data source device 2.
- This command compares the content of S₁ and S₂. Taking "FAND=" as an example, if the result of comparison is "equal," this command will be activated; but it will not be activated when the result is "unequal."
- The FAND\* command can directly input floating point numerical values (for instance: F1.2) to the S₁, S₂ operands, or store floating-point numbers in register D for use in operations.
- This command can be used while directly connected with the busbar

API No.	32-bit commands	Conditions for activation	Conditions for inactivation
281	FAND=	$S_1 = S_2$	S <sub>1</sub> ≠ S <sub>2</sub>
282	FAND>	$S_1 > S_2$	$S_1 \leq S_2$
283	FAND<	$S_1 < S_2$	$S_1 \geq S_2$
284	FAND<>	$S_1 \neq S_2$	$S_1 = S_2$
285	FAND <=	$S_1 \leq S_2$	$S_1 > S_2$
286	FAND>=	$S_1 \geq S_2$	$S_1 < S_2$

Example

When X1 = OFF, and the floating point number in register D100 (D101) is not equal to F1.2, Y21 = ON and remains in that state.



- S<sub>1</sub>: data source device 1. S<sub>2</sub>: data source device 2.
- This command compares the content of S₁ and S₂. Taking "FOR=" as an example, if the result of comparison is "equal," this command will be activated; but it will not be activated when the result is "unequal."
- The FOR\* command can directly input floating point numerical values (for instance: F1.2) to the S<sub>1</sub>, S<sub>2</sub> operands, or store floating-point numbers in register D for use in operations.
- This command can be used while directly connected with the busbar

API No.	32-bit commands	Conditions for activation	Conditions for inactivation
287	FOR=	$S_1 = S_2$	S <sub>1</sub> ≠ S <sub>2</sub>
288	FOR>	$S_1 > S_2$	$S_1 \leq S_2$
289	FOR<	$S_1 < S_2$	$S_1 \geq S_2$
290	FOR<>	S <sub>1</sub> ≠ S <sub>2</sub>	$S_1 = S_2$
291	FOR<=	$S_1 \leq S_2$	$S_1 > S_2$
292	FOR>=	$S_1 \geq S_2$	$S_1 < S_2$

Example

When X2 and M30 are both equal to "On," or the floating point number in register D100 (D101) is greater than or equal to F1.234, M60 = ON.

# 16-6-5 Detailed explanation of driver special applications commands

API 139 RPR P S1 S2								<b>S</b> 2		Re	Read servo parameter					
	Bit device Word device 16-bit command (5 STEP)															
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	RPR Continuous RPRP Pulse				
S1				*	*						*	execution type execution type				
S2											*					
Note	es on	oper	and u	sage:	none							32-bit command_				
	50 011	орог	una u	ougo.	110110							; — ; — ; — ; —				
												Flag signal: none				
	nlan	ation	) <b>=</b>	(S1	): Pa	aram	eter :	addre	ess o	of dat	a to	o be read. S2: Register where data to be				

Explanation S1: Parameter address of data to be read. S2: Register where data to be read is stored.

14		v	VPR	P		S1 S2 Write servo parameter							
	Bit device Word device 16-bit command (5 STEP)												
	X	Υ	M	K	Н	KnX	KnY	KnM	T	С	D	WPR Continuous WPRP Pulse	
S1				*	*						*	execution type execution type	
S2				*	*						*		
Notes	on op	erand u	sage:	none								32-bit command_	
			3									- : <del>-</del> : - : -	
												Flag signal: none	
		$\overline{}$		(0.	1) _							(92) -	


Explanation

ΛDI

S1: Data to write to specified page. S2: Parameter address of data to be written.

Example

- When the data in the CP2000 driver's parameter H01.00 is read and written to D0, data from H01.01 will be read and written to D1.
- When M0 = ON, the content of D10 will be written to the CP2000 driver parameter 04.00 (first speed of multiple speed levels).
- When the parameter has been written successfully, M1017 = ON.
- The CP2000's WPR command does not support writing to the 20XX address, but the RPR command supports reading of 21XX, 22XX.



Recommendation Take care when using the WPR command. When writing parameters, because most parameters are recorded as they are written, these parameters may only be revised 109 times; a memory write error may occur if parameters are written more than 109 times.

Because the following commonly-used parameters have special processing, there are **no** restrictions on the number of times they may be written.

Pr.00-11: Speed mode selection

Pr.00-27: User-defined value

Pr.01-12: Acceleration time 1

Pr.01-13: Deceleration time 1

#### Chapter 16 PLC Function Applications | CP2000

Pr.01-14: Acceleration time 2

Pr.01-15: Deceleration time 2

Pr.01-16: Acceleration time 3

Pr.01-17: Deceleration time 3

Pr.01-18: Acceleration time 4

Pr.01-19: Deceleration time 4

Pr.02-12: Select MI Conversion Time mode:

Pr.02-18: Select MO Conversion Time mode:

Pr.04-50-Pr.04-69: PLC register parameter 0-19


Pr.08-04: Upper limit of integral Pr.08-05: PID output upper limit

Pr.10-17: Electronic gear A

Pr.10-18: Electronic gear B

Calculation of the number of times written is based on whether the written value is modified. For instance, writing the same value 100 times at the same time counts as writing only once.

When writing a PLC program, if unsure of usage of the WPR command, we recommend that you use the WPRP command.



- (S1): PID reference target value input terminal select. (S2): PID function proportional gain P. (S3): PID function integral time I. (S4): PID function differential time D.
- The FPID command can directly control the driver's feedback control of PID parameter Pr.08-00 PID reference target value input terminal selection, Pr.08-01 proposal gain P, Pr.08-02 integral time I, and Pr.08-03 differential time D.

- When M0 = ON, the set PID reference target value input terminal selection is 0 (no PID function), the PID function proportional gain P is 0, the PID function integral time I is 1 (units: 0.01 sec.), and the PID function differential time D is 1 (units: 0.01 sec.).
- When M1 = ON, the set PID reference target value input terminal selection is 0 (no PID function), the PID function proportional gain P is 1 (units: 0.01), the PID function integral time I is 0, and the PID function differential time D is 0.
- When M2 = ON, the set PID reference target value input terminal selection is 1 (target frequency input is controlled from the digital keypad), the PID function proportional gain P is 1 (units: 0.01), the PID function integral time I is 0, and the PID function differential time D is 0.
- D1027: Frequency command after PID operation.

```
M0
  4 F
                                         FPID
                                                          H0
                                                                         H<sub>0</sub>
                                                                                        H1
                                                                                                       H1
  M1
                                         FPID
                                                          H<sub>0</sub>
                                                                                        H<sub>0</sub>
                                                                                                       H<sub>0</sub>
                                                                         H1
  M2
                                         FPID
                                                          H1
                                                                         H1
                                                                                        H<sub>0</sub>
                                                                                                       H<sub>0</sub>
   ┨┠
M1000
                                                       D1027
   ┨┠
                                         MOV
                                                                         D1
                                         END
```

AF 14		F	REC	P		<b>S</b> 1	(S2	(S:	3	Dı	river	speed control mode
	Bit device Word device					devic		16-bit command (7 STEP)				
	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	FREQ Continuous FREQP Pulse
S1				*	*						*	execution type execution type
S2				*	*						*	 ∷32-bit command
S3				*	*						*	32-bit confinant
Note	Notes on operand usage: none  Flag signal: M1015											

- $\frac{(S1)}{S1}$ : Frequency command.  $\frac{(S2)}{S1}$ : Acceleration time.  $\frac{(S3)}{S1}$ : Deceleration time
- S2, S3: In acceleration/deceleration time settings, the number of decimal places is determined by the definitions of Pr.01-45.

#### Example

When Pr.01-45=0: units of 0.01 sec.

The setting of 50 for S2 (acceleration time) in the ladder diagram below implies 0.5 sec, and the S3 (deceleration time) setting of 60 implies 0.6 sec

■ The FREQ command can control driver frequency commands, and acceleration and deceleration time; it also uses special register control actions, such as:

M1025: Control driver RUN(On)/STOP(Off) (RUN requires Servo On (M1040 On) to be effective)

M1026: Control driver operating direction FWD(Off)/REV(On)

M1040: Control Servo On/Servo Off.

M1042: Trigger quick stop (ON)/does not trigger quick stop (Off).

M1044: Pause (On)/release pause (Off)


M1052: Lock frequency (On)/release lock frequency (Off)

Example

- M1025: Driver RUN (On) / STOP (Off), M1026: driver operating direction FWD (Off) / REV (On). M1015: frequency reached.
- When M10 = ON, sets the driver frequency command K300 (3.00 Hz), with an acceleration/deceleration time of 0.

When M11 =ON, sets the driver frequency command K3000 (30.00 Hz), with an acceleration time of 50 (0.5 sec.) and deceleration time of 60 (0.6 sec.). (When Pr.01-45=0)


■ When M11 = OFF, the driver frequency command will now change to 0



■ Pr.09-33 are defined on the basis of whether the reference commands have been cleared before PLC operation.

bit0: Prior to PLC scanning procedures, whether the target frequency has been cleared is 0. (This will be written to the FREQ command when the PLC is ON).

Example: When using r to write a program




If we force M0 to be 1, the frequency command will be 20.00 Hz; but when M0 is set as 0, there will be a different situation.

- Case 1: When the bit0 of Pr.09-33 is 0, and M0 is set as 0, the frequency command remains at 20.00 Hz.
- Case 2: When the bit0 of Pr.09-33 is 1, and M0 is set as 0, the frequency command changes to 0.00 Hz.

The reason is that when the Pr.09-33 bit0 is 1 prior to the PLC scanning procedures, the frequency will firstly revert to 0.

When the Pr.09-33 bit0 is 0, the frequency will not revert to 0.




- (S1): Slave station number. (S2): Main index. (S3): Subindex+bit length. (D): Preset address.
- The CANRX command can read the index of the corresponding slave station. When it is executed, it will send the SDO message format to the slave station. M1066 and M1067 will both be 0 at that time, and M1066 will be set as 1 after reading. If the slave station gives the correct response, it will write the value to the preset register, and set M1067 as 1. If the slave station has a response error, M1067 will be set as 0, and an error message will be recorded to D1076 to D1079.

Example

M1002: When the PLC runs, the command will be triggered once and will set K4M400 = K1

Afterwards, each time M1066 is 1, it will switch to a different message.



	Bit device Word device							16-bit command (9 STEP)				
Ì	Χ	Υ	M	K	Н	KnX	KnY	KnM	Т	С	D	CANTX Continuous CANTXP Pulse
S1				*	*							execution type execution type
S2				*	*				*	*	*	
S3				*	*							32-bit command
S4				*	*							

- (S1): Slave station number. (S2): Address to be written. (S3): Main index. (S4): Subindex+bit length.
- The CANTX command can write a value to the index of the corresponding slave station. When it is executed, it will send the SDO message format to the slave station. M1066 and M1067 will both be 0 at that time, and M1066 will be set as 1 after reading. If the slave station gives the correct response, it will write the value to the preset register, and set M1067 as 1. If the slave station has a response error, M1067 will be set as 0, and an error message will be recorded to D1076 to D1079.


API 265 CANFLS P						R	Refresh special D corresponding to CANopen					
	Bit device Word device							16-bit command (3 STEP)				
lì	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	CANFLS: Continuous CANFLSP: Pulse
D				*	*							execution type execution type
Notes on operand usage: none								32-bit command — — — — — — — — Flag signal				
<u> </u>					`							

Explanation

- : Special D to be refreshed.
- The CANFLS command can refresh special D commands. When is a read only attribute, executing this command will send a message equivalent to that of CANRX to the slave station, and the number of the slave station will be transmitted back and refreshed to this special D. When there is a read/write attribute, executing this command will send a message equivalent to that of CANTX to the slave station, and the value of this special D will be written to the corresponding slave station.
- When M1066 and M1067 are both 0, and M1066 is set as 1 after reading, if the slave station gives a correct response, the value will be written to the designated register, and M1067 will be set as 1. If the slave station's response contains an error, then M1067 will be set as 0, and an error message will be recorded to D1076-D1079.

	API 320 D ICOMR P S1 S2 S3 D Inter										terna	al communications read
	Bit device Word device						Vord	16-bit command (9 STEP)				
Ì	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ICOMR Continuous ICOMRP Pulse
S1				*	*						*	execution type execution type
S2				*	*						*	32-bit command (17 STEP)
S3				*	*						*	DICOMR: Continuous :DICOMRP: Pulse
D				*	*						*	execution type execution
Note	Notes on operand usage: none										Flag signal: M1077 M1078 M1079	

- Explanation S1: Selection of slave device. S2: Device selection (0: converter, 1: internal PLC). S3: Read address. D: Saving target.
  - The ICOMR command can obtain the slave station's converter and the internal PLC's register value.





S1: Selection of slave device. S2: Device selection (0: converter, 1: internal PLC). S3: Read address. D: Saving target.

■ The ICOMW command write a value to the slave station's converter and the internal PLC's register.

Example

#### Please refer to the following example:





S1: Data that is going to write in S2: Parameter address of the write-in data

Example

- Read the data of CP2000 drive's parameter H01.00 and write into D0, read data of H01.01 and write into D1.
- When M0 is ON, write the content of D10 into CP2000 drive's Pr.04-00 (1st step speed frequency).
- When parameter writes-in successfully, M1017 is ON.
- The WPR command does not support the write-in of 20XX address, but the RPR command supports the read-out of 21XX and 22XX.

Recommendation

When WPRA executes, the data is only written into the RAM area, and will get back to previous record when the power is off.

# 16-7 Error display and handling

Code	ID	Description	Recommended handling approach		
PLrA	47	RTC time check	Turn power on and off when resetting the		
PLIA	47	RTC time check	keypad time		
PLrt	49	incorrect RTC mode	Turn power on and off after making sure		
1 LIC	70	moonest it o mode	that the keypad is securely connected		
PLod	50	Data writing memory error	Check whether the program has an error		
1 200			and download the program again		
PLSv	51		Restart power and download the program		
		program execution	again		
PLdA	52	Program transmission error	Try uploading again; if the error persists,		
		Ţ.	sent to the manufacturer for service		
PLFn	53		Check whether the program has an error		
		program	and download the program again		
PLor	54		Restart power and download the program		
. 201	•	or no program	again		
PLFF	55		Check whether the program has an error		
		execution	and download the program again		
PLSn	56	Check code error	Check whether the program has an error		
. 2011			and download the program again		
PLEd	57		Check whether the program has an error		
1 229	07	command	and download the program again		
PLCr	58		Check whether the program has an error		
. 20.		continuously more than nine times	and download the program again		
PLdF	59	Download program error	Check whether the program has an error		
I Edi	3	Download program error	and download again		
PLSF	60	PLC scan time excessively long	Check whether the program code has a		
1 201	00	1 20 30dil tillic chocssively long	writing error and download again		

# 16-8 CANopen Master control applications


Control of a simple multi-axis application is required in certain situations. If the device supports the CANopen protocol, a CP2000 can serve as the master in implementing simple control (speed control). The setting method comprises the following seven steps:

# Step 1: Activating CANopen Master functions


- 1. Pr.09-45 = 1 (initiates Master functions); restart power after completing setting, the status bar on the KPC-CC01 digital keypad will display "CAN Master".
- Pr.00-02 = 6 reset PLC (please note that this action will reset the program and PLC registers to the default values)
- 3. Turn power off and on again.
- 4. Use the KPC-CC01 digital keypad to set the PLC control mode as "PLC Stop" (if a newly-introduced driver is used, the blank internal PLC program will cause a PLFF warning code to be issued).

# Step 2: Master memory settings


- After connecting the 485 communications cable, use WPL Soft to set the PLC status as Stop (if the PLC mode has been switched to the "PLC Stop" mode, the PLC status should already be Stop)
- 2. Set the address and corresponding station number of the slave station to be controlled. For instance, if it is wished to control two slave stations (a maximum of 8 stations can be controlled simultaneously), and the station numbers are 21 and 22, it is only necessary to set D2000 and D2100 as 20 and 21, and then set D2200, D2300, D2400, D2500, D2600, and D2700 as 0. The setting method involves use of the PLC's WPL editing software WPL as follows:
  - Open WPL and implement communications > register edit (T C D) function



After leaving the PLC register window, the register setting screen will appear, as shown below:



If there is a new PLC program and no settings have yet been made, you can read default data from the converter, and merely edit it to suit the current application. If settings have already been made, however, the special D in the CANopen area will display the saved status (the CANopen D area is located at D1090 to D1099 and D2000 to D2799). Assuming it is a new program, we will first read the default data from the converter; check the communications format if there is no communications link (the default PLC station number is 2, 9600, 7N2, ASCII). Perform the following steps: 1. Switch the PLC to Stop status; 2. Press the transmit button; 3. click on read memory after exiting the window; 4. Ignore D0-D399; and 5. click on the confirm button.)



After reading the data, it is necessary to perform some special D settings. Before proceeding, we will first introduce the special D implications and setting range. The CANopen Master's special D range is currently D1070 to D1099 and D2000 to D2799; this range is divided into 3 blocks:

The first block is used to display CANopen's current status, and has a range of D1070 to D1089; the second block is used for CANopen's basic settings, and has a range of D1090 to D1099; the third block is the slave station mapping and control area, and has a range of D2000 to D2799;

These areas are therefore introduced as follows:

The first contains the current CANopen status display:

When the master initializes a slave station, we can find out from D1070 whether configuration of the slave device has been completed; we can find out whether an error occurred in the configuration process from D1071 and whether the configuration is inappropriate from D1074. After entering normal control, we can find out whether the slave device is offline from D1073. In addition, we can check the slave device's read/write information using the CANRX, CANTX, and CANFLS commands; error information can be obtained from D1076 to D1079 if there has been a read/write failure.

Special D	Description of Function	R/W
	Channel opened by CANopen initialization (bit0=Machine code0)	R
1 11111/1	Error channel occurring in CANopen initialization process (bit0=Machine code0)	R
D1072	Reserved	-

Special D	Description of Function	R/W
D1073	CANopen break channel (bit0=Machine code0)	R
D1074	Error code of master error  0: No error  1: Slave station setting error  2: Synchronizing cycle setting error (too small)	R
D1075	Reserved	_
D1076	SDO error message (main index value)	R
D1077	SDO error message (secondary index value)	R
D1078	SDO error message (error code L)	R
D1079	SDO error message (error code H)	R

The second area is for basic CANopen settings: (the PLC must have **stopped** when this area is used to make settings)

We must set the information exchange time for the master and slave station,

Special D	Description of Function	Default:	R/W
D1090	Synchronizing cycle setting	4	RW

Use D1090 to perform settings; setting time relationships include:

Sync time 
$$\geqslant \frac{1M}{Rate} * \frac{N}{4}$$


N: TXPDO + RXPDO

For instance, when communications speed is 500Kbps, TXPDO + RXPDO have 8 sets, and synchronizing time will require more than 4 ms

We must also define how many slave stations will be open. D1091 is the channel for defining station opening, and D2000+100  $\times$  n is the station number defining this channel. See the detailed explanation below.

Slave station number  $\mathbf{n} = 0-7$ 

Special D	Description of Function	R/W
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Sets slave station On or Off (bit0-bit 7 correspond to slave stations number 0-7)	RW
D2000+100* <b>n</b>	Slave station number	RW



If slave devices have a slow start-up, the master can delay for a short time before performing slave station configuration; this time delay can be set via D1092.

Special D	Description of Function	Default:	R/W
D1092	Delay before start of initialization	0	RW

With regard to slave device initialization, a delay time can be set to judge whether failure has occurred. If the communications speed is relatively slow, the delay time can be adjusted to judge whether initialization has been completed, which will ensure that there is time to perform slave device initialization.

Special D	Description of Function	Default:	R/W
1111144	Initialization completion delay time Setting range: 1 to 60000 sec	15 sec.	RW

After communication is successful, the system must detect whether there is a break in communications with the slave station. D1093 is used to set detection time, and D1094 sets the number of consecutive errors that will trigger a break error.

	Special D	Description of Function	Default:	R/W
Ī	D1093	Break time detection	1000ms	RW
Ī	D1094	Break number detection	3	RW

The packet type transmitted by PDO is set before establishing normal communications and generally does not require adjustment.

Special D	Description of Function	Default:	R/W
D1097	Corresponding real-time transmission type (PDO) Setting range: 1–240	1	RW
	Corresponding real-time receiving type (PDO) Setting range: 1–240	1	RW

The third block is the slave station mapping and control area.

CANopen provides a PDO method to perform mapping of the master and slave station memory, and enables the master to directly access read/write data in a certain memory area. The master will automatically perform data exchange with the corresponding slave device, and the read/write values can be seen directly from the special D area after real-time exchange (M1034 = 1 time) has been established. The CP2000 currently supports real-time mapping of four PDOs, and there are two types of PDO RXPDO (reads slave device information) and TXPDO (writes to slave device). In addition, in order to facilitate control, the CP2000 cannot perform mapping of commonly used registers; the following is an overview of the current PDO mapping situation:

TX PDO				
PDO2 (R	emote I/O)	PDO1	(Speed)	
Description	Special D	Description	Special D	
Slave device DO	D2027 + 100 × n	Controller word	D2008 + 100 × n	
Slave device AO1	D2031 + 100 × n	Target speed	D2012 + 100 × n	
Slave device AO2	D2032 + 100 × n			
Slave device AO3	D2033 + 100 × n			

RXPDO					
PDO2 (Re	emote I/O)	PDO1 (	Speed)		
Description	Special D	Description	Special D		
Slave device DI	D2026 + 100 × n	Mode word	D2009 + 100 × n		
Slave device Al1	D2028 + 100 × n	Actual frequency	D2013 + 100 × n		
Slave device Al2	D2029 + 100 × n				
Slave device Al3	D2030 + 100 × n				

Because usage requires only simple to open the corresponding PDO, where TXPDO employs D2034+100\*n settings and RXPDO employs D2067+100\*n settings.

These two special D areas are defined as follows:

	PDO2		PDO1		
Default definition	Remote I/O		Speed		
bit	7	6–4	3	2–0	
Definition	En	Length:	En	Length:	

En: indicates whether PDO is used

Length: indicates mapping of several variables

In a simple example, if we wish to control a CP2000 slave device and cause it to operate in speed mode, we only have to make the following settings:

#### D2034+100\*n =000Ah

		TX P				
Length	PDO2		PDO2		PD	001
	Description	Special D	Description	Special D		
1	Slave device DO	D2027 + 100 × n	Controller word	D2008 + 100 × n		
2	Slave device AO1	D2031 + 100 × n	Target speed	D2012 + 100 × n		
3	Slave device AO2	D2032 + 100 × n				
4	Slave device AO3	D2033 + 100 × n				

	PDO2		PDO1		
Definition	Remote I/O		Speed		
bit	7	6–4	3	2–0	
Definition	0	0	0 1 2		

#### D2067+100\*n =000Ah

	TX PDO				
Length	PDO2		PD	01	
	Description	Special D	Description	Special D	
1	Slave device DI	D2026 + 100 × n	Controller word	D2009 + 100 × n	
2	Slave device Al1	D2028 + 100 × n	Actual frequency	D2013 + 100 × n	
3	Slave device Al2	D2029 + 100 × n			
4	Slave device Al3	D2030 + 100 × n			

	PDO2		PDO1		
Definition	Remote I/O		Speed		
bit	7	6–4	3	2–0	
Definition	0	0 1			

Switch the PLC to Run after completing settings. Now wait for successful initialization of CANopen (M1059 = 1 and M1061 = 0), and then initiate CANopen memory mapping (M1034 = 1). The control word and frequency command will now automatically refresh to the corresponding slave device (D2008 + n  $\times$  100 and D2012 + n  $\times$ 100), and the slave device's status word and currently frequency will also be automatically sent back to the master station (D2009 + n  $\times$  100 and

D2013 + n  $\times$  100). This also illustrates how the master can handle these tasks through read/write operations in the special D area.

Furthermore, it should be noted that the remote I/O of PDO2 can obtain the slave device's current DI and AI status, and can also control the slave device's DO and AO status. Nevertheless, after introducing a fully automatic mapping special D, the CP2000 CANopen master also provides additional information refreshes. For instance, while in speed mode, acceleration/deceleration settings may have been refreshed. The special D therefore also stores some seldom-used real-time information, and these commands can be refreshed using the CANFLS command. The following is the CP2000's current CANopen master data conversion area, which has a range of  $D2001 + 100 \times n - D2033 + 100 \times n$ , as shown below:

- 1. The range of n is 0-7
- 2. ●Indicates PDOTX, ▲Indicates PDORX; unmarked special D can be refreshed using the CANFLS command

Special D	Description of Function		PDO Default		R/W	
Special D	Description of Function	Default	1	2	1 1/ 1/ 1/	
	Station number n of slave station Setting range: 0–127 0: No CANopen function	0			RW	
	Manufacturer code of slave station number n (L)	0			R	
D2003 + 100 × n	Manufacturer code of slave station number n (H)	0			R	
11 1 / 1 / 1 / 1 / 1 / 1 / 1	Manufacturer's product code of slave station number n (L)	0			R	
111/005 + 100 × n	Manufacturer's product code of slave station number n (H)	0			R	

#### **Basic definitions**

Special D	Description of Function	Default	PDO I	Default 2	R/W
D2006 + 100 × n	Communications break handling method of slave station number n	0			RW
D2007 + 100 × n	Error code of slave station number n error	0			R
D2008 + 100 × n	Control word of slave station number n	0	•		RW
D2009 + 100 × n	Status word of slave station number n	0	•		R
D2010 + 100 × n	Control mode of slave station number n	2			RW
D2011 + 100 × n	Actual mode of slave station number n	2			R


# Velocity Control

Special D	Description of Function		PDO Default		R/W
·	·		1	2	
D2001 + 100 × n	Torque restriction on slave station number n	0			RW
D2012 + 100 × n	Target speed of slave station number n (rpm)	0	•		RW
D2013 + 100 × n	Actual speed of slave station number n (rpm)	0	<b>A</b>		R
D2014 + 100 × n	Error speed of slave station number n (rpm)	0			R
D2015 + 100 × n	Acceleration time of slave station number n (ms)	1000			RW
D2016 + 100 × n	Deceleration time of slave station number n (ms)	1000			RW

Remote I/O

Special D	Description of Function	Default	PDO Default		R/W
•	·	Delauit	1	2	1 1/ V V
	MI status of slave station number n	0		<b>A</b>	R
D2027 + 100 × n	MO setting of slave station number n	0		•	RW
D2028 + 100 × n	Al1 status of slave station number n	0		<b>A</b>	R
D2029 + 100 × n	Al2 status of slave station number n	0		<b>A</b>	R
D2030 + 100 × n	Al3 status of slave station number n	0		<b>A</b>	R
D2031 + 100 × n	AO1 setting of slave station number n	0		•	RW
D2032 + 100 × n	AO2 setting of slave station number n	0		•	RW
D2033 + 100 × n	AO3 setting of slave station number n	0	·	•	RW

After gaining an understanding of special D definitions, we return to setting steps. After entering the values corresponding to D1090 to D1099, D2000+100\*n, D2034+100\*n and D2067+100\*n, we cannot begin to perform downloading, which is performed in accordance with the following steps: (1. D2000 and D2100 are set as 20 and 21, and D2200, D2300, D2400, D2500, D2600, and D2700 are set as 0; if a setting of 0 causes problems, D1091 can be set as 3, and slave stations 2 to 7 can be closed. 2. Switch PLC to Stop status. 3. Press the transmit button. 4. Click on write memory after exiting the window. 5. Ignore D0–D399. 6. Change the second range to D1090–D1099. 7. Click on Confirm.)



■ Another method can be used to set D1091: Determine which of slave stations 0 to 7 will not be needed, and set the corresponding bits to 0. For instance, if it is not necessary to control slave stations 2, 6 and 7, merely set D1091 = 003B, and the setting method is the same as described above: Use WPL to initiate communications > use register edit (T C D) function to perform settings.

# Step 3: Set the master's communications station number and communications speed

- When setting the master's station number (Pr.09-46, default is set as 100), make sure not to use the same number as a slave station.
- ☑ Set the CANopen communications speed (Pr.09-37); regardless of whether the driver is defined as a master or slave station, the communications speed is set via this parameter.

### Step 4: Write program code

Real-time access: Can directly read/write to or from the corresponding D area.

Non real-time access:

#### Read command:

Use the CANRX command for reading. M1066 will be 1 when reading is complete; M1067 will be 1 if reading is successful, and M1067 will be 0 if an error has occurred.

#### Write command:

Use the CANTX command for writing. M1066 will be 1 when writing is complete; M1067 will be 1 if writing is successful, and M1067 will be 0 if an error has occurred.

#### Refresh command:

Use CANFLS command to refresh (if there are RW attributes, the master will write to the slave station; if there are RO attributes, the slave station will return the read values to the master); M1066 will be 1 if refresh has been completed; M1067 will be 1 if refresh is successful, and M1067 will be 0 if an error has occurred.

#### NOTE

When using CANRX, CANTX or CANFLS, internal implementation commands will wait until M1066 is completed before executing the next CANRX, CANTX or CANFLS.

Afterwards, download program to the driver (Please note that the PLC's default communications format is ASCII 7N2 9600, and the station number is 2. The WPL must therefore be modified, and the WPL setting pathway is **settings** > **communications settings**)

Step 5: Set the slave stations' station numbers, communications speed, control source, and command source

Delta's CP2000 and EC series devices currently support the CANopen communications interface driver, and the corresponding slave station numbers and communications speed parameters are as follows:


	Corresponding device parameters		Value	Definition
	CP2000	E-C		
Slave station	09-36	09-20	0	Disable CANopen hardware interface
address	09-30	09-20	1–127	CANopen Communication address
Communication speed	09-37	09-21	0	1 Mbps
			1	500 Kbps
			2	250 Kbps
			3	125 Kbps
			4	100 Kbps
			5	50 Kbps

Delta's A2 Servo currently supports the CANopen communications interface, and the corresponding slave station numbers and communications speed parameters are as follows:

	Corresponding device parameters A2	Value	Definition
Slave station address	Pr.03-00	1–127	CANopen Communication address
Communication speed	Pr.03-01 bit8-11 XRXX	R= 0	125 Kbps
		R= 1	250 Kbps
		R= 2	500 Kbps
		R= 3	750 Kbps
		R= 4	1 Mbps
Control/command source	Pr.01-01	В	

Step 6: Connect hardware wiring

When performing wiring, note the head and tail terminal resistance; connection methods are as follows:



# Step 7: Initiate control

After a program has been written and downloaded, switch the PLC mode to Run. Merely turn power to master and slave stations off and then on again.

Refer to CANMasterTest 1 vs. 2 driver.dvp

#### Example:

CP2000 driver one-to-two control

#### Step 1: Activating CANopen Master functions

- ☑ Pr.09-45 = 1 (initiates Master functions); restart power after completing setting, the status bar on the KPC-CC01 digital keypad will display "CAN Master".
- ☑ Pr.00-02 = 6 reset PLC (please note that this action will reset the program and PLC registers to the default values)
- ☑ Turn power off and on again.
- ☑ Use the KPC-CC01 digital keypad to set the PLC control mode as "PLC Stop" (if a newly-introduced driver is used, the blank internal PLC program will cause a PLFF warning code to be issued).

#### Step 2: Master memory correspondences

- ☑ Enable WPL
- ☑ Use keypad set PLC mode as Stop (PLC 2)
- ☑ WPL read D1070 to D1099, D2000 to D2799
- ☑ Set D2000 = 10 D2100 = 11
- ☑ Set D2100 2200 2300 2400 2500 2600 2700 = 0
- ☑ Download D2000 to D2799 settings

# Step 3: Set the master's communications station number and communications speed

- ☑ When setting the master's station number (Pr.09-46, default is set as 100), make sure not to use the same number as a slave station.
- ☑ Set the CANopen communications speed as 1M (Pr.09-37 = 0); regardless of whether the driver is defined as a master or slave station, the communications speed is set via this parameter.

## Step 4: Write program code

Real-time access: Can directly read/write to or from the corresponding D area.

Non real-time access:

#### Read command:

Use the CANRX command for reading. M1066 will be 1 when reading is complete; M1067 will be 1 if reading is successful, and M1067 will be 0 if an error has occurred.

#### Write command:

Use the CANTX command for writing. M1066 will be 1 when writing is complete; M1067 will be 1 if writing is successful, and M1067 will be 0 if an error has occurred.

#### Refresh command:

Use CANFLS command to refresh (if there are RW attributes, the master will write to the slave station; if there are RO attributes, the slave station will return the read values to the master); M1066 will be 1 if refresh has been completed; M1067 will be 1 if refresh is successful, and M1067 will be 0 if an error has occurred.

# NOTE

When using CANRX, CANTX or CANFLS, internal implementation commands will wait until M1066 is completed before executing the next CANRX, CANTX or CANFLS.


Afterwards, download program to the driver (Please note that the PLC's default communications format is ASCII 7N2 9600, and the station number is 2. The WPL must therefore be modified, and the WPL setting pathway is **settings** > **communications settings**)

# Step 5: Set the slave stations' station numbers and communications speed

Slave station no. 1: Pr.09-37 = 0 (Speed 1M) Pr.09-36 = 10 (Node ID 10) Slave station no. 2: Pr.09-37 = 0 (Speed 1M) Pr.09-36 = 10 (Node ID 11)

#### Step 6: Connect hardware wiring

When performing wiring, note the head and tail terminal resistance; connection methods are as follows:



### Step 7: Initiate control

After a program has been written and downloaded, switch the PLC mode to Run. Merely turn power to master and slave stations off and then on again.

Refer to CANMasterTest 1 vs. 2 driver.dvp

# 16-9 Explanation of various PLC speed mode controls

Speed mode supports SVC control. Under the speed mode of SVC control, it cannot be performed successfully unless finish motor parameter auto tuning ahead of time.

Control methods and settings are explained as follows:

#### Speed control:

Register table for speed mode:

#### Control special M

Special M	Description of Function	Attributes
M1025	Driver frequency = set frequency (ON)/driver frequency =0 (OFF)	RW
M1026	Driver operating direction FWD(OFF)/REV(ON)	RW
M1040	Hardware power (Servo On)	RW
M1042	Quick stop	RW
M1044	Pause (Halt)	RW
M1052	Lock frequency (lock, frequency locked at the current operating frequency)	RW

#### Status special M

Special M	Description of Function	Attributes
M1015	Frequency attained (when used together with M1025)	RO
M1056	Servo On Ready	RO
M1058	On Quick Stopping	RO

#### Control special D

Special	Description of Function	Attributes
D1060	Mode setting (speed mode is 0)	RW

## Status special D

Special D	Description of Function	Attributes
D1037	Converter output frequency (0.00–600.00)	RO
D1050	Actual operating mode (speed mode is 0)	RO

#### Speed mode control commands:

**FREQ (P)** S1 S2 S3

Target speed The first acceleration time setting The first deceleration time setting

Example of speed mode control:

Before performing speed control, if the SVC control method is used, setting of electromechanical parameters must first be completed.

- 1. Setting D1060 = 0 will shift the converter to the speed mode (default).
- 2. Use the FREQ command to control frequency, acceleration time, and deceleration time.
- 3. Set M1040 = 1, the driver will now be excited, but the frequency will be 0.
- 4. Set M1025 = 1, the driver frequency command will now jump to the frequency designated by FREQ, and acceleration/deceleration will be controlled on the basis of the acceleration time and deceleration time specified by FREQ.
- 5. M1052 can be used to lock the current operating frequency.
- M1044 can be used to temporarily pause operation, and the deceleration method will comply with deceleration settings.

- 7. M1042 can be used to perform quick stop, and deceleration will be as quick as possible without giving rise to an error. (There may still be a jump error if the load is too large.)
- 8. Control user rights: M1040(Servo ON) > M1042(Quick Stop) > M1044(Halt) > M1052(LOCK)

```
0
      M1002
                                                MOV
         11
                                                         K0
                                                                D1060
       start running forward (instantaneously)
                                                     control mode setup (0: speed)
         X0
6
         1
                                        FREQ
                                                 K3500
                                                          K100
                                                                 K200
         X<sub>0</sub>
14
                                        FREQ
                                                 K4500
                                                          K40
                                                                  K50
                                                                (M1026)
                                                          running direction
        X1
-|-
23
                                                          of the motor drive FWD(OFF)
                                                                (M1040)
                                                                 Servo On
        X2
25
         11
                                                                (M1025)
                                                        running direction of the
         X3
                                                        motor drive RUN(ON)STOP(OFF)
27
                                                                (M1044)
29
         X4
         11
                                                                (M1052)
                                                                frequency locked
        X5
-| |-
31
                                                                (M1042)
                                                                quick stop
33
                                                                 END
9999
```

## 16-10 Internal communications main node control

The protocol has been developed in order to facilitate the use of 485 instead of CANopen in certain application situations. The 485 protocol offers similar real-time characteristics as CANopen; this protocol can only be used on the CP2000 and CT2000 devices. The maximum number of slave devices is 8.

Internal communications have a master-slave structure. The initiation method is very simple:

#### Slave device:


Set Pr.09-31 = -1 to -8 in order to access 8 nodes, and set Pr.00-20 = 1 to define the control source as 485 and access the reference sources that must be controlled, namely speed command (Pr.00-21 = 2). This will complete slave device settings. (PLC functions do not need to be activated)

#### System:

Setting the master is even simpler; it is only necessary to set Pr.09-31 = -10, and enable the PLC.

#### Hardware wiring:

The master and slave stations are connected via the 485 serial port. The CP2000 provide two types of 485 serial port interfaces, see the figure below: (please refer to Section 06 Control terminals concerning detailed terminal connections)



#### Chapter 16 PLC Function Applications | CP2000

Master programming: In a program, D1110 can be used to define a slave station to be controlled (1–8, if set as 0, can jump between 8 stations). Afterwards, M1035 is set as 1, and the memory positions of the master and slave stations will correspond. At this time, it is only necessary to send commands to the correlation slave station address to control that station. The following is a register table connected with internal communications:

#### Control special M

Special M	Description of Function	Attributes
M1035	Initiates internal communications control	RW

## Control special D

	Special D	Description of Function	Attributes
	1 1)1110	Internal node communications number 1–8 (set the station number of the slave	RW
		station to be controlled)	1

	Descripti	on of Fund	ction		Attributes
Special D	Definition	bit	User rights	Speed mode	
		0	4	Command functions	
		1	4	Reverse rotation requirements	
		2	4	-	
		3	3	Temporary pause	
		4	4	Frequency locking	
D1120 + 10 × N	Internal node N control command	5	4	JOG	RW
		6	2	Quick Stop	
		7	1	Servo ON	
		11–8	4	Speed interval switching	
		13–12	4	Deceleration time change	
		14	4	Enable bit13–8	
		15	4	Clear error code	
D1121 + 10 × N	Internal node N control mode			0	RW
D1122 + 10 × N	Internal node N reference command L			Speed command (no number)	RW
D1123 + 10 × N	Internal node N reference command H			-	RW

**※** N = 0−7

#### Status special D

Special D	Description of Function	Attributes
D1115	Internal node synchronizing cycle (ms)	RO
D1116	Internal node error (bit0 = slave device 1, bit1 = slave device 2,bit7 = slave device 8)	RO
D1117	Internal node online correspondence (bit0 = slave device 1, bit1 = slave device 2,bit7 = slave device 8)	RO

Special D	Description of Function				
Special D	bit	Speed mode			
	0	Frequency command arrival			
	1	Clockwise			
	1	Counterclockwise:			
D1126 + 10 × N	2	Warning	RO		
D1120 + 10 ^ N	3	Error			
	5	JOG			
	6	Quick Stop			
	7	Servo ON			
D1127 + 10 × N		Actual frequency	RO		
D1128 + 10 × N		<del>-</del>	1.0		

**※** N = 0−7


Example: Assume it is desired to control slave station 1 operation at frequencies of 30.00 Hz and 60.00 Hz, status, and online node correspondences:

```
M1000
                                                  MOV
                                                          D1117
                                                                   K1M700
                                                      Internal node Node 0 online
Normally open contact of
                                                      online mapping
operation monitoring (a)
                                                  MOV
                                                                   K4M250
                                                          D1126
                                                        Status of
                                                                    Node 0 arrive
                                                        internal node 0
                                                  MOV
                                                                     D1120
                                                         K4M200
                                                                    Control command of
                                                        Node 0 ack
                                                                    internal node 0
                                                                   (M1035)
                                                                   Ènable internal
                                                                  communication
                                                                  control
```

When it is judged that slave station 1 is online, delay 3 sec. and begin control

```
17
       M700
        4 F
                                                           MOVP
                                                                    K0
                                                                         D1121
       Node 0 ohline
                                                                       Control mode of
                                                                       internal node 0
                                                           TMR
                                                                            K30
                                                                    T0
                                                                   Enable Control Delay
                    T0
                                                                       ( M100 )
                   Enable Control Delay
                                                                        Enable Control
                   T0
                                                                       (M215)
                                                                         Reset
                   Enable Control Delay
33
       M100
        ┨┠
                                                           MOVP
                                                                    K0
                                                                          D1121
       Enable Control
                                                                        Control mode of
                                                                       internal node 0
                                                                        (M207)
                                                                        Node 0 Servo On
                                                                       (M200)
                                                                        Node 0 Ack
```

It is required slave station 1 maintain forward rotation at 30.00 Hz for 1 sec., and maintain reverse rotation at 60.00 Hz for 1 sec., and repeat this cycle continuously.



## 16-11 Modbus remote IO control applications (use MODRW)

The CP2000's internal PLC supports 485 read/write functions, which can be realized using the MODRW command. However, the 485 serial port must be defined as available for the PLC's 485 use before writing a program, and the Pr.09-31 must be set as -12. After completing settings, the standard functions defined by 485 can be used to implement read/write commands at other stations. Communications speed is defined by Pr.09-01, the communications format is defined by Pr.09-04, and the PLC's current station number is defined by Pr.09-35. The CP2000 currently supports the functions read coil (0x01), read input (0x02), read register (0x03), write to single register (0x06), write to several coils (0x0F), and write to several registers (0x10). Explanations and the usage of these functions are provided as follows:

	MODR	W comr	nand				
S1	S2	S3	S4	S5	General	Slave device is Delta's PLC	Slave device is Delta's
Node ID	Command	Address	Return: D area	Length:	meaning	meaning	converter meaning
КЗ	H01	H500	D0	K18	Read coil (Bit)	Read 18 bits of data corresponding to slave station 3 PLC Y0 to Y21. This data is stored by bit 0 to 15 of this station's D0 and bit 0 to bit 3 of D1.	Does not support this function
К3	H02	H400	D10	K10	Read input (Bit)	Read 10 bits of data corresponding to slave station 3 PLC X0 to X11. This data is stored by bit 0 to 9 of this station's D10.	Does not support this function
K3	H03	H600	D20	K3	Read register (word)	Read 3 words of data corresponding to slave station 3 PLC T0 to T2. This data is stored by D20 to D22.	Read 3 words of data corresponding to slave station 3 converter parameters 06-00 to 06-02. This data is stored by D20 to D22
К3	H06	H610	D30	XX	Write to single register (word)	Write slave station 3 PLC's 116 to this station's D30 value	Write slave station 3 converter 06 to 16 parameter to this station's D30 value
КЗ	H0F	H509	D40	K10	lmultinla coile	Write slave station 3 PLC's Y11 to Y22 to bit 0 to 9 of D40.	Does not support this function
КЗ	H10	H602	D50	K4	•	Write slave station 3 PLC's 12 to 15 to	Write slave station 3 converter 06-02 to 06-05 parameters to this station's D50 to D53

XX indicates doesn't matter

After implementing MODRW, the status will be displayed in M1077 (485 read/write complete), M1078 (485 read/write error), and M1079 (485 read/write time out). M1077 is defined so as to immediately revert to 0 after the MODRW command has been implemented. However, any of three situations—a report of no error, a data error report, or time out with no report—will cause the status of M1077 to change to On.


Example program: Testing of various functions

At the start, will cause the transmitted time sequence to switch to the first data unit.




When the reported message indicates no error, it will switch to the next transmitted command

If time out occurs or an error is reported, the M1077 will change to ON. At this time, after a delay of 30 scanning cycles, it will re-issue the original command once



It will repeat after sending all commands



Practical applications:

Actual use to control the RTU-485 module.

Step 1: Set the communications format. Assume that the communications format is 115200, 8,N,2, RTU

CP2000: The default PLC station number is set as 2 (Pr.09-35)


Pr.09-31 = -12 (COM1 is controlled by the PLC), Pr.09-01 = 115.2 (The communications speed is 115200)

Pr.09-04 = 13 (The format is 8,N,2, RTU)

RTU485: The station number = 8 (give example)

I	ID7	ID6	ID5	ID4	ID3	ID2	ID1	ID0
	0	0	0	0	1	0	0	0

PA3	PA2	PA1	PA0	DR2	DR1	DR0	A/R
1	0	0	0	1	1	1	0



Communication station #: ID0~ ID7 are defined as  $2^0$ ,  $2^1$ ,  $2^2$ ... $2^6$ ,  $2^7$ 

#### Communication protocol

PA3	PA2	PA1	PA0	A/R	Communication*Protocol
OFF	OFF	OFF	OFF	ON	7,E,1 · ASCII
OFF	OFF	OFF	ON	ON	7,0,1 · ASCII
OFF	OFF	ON	OFF	ON	7,E,2 · ASCII
OFF	OFF	ON	ON	ON	7,0,2 · ASCII
OFF	ON	OFF	OFF	ON	7,N,2 · ASCII
OFF	ON	OFF	ON	ON	8,E,1 · ASCII
OFF	ON	ON	OFF	ON	8,O,1 · ASCII
OFF	ON	ON	ON	ON	8,N,1 · ASCII
ON	OFF	OFF	OFF	ON	8,N,2 · ASCII
OFF	ON	OFF	ON	OFF	8,E,1 · RTU
OFF	ON	ON	OFF	OFF	8,0,1 · RTU
OFF	ON	ON	ON	OFF	8,N,1 · RTU
ON	OFF	OFF	OFF	OFF	8,N,2 · RTU

DR2	DR1	DR0	Communicaton Speed
OFF	OFF	OFF	1,200 bps
OFF	OFF	ON	2,400 bps
OFF	ON	OFF	4,800 bps
OFF	ON	ON	9,600 bps
ON	OFF	OFF	19,200 bps
ON	OFF	ON	38,400 bps
ON	ON	OFF	57,600 bps
ON	ON	ON	115,200 bps

Step 2: Install control equipment. We sequentially connect a DVP16-SP (8 IN 8 OUT), DVP-04AD (4 channels AD), DVP02DA (2 channels DA), and DVP-08ST (8 switches) to the RTU485.


The following corresponding locations can be obtained from the RTU485's configuration definitions:


Module	Terminals	485 Address	
DVP16-SP	X0-X7	0400H-0407H	
DVF 10-3F	Y0-Y7	0500H-0507H	
DVP-04AD	AD0–AD3	1600H-1603H	
DVP02DA	DA0-DA1	1640H-1641H	
DVP-08ST	Switch 0-7	0408H-040FH	

Step 3: Physical configuration




Step 4: Write to PLC program







#### Step 5: Actual testing situation:

I/O testing: When the switch is activated, it can be discovered that the display corresponds to M115 - M108. Furthermore, it can be seen that one output point light is added every 1 sec. (the display uses a binary format)



AD DA testing: It can be discovered that D200 and D201 are roughly twice of the D300, and continue to increase progressively. For their part, the D202 and D203 are roughly twice of the D301, and continue to decrease progressively.





## 16-12 Calendar functions

Keypad (KPC-CC01) should be connected, or the CP2000 cannot be used. Currently-support commands include TCMP (comparison of calendar data), TZCP (calendar data range comparison), TADD (calendar data addition), TSUB (calendar data subtraction), and TRD (calendar reading). Please refer to the explanation of relevant commands and functions for the usage of these commands.

In real applications, the internal PLC can judge whether calendar function have been activated; if they have been activated, calendar warning codes may be displayed in some situations. The basis for whether a calendar function has been activated is whether the program has written the calendar time (D1063 to D1069) in connection with the foregoing calendar commands or programs.

The calendar's time display is currently assigned to D1063 to D1069, and is defined as follows:

Special D	Item	Content	Attributes
D1063	Year (Western)	20xx (2000–2099)	RO
D1064	Weeks	1–7	RO
D1065	Month	1–12	RO
D1066	Day	1–31	RO
D1067	Hour	0–23	RO
D1068	Minute	0–59	RO
D1069	Second	0–59	RO

## Calendar-related special M items are defined as follows:

Special D	Item	Attributes
M1068	Calendar time error	RO
M1076	Calendar time error or refresh time out	RO
M1036	Ignore calendar warning	RW

<sup>\*</sup>When a program writes to the commands TCMP, TZCP, TADD, or TSUB, if it is discovered that a value exceeds the reasonable range, M1026 will be 1.

#### Calendar trigger warning code is defined as follows:

Warning	Description	Reset approach	Whether it affects PLC operation
PLra	Calendar time correction	Requires power restart	Will not have any effect
PLrt	Calendar time refresh time out	Requires power restart	Will not have any effect

<sup>\*</sup>When the PLC's calendar functions are operating, if the keypad is replaced with another keypad, it will jump to PLra.

<sup>\*</sup>When the keypad display is PLra (RTC correction warning) or PLrt (RTC time out warning), M1076 will be ON.

<sup>\*</sup>When M1036 is 1, the PLC will ignore the calendar warning.

<sup>\*</sup>When it is discovered at startup that the keypad has not been powered for more than 7 days, or the time is wrong, PLra will be triggered.


<sup>\*</sup>When it is discovered that the CP2000 has no keypad in 10 sec. after start up, PLrt will be triggered.

<sup>\*</sup>If the keypad is suddenly pulled out while the calendar is operating normally, and is not reconnected in 1 minute, PLrt will be triggered.


### Practical applications:

We will perform a demo of simple applications.

We first correct the keypad time. After pressing Menu on the keypad, select the 9th time setting option. After selection, set the current time.



We set converter on during the period of 8:00-17:20, which allows us to write the following example



[This page intentionally left blank]

# Chapter 17 Introduction to BACnet

## 1. About BACnet:

**BACnet** is an ASHRAE communication protocol for **b**uilding **a**utomation and **c**ontrol **net**works. (ASHRAE: **A**merican **S**ociety of **H**eating, **R**efrigerating and Air-Conditioning **E**ngineers, Inc.). CP2000's BACnet is based on version 2004.

BACnet's regulations are related to several kinds of physical layers' interfaces. The physical layer built inside CP2000 is achieved via MS/TP interface.

The BACnet of CP2000 supports a device type called B-ASC. B-ASC supports six types of services such as DS-RP-B, DS-RPM-B, DS-WP-B, DM-DDB-B, DM-DOB-B and DM-DCC-B.

## 2. CP2000 BACnet-Object and Property:

In CP2000, BACnet supports 3 object types: Device, AnalogValue (AV) and BinaryValue (BV). In each object type, we have the following table to show the Properties list:

	Dogwood ID	Object Type			
	Property ID	Device	Analog Value	Binary Value	
#4	ACTIVE TEXT			V	
#11	APDU_TIMEOUT	V			
#12	APPLICATION_SOFTWARE_VERSION	V			
#28	DESCRIPTION	V	V	V	
#30	DEVICE ADDRESS BINDING	V	V		
#36	EVENT STATE		V	V	
#44	FIRMWARE_REVISION	V			
#46	INACTIVE TEXT			V	
#62	MAX_APDU_LENGTH_ACCEPTED	V			
#63	MAX_INFO_FRAMES	V			
#64	MAX_MASTER	V			
#70	MODEL_NAME	V			
#73	NUMBER_OF_APDU_RETRIES	V			
#75	OBJECT_IDENTIFIER	V *1	V	V	
#76	OBJECT_LIST	V			
#77	OBJECT_NAME	V *1	V	V	
#79	OBJECT_TYPE	V	V	V	
#81	OUT OF SERVICE		V	V	
#85	PRESENT VALUE		V *2	V *2	
#87	PRIORITY ARRAY		V *3	V *3	
#96	PROTOCOL_OBJECT_TYPES_SUPPORTED	V			
#97	PROTOCOL_SERVICES_SUPPORTED	V			
#98	PROTOCOL_VERSION	V			

	Duomoutiv ID	Object Type				
	Property ID	Device	Analog Value	Binary Value		
#104	RELINQUISH DEFAULT		V *3	V *3		
#107	SEGMENTATION_SUPPORTED	V				
#111	STATUS FLAGS		V	V		
#112	SYSTEM_STATUS	V				
#117	UNITS		V			
#120	VENDOR_IDENTIFIER	V				
#121	VENDOR_NAME	V				
#139	PROTOCOL_REVISION	V				
#155	DATABASE_REVISION	V				

<sup>\*1.</sup> The Object\_ID and Object\_Name Properties of Device are writeable.

#### The AV objects, we have commandable and read-only cases.

- Commendable case: We can use Write\_Service to access the Present\_Value property of commandable
   AV objects. Thus, the commandable AV objects are linking to the Control\_Word and Pr\_Word in CP2000.
- Readonly case: We can use Read\_Service to access the Present\_Value property of readonly AV objects.
   Thus, these readonly AV objects are linking to the Status Word in CP2000.

#### The BV objects, we also have commandable and readonly cases.

- Commandable case: We can use Write\_Service to access the Present\_Value property of commendable BV objects. Thus, the commandable BV objects are linking to the Control\_Bit in CP2000.
- Readonly case: We can use Read\_Service to access the Present\_Value property of readonly BV objects.
   Thus, these readonly BV objects are linking to the Status\_Bit in CP2000.

#### 2.1 Commandable Analog Value Object

In CP2000, we have AV\_000–AV\_026 supporting commandable Present\_Value property. For these AV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 000	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 001	RW	FreqRefValue	Frequency Reference Value	UNITS_HERTZ
AV 002	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 003	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 004	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 005	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 006	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 007	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 008	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 009	RW	Reserved	Reserved	UNITS_NO_UNITS

<sup>\*2.</sup> The Present\_Value Property of some AV and BV objects is commandable.

<sup>\*3.</sup> Only Commandable objects support Priority\_Array and Relinquish\_Default.

Object Number	R/W	Object Name	Object Description	Unit
AV 010	RW	Reserved	Reserved	UNITS_NO_UNITS
AV 011	RW	(P9-11 map set)	AV11 will modify data which is P9-11 mapping to	Depends
AV 012	RW	(P9-12 map set)	AV12 will modify data which is P9-12 mapping to	Depends
AV 013	RW	(P9-13 map set)	AV13 will modify data which is P9-13 mapping to	Depends
AV 014	RW	(P9-14 map set)	AV14 will modify data which is P9-14 mapping to	Depends
AV 015	RW	(P9-15 map set)	AV15 will modify data which is P9-15 mapping to	Depends
AV 016	RW	(P9-16 map set)	AV16 will modify data which is P9-16 mapping to	Depends
AV 017	RW	(P9-17 map set)	AV17 will modify data which is P9-17 mapping to	Depends
AV 018	RW	(P9-18 map set)	AV18 will modify data which is P9-18 mapping to	Depends
AV 019	RW	(P9-19 map set)	AV19 will modify data which is P9-19 mapping to	Depends
AV 020	RW	(P9-20 map set)	AV20 will modify data which is P9-20 mapping to	Depends
AV 021	RW	(P9-21 map set)	AV21 will modify data which is P9-21 mapping to	Depends
AV 022	RW	(P9-22 map set)	AV22 will modify data which is P9-22 mapping to	Depends
AV 023	RW	(P9-23 map set)	AV23 will modify data which is P9-23 mapping to	Depends
AV 024	RW	(P9-24 map set)	AV24 will modify data which is P9-24 mapping to	Depends
AV 025	RW	(P9-25 map set)	AV25 will modify data which is P9-25 mapping to	Depends
AV 026	RW	(P9-26 map set)	AV26 will modify data which is P9-26 mapping to	Depends

## 2.2 Status (Readonly) Analog Value Object

In CP2000, we have AV\_027-AV\_068 with read-only Present\_Value property. For these AV\_Objects, we do NOT have Priority Array and Relinquish Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 027	R	Reserved	Reserved	UNITS_NO_UNITS
AV 028	R	Reserved	Reserved	UNITS_NO_UNITS
AV 029	R	Reserved	Reserved	UNITS_NO_UNITS
AV 030	R	Reserved	Reserved	UNITS_NO_UNITS
AV 031	R	Output frequency	Display output frequency(Hz)	UNITS_HERTZ
AV 032	R	Reserved	Reserved	UNITS_NO_UNITS
AV 033	R	Reserved	Reserved	UNITS_NO_UNITS
AV 034	R	Reserved	Reserved	UNITS_NO_UNITS
AV 035	R	Output torque (%)	Display output torque (%)	UNITS_PERCENT
AV 036	R	Reserved	Reserved	UNITS_NO_UNITS
AV 037	R	Reserved	Reserved	UNITS_NO_UNITS
AV 038	R	Reserved	Reserved	UNITS_NO_UNITS
AV 039	R	Status word	Display status word,made from BV16~BV31	UNITS_NO_UNITS
AV 040	R	Reserved	Reserved	UNITS_NO_UNITS
AV 041	R	Driver type code	Driver type code	UNITS_NO_UNITS
AV 042	R	Warn code	Warn code	UNITS_NO_UNITS

Object Number	R/W	Object Name	Object Description	Unit
AV 043	R	Error code	Error code	UNITS_NO_UNITS
AV 044	R	Output current	Display output current (Amp)	UNITS_AMPERES
AV 045	R	DC bus voltage	Display DC bus voltage (Volt)	UNITS_VOLTS
AV 046	R	Output Voltage	Display output voltage of U, V, W (Volt)	UNITS_VOLTS
AV 047	R	Count Value	Display counter value of TRG terminal	UNITS_NO_UNITS
AV 048	R	Power Angle	Display output power angle of U, V, W	UNITS_POWER_FA CTOR
AV 049	R	Output Power	Display actual output power of U, V, W (kw)	UNITS_KILOWATTS
AV 050	R	IGBT temperature	Display the IGBT temperature	UNITS_DEGREES_ CELSIUS
AV 051	R	Temperature of driver	Display the temperature of capacitance	UNITS_DEGREES_ CELSIUS
AV 052	R	Real carry frequency	Display real carrier frequency of the drive (kHz)	UNITS_KILOHERTZ
AV 053	R	PID feedback value	Display PID feedback value (%)	UNITS_PERCENT
AV 054	R	Overload rate	Display overload condition (%)	UNITS_PERCENT
AV 055	R	Ground fail detect	Display GND fail detect level (%)	UNITS_PERCENT
AV 056	R	DC bus ripple	Display DC bus voltage ripples (Volt)	UNITS_VOLTS
AV 057	R	Fan Speed	Fan speed of the drive (%)	UNITS_PERCENT
AV 058	R	Output speed(rpm)	Output speed(rpm)	UNITS_REVOLUTIO  NS_PER_MINUTE
AV 059	R	kW per Hour	kW per Hour	UNITS_KILOWATTS
AV 060	R	Multi-speed switch	Real multi-speed switch	UNITS_NO_UNITS
AV 061	R	AVI1 input value	0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 062	R	ACI input value	4–20 mA/0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 063	R	AVI2 input value	0–10 V corresponds to 0–100%	UNITS_PERCENT
AV 064	R	Digital input status	Refer to Pr.02-12	UNITS_NO_UNITS
AV 065	R	Digital output status	Refer to Pr.02-18	UNITS_NO_UNITS
AV 066	R	CPU pin status of DI	Corresponding CPU pin status of digital input	UNITS_NO_UNITS
AV 067	R	CPU pin status of DO	Corresponding CPU pin status of digital output	UNITS_NO_UNITS
AV 068	R	PLC D1043 value	PLC D1043 value	UNITS_NO_UNITS

## 2.3 Commandable Binary Value Object

In CP2000, we have BV\_000–BV\_015 supporting commandable Present\_Value property. For these BV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description
BV 000	RW	ACTIVE CMD	(0)FreqCmd=0;(1)FreqCmd=FreqRefValue
BV 001	RW	FWD/REV CMD	(0)Forward; (1)Reverse
BV 002	RW	Reserved	Reserved
BV 003	RW	HALT CMD	(0)None;(1)Ramp Down to 0 Hz.
BV 004	RW	LOCK CMD	(0)None;(1)OutputFreq stays at current frequency
BV 005	RW	Reserved	Reserved
BV 006	RW	QSTOP CMD	(0)None;(1)Force driver quick stop
BV 007	RW	ServoPower CMD	(0)PowerOff(free run to stop);(1)PowerOn
BV 008	RW	Reserved	Reserved
BV 009	RW	Reserved	Reserved
BV 010	RW	Reserved	Reserved
BV 011	RW	Reserved	Reserved
BV 012	RW	Reserved	Reserved
BV 013	RW	Reserved	Reserved
BV 014	RW	Reserved	Reserved
BV 015	RW	RESET	RESET:(0)Do nothing;(1)Reset fault

## 2.4 Status (Readonly) Binary Value Object

In CP2000, we have BV\_016–BV\_031 with read-only Present\_Value property. For these BV\_Objects, we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description
BV 016	R	ARRIVE STATE	(0)Not yet;(1)Arrive (OutputFreq=FreqCmd)
BV 017	R	FWD/REV STATE	(0)Forward;(1)Reverse
BV 018	R	WARN STATE	(0)No Warn;(1)Occur Warn
BV 019	R	ERROR STATE	(0)No Error;(1)Occur Error
BV 020	R	Reserved	Reserved
BV 021	R	Reserved	Reserved
BV 022	R	QSTOP STATE	(0)No QSTOP;(1)Occur QSTOP
BV 023	R	Servo Power STATE	(0)PowerOff(free run to stop);(1)PowerOn
BV 024	R	Reserved	Reserved
BV 025	R	Reserved	Reserved
BV 026	R	Reserved	Reserved
BV 027	R	Reserved	Reserved
BV 028	R	Reserved	Reserved

## Chapter 17 Introduction to BACnet | CP2000

Object Number	R/W	Object Name	Object Description
BV 029	R	Reserved	Reserved
BV 030	R	Reserved	Reserved
BV 031	R	Reserved	Reserved

## 3. Steps to setup the Pr about BACnet in CP2000

Related to BACnet function in CP2000, We have to configure 2 parts of Parameters

Part1. Setup parameters related to Communication at Pr\_Group9.

Part2. Setup parameters related to System Parameter at Pr Group0.

### Part1. Pr\_Group9, Communication.

1-1. Set Pr.09-31 =1, BACnet is enabled, then the COM1\_Port will be accessed by BACnet. When this is set, the COM1\_Port communication format will be changed to RTU 8, N, 1.

(Note: The HW Pins of COM1\_Port are shared by RJ45 and RS-485. When BACnet is enabled, BACnet will access the COM1\_Port, that also means we can **NOT** have Modbus, PLC connections, VFDSoft and VFD Explorer by COM1\_Port).

- 1-2. Set Pr.09-50, Default = 10, BACnet's MS/TP station number 0-127
- 1-3. Set Pr.09-51, Default = 38400, BACnet communication baud rate, 9600, 19200, 38400 or 76800 bps.
- 1-4. Set Pr.09-52 and Pr.09-53, The default setting of Device Object\_Identifier is 0x000A (Pr.09-52=10, Pr.09-53=00). Device Object\_Identifier is the combination of Pr.09-52 and Pr.09-53, thus the setting range can be 0–4194303.

For example, Pr.09-53=12(0x0C) and Pr.09-52=3456(0x0D80), then the device Identifier's value =12\*65536+3456=789888(0x0C0D80).

- 1-5. Set Pr.09-55, Default =127, the highest allowable address for master nodes on the same MS/TP network. CP2000 base on this setting to know the Max search range.
- 1-6. Set Pr.09-56, setup the BACnet password. If setup is successful, the keypad will display 8888.

#### Part2. Pr Group0, System Parameter.

- 2-1. Set Pr.00-20 =1, That means the source of the Frequency command is from RS-485 Interface (accessed by BACnet).
- 2-2. Set Pr.00-21 =2, That means the source of the Operation command is from RS-485 Interface (accessed by BACnet).

## Here is a simple example:


After setting up the 2 parts of Pr, we can enable the BACnet function in CP2000. Thus, we can access some BACnet objects to make the CP2000 driving motor Run or Stop.

Step1. Write\_Service on AV\_001, Present\_Value =60.0 → Setup Frequency Reference Value.

Step2. Write Service on BV 007, Present Value =Active. → Setup Servo Power CMD.

Step3. Write\_Service on BV\_000, Present\_Value =Active. → Setup Active CMD.

Step4. Read Service on AV 031, Present Value → User can know the Output frequency.




PS. In CP2000, base on different Pr setting or IO setting, we can make FreqCmd with different source of Reference Value. Please check the usage of Keypad, Pr and IO setting for more detail information.

Connection of the communication cable as shown in the below diagram.

Please note that HW Pins of COM1\_Port are shared by RJ45 and RS-485. That means user can use RJ45\_cable or RS-485\_lines to access the COM1\_Port.

When BACnet is enabled, COM1\_Port will be dominated by BACnet function. Under this condition, user will not be able to have Modbus VFD Soft, VFD Explorer or PLC function on COM1\_Port.



## **BACnet Protocol Implementation Conformance Statement**

**Date:** July 24, 2014

Vendor Name: Delta Electronics, Inc.			
Product Name: CP2000			
Product Model Number: VFD-CP2000			
Applications Software Version: Ver 01.04- yyyymm Fin	rmware Revision:	Ver 01.04	<b>BACnet Protoco</b>
Revision: 7			
Product Description:			
Delta VFD-CP2000 is a Variable Frequency AC motor Drive	with BACnet embed	lded.	
In VFD-CP2000, the BACnet connection is by MS/TP, RS-4	85-based. VFD-CP	2000 provide	es a BACnet
communication function that permits it as a server and supp	oorts BIBBs defined	by the BACr	net B-ASC.
VFD-CP2000 BACnet provides the capability to control and	monitor the VFD-C	P2000 mach	ine.
BACnet Standardized Device Profile (Annex L):			
☐ BACnet Operator Workstation (B-OWS)_			
☐ BACnet Building Controller (B-BC)			
☐ BACnet Advanced Application Controller (B-AAC)_			
■ BACnet Application Specific Controller (B-ASC)			
□ BACnet Smart Sensor (B-SS)			
□ BACnet Smart Actuator (B-SA)			
List all BACnet Interoperability Building Blocks Support	rted (Annex K):		
Data Sharing BIBBs			
Data Sharing-ReadProperty-B (DS-RP-B)			
Data Sharing-WriteProperty-B (DS-WP-B)			
Data Sharing-ReadPropertyMultiple-B (DS-RPM-B)			
Device and Network Management BIBBs			
Device Management-Dynamic Device Binding-B (DM-DDB-	-B)		
Device Management-Dynamic Object Binding-B (DM-DOB-	-B)		
Device Management-DeviceCommunicationControl-B (DM-	-DCC-B)		
Segmentation Capability:			
□ Segmented requests supported Window Size			
□ Segmented responses supported Window Size			
Standard Object Types Supported:			
Analog Value			
Binary Value			
Device			
Object instantiation is static. Refer to table at en	d of this document	for object det	ails.

## Chapter 17 Introduction to BACnet | CP2000

Data Link Layer Options:		
☐ BACnet IP, (Annex J)		
☐ BACnet IP, (Annex J), Foreig	n Device	
☐ ISO 8802-3, Ethernet (Claus	e 7)	
☐ ANSI/ATA 878.1, 2.5 Mb. AR	CNET (Clause 8)	
☐ ANSI/ATA 878.1, RS-485 AR	CNET (Clause 8), baud rate(s)	
■ MS/TP master (Clause 9), ba	aud rate(s): <u>9600, 19200, 38400</u>	0, 76800
☐ MS/TP slave (Clause 9), bau	d rate(s):	
☐ Point-To-Point, EIA 232 (Clar	use 10), baud rate(s):	
☐ Point-To-Point, modem, (Cla	use 10), baud rate(s):	
☐ LonTalk, (Clause 11), mediur	n:	
□ Other:		
Device Address Binding:		
Is static device binding support	ed? (This is currently necessary	y for two-way communication with MS/TP slaves and
certain other devices.) □Yes	■No	
Networking Options:		
☐ Router, Clause 6 - List all rou	ıting configurations, e.g., ARCN	NET-Ethernet, Ethernet-MS/TP, etc.
☐ Annex H, BACnet Tunneling	Router over IP	
☐ BACnet/IP Broadcast Manag	ement Device (BBMD)	
Does the BBMD support registr	ations by Foreign Devices? □	Yes □ No
Character Sets Supported:		
Indicating support for multiple of	haracter sets does not imply the	at they can all be supported simultaneously.
■ ANSI X3.4	☐ IBM <sup>™</sup> /Microsoft <sup>™</sup> DBCS	☐ ISO 8859-1
□ ISO 10646 (UCS-2)	☐ ISO 10646 (UCS-4)	□ JIS C 6226
If this product is a communic	ation gateway, describe the t	types of non-BACnet equipment/networks(s) that
the gateway supports:		

## The Properties of Objects

	Pura manufaci ID		Object Type			
	Property ID	Device	Analog Value	Binary Value		
#4	ACTIVE TEXT			V		
#11	APDU_TIMEOUT	V				
#12	APPLICATION_SOFTWARE_VERSION	V				
#28	DESCRIPTION	V	V	V		
#30	DEVICE ADDRESS BINDING	V	V			
#36	EVENT STATE		V	V		
#44	FIRMWARE_REVISION	V				
#46	INACTIVE TEXT			V		
#62	MAX_APDU_LENGTH_ACCEPTED	V				
#63	MAX_INFO_FRAMES	V				
#64	MAX_MASTER	V				
#70	MODEL_NAME	V				
#73	NUMBER_OF_APDU_RETRIES	V				
#75	OBJECT_IDENTIFIER	V *1	V	V		
#76	OBJECT_LIST	V				
#77	OBJECT_NAME	V *1	V	V		
#79	OBJECT_TYPE	V	V	V		
#81	OUT OF SERVICE		V	V		
#85	PRESENT VALUE		V *2	V *2		
#87	PRIORITY ARRAY		V *3	V *3		
#96	PROTOCOL_OBJECT_TYPES_SUPPORTED	V				
#97	PROTOCOL_SERVICES_SUPPORTED	V				
#98	PROTOCOL_VERSION	V				
#104	RELINQUISH DEFAULT		V *3	V *3		
#107	SEGMENTATION_SUPPORTED	V				
#111	STATUS FLAGS		V	V		
#112	SYSTEM_STATUS	V				
#117	UNITS		V			
#120	VENDOR_IDENTIFIER	V				
#121	VENDOR_NAME	V				
#139	PROTOCOL_REVISION	V				
#155	DATABASE_REVISION	V				

<sup>\*1.</sup> The Object\_ID and Object\_Name Properties of Device are writeable.

<sup>\*2.</sup> The Present\_Value Property of some AV and BV objects are commandable.

<sup>\*3.</sup> Only Commandable objects support Priority\_Array and Relinquish\_Default.

## • Commandable Analog Value Object

In VFD-CP2000, we have AV\_000–AV\_026 supporting commandable Present\_Value property. In these AV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 000	RW	AV_000_Reserved	Reserved	UNITS_NO_UNITS
AV 001	RW	AV_001_FreqRefValue	Frequency Reference Value	UNITS_HERTZ
AV 002	RW	AV_002_Reserved	Reserved	UNITS_NO_UNITS
AV 003	RW	AV_003_Reserved	Reserved	UNITS_NO_UNITS
AV 004	RW	AV_004_Reserved	Reserved	UNITS_NO_UNITS
AV 005	RW	AV_005_Reserved	Reserved	UNITS_NO_UNITS
AV 006	RW	AV_006_Reserved	Reserved	UNITS_NO_UNITS
AV 007	RW	AV_007_Reserved	Reserved	UNITS_NO_UNITS
AV 008	RW	AV_008_Reserved	Reserved	UNITS_NO_UNITS
AV 009	RW	AV_009_Reserved	Reserved	UNITS_NO_UNITS
AV 010	RW	AV_010_Reserved	Reserved	UNITS_NO_UNITS
AV 011	RW	AV_011_P9-11 map set=	AV11 will modify data which is P9-11 mapping to	Depends
AV 012	RW	AV_012_P9-12 map set=	AV12 will modify data which is P9-12 mapping to	Depends
AV 013	RW	AV_013_P9-13 map set=	AV13 will modify data which is P9-13 mapping to	Depends
AV 014	RW	AV_014_P9-14 map set=	AV14 will modify data which is P9-14 mapping to	Depends
AV 015	RW	AV_015_P9-15 map set=	AV15 will modify data which is P9-15 mapping to	Depends
AV 016	RW	AV_016_P9-16 map set=	AV16 will modify data which is P9-16 mapping to	Depends
AV 017	RW	AV_017_P9-17 map set=	AV17 will modify data which is P9-17 mapping to	Depends
AV 018	RW	AV_018_P9-18 map set=	AV18 will modify data which is P9-18 mapping to	Depends
AV 019	RW	AV_019_P9-19 map set=	AV19 will modify data which is P9-19 mapping to	Depends
AV 020	RW	AV_020_P9-20 map set=	AV20 will modify data which is P9-20 mapping to	Depends
AV 021	RW	AV_021_P9-21 map set=	AV21 will modify data which is P9-21 mapping to	Depends
AV 022	RW	AV_022_P9-22 map set=	AV22 will modify data which is P9-22 mapping to	Depends
AV 023	RW	AV_023_P9-23 map set=	AV23 will modify data which is P9-23 mapping to	Depends
AV 024	RW	AV_024_P9-24 map set=	AV24 will modify data which is P9-24 mapping to	Depends
AV 025	RW	AV_025_P9-25 map set=	AV25 will modify data which is P9-25 mapping to	Depends
AV 026	RW	AV_026_P9-26 map set=	AV26 will modify data which is P9-26 mapping to	Depends

## • Status (Readonly) Analog Value Object

In VFD-CP2000, we have AV\_027–AV\_068 with read-only Present\_Value property. In these AV\_Objects, we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	Unit
AV 027	R	AV_027_Reserved	Reserved	UNITS_NO_UNITS
AV 028	R	AV_028_Reserved	Reserved	UNITS_NO_UNITS
AV 029	R	AV_029_Reserved	Reserved	UNITS_NO_UNITS
AV 030	R	AV_030_Reserved	Reserved	UNITS_NO_UNITS
AV 031	R	AV_031_Output frequency	Display output frequency(Hz)	UNITS_HERTZ
AV 032	R	AV_032_Reserved	Reserved	UNITS_NO_UNITS
AV 033	R	AV_033_Reserved	Reserved	UNITS_NO_UNITS
AV 034	R	AV_034_Reserved	Reserved	UNITS_NO_UNITS
AV 035	R	AV_035_Output torque (%)	Display output torque (%)	UNITS_PERCENT
AV 036	R	AV_036_Reserved	Reserved	UNITS_NO_UNITS
AV 037	R	AV_037_Reserved	Reserved	UNITS_NO_UNITS
AV 038	R	AV_038_Reserved	Reserved	UNITS_NO_UNITS
AV 039	R	AV_039_Status word	Display status word,made from BV16~BV31	UNITS_NO_UNITS
AV 040	R	AV_040_Reserved	Reserved	UNITS_NO_UNITS
AV 041	R	AV_041_Driver type code	Driver type code	UNITS_NO_UNITS
AV 042	R	AV_042_Warn code	Warn code	UNITS_NO_UNITS
AV 043	R	AV_043_Error code	Error code	UNITS_NO_UNITS
AV 044	R	AV_044_Output current	Display output current(Amp)	UNITS_AMPERES
AV 045	R	AV_045_DC-bus voltage	Display DC-BUS voltage(Volt)	UNITS_VOLTS
AV 046	R	AV_046_Output Voltage	Display output voltage of U, V, W(Volt)	UNITS_VOLTS
AV 047	R	AV_047_Count Value	Display counter value of TRG terminal	UNITS_NO_UNITS
AV 048	R	AV_048_Power Angle	Display output power angle of U, V, W	UNITS_POWER_FACT OR
AV 049	R	AV_049_Output Power	Display actual output power of U, V, W(kw)	UNITS_KILOWATTS
	_			UNITS_DEGREES_CE
AV 050	R	AV_050_IGBT temperature	Display the IGBT temperature	LSIUS
AV 051	R	AV_051_Temperature of driver	Display the temperature of capacitance	UNITS_DEGREES_CE LSIUS
AV 052	R	AV_052_Real carry frequency	Display real carrier frequency of the drive(KHz)	UNITS_KILOHERTZ
AV 053	R	AV_053_PID feedback value	Display PID feedback value (%)	UNITS_PERCENT
AV 054	R	AV_054_Overload rate	Display overload condition (%)	UNITS_PERCENT
AV 055	R	AV_055_Ground fail detect level	Display GND fail detect level (%)	UNITS_PERCENT
AV 056	R	AV_056_DC bus ripple	Display DCbus voltage ripples(Volt)	UNITS_VOLTS
AV 057	R	AV_057_Fan Speed	Fan speed of the drive (%)	UNITS_PERCENT
A) / 0=0				UNITS_REVOLUTION
AV 058	K	R AV_058_Output speed(rpm)	Output speed(rpm)	S_PER_MINUTE

Object Number	R/W	Object Name	Object Description	Unit
AV 059	R	AV_059_KW per Hour	KW per Hour	UNITS_KILOWATTS
AV 060	R	AV_060_Multi-speed switch	Real multi-speed switch	UNITS_NO_UNITS
AV 061	R	AV_061_AVI1 input value	0~10V corresponds to 0~100%	UNITS_PERCENT
AV 062	R	AV_062_ACI input value	4~20mA/0~10V corresponds to 0~100%	UNITS_PERCENT
AV 063	R	AV_063_AVI2 input value	0V~10V corresponds to 0~100%	UNITS_PERCENT
AV 064	R	AV_064_Digital input status	Refer to P2-12	UNITS_NO_UNITS
AV 065	R	AV_065_Digital output status	Refer to P2-18	UNITS_NO_UNITS
AV 066	R	AV_066_CPU pin status of DI	Corresponding CPU pin status of digital input	UNITS_NO_UNITS
AV 067	R	AV_067_CPU pin status of DO	Corresponding CPU pin status of digital output	UNITS_NO_UNITS
AV 068	R	AV_068_PLC D1043 value	PLC D1043 value	UNITS_NO_UNITS

## • Commandable Binary Value Object

In VFD-CP2000, we have BV\_000–BV\_015 supporting commandable Present\_Value property. In these BV\_Objects, we also can use (Multi) Read\_Service to access Priority\_Array and Relinquish Default properties.

Object Number	R/W	Object Name	Object Description	
BV 000	RW	BV_000_ACTIVE CMD	(0)FreqCmd=0;(1)FreqCmd=FreqRefValue	
BV 001	RW	BV_001_FWD/REV CMD	(0)Forward; (1)Reverse	
BV 002	RW	BV_002_Reserved	Reserved	
BV 003	RW	BV_003_HALT CMD	(0)None;(1)RampDown to 0Hz.	
BV 004	RW	BV_004_LOCK CMD	(0)None;(1)OutputFreq stays at current frequency	
BV 005	RW	BV_005_Reserved	Reserved	
BV 006	RW	BV_006_QSTOP CMD	(0)None;(1)Force driver quick stop	
BV 007	RW	BV_007_ServoPower CMD	(0)PowerOff(free run to stop);(1)PowerOn	
BV 008	RW	BV_008_Reserved	Reserved	
BV 009	RW	BV_009_Reserved	Reserved	
BV 010	RW	BV_010_Reserved	Reserved	
BV 011	RW	BV_011_Reserved	Reserved	
BV 012	RW	BV_012_Reserved	Reserved	
BV 013	RW	BV_013_Reserved	Reserved	
BV 014	RW	BV_014_Reserved	Reserved	
BV 015	RW	BV_015_RESET	RESET:(0)Do nothing;(1)Reset fault	

## • Status (Readonly) Binary Value Object

In VFD-CP2000, we have BV\_016–BV\_031 with read-only Present\_Value property. In these BV\_Objects, we do NOT have Priority\_Array and Relinquish\_Default properties.

Object Number	R/W	Object Name	Object Description	
BV 016	R	BV_016_ARRIVE STATE	(0)Not yet;(1)Arrive (OutputFreq=FreqCmd)	
BV 017	R	BV_017_FWD/REV STATE	(0)Forward;(1)Reverse	
BV 018	R	BV_018_WARN STATE	(0)No Warn;(1)Occur Warn	
BV 019	R	BV_019_ERROR STATE	(0)No Error;(1)Occur Error	
BV 020	R	BV_020_Reserved	Reserved	
BV 021	R	BV_021_Reserved	Reserved	
BV 022	R	BV_022_QSTOP STATE	(0)No QSTOP;(1)Occur QSTOP	
BV 023	R	BV_023_ServoPower STATE	(0)PowerOff(free run to stop);(1)PowerOn	
BV 024	R	BV_024_Reserved	Reserved	
BV 025	R	BV_025_Reserved	Reserved	
BV 026	R	BV_026_Reserved	Reserved	
BV 027	R	BV_027_Reserved	Reserved	
BV 028	R	BV_028_Reserved	Reserved	
BV 029	R	BV_029_Reserved	Reserved	
BV 030	R	BV_030_Reserved	Reserved	
BV 031	R	BV_031_Reserved	Reserved	

[This page intentionally left blank]

# Chapter 18 Safe Torque Off Function

- 18-1 The Drive Safety Function Failure Rate
- 18-2 Safe Torque Off Terminal Function Description
- 18-3 Wiring Diagram
- 18-4 Parameter
- 18-5 Operating Sequence Description
- 18-6 New Error Code for STO Function

## 18-1 The Drive Safety Function Failure Rate

Item	Definition	Standard	Performance
STO	Safe Torque Off	IEC61508	Channel 1: 80.08% Channel 2: 68.91%
HFT (Type A subsystem)	Hardware Fault Tolerance	IEC61508	1
CII	Cofoty Integrity Lavel	IEC61508	SIL 2
SIL	Safety Integrity Level	IEC62061	SILCL 2
PFH	Average frequency of dangerous failure [h-1]	IEC61508	9.56×10 <sup>-10</sup>
PFD <sub>av</sub>	Probability of Dangerous Failure on Demand	IEC61508	4.18×10 <sup>-6</sup>
Category	Category	ISO13849-1	Category 3
PL	Performance level	ISO13849-1	d
MTTF <sub>d</sub>	Mean time to dangerous failure	ISO13849-1	High
DC	Diagnostic coverage	ISO13849-1	Low

## 18-2 Safe Torque Off Terminal Function Description

The Safe Torque Off function is to cut off the power supply to motor through the hardware, thereby the motor could not produce torque.

The STO function controls the motor current driving signal through two hardware circuits respectively, and thus cut off the inverter power module output in order to achieve the status of safety stop.

Operation Principle Description as following table 1:


Table 1: Terminal operation description

Signal	Channel		Photo-coupler status			
STO signal	STO1-SCM1	ON (High)	ON (High)	OFF (Low)	OFF (Low)	
	STO2-SCM2	ON (High)	OFF (Low)	ON (High)	OFF (Low)	
Driver Output status		Ready	STL2 mode (Torque output off)	STL1 mode (Torque output off)	STO mode (Torque output off)	


- STO means Safe Torque Off
- STL1-STL3 means Safe Torque Off hardware abnormal.
- STL3 means STO1–SCM1 and STO2–SCM2 internal circuit detected abnormal.
- STO1–SCM1 ON (High): means STO1–SCM1 has connected to a +24 V<sub>DC</sub> power supply.
- STO2–SCM2 ON (High): means STO2–SCM2 has connected to a +24 V<sub>DC</sub> power supply.
- STO1–SCM1 OFF (Low): means STO1–SCM1 has not connected to a +24 V<sub>DC</sub> power supply.
- STO2–SCM2 OFF (Low): means STO2–SCM2 has not connected to a +24 V<sub>DC</sub> power supply.

## 18-3 Wiring diagram

18-3-1Internal STO circuit as below:




18-3-2 In the figure below, the default setting for +24V-STO1-STO2 and SCM1-SCM2-DCM is short circuit:



#### Chapter 18 Safe Torque Off Function | CP2000

## 18-3-3 The control loop wiring diagram:

- 1. Remove the shot-circuit of +24V-STO1-STO2 and DCM-SCM1-SCM2.
- 2. The wiring as below diagram. The ESTOP switch must at Close status in normal situation and drive will be able to Run.
- 3. STO mode, switch ESTOP open. Drive output stop and keypad display STO.



#### NOTE

- \*1: Factory short-circuit of DCM-SCM1-SCM2. Remove the short-circuit to use the Safety function.
- \*2: Factory short-circuit of +24V-STO1-STO2. Remove the short-circuit to use the Safety function.

### 18-4 Parameter

## **グ 35 - ЧЧ** STO Alarm Latch

Default: 0

Settings 0 : STO Alarm Latch 1 : STO Alarm no Latch

- Pr.06-44 = 0 STO Alarm Latch: after the reason of STO Alarm is cleared, you need a Reset command to clear STO Alarm.
- Pr.06-44 = 1 STO Alarm no Latch: after the reason of STO Alarm is cleared, the STO Alarm will be cleared automatically.
- The STL1-STL3 error are all "Alarm latch" mode (in STL1-STL3 mode, the Pr.06-44 function is no effective).
- Multi-function Output 1 (Relay1)

Default: 11

Multi-function Output 2 (Relay2)

Default: 1

Multi-function Output 3 (Relay3)

Default: 66

Settings

66: SO N.O. logic A output 68: SO N.C. logic B output

Settings	Functions	Descriptions
66	SO Logic A output	Safety Output Normal Open
68	SO Logic B output	Safety Output Normal Close

CP2000 default Pr.02-15 (Relay3) = 66 (N.O.) and Multi-function Output setting item adds two new functions: 66 and 68.

Drive status	Safety Output status		
	N.O.	N.C.	
	(MOx = 66)	(MOx = 68)	
Normal run	Open	Close	
STO	Close	Open	
STL1~STL3	Close	Open	

**『 ! ! ! !** Content of Multi-function Display


Default: 3

Settings 45: Hardware version

## 18-5 Operating Sequence Description

#### 18-5-1 Normal operation status

As shown in Figure 1: When the STO1–SCM1 and STO2–SCM2 = ON (no STO function is needed), the drive executes "Operating" or "Output Stop" according to the RUN/STOP command.



### 18-5-2-1 STO, Pr.06-44 = 0, Pr.02-35 = 0

As shown in Figure 4: When both of STO1–SCM1 and STO2–SCM2 channel have turned off during operating, the STO function enables and the drive stops output regardless of Run command is ON or OFF status.






Figure 2

#### 18-5-2-2 STO, Pr.06-44 = 0, Pr.02-35 = 1

As shown in Figure 3: the same as figure 2. However, due to the setting for Pr.02-35 is 1, if the operating command still exists after the Reset command, the drive will immediately execute the run command again.



## 18-5-3 STO, Pr.06-44 = 1 STO Alarm no latch



### 18-5-4 STL1





Figure 5

## 18-5-4 STL2



## **18-6 New Error Code for STO Function**

☐ 6 - 17 Fault Record 1	
### Fault Record 2	
### Fault Record 3	
☐ 6 - 2 ☐ Fault Record 4	
<b>35 - 2 ∤</b> Fault Record 5	
☐ 6 - 2 2 Fault Record 6	

## Settings

72: Channel 1 (STO1–SCM1) safety loop error (STL1)

76: Safe torque off (STO)

77: Channel 2 (STO2–SCM2) safety loop error (STL2)

78: Internal loop error (STL3)

Error code	Name	Description
76	STO	Safe Torque Off function active
72	STL1 (STO1-SCM1)	STO1–SCM1 internal hardware detect error
77	STL2 (STO2-SCM2)	STO2–SCM2 internal hardware detect error
78	STL3	STO1–SCM1 and STO2–SCM2 internal hardware detect error

## The Old/New control board and Old/New I/O card:

CP2000	v1.20 firmware	v1.21 firmware
v1.20 control board + old I/O card (no STO function)	OK	OK
v1.20 control board + new I/O card (with STO function)	Error	Error
v1.21 control board + old I/O card (no STO function)	Error	Error
v1.21 control board + new I/O card (with STO function)	Error	OK

# Appendix A. Revision History

New information				
Description	Related part			
Add 200 kW and 250 kW models to 460V series	Whole manual			
Add consumption data to AC input / output reactor	Chapter 07			
Add option card eZVFD-CC	Chapter 08			
Add SynRM Sensorless control mode and PM Sensorless control mode	Whole manual			
Add keypad languages: Polski, Deutsch, Italiano and Svenska	Chapter 10			
SynRM parameters:				
Parameter group 00: 00-11, 00-17				
<ul> <li>Parameter group 05: 05-00, 05-33, 05-34~05-41</li> </ul>				
Other new parameters:	Chapter 11 Section 12-1			
Parameter group 00: 00-37				
Parameter group 01: 01-50, 01-51				
Parameter group 06: 06-12	Section 12-1			
• Parameter group 07: 07-21, 07-41–07-45				
Parameter group 09: 09-49				
Parameter group 10: 10-08–10-15, 10-33, 10-35, 10-36, 10-54–10-58				
● Parameter group 11: 11-00–11-23				
Add Adjustment for SynRM	Section 12-2			
Add Warning code of CKx	Chapter 13			
Add CANopen built-in PLC register D indexes	Chapter 15			
Add PLC special M register: M1019 Motor drive warning indicator	Chapter 16			
Add PLC special D register: D1560 Motor drive warning code	Chapter 10			

Updated information				
Description	Related part			
Update specification of main circuit terminals, and add operation conditions under ambient termperature 50°C	Chapter 05			
Update the motor cable length for 230V models	Chapter 07			
Update the part number of zero phase reactors	Chapter 07			
Update information of option card EMC-A22A	Chapter 07			
Correct the HP value of 630 kW and 560kW models for 690V	Chapter 09			
Update derating curve for ambient temperature, altitude and carrier frequency Update efficiency curve	Chapter 09			
Update certification	Chapter 09			
Update information of keypad function, Start Wizard and Warning / Fault codes	Chapter 10			
<ul> <li>Update parameter settings and descriptions:</li> <li>Parameter group 00: 00-00, 00-04, 00-06, 00-11, 00-17, 00-20, 00-30</li> <li>Parameter group 01: 01-01, 01-02, 01-10, 01-11, 01-23, 01-35, 01-36, 01-49</li> <li>Parameter group 02: 02-01-02-08, 02-26-02-31, 02-10-02-15, 02-36-02-46, 02-50, 02-51, 02-53, 02-73</li> <li>Parameter group 03: 03-20-03-25, 03-29</li> <li>Parameter group 05: 05-24, 05-28-05-30</li> <li>Parameter group 06: 06-03, 06-04, 06-16, 06-17-06-22, 06-23-06-26, 06-29, 06-46-06-48, 06-49, 06-53, 06-55, 06-73, 06-80-06-87</li> <li>Parameter group 07: 07-08, 07-12, 07-19, 07-26, 07-27</li> <li>Parameter group 08: 08-00, 08-06, 08-10, 08-11, 08-15 (Reserve)</li> <li>Parameter group 10: 10-34, 10-53</li> <li>Parameter group 12: 12-00, 12-04, 12-09</li> <li>Parameter group 14: 14-10, 14-11, 14-16, 14-17</li> </ul>	Chapter 11 Section 12-1			
Update DO terminals	Chapter 15			
Delete setting 4: Torque Profile Mode from 6060h	Chapter 15			
Update the fault codes for CANopen	Chapter 15			
Correct the STO operating diagram	Chapter 18			