




Software Manual

## 9400



**E94AxHExxxx**

**Servo Drives 9400 HighLine**  
*Parameter setting & configuration*

# Lenze

## Overview of technical documentation for Servo Drives 9400

<b>Project planning, selection &amp; order</b>
<input type="checkbox"/> Hardware manual 9400
<input checked="" type="checkbox"/> Catalogue / electronic catalogue (DSC - Drive Solution Catalogue)
<b>Mounting &amp; wiring</b>
<input checked="" type="checkbox"/> MA - 9400 StateLine/HighLine
<input checked="" type="checkbox"/> MA - communication module
<input checked="" type="checkbox"/> MA - extension module
<input checked="" type="checkbox"/> MA - safety module
<input checked="" type="checkbox"/> MA - accessories
<input checked="" type="checkbox"/> MA - remote maintenance components
<b>Parameter setting</b>
<input checked="" type="checkbox"/> BA - keypad
<input type="checkbox"/> SW - Lenze software »Engineer«
<input checked="" type="checkbox"/> <b>SW - controller</b> (9400 StateLine/HighLine/PLC)
<input type="checkbox"/> SW - regenerative power supply module
<input type="checkbox"/> KHB - communication module
<input type="checkbox"/> SW - extension module
<input type="checkbox"/> SW - safety module
<input type="checkbox"/> SW - Lenze technology application
<input type="checkbox"/> SW - function library 9400
<b>Configuring &amp; programming</b>
<input type="checkbox"/> SW - Lenze software »Engineer«
<input type="checkbox"/> SW - Lenze software »PLC Designer«
<input checked="" type="checkbox"/> <b>SW - controller</b> (9400 HighLine/PLC)
<input type="checkbox"/> KHB - communication module
<input type="checkbox"/> SW - extension module
<input type="checkbox"/> SW - safety module
<input type="checkbox"/> SW - Lenze technology application
<input type="checkbox"/> SW - function library 9400
<b>Drive commissioning</b>
<input checked="" type="checkbox"/> Commissioning guide
<input type="checkbox"/> <b>SW - controller</b> (9400 StateLine/HighLine/PLC)
→ Chapter " <a href="#">Commissioning</a> " ( <a href="#">📖 29</a> )
→ Chapter " <a href="#">Oscilloscope</a> " ( <a href="#">📖 590</a> )
→ Chapter " <a href="#">Diagnostics &amp; fault analysis</a> " ( <a href="#">📖 611</a> )
<input type="checkbox"/> Remote maintenance manual
<b>Networking structure</b>
<input type="checkbox"/> KHB - communication medium used

### Legend:

- Printed documentation
- Online documentation (PDF/Engineer online help)

### Abbreviations used:

- BA Operating instructions
- KHB Communication manual
- MA Mounting instructions
- SW Software Manual

← This documentation

← This documentation

← This documentation

## Content

<b>1</b>	<b><a href="#">About this documentation</a></b> .....	<b>18</b>
1.1	<a href="#">Conventions used</a> .....	19
1.2	<a href="#">Terminology used</a> .....	20
1.3	<a href="#">Definition of notes used</a> .....	21
<b>2</b>	<b><a href="#">Introduction</a></b> .....	<b>22</b>
2.1	<a href="#">Parameter setting, configuring, or programming?</a> .....	22
2.1.1	<a href="#">Basic functionalities</a> .....	23
2.1.2	<a href="#">Technology applications</a> .....	23
2.2	<a href="#">Communicating with the controller</a> .....	24
2.2.1	<a href="#">Going online via diagnostic adapter</a> .....	24
2.2.2	<a href="#">Going online via system bus (CAN on board)</a> .....	27
2.2.3	<a href="#">Use of other communication interfaces</a> .....	27
2.3	<a href="#">Signal types &amp; scaling</a> .....	28
<b>3</b>	<b><a href="#">Commissioning</a></b> .....	<b>29</b>
3.1	<a href="#">General information</a> .....	30
3.2	<a href="#">Notes on commissioning using the keypad</a> .....	31
3.3	<a href="#">Initial commissioning</a> .....	32
3.4	<a href="#">Standard set-up</a> .....	33
3.5	<a href="#">Controller replacement</a> .....	34
3.6	<a href="#">Motor replacement</a> .....	34
<b>4</b>	<b><a href="#">Drive interface</a></b> .....	<b>35</b>
4.1	<a href="#">Machine parameters</a> .....	36
4.1.1	<a href="#">Mains voltage</a> .....	37
4.1.2	<a href="#">Gearbox ratio</a> .....	38
4.1.3	<a href="#">Motor mounting direction</a> .....	39
4.1.4	<a href="#">Feedback configuration</a> .....	39
4.1.5	<a href="#">Unit/user-defined unit</a> .....	40
4.1.6	<a href="#">Traversing range</a> .....	41
4.1.7	<a href="#">Feed constant</a> .....	43
4.1.8	<a href="#">Resolution of an encoder revolution</a> .....	44
4.1.8.1	<a href="#">Determining the optimum resolution</a> .....	46
4.1.9	<a href="#">Max. position, speed, and acceleration that can be displayed internally</a> .....	47

4.2	<a href="#">Device commands</a>	49
4.2.1	<a href="#">Load Lenze setting</a>	51
4.2.2	<a href="#">Load start parameters</a>	52
4.2.3	<a href="#">ENP:Load plant data</a>	53
4.2.4	<a href="#">Activate application</a>	54
4.2.5	<a href="#">Save selected application</a>	55
4.2.6	<a href="#">Save start parameters</a>	56
4.2.7	<a href="#">Delete logbook</a>	58
4.2.8	<a href="#">Archive logbook</a>	59
4.2.9	<a href="#">Start application</a>	60
4.2.10	<a href="#">Stop application</a>	61
4.2.11	<a href="#">Reset program</a>	62
4.2.12	<a href="#">Delete program</a>	63
4.2.13	<a href="#">Restart program</a>	64
4.2.14	<a href="#">Reset runtime measurement</a>	65
4.2.15	<a href="#">Inhibit controller</a>	67
4.2.16	<a href="#">Enable controller</a>	68
4.2.17	<a href="#">Reset error</a>	69
4.2.18	<a href="#">Activate quick stop</a>	70
4.2.19	<a href="#">Reset quick stop</a>	71
4.2.20	<a href="#">Identify pole position (360°)</a>	72
4.2.21	<a href="#">Identify pole position (min. motion)</a>	74
4.2.22	<a href="#">Resolver error identification</a>	76
4.2.23	<a href="#">Load Lenze inverter characteristic</a>	77
4.2.24	<a href="#">Calculate inv. characteristic</a>	78
4.2.25	<a href="#">Determine motor parameters</a>	79
4.2.26	<a href="#">Calculate current controller parameters</a>	80
4.2.27	<a href="#">Calculate speed controller parameters</a>	82
4.2.28	<a href="#">CAN on board: Reset node</a>	83
4.2.29	<a href="#">CAN module: Reset node</a>	84
4.2.30	<a href="#">CAN on board: Pred.Connect.Set</a>	85
4.2.31	<a href="#">CAN module: Pred.Connect.Set</a>	86
4.2.32	<a href="#">CAN on board: Identify node</a>	87
4.2.33	<a href="#">CAN module: Identify node</a>	88
4.2.34	<a href="#">Ethernet module MXI2 unbind/bind</a>	89
4.2.35	<a href="#">Ethernet module MXI2 unbind/bind</a>	90
4.2.36	<a href="#">Activate parameter set 1 ... 4</a>	91
4.2.37	<a href="#">Activate parameter set 1 ... 4</a>	93
4.2.38	<a href="#">Load cam data</a>	95
4.2.39	<a href="#">Save cam data</a>	97
4.2.40	<a href="#">Calculate cam data</a>	99
4.2.41	<a href="#">Calculate cam data checksum</a>	100

4.2.42	<a href="#">Format file system</a>	101
4.2.43	<a href="#">Restore file system</a>	102
4.2.44	<a href="#">Prepare firmware update</a>	103
4.2.45	<a href="#">Restart controller</a>	104
4.3	<a href="#">Device states</a>	105
4.3.1	<a href="#">"Initialisation active" state</a>	107
4.3.2	<a href="#">"Safe torque off active" state</a>	108
4.3.3	<a href="#">"Device is ready to switch on" state</a>	108
4.3.4	<a href="#">"Device is switched on" state</a>	109
4.3.5	<a href="#">"Operation" state</a>	109
4.3.6	<a href="#">"Warning active" state</a>	110
4.3.7	<a href="#">"Warning locked active" state</a>	110
4.3.8	<a href="#">"Quick stop by trouble active" state</a>	110
4.3.9	<a href="#">"Trouble active" state</a>	111
4.3.10	<a href="#">"Fault active" state</a>	111
4.3.11	<a href="#">"System fault active" state</a>	111
4.4	<a href="#">Automatic restart after mains connection/trouble...</a>	112
4.5	<a href="#">Behaviour after task overflow</a>	114
4.6	<a href="#">Device output power</a>	115
4.6.1	<a href="#">Switching frequency</a>	115
4.6.2	<a href="#">Monitoring of the device utilisation</a>	116
4.6.3	<a href="#">Operation with increased continuous power</a>	117
4.7	<a href="#">Internal interfaces   "LS_DriveInterface" system block</a>	118
4.7.1	<a href="#">Status signals</a>	121
4.7.2	<a href="#">Monitoring of external events</a>	122
5	<a href="#">Motor interface</a>	123
5.1	<a href="#">General information</a>	125
5.1.1	<a href="#">Reading out motor data from the controller</a>	125
5.1.2	<a href="#">Selecting motor in the »Engineer« motor catalogue</a>	126
5.1.3	<a href="#">Displaying/editing motor data in the »Engineer«</a>	127
5.2	<a href="#">Select motor control</a>	129
5.3	<a href="#">Adjusting motor and controller to each other</a>	131
5.3.1	<a href="#">Accepting/adapting plant parameters</a>	132
5.3.2	<a href="#">Parameterise motor encoder</a>	134
5.3.3	<a href="#">Pole position identification</a>	136
5.3.3.1	<a href="#">Adjustment of the pole position identification</a>	140
5.3.4	<a href="#">Optimising the switching performance of the inverter</a>	143
5.3.5	<a href="#">Determining the motor parameters</a>	146

5.4	<a href="#">Servo control (SC)</a>	151
5.4.1	<a href="#">Optimise control mode</a>	152
5.4.1.1	<a href="#">Optimise current controller</a>	153
5.4.1.2	<a href="#">Optimising the speed controller</a>	156
5.4.1.3	<a href="#">Set current setpoint filter (band-stop filter)</a>	159
5.4.1.4	<a href="#">Optimising phase controller</a>	162
5.4.1.5	<a href="#">Optimise response to setpoint changes</a>	163
5.4.1.6	<a href="#">Setting the field weakening for asynchronous machines</a>	165
5.4.2	<a href="#">Signal flow (servo control for synchronous motor)</a>	168
5.4.3	<a href="#">Signal flow (servo control for asynchronous motor)</a>	170
5.5	<a href="#">Sensorless vector control (SLVC)</a>	172
5.5.1	<a href="#">Basic settings</a>	173
5.5.1.1	<a href="#">Parameterising speed and torque controller</a>	174
5.5.2	<a href="#">Optimising motor parameters</a>	175
5.5.2.1	<a href="#">Motor power factor</a>	176
5.5.2.2	<a href="#">Motor stator resistance</a>	177
5.5.2.3	<a href="#">Mutual motor inductance</a>	178
5.5.2.4	<a href="#">Motor rotor resistance</a>	180
5.5.3	<a href="#">Optimise control mode</a>	181
5.5.3.1	<a href="#">Optimising field feedforward control</a>	182
5.5.3.2	<a href="#">Optimising the speed controller</a>	183
5.5.3.3	<a href="#">Optimising torque controller</a>	185
5.5.3.4	<a href="#">Optimise current controller</a>	187
5.5.4	<a href="#">Signal flow</a>	189
5.6	<a href="#">V/f control (VFCplus)</a>	190
5.6.1	<a href="#">Basic settings</a>	190
5.6.1.1	<a href="#">Defining the V/f characteristic</a>	191
5.6.1.2	<a href="#">Setting the voltage boost</a>	192
5.6.1.3	<a href="#">Parameterising load adjustment</a>	194
5.6.1.4	<a href="#">Activating voltage vector control</a>	195
5.6.1.5	<a href="#">Defining the current limit (I<sub>max</sub> controller)</a>	196
5.6.2	<a href="#">Optimise control mode</a>	197
5.6.2.1	<a href="#">Free definition of the V/f characteristic</a>	198
5.6.2.2	<a href="#">Parameterising slip compensation</a>	199
5.6.2.3	<a href="#">Parameterising oscillation damping</a>	200
5.6.2.4	<a href="#">Optimise current controller</a>	202
5.6.2.5	<a href="#">Optimise pull-out slip limitation</a>	204
5.6.3	<a href="#">Signal flow</a>	205
5.7	<a href="#">V/f control (VFCplus)</a>	206
5.7.1	<a href="#">Signal flow</a>	207

5.8	<a href="#">Parameterisable additional functions</a>	209
5.8.1	<a href="#">Correction of the stator leakage inductance...</a>	210
5.8.2	<a href="#">Field weakening for synchronous machines</a>	215
5.8.3	<a href="#">Flying restart function</a>	218
5.8.4	<a href="#">DC-injection braking</a>	221
5.9	<a href="#">Monitoring</a>	223
5.9.1	<a href="#">Signal flow</a>	223
5.9.2	<a href="#">Motor monitoring (<math>I^2xt</math>)</a>	224
5.9.2.1	<a href="#">Example for entry of the characteristic for asynchronous servo motor</a>	227
5.9.2.2	<a href="#">Example for entry of the characteristic for synchronous servo motor</a>	228
5.9.3	<a href="#">Motor temperature monitoring</a>	229
5.9.3.1	<a href="#">Special characteristic for motor temperature sensor</a>	230
5.9.3.2	<a href="#">Motor temperature monitoring (PTC)</a>	231
5.9.3.3	<a href="#">Temperature monitoring of a second motor</a>	232
5.9.4	<a href="#">Motor phase failure monitoring</a>	233
5.9.4.1	<a href="#">Monitoring of the individual motor phases during operation</a>	233
5.9.4.2	<a href="#">Checking the individual motor phases before operation is started</a>	234
5.9.5	<a href="#">Maximum current monitoring</a>	235
5.10	<a href="#">Internal interfaces   "LS MotorInterface" system block</a>	236

<b>6</b>	<b><u>Encoder evaluation</u></b> .....	<b>241</b>
6.1	<u>Internal interfaces   "LS Feedback" system block</u> .....	242
6.1.1	<u>Use of an external position encoder</u> .....	244
6.2	<u>Signal flow</u> .....	245
6.3	<u>Parameter setting</u> .....	246
6.3.1	<u>Controller configuration</u> .....	248
6.3.2	<u>System with motor encoder</u> .....	250
6.3.3	<u>System with motor encoder and position encoder</u> .....	251
6.3.4	<u>Adaptation of the resolver evaluation dynamics</u> .....	252
6.3.5	<u>Parameterisation of an unknown Hiperface encoder</u> .....	253
6.3.6	<u>Support of the laser measuring system (DME4000/5000)</u> .....	254
6.3.7	<u>Use of an SSI encoder at X8</u> .....	255
6.3.7.1	<u>"LS SsiEncoderX8" system block</u> .....	256
6.3.7.2	<u>Division of the SSI data word into partwords</u> .....	257
6.3.8	<u>Provision of the encoder signal of input X8</u> .....	258
6.3.8.1	<u>System block "LS EncoderX8"</u> .....	258
6.3.8.2	<u>Activate evaluation</u> .....	259
6.3.9	<u>Resolver error compensation</u> .....	261
6.3.10	<u>Encoder angular drift monitoring</u> .....	263
6.3.10.1	<u>Angular drift monitoring for encoders without absolute information</u> 263	
6.3.10.2	<u>Angular drift monitoring for encoders with absolute information</u>	264
<b>7</b>	<b><u>Braking operation</u></b> .....	<b>265</b>
7.1	<u>Parameter setting</u> .....	266
7.1.1	<u>Setting the voltage threshold for braking operation</u> .....	266
7.2	<u>Monitoring</u> .....	267
7.2.1	<u>Overcurrent protection</u> .....	267
7.2.2	<u>Ixt utilisation - brake transistor</u> .....	268
7.2.3	<u>I2t utilisation - brake resistor</u> .....	269
7.2.4	<u>DC bus overvoltage</u> .....	271



<b>8</b>	<b><u>I/O terminals</u></b> .....	<b>272</b>
8.1	<u>Overview</u> .....	273
8.2	<u>Analog inputs</u> .....	274
8.2.1	<u>Terminal assignment/electrical data</u> .....	274
8.2.2	<u>Parameter setting</u> .....	275
8.2.3	<u>Reconfiguring analog input 1 into current input</u> .....	275
8.2.4	<u>"LS AnalogInput" system block</u> .....	276
8.3	<u>Analog outputs</u> .....	277
8.3.1	<u>Terminal assignment/electrical data</u> .....	277
8.3.2	<u>Parameter setting</u> .....	278
8.3.3	<u>"LS AnalogOutput" system block</u> .....	278
8.4	<u>Digital inputs</u> .....	279
8.4.1	<u>Terminal assignment/electrical data</u> .....	279
8.4.2	<u>Parameter setting</u> .....	279
8.4.3	<u>"LS DigitalInput" system block</u> .....	280
8.5	<u>Digital outputs</u> .....	281
8.5.1	<u>Terminal assignment/electrical data</u> .....	281
8.5.2	<u>Parameter setting</u> .....	281
8.5.3	<u>"LS DigitalOutput" system block</u> .....	282
8.6	<u>"State bus" monitoring function</u> .....	283
8.6.1	<u>Detecting the current state</u> .....	284
8.6.2	<u>Setting the state bus to the "Error" state</u> .....	284
8.7	<u>Touch probe detection</u> .....	285
8.7.1	<u>Actual value interpolation (principle)</u> .....	286
8.7.2	<u>Dead time compensation</u> .....	287
8.7.3	<u>"LS TouchProbe1...8" system block</u> .....	288
8.7.4	<u>"LS TouchProbeMotor" system block</u> .....	289
8.7.5	<u>"LS TouchProbeLoad" system block</u> .....	289
8.8	<u>Configure exception handling of the outputs</u> .....	290

<b>9</b>	<b><u>"CAN on board" system bus</u></b>	<b>292</b>
9.1	<u>General information</u>	293
9.1.1	<u>General data and operating conditions</u>	294
9.1.2	<u>Supported protocols</u>	294
9.1.3	<u>Communication time</u>	295
9.2	<u>Possible settings by DIP switch</u>	296
9.2.1	<u>Setting the node address</u>	296
9.2.2	<u>Setting the baud rate</u>	297
9.3	<u>LED status displays for the system bus</u>	298
9.4	<u>Structure of the CAN data telegram</u>	299
9.4.1	<u>Identifier</u>	299
9.4.2	<u>User data</u>	301
9.5	<u>Communication phases/network management</u>	302
9.5.1	<u>State transitions</u>	303
9.5.2	<u>Network management telegram (NMT)</u>	304
9.5.3	<u>Parameterising the controller as CAN master</u>	305
9.6	<u>Process data transfer</u>	306
9.6.1	<u>Identifiers of the process data objects</u>	307
9.6.2	<u>Transmission type</u>	308
9.6.3	<u>Masking of the TPDOs for event control</u>	309
9.6.4	<u>Monitoring of the RPDOs for data reception</u>	309
9.6.5	<u>Synchronisation of PDOs via sync telegram</u>	310
9.6.5.1	<u>Parameter setting</u>	311
9.6.5.2	<u>Effect of C01130 on the sync phase position</u>	313
9.7	<u>Parameter data transfer</u>	315
9.7.1	<u>Identifiers of the parameter data objects</u>	316
9.7.2	<u>User data</u>	317
9.7.2.1	<u>Command</u>	318
9.7.2.2	<u>Addressing through index and subindex</u>	319
9.7.2.3	<u>Data 1 ... data 4</u>	320
9.7.2.4	<u>Error messages</u>	321
9.7.3	<u>Examples for a parameter data telegram</u>	323
9.7.3.1	<u>Reading parameters</u>	323
9.7.3.2	<u>Writing parameters</u>	324
9.7.3.3	<u>Reading block parameters</u>	325
9.8	<u>Diagnostics</u>	328

9.9	<a href="#">Monitoring</a>	329
9.9.1	<a href="#">Node guarding protocol</a>	329
9.9.1.1	<a href="#">Telegram structure</a>	330
9.9.1.2	<a href="#">Parameter setting</a>	331
9.9.1.3	<a href="#">Commissioning example</a>	333
9.9.2	<a href="#">Heartbeat protocol</a>	335
9.9.2.1	<a href="#">Telegram structure</a>	336
9.9.2.2	<a href="#">Parameter setting</a>	336
9.9.2.3	<a href="#">Commissioning example</a>	338
9.9.3	<a href="#">Emergency telegram</a>	339
9.10	<a href="#">Implemented CANopen objects</a>	340
9.11	<a href="#">System block "LS_SyncInput"</a>	365
9.11.1	<a href="#">Behaviour of the status signal bSyncInsideWindow</a>	366
<b>10</b>	<b><a href="#">Safety engineering</a></b>	<b>367</b>
10.1	<a href="#">Integration into the application</a>	368
10.2	<a href="#">Selecting the required safety module</a>	369
10.3	<a href="#">System block "LS_SafetyModuleInterface"</a>	370
10.3.1	<a href="#">Status information</a>	371
10.3.2	<a href="#">I/O status information</a>	372
10.3.3	<a href="#">Control information</a>	373
<b>11</b>	<b><a href="#">Basic drive functions</a></b>	<b>375</b>
11.1	<a href="#">General information</a>	376
11.1.1	<a href="#">Internal state machine</a>	376
11.1.2	<a href="#">Function states</a>	378
11.1.3	<a href="#">Interrupting/replacing states</a>	380
11.1.4	<a href="#">Priorities</a>	381
11.1.5	<a href="#">Requesting control via a basic function</a>	381
11.1.6	<a href="#">Start acceleration/acceleration reduction when the basic function changes</a>	383
11.1.7	<a href="#">Setting the S-ramp time</a>	385
11.2	<a href="#">Stop</a>	387
11.2.1	<a href="#">Internal interfaces   "LS_Stop" system block</a>	388
11.2.2	<a href="#">Parameter setting</a>	389
11.2.3	<a href="#">Behaviour of the function (example)</a>	390

11.3	<a href="#">Quick stop</a>	391
11.3.1	<a href="#">Internal interfaces   "LS Quickstop" system block</a>	391
11.3.2	<a href="#">Parameter setting</a>	392
11.3.3	<a href="#">Activating/deactivating quick stop</a>	394
11.3.4	<a href="#">DC-injection braking</a>	395
11.3.4.1	<a href="#">DC-injection braking and flying restart process</a>	396
11.3.4.2	<a href="#">DC-injection braking when quick stop is activated</a>	397
11.4	<a href="#">Manual jog</a>	398
11.4.1	<a href="#">Internal interfaces   "LS ManualJog" system block</a>	399
11.4.2	<a href="#">Parameter setting</a>	402
11.4.2.1	<a href="#">Smooth start and quick stop of the drive</a>	402
11.4.2.2	<a href="#">Second speed</a>	403
11.4.3	<a href="#">Executing manual jog</a>	404
11.4.3.1	<a href="#">Manual jog in positive/negative direction</a>	405
11.4.3.2	<a href="#">Manual jog with step limitation</a>	406
11.4.3.3	<a href="#">Manual jog with intermediate stop</a>	407
11.4.3.4	<a href="#">Manual jog to limit position</a>	408
11.4.3.5	<a href="#">Retracting of an activated limit switch</a>	409
11.5	<a href="#">Manual jog, encoderless</a>	410
11.5.1	<a href="#">Internal interfaces   "LS ManualJogOpenLoop" system block</a>	411
11.5.2	<a href="#">Parameter setting</a>	413
11.5.2.1	<a href="#">Necessary basic parameter settings</a>	414
11.5.2.2	<a href="#">Profile parameters</a>	414
11.5.3	<a href="#">Executing manual jog open loop</a>	415
11.5.3.1	<a href="#">Selection of the profile parameter set</a>	418
11.5.3.2	<a href="#">Manual jog open loop in positive/negative direction</a>	418

11.6	<a href="#">Homing</a>	419
11.6.1	<a href="#">Internal interfaces   "LS Homing" system block</a>	421
11.6.2	<a href="#">Parameter setting</a>	423
11.6.2.1	<a href="#">Behaviour of the home position after mains switching</a>	424
11.6.2.2	<a href="#">Homing mode</a>	425
11.6.2.3	<a href="#">Home position &amp; target position</a>	426
11.6.2.4	<a href="#">Drive behaviour after setting the home position</a>	426
11.6.2.5	<a href="#">Profile data set change-over</a>	427
11.6.2.6	<a href="#">Homing to end stop</a>	429
11.6.2.7	<a href="#">Connection of reference switch</a>	429
11.6.2.8	<a href="#">Touch probe interface configuration</a>	429
11.6.3	<a href="#">Overview of the Lenze homing modes</a>	430
11.6.4	<a href="#">Overview of DS402 homing modes</a>	445
11.6.5	<a href="#">Execute homing</a>	479
11.6.5.1	<a href="#">Starting reference search/setting the reference directly</a>	480
11.6.5.2	<a href="#">Loading home position via input</a>	480
11.6.5.3	<a href="#">Resetting home position</a>	481
11.7	<a href="#">Positioning</a>	482
11.7.1	<a href="#">Internal interfaces   "LS Positioner" system block</a>	483
11.7.1.1	<a href="#">Possibilities for the selection of the profile</a>	487
11.7.2	<a href="#">Parameter setting</a>	488
11.7.2.1	<a href="#">Actual value-based evaluation "Target position reached"</a>	488
11.7.2.2	<a href="#">Actual value- and setpoint-based evaluation "Drive in the target"</a>	489
11.7.3	<a href="#">Carrying out positioning</a>	490
11.7.3.1	<a href="#">Starting positioning</a>	491
11.7.3.2	<a href="#">Aborting/interrupting positioning</a>	491
11.7.3.3	<a href="#">Continue interrupted positioning</a>	492
11.7.3.4	<a href="#">Activating override</a>	493
11.8	<a href="#">Position follower</a>	494
11.8.1	<a href="#">Internal interfaces   "LS PositionFollower" system block</a>	495
11.8.2	<a href="#">Signal flow</a>	497
11.8.3	<a href="#">Parameter setting</a>	499
11.8.3.1	<a href="#">Setpoint interpolation</a>	500
11.8.3.2	<a href="#">Inversion of the direction of rotation</a>	500
11.8.4	<a href="#">Activating setpoint interface</a>	501

11.9	<a href="#">Speed follower</a>	502
11.9.1	<a href="#">Internal interfaces   "LS SpeedFollower" system block</a>	502
11.9.2	<a href="#">Signal flow</a>	504
11.9.3	<a href="#">Parameter setting</a>	505
11.9.3.1	<a href="#">Setpoint interpolation</a>	506
11.9.3.2	<a href="#">Inversion of the direction of rotation</a>	506
11.9.4	<a href="#">Activating setpoint interface</a>	507
11.10	<a href="#">Torque follower</a>	508
11.10.1	<a href="#">Internal interfaces   "LS TorqueFollower" system block</a>	509
11.10.2	<a href="#">Signal flow</a>	510
11.10.3	<a href="#">Parameter setting</a>	511
11.10.3.1	<a href="#">Setpoint interpolation</a>	511
11.10.3.2	<a href="#">Inversion of the direction of rotation</a>	511
11.10.4	<a href="#">Activating setpoint interface</a>	512
11.11	<a href="#">Limiter</a>	513
11.11.1	<a href="#">Internal interfaces   "LS Limiter" system block</a>	513
11.11.1.1	<a href="#">Interface to the safety module</a>	517
11.11.2	<a href="#">Parameter setting</a>	518
11.11.2.1	<a href="#">Software limit positions</a>	519
11.11.2.2	<a href="#">Triggering behaviour of software limit position monitoring</a>	521
11.11.2.3	<a href="#">Hardware limit positions (limit switch)</a>	522
11.11.2.4	<a href="#">Limitations</a>	524
11.11.2.5	<a href="#">Permissible direction of rotation</a>	525
11.11.2.6	<a href="#">Limited speed</a>	526
11.11.2.7	<a href="#">Limited increment for manual jog</a>	527

11.12	<a href="#">Brake control</a>	528
11.12.1	<a href="#">Internal interfaces   "LS Brake" system block</a>	530
11.12.2	<a href="#">Parameter setting</a>	532
11.12.2.1	<a href="#">Operating mode</a>	533
11.12.2.2	<a href="#">Signal configuration</a>	534
11.12.2.3	<a href="#">Standstill monitoring</a>	537
11.12.2.4	<a href="#">Brake activation in automatic operation</a>	538
11.12.2.5	<a href="#">Brake time response</a>	540
11.12.2.6	<a href="#">Torque feedforward control</a>	543
11.12.2.7	<a href="#">Torque feedforward control via ramp function</a>	546
11.12.2.8	<a href="#">Speed feedforward control via ramp function for V/f control</a>	547
11.12.3	<a href="#">Mode 0: Brake control is switched off</a>	548
11.12.4	<a href="#">Mode 1/11: Direct control of the brake</a>	549
11.12.5	<a href="#">Mode 2/12: Automatic control of the brake</a>	550
11.12.5.1	<a href="#">Behaviour at pulse inhibit</a>	551
11.12.5.2	<a href="#">Process when brake is released</a>	553
11.12.5.3	<a href="#">Process when brake is closed</a>	554
11.12.6	<a href="#">Mode 22: Automatic DC-injection braking</a>	555
11.12.7	<a href="#">Grinding the brake</a>	558
11.12.8	<a href="#">Carrying out brake test</a>	560
11.12.9	<a href="#">Control of two motor holding brakes</a>	562
11.13	<a href="#">Cam data management</a>	563
11.13.1	<a href="#">"Online" tab for cam data management</a>	564
11.13.1.1	<a href="#">Memory distribution</a>	565
11.13.1.2	<a href="#">Access protection</a>	566
11.13.1.3	<a href="#">Regenerating the cam data file and transferring it to the controller</a>	568
11.13.2	<a href="#">Internal interfaces   "LS CamInterface" system block</a>	569
11.13.3	<a href="#">Parameter setting</a>	571
11.13.3.1	<a href="#">Password entry</a>	572
11.13.3.2	<a href="#">Online change mode</a>	573
11.13.3.3	<a href="#">Changing cam data via parameterisation</a>	575
11.13.4	<a href="#">Product/track change-over</a>	578
11.13.5	<a href="#">Invalid cam data due to changed machine parameters</a>	579
11.13.6	<a href="#">Behaviour after mains switching</a>	580
11.14	<a href="#">Pole position identification</a>	581
11.14.1	<a href="#">Internal interfaces   System block "LS PolePositionIdentification"</a>	582
11.14.2	<a href="#">Parameter setting</a>	584
11.14.3	<a href="#">Execute pole position identification</a>	584
11.14.4	<a href="#">Signal characteristics</a>	586
11.14.5	<a href="#">Impacts of parameter changes on the signal PPI bPolePositionAvailable</a>	588

<b>12</b>	<b><u>Oscilloscope</u></b> .....	<b>590</b>
12.1	<u>Technical data</u> .....	590
12.2	<u>Functional description</u> .....	591
12.3	<u>User interface</u> .....	592
12.3.1	<u>Oscilloscope toolbar</u> .....	593
12.3.2	<u>Oscillograph</u> .....	593
12.3.3	<u>Vertical settings</u> .....	594
12.3.4	<u>Status bar</u> .....	594
12.3.5	<u>Trigger/cursor settings</u> .....	594
12.3.6	<u>Horizontal settings</u> .....	595
12.3.7	<u>Recording settings</u> .....	595
12.4	<u>Operation</u> .....	596
12.4.1	<u>Selecting the variables to be recorded</u> .....	596
12.4.2	<u>Selecting the recording time/sample rate</u> .....	597
12.4.3	<u>Selecting the trigger condition</u> .....	598
12.4.4	<u>Starting recording</u> .....	599
12.4.5	<u>Adjusting the representation</u> .....	600
12.4.6	<u>Reading individual measured values</u> .....	601
12.4.7	<u>Compare peak values</u> .....	602
12.5	<u>Data records</u> .....	603
12.5.1	<u>Comment data record</u> .....	603
12.5.2	<u>Saving/exporting a data record</u> .....	604
12.5.3	<u>Loading/importing a data record</u> .....	605
12.5.4	<u>Close data record</u> .....	606
12.5.5	<u>Deleting a data record in the project</u> .....	606
12.5.6	<u>Overlay function</u> .....	607
12.5.7	<u>Copying a data record to the clipboard</u> .....	607
12.6	<u>Variables of the motor control (oscilloscope signals)</u> .....	608
<b>13</b>	<b><u>Diagnostics &amp; fault analysis</u></b> .....	<b>611</b>
13.1	<u>LED status displays</u> .....	611
13.1.1	<u>LED status displays for the device state</u> .....	612
13.2	<u>Drive diagnostics with the »Engineer«</u> .....	613
13.3	<u>Drive diagnostics via keypad/bus system</u> .....	614
13.4	<u>Logbook</u> .....	616
13.4.1	<u>Functional description</u> .....	617
13.4.2	<u>Filtering logbook entries</u> .....	617
13.4.3	<u>Reading out logbook entries</u> .....	618
13.4.4	<u>Export logbook entries into a file</u> .....	619



13.5	<a href="#">Monitoring</a>	620
13.5.1	<a href="#">Setting the error response</a>	621
13.6	<a href="#">Maloperation of the drive</a>	622
13.7	<a href="#">Error messages of the operating system</a>	623
13.7.1	<a href="#">Structure of the error number (bit coding)</a>	623
13.7.1.1	<a href="#">Response</a>	624
13.7.1.2	<a href="#">Instance ID</a>	624
13.7.1.3	<a href="#">Module ID</a>	625
13.7.1.4	<a href="#">Error ID</a>	626
13.7.1.5	<a href="#">Example for bit coding of the error number</a>	626
13.7.2	<a href="#">Reset of error message</a>	627
13.7.3	<a href="#">Short overview (A-Z)</a>	628
13.7.4	<a href="#">Cause &amp; possible remedies</a>	636
<b>14</b>	<b><a href="#">Parameter reference</a></b>	<b>705</b>
14.1	<a href="#">Structure of the parameter descriptions</a>	706
14.1.1	<a href="#">Data type</a>	706
14.1.2	<a href="#">Parameters with read-only access</a>	707
14.1.3	<a href="#">Parameters with write access</a>	707
14.1.3.1	<a href="#">Parameters with setting range</a>	708
14.1.3.2	<a href="#">Parameters with selection list</a>	708
14.1.3.3	<a href="#">Parameters with a bit coded setting</a>	709
14.1.3.4	<a href="#">Parameters with subcodes</a>	710
14.1.4	<a href="#">Parameter attributes</a>	711
14.1.5	<a href="#">Abbreviations used in parameter &amp; selection texts</a>	711
14.2	<a href="#">Parameter list</a>	712
14.3	<a href="#">Attribute table</a>	881
<b>15</b>	<b><a href="#">Index</a></b>	<b>894</b>
	<a href="#">Your opinion is important to us</a>	919

## 1 About this documentation

This documentation contains information on the 9400 HighLine controller.



Read the Mounting Instructions supplied with the controller before you start working!

**The Mounting Instructions contain safety information which must be observed!**

### Target group

This documentation addresses to all persons who want to parameterise, configure, and diagnose the 9400 HighLine controller by means of the engineering software L-force »Engineer« and the keypad.

### Validity information

The information in this documentation applies to the following standard devices:



Product series	Type designation	From software version
Servo Drives 9400	E94AxHExxxx	1.5

### Document history

Version			Description
1.0	12/2006	TD05	First edition for 9400 HighLine V1.5
2.0	05/2007	TD05	Extended edition
3.0	11/2007	TD05	Supplemented with new functions for 9400 HighLine V3
4.0	06/2008	TD05	Supplemented with new functions for 9400 HighLine V4
4.1	07/2008	TD05	New main chapter: " <a href="#">CAN on board</a> " system bus
5.0	11/2008	TD05	Extended by new functions for 9400 HighLine V5
5.1	12/2008	TD05	Error corrections
5.2	01/2009	TD05	Error corrections & supplements
6.0	08/2009	TD05	Extended by new functions for 9400 HighLine V7
6.1	08/2009	TD05	Error corrections & supplements

## 1.1 Conventions used

This documentation uses the following conventions to distinguish between different types of information:

Type of information	Writing	Examples/notes
Numbers		
Decimal separator	Point	The decimal point is always used. Example: 1234.56
Text		
Version information	Text colour blue	The information valid for or from one specific software version of the controller is marked accordingly in this documentation. Example: <a href="#">This function extension is available from software version V3.0!</a>
Program name	» «	The Lenze PC software »Engineer«...
Window	<i>Italics</i>	The <i>Message window</i> ... / The <i>Options</i> dialog box...
Variable identifier		By setting <i>bEnable</i> to TRUE...
Control element	<b>Bold</b>	The <b>OK</b> button... / The <b>Copy</b> command... / The <b>Properties</b> tab... / The <b>Name</b> input field...
Sequence of menu commands		If the execution of a function requires several commands, the individual commands are separated by an arrow: Select <b>File</b> → <b>Open</b> to...
Shortcut	< <b>Bold</b> >	Use < <b>F1</b> > to open the online help. If a command requires a combination of keys, a "+" is placed between the key symbols: Use < <b>Shift</b> >+< <b>ESC</b> > to...
Program code	Courier	<b>IF</b> var1 < var2 <b>THEN</b>
Keyword	<b>Courier bold</b>	a = a + 1 <b>END IF</b>
Hyperlink	<u>Underlined</u>	Optically highlighted reference to another topic. It is activated with a mouse click in this online documentation.
Symbols		
Page reference	 19	Optically highlighted reference to another page. It is activated with a mouse click in this online documentation.
Step-by-step instructions		Step-by-step instructions are indicated by a pictograph.

---

The information valid for or from one specific software version of the controller is marked accordingly in this documentation.

---

## 1.2 Terminology used

Term	Meaning
»Engineer«	Lenze software which supports you throughout the whole machine life cycle - from planning to maintenance.
Code	"Container" for one or several parameters used for controller parameter setting or monitoring.
Subcode	If a code contains several parameters, the individual parameters are stored under "subcodes". This Manual uses a slash "/" as a separator between code and subcode (e.g. "C00118/3").
Function block editor	Graphical interconnection tool which is provided for controllers in the MotionControl HighLevel and TopLevel license level in the »Engineer« on the <b>FB editor</b> tab and by means of which the technology applications supplied can also be reconfigured and extended by individual functions.
Function block	A function block (FB) can be compared with an integrated circuit that contains a certain control logic and delivers one or several values when being executed. <ul style="list-style-type: none"><li>• An instance (reproduction, copy) of the function block is always inserted in the circuit.</li><li>• It is also possible to insert several instances of a function block in a circuit.</li><li>• Each instance has an unequivocal identifier (the instance name) and a processing number which defines the position at which the function block is calculated during the task cycle.</li></ul>
System block	System blocks provide interfaces to basic functions and hardware of the controller in the function block editor of the »Engineer« (e.g. to the digital inputs). <ul style="list-style-type: none"><li>• System blocks cannot be instanced in contrast to function blocks.</li></ul>
DIS code	Parameter that displays the current state or value of an input/output of a system block.
TA	Abbreviation for "Technology Application". Technology applications are applications prepared by Lenze which form the basis of solving typical applications. Each technology application is provided with an individual online documentation.

## 1.3 Definition of notes used

The following signal words and symbols are used in this documentation to indicate dangers and important information:

### Safety instructions

Layout of the safety instructions:



#### **Danger!**

(characterises the type and severity of danger)

#### **Note**

(describes the danger and gives information about how to prevent dangerous situations)

Pictograph	Signal word	Meaning
	<b>Danger!</b>	<b>Danger of personal injury through dangerous electrical voltage</b> Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
	<b>Danger!</b>	<b>Danger of personal injury through a general source of danger</b> Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
	<b>Stop!</b>	<b>Danger of property damage</b> Reference to a possible danger that may result in property damage if the corresponding measures are not taken.

### Application notes

Pictograph	Signal word	Meaning
	<b>Note!</b>	Important note to ensure trouble-free operation
	<b>Tip!</b>	Useful tip for simple handling
		Reference to another document

## 2 Introduction

The basis of every **L-force** application is an easy and quick parameter setting of prepared technology applications and solutions\*.


This chapter contains basic information on the runtime software model of **L-force** and on how you can establish an online connection between the PC and controller for parameter setting with the »Engineer« very easily.

At the end of this chapter you will find an overview of the different signal types & scaling which serve to process physical values (e.g. a speed or position) within the application.

\* In preparation!

### 2.1 Parameter setting, configuring, or programming?

The graded runtime software model of **L-force** provides a simple and consistent solution for motion and process tasks as well as for complex machine functions:



Programming\*

#### Configuring

The HighLevel and TopLevel licenses enable you to extend the provided technology applications by individual functions using the graphic function block editor of the »Engineer«. Here you can access the comprehensive function libraries of Lenze which among other things contain process controllers, arithmetic functions, logic blocks, and ramp generators and integrators.

#### Parameter setting

The StateLevel license includes a range of technology applications which can be put into operation easily with a keypad or via dialogs in the »Engineer«.

\* In preparation!

## 2.1.1 Basic functionalities

Important basic drive functions and further basic functions are implemented in the firmware of the controller and thus are always provided, irrespective of the runtime software licence available.

**Firmware**

<p><b>Motion Control basic drive functions</b></p> <ul style="list-style-type: none"> <li>• <a href="#">Stop</a></li> <li>• <a href="#">Quick stop</a></li> <li>• <a href="#">Manual jog</a></li> <li>• <a href="#">Homing</a></li> <li>• <a href="#">Positioning</a></li> <li>• <a href="#">Position follower</a></li> <li>• <a href="#">Speed follower</a></li> <li>• <a href="#">Torque follower</a></li> <li>• <a href="#">Limiter</a></li> <li>• <a href="#">Brake control</a></li> </ul>	<p><b>Further basic functionalities</b></p> <ul style="list-style-type: none"> <li>• <a href="#">Drive interface</a></li> <li>• <a href="#">Motor interface</a></li> <li>• <a href="#">Encoder evaluation</a></li> <li>• <a href="#">I/O terminals</a></li> <li>• <a href="#">Safety engineering</a></li> <li>• <a href="#">Logbook</a></li> <li>• <a href="#">Oscilloscope</a></li> </ul>
--	--

## 2.1.2 Technology applications

Technology applications (TAs) are applications prepared by Lenze which can serve as a basis for solving typical applications.

- ▶ The technology applications available for the Servo Drives 9400 can be selected in the »Engineer« from the application catalogue.

**Runtime software**

**Technology level**

**Motion Control TopLevel**

- TA "Positioning sequence control"
- TA "Electronic cam" \*
- TA "Register control" \*
- TA "Winding technology" \*

**Motion Control HighLevel**

- TA "Electronic gearbox"
- TA "Synchronism with mark synchronisation"

**Motion Control StateLevel**

- TA "Actuator – speed"
- TA "Actuator – torque"
- TA "Table positioning"

Each higher license contains additional technology applications for further application fields.

\* In preparation!



**Tip!**

Detailed information about the individual technology applications can be found in the corresponding software manuals.

## 2.2 Communicating with the controller

The following interfaces/communication modules can be used to establish communication between the PC and controller:

- ▶ Diagnostic interface X6/[Going online via diagnostic adapter](#)
- ▶ CAN on board interface/[Going online via system bus \(CAN on board\)](#) (☰ 27)
- ▶ Optional interfaces which are provided by corresponding communication modules in the module slots MXI1/MXI2 of the controller.



### Note!

For communication with the controller, at least the control electronics of the controller must be supplied with 24 V low voltage via plug X2. For detailed information, please see the Mounting Instructions for the controller.



### Stop!

If you change parameters in the »Engineer« while the controller is connected online, the changes will be directly accepted by the controller!



### Tip!

Detailed information about the individual interfaces can be found in the corresponding Communication Manuals (KHB).

### 2.2.1 Going online via diagnostic adapter

For initial commissioning of the controller you can for instance use the diagnostic adapter offered by Lenze:





**Note!**


Please observe the documentation for the diagnostic adapter!

**Preconditions:**

- ▶ The diagnostic adapter is connected to the controller at the diagnostic interface X6 and to the PC at a free USB port.
- ▶ The driver required for the diagnostic adapter is installed.
- ▶ The control electronics of the controller is supplied with 24 V low voltage via plug X2.

**How to build up an online connection via the diagnostic adapter:**

1. Select the 9400 HighLine controller to which you want to build up an online connection in the *Project view* of the »Engineer«:




2. Click the  icon.

If the changes you have made on the project have not been accepted yet, first a query on whether an update is to be carried out is effected.


If an update is to be carried out:



- Click on **Yes** to open the *Update project* dialog box.
- Press the **Create** button in the *Update project* dialog box to update the changed project elements.
- After the update a note is shown, saying whether the update was carried out successfully.

If no communication path was configured yet for the controller selected, the *Communication path* dialog box is shown after the update has been carried out:



- The "Diagnostic adapter" bus connection is already preset.
3. Click on **Connect**.
    - The dialog box is closed and the online connection with the controller is built up.
    - In the *Project view* a yellow icon indicates the online connection with the controller:



Now you can use the icons  and  to easily build up and end a connection with the controller. The communication settings are only required when communication with a controller is built up for the first time.

- ▶ If you want to change the configured communication path, select the command **Online** → **Set communication path and go online** to open the *Communication path* dialog box and change the settings.
- ▶ When an online connection has been established, the »Engineer« displays the current parameter settings of the controller with a yellow background colour.

## 2.2.2 Going online via system bus (CAN on board)

As an alternative to the diagnostic adapter, you can use the integrated system bus interface (CAN on board, terminal X1) of the controller for communication.

► Lenze offers the following communication accessories for connection to the PC:

Communication accessories	PC interface
<b>PC system bus adapter 2173</b> incl. connection cable and voltage supply adapter <ul style="list-style-type: none"> <li>• for DIN keyboard connection (EMF2173IB)</li> <li>• for PS/2 keyboard connection (EMF2173IBV002)</li> <li>• for PS/2 keyboard connection with electrical isolation (EMF2173IBV003)</li> </ul>	Parallel interface (LPT port)
<b>PC system bus adapter 2177</b> incl. connection cable (EMF2177IB)	USB (Universal Serial Bus)



### Note!

- For detailed information about the PC system bus adapter, please see the "CAN Communication Manual".
- Please observe the documentation for the PC system bus adapter!
- The online connection is established as described in the previous chapter "[Going online via diagnostic adapter](#)", only that this time the entry "CAN system bus" is to be selected in the **Bus connection** list field of the *Communication path* dialog box. (📖 25)

## 2.2.3 Use of other communication interfaces

The controller can be extended by further communication interfaces, if required, e.g. Ethernet, ETHERNET Powerlink, or PROFIBUS.

- For this the controller is provided with the module slots MXI1 and MXI2 for accepting communication modules.
- Detailed information on this subject can be found in the Hardware Manual and Communication Manual for the corresponding communication system.

## 2.3 Signal types & scaling

It is very helpful for the parameterisation & configuration of the controller to know the signal types and their scaling listed below, which serve to process physical quantities (e.g. a speed or position) within the function block interconnection.



### Note!

From software version V3.0 the resolution of an encoder revolution can be parameterised in [C00100](#) (Lenze setting: 16 bits/encoder revolution).

► [Resolution of an encoder revolution](#) (📖 44)

Signal type (data type)	Connection symbol in the FB editor	Resolution	Value range (external)	Decimal positions/ signal type suffix in the identifier
Scaled (INT)	○	16 bits	± 199.99 %	2    _a
Scaled (DINT)	●	32 bits	± 200.00 %	2    _n
Speed (INT)	◁/▷	16 bits	± 30000.0 rpm	1    _v
Speed (DINT)	◆	32 bits	± 480000.0 rpm	1    _s
Position/angle (DINT)	◁/▷	32 bits	-2 <sup>31</sup> ... 2 <sup>31</sup> -1 increments	3    _p
Digital (BOOL)	□	1 bit	0 ≡ FALSE; 1 ≡ TRUE	0
Acceleration (DINT)	■	32 bits	± 7.69 * 10 <sup>9</sup> rpm/s	3    _x
Time	■	28 bits	0 ... 268435.456 s	3
Other (BYTE)	■	8 bits	0 ... 255	0
Other (WORD)	■	16 bits	0 ... 65535	0
Other (DWORD)	■	32 bits	0 ... 4294967295	0
Other (INT)	■	16 bits	-32768 ... 32767	0
Other (DINT)	■	32 bits	-2147483648 ... 2147483647	0

### Scaling of physical quantities

Signal type	Connection symbol in the FB editor	Resolution	Scaling	
			External value	≡ internal value
Scaled (INT)	○	16 bits	100 %	≡ 2 <sup>14</sup> ≡ 16384
Scaled (DINT)	●	32 bits	100 %	≡ 2 <sup>30</sup> ≡ 1073741824
Speed (INT)	◁/▷	16 bits	15000 rpm	≡ 2 <sup>14</sup> ≡ 16384
Speed (DINT)	◆	32 bits	15000 rpm	≡ 2 <sup>26</sup> ≡ 67108864
Position/angle (DINT)	◁/▷	32 bits	1 encoder revolution	≡ 2 <sup>16</sup> increments
Acceleration (DINT)	■	32 bits	15000000 rpm/s	≡ 2 <sup>22</sup> ≡ 4194304

### 3 Commissioning

This documentation contains detailed information on parameter setting and configuration of the controller. Sequential reading is not required.

In order to obtain the information relevant for initial commissioning, this chapter describes different commissioning scenarios which can also be used as a guide through this manual:

A. [Initial commissioning](#) (📖 32)

- **Target:** Adapting the controller to the electromechanics and the control system.

B. [Standard set-up](#) (📖 33)

- **Target:** Taking over the application and parameter set of an already preconfigured "Engineer" project into several controllers.

C. [Controller replacement](#) (📖 34)

- **Target:** Replacing a controller which has failed in a running system by a replacement device using the "old" memory module.

D. [Motor replacement](#) (📖 34)

- **Target:** Replacing a motor which has failed in a running system.

## 3.1 General information



### Note!

Some parameters of the controller have a setting range depending on the device type.

If parameterisation is carried out offline or if the memory module is exchanged between different 9400 HighLine device types, always check the settings of the parameters listed in the following table and adapt them, if required, to prevent a parameter error after the parameter set download or module change!

Parameter	Information	Lenze setting
<a href="#">C00018</a>	<a href="#">Switching frequency</a>	8 kHz variable
<a href="#">C00022</a>	Maximum current ▶ <a href="#">Accepting/adapting plant parameters</a> (📖 132)	0.00 A
<a href="#">C00173</a> <a href="#">C00174</a>	Mains voltage and undervoltage threshold (LU) ▶ <a href="#">Machine parameters</a> (📖 36)	400/415 V, LU = 285 V



### Tip!

The rated data of the different device types can be found in the Hardware Manual in the "Rated data" chapter.

### Term definition of "Plant parameters"

The term "plant parameters" which is frequently used in the following chapters summarises all parameters which result from the combination of motor and load. They characterise the transfer behaviour of the entire controlled system including the desired monitoring functions. The plant parameters depend on the application in which the controller and motor are used.

### 3.2 Notes on commissioning using the keypad

#### For a motor with an electronic nameplate (ENP)

- ▶ A display of the plant parameters offered by ENP via keypad is not provided. The plant parameters must be edited and optimised individually.
- ▶ To avoid that the motor starts unintentionally without adjusting the plant parameters, the maximum current in the Lenze setting is set to "0 A" in [C00022](#).
- ▶ After setting the plant parameters, they have to be saved on the memory module of the controller with mains failure protection, just as the motor data that have been read out from the ENP ([C00002](#) = "11: Save start parameters").

#### For a motor without an electronic nameplate (ENP)

- ▶ The motor data and plant parameters must be edited and set individually.
- ▶ To avoid that the motor starts unintentionally without adjusting the plant parameters, the maximum current is set to "0 A" in [C00022](#) by the factory.
- ▶ After setting the motor data and plant parameters, they have to be saved on the memory module of the controller with mains failure protection ([C00002](#) = "11: Save start parameters").

#### Commissioning of the application


- ▶ The application must already be stored on the memory module of the controller. Otherwise commissioning by only using the keypad is not possible.
- ▶ All application parameters which deviate from the factory adjustment have to be edited individually. For this the project planner has to provide a corresponding list to the commissioner (including the motor and plant data).
- ▶ In the case of a standard set-up, a pole position identification may have to be carried out for synchronous motors of a third party manufacturer or Lenze synchronous motors with a Stegmann absolute value encoder.
- ▶ After setting the parameters, they have to be saved on the memory module of the controller with mains failure protection ([C00002](#) = "11: Save start parameters").



#### Tip!

Detailed information on the individual technology applications can be found in the corresponding Software Manual for the technology application and the »Engineer« online help in the chapter "L-force Servo Drives 9400 → Technology applications".

### 3.3 Initial commissioning

Worksteps	
<b>Parameterise motor control:</b>	
1.	Read out the motor data of the controller or select them via the »Engineer« motor catalogue. <ul style="list-style-type: none"><li>• If the motor connected to the controller is provided with an electronic nameplate (ENP), all motor data are automatically read out from the ENP and a selection in the motor catalogue is not required.<ul style="list-style-type: none"><li>▶ <a href="#">Reading out motor data from the controller</a> (📖 125)</li></ul></li><li>• If a motor without ENP or a motor by a third-party manufacturer is used, the selection is carried out via the »Engineer« motor catalogue. ▶ <a href="#">Selecting motor in the »Engineer« motor catalogue</a> (📖 126)</li></ul>
2.	<a href="#">Select motor control.</a> (📖 129) <ul style="list-style-type: none"><li>• Servo control is preset for the synchronous motor.</li></ul>
3.	<a href="#">Adjusting motor and controller to each other</a> (📖 131)
4.	Carry out settings for selected motor control. <ul style="list-style-type: none"><li>• For this see description for the corresponding motor control:<ul style="list-style-type: none"><li>– <a href="#">Servo control (SC)</a></li><li>– <a href="#">Sensorless vector control (SLVC)</a> (from software version V3.0)</li><li>– <a href="#">V/f control (VFCplus)</a> (from software version V3.0)</li><li>– <a href="#">V/f control (VFCplus)</a> (from software version V3.0)</li></ul></li></ul>
<b>Parameterise/configure application:</b>	
5.	Load & parameterise technology application.
	Detailed information on the individual technology applications can be found in the corresponding Software Manual for the technology application and the »Engineer« online help in the chapter "L-force Servo Drives 9400 → Technology applications".
6.	If required, reconfigure the interconnection of the technology application with the function block editor.
<b>Optimise control mode:</b>	
7.	Optimise control mode of the selected motor control. <ul style="list-style-type: none"><li>• By means of traversing profile from the application and oscilloscope.</li><li>• For this see description for the corresponding motor control:<ul style="list-style-type: none"><li>– <a href="#">Servo control (SC)</a></li><li>– <a href="#">Sensorless vector control (SLVC)</a> (from software version V3.0)</li><li>– <a href="#">V/f control (VFCplus)</a> (from software version V3.0)</li><li>– <a href="#">V/f control (VFCplus)</a> (from software version V3.0)</li></ul></li></ul>
<b>Save project and parameter set:</b>	
8.	Execute device command <a href="#">C00002</a> = "11: Save start parameters".
9.	Save »Engineer« project.


### More (optional) worksteps

Worksteps	
<b>Establish network:</b>	
1.	Insert network and machine application into the »Engineer« project.
2.	Interconnect port blocks reasonably to each other within the machine application.
3.	Configure network (set addresses, baud rate, and process data channels in a reasonable manner).
4.	Establish communication with the control system.
5.	Establish communication with other drive components (e.g. HMIs, I/O extensions and other controllers).



Worksteps	
<b>Check &amp; optimise application/DC-bus operation:</b>	
1.	Traverse axis in manual operation. • See chapter <a href="#">Basic drive functions</a> ▶ <a href="#">Manual jog</a> (📖 398)
2.	Check area boundaries (path, speed, torque).
3.	Traverse axis in automatic operation with set-up speed, possibly together with coupled axes.
4.	Check coupling with other movements (master/slave axes, tools, ...).
5.	Optimisation of the process at higher speeds.
6.	Recording of typical signal characteristics using the oscilloscope function for the documentation. • See chapter <a href="#">Oscilloscope</a> (📖 590)
<b>Save &amp; archive project and parameter set:</b>	
1.	Execute device command <a href="#">C00002</a> = "11: Save start parameters".
2.	Save »Engineer« project.
3.	Deposit a backup copy of the »Engineer« project, e.g. on CD ROM, in the control cabinet.

## 3.4 Standard set-up

Worksteps	
<b>Transfer application and parameter set to the controller:</b>	
1.	Transfer the application preconfigured in the »Engineer« and the corresponding parameter set to the memory module of the controller.
2.	Execute device command <a href="#">C00002</a> = "11: Save start parameters".
<b>For a motor with an electronic nameplate (ENP):</b>	
3.	Restart controller with connected motor to read out the motor data from the electronic nameplate (ENP). • Either by switching off/switching on again the voltage supply or by means of device command <a href="#">C00002</a> = "11000: Restart controller". • See chapter <a href="#">Motor interface</a> ▶ <a href="#">Reading out motor data from the controller</a> (📖 125)
4.	Execute device command <a href="#">C00002</a> = "11: Save start parameters".
<b>For a motor without an electronic nameplate (ENP):</b>	
	<b>Note:</b> The motor is operated with the motor data and plant parameters identified during initial commissioning. ▶ <a href="#">Adjusting motor and controller to each other</a> (📖 131)

## 3.5 Controller replacement

Scenario: The controller has failed in a running system.



### Note!

For the procedure described in the following it is assumed that the memory module and possibly available extension modules in the controller, as well as the motor are not affected by the failure and that all parameters have been saved with mains failure protection.

#### Worksteps

##### Replacement of the controller:

1. Replace controller.  
**See Mounting Instructions for the controller!**
2. Insert the memory module of the failed controller into the replacement device.
3. If further extension modules are plugged into the failed controller, they must be inserted into the replacement device as well.

Further steps are not required since all data required are on the memory module.

## 3.6 Motor replacement

Scenario: The motor has failed in a running system.



### Note!

For the procedure described in the following it is assumed that the controller is not affected by the failure.

#### Worksteps

##### Replacement of the motor:

1. Replace the motor.  
**See Mounting Instructions for the controller!**



#### Note:

The motor connection on the controller is accessible without having to remove the standard device from the installation backplane.

##### For a motor with an electronic nameplate (ENP):

2. Restart controller with connected motor to read out the motor data from the electronic nameplate.
  - Either by switching off/switching on again the voltage supply or by means of device command [C00002](#) = "11000: Restart controller".
  - See chapter [Motor interface](#) ▶ [Reading out motor data from the controller](#) (📖 125)
3. Execute device command [C00002](#) = "11: Save start parameters".

##### For a motor without an electronic nameplate (ENP):



#### Note:

The motor is operated with the motor data and plant data from the memory module.

## 4 Drive interface

This chapter provides you with information on the drive interface via which you can control the drive controller into specific states and call different pieces of status information of the controller. Furthermore the machine constants for the motor end are entered via the drive interface.




**How to get to the dialog for setting the drive interface parameters:**

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Select the **Application parameters** tab from the *Workspace*.
3. Click the following button of the *Overview* dialog level:



### Parameterisation dialog in the »Engineer«



- ▶ The white buttons indicate the configuration of the drive interface inputs. ▶ [Internal interfaces | "LS DriveInterface" system block \(118\)](#)
  - The assignment is predefined by the technology application selected (in the example "Actuating drive – speed"). If required, this assignment configuration can be changed by clicking the corresponding buttons.
- ▶ If you click a button marked with the → symbol, you go one level deeper in the corresponding parameterisation dialog.

## 4.1 Machine parameters

The global machine constants ("machine parameters") are set in the »Engineer« on the **Application parameters** tab in the dialog level *Overview* → *Drive interface* → *Machine parameters*:

Application Parameters

Overview → Drive interface → Machine parameter

**1** Mains voltage: 400/415 V  
Undervoltage (LU) threshold: 285 V  
Resp. to DC bus overvoltage: Trouble

**2** Gearbox reduction (motor)  
Motor encoder selection: Resolver on X7  
Gearbox factor numerator: 1 Z2  
Gearbox factor denom.: Mo.: 1 Z1  
Motor mounting direction: Motor rotating CW

**3** Gearbox reduction (load-side encoder)  
Position encoder selection: Motor encoder  
Gearbox factor num.: Pos. enc.: 1 Z4  
Gearbox fac. denom.: Pos. enc.: 1 Z3  
Position encoder mounting dir.: Encoder rotating CW

**4** Description for mechanism (load, tool)  
Traversing range: Unlimited  
Feed constant: 360.0000 /rev.  
Cycle: 360.0000  
Unit: \*  
User-defined unit: \*  
Time unit: s  
Load moment of inertia: 0.00 kg cm<sup>2</sup>  
Motor moment of inertia: 2.40 kg cm<sup>2</sup>  
Resol. of an encoder revolution: 24 Bit/Resolution  
Resolution of a unit: 46603.3778 Inc./unit  
Optimum



**Tip!**

Detailed information on the different machine parameters can be obtained from the following subchapters.

### 4.1.1 Mains voltage

Via the **Mains voltage** list field ([C00173](#)) the mains voltage for the controller is set.

- ▶ If you set a mains voltage with an adjustable threshold for undervoltage ("LU adjustable"), this undervoltage threshold can be set in the **Undervoltage threshold (LU)** input field ([C00174](#)).
- ▶ In the **Resp. to DC-bus overvoltage** list field ([C00600](#)) you can select the response that is to be effected when a DC-bus overvoltage occurs.



#### Note!

Changing the setting in [C00173](#) also affects the permissible device utilisation!




#### Tip!

In the chapter "Rated data" of the hardware manual the device types and their permissible device utilisation at a certain mains voltage and switching frequency are specified.

*See also:* ▶ [Monitoring of the device utilisation](#) (□ 116)

## 4.1.2 Gearbox ratio

The gearbox ratio specifies the number of revolutions of the motor axis needed for one rotation of the load axis (e.g. spindle or drive roll).




[4-1] Schematic diagram - gearbox ratio

- In the example shown in illustration [4-1] one revolution of the spindle is carried out at exactly 58,667 revolutions of the motor axis.

### Selection of the gearbox ratio

- The gearbox ratio is to be defined in the form of a quotient (numerator/denominator); the data required can be found in the technical data for the gearbox:



[4-2] Example: Technical data for the gearbox (from the gearbox catalogue)



### Tip!

For an exact selection of the gearbox ratio, use the number of teeth given in the data sheet or catalogue (see the following calculation) instead of the data on the nameplate.

In [C02531/1](#) the gearbox factor is displayed in decimal format.

### Example calculation on the basis of the technical gearbox data:

$$\begin{aligned} \text{Gearbox factor numerator (C02520)} &= z2 \times z4 = 88 \times 72 = 6336 \\ \text{Gearbox factor denominator (C02521)} &= z1 \times z3 = 12 \times 9 = 108 \end{aligned}$$

[4-3] Calculation example


### 4.1.3 Motor mounting direction

Depending on the motor mounting position, you can carry out an inversion of the direction of rotation via the **Motor mounting direction** list field ([C02527](#)), if required:

- ▶ [C02527](#) = "0": Clockwise rotating motor  $\equiv$  positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise rotating motor  $\equiv$  positive machine direction.

### 4.1.4 Feedback configuration

In most cases the system only has one motor encoder, i.e. no separate position encoder is installed on the load side. The motor position (angle of rotation) and motor speed are detected via the motor encoder selected in [C00495](#) and converted with regard to the load side.



[4-4] Schematic diagram - feedback with position encoder = motor encoder

The actual position and speed values on the machine side result from the conversion via the [Gearbox ratio](#) on the motor side and the [Feed constant](#).



#### Tip!

Detailed information on the parameterisation of the feedback systems for the motor control can be found in the chapter "[Encoder evaluation](#)". (□ 241)

## 4.1.5 Unit/user-defined unit

Via these machine parameters you define the real unit of the machine in which the feed constant and the parameters for a travel profile must be specified (e.g. position, speed, acceleration, and deceleration).

- ▶ If you for instance set the unit "mm" for a linear axis, the position must be specified in [mm] and the speed in [mm/s].
- ▶ By means of the user-defined unit, significant production units, like for example "bottles" can also be set.
  - For this, select the "User-defined" entry as unit in [C02525](#) and then enter the desired user-defined unit in [C02526](#).



### Note!

In this documentation the term "unit" in the parameter unit data only serves as a wildcard for the real unit of the machine.

## Display parameters

Parameter	Information
<a href="#">C02534</a>	Used time unit
<a href="#">C02535</a>	Used unit
<a href="#">C02537</a>	Speed unit
<a href="#">C02538</a>	Acceleration unit

Highlighted in grey = display parameter



## 4.1.6 Traversing range

The selection of the traversing range ("Unlimited", "Limited", or "Modulo") in the **Traversing range** list field ([C02528](#)) serves to define the machine measuring system.




### Note!

A change-over of the traversing range results in a loss of the reference information!

### "Unlimited" traversing range

The drive can rotate continuously in one direction.

- ▶ By referencing and activating the software limit positions the traversing range can be limited.
- ▶ For positioning with absolute travel command the home position must be known.




[4-5] Unlimited traversing range, taking the "feed control tape" as an example

### "Limited" traversing range

The travel range is limited by positive and negative position limits (mechanical limits/travel range limit switches/software limit positions). ▶ [Limiter](#) ([□ 513](#))

- ▶ After a defined distance the drive must travel in the opposite direction again.
- ▶ For positioning in the limited traversing range the home position must be known.
- ▶ The software limit positions are basically monitored with regard to the maximum internally representable value range ( $\pm 2^{31}$  increments), even if monitoring has been deactivated via [C02700](#).
- ▶ An overflow of the value range results in a loss of the reference information.




[4-6] Example: Limited traversing range - "spindle drive" (linear axis)

## "Modulo" traversing range

The measuring system is repeated.

- ▶ If the cycle set in [C02536](#) is exceeded, a defined overflow occurs. In a rotative system, the cycle typically corresponds to a revolution or tool distance.
- ▶ For positioning in the "Modulo" traversing range the home position must be known.
- ▶ Software limit positions are not effective.
- ▶ Absolute targets can be approached by exceeding the measuring system limit, e.g. from 10° to 350°.




[4-7] Example: Modulo traversing range - "rotary table"

## Dependencies - traversing range/basic drive functions

- ▶ The following table lists the different dependencies between the selected traversing range and the basic drive functions.

Basic drive function	Traversing range		
	Unlimited	Limited	Modulo
Position data for <a href="#">Encoder evaluation</a>	continuously	continuously	clocked
Position data for <a href="#">Position follower</a>	absolute	absolute	absolute (in time)
Positioning modes for <a href="#">Positioning</a>	1, 2, 5, 6, 7, 8	1, 2, 5, 6, 7, 8	5, 6, 11 ... 16
Restrictions for <a href="#">Homing</a>	none	none	home position must be in time
Limit positions ( <a href="#">Limiter</a> )	permitted	permitted	not permitted



Example 1: Unlimited/limited position display

- 1 Reference setting
- 2 Position in the machine measuring system
- 3 Position in the motor measuring system


Example 2: Modulo position display

- 1 Cycle
- 2 Position in the machine measuring system
- 3 Position in the motor measuring system

## 4.1.7 Feed constant

The feed constant corresponds to the movement of the machine during one revolution of the gearbox output shaft.


- ▶ The entry in the **Feed constant** field ([C02524](#)) is made in the unit defined in [C02525](#) relating to one revolution.
- ▶ In the case of a conveyor drive, the feed constant results from the circumference of the drive roll, which in the following example is calculated on the basis of the diameter specified:



$$\text{Feed constant} = \pi \cdot d \frac{[\text{unit}]}{\text{Revolution}} = \pi \cdot 200 \frac{\text{mm}}{\text{Revolution}} = 628.3185 \frac{\text{mm}}{\text{Revolution}}$$

[4-8] Schematic diagram: Feed constant for a conveyor drive

- ▶ In the case of a spindle drive (linear axis), the feed constant results from the leadscrew pitch. The feed constant indicates the distance travelled by the slide during one revolution of the spindle (in the following example 5,023 mm).



[4-9] Schematic diagram: Feed constant for a spindle drive

- ▶ For a rotary table and defined as an angle, the feed constant is = 360°/rev.

## 4.1.8 Resolution of an encoder revolution


The following applies to software versions lower than V3.0:

The resolution of an encoder revolution and hence of a position value is constantly set to 16 bits/revolution, which corresponds to 65536 increments/revolution. At this resolution, the traversing range comprises  $\pm 32767$  revolutions.

The following applies from software version V3.0:


C00100 serves to adjust the resolution according to the application.

- ▶ The default resolution of 16 bits/revolution is sufficient for standard applications.



[4-10] Example: standard resolution (16 bits/revolution)

- ▶ For more significant applications, a higher resolution of the position values can clearly improve the control properties and positioning accuracies:
  - Finer resolution of the position targets  $\rightarrow$  improved positioning accuracy
  - Finer quantisation of setpoints and actual values  $\rightarrow$  better control quality
  - Higher loop gain can be set  $\rightarrow$  less following errors
- ▶ However, a higher resolution at the same time causes a restricted number of encoder revolutions, and only smaller traversing distances can be displayed.



[4-11] Example: Higher resolution (22 bits/revolution) with a restricted traversing range



### Tip!

In the following subchapter "[Determining the optimum resolution](#)" (46) it is described how you can determine the optimum resolution of the position values.



## Note!

The position values (e.g. setpoints, actual values, parameters, ...) in the signal flow always use the resolution set in [C00100](#). In this connection it is irrelevant which resolution is delivered directly by the encoder.

### Multi-axis systems

In an interconnection via the electrical shaft, at least two measuring systems (master and slave) are available in the drive.

- Each measuring system is provided with an individual setting of the resolution.
- The machine parameters (gearbox factors, feed constants, encoder resolution and cycle) for the master measuring system or master value must be set identically for all drives in the system.

### Technology applications "Electronic gearbox" and "Synchronism"

For these two technology applications the machine parameters of the master measuring system are defined on the *Application parameters* tab in the "Master value scaling" dialog level.

### Electronic cam

The machine parameters of the master measuring system for electronic cams can be defined on the *Measuring systems* tab for the electrical shaft.

## 4.1.8.1 Determining the optimum resolution

This function extension is available from software version V3.0!



### How to determine the optimum resolution:

In the dialog level *Overview* → *Drive interface* → *Machine parameters*:

1. Set gearbox factors.
2. Set real unit of the machine.
3. Set feed constant.
4. Press the **Optimum positional resolution** button.
  - The *Optimum positional resolution* dialog box is displayed:

5. Go to the **Max. presentable position** input field and enter the highest position which is to be entered in a parameter during operation.
  - If required, set a reserve in the **Overshoot** input field to take into account possible following errors (overshoot of actual values).

Then the maximum resolution for the position entered is shown in the **Maximum resolution for encoder revolution** field.

6. Click on **Accept value** to accept the displayed resolution in [C00100](#).
7. Click on **Close** to close the dialog box again.



### Tip!

In order to have the maximally presentable position for a defined resolution displayed, activate the second option **Determine max. presentable position**. Then you can set the resolution for which the maximally presentable position is to be displayed in the **Maximum resolution for encoder revolution** input field.

## 4.1.9 Max. position, speed, and acceleration that can be displayed internally

By setting the following machine parameters, the connection between the real units (application units) of the machine and the internal units in the controller is described:

- ▶ Gearbox ratio ([C02520](#), [C02521](#), [C02522](#), [C02523](#))
- ▶ Feed constant ([C02524](#))
- ▶ Resolution of an encoder revolution ([C00100](#))

Possibly the defined values for position, speed, and acceleration cannot be represented in the internal units by the numerical 32-bit format used.

- ▶ The following display parameters show the values that can be maximally displayed:

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02539</a>	Max. presentable position	-	Unit
<a href="#">C02540</a>	Speed that can be maximally displayed	-	Unit/s
<a href="#">C02541</a>	Acceleration that can be maximally displayed	-	Unit/s <sup>2</sup>

Highlighted in grey = display parameter

### Behaviour when entering a value that cannot be displayed internally

If a position, speed, or acceleration which cannot be represented internally is defined via parameters, the value defined is limited to the maximum value that can be represented internally ( $\pm 2147483647$ ).

The following only applies to software version V3.0:

- ▶ If a position, speed, or acceleration which cannot be represented internally is defined via parameters, the value defined is rejected.
- ▶ If an internal counter overflow of a parameter value due to a subsequent change of the machine parameters for the gearbox ratio, feed constant, or resolution of an encoder revolution is detected, the "Fault" error response is triggered and a corresponding error message is entered in the logbook of the controller:

Error number	Error message
0x00B8001A	Int. overflow <a href="#">C02620</a> (manual speed 1)
0x00B8001B	Int. overflow <a href="#">C02621</a> (manual speed 2)
0x00B8001C	Int. overflow <a href="#">C02622</a> (manual acceleration)
0x00B8001D	Int. overflow <a href="#">C02624</a> (manual deceleration)
0x00B80020	Int. overflow <a href="#">C02701/1</a> (positive SW limit position)
0x00B80021	Int. overflow <a href="#">C02701/2</a> (negative SW limit position)
0x00B80022	Int. overflow <a href="#">C02703</a> (maximum speed)
0x00B80023	Int. overflow <a href="#">C02705</a> (maximum acceleration)
0x00B80024	Int. Overflow <a href="#">C02708/1</a> (Limited speed 1)
0x00B80025	Int. Overflow <a href="#">C02708/2</a> (Limited speed 2)
0x00B80026	Int. Overflow <a href="#">C02708/3</a> (Limited speed 3)
0x00B80027	Int. Overflow <a href="#">C02708/4</a> (Limited speed 4)
0x00B80028	Int. overflow <a href="#">C02710/1</a> (decel. limited speed 1)
0x00B80029	Int. overflow <a href="#">C02710/2</a> (decel. limited speed 2)
0x00B8002A	Int. overflow <a href="#">C02710/3</a> (decel. limited speed 3)
0x00B8002B	Int. overflow <a href="#">C02710/4</a> (decel. limited speed 4)
0x00B8002C	Int. overflow <a href="#">C02713</a> (maximum distance manual jog)
0x00B8002D	Int. Overflow <a href="#">C02642</a> (home position)
0x00B8002E	Int. Overflow <a href="#">C02643</a> (homing: target position)
0x00b8002f	Int. Overflow <a href="#">C02644</a> (homing: speed 1)
0x00B80030	Int. Overflow <a href="#">C02645</a> (homing: acceleration 1)
0x00B80031	Int. Overflow <a href="#">C02646</a> (homing: speed 2)
0x00B80032	Int. Overflow <a href="#">C02647</a> (homing: acceleration 2)
0x00B80033	Int. overflow <a href="#">C02670</a> (positioning: tolerance for target position)



### Tip!

Possible measures for error correction:

- Plausibility check of the machine parameters set for gearbox ratio, feed constant, or resolution of an encoder revolution.
- Set parameters with a counter overflow to a value which can also be represented internally.



## 4.2 Device commands

In the following subchapters the device commands of the controller are described, which are provided in [C00002](#) and which can be executed by means of the »Engineer« or alternatively with the keypad when an online connection has been established.



### Note!

Before switching off the supply voltage after a device command has been executed, check the successful execution of the device command via the status display in [C00003](#)!

The meaning of the status display in [C00003](#) can be obtained from the subchapter for the corresponding device command.

### Activating frequently required device commands via the toolbar

The simplest way to execute the frequently required device commands is directly via the *Toolbar* of the »Engineer« when an online connection has been established.

Icon	Function
	<a href="#">Enable controller</a>
	<a href="#">Inhibit controller</a>
	<a href="#">Start application</a>
	<a href="#">Inhibit controller</a> and <a href="#">Stop application</a>



### Note!


Device commands that can be executed via the *Toolbar* of the »Engineer« always affect the element currently selected in the *Project View* including all subelements!

- If no controller but a system module is selected in the *Project view*, the corresponding device command will be activated in all lower-level controllers having an online connection with the »Engineer«.

Before executing the corresponding action a confirmation prompt is displayed, asking you whether the action should really be carried out.

## Activating device commands via the "Device commands" dialog box

All device commands of the controller are available in the »Engineer« in the *Device Commands* dialog box:




- ▶ The *Device commands* dialog box can be opened by clicking on the **Device commands** list field on the **Application parameters** tab in the dialog level *Overview* → *Drive interface*.
- ▶ The *Device commands* dialog box can also be opened by clicking on the setting of [C00002](#) on the **All parameters** tab.



### Note!


If you click on a device command in the list field of the *Device commands* dialog box, the corresponding device command is executed immediately!

- ▶ During and after the execution of the device command, the processing status is displayed in the *Device Commands* dialog box:



## 4.2.1 Load Lenze setting




The [C00002](#) = "0: Load Lenze setting" device command is used to reset the parameters of the active application to the Lenze setting, which is stored in the controller firmware:



[4-12] "Load Lenze setting" function

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ All parameter changes made since the last saving of the parameter set will get lost!
- ▶ This device command only affects the settings of the operating system, application and module parameters, the active application or the configuration selected with the function block editor remain unchanged.

### Possible status displays for this device command


Status ( <a href="#">C00003</a> )	Meaning
 34050	Device command in process
 0	Device command executed successfully
	1 General fault
	39424 CAN fault
	... ..
39679	CAN fault

### Related device commands

- ▶ [Load start parameters](#) ([□ 52](#))
- ▶ [Save start parameters](#) ([□ 56](#))

## 4.2.2 Load start parameters




Via [C00002](#) = "1: Load start parameters" the start parameters of the active application can be reloaded from the memory module to the controller:



[4-13] "Load start parameters" function

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ All parameter changes made since the last saving of the parameter set will get lost!
- ▶ This device command only affects the settings of the operating system, application and module parameters, the active application or the configuration selected with the function block editor remain unchanged.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	99586 Device command in process
	65536 Device command executed successfully
	65537 General fault
	99371 Fault while reading the parameter set partition
	99374 No memory module available
	104960 CAN fault
	... ..
	105215 CAN fault

### Related device commands

- ▶ [Save start parameters](#) ([□ 56](#))
- ▶ [Load Lenze setting](#) ([□ 51](#))

## 4.2.3 ENP:Load plant data

If the Lenze motor connected to the controller is provided with an electronic nameplate (ENP), all motor data are automatically read out from the electronic nameplate of the motor when the controller is switched on for the first time and are temporarily stored in the controller at first.

With the device command [C00002](#) = "2: ENP: Load plant data" the motor data can be reread from the electronic nameplate (ENP) of the motor.

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ For a permanent acceptance of the motor data, the parameter set must be saved. ▶ [Save start parameters](#) (p. 56)
- ▶ The following plant data are read out from the ENP:

Parameter	Information
<a href="#">C00022</a>	Maximum current
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00596</a>	Threshold max. speed reached






### Note!

The two pieces of plant data [C00011](#) and [C00497](#) listed in the following table are not read out from the ENP and thus have to be checked and, if required, set manually after this device command has been executed!


Parameter	Information
<a href="#">C00011</a>	Motor reference speed
<a href="#">C00497</a>	Speed act. val. time const.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 165122	Device command in process
 131072	Device command executed successfully
 131073	General fault

## 4.2.4 Activate application

If several applications are available on the memory module, the [C00002](#) = "5: Activate application" device command can be used to activate the application the number of which has been set in [C00005](#).



[4-14] "Activate application" function

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ Whether the application is started at the same time, depends on the auto-start setting selected in [C02104](#).
- ▶ After mains switching, the preset application will be loaded into the controller.
- ▶ If after mains switching another application than the one preset by Lenze is to be loaded, it must be activated first and then the selected application must be saved with the device command "[Save selected application](#)" (📖 55).
- ▶ The number of the currently active application is displayed in [C00007](#).



### Note!

When the application is activated, the corresponding start parameter set is loaded automatically and parameter settings executed before will get lost unless the parameter set was saved before!

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
361730	Device command in process
327680	Device command executed successfully
327681	General fault


### Related device commands

- ▶ [Save selected application](#) (📖 55)
- ▶ [Start application](#) (📖 60) / ▶ [Stop application](#) (📖 61)

## 4.2.5 Save selected application

After mains switching the controller always loads the preset start application from the memory module, even if a different application has been active before.




With the device command [C00002](#) = "7: Save selected application" the active application can be defined as start application.



[4-15] "Save selected application" function

- ▶ When this device command is executed, the parameter set is also saved automatically.
- ▶ The number of the currently active application is displayed in [C00007](#).

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 492802	Device command in process
 458752	Device command executed successfully
 458753	General fault


### Related device commands

- ▶ [Activate application](#) (p. 54)
- ▶ [Start application](#) (p. 60)
- ▶ [Stop application](#) (p. 61)

## 4.2.6 Save start parameters

Controller parameter changes made via the »Engineer« or keypad will get lost after mains switching of the controller or loading of another application unless the settings have been explicitly saved.

With the device command [C00002](#) = "11: Save start parameters" the current parameter settings of the active application can be saved with mains failure protection in the memory module of the controller:



[4-16] "Save start parameters" function



### Tip!

With the keypad this device command can be executed via the left function key if it is currently assigned with the **SAVE** function.



### Note!

The saving process can take several seconds. Before you switch off the supply voltage after having executed this device command, therefore be absolutely sure to check via the status display in [C00003](#) whether the device command has been executed successfully!




#### Saving of the cam data

From software version V4.0, this device command also includes the powerfail-proof saving of the cam data on the memory module.

- The saving process is only carried out if the cam data in the controller and the memory module differ from each other (based on the time stamp/GUID of the cam data).
- For saving the cam data, you do not need to enter a possibly existing user password ([C02900](#)).
- The [C00002](#) = "502: Save Cam Data" device command remains available. ▶ [Save cam data](#) (□ 97)



## Possible status displays for this device command

Status (C00003)	Meaning
	754946 Device command in process
	720896 Device command executed successfully
	720897 General fault
	754718 Fault while writing into a file
	754734 No memory module available
	761857 Access to file has been denied since the file is already accessed from another position
	761861 I/O fault when accessing the file system
	761868 RAM is full
	761869 Access authorisation denied
	761884 No free memory on the memory module

## Related device commands

▶ [Load start parameters](#) (□ 52)

## 4.2.7 Delete logbook

The [C00002](#) = "20: Delete logbook" device command is used to delete all entries in the logbook.






### Tip!

To display the logbook in the »Engineer«, click the **Logbook** button on the **Diagnostics** tab.

You can also delete all entries in the logbook by clicking the **Delete** button in the *Logbook* dialog box.

Further information on the logbook can be found in the chapter "[Diagnostics & fault analysis](#)". (📖 611)

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 1344770	Device command in process
 1310720	Device command executed successfully
 1310721	General fault

### Related device commands

- ▶ [Archive logbook](#) (📖 59)

#### 4.2.8 Archive logbook

The [C00002](#) = "21: Archive logbook" device command is used to archive the entries in the logbook.






#### Tip!

To display the logbook in the »Engineer«, click the **Logbook** button on the **Diagnostics** tab.

You can also export all entries available in the logbook into a file (\*.log) by clicking the **Export** button in the *Logbook* dialog box.

Further information on the logbook can be found in the chapter "[Diagnostics & fault analysis](#)". (📖 611)

#### Possible status displays for this device command


Status <a href="#">(C00003)</a>	Meaning
 1410306	Device command in process
 1376256	Device command executed successfully
 1376257	General fault

#### Related device commands

▶ [Delete logbook](#) (📖 58)

## 4.2.9 Start application

The [C00002](#) = "31: Start application" device command is used to start the active application in the controller.



[4-17] "Start application" function




- ▶ The number of the currently active application is displayed in [C00007](#).
- ▶ The current program status is displayed in [C02108](#).
- ▶ The active function state of the application is displayed in [C02530](#).



**Tip!**

This device command can also be activated via the  icon in the *Toolbar*.

### Possible status displays for this device command


Status ( <a href="#">C00003</a> )	Meaning
 2065666	Device command in process
 2031616	Device command executed successfully
 2031617	General fault

### Related device commands

- ▶ [Stop application](#) (📖 61)
- ▶ [Activate application](#) (📖 54)
- ▶ [Save selected application](#) (📖 55)

## 4.2.10 Stop application

The [C00002](#) = "32: Stop application" device command can be used to stop the application started in the controller again.




[4-18] "Stop application" function




- ▶ Only possible when controller is inhibited.



**Tip!**

Via the  icon in the *Toolbar* the controller can be inhibited, and at the same time the application in the controller can be stopped.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 2131202	Device command in process
 2097152	Device command executed successfully
 2097153	General fault

### Related device commands




- ▶ [Start application](#) (📖 60)
- ▶ [Inhibit controller](#) (📖 67)
- ▶ [Activate application](#) (📖 54)
- ▶ [Save selected application](#) (📖 55)

## 4.2.11 Reset program

The [C00002](#) = "33: Reset program" device command is used to reset the application program in the controller.

- ▶ All variables are reset to their initialisation value.
- ▶ The situation corresponds to the start of a new program loaded into the control (cold start).

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 2196738	Device command in process
 2162688	Device command executed successfully
 2162689	General fault

### Related device commands




- ▶ [Delete program](#) (📖 63)
- ▶ [Restart program](#) (📖 64)

#### 4.2.12 Delete program



The [C00002](#) = "34: Delete program" device command is used to delete the application program in the controller and reset the controller to its original state.

- ▶ All variables are reset to their initialisation value.

#### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 2262274	Device command in process
 2228224	Device command executed successfully
 2228225	General fault

#### Related device commands




- ▶ [Reset program](#) ( 62)
- ▶ [Restart program](#) ( 64)

## 4.2.13 Restart program

The [C00002](#) = "35: Restart program" device command is used to restart the application program in the controller.

- ▶ All variables except the RETAIN variables are reset to their initialisation value.
- ▶ The situation corresponds to a power failure or switching the controller off/on (warm start) while the program is running.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 2327810	Device command in process
 2293760	Device command executed successfully
 2293761	General fault

### Related device commands

- ▶ [Reset program](#) ([📖 62](#))
- ▶ [Delete program](#) ([📖 63](#))






## 4.2.14 Reset runtime measurement

When the application is started, the controller continuously carries out a runtime measurement for the interval-controlled application task, the interval-controlled user task, and the free-running idle task and displays the current and maximum task runtimes via parameters.

The [C00002](#) = "36: Reset runtime measurement" device command is used to reset the runtime measurement, i.e. the memory for the maximum values is reset to "0".

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 2393346	Device command in process
 2359296	Device command executed successfully
 2359297	General fault




### Note!

The runtime measurement is also reset by the following actions:

- Start application
- Reset/delete/restart program

### Example for runtime measurement



[4-19] Example: runtimes of the different tasks

## Display parameters

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02121/1</a>	Current runtime - application task	-	µs
<a href="#">C02121/2</a>	Maximum runtime - application task	-	µs
<a href="#">C02122/1</a>	Current runtime - user task	-	µs
<a href="#">C02122/2</a>	Maximum runtime - user task	-	µs
<a href="#">C02123/1</a>	Current runtime - idle task	-	µs
<a href="#">C02123/2</a>	Maximum runtime - idle task	-	µs

Highlighted in grey = display parameter

#### 4.2.15 Inhibit controller

The [C00002](#) = "41: Inhibit controller" device command is used to inhibit the controller ("controller inhibit"), i.e. the power output stages in the controller are inhibited and the speed/current and position controllers of the motor control are reset. The motor becomes torqueless and coasts unless it is already at standstill.

- ▶ The controller can also be inhibited by other sources, e.g. via the digital input RFR or through the application.
- ▶ The sources or triggers that are active for controller inhibit are shown in [C00158](#) in a bit coded manner.



#### Note!

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



#### Tip!

This device command can also be activated via the  icon in the *Toolbar*.

#### Related device commands

- ▶ [Enable controller](#) (□ 68)

## 4.2.16 Enable controller

The [C00002](#) = "42: Enable controller" device command is used to re-enable an inhibited controller.



### Note!

Please note that the controller will only be enabled if all sources for controller inhibit are reset!

- The sources or triggers that are active for controller inhibit are shown in [C00158](#) in a bit coded manner.

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



### Tip!

This device command can also be activated via the  icon in the *Toolbar*.

### Related device commands

▶ [Inhibit controller](#) (67)

## 4.2.17 Reset error

The [C00002](#) = "43: Reset error" device command is used to acknowledge an error message if the error cause has been eliminated and the error is thus no longer pending.



### Tip!

An error message can also be acknowledged by clicking the **Reset error** button on the **Diagnostics** tab.

Further information on error messages can be found in the chapter "[Diagnostics & fault analysis](#)". ([📖 611](#))



### Note!

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.

## 4.2.18 Activate quick stop

The [C00002](#) = "45: Activate quick stop" device command is used to activate the basic function "Quick stop", i. e. the drive is brought to standstill within the deceleration time set, irrespective of the setpoint defined.

- ▶ Quick stop can also be activated by other sources, e.g. by the application.
- ▶ The sources or triggers that are active for quick stop are shown in [C00159](#) in a bit coded manner.



### Note!

The activation of quick stop may cause following errors in superimposed controls (e.g. synchronous or position control). If several drives execute a coordinated movement, the quick stop function should therefore only be used for the motion master (master drive) in order to maintain the coordination.

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



### Tip!

In contrast to the "stop" function, quick stop is required for a stop in case of error. Thus, quick stop can also be set as an error response ("quick stop by trouble) for many monitoring functions. Detailed information on this can be found in the chapter "[Diagnostics & fault analysis](#)". (📖 611)

### Related device commands

- ▶ [Reset quick stop](#) (📖 71)

## 4.2.19 Reset quick stop

The [C00002](#) = "46: Reset quick stop" device command is used to exit an active quick stop again.



### Note!

Please note that the quick stop is only exited if all sources for quick stop are reset!

- The sources or triggers that are active for quick stop are shown in [C00159](#) in a bit coded manner.

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.

### Related device commands

- ▶ [Activate quick stop](#) (📖 70)

## 4.2.20 Identify pole position (360°)

If no absolute value encoder is connected or a synchronous motor of a third-party manufacturer is driven by the controller, the [C00002](#) = "51: Identify pole position (360°)" device command is used to determine the pole position with regard to the motor encoder currently activated in [C00495](#).

- ▶ The function can only be activated if the controller is inhibited. Then the execution of the function starts automatically as soon as the controller inhibit is deactivated again.
- ▶ During the pole position identification, the motor makes one electrical revolution. This leads to a mechanical rotation of the motor shaft.
- ▶ The determined pole position is indicated under code [C00058](#).



### Note!




From software version V4.0 the response parameterised in [C00640](#) (Lenze setting: "Fault") is triggered and the error message "Pole position identification cancelled" is entered in the logbook of the controller if the pole position identification process is aborted.



### Tip!

Detailed information on the pole position identification can be found in the chapter "Motor interface", subchapter "[Pole position identification](#)". (136)

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	3376386 Device command in process
	3342336 Device command executed successfully
	3342337 General fault
	3382023 Pole position identification cannot be executed because of wrong motor type (asynchronous motor).
	3382024 Pole position identification has been aborted
	3382025 Pole position identification cannot be executed because another identification is already active.
	3382026 Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.
	3382027 Identification of pole position cannot be executed because current controller optimisation mode is active.
	3382033 Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable.
	3382047 Pole position identification cannot be executed because an error or trouble is active.
3382065 Pole position identification cannot be executed because either the entire motor or a motor phase is not connected.	
	<ul style="list-style-type: none"> <li>• <a href="#">This error message is only available from software version V3.0 onwards.</a></li> </ul>



## Related device commands

▶ [Identify pole position \(min. motion\)](#) (📖 74)

## 4.2.21 Identify pole position (min. motion)

If no absolute value encoder is connected or a synchronous motor of a third-party manufacturer is driven by the controller, the [C00002](#) = "52: Identify pole position (min. motion)" device command is used to determine the pole position with respect to the motor encoder currently activated in [C00495](#).

- ▶ The function can only be activated if the controller is inhibited. Then the execution of the function starts automatically as soon as the controller inhibit is deactivated again.
- ▶ During the pole position identification, the rotor aligns itself. This is compensated by a position control.
- ▶ The determined pole position is indicated under code [C00058](#).



### Note!




From software version V4.0 the response parameterised in [C00640](#) (Lenze setting: "Fault") is triggered and the error message "Pole position identification cancelled" is entered in the logbook of the controller if the pole position identification process is aborted.



### Tip!

Detailed information on the pole position identification can be found in the chapter "Motor interface", subchapter "[Pole position identification](#)". (136)

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	3441922 Device command in process
	3407872 Device command executed successfully
	3407873 General fault
	3447559 Pole position identification cannot be executed because of wrong motor type (asynchronous motor).
	3447560 Pole position identification has been aborted
	3447561 Pole position identification cannot be executed because another identification is already active.
	3447562 Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.
	3447563 Identification of pole position cannot be executed because current controller optimisation mode is active.
	3447569 Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable. <ul style="list-style-type: none"> <li>• <a href="#">This error message is only available from software version V4.0 onwards.</a></li> </ul>
	3447583 Pole position identification cannot be executed because an error or trouble is active.
	3447597 Identification of pole position cannot be executed because the rotor has moved too strongly.
3447601 Pole position identification cannot be executed because either the entire motor or a motor phase is not connected. <ul style="list-style-type: none"> <li>• <a href="#">This error message is only available from software version V3.0 onwards.</a></li> </ul>	

## Related device commands

▶ [Identify pole position \(360°\)](#) (📖 72)

## 4.2.22 Resolver error identification

This function extension is available from software version V7.0!

The [C00002](#) = "59: Resolver error identification" device command serves to detect resolver errors which are caused when sine and cosine tracks do not magnetise orthogonally. The identified resolver errors serve to compensate the resolver errors.




- Only possible with servo control.



### Tip!

Detailed information on the resolver error compensation can be found in the chapter "Encoder evaluation" in the subchapter "[Resolver error compensation](#)".  
([book icon](#) 261)

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 3900674	Device command in process
 3866624	Device command executed successfully
	3866625 General fault
	3906358 Resolver error identification cannot be executed since the wrong control type is active (no servo control).
	3906359 Resolver error identification cannot be executed since an error or trouble is active.
	3906360 Resolver error identification cannot be executed because another identification is already active.
3906361	Resolver error identification cannot be executed because of too small speed (< 500 rpm).

#### 4.2.23 Load Lenze inverter characteristic

This function extension is available from software version V4.0!

If it is not possible to determine the so-called "Inverter error characteristic" by means of the "[Calculate inv. characteristic](#)" device command, or if the results of the determination are incorrect, the [C00002](#) = "70: Load Lenze inverter characteristic" device command can be used to load a characteristic typical for the device.




- ▶ Only possible when controller is inhibited.



#### Tip!

Detailed information about the determination of the inverter error characteristic can be found in the chapter "Motor interface" in the subchapter "[Optimising the switching performance of the inverter](#)". (📖 143)

#### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning	
	4621570	Device command in process
	4587520	Device command executed successfully
	4587521	General fault

#### Related device commands

- ▶ [Calculate inv. characteristic](#) (📖 78)

## 4.2.24 Calculate inv. characteristic

If a motor of a third-party manufacturer with unknown motor parameters is driven by the controller, the [C00002](#) = "71: Determine inverter characteristic" device command can be used to determine the so-called "Inverter error characteristic" for optimising the inverter switching behaviour.






### Tip!

Detailed information about the determination of the inverter error characteristic can be found in the chapter "Motor interface" in the subchapter "[Optimising the switching performance of the inverter](#)". (📖 143)

**From software version V4.0:** If the inverter error characteristic cannot be determined by means of this device command, or if the results of the determination are incorrect, the device command "[Load Lenze inverter characteristic](#)" can be used to load a characteristic typical for the device. (📖 77)

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	4687106 Device command in process
	4653056 Device command executed successfully
	4653057 General fault
	4692754 The calculation of the inverter characteristic cannot be started since the current controller test mode is active.
	4692755 The calculation of the inverter characteristic cannot be started since the V/f test mode is active.
	4692756 The calculation of the inverter characteristic cannot be started since the pole position identification is active.
	4692757 Calculation of the inverter characteristic has been aborted.
	4692758 Calculation of the inverter characteristic has been interrupted by error.
	4692789 Determined inverter error characteristic exceeds internal limits. <ul style="list-style-type: none"><li>• This situation can for instance occur if the motor power is very much lower than the device power.</li><li>• <a href="#">This error message is only available from software version V5.0 onwards.</a></li></ul>

### Related device commands

- ▶ [Load Lenze inverter characteristic](#) (📖 77)

## 4.2.25 Determine motor parameters

The [C00002](#) = "72: Determine motor parameters" device command is used to automatically determine the motor parameters for a third-party motor that are listed in the following table – if they are not known:




Parameter	Information	ASM	SM
<a href="#">C00079</a>	Mutual motor inductance	<input checked="" type="checkbox"/>	
<a href="#">C00082</a>	Motor rotor resistance	<input checked="" type="checkbox"/>	
<a href="#">C00084</a>	Motor stator resistance	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00085</a>	Motor stator leakage induct.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00091</a>	Motor - cosine phi	<input checked="" type="checkbox"/>	
<a href="#">C00092</a>	Motor magnetising current	<input checked="" type="checkbox"/>	



### Tip!

Detailed information about the automatic determination of the motor parameters can be found in the chapter "Motor interface" in the subchapter "[Determining the motor parameters](#)". (📖 146)

## Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 4752642	Device command in process
 4718592	Device command executed successfully
	4718593 General fault
	4758290 Motor identification cannot be started since the current controller test mode is active.
	4758291 Motor identification cannot be started since the V/f test mode is active.
	4758292 Motor identification cannot be started because pole position identification is active.
	4758293 Motor identification has been aborted.
	4758294 Motor identification has been aborted by fault.
	4758332 Motor identification aborted due to inconsistent motor parameters. <ul style="list-style-type: none"> <li><a href="#">This error message is only available from software version V7.0 onwards.</a></li> </ul>

## 4.2.26 Calculate current controller parameters

This function extension is available from software version V5.0 onwards!

The device command [C00002](#) = "77: Calculate current controller parameters" is used to calculate the gain and the reset time of the current controller for a third-party motor.

**Precondition:** The two motor parameters "stator resistance" ([C00084](#)) and "stator leakage inductance" ([C00085](#)) either have been parameterised manually on the basis of the manufacturer information before, or have been determined automatically via the device command "[Determine motor parameters](#)".



### Note!

For a Lenze motor the calculation and the subsequent optimisation of the current controller parameters is not required, as the correct current controller parameters are accepted from the »Engineer« motor catalogue.

The device command is no identification procedure for determining the current controller parameters!

- The calculation is carried out according to the following formulas:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$
$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$

- After the device command has been executed successfully (see status in [C00003](#)), the two calculated values are set in [C00075](#) and [C00076](#). They serve as starting values for a subsequent optimisation of the current controller in the test mode.
- In case of error, codes [C00075](#) and [C00076](#) are not altered.






### Tip!

Detailed information on the optimisation of the current controller in the test mode can be found in the chapter "Motor interface" in the subchapter for the respective motor control:

- Servo control (SC) ► [Optimise current controller](#) (153)
- Sensorless vector control (SLVC) ► [Optimise current controller](#) (187)
- V/f control (VFCplus) ► [Optimise current controller](#) (202)



## Possible status displays for this device command

Status (C00003)	Meaning	
 5080322	Device command in process	
 5046272	Device command executed successfully	
	5046273	General fault
	5086002	At least one calculated value is beyond the valid setting range.
	5086003	Stator resistance (C00084) too small (zero).

## Related device commands

- ▶ [Determine motor parameters](#) (📖 79)
- ▶ [Calculate speed controller parameters](#) (📖 82)

## 4.2.27 Calculate speed controller parameters

This function extension is available from software version V5.0 onwards!

The device command [C00002](#) = "78: Calculate speed controller parameters" is used to calculate the gain, reset time, and rate time of the speed controller.

**Precondition:** The moments of inertia for the motor ([C00273/1](#)) and load ([C00273/2](#)) have been parameterised correctly before.



### Note!

The device command is no identification procedure for determining the speed controller parameters!

- ▶ The calculation is carried out according to the following formulas, taking the actual speed value filter time constant into consideration ([C00497](#)):

$$\text{Gain} = \frac{\text{Moment of inertia of motor+load}}{4 \cdot (\text{Actual speed value filter time constant} + 500 \mu\text{s})} \cdot \frac{2\pi}{60}$$

$$\text{Reset time} = 4^2 \cdot (\text{Actual speed value filter time constant} + 500 \mu\text{s})$$

$$\text{Rate time} = 0 \text{ ms}$$

- ▶ After the device command has been executed successfully (see status in [C00003](#)), the calculated values are set in the corresponding codes:
  - [C00070](#): Speed controller gain
  - [C00071](#): Speed controller reset time
  - [C00072](#): Speed controller rate time
- ▶ In case of error, these codes are not altered.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
5145858	Device command in process
5111808	Device command executed successfully
5111809	General fault
	5151540

### Related device commands

- ▶ [Calculate current controller parameters](#) (80)

## 4.2.28 CAN on board: Reset node




The [C00002](#) = "91: CAN on board: reset node" device command is used to reinitialise the CANopen system bus interface of the controller ("CAN on board"), which is required, for instance, after the data transfer rate, node address, or identifiers have been changed.



**Tip!**

For detailed information about the "CAN on board" CANopen system bus interface, please see the "CAN" Communication Manual.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	5997826 Device command in process
	5963776 Device command executed successfully
	5963777 General fault
	6003200 CAN fault
	... ..
	6003455 CAN fault

### Related device commands

- ▶ [CAN on board: Pred.Connect.Set](#) (□ 85)
- ▶ [CAN on board: Identify node](#) (□ 87)

## 4.2.29 CAN module: Reset node




The [C00002](#) = "92: CAN module: reset node" device command is used to reinitialise the CANopen interface of a CANopen communication module in module slot MXI1 or MXI2, which is required, for instance, after the data transfer rate, node address, or identifiers have been changed.



### Tip!

Detailed information on the CANopen communication module (E94AYCCA) can be found in the "CAN" Communication Manual.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	6063362 Device command in process
	6029312 Device command executed successfully
	6029313 General fault
	6068736 CAN fault
	6068991 CAN fault
	...

### Related device commands

- ▶ [CAN module: Pred.Connect.Set](#) (□ 86)
- ▶ [CAN module: Identify node](#) (□ 88)




### 4.2.30 CAN on board: Pred.Connect.Set

The [C00002](#) = "93: CAN on board: Pred.Connect.Set" device command is used to set the basic identifiers for the CANopen system bus interface of the controller ("CAN on board") according to the "Predefined Connection Set" (DS301V402).

**Tip!**

For detailed information about the "CAN on board" CANopen system bus interface, please see the "CAN" Communication Manual.

#### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	6128898 Device command in process
	6094848 Device command executed successfully
	6094849 General fault

#### Related device commands

- ▶ [CAN on board: Reset node](#) ([□ 83](#))
- ▶ [CAN on board: Identify node](#) ([□ 87](#))

## 4.2.31 CAN module: Pred.Connect.Set




The [C00002](#) = "94: CAN module: pred.connect.set" device command is used to set the basic identifiers for the CANopen system bus interface of a CANopen communication module in module slot MXI1 or MXI2 according to the "Predefined Connection Set" (DS301V402).



### Tip!

Detailed information on the CANopen communication module (E94AYCCA) can be found in the "CAN" Communication Manual.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	6194434 Device command in process
	6160384 Device command executed successfully
	6160385 General fault

### Related device commands

- ▶ [CAN module: Reset node](#) ([□ 84](#))
- ▶ [CAN module: Identify node](#) ([□ 88](#))

### 4.2.32 CAN on board: Identify node

The [C00002](#) = "95: CAN on board: identify node" device command is used to determine the nodes connected to the CANopen system bus interface of the controller ("CAN on board").




► The result of the CAN bus scan is displayed in [C00393](#).



#### Tip!

For detailed information about the "CAN on board" CANopen system bus interface, please see the "CAN" Communication Manual.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 6259970	Device command in process
 6225920	Device command executed successfully
 6225921	General fault

### Related device commands

- [CAN on board: Reset node](#) ([□ 83](#))
- [CAN on board: Pred.Connect.Set](#) ([□ 85](#))

## 4.2.33 CAN module: Identify node

The [C00002](#) = "96: CAN module: identify node" device command is used to determine the nodes connected to the CANopen system bus interface of a CANopen communication module in module slot MXI1 or MXI2.




- ▶ The result of the CAN bus scan is displayed in [C13393](#) (for MXI1) or in [C14393](#) (for MXI2).



### Tip!

Detailed information on the CANopen communication module (E94AYCCA) can be found in the "CAN" Communication Manual.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 6325506	Device command in process
 6291456	Device command executed successfully
 6291457	General fault

### Related device commands

- ▶ [CAN module: Reset node](#) ([📖 84](#))
- ▶ [CAN module: Pred.Connect.Set](#) ([📖 86](#))



#### 4.2.34 Ethernet module MXI2 unbind/bind




The [C00002](#) = "101: Unbind/bind Ethernet module: MXI1" device command is used to reinitialise the Ethernet interface of an Ethernet communication module in module slot MXI1, e. g. to accept a newly set IP or gateway address without mains switching.



**Tip!**

Detailed information on the Ethernet communication module (E94AYCEN) can be found in the "Ethernet" Communication Manual.

#### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 6653186	Device command in process
 6619136	Device command executed successfully
 6619137	General fault

#### Related device commands

▶ [Ethernet module MXI2 unbind/bind](#) (📖 90)

## 4.2.35 Ethernet module MXI2 unbind/bind




The [C00002](#) = "102: Unbind/bind Ethernet module: MXI2" device command is used to reinitialise the Ethernet interface of an Ethernet communication module in module slot MXI2, e. g. to accept a newly set IP or gateway address without mains switching.



**Tip!**

Detailed information on the Ethernet communication module (E94AYCEN) can be found in the "Ethernet" Communication Manual.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
	6718722 Device command in process
	6684672 Device command executed successfully
	6684673 General fault

### Related device commands

▶ [Ethernet module MXI2 unbind/bind](#) ([📖 89](#))

## 4.2.36 Activate parameter set 1 ... 4

In addition to the start parameters, up to four further parameter sets can be stored in the memory module for each application. Like this you can for instance define different controller settings for an application, which are then simply activated via device command, if required.


The following device commands can be used to activate the parameter set 1 ... 4 for the active application (if available on the memory module):

C00002 = "201: Activate parameter set 1"

C00002 = "202: Activate parameter set 2"

C00002 = "203: Activate parameter set 3"




C00002 = "204: Activate parameter set 4"



[4-20] Example: "Activate parameter set 1" function

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ All parameter changes of the previously active parameter set carried out since the last saving will get lost!
- ▶ These device commands only affect the settings of the operating system, application and module parameters, the active application or a configuration selected with the function block editor remain unchanged.

## Possible status displays for these device commands

Status (C00003)	for command				Meaning
	201	202	203	204	
	13206786	13272322	13337858	13403394	Device command in process
	13172736	13238272	13303808	13369344	Device command executed successfully
	13172731	13238273	13303809	13369345	General fault
	13206532	13272068	13337604	13403140	File could not be opened.
	13206557	13272093	13337629	13403165	Fault while reading out of a file.
	13206558	13272094	13337630	13403166	Fault while writing into a file.
	13206559	13272095	13337631	13403167	Invalid file type.
	13206560	13272096	13337632	13403168	Unexpected file end.
	13206562	13272098	13337634	13403170	Checksum error
	13212160	13277696	13343232	13408768	CAN fault
	...	...	...	...	...
	13212415	13277951	13343487	13409023	CAN fault
	13213697	13279233	13344769	13410305	Access to file has been denied since the file is already accessed from another position
	13213701	13279237	13344773	13410309	I/O fault when accessing the file system
	13213708	13279244	13344780	13410316	RAM is full
	13213709	13279245	13344781	13410317	Access authorisation denied
13213724	13279260	13344796	13410332	No free memory on the memory module	

## Related device commands

▶ [Activate parameter set 1 ... 4](#) (📖 93)

## 4.2.37 Activate parameter set 1 ... 4

In addition to the start parameters, up to four further parameter sets can be stored in the memory module for each application. Like this you can for instance define different controller settings for an application, which are then simply activated via device command, if required.


The following device commands are used to archive the current parameter settings of the controller for the active application in the memory module as parameter set 1 ... 4:

C00002 = "301: Archive parameter set 1"

C00002 = "302: Archive parameter set 2"

C00002 = "303: Archive parameter set 3"




C00002 = "304: Archive parameter set 4"



[4-21] Example: "Archive parameter set 1" function

- ▶ Previously archived parameter settings will be overwritten with the current parameter settings!

## Possible status displays for these device commands

Status (C00003)	for command				Meaning
	301	302	303	304	
	19760386	19825922	19891458	19956994	Device command in process
	19726336	19791872	19857408	19922944	Device command executed successfully
	19726337	19791873	19857409	19922945	General fault
	19760132	19825668	19891204	19956740	File could not be opened.
	19760157	19825693	19891229	19956765	Fault while reading out of a file.
	19760158	19825694	19891230	19956766	Fault while writing into a file.
	19760160	19825696	19891232	19956768	Unexpected file end.
	19767297	19832833	19898369	19963905	Access to file has been denied since the file is already accessed from another position
	19767301	19832837	19898373	19963909	I/O fault when accessing the file system
	19767308	19832844	19898380	19963916	RAM is full
	19767309	19832845	19898381	19963917	Access authorisation denied
	19767324	19832860	19898396	19963932	No free memory on the memory module

## Related device commands

▶ [Activate parameter set 1 ... 4](#) (📖 91)

## 4.2.38 Load cam data


This function extension is available from software version V3.0!

The [C00002](#) = "501: Load cam data" device command serves to reload cam data from the memory module into the controller.

**Note!**

If you transfer the parameter set or the application from the »Engineer« to the controller, the cam data are also transferred automatically to the controller.

- The new/altered cam data are accepted in the controller according to the online change mode set.
- Thus, normally this device command does not need to be executed manually.



[4-22] "Load cam data" function

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ If the cam data are provided with an access protection, the user password has to be entered in [C02900](#) first.

**Tip!**




Detailed information on the online change mode and the access protection can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)".

([book icon](#) 563)

**Sequence**

1. The cam data are completely loaded from the memory module into the main memory of the controller.
2. The present cam data in the application unit are converted to the internal unit [increments] and are reorganised.
3. The processed cam data are stored in a separate main memory that can be accessed by the cam application.

## Possible status displays for this device command

Status (C00003)	Meaning
 32867586	Device command in process
 32833536	Device command executed successfully
	32833537 General fault
	32875521 No cam data available on the memory module
	32875523 Loading of the cam data failed
	32875525 Checksum error
	32875542 Wrong password entered
32875545	The cam functionality is deactivated

## Related device commands


- ▶ [Save cam data](#) (📖 97)
- ▶ [Calculate cam data](#) (📖 99)
- ▶ [Calculate cam data checksum](#) (📖 100)



## 4.2.39 Save cam data

This function extension is available from software version V3.0!

The [C00002](#) = "502: Save cam data" device command serves to save the cam data available in the main memory of the controller with mains failure protection in the memory module.



[4-23] "Save cam data" function

- ▶ This function is executed in the background and is also possible when the controller is enabled and the application is running.
  - However, this function is only executed if valid cam data are available.
  - The cam data can also be saved if previously no cam data have been available on the memory module.
- ▶ While the function is executed, no online change and no change of the cam data via parameters can be carried out.

For software versions lower than V4.0 the following applies:

- ▶ If the cam data are provided with an access protection, the user password has to be entered in [C02900](#) first.




The following applies from software version V4.0:

- ▶ For saving the cam data, you do not need to enter a possibly existing user password ([C02900](#)).

**Tip!**

Detailed information on the access protection can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". (📖 563)

## Possible status displays for this device command

Status (C00003)	Meaning
 32933122	Device command in process
 32899072	Device command executed successfully
	32899073 General fault
	32941057 No cam data to be saved are available in the RAM of the controller
	32941060 Saving of the cam data failed
	32941078 Wrong password entered
32941081	The cam functionality is deactivated

## Related device commands

- ▶ [Load cam data](#) (📖 95)
- ▶ [Calculate cam data](#) (📖 99)
- ▶ [Calculate cam data checksum](#) (📖 100)

## 4.2.40 Calculate cam data

This function extension is available from software version V3.0!





The [C00002](#) = "503: Calculate cam data" device command converts the cam data stored in the main memory of the controller to the internal format and makes them available to the application. This, for instance, is necessary if one or more machine parameters affecting the internal scaling of cam data have been changed.

- ▶ The status signal *bNewDataAvailable* of the basic drive function "[Cam data management](#)" (LS\_CamInterface system block) is set to TRUE and the cam data are accepted automatically or manually depending on the online change mode set. After successful data acceptance, the status signal *bNewDataAvailable* is automatically reset to FALSE.
- ▶ The user password does not have to be entered in [C02900](#).
- ▶ While the function is executed, no online change and no change of the cam data via parameters can be carried out.
- ▶ This function is executed in the background and can also be activated when the controller is enabled and the application is running.

**Tip!**

Detailed information on the cam functionality can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". (📖 563)

**Possible status displays for this device command**

Status ( <a href="#">C00003</a> )	Meaning
 32998658	Device command in process
 32964608	Device command executed successfully
 32964609	General fault
 33006617	The cam functionality is deactivated

**Related device commands**

- ▶ [Load cam data](#) (📖 95)
- ▶ [Save cam data](#) (📖 97)
- ▶ [Calculate cam data checksum](#) (📖 100)

## 4.2.41 Calculate cam data checksum

This function extension is available from software version V3.0!

The [C00002](#) = "504: Calculate cam data checksum" device command is used to recalculate the checksum of the cam data available in the main memory of the controller. This is required if the cam data in the main memory of the controller have been changed via parameters. Afterwards the cam data can be converted to the internal format using the "503: Calculate cam data" device command, or they can be saved with mains failure protection in the memory module using the "502: Save cam data" device command.




- ▶ The user password does not have to be entered in [C02900](#).
- ▶ This function is executed in the background and can also be activated when the controller is enabled and the application is running.



### Tip!

Detailed information on the cam functionality can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". (📖 563)

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 33064194	Device command in process
 33030144	Device command executed successfully
	33030145 General fault
	33072153 The cam functionality is deactivated

### Related device commands

- ▶ [Load cam data](#) (📖 95)
- ▶ [Save cam data](#) (📖 97)
- ▶ [Calculate cam data](#) (📖 99)

#### 4.2.42 Format file system

The [C00002](#) = "1030: Format file system" device command is used to format the file system in the memory module.






#### Note!

By means of this device command all folders and files in the file system of the memory module are irrevocably deleted!

The application has to be downloaded again with the »Engineer«.

#### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 67536130	Device command in process
 67502080	Device command executed successfully
 67502081	General fault

#### Related device commands

▶ [Restore file system](#) (📖 102)

## 4.2.43 Restore file system

The [C00002](#) = "1040: Restore file system" device command is used to execute a low level formatting of the file system in the memory module.



### Note!

By means of this device command all folders and files in the file system of the memory module and all internal information for the management of the file system are irrevocably deleted!

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



### Stop!

The low level formatting of the file system by the user is only intended for the exceptional case when the standard formatting of the file system via the [C00002](#) = "1030: Format file system" device command is no longer possible, e.g. due to damaged internal management information.

### Related device commands

▶ [Format file system](#) (📖 101)

## 4.2.44 Prepare firmware update




**Note!**

For Lenze service only!

The [C00002](#) = "10000: Prepare firmware update" device command is used to set the controller to the firmware update mode to update the firmware, if required, using the corresponding software.

- ▶ Only possible when the application has stopped and the controller is inhibited.

**Possible status displays for this device command**


Status <a href="#">(C00003)</a>	Meaning
 655394050	Device command in process
 655360000	Device command executed successfully
 655360001	General fault

## 4.2.45 Restart controller

The [C00002](#) = "11000: Restart controller" device command is used to restart the controller via parameter setting.

- ▶ Only possible when the application has stopped and the controller is inhibited.

### Possible status displays for this device command

Status ( <a href="#">C00003</a> )	Meaning
 720930050	Device command in process
 720896001	General fault



### Note!


Due to the restart at the successful execution of the device command, this status is no longer displayed in [C00003](#).

If this device command is used, the message "Undervoltage in the DC bus (0x007b000f)" may appear in the logbook.



## 4.3 Device states

The state control of the drive is controlled internally via a state machine which can adopt the following "device states":



[4-24] Device states of the state machine for the device control



### Note!

The device states of the controller must not be confused with the function states of the [Basic drive functions](#). (375)

- In the device state "Operation" the [Basic drive functions](#) define the motion control of the drive.

## Display parameters for diagnostic purposes

- ▶ In [C00183](#) the current device state is shown.
- ▶ In [C00150](#) (status word 1) the current device state is shown bit coded via bits 8 ... 11:

Bit 11	Bit 10	Bit 9	Bit 8	Meaning
0	0	0	0	<a href="#">"Initialisation active" state</a>
0	0	0	1	<a href="#">"Device is ready to switch on" state</a>
0	0	1	0	-
0	0	1	1	<a href="#">"Device is switched on" state</a>
0	1	0	0	-
0	1	0	1	-
0	1	1	0	<a href="#">"Operation" state</a>
0	1	1	1	<a href="#">"Warning active" state</a> or <a href="#">"Warning locked active" state</a> The controller is ready to switch on, switched on or operation is enabled, and a warning is present.
1	0	0	0	<a href="#">"Trouble active" state</a>
1	0	0	1	-
1	0	1	0	<a href="#">"Quick stop by trouble active" state</a>
1	0	1	1	<a href="#">"Safe torque off active" state</a> Observe LED of the safety module!
1	1	0	0	<a href="#">"Fault active" state</a>
1	1	0	1	-
1	1	1	0	-
1	1	1	1	-

- ▶ [C02530](#) displays the active function state.

## LED status displays

The control of the two LEDs "DRIVE READY" and "DRIVE ERROR" in the middle of the controller's front panel depends on the device state. ▶ [LED status displays for the device state](#) (📖 612)

## Influence of the status signals of the SB LS\_DriveInterface by the device state

Device state	Status signals (Outputs of the SB LS_DriveInterface)						
	DI_bReady	DI_bFail Active	DI_bImp Active	DI_bCInh Active	DI_bWarning Active	DI_bReady ToSwitchOn	DI_bOperation Enabled
<a href="#">Initialisation active</a>	FALSE	FALSE	TRUE	TRUE	FALSE	FALSE	FALSE
<a href="#">Safe torque off active</a>	FALSE	FALSE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
<a href="#">Device is ready to switch on</a>	FALSE	FALSE	TRUE	TRUE	TRUE/FALSE	TRUE	FALSE
<a href="#">Device is switched on</a>	TRUE	FALSE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
<a href="#">Operation</a>	TRUE	FALSE	FALSE	FALSE	TRUE/FALSE	FALSE	TRUE
<a href="#">Warning active</a>	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE	TRUE/FALSE	TRUE/FALSE
<a href="#">Warning locked active</a>	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE	TRUE/FALSE	TRUE/FALSE
<a href="#">Quick stop by trouble active</a>	FALSE	TRUE	FALSE	FALSE	TRUE/FALSE	FALSE	FALSE
<a href="#">Trouble active</a>	FALSE	FALSE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
<a href="#">Fault active</a>	FALSE	TRUE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
<a href="#">System fault active</a>	FALSE	TRUE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE

► [Internal interfaces | "LS\\_DriveInterface" system block \(118\)](#)


### 4.3.1 "Initialisation active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF	OFF	10: Initialisation active

This is the controller's state directly after switching on the supply voltage.

- In this device state the operating system is initialised.
- The application is not processed yet.
- The monitoring is not active yet.
- Communication is not possible yet.
- The controller cannot be parameterised yet and no device commands can be executed.
- When the device initialisation is completed, the device state is automatically changed to "Safe torque off active".

## 4.3.2 "Safe torque off active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	101: Safe torque off active

This device state becomes active if the controller receives the "Safe torque off" request by the safety module.


- ▶ "Drive is torqueless" (0x00750003) is entered in the logbook.
- ▶ If no corresponding request by the safety module is available, a change to the subsequent state "Device is ready to switch on" is effected.



### Note!

The "Safe torque off active" status is also passed through after an error has been acknowledged (see illustration [\[4-24\]](#)).

## 4.3.3 "Device is ready to switch on" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	"Device is ready to switch on"

This is the device state of the controller directly after the initialisation has been completed and where no DC-bus voltage is applied yet.

- ▶ The bus systems are running and the terminals and encoders are evaluated.
- ▶ Monitoring is active.
- ▶ The controller can be parameterised and device commands can be executed to a limited extent.
- ▶ The application is basically executable.
- ▶ The functions of the user task can be used.
  - Precondition: The application has started (status display in [C02108](#)).
- ▶ The basic drive functions cannot be used yet.



### Note!

The "Device is ready to switch on" status is not only activated after mains connection but also after reset of "Trouble", "Fault" or "Safe torque off active".

- In order to change from the "Device is ready to switch on" to the "Device is switched on" status when [C00142](#) = "0: inhibited", at least one of the controller inhibit sources must be active.
- When [C00142](#) = "1: Enabled", the "Device is ready to switch on" status directly changes to the "Device is switched on" status.



## Danger!

If automatic restart is enabled ([C00142](#) = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or requirement for "Safe torque off active" has been eliminated!

▶ [Automatic restart after mains connection/trouble...](#) (📖 112)

### 4.3.4 "Device is switched on" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	90: Drive is switched on

This is the device state of the controller if the DC-bus voltage is applied and the controller is still inhibited by the user (controller inhibit).



- ▶ The bus systems are running and the terminals and encoders are evaluated.
- ▶ Monitoring is active.
- ▶ The controller can be parameterised and device commands can be executed to a limited extent.
- ▶ The application is basically executable.
- ▶ The functions of the user task can be used.
  - Precondition: The application has started (status display in [C02108](#)).
- ▶ The basic drive functions cannot be used yet.
- ▶ If the controller is enabled, the motor builds up a torque.

### 4.3.5 "Operation" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	0: Operation



In this device state the motor follows its setpoint according to the basic drive function selected.

## 4.3.6 "Warning active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
		1: Operation/warning active



This state can occur at the same time as the device states "Device is ready to switch on", "Device is switched on" and "Operation" if a monitoring function is activated for which the "Warning" error response has been parameterised.

## 4.3.7 "Warning locked active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
		2: Operation/warning locked active

This state can occur at the same time as the device states "Device is ready to switch on", "Device is switched on" and "Operation" if a monitoring function is activated for which the "Warning locked" error response has been parameterised.


## 4.3.8 "Quick stop by trouble active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
		151: Quick stop by trouble active

This device state becomes active as soon as a monitoring function responds for which the "Quick stop by trouble" error response has been parameterised.

- ▶ Irrespective of the setpoint defined, the drive is brought to standstill with a torque within the parameterised deceleration time for quick stop and can be held there.
- ▶ The device state can only be exited by acknowledging the error if the error cause has been eliminated.
- ▶ It is also possible to skip to the "Operation" state during the error status by setting controller inhibit, as controller inhibit has a higher priority. As long as the error is still available and has not been acknowledged, a change back to the "Quick stop by trouble active" state is effected when the controller is enabled afterwards.


## 4.3.9 "Trouble active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF		104: Trouble active

This device state becomes active as soon as a monitoring function responds for which the "Trouble" error response has been parameterised.


- ▶ The motor has no torque (is coasting).
- ▶ The device state is automatically exited if the error cause is eliminated:
  - "Trouble active" state < 500 ms: Return to the original device state.
  - "Trouble active" state > 500 ms: Return via the device state "Safe torque off active".

## 4.3.10 "Fault active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF		102: Fault active

This device state becomes active as soon as a monitoring function responds for which the "Fault" error response has been parameterised.

## 4.3.11 "System fault active" state

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF		20: System fault active

This device state becomes active if a system fault occurs.

- ▶ The device state can only be exited by mains switching.

## 4.4 Automatic restart after mains connection/trouble...

.../Fault/"safe torque off active"

In [C00142](#), the starting performance of the controller after mains connection and reset of "Trouble", "Fault" or "safe torque off active" can be parameterised.



### Note!

From software version V4.0 the automatic restart is inhibited in the Lenze setting! Set the selection "1: Enabled" in [C00142](#) to obtain the former behaviour.




### Danger!

If automatic restart is enabled ([C00142](#) = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or requirement for "Safe torque off active" has been eliminated!

### Auto-start option 0: Auto restart inhibited after mains connection

Controller inhibit always has to be set if the controller is to change from the "Ready to switch on" state to the "Switched on" state after mains connection or reset of "Trouble", "Fault", or "Safe torque off active". The following change to the "Operation" state is performed when the controller is enabled:




[4-25] State change when auto-restart is inhibited (C00142 = "0: Inhibited")



## Auto-start option 1: Auto restart enabled after mains connection

The following illustration shows the state changes for the auto-start option 1 and their relationship to controller inhibit:



[4-26] State change when auto-restart is enabled (C00142 = "1: Enabled")

## 4.5 Behaviour after task overflow

Up to software version V5.0 the following applies:

- ▶ After a task overflow in the application or user task the "Error" response is effected.

The following applies from software version V5.0:

- ▶ In [C02111](#) the error response after a task overflow in the application or user task can be parameterised. The Lenze setting "Error" corresponds to the previous behaviour of the controller with software versions lower than V5.0.



### Tip!

For a hoist for instance the "Quick stop by trouble" error response with engagement of the brake can be set, so that the drive is brought to standstill within the shortest time possible.

From »Engineer« version 2.10 onwards, the function block editor can also be used to configure the behaviour of the analog and digital outputs and that of the brake control and the output ports after a task overflow in order to adapt it to the respective application. ▶ [Configure exception handling of the outputs](#) (📖 290)

## 4.6 Device output power

The parameters described in the following subchapters influence the output power of the controller.

### 4.6.1 Switching frequency

The controller uses a pulse-width modulation to generate its output voltage. The switching frequency is used to change the control factor of the pulse-width modulation.

#### Automatic switching frequency reduction

In the Lenze setting, the "variable" switching frequency "8 kHz" has been selected in [C00018](#), which means that the controller automatically reduces the switching frequency depending on the setpoint current.

- ▶ Depending on the current amount, it is changed down to an assigned switching frequency.
- ▶ The switching thresholds are device-dependent (see 9400 hardware manual, chapter "Rated data").
- ▶ If a fixed switching frequency is selected in [C00018](#) instead of a variable one, there is no switching frequency changeover, however, (due to the field frequency range 0...5 Hz) it can only be traversed at a low continuous current and low maximum currents (see 9400 hardware manual, chapter "Rated data").



#### Note!

If parameterisation is carried out offline or if the memory module is exchanged between different 9400 HighLine device types, always check the setting of the switching frequency in [C00018](#) and adapt it, if required, to prevent a parameter error after the parameter set download or module change!

The maximum output frequency of the controller is limited to 1/8 of the switching frequency selected in [C00018](#)! (See the following table.)

Switching frequency ( <a href="#">C00018</a> ):	1 kHz	2 kHz	4 kHz	8 kHz	16 kHz
Maximum output frequency:	125 Hz	250 Hz	500 Hz	1000 Hz	1999 Hz
Motor - number of pole pairs:	Maximum speed [rpm]				
1	7500	15000	30000	60000	120000
2	3750	7500	15000	30000	60000
3	2500	5000	10000	20000	40000
4	1875	3750	7500	15000	30000
5	1500	3000	6000	12000	24000
6	1250	2500	5000	10000	20000



## Tip!

If a load profile and a fixed setting of the switching frequency (e. g. 8 kHz fixed) are given, an I x t disconnection due to a high device utilisation can be avoided by selecting the variable setting for the same switching frequency instead.

▶ [Monitoring of the device utilisation](#)

## Reduced switching losses through switching frequency reduction

The advantage of a switching frequency reduction are the reduced switching losses in the controller, which are monitored via an I x t evaluation.

- ▶ A reduced switching frequency enables a greater current-time area at the output than it would be the case with a higher switching frequency. However, depending on the process, you always have to make a compromise between the torque ripple and the output power.

### 4.6.2 Monitoring of the device utilisation

In [C00064](#) the device utilisation (I x t) is displayed over the last 180 seconds in [%].

- ▶ If the value displayed in [C00064](#) exceeds the warning threshold set in [C00123](#), the error message "device utilisation Ixt > C00123" is output and the fault response set in [C00604](#) occurs (default setting: "Warning").
- ▶ If the value displayed in [C00064](#) exceeds 100 %, the error message "device utilisation Ixt > 100 %" is output and the "Fault" error response occurs.
  - The fault can only be reset if the value displayed in [C00064](#) is < 95 % again.

### 4.6.3 Operation with increased continuous power

This function extension is available from software version V3.0!

If required, operation with an increased continuous power for the switching frequencies 1 kHz and 2 kHz can be activated in [C01199](#) for controllers from the device size 8S, if the following requirements are met:

- ▶ Controller is of E94AxxE1454 ... E94AxxE6954 type (device size 8S ... 10).
- ▶ The maximum current ([C00022](#)) is < 150 % of the rated device current.



#### Stop!

During operation with increased continuous power, the max. permissible ambient temperature is reduced to 40 °C.

The overload current must be reduced. An overload current of 180 % for 10 s is no longer permissible during operation with increased continuous power.



#### Note!

To activate the operation with increased continuous power, controller inhibit must be set in the controller.

The "activated" setting in [C01199](#) is automatically reset to "deactivated" (without error message) if the previously mentioned requirements are not (no longer) met.

- This is the also the case if the memory module is plugged into a controller of the smaller design 8 (device exchange).




#### Tip!

The permissible output currents and overload factors for operation with increased continuous power for different device types can be found in the Hardware Manual in the "Rated data" chapter.

## 4.7 Internal interfaces | "LS\_DriveInterface" system block

The **LS\_DriveInterface** system block provides the internal interfaces to the drive interface in the function block editor.



### Inputs

Identifier DIS code   data type	Information/possible settings				
DI_bSetClnh <a href="#">C02549/1</a>   BOOL	<p>Set/remove controller inhibit</p> <ul style="list-style-type: none"> <li>The controller can be inhibited by different sources, e.g. via the digital input RFR or using the device command "<a href="#">Inhibit controller</a>". (<a href="#">□ 67</a>)</li> <li>The bit code under <a href="#">C00158</a> shows the source that inhibited the controller.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Set controller inhibit.                             <ul style="list-style-type: none"> <li>The power output stages in the controller are inhibited and the speed, current, and position controller of the motor control are reset.</li> </ul> </td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Remove controller inhibit.                             <ul style="list-style-type: none"> <li>Please note that the controller will only be enabled if <u>all</u> sources for controller inhibit are reset!</li> </ul> </td> </tr> </table>	TRUE	Set controller inhibit. <ul style="list-style-type: none"> <li>The power output stages in the controller are inhibited and the speed, current, and position controller of the motor control are reset.</li> </ul>	TRUE↔FALSE	Remove controller inhibit. <ul style="list-style-type: none"> <li>Please note that the controller will only be enabled if <u>all</u> sources for controller inhibit are reset!</li> </ul>
TRUE	Set controller inhibit. <ul style="list-style-type: none"> <li>The power output stages in the controller are inhibited and the speed, current, and position controller of the motor control are reset.</li> </ul>				
TRUE↔FALSE	Remove controller inhibit. <ul style="list-style-type: none"> <li>Please note that the controller will only be enabled if <u>all</u> sources for controller inhibit are reset!</li> </ul>				
DI_bResetError1 <a href="#">C02548/1</a>   BOOL	<p>Error message reset (acknowledgement)</p> <ul style="list-style-type: none"> <li>This function resets an active error message if the cause of the error message has been eliminated.</li> <li>The three inputs are linked via a logic OR gate.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Reset (acknowledge) error message.</td> </tr> </table>	TRUE	Reset (acknowledge) error message.		
TRUE		Reset (acknowledge) error message.			
DI_bResetError2 <a href="#">C02548/2</a>   BOOL					
DI_bResetError3 <a href="#">C02548/3</a>   BOOL					
DI_bSetExternError <a href="#">C02548/4</a>   BOOL	<p>Activation of error message "External error".</p> <p>▶ <a href="#">Monitoring of external events</a> (<a href="#">□ 122</a>)</p> <table border="1"> <tr> <td>TRUE</td> <td>Activate error message with the response selected in <a href="#">C00581</a>.</td> </tr> </table>	TRUE	Activate error message with the response selected in <a href="#">C00581</a> .		
TRUE	Activate error message with the response selected in <a href="#">C00581</a> .				
DI_bSwitchOn <a href="#">C02549/4</a>   BOOL	<p>Deactivate switch-on inhibit</p> <ul style="list-style-type: none"> <li>If the automatic restart is inhibited (<a href="#">C00142</a> = "0"), the state machine remains in the "Device is ready to switch on" state after mains switching.                             <ul style="list-style-type: none"> <li>▶ "<a href="#">Device is ready to switch on</a>" state (<a href="#">□ 108</a>)</li> </ul> </li> </ul> <table border="1"> <tr> <td>FALSE↔TRUE</td> <td>The switch-on inhibit is deactivated and the controller changes to the device state "Device is switched on".</td> </tr> </table>	FALSE↔TRUE	The switch-on inhibit is deactivated and the controller changes to the device state "Device is switched on".		
FALSE↔TRUE	The switch-on inhibit is deactivated and the controller changes to the device state "Device is switched on".				

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
DI_dnState  <a href="#">C02547</a>   DINT	Status (bit coded)
	<b>Status signals of the currently enabled basic function (if available):</b>
	Bit 0 -
	Bit 1 Basic function is active (signal <i>bActive</i> ).
	Bit 2 Basic function is completed (signal <i>bDone</i> ).
	Bit 3 Acceleration/deceleration phase is active (signal <i>bAccDec</i> ).
	Bit 4 -
	Bit 5 CCW rotation is active (signal <i>bCcw</i> ).
	Bit 6 -
	Bit 7 Reference known.
	Bit 8 Brake is open.
	Bit 9 Waiting for clutch condition.
	Bit 10 Zero crossing detected or position = "0".
	Bit 11 -
	Bit 12 -
	Bit 13 -
	Bit 14 -
	Bit 15 Fault in active basic function (group signal).
	<b>Status signals of the internal state machine for the basic functions:</b>
	Bit 16 <a href="#">Torque follower</a> active.
	Bit 17 <a href="#">Speed follower</a> active.
	Bit 18 <a href="#">Position follower</a> active.
	Bit 19 Setpoint follower is active (group signal for bit 16 ...18).
	Bit 20 <a href="#">Positioning</a> active.
	Bit 21 <a href="#">Homing</a> active.
	Bit 22 <a href="#">Manual jog</a> active.
	Bit 23 Brake test is active.
	Bit 24 Drive at standstill.
	Bit 25 Drive is stopped.
	Bit 26 <a href="#">Quick stop</a> active.
	Bit 27 -
	Bit 28 Controller is not ready.
Bit 29 Initialisation	
Bit 30 State "Fault active" (signal <i>DI_bFailActive</i> ).	
Bit 31 State machine is not ready to receive setpoints. (Group signal for bit 28 ... 30)	
DI_bReady  <a href="#">C02549/6</a>   BOOL	Status signal "Controller is ready for operation"  TRUE The controller is ready for operation.
DI_bFailActive  <a href="#">C02549/7</a>   BOOL	Status signal "Error active - acknowledgement required"  TRUE Monitoring with the "Fault" or "Quick stop by trouble" error response has responded and the controller is in the device state "Fault active" or "Quick stop by trouble active". For exiting the device state the fault has to be acknowledged, e. g. via the input <i>DI_bErrorReset1...3</i> .

# 9400 HighLine | Parameter setting & configuration

Drive interface


Internal interfaces | "LS\_DriveInterface" system block

Identifier <small>DIS code   data type</small>	Value/meaning
DI_bImpActive <a href="#">C02549/8</a>   BOOL	Status signal "Pulse inhibit set" TRUE   The power output stages are switched to high impedance.
DI_bClnhActive <a href="#">C02549/9</a>   BOOL	Status signal "Controller inhibit active" TRUE   The controller inhibit is active.
DI_bWarningActive <a href="#">C02549/10</a>   BOOL	Status signal "Warning active" TRUE   A warning is active in the controller.
DI_bUVDetected <a href="#">C02549/11</a>   BOOL	Status signal "Undervoltage detected" • The threshold for this monitoring function depends on the setting under <a href="#">C00173</a> . TRUE   Undervoltage detected in DC bus.
DI_bOVDetected <a href="#">C02549/12</a>   BOOL	Status signal "Overvoltage detected" • The threshold for this monitoring function depends on the setting under <a href="#">C00173</a> . TRUE   Overvoltage detected in DC bus.
DI_bMainSupplyOk <a href="#">C02549/13</a>   BOOL	Status signal "Mains voltage is applied" TRUE   A voltage is applied to the mains voltage inputs L1, L2 and L3.
DI_bReadyToSwitchOn <a href="#">C02549/14</a>   BOOL	Status signal "Controller ready to switch on" TRUE   The controller has completed the initialisation and is in the "Device is ready to switch on" device state.
DI_bOperationEnabled <a href="#">C02549/15</a>   BOOL	Status signal "Operation is enabled" TRUE   The controller is in the "Operation" device state and the motor follows its setpoint according to the selected basic drive function or is at standstill due to stop or quick stop.
DI_dwErrorCode <small>DWORD</small>	Error number of the current error message ▶ <a href="#">Error messages of the operating system</a> (□ 623)
DI_AxisData	Data structure, which contains all required machine constants.



## 4.7.1 Status signals

The following representation shows which status signals of the drive interface are set to TRUE in different typical cases:



Status	Case 1	Case 2	Case 3	Case 4	Case 5	Status signal (output)
Ready for operation	●	○	○	○	○	DI_bReady
Fault active	○	○	○	●	●	DI_bFailActive
Pulse inhibit active	○	○	○	○	○	DI_bImpActive
Controller inhibit active	○	○	○	○	○	DI_bCInhActive
Warning active	○	○	○	○	○	DI_bWarningActive
Undervoltage detected	○	○	○	○	○	DI_bUVDetected
Overvoltage detected	○	○	○	○	○	DI_bOVDetected
Mains supply is ok	○	○	○	○	○	DI_bMainSupplyOk
Ready to switch on	○	○	○	○	○	DI_bReadyToSwitchOn
Operation enabled	○	○	○	○	○	DI_bOperationEnabled

## 4.7.2 Monitoring of external events

Use the input *DI\_bSetExternError* of the [LS DriveInterface](#) system block to monitor external events by means of corresponding logic operations and activate the error message "External error" in the controller.

### Parameterising a response to an external error

The controller response to the error message "External error" can be selected under [C00581](#).

### Activation of error message "External error".

The error message "External error" is activated by setting the input *DI\_bSetExternError* to TRUE.

- ▶ After this, the error number for the error message "External error" "[0x20750000](#)" (when "Fault" has been selected as response) will be stored in the internal fault memory ([C00168](#)).

### Reset of error message

The error message "External error" and other active error messages are reset by setting the input *DI\_bResetError* to TRUE.

- ▶ If the input *DI\_bSetExternError* is still set to TRUE, the reset will not be carried out.
- ▶ Error messages can only be reset if the cause of the error has been eliminated.

## 5 Motor interface

This chapter provides you with information on initial commissioning of the motor and the parameterisation of the internal motor control of the controller.



### Note!

The motor interface contains all control functions that are not provided by other basic drive functions.


To select application-specific setpoints, the motor interface can be extended by appropriate interfaces using the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)".

The application-specific conditioning of the encoder signals is executed with the basic function "[Encoder evaluation](#)".



**How to get to the dialog for setting the motor interface parameters:**

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Select the **Application parameters** tab from the *Workspace*.
3. Click the following button of the *Overview* dialog level:



### Parameterisation dialog in the »Engineer«

- ▶ The white buttons indicate the configuration of the motor interface inputs. ▶ [Internal interfaces | "LS MotorInterface" system block](#) (236)
  - The configuration is predefined by the technology application selected (in this example "Actuating drive – speed"). If required, this configuration can be changed by clicking the corresponding buttons.
- ▶ If you click a button marked with the → symbol, you go one level deeper in the corresponding parameterisation dialog.

## 5.1 General information

### 5.1.1 Reading out motor data from the controller

If the Lenze motor connected to the controller has an electronic nameplate (ENP), the motor does not need to be selected in the »Engineer« motor catalogue.

- ▶ With the first switch-on of the controller all motor data are automatically read out from the electronic nameplate of the motor and at first are saved temporarily within the controller.
- ▶ For a permanent acceptance of the motor data, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- ▶ If there is an online connection between the »Engineer« and the controller, the motor data can be accepted from the controller to the »Engineer« project.



#### How to read out the motor data from the controller:

1. Establish an online connection between »Engineer« and controller.
2. Select the **Application parameters** tab and change to the *Overview* → *Motor* → *Motor* dialog level.
3. Click on the **From Drive** button.
  - Then the motor data are read out of the controller and directly written into the corresponding codes of the »Engineer« project.


#### Display parameters for electronic nameplate (ENP)

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00186</a>	ENP: Identified motor type	-	
<a href="#">C00187</a>	ENP: Identified serial number	-	
<a href="#">C00188</a>	ENP: Status	-	

#### 5.1.2 Selecting motor in the »Engineer« motor catalogue

If the Lenze motor does not have an electronic nameplate (ENP) or if a motor of a third-party manufacturer is used, select the motor in the »Engineer« via the motor catalogue and transfer the motor data to the controller.

- ▶ If you, when inserting the controller into the project in the dialog step "Other components", put a checkmark in the control field **Motor**, you can select as a further dialog step the motor for the controller from the motor catalogue:



- ▶ As an alternative you can also insert the motor into the project later on via the **Insert component** command.



#### Tip!

If you use a motor of a third-party manufacturer, you can first select a suitable motor regarding the rated data for current, voltage and speed and then adapt the motor data exactly to the existing motor.

- ▶ [Displaying/editing motor data in the »Engineer«](#) (127)

### 5.1.3 Displaying/editing motor data in the »Engineer«

The term "Motor data" combines all parameters that only depend on the motor. They solely characterise the electrical behaviour of the machine.

- ▶ The motor data do not depend on the application in which the controller and motor are used.
- ▶ The motor data are, if available in the »Engineer« via electronic nameplate or motor catalogue, accepted by the controller without confirmation prompt.

In the »Engineer« the motor data are shown on the **Application parameters** tab in the dialog level *Overview*→*Motor*→*Motor*:

- ▶ If you use a motor of a third-party manufacturer, the displayed motor data can be adapted exactly to the existing motor by clicking the **From Project** button and then selecting the "Own motor settings" entry in the **Motor selection** dialog box.
- ▶ Click **From Motor Catalogue** to open the motor catalogue and select a different motor.
  - ▶ [Selecting motor in the »Engineer« motor catalogue](#) (126)
- ▶ If an online connection has been established, the motor data set in the controller can be accepted in the »Engineer« via the button **From Drive**. ▶ [Reading out motor data from the controller](#) (125)

## Overview of motor data

Parameter	Information	Lenze setting *	
		Value	Unit
<a href="#">C00052</a>	Motor voltage	-	V
<a href="#">C00054</a>	Motor current	-	A
<a href="#">C00057/1</a>	Maximum torque	-	Nm
<a href="#">C00057/2</a>	Motor reference torque	-	Nm
<a href="#">C00059</a>	Motor - number of pole pairs	-	
<a href="#">C00060</a>	Rotor position	-	
<a href="#">C00079</a>	Mutual motor inductance	-	mH
<a href="#">C00081</a>	Rated motor power		kW
<a href="#">C00082</a>	Motor rotor resistance	-	Ohm
<a href="#">C00083</a>	Motor - rotor time constant	-	ms
<a href="#">C00084</a>	Motor stator resistance		Ohm
<a href="#">C00085</a>	Motor stator leakage induct.		mH
<a href="#">C00087</a>	Rated motor speed		rpm
<a href="#">C00088</a>	Rated motor current		A
<a href="#">C00089</a>	Rated motor frequency		Hz
<a href="#">C00090</a>	Rated motor voltage		V
<a href="#">C00091</a>	Motor - cosine phi		
<a href="#">C00092</a>	Motor magnetising current	-	A
<a href="#">C00128/1</a>	Therm. time constant coil		min
<a href="#">C00128/2</a>	Therm. time constant plates		min
<a href="#">C00273/1</a>	Motor moment of inertia		kg cm <sup>2</sup>
<a href="#">C01190</a>	Motor thermal sensor		
<a href="#">C01191/1</a>	Spec. characteristic: Temperature		°C
<a href="#">C01191/2</a>	Spec. characteristic: Temperature		°C
<a href="#">C01192/1</a>	Spec. characteristic: resistance		Ohm
<a href="#">C01192/2</a>	Spec. characteristic: resistance		Ohm

Highlighted in grey = display parameter \* depending on the selected motor type



### Note!

If the motor has been selected via the »Engineer« motor catalogue, or if the motor data have been adapted offline in the »Engineer«, all motor data have to be transferred to the controller afterwards when an online connection has been established and have to be saved in the memory module with mains failure protection (device command [C00002](#) = "11: Save start parameters").



## 5.2 Select motor control


In [C00006](#) the motor control is selected; the default is the servo control for synchronous motors.

### Function extension from software version V3.0:

From software version V3.0, alternatively to the servo control also the V/f control and the sensorless vector control are provided as control types in [C00006](#):

Open/closed loop control	Detailed information
1 SC: Servo control for synchronous motor	▶ <a href="#">Servo control (SC)</a> (📖 151)
2 SC: Servo control for asynchronous motor	
4 SLVC: Sensorless vector control	▶ <a href="#">Sensorless vector control (SLVC)</a> (📖 172)
6 VFCplus: V/f control open loop	▶ <a href="#">V/f control (VFCplus)</a> (📖 190)
7 VFCplus: V/f control closed loop	▶ <a href="#">V/f control (VFCplus)</a> (📖 206)

- ▶ The V/f control is the classic operating mode for standard applications.
- ▶ Compared to the V/f control, improved drive characteristics can be achieved with sensorless vector control by:
  - a higher torque across the entire speed range
  - a higher speed accuracy and a higher concentricity factor
  - Higher efficiency



[5-1] Comparison of V/f control and sensorless vector control



### Note!

Sensorless vector control (SLVC) is only approved for powers up to 55 kW and horizontal applications (no hoists or lifting equipment)!

# 9400 HighLine | Parameter setting & configuration

Motor interface

Select motor control

For the V/f control and sensorless vector control the following table helps with the selection of the correct control type:

	Selection of the motor control in <a href="#">C00006</a>			
	Motor cable shielded ≤ 50 m unshielded ≤ 100 m		Motor cable shielded > 50 m unshielded > 100 m	
	recommended	optional	recommended	optional
<b>Single drives</b>				
With motor filter	6 / 7	-	6 / 7	-
With constant load	4	6 / 7	6 / 7	-
With extremely alternating loads	4	6 / 7	6 / 7	-
With high starting duty	4	6 / 7	6 / 7	-
Positioning and infeed drives	4	6 / 7	6 / 7	-
Winders/unwinders dancer	6 / 7	-	6 / 7	-
Pump and fan drives *	6 / 7	-	6 / 7	-
Three-phase reluctance motors	6 / 7	-	6 / 7	-
Three-phase sliding rotor motors	6 / 7	-	6 / 7	-
Three-phase AC motors with firmly assigned voltage/frequency characteristic	6 / 7	-	6 / 7	-
Vertical drive/hoist (up to 55 kW)	6 / 7 (with VCC**)	-	6 / 7 (with VCC**)	-

\* For this application, we recommend a square-law voltage characteristic ([C00950](#) = "1")

\*\* VCC = [voltage vector control](#)

### Group drives

Depending on the resulting motor cable length:

$$I_{res} = \sqrt{i} \cdot (I_1 + I_2 + \dots + I_i)$$

Identical motors and loads	4	6 / 7	6 / 7	-
Different motors and/or alternating loads	6 / 7	-	6 / 7	-



### Note!

For operation with motor encoder, we recommend to use the servo control!

For operation with motor filter, always use the V/f control!

#### 5.3 Adjusting motor and controller to each other

This "initial commissioning" of the motor is required if no motor data suitable for the application is available yet in the memory module of the controller and in the »Engineer« project.

- ▶ The following step-by-step instructions can be used as a "check list" to correctly adjust the motor and controller to each other.
- ▶ Detailed information on the individual steps can be found in the following subchapters.

Worksteps	Motor control*		
	SC	SLVC	VFC plus
1. <a href="#">Accepting/adapting plant parameters.</a> (📖 132)	●	●	●
2. <a href="#">Parameterise motor encoder.</a> (📖 134) <ul style="list-style-type: none"> <li>• Only required for the control types with speed feedback (servo control and V/f control).</li> </ul>	●		(●)
3. <a href="#">Pole position identification.</a> (📖 136) <ul style="list-style-type: none"> <li>• Only required:                             <ul style="list-style-type: none"> <li>– For servo control with synchronous motor of a third-party manufacturer.</li> <li>– For servo control with synchronous motor and use of incremental encoders (TTL or sin/cos encoders as well as multi-pole-pair resolvers).</li> <li>– After changes of the motor feedback system, e.g. encoder exchange.</li> </ul> </li> </ul>	(●)		
4. <a href="#">Optimising the switching performance of the inverter.</a> (📖 143) <ul style="list-style-type: none"> <li>• Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer!</li> <li>• Always required for sensorless vector control and open loop V/f control!                             <ul style="list-style-type: none"> <li>– An optimum drive performance can only be achieved with the sensorless operating modes if the voltage errors in the inverter are compensated as exactly as possible.</li> </ul> </li> </ul>	(●)	●	●
5. <a href="#">Determining the motor parameters.</a> (📖 146) <ul style="list-style-type: none"> <li>• Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer!</li> <li>• Always required for sensorless vector control!                             <ul style="list-style-type: none"> <li>– An optimum drive performance can only be achieved with the sensorless vector control if the motor parameters correspond to the real motor as exactly as possible.</li> </ul> </li> </ul>	(●)	●	

\* SC = servo control    SLVC = sensorless vector control    VFCplus = V/f control

#### 5.3.1 Accepting/adapting plant parameters

The "plant parameters" summarise all parameters which result from the combination of motor and load. These characterise the transfer behaviour of the entire controlled system including the required monitoring modes.

- ▶ The plant parameters depend on the application in which the controller and motor are used.
- ▶ If a Lenze motor is selected in the »Engineer«, the plant parameters for no-load operation will be suggested for this motor.

#### Overview of plant parameters

Parameter	Information	Lenze setting		Motor control*		
		Value	Unit	SC	SLVC	VFC plus
<a href="#">C00011</a>	Motor reference speed	3000	rpm	●	●	●
<a href="#">C00022</a>	Maximum current	0.00	A	●	●	●
<a href="#">C00070</a>	Speed controller gain	0.500	Nm/rpm	●	●	● <sup>1</sup>
<a href="#">C00071</a>	Speed controller reset time	24.0	ms	●	●	● <sup>1</sup>
<a href="#">C00072</a>	Speed controller rate time	0.00	ms	●		
<a href="#">C00497</a>	Speed act. val. time const.	2.0	ms	●	●	●
<a href="#">C00596</a>	Threshold max. speed reached	6500	rpm	●	●	●

\* SC = servo control    SLVC = sensorless vector control    VFCplus = V/f control open loop    <sup>1</sup> Only for V/f control closed loop



#### Note!

If plant data have been adapted offline in the »Engineer«, all plant data have to be transferred to the control afterwards when an online connection has been established and have to be saved in the memory module with mains failure protection (device command [C00002](#) = "11: Save start parameters").

### Motor reference speed

In [C00011](#) the reference speed of the motor must be set.



#### Note!

From the perspective of the application it has to be ensured that a maximum of 100 % of the reference speed set in [C00011](#) is requested as speed setpoint.

#### When using MCS motors, please observe the following:

The controller with software version V01.xx does not support a field weakening control for synchronous motors, so that for this version the operation of MCS motors at the voltage limit may present an undefined behaviour.

Therefore, it should be detected whether the motor used exceeds the voltage limit within the desired operating range up to the maximum current/reference speed. If so, the reference speed must be reduced to a value permissible with regard to voltage.

### Maximum current

In [C00022](#) the required maximum current must be set.

- ▶ To avoid that the motor starts unintentionally without adjusting the plant data, the maximum current in the Lenze setting is set to "0 A" in [C00022](#).

### Ultimate motor current $I_{ULT}$

[C00620](#) serves to check the set ultimate motor current  $I_{ULT}$ .



#### Note!

When you select a Lenze motor from the catalogue and transfer the plant parameters of the motor to the controller, the setting in [C00620](#) is automatically adjusted to the selected motor.

The ultimate motor current  $I_{ULT}$  is a limit value to protect the motor from destruction or influence of the rated data.

- ▶ This limit value must not be travelled cyclically during the drive process.
- ▶ The maximum current parameterisable in [C00022](#) should have a sufficient distance from this limit value.
- ▶ If the instantaneous value of the motor current exceeds the limit value set in [C00620](#), the response set in [C00619](#) is executed for motor protection (Lenze setting: Fault).

### Maximum motor speed

Adapt the maximum motor speed in [C00596](#) and select the error response required when this speed limit has been reached in [C00607](#).

#### 5.3.2 Parameterise motor encoder



#### Note!

Only required for servo control and closed loop V/f control!



#### Tip!

Detailed information on the encoder evaluation and on the use of a separate position encoder can be found in the following main chapter "[Encoder evaluation](#)".  
([book 241](#))

- ▶ The motor encoder can be parameterised on the **Application parameters** tab of the »Engineer« in the *Overview* → *Motor* → *Encoder* dialog level.
- ▶ The following table shows the required settings for different encoder types:

Encoder type:	Resolver Tamagawa	CDD50	ITD21	ITD22	SEK... SEL...	SKS... SKM...	SCS70 SCM70	SRS50 SRM50	ECN1313 EQN1325	EQ1329
Motor type:	MCS MCA MDxKS MDXMA	MCA	MDFQA LMR	MDFQA LMR			MDxKS	MCS MCA	MCS MCA	MCS MCA
<a href="#">C00495</a> Motor encoder selection	0 Resolver									1 Encoder
<a href="#">C00080</a> Resolver - number of pole pairs	1	-	-	-	-	-	-	-	-	-
<a href="#">C00422</a> Encoder type	-	0 Incremental encoder (TTL signal)	1 Sin/cos encoder	2 Absolute value encoder (Hiperface)			3 Absolute value encoder (EnDat)			
<a href="#">C00420</a> Encoder - number of increments	-	2048		16	128	512	1024	2048	32	
<a href="#">C00421</a> Encoder voltage	-	5 V		8 V			5 V			



#### Danger!

If the encoder/resolver is used as motor encoder:  
In case of error, safe operation of the motor is no longer guaranteed!

When servo control is used:

- For the (open circuit) monitoring of the encoder/resolver for reasons of safety always the "Fault" response (Lenze setting) should be set!

When V/f control is used:

- For this type of motor control, the drive basically is to coast down after an encoder failure and may not stop, therefore the "Warning" response is to be set for the (open circuit) monitoring in this case!

## Short overview: Parameters for setting the response to (open circuit) monitoring

Parameter	Information	Lenze setting
<a href="#">C00580</a>	Resp. to encoder open circuit	Fault
<a href="#">C00586</a>	Resp. to resolver open circuit	Fault
<a href="#">C00601</a>	Resp. to encoder comm. error	Fault

#### 5.3.3 Pole position identification



#### Note!

Only required:

- For servo control with synchronous motor of a third-party manufacturer.
- For servo control with synchronous motor and use of incremental encoders (TTL or sin/cos encoders as well as multi-pole-pair resolvers).
- After changes of the motor feedback system, e.g. encoder exchange.

For the control of permanent-magnet synchronous machines, the pole position – the angle between the motor phase U and the field axis of the rotor – must be known.

- ▶ For Lenze motors with absolute value encoder or resolver, the pole position is already set correctly in [C00058/1...3](#).
- ▶ When incremental encoders (TTL or sin/cos encoders) are used, a pole position identification (PPI) is always required after mains switching, even with Lenze motors.
- ▶ The controller can also evaluate multi-pole-pair resolvers.
  - When the number of motor pole pairs is an integer multiple of the number of pole pairs of the resolver, a pole position identification must only be executed once.
  - When the number of motor pole pairs is no integer multiple of the number of pole pairs of the resolver, a pole position identification must be executed after every mains switching.
- ▶ The device commands "Identify pole position (360°)" and "Identify pole position (min. motion)" serve to determine the pole position for the motor encoder currently activated in [C00495](#) (see the following instructions).



#### Danger!

The machine must not be braked or blocked during the pole position identification! For this reason, the pole position identification is not permitted for hanging loads!

During the pole position identification the rotor aligns itself. The motor shaft moves by max. one electrical revolution which causes the corresponding movement of the connected mechanical components!



#### Stop!

Check the correct parameterisation of the max. motor current monitoring ([C00619](#) and [C00620](#)) before carrying out the pole position identification to prevent the motor from being permanently damaged.



**Note!**

From software version V4.0 onwards:

If the pole position identification is aborted, the response parameterised in [C00640](#) is activated (Lenze setting: "Fault").

- Pay attention to this changed behaviour in the Lenze setting when updating the firmware of existing systems!
- If this behaviour is not wanted, deactivate the monitoring by selecting "0: No response" in [C00640](#).

The pole position identification can be adjusted to the respective machine and the prevailing moments of inertia by means of parameters.

- In the Lenze setting of the parameters, the pole position identification remains the same as in software versions < V4.0.

► [Adjustment of the pole position identification](#) (📖 140)

**How to execute the pole position identification:**

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Execute device command [C00002](#) = "51: Identify pole position (360°)" or

device command [C00002](#) = "52: Identify pole position (min. motion)".

The procedure starts with controller enable, if

- a synchronous machine is selected,
- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated under [C00003](#).

**Note:**

By means of controller inhibit, the procedure started can be cancelled anytime, if required, without carrying out a change in [C00058](#).

For detailed information about the corresponding procedure, please see the following sections:

**Tip!**

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the device command activated under [C00002](#) is indicated under [C00003](#).

#### Procedure for "pole position identification 360°"

If all conditions are met, the motor is energised with a direct current corresponding to the lower of the following two values:

$$\sqrt{2} \cdot \text{Rated device current}$$

or

$$\sqrt{2} \cdot \text{Rated motor current}$$

- ▶ The rotor is aligned through the current flow. This is absolutely necessary for the procedure.
- ▶ To ensure that the torque-neutral axis is not accidentally energised and the rotor stops, a 45° current vector is (electrically) generated for a short instant and then (electrically) switched back to 0° (≡ phase U).
  - Then a DC current of the above-mentioned value could be measured in this motor phase.

The next steps of the procedure depend on the feedback system used:

- ▶ If an absolute value encoder with Hiperface or EnDat protocol is used, the encoder position is set to zero and the procedure is cancelled.
- ▶ If a resolver or an optical encoder without absolute track is used, the difference between the preselected current angle and the mechanical rotor angle is determined. After this, the current vector is (electrically) turned by another 22.5° and the difference between current angle and rotor angle is determined once again.
  - The procedure is repeated 16 times. This corresponds to one electrical revolution. The machine rotates by 360° (mech.)/pole pair number.
  - Take the average value of the 16 measurements to compensate for asymmetries.

#### Procedure for "pole position identification with minimal movement"

If all conditions are met, the motor current is increased step by step to the smaller of the following two values:

$$25 \% \cdot \sqrt{2} \cdot \text{Rated device current}$$

or

$$25 \% \cdot \sqrt{2} \cdot \text{Rated motor current}$$

- ▶ By the current flow the rotor aligns itself, which, however, is compensated by a position control.
- ▶ If the rotor moves electrically by more than 20°, a fault message is output and the value measured is rejected. This may occur in the case of motors with a noticeable detent torque.
- ▶ In order to detect a non-permissible blocking of the machine, a positive and negative test angle ( $\pm 20^\circ$ ) relative to the current position are defined after the identification. The machine must align itself to these two test angles within a tolerance of 25 %.



## Note!

In this procedure it is not written back into an optical absolute value encoder and all feedback systems are treated the same way.

Unlike in the "pole position identification 360°" procedure where, when an optical absolute value encoder is used, a "0" is entered into the encoder and into [C00058/2](#), for this procedure nothing needs to be entered into the encoder and the identification result is entered into [C00058/2](#).

### After successful completion...

...the controller is inhibited automatically and the pole position determined for the activated feedback system is set in the corresponding subcode of [C00058](#).

- ▶ For a permanent acceptance of the identified pole position, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- ▶ The next controller inhibit and subsequent controller enable serve to cancel the controller inhibit automatically set by the procedure (e.g. by first executing the device command [C00002](#) = "41: Inhibit controller" and then executing the device command [C00002](#) = "42: Enable controller").

### If an error occurs

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit without making a change in [C00058](#).

If the machine was braked or blocked during the procedure, this will be recognised at the end of the measurement and no change is made in [C00058](#).

From software version V4.0 onwards, the response parameterised in [C00640](#) (Lenze setting: "Fault") is triggered and the error message "Pole position identification cancelled" is entered in the logbook of the controller if the pole position identification process is aborted.



### Tip!

From software version V7.0 onwards, the pole position identification is additionally available as a basic function in the form of the [LS PolePositionIdentification](#) system block.

Basic drive functions: ▶ [Pole position identification](#) (📖 581)

#### 5.3.3.1 Adjustment of the pole position identification

This function extension is available from software version V4.0!

The two procedures for [Pole position identification](#) (PPI) described in the previous sections can be adjusted to the respective machine and the prevailing moments of inertia by means of the parameters described below.

In the Lenze setting of the parameters, the pole position identification remains the same as in software versions < V4.0.



#### Note!

The two procedures for the pole position identification should give the same results. But, due to e.g. friction, bearing forces and a trapezoidal field pattern, the results may differ. A proportional increase of the current amplitude in [C00641](#) or [C00646](#) can counteract this deviation.

#### Parameters for the pole position identification 360°

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00641</a>	PolePosId 360° current amp.	100	%
<a href="#">C00642</a>	PolePosId 360° ramp time	100	%
<a href="#">C00643</a>	PolePosId 360° travel dir.	Clockwise rotating field	
<a href="#">C00644</a>	PolePosId 360° fault tol.	0	°

- ▶ The current amplitude can be adjusted proportionally in [C00641](#).
  - For large machines and high mass inertia values or for linear direct drives, the current amplitude usually has to be increased.
  - The Lenze setting "100 %" corresponds to the smaller of the two following values:

$$\sqrt{2} \cdot \text{Rated device current}$$

or

$$\sqrt{2} \cdot \text{Rated motor current}$$



#### Stop!

If there is no temperature monitoring in the motor and/or the  $I^2xt$  motor monitoring and the maximum current monitoring are not parameterised correctly, the motor may be permanently damaged when the current amplitude is set too high (e.g. to the maximum value)!

- ▶ [Motor monitoring \( \$I^2xt\$ \)](#) (☞ 224)
- ▶ [Maximum current monitoring](#) (☞ 235)



## Note!

If the current amplitude is set to 100 % in [C00641](#) >, the device utilisation (lxt) monitoring and/or one of the motor monitoring functions may respond and cause the abort of the pole position identification.

- ▶ The ramp time can be adjusted proportionally in [C00642](#).
  - For large machines and high mass inertia values, the ramp time usually has to be increased.
  - For small machines, a reduction of the ramp time can speed up the pole position identification process.
- ▶ In some situations it may be helpful to reverse the travel direction ([C00643](#)) for the pole position identification (e.g. for linear motor at the end stop).
- ▶ The "pole position identification 360°" procedure comprises a plausibility check. If the rotor position determined via the encoder system does not correspond to the controlled output position:
  - the pole position identification procedure is aborted.
  - the response parameterised in [C00640](#) (Lenze setting: "Fault") is activated.
  - the error message "Pole position identification cancelled" is entered into the logbook of the controller.
- ▶ The preset fault tolerance for the plausibility check can be changed via [C00644](#).

## Parameters for the pole position identification with minimal movement

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00646</a>	PolePosId min.mov. cur. amp.	100	%
<a href="#">C00647</a>	PolePosId min.mov. cur.rise rate	100	%
<a href="#">C00648</a>	PolePosId min.mov. gain Vp	0	
<a href="#">C00649</a>	PolePosId min.mov. reset time Tn	62.5	ms
<a href="#">C00650</a>	PolePosId min.mov. max.perm.mov.	20	°

- ▶ The current amplitude can be adjusted proportionally in [C00646](#).
  - For large machines and high mass inertia values or for linear direct drives, the current amplitude usually has to be increased.
  - The Lenze setting "100 %" corresponds to the smaller of the two following values:

$$25 \% \cdot \sqrt{2} \cdot \text{Rated device current}$$

or

$$25 \% \cdot \sqrt{2} \cdot \text{Rated motor current}$$



#### Stop!

If there is no temperature monitoring in the motor and/or the I<sup>2</sup>xt motor monitoring and the maximum current monitoring are not parameterised correctly, the motor may be permanently damaged when the current amplitude is set too high (e.g. to the maximum value)!

▶ [Motor monitoring \(I<sup>2</sup>xt\)](#) (📖 224)

▶ [Maximum current monitoring](#) (📖 235)



#### Note!

If the current amplitude is set to 400 % in [C00646](#) >, the device utilisation (Ixt) monitoring and/or one of the motor monitoring functions may respond and cause the abort of the pole position identification.

- ▶ The rate of the current rise for the pole position identification can be adjusted proportionally in [C00647](#). The Lenze setting "100 %" corresponds to the fixed rise rate setting of the software versions < V4.0.
- ▶ The P component of the PI controller for the pole position identification can be adjusted in [C00648](#). With the Lenze setting "0", the PI controller continues to work as an I controller (as in the previous software versions).
- ▶ The I component of the PI controller for the pole position identification can be adjusted in [C00649](#). Please observe the following notes:
  - The variable *Position.dnActualMotorPos* can be used to monitor the deviation of the position from the start position with the [Oscilloscope](#) function in the »Engineer«.
  - In order to be able to compensate a position deviation faster, first the reset time in [C00649](#) should be reduced. If this does not result in the desired behaviour, the proportional gain can be increased in [C00648](#).
  - Ensure that the position control does not get unstable. We therefore recommend to use an I controller.
- ▶ The pole position identification comprises a monitoring function for the follow-up control. If a movement greater than the permissible movement set in [C00650](#) is detected by the encoder system:
  - the pole position identification procedure is aborted.
  - the response parameterised in [C00640](#) (Lenze setting: "Fault") is activated.
  - the error message "Pole position identification cancelled" is entered into the logbook of the controller.
- ▶ In order to detect a non-permissible blocking of the machine, a positive and negative test angle relative to the current position are defined after the identification. The machine must align itself to these two test angles within a tolerance of 25 %. The size of the test angle corresponds to the max. permissible movement set in [C00650](#).

### 5.3.4 Optimising the switching performance of the inverter



#### Note!

Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer!

Always required for sensorless vector control and open loop V/f control!

- An optimum drive performance can only be achieved with the sensorless operating modes if the voltage errors in the inverter are compensated as exactly as possible.

An inverter generates a pulse-width-modulated, three-phase voltage system. Due to the design of the inverter, current-dependent and switching frequency-dependent losses inside of the inverter falsify the voltage that is output. As the voltage that is output is not measured, the losses have to be compensated by a suitable feedforward control. This compensation is based on an inverter error characteristic.

Among other things, the inverter error characteristic depends on the length of the motor cable and at least has to be individually determined once for the connected motor by means of the device command "Calculate inv. characteristic". For an automatic determination of the motor parameters, this ensures that the current has a sinusoidal form.



#### Danger!

This procedure may only be carried out during commissioning, not during operation!

- During the procedure the motor is energised so that:
  - it cannot be excluded that the connected mechanical components may move!
  - the windings heat up.  
If you repeat the procedure, ensure that the motor is not thermally overloaded (particularly if no temperature feedback is used).

**For software versions lower than V4.0 the following applies:**

- If the automatic brake operation is used, ensure that no basic function is requested or that the application is stopped before this procedure is called. Otherwise the applied holding brake could be released!
- For positioning applications you have to observe that the absolute position and the home position will get lost when this procedure is called. The loss of the home position is not signalled to the application. The following sequence has to be observed for positioning applications: 1.) Execute identification → 2.) Save parameter set → 3.) Restart controller → 4.) Execute homing procedure.



#### Note!

For devices of the types 6 + 7 the lxt monitoring may be activated during the inverter error characteristic is determined.

**Remedy:** Only start identification at a device utilisation ([C00066](#)) of 0 % and/or reduce rated motor current ([C00088](#)) and reset it to the original value after the identification.



#### How to determine the inverter error characteristic:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Execute device command [C00002](#) = "71: Calculate inv. error characteristic".

The procedure starts with controller enable, if

- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated under [C00003](#).

#### Note:

By means of controller inhibit, the started procedure can be cancelled anytime, if required. Characteristic values that have already been determined in this case are rejected.

For detailed information about the procedure, please see the following section "Sequence".



#### Tip!

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the device command activated under [C00002](#) is indicated under [C00003](#).



## Sequence

If all conditions are met, the motor is energised with a maximum direct current corresponding to the lower of the following two values:

$$\begin{aligned} & \sqrt{2} \cdot \text{Rated device current} \\ & \text{or} \\ & \sqrt{2} \cdot 1.8 \cdot \text{Rated motor current} \end{aligned}$$

- ▶ Ideally, the first value should be reached, the second value is to ensure that the load on the machine is not too high during this test.

During the procedure, the motor current rises up to the specified maximum value and falls back to "0" to repeat the cycle with a negative current sign.

- ▶ The maximum value is reached four times.
- ▶ The switching frequency is set to rated switching frequency and after the procedure, it is reset to the original value.
  - If the switching frequency should be changed later during operation, the characteristic will be adapted to the current switching frequency.

## After successful completion...

...the controller is inhibited automatically and the detected characteristic is set in the controller.

- ▶ For a permanent acceptance of the characteristic, the parameter set must be saved afterwards ([C00002](#) = "11: Save start parameters").
- ▶ With the device command [C00002](#) = "42: Enable controller" the controller inhibit set automatically during the procedure can be deactivated again.



### Tip!

The inverter error characteristic must only be detected again if the controller, motor, or motor cable has changed e.g. due to an exchange.

## If an error occurs

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit and the detected characteristic is not considered.



### Tip!

**From software version V4.0:** If it is not possible to determine the so-called "Inverter error characteristic", or if the results of the determination are incorrect, the device command [C00002](#) = "70: Load Lenze inverter characteristic" can be used to load a characteristic typical for the device. ▶ [Load Lenze inverter characteristic](#) (77)

#### 5.3.5 Determining the motor parameters



#### Note!

Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer!

Always required for sensorless vector control!

- An optimum drive performance can only be achieved with the sensorless vector control if the motor parameters correspond to the real motor as exactly as possible.

To control an electrical machine, the motor parameters must be known.

- ▶ The motor parameters for Lenze motors are known and are already set accordingly by selecting them from the »Engineer« motor catalogue or reading out the ENP.
- ▶ The device command "Determine motor parameters" is used to automatically determine the motor parameters for a third-party motor that are listed in the following table – if they are not known:

Parameter	Information	ASM	SM
<a href="#">C00079</a>	Mutual motor inductance	<input checked="" type="checkbox"/>	
<a href="#">C00082</a>	Motor rotor resistance	<input checked="" type="checkbox"/>	
<a href="#">C00084</a>	Motor stator resistance	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00085</a>	Motor stator leakage induct.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00091</a>	Motor - cosine phi	<input checked="" type="checkbox"/>	
<a href="#">C00092</a>	Motor magnetising current	<input checked="" type="checkbox"/>	



## Danger!

This procedure may only be carried out during commissioning, not during operation!

- During the procedure the motor is energised so that:
  - it cannot be excluded that the connected mechanical components may move!
  - the windings heat up.
 If you repeat the procedure, ensure that the motor is not thermally overloaded (particularly if no temperature feedback is used).

For software versions lower than V4.0 the following applies:

- If the automatic brake operation is used, ensure that no basic function is requested or that the application is stopped before this procedure is called. Otherwise the applied holding brake could be released!
- For positioning applications you have to observe that the absolute position and the home position will get lost when this procedure is called. The loss of the home position is not signalled to the application. The following sequence has to be observed for positioning applications: 1.) Execute identification → 2.) Save parameter set → 3.) Restart controller → 4.) Execute homing procedure.

## Requirements

- ▶ For the automatic determination of the motor parameters it is required that first the switching performance of the inverter has been optimised successfully, to ensure that the current has a sinusoidal form. ▶ [Optimising the switching performance of the inverter](#) (143)
- ▶ The motor parameters listed in the following table are excluded from the automatic determination and must be adapted to the motor used (see motor nameplate) before the determination.

Parameter	Information
<a href="#">C00081</a>	Rated motor power
<a href="#">C00084</a>	Motor stator resistance (Default setting is used as starting value for the automatic determination.)
<a href="#">C00087</a>	Rated motor speed
<a href="#">C00088</a>	Rated motor current (The current amount for the procedure is derived from this specification)
<a href="#">C00089</a>	Rated motor frequency
<a href="#">C00090</a>	Rated motor voltage



#### Note!

For devices of the types 9 + 10 (from 132 kW) the automatic determination of the motor parameters may fail and a corresponding status display is output.

**Remedy:** Parameterise the motor parameters manually by means of the manufacturer's data sheet.



#### How to determine the motor parameters:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Execute device command [C00002](#) = "72: Determine motor parameters".

The procedure starts with controller enable, if

- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated under [C00003](#).

#### Note:

By means of controller inhibit, the started procedure can be cancelled anytime, if required, without altering the codes for the motor parameters.

For detailed information about the procedure, please see the following section "Sequence".



#### Tip!

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the device command activated under [C00002](#) is indicated under [C00003](#).

## Sequence

If all conditions are met, the impedance of the controlled system is determined for approx. 30 different frequencies. These values are used to determine the electrical machine parameters by means of a mathematical procedure.

- ▶ Since the procedure starts with very low frequencies and always considers several complete periods, the whole process takes approx. 3 minutes.
- ▶ During the procedure, the motor is energised with a current, the r.m.s. value of which corresponds to the lower of the following two values:

$$\begin{array}{c} \text{Rated device current} \\ \text{or} \\ \frac{1}{2} \cdot \text{Rated motor current} \end{array}$$

After the parameters have been extracted from the impedance, they are checked for consistency with the required rated values. If an inconsistent parameter set is detected, is this an indication of faulty rated values on the nameplate.



### Note!

During the procedure, the motor should not rotate.

With synchronous machines, this cannot always be ensured. Although the current flow is produced in the torque-neutral axis, asymmetries in the machine lead to a rotation of the rotor.

- In such a case, the measurement would be useless and would have to be repeated.
- As a remedy, we recommend to use a holding brake.

With asynchronous machines, slight rotations might possibly occur. Their influence on the measurements is, however, not worth mentioning.

- In case of uncertainties, the measurement should be repeated several times to check if the results for the stator resistance, the leakage inductance of the stator and the rotor resistance differ widely. This should not be the case.
- The magnetising inductance and the  $\cos(\varphi)$  values are not that important for the diagnostics, because they are strongly non-linear.

## After successful completion...

...controller inhibit is set automatically and the motor data determined are set in the corresponding codes.


- ▶ For a permanent acceptance of the settings, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- ▶ With the device command [C00002](#) = "42: Enable controller" the controller inhibit set automatically during the procedure can be deactivated again.

#### If an error occurs

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit without changing the codes for the motor parameters.

#### Display and manual adjustment of motor data

In the »Engineer« you can have an equivalent circuit diagram with the motor parameters displayed by clicking on the **Further motor data...** button on the **Application parameters** in the dialog level *Overview*→*Motor*→*Motor*:



- ▶ The representation of the equivalent circuit diagram depends on the motor control selected ([C00006](#)).
- ▶ The motor stator resistance ([C00084](#)) and motor stator leakage inductance ([C00085](#)) can be altered directly via the input fields in the equivalent circuit diagram.
- ▶ The motor magnetising current ([C00092](#)) is displayed as comparison value to the motor current ([C00054](#)).
  - The motor magnetising current must especially be observed in case of a no-load operation, both at standstill and with rated speed.
  - The motor magnetising current is directly calculated from the rated motor current ([C00088](#)) and the motor power factor ([C00091](#)).
- ▶ The mutual motor inductance can be indirectly adapted via the parameter Lh adjustment ([C02861](#)) in the range of 50 ... 200 %. The mutual motor inductance evaluated in percent is shown in [C00079](#).
- ▶ The motor rotor resistance can be indirectly adapted via the parameter Rr adjustment ([C02860](#)) in the range of 50 ... 200 %. The motor rotor resistance evaluated in percent is shown in [C00082](#).

## 5.4 Servo control (SC)

In the Lenze setting the servo control for synchronous motors is selected in [C00006](#).

After the motor and controller are optimally adjusted to each other, no more basic settings are required for servo control.



### Tip!

How to optimise the control behaviour and adjust it to the concrete application is described in the chapter "[Optimise control mode](#)". (☞ 152)

From software version V2.0 the parameterisable additional function "[Field weakening for synchronous machines](#)" is provided for the servo control. (☞ 215)

## 5.4.1 Optimise control mode

The "optimisation steps" given in the following table serve to further optimise the control behaviour of the servo control and adjust it to the concrete application.

- Detailed information on the individual steps can be found in the following subchapters.

Optimisation steps	
1.	<a href="#">Optimise current controller.</a> (📖 153) <ul style="list-style-type: none"><li>The current controller should always be optimised if a motor of a third-party manufacturer with unknown motor data is used!</li></ul>
	Parameterise selected technology application in the »Engineer« and load it into the controller. <ul style="list-style-type: none"><li>See description for the corresponding technology application.</li><li>During operation (with setpoint selection) further steps can be carried out to optimise the motor control:</li></ul>
2.	<a href="#">Optimising the speed controller.</a> (📖 156) <ul style="list-style-type: none"><li>Via running a typical speed profile and recording the ramp response of the speed controller with the oscilloscope.</li></ul>
3.	If the speed controller optimisation did not achieve the intended result: <a href="#">Set current setpoint filter (band-stop filter).</a> (📖 159) <ul style="list-style-type: none"><li>In order to suppress or damp (mechanical) resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller which are switched off in the default setting but can be parameterised accordingly, if required.</li></ul>
	Then readjust the speed controller: <a href="#">Optimising the speed controller.</a> (📖 156)
4.	<a href="#">Optimising phase controller.</a> (📖 162) <ul style="list-style-type: none"><li>Via running a typical speed profile and recording the ramp response of the phase controller with the oscilloscope.</li></ul>
5.	<a href="#">Optimise response to setpoint changes.</a> (📖 163) <ul style="list-style-type: none"><li>Via running a typical speed profile and recording the inputs and outputs of the speed controller with the oscilloscope.</li></ul>
6.	<a href="#">Setting the field weakening for asynchronous machines.</a> (📖 165) <ul style="list-style-type: none"><li>By means of traversing a speed profile <math>0 \leftrightarrow n_{\max}</math> and recording the speed, flow, and D-current setpoints/ actual values with the oscilloscope.</li></ul>
7.	Save »Engineer« project.



### Tip!

To run a typical speed profile for optimising the motor control, you can also use the basic function "manual jog" with suitably adapted manual jog parameters if this basic function is supported by the technology application selected. ► [Manual jog](#) (📖 398)



## 5.4.1.1 Optimise current controller

**Note!**

The current controller should always be optimised if a motor of a third-party manufacturer with unknown motor data is used!

An optimisation of the current controller is useful, as the two controller parameters gain ([C00075](#)) and reset time ([C00076](#)) depend on the maximum current required and the switching frequency set.

For this purpose, the controller parameters only need to be adapted once at a fixed switching frequency.

We recommend to select a switching frequency

- ▶ as low as possible if the controller is to be operated frequently at the maximum current limit.
- ▶ of 8 kHz (up to and including model 7) or 4 kHz (from model 8 onwards) if the maximum current limit will not be reached or will only be reached rarely.

The controller parameters are then automatically adapted to the other switching frequencies.

In a test mode you can select current setpoint step-changes and optimise the setting of both control parameters by evaluating the step responses.

- ▶ The starting values for gain and reset time can be calculated with the following formula:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$


$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$



## How to optimise the current controller in the test mode:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Set a fixed switching frequency using [C00018](#). Observe the above mentioned recommendations.
3. Activate one of the two following optimisation modes for the current controller:
  - [C00398](#) = "3: Current controller optimisation mode":  
After controller enable, the motor is supplied with current as long as the controller is enabled.
  - From software version V7.0:  
[C00398](#) = "4: Current controller optimisation mode pulse":  
The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
4. Select the effective value of the current setpoint step change under [C00022](#).
  - The peak value of the measurable motor current will be 1.41 times higher.
5. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in the »Engineer«. ([□ 590](#))
  - Variable of the motor control to be recorded:  
*Current.dnActualDirectCurrent* (field-oriented direct-axis current)

6. Evaluate the step response:



7. Change the gain  $V_p$  under [C00075](#) and the reset time  $T_n$  under [C00076](#).

8. Repeat steps 4 ... 6 until the optimum step response of the motor current is reached.

- In the optimised state the current rise time typically is 0.5 ... 1 ms.
- If the adjustment results are not satisfactory, the decoupling network can be additionally activated via the setting [C00074](#) = "1". After this, repeat the steps 2 ... 6.
- In case of MCS, satisfying results may only be achieved with a current-dependent correction of the current controller parameters based on the saturation behaviour of the motor stator leakage inductance. For this purpose, it is required to use a motor with an electronic nameplate (ENP) or to set the saturation characteristic manually. ▶ [Correction of the stator leakage inductance...](#) (📖 210)

9. After the optimisation has been completed, deactivate the test mode again ([C00398](#) = "0: Test mode deactivated").

10. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.4.1.2 Optimising the speed controller

The speed controller is designed as PID controller.

### Gain setting

The proportional gain  $V_p$  is selected under [C00070](#):

1. Select the speed setpoint.
2. Increase C00070 until the drive becomes unstable (observe motor noises).
3. Reduce C00070 until the drive becomes stable again.
4. Reduce C00070 to approx. half the value.

### Reset time setting

The reset time is selected under [C00071](#):

1. Reduce C00071 until the drive becomes unstable (observe motor noises).
2. Increase C00071 until the drive is stable again.
3. Increase C00071 to approx. double the value.

### Rate time setting

The rate time  $T_d$  is selected under [C00072](#):

- ▶ Increase C00072 during operation until an optimum control behaviour is reached.

## Using the ramp response for setting the speed controller

When operation of the mechanics at the stability limit is not possible, the ramp response can be used to set the speed controller. The proceeding is similar to optimising the current controller.



### Stop!


If the controller parameters are preset unfavourably, the control can tend to heavy overshoots up to instability!

- Following and speed errors can adopt very high values.
- For sensitive mechanical systems, the corresponding monitoring systems have to be activated.



### How to optimise the speed controller setting by means of the ramp response:

1. Run a typical speed profile and record the ramp response of the speed with the [Oscilloscope](#). (□ 590)
  - Motor control variables to be recorded:  
*Speed.dnSpeedSetpoint* (speed setpoint)  
*Speed.dnActualMotorSpeed* (actual speed value)
2. Evaluate the ramp response:



- Solid line = ramp response (actual speed value)
- Dash line = speed setpoint

3. Change the gain  $V_p$  under [C00070](#) and the reset time  $T_n$  under [C00071](#).
4. Repeat steps 1 ... 3 until the optimum ramp response is reached.
5. Save parameter set ([C00002](#) = "11").

## Setting of actual speed filter

In order to maximise the dynamics of the speed control loop, the actual speed filter should be operated with a time constant as low as possible ([C00497](#)). The lower the time constant the higher the gain of the speed controller. Since actual value filters have the task to dampen measuring errors or interference components, it must be found a compromise between filter task and the resulting delay.

If a Lenze motor is selected from the motor catalogue, a time constant is automatically preset in [C00497](#) which serves to operate the motor even with a faulty detection (e.g. in case of a bad shield connection).

When using EMC-compliant systems or high-quality encoders, you can reduce the preset time constant considerably. For this purpose, the running noise of the motor can be used for setting [C00497](#) at constant speed.

If this is not possible, e.g. due to a too loud environment or because the motor is too far away, the noise of the actual speed value or the setpoint torque value can be used for evaluation by means of the [Oscilloscope](#). Please observe that the speed controller gain  $V_p$  ([C00070](#)) is used for the torque setpoint.

## Dynamics of the actual value detection

Another element which influences the maximally achievable control dynamics, is the dynamics of the actual value detection itself. In case of optical encoders, the time delay by the actual value detection does not need to be considered. This does not apply to resolvers.

The resolver evaluation of the controller is adapted to the resolver types mounted in Lenze motors and offers a good compromise between the dynamic performance and interference suppression. If the resolver is used as a speed feedback system, the dynamic performance of the resolver evaluation determines, among other things, the maximum speed controller gain by means of which stable operation is possible.


From software version V5.0 onwards, it is possible to increase the dynamics of the resolver evaluation in [C00417](#) in an EMC-compliant system (with low interference) without a quality loss in the speed signal.

▶ [Adaptation of the resolver evaluation dynamics](#) (📖 252)

### 5.4.1.3 Set current setpoint filter (band-stop filter)

Due to the high dynamic performance or the high limit frequency of the closed current control loop, mechanical natural frequencies can be excited, which can result in resonance and thus cause the speed control loop to become unstable.

In order to suppress or damp these resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller, which need to be parameterised. In the Lenze setting, these filters are switched off:



[5-2] Optional current setpoint filters (filter cascade) in the speed control loop

### Overview of parameters for current setpoint filter

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00270/1</a>	Freq. - current setpoint filter 1	200.0	Hz
<a href="#">C00270/2</a>	Freq. - current setpoint filter 2	400.0	Hz
<a href="#">C00271/1</a>	Width current setp. filter 1	20.0	Hz
<a href="#">C00271/2</a>	Width current setp. filter 2	40.0	Hz
<a href="#">C00272/1</a>	Depth current setp. filter 1	0	DB
<a href="#">C00272/2</a>	Depth current setp. filter 2	0	DB

## Use of the current setpoint filters depending on the resonant frequency




### Stop!

If the filter parameters are set incorrectly, the impaired closed-loop control can respond with too large overshoots and cause the controller to become unstable, e.g. if the filter width is set to a value more than twice as large as the filter frequency.

After setting the filter parameters, the drive behaviour during stop and quick stop (QSP, Fail-QSP) must be checked. If impairments exist,

- the still running drive must either be coasted down by activating the controller inhibit or immediately be brought to a standstill via a brake.
- the speed controller must afterwards be optimised again.
- the test procedure must be repeated.



[5-3] Use of the current setpoint filter depending on the resonant frequency

- ▶ Resonant frequencies  $\geq f_{\text{limit\_SPEED}} = 70 \text{ Hz} \dots 110 \text{ Hz}$

This filter is suitable for use with resonant frequencies in the range around or above the limit frequency of the speed controller.

- ▶ Resonant frequencies  $< f_{\text{limit\_SPEED}}$

Please follow the Lenze recommendation and select suitable speed profiles, S-ramp or S-rounding, for avoiding resonances.

### Setting of the current setpoint filter

Since the frequency response of the speed controlled system is only rarely known to such an extent that the current setpoint filters can be adjusted to the controlled system in the run-up, the following example describes an experimental procedure for setting the current setpoint filters:



**How to set the current setpoint filters:**

1. Adjust the current control loop.
2. Go to [C00071](#) and adapt the reset time of the speed controller to the filter time constant of the speed filter ([C00497](#)) and the equivalent time constant of the current control loop:  $C00071 = 16 * (C00497 + 200 \mu s)$ 

**Note:** The setting of [C00071](#) incorporates the equivalent time constant of the current control loop. The indicated 200  $\mu s$  are typical in a power range of up to 20 kW. Beyond it, higher time constants may occur.
3. Slowly increase the proportional gain in [C00070](#) until the speed control loop starts to become unstable (acoustic determination or measuring of the motor current).
4. Measure the oscillation frequency using an oscilloscope (observe current or speed).
5. Set the measured oscillation frequency in [C00270/1](#) as filter frequency.
6. Set "50%" of the filter frequency in [C00271/1](#) as filter width.
  - Example: Filter frequency = 200 Hz → filter width = 100 Hz.
7. Set "40 dB" in [C00272/1](#) as filter depth.
  - If the filter depth is set to "0 dB" (default setting), the filter is not active.
8. Further increase the proportional gain in [C00070](#) until the speed control loop starts to become unstable again.
  - If the oscillation frequency has changed now, readjust the filter frequency by trimming. The use of a second filter is ineffective here.
  - If the oscillation frequency remains the same, readjust the filter depth and/or the filter width by trimming (the first reduces the amplitude, the second lets the phase rotate faster).
  - Repeat step 8 until the desired behaviour or the limit of a sensible speed controller gain has been reached.
9. Save parameter set ([C00002](#) = "11: Save start parameters").

**Note!**

Readjust the speed controller after setting the current setpoint filter.

► [Optimising the speed controller](#). (156)

## 5.4.1.4 Optimising phase controller




### How to optimise the phase controller setting by means of the ramp response:

1. Run a typical speed profile and record the ramp response of the phase controller with the [Oscilloscope](#). (📖 590)
  - Motor control variables to be recorded:
    - Speed.dnSpeedSetpoint* (speed setpoint)
    - Speed.dnActualMotorSpeed* (actual speed value)
    - Speed.dnOutputPosCtrl* (phase controller output)
    - Position.dnEncounteringError* (following error)
2. Adjust the gain  $V_p$  of the phase controller under [C00254](#) and repeat oscilloscope recording until the intended following error behaviour is reached and the motor runs sufficiently smoothly during the constant travel phase.
3. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.4.1.5 Optimise response to setpoint changes

Setting the load moment of inertia under [C00273/2](#) does not always provide the optimum torque feedforward control. Depending on the application, an adjustment of the setting under [C00273/2](#) may be necessary to optimise the response to position/speed setpoint changes by means of the torque feedforward control.



[5-4] Typical signal characteristics for different settings of the load moment of inertia

Apart from the load moment of inertia, effects can be compensated with [C00273/2](#), which in the closed speed control loop are identified by the speed controller. These for example include the friction torques.

Below you will find a description of a procedure for optimising the feedforward control behaviour starting from the system's moment of inertia.



## How to optimise the torque feedforward control:

1. Run a typical speed profile and record the inputs and outputs of the speed controller with the [Oscilloscope](#). (📖 590)
  - Motor control variables to be recorded:
    - Speed.dnSpeedSetpoint* (speed setpoint)
    - Speed.dnActualMotorSpeed* (actual speed value)
    - Torque.dnOutputSpeedCtrl* (speed controller output)
    - Torque.dnTotalTorqueAdd* (torque feedforward control)
  - Application variable to be recorded (if available):
    - L\_LdMonitFollowError1.dnFollowErrorIn\_p* (following error)

It is essential for optimising the response to setpoint changes to monitor the speed controller output (*Torque.dnOutputSpeedCtrl*) and the torque feedforward control (*Torque.dnTotalTorqueAdd*). The effect of the feedforward control can also be observed in the following error.

2. Select the signal source required for the torque setpoint (feedforward control path) under [C00276](#).
3. Estimate the load moment of inertia and set it under [C00273/2](#) with regard to the motor end (i.e. considering the gearbox factors).
4. Repeat the oscilloscope recording (see step 1).

Now the oscillogram should show that part of the required torque is generated by the feedforward control (*Torque.dnTotalTorqueAdd*) and the speed controller output signal (*Torque.dnOutputSpeedCtrl*) should be correspondingly smaller. The resulting following error decreases.

5. Change the setting under [C00273/2](#) and repeat the oscilloscope recording until the intended response to setpoint changes is reached.
  - The optimisation could aim at the speed controller being completely relieved (see signal characteristics in Fig. [\[5-4\]](#)).
6. Save parameter set ([C00002](#) = "11: Save start parameters").

#### 5.4.1.6 Setting the field weakening for asynchronous machines

For the following setting instructions it is assumed that the drive has been adjusted in the base speed range (inverter error characteristic, motor parameters, current controller, speed controller, current setpoint filter, angle controller, torque feedforward control) and is running satisfactorily to the rated motor speed.



##### How to set the field weakening for an asynchronous machine:

1. Set the desired maximum speed (with field weakening) in [C00011](#).
2. Carry out the following basic setting for the controller parameters for third-party motors:
  - Field controller gain ([C00077](#)) =  $1 / (2 * \text{C00082} * 500 \mu\text{s})$
  - Field controller reset time ([C00078](#)) = motor rotor time constant ([C00083](#))
  - Field weakening controller gain ([C00577](#)) = 0 [Vs/V]
  - Field weakening controller reset time ([C00578](#))  
=  $4 \text{ ms} / (0.3 \dots 1.0 * 60) * \text{C00059} * 2\pi * \text{C00011} [\text{rpm}] * \text{s}$   
(with factor 0.3 ... 1.0 for motor with rated power of 400 kW ... 0.4 kW)

##### Optimising the static behaviour in the field weakening range:

3. By means of speed ramp (acceleration time several seconds), slowly accelerate to the field weakening range up to maximum speed ([C00011](#)), and decelerate to speed 0 again and record the signal characteristic using the [Oscilloscope](#) (see example oscillogram [\[5-5\]](#)).
  - From the entry into the field weakening range, the flow setpoint (output of the field weakening controller) should decrease with  $1/n$ . Influences of the DC-bus voltage may be seen in the flow setpoint. The signal characteristic should preferably be "smooth".
  - From the entry into the field weakening range, the D-current setpoint (output of the field controller) should always decrease with  $1/n$ . In the signal characteristic no heavy vibrations may occur.

## Optimising the dynamic behaviour in the field weakening range:


4. Adapt the dynamic performance to the behaviour required for the machine application.
5. Repeat the recording of the speed characteristic and record the small signal range in the field weakening range ( $n_1 \leftrightarrow n_2$ ).
  - If the flow setpoint is adapted to the speed too slowly, increase the dynamic performance of the field weakening controller: reduce the reset time ([C00578](#)) in small steps, the gain ([C00577](#)) should remain set to 0 [Vs/V] for most machines.
  - If the flow setpoint in the field weakening range falls "too early" with  $1/n^2$  (stability limit of the machine reached), the leakage inductance of the motor ([C00085](#)) may be reduced a bit.
  - If the actual flow value follows the flow setpoint too slowly, increase the dynamic performance of the field controller: increase gain ([C00077](#)), reduce reset time ([C00078](#)).
  - If the actual D-current value does not correspond enough to the D-current setpoint, the dynamic performance of the current controller has to be adapted.
    - ▶ [Optimise current controller](#) (▣ 153)
  - If the motor speed does not feature the desired characteristic, the speed controller has to be readjusted with maximum speed in the field weakening range. ▶ [Optimising the speed controller](#) (▣ 156)

## Checking the motor parameters:

6. Carry out dynamic measurement in the range  $-n_{Max} \leftrightarrow +n_{Max}$  and record the motor speed using the [Oscilloscope](#).
  - The objective is a preferably linear speed characteristic.
  - In particular check the ranges around the rated motor speed and speed 0 and, if required, improve them by adjusting  $R_R$  ([C02860](#)) or  $L_H$  ([C02861](#))!


## Example oscillogram

Ch	Variable of the motor control	Unit	1/div	Offset	Position
1	Speed.dnActualMotorSpeed (current speed)	rpm	1k	0	-4
2	Voltage.dnActualMotorVoltage (current motor voltage)	V	100	0	-5
3	Torque.dnActualMotorTorque (current motor torque)	Nm	500m	0	0
4	Speed.dnSpeedSetpoint (speed setpoint)	rpm	1k	0	-4
5	Common.dnFluxSet (flux setpoint)	%	20	0	-5
6	Common.dnActualFlux (actual flux value)	%	20	0	-5
7	Current.dnDirectCurrentSet (D-current setpoint)	A	1	0	0
8	Current.dnActualDirectCurrent (actual D-current value)	A	1	0	0



[5-5] Example oscillogram

## 5.4.2 Signal flow (servo control for synchronous motor)



[5-6] Signal flow - servo control for synchronous motor

See also:

- ▶ [Signal flow - encoder evaluation](#) (📖 245)
- ▶ [Signal flow - speed follower](#) (📖 504)
- ▶ [Signal flow - torque follower](#) (📖 510)
- ▶ [Signal flow - position follower](#) (📖 497)




## Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (🔗 590)

No.	Variable of the motor control	Meaning
(1)	Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
(2)	Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter 2 input
(3)	Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
(4)	Current.dnQuadratureCurrentSet	Q current setpoint
(5)	Current.dnActualQuadratureCurrent	Actual Q current
(6)	Current.dnActualDirectCurrent	Actual D current
(7)	Current.dnDirectCurrentSet	D current setpoint
(8)	Voltage.dnOutputQuadratureCurrentCtrl	Q-output voltage of the current controller
(9)	Voltage.dnOutputDirectCurrentCtrl	D-output voltage of the current controller
(10)	Voltage.dnQuadratureVoltage	Q voltage
(11)	Voltage.dnDirectVoltage	D voltage
(12)	-	
(13)	-	
(14)	Voltage.dnActualMotorVoltage	Current motor voltage

## 5.4.3 Signal flow (servo control for asynchronous motor)



[5-7] Signal flow - servo control for asynchronous motor

- See also:
- ▶ [Signal flow - encoder evaluation](#) (📖 245)
  - ▶ [Signal flow - speed follower](#) (📖 504)
  - ▶ [Signal flow - torque follower](#) (📖 510)
  - ▶ [Signal flow - position follower](#) (📖 497)

## Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (🔗 590)

No.	Variable of the motor control	Meaning
(1)	Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
(2)	Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter 2 input
(3)	Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
(4)	Current.dnQuadratureCurrentSet	Q current setpoint
(5)	Current.dnActualQuadratureCurrent	Actual Q current
(6)	Current.dnActualDirectCurrent	Actual D current
(7)	Current.dnDirectCurrentSet	D current setpoint
(8)	Voltage.dnOutputQuadratureCurrentCtrl	Q-output voltage of the current controller
(9)	Voltage.dnOutputDirectCurrentCtrl	D-output voltage of the current controller
(10)	Voltage.dnQuadratureVoltage	Q voltage
(11)	Voltage.dnDirectVoltage	D voltage
(12)	Common.dnActualFlux	Actual flux value
(13)	Common.dnFluxSet	Flux setpoint
(14)	Voltage.dnActualMotorVoltage	Current motor voltage

## 5.5 Sensorless vector control (SLVC)

This function extension is available from software version V3.0!

If this motor control mode is set in [C00006](#), a considerably higher torque and a lower current consumption in idle state can be achieved compared to the V/f control mode.



### Note!

Observe the following application limits of the sensorless vector control:

- Only approved for power up to 55 kW and horizontal applications (no hoists or lifting equipment)
- For single drives only
- For asynchronous motors only
- Not suitable for operation in generator mode/braking operation (e. g. unwinders)




### Tip!

For vertical drives/hoists, use the servo control (with feedback), or the V/f control with activated voltage vector control (VVC), which supports vertical drives/hoists up to 55 kW.

## 5.5.1 Basic settings

After the motor and controller have been optimally adjusted to each other, the "initial commissioning steps" described in the following table are sufficient for a quick initial commissioning.

- Detailed information on the individual steps can be found in the following subchapters.

Initial commissioning steps	
1.	<a href="#">Parameterising speed and torque controller.</a> (📖 174)
2.	<p>Additional "flying restart" function:</p> <ul style="list-style-type: none"> <li>• In the Lenze setting, this parameterisable additional function is activated.</li> <li>• If the flying restart function is not required, deactivate this function. ► <a href="#">Flying restart function</a> (📖 218)</li> </ul> <p> <b>Only deactivate the flying restart if it is ensured that the drive is always at standstill in the case of controller enable!</b></p>
3.	<p>Additional "DC-injection braking" function:</p> <ul style="list-style-type: none"> <li>• In the Lenze setting, this parameterisable additional function is deactivated.</li> <li>• If DC-injection braking is required, activate this function. ► <a href="#">DC-injection braking</a> (📖 221)</li> </ul>

**Tip!**

A precise adjustment of the motor parameters for an improved concentricity factor and stability is described in the chapter "[Optimising motor parameters](#)". (📖 175)

How to optimise the control behaviour and adjust it to the concrete application is described in the chapter "[Optimise control mode](#)". (📖 181)

The parameterisable additional functions are described in the chapter of the same name "[Parameterisable additional functions](#)". (📖 209)

## 5.5.1.1 Parameterising speed and torque controller

### Short overview: Parameters for controller settings

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00070</a>	Speed controller gain	0.500	Nm/rpm
<a href="#">C00071</a>	Speed controller reset time	24.0	ms
<a href="#">C00987</a>	SLVC: Torque controller gain	0.5000	Hz/A
<a href="#">C00988</a>	SLVC: Torque controller reset time	10.00	ms

### Typical controller settings

The following table contains typical guide values concerning the setting of the speed and torque control for different device types/motor powers:

Device type E94ASx	Motor power (4-pole standard ASM)	Speed controller		Torque controller	
		Gain <a href="#">C00070</a> [Nm/rpm]	Reset time <a href="#">C00071</a> [ms]	Gain <a href="#">C00987</a> [Hz/A]	Reset time <a href="#">C00988</a> [ms]
E0024	0.37 kW	0.0122	50.00	5.0833	10.00
E0034	0.75 kW	0.0138	50.00	3.0500	10.00
E0044	1.50 kW	0.0264	50.00	1.9818	10.00
E0074	3.00 kW	0.0411	50.00	1.1077	10.00
E0134	5.50 kW	0.0674	50.00	0.5965	10.00
E0174	7.50 kW	0.1183	50.00	0.3303	10.00
E0244	11.00 kW	0.1183	50.00	0.3303	10.00
E0324	15.00 kW	0.2244	50.00	0.2368	10.00
E0474	22.00 kW	0.3442	50.00	0.1547	10.00
E0594	30.00 kW	1.1503	50.00	0.1232	10.00
E0864	45.00 kW	1.7400	50.00	0.0817	10.00
E1044	55.00 kW	2.1712	50.00	0.0661	10.00

[5-1] Typical controller settings

The gain for the field current controller ([C00985](#)) and the gain for the cross current controller ([C00986](#)) are initially set to "0.00".

### 5.5.2 Optimising motor parameters

Although the motor parameters have been determined before as described in the chapter "[Adjusting motor and controller to each other](#)", an additional optimisation may be required in the following cases using the adjustment processes described in this chapter:

- ▶ When the concentricity factor in the lowest speed range is to be improved.
- ▶ When the stability in the lower speed range is to be improved.
- ▶ When the rated torque is not reached in the rated point, i. e. at rated speed and rated current.
- ▶ When a too high magnetising current is injected in idle state.

#### General information on the motor parameter adjustment

The motor stator resistance can generally always be adjusted with a passive load since the motor is stopped when this parameter is set.

An optimisation of the mutual motor inductance, however, is only sensible when the motor rotates in the medium speed range. In the majority of cases, the no-load operation is sufficient for this adjustment. In contrast to the rated operation, the no-load operation is also possible for initial commissioning in many applications.

The motor rotor resistance can only be adjusted exactly if the current motor speed is available. Thus, for this adjustment only applications are considered where a speed measurement is possible, even with a manual tachometer. If, under operating conditions (e.g. at rated load), the motor consumes more than the rated motor current indicated, an adjustment can also be executed by reducing the mutual motor inductance.



#### Note!

To execute the adjustment processes described in the following subchapters, the controller must always be enabled!

## 5.5.2.1 Motor power factor

Together with the rated motor current, the motor power factor ([C00091](#)) defines the motor magnetising current ([C00092](#)) and thus the current consumption of the controller in idle state.



### Note!

The following adjustment of the motor power factor should be executed after the motor parameters have been determined and when the value set in [C00091](#) deviates more than 10 % from the data on the motor nameplate.

If the setting of the motor power factor in [C00091](#) is changed, the setting of the mutual motor inductance also changes in [C00079](#).

For the adjustment of the motor power factor, first the motor current in idle state at rated speed is determined in the control type "V/f control". Afterwards the motor power factor is set in the control type "Sensorless vector control" so that the motor magnetising current corresponds to the previously determined no-load current.



### How to adjust the motor power factor:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Select the control type VFCplus: V/f control" in [C00006](#).
3. Select setpoint speed 0 rpm
4. Enable controller.
5. Slowly increase setpoint speed to rated speed (no field weakening) and then keep it at rated speed constantly.
6. Take down the motor current displayed in [C00054](#).
7. Slowly reduce the setpoint speed to 0 rpm again.
8. Inhibit controller.
9. Go to [C00006](#) and select the "SLVC: Sensorless vector control" again.
10. Set Lh adjustment in [C02861](#) to 100 %.
11. Set the motor power factor ([C00091](#)) so that the following applies:  
motor magnetising current ([C00092](#))  $\approx$  motor current taken down before.
12. Save parameter set ([C00002](#) = "11: Save start parameters").



### 5.5.2.2 Motor stator resistance

For the adjustment of the motor stator resistance, first the motor current at standstill (without load of the motor) is compared to the motor magnetising current. Afterwards the setting of the motor stator resistance is changed step by step until the motor current stably reaches the motor magnetising current.



#### How to adjust the motor stator resistance:

1. Select setpoint speed 0 rpm or activate quick stop.
2. Enable controller.
3. Compare the motor current displayed in [C00054](#) with the motor magnetising current displayed in [C00092](#).
4. Inhibit controller.
5. If motor current > motor magnetising current:
  - Reduce the motor stator resistance stepwise in [C00084](#).If motor current < motor magnetising current:
  - Increase the motor stator resistance stepwise in [C00084](#).
6. Repeat steps 2 ... 5 until the following applies: Motor current  $\approx$  motor magnetising current.
7. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.5.2.3 Mutual motor inductance

### Adjustment at rated operation

This adjustment is executed at rated speed and a defined load (e.g. measuring brake) which serves to define the rated torque. A condition for the adjustment is to know the real load torque. The motor current is compared to the rated current. At rated load, these two values should be almost identical.

If an adjustment at rated operation is not possible, alternatively execute the adjustment at no-load operation (see the following section "Adjustment at no-load operation").



#### How to adjust the mutual motor inductance at rated operation:

1. Set the maximum current in [C00022](#) to 110 % of the rated motor current ([C00088](#)).
2. Select setpoint speed 0 rpm
3. Enable controller.
4. Slowly increase setpoint speed to rated speed (no field weakening) and then keep it at rated speed constantly.
5. Apply rated load to the motor.
6. Compare the motor current displayed in [C00054](#) with the rated motor current displayed in [C00088](#).
7. If motor current > rated motor current:
  - Reduce the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) until the following applies: motor current  $\approx$  rated motor current.
8. If motor current < rated motor current:
  - Increase the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) until the following applies: motor current  $\approx$  rated motor current.
8. Unload the motor again and slowly reduce the setpoint speed to 0 rpm again.
9. Inhibit controller.
10. Save parameter set ([C00002](#) = "11: Save start parameters").

**Adjustment at no-load operation**

If an adjustment at rated operation is not possible, alternatively execute the adjustment at no-load operation.

For the adjustment of the mutual motor inductance in no-load operation, first the motor current is compared to the motor magnetising current at a setpoint speed of approx. 75 % of the rated speed (without load of the motor). Afterwards the setting of the mutual motor inductance is changed step by step until the motor current just, but stably reaches the motor magnetising current.

**How to adjust the mutual motor inductance at no-load operation:**

1. Select setpoint speed 0 rpm
2. Enable controller.
3. Slowly increase the setpoint speed to approx. 75 % of the rated speed and keep this value constant.
  - If the controller oscillates, check the speed controller.
4. Compare the motor current displayed in [C00054](#) with the motor magnetising current displayed in [C00092](#).
5. If motor current > motor magnetising current:
  - Reduce the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) (based on 100 %) until the following applies:  
motor current < motor magnetising current
 If motor current << motor magnetising current:
  - Increase the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) (based on 100 %) until the following just applies:  
motor current < motor magnetising current
6. Slowly reduce the setpoint speed to 0 rpm again.
7. Inhibit controller.
8. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.5.2.4 Motor rotor resistance

This adjustment is carried out at a setpoint speed of approx. 75 % of the rated speed and with a defined load (e. g. measuring brake). The precondition for the adjustment is that the actual speed is known (e. g. by the use of a manual tachometer). At constant setpoint speed first the actual speed is measured while the machine is unloaded. Afterwards the motor is loaded at the same setpoint speed until the rated torque is reached (rated current). The speed measured should preferably correspond in idle state and at rated speed.



### How to adjust the motor rotor resistance:

1. Select setpoint speed 0 rpm
2. Enable controller.
3. Slowly increase the setpoint speed to approx. 75 % of the rated speed and keep this value constant.
4. Measure actual speed  $n_{Idle}$  (e.g. using a manual tachometer) and take it down.
5. Increase load of the motor until the motor current displayed in [C00054](#) corresponds to the rated current.
6. Measure actual speed  $n_{Load}$ .
7. If  $n_{Load} < n_{Idle}$ :
  - Reduce motor rotor resistance stepwise and indirectly via the  $R_r$  adjustment in [C02860](#) until the following applies:  $n_{Load} \approx n_{Idle}$ .
8. If  $n_{Load} > n_{Idle}$ :
  - Increase motor rotor resistance stepwise and indirectly via the  $R_r$  adjustment in [C02860](#) until the following applies:  $n_{Load} \approx n_{Idle}$ .
8. Unload the motor again and slowly reduce the setpoint speed to 0 rpm again.
9. Inhibit controller.
10. Save parameter set ([C00002](#) = "11: Save start parameters").

### 5.5.3 Optimise control mode

A manual optimisation of the controller settings may be required for very dynamic applications and in the field weakening range.



#### Note!

The processes for optimising the controller settings described in the following subchapters can only be executed while the drive is rotating and never when being at standstill!

For all optimisation processes the magnetisation phase has to be completed!

Based on the typical controller settings which are listed in the chapter "[Parameterising speed and torque controller](#)" in table [\[5-1\]](#), first the field feedforward control and the speed controller are optimised in the base speed range. Afterwards, the torque controller is optimised in the field weakening range.

For optimisation, a suitable speed ramp must be selected for the drive and the acceleration must be recorded, e.g. using the [Oscilloscope](#) function in the »Engineer«. ([□ 590](#))

#### Short overview: Parameters for controller settings


Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00070</a>	Speed controller gain	0.500	Nm/rpm
<a href="#">C00071</a>	Speed controller reset time	24.0	ms
<a href="#">C00985</a>	SLVC: Field controller gain	0.00	
<a href="#">C00986</a>	SLVC: Cross current controller gain	0.00	
<a href="#">C00987</a>	SLVC: Torque controller gain	0.5000	Hz/A
<a href="#">C00988</a>	SLVC: Torque controller reset time	10.00	ms

## 5.5.3.1 Optimising field feedforward control


To optimise the field feedforward control, the drive must be accelerated in the base speed range with slow setpoint ramps (e.g. acceleration time = 5 s) to speed values below the rated speed and then decelerated again.

- If the field current oscillates at the beginning of the acceleration and at the end of the deceleration (Current.dnActualDirectCurrent), these oscillations can be reduced by increasing the gain for the field current controller in [C00985](#).

Ch	Variable of the motor control	Unit	1/div	Offset	Position
1	Speed.dnSpeedSetpoint (speed setpoint)	rpm	0.2k	0	-4
2	Speed.dnActualMotorSpeed (current speed)	rpm	0.2k	0	-4
3	Current.dnActualDirectCurrent (actual field current)	A	10	0	0
4	Current.dnQuadratureCurrentSet (cross current setpoint)	A	10	0	0
5	Current.dnActualQuadratureCurrent (actual cross current)	A	10	0	0



[5-8] Oscillogram 1: speed ramp (motor 55 kw) – field controller gain = 0.00



[5-9] Oscillogram 2: speed ramp (motor 55 kw) – field controller gain = 2.00

## 5.5.3.2 Optimising the speed controller

To optimise the speed controller, the drive must be accelerated in the base speed range with slow setpoint ramps (e.g. acceleration time = 5 s) to speed values below the rated speed and then decelerated again.

### Gain optimisation

The proportional gain  $V_p$  is selected under [C00070](#):

1. Increase [C00070](#) until the drive oscillates slightly (see picture [\[5-10\]](#)).
2. Reduce [C00070](#) until the drive runs stable again (see picture [\[5-11\]](#)).
3. Reduce [C00070](#) to approx. half the value.

### Optimise the reset time

The reset time is selected under [C00071](#):


1. Reduce [C00071](#) until the drive oscillates slightly.
2. Increase [C00071](#) until the drive is stable again.
3. Increase [C00071](#) to approx. double the value.

# 9400 HighLine | Parameter setting & configuration


Motor interface

Sensorless vector control (SLVC)

Ch	Variable of the motor control	Unit	1/div	Offset	Position
1	Speed.dnSpeedSetpoint (speed setpoint)	rpm	0.2k	0	-4
2	Speed.dnActualMotorSpeed (current speed)	rpm	0.2k	0	-4
3	Current.dnActualDirectCurrent (actual field current)	A	10	0	0
4	Current.dnQuadratureCurrentSet (cross current setpoint)	A	10	0	0
5	Current.dnActualQuadratureCurrent (actual cross current)	A	10	0	0



[5-10] Oscillogram 1: speed ramp (motor 55 kw) – speed controller gain = 15.49



[5-11] Oscillogram 2: speed ramp (motor 55 kw) – speed controller gain = 7.49



### Setting of actual speed filter

In order to maximise the dynamics of the speed control loop, the actual speed filter should be operated with a time constant as low as possible ([C00497](#)). The lower the time constant the higher the gain of the speed controller. Since actual value filters have the task to dampen measuring errors or interference components, it must be found a compromise between filter task and the resulting delay.

If a Lenze motor is selected from the motor catalogue, a time constant is automatically preset in [C00497](#) which serves to operate the motor even with a faulty detection (e.g. in case of a bad shield connection).

When using EMC-compliant systems or high-quality encoders, you can reduce the preset time constant considerably. For this purpose, the running noise of the motor can be used for setting [C00497](#) at constant speed.

If this is not possible, e.g. due to a too loud environment or because the motor is too far away, the noise of the actual speed value or the setpoint torque value can be used for evaluation by means of the [Oscilloscope](#). Please observe that the speed controller gain  $V_p$  ([C00070](#)) is used for the torque setpoint.

### 5.5.3.3 Optimising torque controller

To optimise the torque controller a steep speed ramp is required which reaches into the field weakening range (e.g. 1.2 \* rated speed). For this purpose, the drive must be operated at its current and voltage limit.



#### Stop!

Reduce the maximum current in [C00022](#) for this adjustment to approx. 130 % of the motor magnetising current ([C00092](#)) to prevent shocks on the drive!



#### Note!

If no field weakening operation is required, the adjustment must be executed in the base speed range.

The gain ([C00987](#)) and reset time ([C00988](#)) of the torque controller are to be set so that the actual cross current can preferably follow the cross current setpoint.


- ▶ If oscillations occur during the cross current (see illustration [\[5-12\]](#)), the gain ([C00987](#)) is to be reduced until the drive is stable again (see illustration [\[5-13\]](#)).
- ▶ Afterwards the reset time ([C00988](#)) can be reduced as long as the drive accelerates in a stable way.

# 9400 HighLine | Parameter setting & configuration


Motor interface

Sensorless vector control (SLVC)

Ch	Variable of the motor control	Unit	1/div	Offset	Position
1	Speed.dnSpeedSetpoint (speed setpoint)	rpm	0.2k	0	-4
2	Speed.dnActualMotorSpeed (current speed)	rpm	0.2k	0	-4
3	Current.dnActualDirectCurrent (actual field current)	A	10	0	0
4	Current.dnQuadratureCurrentSet (cross current setpoint)	A	10	0	0
5	Current.dnActualQuadratureCurrent (actual cross current)	A	10	0	0



[5-12] Oscillogram 1: speed ramp (motor 55 kw) – torque controller gain = 0.0661



[5-13] Oscillogram 2: speed ramp (motor 55 kw) – torque controller gain = 0.0361

## 5.5.3.4 Optimise current controller

**Note!**

Only required for sensorless vector control if one of the following functions is used.

- [Flying restart function](#) (☞ 218)
- [DC-injection braking](#) (☞ 221)

In a test mode you can select current setpoint step-changes and optimise the parameter settings of the current controller (gain and reset time) by evaluating the step responses.

- ▶ The starting values for gain and reset time can be calculated with the following formula:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$

$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$

**How to optimise the current controller in the test mode:**


1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Activate one of the two following optimisation modes for the current controller:
  - [C00398](#) = "3: Current controller optimisation mode":  
After controller enable, the motor is supplied with current as long as the controller is enabled.
  - [From software version V7.0:](#)  
[C00398](#) = "4: Current controller optimisation mode pulse":  
The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
3. Select the effective value of the current setpoint step change under [C00022](#).
  - The peak value of the measurable motor current will be 1.41 times higher.
4. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in the »Engineer«. (☞ 590)
  - Variable of the motor control to be recorded:  
*Current.dnActualDirectCurrent* (field-oriented direct-axis current)

# 9400 HighLine | Parameter setting & configuration

Motor interface


Sensorless vector control (SLVC)

5. Evaluate the step response:



6. Change the gain  $V_p$  under [C00075](#) and the reset time  $T_n$  under [C00076](#).
7. Repeat steps 4 ... 6 until the optimum step response of the motor current is reached.
  - In the optimised state the current rise time typically is 0.5 ... 1 ms.
8. After the optimisation has been completed, deactivate the test mode again ([C00398](#) = "0: Test mode deactivated").
9. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.5.4 Signal flow



[5-14] Signal flow - sensorless vector control

### Internal variables of the motor control (oscilloscope signals)

► The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. ( 590)

No.	Variable of the motor control	Meaning
(1)	Torque.dnTorqueSetpoint	Torque setpoint
(2)	Current.dnQuadratureCurrentSet	Q current setpoint
(3)	Current.dnActualQuadratureCurrent	Actual Q current
(4)	Speed.dnActualMotorSpeed	Actual speed
(5)	Common.dnActualFlux	Actual flux value
(6)	Frequency.dnActualSlipFrequency	Actual slip frequency
(7)	Frequency.dnActualRotatingFieldFrequency	Actual field frequency
(8)	Voltage.dnQuadratureVoltage	Q voltage
(9)	Voltage.dnDirectVoltage	D voltage
(10)	Voltage.dnActualMotorVoltage	Current motor voltage
(11)	Current.dnDirectCurrentSet	D current setpoint
(12)	Current.dnActualDirectCurrent	Actual D current

## 5.6 V/f control (VFCplus)

This function extension is available from software version V3.0!

If this motor control mode is set in [C00006](#), the output voltage of the controller follows a firmly defined characteristic.




### Note!

The operation of vertical drives/hoists is only supported up to 55 kW by the V/f control!

### 5.6.1 Basic settings

After the motor and controller have been optimally adjusted to each other, the "initial commissioning steps" described in the following table are sufficient for a simple characteristic control.

- Detailed information on the individual steps can be found in the following subchapters.

Initial commissioning steps	
1.	<a href="#">Defining the V/f characteristic</a> . (📖 191)
2.	<a href="#">Setting the voltage boost</a> . (📖 192)
3.	<a href="#">Parameterising load adjustment</a> . (📖 194)
4.	<a href="#">Activating voltage vector control</a> . (📖 195) <ul style="list-style-type: none"><li>• The <i>Voltage Vector Control</i> (VCC), which can be activated, serves to provide a torque at low field frequencies. This task is executed by a current controller the output voltage of which is added to the voltage from the characteristic.</li></ul>
5.	<a href="#">Defining the current limit (Imax controller)</a> . (📖 196)
6.	Additional "flying restart" function: <ul style="list-style-type: none"><li>• In the Lenze setting, this parameterisable additional function is activated.</li><li>• If the flying restart function is not required, deactivate this function. ► <a href="#">Flying restart function</a> (📖 218)</li></ul>  <p><b>Only deactivate the flying restart if it is ensured that the drive is always at standstill in the case of controller enable!</b></p>
7.	Additional "DC-injection braking" function: <ul style="list-style-type: none"><li>• In the Lenze setting, this parameterisable additional function is deactivated.</li><li>• If DC-injection braking is required, activate this function. ► <a href="#">DC-injection braking</a> (📖 221)</li></ul>



### Tip!

How to optimise the control behaviour and adjust it to the concrete application is described in the chapter "[Optimise control mode](#)". (📖 197)


The parameterisable additional functions are described in the chapter of the same name "[Parameterisable additional functions](#)". (📖 209)

## 5.6.1.1 Defining the V/f characteristic

### Linear/square-law characteristic

[C00950](#) serves to select the shape of the characteristic to adjust the characteristic to different load profiles:

- ▶ Linear characteristic for drives with constant load torque over the speed.
- ▶ Square-law characteristic for drives with a linear or square-law load torque over the speed:
  - Square-law V/f characteristics are mostly used in centrifugal pump and fan drives. However, it must be checked in each individual case if your pump or fan drive can be used in this operating mode!
  - If your pump or fan drive is not suitable for operation with a square-law V/f characteristic, you have to use the linear or user-definable V/f characteristic or the sensorless vector control instead of the V/f control.



[5-15] Linear/square-law V/f characteristic

- ▶ The calculation of the characteristic considers the rated motor voltage ([C00090](#)) and the V/f base frequency ([C00951](#)).

### Short overview: Parameters for V/f characteristic

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00950</a>	VFC: V/f characteristic shape	Linear (V/f)	
<a href="#">C00951</a>	VFC: V/f base frequency	50	Hz
<a href="#">C00952/1...11</a>	VFC: Frequency interpol. point n	▶ <a href="#">Free definition of the V/f characteristic</a> (□ 198)	
<a href="#">C00953/1...11</a>	VFC: Voltage interpol. point n		
<a href="#">C00954/1...11</a>	VFC: Activat. interpol. point n		

## 5.6.1.2 Setting the voltage boost

[C00960](#) and the  $MI\_dnBoostSet\_n$  input of the motor interface serve to define a constant, load independent voltage boost at low speeds (below the V/f rated frequency) or at motor standstill to optimise the starting performance.



### Stop!

If the motor is operated at standstill for a longer time - especially in case of smaller motors - the motor can be destroyed by overtemperature!

- Connect the thermal contact (NC contact), PTC, or KTY of the motor and activate the motor temperature monitoring of the controller.
- Operate self-ventilated motors with a blower, if required.



### Note!

When device types > BF7 are used, the voltage boost only functions in a restricted way due to the hardware properties!

Depending on the required starting torque, the voltage boost must be set so that the required motor current will be available after controller enable (starting current  $\sim V_{min}$ ).



### Tip!

The required voltage can be calculated by multiplying the stator resistance by the rated magnetising current:

$$U_{min} = R_S \cdot I_{mN}$$

Optionally, the voltage can be determined empirically by increasing the value for the voltage boost until the rated magnetising current flows.


- ▶ Via the input  $MI\_dnBoostSet\_n$  the voltage has to be selected in [%] relating to the rated motor voltage ([C00090](#)).
- ▶ In [C00960](#), however, the voltage must be set directly in [V].
- ▶ Only positive voltage values can be selected, negative values are limited to 0 V.
- ▶ Both selections are added:

$$U_{Boost} = MI\_dnBoostSet\_n \cdot \frac{C00090}{100\%} + C00960$$

- ▶ The resulting voltage  $V_{Boost}$  is added geometrically to the characteristic voltage:

$$U = \sqrt{U_{Characteristic}^2 + U_{Boost}^2}$$





[5-16] Voltage boost at linear/square-law V/f characteristic

## Short overview: Parameters for voltage boost

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00960</a>	VFC: V/f voltage boost	0	V



### Tip!

For magnetising the motor, consider a sufficient time from the controller enable to the start of the speed ramp function generator.

- The bigger the motor the longer the time required for magnetisation. A motor with a power of 90 kW requires up to 2 seconds.

## 5.6.1.3 Parameterising load adjustment

[C00962](#) serves to parameterise a load adjustment in [%] proportionally to the rated torque to obtain a correspondingly "rigid" drive behaviour even after the starting action.

- ▶ When starting torque = rated torque, a load adjustment of 50 % is suitable for most applications.



### Stop!

If the load adjustment is too high, the motor current may increase in idle state and the motor may overheat!

The [C00961](#) parameter serves to adjust the characteristic depending on the load at CW and CCW rotation:

Setting in C00961	Information
0: CW rotation in motor mode/CCW rotation in motor mode	The motor operates in motor mode in both directions.
1: CW rotation in motor mode/CCW rotation in generator mode	Application example: Hoist without counterweight
2: CW rotation in generator mode/CCW rotation in motor mode	Application example: Dancer-controlled unwinder

### Short overview: Parameters for load adjustment

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00961</a>	VFC: Load - cw/ccw-operation	CW: mot. / CCW: mot.	
<a href="#">C00962</a>	VFC: Load adjustment	20.00	%

## 5.6.1.4 Activating voltage vector control

The *Voltage Vector Control (VCC)*, which can be activated, is an alternative to the voltage boost. The voltage vector control is used if a high starting torque has to be ensured. The voltage vector control ensures that the motor current required for this purpose is available in the zero speed range.



### Note!

A disadvantage of the voltage vector control is the increased current at low speeds. This causes higher losses and thus an increased heating of the machine.

The voltage vector control is activated by defining a current setpoint in [C00957](#) and can be deactivated again by setting "0.0 A".

- ▶ The voltage vector control is additive to the voltage boost.
  - ▶ [Setting the voltage boost](#) (📖 192)
- ▶ When the current setpoint is defined, provide a reserve of 20 % to prevent a motor stalling caused by sudden additional loads.
- ▶ Example for starting torque = rated motor torque:  
The current setpoint must be parameterised in [C00957](#) to approx. 120 % of the load current.

### Setting of the controller parameters

For the gain ([C00958](#)) and the reset time ([C00959](#)), accept the values that have been detected for the current controller gain ([C00075](#)) and reset time ([C00076](#)) in the test mode.

▶ [Optimise current controller](#) (📖 202)

Since the voltage vector control controls the current value which has a higher background noise due to its calculation, the reset time might possibly be increased.

### Short overview: Parameters for voltage vector control

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00957</a>	VFC: VVC current setpoint	0.00	A
<a href="#">C00958</a>	VFC: VVC gain	0.00	V/A
<a href="#">C00959</a>	VFC: VVC reset time	2000.00	ms



### Tip!

For controllers with a power > 55 kW we recommend to use the voltage vector control for horizontal drives for improving the smooth running characteristics.

## 5.6.1.5 Defining the current limit (Imax controller)

The current limit for the I<sub>max</sub> controller is defined by the maximum current which must be set in [C00022](#). If the motor current exceeds the value set in [C00022](#), the I<sub>max</sub> controller gets active.

- ▶ The I<sub>max</sub> controller changes the field frequency so that the motor current does not exceed the current limit. In motor mode, the frequency is reduced and in generator mode it is increased.
- ▶ Gain and reset time of the I<sub>max</sub> controller can be parameterised in [C00963](#) and [C00964](#).

### Short overview: Parameters for I<sub>max</sub> controller

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00022</a>	Maximum current	0.00	A
<a href="#">C00963</a>	VFC: Gain - I <sub>max</sub> controller	0.001	Hz/A
<a href="#">C00964</a>	VFC: Reset time - I <sub>max</sub> controller	100.0	ms

### Optimise the I<sub>max</sub> controller

- ▶ If oscillations occur during operation at the current limit, the I<sub>max</sub> controller has to be decelerated:
  - Reduce gain ([C00963](#))
  - Increase reset time ([C00964](#))
- ▶ If the I<sub>max</sub> controller does not operate fast enough after having exceeded the current limit, it must be accelerated:
  - Increase gain ([C00963](#))
  - Reduce reset time ([C00964](#)).

## 5.6.2 Optimise control mode

The "optimisation steps" given in the following table serve to further optimise the control behaviour of the V/f control and adjust it to the concrete application.


- ▶ Detailed information on the individual steps can be found in the following subchapters.

Optimisation steps	
1.	<a href="#">Free definition of the V/f characteristic.</a> (📖 198) <ul style="list-style-type: none"> <li>• Individual adjustment of the motor magnetisation to the concrete application if linear and square-law characteristics are not suitable.</li> </ul>
2.	<a href="#">Parameterising slip compensation.</a> (📖 199)
3.	<a href="#">Parameterising oscillation damping.</a> (📖 200)
4.	When the flying restart function is used: Optimise flying restart process. ▶ <a href="#">Flying restart function</a> (📖 218)
5.	<a href="#">Optimise current controller.</a> (📖 202) <ul style="list-style-type: none"> <li>• Only required if one of the following functions is used:               <ul style="list-style-type: none"> <li>– <a href="#">Voltage vector control</a> (📖 195)</li> <li>– <a href="#">Flying restart function</a> (📖 218)</li> <li>– <a href="#">DC-injection braking</a> (📖 221)</li> </ul> </li> </ul>
6.	Save »Engineer« project.

## 5.6.2.1 Free definition of the V/f characteristic

To individually adjust the motor magnetisation to the real application, a user-definable characteristic can be selected in [C00950](#) if the linear and square-law characteristic are not suitable.

- ▶ The interpolation points (voltage/frequency values) of this characteristic are selected via the 11 subcodes of [C00952](#) and [C00953](#).
- ▶ If less interpolation points are required, the interpolation points that are not needed have to be deactivated via the subcodes of [C00954](#).
- ▶ In the Lenze setting the 11 interpolation points represent a linear characteristic:



	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11
V	400 V	320 V	240 V	160 V	80 V	0 V	80 V	160 V	240 V	320 V	400 V
f	-50 Hz	-40 Hz	-30 Hz	-20 Hz	-10 Hz	0 Hz	10 Hz	20 Hz	30 Hz	40 Hz	50 Hz

[5-17] User-definable characteristic (Lenze setting)

## 5.6.2.2 Parameterising slip compensation

The slip compensation serves to automatically compensate a load-dependent speed loss. In order that the slip compensation can operate correctly, the rated slip of the motor is required. This is calculated from the rated frequency ([C00089](#)) and the rated speed ([C00087](#)), thus both parameters must be parameterised correctly.

- ▶ A percentage adjustment of the calculated slip can be made in [C00965](#), e.g. when the real motor data deviate from the data given on the nameplate. A value of 100 % in [C00965](#) corresponds to the rated slip of the machine.
- ▶ The time behaviour of the slip compensation can be parameterised in [C00966](#).

### Short overview: Parameters for slip compensation

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00965</a>	VFC: Gain - slip compensation	0.00	%
<a href="#">C00966</a>	VFC: Time constant - slip compens.	2000	ms

## 5.6.2.3 Parameterising oscillation damping

The oscillation damping serves to reduce the oscillations during no-load operation which are caused by energy oscillating between the mechanical system (mass inertia) and the electrical system (DC bus). Furthermore, the oscillation damping can also be used to compensate resonances.



### Note!


Observe the following restrictions:

- Oscillations occurring sporadically cannot be damped.
- Damping is possible only for constant oscillations at a steady-state operating point.
- The oscillation damping is not suitable for oscillations occurring during dynamic processes (e.g. accelerations or load changes).

### Function

The determination of the oscillation is based on the active current. In order to obtain the alternating component of the active current, this current is differentiated. This signal is then passed through a PT1 filter.

- ▶ The base frequency of the PT1 filter has to be set in such a way that the oscillation can be damped and higher-frequency components are filtered out of the signal. For this purpose the time constant ([C00968](#)) is used.
- ▶ [C00967](#) serves to parameterise the gain of the oscillation signal. The maximum amplitude of the frequency change determined by the oscillation damping is set via [C00969](#).
- ▶ Oscillation damping is only active if the setpoint speed is greater than 10 rpm and the DC-bus voltage exceeds a value of 100 V.
- ▶ In the lower speed range, the oscillation damping may have a negative impact on the concentricity factor.
  - Therefore from software version V5.0 a ramp end frequency can be set in [C00970](#), up to which the gain of the oscillation damping ([C00967](#)) from 10 rpm is slowly increased with increasing rotational frequency.





## Identification of the oscillation

Before the oscillation damping can be parameterised, the oscillation has to be identified. One way is to examine the motor current while oscillation damping is switched off ([C00967](#) = 0 %). At steady-state operation, a constant current flows. If the drive oscillates, these oscillations are also visible on the motor current. It is therefore possible to determine the frequency and the amplitude of the oscillation from the alternating component of the motor current. In the following, this alternating component is referred to as "current oscillation".

## Parameter setting

- ▶ The time constant ([C00968](#)) is determined from the reciprocal value of twice the frequency of the current oscillation:

$$\text{Time constant} = \frac{1}{2 \cdot \text{Oscillation frequency}}$$

- ▶ The gain factor ([C00967](#)) is calculated with the following formula based on the relationship between the amplitude of the current oscillation and the maximum device current:

$$\text{Gain} = \frac{\text{Current amplitude}}{\sqrt{2} \cdot \text{Maximum device current (C00789)}} \cdot 100 \%$$

- ▶ The maximum oscillation frequency ([C00969](#)) serves to the absolute limitation of the oscillation frequency calculated before it is added to the field frequency. It can be derived from the amplitude of the current oscillation, the rated motor current, and the slip frequency of the motor connected:

$$\text{Max. frequency} = \frac{2 \cdot \text{Amplitude of the current oscillation}}{\text{Rated motor current}} \cdot \text{Rated slip frequency}$$

- ▶ **From software version V5.0:** The ramp end frequency ([C00970](#)) defines the rotational frequency from which the gain factor is to have reached its nominal value ([C00967](#)).
  - The ramp end frequency refers to the rated motor frequency in percent ([C00089](#)).
  - Below a speed of 10 rpm, the oscillation damping remains deactivated.
  - For machines with a power greater than 55 kW a ramp end frequency of 20 % is recommended.

## Short overview: Parameters for oscillation damping

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00967</a>	VFC: Gain - oscillation damping	20	%
<a href="#">C00968</a>	VFC: Time const. - oscill. damp.	5	ms
<a href="#">C00969</a>	VFC: Limitation - oscillation damping	0.2	Hz
<a href="#">C00970</a>	VFC: Ramp end freq. - oscillation damping	0	%

## 5.6.2.4 Optimise current controller



### Note!

Only required if one of the following functions is used:

- [Voltage vector control](#) (□ 195)
- [Flying restart function](#) (□ 218)
- [DC-injection braking](#) (□ 221)

In a test mode you can select current setpoint step-changes and optimise the parameter settings of the current controller (gain and reset time) by evaluating the step responses.

- ▶ The starting values for gain and reset time can be calculated with the following formula:


$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$
$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$



### How to optimise the current controller in the test mode:


1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Activate one of the two following optimisation modes for the current controller:
  - [C00398](#) = "3: Current controller optimisation mode":  
After controller enable, the motor is supplied with current as long as the controller is enabled.
  - [From software version V7.0:](#)  
[C00398](#) = "4: Current controller optimisation mode pulse":  
The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
3. Select the effective value of the current setpoint step change under [C00022](#).
  - The peak value of the measurable motor current will be 1.41 times higher.
4. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in the »Engineer«. (□ 590)
  - Variable of the motor control to be recorded:  
*Current.dnActualDirectCurrent* (field-oriented direct-axis current)

5. Evaluate the step response:



6. Change the gain  $V_p$  under [C00075](#) and the reset time  $T_n$  under [C00076](#).
7. Repeat steps 4 ... 6 until the optimum step response of the motor current is reached.
  - In the optimised state the current rise time typically is 0.5 ... 1 ms.
8. After the optimisation has been completed, deactivate the test mode again ([C00398](#) = "0: Test mode deactivated").
9. If the  $I_{min}$  control is used, both calculated controller parameters can also be used for the  $I_{min}$  controller:
  - [C00075](#) → [C00958](#) ( $I_{min}$  controller: gain)
  - [C00076](#) → [C00959](#) ( $I_{min}$  controller: reset time)
10. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.6.2.5 Optimise pull-out slip limitation



[5-18] Speed/torque curve of the asynchronous motor with two field weakening ranges **B** and **C**


The operating range of an asynchronous motor consists of the voltage control range **A** and the field weakening range. The field weakening range again is divided into two ranges:

- ▶ In the first range **B**, the power can be kept constant without causing motor stalling.
- ▶ The second field weakening range **C** is characterised by the fact that the maximum permissible stator current (defined via [C00022](#) "Maximum current") is reduced to prevent motor stalling.

The override point ( $n_2$ ,  $M_2$ ) can be influenced via [C00980](#) ("VFC: Override point of field weakening"). If the motor stalls in the field weakening range, the override point ( $n_2$ ,  $M_2$ ) can be adjusted by decreasing [C00980](#) so that motor stalling is avoided.

If the motor does not provide sufficient torque in the field weakening range, [C00980](#) must be increased.

## 5.6.3 Signal flow



[5-19] Signal flow - V/f control

### Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (📖 590)

No.	Variable of the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Current.Current.dnActualMotorCurrent	Actual motor current
(3)	Current.dnActualQuadratureCurrent	Actual Q current
(4)	Speed.dnActualMotorSpeed	Current motor speed
(5)	Frequency.dnActualSlipFrequency	Actual slip frequency
(6)	Frequency.dnActualRotatingFieldFrequency	Actual field frequency
(7)	Voltage.dnOutputQuadratureVoltage	Q voltage
(8)	Voltage.dnOutputDirectCurrentCtrl	D voltage
(9)	Voltage.dnActualMotorVoltage	Current motor voltage

## 5.7 V/f control (VFCplus)

This function extension is available from software version V3.0!



### Note!

The descriptions in the chapter "[V/f control \(VFCplus\)](#)" also apply to the V/f control closed loop. [\(190\)](#)

When this motor control mode is used, the operation can be continued if the encoder fails. For this, the encoder monitoring must be parameterised to "Warning". If the encoder fails, the speed controller is "frozen" so that the slip correction via the speed controller is maintained.


For the closed loop V/f control, the speed controller (also called "slip regulator") also has to be parameterised for the speed feedback.

- ▶ [C00971](#) serves to define the influence of the speed controller in [%] with regard to the reference speed of the motor ([C00011](#)). If the influence is adjusted to the slip expected under normal operating conditions, the motor cannot accelerate in an uncontrolled way when the encoder fails.
- ▶ To activate the speed controller, parameterise the gain ([C00972](#)) and the reset time ([C00973](#)).

### Short overview: Parameters for speed controller

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00971</a>	VFC: Influence - speed controller	10.00	%
<a href="#">C00972</a>	VFC: Gain - speed controller	0.000	Hz/rpm
<a href="#">C00973</a>	VFC: Reset time - speed controller	6000.0	ms

## 5.7.1 Signal flow



[5-20] Signal flow for closed loop V/f control

## Internal variables of the motor control (oscilloscope signals)

- ▶ The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (🔗 590)

No.	Variable of the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Current.Current.dnActualMotorCurrent	Actual motor current
(3)	Current.dnActualQuadratureCurrent	Actual Q current
(4)	Speed.dnActualMotorSpeed	Current motor speed
(6)	Frequency.dnActualRotatingFieldFrequency	Actual field frequency
(7)	Voltage.dnOutputQuadratureVoltage	Q voltage
(8)	Voltage.dnOutputDirectCurrentCtrl	D voltage
(9)	Voltage.dnActualMotorVoltage	Current motor voltage



## 5.8 Parameterisable additional functions

Detailed information on the parameterisable additional functions can be found in the following subchapters:

Parameterisable additional functions	Available from software version	Motor control*		
		SC	SLVC	VFC plus
<a href="#">Correction of the stator leakage inductance...</a> (📖 210)	V1.0	●		
<a href="#">Field weakening for synchronous machines</a> (📖 215)	V2.0	●		
<a href="#">Flying restart function</a> (📖 218)	V3.0		●	●
<a href="#">DC-injection braking</a> (📖 221)	V3.0		●	●

\* SC = servo control    SLVC = sensorless vector control    VFCplus = V/f control

#### 5.8.1 Correction of the stator leakage inductance...

...and the current controller parameters by means of the saturation characteristic




#### Note!

Function only possible for servo control!

The current controller must be adjusted to the electrical characteristics of the motor stator resistance ([C00084](#)) and stator leakage inductance ([C00085](#)). In case of modern motors, the stator leakage inductance changes with the height of the current so that a new current controller setting is required for each current height.

When the motor is operated with very low and very high currents (e.g. in *pick and place* applications), it is not always possible to achieve a satisfactory current controller setting for all operating points. For this purpose, the correction of the stator leakage inductance and current controller parameters is now possible via an adjustable saturation characteristic that can be set in [C02853](#) (17 interpolation points).

The following picture shows a typical saturation characteristic of an MCS motor:



[5-21] Saturation characteristic: Inductance referring to the inductance for rated current

- ▶ By optimising the current controller with different current setpoints such a characteristic can be determined "by trial" and set in [C02853](#).
- ▶ The correction by means of this saturation characteristic can be switched off or on via [C02859](#).




#### Note!

The saturation characteristic is not only used for the correction of the current controller but also influences the current controller feedforward control ([C00074](#)).

### Distribution of the interpolation points

- ▶ The saturation characteristic is defined by 17 interpolation points which are distributed linearly on the x axis.
- ▶ Interpolation point 17 represents 100 % of the maximum motor current in the process ([C02855](#)).



[5-22] Saturation characteristic: Distribution of the interpolation points

### Example for determining the saturation characteristic

#### Given values:

- ▶ Rated motor current: 5 A
- ▶ Maximum motor current: 20 A
- ▶ Maximum process current: 15 A (must be set later in [C00022](#))

#### Procedure:


1. Deactivate correction ([C02859](#) = "OFF").
2. Set the maximum current up to which the motor is to be operated in the process in [C02855](#) (in this example "15 A").
  - The value set in [C02855](#) has to be greater or the same as [C00022](#).
3. Adjust the current controller with different current setpoints and take down the corresponding settings for Vp and Tn.
  - The procedure for the adjustment is described in the chapter "[Optimise current controller](#)".
  - The current setpoints that are to be set for the respective adjustment in [C00022](#) result from the scaling of the maximum process current to the x axis of the saturation characteristic.
  - The interpolation points which are required to define the saturation characteristic with a sufficient quality varies from motor to motor and thus has to be determined individually.

# 9400 HighLine | Parameter setting & configuration

## Motor interface

### Parameterisable additional functions

- For this example currents were selected that are part of the interpolation points 5, 9, 13, and 15, and a measurement at rated motor current was carried out:




[5-23] Saturation characteristic: Distribution of the interpolation points

Specifications for adjustment			Measured values	
Interpolation point	Scaling	Setting in C00022	Vp [V/A]	Tn [ms]
5	$0.25 * 15\text{ A} =$	3.75 A	13	6.5
9	$0.5 * 15\text{ A} =$	7.5 A	8	4
13	$0.75 * 15\text{ A} =$	11.25 A	5	2.5
15	$0.875 * 15\text{ A} =$	12.38 A	4	2
17	$1.0 * 15\text{ A} =$	15 A	3	1.7
Rated motor current =		5 A	10	5

#### 4. Create a characteristic based on the values calculated for Vp.

- Here, the values which have not been adjusted must be determined by interpolation between two values.
- **Note:** In this example it was assumed that the inductance does not change considerably below 3.75 A. For this reason the same Vp value resulting from a measurement with a motor current of 3.75 A was used for all interpolation points below 3.75 A.




[5-24] Determined saturation characteristic

5. Set the gain  $V_p$  in [C00075](#) and the reset time  $T_n$  in [C00076](#), which have been determined during the adjustment with rated motor current (in this example "5 A"):


- Set [C00075](#) = "10 V/A".
- Set [C00076](#) = "5 ms".

6. Scale the  $V_p$  values on the Y axis of the characteristic to the 100 %  $V_p$  setting in [C00075](#):



[5-25] Scaling of the determined saturation characteristic to the "100 %" setting in C00075

7. Enter the  $V_p$  values in percent, which are placed on the interpolation point, in [C02853/1...17](#):



[5-26] Interpolation point values of the saturation characteristic determined

# 9400 HighLine | Parameter setting & configuration

Motor interface

Parameterisable additional functions

Interpolation point	Setting	Interpolation point	Setting
1	<a href="#">C02853/1</a> = 130 %	10	<a href="#">C02853/10</a> = 72.5 %
2	<a href="#">C02853/2</a> = 130 %	11	<a href="#">C02853/11</a> = 65 %
3	<a href="#">C02853/3</a> = 130 %	12	<a href="#">C02853/12</a> = 57.5 %
4	<a href="#">C02853/4</a> = 130 %	13	<a href="#">C02853/13</a> = 50 %
5	<a href="#">C02853/5</a> = 130 %	14	<a href="#">C02853/14</a> = 45 %
6	<a href="#">C02853/6</a> = 107 %	15	<a href="#">C02853/15</a> = 40 %
7	<a href="#">C02853/7</a> = 95 %	16	<a href="#">C02853/16</a> = 35 %
8	<a href="#">C02853/8</a> = 87.5 %	17	<a href="#">C02853/17</a> = 30 %
9	<a href="#">C02853/9</a> = 80 %		

8. Enter the maximum process current ("15 A") in [C00022](#).
9. Switch on the correction ([C02859](#) = "ON").
  - When the correction of the stator leakage inductance is switched on, the same current characteristic should occur, irrespective of the current magnitude.
  - Since the current controller gain is corrected actively, the step responses may differ slightly compared to the previous measurements. In this case [C00075](#) and [C00076](#) must be optimised one last time.
10. Save parameter set ([C00002](#) = "11: Save start parameters").

## 5.8.2 Field weakening for synchronous machines


This function is available from software version V2.0!



### Note!

Function only possible for servo control!

If required, the field weakening mode can be switched on in [C00093](#) for synchronous machines.




- ▶ If field weakening is switched on and the DC-bus voltage limit is reached, the motor magnetising current is increased via an internal control loop from 0 A to the maximally effective magnetising current.
- ▶ The result is that a higher speed can be reached at the same motor voltage or DC-bus voltage.

[5-27] Voltage/speed characteristic with active field weakening

$$n_{\max} = n_{\text{rated\_mot}} \cdot \frac{800\text{V}}{\sqrt{2} \cdot U_{\text{rated\_mot}}}$$

[5-28] Calculation of the maximum speed that can be reached when field weakening is switched on



[5-29] Speed-torque characteristics of a synchronous servo motor with field weakening

- ▶ The maximally effective motor magnetising current is calculated based on the motor data set in C00084 to C00091. Then the calculated value is internally limited to 98 % of the maximum current set in [C00022](#).
- ▶ When field weakening is switched on, the actually used maximum effective motor magnetising current is shown in [C00092](#), if field weakening is switched off, "0 A" are displayed, as before.



#### Note!

##### If a Lenze motor is used:

The controller is parameterised automatically so that the field weakening works optimally and there is no danger to the devices.



#### Stop!

##### If a motor of a third-party manufacturer is used:

If pulse inhibit is set in the controller, the DC bus is charged with the voltage which corresponds to the current speed of the machine.

As higher speeds at an accordingly higher rotor voltage of the motor can be reached if the field weakening mode is switched on, the DC bus can be charged with a voltage higher than the set DC-bus voltage  $v_{dc-bus}$  and possibly exceed the maximum permissible voltage of 800 V when pulse inhibit is set and the motor speed is high!

In order to protect the device, either use a brake chopper, or parameterise the speed monitoring via [C00596](#) and [C00607](#), so that only a maximum motor speed is possible that could also be reached with  $V_{dc-bus} = 800 \text{ V}$  without field weakening.


▶ [Maximum motor speed](#) (📖 132)



## Example: Voltage increase in the DC bus at field weakening loss

(For example by an active setting of controller inhibit, or by activation of trouble or fault at a high motor speed.)

Field weakening	Speed n	Motor voltage peak value
Switched off	4000 rpm	560 V
	5700 rpm	800 V
	6000 rpm	840 V
Switched on	6000 rpm	560 V



- ▶ If pulse inhibit is set at 6000 rpm and switched-on field weakening, the DC bus is charged to over 800 V (❶).
- ▶ A speed limitation to 5700 rpm is required, as this speed generates a DC-bus voltage of 800 V when the field weakening mode is switched off.

[5-30] Example: Possible DC-bus voltage > 800 V at field weakening loss

## 5.8.3 Flying restart function

This function is available from software version V3.0!



### Note!

Function only possible for V/f control or sensorless vector control!

In the case of V/f control or sensorless vector control, the current motor speed is only provided to the controller if the motor control is active. However, if the controller is enabled, one cannot always assume that the drive is at standstill. The drive for example may still coast down, or be further operated by a load. It cannot always be assumed that fans are at standstill if the controller is enabled, e. g. if the fan impeller is further driven by an air flow in an undefined direction.

If the flying restart mode is activated in [C00990](#), after controller inhibit is deactivated (or DC-injection braking is cancelled), a flying restart process is automatically started to determine the current motor speed if the following conditions are met:

- ▶ V/f control or sensorless vector control are selected as motor control in [C00006](#).
- ▶ The position control structure is set to "Phase controller is active" in [C02570](#).
- ▶ The *MI\_bFlyingSyncBlocked* control input of the motor interface is not assigned or set to FALSE.
- ▶ The holding brake, if available, is not applied.



### Stop!

If the flying restart function is deactivated and the controller is not enabled at standstill, the output voltage and output frequency does not match the current motor speed. High compensation currents may flow!

- The drive is first braked towards 0 Hz and is then accelerated again!
- This may cause the following error messages:
  - Controller: Overload during acceleration phases (fault)
  - Device utilisation Ixt > C00123 (warning)
  - Device utilisation Ixt > 100 % (fault)
  - Motor load I2xt > C00127 (warning)
  - Motor load I2xt > C00120 (fault)
  - Overcurrent detected (fault)
  - Overvoltage in DC bus (trouble)




## Note!

The flying restart algorithm requires the motor voltage as exact as possible. Therefore it is absolutely necessary to predetermine the inverter error characteristic. ▶ [Optimising the switching performance of the inverter](#) (□ 143)

In addition to the exact motor voltage, the stator resistance must also be known exactly. If the flying restart function should not work as required, slightly adjust the setting of the stator resistance in [C00084](#).

## Sequence



- A. Initial situation: basic function "Speed follower" is enabled and active.
- B. The controller is inhibited while the drive is not at standstill.
- C. The motor coasts down (torqueless).
- D. The controller inhibit is deactivated again.
- E. The flying restart process starts.

[5-31] Process example: Speed follower is active → Controller inhibit → Controller enable

## Flying restart process

The controller calculates the output frequency required for the momentary speed of the coasting motor, then connects to the system, and accelerates the motor to the defined setpoint again.

- ▶ The flying restart process serves to prevent the motor from decelerating to zero speed with subsequent acceleration.
- ▶ The currently detected flying restart speed is provided to the application via the current motor speed `MI_dnActualMotorSpeed_s`.

## Parameter setting

- ▶ The flying restart algorithm injects a current into the motor to identify the current speed. This flying restart current can be parameterised in [C00991](#) in [%] relating to the rated motor current.
  - The higher the current the higher the torque imposed upon the motor.
  - If the current is too low, a wrong speed can be detected.
- ▶ The starting frequency of the flying restart algorithm can be set in [C00992](#).
  - If it can be anticipated at which frequency the motor "caught" most frequently in a flying restart process, this frequency is to be set here.
- ▶ The integration time of the phase controller is set in [C00993](#).
  - The Lenze setting "60 ms" is adapted for machines with a medium power (45 kW).
  - A guide value for the integration time can be calculated with the following equation as a function of the motor power ([C00081](#)):
 
$$T_i = 1.1 \frac{\mu s}{W} \cdot \text{Motor power (C00081)} + 9.4 \text{ ms}$$
  - For accelerating the flying restart process, this guide value can be reduced.
  - If the flying restart frequency (*Frequency.dnActualRotatingFieldFrequency*) oscillates too much, the integration time has to be increased again.
  - A longer integration time increases the time for "catching" the drive.
- ▶ To avoid starting a flying restart process at short-time controller inhibit, a time can be set in [C00995](#) for the minimum active controller inhibit time.
  - Since a pulse inhibit > 500 ms causes a controller inhibit, this also applies to the pulse inhibit.

## Short overview: Parameters for flying restart process

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00990</a>	Flying restart: Activation	Off	
<a href="#">C00991</a>	Flying restart: Current	15	%
<a href="#">C00992</a>	Flying restart: Start frequency	20.0	Hz
<a href="#">C00993</a>	Flying restart: Integration time	60	ms
<a href="#">C00994</a>	Flying restart: Min. deviation	5.00	°
<a href="#">C00995</a>	Flying restart: Delay time	0	ms

## 5.8.4 DC-injection braking

This function is available from software version V3.0!

---



### Note!

Function only possible for V/f control or sensorless vector control!

DC-injection braking can be divided into three functionalities:

### Manual DC-injection braking

Braking can be activated and deactivated via the internal interface *QSP\_bActivateDCBrake* of the basic function "[Quick stop](#)".



### Tip!

A detailed description of this functionality can be found in the main chapter "Basic drive functions", subchapter "[Quick stop](#)":

▶ [DC-injection braking](#)". (☰ 395)

### DC-injection braking instead of quick stop

If DC-injection braking is activated in [C00976](#) instead of quick stop, DC-injection braking is executed automatically when quick stop is activated.



### Tip!

A detailed description of this functionality can be found in the main chapter "Basic drive functions", subchapter "[Quick stop](#)":

▶ [DC-injection braking when quick stop is activated](#)". (☰ 397)

### Automatic DC-injection braking

This functionality is part of the basic function "[Brake control](#)".

If mode 22 has been selected for the brake control in [C02580](#), DC-injection braking is executed automatically if the current speed setpoint falls below the speed threshold set in [C02581](#).



### Tip!

A detailed description of this functionality can be found in the main chapter "Basic drive functions", subchapter "[Brake control](#)":


▶ [Mode 22: Automatic DC-injection braking](#)". (☰ 395)

## Short overview: Parameters for DC-injection braking

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00974</a>	DC brakes: Current	0.00	A
<a href="#">C00975</a>	DC brakes Current for quick stop	0.00	A
<a href="#">C00976</a>	DC brake: Activat. by quick stop	Off	

## 5.9 Monitoring

### 5.9.1 Signal flow



[5-32] Signal flow of motor interface (monitoring)

### Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (📖 590)

No.	Variable of the motor control	Meaning
(15)	Voltage.dnActualDCBusVoltage	Actual DC-bus voltage
(16)	Current.dnActualCurrentPhaseU	Actual motor current (phase U)
(17)	Current.dnActualCurrentPhaseV	Actual motor current (phase V)
(18)	Current.dnActualCurrentPhaseW	Actual motor current (phase W)

## 5.9.2 Motor monitoring (I<sup>2</sup>xt)

The "Servo Drives 9400" are provided with an extended, sensorless thermal I<sup>2</sup>xt motor monitoring function which is based on a mathematical model that calculates a thermal motor utilisation from the detected motor currents.

- ▶ The calculation considers the speed dependency of the torque (difference between standstill torque and rated torque).
- ▶ [C00066](#) indicates the calculated motor utilisation in [%].
- ▶ If the motor utilisation exceeds the advance warning threshold set in [C00127](#), the error message "I2t motor overload OC8" is output and the response (default setting: "Warning") set in [C00606](#) is activated..
- ▶ If the switch-off threshold set in [C00120](#) is exceeded, the error message "I2t motor overload OC6" is output and the "Fault" response is activated.



### Stop!

The I<sup>2</sup>xt motor monitoring function is no full motor protection!

Since the motor utilisation calculated in the thermal model gets lost after mains switching, the following operating states cannot be determined correctly:


- Restart (after mains switching) of a motor that is already very hot.
- Change of the cooling conditions (e.g. cooling air flow interrupted or too warm).

A full motor protection requires additional measures as e.g. the evaluation of temperature sensors that are situated directly in the winding of thermal contacts.



## Structure of the I<sup>2</sup>xt monitoring

The introduction of a two-component model with two time constants (one for the winding and the other for the housing/laminated core) serves to display the thermal behaviour of the motor up to 500% of the rated current:



[5-33] Structure of the motor monitoring

Parameter		Setting
$I_{act\ motor}$	Actual motor current	-
$I_{perm\ motor\ (n)}$	Permissible motor current (speed-dependent)	-
$\tau_1$	Therm. time constant coil	<a href="#">C00128/1</a>
$k_1$	Percentage of the winding in the final temperature	<a href="#">C01195</a>
$\tau_2$	Therm. time constant plates	<a href="#">C00128/2</a>
$k_2$	Percentage of the steel plates in the final temperature	100 % - <a href="#">C01195</a>

## Calculation with only one time constant

With [C01195](#) = "0 %" the time constant for the winding is not considered and the thermal model is only calculated with the time constant set for the housing/laminated core.

- ▶ The setting [C01195](#) = "0 %" is reasonable if for example the two time constants are not known.
- ▶ The calculation simplified due to this setting corresponds to the calculation in the previous Lenze devices (e.g. 9300 servo inverter or ECS).

## Speed-dependent evaluation of the motor current

By selecting a characteristic in [C01196/1...8](#) the permissible motor current is evaluated depending on speed for calculating the thermal motor utilisation.

Parameter	Characteristic point	
<a href="#">C01196/1</a>	$n_1/n_n$	Speed = "0" (standstill)
<a href="#">C01196/2</a>	$I_1/I_n$	Permissible motor current at standstill
<a href="#">C01196/3</a>	$n_2/n_n$	Speed from which the torque must be reduced for self-ventilated motors. • Below this speed the cooling air flow of the integral fan is not sufficient anymore.
<a href="#">C01196/4</a>	$I_2/I_n$	Permissible motor current at speed $n_2$ (torque reduction)
<a href="#">C01196/5</a>	$n_3/n_n$	Rated speed
<a href="#">C01196/6</a>	$I_3/I_n$	Permissible motor current at rated speed
<a href="#">C01196/7</a>	$n_4/n_n$	Speed above the rated speed (in the field weakening range for asynchronous motors)
<a href="#">C01196/8</a>	$I_4/I_n$	Permissible motor current at speed $n_4$ (field weakening)

- The speed-dependent evaluation can be more or less switched off by setting [C01196/1...8](#) to "100 %" each. The calculation simplified due to this setting corresponds to the calculation in previous Lenze devices (e.g. 9300 servo inverter or ECS).



### Note!

Self-ventilated standard motors are protected insufficiently at low speeds by setting [C01196/1...8](#) to "100 %" each.

Servo motors, however, do not have a point from which the torque must be reduced due to a too low speed.


- When setting the characteristic in [C01196/1...8](#) this point must not be ignored. Hence, point 2 is to be set ideally to point 1 or point 3.

## 5.9.2.1 Example for entry of the characteristic for asynchronous servo motor

Motor type: MDFMARS 090-32

Data from the catalogue:

- ▶ Rated speed  $n_N$ : 1410 rpm → Setting in [C00087](#)
- ▶ Rated current I: 6.1 A → Setting in [C00088](#)
- ▶ Rated torque  $M_{rated}$ : 10.2 Nm
- ▶ Characteristic of maximum torques (50 Hz, star connection):



[5-34] Torque/speed characteristic for motor type MDFMARS 090-32 from catalogue



### Note!

At present, relative current values are still expected for the specification of the interpolation points in subcodes 2, 4, 6, 8 of [C01196](#). This example, however, already uses relative torque values, the entry of which shall be possible at a later date.


Parameter	Setting	Information
<a href="#">C00128/1</a>	1.0 min	Thermal time constant - winding • Is unknown and is therefore deactivated by setting <a href="#">C01195</a> = "0 %".
<a href="#">C00128/2</a>	5.0 min	Thermal time constant - laminated core/housing
<a href="#">C01195</a>	0 %	Percentage of the winding in the final temperature.
<a href="#">C01196/1</a>	0 %	Speed = "0" (standstill)
<a href="#">C01196/2</a>	Permissible motor torque at standstill	
Self-ventilated:	60 %	= 6.1 Nm / 10.2 Nm * 100 %
Forced-ventilated:	100 %	= 10.2 Nm / 10.2 Nm * 100 %
<a href="#">C01196/3</a>	Speed $n_2$ from which the torque must be reduced for self-ventilated motors.	
Self-ventilated:	43 %	= 600 rpm / 1410 rpm * 100 %
Forced-ventilated:	0 %	No torque reduction required.
<a href="#">C01196/4</a>	100 %	Permissible motor torque at speed $n_2$ (torque reduction)
<a href="#">C01196/5</a>	100 %	Rated speed ( $\equiv$ 1410 rpm)
<a href="#">C01196/6</a>	100 %	Permissible motor torque at rated speed ( $\equiv$ 10.2 Nm)
<a href="#">C01196/7</a>	213 %	Speed above the rated speed (in the field weakening range for asynchronous motors) = 3000 rpm / 1410 rpm * 100 %
<a href="#">C01196/8</a>	44 %	Permissible motor torque at speed $n_4$ (field weakening) = 4.5 Nm / 10.2 Nm * 100 %

## 5.9.2.2 Example for entry of the characteristic for synchronous servo motor

Motor type: MCS 06C60

Data from the catalogue:

- ▶ Rated speed  $n_{\text{rated}}$ : 6000 rpm → Setting in [C00087](#)
- ▶ Rated current I: 2.4 A → Setting in [C00088](#)
- ▶ Rated torque  $M_N$ : 0.5 Nm (in S1 operation: 0.55 Nm)
- ▶ Characteristic - maximum torques:



[5-35] Torque/speed characteristic for motor type MCS 06C60 from the catalogue



### Note!

At present, relative current values are still expected for the specification of the interpolation points in subcodes 2, 4, 6, 8 of [C01196](#). This example, however, already uses relative torque values, the entry of which shall be possible at a later date.

Parameter	Setting	Information
<a href="#">C00128/1</a>	1.0 min	Thermal time constant - winding
<a href="#">C00128/2</a>	14.2 min	Thermal time constant - laminated core/housing
<a href="#">C01195</a>	27 %	Percentage of the winding in the final temperature. (Only the laminated core percentage is known.)
<a href="#">C01196/1</a>	0 %	Speed = "0" (standstill)
<a href="#">C01196/2</a>	160 %	Permissible motor torque at standstill = 0.8 Nm / 0.5 Nm * 100 %
<a href="#">C01196/3</a>	0 %	Speed $n_2$ from which the torque must be reduced for self-ventilated motors.
<a href="#">C01196/4</a>	160 %	Permissible motor torque at speed $n_2$ (torque reduction)
<a href="#">C01196/5</a>	100 %	Rated speed ( $\equiv$ 6000 rpm)
<a href="#">C01196/6</a>	100 %	Permissible motor torque at rated speed ( $\equiv$ 0.5 Nm)
<a href="#">C01196/7</a>	100 %	Speed above rated speed
<a href="#">C01196/8</a>	100 %	Permissible motor torque at speed $n_4$ (field weakening)

### 5.9.3 Motor temperature monitoring

If the winding temperature detected by the motor temperature sensor exceeds the limit value set in [C00121](#), the response set in [C00584](#) is activated as advance warning.

- ▶ In the Lenze setting the "Warning" response occurs if the winding temperature exceeds 120 °C.
- ▶ As soon as the fixed limit value of 150 °C is exceeded, the response set in [C00583](#) is activated (default setting: "Fault").
- ▶ If an open circuit is detected in the motor temperature sensor, the response set in [C00594](#) (default setting: "Fault") is activated.



#### Note!

By setting [C00583](#) = "0" the monitoring response and the temperature correction is switched off within the motor control (identification and parameter correction)

This setting for example is reasonable if no usable winding temperature signal is available.




#### Tip!

The winding temperature currently detected by the motor temperature sensor is displayed in [C00063](#).

## 5.9.3.1 Special characteristic for motor temperature sensor

If required, you can select and activate a special characteristic for the motor temperature sensor.

- ▶ The specific characteristic is selected on the basis of two interpolation points which are to be set in [C01191](#) and [C01192](#). Both interpolation points define a line which is extrapolated to the right and to the left.
- ▶ The special characteristic is activated by setting [C01190](#) = "1".
- ▶ In the Lenze setting the special characteristic is defined as follows:



- ▶ Interpolation point ❶
  - [C01191/1](#) = 25°C
  - [C01192/1](#) = 1000 Ω
- ▶ Interpolation point ❷
  - [C01191/2](#) = 150°C
  - [C01192/2](#) = 2225 Ω

[5-36] Lenze setting of the special characteristic



### Note!

- By selecting a motor from the motor catalogue the parameters [C01190](#), [C01191](#) and [C01192](#) are overwritten!
- If the controller measures a resistance below 122 Ω, this is interpreted as a sensor error and a temperature of 255 °C is output.

The following applies from software version V4.0:

- ▶ Sometimes a short circuit is a desired state (e.g. temperature contact closed below 140 °C). For this purpose, the interpolation point 1 ([C01191/1](#)) must be below 122 Ω to prevent the triggering of sensor errors. In this case the temperature continues to be calculated.

### 5.9.3.2 Motor temperature monitoring (PTC)

For detecting and monitoring the motor temperature, a PTC thermistor (DIN 44081/ DIN 44082) or a thermal contact (NC contact) can be connected to the terminals X106/T1 and X106/T2.



#### Stop!

- This monitoring function is only active with line-side power supply of the controller.
- The controller can only evaluate one PTC thermistor!  
Do not connect several PTC thermistors connected in series or in parallel.
- If several motors are operated via one controller, use thermal contacts (NC contacts) connected in series.
- For full motor protection, you have to install an additional temperature monitoring system with separate evaluation.



#### Note!

- In the Lenze setting ([C00585](#) = "1: Fault"), motor temperature monitoring is activated!
- In the delivery state, a wire jumper is installed between the terminals X106/T1 and X106/T2.
- Lenze three-phase AC motor are factory-equipped with a thermal contact.

- ▶ The monitoring function responds at  $1.6 \text{ k}\Omega < R < 4 \text{ k}\Omega$  across terminals X106/T1 and X106/T2, see functional test below.
- ▶ If the monitoring function responds:
  - the error response set in [C00585](#) is executed (Lenze setting: "Fault").
  - the error message "PTC has triggered" (0x0077000f) is entered into the logbook of the controller.
  - the status output *MI\_bMotorOverloadWarning* is set to TRUE.
- ▶ Setting [C00585](#) = "0: No response" deactivates the monitoring function.



#### Tip!

For the operation of motors equipped with PTC thermistors or thermostats, we recommend always to activate the PTC input. This prevents the motor from being destroyed by overheating.

#### Functional test

Connect an invariable resistor to the PTC input:

- ▶  $R > 4 \text{ k}\Omega$  : The fault message must be triggered.
- ▶  $R < 1 \text{ k}\Omega$  : The fault message must not be triggered.

## 5.9.3.3 Temperature monitoring of a second motor

This function is available from software version V7.0!

---

From software version V7.0 onwards, two motor temperature sensors can be evaluated simultaneously via the two encoder inputs X7 and X8 when two motor are used (e.g. double motor for a storage and retrieval unit). For this purpose, the selection "X7 and X8 in parallel" must be set as feedback system for the motor temperature in [C01193](#).

- ▶ In this case, always the higher temperature of the two detected temperatures is displayed as the current motor temperature on the **Diagnostics** tab and in [C00063](#).
- ▶ Moreover, the following display parameters are available from software version V6.0 onwards:
  - [C01200/1](#): Motor temperature via X7
  - [C01200/2](#): Motor temperature via X8
- ▶ If one of the two detected temperatures exceeds the limit value set in [C00121](#), the response set in [C00584](#) is activated as advance warning.
  - In the Lenze setting the "Warning" response occurs if one of the two winding temperature exceeds 120 °C.
- ▶ As soon as one of the two detected temperatures exceeds the fixed limit value of 150 °C, the response set in [C00583](#) is activated (default setting: "Fault").
- ▶ If an open circuit is detected in one of the two motor temperature sensors, the response set in [C00594](#) (default setting: "Fault") is activated.
- ▶ It is not possible to set different responses for the two temperature monitoring modes.
- ▶ For the motor model in the controller, the mean value of both detected temperatures is used.

### Related topics:

- ▶ [Brake control](#) ▶ [Control of two motor holding brakes](#) (📄 562)



## 5.9.4 Motor phase failure monitoring

### 5.9.4.1 Monitoring of the individual motor phases during operation

If a current-carrying motor phase (U, V, W) fails during operation, the response set in [C00597](#) is executed (Lenze setting: "No response") if two conditions are fulfilled:

#### Condition 1: Monitoring is activated

To safely detect a motor phase failure, a certain motor current must flow for the current sensor system.

- ▶ Monitoring will therefore only be activated if, in the case of servo control the setpoint of the motor current, and in the case of sensorless vector control or V/f control the actual value motor current (display in [C00054](#)) has exceeded a certain current value.
- ▶ The current value for the activation can be set in [C00599](#) in [%] with regard to the maximum device current (display in [C00789](#)).

#### Condition 2: A certain commutation angle has been covered

In this case monitoring works according to the principle of checking for each motor phase that a current flows depending on the commutation angle.

- ▶ Monitoring responds if a certain commutation angle (approx. 150°) is covered without the current having exceeded a (non-parameterisable) threshold that depends on the device power.



#### Note!

The dependence on the commutation angle also causes a dependence on the motor type used:

- The commutation angle and the angle at the shaft (number of pole pairs) of a synchronous machine are proportional. This makes it possible to predict which shaft angle is maximally covered in case of error.
- There still exists a slip between the commutation angle and the angle at the shaft of an asynchronous machine. This results in a load dependency which makes it impossible to predict a maximally covered shaft angle in case of error.
  - Thus, when a hoist is lowered (non-zero speed), it may happen that no rotating field is applied anymore but a DC current flows. In this case, condition 2 is not fulfilled anymore.

## 5.9.4.2 Checking the individual motor phases before operation is started

This function is available from software version V5.0!

From software version V5.0 a check via test signal application has been added. It injects a current into the machine before the actual operation is started, by means of which both a motor phase failure and the existence of the motor are checked. Only after the check has been carried out successfully, the actual operation is continued.

- ▶ The setpoint current amplitude corresponds to the lower of the two following values:

$$50\% \cdot \sqrt{2} \cdot \text{Rated device current}$$

or

$$50\% \cdot \sqrt{2} \cdot \text{Rated motor current}$$

- ▶ The test signal application is activated directly after controller enable if the following conditions are fulfilled:
  - In [C00597](#) a response other than "No response" is set.
  - No test mode is activated ([C00398](#) = 0).
  - No identification of pole position is active (by device command [C00002](#) = "51" or "52").
  - No identification procedure is active (by device command [C00002](#) = "71" or "72").
- ▶ The check actuates the response set in [C00597](#) if one or more motor phase currents have not reached a certain threshold value within 5 ms after controller enable.
  - The threshold value depends on the device power and cannot be parameterised.
  - If only one motor phase current does not reach the threshold value, "Motor phase U/V/W not available" is entered in the logbook.
  - If several motor phases do not reach the threshold value, the motor is considered as not connected, and "Motor not connected" is entered in the logbook.
- ▶ The check is completed successfully if all three motor phase currents have exceeded the threshold value. Then the actual operation is continued immediately.



### Note!

- As the check is cancelled immediately if all three motor phase currents have exceeded the threshold value, the setpoint current usually is not achieved.
- In order to be able to achieve the threshold value used for the check, the rated motor current must at least be 10 % of the maximum device current.
- This monitoring is independent of the further rotation of the commutation angle.

### 5.9.5 Maximum current monitoring

The ultimate motor current  $I_{ULT}$  to be parameterised in [C00620](#) is a limit value to protect the motor from destruction or influence of the rated data.

- ▶ This limit value must not be travelled cyclically during the drive process.
- ▶ The maximum current parameterisable in [C00022](#) should have a sufficient distance from this limit value.
- ▶ If the instantaneous value of the motor current exceeds the limit value set in [C00620](#), the response set in [C00619](#) is executed for motor protection (Lenze setting: Fault).




#### Note!

When you select a Lenze motor from the catalogue and transfer the plant parameters of the motor to the controller, the setting in [C00620](#) is automatically adjusted to the selected motor.

#### 5.10 Internal interfaces | "LS\_MotorInterface" system block

The **LS\_MotorInterface** system block provides the internal interfaces to the driving machine, consisting of the phase controller, speed controller, and motor control in the function block editor.



#### Note!

All input and output signals of the motor interface directly refer to the motor!

## Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
MI_dnPosCtrlAdaptLoad_n <a href="#">C02568/1</a>   DINT	Dynamic change of the proportional gain $V_p$ of the position controller during operation <ul style="list-style-type: none"> <li>For software versions lower than V5.0 the following applies: Internal limitation to 10 ... 200 %</li> <li>From software version V5.0 the following applies: Internal limitation to 0 ... 200 %</li> </ul>				
MI_dnPosCtrlAdaptMotor_n <a href="#">C02568/2</a>   DINT	Dynamic change of the proportional gain $V_p$ of the phase controller during operation <ul style="list-style-type: none"> <li>For software versions lower than V5.0 the following applies: Internal limitation to 10 ... 200 %</li> <li>From software version V5.0 the following applies: Internal limitation to 0 ... 200 %</li> </ul>				
MI_dnSpeedCtrlAdapt_n <a href="#">C02568/3</a>   DINT	Dynamic change of the proportional gain $V_p$ of the speed controller during operation <ul style="list-style-type: none"> <li>If the input is assigned, the following applies: <math>V_p = MI\_dnSpeedCtrlAdapt\_n [\%] * C00070</math></li> <li>If the input is not assigned, the following applies: <math>V_p = 100 \% * C00070 = C00070</math></li> <li>Internal limitation to 10 ... 200 %</li> <li>▶ <a href="#">Optimising the speed controller</a> (☞ 156)</li> </ul>				
MI_bResetSpeedCtrlIntegrator <a href="#">C02569/2</a>   BOOL	Reset integral action component in the speed controller <table border="1" data-bbox="643 981 1441 1016"> <tr> <td>TRUE</td> <td>Integral action component is reset to "0".</td> </tr> </table>	TRUE	Integral action component is reset to "0".		
TRUE	Integral action component is reset to "0".				
MI_dnTorqueHighLimit_n <a href="#">C02568/4</a>   DINT MI_dnTorqueLowLimit_n <a href="#">C02568/5</a>   DINT	Upper/lower limit value for correcting variable of the speed controller and total torque setpoint <ul style="list-style-type: none"> <li>These two inputs serve to select an external torque limitation.                             <ul style="list-style-type: none"> <li>– If the motor torque reaches the selected limits, the drive can no longer follow the speed setpoint!</li> <li>– If the torque limitation is active, the output <i>MI_bTorqueSetpointLimited</i> is set to TRUE.</li> </ul> </li> <li>100 % ≙ <a href="#">C00057/2</a></li> <li>Only a positive torque is permissible as upper limit value.</li> <li>Only a negative torque is permissible as lower limit value.</li> <li>The motor mounting position (<a href="#">C02527</a>) defines the assignment to the limitation inputs of the motor control.</li> <li>The internally effective torque limit values are displayed in <a href="#">C02559/1...2</a>.</li> </ul>				
MI_dnFluxSetpoint_n <a href="#">C02568/7</a>   DINT	Setpoint for the field controller				
MI_dnInertiaAdapt_n <a href="#">C02568/8</a>   DINT	Adaptation of the moment of inertia in [%] <ul style="list-style-type: none"> <li>If input is not assigned = 100 %</li> <li>Internal limitation to 0 ... 200 %</li> </ul>				
MI_dnBoostSet_n <a href="#">C02568/9</a>   DINT From V3.0	Boost voltage <ul style="list-style-type: none"> <li>100 % ≙ 1000 V</li> </ul>				
MI_bFlyingSyncBlocked <a href="#">C02569/16</a>   BOOL From V3.0	Block flying restart <ul style="list-style-type: none"> <li>▶ <a href="#">Flying restart function</a> (☞ 218)</li> </ul> <table border="1" data-bbox="643 1686 1441 1756"> <tr> <td>FALSE</td> <td>Flying restart is executed.</td> </tr> <tr> <td>TRUE</td> <td>Flying restart process is blocked.</td> </tr> </table>	FALSE	Flying restart is executed.	TRUE	Flying restart process is blocked.
FALSE	Flying restart is executed.				
TRUE	Flying restart process is blocked.				

# 9400 HighLine | Parameter setting & configuration

Motor interface

Internal interfaces | "LS\_MotorInterface" system block

Identifier <small>DIS code   data type</small>	Information/possible settings
MI_dnTorqueAdd_n <small>From V8.0</small> <a href="#">C02568/10</a>   DINT	<p>Additional torque feedforward control value in [%]</p> <p>This input serves to provide an additional torque setpoint. In this way, you can provide an additional torque for the basic functions manual jog, positioning and homing besides the acceleration feedforward control.</p> <ul style="list-style-type: none"> <li>100 % = motor reference torque</li> </ul> <p>If the controller is enabled, the torque setpoints at this input have a direct effect on the drive!</p> <p>The user has to</p> <ul style="list-style-type: none"> <li>apply the appropriate setpoint for every state of the drive.</li> <li>avoid setpoint step-changes.</li> </ul>
	- 200 %
	+ 200 %

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
MI_dwControlMode <small>DWORD</small>	<p>Active control structure of the motor control</p> <ul style="list-style-type: none"> <li>Displayed value is bit-coded:</li> </ul>
	Bit 1   Position control without feedback, external following error calculation
	Bit 2   Position control with encoder on the motor side
	Bit 3   Position control with encoder on the load side
	Bit 4   Speed control
	Bit 5   Torque control
MI_bMotorOrientationInverse <small>BOOL</small>	<p>Parameterised motor mounting position</p>
	FALSE   Motor mounting position in the same direction, setpoints are not defined.
	TRUE   Motor mounting position in the opposite direction, setpoints are reversed.
MI_dwReferenceSpeed <small>DWORD</small>	Parameterised motor reference speed ( <a href="#">C00011</a> ) in [rpm]
MI_dwReferenceTorque <small>DWORD</small>	<p>Reachable motor torque with <math>I_{max\_device}</math> (<a href="#">C00022</a>) in [mNm]</p> <ul style="list-style-type: none"> <li>1000 mNm <math>\equiv</math> 1 Nm</li> <li>Display in <a href="#">C00057/2</a> in [Nm]</li> </ul>
MI_bLimitationActive <small><a href="#">C02569/3</a>   BOOL</small>	<p>Status signal "Internal limitation active"</p> <ul style="list-style-type: none"> <li>Group signal for all limitation messages.</li> </ul>
	TRUE   One of the internal limitations is active.
MI_bPosCtrlLimited <small><a href="#">C02569/4</a>   BOOL</small>	<p>Status signal "Phase/position controller at the limit"</p>
	TRUE   The limitation of the phase and/or position controller is active.
MI_bSpeedSetPointLimited <small><a href="#">C02569/5</a>   BOOL</small>	<p>Status signal "Resulting speed setpoint at the limit"</p>
	TRUE   The resulting speed setpoint is limited to the limit values parameterised in <a href="#">C00909/1</a> and <a href="#">C00909/2</a> .
MI_dnSpeedSetpoint_n <small>DINT</small>	<p>Current speed setpoint from position control and speed feedforward control or direct setpoint selection in [%]</p> <ul style="list-style-type: none"> <li>After limitation by the upper speed limit value (<a href="#">C00909/1</a>) and lower speed limit value (<a href="#">C00909/2</a>).</li> <li>100 % <math>\equiv</math> Motor reference speed (<a href="#">C00011</a>)</li> </ul>
MI_dnSpeedSetpoint_s <small>DINT</small>	<p>Current speed setpoint from position control and speed feedforward control or direct setpoint selection in [rpm]</p> <ul style="list-style-type: none"> <li>After limitation by the upper speed limit value (<a href="#">C00909/1</a>) and lower speed limit value (<a href="#">C00909/2</a>).</li> </ul>

Identifier <small>DIS code   data type</small>	Value/meaning
MI_bSpeedFollowingError <small><a href="#">C02569/10</a>   BOOL</small>	Status signal "Impermissible speed control deviation" TRUE   Speed control deviation is higher than the window set in <a href="#">C00576</a> .
MI_bSpeedCtrlLimited <small><a href="#">C02569/6</a>   BOOL</small>	Status signal "Speed controller at the limit" TRUE   The speed controller limitation is active.
MI_bTorqueSetpointLimited <small><a href="#">C02569/7</a>   BOOL</small>	Status signal "Total torque setpoint at the limit" TRUE   The total torque setpoint is limited.
MI_dnTorqueSetpoint_n <small>DINT</small>	Current torque setpoint from speed control and torque feedforward control or direct setpoint selection • After limitation by <i>MI_dnTorqueLimit_n</i> . • 100 % ≙ <a href="#">C00057/2</a>
MI_dnFilteredTorqueSetpoint_n <small>DINT</small>	Filtered torque setpoint (after jerk limitation and band-stop filter) • 100 % ≙ <a href="#">C00057/2</a>
MI_bCurrentSetpointLimited <small><a href="#">C02569/8</a>   BOOL</small>	Status signal "Setpoint for current controller at the limit" TRUE   The setpoint for the current controller is limited to $I_{\max\_device}$ ( <a href="#">C00022</a> ).
MI_bMotorOverloadWarning <small><a href="#">C02569/11</a>   BOOL</small>	Status signal "Motor overload" • Group signal for warning signals from temperature monitoring (KTY, PTC, thermal switch) or $I^2xt$ monitoring. TRUE   One of the monitoring modes for motor overload protection is active.
MI_bSpeedBelowThresholdC19 <small><a href="#">C02569/9</a>   BOOL</small>	Status signal "Standstill reached" TRUE   The current speed is below the threshold set in <a href="#">C00019</a> .
MI_dnActualMotorCurrent_n <small>DINT</small>	Actual motor current • 100 % ≙ $I_{\max\_device}$ ( <a href="#">C00789</a> ) • Display in <a href="#">C00780</a> in [A]
MI_dnActualMotorVoltage_n <small>DINT</small>	Current motor voltage • 100 % ≙ 1000 V • Display in <a href="#">C00783</a> in [V]
MI_dnActualMotorTorque_n <small>DINT</small>	Current motor torque • 100 % ≙ <a href="#">C00057/2</a> • Display in <a href="#">C00774</a> in [Nm]
MI_dnActualMotorSpeed_n <small>DINT</small>	Current speed of the motor shaft in [%] • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> )
MI_dnActualMotorSpeed_s <small>DINT</small>	Current speed of the motor shaft in [rpm] • Display under <a href="#">C00772</a>
MI_dnActualMotorPos_p <small>DINT</small>	Current position of the motor shaft in [increments] • Display under <a href="#">C00770</a>
MI_dnActualDCBusVoltage_n <small>DINT</small>	Actual DC-bus voltage • 100 % ≙ 1000 V
MI_dnThermalLoadDevice_n <small>DINT</small>	Thermal device utilisation in [%] • Current result of the $Ixt$ calculation. • Display in <a href="#">C00064</a> ▶ <a href="#">Monitoring of the device utilisation</a> (□ 116)
MI_dnThermalLoadMotor_n <small>DINT</small>	Thermal motor utilisation in [%] • Current result of the $I^2xt$ calculation. • Display in <a href="#">C00066</a> ▶ <a href="#">Motor monitoring (<math>I^2xt</math>)</a> (□ 224)
MI_dnActualMotorFreq_s <small>DINT</small> <small>From V3.0</small>	Current motor frequency in [Hz] The motor frequency corresponds to the field frequency [Hz]. Field frequency [Hz] = motor speed × number of motor pole pairs

# 9400 HighLine | Parameter setting & configuration

Motor interface

Internal interfaces | "LS\_MotorInterface" system block

Identifier <small>DIS code   data type</small>	Value/meaning
MI_dnActualFlux_n <small>DINT</small> <small>From V3.0</small>	Actual flux value
MI_bFlyingSyncBusy <small>C02569/13   BOOL</small> <small>From V3.0</small>	Status signal "Flying restart is active" ▶ <a href="#">Flying restart function (☰ 218)</a>
	TRUE   Flying restart is executed.
MI_bClampsActive <small>C02569/14   BOOL</small> <small>From V3.0</small>	Status signal "Clamping is active"
	TRUE   Clamping is active.
MI_bMagnetisationFinished <small>C02569/15   BOOL</small> <small>From V3.0</small>	Status signal "Motor magnetisation is completed"
	TRUE   Motor magnetisation is completed.



## 6 Encoder evaluation

This chapter contains information on how to use feedback systems for the motor control.



### Danger!

If the encoder/resolver is used as motor encoder:

In case of error, safe operation of the motor is no longer guaranteed!

When servo control is used:

- For the (open circuit) monitoring of the encoder/resolver for reasons of safety always the "Fault" response (Lenze setting) should be set!

When V/f control is used:

- For this type of motor control, the drive basically is to coast down after an encoder failure and may not stop, therefore the "Warning" response is to be set for the (open circuit) monitoring in this case!

Parameters for the (open circuit) monitoring:

- [C00580](#): Response to open circuit of encoder
- [C00586](#): Response to open circuit of resolver
- [C00601](#): Response to communication error of encoder



### Note!

The encoder position is stored safe against mains failure in the memory module and is therefore known to the drive control even after the mains has been switched.

With regard to their position resolution, higher-level applications are based on the resolution of the encoder which is activated for position control.

#### Behaviour of the home position after mains switching


If the home position/information is also to be available after mains switching, the setting [C02652](#) = "1: Received" is required.

- Another condition for keeping the home position/information after mains switching is the compliance with the maximum permissible angle of rotation of the encoder, which can be set in [C02653](#).
- When resolvers or single-turn absolute value encoders are used and the mains is switched off (24 V supply off), the encoder may only be moved by ½ revolution since otherwise the home position will get lost due to the ambiguity of the encoder information.

See also: [▶ Parameterise motor encoder \(134\)](#)

## 6.1 Internal interfaces | "LS\_Feedback" system block

The **LS\_Feedback** system block provides the internal interfaces for the basic function "Encoder evaluation" in the function block editor.



### Inputs

Identifier	Data type	Information/possible settings
FDB_dnPosOffset_p	DINT	Offset for position setpoint and actual position in [increments]
FDB_dnActPosIn_p	DINT	External actual position in [increments] <ul style="list-style-type: none"> <li>For the selection of an external actual position with a corresponding position control.</li> </ul> <a href="#">▶ Use of an external position encoder (EN 244)</a>

### Outputs

Identifier	Value/meaning
FDB_dnActualPos_p	Current position of the position encoder in [increments]
FDB_dnActualSpeed_s	Current speed of the position encoder in [rpm]
FDB_dnPosFollowingError_p	Current following error in [increments]
FDB_dnSetPos_p	Set position calculated by active basic drive function in [increments] <ul style="list-style-type: none"> <li>Considering the motor mounting position.</li> <li>In the case of an active speed or torque control (instead of position control) the actual position (<i>FDB_dnActualPos_p</i>) is shown at this output.</li> </ul>
FDB_dnSetSpeed_s	Setpoint speed calculated by active basic drive function in [rpm] <ul style="list-style-type: none"> <li>Considering the motor mounting position.</li> </ul>
FDB_bResolverError	Status signal "Resolver error"
<a href="#">C02579/1</a>   BOOL	TRUE   A resolver error (e.g. open circuit) has occurred.
FDB_bSinCosSignalError	Status signal "sine/cosine encoder error"
<a href="#">C02579/2</a>   BOOL	TRUE   A sine/cosine encoder error has occurred.

Identifier DIS code   data type	Value/meaning
FDB_bEncoderComError <a href="#">C02579/3</a>   BOOL	Status signal "Encoder communication error" TRUE   An encoder communication error has occurred.
FDB_dnSetAcc_x  From V7.0	Setpoint acceleration calculated by active basic function <ul style="list-style-type: none"> <li>• Considering the motor mounting position.</li> <li>• For the basic functions <a href="#">Stop</a>, <a href="#">Manual jog</a>, <a href="#">Homing</a> and <a href="#">Positioning</a>, the internal acceleration resulting from the profile generation is output.</li> <li>• For the basic functions <a href="#">Quick stop</a>, <a href="#">Position follower</a> and <a href="#">Speed follower</a>, the acceleration from the differentiated setpoint speed is determined. <a href="#">C02562</a> serves to filter the determined acceleration.</li> <li>• With an active torque control or in a non-controlled operation (function states "Controller not ready" and "Error"), the value "0" is output.</li> </ul>

## 6.1.1 Use of an external position encoder

The *FDB\_dnActPosIn\_p* input serves to evaluate an external encoder (CAN, SSI, Profibus) for the position control.

- ▶ Via this input, a current actual position of an external encoder in [increments] can be directly transferred to the encoder evaluation.



### How to activate the use of the external actual position:

On the **Application parameters**

tab in the dialog level *Overview* → *Drive interface* → *Machine parameters*:


1. Select the "Position controller active" setting in the **Position control structure** list field ([C02570](#)), so that the position encoder is evaluated.
2. Set "From application" in the **Position encoder selection** list field ([C00490](#)).



### Note!

- Encoder inversion and offset selection *FDB\_dnPositionOffset\_p* also affect the external actual position.
- If the use of the external actual position preset via *FDB\_dnActPosIn\_p* is activated, the "Home position known" status (*HM\_bHomePosAvailable* = TRUE) is automatically set and homing with the basic function "Homing" cannot be activated anymore.
- If the traversing range ([C02528](#)) is set to "Modulo", the external actual position also has to be defined as modulo (0 ... cycle-1).

## 6.2 Signal flow



[6-1] Signal flow - encoder evaluation

### Internal variables of the motor control (oscilloscope signals)

▶ The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (590)

No.	Variable of the motor control	Meaning
(1)	Position.dnActualLoadPos	Actual position
(2)	Position.dnActualMotorPos	Current motor position
(3)	Speed.dnActualMotorSpeed	Current motor speed
(4)	Speed.dnActualEncoderSpeed	Current encoder speed
(5)	Speed.dnActualResolverSpeed	Current resolver speed

## 6.3 Parameter setting

Short overview of parameters for the encoder evaluation:

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00058/1</a>	Pole position resolver	-90.0	°
<a href="#">C00058/2</a>	Rotor displ. angle encoder	0.0	°
<a href="#">C00058/3</a>	Pole position module	0.0	°
<a href="#">C00080</a>	Resolver - number of pole pairs	1	
<a href="#">C00416</a>	Resolver error correction	0	
<a href="#">C00417</a>	Dynamics of the resolver evaluation	100	%
<a href="#">C00418</a>	Activate resolver error compensation	Deactivated	
<a href="#">C00420</a>	Encoder - number of increments	512	
<a href="#">C00421</a>	Encoder voltage	5.0	V
<a href="#">C00422</a>	Encoder type	Incremental encoder (TTL signal)	
<a href="#">C00423</a>	SSI encoder: Bit rate	400	kbps
<a href="#">C00424</a>	SSI encoder: Data word length	25	Bit
<a href="#">C00427</a>	TTL encoder signal evaluation	4x evaluation (A, B)	
<a href="#">C00435/1...8</a>	SSI encoder: Partword starting position	0	
<a href="#">C00436/1</a>	SSI encoder: partword length (partword 1)	31	
<a href="#">C00436/2...8</a>	SSI encoder: partword length (partwords 2...8)	0	
<a href="#">C00437/1...8</a>	SSI encoder: partword coding	Binary coded	
<a href="#">C00490</a>	Position encoder selection	Motor encoder	
<a href="#">C00495</a>	Motor encoder selection	Resolver X7	
<a href="#">C00497</a>	Speed act. val. time const.	2.0	ms
<a href="#">C00579</a>	Resp. to speed monitoring	Off	
<a href="#">C00580</a>	Resp. to encoder open circuit	Fault	
<a href="#">C00586</a>	Resp. to resolver open circuit	Fault	
<a href="#">C00601</a>	Resp. to encoder fault	Fault	
<a href="#">C00621</a>	Resp. to angular drift of encoder	No response	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating CW	
<a href="#">C02529</a>	Position encoder mounting direction	Encoder rotating CW	
<a href="#">C02570</a>	Position control structure	Phase controller is active	
<a href="#">C02572</a>	Speed setpoint (enc. eval.)	-	Unit/s
<a href="#">C02573</a>	Position setpoint (enc. eval.)	-	Unit
<a href="#">C02574</a>	Actual speed (encoder eval.)	-	Unit/s
<a href="#">C02575</a>	Actual position (enc. eval.)	-	Unit
<a href="#">C02576</a>	Following error	-	Unit
<a href="#">C02577</a>	External actual position	-	Unit
<a href="#">C02578</a>	Offset actual pos. value/setp.	-	Unit
<a href="#">C02760</a>	Activate Encoder	Deactivated	
<a href="#">C02761</a>	Resolution Multiturn	-	Rev
<a href="#">C02762</a>	Encoder position	-	Steps.
<a href="#">C02763</a>	Encoder position	-	Rev
<a href="#">C02764</a>	Encoderspeed	-	rpm

Highlighted in grey = display parameter

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02765</a>	ENC_bError	-	
<a href="#">C02862/1</a>	Resolver: Cos gain	100	%
<a href="#">C02862/1</a>	Resolver: Sin gain	100	%
<a href="#">C02863</a>	Resolver: Angle correction	0	


Highlighted in grey = display parameter



## How to get to the dialog for setting the encoder evaluation parameters:

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Select the **Application parameters** tab from the *Workspace*.
3. Click the button **All basic functions** in the *Overview* dialog level.
4. Click the button **Encoder evaluation** in the dialog level *Overview* → *All basic functions*.

## Parameterisation dialog in the »Engineer«



See also: [▶ Parameterise motor encoder \(134\)](#)

## 6.3.1 Controller configuration

The device interfaces for the encoder on the motor side and, if available, on the load side are directly assigned to the corresponding control according to the structure of the position control selected ([C02570](#)):

	Phase control (Lenze setting)	Position control
<b>Cycle time:</b>	250 µs	Application-dependent
<b>Dead time:</b>	Smaller dead time in the actual value channel	Same dead time for position setpoint and actual position
<b>Use:</b>	In positioning technology and single-axis applications or if only one encoder is used.	In multi-axis applications or if a position encoder is used in addition to the motor encoder.

- ▶ If only an encoder on the motor side is available, this "motor encoder" provides the actual value signals for the phase/position control and the speed control.
  - In this case both the angle control and the position control can be selected.
  - When selecting the position control, make sure that the position encoder selection "10: Motor encoder (C00495)" is set in [C00490](#). With this selection, the mounting position and the resulting gearbox factor are already considered.
  - The motor encoder supports the secondary servo control irrespective of the use for position and speed control (commutation).
- ▶ If an additional encoder is available on the load side, this "position encoder" only supports the position control and [C02570](#) accordingly has to be set to "Position controller active", so that the position encoder is evaluated.
  - The used position encoder must be set in [C00490](#).
  - The position encoder mounting direction must be set in [C02529](#).
  - The starting position of the position encoder can be set via the basic function "Homing".



### Note!

When the basic function "Quick stop" is activated, the controller configuration is always switched over to angle control internally, irrespective of the setting in [C02570](#).

- If the basic function "Quick stop" is to be used, the gain of the phase controller ([C00254](#)) must also be set correctly for the "Position control" controller configuration.

For the technology applications for the interconnection via the "Electrical shaft", the controller configuration is set to position control in the default setting.




From software version V7.0 onwards, the selection "3: Position controller active" is available in [C02570](#).

- ▶ In contrast to the already existing selection "2: Position controller active (<= FW V5.xx)", this selection considers the gearbox factor.
- ▶ Further explanations on this can be obtained from the following table:

<a href="#">C02570</a> = 2: Position controller active (<= FW V5.xx)	<a href="#">C02570</a> = 3: Position controller active
<p>When the separate position encoder at the output end is used, the reference speed to the tool is assumed. This causes the acceleration and deceleration times not to refer to the motor but to the encoder.</p> <p>In order to re-establish the motor reference, the desired acceleration time of the corresponding function must be multiplied by the resulting gearbox factor.</p> <p><b>Example:</b></p> <ul style="list-style-type: none"> <li>• Motor reference speed (C00011) = 3000 rpm</li> <li>• Resulting gearbox factor = 10</li> <li>• Acceleration time = 1 s</li> </ul> <p>With 10 % setpoint selection:</p> <ul style="list-style-type: none"> <li>• Motor speed = 100 % (3000 rpm)</li> <li>• Tool speed = 300 rpm</li> <li>• Acceleration time up to 10 % setpoint selection (100 % motor speed) = 0.1 s</li> </ul>	<p>When the separate position encoder at the output end is used, the reference speed is referred to the motor. Thus, all acceleration and deceleration times are calculated with regard to the reference speed at the motor.</p> <ul style="list-style-type: none"> <li>• Motor speed = 10 % (300 rpm)</li> <li>• Tool speed = 30 rpm</li> <li>• Acceleration time up to 10 % setpoint selection (10 % motor speed) = 0.1 s</li> </ul>

## 6.3.2 System with motor encoder

No encoder is installed on the load side. The motor position (angle of rotation) and motor speed are detected via the motor encoder selected in [C00495](#) and are converted with regard to the load side.



[6-2] Schematic diagram - feedback with position encoder = motor encoder


The actual position and actual speed values on the machine side result from the conversion via the gearbox factor on the motor side ([C02520/C02521](#)) and the feed constant ([C02524](#)).

See also:

- ▶ [Gearbox ratio](#) (□ 38)
- ▶ [Feed constant](#) (□ 43)

### 6.3.3 System with motor encoder and position encoder

The optional position encoder is used as a feedback for the position control and transmits the position of slide or drive roll to the controller.



[6-3] Schematic diagram - feedback with separate position encoder

In this case, the actual position and actual speed values on the machine side result from the conversion of the position encoder position via the resulting gearbox factor (ratio of the motor speed to the position encoder speed; display in [C02531/3](#)) and the feed constant ([C02524](#)).



#### How to activate the use of a separate position encoder:

On the **Application parameters**

tab in the dialog level *Overview* → *Drive interface* → *Machine parameters*:

1. Select the "Position controller active" setting in the **Position control structure** list field ([C02570](#)), so that the position encoder is evaluated.
2. Select the position encoder available in the **Position encoder selection** list field ([C00490](#)).
3. Select the gearbox ratio of the position encoder (ratio of load speed to encoder speed) as a quotient (numerator/denominator) which results from the resulting teeth number:
  - Enter numerator in the input field **Gearbox fact. num.: Pos. enc.** ([C02522](#)).
  - Enter denominator in the input field **Gearbox fact. denom.: Pos. enc.** ([C02523](#)).
4. If required, adapt the position encoder mounting direction via the **Position encoder mounting direction** list field ([C02529](#)). The position encoder mounting direction is preset to "Encoder rotating CW".



#### Tip!

In [C02531/2](#) the gearbox factor is displayed in decimal format.

Important reference variables converted to the load side:

- Motor reference speed ([C00011](#)) → Load reference speed ([C02542](#))
- Reference torque ([C00057/2](#)) → Load reference torque ([C02543](#))

See also: ▶ [Feed constant](#) (43)

## 6.3.4 Adaptation of the resolver evaluation dynamics

[This function extension is available from software version V5.0 onwards!](#)

---

The resolver evaluation of the controller is adapted to the resolver types mounted in Lenze motors and offers a good compromise between the dynamic performance and interference suppression. If the resolver is used as a speed feedback system, the dynamic performance of the resolver evaluation determines, among other things, the maximum speed controller gain by means of which stable operation is possible.

In a system with an EMC-compliant structure (low interference), you can increase the dynamics of the resolver evaluation in [C00417](#) without a loss in quality in the speed signal. By increasing [C00417](#), the evaluation gets more dynamic and thus the speed controller gain  $V_p$  ([C00070](#)) also increases without leaving the stable operating range.

The acceleration of the evaluation depends on the cable length, the resolver, and the quality of the electrical shielding. In many cases, a setting of [C00417](#) = 300 % is possible which can double the speed controller gain. The higher gain in the speed controller may reduce following errors.

*See also:*

- ▶ Servo control (SC): [Optimising the speed controller](#) (□ 156)
- ▶ Sensorless vector control (SLVC): [Optimising the speed controller](#) (□ 183)

### 6.3.5 Parameterisation of an unknown Hiperface encoder

This function extension is available from software version V4.0!

---

Application: A Hiperface encoder is to be used with the controller, the current firmware of which has not (yet) been stored permanently.



#### How to parameterise a Hiperface encoder unknown to the controller:

1. Determine the type code of the encoder.
  - If the encoder has already been connected and read out, the type code is indicated in [C00413](#).
  - Alternatively, the type code can be obtained from the manufacturer or gathered from the documentation for the encoder.
2. Set the type code of the encoder in [C00414](#).
  - Please observe that the decimal format has to be used for the setting. The type codes provided by the manufacturer, however, are in the hexadecimal format.
3. If a multi-turn encoder is used, set the number of displayable resolutions in [C00415](#).
  - This value can also be gathered from the documentation for the encoder.
4. Set the number of encoder increments in [C00420](#).
  - This step should be the last step because it initiates a new readout of the encoder.

## 6.3.6 Support of the laser measuring system (DME4000/5000)

This function extension is available from software version V4.0!

From software version V4.0, the laser measuring system (DME4000/5000) is supported. The laser measuring system provides the opportunity to set the period length on the encoder.



### Note!

Due to its properties, the laser measuring system may not be used as a motor encoder!

Within the controller the evaluation of optical encoders is dimensioned for rotary-operating encoders. Code [C00420](#) describes the number of encoder increments per mechanical motor revolution. In order to be able to correctly evaluate the laser measuring system, or an optical linear measuring scale in general, a back calculation from a linear movement to one motor revolution has to be carried out.

### Calculation of the number of increments for rotary machines

For rotary machines driving a slide via a spindle or similar, to which the length measuring system is mounted, the number of encoder increments ([C00420](#)) is calculated as follows:

$$\text{Number of increments} = \frac{\text{Distance covered on the encoder during one motor revolution}}{\text{Period length of the encoder}}$$

### Calculation of the number of increments for linear direct drives

If the controller activates a linear direct drive, one mechanical motor revolution is defined as follows:

$$\text{One mech. motor revolution} = 2 \cdot \text{length of a pole pitch} \cdot \text{number of pole pairs}$$

The length of a pole pitch describes the distance between the north and south pole at the linear direct drive. The number of encoder increments ([C00420](#)) thus is calculated as follows:

$$\text{Number of increments} = \frac{2 \cdot \text{length of a pole pitch} \cdot \text{number of pole pairs}}{\text{Period length of the encoder}}$$

### 6.3.7 Use of an SSI encoder at X8

This function extension is available from software version V5.0 onwards!

From software version V5.0 all encoders at X8 using the Stegmann SSI protocol are supported.

- ▶ Supported bit rates for the SSI communication: 150 ... 1000 kbits
- ▶ Supported data word widths: 1 ... 31 bits (effectively)
- ▶ Supported output code of the SSI encoder: Gray or binary
- ▶ The SSI encoder can be used as position encoder or master encoder with a minimum cycle time of 1 ms.
- ▶ The SSI encoder can be supplied with a voltage of up to 12 V and a current of 0.25 A via X8.
- ▶ The SSI data words received are provided to the application via the [LS SsiEncoderX8](#) system block for further processing within the function block editor.



#### Note!

The [LS SsiEncoderX8](#) SB is only provided within controllers with a MM3xx or MM4xx memory module.



#### How to parameterise the SSI encoder at X8:

1. Set the supply voltage of the SSI encoder used in [C00421](#).
2. Set the selection "4: SSI encoder" as encoder type in [C00422](#).
3. Set the bit rate for SSI communication in [C00423](#).
  - In the case of the SSI protocol, the permissible baud rate decreases with an increasing cable length. Depending on the length of the encoder cable used and the electromagnetic interference level, a safe bit rate must be set here.
  - Lenze setting: 400 kbits (for encoder cables with a length of up to  $\approx$  50 meters)
4. Set the data word width in [C00424](#), i. e. the number of data bits that is used for the transmission of a complete SSI data packet.
  - Lenze setting: 25 bits (Stegmann multiturn SSI encoder)
5. Optionally: Split the SSI data word received into partwords and connect a data conversion from Gray into binary code, which may be required (see the following subchapters).


## 6.3.7.1 "LS\_SsiEncoderX8" system block

The **LS\_SsiEncoderX8** system block provides the SSI data words received to the application for further processing in the function block editor.



### Note!

- The **LS\_SsiEncoderX8** SB is only provided within controllers with a MM3xx or MM4xx memory module.
- If a position is transmitted in the SSI data word, it is output in an unchanged manner with regard to the position format by the **LS\_SsiEncoderX8** SB. For a use of the SSI encoder as position encoder the position has to be converted into the 9400 format afterwards by means of the **L\_EsEncoderConv** FB.



## Outputs

Identifier	Data type	Value/meaning
SSI_dwDataword_1	DWORD	SSI partword 1 • In the Lenze setting the complete SSI data word received is shown at this output without a conversion of the data format.
SSI_dwDataword_2 ... SSI_dwDataword_8	DWORD	SSI partwords 2 ... 8 • In the Lenze setting these outputs are deactivated. ▶ <a href="#">Division of the SSI data word into partwords</a> (□ 257)

## Gray-binary conversion

If an SSI encoder with Gray coding is used, a data conversion of Gray-to-binary code can be connected in [C00437/1...8](#) individually for each output of the **LS\_SsiEncoderX8** SB, and thus for each partword.

- ▶ In the Lenze setting "Binary coded" there is no conversion, i. e. an SSI encoder with binary coding is expected.




## 6.3.7.2 Division of the SSI data word into partwords

The [LS SsiEncoderX8](#) SB can be configured so that it splits up the SSI data word received by the encoder interface into several partwords.

- ▶ A separation into partwords is reasonable if the SSI data word also contains other data (like for instance fault or status information) in addition to the position.
- ▶ The max. 8 possible partwords are fixedly assigned to the outputs *SSI\_dwDataword\_1* ... *SSI\_dwDataword\_8*.
- ▶ The partwords are configured via the following parameters:


Parameter	Information
<a href="#">C00435/1...8</a>	<b>Starting position for partwords 1 ... 8</b> In order to be able to display the individual components of the SSI data word received at different outputs, this code serves to specify the bit position with which the partword for the respective output starts for the eight possible outputs of the <a href="#">LS SsiEncoderX8</a> SB . Subcode 1 is fixedly assigned to the first output, subcode 2 to the second output, etc.
<a href="#">C00436/1...8</a>	<b>Length of the partwords 1 ... 8</b> Apart from the position of the first bit, also the bit length of each partword is important for the separation. A length of zero means that no partword is to be shown at the corresponding output (output = 0). Here also subcode 1 is fixedly assigned to the first output, subcode 2 to the second output, etc.

- ▶ In the Lenze setting the complete SSI data word received is shown at the output *SSI\_dwDataword\_1*:



[6-4] Example 1: Lenze setting

- ▶ The following example shows the parameterisation required to split up the SSI data word received into three partwords (here status information, error bit, and position information):



[6-5] Example 2: Splitting up the SSI data word received into three partwords

## 6.3.8 Provision of the encoder signal of input X8

This function extension is available from software version V7.0!

The **LS\_EncoderX8** system block serves to provide the encoder signal of input X8 to the application, independent of the selected feedback system for the motor encoder and position encoder.

### Application cases:

- ▶ High-resolution speed encoder as master encoder /value, correcting signal, ...
- ▶ Absolute value encoder for length measurements
- ▶ Display of the absolute encoder value without considering an offset




### Note!

For SSL encoders, the **LS\_SsiEncoderX8** system block must be used. ▶ [Use of an SSI encoder at X8](#) (📖 255)

### 6.3.8.1 System block "LS\_EncoderX8"

The **LS\_EncoderX8** system block provides the input X8 to the application in the function block editor.



### Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
ENC_dnEncoderOut1 <a href="#">C02762</a>   DINT	Display of the current encoder position (steps) within one revolution <ul style="list-style-type: none"> <li>• 1 revolution <math>\equiv 2^{32}</math> bits</li> </ul> <b>Note:</b> In order to convert the encoder information/position into a position_p in the internal measuring system, connect both outputs <i>ENC_dnEncoderOut1</i> and <i>ENC_dnEncoderOut2</i> with the inputs <i>dnEncoderIn</i> and <i>dnEncoderIn2</i> of the FB <b>L_EsEncoderConv</b> . A storage with mains failure protection of the position signal is also processed via this FB.
ENC_dnEncoderOut2 <a href="#">C02763</a>   DINT	Display of all revolutions of the encoder (only with Multiturn) <ul style="list-style-type: none"> <li>• After the max. presentable revolutions have been reached, the value jumps back to "0".</li> <li>• <a href="#">C02761</a> shows the max. presentable revolutions of the MultiTurn encoder (encoder-dependent).</li> <li>• In case of SingleTurn, the value "0" is always output.</li> </ul>

Identifier <small>DIS code   data type</small>	Value/meaning
ENC_dnActualSpeed_s <a href="#">C02764</a>   DINT	Current encoder speed in [rpm]
ENC_bError <a href="#">C02765</a>   BOOL	Status signal "Encoder error"
	TRUE   An encoder error has occurred.

### 6.3.8.2 Activate evaluation

[C02760](#) serves to activate the evaluation of the encoder signal of input X8.

- ▶ When the evaluation is activated, the encoder parameterised in [C00422](#) is read in.
  - At the same time, the monitoring functions are active. If no encoder is available, the corresponding monitoring functions are triggered.
- ▶ When the evaluation is deactivated, the outputs of the system block are reset.
  - Monitoring is deactivated depending on the position encoder selection ([C00490](#)) and the motor encoder selection ([C00495](#)).

#### Monitoring

The monitoring functions depend on the encoder type selected in [C00422](#) and do not differ from the existing monitoring functions:

- ▶ Open circuit of encoder (response: [C00580](#))
- ▶ [Encoder angular drift monitoring](#) (□ 263)
- ▶ Encoder communication error (*FDB\_bEncoderComError*; response: [C00601](#))
- ▶ Sine/cosine encoder error (*FDB\_bSinCosSignalError*)
- ▶ Group signal for errors as process date (*ENC\_bError*)

#### Conditioning of the encoder signal

- ▶ The encoder signal is conditioned to a position (including a storage with mains failure protection) within the application using the FB **L\_EsEncoderConv**:
  - Interconnection of the *ENC\_dnEncoderOut1* output signal with the *dnEncoderIn* input of the FB **L\_EsEncoderConv**.
  - Interconnection of the *ENC\_dnEncoderOut2* output signal with the *dnEncoderIn2* input of the FB **L\_EsEncoderConv**.
  - Additional parameter setting of the FB **L\_EsEncoderConv**:
    - Mode selection: Cxxxx = 1
    - Number of revolutions transmitted from [C02761](#)
  - The (optional) reconstruction of the position after mains switching is also made by the FB **L\_EsEncoderConv**.
- ▶ In contrast, the conditioning of the encoder signal to a speed is directly made in the [LS\\_EncoderX8](#) system block.
  - The current encoder speed is provided at the *ENC\_dnActualSpeed\_s* output in [rpm] (display parameter: [C02764](#)).
- ▶ TouchProbe function is not supported (continues to be only available for motor and position encoders).

# 9400 HighLine | Parameter setting & configuration

Encoder evaluation

Parameter setting

- ▶ If the encoder at X8 is simultaneously used as motor or position encoder, the "raw value" of the encoder is continued to be output.

## Display parameters

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02761</a>	Resolution Multiturn	-	Rev
<a href="#">C02762</a>	Encoder position: Steps within one revolution	-	Steps
<a href="#">C02763</a>	Encoderrev: Number of revolutions	-	Rev
<a href="#">C02764</a>	Encoderspeed	-	rpm
<a href="#">C02765</a>	Encoder error	-	

Highlighted in grey = display parameter

### 6.3.9 Resolver error compensation

This function extension is available from software version V7.0!

Resolver errors typically occur in form of the 1st and 2nd harmonic. They have two different causes:

1. The inductances of the sine and cosine track of the resolver have slightly different values.
2. The sine and cosine track do not magnetise orthogonally to each other.

The resolver error which is based on cause 1 can be corrected by adapting the gains of the digital/analog converters which feed the resolver tracks. In the Lenze setting, the gains for both resolver tracks are preset identically.

A resolver error based on cause 2, can be compensated by a slight correction of the angle which serves to feed the two resolver tracks relatively to each other.

By executing the device command [C00002](#) = "59: Resolver error identification", the gain of the digital/analog converter for feeding the resolver and the angle which serves to feed the two resolver tracks relatively to each other are corrected so that the resolver error is minimised.

- ▶ A precondition for the execution of the device command is that the machine is in speed-controlled operation (servo control). The speed amount during the identification must be constant and higher than 500 rpm.
- ▶ After the resolver error identification has been executed successfully, the resolver error compensation is activated automatically ([C00418](#) = "1: Activated"). Now the resolver operates with the following resolver error parameters which have been identified during the procedure:

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02862/1</a>	Resolver: Cos gain	100	%
<a href="#">C02862/1</a>	Resolver: Sin gain	100	%
<a href="#">C02863</a>	Resolver: Angle correction	0	

- ▶ The detected gain can take values between 0 ...100 %.
  - With a setting of 0 %, the gain of the corresponding resolver track is only 95 % of the default setting.
  - With a sensible resolver error compensation only one of the two gains is adapted. The other remains at 100 %.
- ▶ For a permanent acceptance of the identified resolver error parameters, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- ▶ When the resolver error compensation is deactivated ([C00418](#) = "0: Deactivated"), the resolver operates with the Lenze setting again. The identified resolver error parameters remain stored.

The resolver error identification can fail due to the following:

- ▶ Wrong control mode is active (no servo control)
- ▶ Error or fault is active
- ▶ Another identification is active
- ▶ The speed is too low (< 500 rpm)
- ▶ Time-out while the algorithm is processed

### 6.3.10 Encoder angular drift monitoring

The optional encoder angular drift monitoring monitors a potential deviation between the actual encoder angle and the angle calculated by the counting of increments in the encoder evaluation.



The encoder angular drift monitoring is activated by parameterising an error response that is not "0: No response" in [C00621](#).

If a deviation greater than 45° (electrical) is detected while monitoring is activated:

- ▶ The error message "Encoder monitoring: pulse deviation detected" is entered in the logbook of the controller.
- ▶ The error response parameterised in [C00621](#) is triggered.
- ▶ The "Reference known" status of the basic drive function "Homing" is reset (provided that this status was set before).



#### Tip!

A deviation can for instance occur by incorrect parameter setting of the encoder increments, by additional increments due to EMC interferences, or by an EMC-related loss of increments.

The encoder angular drift monitoring is implemented for encoders with and without absolute information by two different principles which are explained in detail in the following subchapters.

#### 6.3.10.1 Angular drift monitoring for encoders without absolute information

When an encoder without absolute information is used, the number of increments between two zero pulses (one revolution) is monitored. This value must equal the encoder increments set in [C00420](#).



#### Note!

After mains switching, the monitoring function is only active after the second zero pulse, since the first difference in increments to be used can only be calculated with the second and first zero pulse.

When the motor (and thus the encoder) is replaced, an angular drift error is likely to occur within the first revolution after the encoder error is acknowledged, since the monitoring function cannot recognise that the encoder has been replaced.

### 6.3.10.2 Angular drift monitoring for encoders with absolute information

When an encoder with absolute information is used, cyclic communication with the encoder takes place and the angle is read out digitally. This angle is compared with the angle from the encoder evaluation.



#### Note!

If monitoring is deactivated ([C00621](#) = "0: No response"), there is no cyclic communication with the encoder, and therefore no communication errors with the encoder can occur.

If monitoring is activated, it is only carried out for speeds below 100 rpm due to runtimes for communication .

- If increments get lost at higher speeds, this deviation can only be detected if the speed is below 100 rpm for at least 80 ms.

After every detected angular drift error of the encoder, the position is automatically read out again and this angle is written into the encoder evaluation. This makes it possible to acknowledge the error. When synchronous machines are used, the pole position is corrected again simultaneously.



## 7 Braking operation

The 9400 HighLine controller as a single-axis controller (Single Drive) is provided with an integrated brake transistor.

- ▶ The required brake resistor must be connected externally (see Mounting Instructions/ Hardware Manual).
- ▶ The rated values for the internal brake transistor are given in the Hardware Manual in the "Rated data" chapter.



### Stop!

If the brake resistor actually connected is smaller than the brake transistor parameterised, the brake chopper can be destroyed!

The brake resistor can be overloaded thermally. Carry out protective measures suitable for the installation, e.g.:

- Parameterisation of an error response in [C00574](#) and evaluation of the parameterised error message within the application or within the machine control. ▶ [I2t utilisation - brake resistor](#) (📖 269)
- External wiring using the temperature contact on the brake resistor (e.g. interruption of the supply via mains contactor and activation of the mechanical brakes).



### Note!

The brake chopper control is also guaranteed if, for example, the application stands still or the 24-V supply is not connected and the controller is only fed by the DC bus.

## 7.1 Parameter setting

### Short overview: Parameters for braking operation

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00129</a>	Brake resistor value	180.0	Ohm
<a href="#">C00130</a>	Rated power of brake resistor	5600	W
<a href="#">C00131</a>	Rated heat quantity of brake resistor	485	kWs
<a href="#">C00133</a>	Ref.: Brake chopper utilisation	Minimum resistance (C00134)	
<a href="#">C00134</a>	Min. brake resistance	-	Ohm
<a href="#">C00137</a>	Brake transistor utilisation	-	%
<a href="#">C00138</a>	Brake resistor utilisation	-	%
<a href="#">C00173</a>	Mains voltage	400/415	V
<a href="#">C00181</a>	Reduced brake chopper threshold	0	V
<a href="#">C00569</a>	Resp. brake trans. ixt > C00570	Warning	
<a href="#">C00570</a>	Warning thres. brake transistor	90	%
<a href="#">C00571</a>	Resp. brake res. i2t > C00572	Warning	
<a href="#">C00572</a>	Warning thres. brake resistor	90	%
<a href="#">C00573</a>	Resp. to brake transistor overload	No response	
<a href="#">C00574</a>	Resp. to overtemp. brake resist.	No response	
<a href="#">C00600</a>	Resp. to DC bus overvoltage	Trouble	

Highlighted in grey = display parameter

### 7.1.1 Setting the voltage threshold for braking operation

The voltage threshold for the braking operation is set via [C00173](#) (mains voltage) and [C00181](#) (reduced brake chopper threshold). If the brake chopper threshold in the DC bus is exceeded, the brake transistor is switched on.

Mains voltage selected in C00173	Effective brake chopper threshold
230 V	390 V - value in <a href="#">C00181</a> (0 ... 100 V)
400/415 V	725 V - value in <a href="#">C00181</a> (0 ... 100 V)
460/480 V	765 V - value in <a href="#">C00181</a> (0 ... 100 V)
500 V	790 V - value in <a href="#">C00181</a> (0 ... 100 V)

## 7.2 Monitoring

### 7.2.1 Overcurrent protection

The brake chopper hardware is monitored with regard to overcurrent (short circuit or earth fault).



#### Note!

The monitoring with regard to overcurrent can only be triggered if a braking current is actually available. It is not possible to carry out a test in idle state (without connected brake resistor).

► If monitoring responds:

- The brake chopper is switched off immediately.
- The "Fault" response is activated.
- The "Brake transistor: overcurrent" error message is entered into the logbook of the controller.



#### Note!

The error can only be acknowledged after 2 seconds at the earliest to resume the braking operation.



#### Tip!

In addition to the overcurrent protection the controller is provided with two further monitoring functions for the braking operation, which are also activated if no brake resistor is connected at all (testing mode for checking the parameterisation):

► [Ixt utilisation - brake transistor](#) (📖 268)

► [I2t utilisation - brake resistor](#) (📖 269)


## 7.2.2 Ixt utilisation - brake transistor

The controller is provided with a monitoring function for the Ixt utilisation of the internal brake transistor.



### Note!

The braking operation will never be switched off by this monitoring function.



[7-1] Signal flow of Ixt utilisation - brake chopper

- ▶ Monitoring is based on a mathematical model which calculates the braking current from the current DC-bus voltage and the brake resistance parameterised.
  - Hence, monitoring can be activated although no brake resistor is connected and can therefore also be used for a testing mode to check the parameterisation.
- ▶ During the calculation the thermal utilisation of the brake transistor is taken into consideration by the use of an accordingly adapted time constant.
- ▶ In [C00133](#) it can be selected whether the minimum brake resistance (display in [C00134](#)) which depends on the network setting in [C00173](#)) or the brake resistor value parameterised in [C00129](#) is to be used as a reference for calculating the utilisation.
- ▶ [C00137](#) displays the calculated utilisation of the brake transistor in [%].
  - A 100 % utilisation corresponds to the continuous braking power which is provided by the integrated brake chopper at a DC-bus voltage of 790 V (or 390 V at a mains voltage of 230 V).
  - The maximum braking power (assuming that the utilisation starts at 0 %) can be provided for a time period depending on the device.
  - The calculated utilisation is provided as oscilloscope signal *Common.dnlxtBrakeChopper* to check the braking operation while the system is running (scaling:  $2^{30} \equiv 100 \%$ ).
- ▶ If the utilisation exceeds the advance warning threshold set in [C00570](#), "Brake chopper: Ixt > C00570" is entered in the logbook and the response set in [C00569](#) (default setting: "Warning") is activated.
- ▶ When the utilisation reaches the limit value (100 %):
  - The activation of the brake chopper is reset to the permanently permissible mark-to-space ratio (taking the parameterised brake resistance into consideration). (The brake chopper is activated with 4 kHz, which means that it can be switched on/off at minimum intervals of 250 µs.)
  - The response set in [C00573](#) (default setting: "No response") is activated with the corresponding effects on the state machine and the inverter.

**Note!**

If the DC-bus voltage exceeds the overvoltage threshold due to a too high braking energy, the monitoring function for overvoltage in the DC bus responds.


► [DC bus overvoltage](#) (□ 271)

**7.2.3 I2t utilisation - brake resistor**

The controller is provided with a monitoring function of the I<sup>2</sup>t utilisation of the brake resistor which is proportional to the converted braking power.

**Note!**

The braking operation will never be switched off by this monitoring function.



[7-2] Signal flow - I2t utilisation - brake resistor

- The monitoring function is based on the mathematical model which calculates the braking current from the current DC-bus voltage and the brake resistance parameterised in [C00129](#).
  - Hence, monitoring can be activated although no brake resistor is connected and can therefore also be used for a testing mode to check the parameterisation.
- The calculation considers the thermal utilisation of the brake resistor based on the following parameters:
  - Resistance value ([C00129](#))
  - Continuous power ([C00130](#))
  - Thermal capacity ([C00131](#))
- [C00138](#) displays the calculated utilisation of the brake resistor in [%].
  - A 100 % utilisation corresponds to the continuous power of the brake resistor which results at the maximum permissible temperature limit of the brake resistor.
  - The calculated utilisation is provided as oscilloscope signal *Common.dnI2tBrakeResistor* to check the braking operation while the system is running (scaling:  $2^{30} \equiv 100\%$ ).
- If the utilisation exceeds the advance warning threshold set in [C00572](#), "Brake resistor: I2t > C00572" is entered in the logbook and the response set in [C00571](#) (default setting: "Warning") is activated.

- ▶ When the utilisation reaches the limit value (100 %):
  - The response set in [C00574](#) (default setting: "No response") is activated with the corresponding effects on the state machine and the inverter.
  - **Only applies to software versions lower than V3.0:**

The activation of the brake chopper is reset to the permanently permissible mark-to-space ratio (taking the parameterised brake resistance into consideration). (The brake chopper is activated with 4 kHz, which means that it can be switched on/off at minimum intervals of 250 µs.)



## Stop!

The brake resistor can be overloaded thermally. Carry out protective measures suitable for the installation, e.g.:

- Parameterisation of an error response in [C00574](#) and evaluation of the parameterised error message within the application or within the machine control.
- External wiring using the temperature contact on the brake resistor (e.g. interruption of the supply via mains contactor and activation of the mechanical brakes).



## Note!

If the system is dimensioned correctly, this monitoring should not respond. If individual rated data of the actually connected brake resistor are not known, they have to be determined "empirically".

## 7.2.4 DC bus overvoltage

If, due to a too high braking energy, the DC-bus voltage exceeds the overvoltage threshold which results from the mains voltage setting in [C00173](#), the "Overvoltage in the DC bus" error message is output and the response set in [C00600](#) is activated (default setting: "Trouble").



### Note!

For hoist applications, the "Fault" response should be selected in [C00600](#) (in combination with an emergency stop via mechanical brakes).

### 8 I/O terminals

This chapter provides information about options for parameter setting and configuration of the controller input and output terminals.











#### **Tip!**

Information on wiring the terminals can be found in the Mounting Instructions for the controller!



## 8.1 Overview


Front view	Terminal assignment	Information
 <p>X2</p>	<p>X2</p> 	<p>▶ <a href="#">"State bus" monitoring function</a> (📖 283)</p>
 <p>X3</p>	<p>X3</p> 	<p>▶ <a href="#">Analog inputs</a> (📖 274) ▶ <a href="#">Analog outputs</a> (📖 277)</p>
 <p>X4</p>	<p>X4</p> 	<p>▶ <a href="#">Digital outputs</a> (📖 281)</p>
 <p>X5</p>	<p>X5</p> 	<p>▶ <a href="#">Digital inputs</a> (📖 279) ▶ <a href="#">Touch probe detection</a> (📖 285)</p>

## 8.2 Analog inputs

The controller has two analog inputs that can be used to detect differential voltage signals in the range of  $\pm 10$  V, e.g. analog speed setpoint selections or the voltage signals of an external sensor (temperature, pressure, etc.).

- Optionally, analog input 1 can also be used to detect current setpoints.

### 8.2.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X3/A1- X3/A1+	Differential voltage input 1 (no jumper between A1R and A1-)	Level: -10 V ... +10 V
		Resolution: 11 bits + sign
		Scaling: When <a href="#">C00034</a> = "0": $\pm 10 \text{ V} \equiv \pm 2^{30}$
		Conversion rate: 1 kHz
	Current input (jumper between A1R and A1-)	Level: -20 mA ... +20 mA
	Resolution: 10 bits + sign	
	Scaling: When <a href="#">C00034</a> = "1": -20 mA ... -4 mA = $-2^{30}$ ... 0 +4 mA ... +20 mA = 0 ... $2^{30}$ When <a href="#">C00034</a> = "2": $\pm 20 \text{ mA} \equiv \pm 2^{30}$	
	Conversion rate: 1 kHz	
X3/A2- X3/A2+	Differential voltage input 2	Level: -10 V ... +10 V
		Resolution: 11 bits + sign
		Scaling: $\pm 10 \text{ V} \equiv \pm 2^{30}$
		Conversion rate: 1 kHz

## 8.2.2 Parameter setting

Short overview of parameters for the analog inputs:

Parameter	Information
<a href="#">C00034</a>	Config. analog input 1
<a href="#">C00598</a>	Resp. to open circuit AIN1
<a href="#">C02730/1</a>	Analog input 1: Gain
<a href="#">C02730/2</a>	Analog input 2: Gain
<a href="#">C02731/1</a>	Analog input 1: Offset
<a href="#">C02731/2</a>	Analog input 2: Offset
<a href="#">C02732/1</a>	Analog input 1: Dead band
<a href="#">C02732/2</a>	Analog input 2: Dead band
<a href="#">C02800/1</a>	Analog input 1: Input signal (-16384 ≙ -100 %, 16383 ≙ 100 %)
<a href="#">C02800/2</a>	Analog input 2: Input signal (-16384 ≙ -100 %, 16383 ≙ 100 %)

Highlighted in grey = display parameter

## 8.2.3 Reconfiguring analog input 1 into current input

By means of the following two steps, analog input 1 can be reconfigured into a current input:

1. Bridge the terminals A1R and A1- at terminal strip X3 by means of wiring.
2. Select the corresponding current loop under [C00034](#).



**Tip!**


Like this you can implement a 4 ...20 mA current loop, e.g. for speed setpoint selection.

### Open-circuit monitoring

Under [C00598](#) you can set an error response to open circuit for the 4 ...20 mA current loop.

## 8.2.4 "LS\_AnalogInput" system block

The LS\_AnalogInput system block displays the analog inputs in the function block editor.



Output	Data type	Value/meaning
AIN1_dnIn_n	DINT	Analog input 1 <ul style="list-style-type: none"> <li>Scaling:                             <ul style="list-style-type: none"> <li><math>\pm 2^{30} \equiv \pm 10 \text{ V}</math> for use as a voltage input</li> <li><math>\pm 2^{30} \equiv \pm 20 \text{ mA}</math> for use as a current input</li> </ul> </li> </ul>
AIN2_dnIn_n	DINT	Analog input 2 <ul style="list-style-type: none"> <li>Scaling: <math>\pm 2^{30} \equiv \pm 10 \text{ V}</math></li> </ul>
AIN1_bCurrentError	BOOL	Status signal "Current input error" <ul style="list-style-type: none"> <li>Only when analog input 1 is used as current input.</li> <li>Application: Monitoring of the 4 ...20 mA circuit with regard to cable break.</li> </ul>
		TRUE   $ I_{AIN1}  < 2 \text{ mA}$

## 8.3 Analog outputs

The controller has two analog outputs that can be used to output internal analog signals as voltage signals, e.g. for the control of analog indicating instruments or as a setpoint for slave drives.



### Note!


Initialisation behaviour:

- After mains switching until the application is started, the analog outputs remain on 0 V.

Exceptional behaviour:

- In the case of a critical exception within the application (e. g. reset), the analog outputs are set to 0 V.

### 8.3.1 Terminal assignment/electrical data



Terminal	Use	Electrical data	
X3/AO1	Voltage output 1	Level:	-10 V ... +10 V (max. 2 mA)
		Resolution:	11 bits + sign
		Scaling:	$\pm 2^{30} \equiv \pm 10$ V
		Conversion rate:	1 kHz
X3/AO2	Voltage output 2	Level:	-10 V ... +10 V (max. 2 mA)
		Resolution:	11 bits + sign
		Scaling:	$\pm 2^{30} \equiv \pm 10$ V
		Conversion rate:	1 kHz
X3/GA	Reference potential (analog ground)		

## 8.3.2 Parameter setting


Short overview of parameters for the analog outputs:

Parameter	Information
<a href="#">C02733/1</a>	Analog output 1: Gain
<a href="#">C02733/2</a>	Analog output 2: Gain
<a href="#">C02734/1</a>	Analog output 1: Offset
<a href="#">C02734/2</a>	Analog output 2: Offset
<a href="#">C02801/1</a>	Analog output 1: Output signal
<a href="#">C02801/2</a>	Analog output 2: Output signal

Highlighted in grey = display parameter

## 8.3.3 "LS\_AnalogOutput" system block

In the function block editor the LS\_AnalogOutput system block provides the interface to the analog outputs.




Input	Data type	Information/possible settings
AOUT1_dnOut_n	DINT	Analog output 1 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$
AOUT2_dnOut_n	DINT	Analog output 2 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$

## 8.4 Digital inputs

The controller is provided with eight freely configurable digital inputs.

- ▶ All digital inputs can be used for touch probe. ▶ [Touch probe detection](#) (p. 285)
- ▶ The control input RFR of terminal strip X5 for controller enable is fixedly connected to the device control.

### 8.4.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X5/D11	Digital input 1 ... 8	LOW level: 0 ... +5 V
X5/D18		HIGH level: +15 ... +30 V
		Input current: 8 mA per input (at 24 V)
		External-voltage protection: Max. ±30 V
		Conversion rate: 1 kHz
X5/RFR	Controller enable	See digital inputs
X5/GI	Reference potential (digital ground)	


### 8.4.2 Parameter setting

Short overview of parameters for the digital inputs:

Parameter	Information
<a href="#">C00114</a>	Digital input x - terminal pol.
<a href="#">C00443</a>	Status: Digital inputs
<a href="#">C02803</a>	Status word: Digital inputs
<a href="#">C02830</a>	Digital inputs: Delay time
Highlighted in grey = display parameter	

## 8.4.3 "LS\_DigitalInput" system block

The LS\_DigitalInput system block displays the digital inputs and the status of the state bus in the function block editor.



Output	Value/meaning
DIGIN_bCInh <small>DIS code   data type</small> <a href="#">C00443/9</a>   BOOL	Status signal "Controller inhibit" <ul style="list-style-type: none"> <li>The control input RFR (X5/pin 9) for setting/deactivating controller inhibit is fixedly connected to the device control (DCTRL) via an inverter.</li> </ul> TRUE   Controller inhibit active
DIGIN_bIn1 <small>DIS code   data type</small> <a href="#">C00443/1</a>   BOOL	Digital input 1 ... 8
... DIGIN_bIn8 <small>DIS code   data type</small> <a href="#">C00443/8</a>   BOOL	
DIGIN_bStateBusIn <small>DIS code   data type</small> <a href="#">C00443/12</a>   BOOL	State bus status ▶ <a href="#">"State bus" monitoring function (📖 283)</a>
	TRUE   A node connected to the state bus has set the state bus to LOW level and the "Error" state has been set. <ul style="list-style-type: none"> <li>The "Error" state is also set if a node connected to the state bus is not supplied with voltage.</li> </ul>



## 8.5 Digital outputs

The controller is provided with four freely configurable digital outputs.



### Note!


Initialisation behaviour:

- After mains switching until the application is started, the digital outputs remain on FALSE.

Exceptional behaviour:

- In the case of a critical exception within the application (e. g. reset), the digital outputs are set to FALSE, taking the terminal polarity parameterised in [C00118](#) into consideration.

### 8.5.1 Terminal assignment/electrical data



Terminal	Use	Electrical data	
X4/DO1 ... X4/DO4	Digital output 1 ... 4	LOW level:	0 ... +5 V
		HIGH level:	+15 ... +30 V
		Output current:	Max. 50 mA per output (external resistance > 480 Ω at 24 V)
		Conversion rate:	1 kHz
X4/240	External 24 V voltage supply for the digital outputs		
X4/GO	Reference potential (digital ground)		

### 8.5.2 Parameter setting


Short overview of parameters for the digital outputs:

Parameter	Information
<a href="#">C00118</a>	Digital output x - terminal pol.
<a href="#">C00444</a>	Status: Digital outputs
<a href="#">C02802</a>	Status word: Digital outputs

Highlighted in grey = display parameter

## 8.5.3 "LS\_DigitalOutput" system block


In the function block editor the **LS\_DigitalOutput** system block provides the interface to the digital outputs, the state bus, and the yellow user LED at the front of the controller.



Input	Information/possible settings
DIGOUT_bOut1 <small>C00444/1   BOOL</small> ... DIGOUT_bOut4 <small>C00444/4   BOOL</small>	Digital output 1 ... 4
DIGOUT_bStateBusOut <small>C00444/18   BOOL</small>	Setting the state bus to the "Error" state ▶ <a href="#">"State bus" monitoring function (EN 283)</a>
	TRUE The state bus is set to LOW level, all nodes connected to the state bus start their pre-programmed response.
DIGOUT_bUserLED <small>C00444/9   BOOL</small>	Control of yellow user LED on the front of the controller
	TRUE LED on

## 8.6 "State bus" monitoring function

The state bus is a bus system that is solely designed for Lenze controllers, via which up to 20 controllers can be connected to each other, and by means of which the function of a "release cord" can be simulated:



[8-1] Schematic diagram: Networking via state bus

- ▶ The state bus only knows the states "OK" and "Error".
- ▶ The state bus is a bus with multi-master capability, i.e. each node connected to the state bus can set the state bus to the "Error" state by setting it to LOW level.
- ▶ In the "Error" status, all nodes start their adjustable response, e.g. synchronised braking of the drive system.
- ▶ The "Error" state is also set if a node connected to the state bus is not supplied with voltage.




### Note!

Exceptional behaviour:

- In the case of a critical exception within the application (e. g. reset), the "release cord" is not triggered, the state bus remains in the "OK" status.


## 8.6.1 Detecting the current state

Via the output *DIGIN\_bStateBusIn* of the [LS\\_DigitalInput](#) system block, the current status of the state bus can be queried. In case of error the output *DIGIN\_bStateBusIn* is set to TRUE.



## 8.6.2 Setting the state bus to the "Error" state

If the input *DIGOUT\_bStateBusOut* of the [LS\\_DigitalOutput](#) system block is set to TRUE, the state bus is set to "Error" and all connected nodes start their pre-programmed response.



## 8.7 Touch probe detection

A "Touch probe" is an event which can for instance be actuated in an edge-controlled manner via a digital input to detect an actual value (that changes quickly) at the time of activation and to process it further within the program afterwards.

### Overview of the touch probe channels


For the touch probe detection 12 touch probe channels are provided, which can be configured independently of each other:

Touch probe channel	Activating event	System block
1	Edge change at digital input 1	<a href="#">LS_TouchProbe1...8</a> (📖 288)
2	Edge change at digital input 2	
3	Edge change at digital input 3	
4	Edge change at digital input 4	
5	Edge change at digital input 5	
6	Edge change at digital input 6	
7	Edge change at digital input 7	
8	Edge change at digital input 8	
9	Motor encoder zero pulse	<a href="#">LS_TouchProbeMotor</a> (📖 289)
10	Position encoder zero pulse	<a href="#">LS_TouchProbeLoad</a> (📖 289)
11	DFIN zero pulse	LS_TouchProbeDFIN
12	DFOUT zero pulse	LS_TouchProbeDFOUT

- ▶ Each touch probe channel is assigned to a system block which provides the application with a scaled time stamp.
- ▶ The time stamp refers to the sampling time of the encoder signals and outputs the difference with regard to the touch probe event.

### Further processing of the touch probe

For further processing of the touch probe event the time stamp is to be transmitted to an instance of the **L\_SdTouchProbe** FB:




[8-2] Transfer of the time stamp to the L\_SdTouchProbe FB

- ▶ The **L\_SdTouchProbe** FB takes over the interpolation of the input signal on the basis of the time stamp and outputs the interpolated value and the difference to the last input signal.

## 8.7.1 Actual value interpolation (principle)


If a touch probe is detected, the (remaining) time until the following task cycle is determined and from this a time stamp is generated. On the basis of this time stamp, the **L\_SdTouchProbe** FB can then carry out a linear interpolation between the two actual position interpolation points; the result is the precise actual position at the time of the physical touch probe event.



[8-3] Actual value determination through linear interpolation (principle)

## 8.7.2 Dead time compensation

For dead time compensation during the detection of the touch probe event, it is possible to select a delay time (*Touch probe delay*) in [C02810](#) for each touch probe channel, which will be considered in the touch probe calculation.




[8-4] Dead time compensation (principle)

- ▶ The filtering of the digital inputs has an impact on the electrical detection of the touch probe, i. e. the delay time for the digital inputs set in [C02830](#) has to be taken into consideration within the delay time [C02810](#).
- ▶ For the optional digital frequency input/output the setting of the delay times is effected via separate parameters:
  - C13021 or C14021: TP delay time - digital frequency input.
  - C13061 or C14061: TP delay time - digital frequency output.

## 8.7.3 "LS\_TouchProbe1...8" system block

In the function block editor the LS\_TouchProbe1 ... LS\_TouchProbe8 system blocks display the touch probe channels 1 ... 8 which are assigned to the digital inputs DI1 ... DI8.




Input	Data type	Value/meaning
TPx_bEnablePosEdge	BOOL	Enable response to positive edge <b>Note:</b> <ul style="list-style-type: none"> <li>If several positive edges occur within the basic cycle time (HighLine: 1 ms), only the first positive edge initiates the touch probe event and no status signal "touch probe(s) lost" is generated.</li> </ul>
		TRUE   A touch probe event is activated by a positive edge at the digital input DIx.
TPx_bEnableNegEdge	BOOL	Enable response to negative edge <b>Note:</b> <ul style="list-style-type: none"> <li>If several negative edges occur within the basic cycle time (HighLine: 1 ms), only the first negative edge initiates the touch probe event.</li> <li>If a positive and negative edge occur within the basic cycle time (1 ms), and if the response to both edges is enabled, only the positive edge initiates the touch probe event.</li> <li>In both cases no status signal "touch probe(s) lost" is generated.</li> </ul>
		TRUE   A touch probe event is activated by a negative edge at the digital input DIx.
Output	Data type	Value/meaning
TPx_dnTouchProbeTimeLag	DINT	Scaled time stamp for further processing of the touch probe event with the L_SdTouchProbe FB. • 1 ms = 20 bits
TPx_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" • State is only set for one task cycle.
		TRUE   Touch probe event has been activated.
TPx_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" • State is only set for one task cycle.
		TRUE   More than one touch probe event was actuated within the task runtime. The time stamp that is output only refers to the first touch probe event.
TPx_bNegativeEdge	BOOL	Status signal "Negative edge detected" • State is only set for one task cycle.
		TRUE   A negative edge has been detected at the digital input DIx.



8.7.4 "LS\_TouchProbeMotor" system block


In the function block editor the LS\_TouchProbeMotor system block represents the touch probe channel that is assigned to the motor encoder zero pulse.



Output	Data type	Value/meaning		
TPM_dnTouchProbeTimeLag	DINT	Scaled time stamp for further processing of the touch probe event with the L_SdTouchProbe FB.		
TPM_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" <ul style="list-style-type: none"> <li>• State is only set for one task cycle.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Touch probe event has been activated.</td> </tr> </table>	TRUE	Touch probe event has been activated.
TRUE	Touch probe event has been activated.			
TPM_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" <ul style="list-style-type: none"> <li>• State is only set for one task cycle.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.</td> </tr> </table>	TRUE	More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.
TRUE	More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.			

8.7.5 "LS\_TouchProbeLoad" system block

In the function block editor the LS\_TouchProbeLoad system block represents the touch probe channel that is assigned to the position encoder zero pulse.




Output	Data type	Value/meaning		
TPL_dnTouchProbeTimeLag	DINT	Scaled time stamp for further processing of the touch probe event with the L_SdTouchProbe FB.		
TPL_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" <ul style="list-style-type: none"> <li>• State is only set for one task cycle.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Touch probe event has been activated.</td> </tr> </table>	TRUE	Touch probe event has been activated.
TRUE	Touch probe event has been activated.			
TPL_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" <ul style="list-style-type: none"> <li>• State is only set for one task cycle.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.</td> </tr> </table>	TRUE	More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.
TRUE	More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.			


## 8.8 Configure exception handling of the outputs

From »Engineer« version 2.10 onwards, the function block editor for the controller can also be used to configure the behaviour of the analog and digital outputs and that of the brake control and the output ports after a task overflow in order to adapt it to the respective application.



### How to configure the exception handling:

1. Go to the *Project* view of the »Engineer« and select the 9400 HighLine controller.
2. Change to the **FB-Editor** tab in the *Workspace*.
3. Click on the  icon in the *FB editor toolbar* to open the *Configure exception handling* dialog box:



- On the **FB TaskOverrun** tab the behaviour of the controller outputs and that of the output ports defined in the application in the case of a task overflow can be configured.
- On the **FB System Events** tab, the behaviour of the outputs of the drive controller and the application is only displayed and cannot be configured.

4. Carry out the desired configuration.
  - Each output can be configured individually. A free value can be set for the analog outputs (-200.00 ... 200.00 %).
  - If you select an output port in the "Ports" area on the right, all application variables for this output port are shown in the table below. In the "Value" column a value can be set for each application variable to which it is to be set if an event occurs can be specified.
  - If a value has been set for at least one application variable, the status "Exceptional behaviour parameterised" is shown for the corresponding output port.
  - If the **Restore standard settings** button is clicked, the default setting for task overflow is restored. In this case, all output terminals would be set to LOW level or 0 V in the event of a task overflow and the output ports would retain their last value.
5. Click **OK** to accept the configuration and close the dialog box.



## Danger!

In case a task overflow occurs, the brake can be configured to "open". This setting should be used with caution as the brake is then forcibly opened and does not close even if the drive controller is inhibited!



## Note!

- To render the changes effective within the controller, the project has to be updated, and the changed application has to be transferred to the controller.
- During the reset or download of an application, all output signals are set to LOW level or 0 V for a short time (the state bus, in contrast, is set to HIGH level due to hardware inversion).

See also:

▶ [Behaviour after task overflow](#) (📖 114)

### 9 "CAN on board" system bus

The controller is provided with an implemented CANopen system bus interface ("CAN on board") via which, for instance, process data and parameter values can be exchanged between the nodes. In addition, the interface enables the connection of further modules, such as distributed terminals, operator and input devices ("HMI's") or external controls and host systems.

The interface transfers CAN objects following the CANopen communication profile CANopen (CiA DS301, version 4.02) developed by the umbrella organisation of CiA (CAN in Automation) in conformity with the CAL (CAN Application Layer).



#### Tip!

- The parameters relevant for the CANopen system bus interface are assigned to different subcategories in the parameter list in the »Engineer« and in the keypad in the **CAN** category.
- Information on CAN communication modules and CANopen system bus interfaces of other Lenze devices can be found in the Lenze library in the "CAN" communication manual.

## 9.1 General information

For many years the system bus (CAN) based on the CANopen communication profile has been integrated in Lenze controllers. Due to the lower number of data objects available, the functionality and compatibility of the old system bus are lower as compared with CANopen. For parameter setting, two parameter data channels are always available to the user while CANopen provides only one active parameter data channel (along with the possibility to establish further channels).

The system bus (CANopen) of the Servo Drives 9400 has been developed from the system bus (CAN) of the controller of the 9300 series with the following properties:

- ▶ Full compatibility according to CANopen DS301 V4.02.
- ▶ Support of the NMT master/slave function "Node Guarding" (DS301 V4.02).
- ▶ Support of the NMT slave function "Heartbeat" (DS301 V4.02).
- ▶ There are no restrictions regarding the selection of the node addresses.
- ▶ Number of parameterisable server and client SDO channels:
  - max. 10 channels with 1 ... 8 bytes
- ▶ Number of parameterisable PDO channels:
  - max. 4 Transmit-PDOs (TPDOs) with 1 ... 8 bytes
  - max. 4 Receive-PDOs (RPDOs) with 1 ... 8 bytes
- ▶ All PDO channels are functionally equivalent.
- ▶ Monitoring of the RPDOs for data reception
- ▶ Telegram counters for SDOs and PDOs
- ▶ Bus status diagnostics
- ▶ Boot-up telegram generation
- ▶ Emergency telegram generation
- ▶ Reset node telegram generation (with master configuration).
- ▶ Sync telegram generation and response to sync telegrams:
  - Transmit/receive data
  - Synchronisation of the device-internal time base
- ▶ Abort codes
- ▶ All "CAN on board" functions can be parameterised via codes.
- ▶ Object directory (all mandatory functions, optional functions, indexes)

#### 9.1.1 General data and operating conditions

Field	Values
Communication profile	CANopen (DS301 V4.02)
Communication medium	DIN ISO 11898
Network topology	Line closed on both sides (e.g. termination by Sub-D plug, type EWZ0046)
Adjustable node addresses	1 ... 127 <ul style="list-style-type: none"> <li>Adjustable via DIP switch on the memory module (exception: memory module MM1xx) or via code <a href="#">C00350</a>.</li> </ul>
Max. number of nodes	127
Baud rate	10, 20, 50, 125, 250, 500, 800, 1000 kbit/s or automatic recognition <ul style="list-style-type: none"> <li>Adjustable via DIP switch on the memory module (exception: memory module MM1xx) or via code <a href="#">C00351</a>.</li> </ul>
Process data	<ul style="list-style-type: none"> <li>max. 4 TPDOs with 1 ... 8 bytes</li> <li>max. 4 RPDOs with 1 ... 8 bytes</li> </ul>
Parameter data	Max. 10 client and server SDO channels with 1 ... 8 bytes
Transfer mode for TPDOs	<ul style="list-style-type: none"> <li>With change of data</li> <li>Time-controlled, 1 to x ms</li> <li>After the reception of 1 to 240 sync telegrams</li> </ul>

#### 9.1.2 Supported protocols

Category	Protocol
Standard PDO protocols	PDO write PDO read
SDO protocols	SDO download SDO download initiate SDO download segment <hr/> SDO upload SDO upload initiate SDO upload segment <hr/> SDO abort transfer <hr/> SDO block download SDO block download initiate SDO block download end <hr/> SDO block upload SDO block upload initiate SDO block upload end
NMT protocols	Start remote node (master and slave) <hr/> Stop remote node (slave) <hr/> Enter pre-operational (slave) <hr/> Reset node (slave and local device) <hr/> Reset communication (slave)
Monitoring protocols	Node guarding (master and slave) <hr/> Heartbeat (heartbeat producer and heartbeat consumer)

## 9.1.3 Communication time

The communication time is the time between the start of a request and the arrival of the corresponding response.



### Tip!

The communication times in the CAN network depend on the

- processing time in the device
- telegram run time (baud rate / telegram length)
- bus load (especially if the bus is loaded with PDOs and SDOs at a low baud rate.)

### Servo Drives 9400 processing time

Parameter data and process data are independent of each other.


- ▶ Parameter data:
  - For controller-internal parameters: approx. 30 ms ± 20 ms tolerance (typically)
  - For some codes the processing time can be longer.
- ▶ Process data are transported in real time.

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Possible settings by DIP switch

## 9.2 Possible settings by DIP switch

The DIP switches on the front of the memory serve to set the baud rate and the node address.



[9-1] DIP switch

### 9.2.1 Setting the node address

The node address can be set via code [C00350](#) or with the DIP switches 1 to 64.

- ▶ The labelling on the housing corresponds to the values of the individual DIP switches for determining the node address.
- ▶ Valid address range: 1 ... 127



#### Note!

- The addresses of the nodes must differ from each other.
- All twelve DIP switches = OFF (Lenze setting):
  - At switching on, the settings under code [C00350](#) (node address) and [C00351](#) (baud rate) will become active.
- Switch the voltage supply of the basic device off and then on again to activate altered settings.

#### Example: Setting of the node address 23

DIP switch	64	32	16	8	4	2	1
Switch position	OFF	OFF	ON	OFF	ON	ON	ON
Value	0	0	16	0	4	2	1
Node address	= Sum of the values = 16 + 4 + 2 + 1 = 23						



#### Tip!

The node address resulting from the setting of the DIP switches at the last mains switching is displayed in [C00349/1](#).



## 9.2.2 Setting the baud rate

The baud rate can be set via code [C00351](#) or with the DIP switches a to d:

Switch positions				Baud rate
d	c	b	a	
OFF	ON	ON	OFF	10 kbps
OFF	ON	OFF	ON	20 kbps
OFF	OFF	ON	ON	50 kbps
OFF	OFF	ON	OFF	125 kbps
OFF	OFF	OFF	ON	250 kbps
OFF	OFF	OFF	OFF	500 kbps
ON	ON	ON	OFF	800 kbps
OFF	ON	OFF	OFF	1 Mbps
OFF	ON	ON	ON	Automatic recognition



### Note!

Switch the voltage supply of the basic device off and then on again to activate altered settings.



### Tip!

The baud rate resulting from the setting of the DIP switches at the last mains switching is displayed in [C00349/2](#).


# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus

LED status displays for the system bus













## 9.3 LED status displays for the system bus

Both upper LEDs "CAN-RUN" and "CAN-ERR" on the front of the controller inform about the CANopen state and report CANopen errors.




[9-2] LED status displays CAN-RUN and CAN-ERR

The meaning can be obtained from the following table:

LED status display		Meaning	
CAN-RUN	CAN-ERR	CANopen state	CANopen error
Only CAN-ERR is on 		-	Bus off
CAN-RUN and CAN-ERR jitter 		Automatic detection of the baud rate is active.	
CAN-RUN is blinking every 0.2 seconds   CAN-ERR is off 		Pre-operational	-
CAN-RUN is blinking every 0.2 seconds   CAN-ERR 1 x blinking, 1 s off 			Warning limit reached
CAN-RUN is blinking every 0.2 seconds   CAN-ERR 2 x blinking, 1 s off 			Node guard event
Only CAN-RUN is on 		Operational	-
CAN-RUN on   CAN-ERR 1 x blinking, 1 s off 			Warning limit reached
CAN-RUN on   CAN-ERR 2 x blinking, 1 s off 			Node guard event
CAN-RUN on   CAN-ERR 3 x blinking, 1 s off 			Sync message error
CAN-RUN is blinking every 1 second   CAN-ERR is off 		Stopped	-
CAN-RUN is blinking every 1 second   CAN-ERR 1 x blinking, 1 s off 			Warning limit reached
CAN-RUN is blinking every 1 second   CAN-ERR 2 x blinking, 1 s off 			Node guard event

## 9.4 Structure of the CAN data telegram



[9-3] Basic structure of the CAN telegram

The identifier and the user data are described in detail in the following subchapters. The other signals refer to the transfer characteristics of the CAN telegram that are not described in this documentation.

### 9.4.1 Identifier

The principle of the CAN communication is based on a message-oriented data exchange between a transmitter and many receivers. All nodes can transmit and receive quasi-simultaneously.

The identifier, also called "COB-ID" (Communication Object Identifier), is used to control which node is to receive a transmitted message. In addition to the addressing, the identifier contains information on the priority of the message and the type of the user data.

The identifier consists of a so-called basic identifier and the node address of the node to be addressed:

**Identifier (COB-ID) = basic identifier + node address (node ID)**

Exception: For process data, heartbeat and emergency objects as well as network management and syn telegrams, the identifier is assigned freely by the user (either manually or automatically by the network configurator) or is firmly allocated.

## Node address (node ID)

For purposes of definite identification, a node address, also referred to as "node ID", in the valid address range (1 ... 127) is to be assigned to each node within the system bus network.

- ▶ A node address may not be assigned more than once within a network.
- ▶ The own node address can be configured via the DIP switch of the memory module (exception: MM1xx memory module) or via code [C00350](#). ▶ [Setting the node address](#) (☰ 296)

## Identifier assignment

The system bus is message-oriented and not node-oriented. Each message has a definite identification, the identifier. In the case of CANopen, a node-orientation is achieved by the fact that for each message there is only one transmitter.

- ▶ The basic identifiers for network management (NMT) and Sync as well as the basic SDO channel (SDO1) are specified in the CANopen protocol and cannot be changed.
- ▶ The basic identifiers of the PDOs are preset in the Lenze setting according to the "Predefined Connection Set" of DS301 V4.02 and can be changed via parameters/ indexes, if required. ▶ [Identifiers of the process data objects](#) (☰ 307)

Object	Direction		Basic identifier	
	from the device	to the device	dec	hex
Network management (NMT)			0	0
Sync			128	80
Emergency	●		128	80
PDO1 (Process data channel 1)	TPDO1	●	384	180
	RPDO1		512	200
PDO2 (Process data channel 2)	TPDO2	●	640	280
	RPDO2		768	300
PDO3 (Process data channel 3)	TPDO3	●	896	380
	RPDO3		1024	400
PDO4 (Process data channel 4)	TPDO4	●	1152	480
	RPDO4		1280	500
SDO1 (Basic SDO channel)		●	1408	580
			1536	600
SDO2 ... SDO10 (Parameter data channel 2 ... 10)		●	1472	5C0
			1600	640
Node guarding, heartbeat	●		1792	700

## 9.4.2 User data

All nodes communicate with each other by exchanging data telegrams via the system bus. The user data area of the CAN telegram either contains network management data, parameter data, or process data:

### Network management data

(NMT data)

- ▶ Control information on start, stop, reset, etc. of communication to certain or all nodes of the CAN network.

### Process data

(PDOs – Process Data Objects)

- ▶ Process data are transferred via the process data channel.
- ▶ The controller can be controlled using process data.
- ▶ Process data are not saved in the controller.
- ▶ Process data are transferred between the host and the nodes to ensure a continuous exchange of current input and output data.
- ▶ Process data usually are unscaled/scalable raw data
- ▶ Process data are, for instance, setpoints and actual values.

### Parameter data

(SDOs – Service Data Objects)

- ▶ Parameter data are the CANopen indexes or, in case of Lenze devices, the codes.
- ▶ Parameters are, for instance, used for one-off plant setting during commissioning or when the material is changed on a production machine.
- ▶ Parameter data are transmitted as SDOs via the parameter data channel. They are acknowledged by the receiver, i.e. the sender gets a feedback about the transmission being successful or not.
- ▶ The parameter data channel enables access to all Lenze codes and CANopen indexes.
- ▶ Parameter changes are automatically saved in the controller until the mains is switched.
- ▶ In general, the parameter transfer is not time-critical.
- ▶ Parameter data are, for instance, operating parameters, diagnostic information and motor data.

## 9.5 Communication phases/network management

Regarding communication via the system bus, the drive distinguishes between the following states:

Status	Explanation
"Initialisation" (Initialisation)	After power-up, initialisation is executed. <ul style="list-style-type: none"> <li>• During this phase, the drive does not take part in the data transfer.</li> <li>• All CAN-relevant parameters are written with their standard values again.</li> <li>• After initialisation has been completed, the controller is automatically set to the "pre-operational" status.</li> </ul>
"Pre-operational" (before being ready for operation)	Parameter data can be received, process data is ignored.
"Operational" (ready for operation)	Parameter data and process data can be received!
"Stopped" (Stopped)	Only network management telegrams can be received.


Communication object	Initialisation	Pre-operational	Operational	Stopped
PDO			●	
SDO		●	●	
Sync		●	●	
Emergency		●	●	
Boot up	●			
Network management (NMT)		●	●	●





### Tip!

In every state, the initialisation can be re-executed partly or completely by transmitting appropriate network management telegrams.

## 9.5.1 State transitions




[9-4] NMT state transitions in the CAN network

Transition	NMT command	State after change	Effect on process or parameter data after state change
(1)	-	Initialisation	Initialisation starts automatically when the mains is switched on. <ul style="list-style-type: none"> <li>During initialisation, the controller does not take part in the data transfer.</li> <li>After initialisation has been completed, the node sends a boot-up message with an individual identifier and automatically changes to the "pre-operational" status.</li> </ul>
(2)	-	Pre-operational	In this phase, the master determines the way in which the node(s) takes/take part in the communication.
	From here, the states are changed over by the master for the entire network. <ul style="list-style-type: none"> <li>A target address contained in the NMT command specifies the receiver(s).</li> <li>If the 9400 controller has been configured as CAN master, the state automatically changes to "Operational" after the waiting time has expired (<a href="#">C00378</a>) and the NMT command 0x0100 ("Start Remote Node") is sent to all nodes.</li> <li>Data can only be exchanged via process data objects if the state is "Operational".</li> </ul>		
(3), (6)	0x01 xx Start Remote Node	Operational	Network management, sync and emergency telegrams as well as process data (PDO) and parameter data (SDO) are active. Optional: When the state is changed, event and time-controlled process data (PDOs) will be sent once.
(4), (7)	0x80 xx Enter Pre-Operational	Pre-operational	Network management, sync and emergency telegrams as well as parameter data (SDO) are active.
(5), (8)	0x02 xx Stop Remote Node	Stopped	Only network management telegrams can be received.
(9), (10), (11)	0x81 xx Reset node	Initialisation	Initialisation of all CAN-relevant parameters (CiA DS 301) with the saved values.
(12), (13), (14)	0x82 xx Reset communication		Initialisation of all CAN-relevant parameters (CiA DS 301) with the saved values.
	Meaning of the node address in the NMT command: <ul style="list-style-type: none"> <li>xx = 0x00: With this assignment, all nodes are addressed by the telegram (Broadcast telegram). The state can be changed for all nodes at the same time.</li> <li>xx = Node-ID: If a node address is indicated, the state will only be changed for the node addressed.</li> </ul>		

## 9.5.2 Network management telegram (NMT)

The telegram for the network management contains the identifier "0" and the command included in the user data, which consists of the command byte and the node address.



[9-5] Network management telegram for changing the communication phases

Command specifier (cs)		NMT command
dec	hex	
1	0x01	Start Remote Node
2	0x02	Stop Remote Node
128	0x80	Enter Pre-Operational
129	0x81	Reset node
130	0x82	Reset communication

The communication phases are changed over by a node, the CAN master, for the entire network. The CAN master can also be a controller. ▶ [Parameterising the controller as CAN master](#) (📖 305)

### Example:

Data can only be exchanged via the process data objects in the "Operational" state. To change all nodes on the bus from "Pre-Operational" to "Operational" via the CAN master, the following identifiers and user data must be set as follows in the transmit telegram:

- ▶ Identifier: 0x00 (network management)
- ▶ User data: 0x0100 (NMT command "Start Remote Node" to all nodes)



## 9.5.3 Parameterising the controller as CAN master

If the initialisation of the system bus and the connected status change from "Pre-operational" to "Operational" is not carried out by a higher-level host system, the controller can be defined to be a "quasi" master to take over this task.

The controller is configured as CAN master in [C00352](#).

- ▶ As a CAN master, the controller sets " all nodes on the bus (broadcast telegram) to the "Operational" communication status using the "Start Remote Node" NMT telegram. Only this communication status enables a data exchange via the process data objects.
- ▶ In [C00378](#), you can set a delay time which must elapse after power-up before the controller applies the "Start Remote Node" NMT telegram to the bus.

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00352</a>	CAN slave/master	Slave	
<a href="#">C00378</a>	CAN delay boot-up - operational	3000	ms



### Note!

Changing the master/slave operation in [C00352](#) will only be effective

- by repeated mains switching of the controller

or

- by sending the NMT telegram "Reset Node" or "Reset Communication" to the controller.


As an alternative to the "Reset Node" NMT telegram, the device command [C00002](#) = "91: CAN on board: Reset Node" can be used to reinitialise the CAN-specific device parameters.



### Tip!

The master functionality is only required for the initialisation phase of the drive system.

## 9.6 Process data transfer



[9-6] PDO data transfer from / to the higher-level host system

For the transfer of process data, four separated process data channels (PDO1 ... PDO4) are available.

### Definitions

- ▶ Process data telegrams between the host and the devices are distinguished as follows:
  - Process data telegrams to the device (RPDO)
  - Process data telegrams from the device (TPDO)
- ▶ The CANopen process data objects are designated as seen from the node's view:
  - Receive PDO (RPDO<sub>x</sub>): process data object received by a node
  - Transmit PDO (TPDO<sub>x</sub>): process data object transmitted by a node



### Note!

Data can only be exchanged via the process data objects if the state is "Operational".

- ▶ [Communication phases/network management](#) (📖 302)

## 9.6.1 Identifiers of the process data objects

The identifiers for the process data objects PDO1 ... PDO4 in the Lenze setting result from the basic identifier and the node address set in [C00350](#).

**Identifier (COB-ID) = basic identifier + node address (node ID)**

- ▶ The basic identifiers of the PDOs are preset in the Lenze setting according to the "Predefined Connection Set" of DS301 V4.02.
- ▶ The identifiers for the PDOs can be set individually via the Lenze codes and CANopen indexes listed in the following table. Thus, you can also set an identifier independent of the node address for certain PDOs.

Process data object	Basic identifier		Individual setting	
	dec	hex	Lenze code	CANopen index
PDO1				
RPDO1	512	0x200	<a href="#">C00321/1</a>	<a href="#">I-1400/1</a>
TPDO1	384	0x180	<a href="#">C00320/1</a>	<a href="#">I-1800/1</a>
PDO2				
RPDO2	768	0x300	<a href="#">C00321/2</a>	<a href="#">I-1401/1</a>
TPDO2	640	0x280	<a href="#">C00320/2</a>	<a href="#">I-1801/1</a>
PDO3				
RPDO3	1024	0x400	<a href="#">C00321/3</a>	<a href="#">I-1402/1</a>
TPDO3	896	0x380	<a href="#">C00320/3</a>	<a href="#">I-1802/1</a>
PDO4				
RPDO4	1280	0x500	<a href="#">C00321/4</a>	<a href="#">I-1403/1</a>
TPDO4	1152	0x480	<a href="#">C00320/4</a>	<a href="#">I-1803/1</a>



### Note!

After the node address ([C00350](#)) has changed and a subsequent CAN reset node, the identifiers which result from the corresponding basic identifiers and the set node address are automatically set again in the subcodes of [C00320](#) and [C00321](#).



### Tip!

The "Predefined Connection Set" can be re-established anytime using the following device commands ([C00002](#)):

- "93: CAN on board: Pred.Connect.Set" for CAN on board
- "94: CAN module: Pred.Connect.Set" for E94AYCCA communication module

## 9.6.2 Transmission type

The process data objects are transmitted in an event-controlled or time-controlled way.

- ▶ **Event-controlled:** The PDO is sent if a special device-internal event has occurred, for instance, when the data contents of the TPDO have changed or when a transmission cycle time has elapsed.
- ▶ **Synchronous:** A TPDO (or RPDO) is transmitted (or received) after the device has received a sync telegram (with identifier 0x80).
- ▶ **Cyclically:** The PDOs are transmitted in fixed time intervals after the transmission cycle time has elapsed.

The table shows that combinations of logic operations (AND, OR) are also possible between the different transmission modes:

Transmission type	PDO transmission			Logic operation
	cyclic	synchronous	event-controlled	
0		●	●	AND
1 ... 240		●		-
254, 255	●		●	OR

Transmission type	Description
0	The PDO is transmitted at every sync in an event-controlled manner (e. g. by means of a bit change within the PDO).
1 ... 240	<b>SYNC (with response)</b> <ul style="list-style-type: none"> <li>• Selection n = 1: The PDO is transmitted with <u>every</u> sync.</li> <li>• Selection 1 &lt; n ≤ 240: The PDO is transmitted with <u>every n-th</u> sync.</li> </ul>
254, 255	<b>Event-controlled (with mask) with cyclic overlay</b> If this value is entered, the PDO transmission is event-controlled <u>or</u> cyclic. (Note: The values "254" and "255" have the same meaning). For cyclic overlay, a cycle time must be set for the respective PDO. In this case, cyclic transmission takes place in addition to event-controlled transmission (e.g. through a bit change in the PDO).

The communication parameters (as e.g. transmission mode and cycle time) can be freely adjusted for any PDO and independent of the settings of other PDOs:

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00322/1...4</a>	CAN TPDOx Tx mode	254	
<a href="#">C00323/1...4</a>	CAN RPDOx Rx mode	254	
<a href="#">C00324/1...4</a>	CAN TPDOx delay time	0	1/10 ms
<a href="#">C00356/1...4</a>	CAN TPDOx cycle time	0	ms



**Tip!**

The setting can also be made via the following CANopen projects:

- [I-1400](#) ... [I-1403](#): Communication parameters for RPDO1 ... RPDO4
- [I-1800](#) ... [I-1803](#): Communication parameters for TPDO1 ... TPDO4

## 9.6.3 Masking of the TPDOs for event control

For TPDO1 ... TPDO4, a mask can be parameterised for every byte. In case of the event-controlled transmission of a PDO, only the masked bits are used for the event control.

- ▶ Mask "0x0" means that no bit of the corresponding byte actuates the transmission.
- ▶ Mask "0xff" means that every bit of the corresponding byte can actuate the transmission.

### Short overview: Parameters for masking the TPDOs

Parameter	Information	Lenze setting
<a href="#">C00311/1...8</a>	CAN TPDO1 mask byte x	0x00
<a href="#">C00312/1...8</a>	CAN TPDO2 mask byte x	0x00
<a href="#">C00313/1...8</a>	CAN TPDO3 mask byte x	0x00
<a href="#">C00314/1...8</a>	CAN TPDO4 mask byte x	0x00

## 9.6.4 Monitoring of the RPDOs for data reception

For RPDO1 ... RPDO4 each, a monitoring time can be parameterised within which the RPDO must arrive. If the RPDO is not received within the monitoring time or not with the configured sync, the response parameterised for each RPDO takes place.

### Short overview: Parameters for monitoring the RPDOs


Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00357/1...4</a>	CAN RPDOx monitoring time	3000	ms
<a href="#">C00591/1...4</a>	Resp. to CAN-RPDOx error	No response	

## 9.6.5 Synchronisation of PDOs via sync telegram

In case of cyclic transmission, one or several PDOs are transmitted/received at fixed time intervals. For synchronising the cyclic process data, an additional special telegram, the sync telegram, is used.

- ▶ The sync telegram is the trigger point for the transmission of process data from the frequency inverters to the master and for the acceptance of process data from the master by the slaves.
- ▶ For sync-controlled process data processing, the sync telegram must be generated accordingly.
- ▶ The response to a sync telegram is determined by the transmission type selected.
  - ▶ [Transmission type](#) (□ 308)

### General procedure



[9-7] Sync telegram

- After the sync telegram has been received, the slaves send the synchronous process data to the master (TPDOs). The master reads them as process input data.
- When the sending process has been completed, the slaves (RPDOs) receive the process output data (from the master).
  - All other telegrams (e.g. parameters or the event-controlled process data) are accepted acyclically by the slaves after the transmission has been completed successfully.
  - The acyclic data are not shown in illustration [9-7] They must be considered when the cycle time is dimensioned.
- The data in the slave is accepted with the next sync telegram if the Rx mode is set to 1 ... 240. When the Rx mode is set to 254 or 255 the data is accepted in the next device cycle independent of the sync telegram.

## 9.6.5.1 Parameter setting

## Short overview: Parameters for synchronisation via sync telegram

Parameter	Information	Lenze setting		Assignment	
		Value	Unit	Sync master	Sync slave
<a href="#">C00367</a>	CAN SYNC Rx identifier	128			●
<a href="#">C00368</a>	CAN SYNC Tx identifier	128		●	
<a href="#">C00369/1</a>	CAN sync transmission cycle time	0	ms	●	
<a href="#">C01120</a>	Sync source	Off			●
<a href="#">C01121</a>	Sync cycle time	1000	µs		●
<a href="#">C01122</a>	Sync phase position	400	µs		●
<a href="#">C01123</a>	Sync tolerance	0	µs		●
<a href="#">C01124</a>	Sync PLL increment	109	ns		●
<a href="#">C01130</a>	Sync application cycle	1000	µs		●

**Sync source**

[C01120](#) is used to select the source of the synchronisation signals. Only one source can synchronise the node.

**Sync cycle time**

Time with which the internal phase-locking loop (PLL) visualises the synchronisation signals. The time must be set in [C01121](#) in accordance with the cycle of the synchronisation source selected in [C01120](#).

**Note!**

If the synchronisation takes place via the system bus, it is reasonable to only enter integer multiples of 1000 µs in [C01121](#).

Example: For the system bus, the distance between two synchronisation signals is set to 2 ms. If the system bus is to be used as synchronisation source, a sync cycle time of 2000 µs must be set in [C01121](#).

## Sync phase position

The phase position defines the zero point of time for the application relating to the synchronisation signal (bus cycle). Since PDO processing is integrated in the system part of the application, the instant of the PDO acceptance also changes if the phase position is changed.

- ▶ If 0 is set, the application is started together with the synchronisation signal.
- ▶ If a value  $> 0$  is set, the application starts by the set time interval before the synchronisation signal arrives (the phase position acts negatively).

Example: If the phase position is set to  $400 \mu\text{s}$ , the system part of the application starts  $400 \mu\text{s}$  before the synchronisation signal arrives.



### Note!

From software version V3.0:

The effect of the sync phase position can be affected by the application cycle set in [C01130](#). For the Lenze setting of [C01130](#) the behaviour remains as before.

## Sync tolerance

Time slot for monitoring the synchronisation signal via the system block **LS\_SyncInput**.

▶ [System block "LS\\_SyncInput"](#) (📖 365)

- ▶ If the last synchronisation signal amounted to approx. the expected value within this time slot, the *SYNC\_bSynclnsideWindow* output of the **LS\_SyncInput** system block is set to TRUE.
- ▶ This setting does not affect the synchronisation process.

## Sync PLL increment

If the cycle times of the synchronisation signal and the phase-locking loop (PLL) differ from each other, the setting in [C01124](#) defines the increment with which the phase-locking loop can be reset.

- ▶ The recommended reset time for the system bus as synchronisation source with regard to occurring deviations is 109 ns (Lenze setting).



## Sync application cycle

This parameter influences the effect of the sync phase position ([C01122](#)) with regard to the instant of acceptance of the synchronous PDOs by the application or the instant of transmission of the synchronous PDOs to the system bus.

The following applies to software versions lower than V3.0:

- ▶ The sync application cycle is permanently set to 1000 µs.
- ▶ The resulting PDO delay can be calculated with the following formula taking into consideration an internal processing time of 150 s:  $\text{PDO delay} = (\text{sync cycle time} - \text{sync phase position} + 150 \mu\text{s}) \text{ modulo } 1000$

The following applies from software version V3.0:

- ▶ The sync application cycle can be set in [C01130](#). The set value is automatically rounded down to full 1000 µs.
- ▶ The resulting PDO delay can be calculated with the following formula taking into consideration an internal processing time of 150 s:  $\text{PDO delay} = (\text{sync cycle time} - \text{sync phase position} + 150 \mu\text{s}) \text{ modulo } \text{C01130}$




### Note!

If the sync application cycle in [C01130](#) is set higher than the sync cycle time ([C01121](#)), the behaviour is undefined. The same applies if the sync phase position ([C01122](#)) is set higher than the sync cycle time ([C01121](#)).

Usually, no synchronous PDOs are then applied to the system bus anymore.


## 9.6.5.2 Effect of C01130 on the sync phase position



# 9400 HighLine | Parameter setting & configuration


"CAN on board" system bus  
Process data transfer

## Example 2:




- ❶ Sync cycle time ([C01121](#)) = 2000 µs
- ❷ Sync phase position ([C01122](#)) = 400 µs  
Sync application cycle ([C01130](#)) = 1000 µs
- ❸ PDO delay = ([C01121](#) - [C01122](#) + 150 µs) modulo [C01130](#) = 750 µs
- Ⓐ Instant of acceptance/transmission of synchronous PDOs
- Ⓑ Inactive instant of acceptance
- n Device cycle

## Example 3:




- ❶ Sync cycle time ([C01121](#)) = 2000 µs
- ❷ Sync phase position ([C01122](#)) = 400 µs  
Sync application cycle ([C01130](#)) = 2000 µs
- ❸ PDO delay = ([C01121](#) - [C01122](#) + 150 µs) modulo [C01130](#) = 1750 µs
- Ⓐ Instant of acceptance/transmission of synchronous PDOs
- Ⓑ Inactive instant of acceptance
- n Device cycle

## Example 4:



- ❶ Sync cycle time ([C01121](#)) = 2000 µs
- ❷ Sync phase position ([C01122](#)) = 1400 µs  
Sync application cycle ([C01130](#)) = 1000 µs
- ❸ PDO delay = ([C01121](#) - [C01122](#) + 150 µs) modulo [C01130](#) = 750 µs
- Ⓐ Instant of acceptance/transmission of synchronous PDOs
- Ⓑ Inactive instant of acceptance
- n Device cycle

## 9.7 Parameter data transfer



[9-8] Parameter data transfer via available parameter data channels

Parameters are values stored in codes on Lenze controllers.

Ten separate parameter data channels are available for parameter setting, enabling the simultaneous connection of several devices for configuration.

Parameter data are transmitted via the system bus as SDOs ("Service Data Objects") and acknowledged by the receiver. The SDO enables read and write access to the object directory. Indexes (e.g. [I-1000](#)) ensure access to parameters and functions included in the object directory. To transfer SDOs, the information contained in the user data must comply with the CAN-SDO protocol.

## 9.7.1 Identifiers of the parameter data objects

The identifiers for the parameter data objects SDO1 ... SDO10 in the Lenze setting result from the basic identifier and the node address set in [C00350](#).

**Identifier (COB-ID) = basic identifier + node address (node ID)**

- ▶ The basic identifiers of the SDOs are preset in the Lenze setting according to the "Predefined Connection Set" of DS301 V4.02.

Parameter data object	Direction		Basic identifier	
	from the device	to the device	dec	hex
SDO1 (Parameter data channel 1)	●		1408	580
		●	1536	600
SDO2 ... 10 (Parameter data channel 2 ... 10)	●	●	Deactivated	
Node guarding, heartbeat	●		1792	700
Boot up	●		1792	700



### Note!

Please observe that the parameter data channels 2 ... 10 are deactivated in the Lenze setting.

The procedure for activating these parameter data channels is explained in the description of parameters [C00372](#) and [C00373](#) and the description for the implemented CAN object [I-1201](#). ▶ [Example](#) (□ 353)

## 9.7.2 User data

### Structure of the user data of the parameter data telegram

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	Low byte	High byte		Low word		High word	
				Low byte	High byte	Low byte	High byte



#### Note!

User data are displayed in the Motorola format.

▶ [Examples for a parameter data telegram](#) (📖 323)

The following subchapters describe the user data in detail.

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Parameter data transfer

## 9.7.2.1 Command

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
<b>Command</b>	<b>Index</b>		<b>Subindex</b>	<b>Data 1</b>	<b>Data 2</b>	<b>Data 3</b>	<b>Data 4</b>
	Low byte	High byte		Low word		High word	
				Low byte	High byte	Low byte	High byte

The following commands can be transmitted or received for writing and reading the parameters:

Command	1st byte		Data length	Information
	hex	dec		
Write request	0x23	35	4 byte	Writing a parameter to the controller.
	0x2B	43	2 bytes	
	0x2F	47	1 byte	
	0x21	33	Block	
Write response	0x60	96	4 byte	Acknowledgement by the controller regarding a write request.
Read request	0x40	64	4 byte	Reading a parameter from the controller.
Read response	0x43	67	4 byte	Response from the controller to a read request with the current parameter value.
	0x4B	75	2 bytes	
	0x4F	79	1 byte	
	0x41	65	Block	
Error response	0x80	128	4 byte	Response from the controller when the read/write request could not be executed correctly. ▶ <a href="#">Error messages</a> (📖 321)

In detail, the command byte contains the following information:

Command	1st byte							
	Command specifier (cs)			Toggle (t)	Length*		e	s
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Write request	0	0	1	0	0/1	0/1	1	1
Write response	0	1	1	0	0	0	0	0
Read request	0	1	0	0	0	0	0	0
Read response	0	1	0	0	0/1	0/1	1	1
Error response	1	0	0	0	0	0	0	0

\*Bit coding of the length: 00 = 4 bytes, 01 = 3 bytes, 10 = 2 bytes, 11 = 1 bytes  
e: expedited (shortened block service)  
s: segmented (normal block service)



**Tip!**

Further commands are defined in the CANopen specification DS301, V4.02 (e. g. segmented transfer).

## 9.7.2.2 Addressing through index and subindex

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	Low byte	High byte		Low word		High word	
				Low byte	High byte	Low byte	High byte

A parameter (Lenze code) is addressed according to the following formula:  
**Index = 24575 - (Lenze code number)**

### Example

The parameter C00011 (motor reference speed) is to be addressed.

Calculation:

- ▶ Index:
  - Decimal:  $24575 - 11 = 24564$
  - Hexadecimal:  $0x5FFF - 0xB = 0x5FF4$
- ▶ Subindex: 0x00 (subindex 0, since the parameter has no subcodes.)

Entries:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	0xF4	0x5F	0x00				

## 9.7.2.3 Data 1 ... data 4

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	Low byte	High byte		Low word		High word	
				Low byte	High byte	Low byte	High byte

A maximum of 4 bytes is available for parameter value entries. The bytes are assigned as follows, depending on the data format:

5th byte	6th byte	7th byte	8th byte
Parameter value (1 byte)	0x00	0x00	0x00
Parameter value (2 bytes)		0x00	0x00
Low byte	High byte		
Parameter value (4 bytes)			
Low word		High word	
Low byte	High byte	Low byte	High byte



### Note!

The [table of attributes](#) contains a scaling factor for all Lenze parameters in the "factor" column. The scaling factor is important for the transfer of parameter values which are shown with one or several decimal positions in the parameter list.

When the scaling factor is > 1, the value must be multiplied by the scaling factor before being transmitted to be able to transmit the value as an integer. On the SDO client side, the integer must be divided by the scaling factor again to obtain the original value with decimal positions.

### Example

For a code with the scaling factor "100" and the data format U32 the value "123.45" is to be transmitted.

Calculation:

- ▶ Value to be transmitted = scaling factor x value
- ▶ Data (1 ... 4) = 100 x 123.45 = 12345 (0x00 00 30 39)

Entries:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
				0x39	0x30	0x00	0x00



## 9.7.2.4 Error messages

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Error code			
0x80 (128)	Low byte	High byte		Low word		High word	
				Low byte	High byte	Low byte	High byte

In case of an error, the addressed node generates a telegram with the "Error Response" (0x80) command.

- ▶ The telegram contains the index and subindex of the code in which an error has occurred.
- ▶ Bytes 5 ... 8 contain the error code.
  - The error codes are standardised acc. to DS301, V4.02.
  - The representation of the error codes is reversed to the read direction (see the following example).

### Example

Representation of the error codes "0x06 04 00 41" in the bytes 5 ... 8:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Error code			
				0x41	0x00	0x04	0x06

#### Meaning of the error codes

Error code	Explanation
0x0503 0000	Toggle bit not changed.
0x0504 0000	SDO protocol expired.
0x0504 0001	Invalid or unknown client/server command specifier.
0x0504 0002	Invalid block size (block mode only).
0x0504 0003	Invalid processing number (block mode only).
0x0504 0004	CRC error (block mode only).
0x0504 0005	Memory does not suffice.
0x0601 0000	Object access not supported.
0x0601 0001	Attempted read access to a writable only object.
0x0601 0002	Attempted write access to a readable only object.
0x0602 0000	Object not listed in object directory.
0x0604 0041	Object not mapped to PDO.
0x0604 0042	Number and length of objects to be transferred longer than PDO.
0x0604 0043	General parameter incompatibility.
0x0604 0047	General internal device incompatibility.
0x0606 0000	Access denied because of hardware error.
0x0607 0010	Unsuitable data type (unsuitable service parameter length).
0x0607 0012	Unsuitable data type (service parameter length exceeded).
0x0607 0013	Unsuitable data type (service parameter length too short).
0x0609 0011	Subindex does not exist.
0x0609 0030	Parameter value range exceeded.
0x0609 0031	Parameter values too high.
0x0609 0032	Parameter values too low.
0x0609 0036	Maximum value falls below minimum value.
0x0800 0000	General error.
0x0800 0020	Data cannot be transferred or saved for application.
0x0800 0021	Data cannot be transferred or saved for application due to local control.
0x0800 0022	Data cannot be transferred or saved for application due to current device status.
0x0800 0023	Dynamic generation of object directory failed or no object directory available (e.g. object directory generated from file, generation not possible because of a file error).

## 9.7.3 Examples for a parameter data telegram

### 9.7.3.1 Reading parameters

**Task:** The heatsink temperature of 43 °C (code [C00061](#), data format INTEGER32, scaling factor 1) is to be read from the controller with node address 5.

#### Telegram to drive

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0605	0x40	0xC2	0x5F	0x00	0x00	0x00	0x00	0x00

#### Explanations of the telegram to the drive

Identifier	= 1536 + node address = 1536 + 5 = 1541 = 0x0605 (1536 = basic identifier SDO1 to the controller)
Command	= 0x40 = "Read Request" (read request of a parameter from the controller)
Index	= 24575 - code number = 24575 - 61 = 24514 = 0x5FC2
Subindex	= 0 (code <a href="#">C00061</a> has no subcodes)

#### Response telegram from drive (if data has been transmitted correctly)

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0585	0x43	0xC2	0x5F	0x00	0x2B	0x00	0x00	0x00

#### Explanations of the telegram from the drive

Identifier	= 1408 + node address = 1408 + 5 = 1413 = 0x0585 (1408 = basic identifier SDO1 from the controller)
Command	= 0x43 = "Read Response" (response to read request with current value)
Index	as in telegram to the drive
Subindex	
Data 1 ... 4	= 0x0000002B = 43 [°C]

## 9.7.3.2 Writing parameters

**Task:** The rated current of the connected motor with  $I_{\text{rated}} = 10.2 \text{ A}$  (code [C00088](#)) is to be entered in the controller.

### Telegram to drive

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0602	0x23	0xA7	0x5F	0x00	0x66	0x00	0x03	0x00

#### Explanations of the telegram to the drive

Identifier	= 1536 + node address = 1536 + 2 = 1538 = 0x0602 (1536 = basic identifier SDO1 to the controller)
Command	= 0x23 = "Write Request" (write request of a parameter to the controller)
Index	= 24575 - code number = 24575 - 88 = 24487 = 0x5FA7
Subindex	= 0 (code <a href="#">C00088</a> has no subcodes)
Data 1 ... 4	= $10,2 \times 10 = 102 = 0x00030066$ (Value for motor current, data type U32; display factor 1/10)

### Response telegram from drive (if data has been transmitted correctly)

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0582	0x60	0xA7	0x5F	0x00	0x00	0x00	0x00	0x00

#### Explanations of the telegram from the drive

Identifier	= 1408 + node address = 1408 + 2 = 1410 = 0x0582 (1408 = basic identifier SDO1 from the controller)
Command	= 0x60 = "Write Response" (acknowledgement of the write access from the controller)
Index	as in telegram to the drive
Subindex	

## 9.7.3.3 Reading block parameters

**Task:** The firmware version (code [C00099](#)) is to be read from the parameter set of the controller with the node address "12". The firmware version has a length of 11 ASCII characters which are transmitted as block parameters. Within the user data, the data width from the 2nd to the 8th byte is assigned per block.

### Telegram 1 to the drive: read request

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x060C	0x40	0x9C	0x5F	0x00	0x00	0x00	0x00	0x00

#### Explanations of the telegram to the drive

Identifier	= 1536 + node address = 1536 + 12 = 1548 = 0x060C (1536 = basic identifier SDO1 to the controller)
Command	= 0x40 = "Read Request" (read request of a parameter from the controller)
Index	= 24575 - code number = 24575 - 99 = 24476 = 0x5F9C
Subindex	= 0 (code <a href="#">C00099</a> has no subcodes)

### Response telegram 1 from the drive: Data of the block length (11 characters)

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x058C	0x41	0x9C	0x5F	0x00	0x0B	0x00	0x00	0x00

#### Explanations of the telegram from the drive

Identifier	= 1408 + node address = 1408 + 12 = 1420 = 0x058C (1408 = basic identifier SDO1 from the controller)
Command	= 0x41 = "Read Response" (response is a block telegram)
Index	as in telegram to the drive
Subindex	
Data 1 ... 4	= 0x0000000B = data length of 11 characters in ASCII format

## Telegram 2 to the drive: Request of the 1st data block

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x060C	0x60	0x00	0x00	0x00	0x00	0x00	0x00	0x00

### Explanations of the telegram to the drive

Command = 0x60 = "Read Segment Request" (request: read data block)  
 • Bit 4 = 0 (toggle bit)

#### Influence of the toggle bit to the request command

The individual blocks are toggled successively, i.e. first the request with command "0x60" is effected (=  $0110 * 0000_{bin}$ ), then command "0x70" (=  $0111 * 0000_{bin}$ ), then "0x60" again, etc.  
 \* Toggle bit

## Response telegram 2 from the drive: Send 1st data block

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x058C	0x00	0x30	0x31	0x2E	0x30	0x30	0x2E	0x30
		0 <sub>asc</sub>	1 <sub>asc</sub>	· <sub>asc</sub>	0 <sub>asc</sub>	0 <sub>asc</sub>	· <sub>asc</sub>	0 <sub>asc</sub>

### Explanations of the telegram to the drive

Command = 0x00 =  $00000000_{bin}$   
 • Bit 4 = 0 (toggle bit)

#### Influence of the toggle bit to the transmission command

- The first response of the controller in the command byte is " $0x0000 * 0000_{bin}$ " if bytes 2 ... 8 are completely assigned with data and further telegrams are following.
  - The second response of the controller in the command byte is " $0x0001 * 0000_{bin}$ " if bytes 2 ... 8 are completely assigned with data and further telegrams are following, etc.
- \* Toggle bit

Data 1 ... 7 = "01.00.0" (ASCII representation)

## Telegram 3 to the drive: Request of the 2nd data block

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x060C	0x70	0x00	0x00	0x00	0x00	0x00	0x00	0x00

### Explanations of the telegram 3 to the drive

Command	= 0x70 = "Read Segment Request" (request: read data block) • Bit 4 = 1 (toggle bit)
---------	--

## Response telegram 3 from the drive: Send 2nd data block with end identifier

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x058C	0x17	0x30	0x2E	0x30	0x30	0x00	0x00	0x00
		0 <sub>asc</sub>	-asc	0 <sub>asc</sub>	0 <sub>asc</sub>	-	-	-

### Explanations of the telegram 3 from the drive

Command	= 0x17 = 00010111 <sub>bin</sub> : • Bit 0 = 1 (end of transmission) • Bit 1 ... bit 3 = 011 <sub>bin</sub> (3 bytes do not contain any data) • Bit 4 = 1 (toggle bit)
	<b>Influence of the end bit and the residual data length on the transmission command</b> • The end of transmission is reported by the set end bit 0. • By means of bit 1 ... 3, the number of bytes which do not contain data anymore is announced. * Toggle bit
Data 1 ... 7	= "0.00" (ASCII representation) The result of the data block transfer is: "01.00.00.00"

## 9.8 Diagnostics

The display parameters listed in the following table serve to request current information on the system bus for diagnostic purposes, e.g. using the keypad, via a bus system, or using the »Engineer« (when an online connection has been established to the controller).

- ▶ The »Engineer« parameter list and the keypad contain these parameters in the category **CAN → CAN management**.
- ▶ A detailed description of these parameters can be found in the chapter "[Parameter reference](#)". (📖 705)

Parameter	Display
<a href="#">C00345</a>	CAN error
<a href="#">C00359</a>	CAN status
<a href="#">C00360/1</a>	CAN stuffing bit error counter
<a href="#">C00360/2</a>	CAN format error counter
<a href="#">C00360/3</a>	CAN acknow. error counter
<a href="#">C00360/4</a>	CAN bit 1 error counter
<a href="#">C00360/5</a>	CAN bit 0 error counter
<a href="#">C00360/6</a>	CAN CRC error counter
<a href="#">C00360/7</a>	CAN Tx telegram counter
<a href="#">C00360/8</a>	CAN Rx telegram counter
<a href="#">C00361/1</a>	CAN bus load: Current node load in Tx direction
<a href="#">C00361/2</a>	CAN bus load: Current node load in Rx direction
<a href="#">C00361/3</a>	CAN bus load: Current node load of faulty telegrams
<a href="#">C00361/4</a>	CAN bus load: Node peak load in Tx direction
<a href="#">C00361/5</a>	CAN bus load: Node peak load in Rx direction
<a href="#">C00361/6</a>	CAN bus load: Node peak load of faulty telegrams
<a href="#">C00390</a>	CAN Error Register (DS301V402)




## 9.9 Monitoring

### 9.9.1 Node guarding protocol

In a CAN network, the node guarding protocol serves to monitor the connection between the NMT master and the NMT slave(s). If the controller was parameterised as NMT master, it can monitor up to 32 NMT slaves.

#### General procedure



[9-9] Node guarding protocol

1. The NMT master within cyclic time intervals sends a data telegram to the NMT slave, which is referred to as "Remote Transmission Request" (RTR).
2. The NMT slave then returns a response telegram ("Response") to the NMT master.

## 9.9.1.1 Telegram structure

### RTR telegram

- ▶ The RTR telegram from the NMT master has the following identifiers:  
Identifier (COB-ID) = 1792 + node address of the NMT slave
- ▶ The RTR telegram does not contain any user data.
- ▶ The RTR bit in the arbitration field of the RTR telegram is set to the valency LOW (dominant level).

### Response telegram

- ▶ The response telegram from the requested NMT slave has the same identifier as the RTR telegram received by the NMT master.
- ▶ The user data (1 byte) contains the NMT slave status and the toggle bit (see the following description).

### NMT slave state (s)

NMT slave status		Data								
Communication status	Decimal value (s)	(t)	NMT slave state (s)							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
Stopped	4	0/1	0	0	0	0	0	1	0	0
Operational	5	0/1	0	0	0	0	0	1	0	1
Pre-operational	127	0/1	1	1	1	1	1	1	1	1

### Toggle bit (t)

- ▶ The toggle bit (t) in the response telegram has the value "0" when the node guarding protocol is activated for the first time.
- ▶ The toggle bit (t) must change its value with each response.



### Note!

The toggle bit is monitored by the NMT master.

If a telegram is received with a toggle bit value that has not changed compared to the previously received telegram, it will be treated as if it were not received, i.e. the monitoring time is not reset and elapses further.

The toggle bit can only be reset to the value "0" by the "Reset Communication" telegram of the NMT master.

## 9.9.1.2 Parameter setting

Short overview of parameters for the "Node Guarding" monitoring function:

Parameter	Information	Lenze setting		Assignment	
		Value	Unit	Master	Slave
<a href="#">C00382</a>	CAN guard time	0	ms		●
<a href="#">C00383</a>	CAN Life Time Factor	0			●
<a href="#">C00386/1...32</a>	CAN node guarding	0x00000000		●	
<a href="#">C00387</a>	CAN Node Guarding Activity	-		●	
<a href="#">C00388/1...32</a>	CAN node guarding status	-		●	
<a href="#">C00612/1...32</a>	Resp. to CAN node guarding error	No response		●	
<a href="#">C00614</a>	Resp. to CAN life guarding error	No response			●
<a href="#">C00625</a>	CAN behaviour in case of fault	Pre-operational state		●	●

Highlighted in grey = display parameter

### Guard time

The time interval with which the NMT master transmits the RTR telegram is the "Guard Time".

- ▶ For each NMT slave to be monitored an individual time interval can be set.
- ▶ The RTR telegram prompts the NMT slave to send its current status.

### Node life time

The "Node Life Time" is the product of the "Guard Time" and the "Life Time Factor":

**Node Life Time = Guard Time x Life Time Factor**

- ▶ "Life time factor" and "Guard time" have to be known to the NMT master. For this, the values from the NMT slave are read at each reboot, or defined values are sent to the NMT slave at each reboot.
- ▶ It is possible to select a different "node life time" for each NMT slave to be monitored.

### OK status

The status of the connection is ok (OK status) if within the "Node life time"

- ▶ the NMT slave has received an RTR telegram from the NMT master and
- ▶ the NMT master has received a correct response from the requested NMT slave.

In the OK status the monitoring times for the NMT master and the NMT slave are reset and the node guarding protocol is continued.

## Life guarding event

The "Life Guarding Event" is triggered in the NMT slave if this has not received an RTR telegram from the NMT master within the "Node Life Time":

- ▶ In the Lenze setting, the NMT slave changes from the "Operational" communication status into the "Pre-Operational" communication status.
  - [C00625](#) or the [I-1029](#) object serve to set a status change.
- ▶ An emergency telegram with the emergency error code 0x8130 is transmitted to the NMT master.
- ▶ The response parameterised in [C00614](#) takes place (Lenze setting: "No response").



### Note!

The "Life Guarding Event" can only be triggered in the NMT slave if at least one RTR telegram has been received successfully from the NMT master.

## Node guarding event

The "Node Guarding Event" is triggered in the NMT master if this has not received any response to its RTR telegram from the requested NMT slave within the "Node Life Time" or the toggle bit in the response telegram has not changed within the "Node Life Time".

- ▶ In the Lenze setting, the NMT master changes from the "Operational" communication status into the "Pre-Operational" communication status.
  - [C00625](#) or the [I-1029](#) object serve to set a status change.
- ▶ The response parameterised in [C00612/1...32](#) takes place (Lenze setting: "No response"). The response in the NMT master can be set individually for each monitored node.



### Note!

The "Node Guarding Event" can only be triggered in the NMT master if at least one response has been received successfully from the requested NMT slave.

## 9.9.1.3 Commissioning example

### Task

A 9400 controller configured as NMT master (node 1) is to monitor another 9400 controller (node 2).

- ▶ The node guarding telegram is to be transmitted from the NMT master to the NMT slave in intervals of 1 s:
  - Guard time = 1000 ms
- ▶ The node life time is to amount to 5 seconds:
  - Node life time = guard time (1000 ms) x life time factor (5)
- ▶ If an error occurs, an error response is to be activated both in the NMT master and the NMT slave.

### Parameter setting of the NMT master (node 1)

1. Set heartbeat producer time ([C00381](#)) to 0 ms to deactivate the heartbeat monitoring (node guarding and heartbeat must not be used simultaneously in a CANopen device).
2. Configure controller as NMT master: Set [C00352](#) = "1: Master".
3. Set guard time ([C00382](#)) to 0 ms (slave parameter).
4. Set life time factor ([C00383](#)) to 0 (slave parameter).
5. Configure monitoring for the node guarding in [C00386](#).
  - The value to be entered into a free subcode (1 ... 32) is "0x050203E8". It consists of the following:

Bit 31 ... bit 24 Life time factor	Bit 23 ... bit 16 Node address of slave	Bit 15 ... bit 0 Guard time
0x05	0x02	1000 [ms] = 0x03E8

6. Go to [C00612/1...32](#) and set the response required for the monitoring functions parameterised in [C00386/1...32](#) which are to take place in case of a "Node Guarding Event" in the NMT master.



### Tip!

- [C00387](#) displays the activity of every monitoring function parameterised in [C00386/1...32](#) in a bit-coded form.
- [C00388/1...32](#) displays the node guarding status of the monitored NMT slaves.
- [C00625](#) serves to set which status change is to occur in the NMT master in case of a "Node Guarding Event".

## Parameterise NMT slave (node 2)

1. Accept the settings made in the NMT master in [C00386](#) of the life time factor and the guard time for the NMTslave:
  - Set guard time ([C00382](#)) to 1000 ms.
  - Set life time factor ([C00383](#)) to 5.
2. Go to [C00614](#) and set the response required in case of a "Life Guarding Event" in the NMT slave.



### Tip!

[C00625](#) serves to set which status change is to occur in case of a "Life Guarding Event" in the NMT slave.

## Node guarding telegrams

- ▶ Remote Transmission Request:  
The RTR telegram from the NMT master has the following identifiers:  
Identifier (COB-ID) = 1792 + node address of slave = 1792 + 2 = 1794 = 0x702
- ▶ Remote Transmission Response:  
The response telegram from the NMT slave has the same identifier and the "Operational" NMT status in the user data (s = 5). ▶ [Telegram structure](#) (□ 330)

## 9.9.2 Heartbeat protocol


The heartbeat protocol can be used optionally to the node guarding protocol for monitoring nodes within a CAN network. Unlike the node guarding, this monitoring does not require a polling by means of an RTR telegram (Remote Transmission Request) from the NMT master.



### Note!

Heartbeat and node guarding protocols must not be used simultaneously in a CANopen device. If the heartbeat producer time is set > 0 ms, the heartbeat protocol is used.

### General procedure



[9-10] Heartbeat protocol

1. A heartbeat producer cyclically sends a heartbeat telegram to one or several heartbeat consumers.
2. One or several consumers monitor the regular arrival of the heartbeat telegram.

## 9.9.2.1 Telegram structure

- ▶ The heartbeat telegram from the producer has the following identifier:  
Identifier (COB-ID) = 1792 + node address of the producer
- ▶ The user data (1 byte) contain the status (s) of the producer:

Heartbeat producer status		Data							
Communication status	Decimal value (s)	(r)	Producer status (s)						
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Boot up	0	0	0	0	0	0	0	0	0
Stopped	4	0	0	0	0	0	1	0	0
Operational	5	0	0	0	0	0	1	0	1
Pre-operational	127	0	1	1	1	1	1	1	1

## 9.9.2.2 Parameter setting

Short overview of the parameters for the "Heartbeat" monitoring function:

Parameter	Information	Lenze setting		Assignment	
		Value	Unit	Consumer	Producer
<a href="#">C00346</a>	CAN heartbeat activity	-		●	
<a href="#">C00347/1...32</a>	CAN heartbeat status	-		●	
<a href="#">C00381</a>	CAN heartbeat producer time	0	ms		●
<a href="#">C00385/1...32</a>	CAN heartbeat consumer time	0x00000000		●	
<a href="#">C00613/1...32</a>	Resp. to CAN heartbeat error	No response		●	
<a href="#">C00625</a>	CAN behaviour in case of fault	Pre-operational state		●	●

Highlighted in grey = display parameter

### Heartbeat producer time

Time interval for the transmission of the heartbeat telegram to one or several consumers.

- ▶ Can be parameterised in [C00381](#) or via the object [I-1017](#). The parameterised time is rounded down to an integer multiple of 5 ms.
- ▶ The heartbeat telegram is automatically transmitted as soon as a time > 0 ms is set.



### Note!

Heartbeat and node guarding protocols must not be used simultaneously in a CANopen device. If the heartbeat producer time is set > 0 ms, the heartbeat protocol is used.



## Heartbeat consumer time

Monitoring time for the node (producer) to be monitored.

- ▶ Can be parameterised in [C00385/1...32](#) or via the object [I-1016](#).
- ▶ The parameterised time is rounded down to an integer multiple of 5 ms and must have a higher value than the heartbeat producer time of the node to be monitored.
- ▶ A consumer can monitor up to 32 producers.

## Heartbeat event

The "Heartbeat Event" is triggered in the consumer if this has not received a heartbeat telegram from the producer within the "Heartbeat Consumer Time":

- ▶ In the Lenze setting, the consumer changes from the "Operational" communication status into the "Pre-Operational" communication status.
  - [C00625](#) or the [I-1029](#) object serve to set a status change.
- ▶ An emergency telegram with the emergency error code 0x8130 is transmitted to the NMT master.
- ▶ The response parameterised in [C00613/1...32](#) for the corresponding producer takes place (Lenze setting: "No response").



### Note!

The heartbeat monitoring starts when the first heartbeat telegram of a monitored producer has been successfully received and the "pre-operational" NMT status has been assumed.

The boot-up telegram counts as the first heartbeat telegram!

## 9.9.2.3 Commissioning example

### Task

A 9400 controller (node 2) configured as a heartbeat consumer is to monitor another 9400 controller (Heartbeat Producer; node 1).

- ▶ The heartbeat producer is to transmit every 10 seconds a heartbeat telegram to the heartbeat consumer.
- ▶ The heartbeat consumer monitors the arrival of the heartbeat telegram. In case of an error, a response is to take place.

### Parameter setting of the heartbeat producer (node 1)

1. Set heartbeat producer time ([C00381](#)) to 10 ms.

### Parameter setting of the heartbeat consumer (node 2)

1. Configure monitoring for the heartbeat in [C00385](#).
  - Note: The heartbeat consumer time must be higher than the heartbeat producer time set in [C00381](#) for the node to be monitored.
  - The value to be entered into a free subcode (1 ... 32) is "0x0001000F". It consists of the following:

Bit 31 ... bit 24 Reserved	Bit 23 ... bit 16 Node address of the producer	Bit 15 ... bit 0 Heartbeat consumer time (integer multiple of 5 ms)
0x00	0x01	15 [ms] = 0x000F

2. Go to [C00613/1...32](#) and set the response required for the monitoring functions parameterised in [C00385/1...32](#) which are to take place in case of a "Heartbeat Event" in the consumer.



### Tip!

- [C00346](#) displays the activity of every monitoring function parameterised in [C00385/1...32](#) in a bit-coded form.
- [C00347/1...32](#) displays the node guarding status of the monitored NMT slaves.
- [C00625](#) serves to set which status change is to occur in case of a "Heartbeat Event".

### Heartbeat telegram

- ▶ The heartbeat telegram from the producer has the following identifier:  
Identifier (COB-ID) = 1792 + node address of the producer = 1792 + 1 = 1793 = 0x701

## 9.9.3 Emergency telegram

If the error status changes due to the occurrence or elimination of an internal device error, an emergency telegram with the following structure is sent once to the NMT master:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Emergency error code		Error register	Manufacturer-specific error message				
Low byte	High byte	<a href="#">I-1001</a>	0x00 (reserved)	Low word		High word	
See table below				Low byte	High byte	Low byte	High byte
			<ul style="list-style-type: none"> <li>• With emergency error code 0x1000: Lenze error number (displayed value in <a href="#">C00168</a>)</li> <li>• With all other emergency error codes, the value "0" is entered here.</li> </ul>				

Emergency error code	Error register	Cause
0x0000	0xxx	One of several errors eliminated
	0x00	Single error eliminated (afterwards no more errors)
0x1000	0x01	Generic error <ul style="list-style-type: none"> <li>• In the standard device, an error has occurred with the error response "Fault", "Trouble", "Quick stop by trouble", "Warning", "Warning locked" or "System fault".</li> <li>• Error message is the Lenze error number (<a href="#">C00168</a>).</li> <li>• For error cause see fault error description (<a href="#">C00166</a>).</li> </ul>
0x3100	0x01	Supply voltage of standard device faulty or failed
0x8100	0x11	Communication error (warning)
0x8130	0x11	Life guarding error or heartbeat error
0x8150	0x11	Collision of identifiers (COB-IDs): An identifier parameterised for reception is also used for transmission.
0x8210	0x11	PDO length is shorter than the expected PDO length
0x8220	0x11	PDO length is longer than the expected PDO length
0x8700	0x11	Monitoring of the sync telegram

### Example

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Emergency error code		Error register	Manufacturer-specific error message				
0x00	0x10	0x01	0x00 (reserved)	0x1b	0x00	0x7b	0x00
Generic error				Lenze error message 0x007b001b: Encoder wire breakage. ▶ <a href="#">Error messages of the operating system</a> Corresponding "error-free" message: value "0x00000000"			



**Tip!**

A detailed description can be gathered from the CAN specification DS301, V4.02.

## 9.10 Implemented CANopen objects

Lenze devices can both be parameterised with Lenze codes and manufacturer-independent "CANopen objects". A completely CANopen compliant communication can only be achieved by using CANopen objects for parameter setting. The CANopen objects described in this chapter are defined in the CAN specification DS301 V4.02.

Many CANopen objects can be mapped on Lenze codes. The following table lists the related Lenze codes in the column "Relationship to Lenze codes".



### Note!

Some of the terms used here derive from the CANopen protocol.

### Overview of the CANopen indexes and their relationship to Lenze codes

CANopen object			Relationship to Lenze code
Index	Subindex	Name	
<a href="#">I-1000</a>	0	Device type	-
<a href="#">I-1001</a>	0	Error register	<a href="#">C00390</a>
<a href="#">I-1003</a>	Pre-defined error field		
	0	Number of errors	-
	1 ... 10	Standard error field	-
<a href="#">I-1005</a>	0	COB-ID SYNC message	<a href="#">C00367</a> <a href="#">C00368</a>
<a href="#">I-1006</a>	0	Communication cycle period	<a href="#">C00369</a>
<a href="#">I-100C</a>	0	Guard time	<a href="#">C00382</a>
<a href="#">I-100D</a>	0	Life time factor	<a href="#">C00383</a>
<a href="#">I-1010</a>	Store parameters		
	0	Highest subindex supported	-
	1	Save all parameters	-
<a href="#">I-1011</a>	Restore default parameters		
	0	Highest subindex supported	-
	1	restore all default parameters	-
<a href="#">I-1014</a>	0	COB-ID EMCY	<a href="#">C00391</a>
<a href="#">I-1015</a>	0	Inhibit time EMCY	<a href="#">C00392</a>
<a href="#">I-1016</a>	Consumer heartbeat time		
	0	Highest subindex supported	-
	1 ... 32	Consumer heartbeat time	<a href="#">C00385/1...32</a>
<a href="#">I-1017</a>	0	Producer heartbeat time	<a href="#">C00381</a>
<a href="#">I-1018</a>	Identity object		
	0	Highest subindex supported	-
	1	Vendor ID	-
	2	Product code	-
	3	Revision number	-
	4	Serial number	-

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

CANopen object			Relationship to Lenze code
Index	Subindex	Name	
<a href="#">I-1029</a>	Error behaviour		
	0	Highest subindex supported	-
	1	Communication error	<a href="#">C00625</a>
<a href="#">I-1200</a>	SDO1 server parameter		
	0	Highest subindex supported	-
	1	COB-ID client → server (rx)	<a href="#">C00372/1</a>
	2	COB-ID server → client (tx)	<a href="#">C00373/1</a>
<a href="#">I-1201</a>	SDO2 ... SDO10 server parameter		
...	0	Highest subindex supported	-
<a href="#">I-1209</a>	1	COB-ID client → server (rx)	<a href="#">C00372/2...10</a>
	2	COB-ID server → client (tx)	<a href="#">C00373/2...10</a>
	3	Node-ID of the SDO client	-
<a href="#">I-1400</a>	RPDO1 ... RPDO4 communication parameter		
...	0	Highest subindex supported	-
<a href="#">I-1403</a>	1	COB-ID used by RPDO	<a href="#">C00321/1...4</a>
	2	Transmission type	<a href="#">C00323/1...4</a>
	3	Inhibit time	-
	4	Compatibility entry	-
	5	Event timer	-
<a href="#">I-1600</a>	RPDO1 ... RPDO4 mapping parameter		
...	0	Number of mapped application objects in PDO	-
<a href="#">I-1603</a>	1 ... 8	Application object 1 ... 8	-
<a href="#">I-1800</a>	TPDO1 ... TPDO4 communication parameter		
...	0	Highest subindex supported	-
<a href="#">I-1803</a>	1	COB-ID used by TPDO	<a href="#">C00320/1...4</a>
	2	Transmission type	<a href="#">C00322/1...4</a>
	3	Inhibit time	<a href="#">C00324/1...4</a>
	4	Reserved	-
	5	Event timer	<a href="#">C00356/1...4</a>
<a href="#">I-1A00</a>	TPDO1 ... TPDO4 mapping parameter		
...	0	Number of mapped application objects in PDO	-
<a href="#">I-1A03</a>	1 ... 8	Application object 1 ... 8	-

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

## I-1000

Index: <b>I-1000</b>	Name: <b>Device type</b>					
Subindex	Default setting	Display area (min. value   unit   max. value)		Access	Data type	
0: Device type	0	0		4294967295	ro	U32

The CANopen index I-1000 specifies the profile for this device. Furthermore, additional information defined in the device profile itself can be stored here.

8th byte	7th byte	6th byte	5th byte
Data 4	Data 3	Data 2	Data 1
High word		Low word	
High byte	Low byte	High byte	Low byte
Additional information		Device profile number	

[9-1] Data telegram assignment

## I-1001

Index: <b>I-1001</b>	Name: <b>Error register</b>					
Subindex	Default setting	Display area (min. value   unit   max. value)		Access	Data type	
0: Error register	-	0		255	ro	U8

### Error register

- ▶ This object is related to the Lenze code [C00390](#).
- ▶ The error status in the data byte (U8) is bit coded (see the following table). Currently only bit 0 and bit 4 in the data byte contain the corresponding information.

Bit	Meaning if bit is set:
Bit 0	Generic error
Bit 1	Current error (not used)
Bit 2	Voltage error (not used)
Bit 3	Temperature error (not used)
Bit 4	Communication error
Bit 5	Device profile spec. error (not used)
Bit 6	Reserved
Bit 7	Manufacturer-specific error (not used)

I-1003

Index: <b>I-1003</b>	Name: <b>Pre-defined error field</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: Number of errors	0	0		255	rw	U8
1 ... 10: Standard error field	-	0		4294967295	ro	U32

## Error history

This object indicates that an error has occurred in the module and in the standard device.

Subindex	Meaning
0	Number of the error messages stored
1 ... 10	Display of the error list The error messages (U32) consist of a 16-bit error code and a 16-bit manufacturer-specific information field.



### Note!

The values in the "standard error field" under subindexes 1 ... 10 will be deleted if the subindex "number of recorded errors" is overwritten with the value "0".

Emergency error code	Cause	Entry in the error register ( <a href="#">I-1001</a> )
0x0000	One of several errors eliminated	0xxx
	Elimination of an individual error (afterwards error-free state)	0x00
0x1000	Standard device is in error status (error response "Trouble", "Message", "Warning", "Fault", "Quick stop by trouble" or "System fault")	0x01
0x3100	Supply voltage of standard device faulty or failed	0x01
0x8100	Communication error (warning)	0x11
0x8130	Life guard error or heartbeat error	0x11
0x8150	Collision of COB-IDs: an ID parameterised for reception also is used for transmission.	0x11
0x8210	PDO length is shorter than the expected PDO length	0x11
0x8220	PDO length is longer than the expected PDO length	0x11
0x8700	Monitoring of the sync telegram	0x11

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANOpen objects

I-1005

Index: <b>I-1005</b>	Name: <b>COB-ID SYNC message</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: COB-ID SYNC message	0x0000 0080 or 0x8000 0080	0		4294967295	rw	U32

This object serves to activate the creation of sync telegrams and write the value of the identifier.

- ▶ This object is related to the Lenze codes [C00367](#) and [C00368](#).

## Creating sync telegrams

To create sync telegrams, the bit 30 (see below) must be set to "1". The interval of the sync telegrams can be set with the object [I-1006](#).

## Writing identifiers

To receive PDOs, the value 0x80 must be entered in the 11-bit identifier in the Lenze setting (and according to the CANopen specification). This means that all modules are by default set to the same sync telegram.

- ▶ If sync telegrams are only to be received from specific communication modules, their identifiers can be entered with a value of up to and including 0x07FF.
- ▶ The identifier may only be changed if the communication module does not transmit a sync telegram (bit 30 = "0").
- ▶ How to change the identifier:
  - Deactivate identifier (set bit 30 to "0").
  - Change identifier.
  - Activate identifier (set bit 30 to "1").

8th byte		7th byte			6th byte		5th byte	
Data 4		Data 3			Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11					Bit 10 ... bit 0	
<b>X</b>	<b>0/1</b>	<b>Extended identifier*</b>					<b>11-bit identifier</b>	

\* The extended identifier is not supported - bit 11 ... bit 29 must be set to "0".

[9-2] Data telegram assignment



## I-1006

Index:	Name:					
<b>I-1006</b>	<b>Communication cycle period</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: Communication cycle period	0 µs	0	µs	65535000	rw	U32

Setting the sync telegram cycle time.

- ▶ A cycle time can be defined with the entry "1000" or an integer multiple of it.
- ▶ With "0 µs" (Lenze setting), no sync telegrams are created.
- ▶ This object is related to the Lenze code [C00369](#).

## I-100C

Index:	Name:					
<b>I-100C</b>	<b>Guard time</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: Guard time	0 ms	0	ms	65535	rw	U16

Monitoring time for node guarding. ▶ [Node guarding protocol](#) (329)

- ▶ Time within the NMT slave expects the RTRs from the NMTmaster.
- ▶ The "Node Life Time" is the product from "Guard Time" and "Life Time Factor":  
**Node Life Time = Guard Time (I-100C) x Life Time Factor (I-100D)**
- ▶ The "Life Guarding Event" occurs in the NMT slave if this has not been triggered from the NMT master trough an RTR within the "Node Life Time".
- ▶ With "0 ms" (Lenze setting) monitoring is not supported by the slave.
- ▶ This object is related to the Lenze code [C00382](#).

## I-100D

Index:	Name:					
<b>I-100D</b>	<b>Life time factor</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: Life time factor	0	0		255	rw	U8

Life Time Factor for node guarding. ▶ [Node guarding protocol](#) (329)

- ▶ The "Node Life Time" is the product from "Guard Time" and "Life Time Factor":  
**Node Life Time = Guard Time (I-100C) x Life Time Factor (I-100D)**
- ▶ The "Life Guarding Event" occurs in the NMT slave if this has not been triggered from the NMT master trough an RTR within the "Node Life Time".
- ▶ With "0" (Lenze setting) monitoring is not supported by the slave.
- ▶ This object is related to the Lenze code [C00383](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

I-1010

Index: <b>I-1010</b>	Name: <b>Store parameters</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type
0: highest subindex supported	1	- (only read access)		ro	U32
1: Save all parameters	-	0	4294967295	rw	U32

Save parameters with mains failure protection.

- ▶ Corresponds to the device command [C00002](#) = "11: Save start parameters".
- ▶ This command serves to save the current parameter settings of the active application with mains failure protection in the memory module of the controller.

Subindex	Meaning	
	Read	Write
0	Max. supported subindex: 1	- (a write attempt triggers the error message 0x06010002.)
1	Reading memory functions of all parameters.	Save parameters with mains failure protection.

## Read subindex 1

8th byte	7th byte	6th byte	5th byte	
Data 4	Data 3	Data 2	Data 1	
Bit 31 ... bit 2			Bit 1	Bit 0
0			0/1	0/1

[9-3] Assignment of the data telegram (read access)

Bit	Meaning	
Bit 0	0	No saving of parameters on command.
	1	Saving of parameters on command (Lenze).
Bit 1	0	No automatic saving of parameters (Lenze).
	1	Automatic saving of parameters.

## Write subindex 1

In addition to the index and subindex, the telegram data must also include the "save" signature (ASCII characters; ISO 8859) so that the parameters are stored.

- ▶ A response according to the DS301 V4.02 specification occurs while writing with a wrong identifier.

8th byte	7th byte	6th byte	5th byte
Data 4	Data 3	Data 2	Data 1
"e" = 0x65	"v" = 0x76	"a" = 0x61	"s" = 0x73

[9-4] Assignment of the data telegram (write access)

## I-1011

Index: <b>I-1011</b>	Name: <b>Restore default parameters</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type
0: highest subindex supported	1	- (only read access)		ro	U32
1: restore all default parameters	-	0		4294967295 rw	U32

### Load Lenze setting.

- ▶ Corresponds to the device command [C00002](#) = "0: Load Lenze setting".
- ▶ This command serves to reset the parameters of the active application to the Lenze setting which is stored in the firmware.

Subindex	Meaning	
	Read	Write
0	Max. supported subindex: 1	- (a write attempt triggers the error message 0x06010002.)
1	Loading of all parameters possible.	Load Lenze setting.

### Read subindex 1

8th byte	7th byte	6th byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 1			Bit 0
0			0/1

[9-5] Assignment of the data telegram (read )

Bit	Setting
Bit 0	0 Parameters cannot be loaded.
	1 Parameters can be loaded (Lenze).

### Write subindex 1

In addition to the index and subindex, the telegram data must include the "load" signature (ASCII characters; ISO 8859) so that the Lenze setting can be loaded.

- ▶ A response according to the DS301 V4.02 specification occurs while writing with a wrong identifier.

8th byte	7th byte	6th byte	5th byte
Data 4	Data 3	Data 2	Data 1
"d" = 0x64	"a" = 0x61	"o" = 0x6F	"l" = 0x6C

[9-6] Assignment of the data telegram (write)

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

I-1014

Index: <b>I-1014</b>	Name: <b>COB-ID EMCY</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: COB-ID EMCY	0x80+Node-ID	0		4294967295	rw	U32

If a communication error or an internal error of the communication module or the controller occurs or is acknowledged (e. g. "trouble"), an error message is sent via the system bus. For each error, the telegram is interrupted once. By means of bit 31 this function can be activated or deactivated.

► This object is related to the Lenze code [C00391](#).

8th byte		7th byte		6th byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
<b>0/1</b>	<b>0</b>	<b>Extended identifier*</b>				<b>11-bit identifier</b>	
* The extended identifier is not supported - bit 11 ... bit 29 must be set to "0".							

[9-7] Data telegram assignment

Bit	Setting
Bit 31	0 Emergency object valid.
	1 Emergency object invalid.



## Note!

The identifier can only be changed in the "Emergency object invalid" status (bit 31 = 1).

I-1015

Index: <b>I-1015</b>	Name: <b>Inhibit time EMCY</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: inhibit time EMCY	0	0	0.1 ms	65535	rw	U32

Time which must elapse after an error message ([I-1014](#)) has been transmitted before further error messages can be sent via the bus.

► The entered value multiplied by "0.1" gives the delay time in [ms]. The values are automatically rounded up to whole values in [ms].

► This object is related to the Lenze code [C00392](#).

## I-1016

Index: <b>I-1016</b>	Name: <b>Consumer heartbeat time</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	32	- (only read access)			ro	U32
1 ... 32: consumer heartbeat time	0	0		4294967295	rw	U32

Monitoring time for the nodes 1 ... 32 to be monitored via heartbeat. ▶ [Heartbeat protocol](#) (335)

- ▶ The parameterised time is rounded down to an integer multiple of 5 ms and must have a higher value than the heartbeat producer time of the node to be monitored.

Subindex	Meaning	Lenze code
0	Number of nodes to be monitored	
1 ... 32	Node-ID and heartbeat time of the node 1 ... 32 to be monitored	<a href="#">C00385/1...32</a>

8th byte	7th byte	6th byte	5th byte
<b>Data 4</b>	<b>Data 3</b>	<b>Data 2</b>	<b>Data 1</b>
Bit 31 ... bit 24	Bit 23 ... bit 16	Bit 15 ... bit 0	
<b>0</b> (reserved)	<b>Node ID</b>	<b>Heartbeat time</b> in [ms]	

[9-8] Data telegram assignment

## I-1017

Index: <b>I-1017</b>	Name: <b>Producer heartbeat time</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: Producer heartbeat time	0	0	ms	65535	rw	U32

Time interval for the transmission of the heartbeat telegram to one or several consumers. ▶ [Heartbeat protocol](#) (335)

- ▶ The parameterised time is rounded down to an integer multiple of 5 ms.
- ▶ The heartbeat telegram is transmitted automatically as soon as a time > 0 ms is set. The monitoring function "Node Guarding" is deactivated in this case.
- ▶ This object is related to the Lenze code [C00381](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

## I-1018

Index: <b>I-1018</b>		Name: <b>Identity object</b>				
Subindex	Default setting	Display area (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	see below	0		4294967295	ro	U32
1: Vendor ID						
2: Product code						
3: Revision number						
4: Serial number						

Subindex	Meaning						
1	Manufacturer identification number <ul style="list-style-type: none"> <li>The identification number allocated to Lenze by the "CAN in Automation e. V." organisation is "0x0000003B".</li> </ul>						
2	Product code <table border="1"> <tr> <td>0x94001</td> <td>9400 Stateline</td> </tr> <tr> <td>0x94002</td> <td>9400 HighLine / ServoPLC</td> </tr> <tr> <td>0x94004</td> <td>9400 regenerative power supply module</td> </tr> </table>	0x94001	9400 Stateline	0x94002	9400 HighLine / ServoPLC	0x94004	9400 regenerative power supply module
0x94001	9400 Stateline						
0x94002	9400 HighLine / ServoPLC						
0x94004	9400 regenerative power supply module						
3	Main version and subversion of the firmware						
4	Serial number						

## I-1029

Index: <b>I-1029</b>		Name: <b>Error behaviour</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	1	- (only read access)			ro	U8
1: Communication error	0	0		2	rw	U8

This object serves to set the communication status to which the controller is to change after a bus off, a node/life guarding event or a heartbeat event.

Subindex	Meaning	Lenze code
1	Status change after bus off, node/life guarding event or heartbeat event:	<a href="#">C00625</a>
	0 State change from "Operational" to "Pre-operational"	
	1 No state change	
	2 State change to "Stopped"	

## I-1200

Index: <b>I-1200</b>	Name: <b>SDO1 server parameter</b>					
Subindex	Default setting	Display area (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	2	2			2 ro	U8
1: COB-ID client -> server (Rx)	Node ID + 0x600	0		4294967295	ro	U32
2: COB-ID server -> client (Tx)	Node ID + 0x580	0		4294967295	ro	U32

Identifier for the SDO server channel 1 (basic SDO channel).

- ▶ The basic SDO channel can neither be changed nor deactivated according to DS301 V4.02.

Subindex	Meaning
1	Receive identifier specification <ul style="list-style-type: none"> <li>• For SDO server channel 1: node address (C00350) + 0x600</li> </ul>
2	Send identifier specification <ul style="list-style-type: none"> <li>• For SDO server channel 1: node address (C00350) + 0x580</li> </ul>

8th byte		7th byte		6th byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
<b>0</b>	<b>0</b>	<b>Extended identifier*</b>				<b>11-bit identifier</b>	

\* The extended identifier is not supported - bit 11 ... bit 29 must be set to "0".

[9-9] Data telegram assignment

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

I-1201

Index: <b>I-1201</b>		Name: <b>SDO2 server parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	3	- (only read access)		ro	U8	
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw	U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32	

Setting of the identifiers for the SDO server channel 2.

- ▶ The server SDO parameter is only valid if the bit 31 is set to "0" for both transmission directions (subindex 1 and 2).
- ▶ In the Lenze setting, the SDO server channels 2 ... 10 are deactivated (bit 31 = "1").
- ▶ The identifier may only be changed if the SDO is invalid (bit 31 = "1").

Subindex	Meaning
1	Receive identifier specification
2	Send identifier specification
3	Node address of the client

8th byte		7th byte		6th byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
<b>0/1</b>	<b>0</b>	<b>Extended identifier*</b>				<b>11-bit identifier</b>	

\* The extended identifier is not supported - bit 11 ... bit 29 must be set to "0".

[9-10] Data telegram assignment

Bit	Setting
Bit 31	0 SDO valid.
	1 SDO invalid.

How to change the identifier:

1. Deactivate identifier (set bit 31 to "1").
2. Change identifier.
3. Activate identifier (set bit 31 to "0").



## Example

The parameter data channel 2 of the controller with the node address 4 is to be activated.

- ▶ For this purpose, the bit 31 in the subindexes 1 and 2 of the object [I-1201](#) must be set to the value "0" (≡ "SDO valid").
- ▶ Both "Write request" commands must be transmitted from the master to the nodes via the basic SDO channel.

## Calculation of the identifiers

- ▶ Identifier (COB-ID) = basic identifier + node address (node ID)
- ▶ Basic identifier SDO2 from the master to the drive: 1600 (0x640)  
→ identifier = 0x640 + 0x4 = 0x644
- ▶ Basic identifier SDO2 from the drive to the master: 1472 (0x5C0)  
→ identifier = 0x5C0 + 0x4 = 0x5C4

## Resulting data (data 1 ... data 4)

8th byte		7th byte			6th byte		5th byte	
Data 4		Data 3			Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11					Bit 10 ... bit 0	
0	0	Extended identifier = 0					11-bit identifier = 0x644	
0x00		0x00			0x06		0x44	

[9-11] Data telegram assignment for subindices 1

8th byte		7th byte			6th byte		5th byte	
Data 4		Data 3			Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11					Bit 10 ... bit 0	
0	0	Extended identifier = 0					11-bit identifier = 0x5C4	
0x00		0x00			0x05		0xC4	

[9-12] Data telegram assignment for subindices 2

## Assignment of the user data

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x23	0x01	0x12	0x01	0x44	0x06	0x00	0x00

[9-13] Assignment of the user data for writing the subindex 1

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x23	0x01	0x12	0x02	0xC4	0x05	0x00	0x00

[9-14] Assignment of the user data for writing the subindex 2

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus

Implemented CANopen objects

## I-1202

Index: <b>I-1202</b>		Name: <b>SDO3 server parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	3	- (only read access)		ro	U8	
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw	U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32	

Setting of the identifiers for the SDO server channel 3. For description see object [I-1201](#).

## I-1203

Index: <b>I-1203</b>		Name: <b>SDO4 server parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	3	- (only read access)		ro	U8	
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw	U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32	

Setting of the identifiers for the SDO server channel 4. For description see object [I-1201](#).

## I-1204

Index: <b>I-1204</b>		Name: <b>SDO5 server parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	3	- (only read access)		ro	U8	
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw	U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32	

Setting of the identifiers for the SDO server channel 5. For description see object [I-1201](#).

## I-1205

Index: <b>I-1205</b>		Name: <b>SDO6 server parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	3	- (only read access)		ro	U8	
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw	U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32	

Setting of the identifiers for the SDO server channel 6. For description see object [I-1201](#).

## I-1206

Index: <b>I-1206</b>		Name: <b>SDO7 server parameter</b>			
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type
0: highest subindex supported	3	- (only read access)		ro	U8
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32

Setting of the identifiers for the SDO server channel 7. For description see object [I-1201](#).

## I-1207

Index: <b>I-1207</b>		Name: <b>SDO8 server parameter</b>			
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type
0: highest subindex supported	3	- (only read access)		ro	U8
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32

Setting of the identifiers for the SDO server channel 8. For description see object [I-1201](#).

## I-1208

Index: <b>I-1208</b>		Name: <b>SDO9 server parameter</b>			
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type
0: highest subindex supported	3	- (only read access)		ro	U8
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32

Setting of the identifiers for the SDO server channel 9. For description see object [I-1201](#).

## I-1209

Index: <b>I-1209</b>		Name: <b>SDO10 server parameter</b>			
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type
0: highest subindex supported	3	- (only read access)		ro	U8
1: COB-ID client -> server (Rx)	0x80000000	0		4294967295	rw U32
2: COB-ID server -> client (Tx)	0x80000000	0		4294967295	rw U32
3: Node-ID of the SDO client	1 ... 127	- (only read access)		ro	U32

Setting of the identifiers for the SDO server channel 10. For description see object [I-1201](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

I-1400

Index: <b>I-1400</b>		Name: <b>RPDO1 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	5	- (only read access)		ro	U8	
1: COB-ID used by RPDO	0x200 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	-	- (for RPDOs unused)		rw	U16	
4: compatibility entry	-	- (reserved, write or read access results in error message 0x06090011)		rw	U8	
5: event timer	-	- (for RPDOs unused)		rw	U16	

Communication parameter for the reception of process data via RPDO1

Subindex	Meaning	Lenze code
1	Identifier RPDO1 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x200 + node ID	<a href="#">C00321/1</a>
2	RPDO Transmission type according to DS301 V4.02 ▶ <a href="#">Transmission type</a> (□ 308)	<a href="#">C00323/1</a>

8th byte		7th byte		6th byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0/1	0/1	Extended identifier*				11-bit identifier	

\* The extended identifier is not supported - bit 11 ... bit 29 must be set to "0".

[9-15] Data telegram assignment

Bit	Setting
Bit 30	0 RTR to this PDO possible (cannot be set).
	1 RTR to this PDO not possible (Lenze).
Bit 31	0 PDO active.
	1 PDO inactive.

How to change the identifier:

1. Deactivate identifier (set bit 31 to "1").
2. Change identifier.
3. Activate identifier (set bit 31 to "0").

## I-1401

Index: <b>I-1401</b>		Name: <b>RPDO2 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	5	- (only read access)		ro	U8	
1: COB-ID used by RPDO	0x300 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	-	- (for RPDOs unused)		rw	U16	
4: compatibility entry	-	- (reserved, write or read access results in error message 0x06090011)		rw	U8	
5: event timer	-	- (for RPDOs unused)		rw	U16	

Communication parameter for the reception of process data via RPDO2

Subindex	Meaning	Lenze code
1	Identifier RPDO2 <ul style="list-style-type: none"> <li>The basic setting is according to the "Predefined Connection Set": Identifier = 0x300 + node ID</li> </ul>	<a href="#">C00321/2</a>
2	RPDO Transmission type according to DS301 V4.02 <ul style="list-style-type: none"> <li><a href="#">Transmission type</a> (□ 308)</li> </ul>	<a href="#">C00323/2</a>

► For assignment of the data telegram see object [I-1400](#).

## I-1402

Index: <b>I-1402</b>		Name: <b>RPDO3 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	5	- (only read access)		ro	U8	
1: COB-ID used by RPDO	0x400 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	-	- (for RPDOs unused)		rw	U16	
4: compatibility entry	-	- (reserved, write or read access results in error message 0x06090011)		rw	U8	
5: event timer	-	- (for RPDOs unused)		rw	U16	

Communication parameter for the reception of process data via RPDO3

Subindex	Meaning	Lenze code
1	Identifier RPDO3 <ul style="list-style-type: none"> <li>The basic setting is according to the "Predefined Connection Set": Identifier = 0x400 + node ID</li> </ul>	<a href="#">C00321/3</a>
2	RPDO Transmission type according to DS301 V4.02 <ul style="list-style-type: none"> <li><a href="#">Transmission type</a> (□ 308)</li> </ul>	<a href="#">C00323/3</a>

► For assignment of the data telegram see object [I-1400](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

## I-1403

Index: <b>I-1403</b>		Name: <b>RPDO4 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: highest subindex supported	5	- (only read access)		ro	U8	
1: COB-ID used by RPDO	0x500 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	-	- (for RPDOs unused)		rw	U16	
4: compatibility entry	-	- (reserved, write or read access results in error message 0x06090011)		rw	U8	
5: event timer	-	- (for RPDOs unused)		rw	U16	

Communication parameter for the reception of process data via RPDO4

Subindex	Meaning	Lenze code
1	Identifier RPDO4 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x500 + node ID	<a href="#">C00321/4</a>
2	RPDO Transmission type according to DS301 V4.02 ▶ <a href="#">Transmission type</a> (□ 308)	<a href="#">C00323/4</a>

▶ For assignment of the data telegram see object [I-1400](#).

## I-1600

Index: <b>I-1600</b>		Name: <b>RPDO1 mapping parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)		Access	Data type	
0: number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1600 serves to receive parameter data as RPDO1.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO1

8th byte	7th byte	6th byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 16		Bit 15 ... bit 8	Bit 7 ... bit 0
Index		Subindex	Length

[9-16] Data telegram assignment

IEC 61131 process data words are mapped. Only whole bytes can be mapped (the granularity of the mapping entries is one byte).

## I-1601

Index: <b>I-1601</b>		Name: <b>RPDO2 mapping parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1601 serves to receive parameter data as RPDO2.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO2

► For assignment of the data telegram see object [I-1600](#).

## I-1602

Index: <b>I-1602</b>		Name: <b>RPDO3 mapping parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1602 serves to receive parameter data as RPDO3.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO3

► For assignment of the data telegram see object [I-1600](#).

## I-1603

Index: <b>I-1603</b>		Name: <b>RPDO4 mapping parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1603 serves to receive parameter data as RPDO4.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO4

► For assignment of the data telegram see object [I-1600](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

I-1800

Index: <b>I-1800</b>		Name: <b>TPDO1 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	5	- (only read access)			ro	U8
1: COB-ID used by TPDO	0x180 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	0 ms	0	0.1 ms	65535	rw	U16
4: reserved	-	- (reserved, write or read access results in error message 0x06090011)			rw	U8
5: event timer	0 ms	0	ms	65535	rw	U16

Communication parameter for the transmission of process data via TPDO1

Subindex	Meaning	Lenze code
1	Identifier TPDO1 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x180 + node ID	<a href="#">C00320/1</a>
2	TPDO transmission type according to DS301 V4.02 ▶ <a href="#">Transmission type</a> (□ 308)	<a href="#">C00322/1</a>
3	Minimum time between the transmission of two equal TPDOs (see DS301, V4.02).	<a href="#">C00324/1</a>
5	Cycle time with which the PDOs are transmitted with the transmission type "254".	<a href="#">C00356/1</a>

8th byte		7th byte		6th byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0/1	0/1	Extended identifier*				11-bit identifier	

\* The extended identifier is not supported - bit 11 ... bit 29 must be set to "0".

[9-17] Data telegram assignment

Bit	Setting
Bit 30	0 RTR to this PDO possible (Lenze).
	1 RTR to this PDO not possible (cannot be set).
Bit 31	0 PDO active.
	1 PDO inactive.

How to change the identifier:

1. Deactivate identifier (set bit 31 to "1").
2. Change identifier.
3. Activate identifier (set bit 31 to "0").



## Subindex 3 - inhibit time

The delay time can only be changed if the PDO is inactive (subindex 1, bit 31 = 1). The entered value multiplied by 0.1 results in the delay time in [ms]. The calculated delay time is always rounded down to an inter value.

Example:

- ▶ Entered value: 26
- ▶ Calculated time =  $26 * 0.1 \text{ [ms]} = 2.6 \text{ [ms]} \rightarrow \text{delay time} = 2 \text{ [ms]}$

### I-1801

Index:	Name:					
<b>I-1801</b>	<b>TPDO2 communication parameter</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	5	- (only read access)			ro	U8
1: COB-ID used by TPDO	0x280 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	0 ms	0	0.1 ms	65535	rw	U16
4: reserved	-	- (reserved, write or read access results in error message 0x06090011)			rw	U8
5: event timer	0 ms	0	ms	65535	rw	U16

Communication parameter for the transmission of process data via TPDO2

Subindex	Meaning	Lenze code
1	Identifier TPDO2 <ul style="list-style-type: none"> <li>• The basic setting is according to the "Predefined Connection Set": Identifier = 0x280 + node ID</li> </ul>	<a href="#">C00320/2</a>
2	TPDO transmission type according to DS301 V4.02 ▶ <a href="#">Transmission type</a> (□ 308)	<a href="#">C00322/2</a>
3	Minimum time between the transmission of two equal TPDOs (see DS301, V4.02).	<a href="#">C00324/2</a>
5	Cycle time with which the PDOs are transmitted with the transmission type "254".	<a href="#">C00356/2</a>

- ▶ For assignment of the data telegram see object [I-1800](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

## I-1802

Index: <b>I-1802</b>		Name: <b>TPDO3 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	5	- (only read access)			ro	U8
1: COB-ID used by TPDO	0x380 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	0 ms	0	0.1 ms	65535	rw	U16
4: reserved	-	- (reserved, write or read access results in error message 0x06090011)			rw	U8
5: event timer	0 ms	0	ms	65535	rw	U16

Communication parameter for the transmission of process data via TPDO3

Subindex	Meaning	Lenze code
1	Identifier TPDO3 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x380 + node ID	<a href="#">C00320/3</a>
2	TPDO transmission type according to DS301 V4.02 ▶ <a href="#">Transmission type</a> (□ 308)	<a href="#">C00322/3</a>
3	Minimum time between the transmission of two equal TPDOs (see DS301, V4.02).	<a href="#">C00324/3</a>
5	Cycle time with which the PDOs are transmitted with the transmission type "254".	<a href="#">C00356/3</a>

▶ For assignment of the data telegram see object [I-1800](#).

## I-1803

Index: <b>I-1803</b>		Name: <b>TPDO4 communication parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: highest subindex supported	5	- (only read access)			ro	U8
1: COB-ID used by TPDO	0x480 + node ID	0		4294967295	rw	U32
2: transmission type	254	0		255	rw	U8
3: inhibit time	0 ms	0	0.1 ms	65535	rw	U16
4: reserved	-	- (reserved, write or read access results in error message 0x06090011)			rw	U8
5: event timer	0 ms	0	ms	65535	rw	U16

Communication parameter for the transmission of process data via TPDO4

Subindex	Meaning	Lenze code
1	Identifier TPDO4 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x480 + node ID	<a href="#">C00320/4</a>
2	TPDO transmission type according to DS301 V4.02 ▶ <a href="#">Transmission type</a> (□ 308)	<a href="#">C00322/4</a>
3	Minimum time between the transmission of two equal TPDOs (see DS301, V4.02).	<a href="#">C00324/4</a>
5	Cycle time with which the PDOs are transmitted with the transmission type "254".	<a href="#">C00356/4</a>

▶ For assignment of the data telegram see object [I-1800](#).

## I-1A00

Index: <b>I-1A00</b>	Name: <b>TPDO1 mapping parameter</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1A00 serves to transmit parameter data as TPDO1.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entry 1 ... 8 for TPDO1

8th byte	7th byte	6th byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 16		Bit 15 ... bit 8	Bit 7 ... bit 0
Index		Subindex	Length

[9-18] Data telegram assignment

IEC 61131 process data words are mapped. Only whole bytes can be mapped (the granularity of the mapping entries is one byte).

## I-1A01

Index: <b>I-1A01</b>	Name: <b>TPDO2 mapping parameter</b>					
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1A01 serves to transmit parameter data as TPDO2.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO2

► For assignment of the data telegram see object [I-1A00](#).

# 9400 HighLine | Parameter setting & configuration

"CAN on board" system bus  
Implemented CANopen objects

## I-1A02

Index: <b>I-1A02</b>		Name: <b>TPDO3 mapping parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1A02 serves to transmit parameter data as TPDO3.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO4

► For assignment of the data telegram see object [I-1A00](#).

## I-1A03

Index: <b>I-1A03</b>		Name: <b>TPDO4 mapping parameter</b>				
Subindex	Default setting	Setting range (min. value   unit   max. value)			Access	Data type
0: number of mapped application objects in PDO	0	0			8 rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32


The object I-1A03 serves to transmit parameter data as TPDO4.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for TPDO4

► For assignment of the data telegram see object [I-1A00](#).

## 9.11 System block "LS\_SyncInput"

The LS\_SyncInput system block provides status information in the function block editor about the sync telegram received via the system block.



### Outputs

Identifier	Data type	Value/meaning																										
SYNC_wSyncCycleTime	WORD	Sync cycle time in [ $\mu$ s] <ul style="list-style-type: none"> <li>Time with which the internal phase-locking loop (PLL) visualises the synchronisation signals. The time must be set in <a href="#">C01121</a> in accordance with the cycle of the synchronisation source selected in <a href="#">C01120</a>.</li> </ul>																										
SYNC_wSource	WORD	Synchronisation source selected in <a href="#">C01120</a> : <table border="1"> <tr><td>0</td><td>Off</td></tr> <tr><td>1</td><td>CAN on board</td></tr> <tr><td>2</td><td>CAN module</td></tr> <tr><td>4</td><td>Module in MX11</td></tr> <tr><td>5</td><td>Module in MX12</td></tr> <tr><td>6</td><td>Digital input 1</td></tr> <tr><td>7</td><td>Digital input 2</td></tr> <tr><td>8</td><td>Digital input 3</td></tr> <tr><td>9</td><td>Digital input 4</td></tr> <tr><td>10</td><td>Digital input 5</td></tr> <tr><td>11</td><td>Digital input 6</td></tr> <tr><td>12</td><td>Digital input 7</td></tr> <tr><td>13</td><td>Digital input 8</td></tr> </table>	0	Off	1	CAN on board	2	CAN module	4	Module in MX11	5	Module in MX12	6	Digital input 1	7	Digital input 2	8	Digital input 3	9	Digital input 4	10	Digital input 5	11	Digital input 6	12	Digital input 7	13	Digital input 8
0	Off																											
1	CAN on board																											
2	CAN module																											
4	Module in MX11																											
5	Module in MX12																											
6	Digital input 1																											
7	Digital input 2																											
8	Digital input 3																											
9	Digital input 4																											
10	Digital input 5																											
11	Digital input 6																											
12	Digital input 7																											
13	Digital input 8																											
SYNC_nSyncDeviation	INT	Deviation of the synchronisation signal in [increments] <ul style="list-style-type: none"> <li><math>\pm 16000</math> increments <math>\equiv \pm 1</math> ms</li> </ul>																										
SYNC_bSyncInsideWindow	BOOL	Status signal "Synchronisation signal within time slot" <b>Note!</b> If you use this signal in the application, observe the change in behaviour from software version V7.= onwards described in the following subchapter! <a href="#">► Behaviour of the status signal bSyncInsideWindow ( 366)</a> <table border="1"> <tr> <td>TRUE</td> <td>The last synchronisation signal has been around the expected value within the time slot parameterised in <a href="#">C01123</a>.</td> </tr> </table>	TRUE	The last synchronisation signal has been around the expected value within the time slot parameterised in <a href="#">C01123</a> .																								
TRUE	The last synchronisation signal has been around the expected value within the time slot parameterised in <a href="#">C01123</a> .																											
SYNC_bSyncSignalReceived	BOOL	Status signal "Receive synchronisation signal" <table border="1"> <tr> <td>TRUE</td> <td>Synchronisation signal has been received.</td> </tr> </table>	TRUE	Synchronisation signal has been received.																								
TRUE	Synchronisation signal has been received.																											

► [Synchronisation of PDOs via sync telegram \( 310\)](#)

### 9.11.1 Behaviour of the status signal *bSyncInsideWindow*

[C01123](#) serves to set a time slot for monitoring the synchronisation signal. If the synchronisation signal received via the bus is in this time slot (around the expected time of the synchronisation signal), the *bSyncInsideWindow* output is set to TRUE.

#### Up to and including software version V6.0 the following applies:

Due to an error in the implementation, the phase position set in [C01122](#) is included in the calculation of the time slot. The time slot effective for monitoring around the expected time of the synchronisation signal is thus increased by the amount of the set phase position.

Example:

- ▶ Sync phase position ([C01122](#)) = 400 µs
  - ▶ Sync tolerance ([C01123](#)) = 20 µs
- The time slot for monitoring has a size of 420 µs!

#### The following applies from software version V7.0 onwards:

The faulty inclusion of the phase position set in [C01122](#) into the calculation of the time slot has been removed. The time slot for monitoring the synchronisation signal only corresponds to the sync tolerance set in [C01123](#).

Example:

- ▶ Sync phase position ([C01122](#)) = 400 µs
  - ▶ Sync tolerance ([C01123](#)) = 20 µs
- The time slot for monitoring has a size of 20 µs!

#### Feedbacks and their remedies

If the *bSyncInsideWindow* status signal is used in existing systems, this remedy reduces the monitoring window by the amount of the phase position if it is non-zero. This may cause an unwanted activation of the monitoring of the synchronisation signal programmed by the user.

Remedy: When the sync tolerance is increased ([C01123](#)) by the amount of the phase position set in [C01122](#), the compatible state is restored.

## 10 Safety engineering

The controller can be equipped with a safety module. The individual safety module types have a different range of functions to optimally meet different requirements.

"Integrated safety technology" stands for user-related safety functions that are applicable to the protection of persons working with machines and the machine protection.

The motion functions are furthermore executed by the controller. The safety modules monitor the reliable compliance with limit values and provide safe inputs and outputs. If limit values are exceeded, the safety modules start control functions for the fault scenario in accordance with EN 60204-1 directly in the controller.

The safety functions are suitable for applications according to IEC 61508, SIL 3 and, depending on the module, meet the requirements of EN 954, part 1, up to control category 4.



### Note!

For detailed information about the integrated safety technology, please see the manual for the safety module.

## 10.1 Integration into the application

If a safety function is requested, the safety engineering activates a corresponding safe monitoring function. The standstill function, however, is only executed directly if the "Safe torque off" function (STO) is activated. For the other safety functions, an action of the controller is required, which is safely monitored. The implementation of the corresponding action (e.g. braking, braking to standstill, holding of the standstill position) must be carried out by the application.

### System block "LS\_SafetyModuleInterface"

For the transmission of the control and status information from the safety module to the application, the **LS\_SafetyModuleInterface** system block is provided in the function block editor of the »Engineer«. ([□ 370](#))

### System block "LS\_Limiter"/basic function "Limiter"

Furthermore the **LS\_Limiter** system block which contains the basic function "[Limiter](#)" is provided in the function block editor for the connection of safety engineering to the application. ([□ 513](#))

For one thing, the basic function "Limiter" provides a parameterisation interface in the »Engineer« for a comfortable setting of limit positions, limited speeds, and limit values, and for another it enables the drive to be braked specifically **after request** through the safety module.

### General procedure

1. Activation of the safety function on the safety module (e. g. SS1 - safe stop 1).  
→ Monitoring starts.
2. The safety module informs the controller via a control word that the safety function has been activated.
3. The application evaluates the control word and starts the required motion sequence (e.g. braking).



### Note!

If communication to the controller is interrupted, e.g. by switching off the controller, the safety module responds as follows:

- Fault stop with STO is activated.
- "Warning" error message is transmitted.
- The LED "ME" is blinking.

The required fault acknowledgement (AIE) is possible via terminal or safety bus.




## 10.2 Selecting the required safety module

The safety module expected by the application and the controller is selected in [C00214](#).

- ▶ In the »Engineer« this setting is carried out automatically by assigning the device modules to the controller, i.e. the »Engineer« automatically sets [C00214](#) according to the safety module selected.
- ▶ If the safety module selected in [C00214](#) does not correspond to the safety module type connected, an error will be activated.

## 10.3 System block "LS\_SafetyModuleInterface"

The **LS\_SafetyModuleInterface** system block is the interface to the safety module in the function block editor.



### Outputs

Identifier	Data type	Value/meaning
SMI_dnState	DINT	Bit coded status information from the safety module ▶ <a href="#">Status information</a> (EN 371)
SMI_dnIoState	DINT	Bit coded I/O status information from the safety module ▶ <a href="#">I/O status information</a> (EN 372)
SMI_dwControl	DWORD	Bit coded control information from the safety module ▶ <a href="#">Control information</a> (EN 373)
SMI_bPowerStageEnable	BOOL	Status signal "Inverter enable" TRUE   Inverter is enabled by the safety module.
SMI_byModuleId	BYTE	ID of the safety module available in the controller

### 10.3.1 Status information

Via the bit-coded status signal *SMI\_dnState* of the **LS\_SafetyModuleInterface** SB, the SM3xx safety module transmits the status of safety functions to the application.

► Which bits are supported depends on the safety module used.

Bit coding of the status signal <i>SMI_dnState</i>		
Bit	Name	Meaning
0	STO	"Safe torque off (STO)" function is active. • The drive is safely switched to torqueless operation.
3	EC_STO	Error stop category 0: "Safe torque off (STO)" function is active.
4	EC_SS1	Error stop category 1: "Safe stop 1 (SS1)" function is active.
5	EC_SS2	Error stop category 2: "Safe stop 2 (SS2)" function is active.
8	SLS1 monitored	Safely limited speed 1 is activated and complied with.
9	SLS2 monitored	Safely limited speed 2 is activated and complied with.
10	SLS3 monitored	Safely limited speed 3 is activated and complied with.
11	SLS4 monitored	Safely limited speed 4 is activated and complied with.
12	SDIpos monitored	Safe positive direction of rotation (SDIpos) is activated and complied with.
13	SDIneg monitored	Safe negative direction of rotation (SDIneg) is activated and complied with.
14	Fault active	SM3xx safety module has the error status (trouble or warning).

Bits not listed are reserved for future extensions!



#### Tip!

For decoding the status signal into individual boolean status signals, simply connect the output *SMI\_dnState* to the **L\_DevSMStateDecoder** FB which is available in the function library from V2.0.

## 10.3.2 I/O status information

Via the bit coded status signal *SMI\_dnloState* of the **LS\_SafetyModuleInterface** SB, the SM3xx safety module transmits the status of the safe inputs and outputs to the application.

► Which bits are supported depends on the safety module used.

Bit coding of the SMI_dnloState status signal		
Bit	Name	Meaning
0	SD-In1	Sensor input 1 in ON state.
1	SD-In2	Sensor input 2 in ON state.
2	SD-In3	Sensor input 3 in ON state.
3	SD-In4	Sensor input 4 in ON state.
5	AIS	Restart acknowledgement via terminal effected (negative edge: 1↘0).
6	AIE	Error acknowledgement via terminal effected (negative edge: 1↘0).
8	PS_AIS	Restart acknowledgement via safety bus effected (positive edge: 0↗1)
9	PS_AIE	Error acknowledgement via safety bus effected (positive edge: 0↗1)
12	SD-Out1	Safe output 1 (feedback output) in the ON state.

Bits not listed are reserved for future extensions!



### Tip!

For decoding the status signal into individual boolean status signals, simply connect the output *SMI\_dnloState* to the **L\_DevSMStateDecoderIO** FB which is available in the function library from V2.0.

## 10.3.3 Control information

Via the bit coded control signal *SMI\_dwControl* of the **LS\_SafetyModuleInterface** SB, the SM3xx safety module transmits information on safety functions requested, or on active safety functions to the application.

- ▶ Several safety functions can be requested/active at the same time.
- ▶ Which bits are supported depends on the safety module used.



### Note!

The corresponding actions (e.g. braking, braking to standstill, holding of the standstill position) must be executed by the application, e.g. via the basic function "[Limiter](#)". (☞ 513)

- To integrate the basic function "Limiter", the output *SMI\_dwControl* is to be connected to the input *LIM\_dwControl* of the **LS\_Limiter** system block.

#### Bit coding of the control signal *SMI\_dwControl*

Bit	Name	Meaning
1	SS1 active	"Safe stop 1 (SS1)" function is active. • After the parameterised stopping time has elapsed, bit 0 of the status signal <i>SMI_dnState</i> (STO active) is set.
2	SS2 active	"Safe stop 2 (SS2)" function is active. • After the parameterised stopping time has elapsed, bit 16 (SOS monitored) is set.
3	SLS1 active	"Safely limited speed 1 (SLS1)" function is active. • After the parameterised braking time has elapsed, bit 8 of the status signal <i>SMI_dnState</i> (SLS1 monitored) is additionally set.
4	SLS2 active	"Safely limited speed 2 (SLS2)" function is active. • After the parameterised braking time has elapsed, bit 9 of the status signal <i>SMI_dnState</i> (SLS2 monitored) is additionally set.
5	SLS3 active	"Safely limited speed 3 (SLS3)" function is active. • After the parameterised braking time has elapsed, bit 10 of the status signal <i>SMI_dnState</i> (SLS3 monitored) is additionally set.
6	SLS4 active	"Safely limited speed 4 (SLS4)" function is active. • After the parameterised braking time has elapsed, bit 11 of the status signal <i>SMI_dnState</i> (SLS4 monitored) is additionally set.
7	SDIpos active	"Safe positive direction of rotation (SDIpos)" function is active.
8	SDIneg active	"Safe negative direction of rotation (SDIneg)" function is active.
9	ES active	"Confirm button (ES)" function for motion functions in special operation is active.
10	SLI active	"Safely limited increment (SLI)" function is active.
11	OMS active	"Operation mode selector (OMS)" function for special operation is active.
12	SLP1 active	"Safely-limited position 1 (SLP1)" function is active.
13	SLP2 active	"Safely-limited position 2 (SLP2)" function is active.
14	SLP3 active	"Safely-limited position 3 (SLP3)" function is active.
15	SLP4 active	"Safely-limited position 4 (SLP4)" function is active.

Bits not listed are reserved for future extensions!

# 9400 HighLine | Parameter setting & configuration

Safety engineering

System block "LS\_SafetyModuleInterface"

## Bit coding of the control signal *SMI\_dwControl*

Bit	Name	Meaning
16	SOS active	"Safe operating stop (SOS)" function is active. <ul style="list-style-type: none"><li>• The safe operating stop is monitored.</li><li>• The function becomes active after the "Safe stop 2 (SS2)" function has been executed.</li></ul>
23	SSE active	Emergency stop function (SSE) is active. <ul style="list-style-type: none"><li>• At the end of the function, bit 1 (SS1 active) or bit 0 of the status signal <i>SMI_dnState</i> (STO active) is set according to the emergency stop function parameterised.</li></ul>

Bits not listed are reserved for future extensions!



### Tip!

For decoding the control signal into individual boolean control signals, simply connect the output *SMI\_dwControl* to the **L\_DevSMControlDecoder** FB which is available in the function library from V2.0.

## 11 Basic drive functions

In this chapter the basic (drive) functions of the "Servo Drives 9400" are described, to which the active application can access via defined, internal interfaces, and which can be carried out in the following way, depending on the controller type (StateLine or HighLine) and the Motion Control licence available:

### Parameter setting by means of »Engineer« or keypad

In each licence level the basic functions can be parameterised in the »Engineer« via a corresponding dialog or alternatively via the keypad.

In the case of the 9400 StateLine (licence level Motion Control StateLevel), the interconnection of the internal interfaces is defined by the technology application selected.

### Configuration in the »Engineer« function block editor

The »Engineer« additionally provides the graphic function block editor for the 9400 HighLine which can be used to reconfigure and extend the application interconnection by individual functions using the function library.

### Programming according to IEC 61131-3 in the »PLC Designer«\*

For the 9400 HighLine with the licence level Motion Control PLC the basic functions are also provided as separate system blocks in the »PLC Designer«, which, if required, can be integrated in the control configuration, and which then can be accessed from the IEC 61131-3 program via the corresponding system variables.

\* In preparation!

## 11.1 General information

### 11.1.1 Internal state machine

The execution of the different basic functions is internally controlled by a state machine which can adopt the following "function states":



[11-1] Function states of the state machine "Basic functions"

The state machine ensures that:

- ▶ one basic function at a time adopts the control of the drive.
- ▶ only the basic function with the highest priority (= smallest number) is executed if several basic functions are activated at the same time. ▶ [Priorities](#) (□ 381)
- ▶ the drive always has a defined state both in case of error and in normal operation.






## Note!

The basic functions "[Limiter](#)" and "[Brake control](#)" run autonomously, but are able to control the state machine to a certain function state, if required.

The function states are not to be confused with the device states ("Operation", "Fault active", "Device is switched on", etc.) of the controller. ▶ [Device states](#)  
(105)

From software version V7.0 onwards, the basic functions "[Manual jog, encoderless](#)" and "[Pole position identification](#)" are additionally available for the setting-up operation. Both basic functions can only be requested when the controller is inhibited and with the "Controller not ready" function state:



[11-2] Sequence diagram for basic functions "[Manual jog, encoderless](#)" and "[Pole position identification](#)"

## 11.1.2 Function states



**Tip!**

In [C02530](#) the currently active function state is displayed.

### State "Initialisation"

If the controller has completed the device initialisation, the function state "Initialisation" is passed through automatically.

- ▶ In the "Initialisation" function state, the process data required for processing the basic functions are initialised.
- ▶ The monitoring is not active yet.
- ▶ The basic functions are not yet processed (e.g. brake control) and cannot yet be parameterised or activated either.
- ▶ If the initialisation of the basic functions is completed and no fault is available, a change-over to the basic state "Drive at standstill" is automatically effected.

### State "Controller not ready"

In this function state the pulse inhibit is set in the controller, which means that the power output stages are high-resistance and the drive cannot be controlled.

### State "Manual jog encoderless active"

From [software version V7.0](#) onwards, the drive can be controlled without feedback (encoderless) in this function state, e.g. for a setting-up operation or in the event of service when the feedback system fails. ▶ [Manual jog, encoderless](#) (📖 410)

### State "Identification of pole position active"

From [software version V7.0](#) onwards, an identification of pole position can be executed in this function state in order to detect the pole position for the motor encoder that is currently activated in [C00495](#). ▶ [Pole position identification](#) (📖 581)

### State "Drive at standstill"

This "basic state" is automatically adopted if no other state is active.

- ▶ The setpoints for speed and acceleration are set to "0".
- ▶ The drive is position-controlled.
- ▶ No error has occurred and quick stop is not active.
- ▶ Every basic function can be activated out of this state.

## State "Drive is stopped"

This function state is automatically passed through when a basic function is deactivated.

- ▶ If the drive is not yet in the standstill state, it is decelerated to standstill via a parameterisable deceleration ramp.
- ▶ If a basic function is activated during the "stopping" process, this basic function takes over the control of the drive from the current speed on and the function state "Drive is stopped" is abandoned.
- ▶ If the drive is at standstill, a change-over to the basic state "Drive at standstill" is automatically effected.

## State "Manual jog active"

In this function state the drive can be traversed manually to the right or left direction of rotation ("Inching mode"). ▶ [Manual jog](#) (☞ 398)

- ▶ If the home position is known to the controller, the software limit positions set and a potentially connected travel range limit switch are monitored.
- ▶ "Retracting" from an activated travel range limit switch is also possible.

## State "Homing active"

In this function state the home position and the machine measuring system for the drive can be determined. ▶ [Homing](#) (☞ 419)

- ▶ The home position can be specified by an active homing or by reference setting.
- ▶ A redetermination of the home position is only required in case of recommissioning or in case of service (e.g. when drive components are exchanged) or after travel commands have been executed which reset the reference.

## State "Positioning active"

In this function state all positioning types (absolute, relative, modulo, continuous, touch probe etc.) can be executed. ▶ [Positioning](#) (☞ 482)

- ▶ In the position-controlled mode, the drive executes a time-controlled point-to-point setpoint generation based on the defined motion profile.

## State "Setpoint follower active"

In this function state the drive directly follows the defined setpoint.

- ▶ The setpoint can be optionally defined as speed, torque, or position via three separate basic functions:
  - [Speed follower](#) (☞ 502)
  - [Torque follower](#) (☞ 508)
  - [Position follower](#) (☞ 494)

## State "Quick stop active"

This function state is active if quick stop has been activated by the user. ▶ [Quick stop](#) (☞ 391)

- ▶ The drive is brought to standstill within the deceleration time parameterised, irrespective of the setpoint defined.
- ▶ If the quick stop is cancelled again by the user, a change-over to a setpoint-generating basic function (e. g. "Speed follower") is effected, if requested.



## Note!

**For the encoderless motor control types (from software version V3.0) the following applies:**

The "Quick stop active" function state is also activated when DC-injection braking is executed.



## Tip!

Quick stop can also be set as error response for many monitoring functions ("quick stop by trouble"). Detailed information can be found in the chapter "Diagnostics & fault analysis".

The source from which the quick stop was activated is shown in a bit coded manner in [C00159](#).

## "Fault" state

This function state is active if a fault has occurred and the controller is in the "Fault active" or "Quick stop by trouble active" device state.

- ▶ The function state can only be abandoned by acknowledging the error if the error is removed.

### 11.1.3 Interrupting/replacing states

An active function state cannot be interrupted or replaced by the activation of another function state. However, the following exceptions apply:

- ▶ The "Initialisation" state replaces all other states.
- ▶ The "Fault" state can replace all other states except "Initialisation".
- ▶ The "Controller not ready" state can replace all other states except "Error" and "Initialisation".
- ▶ The "Quick stop active" state can replace all other states except "Initialisation", "Error" and "Controller not ready".

### 11.1.4 Priorities

The function states are assigned to priorities so that, if several basic functions are activated at the same time, it is always changed to the function state with the highest priority:

Priority	Function state	Executable basic function
1	Initialisation	-
2	Fault	-
3	Controller is not ready	-
4	Quick stop active	▶ <a href="#">Quick stop</a> (□ 391)
5	Manual jog active	▶ <a href="#">Manual jog</a> (□ 398)
6	Homing active	▶ <a href="#">Homing</a> (□ 419)
7	Positioning active	▶ <a href="#">Positioning</a> (□ 482)
8	Setpoint follower (position) active	▶ <a href="#">Position follower</a> (□ 494)
9	Setpoint follower (speed) active	▶ <a href="#">Speed follower</a> (□ 502)
10	Setpoint follower (torque) active	▶ <a href="#">Torque follower</a> (□ 508)
10	Brake check	▶ <a href="#">Brake control</a> (□ 528)
12	Drive is stopped	▶ <a href="#">Stop</a> (□ 387)
13	Manual control open loop active	▶ <a href="#">Manual jog, encoderless</a> (□ 410)
14	Pole position identification active	▶ <a href="#">Pole position identification</a> (□ 581)

1 ≙ highest priority; 14 ≙ lowest priority



#### Note!

The basic state "Drive at standstill" is automatically adopted if no other state is active.

### 11.1.5 Requesting control via a basic function

#### Enable input "bEnable"

The basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" and the three setpoint followers each possess an *bEnable* enable input, via which the control of the corresponding basic function can be requested.

- ▶ If no other basic function and no error status is active, a change-over to the corresponding function state is effected, and the basic function can be controlled now.
- ▶ If several enable inputs are set to TRUE at the same time, the change-over to the function state is effected with the highest priority.

#### Status outputs "bEnabled", "bActive" and "bDone"

If the basic function is enabled, the *bEnabled* status output of the basic function is set to TRUE and the corresponding drive motion can be started via the control inputs of the basic function.

- ▶ If the basic function is currently carrying out a drive movement, this is shown by a TRUE signal at the status output *bActive*.

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

General information

- ▶ The basic functions "[Speed follower](#)", "[Torque follower](#)", and "[Position follower](#)" are only provided with the status output *bEnabled*, as the drive directly follows the setpoint selection after being enabled.
- ▶ The basic functions "[Homing](#)" and "[Positioning](#)" are furthermore provided with a status output *bDone* showing that the drive movement started (Homing or positioning) has been completed.

Priority	Basic function	Status outputs		
		<i>bEnabled</i>	<i>bActive</i>	<i>bDone</i>
1	<a href="#">Manual jog</a>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
2	<a href="#">Homing</a>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	<a href="#">Positioning</a>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	<a href="#">Speed follower</a>	<input checked="" type="checkbox"/>		
5	<a href="#">Torque follower</a>	<input checked="" type="checkbox"/>		
6	<a href="#">Position follower</a>	<input checked="" type="checkbox"/>		

## Re-deactivating the enable of a basic function

When the *bEnable* enable input of the active basic function is reset to FALSE, the control inputs of the basic function are inhibited and the status outputs *bEnabled*, *bActive* and *bDone* are reset to FALSE.

- ▶ If the drive is not at standstill, it is brought to standstill within the deceleration time for [Stop](#) if no other basic function takes over the control of the drive. Here a change-over from the active function state via the function state "Drive is stopped" back to the basic state "Drive at standstill" is effected.
- ▶ When the enable input of another basic function is set to TRUE, this basic function adopts the control of the drive immediately.

## 11.1.6 Start acceleration/acceleration reduction when the basic function changes

In order to make the transitions during the changeover between the single basic functions as jerk-free as possible, i.e. preventing acceleration steps, the current setpoint acceleration is used as starting value for the new basic function (see the following table).

from	to						
	Position, speed or torque follower	Manual jog	Homing	Positioning	Error/controller not ready	Stop	Quick stop*
<a href="#">Position follower</a>	0	A	A	A	0	A	0
<a href="#">Speed follower</a>	0	A	A	A	0	A	0
<a href="#">Torque follower</a>	0	0	0	0	0	0	0
<a href="#">Manual jog</a>	0	-	B	B	0	B	0
<a href="#">Homing</a>	0	B	-	B	0	B	0
<a href="#">Positioning</a>	0	B	B	-	0	B	0
Error/controller not ready	0	0	0	0	-	0	0
<a href="#">Stop</a>	0	B	B	B	0	-	0
<a href="#">Quick stop*</a>	0	A	A	A	0	A	-

**Legend:**

0	The start acceleration is defined with "0", thus no acceleration reduction is required.
A	<ul style="list-style-type: none"> <li>Acceleration value is generated from the differentiation and filtering (<a href="#">C02562</a>) of the active setpoint speed.</li> <li>Jerk = Maximum value from transition jerk (defined via <a href="#">C02545</a>) and jerk of the "new" profile data.</li> </ul>
B	<ul style="list-style-type: none"> <li>Acceleration value is taken from the setpoint generator (e.g. profile generator).</li> <li>Jerk = maximum value from the jerk of the "old" and "new" profile data.</li> </ul>

\* Also quick stop by trouble

### Reduction of the start acceleration

Depending on the acceleration and S-ramp time parameterised in the basic function, the start acceleration is reduced.

The following applies for software versions lower than V7.0:

- ▶ The start acceleration is always reduced with the jerk of the new basic function.
  - ▶ [Setting the S-ramp time](#) ([385](#))



#### Note!

Very low jerks cause very high speeds!

See also the following chapter "[Setting the S-ramp time](#)". ([385](#))

Since this behaviour is mostly not wanted or expected, the acceleration is reduced from software version V7.0 as described in the following section.

The following applies from software version V7.0 onwards:

- ▶ The start acceleration is reduced with the maximum jerk of the old or new basic function.

### Transition of a profile-generating to a profile-generating basic function

The corresponding jerk results from the profile data:

$$\text{Jerk} = \frac{\text{Profile acceleration/deceleration}}{\text{Verschliffzeit}}$$

### Transition of a non-profile-generating to a profile-generating basic function

- ▶ The jerk of the profile-generating basic function results from the profile data:

$$\text{Jerk} = \frac{\text{Profile acceleration/deceleration}}{\text{Verschliffzeit}}$$

- ▶ Since a non-profile-generating basic function has no defined jerk, a "transition jerk" is used which results from the reference acceleration and the reference S-ramp time parameterised in [C02545](#).

$$\text{Transition jerk} = \frac{\text{Bezugsacceleration}}{\text{Bezugsverschliffzeit}} = \frac{\text{C00011} / 1 \text{ ms}}{\text{C02545}}$$

- ▶ With a Lenze setting [C02545](#) = 0.001 s, a maximum jerk occurs, i.g. the start acceleration is reduced in one cycle (1 ms).
- ▶ The setting [C02545](#) = 0.000 s results in a compatible behaviour lower than V7.0.



#### Tip!

Profile-generating basic functions are:  
"[Stop](#)", "[Manual jog](#)", "[Homing](#)", "[Positioning](#)"

Non-profile-generating basic functions are:  
"[Quick stop](#)", "[Position follower](#)", "[Speed follower](#)", "[Torque follower](#)"



## 11.1.7 Setting the S-ramp time

For path planning, various basic functions serve to build up or reduce the acceleration linearly. The motion profile causes less structural vibrations and the gearboxes are protected.

The smoothening (jerk) is calculated via the S-ramp time and the maximum acceleration permitted in the profile:

$$\text{Jerk} = \frac{\text{maximum acceleration}}{\text{S-ramp time}}$$

[11-3] Formula for calculating the jerk for acceleration and deceleration phases

S-ramp times can be set in the given parameters for the following basic functions:

Basic function	Parameter for S-ramp time
<a href="#">Stop</a>	<a href="#">C02611</a>
<a href="#">Quick stop</a>	<a href="#">C00106</a>
<a href="#">Manual jog</a>	<a href="#">C02624</a>
<a href="#">Homing</a>	<a href="#">C02648</a>
<a href="#">Positioning</a>	The S-ramp time is selected via FB L_PosPositionerTable or FB L_PosProfileTable.




### Stop!


When it is switched to another basic function, the start acceleration is reduced with the jerk of the new basic function. **A small jerk causes very high speeds!**

Remedy: Avoid unnecessarily long S-ramp times. Set the profile parameters of the different basic functions so that the jerk is roughly the same for all basic functions.

## Examples



[11-4] Example 1: Point-to-point positioning from standstill without start acceleration



[11-5] Example 2: Point-to-point positioning from standstill with start acceleration

In the example 2, the slow reduction of the start acceleration results in very high speeds!

## 11.2 Stop

The standard stop (in the following called "stop") of the drive will be automatically activated by the internal state machine if a basic function is deactivated and the drive is not yet at standstill.

- ▶ The drive is braked to standstill via a parameterisable deceleration ramp.
  - While the drive is braked to standstill, the state machine is in the "Drive is stopped" function state.
  - If meanwhile another basic function is activated, this basic function takes over the control of the drive from the current speed on and the function state "Drive is stopped" is abandoned.
  - If the drive is at standstill, a change-over to the basic state "Drive at standstill" is automatically effected.
- ▶ An acceleration phase active at the time of activating the stopping process is considered by the standard stop, i.e. the current acceleration is first led to "0" with the parameterised S-ramp time before the real deceleration process starts.
- ▶ If the controller is enabled while the shaft is coasting (controller inhibit and pulse inhibit are deactivated), the drive is braked from the current speed to standstill.



### Stop!

The basic functions "[Speed follower](#)", "[Torque follower](#)", and "[Position follower](#)" do not take over the control of the from the current speed, but immediately with the setpoint defined, which may cause a jerk!



### Note!


- As the stop function takes into account the acceleration active at the moment of activation, the deceleration of the stop function should always be set greater than the deceleration of the active process in order to avoid a possible overshoot.
- If the stop function is activated while the basic function "[Torque follower](#)" or the states "Controller inhibited" or "Error" are active, the drive is braked to standstill starting from the current speed and without taking into account the current acceleration.

▶ [Start acceleration/acceleration reduction when the basic function changes](#)

( 383)

#### 11.2.1 Internal interfaces | "LS\_Stop" system block

The **LS\_Stop** system block provides the internal interfaces for the basic function "Stop" in the function block editor.



#### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

#### Outputs


Identifier <small>DIS code   data type</small>	Value/meaning
STP_dnState <a href="#">C02616</a>   DINT	Status (bit coded) <ul style="list-style-type: none"> <li>When the basic function is not active, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul>
	Bit 1 Drive is braked to standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the "Drive is stopped" function state.</li> </ul>
	Bit 2 Drive is at standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the "Drive at standstill" function state.</li> </ul>
	Bit 3 Deceleration phase is active.
	Bit 5 CCW rotation is active.
STP_bStopActive <a href="#">C02617</a>   BOOL	Status signal "Stop is active"
	TRUE The drive is braked to standstill or is at standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the "Drive is stopped" or "Drive at standstill" function state.</li> </ul>

## 11.2.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Stop*
- ▶ Short overview of parameters for standard stop :


Parameter	Information
<a href="#">C02610</a>	Deceleration time for stop
<a href="#">C02611</a>	S-ramp time for stop
<a href="#">C02612</a>	Ref. for decel. time of stop

### Parameter setting of stop




[11-6] Deceleration time referred to the motor reference speed

- ▶ The deceleration time for stop set in [C02610](#) refers to a speed variation from the motor reference speed ([C00011](#)) to standstill, i. e. the deceleration is constant.



[11-7] Deceleration time referred to the current speed

- ▶ When [C02612](#) is set = "1", the deceleration time refers to the current speed, i. e. the braking time is constant.




[11-8] S-shaped deceleration ramp through selection of a relative S-ramp time

- ▶ By entering an S-ramp time in [C02611](#), the deceleration ramp can be set in an S-shaped manner for purposes of jerk limitation; the total time until standstill is then extended by the S-ramp time set. ▶ [Setting the S-ramp time](#) (📖 385)
- ▶ Braking time at motor reference speed or [C02612](#) = "1":

$$C02610 [s] + C02611 [s]$$


#### 11.2.3 Behaviour of the function (example)

In the following example the enable of manual jog is deactivated during an active manual jog. Then the drive is braked to standstill within the deceleration time ❶ set for stop.



[11-9] Example: Stop with reaching standstill

If the basic function "Manual Jog" is reactivated within the deceleration time ❶, this basic function takes over the control of the drive from the current speed and the function state "Drive is stopped" is abandoned immediately:



[11-10] Example: Stop without reaching standstill

## 11.3 Quick stop

In contrast to [Stop](#), the purpose of quick stop (QSP) is a stop in case of error. If quick stop is activated, the drive is brought to standstill within the deceleration time set irrespective of the setpoint that is preselected.



### Note!

Through this, superimposed controls (e.g. synchronous or position control) may produce following errors. If several drives execute a coordinated motion, the quick stop function should only be used for the motion master (master drive) in order to maintain the coordination.

When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 383)




### Tip!

Quick stop can also be set as error response for many monitoring functions ("quick stop by trouble"). Detailed information can be found in the chapter "[Diagnostics & fault analysis](#)". (□ 611)

The source from which the quick stop was activated is shown in a bit coded manner in [C00159](#).

### 11.3.1 Internal interfaces | "LS\_Quickstop" system block"

The **LS\_Quickstop** system block provides the internal interfaces for the basic function "Stop" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

#### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
QSP_bActivate1 <a href="#">C02619/1</a>   BOOL	Activate quick stop <ul style="list-style-type: none"> <li>The three inputs are linked via a logic OR gate.</li> </ul>
QSP_bActivate2 <a href="#">C02619/2</a>   BOOL	
QSP_bActivate3 <a href="#">C02619/3</a>   BOOL	
QSP_bActivateDCBrake <a href="#">C02619/5</a>   BOOL <small>From V3.0</small>	Activate <a href="#">DC-injection braking</a> . ( <a href="#">□ 395</a> ) <ul style="list-style-type: none"> <li>Only possible if V/f control or sensorless vector control is selected as motor control type in <a href="#">C00006</a>!</li> <li>This input has a higher priority than the three inputs <i>QSP_bActivate1 ... 3</i>.</li> </ul>
	TRUE If one of the three inputs is set to TRUE, a change-over to the "Quick stop active" function state is effected and the drive is brought to standstill within the deceleration time set for quick stop.
	TRUE↔FALSE If all three inputs are reset to FALSE, a change-over to a setpoint-generating basic function (e. g. "Speed follower") via the "Drive is stopped" function state is effected.
	TRUE A change-over to the "Quick stop active" function state is effected and the drive is decelerated with the braking current set in <a href="#">C00974</a> .
	TRUE↔FALSE DC-injection braking is activated again. <ul style="list-style-type: none"> <li>If flying restart is activated in <a href="#">C00990</a>, a flying restart process is automatically started to determine the current motor speed.</li> </ul>

#### Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
QSP_bActive <a href="#">C02619/4</a>   BOOL	Status signal "Quick stop by application active" <ul style="list-style-type: none"> <li><i>QSP_bActive</i> is not set to TRUE if quick stop has been activated by another source, e. g. via device command or as an error response ("Quick stop by trouble").</li> </ul>
	TRUE Quick stop has been requested via one of the three inputs <i>QSP_bActivate1 ... 3</i> and is active. - or - <a href="#">DC-injection braking</a> has been requested via <i>QSP_bActivateDCBrake</i> and is active (only for motor control mode without encoder).


### 11.3.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Quick stop*
- ▶ Short overview of the parameters for quick stop:

Parameter	Information
<a href="#">C00105</a>	Quick stop decel. time
<a href="#">C00106</a>	Quick stop S-ramp time
<a href="#">C00107</a>	Reference for quick stop deceleration time




## Parameter setting of quick stop




[11-11] Deceleration time referred to the motor reference speed

- ▶ The deceleration time for the quick stop function set in [C00105](#) refers to a speed variation from the motor reference speed ([C00011](#)) to standstill.



[11-12] Deceleration time referred to the current speed

- ▶ When [C00107](#) is set = "1", the deceleration time refers to the current speed.



[11-13] S-shaped deceleration ramp through selection of a relative S-ramp time

- ▶ By entering a relative S-ramp time in [C00106](#), the deceleration ramp can be set in an S-shaped manner for purposes of jerk limitation; the total time until standstill is then extended by the S-ramp time set. ▶ [Setting the S-ramp time](#) (□ 385)

- ▶ Braking time at motor reference speed or [C00107](#) = "1":

$$C00105 + \frac{C00105 \cdot C00106 [\%]}{100 \%}$$



### Tip!

After reaching standstill, the standstill position can be maintained while a torque is applied.

- For this purpose, select the phase controller gain in [C00254](#) > "0".
- With [C00254](#) > "0" the phase control is automatically activated after the standstill is reached.

#### 11.3.3 Activating/deactivating quick stop

For activation/deactivation of quick stop by the application, the three inputs *QSP\_bActivate1...3* are provided. (□ 391)


- ▶ The three control inputs are linked via a logic OR gate, i.e. in order to activate quick stop, only one of the three inputs must be set to TRUE. To deactivate quick stop, though, all three inputs must be reset to FALSE.
- ▶ The control inputs can be linked with terminals (digital inputs) and/or process data in the function block editor.



#### Note!

In the standard technology applications the control input *QSP\_bActivate1* is linked with the digital input DI1 in the Lenze setting.

#### Further options for activating quick stop

- ▶ Via device command "Activate quick stop" ([C00002](#) = "45"), e.g. via a corresponding SDO of a higher-level control, an HMI or the »Engineer«.
- ▶ Via the  key at the keypad, unless the Lenze setting of [C00469](#) (assignment of the key) has been changed.
- ▶ Through the response "quick stop by trouble" parameterised for monitoring.

### 11.3.4 DC-injection braking

This function extension is available from software version V3.0!

---



#### Note!

DC-injection braking is only possible if V/f control or sensorless vector control is selected as motor control type in [C00006](#)!

#### Activate DC-injection braking

To activate DC-injection braking through the application, the *bActivateDCBrake* control input must be set to TRUE.


- ▶ A change-over to the "Quick stop active" function state is effected and DC-injection braking with the braking current set in [C00974](#) is carried out.

#### Flying restart process after cancelling DC injection braking

If the flying restart mode is activated in [C00990](#) and DC-injection braking is cancelled, a flying restart process is automatically started to determine the current motor speed if the following conditions are met:

- ▶ V/f control or sensorless vector control are selected as motor control in [C00006](#).
- ▶ The position control structure is set to "Phase controller is active" in [C02570](#).
- ▶ The *MI\_bFlyingSyncBlocked* control input of the motor interface is not assigned or set to FALSE.
- ▶ The holding brake, if available, is not applied.

#### 11.3.4.1 DC-injection braking and flying restart process




[11-14] Process example: speed follower is active → QSP\_bActivateDCBrake is active → speed follower is active

- A. Initial situation: basic function "Speed follower" is enabled and active.
- B. `QSP_bActivateDCBrake` control input is set to TRUE through the application to activate DC-injection braking.
- C. DC-injection braking is executed with the braking current set in [C00974](#).
- D. `QSP_bActivateDCBrake` control input is reset to FALSE through the application to deactivate DC-injection braking.
- E. The flying restart process starts, i.e. the controller calculates the output frequency required for the momentary motor speed, then connects to the system, and accelerates the motor to the defined setpoint again.

## 11.3.4.2 DC-injection braking when quick stop is activated

If DC-injection braking is activated in [C00976](#) instead of quick stop, DC-injection braking is executed automatically when quick stop is activated.

- ▶ After activating quick stop, a change-over to the "Quick stop active" function state is effected, and for the quick stop deceleration time set in [C00105](#) a DC-injection braking process with the braking current set in [C00975](#) is carried out.
- ▶ After this time has elapsed, a change-over to the braking current parameterised in [C00974](#) is carried out and DC-injection braking is continued with this braking current.
- ▶ The DC-injection braking in this case is also carried out when the "Quick stop by trouble" error response is actuated; however, instead of the "Quick stop active" function state, the "Fault" function state is active, and the controller is in the "Quick stop by trouble active" device state.



[11-15] Process example: speed follower is active → quick stop activation → speed follower is active



### Note!

The quick stop braking current in [C00975](#) has to be set so that the drive can be decelerated from the maximum operating speed to standstill within the deceleration time for quick stop set in [C00105](#)!

#### 11.4 Manual jog

The basic function "Manual jog" serves to traverse the drive manually, e.g. to clean or exchange the tool.

- ▶ Optionally a change-over to a second speed can be carried out during the traversing process.
- ▶ "Retracting" from activated (travel range) limit switches is also supported, then traversing can automatically only be carried out in the corresponding retracting direction.



#### Danger!

During manual jog operations, specially assigned profile parameters are effective. If these parameters are not set correctly, the drive may execute uncontrolled movements!



#### Stop!

In manual mode a travel range monitoring via limit switches and software limit positions is carried out via the basic function "[Limiter](#)". ([□ 513](#))

If no limit switches are connected and no software limit positions are set, and the reference is not known, the drive can travel into a mechanical barrier during manual mode and machine parts can be destroyed or damaged!



#### Note!

For manual jog setpoint speeds greater than 30000 rpm are not possible. The speeds defined for these basic function are internally limited to 30000 rpm.


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) ([□ 383](#))

**For the encoderless motor control types (from software version V3.0) the following applies:**

If no position controller has been selected for position control in case of V/f control or sensorless vector control ([C02570](#) = "1: Phase controller is active"), the manual jog is only executed via the speed profile resulting from the manual jog parameters.

## 11.4.1 Internal interfaces | "LS\_ManualJog" system block

The **LS\_ManualJog** system block provides the internal interfaces for the basic function "Manual jog" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
MAN_bEnable <a href="#">C02639/1</a>   BOOL	Requesting control via the basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Active manual jog is stopped, i. e. a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.	TRUE↔FALSE	Active manual jog is stopped, i. e. a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
TRUE	If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.				
TRUE↔FALSE	Active manual jog is stopped, i. e. a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.				
MAN_bJogPositive <a href="#">C02639/2</a>   BOOL	▶ <a href="#">Manual jog in positive/negative direction</a> (□ 405)				
MAN_bJogNegative <a href="#">C02639/3</a>   BOOL					
MAN_bActivateJogSpeed2 <a href="#">C02639/4</a>   BOOL	Change-over to speed 2 for manual jog <table border="1"> <tr> <td>FALSE</td> <td>Speed 1 (<a href="#">C02620</a>) active.</td> </tr> <tr> <td>TRUE</td> <td>Speed 2 (<a href="#">C02621</a>) active.</td> </tr> </table>	FALSE	Speed 1 ( <a href="#">C02620</a> ) active.	TRUE	Speed 2 ( <a href="#">C02621</a> ) active.
FALSE	Speed 1 ( <a href="#">C02620</a> ) active.				
TRUE	Speed 2 ( <a href="#">C02621</a> ) active.				
MAN_bReleaseLimitSwitch <a href="#">C02639/5</a>   BOOL	Retracting of an activated limit switch <table border="1"> <tr> <td>TRUE</td> <td>Retracting of the accordingly operated limit switch in the corresponding retracting direction until the limit switch is cleared again (no longer operated) and the drive is within the software limit positions again. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.</td> </tr> </table>	TRUE	Retracting of the accordingly operated limit switch in the corresponding retracting direction until the limit switch is cleared again (no longer operated) and the drive is within the software limit positions again. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.		
TRUE	Retracting of the accordingly operated limit switch in the corresponding retracting direction until the limit switch is cleared again (no longer operated) and the drive is within the software limit positions again. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.				

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Manual jog

Identifier DIS code   data type	Information/possible settings
MAN_dnSpeedOverride_n <a href="#">C02637</a>   DINT From V5.0	Value of speed override <ul style="list-style-type: none"> <li>• Percentage multiplier for the currently active speed (<a href="#">C02620</a> or <a href="#">C02621</a>).</li> <li>• In the case of active manual jog, the speed override is always active and does not have to be activated separately.</li> <li>• Changes are accepted in each cycle.</li> <li>• <math>2^{30} \equiv 100\%</math> of the speed parameterised in <a href="#">C02620</a> or <a href="#">C02621</a>.</li> <li>• For values <math>\leq 1\%</math> the status bit 19 is set.</li> <li>• Values <math>\leq 0\%</math> are set to <math>0\%</math> internally and lead to the standstill of the drive.</li> </ul>
MAN_bStepMode <a href="#">C02639/8</a>   BOOL From V5.0	▶ <a href="#">Manual jog with step limitation</a> (☰ 406) <ul style="list-style-type: none"> <li>• Only possible if the "Manual jog with intermediate stop" mode is not active.</li> </ul>
MAN_bIntermediateStopMode <a href="#">C02639/9</a>   BOOL From V5.0	▶ <a href="#">Manual jog with intermediate stop</a> (☰ 407) <ul style="list-style-type: none"> <li>• This mode has a higher priority than the "Manual jog with step limitation" mode.</li> </ul>
MAN_FBData From V5.0	Interface for the transfer of the function block instance data for determining the positions for intermediate stop <ul style="list-style-type: none"> <li>• Connect this input to the output <i>FBData</i> of the function block instance of type <b>L_PosPositionerTable</b> or <b>L_PosProfileTable</b>.</li> </ul>



## Outputs

Identifier DIS code   data type	Value/meaning
MAN_dnState <a href="#">C02638</a>   DINT	Status (bit coded) <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul>
	Bit 1 Manual jog is active.
	Bit 2 Manual jog is completed.
	Bit 3 Acceleration/deceleration phase is active.
	Bit 5 CCW rotation is active.
	Bit 15 Fault in basic function active (group signal).
	Bit 16 Stop by simultaneous selection of negative direction and retraction of limit switch.
	Bit 17 Stop by simultaneous selection of positive and negative direction.
	Bit 18 Stop by simultaneous selection of positive direction and retraction of limit switch.
	Bit 19 Speed override ≤1 % <ul style="list-style-type: none"> <li>This status is only available from software version V5.0.</li> </ul>
	Bit 20 Speed 2 ( <a href="#">C02621</a> ) active.
	Bit 21 Speed 1 ( <a href="#">C02620</a> ) active.
	Bit 22 Stop by selection of positive direction and simultaneous activation of the positive software limit position or the positive limit switch.
	Bit 23 Stop by selection of negative direction and simultaneous activation of the negative software limit position or the negative limit switch.
	Bit 24 General abort process (ramp down of the speed setpoint) <ul style="list-style-type: none"> <li>Takes place e.g. when a manual direction initiator is released or due to an impermissible state (see bit 16, 17, 18, 22, 23).</li> </ul>
	Bit 25 Stopping is active. <ul style="list-style-type: none"> <li>Basic function enabled for the first time but no manual jog has been requested/is active yet or current speed is higher than the manual jog speed.</li> </ul>
Bit 26 Home position is not known. <ul style="list-style-type: none"> <li>This status is only available from software version V5.0.</li> </ul>	
Bit 27 No intermediate stop position available. <ul style="list-style-type: none"> <li>This status is only available from software version V5.0.</li> </ul>	
Bit 30 Profile generation error.	
MAN_bEnabled <a href="#">C02639/6</a>   BOOL	Status signal "Basic function is enabled"
	TRUE Manual jog via the control inputs is possible. <ul style="list-style-type: none"> <li>The <i>MAN_bEnable</i> enable input is set to TRUE and the controller is in the "Manual jog active" function state.</li> </ul>
MAN_bActive <a href="#">C02639/7</a>   BOOL	Status signal "Basic function is active"
	TRUE Manual jog is active (the drive axis is moving).


#### 11.4.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Manual jog*
- ▶ Short overview of the parameters for manual jog:

Parameter	Information
<a href="#">C02620</a>	Manual jog: Speed 1
<a href="#">C02621</a>	Manual jog: Speed 2
<a href="#">C02622</a>	Manual jog: Acceleration
<a href="#">C02623</a>	Manual jog: Deceleration
<a href="#">C02624</a>	Manual jog: S-ramp time
<a href="#">C02625</a>	Manual jog: Step distance
<a href="#">C02626/1...16</a>	Manual jog: Index stop position
<a href="#">C02627/1...16</a>	Manual jog: Selected stop position

Highlighted in grey = display parameter

##### 11.4.2.1 Smooth start and quick stop of the drive



[11-16] Example: Smooth start and quick stop


- ▶ Different values for acceleration and deceleration can be set in [C02622/C02623](#) in order to implement a smooth start and a quick stop of the drive.
- ▶ By entering a relative S-ramp time in [C02624](#) both ramps can be set in S-shape for jerk reduction. ▶ [Setting the S-ramp time](#) (□ 385)



#### Tip!

A quick deceleration ([C02623](#)) reduces the time from letting go of the "Jog key" to the actual stop of the drive, so that the drive can thus be better positioned "by eye" and the desired stop position is not overtravelled.

## 11.4.2.2 Second speed



[11-17] Example: Change-over to second speed

► By setting the input *MAN\_bActivateJogSpeed2* to TRUE, a change-over to a second speed (C02621) can be carried out during the traversing process.

## 11.4.3 Executing manual jog

### Requirements

- ▶ The controller is in the "Operation" device state.
- ▶ The basic function "manual jog" is part of the active application.
- ▶ No other basic function is active.

### Activation

To request the control via the basic function, the *MAN\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.
- ▶ A successful change to the function state "Manual jog active" is displayed by a TRUE signal at the *MAN\_bEnabled* status output.

### Deactivation

If the *MAN\_bEnable* enable input is reset to FALSE, an active manual jog is reset, i.e. the control inputs for manual jog are inhibited and the drive is braked to standstill within the deceleration time for [Stop](#). (☞ 387)

- ▶ The status output *MAN\_bEnabled* is reset to FALSE and a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

## 11.4.3.1 Manual jog in positive/negative direction

In the "Manual jog active" function state the drive can be traversed manually according to the following truth table via the control inputs:

MAN_bJogNegative	MAN_bJogPositive	MAN_bActivateJogSpeed2	Function
FALSE	FALSE	-	Stop <ul style="list-style-type: none"> <li>The drive is braked to standstill with the deceleration set.</li> </ul>
FALSE	TRUE	FALSE	Manual jog <ul style="list-style-type: none"> <li>In positive direction</li> <li>Using speed 1 (<a href="#">C02620</a>)</li> </ul>
		TRUE	Manual jog <ul style="list-style-type: none"> <li>In positive direction</li> <li>Using speed 2 (<a href="#">C02621</a>)</li> </ul>
TRUE	FALSE	FALSE	Manual jog <ul style="list-style-type: none"> <li>In negative direction</li> <li>Using speed 1 (<a href="#">C02620</a>)</li> </ul>
		TRUE	Manual jog <ul style="list-style-type: none"> <li>In negative direction</li> <li>Using speed 2 (<a href="#">C02621</a>)</li> </ul>
TRUE	TRUE	-	When both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> <li>The drive is braked to standstill with the deceleration set.</li> </ul> If not both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> <li>The drive continues to traverse in the direction that was selected first.</li> </ul>



### Note!

In the standard technology applications "Actuating drive – speed" and "Actuating drive – torque", in the Lenze setting the control inputs are linked to the following digital inputs:

- **DI6:** Activate manual mode
- **DI7:** Manual jog in positive direction
- **DI8:** Manual jog in negative direction

## 11.4.3.2 Manual jog with step limitation

This function extension is available from software version V5.0 onwards!

---

This mode can be activated via the control input *MAN\_bStepMode*.

In the "Manual jog with step limitation" mode the drive traverses by the "step distance" parameterised in [C02625](#) if a direction is requested via the control inputs *MAN\_bJogPositive*/*MAN\_bJogNegative*. After traversing this distance, the drive stops.

- ▶ A new positive edge for the routing request causes a restart of the function or a reset of the distance counter, even if the drive is not at standstill yet.
- ▶ If the routing request is reset before the distance is reached, the drive stops immediately (with the deceleration set).



### Note!

The two modes "Manual jog with step limitation" and "Manual jog with intermediate stop" cannot be active at the same time.

If there is a simultaneous request via the control inputs *MAN\_bStepMode* and *MAN\_bIntermediateStopMode*, only the "Manual jog with intermediate stop" mode is active. ▶ [Manual jog with intermediate stop](#) (📖 407)

### 11.4.3.3 Manual jog with intermediate stop

This function extension is available from software version V5.0 onwards!

This mode can be activated via the control input *MAN\_bIntermediateStopMode*.

In the "Manual jog with intermediate stop" mode, in the case of a routing request via the control inputs *MAN\_bJogPositive*/*MAN\_bJogNegative* the drive traverses to the defined "Intermediate stop position" that is next in the corresponding direction.

MAN_bJogNegative	MAN_bJogPositive	Function
FALSE	TRUE	Drive traverses from the current position to the next target in positive direction of the intermediate positions defined.
TRUE	FALSE	Drive traverses from the current position to the next target in negative direction of the intermediate positions defined.

- ▶ The drive stops on the intermediate position that is approached.
- ▶ If the routing request is reset before the intermediate position is reached, the drive stops immediately (with the deceleration set).
- ▶ After the drive has stopped on the intermediate position, it can only continue after a new positive edge for the routing request.
- ▶ If the drive is in the outmost intermediate position defined and a new routing request is effected, the drive stops.



#### Note!

Requirements for manual jog with intermediate stop:

- The home position is known (otherwise status bit 26 is set).
- At least one intermediate stop position is defined (otherwise status bit 27 is set).

#### Selection of the intermediate stop positions

The max. 16 intermediate stop positions are selected/defined via a function block instance of type *L\_PosPositionerTable* or *L\_PosProfileTable*.

- ▶ For the transfer of the intermediate stop positions the output *FBData* of the respective function block instance is to be connected to the input *MAN\_FBData* of the *LS\_ManualJog* SB.
- ▶ The positions defined by the function block instance, which are to be used as intermediate stop positions are selected via [C02626/1...16](#).
  - In connection with a function block instance of type *L\_PosPositionerTable*:  
In [C02626/x](#) the index [1...75] of the table position in the VTPOS table has to be specified, which contains the intermediate stop position x that is to be used.
  - In connection with a function block instance of type *L\_PosProfileTable*:  
In [C02626/x](#) the index [1...4] of the profile data set has to be specified, which contains the intermediate stop position x that is to be used.
- ▶ The positions selected are shown in [C02627/1...16](#).

## 11.4.3.4 Manual jog to limit position




### Note!

Detailed information on travel range monitoring via limit switches and software limit positions can be found in the description of the basic function "[Limiter](#)".

([513](#))


### Manual jog to software limit position



[11-18] Example: Manual jog to positive software limit position

- ▶ If the reference is known and the software limit positions are set, a positioning to the corresponding software limit position is carried out, if manual jog was not exited manually before by resetting *MAN\_bJogNegative* or *MAN\_bJogPositive*.
- ▶ The drive brakes with the deceleration set ([C02623](#)) to the position of the corresponding software limit position.

### Manual jog to hardware limit position (limit switch)



[11-19] Example: Manual jog to positive limit switch

- ▶ When a limit switch is approached during manual jog, the drive is braked to standstill within the deceleration time set for the quick stop function.

See also:

- ▶ [Software limit positions](#) ([519](#))
- ▶ [Hardware limit positions \(limit switch\)](#) ([522](#))



### 11.4.3.5 Retracting of an activated limit switch

By setting *MAN\_bReleaseLimitSwitch* to TRUE, retracting from an operated limit switch is possible. The traversing process in the corresponding retracting direction is carried out until the limit switch is no longer activated.

- ▶ If, while retracting, a direction is selected additionally via the control inputs *MAN\_bJogPositive* or *MAN\_bJogNegative* towards the retracting direction, the travel is continued even after the limit switch has been abandoned until *MAN\_bJogPositive* or *MAN\_bJogNegative* are reset to FALSE.
- ▶ If the direction opposite to the retracting direction is preselected instead, the drive stops, and a corresponding status is shown via the status output *MAN\_dnState*.



#### Note!

Retracting from a limit switch is only possible if it is still activated, i. e. if the corresponding limit switch input of the limiter is still activated. Therefore ensure that if a limit switch is approached, its trigger mechanics is not "overtravelled", for instance by a too great mass or drive, so that by this the limit switch is no longer activated.



#### Tip!

An activated limit switch can also be exited again by manual jog in the retracting direction via the control input *MAN\_bJogPositive* or *MAN\_bJogNegative*.

See also: [▶ Hardware limit positions \(limit switch\) \(□ 522\)](#)

## 11.5 Manual jog, encoderless

This function extension is available from software version V7.0!

---

In various applications where drives are operated with feedback in the production process, it may be required to execute a controlled operation without feedback of position values and speed and torque values derived from the position values as well.

- ▶ For initial commissioning and test of the system hardware.  
(Control cabinet function, connection system, test of trailing cables)
- ▶ In case of feedback failure in order to move the drive/machine to a service position afterwards.

The U and I rotation test modes implemented in the motor control of the drive controller make it possible for the user to move the drive in a controlled manner. In the case of an asynchronous motor, a load-dependent speed is adopted. A synchronous motor rotates with a predefined field frequency provided the motor can generate the necessary load torque.

The basic function "Manual jog, encoderless" described in this chapter is available together with the corresponding Engineer dialogs for controlled manual jogging on the basis of the I rotation test mode.




### Note!

The activation and control of the basic function "Manual jog encoderless" can either be executed via process data (system block inputs or code accesses (e.g. via keypad)).

## 11.5.1 Internal interfaces | "LS\_ManualJogOpenLoop" system block

The **LS\_ManualJogOpenLoop** system block provides the internal interfaces for the basic function "Manual jog encoderless" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
MOL_bEnable <a href="#">C02781/1</a>   BOOL	Requesting control via the basic function. <ul style="list-style-type: none"> <li>Request is also possible via <a href="#">C02770/1</a>.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, it is changed to the "Manual jog encoderless active" and the drive can be traversed in a controlled way via the control inputs.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Active controlled traversing is stopped, i.e. a change-over from the active "Manual jog encoderless active" function state back to the "Controller not ready" basic state is effected.</td> </tr> </table>	TRUE	If no other basic function is active, it is changed to the "Manual jog encoderless active" and the drive can be traversed in a controlled way via the control inputs.	TRUE↔FALSE	Active controlled traversing is stopped, i.e. a change-over from the active "Manual jog encoderless active" function state back to the "Controller not ready" basic state is effected.
TRUE	If no other basic function is active, it is changed to the "Manual jog encoderless active" and the drive can be traversed in a controlled way via the control inputs.				
TRUE↔FALSE	Active controlled traversing is stopped, i.e. a change-over from the active "Manual jog encoderless active" function state back to the "Controller not ready" basic state is effected.				
MOL_bJogPositive <a href="#">C02781/2</a>   BOOL	<ul style="list-style-type: none"> <li>▶ <a href="#">Manual jog open loop in positive/negative direction</a> (□ 418)</li> <li>• Control is also possible via <a href="#">C02770/2</a> and <a href="#">C02770/3</a>.</li> </ul>				
MOL_bJogNegative <a href="#">C02781/3</a>   BOOL					
MOL_bActivateDataBit1 <a href="#">C02781/4</a>   BOOL	<ul style="list-style-type: none"> <li>▶ <a href="#">Selection of the profile parameter set</a> (□ 418)</li> <li>• Selection is also possible via <a href="#">C02770/4</a> and <a href="#">C02770/5</a>.</li> </ul>				
MOL_bActivateDataBit2 <a href="#">C02781/5</a>   BOOL					

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Manual jog, encoderless

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning				
Mol_dnState <a href="#">C02780</a>   DINT	<p>Status (bit coded)</p> <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr> <td>Bit 1</td> <td>Manual jog open loop active.</td> </tr> <tr> <td>Bit 2</td> <td>Profile executed.</td> </tr> </table>	Bit 1	Manual jog open loop active.	Bit 2	Profile executed.
Bit 1	Manual jog open loop active.				
Bit 2	Profile executed.				
MOL_bEnabled <a href="#">C02781/6</a>   BOOL	<p>Status signal "Basic function is enabled"</p> <table border="1"> <tr> <td>TRUE</td> <td>Controlled traversing via the control inputs is possible.                             <ul style="list-style-type: none"> <li>The <i>MOL_bEnable</i> enable input is set to TRUE and the controller is in the "Manual jog open loop active" function state.</li> </ul> </td> </tr> </table>	TRUE	Controlled traversing via the control inputs is possible. <ul style="list-style-type: none"> <li>The <i>MOL_bEnable</i> enable input is set to TRUE and the controller is in the "Manual jog open loop active" function state.</li> </ul>		
TRUE	Controlled traversing via the control inputs is possible. <ul style="list-style-type: none"> <li>The <i>MOL_bEnable</i> enable input is set to TRUE and the controller is in the "Manual jog open loop active" function state.</li> </ul>				
MOL_bActive <a href="#">C02781/7</a>   BOOL	<p>Status signal "Basic function is active"</p> <table border="1"> <tr> <td>TRUE</td> <td>Controlled traversing is active (the drive axis moves according to the defined profile).</td> </tr> </table>	TRUE	Controlled traversing is active (the drive axis moves according to the defined profile).		
TRUE	Controlled traversing is active (the drive axis moves according to the defined profile).				
MOL_bDone <a href="#">C02781/8</a>   BOOL	<p>Status signal "Max. activation time reached"</p> <ul style="list-style-type: none"> <li>The status signal indicates that the respective parameterised max. activation time has been reached.</li> <li>The counter of the max. activation time is reset every time there is a TRUE-FALSE edge at <i>MOL_bJogPositive</i>/<i>MOL_bJogNegative</i>.</li> <li>The setpoint frequency and therefore the rotating field at the motor terminals is generated within the acceleration time parameterised in <a href="#">C02774/1...4</a> for the selected profile and the drive movement starts accordingly.</li> <li>At the instant of "Max. activation time reached", the drive is still moving and ramping down within the deceleration time parameterised in <a href="#">C02775/1...4</a> for the selected profile is initiated.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Controlled manual jogging is active                             <ul style="list-style-type: none"> <li>The max. activation time parameterised for the selected profile in <a href="#">C02776/1...4</a> has expired.</li> <li><i>MOL_bJogPositive</i> or <i>MOL_bJogNegative</i> is TRUE</li> <li>The setpoint frequency still corresponds to the setpoint frequency parameterised in <a href="#">C02771/1...4</a> for the selected profile.</li> </ul> </td> </tr> </table>	TRUE	Controlled manual jogging is active <ul style="list-style-type: none"> <li>The max. activation time parameterised for the selected profile in <a href="#">C02776/1...4</a> has expired.</li> <li><i>MOL_bJogPositive</i> or <i>MOL_bJogNegative</i> is TRUE</li> <li>The setpoint frequency still corresponds to the setpoint frequency parameterised in <a href="#">C02771/1...4</a> for the selected profile.</li> </ul>		
TRUE	Controlled manual jogging is active <ul style="list-style-type: none"> <li>The max. activation time parameterised for the selected profile in <a href="#">C02776/1...4</a> has expired.</li> <li><i>MOL_bJogPositive</i> or <i>MOL_bJogNegative</i> is TRUE</li> <li>The setpoint frequency still corresponds to the setpoint frequency parameterised in <a href="#">C02771/1...4</a> for the selected profile.</li> </ul>				

## 11.5.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Manual jog open loop*
- ▶ Short overview of the parameters for manual jog open loop:

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02770/1</a>	EnableManualMode	0: Deactivate	
<a href="#">C02770/2</a>	JogPositive	0: Deactivate	
<a href="#">C02770/3</a>	JogNegative	0: Deactivate	
<a href="#">C02770/4</a>	SelectTab1	0: Deactivate	
<a href="#">C02770/5</a>	SelectTab2	0: Deactivate	
<a href="#">C02771/1...4</a>	Frequency <ul style="list-style-type: none"> <li>• Field frequency <math>f_d</math> with which the current vector rotates.</li> </ul>	1.0	Hz
<a href="#">C02772/1...4</a>	Starting angle	0.0	°
<a href="#">C02773/1...4</a>	Current <ul style="list-style-type: none"> <li>• R.m.s. value of the current vector which is injected with the parameterised frequency/starting angle.</li> <li>• 100 % <math>\equiv I_{\max\_device}</math> (<a href="#">C00022</a>)</li> </ul>	10.00	%
<a href="#">C02774/1...4</a>	Acceleration time	1.000	s
<a href="#">C02775/1...4</a>	Deceleration time	1.000	s
<a href="#">C02776/1...4</a>	Duration (max. activation time)	1.000	s
<a href="#">C02779</a>	Mol_SetpointCurrent	-	A
<a href="#">C02780</a>	Mol_dnState	-	
<a href="#">C02781</a>	ManualJogOpenLoop: Dig. signals	-	

Highlighted in grey = display parameter



### Stop!

At the frequency  $f_d = 0$  Hz, the r.m.s. value increases to 141 % of the current parameterised in [C02773/x](#). As a result, the connected motor can be destroyed!

**Remedy:** Activation of a derating curve in i2xt monitoring or limitation of the parameterised current in [C02773/x](#) to 71 % of the rated motor current. ▶ [Motor monitoring \(I<sup>2</sup>xt\)](#) (□ 224)

## 11.5.2.1 Necessary basic parameter settings

Before encoderless manual jogging is performed, the following basic parameter settings must be made:

1. Optimisation of the current controller in the case of non-Lenze motors or motors that are not included in the »Engineer« motor catalogue. ▶ [Optimise current controller](#) (□ 187)
2. Parameterisation of motor monitoring corresponding to the existing motor with the monitoring response "Fault". ▶ [Motor monitoring \( \$I^2xt\$ \)](#) (□ 224)
  - This function is especially important for monitoring the permissible r.m.s. current load on motors at  $f_d = 0$  Hz.
3. Activation of maximum current monitoring with the monitoring response "Fault" in the case of non-Lenze motors or motor that are not included in the »Engineer« motor catalogue. ▶ [Maximum current monitoring](#) (□ 235)
4. Activation of motor temperature monitoring via PTC and/or KTY. ▶ [Motor temperature monitoring](#) (□ 229)

## 11.5.2.2 Profile parameters

For controlled traversing, four different profiles (profile parameter sets) can be parameterised:

Setpoint	Profile parameter set 1	Profile parameter set 2	Profile parameter set 3	Profile parameter set 4
Frequency	<a href="#">C02771/1</a>	<a href="#">C02771/2</a>	<a href="#">C02771/3</a>	<a href="#">C02771/4</a>
Starting angle	<a href="#">C02772/1</a>	<a href="#">C02772/2</a>	<a href="#">C02772/3</a>	<a href="#">C02772/4</a>
Current	<a href="#">C02773/1</a>	<a href="#">C02773/2</a>	<a href="#">C02773/3</a>	<a href="#">C02773/4</a>
Acceleration time	<a href="#">C02774/1</a>	<a href="#">C02774/2</a>	<a href="#">C02774/3</a>	<a href="#">C02774/4</a>
Deceleration time	<a href="#">C02775/1</a>	<a href="#">C02775/2</a>	<a href="#">C02775/3</a>	<a href="#">C02775/4</a>
Duration time	<a href="#">C02776/1</a>	<a href="#">C02776/2</a>	<a href="#">C02776/3</a>	<a href="#">C02776/4</a>

The profile parameter set to be used is selected via the control inputs *MOL\_bActivateDataBit1* and *MOL\_bActivateDataBit2* or alternatively via the parameters [C02770/4](#) and [C02770/5](#).

### 11.5.3 Executing manual jog open loop

#### Requirements

- ▶ The basic parameter settings described in chapter [\[11.5.2.1\]](#) are made. ▶ [Necessary basic parameter settings](#) (□ 414)
- ▶ The controller inhibit is active.
- ▶ The controller has the "Controller not ready" function state.
- ▶ The basic function "Manual jog open loop" is part of the active application.
- ▶ No other basic function is active.

#### Activation

In order to request the control via the basic function, the *MOL\_bEnable* enable input in the application must be set to TRUE or [C02770/1](#) to "1".

- ▶ If no other basic function is active, it is changed to the "Manual jog open loop active" function state and a controlled traversing can take place via the control inputs or by writing [C02770/2...5](#).
- ▶ A successful change to the function state "Manual jog open loop active" is displayed by a TRUE signal at the *MOL\_bEnabled* status output.



#### Stop!

If a quick stop is requested with the "Manual jog, encoderless" function active, ramping-down of the setpoint frequency occurs with a fixed deceleration time  $t = 0$  s.

- The thus generated braking effect at the drive is not comparable with the braking effect in the controlled motor mode!
- Under certain conditions, this can also lead to vibrations in the drive.

The user must select suitable setpoint frequencies to reduce the speeds of the machine to a minimum so that shutdown by means of the basic "[Quick stop](#)" function can be ensured in the case of encoderless manual jogging as well.

#### Deactivation



#### Note!

The controller must be inhibited before the basic function is deactivated!

Otherwise, the consequence is unsteady drive behaviour via the function state "Controller not ready" into the basic "[Stop](#)" function.

If the enable input *MOL\_bEnable* is reset to FALSE, active manual jogging is stopped according to the following different cases that are distinguished.


**Case 1:** If *MOL\_bEnable* is reset to FALSE and the drive controller is still enabled, the function state "Manual jog encoderless, active" is exited and the basic "[Stop](#)" function is

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Manual jog, encoderless

activated. A changeover is then made back the basic state "Drive at a standstill" via the function state "Drive is being stopped".




[11-20] Signal characteristic, case 1: *MOL\_bEnable* is reset to FALSE while the drive controller is still enabled

- ▶ In line with the motor control selected in [C00006](#), additional basic conditions are necessary in order to avoid unsteady drive behaviour:
  - [C00006](#) = "1: SC: Servo control sync. motor":  
Parameterised and connected motor encoder as well as a correct pole position in [C00058/x](#)  
- or -  
activation of the basic "[Pole position identification](#)" function and its monitoring in [C02785](#) (Lenze recommendation).
  - [C00006](#) = "2: SC: Servo control async. motor":  
Parameterised and connected motor encoder.



**Case 2:** If *MOL\_bEnable* is reset to FALSE and the controller inhibit has been set at least at the same time, a changeover takes place from the function state "Manual jog encoderless active" to the function state "Drive controller not ready":



[11-21] Signal characteristic, case 2: *MOL\_bEnable* is reset to FALSE and the controller inhibit is set at least at the same time

- With this signal sequence, drives can be operated for which the function of the motor encoder and/or the pole position do not exist.

## 11.5.3.1 Selection of the profile parameter set

For a controlled traversing, four different profiles can be parameterised. The profile parameter set to be used is selected via the control inputs given in the following truth table:

MOL_bActivateData Bit2 <a href="#">C02770/5</a>	MOL_bActivateData Bit1 <a href="#">C02770/4</a>	Selected profile parameter set
FALSE	FALSE	Profile parameter set 1
FALSE	TRUE	Profile parameter set 2
TRUE	FALSE	Profile parameter set 3
TRUE	TRUE	Profile parameter set 4



### Note!

The four profile parameter sets may only be processed sequentially, i.e. a selected profile parameter set must be completed with  $f_d = 0$  Hz before another profile parameter set can be activated.

- See signal characteristic (Fig. [\[11-20\]](#)) in the previous chapter. ([□ 416](#))
- Lenze recommends to control the basic function in accordance with this signal characteristic.

## 11.5.3.2 Manual jog open loop in positive/negative direction

In the "Manual jog open loop active" function state the drive can be traversed manually via the control inputs given in the following truth table:

MOL_bJogNegative <a href="#">C02770/3</a>	MOL_bJogPositive <a href="#">C02770/2</a>	Function
FALSE	FALSE	Stop <ul style="list-style-type: none"> <li>• The drive is braked to standstill with the deceleration time in <a href="#">(C02775/x)</a> set for the selected profile.</li> </ul>
FALSE	TRUE	Controlled traversing in positive direction <ul style="list-style-type: none"> <li>• The drive is led to the setpoint frequency with the acceleration time <a href="#">(C02774/x)</a> set for the selected profile <a href="#">(C02771/x)</a>.</li> </ul>
TRUE	FALSE	Controlled traversing in negative direction <ul style="list-style-type: none"> <li>• The drive is led to the setpoint frequency with the acceleration time <a href="#">(C02774/x)</a> set for the selected profile <a href="#">(C02771/x)</a>.</li> </ul>
TRUE	TRUE	When both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> <li>• The drive is braked to standstill with the deceleration time in <a href="#">(C02775/x)</a> set for the selected profile.</li> </ul> If not both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> <li>• The drive continues to traverse in the direction that was selected first.</li> </ul>

x = number (1...4) of the selected profile parameter set

## 11.6 Homing

With the basic function "Homing" the measuring system of the machine is transmitted to the controller within the travel range that is physically possible.

- ▶ The reference (e.g. zero position of the drive axis in the machine measuring system) can be defined by reference search or reference setting.
- ▶ In case of reference search, the drive travels according to the defined homing mode to detect the reference in the measuring system independently.
  - In the reference point, the home position parameterised in [C02642](#) is set as the current position. Afterwards, an absolute positioning to the target position parameterised in [C02643](#) takes place (if [C02641](#) = "0").
- ▶ If the reference is set in the homing mode "100: Set reference directly" or via the control input *HM\_bLoadHomePos*, the drive can also be referenced manually if the motor is at standstill. The measuring system is set by means of the home position parameterised in [C02642](#) or applied at the input *HM\_dnHomePos\_p*.



### Danger!

During homing operations, specially assigned profile parameters are effective. If these parameters are not set correctly, the drive may execute uncontrolled movements!



### Note!

Normally homing is only required once during commissioning of systems for which the machine cycle can be represented in the display area of the encoder, e. g. if multiturn absolute value encoders or singleturn absolute value encoders/resolvers are used during the machine cycle on one motor revolution.

- The encoder position is stored safe against mains failure in the memory module and is therefore known to the drive control even after the mains has been switched. ▶ [Behaviour of the home position after mains switching](#) (□ 424)
- A renewed reference setting is only required in case of a renewed commissioning or in case of service (e.g. when drive components are exchanged).



#### Note!

For homing, setpoint speeds greater than 30000 rpm are not possible. The speeds defined for these basic function are internally limited to 30000 rpm.

When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 383)

**For the encoderless motor control types (from software version V3.0) the following applies:**

The basic function "Homing" can only be activated for V/f control or sensorless vector control if the position controller has been selected for the position control ([C02570](#) = "2: position controller active").

- The homing modes 14 & 15 are not permissible for the V/f control. If the selection is impermissible, the error message "Homing mode not allowed" is output.


**For the encoderless motor control types (from software version V5.0) the following applies:**

If the V/f control or sensorless vector control is selected, the basic function "Homing" can be activated, irrespective of the use of the position controller.

- If no position controller has been selected for the position control in case of V/f control or sensorless vector control ([C02570](#) = "1: Phase controller is active"), homing is only carried out via the speed profile resulting from the homing parameters. Because of this, the target positions set will only "roughly" be reached.

## 11.6.1 Internal interfaces | "LS\_Homing" system block

The **LS\_Homing** system block provides the internal interfaces for the basic function "Homing" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
HM_bEnable <small>C02659/1   BOOL</small>	Requesting control via the basic function. TRUE If no other basic function is active, a change-over to the "Homing active" function state is effected and homing can be carried out via the control inputs. TRUE↔FALSE An active reference search is stopped, i. e. a change-over from the active "Homing active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
HM_bActivateHoming <small>C02659/2   BOOL</small>	Starting homing/directly setting reference TRUE Reference search is started in the homing mode selected (C02640). In the homing mode "100: Set reference directly" no reference search is started, but the home position set in C02642 is directly accepted. TRUE↔FALSE Active reference search is completed/cancelled.
HM_bHomingMark <small>C02659/3   BOOL</small>	Input for reference switch TRUE Reference switch is activated.
HM_bLoadHomePos <small>C02659/4   BOOL</small>	Loading home position FALSE↔TRUE The position applied to input HM_dnHomePos_p is accepted as home position.
HM_dnHomePos_p <small>C02658   DINT</small>	Home position in [increments] for acceptance with HM_bLoadHomePos

# 9400 HighLine | Parameter setting & configuration

## Basic drive functions

### Homing

Identifier <small>DIS code   data type</small>	Information/possible settings
HM_bResetHomePos <a href="#">C02659/5</a>   BOOL	Resetting the status "Reference known" FALSE → TRUE The internal status "Reference known" is reset. <ul style="list-style-type: none"> <li>The status outputs <i>HM_bDone</i> and <i>HM_bHomePosAvailable</i> are reset to FALSE.</li> </ul>
HM_dnSpeedOverride_n <a href="#">C02655</a>   DINT <small>From V5.0</small>	Value of speed override <ul style="list-style-type: none"> <li>Percentage multiplier for the currently active speed (<a href="#">C02644</a> or <a href="#">C02646</a>).</li> <li>In the case of active homing, the speed override is always active and does not have to be activated separately.</li> <li>Changes are accepted in each cycle.</li> <li><math>2^{30} \equiv 100\%</math> of the speed parameterised in <a href="#">C02644</a> or <a href="#">C02646</a>.</li> <li>For values <math>\leq 1\%</math> the status bit 19 is set.</li> <li>Values <math>\leq 0\%</math> are set to <math>0\%</math> internally and lead to the standstill of the drive.</li> </ul>

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning																												
HM_dnState <a href="#">C02657</a>   DINT	Status (bit coded) <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr><td>Bit 1</td><td>Reference search is active.</td></tr> <tr><td>Bit 2</td><td>Reference search is completed.</td></tr> <tr><td>Bit 3</td><td>Acceleration/deceleration phase is active.</td></tr> <tr><td>Bit 5</td><td>CCW rotation is active.</td></tr> <tr><td>Bit 7</td><td>Reference known.</td></tr> <tr><td>Bit 15</td><td>Fault in basic function active (group signal).</td></tr> <tr><td>Bit 16</td><td>Pre-switch-off (reference switch) has been detected.</td></tr> <tr><td>Bit 17</td><td>Touch probe/zero pulse has been detected.</td></tr> <tr><td>Bit 19</td><td>Speed override <math>\leq 1\%</math>  <ul style="list-style-type: none"> <li>This status is only available from software version V5.0.</li> </ul> </td></tr> <tr><td>Bit 21</td><td>Profile data are limited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 22</td><td>Traversing direction is inhibited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 23</td><td>Abort by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 25</td><td>Stopping is active.  <ul style="list-style-type: none"> <li>Basic function is enabled for the first time but no referencing has been requested / is active yet or speed <math>\neq 0</math>.</li> </ul> </td></tr> <tr><td>Bit 30</td><td>Profile generation error.</td></tr> </table>	Bit 1	Reference search is active.	Bit 2	Reference search is completed.	Bit 3	Acceleration/deceleration phase is active.	Bit 5	CCW rotation is active.	Bit 7	Reference known.	Bit 15	Fault in basic function active (group signal).	Bit 16	Pre-switch-off (reference switch) has been detected.	Bit 17	Touch probe/zero pulse has been detected.	Bit 19	Speed override $\leq 1\%$ <ul style="list-style-type: none"> <li>This status is only available from software version V5.0.</li> </ul>	Bit 21	Profile data are limited by basic function " <a href="#">Limiter</a> ".	Bit 22	Traversing direction is inhibited by basic function " <a href="#">Limiter</a> ".	Bit 23	Abort by basic function " <a href="#">Limiter</a> ".	Bit 25	Stopping is active. <ul style="list-style-type: none"> <li>Basic function is enabled for the first time but no referencing has been requested / is active yet or speed <math>\neq 0</math>.</li> </ul>	Bit 30	Profile generation error.
Bit 1	Reference search is active.																												
Bit 2	Reference search is completed.																												
Bit 3	Acceleration/deceleration phase is active.																												
Bit 5	CCW rotation is active.																												
Bit 7	Reference known.																												
Bit 15	Fault in basic function active (group signal).																												
Bit 16	Pre-switch-off (reference switch) has been detected.																												
Bit 17	Touch probe/zero pulse has been detected.																												
Bit 19	Speed override $\leq 1\%$ <ul style="list-style-type: none"> <li>This status is only available from software version V5.0.</li> </ul>																												
Bit 21	Profile data are limited by basic function " <a href="#">Limiter</a> ".																												
Bit 22	Traversing direction is inhibited by basic function " <a href="#">Limiter</a> ".																												
Bit 23	Abort by basic function " <a href="#">Limiter</a> ".																												
Bit 25	Stopping is active. <ul style="list-style-type: none"> <li>Basic function is enabled for the first time but no referencing has been requested / is active yet or speed <math>\neq 0</math>.</li> </ul>																												
Bit 30	Profile generation error.																												
HM_bEnabled <a href="#">C02659/6</a>   BOOL	Status signal "Basic function is enabled" TRUE Homing via the control inputs is possible. <ul style="list-style-type: none"> <li>The <i>HM_bEnable</i> enable input is set to TRUE and the controller is in the "Homing active" function state.</li> </ul>																												
HM_bActive <a href="#">C02659/7</a>   BOOL	Status signal "Basic function is active" TRUE Reference search is active (the drive axis is moving).																												
HM_bDone <a href="#">C02659/8</a>   BOOL	Status signal "Basic function is ready" TRUE Reference search is completed. <ul style="list-style-type: none"> <li>Output is reset to FALSE when input <i>HM_bActivateHoming</i> is reset to FALSE.</li> </ul>																												
HM_bHomePosAvailable <a href="#">C02659/9</a>   BOOL	Status signal "Reference is known" TRUE The drive knows the home position.																												

## 11.6.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Homing*
- ▶ Short overview of the parameters for homing:

Parameter	Information
<a href="#">C02528</a>	Traversing range
<a href="#">C02640</a>	Homing mode
<a href="#">C02641</a>	Action after detect Home position
<a href="#">C02642</a>	Home position
<a href="#">C02643</a>	Homing: Target position
<a href="#">C02644</a>	Homing: Speed 1
<a href="#">C02645</a>	Homing: Acceleration 1
<a href="#">C02646</a>	Homing: Speed 2
<a href="#">C02647</a>	Homing: Acceleration 2
<a href="#">C02648</a>	Homing: S-ramp time
<a href="#">C02649</a>	Homing: Torque limit
<a href="#">C02650</a>	Homing: Blocking time
<a href="#">C02651</a>	Homing: TP configuration
<a href="#">C02652</a>	Ref. pos. after mains switching
<a href="#">C02653</a>	Max. rot. ang. aft. mns. swtch.
<a href="#">C02656</a>	Actual position (homing)

#### 11.6.2.1 Behaviour of the home position after mains switching

If the home position/information is also to be available after mains switching, the setting [C02652](#) = "1: Received" is required.

Another condition for keeping the home position/information after mains switching is the compliance with the maximum permissible angle of rotation of the encoder.

- ▶ The maximally permissible angle of rotation can be set in [C02653](#) in angular degree [°] with regard to the encoder shaft (360° ≡ one encoder shaft rotation).



#### Note!

Due to the internal numerical format and the resolution of one encoder revolution according to [C00100](#), the position may not be reconstructed over the complete encoder range!

- The possible number of revolutions can be calculated as follows:  
Number of revolutions =  $2^{(31 - C00100)}$
- Example: For a standard multiturn absolute value encoder with an absolute display area of 4096 revolutions ( $\pm 2048$ ), a maximum position resolution of 20 bits per revolution can be used!

When resolvers or single-turn absolute value encoders are used and the mains is switched off (24 V supply off), the encoder may only be moved by  $\frac{1}{2}$  revolution since otherwise the home position will get lost due to the ambiguity of the encoder information.



### 11.6.2.2 Homing mode

The zero position, also called reference, can be defined by a reference search or reference setting:

- ▶ In case of a reference search the drive travels according to a defined mode to detect the reference independently.
- ▶ In case of reference setting the reference is manually set when the drive has stopped.



#### Tip!

A reference search is mainly used in the case of continuously running systems, or if the traversing range or machine cycle of the drive cannot be represented in the display area of the encoder, e. g. if incremental encoders are used at the motor, or singleturn absolute value encoders or resolvers are used at the gearbox.

A reference is mainly set in systems/machines that bear the risk of collisions, or every time no homing can be executed (e.g. in case of a cross cutter having material in the machine).

- ▶ For reference setting, select the homing mode "100" in [C02640](#).
- ▶ For a reference search the homing modes 0"...15" are provided in [C02640](#).
  - For process descriptions see the chapter "[Overview of the Lenze homing modes](#)". ([430](#))
  - From software version V3.0 according to the DS402 device profile, additionally the homing modes 1001"...1035" are provided in [C02640](#). Process descriptions for these homing modes can be found in the chapter "[Overview of DS402 homing modes](#)". ([430](#))



#### Note!

##### Profile data set change-over

For the reference search, two profile data sets with different speeds and accelerations can be parameterised. In this way, the homing time can be reduced and at the same time the accuracy can be increased.

- ▶ [Profile data set change-over](#) ([427](#))

The process descriptions in the following chapters provide information on the time the change-over to the profile data set 2 takes place in the corresponding homing mode.

- ▶ [Overview of the Lenze homing modes](#) ([430](#))
- ▶ [Overview of DS402 homing modes](#) ([445](#))

If the speed 2 ([C02646](#)) is set to "0" (Lenze setting), no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.



#### Note!

##### Drive behaviour after setting the reference

From software version V4.0 onwards, [C02641](#) serves to parameterise the drive behaviour after setting the home position.

▶ [Drive behaviour after setting the home position](#) (📖 426)

In the Lenze setting ([C02641](#) = "0"), the drive traverses to the absolute target position set in [C02643](#) similarly to the behaviour known from the previous versions.

#### 11.6.2.3 Home position & target position

When the home position is set during the reference search, the position detected in the machine measuring system corresponds to the value set in [C02642](#).

For software versions lower than V4.0 the following applies:

▶ Afterwards the drive travels to the target position set in [C02643](#).

The following applies from software version V4.0:

▶ The subsequent drive behaviour is determined by the mode parameterised in [C02641](#). See the below chapter "[Drive behaviour after setting the home position](#)".

#### 11.6.2.4 Drive behaviour after setting the home position

This function extension is available from software version V4.0!

---

[C02641](#) can be used to select the drive behaviour after setting the home position.

##### Selection "0: Move absolute on Target position"

After setting the home position ([C02642](#)), the drive moves to the absolute target position set in [C02643](#).

This selection is the Lenze setting and corresponds to the behaviour known from the previous versions.

##### Selection "1: Move relative by Target position"

After setting the home position ([C02642](#)), the drive moves relatively by the target position set in [C02643](#).

##### Selection "2: Stop immediately"

After setting the home position ([C02642](#)), the drive stops immediately.

### 11.6.2.5 Profile data set change-over

For the reference search two profile data sets can be parameterised to reduce the homing time and increase the accuracy:

Profile data set 1		Profile data set 2	
<a href="#">C02644</a>	Speed 1	<a href="#">C02646</a>	Speed 2
<a href="#">C02645</a>	Acceleration 1 (and deceleration 1)	<a href="#">C02647</a>	Acceleration 2 (and deceleration 2)
<a href="#">C02648</a>	S-ramp time (identical in both profile data sets) ▶ <a href="#">Setting the S-ramp time</a> (📖 385)	<a href="#">C02648</a>	S-ramp time (identical in both profile data sets) ▶ <a href="#">Setting the S-ramp time</a> (📖 385)

- ▶ With the profile data set 1 first the limit switch/reference switch (depending on the mode selected) is quickly approached.
- ▶ After reversing on the limit switch/reference switch, the slower – but more accurate – approach of the encoder zero pulse/touch probe sensor and the positioning to the target position ([C02643](#)) are effected with profile data set 2.



#### Note!

The change-over to profile data set 2 is only effected if speed 2 ([C02646](#)) is set > "0"!

In the Lenze setting ([C02646](#) = "0") no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.


The process descriptions of the homing modes provide information about when the change-over to profile data set 2 takes place in the respective homing mode.

▶ [Overview of the Lenze homing modes](#) (📖 430)

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing



## Example: Procedure of mode 2:

- Movement in positive direction with profile data set 1.
- Reversing to positive travel range limit switch.
- Positive edge at *HM\_bHomingMark* activates profile data set 2 for the further reference search.
- Negative edge at *HM\_bHomingMark* enables home position detection.
- The following positive edge of the encoder zero pulse (MP) sets the reference.
- Drive has reached defined target position.

### 11.6.2.6 Homing to end stop

By selecting the homing modes 14 & 15, homing to end stop can be executed as follows:

1. The drive travels with reduced torque in positive direction (mode 14) or negative direction (mode 15).
2. When the drive hits an end stop so that the torque limit set in [C02649](#) is exceeded for the blocking time defined in [C02650](#), the reference is set.
  - If a reference offset is set, traversing takes place around this offset in a correctly signed manner.

▶ [Mode 14: positive direction to torque limit](#) (□ 443)

▶ [Mode 15: negative direction to torque limit](#) (□ 443)

### 11.6.2.7 Connection of reference switch

For the homing modes with reference switch, the *HM\_bHomingMark* control input must be connected to the digital input which is connected to the reference switch.

### 11.6.2.8 Touch probe interface configuration

The touch probe channel to be used for homing with touch probe detection in the »Engineer« is selected on the **Application parameters** tab in the dialog level *Overview* → *All basic functions* → *Homing* → *TP interface*.

- ▶ The setting carried out in this parameterisation dialog directly affects the setting of [C02651](#) ("Homing: TP configuration") and vice versa.
- ▶ For directly setting [C02651](#) (e. g. by means of the keypad) the corresponding decimal values are listed for all configuration options in the following table:

Selection Touch probe channel	Touch probe response		
	Positive edge	Negative edge	Both edges
Digital input 1	1	2	3
Digital input 2	4	8	12
Digital input 3	16	32	48
Digital input 4	64	128	192
Digital input 5	256	512	768
Digital input 6	1024	2048	3072
Digital input 7	4096	8192	12288
Digital input 8	16384	32768	49152
Motor encoder zero pulse	65536		
Position encoder zero pulse	262144		

- ▶ Example: For selecting the touch probe channel "Digital input 1" and a response only to a negative edge, the decimal value "2" has to be set in [C02651](#).

#### 11.6.3 Overview of the Lenze homing modes

In the following subchapters the procedures of homing modes 0 ... 15 are described, which can be selected in [C02640](#).

Homing mode <a href="#">C02640</a>	Evaluated signals/sensors			Reference switch at <i>HM_bHomingMark</i>
	Touch probe sensor/ encoder zero pulse	Travel range limit switch		
		Negative limit switch	Positive limit switch	
0	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
1	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
2	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
4	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
5	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
8	<input checked="" type="checkbox"/>			
9	<input checked="" type="checkbox"/>			
10	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
12			<input checked="" type="checkbox"/>	
13		<input checked="" type="checkbox"/>		
14	Positive direction of rotation to torque limit.			
15	Negative direction of rotation to torque limit.			
100	Set home position directly			

The switches/sensors are evaluated via the following internal interfaces:

Switch/sensor	Internal interface for digital input signal
Touch probe sensor	<i>DIGIN_bIn1 ... DIGIN_bIn8</i> <ul style="list-style-type: none"> <li>Alternatively the motor encoder or position encoder zero pulse can be evaluated.</li> </ul> <a href="#">▶ Touch probe interface configuration (429)</a>
Positive travel range limit switch	<i>LIM_bLimitSwitchPositive</i> (basic function " <a href="#">Limiter</a> ")
Negative travel range limit switch	<i>LIM_bLimitSwitchNegative</i> (basic function " <a href="#">Limiter</a> ")
Reference switch	<i>HM_bHomingMark</i> (basic function " <a href="#">Homing</a> ")



#### Note!

##### Profile data set change-over

For the reference search, two profile data sets with different speeds and accelerations can be parameterised. In this way, the homing time can be reduced and at the same time the accuracy can be increased.

[▶ Profile data set change-over \(427\)](#)

The following process descriptions give information about the time the change-over to the profile data set 2 takes place in the corresponding homing mode.

If the speed 2 ([C02646](#)) is set to "0" (Lenze setting), no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.



## Note!

### Drive behaviour after setting the reference

From software version V4.0 onwards, [C02641](#) serves to parameterise the drive behaviour after setting the home position.

▶ [Drive behaviour after setting the home position](#) (📖 426)


In the Lenze setting ([C02641](#) = "0"), the drive traverses to the absolute target position set in [C02643](#) similarly to the behaviour known from the previous versions.

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing

Mode 0: pos. direction - via home mark - to TP




## Procedure:

1. Movement in positive direction with profile data set 1.
2. Positive edge at *HM\_bHomingMark* activates profile data set 2 for the further reference search.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").



**Mode 1: neg. direction - via home mark - to TP**



**Procedure:**


1. Movement in negative direction with profile data set 1.
2. Positive edge at *HM\_bHomingMark* activates profile data set 2 for the further reference search.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing


Mode 2: pos. direction - reversing to limit switch - via home mark - to TP



## Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge at *HM\_bHomingMark* activates profile data set 2 for the further reference search.
4. Negative edge at *HM\_bHomingMark* enables home position detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 3: neg. direction - reversing to limit switch - via home mark - to TP



### Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge at *HM\_bHomingMark* activates profile data set 2 for the further reference search.
4. Negative edge at *HM\_bHomingMark* enables home position detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

#### Mode 4: pos. direction - reversing to home mark - to TP



#### Procedures:

Case 1:

Axis has not yet activated the reference switch:


1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge at *HM\_bHomingMark* and simultaneous activation of the profile data set 2 for further reference search.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Negative edge at *HM\_bHomingMark* enables home position detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 5: neg. direction - reversing to home mark - to TP



### Procedures:

Case 1:

Axis has not yet activated the reference switch:

1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge at *HM\_bHomingMark* and simultaneous activation of the profile data set 2 for further reference search.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:


1. Movement in positive direction with profile data set 2.
2. Negative edge at *HM\_bHomingMark* enables home position detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing


## Mode 8: positive direction to touch probe



### Procedure:

1. Movement in positive direction with profile data set 1.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


## Mode 9: negative direction to touch probe



### Procedure:

1. Movement in negative direction with profile data set 1.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 10: pos. direction - reversing to limit switch - to TP

**Procedure:**


1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge of the positive travel range limit switch and simultaneous activation of the profile data set 2 for further reference search.
3. The following positive edge of the touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

**Note!**

The touch probe detection is already activated after reversing to the travel range limit switch, i.e. the home position may be set to the travel range limit switch.

- We therefore recommend to set a target position ([C02643](#)) unequal to the home position ([C02642](#)), in order to reenble the activated limit switch. Otherwise, the positioning process to the target position may be aborted by the basic function "Limiter" (see status signal *HM\_dnState*).
- If the touch probe detection is to be activated after the travel range limit switch has been left, we recommend to use the DS402 homing methods 1 or 2. ▶ [Overview of DS402 homing modes](#) (📖 445)

#### Mode 11: neg. direction - reversing to limit switch - to TP



#### Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the negative travel range limit switch and simultaneous activation of the profile data set 2 for further reference search.
3. The following positive edge of the touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").




#### Note!

The touch probe detection is already activated after reversing to the travel range limit switch, i.e. the home position may be set to the travel range limit switch.

- We therefore recommend to set a target position ([C02643](#)) unequal to the home position ([C02642](#)), in order to reenble the activated limit switch. Otherwise, the positioning process to the target position may be aborted by the basic function "[Limiter](#)" (see status signal *HM\_dnState*).
- If the touch probe detection is to be activated after the travel range limit switch has been left, we recommend to use the DS402 homing methods 1 or 2. ▶ [Overview of DS402 homing modes](#) (📖 445)



## Mode 12: positive direction to limit switch

**Procedure:**


1. Movement in positive direction with profile data set 1.
2. Positive edge of the travel range limit switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

**Note!**

The load mechanics is able to leave the travel range limit switch. It is then travelled back to the home position which has been set with the positive edge of the travel range limit switch.

- The mechanics may possibly stop on an activated limit switch.
- Therefore it is recommended to set a target position ([C02643](#)) that is unequal to the home position ([C02642](#)) to release the activated limit switch again.

#### Mode 13: negative direction to limit switch



#### Procedure:


1. Movement in negative direction with profile data set 1.
2. Positive edge of the travel range limit switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").




#### Note!

The load mechanics is able to leave the travel range limit switch. It is then travelled back to the home position which has been set with the positive edge of the travel range limit switch.

- The mechanics may possibly stop on an activated limit switch.
- Therefore it is recommended to set a target position ([C02643](#)) that is unequal to the home position ([C02642](#)) to release the activated limit switch again.

**Mode 14: positive direction to torque limit****Procedure:**

1. Movement in positive direction with reduced torque and profile data set 1.
2. The reference is set if the two following conditions for the time set in [C02650](#) are fulfilled at the same time:
  - The current speed is lower than the threshold for standstill detection set in [C00019](#).
  - Current torque is greater than the torque limit set in [C02649](#) ("Homing to end stop").
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

**Mode 15: negative direction to torque limit****Procedure:**


1. Movement in negative direction with reduced torque and profile data set 1.
2. The reference is set if the two following conditions for the time set in [C02650](#) are fulfilled at the same time:
  - The current speed is lower than the threshold for standstill detection set in [C00019](#).
  - Current torque is greater than the torque limit set in [C02649](#) ("Homing to end stop").
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing

Mode 100: Set reference directly



During the drive is at standstill, the measuring system is set by means of the home position parameterised in [C02642](#).

## 11.6.4 Overview of DS402 homing modes

This function extension is available from software version V3.0!

In addition to the homing modes described in the previous subchapter "[Overview of the Lenze homing modes](#)", from software version V3.0 also the homing modes described in the following can be selected for a homing in [C02640](#), according to the DS402 device profile.

DS402 homing method	Evaluated signals/sensors			Reference switch at <i>HM_bHomingMark</i>
	Touch probe sensor/ encoder zero pulse	Travel range limit switch		
		Negative limit switch	Positive limit switch	
01	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
02	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
03	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
04	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
05	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
06	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
07	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
08	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
09	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
10	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
13	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
14	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
15	Reserved: no homing is executed.			
16	Reserved: no homing is executed.			
17		<input checked="" type="checkbox"/>		
18			<input checked="" type="checkbox"/>	
19				<input checked="" type="checkbox"/>
20				<input checked="" type="checkbox"/>
21				<input checked="" type="checkbox"/>
22				<input checked="" type="checkbox"/>
23			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
24			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
25			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
26			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
27		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
28		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
29		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
30		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
31	Reserved: no homing is executed.			
32	Reserved: no homing is executed.			
33	<input checked="" type="checkbox"/>			
34	<input checked="" type="checkbox"/>			
35	Direct reference setting.			

The switches/sensors are evaluated via the following internal interfaces:

Switch/sensor	Internal interface for digital input signal
Touch probe sensor	<i>DIGIN_bIn1 ... DIGIN_bIn8</i> <ul style="list-style-type: none"><li>Alternatively the motor encoder or position encoder zero pulse can be evaluated.</li></ul> <a href="#">▶ Touch probe interface configuration (📖 429)</a>
Positive travel range limit switch	<i>LIM_bLimitSwitchPositive</i> (basic function " <a href="#">"Limiter"</a> ")
Negative travel range limit switch	<i>LIM_bLimitSwitchNegative</i> (basic function " <a href="#">"Limiter"</a> ")
Reference switch	<i>HM_bHomingMark</i> (basic function " <a href="#">"Homing"</a> ")



#### Note!

##### Profile data set change-over

For the reference search, two profile data sets with different speeds and accelerations can be parameterised. In this way, the homing time can be reduced and at the same time the accuracy can be increased.

▶ [Profile data set change-over \(📖 427\)](#)

The following process descriptions give information about the time the change-over to the profile data set 2 takes place in the corresponding homing mode.

If the speed 2 ([C02646](#)) is set to "0" (Lenze setting), no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.



#### Note!


##### Drive behaviour after setting the reference

From software version V4.0 onwards, [C02641](#) serves to parameterise the drive behaviour after setting the home position.

▶ [Drive behaviour after setting the home position \(📖 426\)](#)

In the Lenze setting ([C02641](#) = "0"), the drive traverses to the absolute target position set in [C02643](#) similarly to the behaviour known from the previous versions.

## Mode 1001: DS402 homing method 01

**Procedure:**


1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch and change to profile data set 2.
3. Negative edge of the travel range limit switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing

Mode 1002: DS402 homing method 02




## Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch and change to profile data set 2.
3. Negative edge of the travel range limit switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").



## Mode 1003: DS402 homing method 03



### Procedures:

Case 1:

Axis has not yet activated the reference switch:

1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. Negative edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:


1. Movement in negative direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing

Mode 1004: DS402 homing method 04



## Procedures:


Case 1: Axis has not yet activated the reference switch:

1. Movement in positive direction with profile data set 1.
2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1005: DS402 homing method 05



### Procedures:

Case 1:

Axis has not yet activated the reference switch:


1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. Negative edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


#### Mode 1006: DS402 homing method 06



#### Procedures:

- Case 1: Axis has not yet activated the reference switch:
1. Movement in negative direction with profile data set 1.
  2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
  3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
  4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis already stands on the reference switch:
1. Movement in positive direction with profile data set 2.
  2. Reversing with negative edge of the reference switch.
  3. Positive edge of the reference switch activates touch probe detection.
  4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
  5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1007: DS402 homing method 07



### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Negative edge of the reference switch activates touch probe detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. Negative edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration


## Basic drive functions

### Homing

Case 3: Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1008: DS402 homing method 08



#### Procedures:


Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Reversing with negative edge of the reference switch.
5. Positive edge of the reference switch activates touch probe detection.
6. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
7. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
  2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
  3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
  4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

- Case 3: Axis already stands on the reference switch:
1. Movement in negative direction with profile data set 2.
  2. Reversing with negative edge of the reference switch.
  3. Positive edge of the reference switch activates touch probe detection.
  4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
  5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1009: DS402 homing method 09



#### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis first activates the reference switch while moving towards the limit switch:


1. Movement in positive direction with profile data set 1.
2. Positive edge of the reference switch activates profile data set 2.
3. Reversing with negative edge of the reference switch.
4. Positive edge of the reference switch activates touch probe detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").



## Mode 1010: DS402 homing method 10



### Procedures:

Case 1:

Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Reversing with positive edge of the reference switch and change to profile data set 2.
4. Negative edge of the reference switch activates touch probe detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis first activates the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Negative edge of the reference switch activates touch probe detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration


Basic drive functions

Homing

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1011: DS402 homing method 11



## Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Negative edge of the reference switch activates touch probe detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis first activates the reference switch while moving towards the limit switch:


1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. Negative edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3:

Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1012: DS402 homing method 12



#### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Reversing with negative edge of the reference switch.
5. Positive edge of the reference switch activates touch probe detection.
6. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
7. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1013: DS402 homing method 13



### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Positive edge of the reference switch activates profile data set 2.
3. Reversing with negative edge of the reference switch.
4. Positive edge of the reference switch activates touch probe detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration


## Basic drive functions

### Homing

Case 3: Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1014: DS402 homing method 14



#### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Reversing with positive edge of the reference switch and change to profile data set 2.
4. Negative edge of the reference switch activates touch probe detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
  2. Positive edge of the reference switch activates profile data set 2.
  3. Negative edge of the reference switch activates touch probe detection.
  4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
  5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis already stands on the reference switch:
1. Movement in negative direction with profile data set 2.
  2. Negative edge of the reference switch activates touch probe detection.
  3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
  4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

**Mode 1015: DS402 homing method 15**

Reserved: no homing is executed.

**Mode 1016: DS402 homing method 16**


Reserved: no homing is executed.

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing


## Mode 1017: DS402 homing method 17



### Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch and change to profile data set 2.
3. The following negative edge of the travel range limit switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1018: DS402 homing method 18




### Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch and change to profile data set 2.
3. The following negative edge of the travel range limit switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").



## Mode 1019: DS402 homing method 19

**Procedures:**

Case 1:

Axis has not yet activated the reference switch:


1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. The following negative edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. The following negative edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

#### Mode 1020: DS402 homing method 20



#### Procedures:

Case 1:

Axis has not yet activated the reference switch:


1. Movement in positive direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1021: DS402 homing method 21

**Procedures:**

Case 1: Axis has not yet activated the reference switch:

1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. The following negative edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis already stands on the reference switch:


1. Movement in positive direction with profile data set 2.
2. The following negative edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing

Mode 1022: DS402 homing method 22



## Procedures:

Case 1:

Axis has not yet activated the reference switch:


1. Movement in negative direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1023: DS402 homing method 23



### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. The following negative edge of the reference switch sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. The following negative edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. The following negative edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

#### Mode 1024: DS402 homing method 24



#### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Reversing with negative edge of the reference switch.
5. The following positive edge of the reference switch sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1025: DS402 homing method 25



### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

#### Mode 1026: DS402 homing method 26



#### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Reversing with positive edge of the reference switch and change to profile data set 2.
4. The following negative edge of the reference switch sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis first activates the reference switch while moving towards the limit switch:


1. Movement in positive direction with profile data set 1.
2. Positive edge of the reference switch activates profile data set 2.
3. The following negative edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. The following negative edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").



## Mode 1027: DS402 homing method 27



### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. The following negative edge of the reference switch sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change to profile data set 2.
3. The following negative edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. The following negative edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

#### Mode 1028: DS402 homing method 28



#### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Reversing with negative edge of the reference switch.
5. The following positive edge of the reference switch sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1029: DS402 homing method 29



### Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in negative direction with profile data set 1.
2. Positive edge of the reference switch activates profile data set 2.
3. Reversing with negative edge of the reference switch.
4. The following positive edge of the reference switch sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis already stands on the reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

#### Mode 1030: DS402 homing method 30



#### Procedures:


- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
  2. Reversing to negative travel range limit switch.
  3. Reversing with positive edge of the reference switch and change to profile data set 2.
  4. The following negative edge of the reference switch sets the reference.
  5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
  2. Positive edge of the reference switch activates profile data set 2.
  3. The following negative edge of the reference switch sets the reference.
  4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis already stands on the reference switch:
1. Movement in negative direction with profile data set 2.
  2. The following negative edge of the reference switch sets the reference.
  3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

**Mode 1031: DS402 homing method 31**

Reserved: no homing is executed.

**Mode 1032: DS402 homing method 32**

Reserved: no homing is executed.

**Mode 1033: DS402 homing method 33****Procedure:**


1. Movement in negative direction with profile data set 1 and activation of the touch probe detection.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing


## Mode 1034: DS402 homing method 34



### Procedure:

1. Movement in positive direction with profile data set 1 and activation of the touch probe detection.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

## Mode 1035: DS402 homing method 35



Direct reference setting.

### 11.6.5 Execute homing

#### Requirements

- ▶ The controller is in the "Operation" device state.
- ▶ The basic function "Homing" is part of the active application.
- ▶ No other basic function is active.

#### Activation

To request the control via the basic function, the *HM\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Homing active" function state is effected and homing can be carried out via the control inputs.
- ▶ A successful change to the "Homing active" function state is displayed by a TRUE signal at the *HM\_bEnabled* status output.

#### Deactivation

When the *HM\_bEnable* enable input is reset to FALSE, an active homing is stopped, i.e. the control inputs for homing are inhibited and the drive is braked to standstill within the deceleration time for stop.

- ▶ The status output *HM\_bEnabled* is reset to FALSE and a change-over from the active "Homing active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

#### 11.6.5.1 Starting reference search/setting the reference directly

By setting the *HM\_bActivateHoming* control input to TRUE, the reference search in the selected homing mode is started.

- ▶ During reference search, the *HM\_bActive* status output is set to TRUE.
- ▶ By setting the status output *HM\_bHomePosAvailable* to TRUE, it is already signalled during the reference search that the home position has been found. Depending on the homing mode selected, the drive traverses further on to the target position set in [C02643](#).
- ▶ When the reference search is completed, the *HM\_bActive* status output is reset to FALSE and the *HM\_bDone* status output is set to TRUE.



#### Note!

In the homing mode "100: Set reference directly" no reference search is started, but the home position set in [C02642](#) is directly accepted.

#### 11.6.5.2 Loading home position via input

By setting the control input *HM\_bLoadHomePos* to TRUE, the "Tool position" that is pending at input *HM\_dnHomePos\_p* is manually accepted as home position during the drive is at standstill. This is also possible if the controller is inhibited.

- ▶ The *HM\_bDone* status output is set to TRUE for one cycle.
- ▶ The *HM\_bHomePosAvailable* status output is set to TRUE.



#### Note!

**For the encoderless motor control types (from software version V3.0) the following applies:**

If V/f control or sensorless vector control has been selected, this function is only effective if the position controller has been selected for the position control ([C02570](#) = "2: position controller active").

**For the encoderless motor control types (from software version V5.0) the following applies:**

If the V/f control or sensorless vector control is selected, this function can be activated irrespective of the use of the position controller.



### 11.6.5.3 Resetting home position

By setting the control input *HM\_bResetHomePos* to TRUE, the "Home position known" status can be reset.

- ▶ The status outputs *HM\_bDone* and *HM\_bHomePosAvailable* are reset to FALSE.



#### Note!

**For the encoderless motor control types (from software version V3.0) the following applies:**

If V/f control or sensorless vector control has been selected, this function is only effective if the position controller has also been selected for the position control ([C02570](#) = "2: position controller active").

**For the encoderless motor control types (from software version V5.0) the following applies:**

If the V/f control or sensorless vector control is selected, this function can be activated irrespective of the use of the position controller.

#### 11.7 Positioning

The basic function "Positioning" provides the functions for executing the (travel) profiles and supports an "override" of speed and acceleration.

- ▶ A profile describes a motion request which can be implemented by this basic function into a rotary motion.
- ▶ A profile is described via the following profile parameters: Mode (type of positioning), position, speed, acceleration, deceleration, S-ramp time, final speed, standard sequence profile, TP sequence profile, TP window starting and end position and touch probe signal source(s).



#### Note!

For positioning, setpoint speeds greater than 30000 rpm are not possible. The speeds defined for these basic function are internally limited to 30000 rpm.

If the basic function is activated for a speed greater than 30000 rpm (e. g. if the basic function "Speed follower" is replaced), the internal limitation of the speed setpoint causes a speed step.


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 383)

**For the encoderless motor control types (from software version V3.0) the following applies:**

If no position controller has been selected for the position control in case of V/f control or sensorless vector control ([C02570](#) = "1: Phase controller is active"), positioning is only executed via the speed profile resulting from the profile parameters. Because of this, the target positions set will only "roughly" be reached.

## 11.7.1 Internal interfaces | "LS\_Positioner" system block

The **LS\_Positioner** system block provides the internal interfaces for the basic function "Positioning" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
POS_bEnable  <small>C02679/1   BOOL</small>	Requesting control via the basic function  TRUE If no other basic function is active, a change-over to the "Positioning active" function state is effected and positioning can be carried out via the control inputs.
	TRUE↔FALSE Active positioning is stopped, i. e. a change-over from the active "Positioning active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
POS_bStart  <small>C02679/2   BOOL</small>	Starting positioning  FALSE↗TRUE The profile <i>POS_ProfileData</i> is executed.
	FALSE↗TRUE (once again) "Restart" <ul style="list-style-type: none"> <li>During an active positioning process, another profile can be specified via the input <i>POS_ProfileData</i> which is executed after restart.</li> <li>Distances of a relative positioning that have already been covered are <u>not</u> taken into consideration.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Basic drive functions

### Positioning

Identifier DIS code   data type	Information/possible settings
POS_bAbort <a href="#">C02679/3</a>   BOOL	Aborting or interrupting positioning
	FALSE $\nrightarrow$ TRUE The current profile is not completed but braked to standstill with the deceleration defined in the profile data.
	TRUE A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is inhibited.
POS_bRestart <a href="#">C02679/4</a>   BOOL	Continue interrupted positioning • Only possible if <i>POS_bAbort</i> has been reset from TRUE to FALSE.
	TRUE The positioning interrupted before via <i>POS_bAbort</i> is completed. • Distances of a relative positioning that have already been covered are taken into consideration.
	FALSE $\nrightarrow$ TRUE (once again) "Restart" • During an active positioning process, another profile can be specified via the input <i>POS_ProfileData</i> which is executed after restart. • Distances of a relative positioning that have already been covered are taken into consideration.
POS_ProfileData	Pointer to the profile to be executed in internal units (increments) • A profile linkage results from the fact that a pointer to the sequence profile is contained within the profile.
POS_bEnableOverride <a href="#">C02679/5</a>   BOOL	Activating override TRUE Override of the speed, acceleration, and deceleration is active.
POS_dnSpeedOverride_n <a href="#">C02677/1</a>   DINT	Value of speed override • Percentage multiplier for the current profile parameter "Speed". • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the speed defined in the profile. • For values $\leq 1\%$ the status bit 18 is set. • Values $\leq 0\%$ are set to $0\%$ internally and lead to the standstill of the drive.
POS_dnAccOverride_n <a href="#">C02677/2</a>   DINT	Value for acceleration override • Percentage multiplier for the current profile parameter "Acceleration". • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the acceleration defined in the profile. • For values $\leq 1\%$ the status bit 19 is set. • Values $\leq 0\%$ are internally set to $0\%$ ("no acceleration").
POS_dnDecOverride_n <a href="#">C02677/3</a>   DINT From V5.0	Value for deceleration override • Percentage multiplier for the current profile parameter "Deceleration". • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the acceleration defined in the profile. • For values $\leq 1\%$ the status bit 19 is set. • Values $\leq 0\%$ are internally set to $0\%$ ("no deceleration").
POS_bDisableTP <a href="#">C02679/6</a>   BOOL	Deactivating touch probe positioning
	TRUE Detected touch probes are ignored. There is no automatic change-over to the TP sequence profile defined in the profile data.

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning	
POS_dnState  <a href="#">C02675</a>   DINT	Status (bit coded) <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul>	
	Bit 1 Positioning is active.	
	Bit 2 Positioning is completed (all profiles have been executed).	
	Bit 3 Acceleration/deceleration phase is active.	
	Bit 4 Actual position in the target <ul style="list-style-type: none"> <li>The actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in <a href="#">C02670</a>.</li> </ul>	
	Bit 5 CCW rotation is active.	
	Bit 6 Set position reached (in case of sequence profiles the drive continues to travel).	
	Bit 10 Zero crossing in the positioning mode "modulo".	
	Bit 11 Positioning cannot be continued.	
	Bit 12 Drive in the target (actual position <u>and</u> set position in the target). <ul style="list-style-type: none"> <li>This status is available from software version V5.0.</li> </ul>	
	Bit 15 Fault in basic function active (group signal).	
	Bit 16 Positioning is aborted.	
	Bit 17 Reversing phase is active.	
	Bit 18 Speed override ≤1 %	
	Bit 19 Acceleration or deceleration override ≤ 1 %	
	Bit 20 Position is limited by basic function " <a href="#">Limiter</a> ".	
	Bit 21 Profile data are limited by basic function " <a href="#">Limiter</a> ".	
	Bit 22 Direction is inhibited by basic function " <a href="#">Limiter</a> ".	
	Bit 23 Abort by basic function " <a href="#">Limiter</a> ".	
	Bit 24 Home position is not known.	
	Bit 25 Stopping is active. <ul style="list-style-type: none"> <li>Basic function is enabled for the first time but no positioning has been requested / is active yet.</li> </ul>	
	Bit 26 Cycle is not known.	
	Bit 27 Invalid positioning mode.	
	Bit 28 Invalid change of the positioning mode.	
	Bit 29 Profile data are not plausible or incorrect.	
	Bit 30 Profile generation error.	
	POS_bEnabled  <a href="#">C02679/7</a>   BOOL	Status signal "Basic function is enabled"
		TRUE Positioning via the control inputs is possible. <ul style="list-style-type: none"> <li>The <i>POS_bEnable</i> enable input is set to TRUE and the controller is in the "Positioning active" function state.</li> </ul>
	POS_bActive  <a href="#">C02679/8</a>   BOOL	Status signal "Basic function is active"
		TRUE Positioning is active (the drive axis is moving).
	POS_bDone  <a href="#">C02679/9</a>   BOOL	Status signal "Basic function is ready"
TRUE Positioning is completed. <ul style="list-style-type: none"> <li>The profile is executed and no sequence profile is defined.</li> </ul>		

# 9400 HighLine | Parameter setting & configuration

## Basic drive functions

### Positioning

Identifier <small>DIS code   data type</small>	Value/meaning								
POS_blnTarget <a href="#">C02679/10</a>   BOOL	Status signal "Setpoint has reached target position" <table border="1"> <tr> <td>FALSE</td> <td>Positioning is still active or has been aborted.</td> </tr> <tr> <td>TRUE</td> <td>The current position setpoint has reached the target position.</td> </tr> </table>	FALSE	Positioning is still active or has been aborted.	TRUE	The current position setpoint has reached the target position.				
FALSE	Positioning is still active or has been aborted.								
TRUE	The current position setpoint has reached the target position.								
POS_bActPosInTarget <a href="#">C02679/11</a>   BOOL	Status signal "Actual position in the target" <ul style="list-style-type: none"> <li>In case of sequence profiles: the target position of the last profile to be traversed.</li> </ul> <p>▶ <a href="#">Actual value-based evaluation "Target position reached"</a> (□ 488)</p> <table border="1"> <tr> <td>FALSE</td> <td>Positioning is still active or has been aborted.</td> </tr> <tr> <td>TRUE</td> <td>The current actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in <a href="#">C02670</a>.</td> </tr> </table>	FALSE	Positioning is still active or has been aborted.	TRUE	The current actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in <a href="#">C02670</a> .				
FALSE	Positioning is still active or has been aborted.								
TRUE	The current actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in <a href="#">C02670</a> .								
POS_bDriveInTarget <a href="#">C02679/12</a>   BOOL <small>From V5.0</small>	Status signal "Drive in the target" <ul style="list-style-type: none"> <li>In case of sequence profiles: the target position of the last profile to be traversed.</li> <li>The status is also output if the basic function "Positioning" is deactivated.</li> </ul> <p>▶ <a href="#">Actual value- and setpoint-based evaluation "Drive in the target"</a> (□ 489)</p> <table border="1"> <tr> <td>FALSE</td> <td>Positioning is still active or has been aborted.</td> </tr> <tr> <td>FALSE↗TRUE</td> <td>The current actual position value of the drive has reached the target position within the profile to be traversed last within the tolerance window set in <a href="#">C02671</a>. At this time, the current position setpoint has already reached the target position. <ul style="list-style-type: none"> <li>In the case of positioning processes with sequence profiles, the output is only set to TRUE after the last profile to be traversed.</li> </ul> </td> </tr> <tr> <td>TRUE↘FALSE</td> <td>The current actual position value of the drive has exited the tolerance and hysteresis window set in <a href="#">C02671</a> and <a href="#">C02672</a> again after a positioning process has been completed.</td> </tr> <tr> <td>FALSE↗TRUE (once again)</td> <td>If <a href="#">C02673</a> = "1", a modulo evaluation is carried out in all cycles (Lenze setting): <ul style="list-style-type: none"> <li>The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in an optional modulo cycle</u> again.</li> </ul> If <a href="#">C02673</a> = "0", a modulo evaluation is only carried out in the modulo cycle of the target setpoint: <ul style="list-style-type: none"> <li>The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in the same modulo cycle</u> again.</li> </ul> </td> </tr> </table>	FALSE	Positioning is still active or has been aborted.	FALSE↗TRUE	The current actual position value of the drive has reached the target position within the profile to be traversed last within the tolerance window set in <a href="#">C02671</a> . At this time, the current position setpoint has already reached the target position. <ul style="list-style-type: none"> <li>In the case of positioning processes with sequence profiles, the output is only set to TRUE after the last profile to be traversed.</li> </ul>	TRUE↘FALSE	The current actual position value of the drive has exited the tolerance and hysteresis window set in <a href="#">C02671</a> and <a href="#">C02672</a> again after a positioning process has been completed.	FALSE↗TRUE (once again)	If <a href="#">C02673</a> = "1", a modulo evaluation is carried out in all cycles (Lenze setting): <ul style="list-style-type: none"> <li>The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in an optional modulo cycle</u> again.</li> </ul> If <a href="#">C02673</a> = "0", a modulo evaluation is only carried out in the modulo cycle of the target setpoint: <ul style="list-style-type: none"> <li>The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in the same modulo cycle</u> again.</li> </ul>
FALSE	Positioning is still active or has been aborted.								
FALSE↗TRUE	The current actual position value of the drive has reached the target position within the profile to be traversed last within the tolerance window set in <a href="#">C02671</a> . At this time, the current position setpoint has already reached the target position. <ul style="list-style-type: none"> <li>In the case of positioning processes with sequence profiles, the output is only set to TRUE after the last profile to be traversed.</li> </ul>								
TRUE↘FALSE	The current actual position value of the drive has exited the tolerance and hysteresis window set in <a href="#">C02671</a> and <a href="#">C02672</a> again after a positioning process has been completed.								
FALSE↗TRUE (once again)	If <a href="#">C02673</a> = "1", a modulo evaluation is carried out in all cycles (Lenze setting): <ul style="list-style-type: none"> <li>The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in an optional modulo cycle</u> again.</li> </ul> If <a href="#">C02673</a> = "0", a modulo evaluation is only carried out in the modulo cycle of the target setpoint: <ul style="list-style-type: none"> <li>The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in the same modulo cycle</u> again.</li> </ul>								
POS_dnSetPos_p <a href="#">C02678/1</a>   DINT	Current position setpoint in [increments] <ul style="list-style-type: none"> <li>Reference point is the home position.</li> </ul>								
POS_dnProfileTarget_p <a href="#">C02678/2</a>   DINT	Target position of the current profile in [increments] <ul style="list-style-type: none"> <li>Reference point is the home position.</li> </ul>								
POS_dnProfileSpeed_s <a href="#">C02676</a>   DINT	Current setpoint speed of the current profile as speed in [rpm] <ul style="list-style-type: none"> <li>Taking a speed override into consideration.</li> </ul>								
POS_dwActualProfileNumber <a href="#">C02674</a>   DWORD	Profile number (1 .... 100) of the current profile								

Identifier <small>DIS code   data type</small>	Value/meaning
POS_dnSetPosRelative_p <small>From V5.0</small> <a href="#">C02678/3</a>   DINT	Current relative position setpoint of the current positioning in [increments] <ul style="list-style-type: none"> <li>• The value is also output if the basic function "Positioning" is deactivated.</li> <li>• Reference point is the starting position of the current profile.</li> <li>• After a positioning process has been completed, the output keeps the last relative value of the setpoint profile.</li> <li>• The output is reset when a new positioning is started, or when the home position is set.</li> </ul>
POS_dnActPosRelative_p <small>From V5.0</small> <a href="#">C02678/4</a>   DINT	Current relative actual position value of the current positioning in [increments] <ul style="list-style-type: none"> <li>• The value is also output if the basic function "Positioning" is deactivated.</li> <li>• Reference point is the starting position of the current profile.</li> <li>• The output follows the current position even if the basic function "Positioning" is no longer active.</li> <li>• The output is reset when a new positioning is started, or when the home position is set.</li> </ul>

#### 11.7.1.1 Possibilities for the selection of the profile

For specifying as well as storing and managing (travel) profiles, the following function blocks are available:

Function block	Function
L_PosPositionerTable	...serves to store and manage up to 100 (travel) profiles and to "Teach" positions, speeds, accelerations/decelerations and S-ramp times. <ul style="list-style-type: none"> <li>• A further important task of this FB is the conversion of the table values according to the preselected scaling in the LS_DriveInterface SB.</li> </ul>
L_PosProfileTable	...serves to store and manage up to four (travel) profiles and allows the "teaching" of target positions. <ul style="list-style-type: none"> <li>• In contrast to the FB L_PosPositionerTable this FB does not use any variable tables but the data of the profile parameters are entered directly into the assigned codes.</li> <li>• The position at the input <i>dnExtPos_p</i> is used as target position as a further specific feature for the selection of profile no. 1.</li> </ul>
L_PosProfileInterface	...provides a profile data set for the LS_Positioner SB.

#### Related topics:

▶ [Setting the S-ramp time](#) (📖 385)

#### 11.7.2 Parameter setting

Setting parameters is not required for the basic function "Positioning".

- ▶ After activating the function, the profile is executed which has been transferred from the application to the basic function via the input *POS\_ProfileData*.
- ▶ For profiles with touch probe positioning mode (residual path positioning) touch probe is detected implicitly.

#### Related topics:

- ▶ [Setting the S-ramp time](#) (📖 385)

#### 11.7.2.1 Actual value-based evaluation "Target position reached"

An actual value-based evaluation on whether the drive has reached the target position can be carried out by means of the output *POS\_bActPosInTarget* and parameterisation of [C02670](#).

- ▶ The output *POS\_bActPosInTarget* is set to TRUE if the current actual position value of the drive has reached the target position of the profile to be traversed last within the tolerance window set in [C02670](#).
  - Hence, for sequence profiles the evaluation is only valid for the target position of the last profile.
- ▶ If [C02670](#) is set to "0" (Lenze setting), the evaluation is setpoint-based and the signal at the *POS\_bActPosInTarget* output corresponds to the *POS\_bDone* signal.



#### Tip!

In many cases the signal *POS\_bActPosInTarget* only has to be evaluated if the setpoint has also reached the target position. This can for instance be implemented in the function block editor by a logic "AND" operation with the signal *POS\_bDone*.

From software version V5.0 it is displayed whether the set position and the actual position are in the target via the output *POS\_bDriveInTarget*. ▶ [Actual value- and setpoint-based evaluation "Drive in the target"](#) (📖 489)



### 11.7.2.2 Actual value- and setpoint-based evaluation "Drive in the target"

This function extension is available from software version V5.0 onwards!

An actual value- and setpoint-based evaluation on whether the drive is in the target can be carried out by means of the output *POS\_bDriveInTarget* and parameterisation of [C02671](#), [C02672](#), and [C02673](#).

- ▶ The output *POS\_bDriveInTarget* is set to TRUE if the current actual position value of the drive has reached the target position of the profile to be traversed last within the tolerance window set in [C02671](#).
  - At this time, the current setpoint value has already reached the target position, i. e. the actual position and set position are in the target.
  - In the case of positioning processes with sequence profiles, the output is only set to TRUE after the last profile to be traversed.
- ▶ The output *POS\_bDriveInTarget* is reset to FALSE if the current actual position value of the drive has exited the tolerance and hysteresis window set in [C02671](#) and [C02672](#) again after a positioning process has been completed.
- ▶ How the modulo evaluation is to be carried out if the actual position value enters the tolerance and hysteresis window again can be set in [C02673](#):
  - Modulo evaluation in all cycles (Lenze setting):  
The output *POS\_bDriveInTarget* is set to TRUE again if the current actual position value of the drive enters the tolerance window again in an optional modulo cycle.
  - Modulo evaluation only in the modulo cycle of the target setpoint:  
The output *POS\_bDriveInTarget* is set to TRUE again if the current actual position value of the drive enters the tolerance window again in the same modulo cycle.
- ▶ A new FALSE↗TRUE edge at the output *POS\_bDriveInTarget* after a positioning process has been completed can for instance occur when the basic function is deactivated afterwards, and if the drive axis is skewed so that the tolerance and hysteresis window is exited and then the tolerance range is entered again.

**Short overview of the parameters for the actual value- and setpoint-based evaluation:**

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C02671</a>	Tolerance for target position	2.0000	Unit
<a href="#">C02672</a>	Hysteresis for target position	1.0000	Unit
<a href="#">C02673</a>	Activate DriveInTarget Modulo	All cycles	

#### 11.7.3 Carrying out positioning

##### Requirements

- ▶ The controller is in the "Operation" device state.
- ▶ The basic function "Positioning" is part of the active application.
- ▶ No other basic function is active.

##### Activation

To request the control via the basic function, the *POS\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Positioning active" function state is effected and positioning can be carried out via the control inputs.
- ▶ A successful change to the function state "Positioning active" is displayed by a TRUE signal at the *POS\_bEnabled* status output.

##### Deactivation

When the *POS\_bEnable* enable input is reset to FALSE, an active positioning is stopped, i.e. the control inputs for positioning are inhibited and the drive is braked to standstill within the deceleration time for stop.

- ▶ The status output *POS\_bEnabled* is reset to FALSE and a change-over from the active "Positioning active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

## 11.7.3.1 Starting positioning

By setting the control input *POS\_bStart* to TRUE, the positioning process is started.

- ▶ The (travel) profile that has been transferred to the basic function via the input *POS\_ProfileData* is traversed.

## 11.7.3.2 Aborting/interrupting positioning

By setting the control input *POS\_bAbort* to TRUE, the active positioning can be aborted or interrupted.

- ▶ The current profile is not completed but braked to standstill with the deceleration defined in the profile data.
- ▶ If the control input *POS\_bAbort* remains on TRUE, a restart or the continuation of an interrupted positioning is inhibited.
- ▶ After resetting the control input *POS\_bAbort* to FALSE, a restart or the continuation of an interrupted positioning process is possible again.

#### 11.7.3.3 Continue interrupted positioning

By setting the control input *POS\_bRestart* to TRUE, an interrupted positioning process can be continued if the control input *POS\_bAbort* has been reset to FALSE before.

- ▶ Distances of a relative positioning that have already been covered are taken into consideration.
- ▶ If the continuation of a positioning process via the input *POS\_bRestart* is not possible, this is displayed via bit 11 of the status output *POS\_dnState*.

The following applies to software versions lower than V3.0:

- ▶ If during an active or cancelled positioning process a change-over to the states "Quick stop active", "Drive is stopped", or "Drive at standstill" is effected, it is also possible to continue a positioning process via *POS\_bRestart*, taking the distance that has already been covered into consideration.

The following applies from software version V3.0:

- ▶ If during an active or cancelled positioning process a change-over is effected (e. g. by activating a quick stop or inhibiting the controller), it is also possible to continue a positioning process via *POS\_bRestart*, taking the distance that has already been covered into consideration.
- ▶ However, after a homing has been carried out again, or after the following machine parameters have been changed, a continuation of an interrupted positioning process via the control input *POS\_bRestart* is no longer possible:
  - Encoder resolution ([C00100](#))
  - Position encoder selection ([C00490](#)), motor encoder selection ([C00495](#))
  - Gearbox factors ([C02520](#), [C02521](#), [C02522](#), [C02523](#))
  - Feed constant ([C02524](#))
  - Motor mounting direction ([C02527](#)), position encoder mounting direction ([C02529](#))
  - Traversing range ([C02528](#))
  - Cycle ([C02536](#)) for modulo traversing range
  - Position control structure ([C02570](#))

#### 11.7.3.4 Activating override

"Override" is the change of profile parameters and their acceptance during the positioning process.

- ▶ When the input *POS\_bEnableOverride* is set to TRUE, a speed and acceleration override occurs according to the override values applied to the inputs *POS\_dnSpeedOverride\_n* and *POS\_dnAccOverride\_n*.
  - The override values represent percentage multipliers with regard to the current profile parameters for speed and acceleration.
  - For override values  $\leq 1\%$  a status bit is set.
  - Override values  $\leq 0\%$  are internally set to 0 %.
  - Changes of the override values are accepted in each cycle.



#### Note!

The online change of speed and acceleration is effective from the profile start to the beginning of the deceleration phase. Thus, the deceleration phase cannot be changed via an override!

- If the override value for speed is 0 %, the drive is braked to standstill.
- If the override for the acceleration is 0 %, there is no acceleration.

- ▶ From software version V5.0 also a deceleration override via the input *POS\_dnDecOverride\_n* can be carried out if the input *POS\_bEnableOverride* is set to TRUE.

The deceleration override is effective:

- During the deceleration phase of a profile
- During an abort process
- In the case of a speed change-over from a high to a low speed within a profile (e. g. if the speed override is used)



#### Note!

If the override value for deceleration is 0 %, there is no deceleration, i. e. the drive does not come to a standstill!

- ▶ If the input *POS\_bEnableOverride* is reset to FALSE again, the speeds, accelerations, and decelerations are run again, which have been defined via the profile parameters. There is an immediate acceleration from the override speed to the speed set in the profile.

#### 11.8 Position follower

This basic function is used as setpoint interface for position-controlled drives.

- ▶ The specified position setpoint can either refer to the encoder on the motor side or to the (position) encoder used additionally to detect the machine position. The selection of the encoder configuration serves to adapt the internal control structure accordingly.
- ▶ Instead of a position setpoint alternatively also a speed setpoint can be specified by an according selection in [C02680](#); the set position is then calculated by the integration of the speed setpoint on the basis of the current actual position (relative positioning).
- ▶ If the direction of rotation of the motor has to be inverted due to the mounting position of the motor or the gearbox ratio available, the use of the control signals can be accordingly changed over by means of parameterisation.
- ▶ The speed feedforward control can also be executed with the position setpoint by a corresponding selection in [C02681](#). Then, the speed is calculated by differentiation of the position setpoint.



#### Stop!

If a limit switch is approached by means of the basic function "Position follower" and by this a fault with the "Quick stop by trouble" response is activated, always a set/actual adjustment of the position has to be carried out before the fault is acknowledged, as otherwise an uncontrolled motor movement may result after the fault is acknowledged!

▶ [Hardware limit positions \(limit switch\)](#) (📖 522)



#### Note!


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (📖 383)

**For the encoderless motor control types (from software version V3.0) the following applies:**

The basic function "Position follower" can only be activated for V/f control or sensorless vector control if the position controller has been selected for the position control ([C02570](#) = "2: position controller active").

## 11.8.1 Internal interfaces | "LS\_PositionFollower" system block

The **LS\_PositionFollower** system block provides the internal interfaces for the basic function "Position follower" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
PF_bEnable <a href="#">C02689/1</a>   BOOL	Requesting control via the basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Position follower active" function state is carried out, and the setpoints defined are accepted.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Position follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Position follower active" function state is carried out, and the setpoints defined are accepted.	TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Position follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
TRUE	If no other basic function is active, a change-over to the "Position follower active" function state is carried out, and the setpoints defined are accepted.				
TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Position follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.				
PF_dnPositionSet_p <a href="#">C02688/1</a>   DINT	Position setpoint in [increments]				
PF_dnSpeedAdd1_s <a href="#">C02686</a>   DINT	Speed feedforward control value in [rpm]				
PF_dnSpeedAdd2_n <a href="#">C02687/1</a>   DINT	Additional speed setpoint in [%] • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> )				
PF_dnAccAdd_x <a href="#">C02685</a>   DINT	Motor acceleration • For calculating the acceleration torque (for setting <a href="#">C00276</a> = "0"). • Selection as speed variation/time in [rpm/s]				
PF_dnTorqueAdd_n <a href="#">C02687/2</a>   DINT	Additive torque feedforward control value in [%] • 100 % ≙ motor reference torque (display in <a href="#">C00057/2</a> ).				

### Outputs

Identifier <small>DIS code   data type</small>	Value/meaning		
PF_bEnabled <a href="#">C02689/2</a>   BOOL	Status signal "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>The defined setpoints are accepted.</td> </tr> </table>	TRUE	The defined setpoints are accepted.
TRUE	The defined setpoints are accepted.		


# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Position follower



### 11.8.2 Signal flow



[11-1] Signal flow - position follower

## Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (🔗 590)

No.	Variable of the motor control	Meaning
(1)	Torque.dnTotalTorqueAdd	Additive torque feedforward control value
(2)	Torque.dnTorqueSetpoint	Torque setpoint
(3)	Position.dnActualLoadPos	Actual position
(4)	Position.dnPositionSetpoint	Position setpoint
(5)	Position.dnActualMotorPos	Current motor position
(6)	Position.dnContouringError	Following error
(7)	Speed.dnOutputPosCtrl	Output signal - phase controller
(8)	Speed.dnSpeedSetpoint	Speed setpoint
(9)	Speed.dnActualMotorSpeed	Current motor speed

## 11.8.3 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Position follower*
- ▶ Short overview of the parameters for the position follower:

Parameter	Information
<a href="#">C00050/1</a>	Speed setpoint 1 [rpm]
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00072</a>	Speed controller rate time
<a href="#">C00273/1</a>	Motor moment of inertia
<a href="#">C00273/2</a>	Load moment of inertia
<a href="#">C00275</a>	Signal source - speed setpoint
<a href="#">C00276</a>	Signal source - torque setpoint
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02520</a>	Gearbox factor numerator: Motor
<a href="#">C02521</a>	Gearbox factor denom.: Motor
<a href="#">C02522</a>	Gearbox factor num.: Pos. enc.
<a href="#">C02523</a>	Gearbox fac. denom.: Pos. enc.
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02550/1</a>	Position setpoint interpolat.
<a href="#">C02550/2</a>	Speed setpoint interpolat.
<a href="#">C02550/3</a>	Torque setpoint interpolat.
<a href="#">C02553</a>	Position controller gain
<a href="#">C02554</a>	Position controller reset time
<a href="#">C02555</a>	D component position controller
<a href="#">C02559</a>	Internal torque limit
<a href="#">C02680</a>	Source position setpoint
<a href="#">C02681</a>	Source add. speed

Highlighted in grey = display parameter

## 11.8.3.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the setpoints which may be transferred from a slower task.

- ▶ [C02550/1](#) = "1": The motor control follows the position setpoint in interpolated steps.
- ▶ [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- ▶ [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

## 11.8.3.2 Inversion of the direction of rotation

Depending on the motor mounting position, if required, the direction of rotation can be inverted:

- ▶ [C02527](#) = "0": Clockwise rotating motor  $\equiv$  positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise rotating motor  $\equiv$  positive machine direction.

### 11.8.4 Activating setpoint interface

#### Requirements

- ▶ The controller is in the "Operation" device state.
- ▶ The basic function "Position follower" is part of the active application.
- ▶ No other basic function is active.

#### Activation

To request the control via the basic function, the *PF\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Position follower active" function state is carried out. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- ▶ A successful change to the "Position follower active" function state is displayed by a TRUE signal at the status output *PF\_bEnabled*.



#### Stop!

The basic function does not take over the control of the drive from the current speed, but immediately with the setpoint defined, which may cause a jerk!

#### Deactivation

When the *PF\_bEnable* enable input is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- ▶ The status output *PF\_bEnabled* is reset to FALSE and a change-over from the active "Position follower active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

## 11.9 Speed follower

This basic function is used as setpoint interface for speed-controlled drives.

- ▶ The motor control is switched over automatically to speed control with torque limitation.
- ▶ If the direction of rotation of the motor has to be inverted due to the mounting position of the motor or the gearbox ratio available, the use of the control signals can be accordingly changed over by means of parameterisation.




### Note!

When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 383)

### 11.9.1 Internal interfaces | "LS\_SpeedFollower" system block

The **LS\_SpeedFollower** system block provides the internal interfaces for the basic function "Speed follower" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs


Identifier <small>DIS code   data type</small>	Information/possible settings				
SF_bEnable <small>C02695/1   BOOL</small>	Requesting control via the basic function				
	<table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the setpoints defined are accepted.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Speed follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the setpoints defined are accepted.	TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Speed follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
TRUE	If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the setpoints defined are accepted.				
TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Speed follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.				

Identifier <small>DIS code   data type</small>	Information/possible settings
SF_dnSpeedSet_n <a href="#">C02694/1</a>   DINT	Speed setpoint in [%] • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> )
SF_dnSpeedAdd_s <a href="#">C02693</a>   DINT	Additive speed setpoint in [rpm] • Without position control function.
SF_dnAccAdd_x <a href="#">C02692</a>   DINT	Motor acceleration • For calculating the acceleration torque (for setting <a href="#">C00276</a> = "0"). • Selection as speed variation/time in [rpm/s]
SF_dnTorqueAdd_n <a href="#">C02694/2</a>   DINT	Additive torque feedforward control value in [%] • 100 % ≙ motor reference torque (display in <a href="#">C00057/2</a> ).

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
SF_bEnabled <a href="#">C02695/2</a>   BOOL	Status signal "Basic function is enabled"
	TRUE   The defined setpoints are accepted.

#### 11.9.2 Signal flow



[11-2] Signal flow - speed follower

#### Internal variables of the motor control (oscilloscope signals)

► The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (📖 590)

No.	Variable of the motor control	Meaning
(1)	Torque.dnTotalTorqueAdd	Additive torque feedforward control value
(2)	Torque.dnTorqueSetpoint	Torque setpoint
(3)	Speed.dnTotalSpeedAdd	Additive speed setpoint
(4)	Speed.dnSpeedSetpoint	Speed setpoint
(5)	Speed.dnActualMotorSpeed	Current motor speed



## 11.9.3 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Speed follower*
- ▶ Short overview of the parameters for the speed follower:

Parameter	Information
<a href="#">C00050/1</a>	Speed setpoint 1
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00072</a>	Speed controller rate time
<a href="#">C00273/1</a>	Motor moment of inertia
<a href="#">C00273/2</a>	Load moment of inertia
<a href="#">C00276</a>	Signal source - torque setpoint
<a href="#">C00576</a>	Speed monitoring window
<a href="#">C00579</a>	Resp. to speed monitoring
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02520</a>	Gearbox factor numerator: Motor
<a href="#">C02521</a>	Gearbox factor denom.: Motor
<a href="#">C02522</a>	Gearbox factor num.: Pos. enc.
<a href="#">C02523</a>	Gearbox fac. denom.: Pos. enc.
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02531/3</a>	Effective gearbox factor (dec.)
<a href="#">C02550/2</a>	Speed setpoint interpolat.
<a href="#">C02550/3</a>	Torque setpoint interpolat.
<a href="#">C02570</a>	Position control structure
<a href="#">C02559</a>	Internal torque limit

Highlighted in grey = display parameter

## 11.9.3.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the speed and/or torque setpoints which may be transferred from a slower task.

- ▶ [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- ▶ [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

## 11.9.3.2 Inversion of the direction of rotation

Depending on the motor mounting position, if required, the direction of rotation can be inverted:

- ▶ [C02527](#) = "0": Clockwise rotating motor ≡ positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise rotating motor ≡ positive machine direction.

### 11.9.4 Activating setpoint interface

#### Requirements

- ▶ The controller is in the "Operation" device state.
- ▶ The basic function "Speed follower" is part of the active application.
- ▶ No other basic function is active.

#### Activation

To request the control via the basic function, the *SF\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the motor control is automatically switched over to speed control with torque limitation. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- ▶ A successful change to the function state "Speed follower active" is displayed by a TRUE signal at the *SF\_bEnabled* status output.



#### Stop!

The basic function does not take over the control of the drive from the current speed, but immediately with the setpoint defined, which may cause a jerk!

#### Deactivation

When the *SF\_bEnable* enable input is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- ▶ The status output *SF\_bEnabled* is reset to FALSE and a change-over from the active "Speed follower active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

## 11.10 Torque follower

This basic function is used as setpoint interface for torque-controlled drives.

- ▶ The motor control is switched over automatically to torque control with speed limitation.
- ▶ If the direction of rotation of the motor has to be inverted due to the mounting position of the motor or the gearbox ratio available, the use of the control signals can be accordingly changed over by means of parameterisation.
- ▶ A stable speed limitation requires a minimum difference of the speed limit values of 50 rpm. If the defined speed limit values fall below this minimum difference, the internal lower speed limit value is lowered accordingly. The upper speed limit value remains unchanged. ▶ [Signal flow - torque follower](#) (□ 510)



### Note!


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 383)

**For the encoderless motor control types (from software version V3.0) the following applies:**

The basic function "Torque follower" cannot be activated when the V/f control has been selected.

## 11.10.1 Internal interfaces | "LS\_TorqueFollower" system block

The **LS\_TorqueFollower** system block provides the internal interfaces for the basic function "Torque follower" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!


### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
TF_bEnable <a href="#">C02699/1</a>   BOOL	Requesting control via the basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the setpoints defined are accepted.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Torque follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the setpoints defined are accepted.	TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Torque follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
TRUE	If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the setpoints defined are accepted.				
TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Torque follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.				
TF_dnTorqueSet_n <a href="#">C02698/1</a>   DINT	Torque setpoint in [%] • 100 % ≙ motor reference torque (display in <a href="#">C00057/2</a> ).				
TF_dnSpeedHighLimit_n <a href="#">C02698/2</a>   DINT	Upper speed limit value in [%] for speed limitation • For positive direction of motion. • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> ). • Negative values are limited internally to the value "0".				
TF_dnSpeedLowLimit_n <a href="#">C02698/3</a>   DINT	Lower speed limit value in [%] for speed limitation • For negative direction of motion. • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> ). • Positive values are limited internally to the value "0".				

### Outputs

Identifier <small>DIS code   data type</small>	Value/meaning		
TF_bEnabled <a href="#">C02699/2</a>   BOOL	Status signal "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>The defined setpoints are accepted.</td> </tr> </table>	TRUE	The defined setpoints are accepted.
TRUE	The defined setpoints are accepted.		

#### 11.10.2 Signal flow



[11-3] Signal flow - torque follower

#### Internal variables of the motor control (oscilloscope signals)

- ▶ The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (📖 590)

No.	Variable of the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Speed.dnActualMotorSpeed	Current motor speed

## 11.10.3 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Torque follower*
- ▶ Short overview of the parameters for the torque follower:

Parameter	Information
<a href="#">C00050/1</a>	Speed setpoint 1
<a href="#">C00050/2</a>	Speed setpoint 2
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02550/2</a>	Speed setpoint interpolat.
<a href="#">C02550/3</a>	Torque setpoint interpolat.
<a href="#">C02559</a>	Internal torque limit

Highlighted in grey = display parameter

### 11.10.3.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the speed and/or torque setpoints which may be transferred from a slower task.

- ▶ [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- ▶ [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

### 11.10.3.2 Inversion of the direction of rotation

Depending on the motor mounting position, if required, the direction of rotation can be inverted:

- ▶ [C02527](#) = "0": Clockwise rotating motor ≡ positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise rotating motor ≡ positive machine direction.

## 11.10.4 Activating setpoint interface

### Requirements

- ▶ The controller is in the "Operation" device state.
- ▶ The basic function "Torque follower" is part of the active application.
- ▶ No other basic function is active.

### Activation

To request the control via the basic function, the *TF\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the motor control is automatically switched over to torque control with speed limitation. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- ▶ A successful change to the function state "Torque follower active" is displayed by a TRUE signal at the *TF\_bEnabled* status output.



### Stop!

The basic function does not take over the control of the drive from the current speed, but immediately with the setpoint defined, which may cause a jerk!

### Deactivation

When the *TF\_bEnable* enable input is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- ▶ The status output *TF\_bEnabled* is reset to FALSE and a change-over from the active "Torque follower active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.



## 11.11 Limiter

The basic function "Limiter" monitors the travel range limits via limit switches and parameterised software limit positions and can lead the drive to defined limit ranges when being requested accordingly by the safety module.



### Danger!

The safety is exclusively ensured by the safety module!

When the request for the safety function is cancelled, the drive restarts automatically.

Ensure by external measures that the drive only starts after a confirmation (EN 60204).




### Note!

In order to make it possible for the basic function "Limiter" to lead the drive to the limit ranges defined **after a corresponding request by the safety module**, before the limits set for the safety module have been reached and it shuts down the drive, the limits for the basic function "Limiter" have to be set lower than the limits of the safety module!

See also: [Safety engineering](#) (📖 367)

### 11.11.1 Internal interfaces | "LS\_Limiter" system block

The **LS\_Limiter** system block provides the internal interfaces for the basic function "Limiter" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

#### Inputs

Identifier DIS code   data type	Information/possible settings																						
LIM_dwControl <a href="#">C02717</a>   DWORD	Interface to the safety module (bit coded) <ul style="list-style-type: none"> <li>For a simple connection of the safety module to the application, the transmission of the currently valid safety requirement(s) is effected via this bit coded control signal.</li> <li>It is also possible to make several requirements at the same time via the control signal, e.g. manual jog with limited increment and limited speed 2.</li> <li>Bits not listed are reserved for future extensions!</li> </ul> <table border="1" data-bbox="608 568 1442 1711"> <tbody> <tr> <td data-bbox="608 568 762 663">Bit 0</td> <td data-bbox="762 568 1442 663">                             Switched-off torque: request controller inhibit.                             <ul style="list-style-type: none"> <li>This bit is no longer supported by the control signal of the <b>LS_SafetyModuleInterface</b> system block.</li> </ul> </td> </tr> <tr> <td data-bbox="608 663 762 703">Bit 1</td> <td data-bbox="762 663 1442 703">                             Stop 1: request quick stop with subsequent controller inhibit.                         </td> </tr> <tr> <td data-bbox="608 703 762 797">Bit 2</td> <td data-bbox="762 703 1442 797">                             Stop 2: request quick stop.                             <ul style="list-style-type: none"> <li>If the automatic brake operation is activated, the brake remains open at standstill.</li> </ul> </td> </tr> <tr> <td data-bbox="608 797 762 940">Bit 3</td> <td data-bbox="762 797 1442 940">                             Request limited speed 1.                             <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 1 (<a href="#">C02708/1</a>, <a href="#">C02710/1</a>, <a href="#">C02711/1</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 940 762 1084">Bit 4</td> <td data-bbox="762 940 1442 1084">                             Request limited speed 2.                             <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 2 (<a href="#">C02708/2</a>, <a href="#">C02710/2</a>, <a href="#">C02711/2</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 1084 762 1227">Bit 5</td> <td data-bbox="762 1084 1442 1227">                             Request limited speed 3.                             <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 3 (<a href="#">C02708/3</a>, <a href="#">C02710/3</a>, <a href="#">C02711/3</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 1227 762 1370">Bit 6</td> <td data-bbox="762 1227 1442 1370">                             Request limited speed 4.                             <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 4 (<a href="#">C02708/4</a>, <a href="#">C02710/4</a>, <a href="#">C02711/4</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 1370 762 1464">Bit 7</td> <td data-bbox="762 1370 1442 1464">                             Only permit positive direction of rotation.                             <ul style="list-style-type: none"> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 1464 762 1559">Bit 8</td> <td data-bbox="762 1464 1442 1559">                             Only permit negative direction of rotation.                             <ul style="list-style-type: none"> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 1559 762 1653">Bit 10</td> <td data-bbox="762 1559 1442 1653">                             Limited increment                             <ul style="list-style-type: none"> <li>Activate maximum distance set in <a href="#">C02713</a> as limited increment for the basic function "<a href="#">Manual jog</a>".</li> </ul> </td> </tr> <tr> <td data-bbox="608 1653 762 1711">Bit 12</td> <td data-bbox="762 1653 1442 1711">                             Defined limit positions                             <ul style="list-style-type: none"> <li>Activate software limit positions set in <a href="#">C02701/1</a> and <a href="#">C02701/2</a>.</li> </ul> </td> </tr> </tbody> </table>	Bit 0	Switched-off torque: request controller inhibit. <ul style="list-style-type: none"> <li>This bit is no longer supported by the control signal of the <b>LS_SafetyModuleInterface</b> system block.</li> </ul>	Bit 1	Stop 1: request quick stop with subsequent controller inhibit.	Bit 2	Stop 2: request quick stop. <ul style="list-style-type: none"> <li>If the automatic brake operation is activated, the brake remains open at standstill.</li> </ul>	Bit 3	Request limited speed 1. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 1 (<a href="#">C02708/1</a>, <a href="#">C02710/1</a>, <a href="#">C02711/1</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>	Bit 4	Request limited speed 2. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 2 (<a href="#">C02708/2</a>, <a href="#">C02710/2</a>, <a href="#">C02711/2</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>	Bit 5	Request limited speed 3. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 3 (<a href="#">C02708/3</a>, <a href="#">C02710/3</a>, <a href="#">C02711/3</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>	Bit 6	Request limited speed 4. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 4 (<a href="#">C02708/4</a>, <a href="#">C02710/4</a>, <a href="#">C02711/4</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>	Bit 7	Only permit positive direction of rotation. <ul style="list-style-type: none"> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>	Bit 8	Only permit negative direction of rotation. <ul style="list-style-type: none"> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>	Bit 10	Limited increment <ul style="list-style-type: none"> <li>Activate maximum distance set in <a href="#">C02713</a> as limited increment for the basic function "<a href="#">Manual jog</a>".</li> </ul>	Bit 12	Defined limit positions <ul style="list-style-type: none"> <li>Activate software limit positions set in <a href="#">C02701/1</a> and <a href="#">C02701/2</a>.</li> </ul>
Bit 0	Switched-off torque: request controller inhibit. <ul style="list-style-type: none"> <li>This bit is no longer supported by the control signal of the <b>LS_SafetyModuleInterface</b> system block.</li> </ul>																						
Bit 1	Stop 1: request quick stop with subsequent controller inhibit.																						
Bit 2	Stop 2: request quick stop. <ul style="list-style-type: none"> <li>If the automatic brake operation is activated, the brake remains open at standstill.</li> </ul>																						
Bit 3	Request limited speed 1. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 1 (<a href="#">C02708/1</a>, <a href="#">C02710/1</a>, <a href="#">C02711/1</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>																						
Bit 4	Request limited speed 2. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 2 (<a href="#">C02708/2</a>, <a href="#">C02710/2</a>, <a href="#">C02711/2</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>																						
Bit 5	Request limited speed 3. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 3 (<a href="#">C02708/3</a>, <a href="#">C02710/3</a>, <a href="#">C02711/3</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>																						
Bit 6	Request limited speed 4. <ul style="list-style-type: none"> <li>Change of the traversing profile according to the parameters set for the limited speed 4 (<a href="#">C02708/4</a>, <a href="#">C02710/4</a>, <a href="#">C02711/4</a>).</li> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>																						
Bit 7	Only permit positive direction of rotation. <ul style="list-style-type: none"> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>																						
Bit 8	Only permit negative direction of rotation. <ul style="list-style-type: none"> <li>Only effective for the basic functions "<a href="#">Manual jog</a>", "<a href="#">Homing</a>" and "<a href="#">Positioning</a>".</li> </ul>																						
Bit 10	Limited increment <ul style="list-style-type: none"> <li>Activate maximum distance set in <a href="#">C02713</a> as limited increment for the basic function "<a href="#">Manual jog</a>".</li> </ul>																						
Bit 12	Defined limit positions <ul style="list-style-type: none"> <li>Activate software limit positions set in <a href="#">C02701/1</a> and <a href="#">C02701/2</a>.</li> </ul>																						


Identifier DIS code   data type	Information/possible settings	
LIM_bLimitSwitchPositive <a href="#">C02719/1</a>   BOOL	Input for positive travel range limit switch	
	TRUE	Limit switch is activated.
LIM_bLimitSwitchNegative <a href="#">C02719/2</a>   BOOL	Input for negative travel range limit switch	
	TRUE	Limit switch is activated.
LIM_bActivateLimitedSpeed 1 <a href="#">C02719/3</a>   BOOL	Request limited speed 1 • If a setpoint follower is active, no limitation takes place, but an exceeding of the limit values is displayed via the output <i>LIM_dnState</i> .	
	TRUE	Request limited speed 1.

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
LIM_dnState <a href="#">C02718</a>   DINT	Status word (bit coded) <ul style="list-style-type: none"> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul>
	Bit 0 Controller inhibit is initiated. (Safe torque off is requested; bit 0 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 1 Quick stop is initiated. (Safe stop 1 is requested; bit 1 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 2 Quick stop is initiated. (Safe stop 2 is requested; bit 2 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 3 Profile change due to speed limitation. (Limited speed 1 is requested; bit 3 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 4 Profile change due to speed limitation. (Limited speed 2 is requested; bit 4 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 5 Profile change due to speed limitation. (Limited speed 3 is requested; bit 5 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 6 Profile change due to speed limitation. (Limited speed 4 is requested; bit 6 of the <i>LIM_dwControl</i> control signal is set to "1".)
	Bit 7 Only positive direction of rotation is permissible. <ul style="list-style-type: none"> <li>When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.</li> </ul>
	Bit 8 Only negative direction of rotation is permissible. <ul style="list-style-type: none"> <li>When the direction of rotation is positive while requesting "Only negative direction of rotation", the drive is braked to standstill.</li> </ul>
	Bit 10 Increment in manual jog mode is limited.
	Bit 12 Limitation of the set position is active.
	Bit 16 Positive limit switch inhibits travel in positive direction.
	Bit 17 Negative limit switch inhibits travel in negative direction.
	Bit 18 Positive software limit position inhibits travel in positive direction.
	Bit 19 Negative software limit position inhibits travel in negative direction.
	Bit 20 Limitation of speed is active.
	Bit 21 Limitation of acceleration is active.
	Bit 22 Limitation of deceleration is active.
	Bit 23 Limitation of jerk is active (S-ramp time is increased).
LIM_bLimitationActive <a href="#">C02715</a>   BOOL	Status signal "Limitation is active" (group signal)
	TRUE A limitation is active.

### 11.11.1.1 Interface to the safety module

For the simple connection of the safety module to the application, the transmission of the currently valid safety requirement(s) is effected in the form of a bit coded control signal via the following interface:



[11-4] Interface to connect the safety module to the basic function "Limiter"

- ▶ It is also possible to make several requirements at the same time via the control signal, e.g. manual jog with limited increment and limited speed 2.
- ▶ If no safety module is connected, the control signal can also be generated by means of a converter block (FB **L\_DevSMControlEncoder**).

#### 11.11.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Limiter*
- ▶ Short overview of the parameters for the limiter:

Parameter	Information
<a href="#">C02700</a>	Software limits pos. effective
<a href="#">C02701/1</a>	Positive software limit position
<a href="#">C02701/2</a>	Negative software limit position
<a href="#">C02702</a>	Limitations effective
<a href="#">C02703</a>	Max. speed
<a href="#">C02704</a>	Max. speed [rpm]
<a href="#">C02705</a>	Max. acceleration
<a href="#">C02706</a>	Min. S-ramp time
<a href="#">C02707</a>	Permissible direction of rotation
<a href="#">C02708/1...4</a>	Limited speed 1 .... 4
<a href="#">C02709/1...4</a>	Limited speed 1 .... 4 (display in [rpm])
<a href="#">C02710/1...4</a>	Dec. limited speed 1 .... 4
<a href="#">C02711/1...4</a>	S-ramp time limited speed 1 .... 4
<a href="#">C02712/1...4</a>	Dec. time limited speed 1 .... 4
<a href="#">C02713</a>	Max. distance manual jog
<a href="#">C02714</a>	Max. dist. manual control (display in [increments])
<a href="#">C02715</a>	Limitation active (status display)
<a href="#">C02716/1</a>	Resp. to rotation limitation
<a href="#">C02716/2</a>	Resp. to SW lim. pos. exceeded
<a href="#">C02716/3</a>	Resp. to max. value exceeded
<a href="#">C02720</a>	Observation software limit positions

Highlighted in grey = display parameter



#### Note!

The safety module has its own parameters.

Relevant to the basic function "Limiter" are the parameters of the safety modules for setting "Limited direction of rotation", "Speed with time limit" and "Limited increment (position)".

However, several other parameters of the safety module have no significance for the basic function "Limiter", e. g. the parameters for the configuration of the inputs of the safety module.

### 11.11.2.1 Software limit positions

The parameterisable software limit positions serve to limit the travel range.



#### Note!

Software limit positions are only evaluated and monitored if the drive knows the home position and the software limit positions are active ([C02700](#) = "1").


- When the traversing range is limited ([C02528](#) = "1") and the software limit positions are not active, the range is limited by the software to the internal value range that can be maximally displayed ( $\pm 2^{31}$  increments).
- For the "Modulo" traversing range ([C02528](#) = "2") the software limit positions are generally not effective.
- If the error response that can be set in [C02716/2](#) is deactivated or is only set to "Warning" or "Information", the software limit positions are not effective in an active manner for the basic functions "[Speed follower](#)", "[Torque follower](#)", and "[Position follower](#)"!

From software version V4.0 onwards, the triggering behaviour of the software limit position monitoring can be parameterised in [C02720](#).

- If you want to maintain the device behaviour known from the previous versions, select "1: Based on set and actual value" in [C02720](#).

► [Triggering behaviour of software limit position monitoring](#) (📖 521)

- The positive software limit position is set in [C02701/1](#), and the negative software limit position is set in [C02701/2](#).
- If the software limit positions are effective, travel commands the result of which would be that the permissible travel range would be exited can no longer be executed:




[11-5] Example: Traversing range limitation by software limit position

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Limiter

- ▶ If the drive is already beyond the permissible travel range and the software limit positions are switched effectively, only travel commands resulting in the traversing of the drive back to the permissible travel range can be executed:



[11-6] Example: Permissible traversing direction for effective software limit positions

- ▶ If the software limit positions are active and a software limit position is "overtravelled":
  - The error response "quick stop by trouble" is carried out in the Lenze setting, i.e. the drive is braked to standstill within the deceleration time set for the quick stop function irrespective of the setpoint selection. The error response can be parameterised in [C02716/2](#).
  - The fault message "Pos. SW limit switch overtravelled" or "Neg. SW limit overtravelled" is entered in the logbook of the controller.
  - A corresponding status is output via the `LIM_dnState` output.
  - Depending on the error response parameterised, the drive can only be traversed after the fault has been acknowledged.

See also: ▶ [Manual jog to limit position](#) (📖 408)



### 11.11.2.2 Triggering behaviour of software limit position monitoring

This function extension is available from software version V4.0!

[C02720](#) can be used to select the triggering behaviour of the software limit position monitoring of non-position-controlled basic functions:

#### Selection "0: Based on set value"

From software version V4.0 onwards, this is the Lenze setting:

- ▶ If the basic functions "[Speed follower](#)" and "[Torque follower](#)" are used, the monitoring responds if the drive is outside the software limit positions and a command to travel in the "forbidden" direction is given (depending on the speed setpoint of the application).
- ▶ For all other non-position-controlled basic functions, the monitoring does not respond if a software limit position is exceeded.

#### Selection "1: Based on set and actual value"

This selection corresponds to the behaviour known from the previous versions (software versions < V4.0):

- ▶ For all non-position-controlled basic functions, the monitoring responds if the actual position exceeds a software limit position.
  - The monitoring also responds in the function states "Controller not ready" and "Error". This may cause the monitoring to trigger permanently if the drive traverses to a software limit position and controller inhibit is set subsequently because the actual position slightly changes around the software limit position.
- ▶ If the basic functions "[Speed follower](#)" and "[Torque follower](#)" are used, the monitoring also responds if the drive is outside the software limit positions and a command to travel in the "forbidden" direction is given (depending on the speed setpoint of the application).



#### Note!

If the position-controlled basic functions "[Manual jog](#)", "[Positioning](#)" and "[Position follower](#)" are used, the monitoring responds independently of the triggering behaviour parameterised in [C02720](#) if one of the following cases occurs:


- The setpoint position exceeds a software limit position.
- A travel command is given which would cause the drive to leave the permissible travel range.
- The drive is outside the software limit positions and a command to travel in the "forbidden" direction is given.

If the software limit position monitoring is triggered, the error response parameterised in [C02716/2](#) is carried out.

#### 11.11.2.3 Hardware limit positions (limit switch)

Monitoring of the travel range limit by means of limit switches is effected via the inputs *LIM\_bLimitSwitchPositive* and *LIM\_bLimitSwitchNegative* of the **LS\_Limiter** SB.

- ▶ The two inputs respond to the TRUE state and are to be connected to the corresponding digital inputs to which the limit switches are connected:



[11-7] Example: Connection of the travel range limit switches to the digital inputs DI3 & DI4

- ▶ If the limit switches are connected to decentralised terminals, the two inputs *LIM\_bLimitSwitchPositive* and *LIM\_bLimitSwitchNegative* can be connected to the decentralised terminal via a bus system (e. g. system bus).



#### Note!

If the digital inputs used for the connection of the limit switches are to be designed in a fail-safe manner (activation at LOW level), you simply change the terminal polarity of the corresponding digital inputs in [C00114](#).

- ▶ If one of the two monitoring inputs is set to TRUE:
  - The error response "quick stop by trouble" is carried out, i.e. the drive is braked to standstill within the deceleration time set for the quick stop function irrespective of the setpoint selection.
  - The fault message "Pos. SW limit switch has tripped" or "Neg. SW limit has tripped" is entered in the logbook of the controller.
  - A corresponding status is output via the *LIM\_dnState* output.
  - The drive can only be traversed again after the error has been acknowledged.



## Stop!

If a limit switch is approached by means of the basic function [Position follower](#) and by this a fault with the "Quick stop by trouble" response is activated, always a set/actual adjustment of the position has to be carried out before the fault is acknowledged, as otherwise an uncontrolled motor movement may result after the fault is acknowledged!



## Tip!

An activated limit switch can be retracted using the function "Retracting the limit switch". ▶ [Retracting of an activated limit switch](#) (📖 409)

See also: ▶ [Manual jog to limit position](#) (📖 408)

#### 11.11.2.4 Limitations

Limit values for the basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" can be set via the following parameters:

Parameter	Information
<a href="#">C02703</a>	Max. speed <ul style="list-style-type: none"><li>• Max. permissible speed that can be driven by the system.</li><li>• This parameter depends, among other things, on the max. motor speed.</li></ul>
<a href="#">C02705</a>	Max. acceleration <ul style="list-style-type: none"><li>• Max. permissible acceleration or deceleration for positioning processes.</li><li>• This parameter depends, among other things, on the motor torque and moment of inertia of the entire mechanics which is driven during the positioning process.</li></ul>
<a href="#">C02706</a>	Min. S-ramp time

- ▶ The parameters depend on the mechanics (e.g. the tool used).
- ▶ Usually the parameters must be changed when a tool is exchanged, e.g. by means of a recipe management of a superimposed control or via an HMI ("*Human Machine Interface*").



#### Note!

In order that the set limit values are effective, "1" must be selected in [C02702](#).

- Irrespective of this setting, basically, the speed setpoint is limited to the motor reference speed ([C00011](#))!

The limitations are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- In case of these basic functions only speed and acceleration are monitored.
- If the limit values for speed and acceleration are exceeded, the response parameterised in [C02716/3](#) is activated (Lenze setting: no response).
- **Background:** In the case of technology applications which are synchronised via an electrical shaft, the setpoint followers may not be limited, since synchronism would be lost by this. A possible consequence would be a collision of tools.

- ▶ If the limit values are switched effectively and a limit value that is set is exceeded:
  - The setpoints of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") are changed (limited).
  - The response parameterised in [C02716/3](#) (Lenze setting: "No response") is activated.
  - A corresponding error message is entered into the logbook of the controller.
  - A corresponding status is output via the *LIM\_dnState* output.
  - The display parameter "Limitation active" ([C02715](#)) is set to "1: Activated".

### 11.11.2.5 Permissible direction of rotation

Via [C02707](#), or alternatively via the input *LIM\_dwControl* (generally by the control word of the safety module) the permissible direction of rotation for the basic functions "[Manual jog](#)", "[Homing](#)", and "[Positioning](#)" can be restricted.



#### Note!

The restriction of the permissible direction of rotation is not actively effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- Only the response parameterised in [C02716/1](#) is executed. (Lenze setting: "No response")

- ▶ If the permissible direction of rotation is restricted and a travel command in the inhibited direction of rotation is requested:
  - The movement of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") is cancelled.
  - The response parameterised in [C02716/1](#) (Lenze setting: "No response") is activated.
  - The fault message "Pos. direction of rotation was limited" or "Neg. direction of rotation was limited" is entered in the logbook of the controller.
  - A corresponding status is output via the *LIM\_dnState* output.

#### 11.11.2.6 Limited speed

"Limited speeds" for the basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" can be set via the following parameters:

Parameter	Information
<a href="#">C02708/1...4</a>	Limited speed 1 .... 4
<a href="#">C02710/1...4</a>	Dec. limited speed 1 .... 4
<a href="#">C02711/1...4</a>	S-ramp time limited speed 1 .... 4
<a href="#">C02712/1...4</a>	Dec. time limited speed 1 .... 4



#### Note!

The limited speeds are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- ▶ The request "Limited speed 1 ... 4" is effected via the input *LIM\_dwControl*, generally by the control word of the safety module. If no safety module is available, the control word for the input *LIM\_dwControl* can also be generated by means of an inverter.
- ▶ By means of the input *LIM\_bActivateLimitedSpeed1* additionally the request of "Limited speed 1" can be effected, e. g. via a digital input that is connected to this input.
- ▶ If a limited speed is requested and the current speed exceeds the limited speed:
  - The setpoints of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") are changed (limited).
  - The response parameterised in [C02716/3](#) (Lenze setting: "No response") is activated.
  - The error message "Speed has been limited" is entered into the logbook of the controller.
  - A corresponding status is output via the *LIM\_dnState* output.
  - The display parameter "Limitation active" ([C02715](#)) is set to "1: Activated".

#### Process example: "Manual jog"

1. Manual jog in positive direction is active and the manual speed is greater than the "Limited speed 1" set.
2. Via the control word of the safety module the "Limited speed 1" is requested.
3. The drive is decelerated to the "Limited speed 1" with the deceleration and S-ramp time set for the "Limited speed 1".
4. At the same time, a corresponding status is output via the *LIM\_dnState* output.

## Priorisation of the limited speeds

The following applies to software versions lower than V3.0:

- ▶ If several limited speeds are requested at the same time, the parameters of the limited speed with the lowest number are used, i.e. the "Limited speed 1" has the highest priority.

The following applies from software version V3.0:

- ▶ If several limited speeds are requested at the same time, the lowest speed with the greatest deceleration and the lowest S-ramp time is approached from the parameters of the requested limited speeds.

### 11.11.2.7 Limited increment for manual jog

Via [C02713](#) the maximum permissible distance (limited increment) for the basic function "[Manual jog](#)" can be set.

- ▶ The request "Limited increment" is effected via the input *LIM\_dwControl*, generally by the control word of the safety module. If no safety module is available, the control word for the input *LIM\_dwControl* can also be generated by means of an inverter.
- ▶ In [C02714](#) the maximum permissible distance in [increments] is displayed.

#### 11.12 Brake control

This basic function is used for a wear free control and monitoring of a motor holding brake which in the simplest case is connected to the optionally available motor holding brake control module. Alternatively, the motor holding brake can be controlled via a digital output and monitored via a digital input.

##### Intended use

Motor holding brakes are used to hold axes in the case of controller inhibit or pulse inhibit and in the "Mains OFF" system state. This is not only important for vertical axes, but for instance also for horizontal axes for which an uncontrolled movement can bring about diverse problems.

Examples:

- ▶ Loss of the reference information after mains OFF and coasting of the drive.
- ▶ Collision with other moving machine parts.



##### Danger!

Please bear in mind that the motor holding brake is an important element of the safety concept of the entire machine. Thus maintain this system component with special care!



##### Stop!

Motor holding brakes at Lenze motors are not designed for braking during operation. The increased wear resulting from braking during operation may lead to an early destruction of the motor holding brake!



Please observe the notes in the hardware manual for mounting and electrical installation of the motor holding brake!





## Note!

For the operation with motor holding brake control module:

- For single-axis controllers (Single Drive) the control (release) of the motor holding brake is only possible if both the DC-bus voltage and a 24-V supply voltage are available for the motor brake control!
- For multi-axis controllers (Multi Drive) the motor holding brake can also be released without a DC-bus voltage.

**For the encoderless motor control types (from software version V3.0) the following applies:**


The operation of vertical drives/hoists is

- only supported up to 55 kW by the V/f control!
- not supported by the sensorless vector control!

When the V/f control or sensorless vector control are selected, standstill monitoring is always switched off.

#### 11.12.1 Internal interfaces | "LS\_Brake" system block

The LS\_Brake system block provides the internal interfaces for the basic function "Brake control" in the function block editor.



#### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

#### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
BRK_bReleaseBrake <small>C02609/1   BOOL</small>	Opening/closing the brake in connection with the selected operating mode <table border="1"> <tr> <td>FALSE</td> <td>Close the brake.                             <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic takes over the control of the brake.</li> </ul> </td> </tr> <tr> <td>TRUE</td> <td>Release brake.                             <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic is deactivated and the brake is released. This controller inhibit that may be set by the brake control is deactivated again.</li> </ul> </td> </tr> </table>	FALSE	Close the brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic takes over the control of the brake.</li> </ul>	TRUE	Release brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic is deactivated and the brake is released. This controller inhibit that may be set by the brake control is deactivated again.</li> </ul>
FALSE	Close the brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic takes over the control of the brake.</li> </ul>				
TRUE	Release brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic is deactivated and the brake is released. This controller inhibit that may be set by the brake control is deactivated again.</li> </ul>				
BRK_bStartingTorque2 <small>C02609/2   BOOL</small>	Selection of the torque feedforward control value <ul style="list-style-type: none"> <li>For the general use of the parameterisable starting torque as a feedforward control value, the setting <a href="#">C02588</a> = 0 is required.</li> <li>▶ <a href="#">Torque feedforward control (□ 543)</a></li> </ul> <table border="1"> <tr> <td>FALSE</td> <td>Starting torque 1 (<a href="#">C02586</a>) is active.</td> </tr> <tr> <td>TRUE</td> <td>Starting torque 2 (<a href="#">C02587</a>) is active.</td> </tr> </table>	FALSE	Starting torque 1 ( <a href="#">C02586</a> ) is active.	TRUE	Starting torque 2 ( <a href="#">C02587</a> ) is active.
FALSE	Starting torque 1 ( <a href="#">C02586</a> ) is active.				
TRUE	Starting torque 2 ( <a href="#">C02587</a> ) is active.				
BRK_bDisableStop <small>C02609/10   BOOL</small>	Prevent the brake from being applied in automatic operation <ul style="list-style-type: none"> <li>By this the drive remains position-controlled in the function states "Quick stop active", "Drive is stopped", and "Drive at standstill".</li> <li>The input has no effect when the controller is inhibited.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>The application of the brake in automatic operation is prevented.</td> </tr> </table>	TRUE	The application of the brake in automatic operation is prevented.		
TRUE	The application of the brake in automatic operation is prevented.				
BRK_dnTorqueAdd_n <small>C02608   DINT</small>	Additive torque value in [%] for torque feedforward control during start <ul style="list-style-type: none"> <li>100 % = <a href="#">C00057/2</a></li> <li>▶ <a href="#">Torque feedforward control (□ 543)</a></li> </ul>				

Identifier <small>DIS code   data type</small>	Information/possible settings				
BRK_bBrakeApplied <a href="#">C02609/3</a>   BOOL	Input for status detection via switching contact at the brake <ul style="list-style-type: none"> <li>Activation of the input by setting <a href="#">C02583</a> = 1.</li> <li>▶ <a href="#">Signal configuration</a> (□ 534)</li> </ul> <table border="1"> <tr> <td>FALSE</td> <td>Status "Brake is released".</td> </tr> <tr> <td>TRUE</td> <td>Status "Brake is applied".</td> </tr> </table>	FALSE	Status "Brake is released".	TRUE	Status "Brake is applied".
FALSE	Status "Brake is released".				
TRUE	Status "Brake is applied".				
BRK_bBrakeTest <a href="#">C02609/4</a>   BOOL	Start/abort of the brake test <ul style="list-style-type: none"> <li>▶ <a href="#">Carrying out brake test</a> (□ 560)</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Carry out brake test</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Abort brake test (deactivate mode).</td> </tr> </table>	TRUE	Carry out brake test	TRUE↔FALSE	Abort brake test (deactivate mode).
TRUE	Carry out brake test				
TRUE↔FALSE	Abort brake test (deactivate mode).				
BRK_bBrakeGrindIn <a href="#">C02609/5</a>   BOOL	Start/abort of the brake grinding process <ul style="list-style-type: none"> <li>▶ <a href="#">Grinding the brake</a> (□ 558)</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Brake grinding.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Abort grinding process (deactivate mode).</td> </tr> </table>	TRUE	Brake grinding.	TRUE↔FALSE	Abort grinding process (deactivate mode).
TRUE	Brake grinding.				
TRUE↔FALSE	Abort grinding process (deactivate mode).				

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning																																				
BRK_dnState <a href="#">C02607</a>   DINT	Status (bit coded) <ul style="list-style-type: none"> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr> <td>Bit 1</td> <td>Brake control is active.</td> </tr> <tr> <td>Bit 4</td> <td>Motor holding brake control module is used.</td> </tr> <tr> <td>Bit 8</td> <td>Brake status (internal status signal).</td> </tr> <tr> <td>Bit 9</td> <td>Torque feedforward control is active.</td> </tr> <tr> <td>Bit 10</td> <td>Controller inhibit by brake is active or set.</td> </tr> <tr> <td>Bit 15</td> <td>Fault is active (collective message).</td> </tr> <tr> <td>Bit 16</td> <td>State "Grinding the brake".</td> </tr> <tr> <td>Bit 17</td> <td>State "Brake test".</td> </tr> <tr> <td>Bit 18</td> <td>State "Direct control".</td> </tr> <tr> <td>Bit 19</td> <td>State "Automatic control".</td> </tr> <tr> <td>Bit 20</td> <td>Error: External feedback.</td> </tr> <tr> <td>Bit 21</td> <td>Error: Position drift when brake is applied/checked.</td> </tr> <tr> <td>Bit 22</td> <td>Error: Monitoring of motor holding brake control module</td> </tr> <tr> <td>Bit 23</td> <td>Information: Brake activation via waiting time.</td> </tr> <tr> <td>Bit 24</td> <td>Information: Brake grinding process completed.</td> </tr> <tr> <td>Bit 25</td> <td>Information: Brake test completed.</td> </tr> <tr> <td>Bit 26</td> <td>Fault: Feedforward control torque could not be established within one second.</td> </tr> <tr> <td>Bit 27</td> <td>Information: Current speed has fallen below the threshold for brake activation set in <a href="#">C02581</a>.</td> </tr> </table>	Bit 1	Brake control is active.	Bit 4	Motor holding brake control module is used.	Bit 8	Brake status (internal status signal).	Bit 9	Torque feedforward control is active.	Bit 10	Controller inhibit by brake is active or set.	Bit 15	Fault is active (collective message).	Bit 16	State "Grinding the brake".	Bit 17	State "Brake test".	Bit 18	State "Direct control".	Bit 19	State "Automatic control".	Bit 20	Error: External feedback.	Bit 21	Error: Position drift when brake is applied/checked.	Bit 22	Error: Monitoring of motor holding brake control module	Bit 23	Information: Brake activation via waiting time.	Bit 24	Information: Brake grinding process completed.	Bit 25	Information: Brake test completed.	Bit 26	Fault: Feedforward control torque could not be established within one second.	Bit 27	Information: Current speed has fallen below the threshold for brake activation set in <a href="#">C02581</a> .
Bit 1	Brake control is active.																																				
Bit 4	Motor holding brake control module is used.																																				
Bit 8	Brake status (internal status signal).																																				
Bit 9	Torque feedforward control is active.																																				
Bit 10	Controller inhibit by brake is active or set.																																				
Bit 15	Fault is active (collective message).																																				
Bit 16	State "Grinding the brake".																																				
Bit 17	State "Brake test".																																				
Bit 18	State "Direct control".																																				
Bit 19	State "Automatic control".																																				
Bit 20	Error: External feedback.																																				
Bit 21	Error: Position drift when brake is applied/checked.																																				
Bit 22	Error: Monitoring of motor holding brake control module																																				
Bit 23	Information: Brake activation via waiting time.																																				
Bit 24	Information: Brake grinding process completed.																																				
Bit 25	Information: Brake test completed.																																				
Bit 26	Fault: Feedforward control torque could not be established within one second.																																				
Bit 27	Information: Current speed has fallen below the threshold for brake activation set in <a href="#">C02581</a> .																																				
BRK_bReleaseBrakeOut <a href="#">C02609/6</a>   BOOL	Control signal for triggering an external brake/status signal for control state <table border="1"> <tr> <td>FALSE</td> <td>Close the brake.</td> </tr> <tr> <td>TRUE</td> <td>Release brake.</td> </tr> </table>	FALSE	Close the brake.	TRUE	Release brake.																																
FALSE	Close the brake.																																				
TRUE	Release brake.																																				
BRK_bBrakeReleased <a href="#">C02609/7</a>   BOOL	Status signal of the brake control considering the closing and opening time of the brake <table border="1"> <tr> <td>FALSE</td> <td>Brake is applied (after the brake closing time has elapsed).</td> </tr> <tr> <td>TRUE</td> <td>Brake is released (after the brake opening time has elapsed).</td> </tr> </table>	FALSE	Brake is applied (after the brake closing time has elapsed).	TRUE	Brake is released (after the brake opening time has elapsed).																																
FALSE	Brake is applied (after the brake closing time has elapsed).																																				
TRUE	Brake is released (after the brake opening time has elapsed).																																				

Identifier <small>DIS code   data type</small>	Value/meaning
BRK_bError <a href="#">C02609/8</a>   BOOL	Status signal "Brake error" TRUE   An error has been detected.
BRK_bCInhActive <a href="#">C02609/9</a>   BOOL	Status signal "Controller inhibit" TRUE   Controller inhibit has been set by brake control.

### 11.12.2 Parameter setting



#### Danger!

For the correct function of the brake control the different delay times in the following parameters have to be set correctly!

If the delay times are set incorrectly, a faulty control of the motor holding brake may be caused!

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Brake control*
- ▶ Short overview of parameters for brake control:

Parameter	Information
<a href="#">C02580</a>	Operating mode brake
<a href="#">C02581</a>	Threshold - brake activation
<a href="#">C02582</a>	Brake resp. to pulse inhibit
<a href="#">C02583</a>	Status input monitoring
<a href="#">C02585</a>	Brake control polarity
<a href="#">C02586</a>	Starting torque 1
<a href="#">C02587</a>	Starting torque 2
<a href="#">C02588</a>	Source of starting torque
<a href="#">C02589</a>	Brake closing time
<a href="#">C02590</a>	Brake opening time
<a href="#">C02591</a>	Waiting time - status monitoring
<a href="#">C02593</a>	Waiting time - brake activation
<a href="#">C02594</a>	Test torque
<a href="#">C02595</a>	Permissible angle of rotation
<a href="#">C02596</a>	Grinding speed
<a href="#">C02597</a>	Accel./decel. time - grinding
<a href="#">C02598</a>	Grinding ON time
<a href="#">C02599</a>	Grinding OFF time
<a href="#">C02600</a>	Acceleration time feedf. control
<a href="#">C02601</a>	Ref. for accel. time of brake
<a href="#">C02602</a>	Source for feedf. control brake

Parameter	Information
<a href="#">C02603</a>	Threshold 1 for opening brake
<a href="#">C02604</a>	Threshold 2 for opening brake

### 11.12.2.1 Operating mode

Various operating modes are available in [C02580](#) for different applications and tasks:

- ▶ [Mode 0: Brake control is switched off](#) (📖 548)
- ▶ [Mode 1/11: Direct control of the brake](#) (📖 549)
  - Without a specific logic or automatic system, can for instance be used to carry out a simple check on whether the brake switches correctly.
- ▶ [Mode 2/12: Automatic control of the brake](#) (📖 550)
  - The normal mode for the control of mech. holding brakes with and without holding torque precontrol.

---


Function extension from software version V3.0:

- ▶ [Mode 22: Automatic DC-injection braking](#) (📖 555)
    - DC-injection braking for V/f control and sensorless vector control.
-

## 11.12.2.2 Signal configuration


The signal configuration of the control and status signals for the brake logic and monitoring function is executed via the parameters shown in the following signal flow.

The design of the motor holding brake control module (here: E94AZHA0051) enables the external control of the holding brake via an additional 3-pole terminal (X121).



[11-8] Signal configuration of the control and status signal with the motor holding brake control module E94AZHA0051

The motor holding brake control module E94AZHX0051 does **not** include an additional 3-pole terminal for the external control of the holding brake.



[11-9] Signal configuration of the control and status signal with the motor holding brake control module E84AZHX0051



### Note!

If an electrically holding (self-releasing) motor holding brake is to be controlled instead of an electrically releasing (self-holding) motor holding brake, the corresponding control and status signals must be inverted!



Please observe the notes in the hardware manual for mounting and electrical installation of the motor holding brake!

## Status monitoring by "Motor holding brake control module status"

(See signal path **A** in fig. [\[11-8\]](#))

- ▶ Indirect status detection of the brake function.
- ▶ Monitoring of the motor holding brake control module and the electrical brake circuit.

## Status monitoring by "Brake function test"


(See signal path **B** in fig. [\[11-8\]](#))

- ▶ Direct function test of the complete brake circuit by microswitches at the brake.
- ▶ Wear control of the brake rotor.



## 11.12.2.3 Standstill monitoring

After the brake closing time and the waiting time for the status monitoring have elapsed, the standstill monitoring becomes active, i. e. the holding position is noted and compared to the permissible angle of rotation set in [C02595](#) (Lenze setting: 5°) when the brake is applied.



[11-10] Automatic monitoring of the holding position

► If the stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#), although the brake is engaged:

- The error message "Motor brake: Angular drift with closed brake too high" is entered into the logbook.
- "Quick stop by trouble" is activated as error response to avoid a further rotation/acceleration of the drive.
- The error output *BRK\_bError* is set to TRUE for one task cycle.
- The status "position drift when brake is applied" is displayed at the *BRK\_dnState* status output via bit 21 for one task cycle.



### Note!


The standstill monitoring can be switched off by the setting [C02595](#) = "0°".

**For the encoderless motor control types (from software version V3.0) the following applies:**

If the V/f control or the sensorless vector control is selected, the standstill monitoring is generally switched off, irrespective of the setting in [C02595](#).

#### 11.12.2.4 Brake activation in automatic operation

##### Brake activation through $N < N_{min}$



[11-11] Process of brake activation through  $N < N_{min}$



#### Tip!

The value in [C02581](#) should be set to approx. 5 ... 20 % of the maximum speed to minimise the wear of the brake and also provide for an optimum braking behaviour by a low grinding of the brake.

- ▶ If the motor speed falls below the threshold for brake activation set in [C02581](#), the function "Close brake" is activated in the automatic operation (mode 2/12).
- ▶ Here only the absolute value of the motor speed is considered, the direction of rotation remains unconsidered.
- ▶ In manual operation (mode 1/11) [C02581](#) has no function.


### Brake activation through time-out

If a waiting time for the brake activation  $> 0$  s is set in [C02593](#), the time monitoring is active, i. e. the brake at the latest is activated for application after the waiting time has elapsed, even if the actual speed value is still above the threshold for the brake activation set in [C02581](#).



#### Note!

In the Lenze setting the time monitoring is not active ([C02593](#) = "0 s").



[11-12] Process of brake activation through time-out

- ▶ The waiting time starts to elapse if the speed setpoint has reached the threshold for the brake activation.
- ▶ If the speed setpoint is still above the threshold after the waiting time has elapsed:
  - The brake is automatically triggered to close in automatic operation (mode 2/12).
  - The "brake activation via waiting time" status is displayed at the *BRK\_dnState* status output via bit 23.
  - The information "Motor brake: Automatically activated after waiting time has elapsed" is entered in the logbook.

## 11.12.2.5 Brake time response


### Application and opening time



#### Danger!

A wrong setting of the closing and opening time can cause a wrong activation of the motor holding brake!

- When the closing time is set too low, the controller is inhibited and the drive gets torqueless before the motor holding brake is closed completely.



- ▶ Every mechanical motor holding brake has a construction-conditioned application and opening time which has to be taken into consideration by the brake control and which for this purpose has to be set in [C02589](#) and in [C02590](#).
- ▶ The information on the application and opening time of a Lenze-motor holding brake can be found in the corresponding Operating Instructions in the chapter "Technical data".
- ▶ If the application and opening times are set too great, this may be not critical with regard to safety, but causes unnecessary long delays in the case of cyclic braking processes.

[11-13] Example: Definition of the closing and opening time of the PM brake




#### Tip!

The application and opening times do not only vary between the brake types, but they also depend on the basic conditions in the system, like for instance:

- Parameters of the hardware (cable length, temperature, supply voltage etc.)
- Contact elements used (motor holding brake control module or contactor at the digital output)
- Type of overvoltage limitation/suppressor circuit

For purposes of optimisation, the response times should be determined by measurement for each case.

## Motor magnetising time (only for asynchronous motor)



- ▶ For an asynchronous motor first the magnetic field required for the holding torque is generated after controller inhibit has been deactivated (in the case of a synchronous motor it is already available).
- ▶ The brake is only released if the actual torque has reached 90 % of the feedforward control torque.

[11-14] Example: Consideration of the motor magnetising time in case of a PM brake

#### Waiting time for status monitoring


Every time the brake status changes, the waiting time set in [C02591](#) is awaited after the brake opening or brake closing time has elapsed, before the monitoring of the motor holding brake control module and the status input *BRK\_bBrakeApplied* (if activated via [C02583](#)) and the standstill monitoring function are switched active again.

- ▶ During the "Closing the brake" process, a mechanical contact must signal the "brake closed" state after the waiting time has elapsed.
- ▶ During the "Releasing the brake" process, a mechanical contact must signal the "brake released" state after the waiting time has elapsed.



#### Tip!

The additional waiting time is based on the fact that during the state change of the brake also state changes with regard to the monitored signals within the brake logic can occur, e. g. by bouncing the microswitch on the brake, or activation of the short circuit threshold within the motor holding brake control module due to discharge current peaks when the brake voltage is switched on. These state changes result in the activation of the monitoring function, although no stationary fault is pending.



[11-15] Definition of the waiting time for status monitoring

- ▶ The waiting time in [C02591](#) must be set so that bouncing of a feedback contact and the transient response of the brake current monitoring will be suppressed completely.
- ▶ If no corresponding feedback takes place after the waiting time has elapsed:
  - The error output *BRK\_bError* is set to TRUE until the next trigger attempt starts.
  - The error response "Quick stop by trouble" is activated.
  - The error message "Brake status error" is entered into the logbook.

## 11.12.2.6 Torque feedforward control

In automatic operation (mode 2/12) the brake control offers the possibility of precontrolling the required torque of the drive when the brake is released.




### Note!

The torque is precontrolled for one second. During this time, the actual torque must have reached 90 % of the set torque, otherwise a fault is tripped!

The torque feedforward control is also supported for the V/f control (from software version V3.0).

Via [C02588](#) first the basic selection on whether a parameterised starting torque or the torque memorised during the last application process is to be used for the feedforward control.

### Feedforward control with parameterised starting torque



- ▶ When [C02588](#) = 0, a change-over between two starting torques is possible via input *BRK\_bStartingTorque2*:
  - *BRK\_bStartingTorque2* = FALSE: Starting torque 1 ([C02586](#)) is used.
  - *BRK\_bStartingTorque2* = TRUE: Starting torque 2 ([C02587](#)) is used.

[11-16] Feedforward control with parameterised starting torque

### Application example:

A hoist drive is to be operated with different loads. Unfortunately we do not know when the load is available, but the starting direction (lifting or lowering) is known.

- ▶ In a no-load condition, the hoist drive needs a torque of 10 Nm. For holding the maximum load it needs a torque of 50 Nm.
- ▶ The change-over between lifting and lowering at start-up is done via the input *BRK\_bStartingTorque2*.

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Brake control


- ▶ To ensure the correct direction at start-up, the speed controller is loaded with the following starting torques:

	Lifting	Lowering
Starting torque:	<a href="#">C02586</a> = 50 Nm	<a href="#">C02587</a> = 10 Nm

- ▶ This results in the following behaviour depending on load and direction:

	Lifting	Lowering
Behaviour at max. load:	Optimum behaviour	Start-up a bit fast, but correct direction (non-critical).
Behaviour without load:	Start-up a bit fast, but correct direction (non-critical).	Optimum behaviour

## Feedforward control with memorised torque



[11-17] Feedforward control with parameterised starting torque

- ▶ When [C02588](#) = 1, the starting torque is the setpoint which has been automatically memorised during the last closing process (falling below the speed threshold set in [C02581](#)).




### Note!

The greater the threshold for the brake activation set in [C02581](#), the greater the dynamic portion (e. g. the speed-dependent friction torque) in the memorised torque.

For the specific case that the load is altered while the motor holding brake is closed, a correction value for the torque feedforward control can be defined via the input *BRK\_dnTorqueAdd\_n* that is added to the memorised torque.



## Further torque feedforward control options



[11-18] Feedforward control with parameterised starting torque

- ▶ Via the input *BRK\_dnTorqueAdd\_n* an additional feedforward control value can be defined.

### Application example:

In the case of a hoist drive, the load is always known. For an optimum behaviour a torque proportional to the load and additionally 10 Nm as a constant feedforward control value should be loaded into the speed controller.

- ▶ As a constant feedforward control value the starting torque 1 is used ([C02586](#) = "10 Nm", [C02588](#) = "0", and *BRK\_bStartingTorque2* = FALSE).
- ▶ Via the input *BRK\_dnTorqueAdd\_n* the torque is specified proportional to the load.

#### 11.12.2.7 Torque feedforward control via ramp function


This function extension is available from software version V3.0!

The brake control additionally offers the possibility of establishing the required torque of the drive when the brake is released via a parameterisable ramp function.

#### Settings

1. Go to [C02600](#) and set the acceleration time for the feedforward control.
2. Go to [C02601](#) and select the reference for the acceleration time:
  - Selection "0: Motor reference value":  
The acceleration time refers to the generation of the motor reference torque ([C00057/2](#)), i.e. the acceleration is constant.
  - Selection "1: Starting current value":  
The acceleration time refers to the torque requested, i. e. the acceleration time is constant.

#### Sequence



[11-19] Sequence of torque feedforward control via ramp function

### 11.12.2.8 Speed feedforward control via ramp function for V/f control

This function extension is available from software version V3.0!

For the V/f control there is the possibility of carrying out a feedforward control by means of a speed which is generated via a parameterisable ramp.



#### Note!

The operation of vertical drives/hoists is only supported up to 55 kW by the V/f control!

#### Settings:

1. Go to [C02602](#) and set the selection "1: Speed" as source for the feedforward control.
2. Go to [C02603](#) to set the speed threshold from which on the brake is to be opened.
  - [C02604](#) can be used to parameterise a second speed threshold which can be activated by setting *BRK\_bStartingTorque2* to TRUE.
3. Go to [C02600](#) and set the acceleration time for the feedforward control.
4. Go to [C02601](#) and set the reference for the acceleration time (0: Motor reference value, 1: Starting current value).

#### 11.12.3 Mode 0: Brake control is switched off

If the mode 0 is selected in [C02580](#), the brake control is switched off.

- ▶ If a motor holding brake control module is available, it will not be triggered.
- ▶ The brake monitoring function is not active.
- ▶ A potential fault reported by the brake control is reset automatically.
- ▶ The output signals of the system block LS\_Brake are reset:
  - *BRK\_dnState* = 0
  - *BRK\_bReleaseBrakeOut* = FALSE
  - *BRK\_bBrakeReleased* = FALSE
  - *BRK\_bError* = FALSE



#### Note!

In the Lenze setting the mode 0 is preset to reach a safe state after mains connection.

#### 11.12.4 Mode 1/11: Direct control of the brake

If the mode 1 or 11 has been selected in [C02580](#), the brake is directly controlled via the input *BRK\_bReleaseBrake*.



#### Tip!

Mode 1/11 can be used to easily check if the brake switches correctly.

- ▶ By the selection of the mode it is also defined in which way the brake is to be controlled:
  - Mode 1: Direct brake control via a motor holding brake control module.
  - Mode 11: Direct brake control via a digital output.



#### Note!

The digital outputs are not suitable for the "direct" control of a motor holding brake!

- The digital output used must be connected to a relay or power contactor which switches the brake supply.
- If a power contactor is used, the response and release time of the contactor contact is also added to the response and release time of the brake.

For the operation with motor holding brake control module:

- For single-axis controllers (Single Drive) the control (release) of the motor holding brake is only possible if both the DC-bus voltage and a 24-V supply voltage are available for the motor brake control!
- For multi-axis controllers (Multi Drive) the motor holding brake can also be released without a DC-bus voltage.

- ▶ Setting the pulse inhibit or controller inhibit does not influence the output signal.
- ▶ After the brake has been activated and the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".
- ▶ For the operation with a motor holding brake control module (mode 1) the desired polarity for controlling the brake can be set in [C02585](#).

#### 11.12.5 Mode 2/12: Automatic control of the brake

If mode 2 or mode 12 is selected in [C02580](#), the brake is controlled automatically, i. e. if another basic function is activated, which results in a traversing of the drive, the brake is automatically opened and operation is enabled. If the corresponding basic function is deactivated again, the drive is stopped via the basic function "[Stop](#)" and the brake is automatically closed again if the speed setpoint and the actual speed value are below the speed threshold set in [C02581](#).



#### Tip!

The mode 2/12 is the common mode for brake control.

In this mode, the *BRK\_bReleaseBrake* input should be set permanently to FALSE unless a manual release is required.

If *BRK\_bReleaseBrake* = TRUE, the brake is released permanently and the automatic control cannot close the brake.

- ▶ By the selection of the mode it is also defined in which way the brake is to be controlled:
  - Mode 2: Current monitoring active, brake is automatically controlled via motor holding brake control module.
  - Mode 12: Current monitoring deactivated, brake is controlled via digital output. If a motor holding brake control module is installed, this will also be controlled.



#### Note!

The digital outputs are not suitable for the "direct" control of a motor holding brake!

- The digital output used must be connected to a relay or power contactor which switches the brake supply.
- If a power contactor is used, the response and release time of the contactor contact is also added to the response and release time of the brake.

For the operation with motor holding brake control module:

- For single-axis controllers (Single Drive) the control (release) of the motor holding brake is only possible if both the DC-bus voltage and a 24-V supply voltage are available for the motor brake control!
- For multi-axis controllers (Multi Drive) the motor holding brake can also be released without a DC-bus voltage.

- ▶ The brake is also activated automatically if a quick stop is activated in the drive, e.g. via the basic function "[Quick stop](#)" or as a response to a fault and also in case of a controller inhibit and pulse inhibit. ▶ [Behaviour at pulse inhibit](#) (□ 551)
- ▶ By setting the input *BRK\_bDisableStop* to TRUE, an application of the brake at standstill or during quick stop can be avoided; by this the drive remains position-controlled.
- ▶ After the brake has been activated automatically and the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".
- ▶ For the operation with a motor holding brake control module (in mode 2) the desired polarity for controlling the brake can be set in [C02585](#).

#### 11.12.5.1 Behaviour at pulse inhibit

In case of pulse inhibit the brake is applied. This occurs according to the parameter setting in [C02582](#) either immediately (default setting) or delayed when the threshold set for brake activation is fallen below, which can be selected to protect the brake if high centrifugal masses occur.



#### Note!

Setting the pulse inhibit results causes the motor to coast down in a load-controlled manner until pulse enable is carried out again.

Pulse inhibit can be set in the enabled controller, e.g. due to a DC overvoltage, DC undervoltage or the "Safe torque off" request.



#### Stop!

Before setting the parameters of [C02582](#) it is important to assess the energy conditions of the machine.

The amount of energy stored in the machine can exceed the permissible switching energy of a motor holding brake at the time of pulse inhibit and can thus destroy the brake when being applied!

#### Activate the brake in any case

When [C02582](#) = "0", the brake is immediately triggered to close to prevent the mechanics from being damaged.

## Only activate the brake below the threshold set for brake activation

When [C02582](#) = "1", the brake remains released until the threshold set in [C02581](#) for brake activation has been reached to protect the brake from excessive wear.

- ▶ Braking is exclusively executed by the friction of the load mechanics.
- ▶ Only when the motor speed has reached the threshold for brake activation, the brake will be closed.



### Stop!

Do not set the threshold for brake activation in [C02581](#) too high to protect the motor holding brake from wear!



### Note!

**For the encoderless motor control types (from software version V3.0) the following applies:**

If V/f control without encoder or sensorless vector control is selected, there is no speed information for the controller in the case of pulse inhibit, therefore the threshold set in [C02581](#) for the brake activation is not effective in this case.

In order to avoid that the motor holding brake is closed in case of pulse inhibit, a waiting time for the brake activation can be parameterised in [C02593](#). In case of pulse inhibit, the motor holding brake is then only triggered to close after this application time has elapsed. ▶ [Brake activation in automatic operation](#) (□ 538)



### 11.12.5.2 Process when brake is released

The following process occurs when a basic function is requested which causes the drive to traverse:

1. The controller inhibit is deactivated.
2. A magnetic field is created in the motor required for the holding torque (is already available in synchronous machines).
3. The feedforward control torque is loaded into the speed controller.
4. If the actual torque has reached 90 % of the feedforward control torque:
  - The output *BRK\_bReleaseBrakeOut* is set to TRUE for releasing the brake.
  - Monitoring of the motor holding brake control module is deactivated temporarily.
  - Monitoring of the status input is deactivated temporarily (if switched active via [C02583](#)).
  - The brake opening time starts to elapse.
5. After the brake opening time has elapsed:
  - The output *BRK\_bBrakeReleased* is set to TRUE.
  - The requested basic function is enabled.
6. After the additional waiting time set for the status monitoring in [C02591](#) has elapsed:
  - Monitoring of the motor holding brake control module is active again.
  - Monitoring of the status input is active again (if switched active via [C02583](#)).

#### 11.12.5.3 Process when brake is closed

The following process occurs if the enable of the requested basic function for traversing the drive is deactivated again:

1. The drive is brought to standstill via the basic function "[Stop](#)", or, where required, also via the basic function "[Quick stop](#)".
2. When speed setpoint and actual speed value have fallen below the speed threshold set in [C02581](#):
  - The output *BRK\_bReleaseBrakeOut* is set to FALSE for closing the brake.
  - The current torque is saved, so that, if necessary, it can be used for feedforward control during the next start.
  - Monitoring of the motor holding brake control module is deactivated temporarily.
  - Monitoring of the status input is deactivated temporarily (if switched active via [C02583](#)).
  - The brake closing time starts to elapse.
3. After the brake closing time has elapsed and the corresponding state change of the status signal:
  - The output *BRK\_bBrakeReleased* is reset to FALSE.
  - The controller inhibit is activated.
4. After the additional waiting time set for the status monitoring in [C02591](#) has elapsed:
  - Monitoring of the motor holding brake control module is active again.
  - Monitoring of the status input is active again (if switched active via [C02583](#)).
  - Standstill monitoring is activated. ▶ [Standstill monitoring](#) (□ 537)

## 11.12.6 Mode 22: Automatic DC-injection braking

This function extension is available from software version V3.0!



### Note!

Automatic DC-injection braking is only possible if V/f control or sensorless vector control is selected as motor control type in [C00006](#)!


If mode 22 has been selected in [C02580](#), DC-injection braking is executed automatically if the current speed setpoint falls below the speed threshold set in [C02581](#).

- ▶ The automatic is only effective in the function states "Drive is stopped", "Drive at standstill", "Quick stop active", and "Fault".
- ▶ DC-injection braking is executed for the brake closing time set in [C02589](#) with the braking current set in [C00974](#).
- ▶ After the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".




### Danger!

If the braking current is set too low, or the application time is too short, controller inhibit is set and the drive becomes torqueless before being completely braked to standstill by means of DC-injection braking!



[11-20] Example 1: Speed follower active → stopping active (stopping time > brake closing time) → speed follower active

- ▶ If a basic function is requested again before the brake closing time has elapsed, DC-injection braking is interrupted and - if activated in [C00990](#) – the flying restart process is started and the basic function is activated:




[11-21] Example 2: Speed follower active → stopping active (stopping time > brake closing time) → speed follower active

### Automatic DC-injection braking when quick stop is activated

DC-injection braking is activated automatically if a quick stop is triggered in the drive, e.g. via the basic function "[Quick stop](#)" or as a response to an error.

- ▶ A change-over to the "Quick stop active" function state is effected, and for the quick stop deceleration time set in [C00105](#) a DC-injection braking process with the braking current set in [C00975](#) is carried out.
- ▶ After this time has elapsed, a change-over to the braking current parameterised in [C00974](#) is carried out and DC-injection braking is continued with this braking current.
- ▶ After the brake closing time set in [C02589](#) has also elapsed, the basic function "Brake control" automatically sets controller inhibit.
- ▶ The DC-injection braking in this case is also carried out when the "Quick stop by trouble" error response is actuated; however, instead of the "Quick stop active" function state, the "Fault" function state is active, and the controller is in the "Quick stop by trouble active" device state.



[11-22] Process example: speed follower is active → quick stop activation → speed follower is active



## Note!

The quick stop braking current in [C00975](#) has to be set so that the drive can be decelerated from the maximum operating speed to standstill within the deceleration time for quick stop set in [C00105](#)!

## 11.12.7 Grinding the brake

This function may be required after the brake has been replaced. The holding torque specified in the data sheet is only reached if the friction partners are ground in after mounting.



### Stop!

If this function is activated, the drive is automatically accelerated to the grinding speed parameterised in [C02596](#).

- The axis must move freely without driving against the travel range limitations.
- The maximally permissible friction energy of the brake must not be exceeded (observe the specifications of the manufacturer)!

$$W_{\text{total}}[\text{J}] \sim M_K[\text{Nm}] \cdot \frac{2\pi}{60} \cdot N[\text{min}^{-1}] \cdot t_{\text{total}}[\text{s}]$$

[11-23] Formula for estimating the friction energy during grinding process

### Requirements

In order to be able to activate the grinding of the brake, the following conditions must be fulfilled:

- ▶ The grinding speed in [C02596](#) is set higher than 0 rpm.
- ▶ The brake is activated, i.e. the "brake closing time" ([C02589](#)) and the "waiting time for status monitoring" ([C02591](#)) are elapsed.
- ▶ No other source for controller inhibit is active so that the controller inhibit can be deactivated by the brake control.




### Note!

When grinding the brake, ensure that the motor shaft can be kept at speed against the closed holding brake.

- For this purpose, make sure that the maximum torque of the motor control ([C00057/2](#)) is higher than the holding torque of the brake.

## Sequence

If all requirements mentioned before have been met, the grinding process can be started by setting the input *BRK\_bBrakeGrindIn* to TRUE.



- ▶ After the grinding speed has been reached, the friction partners in the brake are ground by a pulse-type control.
- ▶ After the brake has been closed and opened ten times, the direction of rotation changes and grinding in the opposite direction is carried out.
- ▶ By resetting the input *BRK\_bBrakeGrindIn* to FALSE the grinding process can be aborted.

[11-24] Sequence of the grinding operation

## 11.12.8 Carrying out brake test

This function can be used to check the holding torque of the brake.



### Tip!

You can carry out this test in regular intervals, e. g. to detect a defect or wear of the brake at an early stage.



### Note!

Due to possible deviations in the torque generation, the test of the holding torque cannot determine the holding torque exactly!

- The generated motor torque can deviate up to  $\pm 15\%$  from the default value depending on temperature.

### Requirements


In order to be able to activate the brake test, the following requirements have to be met:

- ▶ The test torque in [C02594](#) is set higher than 0 Nm.
- ▶ The permissible angle of rotation is set greater  $0^\circ$  in [C02595](#), thus standstill monitoring is active. ▶ [Standstill monitoring](#) (□ 537)
- ▶ The brake is activated, i.e. the "brake closing time" ([C02589](#)) and the "waiting time for status monitoring" ([C02591](#)) are elapsed.
- ▶ No other source for controller inhibit is active so that the controller inhibit can be deactivated by the brake control.



## Sequence

If all requirements mentioned before have been met, the brake test can be started by setting the input *BRK\_bBrakeTest* to TRUE.



[11-25] Sequence of the brake test

- ▶ The specified test torque is created via a ramp generator with an acceleration time of 1 s and held max. 4 s.
  - By this the motor shaft tries to rotate while the brake is applied.
- ▶ By resetting the input *BRK\_bBrakeTest* to FALSE the brake test can be aborted.


## Error behaviour

If during the brake test the stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#), although the brake is engaged:

- ▶ The brake test is cancelled immediately and "Quick stop by trouble" is activated as error response to avoid a further rotation/acceleration of the drive.
- ▶ The error message "Motor brake: Angular drift with closed brake too high" is entered into the logbook.
- ▶ The status "position drift when brake is applied" is displayed at the *BRK\_dnState* status output via bit 21 and the status "brake error" is displayed via bit 15.
- ▶ The *BRK\_bError* output is set to TRUE for one task cycle.

#### 11.12.9 Control of two motor holding brakes

The technical implementation is based on the control of an external relay by a digital output. The relay contact then switches an external 24-V supply for both motor holding brakes:



[11-26] Interconnection example for controlling two motor holding brakes



#### Tip!

From software version V7.0 onwards, two motor temperature sensors can be evaluated simultaneously via the two encoder inputs X7 and X8 when two motor are used (e.g. double motor for a storage and retrieval unit).

► [Temperature monitoring of a second motor](#) (📖 232)

## 11.13 Cam data management

This function extension is available from software version V3.0!

---

The basic function "Cam data management" provides different functions for the systemwide management of the cam data available in the memory module for a cam application.

- ▶ Cam data are motion profiles/characteristics, cam tracks, and position marks.
- ▶ The cam data required can either be created using the »Cam Editor« and transmitted to the controller by means of the »Engineer«, or they can be directly entered via the parameters of this basic drive function if cam data have already been downloaded.



### Note!

For the use of cam data in the controller, the licence level Motion Control TopLevel is required!

## 11.13.1 "Online" tab for cam data management

After an interconnection has been created via the electrical shaft, it is shown in the *Project* view with the axes assigned:



If you select the axis representing the 9400 HighLine controller under the electrical shaft, the **Online** tab for cam data management is provided in the *Workspace*:

### Information

A	<b>Cam data-able</b> <ul style="list-style-type: none"> <li>This property is set automatically for the controller if the controller supports cam data (licence level Motion Control TopLevel required).</li> <li><b>Note: The checkmark must not be removed, as otherwise the assignment to the cam data is lost!</b></li> </ul>
B	<b>Cam data status</b> <ul style="list-style-type: none"> <li>The first green LED for instance is lit if the cam data file in the project is active.</li> <li>When an online connection to the controller has been established, also the status of the cam data available in the controller is shown.</li> </ul>
C	Display of the current memory distribution for the cam data. ▶ <a href="#">Memory distribution</a> (📖 565)
D	Configuration of the access protection for the cam data. ▶ <a href="#">Access protection</a> (📖 566)
E	Possibility for quickly updating the cam data in the controller (without having to transfer the complete application). ▶ <a href="#">Regenerating the cam data file and transferring it to the controller</a> (📖 568)

## 11.13.1.1 Memory distribution

From software version V5.0 there are three different storage modes for the distribution of the cam data memory in the controller. The specification of the storage mode is effected automatically by the »Engineer« when the cam data file is generated.



### Note!

For controllers with a software version lower than V5.0 the memory distribution always corresponds to storage mode 1 (see following table), i. e. the max. size of the cam data file is limited to 256 kBytes.

Storage modes 2 and 3 automatically provide a greater memory for an extensive amount of cam data, however, in return certain functions are no longer supported (e. g. changing cam data via parameterisation).

Memory distribution of the cam data	Display in [bytes]	Storage mode		
		1	2*	3*
Memory module	-	262144 bytes (256 kBytes)	524288 bytes (512 kBytes)	1048576 bytes (1024 kBytes)
Internal RAM for quick download	<a href="#">C02901/1</a>	262144 bytes (256 kBytes)	0 bytes	0 bytes
Internal RAM for online change	<a href="#">C02901/2</a>	131072 bytes (128 kBytes)	262144 bytes (256 kBytes)	0 bytes
Internal RAM for cam data	<a href="#">C02901/3</a>	131072 bytes (128 kBytes)	262144 bytes (256 kBytes)	524288 bytes (512 kBytes)

\* Only from software version V5.0

Functions supported	Storage mode		
	1	2*	3*
<a href="#">Changing cam data via parameterisation</a>	●		
Quick download to the RAM	●		
<a href="#">Online change</a>	●	●	
Device command " <a href="#">Load cam data</a> "	●	●	●
Device command " <a href="#">Save cam data</a> "	●		
Device command " <a href="#">Calculate cam data</a> "	●	●	●
Device command " <a href="#">Calculate cam data checksum</a> "	●		

\* Only from software version V5.0

## 11.13.1.2 Access protection

If required, the cam data can be protected against unauthorised or unintentional change by means of a three-stage access protection concept:

### Step 1: Access protection deactivated

- ▶ There is no access protection for the upload/download of new cam data and the change of cam data via parameters.

### Step 2: Access protection via user password

- ▶ The user password must be entered for the upload/download of new cam data and the change of password-protected cam data via parameters.

### Step 3: Linking the cam data to the serial number of the memory module

- ▶ The user password must be entered for the upload/download of new cam data and the change of password-protected cam data via parameters.
- ▶ In addition, the serial number of the memory module must comply with the serial number given in the »Engineer« for the cam data.



### Note!

The settings for the access protection are firmly defined for the existing cam data and cannot be changed.

For a change of the settings the cam data have to be updated in the »Engineer« and then transferred to the controller. These two actions can be carried out on the **Online** tab via the buttons **Generate cam data file** and **Transfer cam data to the device**.

- ▶ [Regenerating the cam data file and transferring it to the controller](#) (📖 568)



### How to define a password for the cam data:

1. Click the lower **Password** button (for new password).
  - The *Change password* dialog box appears:

The dialog box titled "Change password" has a blue header. The main area is light beige and contains the text "Please enter your password for locking Cam-data of the drive". Below this text are two input fields: "Password:" and "Enter password again:". At the bottom right of the dialog box are two buttons: "OK" and "Cancel".

2. Enter desired user password.
3. Click **OK** to accept the entry and close the dialog box.



## How to change an existing password:

1. Click upper **Password** button (for existing password).
2. Enter the existing user password in the *Change password* dialog box.
3. Click **OK** to accept the entry and close the dialog box.
4. Click the lower **Password** button (for new password).
5. Enter the new user password in the *Change password* dialog box.
6. Click **OK** to accept the entry and close the dialog box.



## Tip!

An existing access protection via user password can be cancelled again by carrying out the steps described before for changing the password and simply leaving blank the input field for the new password.



## How to link the cam data to the serial number of the memory module:

Go to the **Serial number** input field and enter the serial number of the memory module.

- When an online connection to the controller has been established, you can read out the serial number of the memory module in the controller by clicking the **Read from device** button.



## Tip!

The linkage of the cam data to the serial number of the memory module can be cancelled again by carrying out the steps described before and simply leaving blank the **Serial number** input field.

### 11.13.1.3 Regenerating the cam data file and transferring it to the controller

If you transfer the parameter set or the application from the »Engineer« to the controller, the cam data are also transferred automatically to the controller.

To only regenerate the cam data file and transferring it to the controller, after the cam data have been changed in the »Cam Manager« or the settings have been changed for access protection, carry out the following steps:



#### How to update the cam data:

1. Click on the **Generate cam data file** button on the **Online** tab to regenerate the cam data file for the controller.
  - The cam data status shown and the information with regard to the memory distribution on the **Online** tab are updated. The green LED behind "In the project" is lit now, which means that the cam data file in the project is active:

Cam data status	Time stamp for data generation	Generated data volume for next transfer
In Project	23.10.2008 07:51:24	9 kbytes
In RAM		
Processing		5 kbytes
In memory module		

When an online connection has been established to the controller:


2. To transmit the cam data to the controller, click the **Download cam data** button.
  - The new/altered cam data are accepted in the controller according to the online change mode set. ▶ [Online change mode](#) (□ 573)
  - The green LED behind "In the memory module" is now lit as well, which means that the cam data file in the memory module is also active:

Cam data status	Time stamp for data generation	Generated data volume for next transfer
In Project	23.10.2008 07:51:24	0 kbytes
In RAM	23.10.2008 07:51:24	
Processing	23.10.2008 07:51:24	5 kbytes
In memory module	23.10.2008 07:51:24	



## 11.13.2 Internal interfaces | "LS\_CamInterface" system block

The **LS\_CamInterface** system block provides the internal interfaces for cam data management in the function block editor.



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
CAM_dnProductNumber <small>DINT</small>	Product number <ul style="list-style-type: none"> <li>The basic function manages the product number for all cam FBs within the application.</li> <li>The product number is displayed in the »Cam Manager« in squared brackets after the product name.</li> <li>If the product number is to be defined via parameter instead, a corresponding user code must be created in the application and connected with this input.</li> <li>The highest product number to be created is shown in <a href="#">C02908</a>.</li> </ul>
CAM_bActivateProduct <small>BOOL</small>	Activate product <ul style="list-style-type: none"> <li>The change-over to another product is caused by an event which is generated from the application.</li> </ul> <p style="text-align: center;">TRUE    The product with the product number at input <i>CAM_dnProductNumber</i> is activated.</p>
CAM_bActivateNewData <small>BOOL</small>	Reload cam data from the backup memory (controlled acceptance) <ul style="list-style-type: none"> <li>Only possible if the online change mode "10: Manual Activation" is set in <a href="#">C02905</a>.</li> <li>If the online change mode "16: Automatic activation with CINH" (Lenze setting) or "15: Automatic activation" is set in <a href="#">C02905</a>, the new cam data are accepted immediately after a download and this input has no function.</li> <li>The current status of the data acceptance is shown in <a href="#">C02906</a>.</li> </ul> <p style="text-align: center;">TRUE    Reload cam data from the backup memory.</p>

### Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
CAM_dnActiveProduct <small><a href="#">C02909</a>   DINT</small>	Product number of the currently active product
CAM_bDownloadBusy <small>BOOL</small>	Status signal "Download/data change active" <ul style="list-style-type: none"> <li>The current status of the data acceptance is shown in <a href="#">C02906</a>.</li> </ul> <p style="text-align: center;">TRUE    Currently the cam data in the RAM of the controller are changed.</p> <ul style="list-style-type: none"> <li>For instance, due to parameter set transfer, device command C00002 = "501: Load cam data" or change of the cam data via parameters.</li> </ul> <p style="text-align: center;">TRUE↔FALSE    Download/data change completed.</p> <ul style="list-style-type: none"> <li>In order to detect if the download/ the data change has been completed correctly, the <i>CAM_bError</i> error output should also be evaluated.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Cam data management

Identifier DIS code   data type	Value/meaning	
CAM_bNewDataAvailable BOOL	Status signal "New cam data available"	
	TRUE	The internal recalculation of the new/changed cam data is completed and the cam data are ready for acceptance. <ul style="list-style-type: none"> <li>The time when the new/altered cam data are accepted depends on the online change mode set in <a href="#">C02905</a>. ▶ <a href="#">Online change mode (□ 573)</a></li> <li>In the Lenze setting the new/altered cam data are accepted automatically as soon as the controller inhibit is set within the controller.</li> <li>If the online change mode "15: Automatic activation" is set in <a href="#">C02905</a>, the new/changed cam data are accepted immediately after the internal recalculation and the TRUE signal is only pending for one task cycle.</li> </ul>
CAM_bError BOOL	TRUE↔FALSE	The new/changed cam data have been accepted.
	TRUE	"Fault" status signal" An error has occurred (group signal).

## 11.13.3 Parameter setting

Short overview of the parameters for cam data management:

Parameter	Information	Effective in storage mode		
		1	2*	3*
<a href="#">C00198</a>	Axis number	●	●	●
<a href="#">C02900</a>	User Password	●	●	●
<a href="#">C02901</a>	Cam storage capacity	●	●	●
<a href="#">C02902</a>	Time stamp of cam data	●	●	●
<a href="#">C02903</a>	GUID cam data	●	●	●
<a href="#">C02905</a>	Online change mode	●	●	
<a href="#">C02906</a>	Online change status	●	●	●
<a href="#">C02908</a>	Number of products	●	●	●
<a href="#">C02909</a>	Active Product	●	●	●
<a href="#">C02910</a>	Product Name	●	●	●
<a href="#">C02911</a>	Product Choice	●	●	●
<a href="#">C02912</a>	Number of products	●		
<a href="#">C02919</a>	Number of curve tracks	●		
<a href="#">C02920</a>	Cam Track Choice	●	●	●
<a href="#">C02921</a>	Cam Track Type	●		
<a href="#">C02922</a>	Number of Cam Data Points	●		
<a href="#">C02923</a>	Cam Data Point Choice	●	●	●
<a href="#">C02924</a>	Change Cam Data Point X	●		
<a href="#">C02925</a>	Change Cam Data Point Y	●		
<a href="#">C02926</a>	Change Cam Data Point M	●		
<a href="#">C02927</a>	Auto Inc Cam Data Points	●	●	●
<a href="#">C02939</a>	Number of Cont Tracks	●		
<a href="#">C02940</a>	Cont Track Choice	●	●	●
<a href="#">C02941</a>	Cont Type	●	●	●
<a href="#">C02942</a>	Number of Cont Data Points	●		
<a href="#">C02943</a>	Cont Data Point Choice	●	●	●
<a href="#">C02944</a>	Cont Pos X0	●		
<a href="#">C02945</a>	Cont Pos X1	●		
<a href="#">C02946</a>	Cont Time	●		
<a href="#">C02959</a>	Number of Position Tracks	●		
<a href="#">C02960</a>	Pos Track Choice	●	●	●
<a href="#">C02962</a>	Number of Pos Data Points	●		
<a href="#">C02963</a>	Pos Data Point Choice	●	●	●
<a href="#">C02964</a>	Change Pos Data Point X	●		
<a href="#">C02965</a>	Change Pos Data Point Y	●		

Highlighted in grey = display parameter

\* Storage modes 2 and 3 are only available from software version V5.0. Parameters that are not effective are set to zero.

## 11.13.3.1 Password entry

If a password has been defined for the cam data in the »Engineer«, the defined user password must be entered once to execute the following actions:

- ▶ Download of new cam data during operation  
→ Entry of the existing password in the »Engineer«.
- ▶ Change of the cam data via parameter setting  
→ Entry of the existing password in [C02900](#).
- ▶ Loading/saving of the cam data  
→ entry of the existing password in [C02900](#).



### Note!

From software version [V4.0 onwards](#), you do not need to enter a possibly existing user password ([C02900](#)) if you want to save the cam data.



### Tip!

The access protection for the cam data can be configured on the **Online** tab.  
▶ ["Online" tab for cam data management](#) (📖 564)

### Validity

The user password entered in [C02900](#) is maintained until the next download, mains switching, or until reset by the user (logout).

- ▶ You can "log out" deliberately by entering an invalid password into [C02900](#).

### Behaviour in case of invalid entry

If the user password is entered incorrectly three times, the cam data are blocked. A correct entry resets the number of the failed attempts.

To remove the blocking of the cam data, there are two possibilities:

- A. Resetting the parameters to the Lenze setting via device command [C00002](#) = "0: Load Lenze setting".
  - When the Lenze setting is loaded, the cam data are deleted.
  - Afterwards the cam data can be transferred to the device again.
- B. Transfer complete application to the device again.
  - The application available and the cam data are deleted and all data are transferred to the device again.

## 11.13.3.2 Online change mode

During running operation, new cam data can be downloaded from the »Engineer« to the controller if the controller is in storage mode 1 or 2.

- ▶ If the cam data are provided with an access protection, the user password has to be entered first. ▶ [Access protection](#) (□ 566)
- ▶ The time when the new/alterd cam data are accepted depends on the online change mode set in [C02905](#).



### Note!


If the controller is in storage mode 3, the "Online change" function is deactivated:

- The online change mode set in [C02905](#) is ineffective.
- In [C02906](#) the status "999: Online change deactivated" is displayed.
- For the download of new cam data, controller inhibit is required.
- The cam data are accepted immediately after download.

▶ [Memory distribution](#) (□ 565)

### Mode 16: Automatic activation with CINH

In the Lenze setting, the online change mode "Automatic activation with CINH" is set in [C02905](#), i.e. the new cam data are accepted automatically as soon as the controller is inhibited.




[11-27] Online change mode "Automatic activation with CINH"

## Mode 15: Automatic activation

In the online change mode "Automatic activation", the new cam data are accepted directly after the internal recalculation of the data from the application unit [unit] into the internal unit [increments] has been completed.


- ▶ The controller does not need to be inhibited for acceptance.



[11-28] Online change mode "Automatic activation"

## Mode 10: Manual activation

In the online change mode "Manual activation", the new cam data are accepted when the *CAM\_bActivateNewData* control input is set to TRUE.



[11-29] Online change mode "Manual activation"

### 11.13.3.3 Changing cam data via parameterisation

If required, the cam data (motion profiles/characteristics, cams, and position markers) can be changed via corresponding parameters if the controller is in storage mode 1.

- ▶ If the cam data are provided with an access protection, the user password has to be entered in [C02900](#) first. ▶ [Access protection](#) (□ 566)
- ▶ **From software version V4.0 onwards**, the time stamp of the cam data is updated if the cam data are changed by parameter setting. This enables, for instance, the »Engineer« to recognise that the cam data of the »Engineer« project and those of the controller differ.



#### Note!

If the controller is in storage mode 2 or 3, the cam data cannot be changed via parameterisation. All parameters for change are ineffective and set to zero.

▶ [Memory distribution](#) (□ 565)

If the cam data of the controller have been changed by parameter setting, the [C00002](#) = "504: Calculate Cam Checksum" device command has to be executed afterwards. ▶ [Calculate cam data checksum](#) (□ 100)

Then the cam data can be converted into the internal format with the "503: Calculate Cam Data" device command or saved on the memory module in a powerfail-proof manner with the "502: Save Cam Data" device command.

▶ [Calculate cam data](#) (□ 99) / ▶ [Save cam data](#) (□ 97)

**From software version V4.0 onwards**, the changed cam data and the parameters can be saved together on the memory module in a powerfail-proof manner with the [C00002](#) = "11: Save start parameters" device command. ▶ [Save start parameters](#) (□ 56)



#### How to change an interpolation point in a curve (motion profile or characteristic):

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02920](#) and set the track number of the curve track to be edited.

#### Tip!

In [C02921](#) the curve type, and in [C02922](#) the number of interpolation points of the curve selected is shown.

3. Set the interpolation point to be edited in [C02923](#).
4. Change the desired parameters of the selected grid point:
  - [C02924](#): x position
  - [C02925](#): y position
  - [C02926](#): Torque feedforward control value  
(only in case of a motion profile with feedforward control.)



## Tip!

[C02927](#) serves to activate a grid point auto increment if several successive grid points are to be changed.

- When the grid point auto increment is activated, it is automatically incremented to the next grid point every time the y position is written into [C02925](#) so that the specification of the grid point to be changed in [C02923](#) is only required once.



## How to change several successive grid points (auto increment):

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02920](#) and set the track number of the curve track to be edited.

## Tip!

In [C02921](#) the curve type, and in [C02922](#) the number of interpolation points of the curve selected is shown.

3. Set selection "1: Activate" in [C02927](#) to activate the grid point auto increment.
4. Set the grid point from which on the grid point auto increment is to be started in [C02923](#).
5. Set the following parameters for the grid point set in [C02923](#) in the given order:
  - [C02924](#): x position
  - [C02926](#): Torque feedforward control value (only in case of a motion profile with feedforward control.)
  - [C02925](#): y position

After the y position is written into [C02925](#) it is automatically incremented to the next grid point.

6. Set the parameters for the next grid point in the same order:
  - [C02924](#): x position
  - [C02926](#): Torque feedforward control value (only in case of a motion profile with feedforward control.)
  - [C02925](#): y position
7. Repeat step 4 until all grid points are changed.

**Note:** Do not change more grid points than available (depending on the start grid point). Changing a non-available grid point causes an error message!





## How to change a cam:

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02940](#) and set the track number of the cam track to be edited.

### Tip!

The cam type is displayed in [C02941](#) and the number of cams of the selected cam data is displayed in [C02942](#).

3. Go to [C02943](#) and set the cam to be edited.
4. Change the desired parameters of the selected cam:
  - [C02944](#): Cam position X0
  - [C02945](#): Cam position X1
  - [C02946](#): Cont Time (for position/time cams)



## How to change a position mark:

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02960](#) and set the track number of the position track to be edited.

### Tip!

In [C02962](#) the number of the position marks of the position data selected is shown.


3. Set the position mark to be edited in [C02963](#).
4. Change the desired parameters of the selected position mark:
  - [C02964](#): x position
  - [C02965](#): y position

## 11.13.4 Product/track change-over

### Product change-over

The change-over to another product number is effected for all cam FBs within the application via the basic function "Cam data management".

- ▶ The change-over is effected via the input *CAM\_bActivateProduct* on the basis of an event that is generated from the application.
- ▶ By setting the input *CAM\_bActivateProduct* to TRUE, the product is activated with the product number at input *CAM\_dnProductNumber*.




[11-30] Principle: Product change-over

### Track change-over

The change-over to another curve track, cam track, or position track, however, is individually effected via the input *dnTrackNumber* at the respective cam function block.

- ▶ For the two FBs *L\_CamProfiler* and *L\_CamContactor* it can be parameterised whether the track change-over is to be effected in the next zero crossing of the x axis or immediately (Lenze setting: in the next zero crossing).



[11-31] Principle: Track change-over

## 11.13.5 Invalid cam data due to changed machine parameters

This function extension is available from software version V4.0!

If one or more machine parameters affecting the internal scaling of the cam data are changed, the message "Cam Data: Invalidated due to change of mechanical data" (error number [0x00b80034](#)) is entered into the logbook and the error response "Warning" occurs.

- ▶ The cam data are no longer valid and have to be recalculated.
- ▶ The warning is automatically reset if the [C00002](#) = "503: Calculate Cam Data" device command is executed. ▶ [Calculate cam data](#) (📖 99)

### Machine parameters affecting the internal scaling of the cam data:

Parameter	Information
<a href="#">C00006</a>	Selection of the motor control
<a href="#">C00100</a>	Resolution of an encoder revolution
<a href="#">C02520</a> / <a href="#">C02521</a>	Gearbox factor - motor (if motor = reference source)
<a href="#">C02522</a> / <a href="#">C02523</a>	Gearbox factor - position encoder (if position encoder = reference source)
<a href="#">C02524</a>	Feed constant
<a href="#">C02570</a>	Position control structure

## 11.13.6 Behaviour after mains switching

After mains switching, the cam data are loaded from the memory module into the controller between loading and start of the application.



### Note!

During the initialisation no check of the user password takes place, but a check of the serial number of the memory module is carried out, if this access protection has been activated by the user in the »Cam Designer«. If the serial number specified and the serial number of the memory module do not match, the cam data are not loaded.

- The "Cam data: serial number" error message is entered in the logbook.
- The "Warning locked" error response occurs.

If a download of cam data that was carried out before mains switching was not completed correctly, the previous cam data – if available – are loaded by the memory module.

- The "Cam data restored" error message is entered into the logbook.
- The "Fault" error response occurs.
- After the error is reset (acknowledged), operation with the previous cam data is possible.

## 11.14 Pole position identification

This function extension is available from software version V7.0!

The device commands "Identify pole position (360°)" and "Identify pole position (min. motion)" serve to execute an identification of pole position to detect the pole position to the motor encoder currently activated in [C00495](#).

From software version V7.0 onwards, the identification of pole position is additionally available as a basic function in the form of the [LS PolePositionIdentification](#) system block.



### Note!


An identification of pole position is only required:

- For servo control with synchronous motor of a third-party manufacturer.
- For servo control with synchronous motor and use of incremental encoders (TTL or sin/cos encoders as well as multi-pole-pair resolvers).
- After changes of the motor feedback system, e.g. encoder exchange.

Detailed information on the identification of pole position can be found in the subchapter "[Pole position identification](#)" for the motor interface. (📖 136)

## 11.14.1 Internal interfaces | System block "LS\_PolePositionIdentification"

The **LS\_PolePositionIdentification** system block provides the internal interfaces for the basic function "identification of pole position" in the function block editor.



### Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
PPI_bEnable <a href="#">C02789/1</a>   BOOL	Requesting control via the basic function. TRUE If no other basic function is active, a change-over to the "Identification of pole position active" function state is effected and an identification of pole position can be carried out via the control inputs. TRUE↔FALSE An active identification of pole position is stopped, i.e. a change-over from the active "Identification of pole position active" function state back to the "Controller not ready" basic state is effected.
PPI_bStart <a href="#">C02789/2</a>   BOOL	Start pole position identification FALSE↗TRUE Pole position identification is started in the mode selected in <a href="#">C02786</a> .
PPI_bLoadPolePosition <a href="#">C02789/3</a>   BOOL	Start pole position identification FALSE↗TRUE The pole position angle applied at <i>PPI_dnPolePosition</i> is accepted in <a href="#">C00058/x</a> . • The subcode to be described of <a href="#">C00058</a> depends on the motor encoder selected in <a href="#">C00495</a> .
PPI_dnPolePosition <a href="#">C02788</a>   DINT	Pole position angle in [°] with one decimal position • Value range: -179.9 ... +179.9 °
PPI_bResetPolePosition <a href="#">C02789/4</a>   BOOL	Reset "Pole position known" status FALSE↗TRUE The status outputs <i>PPI_bDone</i> and <i>PPI_bPolePositionAvailable</i> are reset to FALSE.

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
Ppi_dnState <a href="#">C02787</a>   DINT	Status (bit coded) <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul>
	Bit 1 Pole position identification active.
	Bit 2 Pole position identification completed.
	Bit 14 Pole position known.
	Bit 15 An error has occurred (group signal).
PPI_bEnabled <a href="#">C02789/5</a>   BOOL	Status signal "Basic function is enabled"
	TRUE Pole position identification via the control inputs is possible. <ul style="list-style-type: none"> <li>The <i>PPI_bEnable</i> enable input is set to TRUE and the controller is in the "Pole position identification active" function state.</li> </ul>
PPI_bActive <a href="#">C02789/6</a>   BOOL	Status signal "Basic function is active"
	TRUE Pole position identification is active. <ul style="list-style-type: none"> <li>Output is reset to FALSE if the <i>PPI_bStart</i> is reset to FALSE, the controller enable is deactivated or an error has occurred.</li> </ul>
PPI_bDone <a href="#">C02789/7</a>   BOOL	Status signal "Basic function is ready"
	TRUE Pole position identification is completed. <ul style="list-style-type: none"> <li>Output is reset to FALSE when input <i>PPI_bStart</i> is reset to FALSE.</li> </ul>
PPI_bError <a href="#">C02789/8</a>   BOOL	"Fault" status signal"
	TRUE An error has occurred (group signal).
PPI_bPolePositionAvailable BOOL	Status signal "Pole position is known"
	TRUE The drive knows the pole position. <ul style="list-style-type: none"> <li>The value written into <a href="#">C00058/x</a> corresponds to the pole position (x depends on the motor encoder selected in <a href="#">C00422</a>).</li> </ul>

#### 11.14.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Pole position identification*
- ▶ Short overview of parameters for pole position identification:

Parameter	Information
<a href="#">C02785</a>	Activation of PPI
<a href="#">C02786</a>	Mode of PPI
<a href="#">C02787</a>	Ppi_dnState
<a href="#">C02788</a>	PolePosition Setpoint
<a href="#">C02789</a>	PolePositionIdentification: Dig. signals

Highlighted in grey = display parameter

#### 11.14.3 Execute pole position identification

##### Requirements

- ▶ The controller inhibit is active.
- ▶ The controller has the "Controller not ready" function state.
- ▶ The basic function "Pole position identification" is part of the active application.
- ▶ No other basic function is active.

##### Activate basic function

To request the control via the basic function, the *PPI\_bEnable* enable input in the application must be set to TRUE.

- ▶ If no other basic function is active, a change-over to the "Identification of pole position active" function state is effected and an identification of pole position can be carried out via the control inputs.
- ▶ A successful change to the function state "Pole position identification" is displayed by a TRUE signal at the *PPI\_bEnabled* status output.

##### Start pole position identification



##### Danger!

The machine must not be braked or blocked during the pole position identification! For this reason, the pole position identification is not permitted for hanging loads!

During the pole position identification the rotor aligns itself. The motor shaft moves by max. one electrical revolution which causes the corresponding movement of the connected mechanical components!





## Stop!

Check the correct parameterisation of the max. motor current monitoring ([C00619](#) and [C00620](#)) before carrying out the pole position identification to prevent the motor from being permanently damaged.

By setting the *PPI\_bStart* control input to TRUE, the pole position identification is started in the mode selected in [C02786](#).

- ▶ The procedure starts with controller enable, if
  - a synchronous machine is selected,
  - no other identification is active,
  - no error has occurred, and
  - no test mode is activated.
- ▶ If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated via *PPI\_dnState*.



## Note!


Detailed information on the identification of pole position can be found in the subchapter "[Pole position identification](#)" for the motor interface. ([136](#))

## Deactivation


When the *PPI\_bEnable* enable input is reset to FALSE, an active pole position identification is stopped.

- ▶ If the pole position identification is aborted, no change is made in [C00058/x](#).
- ▶ The *PPI\_bEnabled* status output is reset to FALSE and a change-over from the active "Pole position identification active" function state back to the basic "Controller not ready" state is carried out.


## 11.14.4 Signal characteristics



[11-32] Signal characteristic 1: Normal procedure of the pole position identification



[11-33] Signal characteristic 2: Load pole position



[11-34] Signal characteristic 3: Reset pole position

## 11.14.5 Impacts of parameter changes on the signal PPI\_bPolePositionAvailable

### Changing the type of motor control (C00006)

Initial situation 1	Parameter change	Impact
<ul style="list-style-type: none"> <li>• <i>PPI_bPolePositionAvailable</i> = TRUE</li> <li>• Motor control (C00006) = "1: SC: Servo control sync. motor"</li> </ul>	In <a href="#">C00006</a> another motor control is set.	<i>PPI_bPolePositionAvailable</i> remains on TRUE since the signal is irrelevant for an asynchronous motor.

Initial situation 2	Parameter change	Impact
<ul style="list-style-type: none"> <li>• <i>PPI_bPolePositionAvailable</i> = TRUE</li> <li>• Motor control (C00006) =                             <ul style="list-style-type: none"> <li>–"2: SC: Servo control async. motor" or</li> <li>–"4: SLVC: Sensorless vector control" or</li> <li>–"6: VFCplus: V/f control" or</li> <li>–"7: VFCplus: V/f control"</li> </ul> </li> </ul>	In <a href="#">C00006</a> , the motor control "1: SC: Servo control sync. motor" is set.	<i>PPI_bPolePositionAvailable</i> is reset to FALSE since the signal is relevant for a synchronous motor and apparently a new motor has been selected.

### Changing relevant motor data

Initial situation	Parameter change	Impact
<i>PPI_bPolePositionAvailable</i> = TRUE	One of the following parameters is changed: <ul style="list-style-type: none"> <li>• Rated motor speed (<a href="#">C00087</a>)</li> <li>• Rated motor frequency (<a href="#">C00089</a>)</li> <li>• Rated motor voltage (<a href="#">C00090</a>)</li> </ul>	<i>PPI_bPolePositionAvailable</i> is reset to FALSE since it is assumed that the connected motor has been changed.

### Changing relevant encoder data

Initial situation	Parameter change	Impact
<i>PPI_bPolePositionAvailable</i> = TRUE	One of the following parameters is changed: <ul style="list-style-type: none"> <li>• Resolver - number of pole pairs (<a href="#">C00080</a>)</li> <li>• Encoder - number of increments (<a href="#">C00420</a>)</li> <li>• Encoder type (<a href="#">C00422</a>)</li> <li>• TTL encoder signal evaluation (<a href="#">C00427</a>)</li> <li>• Motor encoder selection (<a href="#">C00495</a>)</li> </ul>	<i>PPI_bPolePositionAvailable</i> is reset to FALSE.

## Behaviour after mains ON

Initial situation 1	Behaviour after mains ON
<ul style="list-style-type: none"> <li>• <math>PPI\_bPolePositionAvailable = TRUE</math></li> <li>• Motor control (C00006) = "1: SC: Servo control sync. motor"</li> <li>• Resolver - number of pole pairs (C00080) &gt; 1</li> </ul>	<p><math>PPI\_bPolePositionAvailable</math> is only reset to FALSE if:</p> <ul style="list-style-type: none"> <li>• Motor encoder selection (C00495) = "0: Resolver to X7"</li> </ul> <p><b>AND</b></p> <ul style="list-style-type: none"> <li>• number of motor pole pairs are (C00059) <u>no</u> integer multiple of the number of resolver pole pairs (C00080).</li> </ul>
<b>Examples:</b>	
<p>MSC motor Motor - number of pole pairs = 4 Resolver - number of pole pairs = 1</p>	The $PPI\_bPolePositionAvailable$ output is <u>not</u> reset to FALSE.
<p>Kuka motor Motor - number of pole pairs = 4 Resolver - number of pole pairs = 4</p>	
<p>Torque motor Motor - number of pole pairs = 12 Resolver - number of pole pairs = 6</p>	

Initial situation 2	Behaviour after mains ON
<ul style="list-style-type: none"> <li>• <math>PPI\_bPolePositionAvailable = TRUE</math></li> <li>• Motor control (C00006) = "1: SC: Servo control sync. motor"</li> <li>• Encoder type (C00422) = – "0: Incremental encoder (TTL signal)" or – "1: Sine/Cosine encoder"</li> <li>• Motor encoder selection (C00495) = "1: Encoder to X8"</li> </ul>	$PPI\_bPolePositionAvailable$ is reset to FALSE.

## Behaviour after encoder error

Initial situation	Behaviour after encoder error
<ul style="list-style-type: none"> <li>• <math>PPI\_bPolePositionAvailable = TRUE</math></li> <li>• Motor control (C00006) = "1: SC: Servo control sync. motor"</li> <li>• Encoder type (C00422) = – "0: Incremental encoder (TTL signal)" or – "1: Sine/Cosine encoder" or</li> <li>• Motor encoder selection (C00495) = "1: Encoder to X8"</li> </ul>	$PPI\_bPolePositionAvailable$ is reset to FALSE.

## Behaviour after resolver error

Initial situation	Behaviour after resolver error
<ul style="list-style-type: none"> <li>• <math>PPI\_bPolePositionAvailable = TRUE</math></li> <li>• Motor control (C00006) = "1: SC: Servo control sync. motor"</li> <li>• The number of motor pole pairs are (C00059) <u>no</u> integer multiple of the number of resolver pole pairs (C00080).</li> <li>• Motor encoder selection (C00495) = "0: Resolver to X7"</li> </ul>	$PPI\_bPolePositionAvailable$ is reset to FALSE.

## 12 Oscilloscope

The oscilloscope function integrated in the controller can be used as support for commissioning, maintenance, and troubleshooting.

### Typical applications

- ▶ Graphical representation of any measured values (e.g. speed setpoint, actual speed, and torque)
- ▶ Detection of process values without additional measuring instruments (e.g. oscilloscope, voltmeter, and ammeter)
- ▶ Convenient documentation for fine tuning of control circuits or parameter changes of the controller
- ▶ Documentation of production quality in the context of product liability and quality assurance

### Special features

- ▶ Recording and saving measured values in the controller
- ▶ Measuring on eight independent channels at the same time
- ▶ Measuring fast and slow signals by adjustable sample rate
- ▶ Triggering on channel, variable, or error message
- ▶ Detecting measured values before and after a trigger event (pre-/post-trigger)
- ▶ Graphical representation and evaluation of measured values on a PC
- ▶ Cursor and zoom function for the measurement analysis
- ▶ Saving & loading of oscilloscope configurations
- ▶ Exporting measured values via the clipboard for further processing

### 12.1 Technical data

Servo Drives 9400	
Memory depth	Max. 16384 measured values, depending on the number of channels and the size of the variables to be recorded.
Memory capacity	32768 bytes
Data width of a channel	1 ... 4 bytes, corresponding to the size of the variables to be recorded
Number of channels	1 ... 8
Trigger level	Corresponding to the value range of the variable to be triggered
Trigger selection	Immediate triggering, rising/falling edge, signal change
Trigger delay	-100 % ... +400 %
Trigger source	Channels 1 ... 8, any variable or error message
Max. time base	8 channels 32 bits each $\equiv$ 26 hours
Max. recording time	8 channels 32 bits each $\equiv$ 10 days

## 12.2 Functional description

With an online connection to the controller, use the oscilloscope user interface of the »Engineer« to set the trigger condition and the sample rate and select the variables to be recorded.

When the measurement is started, the set parameters are transferred to the controller and checked. If invalid settings are found, the oscilloscope sends an error. Otherwise, the measurement is started.

With an online connection, the measured controller data are transferred to the »Engineer« and graphically represented on the oscilloscope user interface as soon as the measurement has been completed.

### Recording variable values

The operating system scans the oscilloscope in fixed 1 ms-cycles, i.e. the oscilloscope can record variable values with a sample rate of max. 1 kHz.

### Recording system variable values of the internal motor control

Unlike the variables declared in the application, the system variables of the internal motor control (MCTRL) can also be recorded with a sample rate higher than 1 kHz.



#### Note!

In the servo operating modes, recordings with a time-based resolution of 31.25  $\mu$ s and 125  $\mu$ s are not possible!

In comparison to all other variable values, the system variables of the internal motor control have a cycle offset of 2 ... 3 ms!

For recording with sample rates of 1 kHz, up to three measured values are missing at the left and right edges of the oscilloscope screen. This can only be noticed for very small time-based deflections  $\leq 1$  ms / div. The missing measured values are system-dependent and caused by oversampling.

### Recording I/O variable values referring to a task

When selecting the variables to be measured, it is possible to indicate a task reference for the variables. If the behaviour of a certain task is to be examined, you can indicate the task reference to exactly record the values valid for the task run-time.

- The variable values are recorded during the process output image generation of the task.


## 12.3 User interface



**How to go to the oscilloscope user interface:**

1. Select the controller in the *Project view*.
2. Select the **Oscilloscope** tab from the *Workspace*.

The oscilloscope user interface contains the following control and function elements:



[A](#) [Oscilloscope toolbar](#)

[B](#) [Data record selection](#)

[C](#) [Oscillograph](#)

[D](#) [Vertical settings](#)

[E](#) [Status bar](#)

[F](#) [Trigger/cursor settings](#)










[G](#) [Horizontal settings](#)

[H](#) [Recording settings](#)

[I](#) [Comment](#)



### 12.3.1 Oscilloscope toolbar

Icon	Function
	<a href="#">Loading/importing a data record</a> (📖 605)
	<a href="#">Close data record</a> (📖 606)
	<a href="#">Saving/exporting a data record</a> (📖 604)
	<a href="#">Copying a data record to the clipboard</a> (📖 607)
	<a href="#">Deleting a data record in the project</a> (📖 606)
	Print oscillogram
	Activate zoom function ▶ <a href="#">Adjusting the representation</a> (📖 600)
	Activate automatic scaling function ▶ <a href="#">Adjusting the representation</a> (📖 600)
	<a href="#">Comment data record</a> (📖 603)

### 12.3.2 Oscillograph

The oscillograph is used to visualise data records.

- ▶ Use the zoom and the automatic scaling function to adjust the representation.
- ▶ The measured data represented in the form of interpolated curves can be optionally shown and hidden, represented in any colour or overlaid with the signal characteristics of other variables recorded.

## 12.3.3 Vertical settings

Use the **Vertical** list field to configure the variables to be recorded.

- ▶ Simply click into a field to alter the corresponding setting.

Column	Name	Meaning
1	-	Curve colour for representation in the oscillograph
2	Ch	Channel number
3	On	On/off
4	Inv	Inversion on/off
5	Variable	Selection of variable to be recorded
6	Unit	Scaling
7	1/div	Vertical scale factor
8	Offset	Offset value <ul style="list-style-type: none"> <li>• The offset value depends on the scale factor and is marked by a dotted line in curve colour at the left edge of the oscillograph.</li> </ul>
9	Position	Position value <ul style="list-style-type: none"> <li>• The position value is independent of the scale factor and is marked by a line at the left edge of the oscillograph.</li> </ul>

## 12.3.4 Status bar

The status messages are displayed in the status bar.

## 12.3.5 Trigger/cursor settings

### Trigger

If the **Trigger** button has been pressed, the input fields for configuring the trigger condition are shown. ▶ [Selecting the trigger condition](#) (📖 598)

### Cursor

If the **Cursor** tab has been pressed instead, you can use a vertical measuring line to read individual measured values of a selectable channel in the oscilloscope. Using a second vertical measuring line, it is possible to indicate the difference between two measured values. ▶ [Reading individual measured values](#) (📖 601)

Group box	Meaning
Channel	Channel selection
Value	Display of the value measured at the position of the active measuring line
Difference	Display of the difference between the values measured at the two measuring lines

### 12.3.6 Horizontal settings

Use the **Horizontal** group box to select the time base and the horizontal position.

▶ [Selecting the recording time/sample rate](#) (□ 597)

Input field	Meaning
Time base [1/Div]	Selection of time base <ul style="list-style-type: none"> <li>• The current time base setting multiplied by ten results in the recording time.</li> <li>• Change the time base to stretch or compress measurements that have already been completed.</li> </ul>
Position	Selection of the horizontal display position <ul style="list-style-type: none"> <li>• The position value can be directly entered into the input field or selected using the arrow buttons.</li> <li>• When the arrow buttons are used and the &lt;Ctrl&gt; key is pressed, you can increase the step size to accelerate the shift.</li> </ul>

### 12.3.7 Recording settings

Use the **Recording** group box to select the sample rate and start recording.

▶ Since the measured data memory has a limited capacity, a compromise must be found between the sample rate and the recording time that results from the time base setting. ▶ [Selecting the recording time/sample rate](#) (□ 597)

## 12.4 Operation

This chapter describes step-by-step how to record the signal characteristics of controller variables and represent, analyse, document and process them in the oscilloscope.



### Note!

In the oscilloscope, settings can only be selected and recording can only be started, when the controller is connected online.

### 12.4.1 Selecting the variables to be recorded

The oscilloscope supports up to eight channels, i.e. max. eight variables can be recorded in a data record. Use the **Vertical** group box to select the variables.



#### How to select a variable for recording:

1. Go to the **Variable** column in the **Vertical** group box and double-click the yellow field to open the *Select variable* dialog box.
2. Select the variable to be recorded from the list field.
3. Click **OK**.
  - The dialog box is closed and the selection is accepted.
4. Repeat steps 1 ... 3 to select up to seven more variables to be recorded.

Of course, it is possible at any time to change or delete a selection later.



#### How to change a selection:


1. Go to the **Vertical** group box and double-click the variable to be changed in the **Variable** column.
2. Select a new variable in the *Select variable* dialog box.
3. Click **OK**.
  - The dialog box is closed and the selection is accepted.

**How to delete a selection:**

1. Go to the **Vertical** group box and double-click the variable to be removed in the **Variable** column.
2. Click **Delete channel** in the *Select variable* dialog box.
  - The dialog box is closed and the selection is deleted.

**12.4.2 Selecting the recording time/sample rate****How to select the recording time and the sample rate:**

1. Go to the **Horizontal** group box and select the desired time base from the **Time base** list field.
  - The current time base setting multiplied by ten results in the recording time.
  - Since the measured data memory of the controller has a limited capacity, usually a compromise is made between sample rate and recording time.
2. Enter the desired sampling rate in [ms] in the **Sampling rate** input field of the **Recording** group field.
  - By pressing the **...** button behind the **Sampling rate** input field, you open the *Sampling rate* dialog box where you can also select the option **Increased sampling rate**:

**Note!**

When the option **Increased sampling rate** is selected, only integer multiples of 1/ (sampling rate in ms) are detected by the system.

- Since a complete representation in the oscillograph requires  $(10 * 1/(\text{sample rate in ms}) * (\text{horizontal resolution in ms/div})) + 1$  measured values, but due to system-dependent reasons only integer multiples of  $(1 / (\text{sample rate in ms}))$  can be recorded, 1 to 3 measured values may be missing at the left or right edges of the oscillograph. The displayed curve then ends before the end or starts after the start of the oscillograph. The curve is not compressed or extended.
- The curve that is recorded is not extended or compressed.

## 12.4.3 Selecting the trigger condition

The trigger condition serves to define the starting time of recording in the controller. The oscilloscope provides various trigger conditions by means of which recording of the measured values can be controlled.



If the cursor display is activated, press the **Trigger** button to show the input fields for configuring the trigger condition.

Setting	Function
<b>Source</b>	Selection of trigger source:
Variable	The oscilloscope triggers on any variable of the PLC program. <ul style="list-style-type: none"> <li>• Unlike triggering on a channel, triggering on a variable requires no recording channel.</li> </ul>
Channel	The oscilloscope triggers on a channel configured in the <b>Vertical</b> table.
System event	Triggering is started on occurrence of a selectable controller event (e.g. TRIP, trouble or warning). <ul style="list-style-type: none"> <li>• Select a negative trigger delay to record signals prior to occurrence of the event.</li> </ul>
Force trigger	No trigger condition, recording starts immediately after the start.
<b>Trigger value</b>	Value from which on triggering is activated. <ul style="list-style-type: none"> <li>• The trigger level is not effective for triggering on Boolean variables.</li> </ul>
<b>Delay</b>	Delay between recording and trigger event.
Pre-trigger	Select a negative delay time to detect signals <b>prior</b> to the trigger event. <div style="text-align: center;"> </div> <ul style="list-style-type: none"> <li>• In the oscillograph, the trigger time is marked by a dotted line.</li> <li>• When triggering on occurrence of an event, it is thus possible to detect the values that have caused the event.</li> </ul>
Post-trigger	Select a positive delay time to detect signals occurring a certain time <b>after</b> the trigger event. <div style="text-align: center;"> </div>
<b>Edge</b>	If the trigger source is a channel or a variable, you can choose between the following trigger modes:
Positive edge	For triggering on a BOOL variable: <ul style="list-style-type: none"> <li>• Trigger activation requires a FALSE-TRUE transition.</li> </ul> For triggering on a different variable: <ul style="list-style-type: none"> <li>• For trigger activation, the selected trigger value must be exceeded.</li> </ul>

Setting	Function
Negative edge	For triggering on a BOOL variable: <ul style="list-style-type: none"> <li>• Trigger activation requires a TRUE-FALSE transition.</li> </ul> For triggering on a different variable: <ul style="list-style-type: none"> <li>• For trigger activation, the selected trigger value must be fallen below.</li> </ul>
Change	For triggering on a BOOL variable: <ul style="list-style-type: none"> <li>• Trigger activation requires a state change.</li> </ul> For triggering on a different variable: <ul style="list-style-type: none"> <li>• For trigger activation, the current value must be different than the last value.</li> </ul>

#### 12.4.4 Starting recording



Click **Start** to start recording.

To obtain a maximum sampling rate when recording the variable values, the data are first stored in the measured data memory of the controller and then transferred as a data record to the PC.

- ▶ The current recording status is displayed in the status bar.

## 12.4.5 Adjusting the representation

After the variable values have been recorded and the online data record has been transferred to the PC, the data record is visualised in the oscillograph. If required, the representation can now be adjusted by using the zoom or the automatic scaling function.




**Tip!**






From the »Engineer» V2.10 onwards, a scrollbar will appear below the time axis as soon as the complete measurement does is not displayed anymore in the oscillograph.

The scrollbar serves to move the visible cutout horizontally. The labelling of the time axis and the position display are automatically updated when the cutout is moved.




### Zoom function



Go to the *oscilloscope toolbar* and click the  icon to activate the zoom function.

Zoom function	Procedure	
Zoom selection		<p>Hold down the left mouse button and draw the oscilloscope section to be zoomed:</p>  <ul style="list-style-type: none"> <li>• The selection is shown with a frame.</li> <li>• When the left mouse button is released, the selection is zoomed in the oscilloscope.</li> </ul>
Horizontal/vertical shift of selection		<p>Hold down the left and right mouse button and move the mouse pointer on the horizontal scale to the left or right or on the vertical scale to the top or bottom to shift the selection accordingly.</p> <ul style="list-style-type: none"> <li>• With a three-button mouse, you can use the mouse button in the middle.</li> </ul>
Horizontal stretching		<p>Hold down the left mouse button and move the mouse pointer on the horizontal scale to the left to stretch the shown selection from the right edge.</p> <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>
		<p>Hold down the right mouse button and move the mouse pointer on the horizontal scale to the right to stretch the shown selection from the left edge.</p> <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>




Zoom function	Procedure	
Vertical stretching		Hold down the left mouse button and move the mouse pointer on the vertical scale to the bottom to stretch the shown selection from the top. <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>
		Hold down the right mouse button and move the mouse pointer on the vertical scale to the top to stretch the shown selection from the bottom. <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>
Return to original representation		Click the right mouse button in the oscillograph to return step by step to the original representation.

### Automatic scaling function

Use the automatic scaling function to automatically scale and reposition the representation of selectable signal characteristics in the oscillograph and reset the offset to "0".



#### How to carry out automatic scaling:

1. Go to the *oscilloscope toolbar* and click the  icon to activate the automatic scaling function.
2. Select the channels/variables for automatic scaling in the *Select variable* dialog box.
3. Click **OK**.
  - The dialog box is closed and the selected channels/variables are scaled automatically.

### 12.4.6 Reading individual measured values

In addition to the zoom and scaling function, the oscilloscope offers a "cursor function" that can be used to display individual measured values of a selectable channel or the difference between two measured values.

- ▶ If the **Cursor** button has been pressed, the cursor function is active and two movable vertical measuring lines are shown in the oscillograph.



#### How to use the cursor function:

1. Press the **Cursor** button.
2. Select the channel for which individual measured values are to be indicated from the **Channel** list field.

3. Hold down the left mouse button and drag the red vertical measuring line to the desired position.
  - The active measuring line is represented by a continuous line, the inactive measuring line is represented by a dotted line.
  - If you position the mouse pointer over the inactive measuring line, the measuring line automatically becomes active.
  - The value measured at the position of the active measuring line is indicated in the **Value** group box.
  - The difference between the values measured at the two measuring lines is indicated in the **Difference** group box.

### 12.4.7 Compare peak values

This function is available from the »Engineer« V2.10 onwards!

---

Several values displayed in the oscillograph can be compared by means of a horizontal measurement line.

- ▶ The horizontal measurement line is displayed if the **Cursor** button is pressed.
- ▶ The measurement line is automatically generated based on the current cursor position and thus cannot be moved separately.

## 12.5 Data records

If several data records are loaded in the oscilloscope at the same time, the data record to be displayed is selected via the **Data record** list field. There are three types of data records:

### Online data record

The online data record is the only data record which serves to establish a connection to the target system. When the online data record has established the connection completely, it can communicate with the target system.

- ▶ In the **Data record** list field the online data record is marked with a prefixed asterisk (\*).

### Offline data record

The offline data record is a data record already stored in the project and loaded in the oscilloscope again, or a data record imported from a file.

### Merge data record

The merge data record is automatically available in the **Data record** list field if two or more data records are loaded in the oscilloscope at the same time.

- ▶ In the merge data record, several characteristics from the currently loaded data records can overlaid, e.g. to compare signal characteristics from different recordings. ▶ [Overlay function](#) (📖 607)

### 12.5.1 Comment data record

This function is available from the »Engineer« V2.10 onwards!

---


You can add a comment to the selected data record.

- ▶ The comment is saved together with the data record, both when saving in a file and in a project.
- ▶ If you select a data record for loading in the *Load data record* dialog box that contains a comment, this comment is shown in the dialog box.



#### How to add a comment to the selected data record:

Option 1: Enter the comment directly into the **Comment** text field.

Option 2: Go to the *Data logger toolbar* and click the  symbol to open the *Comment* dialog box for entering the comment.

## 12.5.2 Saving/exporting a data record

After the variables to be recorded have been selected and the required settings have been entered, you can save the configuration and recording, if already executed, for future use in the project or export them to a file.




### Note!

The reuse of a saved configuration is only reasonable for controllers of the same type, as otherwise due to a scaling of the oscilloscope channels that is not adapted, incorrect values are displayed!



### How to save the data record in the project:

1. Click on the  icon in the *Oscilloscope toolbar*.
  - The *Save data record* dialog box appears.
2. Enter a name in the **Name of the data record to be stored** input field.
3. Click **Filing in the project**.
  - The dialog box is closed and the current data record is filed in the project.




### Note!

The data record is only saved if the entire project is saved!



### How to export the data record to a file:

1. Click on the  icon in the *Oscilloscope toolbar*.
  - The *Save data record* dialog box appears.
2. Enter a name in the **Name of the data record to be stored** input field.
3. Click the **Export to file** button.
4. Specify the data record to be stored and the filing folder in the *Save as* dialog box.
5. Click **Save**.
  - The dialog box is closed and the current data record is saved.

### 12.5.3 Loading/importing a data record

Configurations/data records already stored can be reloaded into the oscilloscope any time, e.g. for the overlay function.




#### Note!

The reuse of a saved configuration is only reasonable for controllers of the same type, as otherwise due to a scaling of the oscilloscope channels that is not adapted, incorrect values are displayed!




#### How to load a data record from the project:

1. Click on the  icon in the *Oscilloscope toolbar*.
  - The *Load data record* dialog box appears.
2. Select the data record to be loaded from the **Data record** list field.
3. If the data record is to be used as configuration, select the option as **configuration....**
4. Click **Open**.
  - The dialog box is closed and the selected data record or the configuration is loaded.
  - If the configuration to be loaded contains variables that are no longer available in the controller, these variables are automatically removed from the configuration.



#### How to import a data record from a file:

1. Click on the  icon in the *Oscilloscope toolbar*.
  - The *Load data record* dialog box appears.
2. Select the option **from a file**.
3. Click the **Search...** button.
4. Select the file to be imported within the desktop environment from the *Open* dialog box.
5. If the data record is to be used as configuration, select the option as **configuration....**
6. Click **Open**.
  - The dialog box is closed and the selected data record or the configuration is imported.
  - If the configuration to be loaded contains variables that are no longer available in the controller, these variables are automatically removed from the configuration.

## 12.5.4 Close data record


This function is available from the »Engineer« V2.10 onwards!

---

You can close an open offline data record at any time.

- ▶ After a data record is closed, it is not available anymore in the **Data record** list field. The oscilloscope changes automatically to the display of the next offline data record in the list field.
- ▶ If the closed data record was included in the MERGE data record, its channels will be removed from the MERGE data record.
- ▶ If all offline data records have been closed, the oscilloscope changes to the online data record if the device is currently online. Otherwise no data record will be displayed.




Go to the *Oscilloscope toolbar* and click the  symbol to close the currently displayed offline data record.

## 12.5.5 Deleting a data record in the project



**How to delete the currently displayed offline data record:**

1. Click on the  icon in the *Oscilloscope toolbar*.
  - You will be prompted to confirm if the data record should really be deleted.
2. Confirm the prompt with **Yes** to delete the data record.
  - The data record is closed and then deleted in the project.
  - After a data record is closed, it is not available anymore in the **Data record** list field. The oscilloscope changes automatically to the display of the next offline data record in the list field.
  - If the closed data record was included in the MERGE data record, its channels will be removed from the MERGE data record.
  - If all offline data records have been deleted, the oscilloscope changes to the online data record if the device is currently online. Otherwise no data record will be displayed.

### 12.5.6 Overlay function

The overlay function serves to lay several characteristics from the currently loaded data records on top of each other, e.g. to compare signal characteristics from different recordings.


- ▶ If two or more data records are loaded in the oscilloscope, e.g. an online data record and a data record saved before in the project, a "merge" data record is automatically provided in the **Data record** list field.
- ▶ If the merge data record is selected, the desired characteristics to be overlaid or compared can be selected from the loaded data records in the **Vertical channel settings** group field.
- ▶ If an online data record is used in the merge data record, an update is carried out in the merge data record in case of a renewed recording.
- ▶ Removing variables from an offline or online data record causes the characteristics in the merge data record to be deleted.

### 12.5.7 Copying a data record to the clipboard

For documentation purposes, it is possible to copy the measured data of a data record as a table or, alternatively, the oscilloscope user interface as a picture, to the clipboard for use in other programs.



**How to copy measured data or a picture of the user interface to the clipboard:**

1. Click on the  icon in the *Oscilloscope toolbar*.
  - The *Clipboard* dialog box appears.
2. Select **Curve points** if the measured data are to be copied to the clipboard as a table, or select **Screenshot** if the oscilloscope user interface is to be copied to the clipboard as a picture.
3. Click **OK**.
  - The dialog box is closed and the selected option is copied to the clipboard.

#### 12.6 Variables of the motor control (oscilloscope signals)

The system variables of the internal motor control listed in the following table can be recorded with the oscilloscope for diagnostic and documentation purposes.



#### Note!

In comparison to all other variable values, the system variables of the internal motor control have a cycle offset of 2 ... 3 ms!



#### Tip!

The exact position of a variable in the motor control can be obtained from the corresponding signal flow.

Variable of the motor control	Meaning
<a href="#">▶ Signal flow - servo control for synchronous motor (📄 168)</a> <a href="#">▶ Signal flow - servo control for asynchronous motor (📄 170)</a>	
Common.dnActualFlux	Actual flux value
Common.dnFluxSet	Flux setpoint
Current.dnActualCurrentPhaseU	Actual motor current (phase U)
Current.dnActualCurrentPhaseV	Actual motor current (phase V)
Current.dnActualCurrentPhaseW	Actual motor current (phase W)
Current.dnActualDirectCurrent	Actual D current
Current.dnActualQuadratureCurrent	Actual Q current
Current.dnDirectCurrentSet	D current setpoint
Current.dnQuadratureCurrentSet	Q current setpoint
Torque.dnActualMotorTorque	Actual torque
Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter 2 input
Voltage.dnActualDCBusVoltage	Actual DC-bus voltage
Voltage.dnActualMotorVoltage	Current motor voltage
Voltage.dnOutputQuadratureCurrentCtrl	Q-output voltage of the current controller
Voltage.dnOutputDirectCurrentCtrl	D-output voltage of the current controller
Voltage.dnDirectVoltage	D voltage
Voltage.dnQuadratureVoltage	Q voltage



Variable of the motor control	Meaning
<b>▶ Signal flow - sensorless vector control (📖 189)</b>	
Common.dnActualFlux	Actual flux value
Current.dnActualDirectCurrent	Actual D current
Current.dnActualQuadratureCurrent	Actual Q current
Current.dnDirectCurrentSet	D current setpoint
Current.dnQuadratureCurrentSet	Q current setpoint
Frequency.dnActualRotatingFieldFrequency	Actual field frequency
Frequency.dnActualSlipFrequency	Actual slip frequency
Speed.dnActualMotorSpeed	Actual speed
Torque.dnTorqueSetpoint	Torque setpoint
Voltage.dnActualMotorVoltage	Current motor voltage
Voltage.dnDirectVoltage	D voltage
Voltage.dnQuadratureVoltage	Q voltage
<b>▶ Signal flow - V/f control (📖 205)</b>	
<b>▶ Signal flow for closed loop V/f control (📖 207)</b>	
Current.Current.dnActualMotorCurrent	Actual motor current
Current.dnActualQuadratureCurrent	Actual Q current
Frequency.dnActualRotatingFieldFrequency	Actual field frequency
Frequency.dnActualSlipFrequency	Actual slip frequency
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnSpeedSetpoint	Speed setpoint
Voltage.dnActualMotorVoltage	Current motor voltage
Voltage.dnOutputDirectCurrentCtrl	D voltage
Voltage.dnOutputQuadratureVoltage	Q voltage
<b>▶ Signal flow - encoder evaluation (📖 245)</b>	
Position.dnActualLoadPos	Actual position
Position.dnActualMotorPos	Current motor position
Speed.dnActualEncoderSpeed	Current encoder speed
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnActualResolverSpeed	Current resolver speed
<b>▶ Signal flow - position follower (📖 497)</b>	
Position.dnActualLoadPos	Actual position
Position.dnActualMotorPos	Current motor position
Position.dnContouringError	Following error
Position.dnPositionSetpoint	Position setpoint
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnOutputPosCtrl	Output signal - phase controller
Speed.dnSpeedSetpoint	Speed setpoint
Torque.dnTorqueSetpoint	Torque setpoint
Torque.dnTotalTorqueAdd	Additive torque feedforward control value

# 9400 HighLine | Parameter setting & configuration

Oscilloscope


Variables of the motor control (oscilloscope signals)

Variable of the motor control	Meaning
▶ <a href="#">Signal flow - speed follower (📖 504)</a>	
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnSpeedSetpoint	Speed setpoint
Speed.dnTotalSpeedAdd	Additive speed setpoint
Torque.dnTorqueSetpoint	Torque setpoint
Torque.dnTotalTorqueAdd	Additive torque feedforward control value
▶ <a href="#">Signal flow - torque follower (📖 510)</a>	
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnSpeedSetpoint	Speed setpoint

## 13 Diagnostics & fault analysis

### 13.1 LED status displays

You can quickly receive notes on some operating states via the LED display:



[13-1] LED display on the front panel of the controller


Labelling	Colour	Description
CAN-RUN	Green	CAN bus is OK
CAN-ERR	Red	CAN bus error
DRIVE READY	Green	Standard device is ready for operation
DRIVE ERROR	Red	Warning/Trouble/Fault
24 V	Green	24 V supply voltage is OK
USER	Yellow	Message parameterised by the application

▶ [LED status displays for the system bus \(□ 298\)](#)

▶ [LED status displays for the device state \(□ 612\)](#)

## 13.1.1 LED status displays for the device state

The control of the two LEDs "DRIVE READY" and "DRIVE ERROR" in the middle of the controller's front panel depends on the device state. ▶ [Device states](#) (105)



[13-2] LED status displays DRIVE READY and DRIVE ERROR

The meaning can be obtained from the following table:

DRIVE READY	DRIVE ERROR	Meaning
OFF	OFF	<a href="#">"Initialisation active" state</a>
	OFF	<a href="#">"Safe torque off active" state</a> Observe LED of the safety module!
	OFF	<a href="#">"Device is ready to switch on" state</a>
	OFF	<a href="#">"Device is switched on" state</a>
	OFF	<a href="#">"Operation" state</a>
  		<a href="#">"Warning active" state</a> or <a href="#">"Warning locked active" state</a> The controller is ready to switch on, switched on or operation is enabled, and a warning is present.
		<a href="#">"Quick stop by trouble active" state</a>
OFF		<a href="#">"Trouble active" state</a>
OFF		<a href="#">"Fault active" state</a>
OFF		<a href="#">"System fault active" state</a>


### Legend

Meaning of the symbols used to describe the LED states:

	LED flashes once approx. every three seconds ( <i>slow flash</i> )
	LED flashes once approx. every 1.25 seconds ( <i>flash</i> )
	LED flashes twice approx. every 1.25 seconds ( <i>double flash</i> )
	LED blinks every second
	LED is permanently on

## 13.2 Drive diagnostics with the »Engineer«


When an online connection to the controller has been established, you can carry out a diagnostics of the connected controller by means of the »Engineer« and have important actual states of the controller displayed in a concise visualisation:



Button	Function	
...	A	Show details on the current error.
	B	Show all active sources for controller inhibit.
	C	Show all active sources for quick stop.
Reset error	Acknowledge error message (if the error cause is eliminated).	
Logbook...	Show <a href="#">Logbook</a> of the controller. (616)	




### How to carry out a drive diagnostics by means of the »Engineer«:

1. Select the 9400 HighLine controller to be diagnosed in the *Project view*.
2. Click the  icon or select the command **Online→Go online** to build up an online connection with the controller.
3. Select the **Diagnostics** tab.
  - With an online connection, the **Diagnostics** tab displays current status information about the controller.

## 13.3 Drive diagnostics via keypad/bus system

### Keypad display of the controller status



- ▶ If the keypad on the front of the controller is connected to the diagnostic interface X6, the status of the controller is shown via different icons on the LCD display in the area ❶.

Icon	Meaning	Note
<b>RDY</b>	Controller is ready for operation.	
<b>RUN</b>	Controller is enabled.	
<b>STP</b>	Application in the controller is stopped.	
<b>QSP</b>	Quick stop active	
<b>CINH</b>	Controller is inhibited.	The power outputs are inhibited.
<b>OFF</b>	Controller is ready to switch on.	
<b>Mmax</b>	Speed controller 1 at the limit.	The drive is torque-controlled.
<b>I<sub>max</sub></b>	Set current limit has been exceeded in motor or generator mode.	
<b>IMP</b>	Pulse inhibit active	The power outputs are inhibited.
<b>ISFLT</b>	System fault active	
<b>IFLT</b>	Fault active	
<b>ITRB</b>	Trouble active	
<b>ITosp</b>	Quick stop by trouble active	
<b>WRN</b>	Warning active	

### Display parameters

Via the parameters listed in the following tables current states and actual values of the controller can be queried for diagnostic purposes, e.g. by using the keypad, a bus system, or the »Engineer« (when an online connection to the controller has been established).

- ▶ These parameters are listed in the »Engineer« parameter list and the keypad in the **Diagnostics** category.
- ▶ A detailed description of these parameters can be found in the chapter "[Parameter reference](#)". (📖 705)

Parameter	Display
<a href="#">C00183</a>	Device state
<a href="#">C00166</a>	Error description
<a href="#">C00168</a>	Error number
<a href="#">C00051</a>	Actual speed [rpm]

Parameter	Display
<a href="#">C00052</a>	Motor voltage
<a href="#">C00054</a>	Motor current
<a href="#">C00057/1</a>	Maximum torque
<a href="#">C00057/2</a>	Motor reference torque
<a href="#">C00059</a>	Motor - number of pole pairs
<a href="#">C00060</a>	Rotor position
<a href="#">C00061</a>	Heatsink temperature
<a href="#">C00062</a>	Temperature inside the controller
<a href="#">C00063</a>	Motor temperature
<a href="#">C00064</a>	Device utilisation (Ixt) during the last 180 seconds
<a href="#">C00065</a>	Ext. 24-V voltage
<a href="#">C00066</a>	Thermal motor load (I <sup>2</sup> xt)
<a href="#">C00068</a>	Capacitor temperature
<a href="#">C00069</a>	CPU temperature
<a href="#">C00178</a>	Time during which the controller was enabled (elapsed-hour meter)
<a href="#">C00179</a>	Time during which the mains was switched on (power-on time meter)
<a href="#">C00186</a>	ENP: Identified motor type

## Identification data

The parameters listed in the following table, which in the »Engineer« parameter list and in the keypad are classified in the category **Identification → Controller**, serve to display the identification data of the controller:

Parameter	Display
<a href="#">C00099</a>	Firmware version
<a href="#">C00200</a>	Firmware product type
<a href="#">C00201</a>	Firmware compilation date
<a href="#">C00203/1...9</a>	HW product types
<a href="#">C00204/1...9</a>	HW serial numbers
<a href="#">C00205/1...6</a>	HW descriptions
<a href="#">C00206/1...6</a>	HW manufacturing data
<a href="#">C00208/1...6</a>	HW manufacturer
<a href="#">C00209/1...6</a>	HW countries of origin
<a href="#">C00210/1...6</a>	HW versions
<a href="#">C02113</a>	Program name

## 13.4 Logbook

The integrated logbook function of the controller chronologically logs important events within the system and thus plays an important role for troubleshooting or controller diagnostics.

### Events that can be logged

The following events can be logged in the logbook:

- ▶ [Error messages of the operating system](#) (□ 623)
- ▶ Error messages generated by the application
- ▶ Controller enable
- ▶ Starting / stopping the application
- ▶ Loading/saving of parameter sets, loading of the Lenze setting
- ▶ Transmitting an application or firmware to the controller
- ▶ Switching the controller on/off
- ▶ Formatting the file system



#### Tip!

Use a parameterisable filter to exclude certain events from logbook entry.

- ▶ [Filtering logbook entries](#) (□ 617)

### Information saved

For each event, the following information is saved in the logbook:

- ▶ Type of response (e.g. trouble, warning, or information) to the event
- ▶ Event
- ▶ Value of power-on time meter
- ▶ Date/time (for memory module with real-time clock)
- ▶ Module that activated the event (A = application; S = system).

### Memory depth


The number of possible logbook entries depends on the memory module used:

- ▶ MM1xx, MM2xx: 7 entries
- ▶ MM3xx, MM4xx: 439 entries



## 13.4.1 Functional description

The structure of the logbook corresponds to a ring buffer structure:



[13-3] Ring buffer structure

- ▶ As long as free logbook memory is available, the entry is placed in the next free position within the memory (A).
- ▶ If all memory units are assigned, the oldest entry (B) is deleted for a new entry.
- ▶ The latest entries always remain available.

## 13.4.2 Filtering logbook entries

The logbook enters new entries in the ring buffer after they have passed through a parameterisable filter. By means of this filter you can exclude events with a specific error response (trouble, warning, information, etc.) from being entered in the logbook.



### Note!

Basically, events with the set response "None" are not entered in the logbook.

The filter is parameterised in [C00169](#) by means of a bit mask. A set bit inhibits the entry of the corresponding event in the logbook.

- ▶ From software version V5.0 the option that identical consecutive entries ("Multiple entries") into the logbook are suppressed can be additionally activated via bit 0. Then only the time stamp of the last (latest) entry and the number of times the same event has occurred successively are saved.


Bit	Filter	Lenze setting
0	No multiple entries	0 ≙ filter inactive
1	Fault	0 ≙ filter inactive
2	Trouble	0 ≙ filter inactive
3	Quick stop by trouble	0 ≙ filter inactive
4	Warning locked	0 ≙ filter inactive
5	Warning	0 ≙ filter inactive
6	Information	0 ≙ filter inactive


#### 13.4.3 Reading out logbook entries

When an online connection has been established, the existing logbook entries can simply be displayed in the »Engineer«. Alternatively, the logbook entries can also be read out via the corresponding parameters (e.g. using the keypad).



#### How to display logbook entries in the »Engineer«:

1. Go to the *Project view* and select the 9400 HighLine controller the logbook entries of which are to be read out.
2. Click the  icon or select the command **Online**→**Go online** to build up an online connection with the controller.
3. Select the **Diagnostics** tab from the *Workspace*.
4. Click **Logbook**.
  - The *Logbook* dialog box appears:



No.	Type	Event	Power-on time meter	Internal clock	Mod..
1	Information	Antriebsregler freigegeben	209:59:58	01.01.1970 00:02:36	S
2	Information	Applikation gestartet	209:57:29	01.01.1970 00:00:07	S
3	Information	Antriebsregler im Zustand STO	209:57:29	01.01.1970 00:00:07	S
4	Information	Interner Fehler (ConnectTable)	209:57:25	01.01.1970 00:00:06	S
5	Information	Netzspannung ist eingeschaltet	209:57:25	01.01.1970 00:00:06	S
6	Trouble	Steuerkarte: Versorgungsspannung (2...	209:57:25	01.01.1970 00:00:52	S
7	Trouble	Unterspannung im Zwischenkreis	209:57:25	01.01.1970 00:00:52	S

- You can filter the entries displayed systematically by selecting or defining filter criteria.
  - Click **Delete** to delete an entry from the logbook.
5. Click **Previous** to close the *Logbook* dialog box.



#### Tip!

- The **Export...** button serves to export the logbook entries into a file. ▶ [Export logbook entries into a file](#) (619)

### 13.4.4 Export logbook entries into a file



#### How to export logbook entries into a file:

1. Click **Export...** in the *Logbook* dialog box.
  - The *Export logbook* dialog box is displayed.
2. Specify the folder, file name, and file type for the file.
3. Click **Save** to export the logbook entries into the given file.
  - Hidden logbook entries are not exported, i.e., the specified filter criteria will also be considered during the export.
  - The logbook entries are written into the file in the form of a list separated by semicolons.







#### Example

```
Type;event;error number;number;power-on time meter;internal clock;module
Fault;motor;overtemperature;611778563;1;16243:36:56;01.01.1970 00:00;temperature monitoring
Fault;motor;thermal detector is defective;611778572;1;16243:36:56;01.01.1970 00:00;temperature
monitoring
Fault;resolver: open circuit;612040728;1;16243:36:55;01.01.1970 00:00;motor control
```

## 13.5 Monitoring

The controller is provided with different monitoring functions that protect the drive against impermissible operating conditions.

- ▶ If a monitoring function responds,
  - an entry is made into the [Logbook](#) of the controller,
  - the response (quick stop by trouble, warning, fault, etc.) selected for this monitoring function is activated,
  - the state of the internal device control changes according to the response selected, controller inhibit is set, and the "DRIVE ERROR" LED on the front of the controller goes on:

Response	Logbook entry	Display under <a href="#">C00168</a>	Pulse inhibit	Controller inhibit	Acknowledgement required	LED "DRIVE ERROR"
None						OFF
Information	<input checked="" type="checkbox"/>					OFF
Warning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				
Warning locked	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Quick stop by trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (after 0.5 s)		
Fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
System fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mains switching is required!	



### Danger!

If the automatic restart is enabled ([C00142](#) = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or requirement for "Safe torque off active" is no longer available!

▶ [Automatic restart after mains connection/trouble...](#) (📖 112)

See also:

- ▶ [Device states](#) (📖 105)
- ▶ [LED status displays for the device state](#) (📖 612)

## 13.5.1 Setting the error response

If a monitoring function responds, the response set for this monitoring function (quick stop by trouble, warning, fault, etc.) is triggered.

- For many monitoring functions the response can be individually configured via parameters:

∕ C ∕ S	Name	Value	Unit
580	Resp. to encoder open circuit	Error	
581	Resp. to external fault	1: Error	
582	Resp. to heatsink temp. > C00122	0: No response 1: Error	
583	Resp. to motor overtemp. KTY	1: Error	
584	Resp. to motor temp. > C00121	2: Fault 3: Quick stop by trouble 4: Warning locked	
585	Resp. to motor overtemp. PTC	5: Warning	
586	Resp. to resolver open circuit	6: Info	
587	Status - fan control	0x00	



**Tip!**

The fault messages for which the response can be set can be gathered from the table in the chapter "[Short overview \(A-Z\)](#)". (📖 628)

## Warning thresholds

Some of the monitoring functions are activated if a defined warning threshold (e.g. temperature) has been exceeded.

- The corresponding preset threshold values can be changed via the following parameters:

Parameter	Information
<a href="#">C00120</a>	Motor overload protection (I <sup>2</sup> xt)
<a href="#">C00121</a>	Motor temp. warning threshold
<a href="#">C00122</a>	Heatsink temp. warn. threshold
<a href="#">C00123</a>	Device utilisation warning threshold
<a href="#">C00126</a>	CPU temp. warning threshold
<a href="#">C00127</a>	Mot. overload warning threshold
<a href="#">C00128</a>	Thermal time constant of motor
<a href="#">C00174</a>	Undervoltage (LU) threshold
<a href="#">C00570</a>	Warning thres. brake transistor
<a href="#">C00572</a>	Warning thres. brake resistor
<a href="#">C00576</a>	Speed monitoring tolerance
<a href="#">C00596</a>	Threshold max. speed reached
<a href="#">C00599</a>	Motor phase failure threshold
<a href="#">C00620</a>	Max. motor current threshold

## 13.6 Maloperation of the drive

### The motor does not rotate.

Cause	Remedy
DC-bus voltage is too low.	Check mains voltage.
Controller is inhibited.	Deactivate controller inhibit (can be set by several sources).
Motor holding brake is not released.	Release motor holding brake.
Quick stop active.	Deactivate quick stop.
Setpoint = 0	Select setpoint.

### With a positive speed setpoint selection, the motor rotates counter-clockwise instead of clockwise (when looking at the motor shaft).

Cause	Remedy
Feedback system is not connected in correct phase relation.	Connect feedback system in correct phase relation.

### The maximum current (C00022) flows and the motor does not rotate according to the defined speed setpoint.

Cause	Remedy
Two motor phases are interchanged, i.e. an anti-clockwise rotating field is applied to the motor.	<p>Carry out the following steps for verification:</p> <ol style="list-style-type: none"> <li>1. Ensure that the motor shaft is not blocked and can rotate freely without damaging the system.</li> <li>2. Activate the "U-rotation test mode" for the motor control (C00398 = "1"). <ul style="list-style-type: none"> <li>– In this test mode a voltage phasor with the frequency set in C00399/1 and the amplitude from the linear characteristic of rated voltage and rated frequency is applied to the machine, which corresponds to a clockwise rotating field.</li> <li>– <b>⚠ Danger!</b> <b>When the test mode is active, the parameterisable error response "Quick stop by trouble" has no effect!</b> If the test mode is active and a monitoring function responds with this error response, <u>no</u> quick stop is executed but the motor continues to rotate with the frequency set for the test mode!</li> </ul> </li> <li>3. Increase the frequency step by step for the test mode in C00399/1 until the motor shaft starts to rotate. <ul style="list-style-type: none"> <li>– If the motor shaft does not rotate, check the electrical connection.</li> </ul> </li> <li>4. While the motor shaft is rotating, check whether it rotates clockwise when looking at the A end shield. If not, two motor phases are interchanged.</li> <li>5. Additionally check whether the actual speed value shown in C00051 is positive and whether it corresponds to the defined frequency, taking the number of pole pairs of the machine into consideration (C00059). If this is not the case, the connection and the parameter setting of the feedback system are to be checked.</li> <li>6. Deactivate the test mode for the motor control again (C00398 = "0").</li> </ol>

## 13.7 Error messages of the operating system

This chapter describes all error messages of the controller operating system and possible causes & remedies.




**Tip!**

Each error message is also saved in the logbook in chronological order. ▶ [Logbook](#) (616)

### 13.7.1 Structure of the error number (bit coding)


If an error occurs in the controller, a 32-bit value will be saved in decimal format in the internal history buffer ([C00168](#)), which contains the following information:




[13-4] Structure of the error number



**Tip!**

If you go to the **Diagnostics** tab and click the button  to the right of the **Error description** display parameter, you will be shown all details on the current error in a separate dialog box.




# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### 13.7.1.1 Response




Bit 31	Bit 30	Bit 29	Response
0	0	0	0: No response
0	0	1	1: Fault
0	1	0	2: Trouble
0	1	1	3: Quick stop by trouble
1	0	0	4: Warning locked
1	0	1	5: Warning
1	1	0	6: Information
1	1	1	7: System fault

The state of the internal device control changes according to the selected response to an error, controller inhibit is set, and the "DRIVE ERROR" LED on the front of the controller goes on:

Response	Logbook entry	Display under <a href="#">C00168</a>	Pulse inhibit	Controller inhibit	Acknowledgement required	LED "DRIVE ERROR"
None						OFF
Information	<input checked="" type="checkbox"/>					OFF
Warning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				
Warning locked	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Quick stop by trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (after 0.5 s)		
Fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
System fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mains switching is required!	

#### 13.7.1.2 Instance ID




The instance ID is dynamically assigned by the operating system.

Bit 28	Bit 27	Bit 26	Meaning
0	0	0	Instance ID 0
0	0	1	Instance ID 1
0	1	0	Instance ID 2
0	1	1	Instance ID 3
1	0	0	Instance ID 4
1	0	1	Instance ID 5



Bit 28	Bit 27	Bit 26	Meaning
1	1	0	Instance ID 6
1	1	1	Instance ID 7

### 13.7.1.3 Module ID



Use the module ID to identify the module in which the error has occurred.

Module ID		Module
hex	decimal	
0x0065	101	Logbook module
0x0068	104	Module identification
0x0069	105	Error check of the program memory during runtime
0x006a	106	Runtime environment for IEC 61131-3 programs
0x006e	110	Supply voltage monitoring
0x006f	111	24-V supply voltage monitoring
0x0072	114	Service register
0x0075	117	Device control
0x0077	119	Temperature monitoring
0x0078	120	Analog signal monitoring
0x0079	121	Motor data interface
0x007a	122	Processing of digital inputs/outputs
0x007b	123	Motor control
0x007c	124	Device command module ( <a href="#">C00002</a> )
0x007d	125	Processing of analog inputs/outputs
0x007f	127	Interface to the intelligent communication module
0x0083	131	"CAN on board": CAN-Dispatcher
0x0084	132	"CAN on board": CAN-NMT-Handler
0x0085	133	"CAN on board": CAN-Emergency-Handler
0x0086	134	"CAN on board": CAN-NMT-Master
0x0087	135	"CAN on board": CAN-PDO-Handler
0x0088	136	"CAN on board": CAN-SDO-Server
0x0089	137	"CAN on board": CAN-SDO-Client
0x008c	140	Application project manager
0x008e	142	Communication interface for internal communication
0x0090	144	Parameter manager
0x0091	145	Lenze runtime system
0x0092	146	Interface for safety module
0x0093	147	Sync signal generation
0x0099	153	Extension module - digital frequency in MXI1
0x009d	157	CAN module in MXI1: CAN-Dispatcher
0x009e	158	CAN module in MXI1: CAN-NMT-Handler
0x009f	159	CAN module in MXI1: CAN-Emergency-Handler
0x00a0	160	CAN module in MXI1: CAN-NMT-Master


# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

Module ID		Module
hex	decimal	
0x00a1	161	CAN module in MXI1: CAN-PDO-Handler
0x00a2	162	CAN module in MXI1: CAN-SDO-Server
0x00a3	163	CAN module in MXI1: CAN-SDO-Client
0x00aa	170	Extension module - digital frequency in MXI2
0x00ac	172	CAN module in MXI2: CAN-Dispatcher
0x00ad	173	CAN module in MXI2: CAN-NMT-Handler
0x00ae	174	CAN module in MXI2: CAN-Emergency-Handler
0x00af	175	CAN module in MXI2: CAN-NMT-Master
0x00b0	176	CAN module in MXI2: CAN-PDO-Handler
0x00b1	177	CAN module in MXI2: CAN-SDO-Server
0x00b2	178	CAN module in MXI2: CAN-SDO-Client
0x00b8	184	Basic drive functions
0x00c8	200	Intelligent communication module
0x012f	303	Safety module SM300/SM301

## 13.7.1.4 Error ID




16-bit value (0 ... 65535<sub>dec</sub>) for error identification.

## 13.7.1.5 Example for bit coding of the error number

[C00168](#) displays the error number "1148911631".

► This decimal value corresponds to the following bit sequence:



Assignment	Information	Meaning in the example
	<a href="#">Response</a>	2: Trouble
	<a href="#">Instance ID</a>	1: Instance ID 1
	<a href="#">Module ID</a>	Module ID 123 (0x007b): Motor control
	<a href="#">Error ID</a>	Error ID 15 (0x000f) for motor control: <a href="#">Undervoltage in the DC bus</a>

► Error number "1148911631" thus means:  
The "DC-bus undervoltage" error with the response "Trouble" occurred in the "motor control" module with the instance ID 1.

## 13.7.2 Reset of error message

An error message with the response "Fault", "Quick stop by trouble", or "Warning locked" must be reset (acknowledged) explicitly after the cause of error has been eliminated.



To reset (acknowledge) a pending error message, execute the device command [C00002](#) = "43: Reset error".



### Tip!

When an online connection to the controller has been established, use the **Diagnostics** tab of the »Engineer« and click **Reset error** to reset a pending error message.

#### 13.7.3 Short overview (A-Z)

The following table contains all error messages of the controller operating system in alphabetical order with the preset error response and - if available – the parameter for setting the error response.



**Tip!**

If you click on the cross-reference in the first column, you get to the detailed description of the corresponding error response in the following chapter "[Cause & possible remedies](#)". (📖 636)



**Note!**

#### Error message "Unknown error"

If the "Unknown error xxxx" error message is indicated in the logbook or in [C00166](#), the reason for the missing plain text is that the error texts required have not been downloaded to the controller during the application download.

- This, for instance, is the case if a device module plugged into the controller has not been included in the Engineer project.
- Remedy: Include the device module, recompile and download the project.

Error number hex	dec	Error message	Response (Lenze setting)	Adjustable in
<a href="#">0x0090000c</a>	9437196	Disconnection in the case of par. storage		-
<a href="#">0x007b001a</a>	8060954	Absolute value encoder: Communication error	Fault	-
<a href="#">0x006a0000</a>	6946816	General error in the application	Fault	-
<a href="#">0x007d0000</a>	8192000	Analog input 1: master current &lt; 4 mA	Fault	<a href="#">C00598</a>
<a href="#">0x00750001</a>	7667713	Controller enabled	Information	-
<a href="#">0x00750003</a>	7667715	Controller in STO state	Information	-
<a href="#">0x007b0047</a>	8060999	Controller: Clamp operation	Information	-
<a href="#">0x00750005</a>	7667717	Controller: Pulse inhibit is active	Information	-
<a href="#">0x007b0035</a>	8060981	Controller: Overload during acceleration phases	Fault	-
<a href="#">0x006a0004</a>	6946820	ApplicationTask: Overflow	Fault	<a href="#">C02111</a>
<a href="#">0x006a0013</a>	6946835	Application has started	Information	-
<a href="#">0x006a000e</a>	6946830	Application has stopped	Information	-
<a href="#">0x006a0014</a>	6946836	Application has stopped	Information	-
<a href="#">0x008c000c</a>	9175052	Application and device are incompatible	Fault	-
<a href="#">0x006a0010</a>	6946832	Faulty application parameter	Fault	-
<a href="#">0x007b003f</a>	8060991	A mains phase has failed	Fault	-
<a href="#">0x007b002d</a>	8060973	Failure of motor phase U	No response	<a href="#">C00597</a>
<a href="#">0x007b002e</a>	8060974	Failure of motor phase V	No response	<a href="#">C00597</a>
<a href="#">0x007b002f</a>	8060975	Failure of motor phase W	No response	<a href="#">C00597</a>
<a href="#">0x00b8000c</a>	12058636	Acceleration has been limited	Information	<a href="#">C02716/3</a>
<a href="#">0x00910012</a>	9502738	Block function in wrong MEC task	Fault	-
<a href="#">0x006a000f</a>	6946831	Breakpoint reached	Information	-
<a href="#">0x007b0040</a>	8060992	Brake chopper: Ixt > C00570	Warning	<a href="#">C00569</a>
<a href="#">0x007b001c</a>	8060956	Brake transistor: Ixt overload	No response	<a href="#">C00573</a>
<a href="#">0x007b0021</a>	8060961	Brake transistor: Overcurrent	Fault	-

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x007b0041</a>	8060993	Brake resistor: I2t &gt; C00572	Warning	<a href="#">C00571</a>
<a href="#">0x007b001d</a>	8060957	Brake resistor: I<xt overload	Information	-
<a href="#">0x00b80014</a>	12058644	Cam Data is corrupted	Warning locked	-
<a href="#">0x00b80016</a>	12058646	Cam Data locked due to wrong password	Warning locked	-
<a href="#">0x00b80017</a>	12058647	Cam Data locked due to wrong security key	Warning locked	-
<a href="#">0x00b80015</a>	12058645	Cam Data restored	Fault	-
<a href="#">0x00b80013</a>	12058643	Cam data: Serial number MM does not match	Warning locked	-
<a href="#">0x00b80034</a>	12058676	Cam Data: Invalidated (due to change of mechanical data)	Warning	-
<a href="#">0x00b80035</a>	12058677	Cam Data: Invalid product number	Information	-
<a href="#">0x00870008</a>	8847368	CAN on board PDO manager: Faulty configuration	Warning locked	-
<a href="#">0x00870000</a>	8847360	CAN on board RPDO1: Telegram not received or faulty	No response	<a href="#">C00591/1</a>
<a href="#">0x00870001</a>	8847361	CAN on board RPDO2: Telegram not received or faulty	No response	<a href="#">C00591/2</a>
<a href="#">0x00870002</a>	8847362	CAN on board RPDO3: Telegram not received or faulty	No response	<a href="#">C00591/3</a>
<a href="#">0x00870003</a>	8847363	CAN on board RPDO4: Telegram not received or faulty	No response	<a href="#">C00591/4</a>
<a href="#">0x00890000</a>	8978432	CAN on board SDO client: Faulty configuration	Warning locked	-
<a href="#">0x00880000</a>	8912896	CAN on board SDO server: Faulty configuration	Warning locked	-
<a href="#">0x00830002</a>	8585218	CAN on board: Basic configuration invalid	Warning locked	-
<a href="#">0x00830000</a>	8585216	CAN on board: Bus off	No response	<a href="#">C00595</a>
<a href="#">0x00850000</a>	8716288	CAN on board: Faulty emergency configuration	Warning locked	-
<a href="#">0x00840000</a>	8650752	CAN on board: Heartbeat error index 1 ... 32	No response	<a href="#">C00613/1...32</a>
<a href="#">0x00840020</a>	8650784	CAN on board: Lifeguarding error	No response	<a href="#">C00614</a>
<a href="#">0x00860020</a>	8781856	CAN on board: Faulty NMT master configuration	Warning locked	-
<a href="#">0x00840021</a>	8650785	CAN on board: Faulty NMT slave configuration	Warning locked	-
<a href="#">0x00860000</a>	8781824	CAN on board: Node guarding error 1 ... 32	No response	<a href="#">C00612/1...32</a>
<a href="#">0x00830001</a>	8585217	CAN on board: Invalid node address 0	Warning	-
<a href="#">0x00a10008</a>	10551304	CAN module (MXI1) PDO manager: Faulty configuration	Warning locked	-
<a href="#">0x00a10000</a>	10551296	CAN module (MXI1) RPDO1: Telegram not received or faulty	No response	<a href="#">C13591/1</a>
<a href="#">0x00a10001</a>	10551297	CAN module (MXI1) RPDO2: Telegram not received or faulty	No response	<a href="#">C13591/2</a>
<a href="#">0x00a10002</a>	10551298	CAN module (MXI1) RPDO3: Telegram not received or faulty	No response	<a href="#">C13591/3</a>
<a href="#">0x00a10003</a>	10551299	CAN module (MXI1) RPDO4: Telegram not received or faulty	No response	<a href="#">C13591/4</a>
<a href="#">0x00a10004</a>	10551300	CAN module (MXI1) RPDO5: Telegram not received or faulty	No response	<a href="#">C13591/5</a>
<a href="#">0x00a10005</a>	10551301	CAN module (MXI1) RPDO6: Telegram not received or faulty	No response	<a href="#">C13591/6</a>
<a href="#">0x00a10006</a>	10551302	CAN module (MXI1) RPDO7: Telegram not received or faulty	No response	<a href="#">C13591/7</a>
<a href="#">0x00a10007</a>	10551303	CAN module (MXI1) RPDO8: Telegram not received or faulty	No response	<a href="#">C13591/8</a>
<a href="#">0x00a30000</a>	10682368	CAN module (MXI1) SDO client: Faulty configuration	Warning locked	-
<a href="#">0x00a20000</a>	10616832	CAN module (MXI1) SDO server: Faulty configuration	Warning locked	-
<a href="#">0x009d0000</a>	10289152	CAN module (MXI1): Bus off	Information	<a href="#">C13595</a>
<a href="#">0x009f0000</a>	10420224	Can module (MXI1): Faulty emergency configuration	Warning locked	-
<a href="#">0x009e0021</a>	10354721	CAN module (MXI1): Faulty NMT slave configuration	Warning locked	-
<a href="#">0x009d0002</a>	10289154	CAN module (MXI1): Basic configuration invalid	Warning locked	-
<a href="#">0x009e0000</a>	10354688	CAN module (MXI1): Heartbeat error index 1 ... 32	No response	<a href="#">C13613/1...32</a>
<a href="#">0x009e0020</a>	10354720	CAN module (MXI1): Lifeguarding error	No response	<a href="#">C13614</a>
<a href="#">0x00a00020</a>	10485792	CAN module (MXI1): Faulty NMT master configuration	Warning locked	-
<a href="#">0x00a00000</a>	10485760	CAN module (MXI1): Node guarding error 1 ... 32	No response	<a href="#">C13612/1...32</a>
<a href="#">0x009d0001</a>	10289153	CAN module (MXI1): Invalid node address 0	Warning	-
<a href="#">0x00b00008</a>	11534344	CAN module (MXI2) PDO manager: Faulty configuration	Warning locked	-
<a href="#">0x00b00000</a>	11534336	CAN module (MXI2) RPDO1: Telegram not received or faulty	No response	<a href="#">C14591/1</a>
<a href="#">0x00b00001</a>	11534337	CAN module (MXI2) RPDO2: Telegram not received or faulty	No response	<a href="#">C14591/2</a>
<a href="#">0x00b00002</a>	11534338	CAN module (MXI2) RPDO3: Telegram not received or faulty	No response	<a href="#">C14591/3</a>
<a href="#">0x00b00003</a>	11534339	CAN module (MXI2) RPDO4: Telegram not received or faulty	No response	<a href="#">C14591/4</a>
<a href="#">0x00b00004</a>	11534340	CAN module (MXI2) RPDO5: Telegram not received or faulty	No response	<a href="#">C14591/5</a>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x00b00005</a>	11534341	CAN module (MXI2) RPDO6: Telegram not received or faulty	No response	<a href="#">C14591/6</a>
<a href="#">0x00b00006</a>	11534342	CAN module (MXI2) RPDO7: Telegram not received or faulty	No response	<a href="#">C14591/7</a>
<a href="#">0x00b00007</a>	11534343	CAN module (MXI2) RPDO8: Telegram not received or faulty	No response	<a href="#">C14591/8</a>
<a href="#">0x00b20000</a>	11665408	CAN module (MXI2) SDO client: Faulty configuration	Warning locked	-
<a href="#">0x00b10000</a>	11599872	CAN module (MXI2) SDO server: Faulty configuration	Warning locked	-
<a href="#">0x00ac0000</a>	11272192	CAN module (MXI2): Bus off	Information	<a href="#">C14595</a>
<a href="#">0x00ae0000</a>	11403264	Can module (MXI2): Faulty emergency configuration	Warning locked	-
<a href="#">0x00ac0002</a>	11272194	CAN module (MXI2): Basic configuration invalid	Warning locked	-
<a href="#">0x00ad0000</a>	11337728	CAN module (MXI2): Heartbeat error index 1 ... 32	No response	<a href="#">C14613/1...32</a>
<a href="#">0x00ad0020</a>	11337760	CAN module (MXI2): Lifeguarding error	No response	<a href="#">C14614</a>
<a href="#">0x00af0020</a>	11468832	CAN module (MXI2): Faulty NMT master configuration	Warning locked	-
<a href="#">0x00ad0021</a>	11337761	CAN module (MXI2): Faulty NMT slave configuration	Warning locked	-
<a href="#">0x00af0000</a>	11468800	CAN module (MXI2): Node guarding error 1 ... 32	No response	<a href="#">C14612/1...32</a>
<a href="#">0x00ac0001</a>	11272193	CAN module (MXI2): Invalid node address 0	Warning	-
<a href="#">0x00900008</a>	9437192	Code number duplicated	Warning locked	-
<a href="#">0x00690000</a>	6881280	Code refresh	System fault	-
<a href="#">0x008c001a</a>	9175066	ConnectTable active	Information	-
<a href="#">0x00770008</a>	7798792	CPU: Temperature > C00126	No response	<a href="#">C00589</a>
<a href="#">0x0077000e</a>	7798798	CPU: Thermal detector is defective	Fault	<a href="#">C00588</a>
<a href="#">0x00770009</a>	7798793	CPU: Overtemperature	Warning	-
<a href="#">0x008c0002</a>	9175042	File DeviceCFG.dat is defective	Fault	-
<a href="#">0x008c0005</a>	9175045	File DeviceCFG.dat is missing	Fault	-
<a href="#">0x008c0008</a>	9175048	File DeviceCFG.dat is invalid	Fault	-
<a href="#">0x008c0001</a>	9175041	File ProjectList.dat is defective	Fault	-
<a href="#">0x008c0004</a>	9175044	File ProjectList.dat is missing	Fault	-
<a href="#">0x008c0007</a>	9175047	File ProjectList.dat is invalid	Fault	-
<a href="#">0x008c0000</a>	9175040	File ProjectSelection.dat is defective	Fault	-
<a href="#">0x008c0003</a>	9175043	File ProjectSelection.dat is missing	Fault	-
<a href="#">0x008c0006</a>	9175046	File ProjectSelection.dat is invalid	Fault	-
<a href="#">0x00990003</a>	10027011	DFIN (MXI1): Signal error enable/lamp control	Warning	<a href="#">C13041</a>
<a href="#">0x00990000</a>	10027008	DFIN (MXI1): Track error A-/A	Fault	<a href="#">C13040</a>
<a href="#">0x00990001</a>	10027009	DFIN (MXI1): Track error B-/B	Fault	<a href="#">C13040</a>
<a href="#">0x00990002</a>	10027010	DFIN (MXI1): Track error Z-/Z	Fault	<a href="#">C13040</a>
<a href="#">0x00990004</a>	10027012	DFIN (MXI1): Supply cannot be corrected anymore	Warning	<a href="#">C13042</a>
<a href="#">0x00aa0003</a>	11141123	DFIN (MXI2): Signal error enable/lamp control	Warning	<a href="#">C14041</a>
<a href="#">0x00aa0000</a>	11141120	DFIN (MXI2): Track error A-/A	Fault	<a href="#">C14040</a>
<a href="#">0x00aa0001</a>	11141121	DFIN (MXI2): Track error B-/B	Fault	<a href="#">C14040</a>
<a href="#">0x00aa0002</a>	11141122	DFIN (MXI2): Track error Z-/Z	Fault	<a href="#">C14040</a>
<a href="#">0x00aa0004</a>	11141124	DFIN (MXI2): Supply cannot be corrected anymore	Warning	<a href="#">C14042</a>
<a href="#">0x00990005</a>	10027013	DFOUT (MXI1): Maximum frequency reached	Warning	<a href="#">C13080</a>
<a href="#">0x00aa0005</a>	11141125	DFOUT (MXI2): Maximum frequency reached	Warning	<a href="#">C14080</a>
<a href="#">0x006a0011</a>	6946833	Division by zero	Fault	-
<a href="#">0x006a0001</a>	6946817	Faulty program download	Fault	-
<a href="#">0x007b0012</a>	8060946	Actual speed value outside tolerance (C00576)	No response	<a href="#">C00579</a>
<a href="#">0x00680022</a>	6815778	Real-time clock is defective	Warning locked	-
<a href="#">0x00680024</a>	6815780	Real-time clock: No battery, time lost	Warning locked	-
<a href="#">0x00680023</a>	6815779	Real-time clock: Change battery	Warning locked	-
<a href="#">0x007b0039</a>	8060985	Electronic nameplate: Data outside parameter limits	Information	-
<a href="#">0x007b0030</a>	8060976	Electronic nameplate: Data loaded	Information	-
<a href="#">0x0078000a</a>	7864330	Electronic nameplate: Data are incompatible	Information	-
<a href="#">0x007b0032</a>	8060978	Electronic nameplate: Encoder protocol unknown	Information	-

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x007b0033</a>	8060979	Electronic nameplate: Encoder signal unknown	Information	-
<a href="#">0x0068001b</a>	6815771	Electronic nameplate: Communication error	Warning	-
<a href="#">0x007b0031</a>	8060977	Electronic nameplate: Not found	Information	-
<a href="#">0x0068001d</a>	6815773	Electronic nameplate: Checksum error	Warning	-
<a href="#">0x007b001b</a>	8060955	Encoder: Open circuit	Fault	<a href="#">C00580</a>
<a href="#">0x007b002c</a>	8060972	EnDat encoder: Battery empty	Information	-
<a href="#">0x007b004f</a>	8061007	EnDat encoder: Command error	Information	-
<a href="#">0x007b0026</a>	8060966	EnDat encoder: Lamp error	Information	-
<a href="#">0x007b0050</a>	8061008	EnDat encoder: Initial position error	Information	-
<a href="#">0x007b0028</a>	8060968	EnDat encoder: Position error	Information	-
<a href="#">0x007b0027</a>	8060967	EnDat encoder: Signal error	Information	-
<a href="#">0x007b0029</a>	8060969	EnDat encoder: Overvoltage	Information	-
<a href="#">0x007b002b</a>	8060971	EnDat encoder: Overcurrent	Information	-
<a href="#">0x007b004e</a>	8061006	EnDat encoder: Transmission error	Information	-
<a href="#">0x007b002a</a>	8060970	EnDat encoder: Undervoltage	Information	-
<a href="#">0x007b0011</a>	8060945	Earth fault detected	Fault	-
<a href="#">0x008c000b</a>	9175051	Required license missing	Fault	-
<a href="#">0x00750000</a>	7667712	External error	Fault	<a href="#">C00581</a>
<a href="#">0x00680013</a>	6815763	Incorrect safety module	System fault	-
<a href="#">0x00680012</a>	6815762	Incorrect memory module	System fault	-
<a href="#">0x006a0002</a>	6946818	Error during the update of inputs and outputs	Fault	-
<a href="#">0x006a0017</a>	6946839	Error in control configuration	System fault	-
<a href="#">0x00910011</a>	9502737	Error during initialisation	System fault	-
<a href="#">0x0068001e</a>	6815774	Firmware incompatible to control card	System fault	-
<a href="#">0x0068001a</a>	6815770	Firmware has been changed	Information	-
<a href="#">0x007b004d</a>	8061005	Encoder: Timeout error		-
<a href="#">0x007b003e</a>	8060990	Encoder monitoring: Pulse deviation detected	No response	<a href="#">C00621</a>
<a href="#">0x00780001</a>	7864321	Device utilisation Ixt &gt; 100 %	Fault	-
<a href="#">0x00780000</a>	7864320	Device utilisation Ixt &gt; C00123	Warning	<a href="#">C00604</a>
<a href="#">0x00790000</a>	7929856	Incorrect device command transfer	System fault	-
<a href="#">0x00770011</a>	7798801	Inside the device: Fan is defective	Fault	<a href="#">C00611</a>
<a href="#">0x0077000b</a>	7798795	Inside the device: Thermal detector is defective	Fault	<a href="#">C00588</a>
<a href="#">0x00b8000b</a>	12058635	Speed has been limited	Information	<a href="#">C02716/3</a>
<a href="#">0x00910003</a>	9502723	Heartbeat not periodic	System fault	-
<a href="#">0x007b003b</a>	8060987	Hiperface encoder: Command error	Information	-
<a href="#">0x007b003c</a>	8060988	Hiperface encoder: Unknown encoder	Information	-
<a href="#">0x007b003d</a>	8060989	Hiperface encoder: Initial position error	Information	-
<a href="#">0x007b003a</a>	8060986	Hiperface encoder: Transmission error	Information	-
<a href="#">0x006a0006</a>	6946822	IdleTask: Overflow	Fault	-
<a href="#">0x00b8001a</a>	12058650	Int. overflow C02620 (manual jog: Speed 1)	Fault	-
<a href="#">0x00b8001b</a>	12058651	Int. overflow C02621 (manual jog: Speed 2)	Fault	-
<a href="#">0x00b8001c</a>	12058652	Int. overflow C02622 (manual jog: Acc.)	Fault	-
<a href="#">0x00b8001d</a>	12058653	Int. overflow C02623 (manual jog: Dec.)	Fault	-
<a href="#">0x00b8002d</a>	12058669	Int. overflow C02642 (home position)	Fault	-
<a href="#">0x00b8002e</a>	12058670	Int. overflow C02643 (homing: Target position)	Fault	-
<a href="#">0x00b8002f</a>	12058671	Int. overflow C02644 (homing: Speed 1)	Fault	-
<a href="#">0x00b80030</a>	12058672	Int. overflow C02645 (homing: Acceleration 1)	Fault	-
<a href="#">0x00b80031</a>	12058673	Int. overflow C02646 (homing: Speed 2)	Fault	-
<a href="#">0x00b80032</a>	12058674	Int. overflow C02647 (homing: Acceleration 2)	Fault	-
<a href="#">0x00b80033</a>	12058675	Int. overflow C02670 (positioner: Tol. for target position)	Fault	-
<a href="#">0x00b80020</a>	12058656	Int. overflow C02701/1 (positive software limit pos.)	Fault	-

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x00b80021</a>	12058657	Int. overflow C02701/2 (negative software limit pos.)	Fault	-
<a href="#">0x00b80022</a>	12058658	Int. overflow C02703 (maximum speed)	Fault	-
<a href="#">0x00b80023</a>	12058659	Int. overflow C02705 (maximum acceleration)	Fault	-
<a href="#">0x00b80028</a>	12058664	Int. overflow C02708/1 (decel. limited speed 1)	Fault	-
<a href="#">0x00b80024</a>	12058660	Int. overflow C02708/1 (limited speed 1)	Fault	-
<a href="#">0x00b80029</a>	12058665	Int. overflow C02708/2 (decel. limited speed 2)	Fault	-
<a href="#">0x00b80025</a>	12058661	Int. overflow C02708/2 (limited speed 2)	Fault	-
<a href="#">0x00b8002a</a>	12058666	Int. overflow C02708/3 (decel. limited speed 3)	Fault	-
<a href="#">0x00b80026</a>	12058662	Int. overflow C02708/3 (limited speed 3)	Fault	-
<a href="#">0x00b8002b</a>	12058667	Int. overflow C02708/4 (decel. limited speed 4)	Fault	-
<a href="#">0x00b80027</a>	12058663	Int. overflow C02708/4 (limited speed 4)	Fault	-
<a href="#">0x00b8002c</a>	12058668	Int. overflow C02713 (max. dist. manual control)	Fault	-
<a href="#">0x00690009</a>	6881289	Internal error (event mechanism)	System fault	-
<a href="#">0x0069000a</a>	6881290	Internal error (event mechanism)	System fault	-
<a href="#">0x00690002</a>	6881282	Internal error (LDS instance data)	System fault	-
<a href="#">0x00690003</a>	6881283	Internal error (LDS tasks)	System fault	-
<a href="#">0x0069000d</a>	6881293	Internal error (file system lifetime)	Warning	-
<a href="#">0x00690007</a>	6881287	Internal error (message queue)	System fault	-
<a href="#">0x00690006</a>	6881286	Internal error (message memory)	System fault	-
<a href="#">0x00690008</a>	6881288	Internal error (name database)	System fault	-
<a href="#">0x0069000b</a>	6881291	Internal error (semaphores)	System fault	-
<a href="#">0x0069000c</a>	6881292	Internal error (semaphores)	System fault	-
<a href="#">0x00690001</a>	6881281	Internal error (memory area - logbook)	System fault	-
<a href="#">0x00690004</a>	6881284	Internal error (memory blocks)	System fault	-
<a href="#">0x00690005</a>	6881285	Internal error (task queue)	System fault	-
<a href="#">0x00910004</a>	9502724	Internal error: See C00180	System fault	-
<a href="#">0x00910005</a>	9502725	Internal error: See C00180	System fault	-
<a href="#">0x00910006</a>	9502726	Internal error: See C00180	System fault	-
<a href="#">0x00910008</a>	9502728	Internal error: See C00180	Fault	-
<a href="#">0x00910009</a>	9502729	Internal error: See C00180	Fault	-
<a href="#">0x007b0034</a>	8060980	Internal communication error (DMA)	System fault	-
<a href="#">0x007b0014</a>	8060948	Internal communication error (host MCTRL)	System fault	-
<a href="#">0x007b0036</a>	8060982	Internal communication error (MCTRL host)	System fault	-
<a href="#">0x00910002</a>	9502722	No heartbeat signal detected	System fault	-
<a href="#">0x0090000a</a>	9437194	No parameters for module in MXI1	Fault	<a href="#">C00615/2</a>
<a href="#">0x0090000b</a>	9437195	No parameters for module in MXI2	Fault	<a href="#">C00615/3</a>
<a href="#">0x00680019</a>	6815769	Combination MXI1/MXI2 not possible	System fault	-
<a href="#">0x0068001f</a>	6815775	Combination of memory module/device not possible	System fault	-
<a href="#">0x00680020</a>	6815776	Combination of module in MXI1/device not possible	System fault	-
<a href="#">0x00680021</a>	6815777	Combination of module in MXI2/device not possible	System fault	-
<a href="#">0x007f0003</a>	8323075	Communication with module in MXI1 interrupted	Information	-
<a href="#">0x007f0004</a>	8323076	Communication with module in MXI2 interrupted	Information	-
<a href="#">0x00920001</a>	9568257	Communication with safety module interrupted	Information	-
<a href="#">0x007f0002</a>	8323074	Communication error between device and device module	No response	<a href="#">C01501</a>
<a href="#">0x0091000e</a>	9502734	Communication task: Standstill &gt; 3 s	Fault	-
<a href="#">0x00770010</a>	7798800	Heatsink: Fan is defective	Fault	<a href="#">C00610</a>
<a href="#">0x00770000</a>	7798784	Heatsink: Temperature &gt; C00122	Warning	<a href="#">C00582</a>
<a href="#">0x0077000a</a>	7798794	Heatsink: Thermal detector is defective	Fault	<a href="#">C00588</a>
<a href="#">0x00770001</a>	7798785	Heatsink: Overtemperature	Fault	-
<a href="#">0x007b0023</a>	8060963	Load encoder: Module selected in C00490 is not available	Fault	-
<a href="#">0x006a000d</a>	6946829	Run-time error	Fault	-



# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x0068000f</a>	6815759	Power section incompatible	System fault	-
<a href="#">0x00680001</a>	6815745	Power section is defective	System fault	-
<a href="#">0x00680009</a>	6815753	Power section is defective	System fault	-
<a href="#">0x007b0042</a>	8060994	Power section is defective	System fault	-
<a href="#">0x00680014</a>	6815764	Power section has been changed	Information or warning locked if the hardware type has also changed.	-
<a href="#">0x00900001</a>	9437185	Lenze setting loaded	Information	-
<a href="#">0x00900004</a>	9437188	Loading of Lenze setting failed	Fault	-
<a href="#">0x00720000</a>	7471104	Read error service register	Fault	-
<a href="#">0x00650001</a>	6619137	Logbook: Reset (read error)	Information	-
<a href="#">0x00650002</a>	6619138	Logbook: Reset (version error)	Information	-
<a href="#">0x00650000</a>	6619136	Logbook: Overflow	Information	-
<a href="#">0x00b80010</a>	12058640	Maximum speed exceeded	Information	<a href="#">C02716/3</a>
<a href="#">0x00b80011</a>	12058641	Maximum acceleration exceeded	Information	<a href="#">C02716/3</a>
<a href="#">0x007b004c</a>	8061004	Motor disconnected	No response	<a href="#">C00597</a>
<a href="#">0x007b0007</a>	8060935	Motor: rated current &lt; rated magnetising current	Information	-
<a href="#">0x007b0002</a>	8060930	Motor: Calculated mutual inductance unrealistic	Information	-
<a href="#">0x007b000a</a>	8060938	Motor: Calculated mutual inductance unrealistic	Information	-
<a href="#">0x007b0001</a>	8060929	Motor: Calculated motor impedance unrealistic	Information	-
<a href="#">0x007b000c</a>	8060940	Motor: Calculated rotor time constant unrealistic	Information	-
<a href="#">0x007b0019</a>	8060953	Motor: Calculated leakage inductance unrealistic	Information	-
<a href="#">0x007b000b</a>	8060939	Motor: Calculated e.m.f. factor unrealistic	Information	-
<a href="#">0x007b000d</a>	8060941	Motor: Calculated flux factor unrealistic	Information	-
<a href="#">0x007b0009</a>	8060937	Motor: Calculated rotor resistance unrealistic	Information	-
<a href="#">0x007b0020</a>	8060960	Motor: Actual speed value &gt; C00596	Fault	<a href="#">C00607</a>
<a href="#">0x007b0006</a>	8060934	Motor: Device current too low for rated magnetisation	Information	-
<a href="#">0x007b0004</a>	8060932	Motor: Phase resistance too high	Information	-
<a href="#">0x0077000f</a>	7798799	Motor: PTC has triggered	No response	<a href="#">C00585</a>
<a href="#">0x007b001e</a>	8060958	Motor: Actual current value &gt; C00620	Fault	<a href="#">C00619</a>
<a href="#">0x00770002</a>	7798786	Motor: Temperature &gt; C00121	Warning	<a href="#">C00584</a>
<a href="#">0x0077000c</a>	7798796	Motor: Thermal detector is defective	Fault	<a href="#">C00594</a>
<a href="#">0x00770003</a>	7798787	Motor: Overtemperature	Fault	<a href="#">C00583</a>
<a href="#">0x00780003</a>	7864323	Motor load I <sup>xt</sup> &gt; C00120	Fault	-
<a href="#">0x00780002</a>	7864322	Motor load I <sup>xt</sup> &gt; C00127	Warning	<a href="#">C00606</a>
<a href="#">0x00b80004</a>	12058628	Motor brake: Autom. activated after waiting time has elapsed	Information	-
<a href="#">0x00b80005</a>	12058629	Motor brake: Status monitoring error	Quick stop by trouble	-
<a href="#">0x00b80003</a>	12058627	Motor brake: Angular drift with closed brake too high	Quick stop by trouble	-
<a href="#">0x007b0003</a>	8060931	Motor data are inconsistent	Information	-
<a href="#">0x007b0017</a>	8060951	Motor data are inconsistent	Information	-
<a href="#">0x007b0024</a>	8060964	Motor encoder: Module selected in C00495 is not available	Fault	-
<a href="#">0x007b0038</a>	8060984	Motor parameter identification cancelled	Fault	-
<a href="#">0x007b0013</a>	8060947	Motor control: Task overflow	System fault	-
<a href="#">0x007b0025</a>	8060965	Motor temperature: Module selected in C01193 is not available	Fault	-
<a href="#">0x008c0017</a>	9175063	MXI1: CAN module is missing or incompatible	Fault	<a href="#">C00615/2</a>
<a href="#">0x008c0011</a>	9175057	MXI1: Ethernet module is missing or incompatible	Fault	<a href="#">C00615/2</a>
<a href="#">0x00680010</a>	6815760	MXI1: Wrong module	System fault	-
<a href="#">0x008c0015</a>	9175061	MXI1: ICM module is missing or incompatible	Fault	<a href="#">C00615/2</a>
<a href="#">0x008c0013</a>	9175059	MXI1: Digital frequency module is missing or incompatible	Fault	<a href="#">C00615/2</a>
<a href="#">0x008c000d</a>	9175053	MXI1: Module is missing or incompatible	Fault	-
<a href="#">0x0068000a</a>	6815754	MXI1: Module is defective or missing	Fault	-
<a href="#">0x00680004</a>	6815748	MXI1: Module changed during operation	Warning locked	-

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x00680015</a>	6815765	MXI1: Module has been changed	Information or warning locked if the hardware type has also changed.	-
<a href="#">0x008c000f</a>	9175055	MXI1: PROFIBUS module is missing or incompatible	Fault	<a href="#">C00615/2</a>
<a href="#">0x008c0018</a>	9175064	MXI2: CAN module is missing or incompatible	Fault	<a href="#">C00615/3</a>
<a href="#">0x008c0012</a>	9175058	MXI2: Ethernet module is missing or incompatible	Fault	<a href="#">C00615/3</a>
<a href="#">0x00680011</a>	6815761	MXI2: Wrong module	System fault	-
<a href="#">0x008c0016</a>	9175062	MXI2: ICM module is missing or incompatible	Fault	<a href="#">C00615/3</a>
<a href="#">0x008c0014</a>	9175060	MXI2: Digital frequency module is missing or incompatible	Fault	<a href="#">C00615/3</a>
<a href="#">0x008c000e</a>	9175054	MXI2: Module is missing or incompatible	Fault	-
<a href="#">0x0068000b</a>	6815755	MXI2: Module is defective or missing	System fault	-
<a href="#">0x00680005</a>	6815749	MXI2: Module changed during operation	Warning locked	-
<a href="#">0x00680016</a>	6815766	MXI2: Module has been changed	Information or warning locked if the hardware type has also changed.	-
<a href="#">0x008c0010</a>	9175056	MXI2: PROFIBUS module is missing or incompatible	Fault	<a href="#">C00615/3</a>
<a href="#">0x00b8000a</a>	12058634	Negative direction of rotation limited	Information	<a href="#">C02716/1</a>
<a href="#">0x00b80002</a>	12058626	Negative limit switch has triggered	Quick stop by trouble	-
<a href="#">0x00b80008</a>	12058632	Negative software limit switch overtravelled	Quick stop by trouble	<a href="#">C02716/2</a>
<a href="#">0x00910001</a>	9502721	Mains voltage is switched off	Information	-
<a href="#">0x00910000</a>	9502720	Mains voltage is switched on	Information	-
<a href="#">0x006a0003</a>	6946819	New applications loaded	Information	-
<a href="#">0x00900006</a>	9437190	Saving of parameters failed	Fault	-
<a href="#">0x00900000</a>	9437184	Parameter set faulty	Fault	-
<a href="#">0x00900003</a>	9437187	Parameter set loaded	Information	-
<a href="#">0x00900002</a>	9437186	Parameter set saved	Information	-
<a href="#">0x00900005</a>	9437189	Parameter set restored	Fault	-
<a href="#">0x00900009</a>	9437193	Parameter set: Type of standard device has been changed	Information	-
<a href="#">0x00900007</a>	9437191	Parameter set: Version conflict	Fault	-
<a href="#">0x006a0015</a>	6946837	PDO mapping (MXI1): Faulty configuration	Fault	-
<a href="#">0x006a0016</a>	6946838	PDO mapping (MXI2): Faulty configuration	Fault	-
<a href="#">0x007b004a</a>	8061002	Pole position identification cancelled	Fault	<a href="#">C00640</a>
<a href="#">0x00910010</a>	9502736	Position value faulty	Fault	-
<a href="#">0x00b8000f</a>	12058639	Position target outside the software limit positions	Quick stop by trouble	<a href="#">C02716/2</a>
<a href="#">0x00b80009</a>	12058633	Positive direction of rotation limited	Information	<a href="#">C02716/1</a>
<a href="#">0x00b80001</a>	12058625	Positive limit switch has triggered	Quick stop by trouble	-
<a href="#">0x00b80007</a>	12058631	Positive software limit switch overtravelled	Quick stop by trouble	<a href="#">C02716/2</a>
<a href="#">0x008c0009</a>	9175049	Project not loaded	Fault	-
<a href="#">0x008c000a</a>	9175050	Project not available	Fault	-
<a href="#">0x00b80019</a>	12058649	Homing mode not allowed	Fault	-
<a href="#">0x007b001f</a>	8060959	Resolver: Calculated acceleration unrealistic	Information	-
<a href="#">0x007b0018</a>	8060952	Resolver: Open circuit	Fault	-
<a href="#">0x006a001a</a>	6946842	Retain memory of the application faulty		-
<a href="#">0x00b8000e</a>	12058638	Jerk has been limited	Information	<a href="#">C02716/3</a>
<a href="#">0x00680003</a>	6815747	Safety module is defective or missing	System fault	-
<a href="#">0x0068000d</a>	6815757	Safety module is defective or missing	System fault	-
<a href="#">0x00680007</a>	6815751	Safety module has been removed	System fault	-
<a href="#">0x00680018</a>	6815768	Safety module has been changed	Information or warning locked if the hardware type has also changed.	-
<a href="#">0x00920000</a>	9568256	Safety module: Incompatible with setting in C00214	System fault	-
<a href="#">0x00650003</a>	6619139	Memory module is missing	Information	-
<a href="#">0x00680002</a>	6815746	Memory module is defective or missing	Fault	-

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis Error messages of the operating system

Error number		Error message	Response (Lenze setting)	Adjustable in
hex	dec			
<a href="#">0x0068000c</a>	6815756	Memory module is defective or missing	System fault	-
<a href="#">0x00680006</a>	6815750	Memory module has been removed	System fault	-
<a href="#">0x00680017</a>	6815767	Memory module has been changed	Information or warning locked if the hardware type has also changed.	-
<a href="#">0x0068001c</a>	6815772	Memory module: Faulty file system	Fault	-
<a href="#">0x007c0000</a>	8126464	Memory module: File system has been formatted	Information	-
<a href="#">0x007c0001</a>	8126465	Memory module: File system has been restored	Information	-
<a href="#">0x00b80000</a>	12058624	PLC configuration invalid	Fault	-
<a href="#">0x007d0001</a>	8192001	PLC configuration invalid	Fault	-
<a href="#">0x007b0037</a>	8060983	PLC configuration invalid	Fault	-
<a href="#">0x00750006</a>	7667718	PLC configuration invalid	Fault	-
<a href="#">0x0068000e</a>	6815758	Control card incompatible	System fault	-
<a href="#">0x00680000</a>	6815744	Control card is defective	System fault	-
<a href="#">0x00680008</a>	6815752	Control card is defective	System fault	-
<a href="#">0x00780008</a>	7864328	Control card is defective (UB18 neg.)	System fault	-
<a href="#">0x00780004</a>	7864324	Control card is defective (UB24)	System fault	-
<a href="#">0x00780006</a>	7864326	Control card is defective (UB8)	System fault	-
<a href="#">0x00780007</a>	7864327	Control card is defective (VCC15 neg.)	System fault	-
<a href="#">0x00780005</a>	7864325	Control card is defective (VCC15)	System fault	-
<a href="#">0x00780009</a>	7864329	Control card is defective (VCC5)	System fault	-
<a href="#">0x006f0000</a>	7274496	Control card: Supply voltage (24 V DC) too low	Trouble	-
<a href="#">0x0091000a</a>	9502730	System task 1: Task overflow	System fault	-
<a href="#">0x0091000b</a>	9502731	System task 2: Task overflow	Information	-
<a href="#">0x0091000c</a>	9502732	System task 3: Task overflow	System fault	-
<a href="#">0x0091000d</a>	9502733	System task: Task overflow	Fault	-
<a href="#">0x00b80012</a>	12058642	Time-out torque feedforward control brake	Quick stop by trouble	-
<a href="#">0x007b0010</a>	8060944	Overcurrent detected	Fault	-
<a href="#">0x006a0005</a>	6946821	UserTask: Overflow	Fault	<a href="#">C02111</a>
<a href="#">0x00790002</a>	7929858	Violation of time slice	Fault	-
<a href="#">0x00b8000d</a>	12058637	Deceleration has been limited	Information	<a href="#">C02716/3</a>
<a href="#">0x006a0012</a>	6946834	Pointer access in impermissible memory area	Fault	-
<a href="#">0x00790001</a>	7929857	Time error - controller interface	System fault	-
<a href="#">0x0077000d</a>	7798797	DC-bus capacitor: Thermal detector is defective	Fault	<a href="#">C00588</a>
<a href="#">0x007b000e</a>	8060942	DC-bus overvoltage	Trouble	<a href="#">C00600</a>
<a href="#">0x007b000f</a>	8060943	DC-bus undervoltage	Trouble	-
<a href="#">0x0091000f</a>	9502735	Cyclic task: Standstill > 60 s	Information	-

#### 13.7.4 Cause & possible remedies

This chapter contains all error messages of the controller operating system in numerical order of the error number with detailed information on the response to the error message and information on the cause & possible remedies.



#### Tip!

A list of all error messages of the controller operating system in alphabetical order can be found in the previous chapter "[Short overview \(A-Z\)](#)". (📖 628)



#### Note!

##### Error message "Unknown error"

If the "Unknown error xxxx" error message is indicated in the logbook or in [C00166](#), the reason for the missing plain text is that the error texts required have not been downloaded to the controller during the application download.

- This, for instance, is the case if a device module plugged into the controller has not been included in the Engineer project.
- Remedy: Include the device module, recompile and download the project.

#### Logbook: Overflow [0x00650000]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Too many events/faults have occurred in a very short time. It was therefore not possible to list all of them in the logbook.

Remedy

Check whether application generates too many error messages.

#### Logbook: Reset (read error) [0x00650001]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The logbook has been reset due to a read error..

Remedy

- (is irreversible)

#### Logbook: Reset (version error) [0x00650002]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The logbook has been reset due to a version conflict.

Remedy

- (is irreversible)

## Memory module is missing [0x00650003]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

Memory module is defective or not available.

**Remedy**

Use a different memory module.

## Control card is defect [0x00680000]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the control card.

**Remedy**

Mains switching  

- Please contact Lenze if the error occurs again.

## Power section is defect [0x00680001]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the power section.

**Remedy**

Mains switching  

- Please contact Lenze if the error occurs again.

## Memory module is defect or missing [0x00680002]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the memory module.

**Remedy**

Mains switching  

- If the error occurs again: Switch off the controller, remove memory module and plug in again, switch on the controller again.
- If the error still occurs: Switch off controller and use a different memory module.

## Safety module is defect or missing [0x00680003]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the safety module.

**Remedy**

Mains switching  

- If the error occurs again: Switch off the controller, remove safety module and plug in again, switch on the controller again.
- If the error still occurs: Switch off controller and use a different safety module.

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## MXI1: Module changed during operation [0x00680004]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
It was tried to plug an extension module into module slot MXI1, which is not "Hot-plug"-able.	Plug in valid module and switch on mains. <ul style="list-style-type: none"><li>• Through mains switching, the system accepts modules without "hot plug" capability in the following switch-on phase.</li></ul>

## MXI2: Module changed during operation [0x00680005]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
It was tried to plug an extension module into module slot MXI2, which is not "Hot-plug"-able.	Plug in valid module and switch on mains. <ul style="list-style-type: none"><li>• Through mains switching, the system accepts modules without "hot plug" capability in the following switch-on phase.</li></ul>

## Memory module has been removed [0x00680006]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
You have tried to remove or change the memory module during operation.	Switch off the controller, plug in memory module and switch on the controller again. <ul style="list-style-type: none"><li>• If the error occurs again, the memory module is defective and must be replaced.</li></ul>

## Safety module has been removed [0x00680007]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
You have tried to remove or change the safety module during operation.	Switch off the controller, plug in safety module and switch on the controller again. <ul style="list-style-type: none"><li>• If the error occurs again, the safety module is defective and must be replaced.</li></ul>

## Control card is defect [0x00680008]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the control card.	Please contact Lenze.

## Power section is defect [0x00680009]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the power section.	Please contact Lenze.

## MXI1: Module is defect or missing [0x0068000a]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the extension module in module slot MXI1.

**Remedy**

- Use a different extension module.
- Please contact Lenze.

## MXI2: Module is defect or missing [0x0068000b]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the extension module in module slot MXI2.

**Remedy**

- Use a different extension module.
- Please contact Lenze.

## Memory module is defect or missing [0x0068000c]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the memory module.

**Remedy**

- Use a different memory module.
- Please contact Lenze.

## Safety module is defect or missing [0x0068000d]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Operating system could not identify the safety module.

**Remedy**

- Use a different safety module.
- Please contact Lenze.

## Control card incompatible [0x0068000e]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The control card is not supported by the operating system.

**Remedy**

Please contact Lenze.

## Power section incompatible [0x0068000f]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The power section is not supported by the operating system.

**Remedy**

Please contact Lenze.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### MXI1: Wrong module [0x00680010]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The extension module in module slot MXI1 is not supported by the operating system.

**Remedy**

- Use a different module.
- Please contact Lenze.

#### MXI2: Wrong module [0x00680011]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The extension module in module slot MXI2 is not supported by the operating system.

**Remedy**

- Use a different module.
- Please contact Lenze.

#### Incorrect memory module [0x00680012]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The memory module is not supported by the operating system.

**Remedy**

- Use a different module.
- Please contact Lenze.

#### Incorrect safety module [0x00680013]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The safety module is not supported by the operating system.

**Remedy**

- Use a different module.
- Please contact Lenze.

#### Power section was changed [0x00680014]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

**Cause**

The power section has been changed since the last mains switching.

**Remedy**

(Only information or warning locked if the hardware type has also changed.)

#### MXI1: Module has been changed [0x00680015]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

**Cause**

The extension module in module slot MXI1 has been changed since the last mains switching.

**Remedy**

(Only information or warning locked if the hardware type has also changed.)



## MXI2: Module has been changed [0x00680016]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

**Cause**

The extension module in module slot MXI2 has been changed since the last mains switching.

**Remedy**

(Only information or warning locked if the hardware type has also changed.)

## Memory module has been changed [0x00680017]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

**Cause**

The memory module has been changed since the last mains switching.

**Remedy**

(Only information or warning locked if the hardware type has also changed.)

## Safety module has been changed [0x00680018]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

**Cause**

The safety module has been changed since the last mains switching.

**Remedy**

(Only information or warning locked if the hardware type has also changed.)

## Combination MXI1/MXI2 not possible [0x00680019]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Extension modules which are not supported in this combination are plugged into module slots MXI1 & MXI2.

**Remedy**

Create permitted module combination.

## Firmware has been changed [0x0068001a]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

The firmware of the operating system has been updated.

**Remedy**

- (Information only)

## Electronic nameplate: Communication error [0x0068001b]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

**Cause**

Communication with the electronic nameplate is interrupted, the data could not be read.

**Remedy**

Check correct connection of the encoder cable.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Memory module: Faulty file system [0x0068001c]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Memory module is plugged in incorrectly or is defective.

Remedy

- Plug in the memory module correctly.
- Exchange defective memory module.

#### Electronic nameplate: Checksum error [0x0068001d]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

Cause

The checksum of the electronic nameplate is defective.

Remedy

Please contact Lenze.

#### Firmware is incompatible with control card [0x0068001e]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Firmware is not compatible with the hardware.

Remedy

Import the compatible firmware.

#### Combination memory module/device not possible [0x0068001f]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The memory module used is not supported by the controller according to the license model.

Remedy

- Plug in supported module and switch the mains.
- The 9400 HighLine supports the MM220 (licence: Motion Control HighLevel) and MM330 memory modules (licence: Motion Control TopLevel).

#### Combination of module in MXI1/device not possible [0x00680020]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The extension module in module slot MXI1 is not supported by the controller.

Remedy

- Remove the extension module and switch the mains.
- Plug in supported extension module and switch the mains.

#### Combination of module in MXI2/device not possible [0x00680021]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The extension module in module slot MXI2 is not supported by the controller.

Remedy

- Remove the extension module and switch the mains.
- Plug in supported extension module and switch the mains.

## Real-time clock is defective [0x00680022]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

Device error: The clock integrated in the MM440 memory module is defective.

**Remedy**

- Replace memory module.
- Please contact Lenze.

## Real-time clock: Change battery [0x00680023]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

The battery in the clock integrated in the MM440 memory module is low. The clock is expected to fail soon.

**Remedy**

Replace memory module.

## Real-time clock: Battery empty, time lost [0x00680024]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

The battery integrated in the clock in the MM440 memory module is empty. The clock has been reset to its initial value (01.01.1970 - 00:00:00 o'clock).

**Remedy**

- If the memory module is used for the first time, restart the controller to initialise the memory module.
- If the problem occurs again, replace the memory module.

## Code refresh [0x00690000]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Serious device error or component failure.

**Remedy**

- Switch the controller off and then on again.
- Please contact Lenze if the problem occurs again.

## Internal error (memory area - logbook) [0x00690001]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Serious device error or component failure.

**Remedy**

- Switch the controller off and then on again.
- Please contact Lenze if the problem occurs again.

## Internal error (LDS instance data) [0x00690002]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Serious device error or component failure.

**Remedy**

- Switch the controller off and then on again.
- Please contact Lenze if the problem occurs again.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Internal error (LDS tasks) [0x00690003]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

#### Internal error (storage blocks) [0x00690004]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

#### Internal error (task queue) [0x00690005]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

#### Internal error (message memory) [0x00690006]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

#### Internal error (message queue) [0x00690007]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

#### Internal error (name data base) [0x00690008]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

## Internal error (event mechanism) [0x00690009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> <li>• Please contact Lenze if the problem occurs again.</li> </ul>

## Internal error (event mechanism) [0x0069000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> <li>• Please contact Lenze if the problem occurs again.</li> </ul>

## Internal error (semaphores) [0x0069000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> <li>• Please contact Lenze if the problem occurs again.</li> </ul>

## Internal error (semaphores) [0x0069000c]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> <li>• Please contact Lenze if the problem occurs again.</li> </ul>

## Internal error (file system lifetime) [0x0069000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The maximum number of permissible writing cycles has been reached for the memory module.	Replace memory module, otherwise data may get lost.

## General error in the application [0x006a0000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
General application error.	Mains switching. Transmit the application to the controller again. <ul style="list-style-type: none"> <li>• Please contact Lenze if the problem occurs again.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Faulty program download [0x006a0001]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Faulty transmission of the application to the controller (checksum error).	Repeat transmission.

#### Fault during the update of the inputs and outputs [0x006a0002]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Mains switching. Transmit the application to the controller again. <ul style="list-style-type: none"><li>• Please contact Lenze if the problem occurs again.</li></ul>

#### New application loaded [0x006a0003]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Application has been changed by transmission from the Engineer or loading from the memory module.	- (Information only)

#### ApplicationTask: Overflow [0x006a0004]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C02111</a> ( <input checked="" type="checkbox"/> Adjustable response) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in Application task is too high.	Reduce program runtime by means of: <ul style="list-style-type: none"><li>• Omitting functions (e.g. by reducing the number of active FBs).</li><li>• Optimisation of functions to the calculating time.</li></ul>

#### UserTask: Overflow [0x006a0005]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C02111</a> ( <input checked="" type="checkbox"/> Adjustable response) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task is too high.	Reduce program runtime by means of: <ul style="list-style-type: none"><li>• Omitting functions (e.g. by reducing the number of active FBs).</li><li>• Optimisation of functions to the calculating time.</li></ul>

## IdleTask: Overflow [0x006a0006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in idle task is too high.	Reduce program runtime by means of: <ul style="list-style-type: none"> <li>• Omitting functions (e.g. by reducing the number of active FBs).</li> <li>• Optimisation of functions to the calculating time.</li> </ul>

## Runtime error [0x006a000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
A runtime error has occurred in the application. The application processing has been interrupted.	Remove runtime error in the application and retransfer application to controller.

## Application has stopped [0x006a000e]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The application has been stopped using the device command <a href="#">C00002</a> ="32". All user tasks are stopped.	Restart application with device command <a href="#">C00002</a> ="31".

## Breakpoint reached [0x006a000f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The application has reached a set breakpoint and the user task with the breakpoint has stopped.	Delete breakpoint and restart application.

## Faulty application parameter [0x006a0010]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid parameter description is available.	Transmit application and parameter set to the controller again.

## Division by zero [0x006a0011]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An impermissible division by zero occurred in the application. The division has been intercepted and the divisor was replaced by the value "1".	Replace application.

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Pointer access in impermissible memory area [0x006a0012]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid pointer access to a protected area occurred in the application.	Replace application.

## Application has started [0x006a0013]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The application in the controller has been started.	- (Information only)

## Application has stopped [0x006a0014]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The application in the controller has been stopped.	- (Information only)

## PDO mapping (MXI1): Faulty configuration [0x006a0015]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: Incorrectly configured process data mapping. <ul style="list-style-type: none"><li>• The corresponding PDO channel is not installed, e. g. because no communication module was selected for module slot MXI1 in the Engineer project.</li><li>• The communication module selected for module slot MXI1 in the Engineer project does not support PDO mapping.</li><li>• The mapping information downloaded to the controller is faulty.</li></ul>	<ul style="list-style-type: none"><li>• Integrate suitable communication module for module slot MXI1 in the Engineer project.</li><li>• Check the configuration of the network. Then recompile the project and transmit it to the controller.</li></ul>

## PDO mapping (MXI2): Faulty configuration [0x006a0016]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: Incorrectly configured process data mapping. <ul style="list-style-type: none"><li>• The corresponding PDO channel is not installed, e. g. because no communication module was selected for module slot MXI2 in the Engineer project.</li><li>• The communication module selected for module slot MXI2 in the Engineer project does not support PDO mapping.</li><li>• The mapping information downloaded to the controller is faulty.</li></ul>	<ul style="list-style-type: none"><li>• Integrate suitable communication module for module slot MXI2 in the Engineer project.</li><li>• Check the configuration of the network. Then recompile the project and transmit it to the controller.</li></ul>



## Fault in the control configuration [0x006a0017]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid control configuration has occurred.	Load a different application.

## Retain memory of the application faulty [0x006a001a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>

## Control card: Supply voltage (24 V DC) too low [0x006f0000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input checked="" type="checkbox"/> <b>Trouble</b> <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
External 24 V supply voltage of the control card is lower than 18 V.	Check external supply voltage. <ul style="list-style-type: none"> <li>If the external supply voltage is available and the error message does not disappear, please contact Lenze.</li> </ul>

## Read error service register [0x00720000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
During reading or writing the service register a fault has occurred.	Mains switching <ul style="list-style-type: none"> <li>Please contact Lenze if the problem occurs again.</li> </ul>

## External error [0x00750000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00581</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The drive interface has activated the error message "External error". <ul style="list-style-type: none"> <li>The input <i>DI_bSetExternError</i> of the system block <b>LS_DriveInterface</b> has been set to TRUE.</li> </ul>	<ul style="list-style-type: none"> <li>Check external device to be monitored.</li> <li>Check assignment of the input <i>DI_bSetExternError</i> in the application.</li> </ul>	

## Controller enabled [0x00750001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The controller is enabled and has the "Operation" state.	- (Information only)

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Controller in STO state [0x00750003]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

The controller has received the "Safe torque off (STO)" request by the safety module and is now in the "Safe torque off active" device state.

**Remedy**

- (Information only)

#### Controller: Pulse inhibit is active [0x00750005]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

The pulse inhibit is active in the controller.

**Remedy**

- (Information only)

#### PLC configuration invalid [0x00750006]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

An invalid control configuration has occurred.

**Remedy**

Load a different application.

#### Heatsink: Temperature &gt; C00122 [0x00770000]

**Response** (Lenze setting printed in bold)

**Setting:** [C00582](#) ( Adjustable response)

**None**  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

**Cause**

Heatsink temperature higher than variable temperature limit ([C00122](#)).

- Ambient controller temperature too high.
- Dirty fan or ventilation slots.
- Value set under C00122 is too low.

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.
- Set a higher value under [C00122](#).

#### Heatsink: Overtemperature [0x00770001]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Heatsink temperature higher than fixed temperature limit (90 °C).

- Ambient controller temperature too high.
- Dirty fan or ventilation slots.

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.

## Motor: Temperature &gt; C00121 [0x00770002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00584</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Motor temperature higher than variable temperature limit ( <a href="#">C00121</a> ). <ul style="list-style-type: none"> <li>Motor too hot due to impermissibly high currents or frequent and too long acceleration processes.</li> <li>No PTC connected.</li> <li>Value set under <a href="#">C00121</a> is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Connect PTC or switch off monitoring (<a href="#">C00584</a>="0").</li> <li>Set a higher value under <a href="#">C00121</a>.</li> </ul>	

## Motor: Overtemperature [0x00770003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00583</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Motor temperature higher than fixed temperature limit (150 °C). <ul style="list-style-type: none"> <li>Motor too hot due to impermissibly high currents or frequent and too long acceleration processes.</li> <li>No PTC connected.</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Connect PTC or switch off monitoring (<a href="#">C00583</a>="0").</li> </ul>	

## CPU: Temperature &gt; C00126 [0x00770008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00589</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CPU temperature higher than variable temperature limit ( <a href="#">C00126</a> ). <ul style="list-style-type: none"> <li>Ambient controller temperature too high.</li> <li>Dirty fan or ventilation slots.</li> <li>Value set under C00126 is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Check control cabinet temperature.</li> <li>Clean filter.</li> <li>Clean controller.</li> <li>Set a higher value under <a href="#">C00126</a>.</li> </ul>	

## CPU: Overtemperature [0x00770009]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CPU temperature higher than fixed limit temperature (85 °C). <ul style="list-style-type: none"> <li>Ambient controller temperature too high.</li> <li>Dirty fan or ventilation slots.</li> </ul>	<ul style="list-style-type: none"> <li>Check control cabinet temperature.</li> <li>Clean filter.</li> <li>Clean controller.</li> </ul>	

## Heatsink: Thermal detector is defect [0x0077000a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00588</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Encoder for heatsink temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Inside the device: Thermal detector is defective [0x0077000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00588</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Encoder for interior temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.

#### Motor: Thermal detector is defect [0x0077000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00594</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The signals of the connected encoder for the motor temperature detection (resolver at X7 or encoder at X8) are outside the defined operating range of the detection.	<ul style="list-style-type: none"><li>• Check contacts of the encoder cable at the motor and controller.</li><li>• Check selection of the motor temperature sensor in <a href="#">C01190</a> and make sure that it complies with the assembly in the motor.</li><li>• Possibly switch off temperature sensor monitoring (<a href="#">C00594</a>="0").</li><li>• If a PTC is in the motor, activate the monitoring of the PTC temperature in <a href="#">C00585</a> instead.</li></ul>

#### DC-bus capacitor: Thermal detector is defect [0x0077000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00588</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Encoder for capacitor temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.

#### CPU: Thermal detector is defect [0x0077000e]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00588</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Encoder for CPU temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.

#### Motor: PTC has triggered [0x0077000f]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00585</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The motor temperature detected via the terminals T1/T2 is too high. <ul style="list-style-type: none"><li>• Motor is too hot due to an increased effective current that results from operation with too high/too frequent acceleration processes.</li><li>• Motor too hot due to increased ambient conditions.</li><li>• Motor too hot due to lacking cooling in the case of self-ventilation and continuous operation with speeds lower than the rated speed.</li><li>• Terminals T1/T2 are not assigned.</li><li>• Open circuit of the supply cables for terminals T1/T2.</li></ul>	<ul style="list-style-type: none"><li>• Check drive dimensioning.</li><li>• Connect PTC or thermal contact to terminals T1/T2.</li><li>• If a motor without integrated temperature monitoring is used, switch off the monitoring function (<a href="#">C00585</a>="0").</li></ul>

## Heatsink: Fan is defect [0x00770010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00610</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>		<b>Remedy</b>
Speed of heatsink fan too low, e.g. due to dirt.		Check/clean fan.

## Inside the device: Fan is defective [0x00770011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00611</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>		<b>Remedy</b>
Speed of internal fan is too low, e.g. due to dirt.		Check/clean fan.

## Device utilisation &gt; C00123 [0x00780000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00604</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>		<b>Remedy</b>
Frequent and too long acceleration processes with overcurrent > <a href="#">C00123</a> .		Check drive dimensioning.

## Device utilisation Ixt &gt; 100 % [0x00780001]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>		<b>Remedy</b>
Frequent and too long acceleration processes with overcurrent.		Check drive dimensioning.

## Motor load I<sup>2</sup>xt &gt; C00127 [0x00780002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00606</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>		<b>Remedy</b>
Motor is thermally overloaded, e.g. due to: <ul style="list-style-type: none"> <li>• impermissible continuous current</li> <li>• frequent or too long acceleration processes</li> </ul>		<ul style="list-style-type: none"> <li>• Check drive dimensioning.</li> <li>• Check setting under <a href="#">C00127</a>.</li> </ul>

## Motor load I<sup>2</sup>xt &gt; C00120 [0x00780003]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>		<b>Remedy</b>
Motor is thermally overloaded, e.g. due to: <ul style="list-style-type: none"> <li>• impermissible continuous current</li> <li>• frequent or too long acceleration processes</li> </ul>		<ul style="list-style-type: none"> <li>• Check drive dimensioning.</li> <li>• Check setting under <a href="#">C00120</a>.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Control card is defect (UB24) [0x00780004]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Device error

Please contact Lenze.

## Control card is defect (VCC15) [0x00780005]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Device error

Please contact Lenze.

## Control card is defect (UB8) [0x00780006]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Device error

Please contact Lenze.

## Control card is defect (VCC15 neg.) [0x00780007]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Device error

Please contact Lenze.

## Control card is defect (UB18 neg.) [0x00780008]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Device error

Please contact Lenze.

## Control card is defect (VCC5) [0x00780009]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Device error

Please contact Lenze.

## Electronic nameplate: Data are incompatible [0x0078000a]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

The connected motor with feedback is not supported by the controller firmware.

Check drive dimensioning.

## Device command transferred incorrectly [0x00790000]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Internal error

If the error occurs frequently, please contact Lenze.

## Time error - controller interface [0x00790001]

**Response** (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Internal error

If the error occurs frequently, please contact Lenze.

## Violation of time slice [0x00790002]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Internal error

If the error occurs frequently, please contact Lenze.

## Motor: Calculated motor impedance unrealistic [0x007b0001]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

**Remedy**

Faulty motor parameterisation.

Check motor parameters.

## Motor: Calculated mutual inductance unrealistic [0x007b0002]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

**Remedy**

Faulty motor parameterisation.

Check motor parameters.

## Motor data are inconsistent [0x007b0003]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

**Remedy**

Faulty motor parameterisation.

Check motor parameters.

## Motor: Phase resistance too high [0x007b0004]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

**Remedy**

Faulty motor parameterisation.

Check motor parameters.

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Motor: Device current too low for rated magnetisation [0x007b0006]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Controller current is too low for rated magnetisation, i.e. the controller cannot energise the motor sufficiently.

Check drive dimensioning.

## Motor: Rated current &lt; rated magnetising current [0x007b0007]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters and setting of [C00022](#).

## Motor: Calculated rotor resistance unrealistic [0x007b0009]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

## Motor: Calculated mutual inductance unrealistic [0x007b000a]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

## Motor: Calculated e. m. f. factor unrealistic [0x007b000b]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

## Motor: Calculated rotor time constant unrealistic [0x007b000c]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

## Motor: Calculated flux factor unrealistic [0x007b000d]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.



## DC bus overvoltage [0x007b000e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00600</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> <b>Trouble</b> <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Due to a too high braking energy, the DC-bus voltage exceeds the overvoltage threshold which results from the mains voltage setting in <a href="#">C00173</a> .	<ul style="list-style-type: none"> <li>• Use brake resistor or regenerative module.</li> <li>• Check setting under <a href="#">C00173</a>.</li> </ul>	

## DC bus undervoltage [0x007b000f]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input checked="" type="checkbox"/> <b>Trouble</b> <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
DC bus voltage is lower than the undervoltage threshold resulting from the mains setting under <a href="#">C00173</a> .	<ul style="list-style-type: none"> <li>• Check mains voltage.</li> <li>• Check setting under <a href="#">C00173</a>.</li> </ul>	

## Overcurrent detected [0x007b0010]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
<ul style="list-style-type: none"> <li>• Short circuit/earth fault in motor cable.</li> <li>• Excessive capacitive charging current in the motor cable.</li> </ul>	<ul style="list-style-type: none"> <li>• Check motor cable.</li> <li>• Use motor cable that is shorter or has a lower capacitance.</li> </ul>	

## Earth fault detected [0x007b0011]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
<ul style="list-style-type: none"> <li>• Earth fault in motor cable.</li> <li>• Excessive capacitive charging current in the motor cable.</li> </ul>	<ul style="list-style-type: none"> <li>• Check motor cable.</li> <li>• Use motor cable that is shorter or has a lower capacitance.</li> </ul>	

## Actual speed value outside the tolerance (C00576) [0x007b0012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00579</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Difference between actual and setpoint speed is too big.	<ul style="list-style-type: none"> <li>• Increase speed tolerance margin under <a href="#">C00576</a>.</li> <li>• Check drive dimensioning.</li> </ul>	

## Motor control: Task overflow [0x007b0013]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Internal error (motor control).	Please contact Lenze.	

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Internal communication error (host MCTRL) [0x007b0014]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error (motor control).

Please contact Lenze.

## Motor data are inconsistent [0x007b0017]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

## Resolver: Open circuit [0x007b0018]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

- Resolver cable interrupted.
- Resolver defective.

- Check resolver cable.
- Check resolver.
- Switch off the monitoring function ([C00586](#)="3") if no resolver is used.

## Motor: Calculated leakage inductance unrealistic [0x007b0019]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

## Absolute value encoder: Communication error [0x007b001a]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Absolute value encoder does not send any data or a digital readout has been activated while the machine is coasting down.

- Check supply cable.
- Check encoder.
- Check voltage supply ([C00421](#)).

## Encoder: Open circuit [0x007b001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00580</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
<ul style="list-style-type: none"> <li>Encoder cable interrupted.</li> <li>Encoder defective.</li> <li>Faulty parameter setting of the encoder.</li> <li>Interruption of the light path of laser measuring systems.</li> <li>Insufficient reflection of the light of laser measuring systems.</li> </ul> <p><b>Note:</b> The encoder open-circuit monitoring for incremental encoders (<a href="#">C00422</a> = "0: Incremental encoder (TTL signal)") requires a signal amplitude &gt; 3.5 V! If the signal amplitude is lower than 3.0 V, the error response parameterised in <a href="#">C00580</a> is triggered.</p>	<ul style="list-style-type: none"> <li>Check encoder cable.</li> <li>Check encoder.</li> <li>Check parameter setting (<a href="#">C00422</a>).</li> <li>Switch off the monitoring function (<a href="#">C00580</a>="3") if no encoder is used.</li> <li>Correct the light path (for laser measuring systems).</li> <li>Improve the reflection (for laser measuring systems).</li> </ul>	

## Brake transistor: Ixt overload [0x007b001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00573</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Too frequent and too long braking operations.	Check drive dimensioning.	

## Brake resistor: I<sup>2</sup>xt overload [0x007b001d]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
Too frequent and too long braking operations.	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Check parameter setting (<a href="#">C00129</a>, <a href="#">C00130</a>, <a href="#">C00131</a>).</li> </ul>	

## Motor: Actual current value > C00620 [0x007b001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00619</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The instantaneous value of the motor current has exceeded the value set in <a href="#">C00620</a> .	<ul style="list-style-type: none"> <li>Set a higher value in <a href="#">C00620</a>.</li> <li>Reduce maximum current (<a href="#">C00022</a>).</li> <li>Change response (<a href="#">C00619</a>).</li> </ul>	

## Resolver: Calculated acceleration unrealistic [0x007b001f]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
Resolver evaluation faulty (implausible acceleration at the resolver).	Check structure.	

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Motor: Actual speed value &gt; C00596 [0x007b0020]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: <a href="#">C00607</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
Threshold for speed monitoring set in <a href="#">C00596</a> has been exceeded.	Check drive dimensioning.

## Brake transistor: Overcurrent [0x007b0021]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: <a href="#">C00607</a> ( <input type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
Brake chopper short circuit/earth fault detected.	Check brake chopper cable and brake resistor.

## Position encoder: Module selected in C00490 not available [0x007b0023]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: <a href="#">C00607</a> ( <input type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
The position encode selected under <a href="#">C00490</a> has not been recognised.	<ul style="list-style-type: none"><li>• Check position encoder.</li><li>• Check parameter setting (<a href="#">C00490</a>).</li></ul>

## Motor encoder: Module selected in C00495 not available [0x007b0024]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: <a href="#">C00607</a> ( <input type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
The motor encoder selected under <a href="#">C00495</a> has not been recognised.	<ul style="list-style-type: none"><li>• Check motor encoder.</li><li>• Check parameter setting (<a href="#">C00495</a>).</li></ul>

## Motor temperature: Module selected in C01193 not available [0x007b0025]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: <a href="#">C00607</a> ( <input type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
The module for temperature feedback selected in <a href="#">C01193</a> has not been recognised.	<ul style="list-style-type: none"><li>• Check feedback module.</li><li>• Check parameter setting (<a href="#">C01193</a>).</li></ul>

## EnDat encoder: Lamp error [0x007b0026]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
Setting: <a href="#">C00607</a> ( <input type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
EnDat encoder defective.	Check EnDat encoder.

## EnDat encoder: Signal error [0x007b0027]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## EnDat encoder: Position error [0x007b0028]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## EnDat encoder: Overvoltage [0x007b0029]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## EnDat encoder: Undervoltage [0x007b002a]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## EnDat encoder: Overcurrent [0x007b002b]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## EnDat encoder: Battery empty [0x007b002c]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## Failure of motor phase U [0x007b002d]

**Response** (Lenze setting printed in bold)

**Setting:** [C00597](#) ( Adjustable response)

**None**  System fault  **Fault**  **Trouble**  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

U phase interruption of motor cable.

**Remedy**

- Check cabling between the controller and motor.
- Check parameter setting ([C00599](#)).

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Failure of motor phase V [0x007b002e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00597</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
V phase interruption of the motor cable.	<ul style="list-style-type: none"><li>• Check cabling between the controller and motor.</li><li>• Check parameter setting (<a href="#">C00599</a>).</li></ul>	

#### Failure of motor phase W [0x007b002f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00597</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
W phase interruption of the motor cable.	<ul style="list-style-type: none"><li>• Check cabling between the controller and motor.</li><li>• Check parameter setting (<a href="#">C00599</a>).</li></ul>	

#### Electronic nameplate: Data loaded [0x007b0030]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
New electronic nameplate (ENP) has been found.	- (Information only)	

#### Electronic nameplate: Not found [0x007b0031]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
Electronic nameplate (ENP) is not available.	- (Information only)	

#### Electronic nameplate: Encoder protocol unknown [0x007b0032]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
The connected motor with feedback is not supported by the controller firmware.	Check drive dimensioning.	

#### Electronic nameplate: Encoder signal unknown [0x007b0033]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
The connected motor with feedback is not supported by the controller firmware.	Check drive dimensioning.	

## Internal communication error (DMA) [0x007b0034]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error.	Please contact Lenze.

## Controller: Overload during acceleration phases [0x007b0035]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Frequent or too long acceleration processes.	<ul style="list-style-type: none"> <li>• Check drive dimensioning.</li> <li>• Reduce steepness of acceleration ramps.</li> </ul>

## Internal communication error (MCTRL host) [0x007b0036]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error.	Please contact Lenze.

## PLC configuration invalid [0x007b0037]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid control configuration has occurred.	Load a different application.

## Motor parameter identification was cancelled [0x007b0038]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The motor current during identification was too high.	<ul style="list-style-type: none"> <li>• The motor must not move during identification.</li> <li>• Check motor parameters.</li> </ul>

## Electronic nameplate: Data outside the parameter limits [0x007b0039]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The motor parameters of the electronic nameplate are outside of the limit values of the controller and therefore cannot be accepted.	Please contact Lenze.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Hiperface encoder: Transmission error [0x007b003a]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

- Encoder signal interferences (EMC).
- Encoder cable interrupted.
- Encoder defective.
- Faulty parameter setting of the encoder.

**Note:** This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated ([C00580](#)).

Remedy

- Check encoder cable, if required, use shorter encoder cable.
- Check encoder.
- Check parameter setting ([C00420](#), [C00421](#), [C00422](#)).

#### Hiperface encoder: Command error [0x007b003b]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

- Encoder signal interferences (EMC).
- Encoder cable interrupted.
- Encoder defective.
- Faulty parameter setting of the encoder.

**Note:** This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated ([C00580](#)).

Remedy

- Check encoder cable, if required, use shorter encoder cable.
- Check encoder.
- Check parameter setting ([C00420](#), [C00421](#), [C00422](#)).

#### Hiperface encoder: Unknown encoder [0x007b003c]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Encoder is not supported by the controller firmware.

Remedy

- Exchange encoder for known type.
- **From software version V4.0:** Parameterise the unknown encoder with the codes [C00414](#) (type code) and [C00415](#) (number of revolutions).

#### Hiperface encoder: Position initialisation error [0x007b003d]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

A digital readout of the absolute encoder is only possible at standstill.

The readout is activated by the following actions:

- Mains switching
- Change of [C00420](#), [C00422](#) and [C00427](#)
- To "[Absolute value encoder: Communication error](#)"
- To "[Encoder: Open circuit](#)"

**Note:** This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated ([C00580](#)).

Remedy

Prevent coasting of the machine while the absolute encoder is read out.



## Encoder monitoring: Pulse deviation detected [0x007b003e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00621</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
<ul style="list-style-type: none"> <li>Encoder signal interferences (EMC).</li> <li>Encoder cable interrupted.</li> <li>Encoder defective.</li> <li>Faulty parameter setting of the encoder.</li> </ul>	<ul style="list-style-type: none"> <li>Check encoder cable, if required, use shorter encoder cable.</li> <li>Check encoder.</li> <li>Check parameter setting (<a href="#">C00422</a>).</li> <li>Possibly switch off monitoring (<a href="#">C00621</a>).</li> </ul>	

## Failure of a mains phase [0x007b003f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Missing mains phase. <b>Note:</b> This monitoring is only available for devices $\geq 75$ kW (type 8S and bigger).	Check mains connection.

## Brake chopper: Ixt &gt; C00570 [0x007b0040]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00569</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Frequent and too long braking.	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Check setting in <a href="#">C00570</a>.</li> </ul>	

## Brake resistor: I2t &gt; C00572 [0x007b0041]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00571</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Frequent and too long braking.	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Check setting in <a href="#">C00572</a>.</li> <li>Check settings for brake resistor (<a href="#">C00129</a>, <a href="#">C00130</a>, <a href="#">C00131</a>).</li> </ul>	

## Power section is defect [0x007b0042]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Device error	Mains switching <ul style="list-style-type: none"> <li>Please contact Lenze if the problem occurs again.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Controller: Clamp operation [0x007b0047]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Actual motor current is higher than the maximum device current ( <a href="#">C00789</a> ).	<ul style="list-style-type: none"><li>• Increase speed setpoint ramps.</li><li>• Optimise I<sub>max</sub> controller.</li></ul>

#### Pole position recognition cancelled [0x007b004a]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C00640</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
<a href="#">From software version V4.0</a> An error occurred during the pole position identification. The pole position identification could not be completed successfully.	<ul style="list-style-type: none"><li>• Check whether all requirements for an identification of the pole position are fulfilled.</li><li>• Ensure that the machine is not braked or blocked during the pole position identification.</li><li>• Repeat the pole position identification.</li></ul>

#### Motor switched off [0x007b004c]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C00597</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
<a href="#">From software version V5.0</a> Interruption of several motor cable phases.	Check cabling between the controller and motor.

#### Encoder: Time-out error [0x007b004d]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>

#### EnDat encoder: Transmission error [0x007b004e]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
<ul style="list-style-type: none"><li>• Encoder signal interferences (EMC).</li><li>• Encoder cable interrupted.</li><li>• Encoder defective.</li><li>• Faulty parameter setting of the encoder.</li></ul> <b>Note:</b> This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated ( <a href="#">C00580</a> ).	<ul style="list-style-type: none"><li>• Check encoder cable, if required, use shorter encoder cable.</li><li>• Check encoder.</li><li>• Check parameter setting (<a href="#">C00420</a>, <a href="#">C00421</a>, <a href="#">C00422</a>).</li></ul>

## EnDat encoder: Command error [0x007b004f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
<ul style="list-style-type: none"> <li>Encoder signal interferences (EMC).</li> <li>Encoder cable interrupted.</li> <li>Encoder defective.</li> <li>Faulty parameter setting of the encoder.</li> </ul> <p><b>Note:</b> This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (<a href="#">C00580</a>).</p>	<ul style="list-style-type: none"> <li>Check encoder cable, if required, use shorter encoder cable.</li> <li>Check encoder.</li> <li>Check parameter setting (<a href="#">C00420</a>, <a href="#">C00421</a>, <a href="#">C00422</a>).</li> </ul>

## EnDat encoder: Position initialisation error [0x007b0050]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
<p>A digital readout of the absolute encoder is only possible at standstill.</p> <p>The readout is activated by the following actions:</p> <ul style="list-style-type: none"> <li>Mains switching</li> <li>Change of <a href="#">C00420</a>, <a href="#">C00422</a> and <a href="#">C00427</a></li> <li>To "<a href="#">Absolute value encoder: Communication error</a>"</li> <li>To "<a href="#">Encoder: Open circuit</a>"</li> </ul> <p><b>Note:</b> This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (<a href="#">C00580</a>).</p>	Prevent coasting of the machine while the absolute encoder is read out.

## Memory module: File system has been formatted [0x007c0000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
File system of the memory module has been formatted.	-(Information only)

## Memory module: File system has been restored [0x007c0001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
File system of the memory module has been restored.	-(Information only)

## Analog input 1: Master current <math>\leq 4\text{ mA}</math> [0x007d0000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00598</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
<p>Master current is in the impermissible range -4 ... +4 mA, e. g. due to a cable break or a defective master current value encoder.</p> <ul style="list-style-type: none"> <li>Only for parameterisation as master current input (see <a href="#">C00034</a>).</li> </ul>	Remove cable break.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### PLC configuration invalid [0x007d0001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid control configuration has occurred.	Load a different application.

#### Communication error between device and device module [0x007f0002]

<b>Response</b> (Lenze setting printed in bold)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> <b>Quick stop by trouble</b> <input checked="" type="checkbox"/> <b>Warning locked</b> <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C01501</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
Communication between the controller and extension module is interrupted, e.g. due to disturbances in the ambience (EMC), defective hardware, or loose contact. <ul style="list-style-type: none"><li>This monitoring is designed for safe process data communication.</li></ul>	<ul style="list-style-type: none"><li>Remove EMC fault.</li><li>Switch off the controller, plug in module correctly and switch on the controller again.</li><li>Switch the mains or restart controller.</li><li>Exchange module/controller.</li><li>Please contact Lenze if the problem occurs again.</li></ul>

#### Communication with module in MXI1 interrupted [0x007f0003]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Communication between the controller and the extension module in module slot MXI1 cannot be established.	<ul style="list-style-type: none"><li>Switch off controller, plug module correctly in module slot MXI1, switch on controller again.</li><li>If the problem occurs again, replace the module.</li></ul>

#### Communication with module in MXI2 interrupted [0x007f0004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Communication between the controller and the extension module in module slot MXI2 cannot be established.	<ul style="list-style-type: none"><li>Switch off controller, plug module correctly in module slot MXI2, switch on controller again.</li><li>If the problem occurs again, replace the module.</li></ul>

#### CAN on board: Bus off [0x00830000]

<b>Response</b> (Lenze setting printed in bold)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> <b>Quick stop by trouble</b> <input checked="" type="checkbox"/> <b>Warning locked</b> <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> <b>Information</b>	
<b>Setting:</b> <a href="#">C00595</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
CAN on board: "Bus-Off" state <ul style="list-style-type: none"><li>Too many faulty telegrams received.</li><li>Defective cable (e.g. loose contact).</li><li>Two nodes with the same ID.</li></ul>	<ul style="list-style-type: none"><li>Remove fault (e.g. EMC).</li><li>Remove loose contact, screw down adapter.</li><li>Assign different node IDs.</li></ul>

## CAN on board: Invalid node address 0 [0x00830001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: initialisation error <ul style="list-style-type: none"> <li>The hardware allocation of the node address was selected via DIP switches, and the DIP switches of the node address are all on zero.</li> </ul> <b>Note:</b> Instead of the impermissible node address 0, node address 1 is used.	<ul style="list-style-type: none"> <li>Set a non-zero node address by means of the DIP switches and then switch mains.</li> <li>Activation of the software allocation of the node number by switching over DIP switch 2, then switch mains.</li> </ul>

## CAN on board: Basic configuration invalid [0x00830002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: configuration error <ul style="list-style-type: none"> <li>Faulty download of an Engineer or PLC Designer project</li> <li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li> </ul>	<ul style="list-style-type: none"> <li>Repeat download</li> <li>Correct CAN settings in the project and regenerate project.</li> </ul>

## CAN on board: Heartbeat error index 1 ... 32 [0x00840000 ... 0x0084001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/1...32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"> <li>Node station has not received a heartbeat telegram from node 1 ... 32 within the defined time.</li> </ul>	<ul style="list-style-type: none"> <li>Reactivate CAN node by mains switching, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li> <li>Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary.</li> </ul> Tip: Save the current parameter set before mains switching and restart of the controller ( <a href="#">C00002</a> ="11").	

## CAN on board: Lifeguarding error [0x00840020]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00614</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"> <li>Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded.</li> </ul>	Select a different Lifeguarding monitoring time or switch off monitoring.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### CAN on board: Faulty NMT slave configuration [0x00840021]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN on board: Faulty emergency configuration [0x00850000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: CAN emergency configuration is faulty. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN on board: Node guarding error 1 ... 32 [0x00860000 ... 0x0086001f]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00612/1...32</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> <b>Quick stop by trouble</b> <input checked="" type="checkbox"/> <b>Warning locked</b> <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"><li>• CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 ... 32 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>• Reactivate CAN node by mains switching, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>• Select a different node guarding monitoring time or switch off monitoring.</li><li>• Reset potentially caught error status.</li></ul> <p>Tip: Save the current parameter set before mains switching and restart of the controller (<a href="#">C00002</a>="11").</p>

#### CAN on board: Faulty NMT master configuration [0x00860020]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project.</li><li>• Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

## CAN on board RPDO1: Telegram not received or faulty [0x00870000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00591/1</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CAN on board: CAN-IN 1 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN on board RPDO2: Telegram not received or faulty [0x00870001]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00591/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CAN on board: CAN-IN 2 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN on board RPDO3: Telegram not received or faulty [0x00870002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00591/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CAN on board: CAN-IN 3 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN on board RPDO4: Telegram not received or faulty [0x00870003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00591/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CAN on board: CAN-IN 4 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN on board PDO manager: Faulty configuration [0x00870008]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information		
Cause	Remedy	
CAN on board: CAN-PDO configuration error	<ul style="list-style-type: none"> <li>• Repeat download.</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>	
<ul style="list-style-type: none"> <li>• Faulty project download.</li> <li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li> <li>• Mapping variables have incorrect CANopen indices according to DS405.</li> </ul>		

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## CAN on board SDO server: Faulty configuration [0x00880000]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause

CAN on board: A configuration error has occurred in the CAN SDO server.

- Faulty project download.
- Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer.

Remedy

- Repeat download.
- Correct CAN settings in the project and regenerate project.

## CAN on board SDO client: Faulty configuration [0x00890000]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause

CAN on board: A configuration error has occurred in the CAN SDO client.

- Faulty project download.
- Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer.

Remedy

- Repeat download
- Correct CAN settings in the project and regenerate project.

## File ProjectSelection.dat defect [0x008c0000]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

Reformat memory module ([C00002](#)="1030") and repeat project download.

## File ProjectList.dat defect [0x008c0001]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

Reformat memory module ([C00002](#)="1030") and repeat project download.

## File DeviceCFG.dat defect [0x008c0002]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

Reformat memory module ([C00002](#)="1030") and repeat project download.

## File ProjectSelection.dat is missing [0x008c0003]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

Reformat memory module ([C00002](#)="1030") and repeat project download.



## File ProjectList.dat is missing [0x008c0004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

## File DeviceCFG.dat is missing [0x008c0005]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

## File ProjectSelection.dat invalid [0x008c0006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

## File ProjectList.dat invalid [0x008c0007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

## File DeviceCFG.dat invalid [0x008c0008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

## Project is not loaded [0x008c0009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Application could not be loaded because of a file error.	Load new or different application.

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Project is not available [0x008c000a]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Application not available.	<ul style="list-style-type: none"><li>• Download application with the Engineer</li><li>• Switch off controller and use a different memory module with an existing application.</li></ul>

## Required licence missing [0x008c000b]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Memory module could not be initialised.	Two possibilities: <ul style="list-style-type: none"><li>• Use the Engineer to download and activate an application suitable for the memory module.</li><li>• Switch off controller and use memory module suitable for the application.</li></ul>

## Application and device are incompatible [0x008c000c]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Application is incompatible with the controller.	<ul style="list-style-type: none"><li>• Download of an application suitable for the controller using the Engineer.</li><li>• Switch off controller and use a different memory module with suitable application.</li></ul>

## MX11: Module is missing or incompatible [0x008c000d]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Extension module in module slot MX11 is incompatible with the application.	Use extension module supported by the application.

## MX12: Module is missing or incompatible [0x008c000e]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Extension module in module slot MX12 is incompatible with the application.	Use extension module supported by the application.

## MX11: PROFIBUS module is missing or incompatible [0x008c000f]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
E94AYCPM communication module (PROFIBUS) in module slot MX11 is incompatible with the application.	Use communication module supported by the application.

## MXI2: PROFIBUS module is missing or incompatible [0x008c0010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
E94AYCPM communication module (PROFIBUS) in module slot MXI2 is incompatible with the application.	Use communication module supported by the application.	

## MXI1: Ethernet module is missing or incompatible [0x008c0011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
E94AYCEN communication module (Ethernet) in module slot MXI1 is incompatible with the application.	Use communication module supported by the application.	

## MXI2: Ethernet module is missing or incompatible [0x008c0012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
E94AYCEN communication module (Ethernet) in module slot MXI2 is incompatible with the application.	Use communication module supported by the application.	

## MXI1: Digital frequency module is missing or incompatible [0x008c0013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in module slot MXI1 is incompatible with the application.	Use extension module supported by the application.	

## MXI2: Digital frequency module is missing or incompatible [0x008c0014]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in module slot MXI2 is incompatible with the application.	Use extension module supported by the application.	

## MXI1: ICM module is missing or incompatible [0x008c0015]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
ICM extension module in module slot MXI1 is incompatible with the application.	Use extension module supported by the application.	

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## MXI2: ICM module is missing or incompatible [0x008c0016]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
ICM extension module in module slot MXI2 is incompatible with the application.	Use extension module supported by the application.	

## MXI1: CAN module is missing or incompatible [0x008c0017]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in module slot MXI1 is incompatible with the application.	Use communication module supported by the application.	

## MXI2: CAN module is missing or incompatible [0x008c0018]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in module slot MXI2 is incompatible with the application.	Use communication module supported by the application.	

## ConnectTable active [0x008c001a]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
The application is provided with a so-called connection table, i. e. connections can be altered "online" in the function block editor without having to carry out a new complete download.	- (Information only)	

## Parameter set faulty [0x00900000]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Parameter set is invalid.	Transfer parameter set from Engineer to the controller and save with <a href="#">C00002</a> ="11".	

## Lenze setting loaded [0x00900001]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
Lenze setting has been loaded.	- (Information only)	

## Parameter set saved [0x00900002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Parameter set has been saved.	- (Information only)

## Parameter set loaded [0x00900003]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Parameter set has been loaded.	- (Information only)

## Loading of Lenze setting failed [0x00900004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Lenze setting of a parameter is not within the valid limits.	Eliminate error in the application and retransfer application to controller.

## Parameter set restored [0x00900005]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An error has occurred while loading the selected parameter set.	Transfer parameter set from Engineer to the controller and save with <a href="#">C00002</a> ="11".

## Saving of parameters failed [0x00900006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An error has occurred while saving the current parameter set.	Use a different memory module.

## Parameter set: Version conflict [0x00900007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The parameter set version on the memory module is not compatible with the firmware of the controller.	Transfer parameter set from Engineer to the controller and save with <a href="#">C00002</a> ="11".

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Code number duplicated [0x00900008]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Code number of the operating system has been assigned to the application.	Eliminate error in the application and retransfer application to controller.

#### Parameter set: Type of standard device has been changed [0x00900009]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The firmware has loaded a parameter set the type code of which does not correspond to the type code of the controller.	Load a suitable parameter set.

#### No parameters for module in MXI1 [0x0090000a]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The parameter set contains no parameters for the module inserted in MXI1.	Integrate the module inserted in MXI1 into the Engineer project and then retransmit the parameter set to the controller.

#### No parameters for module in MXI2 [0x0090000b]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The parameter set contains no parameters for the module inserted in MXI2.	Integrate the module inserted in MXI2 into the Engineer project and then retransmit the parameter set to the controller.

#### Disconnection in the case of par. storage [0x0090000c]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>

#### Mains voltage is switched on [0x00910000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Mains voltage has been switched on.	- (Information only)

## Mains voltage is switched off [0x00910001]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Mains voltage has been switched off.

- (Information only)

## No heartbeat signal detected [0x00910002]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

## Heartbeat not periodic [0x00910003]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

## Internal error: See C00180 [0x00910004]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

## Internal error: See C00180 [0x00910005]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

Please contact Lenze.

## Internal error: See C00180 [0x00910006]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Divisor of division was "0".

Replace application.

## Internal error: See C00180 [0x00910008]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Internal error: See C00180 [0x00910009]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

## System task 1: Task overflow [0x0091000a]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

System overload.

Please contact Lenze.

## System task 2: Task overflow [0x0091000b]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

System overload.

Please contact Lenze.

## System task 3: Task overflow [0x0091000c]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

System overload.

Please contact Lenze.

## System task: Task overflow [0x0091000d]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

System overload.

Please contact Lenze.

## Communication task: Standstill &gt; 3 s [0x0091000e]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

System overload or communication task crash.

Reduce system load.  
• This is possible in the application or data transfer of the communication interfaces.



## Cyclic task: Standstill &gt; 60 s [0x0091000f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
System overload or CRC check task crash.	Reduce system load. <ul style="list-style-type: none"> <li>• This is possible in the application or data transfer of the communication interfaces.</li> </ul>

## Position value faulty [0x00910010]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	If the error occurs frequently, please contact Lenze.

## Error during initialisation [0x00910011]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	If the error occurs frequently, please contact Lenze.

## Block function in wrong MEC task [0x00910012]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	If the error occurs frequently, please contact Lenze.

## Safety module: Incompatible with setting in C00214 [0x00920000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The controller has detected a safety module which does not match the setting under <a href="#">C00214</a> .	Change setting under <a href="#">C00214</a> or use a suitable safety module. <ul style="list-style-type: none"> <li>• Afterwards mains switching is required.</li> </ul>

## Communication with safety module interrupted [0x00920001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
It is not possible to establish communication between the controller and safety module.	<ul style="list-style-type: none"> <li>• Switch off the controller, plug in safety module correctly and switch on the controller again.</li> <li>• If the problem occurs again, replace the safety module.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### DFIN (MXI1): Track error A-/A [0x00990000]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13040</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track A.	<ul style="list-style-type: none"><li>• Check signal cable for track A.</li><li>• Check encoder.</li></ul>

#### DFIN (MXI1): Track error B-/B [0x00990001]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13040</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track B.	<ul style="list-style-type: none"><li>• Check signal cable for track B.</li><li>• Check encoder.</li></ul>

#### DFIN (MXI1): Track error Z-/Z [0x00990002]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13040</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track Z.	<ul style="list-style-type: none"><li>• Check signal cable for track Z.</li><li>• Check encoder.</li></ul>

#### DFIN (MXI1): Signal error enable/lamp control [0x00990003]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13041</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for the "Enable" signal or no "Enable" signal available.	<ul style="list-style-type: none"><li>• Check signal cable for "Enable" signal.</li><li>• Check encoder.</li></ul>

#### DFIN (MXI1): Supply cannot be corrected anymore [0x00990004]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13042</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI1: The encoder voltage controlled by the digital frequency input has reached the voltage limit.	Check encoder.

#### DFOUT (MXI1): Maximum frequency reached [0x00990005]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13080</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI1: Limit frequency at the digital frequency output reached. <ul style="list-style-type: none"><li>• The digital frequency has reached the limit value set in <a href="#">C013053</a>.</li></ul>	Check limit value set.

## CAN module (MXI1): Bus off [0x009d0000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13595</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: "Bus-off" state <ul style="list-style-type: none"> <li>• Too many faulty telegrams received.</li> <li>• Defective cable (e.g. loose contact).</li> <li>• Two nodes with the same ID.</li> </ul>	<ul style="list-style-type: none"> <li>• Remove fault (e.g. EMC).</li> <li>• Remove loose contact, screw down adapter.</li> <li>• Assign different node IDs.</li> </ul>	

## CAN module (MXI1): Invalid node address 0 [0x009d0001]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: Initialisation error <ul style="list-style-type: none"> <li>• The hardware allocation of the node address was selected via DIP switches, and the DIP switches of the node address are all on zero.</li> </ul> <p><b>Note:</b> Instead of the impermissible node address 0, node address 1 is used.</p>	<ul style="list-style-type: none"> <li>• Set a non-zero node address by means of the DIP switches and then switch mains.</li> <li>• Activation of the software allocation of the node number by switching over DIP switch 2, then switch mains.</li> </ul>	

## CAN module (MXI1): Basic configuration invalid [0x009d0002]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: Configuration error <ul style="list-style-type: none"> <li>• Faulty download of an Engineer or PLC Designer project</li> <li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li> </ul>	<ul style="list-style-type: none"> <li>• Repeat download</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>	

## CAN module (MXI1): Heartbeat error index 1 ... 32 [0x009e0000 ... 0x009e001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/1...32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"> <li>• Node station has not received a heartbeat telegram from node 1 ... 32 within the defined time.</li> </ul>	<ul style="list-style-type: none"> <li>• Reactivate CAN node by mains switching, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li> <li>• Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary.</li> </ul> <p>Tip: Save the current parameter set before mains switching and restart of the controller (<a href="#">C00002</a>="11").</p>	

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## CAN module (MXI1): Lifeguarding error [0x009e0020]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13614</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"><li>Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded.</li></ul>	Select a different Lifeguarding monitoring time or switch off monitoring.

## CAN module (MXI1): Faulty NMT slave configuration [0x009e0021]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

## CAN module (MXI1): Faulty emergency configuration [0x009f0000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN emergency configuration is faulty. <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

## CAN module (MXI1): Node guarding error 1 ... 32 [0x00a00000 ... 0x00a0001f]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/1...32</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"><li>CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 ... 32 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>Reactivate CAN node by mains switching, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>Select a different node guarding monitoring time or switch off monitoring.</li><li>Reset potentially caught error status.</li></ul> <p>Tip: Save the current parameter set before mains switching and restart of the controller (<a href="#">C00002</a>="11").</p>

## CAN module (MXI1): Faulty NMT master configuration [0x00a00020]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"> <li>• Faulty download of an Engineer or PLC Designer project.</li> <li>• Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer.</li> <li>• Incorrect parameterisation of node guarding or heartbeat.</li> </ul>	<ul style="list-style-type: none"> <li>• Repeat download</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>

## CAN module (MXI1) RPDO1: Telegram not received or faulty [0x00a10000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/1</a> <input checked="" type="checkbox"/> Adjustable response
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN-IN 1 error <ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	

## CAN module (MXI1) RPDO2: Telegram not received or faulty [0x00a10001]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/2</a> <input checked="" type="checkbox"/> Adjustable response
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN-IN 2 error <ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	

## CAN module (MXI1) RPDO3: Telegram not received or faulty [0x00a10002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/3</a> <input checked="" type="checkbox"/> Adjustable response
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN-IN 3 error <ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### CAN module (MXI1) RPDO4: Telegram not received or faulty [0x00a10003]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13591/4</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 4 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI1) RPDO5: Telegram not received or faulty [0x00a10004]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13591/5</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 5 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI1) RPDO6: Telegram not received or faulty [0x00a10005]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13591/6</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 6 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI1) RPDO7: Telegram not received or faulty [0x00a10006]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13591/7</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 7 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI1) RPDO8: Telegram not received or faulty [0x00a10007]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13591/8</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 8 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

## CAN module (MXI1) PDO manager: Faulty configuration [0x00a10008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-PDO configuration error <ul style="list-style-type: none"> <li>• Faulty project download.</li> <li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li> <li>• Mapping variables have incorrect CANopen indices according to DS405.</li> </ul>	<ul style="list-style-type: none"> <li>• Repeat download.</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>

## CAN module (MXI1) SDO server: Faulty configuration [0x00a20000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: In the CAN SDO server a configuration error has occurred. <ul style="list-style-type: none"> <li>• Faulty project download.</li> <li>• Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer.</li> </ul>	<ul style="list-style-type: none"> <li>• Repeat download.</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>

## CAN module (MXI1) SDO client: Faulty configuration [0x00a30000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: In the CAN SDO client a configuration error has occurred. <ul style="list-style-type: none"> <li>• Faulty project download.</li> <li>• Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer.</li> </ul>	<ul style="list-style-type: none"> <li>• Repeat download</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>

## DFIN (MXI2): Track error A-/A [0x00aa0000]

<b>Response</b> (Lenze setting printed in bold)	<b>Setting:</b> <a href="#">C14040</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track A.	<ul style="list-style-type: none"> <li>• Check signal cable for track A.</li> <li>• Check encoder.</li> </ul>

## DFIN (MXI2): Track error B-/B [0x00aa0001]

<b>Response</b> (Lenze setting printed in bold)	<b>Setting:</b> <a href="#">C14040</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track B.	<ul style="list-style-type: none"> <li>• Check signal cable for track B.</li> <li>• Check encoder.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### DFIN (MXI2): Track error Z-/Z [0x00aa0002]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C14040</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track Z.	<ul style="list-style-type: none"><li>• Check signal cable for track Z.</li><li>• Check encoder.</li></ul>

#### DFIN (MXI2): Signal error enable/lamp control [0x00aa0003]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C14041</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for the "Enable" signal or no "Enable" signal available.	<ul style="list-style-type: none"><li>• Check signal cable for "Enable" signal.</li><li>• Check encoder.</li></ul>

#### DFIN (MXI2): Supply cannot be corrected anymore [0x00aa0004]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C14042</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI2: The encoder voltage controlled by the digital frequency input has reached the voltage limit.	Check encoder.

#### DFOUT (MXI2): Maximum frequency reached [0x00aa0005]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C14080</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Digital frequency extension module in MXI2: Limit frequency at the digital frequency output reached. <ul style="list-style-type: none"><li>• The digital frequency has reached the limit value set in <a href="#">C014053</a>.</li></ul>	Check limit value set.

#### CAN module (MXI2): Bus off [0x00ac0000]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C14595</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: "Bus-off" state <ul style="list-style-type: none"><li>• Too many faulty telegrams received.</li><li>• Defective cable (e.g. loose contact).</li><li>• Two nodes with the same ID.</li></ul>	<ul style="list-style-type: none"><li>• Remove fault (e.g. EMC).</li><li>• Remove loose contact, screw down adapter.</li><li>• Assign different node IDs.</li></ul>



## CAN module (MXI2): Invalid node address 0 [0x00ac0001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Initialisation error <ul style="list-style-type: none"> <li>The hardware allocation of the node address was selected via DIP switches, and the DIP switches of the node address are all on zero.</li> </ul> <p><b>Note:</b> Instead of the impermissible node address 0, node address 1 is used.</p>	<ul style="list-style-type: none"> <li>Set a non-zero node address by means of the DIP switches and then switch mains.</li> <li>Activation of the software allocation of the node number by switching over DIP switch 2, then switch mains.</li> </ul>

## CAN module (MXI2): Basic configuration invalid [0x00ac0002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Configuration error <ul style="list-style-type: none"> <li>Faulty download of an Engineer or PLC Designer project</li> <li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li> </ul>	<ul style="list-style-type: none"> <li>Repeat download</li> <li>Correct CAN settings in the project and regenerate project.</li> </ul>

## CAN module (MXI2): Heartbeat error index 1 ... 32 [0x00ad0000 ... 0x00ad001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/1...32</a> ( <input checked="" type="checkbox"/> Adjustable response )
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"> <li>Node station has not received a heartbeat telegram from node 1 ... 32 within the defined time.</li> </ul>	<ul style="list-style-type: none"> <li>Reactivate CAN node by mains switching, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li> <li>Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary.</li> </ul> <p>Tip: Save the current parameter set before mains switching and restart of the controller (<a href="#">C00002</a>="11").</p>	

## CAN module (MXI2): Lifeguarding error [0x00ad0020]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14614</a> ( <input checked="" type="checkbox"/> Adjustable response )
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"> <li>Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded.</li> </ul>	Select a different Lifeguarding monitoring time or switch off monitoring.	

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## CAN module (MXI2): Faulty NMT slave configuration [0x00ad0021]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

## CAN module (MXI2): Faulty emergency configuration [0x00ae0000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN emergency configuration is faulty. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

## CAN module (MXI2): Node guarding error 1 ... 32 [0x00af0000 ... 0x00a0001f]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C14612/1...32</a> <input checked="" type="checkbox"/> Adjustable response	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"><li>• CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 ... 32 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>• Reactivate CAN node by mains switching, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>• Select a different node guarding monitoring time or switch off monitoring.</li><li>• Reset potentially caught error status.</li></ul> <p>Tip: Save the current parameter set before mains switching and restart of the controller (<a href="#">C00002</a>="11").</p>

## CAN module (MXI2): Faulty NMT master configuration [0x00af0020]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project.</li><li>• Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

## CAN module (MXI2) RPDO1: Telegram not received or faulty [0x00b00000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/1</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 1 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN module (MXI2) RPDO2: Telegram not received or faulty [0x00b00001]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/2</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 2 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN module (MXI2) RPDO3: Telegram not received or faulty [0x00b00002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/3</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 3 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN module (MXI2) RPDO4: Telegram not received or faulty [0x00b00003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/4</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 4 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

## CAN module (MXI2) RPDO5: Telegram not received or faulty [0x00b00004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/5</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 5 error	<ul style="list-style-type: none"> <li>• Set correct telegram length for CAN master (transmitter).</li> <li>• Eliminate trouble in the environment (e. g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• Time monitoring of the PDOs has tripped.</li> </ul>		

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### CAN module (MXI2) RPDO6: Telegram not received or faulty [0x00b00005]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14591/6</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 6 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI2) RPDO7: Telegram not received or faulty [0x00b00006]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14591/7</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 7 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI2) RPDO8: Telegram not received or faulty [0x00b00007]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14591/8</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 8 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• Time monitoring of the PDOs has tripped.</li></ul>	<ul style="list-style-type: none"><li>• Set correct telegram length for CAN master (transmitter).</li><li>• Eliminate trouble in the environment (e. g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI2) PDO manager: Faulty configuration [0x00b00008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-PDO configuration error <ul style="list-style-type: none"><li>• Faulty project download.</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Mapping variables have incorrect CANopen indices according to DS405.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download.</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

## CAN module (MXI2) SDO server: Faulty configuration [0x00b10000]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

CANopen communication module in MXI2: In the CAN SDO server a configuration error has occurred.

- Faulty project download.
- Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer.

**Remedy**

- Repeat download.
- Correct CAN settings in the project and regenerate project.

## CAN module (MXI2) SDO client: Faulty configuration [0x00b20000]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

CANopen communication module in MXI2: In the CAN SDO client a configuration error has occurred.

- Faulty project download.
- Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer.

**Remedy**

- Repeat download
- Correct CAN settings in the project and regenerate project.

## PLC configuration invalid [0x00b80000]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

An invalid control configuration has occurred.

**Remedy**

Load a different application.

## Positive limit switch has triggered [0x00b80001]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  **Quick stop by trouble**  Warning locked  Warning  Information

**Cause**

The [travel range limit switch](#) in positive traversing direction has tripped.

**Remedy**

Reset error message and [retract limit switch](#).

## Negative limit switch has triggered [0x00b80002]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  **Quick stop by trouble**  Warning locked  Warning  Information

**Cause**

The [travel range limit switch](#) in negative traversing direction has tripped.

**Remedy**

Reset error message and [retract limit switch](#).

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Motor brake: Angular drift with closed brake too high [0x00b80003]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  **Quick stop by trouble**  Warning locked  Warning  Information

Cause

The stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#), although the brake is engaged.

Remedy

- Deactivate standstill monitoring ([C02595](#) = 0).
- Increase waiting time for status monitoring ([C02591](#)). The standstill monitoring only starts after this waiting time has elapsed.
- Increase brake closing time ([C02589](#)) since during the brake closing time the standstill monitoring is not active.
- Reduce threshold for brake activation ([C02581](#)).

#### Motor brake: Automatically activated after waiting time has elapsed [0x00b80004]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

This time monitoring will only be active if the speed setpoint has reached the threshold for brake activation ([C02581](#)).  
If the actual speed value does not reach/fall below the threshold set in [C02581](#) within the parameterised waiting time for brake activation ([C02593](#)), the brake will be closed due to time-out.

Remedy

- Increase waiting time for brake activation ([C02593](#)).
- Reduce threshold for brake activation ([C02581](#)).

#### Motor brake: Status monitoring error [0x00b80005]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  **Quick stop by trouble**  Warning locked  Warning  Information

Cause

Faulty external feedback of the brake status to the brake control.

Remedy

- Check brake configuration with regard to the control selection in [C02580](#).
- Check setting for status input monitoring in [C02583](#). When monitoring is active, the input *bBrakeApplied* must be triggered correctly (*bBrakeApplied* = *bBrakeReleased*).
- Check voltage supply of the brake module.

#### Positive software limit switch overtravelled [0x00b80007]

Response (Lenze setting printed in bold)

Setting: [C02716/2](#) ( Adjustable response)

None  System fault  Fault  Trouble  **Quick stop by trouble**  Warning locked  Warning  Information

Cause

The positive software limit position parameterised in [C02702/2](#) has been overtravelled.

Remedy

- Position within the software limit positions.
- Increase permissible traversing range (change setting of the software limit positions).
- Deactivate monitoring of the software limit positions by the basic function "Limiter".

## Negative software limit switch overtravelled [0x00b80008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The negative software limit position parameterised in <a href="#">C02702/1</a> has been overtravelled.	<ul style="list-style-type: none"> <li>Position within the software limit positions.</li> <li>Increase permissible traversing range (change setting of the software limit positions).</li> <li>Deactivate monitoring of the software limit positions by the basic function "Limiter".</li> </ul>	

## Positive direction of rotation limited [0x00b80009]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/1</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Due to the setting of <a href="#">C02707</a> it was tried to traverse in the impermissible positive direction of rotation.	<ul style="list-style-type: none"> <li>Only traverse in permissible (negative) direction of rotation.</li> <li>Change setting of the permissible direction of rotation (<a href="#">C02707</a>).</li> </ul>	

## Negative direction of rotation limited [0x00b8000a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/1</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Due to the setting of <a href="#">C02707</a> it was tried to traverse in the impermissible negative direction of rotation.	<ul style="list-style-type: none"> <li>Only traverse in permissible (positive) direction of rotation.</li> <li>Change setting of the permissible direction of rotation (<a href="#">C02707</a>).</li> </ul>	

## Speed has been limited [0x00b8000b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
<ul style="list-style-type: none"> <li>The requested profile speed is higher than the maximum speed set in <a href="#">C02703</a> and has been limited to this speed.</li> <li>The required profile speed cannot be achieved with the motor reference speed set in <a href="#">C00011</a>.</li> </ul>	<ul style="list-style-type: none"> <li>Reduce speed of the traversing profile of the basic function (manual jog, homing, or positioning).</li> <li>Increase maximum speed (<a href="#">C02703</a>).</li> <li>Deactivate monitoring of the limit values by the basic function "Limiter".</li> <li>Set motor reference speed correctly (<a href="#">C00011</a>).</li> </ul>	

## Acceleration has been limited [0x00b8000c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested profile acceleration is higher than the maximum acceleration set in <a href="#">C02705</a> and has been limited to this acceleration.	<ul style="list-style-type: none"> <li>Reduce acceleration of the traversing profile of the basic function (manual jog, homing, or positioning).</li> <li>Increase maximum acceleration (<a href="#">C02705</a>).</li> <li>Deactivate monitoring of the limit values by the basic function "Limiter".</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Deceleration has been limited [0x00b8000d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested profile deceleration is higher than the maximum acceleration set in <a href="#">C02705</a> and has been limited to this acceleration.	<ul style="list-style-type: none"><li>• Reduce acceleration of the traversing profile of the basic function (manual jog, homing, or positioning).</li><li>• Increase maximum acceleration (<a href="#">C02705</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	

#### Jerk has been limited [0x00b8000e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested S-ramp time is lower than the minimum S-ramp time set in <a href="#">C02706</a> and has been limited to this S-ramp time.	<ul style="list-style-type: none"><li>• Increase S-ramp time of the traversing profile of the basic function (manual jog, homing, or positioning).</li><li>• Reduce minimum S-ramp time (<a href="#">C02706</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	

#### Position target outside the software limit positions [0x00b8000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
It was tried to position to a target outside the software limit positions.	<ul style="list-style-type: none"><li>• Select position target inside the software limit positions.</li><li>• Increase permissible traversing range (change setting of the software limit positions).</li><li>• Deactivate monitoring of the software limit positions by the basic function "Limiter".</li></ul>	

#### Maximum speed exceeded [0x00b80010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The max. speed parameterised in <a href="#">C02703</a> has been exceeded.	<ul style="list-style-type: none"><li>• Reduce speed.</li><li>• Increase maximum speed (<a href="#">C02703</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	

#### Maximum acceleration exceeded [0x00b80011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The max. acceleration parameterised in <a href="#">C02705</a> has been exceeded.	<ul style="list-style-type: none"><li>• Reduce acceleration.</li><li>• Increase maximum acceleration (<a href="#">C02705</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	



## Time-out torque feedforward control - brake [0x00b80012]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  **Quick stop by trouble**  Warning locked  Warning  Information

**Cause**

After 1 second the actual torque has not yet reached 90 % of the precontrolled setpoint torque for releasing the brake.

**Remedy**

Check settings for torque feedforward control.

- Possibly the maximum current ([C00022](#)) is not sufficient for the required torque feedforward control.

## Cam data: Serial number MM does not match [0x00b80013]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

The cam data are provided with an access protection of level 3 (linkage to the memory module), and the serial number contained in the cam data does not correspond to the serial number of the memory module.

**Remedy**

Check and, if required, correct the serial number entered in the »Cam Designer«. Afterwards redownload the cam data.

## Cam data are corrupted [0x00b80014]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

Checksum error during reading the file, or the password was manipulated.

**Remedy**

Redownload cam data.

## Cam data restored [0x00b80015]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The last download of the cam data was faulty or has not been completed successfully.  
The previous cam data – if available – have been downloaded from the backup file.

**Remedy**

- Redownload cam data.
- Save cam data within the controller in the memory module via device command [C00002](#) = "0: Load Lenze setting". Then download cam data again.

## Cam data locked due to incorrect password [0x00b80016]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

The cam data were locked since the user password was entered incorrectly for three times.  
The cam data were not loaded.

**Remedy**

Reset parameters to the Lenze setting via device command [C00002](#) = "0: Load Lenze setting". Then download cam data again.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Cam data locked due to incorrect safety key [0x00b80017]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause

The cam data were not loaded because the safety key is damaged.  
The password in the cam data or the serial number of the memory module has been manipulated.

Remedy

Reset parameters to the Lenze setting via device command [C00002](#) = "0: Load Lenze setting". Then download cam data again.

#### Homing mode not allowed [0x00b80019]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

**From software version V3.0**  
The homing mode selected in [C02640](#) is not supported in the motor control type selected in [C00006](#).

Remedy

Select another homing mode in [C02640](#).

#### Int. overflow C02620 (manual jog: Speed 1) [0x00b8001a]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

**From software version V3.0**  
Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02620](#).

#### Int. overflow C02621 (manual jog: Speed 2) [0x00b8001b]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

**From software version V3.0**  
Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02621](#).

## Int. overflow C02622 (manual jog: Acceleration) [0x00b8001c]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02622](#).

## Int. overflow C02623 (manual jog: Deceleration) [0x00b8001d]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02623](#).

## Int. overflow C02701/1 (positive software limit position) [0x00b80020]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02701/1](#).

## Int. overflow C02701/2 (negative software limit position) [0x00b80021]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02701/2](#).

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Int. overflow C02703 (maximum speed) [0x00b80022]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02703](#).

## Int. overflow C02705 (maximum acceleration) [0x00b80023]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02705](#).

## Int. overflow C02708/1 (limited speed 1) [0x00b80024]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02708/1](#).

## Int. overflow C02708/2 (limited speed 2) [0x00b80025]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02708/2](#).

## Int. overflow C02708/3 (limited speed 3) [0x00b80026]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02708/3](#).

## Int. overflow C02708/4 (limited speed 4) [0x00b80027]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02708/4](#).

## Int. overflow C02708/1 (decel. limited speed 1) [0x00b80028]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02710/1](#).

## Int. overflow C02708/2 (decel. limited speed 2) [0x00b80029]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02710/2](#).

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & fault analysis

### Error messages of the operating system

#### Int. overflow C02708/3 (decel.limited speed 3) [0x00b8002a]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02710/3](#).

#### Int. overflow C02708/4 (decel. limited speed 4) [0x00b8002b]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02710/4](#).

#### Int. overflow C02713 (max. dist. manual control) [0x00b8002c]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02713](#).

#### Int. overflow C02642 (home position) [0x00b8002d]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02642](#).

## Int. overflow C02643 (homing: Target position) [0x00b8002e]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02643](#).

## Int. overflow C02644 (homing: Speed 1) [0x00b8002f]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02644](#).

## Int. overflow C02645 (homing: Acceleration 1) [0x00b80030]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02645](#).

## Int. overflow C02646 (homing: Speed 2) [0x00b80031]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

[From software version V3.0](#)

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

**Remedy**

- Check machine parameters and adapt them if required.
- Change setting in [C02646](#).

# 9400 HighLine | Parameter setting & configuration

Diagnostics & fault analysis

Error messages of the operating system

## Int. overflow C02647 (homing: Acceleration 2) [0x00b80032]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

From software version V3.0

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02647](#).

## Int. overflow C02670 (positioner: Tol. for target position) [0x00b80033]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

From software version V3.0

Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "[Max. position, speed, and acceleration that can be displayed internally](#)".

Remedy

- Check machine parameters and adapt them if required.
- Change setting in [C02670](#).

## Cam data: Invalidated due to change of mechanical data [0x00b80034]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

Cause

From software version V4.0

One or several machine parameters have been changed that have an influence on the internal scaling of the Cam data. The Cam data has to be recalculated. See chapter "[Invalid Cam data due to changed machine parameters](#)".

Remedy

Execute device command [C00002](#) = "503: Calculate Cam Data". This automatically resets the warning.

## Cam data: invalid product number [0x00b80035]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

From software version V5.0

A product number has been created in the system block [LS\\_CamInterface](#) which is not in the range of product number of the downloaded cam data.

Remedy

Check number of products.

- The product number must be higher than 0 and lower than the value displayed in [C02908](#).
- [C02908](#) displays the highest product number +1 of the cam data currently being processed.



## 14 Parameter reference

All parameters for controller parameter setting or monitoring are stored under "codes".

- ▶ The codes are numbered and designated by a "C" in front of the code, e.g. "C00002".
- ▶ For the sake of clarity, some codes contain "subcodes" for saving parameters. This Manual uses a slash "/" as a separator between code and subcode, e.g. C00118/3".

---

Parameters available in the controller only from a certain software version are marked accordingly ("From software version Vx.x").

The parameter descriptions are based on the software version V07.00.12

---



### Tip!

For quick reference of a parameter with a certain name simply use the **index** of the online documentation. The index always contains the corresponding code in parentheses behind the name.

For general information on how to read and change parameters please see the online documentation for the »Engineer«.

## 14.1 Structure of the parameter descriptions

Each parameter is described in the [Parameter list](#) in the form of a table which consists of the following three areas:

### Table header

The table header contains the following general notes:

- ▶ Parameter number (Cxxxxx)
- ▶ Parameter name (display text in the »Engineer« and keypad)
- ▶ [Data type](#)
- ▶ Decimal and hexadecimal parameter index for access via bus systems

### Table contents

The table contains further general explanations & notes on the parameter and the possible settings the representation of which depends on the parameter type:

- ▶ [Parameters with read-only access](#)
- ▶ [Parameters with write access](#)

### Table footer

The table footer contains the [Parameter attributes](#).

### 14.1.1 Data type

The following data types are available for parameters:

Data type	Meaning
INTEGER_8	8-bit value with sign
INTEGER_16	16-bit value with sign
INTEGER_32	32-bit value with sign
INTEGER_64	64-bit value with sign
UNSIGNED_8	8-bit value without sign
UNSIGNED_16	16-bit value without sign
UNSIGNED_32	32-bit value without sign
UNSIGNED_64	64-bit value without sign
FLOATING_POINT	32-bit floating point number
VISIBLE_STRING	String of characters of printable characters
OCTET_STRING	String of characters of any characters
BITFIELD_8	8-bit value bit-coded
BITFIELD_16	16-bit value bit-coded
BITFIELD_32	32-bit value bit-coded

## 14.1.2 Parameters with read-only access

Parameters for which the "write access" attribute has not been set can only be read and not be changed by the user.

### Description structure

Parameter Name: <b>Cxxxxx</b>   _____	Data type: _____ Index: _____
Description	
<b>Display range (min. value   unit   max. value)</b>	
_____	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	

### Representation in the »Engineer«

The »Engineer« displays these parameters with a grey background or, with an online connection, with a pale-yellow background:

	C...	S	Name	Wert	Einheit
	61	0	Kühlkörpertemperatur	30	°C

## 14.1.3 Parameters with write access

Only parameters with a check mark () in front of the "write access" attribute can be changed by the user. The Lenze setting for these parameters is **printed in bold**.

- ▶ The settings are either selected by means of a selection list or through direct value entry.
- ▶ Values outside the valid setting range are represented in red in the »Engineer«.

## 14.1.3.1 Parameters with setting range

### Description structure

Parameter   Name: Cxxxxx   _____		Data type: _____ Index: _____
Description		
<b>Setting range</b> (min. value   unit   max. value)	<b>Lenze setting</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		

### Parameter setting in the »Engineer«

In the »Engineer«, parameters are set by entering the desired value into the input field:

C...	S	Name	Wert	Einheit
22	0	Maximalstrom	0,00	A

## 14.1.3.2 Parameters with selection list

### Description structure

Parameter   Name: Cxxxxx   _____		Data type: _____ Index: _____
Description		
<b>Selection list</b> (Lenze setting printed in bold)		
<b>1</b>		
2		
3		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		

### Parameter setting in the »Engineer«

In the »Engineer«, a list field is used for parameter setting:

C...	S	Name	Wert	Einheit
34	0	Konfig. Analogeingang 1	0: -10...+10 V	

0: -10...+10 V

1: -20...-4 mA, +4...+20 mA

2: -20...+20 mA

## 14.1.3.3 Parameters with a bit coded setting

### Description structure

Parameter   Name: <b>Cxxxxx</b>   _____	Data type: _____ Index: _____
Description	
<b>Value is bit-coded:</b>	
Bit 0	
...	
Bit 31	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	

### Parameter setting in the »Engineer«

The »Engineer« uses a dialog box for parameter setting in which the individual bits can be set or reset. Alternatively, the value can be entered as a decimal or hexadecimal value:



## 14.1.3.4 Parameters with subcodes

### Description structure

Parameter   Name: <b>Cxxxxx</b>   _____		Data type: _____ Index: _____
Description		
Setting range (min. value   unit   max. value)		
<b>Subcodes</b>	<b>Lenze setting</b>	
Cxxxxx/1		
Cxxxxx/2		
Cxxxxx/3		
Cxxxxx/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		

### Parameter setting in the »Engineer«

The »Engineer« parameter list itemises all subcodes separately. The parameters are set as described in the previous chapters.

	C...	S	Name	Wert	Einheit
	114	1	Digitaleing. 1: Klemmenpol.	0	
	114	2	Digitaleing. 2: Klemmenpol.	0	
	114	3	Digitaleing. 3: Klemmenpol.	0	
	114	4	Digitaleing. 4: Klemmenpol.	0	

## 14.1.4 Parameter attributes

### Description structure

The table footer contains the parameter attributes:

Read access    Write access    CINH    PLC STOP    No transfer

### Meaning of the attributes

Attribute	Meaning
<input checked="" type="checkbox"/> Read access	Read access to parameter possible.
<input checked="" type="checkbox"/> Write access	Write access to parameter possible. • Please also observe the following attributes:
<input checked="" type="checkbox"/> CINH	Parameter value can only be changed when the controller is inhibited.
<input checked="" type="checkbox"/> PLC STOP	Parameter value can only be changed when the application is stopped.
<input checked="" type="checkbox"/> No transfer	The parameter is <b>not</b> transferred to the regenerative power supply module when the command <u>Download parameter set</u> is executed.

### Scaling factor

The "scaling factor" is important for the parameter access via a bus system:

$$\text{Read value (via bus system)} = \text{Scaling factor} \cdot \text{Indicated value (Engineer)}$$

## 14.1.5 Abbreviations used in parameter & selection texts

Since the character length of the parameter and selection texts is limited, the following abbreviations are used:

Abbreviation	Meaning
CAN module	CANopen communication module (type E94AYCCA)
ENP	Electronic nameplate
Ethernet module	Ethernet communication module (type E94AYCEN)
MXI1	<i>Module eXtension Interface 1</i> - module slot for extension 1
MXI2	<i>Module eXtension Interface 2</i> - module slot for extension 2

## 14.2 Parameter list

This chapter describes all parameters of the operating system in numerically ascending order.



### Note!

The parameter descriptions are based on the software version V05.

### C00002

Parameter | Name: **C00002 | Device commands** Data type: UNSIGNED\_32  
Index: 24573<sub>d</sub> = 5FFD<sub>h</sub>

Device commands

- [C00003](#) shows the status of the last executed device command.
- Under [C00150](#) you can query the current status of the device control.

#### Note:

Before switching off the supply voltage after a device command has been executed, check the successful execution of the device command via the status display in [C00003](#)!

The meaning of the status display in [C00003](#) can be obtained from the subchapter for the corresponding device command in chapter "[Device commands](#)".

Selection list (Lenze setting printed in bold)		Information
0	<b>Load Lenze setting</b>	Resets parameters to Lenze setting. <ul style="list-style-type: none"> <li>• Only possible when the application has stopped and the controller is inhibited.</li> </ul>
1	Load start parameters	Loads parameters from the memory module. <ul style="list-style-type: none"> <li>• Only possible when the application has stopped and the controller is inhibited.</li> </ul>
2	ENP: Load plant data	Reads plant data from the electronic motor nameplate. <ul style="list-style-type: none"> <li>• Only possible when the application has stopped and the controller is inhibited.</li> </ul>
5	Activate application	Activates the application selected under <a href="#">C00005</a> . <ul style="list-style-type: none"> <li>• Whether the application is also started, depends on the auto-start setting selected.</li> <li>• Only possible when the application has stopped.</li> </ul>
7	Save selected application	Selects the active application as start application.
11	Save start parameters	Saves parameters fail-safe in the memory module.
20	Delete logbook	Deletes all logbook entries.
21	Archive log file	Exports logbook entries to file.
31	Start application	
32	Stop application	
33	Reset program	Carries out a reset. <ul style="list-style-type: none"> <li>• All variables are reset to their initialisation value.</li> <li>• The situation corresponds to the start of a new program loaded into the control (cold start).</li> </ul>
34	Delete program	Carries out a reset (source). <ul style="list-style-type: none"> <li>• All variables are reset to their initialisation value.</li> <li>• The application program is deleted and the controller is reset to its original state.</li> </ul>



Parameter   Name: <b>C00002   Device commands</b>		Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
35	Restart program	Carries out a reset (warm start). <ul style="list-style-type: none"> <li>All variables except the RETAIN variables are reset to their initialisation value.</li> <li>The situation corresponds to a power failure or switching the controller off/on (warm start) while the program is running.</li> </ul>
36	Reset runtime measurement	▶ <a href="#">Runtime measurement</a>
41	Inhibit controller	
42	Enable controller	
43	Reset error	
45	Activate quick stop	▶ Basic function " <a href="#">Quick stop</a> "
46	Reset quick stop	▶ Basic function " <a href="#">Quick stop</a> "
47	Internal command 47	For Lenze service only
48	Internal command 48	For Lenze service only
51	Identify pole position (360°)	Executes identification of pole position. <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the execution of the command starts automatically when the controller is enabled.</li> <li>During the pole position identification, the motor makes one electrical revolution. This leads to a mechanical rotation of the motor shaft.</li> <li>The determined pole position is indicated under code <a href="#">C00058</a>.</li> </ul> ▶ <a href="#">Pole position identification</a>
52	Identify pole position (min. motion)	Executes identification of pole position. <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the execution of the command starts automatically when the controller is enabled.</li> <li>During the pole position identification, the rotor aligns itself. This is compensated by a position control.</li> <li>The determined pole position is indicated under code <a href="#">C00058</a>.</li> </ul> ▶ <a href="#">Pole position identification</a>
59	Resolver error identification	<b>From software version V7.0</b> Execute resolver error identification. ▶ <a href="#">Resolver error compensation</a>
70	Load Lenze inverter charac.	<b>From software version V4.0</b> Load type-dependent inverter error characteristic. <ul style="list-style-type: none"> <li>For the case that the determination of the inverter error characteristic with the device command "71: Determine inverter characteristic" was not possible or has supplied incorrect results.</li> <li>The function can only be activated when the controller is inhibited.</li> </ul>
71	Calculate inv. characteristic	Determines inverter error characteristic. <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the execution of the command starts automatically when the controller is enabled.</li> </ul> ▶ <a href="#">Optimise the switching performance of the inverter</a>

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list

Parameter Name: <b>C00002   Device commands</b>		Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
72	Set motor parameters	Determines motor parameters automatically. <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the execution of the command starts automatically when the controller is enabled.</li> </ul> ▶ <a href="#">Determine the motor parameters</a>
77	Calculate current controller parameters	<b>From software version V5.0</b> Calculates the gain and reset time of the current controller. <ul style="list-style-type: none"> <li>Usually not required for a Lenze motor.</li> <li>The device command is no identification procedure for determining the current controller parameters!</li> </ul> ▶ <a href="#">Calculate current controller parameters</a>
78	Calculate speed controller parameters	<b>From software version V5.0</b> Calculates the gain, reset, and rate time of the speed controller. <ul style="list-style-type: none"> <li>The device command is no identification procedure for determining the speed controller parameters!</li> </ul> ▶ <a href="#">Calculate speed controller parameters</a>
91	CAN on-board: Reset node	Reinitialises the "CAN on-board" interface. <ul style="list-style-type: none"> <li>Required when the baud rate, node address or identifiers are changed.</li> </ul> ▶ <a href="#">"CAN on board" system bus</a>
92	CAN module: Reset node	Reinitialises CANopen interface of the CANopen communication module. <ul style="list-style-type: none"> <li>Required when the baud rate, node address or identifiers are changed.</li> </ul>
93	CAN on-board: Pred.Connect.Set	Sets basic identifier for the "CAN on board" interface according to the "Predefined Connection Set" (DS301 V4.02). <ul style="list-style-type: none"> <li>▶ <a href="#">"CAN on board" system bus</a></li> </ul>
94	CAN module: Pred.Connect.Set	Sets basic identifier for the CANopen interface of the CANopen communication module according to the "Predefined Connection Set" (DS301 V4.02).
95	CAN on-board: Identify node	Detects nodes connected to the "CAN on board" interface. <ul style="list-style-type: none"> <li>The result of the CAN bus scan is displayed in <a href="#">C00393</a>.</li> </ul> ▶ <a href="#">"CAN on board" system bus</a>
96	CAN module: Identify node	Detects the nodes connected to the CANopen interface of the CANopen communication module. <ul style="list-style-type: none"> <li>The result of the CAN bus scan is displayed in C13393 (for MX1) or C14393 (for MX2).</li> </ul>
101	Unbind/bind Ethernet module MX1	Reinitialises the Ethernet interface of the Ethernet communication module in module slot MX1. <ul style="list-style-type: none"> <li>Required when a new setting for an IP or gateway address is to be accepted without mains switching.</li> </ul>
102	Unbind/bind Ethernet module MX2	Reinitialises the Ethernet interface of the Ethernet communication module in module slot MX2. <ul style="list-style-type: none"> <li>Required when a new setting for an IP or gateway address is to be accepted without mains switching.</li> </ul>
201	Activate parameter set 1	Loads parameter set 1 from the memory module. <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> </ul>
202	Activate parameter set 2	Loads parameter set 2 from the memory module. <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> </ul>

Parameter	Name:	Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
<b>C00002   Device commands</b>		
203	Activate parameter set 3	Loads parameter set 3 from the memory module. <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> </ul>
204	Activate parameter set 4	Loads parameter set 4 from the memory module. <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> </ul>
301	Archive parameter set 1	Saves the current parameter set as parameter set 1 in the memory module.
302	Archive parameter set 2	Saves the current parameter set as parameter set 2 in the memory module.
303	Archive parameter set 3	Saves the current parameter set as parameter set 3 in the memory module.
304	Archive parameter set 4	Saves the current parameter set as parameter set 4 in the memory module.
401	Internal command 401	For Lenze service only
501	Load Cam Data	<b>From software version V3.0</b> Reloads cam data from the memory module into the controller. <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> <li>If the cam data are provided with an access protection, the user password has to be entered in <a href="#">C02900</a> first.</li> </ul> ▶ Basic function " <a href="#">Cam data management</a> "
502	Save Cam Data	<b>From software version V3.0</b> Saves the cam data available in the main memory of the controller in the memory module with mains failure protection. <ul style="list-style-type: none"> <li>If the cam data are provided with an access protection, the user password has to be entered in <a href="#">C02900</a> first.</li> </ul> ▶ Basic function " <a href="#">Cam data management</a> "
503	Calculate Cam Data	<b>From software version V3.0</b> Converts the cam data available in the main memory of the controller into the internal format and provides them to the application. <ul style="list-style-type: none"> <li>▶ Basic function "<a href="#">Cam data management</a>"</li> </ul>
504	Calculate Cam Checksum	<b>From software version V3.0</b> Recalculates the checksum of the cam data available in the main memory of the controller. <ul style="list-style-type: none"> <li>Required if the cam data in the main memory of the controller have been changed via parameters.</li> </ul> ▶ Basic function " <a href="#">Cam data management</a> "
730	Internal command 730	For Lenze service only
731	Internal command 731	For Lenze service only
732	Internal command 732	For Lenze service only
733	Internal command 733	For Lenze service only
800	Internal command 800	For Lenze service only
810	Internal command 810	
811	Internal command 811	
812	Internal command 812	
1001	Internal command 1001	For Lenze service only
1020	Internal command 1020	For Lenze service only
1021	Export parameters to file	For Lenze service only

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00003

Parameter   Name:		Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
<b>C00002   Device commands</b>		
1030	Format file system	Formats file system of the memory module.
1040	Restore file system	Restores file system of the memory module (low level formatting). <ul style="list-style-type: none"> <li>The low level formatting of the file system by the user is only intended for the exceptional case when the standard formatting is not possible anymore, e.g. due to damaged internal management information.</li> </ul>
10000	Prepare firmware update	Sets the controller to the firmware update mode.
11000	Restart controller	Restarts controller via parameter setting.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

## C00003

Parameter   Name:		Data type: UNSIGNED_32 Index: 24572 <sub>d</sub> = 5FFC <sub>h</sub>
<b>C00003   Device command status</b>		
Display of the number/status of the device command last executed ( <a href="#">C00002</a> ).		
<ul style="list-style-type: none"> <li>The number of the command is situated in the upper 16 bits (for the meaning of the number see code <a href="#">C00002</a>).</li> <li>The result of the command stands in the lower 16 bits.</li> </ul>		
<b>Note:</b>		
Before switching off the supply voltage after a device command has been executed, check the successful execution of the device command via the status display in <a href="#">C00003</a> !		
The meaning of the status display in <a href="#">C00003</a> can be obtained from the subchapter for the corresponding device command in chapter " <a href="#">Device commands</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

Status	Meaning	Controller command
0	Device command executed successfully	0: <a href="#">Load Lenze setting</a>
1	General fault	
34050	Device command in process	
39424	CAN fault	
...	...	
39679	CAN fault	
65536	Device command executed successfully	1: <a href="#">Load start parameters</a>
65537	General fault	
99371	Fault while reading the parameter set partition	
99374	No memory module available	
99586	Device command in process	
104960	CAN fault	
...	...	
105215	CAN fault	
131072	Device command executed successfully	2: <a href="#">ENP: Load plant data</a>
131073	General fault	
165122	Device command in process	
327680	Device command executed successfully	5: <a href="#">Activate application</a>
327681	General fault	
361730	Device command in process	

Status	Meaning	Controller command
458752	Device command executed successfully	7: <a href="#">Save selected application</a>
458753	General fault	
492802	Device command in process	
720896	Device command executed successfully	11: <a href="#">Save start parameters</a>
720897	General fault	
754718	Fault while writing into a file	
754734	No memory module available	
754946	Device command in process	
761857	Access to file has been denied since the file is already accessed from another position	
761861	I/O fault when accessing the file system	
761868	RAM is full	
761869	Access authorisation denied	
761884	No free memory on the memory module	
1310720	Device command executed successfully	20: <a href="#">Delete logbook</a>
1310721	General fault	
1344770	Device command in process	
1376256	Device command executed successfully	21: <a href="#">Archive logbook</a>
1376257	General fault	
1410306	Device command in process	
2031616	Device command executed successfully	31: <a href="#">Start application</a>
2031617	General fault	
2065666	Device command in process	
2097152	Device command executed successfully	32: <a href="#">Stop application</a>
2097153	General fault	
2131202	Device command in process	
2162688	Device command executed successfully	33: <a href="#">Reset program</a>
2162689	General fault	
2196738	Device command in process	
2228224	Device command executed successfully	34: <a href="#">Delete program</a>
2228225	General fault	
2262274	Device command in process	
2293760	Device command executed successfully	35: <a href="#">Restart program</a>
2293761	General fault	
2327810	Device command in process	
2359296	Device command executed successfully	36: <a href="#">Reset runtime measurement</a>
2359297	General fault	
2393346	Device command in process	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00003

Status	Meaning	Controller command	
3342336	Device command executed successfully	51: <a href="#">Identify pole position (360°)</a>	
3342337	General fault		
3376386	Device command in process		
3382023	Pole position identification cannot be executed because of wrong motor type (asynchronous motor).		
3382024	Pole position identification has been aborted		
3382025	Pole position identification cannot be executed because another identification is already active.		
3382026	Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.		
3382027	Identification of pole position cannot be executed because current controller optimisation mode is active.		
3382033	Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable.		
3382047	Pole position identification cannot be executed because an error or trouble is active.		
3382065 <small>From software version V3.0</small>	Pole position identification cannot be executed because either the entire motor or a motor phase is not connected.		
3407872	Device command executed successfully		52: <a href="#">Identify pole position (min. motion)</a>
3407873	General fault		
3441922	Device command in process		
3447559	Pole position identification cannot be executed because of wrong motor type (asynchronous motor).		
3447560	Pole position identification has been aborted		
3447561	Pole position identification cannot be executed because another identification is already active.		
3447562	Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.		
3447563	Identification of pole position cannot be executed because current controller optimisation mode is active.		
3447569 <small>From software version V4.0</small>	Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable.		
3447583	Pole position identification cannot be executed because an error or trouble is active.		
3447597	Identification of pole position cannot be executed because the rotor has moved too strongly.		
3447601 <small>From software version V3.0</small>	Pole position identification cannot be executed because either the entire motor or a motor phase is not connected.		

Status	Meaning	Controller command
3900674	Device command in process	59: <a href="#">Resolver error identification</a>
3866624	Device command executed successfully	
3866625	General fault	
3906358	Resolver error identification cannot be executed since the wrong control type is active (no servo control).	
3906359	Resolver error identification cannot be executed since an error or trouble is active.	
3906360	Resolver error identification cannot be executed because another identification is already active.	
3906361	Resolver error identification cannot be executed because of too small speed (< 500 rpm).	
4587520	Device command executed successfully	70: <a href="#">Load Lenze inverter characteristic</a>
4587521	General fault	
4621570	Device command in process	71: <a href="#">Calculate inv. characteristic</a>
4653056	Device command executed successfully	
4653057	General fault	
4687106	Device command in process	
4692754	The calculation of the inverter characteristic cannot be started since the current controller test mode is active.	
4692755	The calculation of the inverter characteristic cannot be started since the V/f test mode is active.	
4692756	The calculation of the inverter characteristic cannot be started since the pole position identification is active.	
4692757	Calculation of the inverter characteristic has been aborted.	
4692758	Calculation of the inverter characteristic has been interrupted by error.	
4692789 <small>From software version V5.0</small>	The detected inverter error characteristic exceeds internal limits. This situation can for instance occur if the motor power is very much lower than the device power.	
4718592	Device command executed successfully	
4718593	General fault	
4752642	Device command in process	
4758290	Motor identification cannot be started since the current controller test mode is active.	
4758291	Motor identification cannot be started since the V/f test mode is active.	
4758292	Motor identification cannot be started because pole position identification is active.	
4758293	Motor identification has been aborted.	
4758294	Motor identification has been aborted by fault.	
4758332 <small>From software version V7.0</small>	Motor identification aborted due to inconsistent motor parameters.	
5046272	Device command executed successfully	77: <a href="#">Calculate current controller parameters</a>
5046273	General fault	
5080322	Device command in process	
5086002	At least one calculated value is beyond the valid setting range.	
5086003	Stator resistance ( <a href="#">C00084</a> ) too small (zero).	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00003

Status	Meaning	Controller command
5111808	Device command executed successfully	78: <a href="#">Calculate speed controller parameters</a>
5111809	General fault	
5145858	Device command in process	
5151540	At least one calculated value is beyond the valid setting range.	91: <a href="#">CAN on board: Reset node</a>
5963776	Device command executed successfully	
5963777	General fault	
5997826	Device command in process	
6003200	CAN fault	
...	...	
6003455	CAN fault	
6029312	Device command executed successfully	92: <a href="#">CAN module: Reset node</a>
6029313	General fault	
6063362	Device command in process	
6068736	CAN fault	
...	...	93: <a href="#">CAN on board: Pred.Connect.Set</a>
6068991	CAN fault	
6094848	Device command executed successfully	
6094849	General fault	
6128898	Device command in process	94: <a href="#">CAN module: Pred.Connect.Set</a>
6160384	Device command executed successfully	
6160385	General fault	
6194434	Device command in process	
6225920	Device command executed successfully	95: <a href="#">CAN on board: Identify node</a>
6225921	General fault	
6259970	Device command in process	
6291456	Device command executed successfully	96: <a href="#">CAN module: Identify node</a>
6291457	General fault	
6325506	Device command in process	
6619136	Device command executed successfully	101: <a href="#">Ethernet module MXI2 unbind/bind</a>
6619137	General fault	
6653186	Device command in process	102: <a href="#">Ethernet module MXI2 unbind/bind</a>
6684672	Device command executed successfully	
6684673	General fault	
6718722	Device command in process	



Status	Meaning	Controller command	
13172731	General fault	201: <a href="#">Activate parameter set 1</a>	
13172736	Device command executed successfully		
13206532	File could not be opened.		
13206557	Fault while reading out of a file.		
13206558	Fault while writing into a file.		
13206559	Invalid file type.		
13206560	Unexpected file end.		
13206562	Checksum error		
13206786	Device command in process		
13212160	CAN fault		
...	...		
13212415	CAN fault		
13213697	Access to file has been denied since the file is already accessed from another position		
13213701	I/O fault when accessing the file system		
13213708	RAM is full		
13213709	Access authorisation denied		
13213724	No free memory on the memory module		
13238272	Device command executed successfully		202: <a href="#">Activate parameter set 2</a>
13238273	General fault		
13272068	File could not be opened.		
13272093	Fault while reading out of a file.		
13272094	Fault while writing into a file.		
13272095	Invalid file type.		
13272096	Unexpected file end.		
13272098	Checksum error		
13272322	Device command in process		
13277696	CAN fault		
...	...		
13277951	CAN fault		
13279233	Access to file has been denied since the file is already accessed from another position		
13279237	I/O fault when accessing the file system		
13279244	RAM is full		
13279245	Access authorisation denied		
13279260	No free memory on the memory module		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00003

Status	Meaning	Controller command
13303808	Device command executed successfully	203: <a href="#">Activate parameter set 3</a>
13303809	General fault	
13337604	File could not be opened.	
13337629	Fault while reading out of a file.	
13337630	Fault while writing into a file.	
13337631	Invalid file type.	
13337632	Unexpected file end.	
13337634	Checksum error	
13337858	Device command in process	
13343232	CAN fault	
...	...	
13343487	CAN fault	
13344769	Access to file has been denied since the file is already accessed from another position	
13344773	I/O fault when accessing the file system	
13344780	RAM is full	
13344781	Access authorisation denied	
13344796	No free memory on the memory module	
13369344	Device command executed successfully	204: <a href="#">Activate parameter set 4</a>
13369345	General fault	
13403140	File could not be opened.	
13403165	Fault while reading out of a file.	
13403166	Fault while writing into a file.	
13403167	Invalid file type.	
13403168	Unexpected file end.	
13403170	Checksum error	
13403394	Device command in process	
13408768	CAN fault	
...	...	
13409023	CAN fault	
13410305	Access to file has been denied since the file is already accessed from another position	
13410309	I/O fault when accessing the file system	
13410316	RAM is full	
13410317	Access authorisation denied	
13410332	No free memory on the memory module	

Status	Meaning	Controller command
19726336	Device command executed successfully	301: <a href="#">Archive parameter set 1</a>
19726337	General fault	
19760132	File could not be opened.	
19760157	Fault while reading out of a file.	
19760158	Fault while writing into a file.	
19760160	Unexpected file end.	
19760386	Device command in process	
19767297	Access to file has been denied since the file is already accessed from another position	
19767301	I/O fault when accessing the file system	
19767308	RAM is full	
19767309	Access authorisation denied	
19767324	No free memory on the memory module	
19791872	Device command executed successfully	302: <a href="#">Archive parameter set 2</a>
19791873	General fault	
19825668	File could not be opened.	
19825693	Fault while reading out of a file.	
19825694	Fault while writing into a file.	
19825696	Unexpected file end.	
19825922	Device command in process	
19832833	Access to file has been denied since the file is already accessed from another position	
19832837	I/O fault when accessing the file system	
19832844	RAM is full	
19832845	Access authorisation denied	
19832860	No free memory on the memory module	
19857408	Device command executed successfully	303: <a href="#">Archive parameter set 3</a>
19857409	General fault	
19891204	File could not be opened.	
19891229	Fault while reading out of a file.	
19891230	Fault while writing into a file.	
19891232	Unexpected file end.	
19891458	Device command in process	
19898369	Access to file has been denied since the file is already accessed from another position	
19898373	I/O fault when accessing the file system	
19898380	RAM is full	
19898381	Access authorisation denied	
19898396	No free memory on the memory module	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00003

Status	Meaning	Controller command
19922944	Device command executed successfully	304: <a href="#">Archive parameter set 4</a>
19922945	General fault	
19956740	File could not be opened.	
19956765	Fault while reading out of a file.	
19956766	Fault while writing into a file.	
19956768	Unexpected file end.	
19956994	Device command in process	
19963905	Access to file has been denied since the file is already accessed from another position	
19963909	I/O fault when accessing the file system	
19963916	RAM is full	
19963917	Access authorisation denied	
19963932	No free memory on the memory module	
32833536	Device command executed successfully	501: <a href="#">Load cam data</a>
32833537	General fault	
32867586	Device command in process	
32875521	No cam data available on the memory module	
32875523	Loading of the cam data failed	
32875525	Checksum error	
32875542	Wrong password entered	
32875545	The cam functionality is deactivated	
32899072	Device command executed successfully	502: <a href="#">Save cam data</a>
32899073	General fault	
32933122	Device command in process	
32941057	No cam data to be saved are available in the RAM of the controller	
32941060	Saving of the cam data failed	
32941078	Wrong password entered	
32941081	The cam functionality is deactivated	
32964608	Device command executed successfully	503: <a href="#">Calculate cam data</a>
32964609	General fault	
32998658	Device command in process	
33006617	The cam functionality is deactivated	
33030144	Device command executed successfully	504: <a href="#">Calculate cam data checksum</a>
33030145	General fault	
33064194	Device command in process	
33072153	The cam functionality is deactivated	
67502080	Device command executed successfully	1030: <a href="#">Format file system</a>
67502081	General fault	
67536130	Device command in process	
655360000	Device command executed successfully	10000: <a href="#">Prepare firmware update</a>
655360001	General fault	
655394050	Device command in process	
720896001	General fault	11000: <a href="#">Restart controller</a>
720930050	Device command in process	

C00004

Parameter   Name: <b>C00004   Service password</b>		Data type: UNSIGNED_32 Index: 24571 <sub>d</sub> = 5FFB <sub>h</sub>
Service code to unlock protected device commands ( <a href="#">C00002</a> ).		
Setting range (min. value   unit   max. value)		Lenze setting
0		4294967295 <b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C00005

Parameter   Name: <b>C00005   Application selection</b>		Data type: INTEGER_32 Index: 24570 <sub>d</sub> = 5FFA <sub>h</sub>
Application selection		
• Use the device command <a href="#">C00002</a> ="5" to activate the selected application.		
Setting range (min. value   unit   max. value)		Lenze setting
-1		16 <b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C00006

Parameter   Name: <b>C00006   Select motor control</b>		Data type: UNSIGNED_32 Index: 24569 <sub>d</sub> = 5FF9 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
Selection list (Lenze setting printed in bold)		Information
1	<b>SC: Servo control sync. motor</b>	For synchronous motors with speed sensor <a href="#">▶ Servo control</a>
2	SC: Servo control async. motor	For asynchronous motors with speed sensor <a href="#">▶ Servo control</a>
4	SLVC: Sensorless vector control	From software version V3.0 <a href="#">▶ Sensorless vector control</a>
6	VFCplus: V/f control open loop	From software version V3.0 <a href="#">▶ V/f control</a>
7	VFCplus: V/f control closed loop	From software version V3.0 <a href="#">▶ V/f control closed loop</a>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00007

Parameter   Name: <b>C00007   Active application</b>		Data type: INTEGER_32 Index: 24568 <sub>d</sub> = 5FF8 <sub>h</sub>
Display range (min. value   unit   max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00008

Parameter   Name: <b>C00008   Progress of device command</b>		Data type: UNSIGNED_32 Index: 24567 <sub>d</sub> = 5FF7 <sub>h</sub>
From software version V7.0		
Display range (min. value   unit   max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00011

C00011

Parameter   Name: <b>C00011   Motor reference speed</b>		Data type: UNSIGNED_32 Index: 24564 <sub>d</sub> = 5FF4 <sub>h</sub>
For parameter setting via interface: In case of bigger changes, only change the setting in one step when the controller is inhibited!		
Setting range (min. value   unit   max. value)		Lenze setting
50	rpm	50000
		<b>3000 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00018

Parameter   Name: <b>C00018   Chopper frequency</b>		Data type: UNSIGNED_32 Index: 24557 <sub>d</sub> = 5FED <sub>h</sub>
Selection list (Lenze setting printed in bold)		Information
2	1 kHz fixed/drive-optimised	<b>Note:</b> <ul style="list-style-type: none"> <li>The maximum output frequency of the controller is limited to 1/8 of the switching frequency selected here!</li> <li>The switching frequencies that can be selected depend on the device type (see Hardware Manual, chapter "Rated data").</li> <li>In the case of an offline parameter setting or when exchanging the memory module between different Servo Drives 9400 HighLine device types, always check the setting of this parameter and adapt it, if required, to prevent a parameter error after the parameter set download or module change!</li> </ul>
3	2 kHz fixed/drive-optimised	
4	4 kHz fixed/drive-optimised	
5	8 kHz fixed/drive-optimised	
8	2 kHz var./drive-optimised	
9	4 kHz var./drive-optimised	
<b>10</b>	<b>8 kHz var./drive-optimised</b>	
11	16 kHz var./drive-optimised	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00019

Parameter   Name: <b>C00019   Threshold - standstill recognition</b>		Data type: UNSIGNED_32 Index: 24556 <sub>d</sub> = 5FEC <sub>h</sub>
Setting range (min. value   unit   max. value)		Lenze setting
0	rpm	450
		<b>5 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00022

Parameter   Name: <b>C00022   Maximum current</b>		Data type: UNSIGNED_32 Index: 24553 <sub>d</sub> = 5FE9 <sub>h</sub>
<b>Note:</b> <ul style="list-style-type: none"> <li>To avoid that the motor starts unintentionally without adjusting the plant data, the maximum current in the Lenze setting is set to "0 A"!</li> <li>The upper limit value is the maximum device current (see display in <a href="#">C00789</a>).</li> <li>In the case of an offline parameter setting or when exchanging the memory module between different 9400 HighLine device types, always check the setting of this parameter and adapt it, if required, to prevent a parameter error after the parameter set download or module change!</li> <li>Also check the threshold set for the maximum motor current monitoring (<a href="#">C00620</a>).</li> </ul>		
Setting range (min. value   unit   max. value)		Lenze setting
0.00	A	21474836.47
		<b>0.00 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00034

Parameter   Name: <b>C00034   Config. analog input 1</b>		Data type: UNSIGNED_32 Index: 24541 <sub>d</sub> = 5FDD <sub>h</sub>
Selection list (Lenze setting printed in bold)		
<b>0</b>	<b>-10 ... +10 V</b>	
1	-20...-4 mA, +4...+20 mA	
2	-20 ... +20 mA	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00050

Parameter   Name: <b>C00050   Speed setpoint [rpm]</b>		Data type: INTEGER_32 Index: 24525 <sub>d</sub> = 5FC <sub>Dh</sub>
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<b>Subcodes</b>		<b>Information</b>
C00050/1		Speed setpoint 1 [rpm]
C00050/2		Speed setpoint 2 [rpm]
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00051

Parameter   Name: <b>C00051   Actual speed [rpm]</b>		Data type: INTEGER_32 Index: 24524 <sub>d</sub> = 5FC <sub>Ch</sub>
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00052

Parameter   Name: <b>C00052   Motor voltage</b>		Data type: UNSIGNED_32 Index: 24523 <sub>d</sub> = 5FC <sub>Bh</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	V	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00053

Parameter   Name: <b>C00053   DC-bus voltage</b>		Data type: UNSIGNED_32 Index: 24522 <sub>d</sub> = 5FC <sub>Ah</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	V	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00054

Parameter   Name: <b>C00054   Motor current</b>		Data type: UNSIGNED_32 Index: 24521 <sub>d</sub> = 5FC <sub>9h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0.00	A	500.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C00055

Parameter   Name: <b>C00055   Phase currents</b>		Data type: INTEGER_32 Index: 24520 <sub>d</sub> = 5FC <sub>8h</sub>
<b>Display range (min. value   unit   max. value)</b>		
-500.00	A	500.00
<b>Subcodes</b>		<b>Information</b>
C00055/1		Phase zero system
C00055/2		Phase U
C00055/3		Phase V
C00055/4		Phase W
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00056

C00056

Parameter   Name:		Data type: INTEGER_32 Index: 24519 <sub>d</sub> = 5FC7 <sub>h</sub>
<b>C00056   Torque setpoint</b>		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00057

Parameter   Name:		Data type: UNSIGNED_32 Index: 24518 <sub>d</sub> = 5FC6 <sub>h</sub>
<b>C00057   Torque</b>		
Display range (min. value   unit   max. value)		
0.000	Nm	2147483.647
<b>Subcodes</b>		<b>Information</b>
C00057/1	Maximum torque <ul style="list-style-type: none"> <li>With regard to the selected motor and the max. short-time output current of the device.</li> </ul>	
C00057/2	Motor reference torque <ul style="list-style-type: none"> <li>Torque at maximum current (<a href="#">C00022</a>).</li> </ul>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C00058

Parameter   Name:		Data type: INTEGER_32 Index: 24517 <sub>d</sub> = 5FC5 <sub>h</sub>
<b>C00058   Pole position</b>		
Setting range (min. value   unit   max. value)		
-179.9	°	179.9
<b>Subcodes</b>		<b>Lenze setting</b>
C00058/1	-90.0 °	
C00058/2	0.0 °	
C00058/3	0.0 °	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00059

Parameter   Name:		Data type: UNSIGNED_32 Index: 24516 <sub>d</sub> = 5FC4 <sub>h</sub>
<b>C00059   Motor - number of pole pairs</b>		
Display range (min. value   unit   max. value)		
0		200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00060

Parameter   Name:		Data type: INTEGER_32 Index: 24515 <sub>d</sub> = 5FC3 <sub>h</sub>
<b>C00060   Rotor position</b>		
Display range (min. value   unit   max. value)		
0		2047
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00061

Parameter   Name:		Data type: INTEGER_32 Index: 24514 <sub>d</sub> = 5FC2 <sub>h</sub>
<b>C00061   Heatsink temperature</b>		
Display range (min. value   unit   max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



C00062

Parameter   Name:	<b>C00062   Temperature inside the controller</b>		Data type: INTEGER_32 Index: 24513 <sub>d</sub> = 5FC1 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200	°C	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00063

Parameter   Name:	<b>C00063   Motor temperature</b>		Data type: INTEGER_32 Index: 24512 <sub>d</sub> = 5FC0 <sub>h</sub>
<a href="#">▶ Motor temperature monitoring</a>			
<b>Display range (min. value   unit   max. value)</b>			
-200	°C	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00064

Parameter   Name:	<b>C00064   Device utilisation (lxt)</b>		Data type: UNSIGNED_32 Index: 24511 <sub>d</sub> = 5FBF <sub>h</sub>
Device utilisation during the last 180 seconds			
<ul style="list-style-type: none"> <li>• C00064 &gt; 100 % activates error (OC5).</li> <li>• Error reset only possible if C00064 &lt; 95 %.</li> </ul>			
<b>Display range (min. value   unit   max. value)</b>			
0	%	250	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00065

Parameter   Name:	<b>C00065   Ext. 24-V voltage</b>		Data type: INTEGER_32 Index: 24510 <sub>d</sub> = 5FB <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.0	V	1000.0	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00066

Parameter   Name:	<b>C00066   Thermal motor load (I<sup>2</sup>xt)</b>		Data type: UNSIGNED_32 Index: 24509 <sub>d</sub> = 5FBD <sub>h</sub>
A 100 % load corresponds to a permanently flowing rated motor current			
<b>Display range (min. value   unit   max. value)</b>			
0	%	250	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00068

Parameter   Name:	<b>C00068   Capacitor temperature</b>		Data type: INTEGER_32 Index: 24507 <sub>d</sub> = 5FB <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200	°C	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00069

Parameter   Name:	<b>C00069   CPU temperature</b>		Data type: INTEGER_32 Index: 24506 <sub>d</sub> = 5FBA <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200	°C	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00070

C00070

Parameter   Name: <b>C00070   Speed controller gain</b>			Data type: UNSIGNED_32 Index: 24505 <sub>d</sub> = 5FB9 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.00000	Nm/rpm	20000.00000	<b>0.00044 Nm/rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100000

C00071

Parameter   Name: <b>C00071   Speed contr. reset time</b>			Data type: UNSIGNED_32 Index: 24504 <sub>d</sub> = 5FB8 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
1.0	ms	6000.0	<b>14.4 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00072

Parameter   Name: <b>C00072   Speed contr.D component</b>			Data type: UNSIGNED_32 Index: 24503 <sub>d</sub> = 5FB7 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.00	ms	3.00	<b>0.00 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00074

Parameter   Name: <b>C00074   Feedfwd. ctrl. - current contr.</b>			Data type: UNSIGNED_8 Index: 24501 <sub>d</sub> = 5FB5 <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>			
0 Deactivate feedfwd. ctrl			
1 Activate feedfwd. ctrl			
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00075

Parameter   Name: <b>C00075   Current controller gain</b>			Data type: UNSIGNED_32 Index: 24500 <sub>d</sub> = 5FB4 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.00	V/A	750.00	<b>105.00 V/A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00076

Parameter   Name: <b>C00076   Current contr. reset time</b>			Data type: UNSIGNED_32 Index: 24499 <sub>d</sub> = 5FB3 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.01	ms	2000.00	<b>2.00 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00077

Parameter   Name: <b>C00077   Field controller gain</b>			Data type: UNSIGNED_32 Index: 24498 <sub>d</sub> = 5FB2 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.00	A/Vs	50000.00	<b>165.84 A/Vs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00078

Parameter   Name: <b>C00078   Field contr. reset time</b>			Data type: UNSIGNED_32 Index: 24497 <sub>d</sub> = 5FB1 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
1.0	ms	6000.0	<b>15.1 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00079

Parameter   Name: <b>C00079   Motor - mutual inductance</b>			Data type: UNSIGNED_32 Index: 24496 <sub>d</sub> = 5FB0 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.0	mH	214748364.7	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00080

Parameter   Name: <b>C00080   Resolver - number of pole pairs</b>			Data type: UNSIGNED_32 Index: 24495 <sub>d</sub> = 5FAF <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
1		10	<b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00081

Parameter   Name: <b>C00081   Rated motor power</b>			Data type: UNSIGNED_32 Index: 24494 <sub>d</sub> = 5FAE <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.01	kW	500.00	<b>0.25 kW</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00082

Parameter   Name: <b>C00082   Motor - rotor resistance</b>			Data type: UNSIGNED_32 Index: 24493 <sub>d</sub> = 5FAD <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.0000	Ohm	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C00083

Parameter   Name: <b>C00083   Motor - rotor time constant</b>			Data type: UNSIGNED_32 Index: 24492 <sub>d</sub> = 5FAC <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.00	ms	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00084

Parameter   Name: <b>C00084   Motor stator resistance</b>			Data type: UNSIGNED_32 Index: 24491 <sub>d</sub> = 5FAB <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Ohm	125.0000	<b>18.2200 Ohm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C00085

Parameter   Name: <b>C00085   Motor stator leakage induct.</b>			Data type: UNSIGNED_32 Index: 24490 <sub>d</sub> = 5FAA <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.000	mH	500.000	<b>51.000 mH</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00087

Parameter   Name: <b>C00087   Rated motor speed</b>			Data type: UNSIGNED_32 Index: 24488 <sub>d</sub> = 5FA8 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
50	rpm	50000	<b>4050 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00088

C00088

Parameter   Name: <b>C00088   Rated motor current</b>			Data type: UNSIGNED_32 Index: 24487 <sub>d</sub> = 5FA7 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.01	A	1500.00	<b>1.30 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00089

Parameter   Name: <b>C00089   Rated motor frequency</b>			Data type: UNSIGNED_32 Index: 24486 <sub>d</sub> = 5FA6 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.1	Hz	1000.0	<b>270.0 Hz</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00090

Parameter   Name: <b>C00090   Rated motor voltage</b>			Data type: UNSIGNED_32 Index: 24485 <sub>d</sub> = 5FA5 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
50	V	15000	<b>225 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00091

Parameter   Name: <b>C00091   Motor - cosine phi</b>			Data type: UNSIGNED_32 Index: 24484 <sub>d</sub> = 5FA4 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.50		1.00	<b>0.80</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00092

Parameter   Name: <b>C00092   Motor - magnetising current</b>			Data type: UNSIGNED_32 Index: 24483 <sub>d</sub> = 5FA3 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.00	A	500.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00093

Parameter   Name: <b>C00093   Field weakening for SM</b>			Data type: UNSIGNED_32 Index: 24482 <sub>d</sub> = 5FA2 <sub>h</sub>
From software version V2.0			
<a href="#">▶ Field weakening for synchronous machines</a>			
<b>Selection list (Lenze setting printed in bold)</b>			
0	<b>Field weakening for SM off</b>		
1	Field weakening for SM on		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00099

Parameter   Name: <b>C00099   Firmware version</b>			Data type: VISIBLE_STRING Index: 24476 <sub>d</sub> = 5F9C <sub>h</sub>
Format: "xx.xx.xx.xx" (main version, subversion, release version, build number)			
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00100

Parameter   Name: <b>C00100   Resol. of an encoder revolution</b>		Data type: UNSIGNED_32 Index: 24475 <sub>d</sub> = 5F9B <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
10		24 <b>16</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00105

Parameter   Name: <b>C00105   Quick stop decel. time</b>		Data type: UNSIGNED_32 Index: 24470 <sub>d</sub> = 5F96 <sub>h</sub>
Time between quick stop activation and standstill plus relative S-ramp time ( <a href="#">C00106</a> ). ▶ Basic function " <a href="#">Quick stop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.000	s	999.999 <b>0.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

## C00106

Parameter   Name: <b>C00106   Quick stop S-ramp time</b>		Data type: UNSIGNED_32 Index: 24469 <sub>d</sub> = 5F95 <sub>h</sub>
S-ramp time in [%] relating to the deceleration time set under <a href="#">C00105</a> . ▶ Basic function " <a href="#">Quick stop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	%	100.00 <b>0.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C00107

Parameter   Name: <b>C00107   Ref. for quick stop dec. time</b>		Data type: UNSIGNED_8 Index: 24468 <sub>d</sub> = 5F94 <sub>h</sub>
Reference for the deceleration time set in <a href="#">C00105</a> . ▶ Basic function " <a href="#">Quick stop</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Motor reference speed (C00011)</b>	
1	Current speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00114

Parameter   Name: <b>C00114   Dig. input x: Terminal polarity</b>		Data type: UNSIGNED_8 Index: 24461 <sub>d</sub> = 5F8D <sub>h</sub>
"0" = positive logic (HIGH level = TRUE, LOW level = FALSE) "1" = negative logic (HIGH level = FALSE, LOW level = TRUE)		
<b>Setting range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00114/1	0	Terminal polarity - digital input 1 ... 8
C00114/...		
C00114/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00118

C00118

Parameter   Name: <b>C00118   Dig. output. x: Terminal polarity</b>		Data type: UNSIGNED_8 Index: 24457 <sub>d</sub> = 5F89 <sub>h</sub>
<p>"0" ≡ positive logic (TRUE ≡ HIGH level, FALSE ≡ LOW level)                  "1" ≡ negative logic (FALSE ≡ HIGH level, TRUE ≡ LOW level)</p>		
<b>Setting range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00118/1	0	Terminal polarity - digital output 1 ... 4
C00118/...		
C00118/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00120

Parameter   Name: <b>C00120   Mot. overload protection (I<sup>2</sup>t)</b>		Data type: UNSIGNED_32 Index: 24455 <sub>d</sub> = 5F87 <sub>h</sub>
<p>Threshold for I<sup>2</sup> x t disconnection</p> <ul style="list-style-type: none"> <li>Disconnection is carried out if the thermal motor load (<a href="#">C00066</a>) is higher than the set threshold.</li> <li>A 100 % thermal motor load corresponds to a permanently flowing rated motor current</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	%	200
		<b>105 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00121

Parameter   Name: <b>C00121   Motor temp. warning threshold</b>		Data type: UNSIGNED_32 Index: 24454 <sub>d</sub> = 5F86 <sub>h</sub>
<p>Temperature threshold for motor temperature advance warning</p> <ul style="list-style-type: none"> <li>The response to reaching the threshold can be selected in <a href="#">C00584</a>.</li> </ul>		
<a href="#">▶ Motor temperature monitoring</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	°C	150
		<b>120 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00122

Parameter   Name: <b>C00122   Heatsink temp. warn. threshold</b>		Data type: UNSIGNED_32 Index: 24453 <sub>d</sub> = 5F85 <sub>h</sub>
<p>Temperature threshold for heatsink temperature advance warning</p> <ul style="list-style-type: none"> <li>The response to reaching the threshold can be selected in <a href="#">C00582</a>.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	°C	85
		<b>85 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00123

Parameter   Name: <b>C00123   Warning threshold device util.</b>		Data type: UNSIGNED_32 Index: 24452 <sub>d</sub> = 5F84 <sub>h</sub>
<p>Adjustable threshold for I x t advance warning</p> <ul style="list-style-type: none"> <li>The advance warning is sent if the device utilisation (<a href="#">C00064</a>) is higher than the set threshold.</li> <li>The response to reaching the threshold can be selected in <a href="#">C00604</a>.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	%	100
		<b>90 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00126

Parameter   Name: <b>C00126   CPU temp. warning threshold</b>		Data type: UNSIGNED_32 Index: 24449 <sub>d</sub> = 5F81 <sub>h</sub>
Temperature threshold for advance warning of CPU temperature on the control card		
<ul style="list-style-type: none"> <li>The response to reaching the threshold can be selected in <a href="#">C00589</a>.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	°C	85
		<b>70 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00127

Parameter   Name: <b>C00127   Mot. overload warning threshold</b>		Data type: UNSIGNED_32 Index: 24448 <sub>d</sub> = 5F80 <sub>h</sub>
Adjustable threshold for I <sup>2</sup> x t advance warning		
<ul style="list-style-type: none"> <li>The advance warning is sent if the thermal motor load (<a href="#">C00066</a>) is higher than the set threshold.</li> <li>The response to reaching the threshold can be selected in <a href="#">C00606</a>.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	%	200
		<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00128

Parameter   Name: <b>C00128   Therm. motor time constant</b>		Data type: UNSIGNED_32 Index: 24447 <sub>d</sub> = 5F7F <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
0.1	min	600.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00128/1	1.0 min	Therm. time constant coil
C00128/2	5.0 min	Therm. time constant plates
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C00129

Parameter   Name: <b>C00129   Brake resistor value</b>		Data type: INTEGER_32 Index: 24446 <sub>d</sub> = 5F7E <sub>h</sub>
Required for monitoring of the brake resistor temperature.		
<a href="#">▶ Braking operation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0	Ohm	500.0
		<b>180.0 Ohm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C00130

Parameter   Name: <b>C00130   Rated power of brake resistor</b>		Data type: INTEGER_32 Index: 24445 <sub>d</sub> = 5F7D <sub>h</sub>
Required for monitoring of the brake resistor temperature.		
<a href="#">▶ Braking operation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	W	800000
		<b>5600 W</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00131

Parameter   Name: <b>C00131 - Rated quantity of heat for brake res.</b>		Data type: INTEGER_32 Index: 24444 <sub>d</sub> = 5F7C <sub>h</sub>
Required for monitoring of the brake resistor temperature.		
<a href="#">▶ Braking operation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	kWs	100000
		<b>485 kW</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00132

C00132

Parameter | Name: **C00132 | Service code** Data type: INTEGER\_32  
Index: 24443<sub>d</sub> = 5F7B<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00133

Parameter | Name: **C00133 | Ref.: Brake chopper utilisation** Data type: UNSIGNED\_8  
Index: 24442<sub>d</sub> = 5F7A<sub>h</sub>

From software version V1.5

► [Braking operation](#)

Selection list (Lenze setting printed in bold)		Information
<b>0</b>	<b>Minimum resistance (C00134)</b>	► <a href="#">C00134</a>
1	Resistance in C00129	► <a href="#">C00129</a>

Read access  Write access  CINH  PLC STOP  No transfer    Scaling factor: 1

C00134

Parameter | Name: **C00134 | Minimum brake resistance** Data type: INTEGER\_32  
Index: 24441<sub>d</sub> = 5F79<sub>h</sub>

From software version V1.5

► [Braking operation](#)

Display range (min. value   unit   max. value)		
0.0	Ohm	500.0

Read access  Write access  CINH  PLC STOP  No transfer    Scaling factor: 10

C00137

Parameter | Name: **C00137 | Brake transistor utilisation** Data type: INTEGER\_32  
Index: 24438<sub>d</sub> = 5F76<sub>h</sub>

From software version V1.5

► [Braking operation](#)

Display range (min. value   unit   max. value)		
0	%	250

Read access  Write access  CINH  PLC STOP  No transfer    Scaling factor: 1

C00138

Parameter | Name: **C00138 | Brake resistor utilisation** Data type: INTEGER\_32  
Index: 24437<sub>d</sub> = 5F75<sub>h</sub>

From software version V1.5

► [Braking operation](#)

Display range (min. value   unit   max. value)		
0	%	250

Read access  Write access  CINH  PLC STOP  No transfer    Scaling factor: 1

C00142

Parameter | Name: **C00142 | Autom. restart after mains ON** Data type: UNSIGNED\_32  
Index: 24433<sub>d</sub> = 5F71<sub>h</sub>

Starting performance of the controller after mains connection and reset of "Trouble", "Fault" or "safe torque off active".

**⚠ Danger!**

**If the automatic restart is enabled (C00142 = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or requirement for "Safe torque off active" is no longer available!**

► [Automatic restart after mains connection](#)

Selection list (Lenze setting printed in bold)	
<b>0</b>	<b>Inhibited</b>
1	Enabled

Read access  Write access  CINH  PLC STOP  No transfer    Scaling factor: 1



## C00150

Parameter   Name: <b>C00150   Status word device control 1</b>		Data type: BITFIELD_16 Index: 24425 <sub>d</sub> = 5F69 <sub>h</sub>
Status word 1 of the <a href="#">drive interface</a>		
<b>Display area</b>		
0x0000		0xFFFF
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Reserved	For the meaning of bits 8 ... 11 see chapter " <a href="#">Device states</a> ".
Bit 1	Pulse inhibit active	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Reserved	
Bit 5	Reserved	
Bit 6	Actual speed value = 0	
Bit 7	Controller inhibit active	
Bit 8	Device state - Bit 1	
Bit 9	Device state - Bit 2	
Bit 10	Device state - Bit 3	
Bit 11	Device state - Bit 4	
Bit 12	Warning active	
Bit 13	Trouble active	
Bit 14	Reserved	
Bit 15	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer           Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00155

## C00155

Parameter   Name: <b>C00155   Status word device control 2</b>		Data type: BITFIELD_16 Index: 24420 <sub>d</sub> = 5F64 <sub>h</sub>
Status word 2 of the <a href="#">drive interface</a>		
<b>Display area</b>		
0x0000		0xFFFF
<b>Value is bit-coded:</b>		
Bit 0	Error status active	
Bit 1	Torque limit reached	
Bit 2	Current limit reached	
Bit 3	Reserved	
Bit 4	Drive switched on/in operation	
Bit 5	Drive ready for operation	
Bit 6	Fault active	
Bit 7	Drive initialisation	
Bit 8	Motor CCW rotation active	
Bit 9	Quick stop by trouble active	
Bit 10	Safe torque off active	
Bit 11	Application active	
Bit 12	Reserved	
Bit 13	Reserved	
Bit 14	Quick stop active	
Bit 15	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00156

Parameter   Name: <b>C00156   Status/Control word MCTRL</b>		Data type: UNSIGNED_32 Index: 24419 <sub>d</sub> = 5F63 <sub>h</sub>
Status and control word of the <a href="#">motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<b>Subcodes</b>	<b>Information</b>	
C00156/1	Status word motor control	
C00156/2	Control word motor control	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00158

Parameter   Name: <b>C00158   Controller inhibit by (source)</b>		Data type: BITFIELD_16 Index: 24417 <sub>d</sub> = 5F61 <sub>h</sub>
<b>Display area</b>		
0x0000		0xFFFF
<b>Value is bit-coded:</b>		
Bit 0	Terminal	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Application	
Bit 5	Controller command	
Bit 6	Error response	
Bit 7	Internal PLC	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Operating system	
Bit 11	Identification program	
Bit 12	Brake	
Bit 13	Limiter	
Bit 14	PPI	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00159

Parameter   Name: <b>C00159   Quick stop by (source)</b>		Data type: BITFIELD_16 Index: 24416 <sub>d</sub> = 5F60 <sub>h</sub>
<b>Display area</b>		
0x0000		0xFFFF
<b>Value is bit-coded:</b>		
Bit 0	Reserved	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Application	
Bit 5	Controller command	
Bit 6	Error response	
Bit 7	Internal PLC	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Reserved	
Bit 11	Reserved	
Bit 12	Reserved	
Bit 13	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00162

C00162

Parameter   Name: <b>C00162   Masked Error number</b>		Data type: UNSIGNED_32 Index: 24413 <sub>d</sub> = 5F5D <sub>h</sub>
From software version V5.0		
Display of the individual components of the error number shown in <a href="#">C00168</a> .		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<b>Subcodes</b>	<b>Information</b>	
C00162/1	Module ID + error number • As described in the chapter " <a href="#">Error messages</a> ".	
C00162/2	Instance number	
C00162/3	Error response	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00166

Parameter   Name: <b>C00166   Error description</b>		Data type: VISIBLE_STRING Index: 24409 <sub>d</sub> = 5F59 <sub>h</sub>
Error description for error number indicated in <a href="#">C00168</a>		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00167

Parameter   Name: <b>C00167   Service code</b>		Data type: VISIBLE_STRING Index: 24408 <sub>d</sub> = 5F58 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00168

Parameter   Name: <b>C00168   Error number</b>		Data type: UNSIGNED_32 Index: 24407 <sub>d</sub> = 5F57 <sub>h</sub>
Display of the error number of the first error with highest priority		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00169

Parameter   Name: <b>C00169   Logbook - event filter</b>		Data type: BITFIELD_32 Index: 24406 <sub>d</sub> = 5F56 <sub>h</sub>
Bit coded word for filtering system events (trouble, warning, information)		
<ul style="list-style-type: none"> <li>• A set filter bit inhibits entry of the corresponding event into the logbook.</li> <li>• From software version V5.0 the option that identical consecutive entries ("Multiple entries") into the logbook are suppressed can be additionally activated via bit 0. Then only the time stamp of the last (latest) entry and the number of times the same event has occurred successively are saved.</li> </ul>		
<a href="#">Logbook</a>		
<b>Setting range</b>		<b>Lenze setting</b>
0x00000000		0xFFFFFFFF (decimal: 1)
<b>Value is bit-coded: (<input checked="" type="checkbox"/> = bit set)</b>		<b>Information</b>
Bit 0 <input checked="" type="checkbox"/>	No multiple entries	Bits not listed are reserved for future extensions!
Bit 1 <input type="checkbox"/>	Fault	
Bit 2 <input type="checkbox"/>	Trouble	
Bit 3 <input type="checkbox"/>	Quick stop by trouble	
Bit 4 <input type="checkbox"/>	Warning locked	
Bit 5 <input type="checkbox"/>	Warning	
Bit 6 <input type="checkbox"/>	Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00171

Parameter   Name: <b>C00171   Service code</b>	Data type: UNSIGNED_32 Index: 24404 <sub>d</sub> = 5F54 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

## C00173

Parameter   Name: <b>C00173   Mains voltage</b>	Data type: UNSIGNED_8 Index: 24402 <sub>d</sub> = 5F52 <sub>h</sub>
--	--

Adjustment of the DC bus voltage thresholds

- Check during commissioning and adapt, if necessary.
- All drive components connected via the DC bus must have the same thresholds.
- For selection 0 ... 3, the undervoltage threshold is firmly defined depending on the device type (see "Rated data" chapter in the Hardware Manual).

**Note:** Altering this setting also has an impact on the permissible device utilisation!

In the chapter "Rated data" of the hardware manual the device types and their permissible device utilisation at a certain mains voltage and switching frequency are specified.

Selection list (Lenze setting printed in bold)	Information
0 230 V	Operation on 230 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is firmly defined.</li> <li>• Overvoltage threshold = 400 V</li> <li>• Brake chopper threshold = 390 V</li> </ul>
<b>1 400/415 V</b>	Operation on 400 V mains/415 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is firmly defined.</li> <li>• Overvoltage threshold = 800 V</li> <li>• Brake chopper threshold = 725 V</li> </ul>
2 460/480 V	Operation on 460 V mains/480 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is firmly defined.</li> <li>• Overvoltage threshold = 800 V</li> <li>• Brake chopper threshold = 765 V</li> </ul>
3 500 V	Operation on 500 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is firmly defined.</li> <li>• Overvoltage threshold = 800 V</li> <li>• Brake chopper threshold = 790 V</li> </ul>
4 230 V, LU configurable	Operation on 230 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is defined in <a href="#">C00174</a>.</li> <li>• Overvoltage threshold = 400 V</li> <li>• Brake chopper threshold = 390 V</li> </ul>
5 400/415 V, LU configurable	Operation on 400 V mains/415 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is defined in <a href="#">C00174</a>.</li> <li>• Overvoltage threshold = 800 V</li> <li>• Brake chopper threshold = 725 V</li> </ul>
6 460/480 V, LU configurable	Operation on 460 V mains/480 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is defined in <a href="#">C00174</a>.</li> <li>• Overvoltage threshold = 800 V</li> <li>• Brake chopper threshold = 765 V</li> </ul>
7 500 V, LU configurable	Operation on 500 V mains <ul style="list-style-type: none"> <li>• Undervoltage threshold is defined in <a href="#">C00174</a>.</li> <li>• Overvoltage threshold = 800 V</li> <li>• Brake chopper threshold = 790 V</li> </ul>

Read access    Write access    CINH    PLC STOP    No transfer   Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00174

C00174

Parameter   Name: <b>C00174   Undervoltage (LU) threshold</b>		Data type: UNSIGNED_32 Index: 24401 <sub>d</sub> = 5F51 <sub>h</sub>
When <a href="#">C00173</a> = 4 ... 7, the undervoltage threshold (LU) can be freely selected.		
<b>Note:</b> The minimum adjustable undervoltage threshold depends on the device type:		
<ul style="list-style-type: none"><li>• Single-axis controller (Single Drive) up to and including BF7: 210 V</li><li>• Single-axis controller (Single Drive) from BF8s: 400 V</li><li>• Multi-axis controller (Multi Drive): 15 V</li></ul>		
In the case of an offline parameter setting or when exchanging the memory module between different 9400 HighLine device types, always check the setting of this parameter and adapt it, if required, to prevent a parameter error after the parameter set download or module change!		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
15	V	400
		<b>285 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00175

Parameter   Name: <b>C00175   Service code</b>		Data type: UNSIGNED_32 Index: 24400 <sub>d</sub> = 5F50 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00176

Parameter   Name: <b>C00176   Service code</b>		Data type: UNSIGNED_32 Index: 24399 <sub>d</sub> = 5F4F <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00177

Parameter   Name: <b>C00177   Service code</b>		Data type: UNSIGNED_32 Index: 24398 <sub>d</sub> = 5F4E <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00178

Parameter   Name: <b>C00178   Elapsed hour meter</b>		Data type: UNSIGNED_32 Index: 24397 <sub>d</sub> = 5F4D <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	s	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00179

Parameter   Name: <b>C00179   Power-on time meter</b>		Data type: UNSIGNED_32 Index: 24396 <sub>d</sub> = 5F4C <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	s	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00180

Parameter   Name: <b>C00180   Service code</b>		Data type: VISIBLE_STRING Index: 24395 <sub>d</sub> = 5F4B <sub>h</sub>
For Lenze service only		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		

## C00181

Parameter   Name: <b>C00181   Red. brake chopper threshold</b>		Data type: UNSIGNED_32 Index: 24394 <sub>d</sub> = 5F4A <sub>h</sub>
<a href="#">▶ Braking operation</a>		
Setting range (min. value   unit   max. value)		Lenze setting
0	V	100
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00183

Parameter   Name: <b>C00183   Device state</b>		Data type: UNSIGNED_32 Index: 24392 <sub>d</sub> = 5F48 <sub>h</sub>
Display of the device state for diagnostic purposes		
Selection list (display only)		
0	Operation	
1	Operation/Warning active	
2	Operation/warning locked act.	
3	Operation/Quick stop active	
4	Operation/Application stopped	
10	Initialisation active	
20	System fault active	
90	Drive switched on	
91	Drive is switched on/QSP trouble	
101	Safe torque off active	
102	Fault active	
104	Trouble active	
141	Drive ready to start --&gt; C00142	
151	Quick stop by trouble active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00185

Parameter   Name: <b>C00185   Mains recov. detect. threshold</b>		Data type: UNSIGNED_32 Index: 24390 <sub>d</sub> = 5F46 <sub>h</sub>
<b>This code must not be written to by the user!</b>		
Setting range (min. value   unit   max. value)		Lenze setting
0	%	100
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00186

Parameter   Name: <b>C00186   ENP: Identified motor type</b>		Data type: VISIBLE_STRING Index: 24389 <sub>d</sub> = 5F45 <sub>h</sub>
Motor type read from the electronic nameplate (ENP)		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00187

Parameter   Name: <b>C00187   ENP: Identified serial number</b>		Data type: VISIBLE_STRING Index: 24388 <sub>d</sub> = 5F44 <sub>h</sub>
Serial number read from the electronic nameplate (ENP)		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00188

C00188

Parameter   Name: <b>C00188   ENP: Status</b>	Data type: UNSIGNED_8 Index: 24387 <sub>d</sub> = 5F43 <sub>h</sub>
<b>Selection list (display only)</b>	
0	No ENP found
1	ENP data loaded
2	Known ENP found
3	ENP found but not read
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00198

Parameter   Name: <b>C00198   Service code</b>	Data type: UNSIGNED_32 Index: 24377 <sub>d</sub> = 5F39 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00199

Parameter   Name: <b>C00199   Device name</b>	Data type: VISIBLE_STRING Index: 24376 <sub>d</sub> = 5F38 <sub>h</sub>
Device name to be defined by the user (e.g. "Cross cutter" or "hoist axis 1") with max. 128 characters	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00200

Parameter   Name: <b>C00200   Firmware product type</b>	Data type: VISIBLE_STRING Index: 24375 <sub>d</sub> = 5F37 <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00201

Parameter   Name: <b>C00201   Firmware - compiling date</b>	Data type: VISIBLE_STRING Index: 24374 <sub>d</sub> = 5F36 <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00202

Parameter   Name: <b>C00202   Autom. ENP data transfer</b>	Data type: UNSIGNED_32 Index: 24373 <sub>d</sub> = 5F35 <sub>h</sub>
From software version V1.5	
<b>Selection list (Lenze setting printed in bold)</b>	
0	Off
1	<b>ON</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00203

Parameter   Name: <b>C00203   HW product types</b>	Data type: VISIBLE_STRING Index: 24372 <sub>d</sub> = 5F34 <sub>h</sub>
<b>Subcodes</b>	<b>Information</b>
C00203/1	Type: Control card
C00203/2	Type: Power section
C00203/3	Type: Module in MXI1
C00203/4	Type: Module in MXI2
C00203/5	Type: Memory module
C00203/6	Type: Safety module
C00203/7	Type: Standard device
C00203/8	Type: Complete device
C00203/9	Type: ENP
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	



## C00204

Parameter   Name: <b>C00204   HW serial numbers</b>		Data type: VISIBLE_STRING Index: 24371 <sub>d</sub> = 5F33 <sub>h</sub>
Subcodes	Information	
C00204/1	Serial no.: Control card	
C00204/2	Serial no.: Power section	
C00204/3	Serial no.: Module in MXI1	
C00204/4	Serial no.: Module in MXI2	
C00204/5	Serial no.: Memory module	
C00204/6	Serial no.: Safety module	
C00204/7	Serial no.: Standard device	
C00204/8	Serial no.: Complete device	
C00204/9	Serial no.: ENP	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00205

Parameter   Name: <b>C00205   HW descriptions</b>		Data type: VISIBLE_STRING Index: 24370 <sub>d</sub> = 5F32 <sub>h</sub>
Subcodes	Information	
C00205/1	Info: Control card	
C00205/2	Info: Power section	
C00205/3	Info: Module in MXI1	
C00205/4	Info: Module in MXI2	
C00205/5	Info: Memory module	
C00205/6	Info: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00206

Parameter   Name: <b>C00206   HW manufacturing data</b>		Data type: VISIBLE_STRING Index: 24369 <sub>d</sub> = 5F31 <sub>h</sub>
Subcodes	Information	
C00206/1	Date: Control card	
C00206/2	Date: Power section	
C00206/3	Date: Module in MXI1	
C00206/4	Date: Module in MXI2	
C00206/5	Date: Memory module	
C00206/6	Date: Safety module	
C00206/7	Date: Standard device	
C00206/8	Date: Complete device	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00208

## C00208

Parameter   Name: <b>C00208   HW manufacturer</b>		Data type: VISIBLE_STRING Index: 24367 <sub>d</sub> = 5F2F <sub>h</sub>
Subcodes	Information	
C00208/1	Manufacturer: Control card	
C00208/2	Manufacturer: Power section	
C00208/3	Manufacturer: Module in MXI1	
C00208/4	Manufacturer: Module in MXI2	
C00208/5	Manufacturer: Memory module	
C00208/6	Manufacturer: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00209

Parameter   Name: <b>C00209   HW countries of origin</b>		Data type: VISIBLE_STRING Index: 24366 <sub>d</sub> = 5F2E <sub>h</sub>
Subcodes	Information	
C00209/1	Country: Control card	
C00209/2	Country: Power section	
C00209/3	Country: Module in MXI1	
C00209/4	Country: Module in MXI2	
C00209/5	Country: Memory module	
C00209/6	Country: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00210

Parameter   Name: <b>C00210   HW versions</b>		Data type: VISIBLE_STRING Index: 24365 <sub>d</sub> = 5F2D <sub>h</sub>
Subcodes	Information	
C00210/1	HW version: Control card	
C00210/2	HW version: Power section	
C00210/3	HW version: Module in MXI1	
C00210/4	HW version: Module in MXI2	
C00210/5	HW version: Memory module	
C00210/6	HW version: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00211

Parameter   Name: <b>C00211   Application: Version</b>		Data type: VISIBLE_STRING Index: 24364 <sub>d</sub> = 5F2C <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00212

Parameter   Name: <b>C00212   Application: Type code</b>		Data type: VISIBLE_STRING Index: 24363 <sub>d</sub> = 5F2B <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00213

Parameter   Name: <b>C00213   Application: Compiler date</b>		Data type: VISIBLE_STRING Index: 24362 <sub>d</sub> = 5F2A <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00214

Parameter   Name: <b>C00214   Required safety module</b>	Data type: UNSIGNED_8 Index: 24361 <sub>d</sub> = 5F29 <sub>h</sub>
Setting of the expected safety module	
<ul style="list-style-type: none"> <li>If a different safety module is detected, a fault (trouble) will be activated. The fault can only be reset by mains switching.</li> </ul>	
<b>Selection list</b> (Lenze setting printed in bold)	
1	<b>SM0</b>
2	SM100
4	SM300
5	SM301
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00217

Parameter   Name: <b>C00217   Parameter error information</b>	Data type: UNSIGNED_32 Index: 24358 <sub>d</sub> = 5F26 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

## C00218

Parameter   Name: <b>C00218   Application: ID number</b>	Data type: UNSIGNED_32 Index: 24357 <sub>d</sub> = 5F25 <sub>h</sub>
<b>Display range</b> (min. value   unit   max. value)	
0	0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00219

Parameter   Name: <b>C00219   CAN/EPL device type</b>	Data type: UNSIGNED_32 Index: 24356 <sub>d</sub> = 5F24 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

## C00225

Parameter   Name: <b>C00225   Check configuration</b>	Data type: UNSIGNED_32 Index: 24350 <sub>d</sub> = 5F1E <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

## C00227

Parameter   Name: <b>C00227   Behaviour due to change of parameter set</b>	Data type: UNSIGNED_32 Index: 24348 <sub>d</sub> = 5F1C <sub>h</sub>	
<a href="#">From software version V5.0</a>		
By selecting "1" in the corresponding subcode a module plugged into module slot MXI1 or MXI2 can be excepted from the parameter set changeover via the device command "Activate parameter set n".		
<ul style="list-style-type: none"> <li>By this the parameter set changeover, in particular for active modules, is carried out much more quickly.</li> <li>An exception from the parameter set changeover for instance is reasonable if different parameter sets are used (e. g. for different tools within the machine), but if the parameters are always the same for the module (e. g. communication parameters).</li> </ul>		
<b>Selection list</b> (Lenze setting printed in bold)		
0	Included	
1	Excluded	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00227/1	0: Included	Change of parameter set: MXI1
C00227/2	0: Included	Change of parameter set: MXI2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00254

C00254

Parameter   Name: <b>C00254   Phase controller gain</b>		Data type: UNSIGNED_32 Index: 24321 <sub>d</sub> = 5F01 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	1/s	1000.00
		<b>20.00 1/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00270

Parameter   Name: <b>C00270   Freq. - current setpoint filter</b>		Data type: UNSIGNED_32 Index: 24305 <sub>d</sub> = 5EF1 <sub>h</sub>
<a href="#">▶ Set current setpoint filter (band-stop filter)</a>		
<b>Setting range (min. value   unit   max. value)</b>		
1.0	Hz	1000.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00270/1	200.0 Hz	Freq. - current setp. filter 1
C00270/2	400.0 Hz	Freq. - current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00271

Parameter   Name: <b>C00271   Width - current setp. filter</b>		Data type: UNSIGNED_32 Index: 24304 <sub>d</sub> = 5EF0 <sub>h</sub>
<a href="#">▶ Set current setpoint filter (band-stop filter)</a>		
<b>Setting range (min. value   unit   max. value)</b>		
0.0	Hz	500.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00271/1	20.0 Hz	Width current setp. filter 1
C00271/2	40.0 Hz	Width current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00272

Parameter   Name: <b>C00272   Depth - current setp. filter</b>		Data type: UNSIGNED_32 Index: 24303 <sub>d</sub> = 5EF <sub>h</sub>
The setting "0 dB" deactivates the current setpoint filter.		
<a href="#">▶ Set current setpoint filter (band-stop filter)</a>		
<b>Setting range (min. value   unit   max. value)</b>		
0	db	100
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00272/1	0 db	Depth current setp. filter 1
C00272/2	0 db	Depth current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00273

Parameter   Name: <b>C00273   Moment of inertia</b>		Data type: UNSIGNED_32 Index: 24302 <sub>d</sub> = 5EE <sub>h</sub>
<b>Note:</b> The load moment of inertia must be set with regard to the motor end (i.e. considering the gearbox factors).		
<b>Setting range (min. value   unit   max. value)</b>		
0.00	kg cm <sup>2</sup>	20000000.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00273/1	0.14 kg cm <sup>2</sup>	Motor moment of inertia
C00273/2	0.00 kg cm <sup>2</sup>	Load moment of inertia
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C00274

Parameter   Name: <b>C00274   Max. acceleration change</b>		Data type: UNSIGNED_32 Index: 24301 <sub>d</sub> = 5EE <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0	%/ms	400.0 <b>400.0 %/ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C00275

Parameter   Name: <b>C00275   Signal source - speed setpoint</b>		Data type: UNSIGNED_16 Index: 24300 <sub>d</sub> = 5EE <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>SpeedAdd signal</b>	
1	Differentiated PosSet signal	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00276

Parameter   Name: <b>C00276   Signal source - torque setpoint</b>		Data type: UNSIGNED_16 Index: 24299 <sub>d</sub> = 5EE <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		<b>Information</b>
<b>0</b>	<b>TorqueAdd/AccAdd signal</b>	
1	Differentiated SpeedSet signal	
2	2x diff. PosSet signal	
3	Differentiated SpeedAdd signal	<p><a href="#">From software version V5.0</a></p> <p>This alternative selection to the differentiated SpeedSet signal is recommended if the position controller works with a high gain.</p> <p>By the position controller also troubles within to the actual position value are detected and like this reach the speed setpoint. In the following differentiation of the feedforward control, these troubles in particular in the case of high position controller gains result in a very unsettled torque feedforward control value. By means of this selection the problem can be avoided, because then only the trouble-free speed feedforward control value is differentiated.</p>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00280

Parameter   Name: <b>C00280   Filter time const. DC detection</b>		Data type: UNSIGNED_32 Index: 24295 <sub>d</sub> = 5EE <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1.0	ms	1000.0 <b>25.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00281

C00281

Parameter   Name: <b>C00281   Filter for PWM adjustment</b>	Data type: UNSIGNED_8 Index: 24294 <sub>d</sub> = 5EE6 <sub>h</sub>
<b>From software version V7.0</b>	
<p>The output voltage of the inverter is generated from the DC-bus voltage by a pulse width modulation (PWM). The product from the DC-bus voltage and the control factor of the PWM corresponds to the height of the output voltage. If the DC-bus voltage changes due to mains fluctuations or load changes, the control factor of the PWM must be adapted if the output voltage is to remain constant. This correction is carried out in the control software by measuring the DC-bus voltage. In order that no response takes place to faults in the DC-bus voltage measurement, a filter can be activated for the measured signal via this parameter.</p> <ul style="list-style-type: none"> <li>• The filter time constant is selected so that a quick correction can be carried out even under bad EMC conditions.</li> <li>• A disadvantage of this filter is that the responses to real flickers on the DC-bus voltage are too slow. In positioning tasks, this may cause an extreme increase of the following error.</li> <li>• Under good EMC conditions, this filter is not required (Lenze setting).</li> <li>• For devices &gt; BF7 the filter is ineffective.</li> </ul>	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Deactivated</b>
1	Activated
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00308

Parameter   Name: <b>C00308   Service code</b>	Data type: UNSIGNED_16 Index: 24267 <sub>d</sub> = 5ECB <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00309

Parameter   Name: <b>C00309   Service code</b>	Data type: UNSIGNED_32 Index: 24266 <sub>d</sub> = 5ECA <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00310

Parameter   Name: <b>C00310   Service code</b>	Data type: UNSIGNED_8 Index: 24265 <sub>d</sub> = 5EC9 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00311

Parameter   Name: <b>C00311   CAN TPDO1 mask byte x</b>	Data type: BITFIELD_8 Index: 24264 <sub>d</sub> = 5EC8 <sub>h</sub>	
<p>A mask can be parameterised for each byte of the TPDO1 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte actuates the transmission.</li> <li>• Mask "0xff" means that every bit of the corresponding byte can actuate the transmission.</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>		
<b>Setting range</b>		
0x00	0xFF	
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00311/1	0x00	Mask for byte 1 ... byte 8 of TPDO1
C00311/...		
C00311/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00312

Parameter   Name: <b>C00312   CAN TPDO2 mask byte x</b>		Data type: BITFIELD_8 Index: 24263 <sub>d</sub> = 5EC7 <sub>h</sub>
<p>A mask can be parameterised for each byte of the TPDO2 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte actuates the transmission.</li> <li>• Mask "0xff" means that every bit of the corresponding byte can actuate the transmission.</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>		
<b>Setting range</b>		
0x00		0xFF
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00312/1	0x00	Mask for byte 1 ... byte 8 of TPDO2
C00312/...		
C00312/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00313

Parameter   Name: <b>C00313   CAN TPDO3 mask byte x</b>		Data type: BITFIELD_8 Index: 24262 <sub>d</sub> = 5EC6 <sub>h</sub>
<p>A mask can be parameterised for each byte of the TPDO3 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte actuates the transmission.</li> <li>• Mask "0xff" means that every bit of the corresponding byte can actuate the transmission.</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>		
<b>Setting range</b>		
0x00		0xFF
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00313/1	0x00	Mask for byte 1 ... byte 8 of TPDO3
C00313/...		
C00313/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00314

## C00314

Parameter   Name: <b>C00314   CAN TPDO4 mask byte x</b>		Data type: BITFIELD_8 Index: 24261 <sub>d</sub> = 5EC5 <sub>h</sub>
<p>A mask can be parameterised for each byte of the TPDO4 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>Mask "0x0" means that no bit of the corresponding byte actuates the transmission.</li> <li>Mask "0xff" means that every bit of the corresponding byte can actuate the transmission.</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>		
<b>Setting range</b>		
0x00		0xFF
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00314/1	0x00	Mask for byte 1 ... byte 8 of TPDO4
C00314/...		
C00314/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00320

Parameter   Name: <b>C00320   CAN TPDOx identifier</b>		Data type: BITFIELD_32 Index: 24255 <sub>d</sub> = 5EBF <sub>h</sub>
<p>Identifier for TPDO1 ... TPDO4</p> <ul style="list-style-type: none"> <li>If bit 31 is set (0x8nnnnnnn), the TPDO is deactivated.</li> <li>The basic setting is according to the "Predefined Connection Set".</li> <li>Mapping of the CANopen objects <a href="#">I-1800/1</a> ... <a href="#">I-1803/1</a> (see DS301 V4.02).</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>		
<b>Setting range</b>		
0x00000000		0xFFFFFFFF
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>Bit 0 ... 10: COB-ID</li> <li>Bit 11 ... 30: Reserved</li> <li>Bit 31: PDO invalid</li> </ul>
...	...	
Bit 31	PDO invalid	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00320/1	0x00000181	Identifier TPDO1 <ul style="list-style-type: none"> <li>After a node address change and CAN reset node, the value 0x180 + node address will be set by default.</li> </ul>
C00320/2	0x00000281	Identifier TPDO2 <ul style="list-style-type: none"> <li>After a node address change and CAN reset node, the value 0x280 + node address will be set by default.</li> </ul>
C00320/3	0x00000381	Identifier TPDO3 <ul style="list-style-type: none"> <li>After a node address change and CAN reset node, the value 0x380 + node address will be set by default.</li> </ul>
C00320/4	0x00000481	Identifier TPDO4 <ul style="list-style-type: none"> <li>After a node address change and CAN reset node, the value 0x480 + node address will be set by default.</li> </ul>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



## C00321

Parameter   Name: <b>C00321   CAN RPDOx identifier</b>		Data type: BITFIELD_32 Index: 24254 <sub>d</sub> = 5EBE <sub>h</sub>
Identifier for RPDO1 ... RPDO4		
<ul style="list-style-type: none"> <li>• If bit 31 is set (0x8nnnnnnn), the RPDO is deactivated.</li> <li>• The basic setting is according to the "Predefined Connection Set".</li> <li>• Mapping of the CANopen objects <a href="#">I-1400/1</a> ... <a href="#">I-1403/1</a> (see DS301 V4.02).</li> </ul>		
<a href="#">▶ "CAN on board" system bus</a>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Information
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: PDO invalid</li> </ul>
...	...	
Bit 31	PDO invalid	
Subcodes	Lenze setting	Information
C00321/1	0x00000201	Identifier RPDO1 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x200 + node address will be set by default.</li> </ul>
C00321/2	0x00000301	Identifier RPDO2 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x300 + node address will be set by default.</li> </ul>
C00321/3	0x00000401	Identifier RPDO3 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x400 + node address will be set by default.</li> </ul>
C00321/4	0x00000501	Identifier RPDO4 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x500 + node address will be set by default.</li> </ul>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00322

Parameter   Name: <b>C00322   CAN TPDOx Tx mode</b>		Data type: UNSIGNED_8 Index: 24253 <sub>d</sub> = 5EBD <sub>h</sub>
TPDO transmission type according to DS301 V4.02		
<ul style="list-style-type: none"> <li>• Types 0 (acyclic sync), 1-240 (cyclic sync), 254 (event-controlled manufacturer-specific), 255 (event-controlled device-profile-specific) are supported.</li> <li>• The basic PDO setting is "254" (event-controlled).</li> <li>• Mapping of the CANopen objects <a href="#">I-1800/2</a> ... <a href="#">I-1803/2</a> (see DS301 V4.02).</li> </ul>		
<a href="#">▶ "CAN on board" system bus</a>		
Setting range (min. value   unit   max. value)		
0		255
Subcodes	Lenze setting	Information
C00322/1	254	Transmission mode for TPDO1 ... TPDO4
C00322/...		
C00322/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00323

C00323

Parameter | Name: **C00323 | CAN RPDOx Rx mode** Data type: UNSIGNED\_8  
Index: 24252<sub>d</sub> = 5EBCh

RPDO Transmission type according to DS301 V4.02

- For the RPDO serves as monitoring setting in the case of sync-controlled PDOs.
- Types 0 (acyclic sync), 1-240 (cyclic sync), 254 (event-controlled manufacturer-specific), 255 (event-controlled device-profile-specific) are supported.
- The basic PDO setting is "254" (event-controlled).
- Mapping of the CANopen objects [I-1400/2](#) ... [I-1403/2](#) (see DS301 V4.02).

[▶ "CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		
0		255
Subcodes	Lenze setting	Information
C00323/1	254	Transmission mode for RPDO1 ... RPDO4
C00323/...		
C00323/4		

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C00324

Parameter | Name: **C00324 | CAN TPDOx delay time** Data type: UNSIGNED\_16  
Index: 24251<sub>d</sub> = 5EBBh

TPDO inhibit time according to DS301 V4.02

- Minimum time between the transmission of two identical TPDOs.
- The delay time is entered in 1/10 ms and automatically rounded to full milliseconds by the code.
- Mapping of the CANopen objects [I-1800/3](#) ... [I-1803/3](#) (see DS301 V4.02).

[▶ "CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		
0	1/10 ms	65535
Subcodes	Lenze setting	Information
C00324/1	0 1/10 ms	Delay time for TPDO1 ... TPDO4
C00324/...		
C00324/4		

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C00325

Parameter | Name: **C00325 | Service code** Data type: UNSIGNED\_8  
Index: 24250<sub>d</sub> = 5EBAh

**This code is used internally by the controller and must not be overwritten by the user!**

C00326

Parameter | Name: **C00326 | Service code** Data type: UNSIGNED\_8  
Index: 24249<sub>d</sub> = 5EB9h

**This code is used internally by the controller and must not be overwritten by the user!**

C00327

Parameter | Name: **C00327 | Service code** Data type: BITFIELD\_32  
Index: 24248<sub>d</sub> = 5EB8h

**This code is used internally by the controller and must not be overwritten by the user!**

C00328

Parameter | Name: **C00328 | Service code** Data type: BITFIELD\_32  
Index: 24247<sub>d</sub> = 5EB7h

**This code is used internally by the controller and must not be overwritten by the user!**

C00329

Parameter | Name: **C00329 | Service code** Data type: BITFIELD\_32  
Index: 24246<sub>d</sub> = 5EB6<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00330

Parameter | Name: **C00330 | Service code** Data type: BITFIELD\_32  
Index: 24245<sub>d</sub> = 5EB5<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00335

Parameter | Name: **C00335 | Service code** Data type: BITFIELD\_32  
Index: 24240<sub>d</sub> = 5EB0<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00336

Parameter | Name: **C00336 | Service code** Data type: BITFIELD\_32  
Index: 24239<sub>d</sub> = 5EAF<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00337

Parameter | Name: **C00337 | Service code** Data type: BITFIELD\_32  
Index: 24238<sub>d</sub> = 5EAE<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00338

Parameter | Name: **C00338 | Service code** Data type: BITFIELD\_32  
Index: 24237<sub>d</sub> = 5EAD<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00343

Parameter | Name: **C00343 | CAN TPDO counter** Data type: UNSIGNED\_32  
Index: 24232<sub>d</sub> = 5EA8<sub>h</sub>

**Display range (min. value | unit | max. value)**  
0 | | 4294967295

Subcodes	Information
C00343/1	From software version V1.5
C00343/...	Counter for TPDO1 ... TPDO4
C00343/4	▶ <a href="#">"CAN on board" system bus</a>

Read access  Write access  CINH  PLC STOP  No transfer      Scaling factor: 1

C00344

Parameter | Name: **C00344 | CAN RPDO counter** Data type: UNSIGNED\_32  
Index: 24231<sub>d</sub> = 5EA7<sub>h</sub>

**Display range (min. value | unit | max. value)**  
0 | | 4294967295

Subcodes	Information
C00344/1	From software version V1.5
C00344/...	Counter for RPDO1 ... RPDO4
C00344/4	▶ <a href="#">"CAN on board" system bus</a>

Read access  Write access  CINH  PLC STOP  No transfer      Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00345

C00345

Parameter   Name: <b>C00345   CAN error</b>	Data type: UNSIGNED_8 Index: 24230 <sub>d</sub> = 5EA6 <sub>h</sub>
<a href="#">▶ "CAN on board" system bus</a>	
<b>Selection list (display only)</b>	
0	No error
1	Guard Event
2	Warning
3	Bus off
4	Sync telegram error
6	CAN controller overflow
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00346

Parameter   Name: <b>C00346   CAN heartbeat activity</b>	Data type: BITFIELD_32 Index: 24229 <sub>d</sub> = 5EA5 <sub>h</sub>
<a href="#">▶ "CAN on board" system bus: heartbeat protocol</a>	
<b>Display area</b>	
0x00000000	0xFFFFFFFF
<b>Value is bit-coded:</b>	
Bit 0	Heartbeat node 1
...	...
Bit 31	Heartbeat node 32
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00347

Parameter   Name: <b>C00347   CAN heartbeat status</b>	Data type: UNSIGNED_8 Index: 24228 <sub>d</sub> = 5EA4 <sub>h</sub>
<a href="#">▶ "CAN on board" system bus: heartbeat protocol</a>	
<b>Selection list (display only)</b>	
0	Unknown
4	Stopped
5	Operational
127	Pre-operational
<b>Subcodes</b>	<b>Information</b>
C00347/1	Status node 1 ... 32
C00347/...	
C00347/32	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00348

Parameter   Name: <b>C00348   CAN status DIP switch</b>	Data type: UNSIGNED_8 Index: 24227 <sub>d</sub> = 5EA3 <sub>h</sub>
<ul style="list-style-type: none"> <li>"1" means that the CAN DIP switch has been identified after mains switching and a valid baud rate and node address have been set.</li> <li>"0" means that no CAN DIP switch or no valid setting has been identified or the setting has been overwritten by writing to code <a href="#">C00350</a> or <a href="#">C00351</a>.</li> </ul>	
<a href="#">▶ "CAN on board" system bus</a>	
<b>Selection list (display only)</b>	
0	Setting not accepted
1	Setting accepted
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00349

Parameter | Name: **C00349 | CAN setting of DIP switch** Data type: UNSIGNED\_8  
Index: 24226<sub>d</sub> = 5EA2<sub>h</sub>

Setting of the CAN DIP switch at the last mains connection

[▶ "CAN on board" system bus](#)

Display range (min. value   unit   max. value)	
0	255
Subcodes	Information
C00349/1	Node address
C00349/2	Baud rate: 0: 500 kbps 1: 250 kbps 2: 125 kbps 3: 50 kbps 4: 1 Mbps 5: 20 kbps 6: 10 kbit/s 14: 800 kbps 255: Automatic recognition
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00350

Parameter | Name: **C00350 | CAN node address** Data type: UNSIGNED\_8  
Index: 24225<sub>d</sub> = 5EA1<sub>h</sub>

- A change of the node address only gets active after a CAN reset node.
- The basic server channel RX/TX is automatically provided by the node address ([C00372](#) and [C00373](#); subcode 1).
- Overwriting the value deactivates a possibly existing node address selection entered by means of hardware.

[▶ "CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		Lenze setting
1	127	<b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00351

## C00351

Parameter   Name: <b>C00351   CAN baud rate</b>	Data type: UNSIGNED_8 Index: 24224 <sub>d</sub> = 5EA0 <sub>h</sub>
<ul style="list-style-type: none"> <li>A change of the baud rate only gets active after a CAN reset node.</li> <li>Overwriting the value deactivates a possibly existing node address selection entered by means of hardware.</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>	
<b>Selection list (Lenze setting printed in bold)</b>	
0	<b>500 kbps</b>
1	250 kbps
2	125 kbps
3	50 kbps
4	1 Mbps
5	20 kbps
6	10 kbps
8	Reserved
9	Reserved
10	Reserved
11	Reserved
12	Reserved
13	Reserved
14	800 kbps
15	Reserved
255	Automatic recognition
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00352

Parameter   Name: <b>C00352   CAN slave/master</b>	Data type: UNSIGNED_8 Index: 24223 <sub>d</sub> = 5E9F <sub>h</sub>
<p>If "1" is entered and saved, the drive will start as CAN master after mains switching.</p> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>	
<b>Selection list (Lenze setting printed in bold)</b>	
0	<b>Slave</b>
1	Master
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00356

Parameter   Name: <b>C00356   CAN TPDOx cycle time</b>	Data type: UNSIGNED_16 Index: 24219 <sub>d</sub> = 5E9B <sub>h</sub>
<p>TPDO event time according to DS301 V4.02</p> <ul style="list-style-type: none"> <li>If the value is entered that is not "0", the TPDO is transmitted without further consideration of the transport type after the set time has elapsed.</li> <li>Mapping of the CANopen objects <a href="#">I-1800/5</a> ... <a href="#">I-1803/5</a> (see DS301 V4.02).</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus</a></p>	
<b>Setting range (min. value   unit   max. value)</b>	
0	ms      65535
<b>Subcodes</b>	<b>Lenze setting      Information</b>
C00356/1	0 ms      Cycle time for TPDO1 ... TPDO4
C00356/...	
C00356/4	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00357

Parameter | Name: **C00357 | CAN RPDOx monitoring time** Data type: UNSIGNED\_16  
Index: 24218<sub>d</sub> = 5E9A<sub>h</sub>

Mapping of the RPDO event time (see DS301 V4.02)

- If a value is entered that is not "0", the RPDO is expected after the time set has elapsed.
- If the RPDO is not received within this time, a parameterisable error message can be activated.

▶ ["CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		
0	ms	65535
Subcodes	Lenze setting	Information
C00357/1	3000 ms	Monitoring time for RPDO1 ... RPDO4
C00357/...		
C00357/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <span style="float: right;">Scaling factor: 1</span>		

## C00359

Parameter | Name: **C00359 | CAN status** Data type: UNSIGNED\_8  
Index: 24216<sub>d</sub> = 5E98<sub>h</sub>

▶ ["CAN on board" system bus](#)

Selection list (display only)	
0	Operational
1	Pre-operational
4	Boot up
5	Stopped
7	Reset
8	Initialisation
9	Unknown
10	Baud rate autom. detected
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <span style="float: right;">Scaling factor: 1</span>	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00360

## C00360

Parameter | Name: **C00360 | CAN telegram and error counter** Data type: UNSIGNED\_16  
Index: 24215<sub>d</sub> = 5E97<sub>h</sub>

- After mains connection all counters start with "0".
- After the maximum value has been reached, counting restarts with "0".

▶ ["CAN on board" system bus](#)

Display range (min. value   unit   max. value)		
0		65535
Subcodes	Information	
C00360/1	Stuffing bit error counter • More than five identical bits have been detected.	
C00360/2	Format error counter • CAN frame has not been observed.	
C00360/3	Acknowledge error counter • No device has acknowledged the telegram.	
C00360/4	Bit1 error counter • "1" should be sent after bus arbitration, but "0" was read.	
C00360/5	Bit0 error counter • "0" should be sent after bus arbitration, but "1" was read.	
C00360/6	CRC error counter • Checksum check has indicated an error.	
C00360/7	Tx telegram counter • Correctly received telegrams.	
C00360/8	Rx telegram counters • Correctly transmitted telegrams.	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00361

Parameter | Name: **C00361 | CAN bus load** Data type: UNSIGNED\_32  
Index: 24214<sub>d</sub> = 5E96<sub>h</sub>

The display of the node peak load (subcodes 4 ... 6) is reset by repeated mains switching or via the "Reset node" device command ([C00002](#)).

▶ ["CAN on board" system bus](#)

Display range (min. value   unit   max. value)		
0	%	100
Subcodes	Information	
C00361/1	Current node load in Tx direction	
C00361/2	Current node load in Rx direction	
C00361/3	Current node load through faulty telegrams	
C00361/4	Maximum node load in Tx direction	
C00361/5	Maximum node load in Rx direction	
C00361/6	Maximum node load through faulty telegrams	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		



## C00367

Parameter   Name: <b>C00367   CAN SYNC Rx identifier</b>	Data type: UNSIGNED_32 Index: 24208 <sub>d</sub> = 5E90 <sub>h</sub>
Identifier with which the sync slave is to receive sync telegrams. <ul style="list-style-type: none"> <li>• Mapping of the CANopen object <a href="#">I-1005</a> (see DS301 V4.02).</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus: sync telegram</a></p>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
0     2047	<b>128</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00368

Parameter   Name: <b>C00368   CAN SYNC Tx identifier</b>	Data type: UNSIGNED_32 Index: 24207 <sub>d</sub> = 5E8F <sub>h</sub>
Identifier with which the sync master is to send sync telegrams. <ul style="list-style-type: none"> <li>• Mapping of the CANopen object <a href="#">I-1005</a> (see DS301 V4.02).</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus: sync telegram</a></p>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
0     2047	<b>128</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00369

Parameter   Name: <b>C00369   CAN SYNC transmit cycle time</b>	Data type: UNSIGNED_16 Index: 24206 <sub>d</sub> = 5E8E <sub>h</sub>	
Cycle within which the sync master is to send sync telegrams. <ul style="list-style-type: none"> <li>• With "0 ms" (Lenze setting), no sync telegrams are created.</li> <li>• Mapping of the CANopen object <a href="#">I-1006</a> (see DS301 V4.02).</li> </ul> <p style="text-align: right;"><a href="#">▶ "CAN on board" system bus: sync telegram</a></p>		
<b>Setting range (min. value   unit   max. value)</b>		
0   ms   65535		
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00369/1	0 ms	Transmission cycle time for CAN on board
C00369/2	0 ms	Transmission cycle time for CAN module in MXI1/MXI2
C00369/3	0 ms	- (no meaning)
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00372

C00372

Parameter   Name: <b>C00372   CAN SDO server Rx identifier</b>		Data type: BITFIELD_32 Index: 24203 <sub>d</sub> = 5E8B <sub>h</sub>
Identifier which serves to reach the assigned SDO server.		
<ul style="list-style-type: none"> <li>• If bit 31 is set (0x8nnnnnnn), the corresponding SDO server is deactivated.</li> <li>• Mapping of the CANopen objects <a href="#">I-1200/1</a> ... <a href="#">I-1209/1</a> (see DS301 V4.02).</li> </ul>		
<a href="#">▶ "CAN on board" system bus</a>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Information
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Information
C00372/1	0x00000601	SDO server channel 1 RX <ul style="list-style-type: none"> <li>• Subcode 1 contains the basic SDO channel which can neither be changed nor deactivated, according to DS301 V4.02. Writing to the subcode has no effect.</li> <li>• The value under subcode 1 results from the node address (<a href="#">C00350</a>) + 0x600.</li> </ul>
C00372/2	0x80000000	SDO server channel 2 RX
C00372/3	0x80000000	SDO server channel 3 RX
C00372/4	0x80000000	SDO server channel 4 RX
C00372/5	0x80000000	SDO server channel 5 RX
C00372/6	0x80000000	SDO server channel 6 RX
C00372/7	0x80000000	SDO server channel 7 RX
C00372/8	0x80000000	SDO server channel 8 RX
C00372/9	0x80000000	SDO server channel 9 RX
C00372/10	0x80000000	SDO server channel 10 RX
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00373

Parameter | Name: **C00373 | CAN SDO server Tx identifier** Data type: BITFIELD\_32  
Index: 24202<sub>d</sub> = 5E8A<sub>h</sub>

Identifier with which the assigned SDO server is able to transmit.

- If bit 31 is set (0x8nnnnnnn), the corresponding SDO server is deactivated.
- Mapping of the CANopen objects [I-1200/2](#) ... [I-1209/2](#) (see DS301 V4.02).

▶ ["CAN on board" system bus](#)

Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Information
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Information
C00373/1	0x00000581	SDO server channel 1 TX <ul style="list-style-type: none"> <li>• Subcode 1 contains the basic SDO channel which can neither be changed nor deactivated, according to DS301 V4.02. Writing to the subcode has no effect.</li> <li>• The value under subcode 1 results from the node address (<a href="#">C00350</a>) + 0x580.</li> </ul>
C00373/2	0x80000000	SDO server channel 2 TX
C00373/3	0x80000000	SDO server channel 3 TX
C00373/4	0x80000000	SDO server channel 4 TX
C00373/5	0x80000000	SDO server channel 5 TX
C00373/6	0x80000000	SDO server channel 6 TX
C00373/7	0x80000000	SDO server channel 7 TX
C00373/8	0x80000000	SDO server channel 8 TX
C00373/9	0x80000000	SDO server channel 9 TX
C00373/10	0x80000000	SDO server channel 10 TX
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00374

## C00374

Parameter | Name: **C00374 | CAN SDO client node address** Data type: UNSIGNED\_8  
Index: 24201<sub>d</sub> = 5E89<sub>h</sub>

Node address of the client assigned to this server (see DS301 V4.02). [▶ "CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		
1		127
Subcodes	Lenze setting	Information
C00374/1	1	SDO server channel 1 remote client node address <ul style="list-style-type: none"> <li>• Subcode 1 contains the basic SDO channel which, according to DS301 V4.02, does not feature this entry. Writing to the subcode has no effect.</li> <li>• The value of subindex 1 results in 0.</li> </ul>
C00374/2	1	SDO server channel 2 remote client node address
C00374/3	1	SDO server channel 3 remote client node address
C00374/4	1	SDO server channel 4 remote client node address
C00374/5	1	SDO server channel 5 remote client node address
C00374/6	1	SDO server channel 6 remote client node address
C00374/7	1	SDO server channel 7 remote client node address
C00374/8	1	SDO server channel 8 remote client node address
C00374/9	1	SDO server channel 9 remote client node address
C00374/10	1	SDO server channel 10 remote client node address

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00375

Parameter | Name: **C00375 | CAN SDO client Rx identifier** Data type: BITFIELD\_32  
Index: 24200<sub>d</sub> = 5E88<sub>h</sub>

Identifier which serves to reach the assigned SDO client.

- If bit 31 is set (0x8nnnnnnn), the corresponding SDO client channel is deactivated (see DS301 V4.02).
- The client channels need not be parameterised right now. Their functionality will only be required when using the gateway services.

[▶ "CAN on board" system bus](#)

Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Information
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Information
C00375/1	0x80000000	SDO client channel 1 RX ... 10 RX
C00375/...		
C00375/10		

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00376

Parameter | Name: **C00376 | CAN SDO client Tx identifier** Data type: BITFIELD\_32  
Index: 24199<sub>d</sub> = 5E87<sub>h</sub>

Identifier with which the assigned SDO client is able to transmit.

- If bit 31 is set (0x8nnnnnnn), the corresponding SDO client channel is deactivated (see DS301 V4.02).
- The client channels need not be parameterised right now. Their functionality will only be required when using the gateway services.

► ["CAN on board" system bus](#)

Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Information
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Information
C00376/1	0x80000000	SDO client channel 1 TX ... 10 TX
C00376/...		
C00376/10		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00377

Parameter | Name: **C00377 | CAN SDO server node address** Data type: UNSIGNED\_8  
Index: 24198<sub>d</sub> = 5E86<sub>h</sub>

Node address of the server with which the SDO client communicates via the selected client channel.

- The client functionality need not be activated.
- The entry is required so that the CAN-SDO client channel can be activated (see DS301 V4.02).

► ["CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		
1		127
Subcodes	Lenze setting	Information
C00377/1	1	Remote server node address for SDO client channel 1 ... 10
C00377/...		
C00377/10		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00378

Parameter | Name: **C00378 | CAN delay boot-up - Operational** Data type: UNSIGNED\_16  
Index: 24197<sub>d</sub> = 5E85<sub>h</sub>

Time that has to elapse after mains switching before the CAN NMT master places the "Start Remote Node" telegram to the bus.

- This time is only used if the master bit is activated ([C00352](#)) and after mains switching.

► ["CAN on board" system bus](#)

Setting range (min. value   unit   max. value)		Lenze setting
0	ms	65535 <b>3000 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00379

Parameter | Name: **C00379 | Service code** Data type: UNSIGNED\_8  
Index: 24196<sub>d</sub> = 5E84<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00381

## C00381

Parameter | Name: **C00381 | CAN Heartbeat Producer Time** Data type: UNSIGNED\_16  
Index: 24194<sub>d</sub> = 5E82<sub>h</sub>

Time interval for the transmission of the heartbeat telegram to one or several consumers.

- The parameterised time is rounded down to an integer multiple of 5 ms.
- The heartbeat telegram is transmitted automatically as soon as a time > 0 ms is set. The monitoring function "Node Guarding" is deactivated in this case.
- Mapping of the CANopen object [I-1017](#) (see DS301 V4.02).

▶ ["CAN on board" system bus: heartbeat protocol](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	ms	65535	0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00382

Parameter | Name: **C00382 | CAN Guard Time** Data type: UNSIGNED\_16  
Index: 24193<sub>d</sub> = 5E81<sub>h</sub>

After the set guard time multiplied by the life time factor ([C00383](#)), a node guarding telegram must have been received.

- Mapping of the CANopen object [I-100C](#) (see DS301 V4.02).

▶ ["CAN on board" system bus: node guarding protocol](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	ms	65535	0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00383

Parameter | Name: **C00383 | CAN Life Time Factor** Data type: UNSIGNED\_8  
Index: 24192<sub>d</sub> = 5E80<sub>h</sub>

The life time factor multiplied by the guard time ([C00382](#)) results in the time in which a node guarding telegram must have been received.

- Mapping of the CANopen object [I-100D](#) (see DS301 V4.02).

▶ ["CAN on board" system bus: node guarding protocol](#)

Setting range (min. value   unit   max. value)			Lenze setting
0		255	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00385

Parameter   Name: <b>C00385   CAN Heartbeat Consumer Time</b>		Data type: BITFIELD_32 Index: 24190 <sub>d</sub> = 5E7E <sub>h</sub>
<p>The 32 subcodes represent the nodes to be monitored by means of heartbeat.</p> <ul style="list-style-type: none"> <li>• Each subcode entry contains the expected "heartbeat" time and the node ID (node address) from which the heartbeat telegram is expected in the form of a bit code.</li> <li>• The parameterised time is rounded down to an integer multiple of 5 ms and must have a higher value than the heartbeat producer time of the node to be monitored.</li> <li>• The response to a missing heartbeat telegram can be parameterised in <a href="#">C00613</a>.</li> <li>• Mapping of the CANopen object <a href="#">I-1016</a> (see DS301 V4.02).</li> </ul> <p style="text-align: right;">▶ <a href="#">"CAN on board" system bus: heartbeat protocol</a></p>		
<b>Setting range</b>		
0x00000000		0xFFFFFFFF
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Heartbeat time bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 15: Heartbeat time</li> <li>• Bit 16 ... 23: Node address</li> <li>• Bit 24 ... 31: Reserved</li> </ul>
...	...	
Bit 31	Reserved	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00385/1	0x00000000	Monitoring entry 1 ... 32
C00385/...		
C00385/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00386

Parameter   Name: <b>C00386   CAN Node Guarding</b>		Data type: BITFIELD_32 Index: 24189 <sub>d</sub> = 5E7D <sub>h</sub>
<p>The 32 subcodes represent the nodes to be monitored by the master by means of node guarding.</p> <ul style="list-style-type: none"> <li>• Each subcode entry contains the guard time, the lifetime factor and the node ID (node address) from which the heartbeat telegram is expected in the form of a bit code.</li> <li>• The response to a missing node guarding response can be parameterised in <a href="#">C00612</a>.</li> </ul> <p style="text-align: right;">▶ <a href="#">"CAN on board" system bus: node guarding protocol</a></p>		
<b>Setting range</b>		
0x00000000		0xFFFFFFFF
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Guard time bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 15: Guard time</li> <li>• Bit 16 ... 23: Node address</li> <li>• Bit 24 ... 31: Lifetime factor</li> </ul>
...	...	
Bit 31	Lifetime factor bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00386/1	0x00000000	Monitoring entry 1 ... 32
C00386/...		
C00386/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00387

C00387

Parameter   Name: <b>C00387   CAN Node Guarding Activity</b>		Data type: BITFIELD_32 Index: 24188 <sub>d</sub> = 5E7C <sub>h</sub>
<a href="#">▶ "CAN on board" system bus: node guarding protocol</a>		
<b>Display area</b>		
0x00000000		0xFFFFFFFF
<b>Value is bit-coded:</b>		
Bit 0	Node guarding of node 1	
...	...	
Bit 31	Node guarding of node 32	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00388

Parameter   Name: <b>C00388   CAN node guarding status</b>		Data type: UNSIGNED_8 Index: 24187 <sub>d</sub> = 5E7B <sub>h</sub>
<a href="#">▶ "CAN on board" system bus: node guarding protocol</a>		
<b>Selection list (display only)</b>		
0	Unknown	
4	Stopped	
5	Operational	
127	Pre-operational	
<b>Subcodes</b>		<b>Information</b>
C00388/1	Status node 1 ... 32	
C00388/...		
C00388/32		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00390

Parameter   Name: <b>C00390   CAN Error Register (DS301V402)</b>		Data type: BITFIELD_8 Index: 24185 <sub>d</sub> = 5E79 <sub>h</sub>
Mapping of the CANopen object <a href="#">I-1001</a> (see DS301 V4.02).		
<a href="#">▶ "CAN on board" system bus</a>		
<b>Display area</b>		
0x00		0xFF
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Generic error	Currently only bit 0 and bit 4 contain the corresponding information.
Bit 1	Current error (not used)	
Bit 2	Voltage error (not used)	
Bit 3	Temperature error (not used)	
Bit 4	Communication error	
Bit 5	Dev. prof. spec. err (not used)	
Bit 6	Reserved	
Bit 7	Manuf. spec. error (not used)	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



C00391

Parameter   Name: <b>C00391   CAN Emergency Object</b>	Data type: BITFIELD_32 Index: 24184 <sub>d</sub> = 5E78 <sub>h</sub>
---	---

Identifier of the emergency telegram

- Setting bit 31 of this code (0x8nnnnnnn) deactivates the generation of emergency telegrams.
- Mapping of the CANopen object [I-1014](#) (see DS301 V4.02).

▶ ["CAN on board" system bus](#)

Setting range		Lenze setting
0x00000000	0xFFFFFFFF	<b>0x0000081</b> (decimal: 129)
Value is bit-coded: ( <input checked="" type="checkbox"/> = bit set)		Information
Bit 0 <input checked="" type="checkbox"/>	COB-ID bit 0	
Bit 1 <input type="checkbox"/>	COB-ID bit 1	
Bit 2 <input type="checkbox"/>	COB-ID bit 2	
Bit 3 <input type="checkbox"/>	COB-ID bit 3	
Bit 4 <input type="checkbox"/>	COB-ID bit 4	
Bit 5 <input type="checkbox"/>	COB-ID bit 5	
Bit 6 <input type="checkbox"/>	COB-ID bit 6	
Bit 7 <input checked="" type="checkbox"/>	COB-ID bit 7	
Bit 8 <input type="checkbox"/>	COB-ID bit 8	
Bit 9 <input type="checkbox"/>	COB-ID bit 9	
Bit 10 <input type="checkbox"/>	COB-ID bit 10	
Bit 11 <input type="checkbox"/>	Reserved	
Bit 12 <input type="checkbox"/>	Reserved	
Bit 13 <input type="checkbox"/>	Reserved	
Bit 14 <input type="checkbox"/>	Reserved	
Bit 15 <input type="checkbox"/>	Reserved	
Bit 16	Reserved	
Bit 17 <input type="checkbox"/>	Reserved	
Bit 18 <input type="checkbox"/>	Reserved	
Bit 19 <input type="checkbox"/>	Reserved	
Bit 20 <input type="checkbox"/>	Reserved	
Bit 21 <input type="checkbox"/>	Reserved	
Bit 22 <input type="checkbox"/>	Reserved	
Bit 23 <input type="checkbox"/>	Reserved	
Bit 24 <input type="checkbox"/>	Reserved	
Bit 25 <input type="checkbox"/>	Reserved	
Bit 26 <input type="checkbox"/>	Reserved	
Bit 27 <input type="checkbox"/>	Reserved	
Bit 28 <input type="checkbox"/>	Reserved	
Bit 29 <input type="checkbox"/>	Reserved	
Bit 30 <input type="checkbox"/>	Reserved	
Bit 31 <input type="checkbox"/>	Emergency inactive/active	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00392

C00392

Parameter   Name: <b>C00392   CAN emergency delay time</b>		Data type: UNSIGNED_16 Index: 24183 <sub>d</sub> = 5E77 <sub>h</sub>
Time which at least has to elapse between two subsequent emergency telegrams.		
<ul style="list-style-type: none"> <li>Setting "0" deactivates the inhibit time check.</li> <li>The inhibit time is entered in 1/10 ms. The code automatically rounds the entries down to the preceding full millisecond.</li> <li>Mapping of the CANopen object <a href="#">I-1015</a> (see DS301 V4.02).</li> </ul>		
<a href="#">▶ "CAN on board" system bus</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		65535 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00393

Parameter   Name: <b>C00393   CAN result - bus scan</b>		Data type: UNSIGNED_8 Index: 24182 <sub>d</sub> = 5E76 <sub>h</sub>
Result of CAN bus scanning (see controller commands under <a href="#">C00002</a> ).		
<ul style="list-style-type: none"> <li>Subcode number 1 ... 128 corresponds to CAN node address 1 ... 128.</li> </ul>		
<a href="#">▶ "CAN on board" system bus</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Information</b>	
C00393/1	Result of CAN bus scanning for CAN node address 1 ...	
C00393/...	128	
C00393/128	<ul style="list-style-type: none"> <li>"1" means that a device with the corresponding node address has been found.</li> </ul>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00394

Parameter   Name: <b>C00394   CAN predefined error field (DS301V402)</b>		Data type: UNSIGNED_32 Index: 24181 <sub>d</sub> = 5E75 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<b>Subcodes</b>	<b>Information</b>	
C00394/1		
C00394/2		
C00394/3		
C00394/4		
C00394/5		
C00394/6		
C00394/7		
C00394/8		
C00394/9		
C00394/10		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00379

Parameter   Name: <b>C00395   Service code</b>		Data type: UNSIGNED_32 Index: 24180 <sub>d</sub> = 5E74 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00396

Parameter | Name: **C00396 | Service code** Data type: UNSIGNED\_32  
Index: 24179<sub>d</sub> = 5E73<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00397

Parameter | Name: **C00397 | Service code** Data type: UNSIGNED\_32  
Index: 24178<sub>d</sub> = 5E72<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00398

Parameter | Name: **C00398 | Test mode motor control** Data type: UNSIGNED\_32  
Index: 24177<sub>d</sub> = 5E71<sub>h</sub>

**⚠ Danger!**

**When the test mode is activated, the parameterisable error response "Quick stop by trouble" has no effect!**

- If the test mode is active and a monitoring function responds with this error response, no quick stop is executed but the motor continues to rotate with the frequency set for the test mode!

Selection list (Lenze setting printed in bold)		Information
0	<b>Test mode deactivated</b>	
1	U rotation test mode	
2	I rotation test mode	
3	Current controller optimisation mode	After controller enable, the motor is supplied with current as long as the controller is enabled.
4	Current controller optimisation mode impulse	<b>From software version V7.0</b> The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C00399

Parameter | Name: **C00399 | Settings for test mode** Data type: INTEGER\_32  
Index: 24176<sub>d</sub> = 5E70<sub>h</sub>

Setting range (min. value   unit   max. value)		
-1000.0	Hz/1°	1000.0

Subcodes	Lenze setting	Information
C00399/1	0.0 Hz/1°	Frequency [Hz] for test mode
C00399/2	0.0 Hz/1°	Start angle [°] for test mode

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 10

C00413

Parameter | Name: **C00413 | Hiperface: detected TypeCode** Data type: UNSIGNED\_32  
Index: 24162<sub>d</sub> = 5E62<sub>h</sub>

**From software version V4.0**

Type code read out of the connected Hiperface encoder

[▶ Parameterisation of an unknown Hiperface encoder](#)

Display range (min. value   unit   max. value)		
0		255

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00414

C00414

Parameter   Name: <b>C00414   Hiperface: TypeCode</b>	Data type: UNSIGNED_32 Index: 24161 <sub>d</sub> = 5E61 <sub>h</sub>
<a href="#">From software version V4.0</a>	
Setting the type code for a Hiperface encoder unknown to the controller <a href="#">▶ Parameterisation of an unknown Hiperface encoder</a>	
<b>Setting range</b> (min. value   unit   max. value)	<b>Lenze setting</b>
0	255 <b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00415

Parameter   Name: <b>C00415   Hiperface: number of rev.</b>	Data type: UNSIGNED_32 Index: 24160 <sub>d</sub> = 5E60 <sub>h</sub>
<a href="#">From software version V4.0</a>	
Number of displayable revolutions for a multi-turn encoder <a href="#">▶ Parameterisation of an unknown Hiperface encoder</a>	
<b>Setting range</b> (min. value   unit   max. value)	<b>Lenze setting</b>
0	16384 <b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00416

Parameter   Name: <b>C00416   Service code</b>	Data type: UNSIGNED_32 Index: 24159 <sub>d</sub> = 5E5F <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00417

Parameter   Name: <b>C00417   Dynamic of resolver evaluation</b>	Data type: UNSIGNED_32 Index: 24158 <sub>d</sub> = 5E5E <sub>h</sub>
<a href="#">From software version V5.0</a>	
The resolver evaluation of the controller is adapted to the resolver types mounted in Lenze motors and offers a good compromise between the dynamic performance and interference suppression. If the resolver is used as speed feedback system, among other things the dynamic performance of the resolver evaluation determines the maximum speed controller gain by means of which stable operation is possible. In an EMC-compliant system (low interference), you can increase the dynamics of the resolver evaluation via this parameter without a quality loss in the speed signal. By increasing the setting, the evaluation gets more dynamic and thus the speed controller gainVp ( <a href="#">C00070</a> ) also increases without leaving the stable operating range. The acceleration of the evaluation depends on the cable length, the resolver, and the quality of the electrical shielding. In many cases, a setting of 300 % is possible which can double the speed controller gain. The higher gain in the speed controller may reduce following errors.	
<b>Setting range</b> (min. value   unit   max. value)	<b>Lenze setting</b>
100	% 1000 <b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00418

Parameter   Name: <b>C00418   Activate resolver error compensation</b>	Data type: UNSIGNED_8 Index: 24157 <sub>d</sub> = 5E5D <sub>h</sub>
<a href="#">From software version V7.0</a>	
<a href="#">▶ Resolver error compensation</a>	
<b>Selection list</b> (Lenze setting printed in bold)	
<b>0</b> Deactivated	
1 Activated	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

## C00420

Parameter   Name: <b>C00420   Encoder - number of increments</b>		Data type: UNSIGNED_16 Index: 24155 <sub>d</sub> = 5E5B <sub>h</sub>
Setting range (min. value   unit   max. value)		Lenze setting
1		16384 <b>512</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00421

Parameter   Name: <b>C00421   Encoder voltage</b>		Data type: UNSIGNED_16 Index: 24154 <sub>d</sub> = 5E5A <sub>h</sub>
Setting range (min. value   unit   max. value)		Lenze setting
5.0	V	12.0 <b>5.0 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C00422

Parameter   Name: <b>C00422   Encoder type</b>		Data type: UNSIGNED_16 Index: 24153 <sub>d</sub> = 5E59 <sub>h</sub>
Selection list (Lenze setting printed in bold)		Information
<b>0</b>	<b>Incremental encoder (TTL signal)</b>	
1	Sin/cos encoder	
2	Absolute value encoder (Hiperface)	
3	Absolute value encoder (EnDat)	
4	SSI encoder	From software version V5.0 ▶ <a href="#">Use of an SSI encoder at X8</a>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00423

Parameter   Name: <b>C00423   SSI encoder: bit rate</b>		Data type: UNSIGNED_32 Index: 24152 <sub>d</sub> = 5E58 <sub>h</sub>
From software version V5.0		
▶ <a href="#">Use of an SSI encoder at X8</a>		
Setting range (min. value   unit   max. value)		Lenze setting
150	kbps	1000 <b>400 kbps</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00424

Parameter   Name: <b>C00424   SSI encoder: Data word length</b>		Data type: UNSIGNED_32 Index: 24151 <sub>d</sub> = 5E57 <sub>h</sub>
From software version V5.0		
▶ <a href="#">Use of an SSI encoder at X8</a>		
Setting range (min. value   unit   max. value)		Lenze setting
1	Bit	31 <b>25 Bit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00427

Parameter   Name: <b>C00427   TTL encoder signal evaluation</b>		Data type: UNSIGNED_16 Index: 24148 <sub>d</sub> = 5E54 <sub>h</sub>
Selection list (Lenze setting printed in bold)		
<b>0</b>	<b>4x evaluation (A, B)</b>	
1	A:Increments B:Sign	
2	Increments A:pos. B:neg.	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00435

## C00435

Parameter | Name: **C00435 | SSI encoder: partword start position** Data type: UNSIGNED\_8  
Index: 24140<sub>d</sub> = 5E4C<sub>h</sub>

From software version V5.0

[▶ Use of an SSI encoder at X8](#)

Setting range (min. value   unit   max. value)		
0		30
Subcodes	Lenze setting	Information
C00435/1	0	Ssi-enc.: Partword 1 start
C00435/2	0	Ssi-enc.: Partword 2 start
C00435/3	0	Ssi-enc.: Partword 3 start
C00435/4	0	Ssi-enc.: Partword 4 start
C00435/5	0	Ssi-enc.: Partword 5 start
C00435/6	0	Ssi-enc.: Partword 6 start
C00435/7	0	SSI enc.: Partword 7 start
C00435/8	0	Ssi-enc.: Partword 8 start
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00436

Parameter | Name: **C00436 | SSI encoder: partword length** Data type: UNSIGNED\_8  
Index: 24139<sub>d</sub> = 5E4B<sub>h</sub>

From software version V5.0

[▶ Use of an SSI encoder at X8](#)

Setting range (min. value   unit   max. value)		
0		31
Subcodes	Lenze setting	Information
C00436/1	31	Ssi-enc.: Partword 1 length
C00436/2	0	Ssi-enc.: Partword 2 length
C00436/3	0	Ssi-enc.: Partword 3 length
C00436/4	0	Ssi-enc.: Partword 4 length
C00436/5	0	Ssi-enc.: Partword 5 length
C00436/6	0	Ssi-enc.: Partword 6 length
C00436/7	0	Ssi-enc.: Partword 7 length
C00436/8	0	SSI enc.: Partword 8 length
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00437

Parameter | Name: **C00437 | SSI encoder: partword data coding** Data type: UNSIGNED\_8  
Index: 24138<sub>d</sub> = 5E4A<sub>h</sub>

From software version V5.0

[▶ Use of an SSI encoder at X8](#)

Selection list (Lenze setting printed in bold)		
0	binary coded	
1	gray coded	
Subcodes	Lenze setting	Information
C00437/1	0: binary coded	Ssi-enc.: Partword 1 coding
C00437/2	0: binary coded	Ssi-enc.: Partword 2 coding
C00437/3	0: binary coded	Ssi-enc.: Partword 3 coding
C00437/4	0: binary coded	Ssi-enc.: Partword 4 coding
C00437/5	0: binary coded	Ssi-enc.: Partword 5 coding
C00437/6	0: binary coded	Ssi-enc.: Partword 6 coding
C00437/7	0: binary coded	SSI enc.: Partword 7 coding
C00437/8	0: binary coded	Ssi-enc.: Partword 8 coding
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00443

Parameter | Name: **C00443 | Status: Digital inputs** Data type: UNSIGNED\_8  
Index: 24132<sub>d</sub> = 5E44<sub>h</sub>

Display range (min. value | unit | max. value)

0 | | 1

Subcodes	Information	
C00443/1	Digital input 1	
C00443/2	Digital input 2	
C00443/3	Digital input 3	
C00443/4	Digital input 4	
C00443/5	Digital input 5	
C00443/6	Digital input 6	
C00443/7	Digital input 7	
C00443/8	Digital input 8	
C00443/9	Controller inhibit (inversion of input X5/RFR)	
C00443/10	Internal signal	
C00443/11	Feedback input of holding brake	
C00443/12	State bus input	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00444

## C00444

Parameter   Name: <b>C00444   Status: Digital outputs</b>		Data type: UNSIGNED_8 Index: 24131 <sub>d</sub> = 5E43 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		1
Subcodes	Information	
C00444/1	Digital output 1	
C00444/2	Digital output 2	
C00444/3	Digital output 3	
C00444/4	Digital output 4	
C00444/5	Internal signal	
C00444/6	Internal signal	
C00444/7	Internal signal	
C00444/8	Internal signal	
C00444/9	User LED	
C00444/10	Internal signal	
C00444/11	Internal signal	
C00444/12	Internal signal	
C00444/13	Control output of holding brake	
C00444/14	Internal signal	
C00444/15	Internal signal	
C00444/16	Internal signal	
C00444/17	Internal signal	
C00444/18	State bus output	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00464

Parameter   Name: <b>C00464   Keypad: Mode</b>		Data type: UNSIGNED_16 Index: 24111 <sub>d</sub> = 5E2F <sub>h</sub>
From software version V5.0		
Definition of the mode in which the keypad attached is to be activated.		
<ul style="list-style-type: none"> <li>If both keypad versions (V1.0 and V2.0) are used, the Lenze setting is to be maintained.</li> <li>If only the new keypad V2.0 is used, the initialisation time of the keypad can be reduced by changing over to mode 2. Furthermore mode 2 supports greater future keypad files.</li> </ul>		
<b>Note: If mode 2 is selected, the keypad V1.0 can no longer be operated on the controller!</b>		
Selection list (Lenze setting printed in bold)		Information
0	Mode 1	For keypad V1.0 and V2.0
1	<b>Mode 2</b>	Only for keypad V2.0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00465

Parameter   Name: <b>C00465   Keypad: Welcome screen time-out</b>		Data type: UNSIGNED_8 Index: 24110 <sub>d</sub> = 5E2E <sub>h</sub>
Selection list (Lenze setting printed in bold)		Information
0	<b>Never show welcome screen</b>	
5	5 min	
15	15 min	
30	30 min	
60	60 min	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



C00466

Parameter   Name: <b>C00466   Keypad: Default parameters</b>		Data type: UNSIGNED_16 Index: 24109 <sub>d</sub> = 5E2D <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	65535	<b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00467

Parameter   Name: <b>C00467   Keypad: Default welcome screen</b>		Data type: UNSIGNED_8 Index: 24108 <sub>d</sub> = 5E2C <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Main menu</b>	
1	Parameter list	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00468

Parameter   Name: <b>C00468   Service code</b>		Data type: UNSIGNED_8 Index: 24107 <sub>d</sub> = 5E2B <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00469

Parameter   Name: <b>C00469   Keypad: Fct. STOP key</b>		Data type: UNSIGNED_8 Index: 24106 <sub>d</sub> = 5E2A <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		
0	No function	
1	Inhibit controller	
<b>2</b>	<b>Activate quick stop</b>	
3	Stop application	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00490

Parameter   Name: <b>C00490   Position encoder selection</b>		Data type: UNSIGNED_16 Index: 24085 <sub>d</sub> = 5E15 <sub>h</sub>
Chapter " <a href="#">Controller configuration</a> " provides you with more information on parameter setting.		
<b>Selection list (Lenze setting printed in bold)</b>		
0	Resolver on X7	
1	Encoder on X8	
4	Encoder signal on LS_Feedback	
<b>10</b>	<b>Motor encoder (C00495)</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00494

Parameter   Name: <b>C00494   Motor standstill time constant</b>		Data type: UNSIGNED_32 Index: 24081 <sub>d</sub> = 5E11 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	ms	100000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00495

C00495

Parameter   Name: <b>C00495   Motor encoder selection</b>	Data type: UNSIGNED_16 Index: 24080 <sub>d</sub> = 5E10 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Resolver on X7</b>
1	Encoder on X8
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer      Scaling factor: 1	

C00497

Parameter   Name: <b>C00497   Speed act. val. time const.</b>	Data type: UNSIGNED_32 Index: 24078 <sub>d</sub> = 5E0E <sub>h</sub>
Time constant for actual speed filter	
<ul style="list-style-type: none"><li>In order to maximise the dynamics of the speed control loop, the actual speed filter should be operated with a time constant as low as possible. The lower the time constant the higher the gain of the speed controller. Since actual value filters have the task to dampen measuring errors or interference components, it must be found a compromise between filter task and the resulting delay.</li><li>If a Lenze motor is selected from the motor catalogue, a time constant is automatically preset here which serves to operate the motor even with a faulty detection (e.g. in case of a bad shield connection).<ul style="list-style-type: none"><li>Servo control (SC): <a href="#">Optimise speed controller</a></li><li>Sensorless vector control (SLVC): <a href="#">Optimise speed controller</a></li></ul></li></ul>	
<b>Setting range</b> (min. value   unit   max. value)	<b>Lenze setting</b>
0.0      ms      50.0	<b>2.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer      Scaling factor: 10	

C00512

Parameter   Name: <b>C00512   Service code</b>	Data type: UNSIGNED_32 Index: 24063 <sub>d</sub> = 5DFF <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00513

Parameter   Name: <b>C00513   Service code</b>	Data type: VISIBLE_STRING Index: 24062 <sub>d</sub> = 5DFE <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00514

Parameter   Name: <b>C00514   Service code</b>	Data type: UNSIGNED_32 Index: 24061 <sub>d</sub> = 5DFD <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00515

Parameter   Name: <b>C00515   Service code</b>	Data type: UNSIGNED_32 Index: 24060 <sub>d</sub> = 5DFC <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00516

Parameter   Name: <b>C00516   Service code</b>	Data type: UNSIGNED_32 Index: 24059 <sub>d</sub> = 5DFB <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

## C00569

Parameter | Name: **C00569 | Resp. brake trans. lxt &gt; C00570** Data type: UNSIGNED\_32  
Index: 24006<sub>d</sub> = 5DC6<sub>h</sub>

From software version V1.5

Response if adjustable warning threshold ([C00570](#)) of brake chopper monitoring is reached. ▶ [Braking operation](#)

Selection list (Lenze setting printed in bold)	
1	Fault
2	Trouble
5	<b>Warning</b>
4	Warning locked
3	Quick stop by trouble
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00570

Parameter | Name: **C00570 | Warning thres. brake transistor** Data type: UNSIGNED\_32  
Index: 24005<sub>d</sub> = 5DC5<sub>h</sub>

From software version V1.5

Warning threshold for brake chopper monitoring

- The response to reaching the threshold can be selected in [C00569](#).

▶ [Braking operation](#)

Setting range (min. value   unit   max. value)	Lenze setting
0   %   100	<b>90 %</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00571

Parameter | Name: **C00571 | Resp. brake res. i>xt &gt; C00572** Data type: UNSIGNED\_32  
Index: 24004<sub>d</sub> = 5DC4<sub>h</sub>

From software version V1.5

Response if adjustable warning threshold ([C00572](#)) of brake resistor monitoring is reached. ▶ [Braking operation](#)

Selection list (Lenze setting printed in bold)	
1	Fault
2	Trouble
5	<b>Warning</b>
4	Warning locked
3	Quick stop by trouble
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00572

Parameter | Name: **C00572 | Warning thres. brake resistor** Data type: UNSIGNED\_32  
Index: 24003<sub>d</sub> = 5DC3<sub>h</sub>

From software version V1.5

Warning threshold for brake resistor monitoring

- The response to reaching the threshold can be selected in [C00571](#).

▶ [Braking operation](#)

Setting range (min. value   unit   max. value)	Lenze setting
0   %   100	<b>90 %</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00573

C00573

Parameter   Name: <b>C00573   Resp. to overload brake trans.</b>	Data type: UNSIGNED_32 Index: 24002 <sub>d</sub> = 5DC2 <sub>h</sub>
Response to activation of brake chopper monitoring	
<a href="#">▶ Braking operation</a>	
<b>Selection list</b> (Lenze setting printed in bold)	
1	Fault
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
<b>0</b>	<b>No response</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00574

Parameter   Name: <b>C00574   Resp. to overtemp. brake resist.</b>	Data type: UNSIGNED_32 Index: 24001 <sub>d</sub> = 5DC1 <sub>h</sub>
Response to activation of brake resistor monitoring	
<a href="#">▶ Braking operation</a>	
<b>Selection list</b> (Lenze setting printed in bold)	
1	Fault
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
<b>0</b>	<b>No response</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00576

Parameter   Name: <b>C00576   Speed monitoring tolerance</b>	Data type: UNSIGNED_32 Index: 23999 <sub>d</sub> = 5DBF <sub>h</sub>		
Monitoring window for speed control error in [%] of nmax			
<b>Setting range</b> (min. value   unit   max. value)			
0	%	100	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1			

C00577

Parameter   Name: <b>C00577   Field weakening controller gain</b>	Data type: UNSIGNED_32 Index: 23998 <sub>d</sub> = 5DBE <sub>h</sub>		
At "0" the P component is deactivated, a pure I-controller is used.			
<b>Setting range</b> (min. value   unit   max. value)			
0.000	Vs/V	2147483.647	<b>0.000 Vs/V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1000			

C00578

Parameter   Name: <b>C00578   Field weak. contr. reset time</b>	Data type: UNSIGNED_32 Index: 23997 <sub>d</sub> = 5DBD <sub>h</sub>		
At "240000.0 ms" the I component of the field weakening controller is deactivated.			
<b>Setting range</b> (min. value   unit   max. value)			
1.0	ms	240000.0	<b>2000.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10			

## C00579

<b>Parameter   Name:</b> <b>C00579   Resp. to speed monitoring</b>	<b>Data type:</b> UNSIGNED_32 <b>Index:</b> 23996 <sub>d</sub> = 5DBC <sub>h</sub>
Response to activation of speed monitoring	
<b>Selection list (Lenze setting printed in bold)</b>	
1	Fault
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
<b>0</b>	<b>No response</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00580

<b>Parameter   Name:</b> <b>C00580   Resp. to encoder open circuit</b>	<b>Data type:</b> UNSIGNED_32 <b>Index:</b> 23995 <sub>d</sub> = 5DBB <sub>h</sub>
Response to open circuit in encoder	
<p><b>⚠ Danger!</b>  <b>If the encoder is used as motor encoder:</b>                  In the event of an error, a safe operation of the motor cannot be ensured anymore!                  For safety reasons, the "Fault" response should always be set for this case!</p>	
<b>Selection list (Lenze setting printed in bold)</b>	
<b>1</b>	<b>Fault</b>
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
13	Quick Stop open loop by trouble
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00581

<b>Parameter   Name:</b> <b>C00581   Resp. to external fault</b>	<b>Data type:</b> UNSIGNED_32 <b>Index:</b> 23994 <sub>d</sub> = 5DBA <sub>h</sub>
Response to an external error	
<a href="#">▶ Drive interface</a>	
<b>Selection list (Lenze setting printed in bold)</b>	
<b>1</b>	<b>Fault</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00582

C00582

Parameter | Name: **C00582 | Resp. to heatsink temp. &gt; C00122** Data type: UNSIGNED\_32  
Index: 23993<sub>d</sub> = 5DB9<sub>h</sub>

Response if heatsink temperature > variable limit temperature ([C00122](#)).

Selection list (Lenze setting printed in bold)	
1	Fault
5	<b>Warning</b>
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C00583

Parameter | Name: **C00583 | Resp. to motor KTY overtemp.** Data type: UNSIGNED\_32  
Index: 23992<sub>d</sub> = 5DB8<sub>h</sub>

Response if motor temperature > fixed limit temperature. ▶ [Motor temperature monitoring](#)

Selection list (Lenze setting printed in bold)	
1	Fault
5	Warning
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C00584

Parameter | Name: **C00584 | Resp. to motor temp. &gt; C00121** Data type: UNSIGNED\_32  
Index: 23991<sub>d</sub> = 5DB7<sub>h</sub>

Response if motor temperature > variable limit temperature ([C00121](#)). ▶ [Motor temperature monitoring](#)

Selection list (Lenze setting printed in bold)	
1	Fault
5	<b>Warning</b>
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C00585

Parameter | Name: **C00585 | Resp. to motor PTC overtemp.** Data type: UNSIGNED\_32  
Index: 23990<sub>d</sub> = 5DB6<sub>h</sub>

Response if motor temperature across PTC input T1/T2 too high.

Selection list (Lenze setting printed in bold)	
1	Fault
5	Warning
0	<b>No response</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00586

Parameter   Name: <b>C00586   Resp. to resolver open circuit</b>	Data type: UNSIGNED_32 Index: 23989 <sub>d</sub> = 5DB5 <sub>h</sub>
Response to open circuit in resolver	
<b>⚠ Danger!</b>	
<b>If the resolver is used as motor encoder:</b>	
In the event of an error, a safe operation of the motor cannot be ensured anymore! For safety reasons, the "Fault" response should always be set for this case!	
<b>Selection list (Lenze setting printed in bold)</b>	
1	<b>Fault</b>
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
13	Quick Stop open loop by trouble
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00587

Parameter   Name: <b>C00587   Fan control status</b>	Data type: BITFIELD_8 Index: 23988 <sub>d</sub> = 5DB4 <sub>h</sub>
<b>Display area</b>	
0x00	0xFF
<b>Value is bit-coded:</b>	
Bit 0	Heatsink fan ON
Bit 1	Integral fan ON
Bit 2	Heatsink fan status 1
Bit 3	Heatsink fan status 2
Bit 4	Integral fan status
Bit 5	Reserved
Bit 6	Reserved
Bit 7	Reserved
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00588

Parameter   Name: <b>C00588   Resp. to failure t. sensor drive</b>	Data type: UNSIGNED_32 Index: 23987 <sub>d</sub> = 5DB3 <sub>h</sub>
Response to error/failure of temperature sensor for heatsink temperature/temperature inside the controller	
<b>Selection list (Lenze setting printed in bold)</b>	
1	<b>Fault</b>
5	Warning
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00589

## C00589

Parameter   Name: <b>C00589   Resp. to CPU temp. &amp;gt; C00126</b>	Data type: UNSIGNED_32 Index: 23986 <sub>d</sub> = 5DB2 <sub>h</sub>
Response if CPU temperature on the control card > variable limit temperature ( <a href="#">C00126</a> ).	
<b>Selection list</b> (Lenze setting printed in bold)	
1	Fault
5	Warning
<b>0</b>	<b>No response</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00591

Parameter   Name: <b>C00591   Resp. to CAN-RPDOx error</b>	Data type: UNSIGNED_8 Index: 23984 <sub>d</sub> = 5DB0 <sub>h</sub>	
Response if the corresponding CAN RPDO has not been received in the configured time or with the configured sync. ▶ <a href="#">"CAN on board" system bus</a>		
<b>Selection list</b> (Lenze setting printed in bold)		
1	Fault	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00591/1	0: No response	Response to non-received RPDO1 ... RPDO4
C00591/...		
C00591/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00594

Parameter   Name: <b>C00594   Resp. temp. sensor motor X7/X8</b>	Data type: UNSIGNED_32 Index: 23981 <sub>d</sub> = 5DAD <sub>h</sub>
Response to motor temperature sensor error. • The response to a too high motor temperature via PTC input T1/T2 can be selected in <a href="#">C00585</a> . ▶ <a href="#">Motor temperature monitoring</a>	
<b>Selection list</b> (Lenze setting printed in bold)	
<b>1</b>	<b>Fault</b>
5	Warning
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	



## C00595

Parameter | Name: **C00595 | Resp. to CAN bus OFF** Data type: UNSIGNED\_8  
Index: 23980<sub>d</sub> = 5DAC<sub>h</sub>

Response if CAN node switches to the bus off state.

[▶ "CAN on board" system bus](#)

Selection list (Lenze setting printed in bold)	
1	Fault
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
<b>0</b>	<b>No response</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00596

Parameter | Name: **C00596 | Threshold max. speed reached** Data type: UNSIGNED\_32  
Index: 23979<sub>d</sub> = 5DAB<sub>h</sub>

Threshold for speed monitoring

- The response to reaching the threshold can be selected in [C00607](#).

Setting range (min. value   unit   max. value)			Lenze setting
50	rpm	50000	<b>6500 rpm</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00597

Parameter | Name: **C00597 | Resp. to motor phase failure** Data type: UNSIGNED\_32  
Index: 23978<sub>d</sub> = 5DAA<sub>h</sub>

Response to activation of motor phase failure monitoring

Selection list (Lenze setting printed in bold)	
1	Fault
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
<b>0</b>	<b>No response</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00598

Parameter | Name: **C00598 | Resp. to open circuit AIN1** Data type: UNSIGNED\_32  
Index: 23977<sub>d</sub> = 5DA9<sub>h</sub>

Response if with master current at AIN1 and "LifeZero" mode ( $\pm 4 \dots \pm 20$ mA) the current is in the non-permitted range (-4 ... +4 mA).

Selection list (Lenze setting printed in bold)	
<b>1</b>	<b>Fault</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00599

C00599

Parameter   Name: <b>C00599   Motor phase failure threshold</b>	Data type: INTEGER_32 Index: 23976 <sub>d</sub> = 5DA8 <sub>h</sub>
Current value for activating the <a href="#">Motor phase failure monitoring</a>	
<ul style="list-style-type: none"> <li>• In [%] relating to the maximum device current (display in <a href="#">C00789</a>).</li> <li>• The response to be triggered by the monitoring can be selected in <a href="#">C00597</a>.</li> </ul>	
<b>Setting range</b> (min. value   unit   max. value)	<b>Lenze setting</b>
1.0   %   10.0	<b>5.0 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10	

C00600

Parameter   Name: <b>C00600   Resp. to DC bus overvoltage</b>	Data type: UNSIGNED_32 Index: 23975 <sub>d</sub> = 5DA7 <sub>h</sub>
Response to DC bus overvoltage	
<a href="#">▶ Braking operation</a>	
<b>Selection list</b> (Lenze setting printed in bold)	
1	Fault
2	<b>Trouble</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00601

Parameter   Name: <b>C00601   Resp. to encoder comm. error</b>	Data type: UNSIGNED_32 Index: 23974 <sub>d</sub> = 5DA6 <sub>h</sub>
Response to activation of encoder monitoring	
<ul style="list-style-type: none"> <li>• <b>For the use of the encoder as motor encoder:</b> If an error occurs, the safe operation of the motor is no longer ensured, therefore for safety reasons the "Fault" response should always be set!</li> </ul>	
<b>Selection list</b> (Lenze setting printed in bold)	
1	<b>Fault</b>
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
13	Quick Stop open loop by trouble
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00604

Parameter   Name: <b>C00604   Resp. to device overload &amp;gt; C00123</b>	Data type: UNSIGNED_32 Index: 23971 <sub>d</sub> = 5DA3 <sub>h</sub>
Response if adjustable "I x t" warning threshold ( <a href="#">C00123</a> ) is reached.	
<b>Selection list</b> (Lenze setting printed in bold)	
1	Fault
5	<b>Warning</b>
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00606

Parameter   Name:	Data type: UNSIGNED_32 Index: 23969 <sub>d</sub> = 5DA1 <sub>h</sub>
<b>C00606   Resp. to motor overload &amp;gt; C00127</b>	
Response if adjustable "I <sup>2</sup> x t" warning threshold ( <a href="#">C00127</a> ) is reached.	
<b>Selection list</b> (Lenze setting printed in bold)	
1	<b>Fault</b>
5	<b>Warning</b>
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00607

Parameter   Name:	Data type: UNSIGNED_32 Index: 23968 <sub>d</sub> = 5DA0 <sub>h</sub>
<b>C00607   Resp. to max. speed reached</b>	
Response if adjustable speed threshold ( <a href="#">C00596</a> ) is reached.	
<b>Selection list</b> (Lenze setting printed in bold)	
1	<b>Fault</b>
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00610

Parameter   Name:	Data type: UNSIGNED_32 Index: 23965 <sub>d</sub> = 5D9D <sub>h</sub>
<b>C00610   Resp. to failure heatsink fan</b>	
Response if fan speed of heatsink fan is too low.	
<b>Selection list</b> (Lenze setting printed in bold)	
1	<b>Fault</b>
5	Warning
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00611

Parameter   Name:	Data type: UNSIGNED_32 Index: 23964 <sub>d</sub> = 5D9C <sub>h</sub>
<b>C00611   Resp. to failure integral fan</b>	
Response if fan speed of internal fan is too low.	
<b>Selection list</b> (Lenze setting printed in bold)	
1	<b>Fault</b>
5	Warning
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00612

## C00612

Parameter | Name: **C00612 | Resp. to CAN node guarding error** Data type: UNSIGNED\_8  
Index: 23963<sub>d</sub> = 5D9B<sub>h</sub>

Response of master if the corresponding node guarding response is not received.

▶ ["CAN on board" system bus: node guarding protocol](#)

Selection list (Lenze setting printed in bold)		
1	Fault	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Information
C00612/1	0: No response	Response to non-received telegram for monitoring entry 1 ... 32
C00612/...		
C00612/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00613

Parameter | Name: **C00613 | Resp. to CAN heartbeat error** Data type: UNSIGNED\_8  
Index: 23962<sub>d</sub> = 5D9A<sub>h</sub>

Response if the corresponding heartbeat telegram is not received.

▶ ["CAN on board" system bus: heartbeat protocol](#)

Selection list (Lenze setting printed in bold)		
1	Fault	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Information
C00613/1	0: No response	Response to non-received telegram for monitoring entry 1 ... 32
C00613/...		
C00613/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C00614

Parameter | Name: **C00614 | Resp. to CAN life guarding error** Data type: UNSIGNED\_8  
Index: 23961<sub>d</sub> = 5D99<sub>h</sub>

Response of slave if node guarding request is not received. ▶ ["CAN on board" system bus: node guarding protocol](#)

Selection list (Lenze setting printed in bold)	
1	<b>Fault</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
<b>0</b>	<b>No response</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00615

Parameter | Name: **C00615 | Resp. to imp. device config.** Data type: UNSIGNED\_32  
Index: 23960<sub>d</sub> = 5D98<sub>h</sub>

Selection list	
1	Fault
3	Quick stop by trouble
4	Warning locked
6	Information
0	No response

Subcodes	Lenze setting	Information
C00615/1	0: No response	Reserved
C00615/2	1: Fault	Resp. to imp. module in MXI1
C00615/3	1: Fault	Resp. to imp. module in MXI2
C00615/4	0: No response	Reserved
C00615/5	0: No response	Reserved

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00618

Parameter | Name: **C00618 | No. of CRC cycles** Data type: UNSIGNED\_32  
Index: 23957<sub>d</sub> = 5D95<sub>h</sub>

Display range (min. value   unit   max. value)	
0	4294967295

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00619

Parameter | Name: **C00619 | Resp. to motor current &gt; C00620** Data type: UNSIGNED\_32  
Index: 23956<sub>d</sub> = 5D94<sub>h</sub>

Response if the ultimate motor current I<sub>ult</sub> parameterised in [C00620](#) is reached.

Selection list (Lenze setting printed in bold)	
<b>1</b>	<b>Fault</b>
2	Trouble
5	Warning
4	Warning locked
3	Quick stop by trouble
0	No response

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00620

C00620

Parameter   Name: <b>C00620   Ultimate motor current I<sub>ult</sub></b>			Data type: UNSIGNED_32 Index: 23955 <sub>d</sub> = 5D93 <sub>h</sub>
Limit value to protect the motor from destruction or influence of the rated data.			
<ul style="list-style-type: none"><li>• This limit value must not be travelled cyclically during the drive process.</li><li>• The maximum current parameterisable in <a href="#">C00022</a> should have a sufficient distance from this limit value.</li><li>• If the set limit value is exceeded, the error response parameterised in <a href="#">C00619</a> is carried out for motor protection.</li></ul>			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.0	A	3000.0	<b>3000.0 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00621

Parameter   Name: <b>C00621   Resp. to encoder pulse deviation</b>			Data type: UNSIGNED_32 Index: 23954 <sub>d</sub> = 5D92 <sub>h</sub>
<a href="#">From software version V1.5</a>			
Response to be triggered by angular drift monitoring			
<a href="#">▶ Angular drift monitoring</a>			
<b>Selection list (Lenze setting printed in bold)</b>			
1	Fault		
2	Trouble		
5	Warning		
4	Warning locked		
3	Quick stop by trouble		
13	Quick Stop open loop by trouble		
<b>0</b>	<b>No response</b>		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00625

Parameter   Name: <b>C00625   CAN behaviour in case of fault</b>			Data type: UNSIGNED_8 Index: 23950 <sub>d</sub> = 5D8E <sub>h</sub>
Mapping of the CANopen object <a href="#">I-1029</a> (see DS301 V4.02).			
<a href="#">▶ "CAN on board" system bus</a>			
<b>Selection list (Lenze setting printed in bold)</b>			
<b>0</b>	<b>Pre-operational state</b>		
1	No state change		
2	Stopped state		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00635

Parameter   Name: <b>C00635   Resp to new firmw. standard dev.</b>			Data type: UNSIGNED_32 Index: 23940 <sub>d</sub> = 5D84 <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>			
<b>1</b>	<b>Fault</b>		
6	Information		
5	Warning		
4	Warning locked		
3	Quick stop by trouble		
0	No response		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00636

Parameter   Name:	C00636   <b>Resp. to new module in MX11</b>		Data type: UNSIGNED_32 Index: 23939 <sub>d</sub> = 5D83 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)			
1	Fault		
6	Information		
5	Warning		
<b>4</b>	<b>Warning locked</b>		
3	Quick stop by trouble		
0	No response		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

## C00637

Parameter   Name:	C00637   <b>Resp. to new module in MX12</b>		Data type: UNSIGNED_32 Index: 23938 <sub>d</sub> = 5D82 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)			
1	Fault		
6	Information		
5	Warning		
<b>4</b>	<b>Warning locked</b>		
3	Quick stop by trouble		
0	No response		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

## C00640

Parameter   Name:	C00640   <b>Resp. to pole pos. id. monit.</b>		Data type: UNSIGNED_32 Index: 23935 <sub>d</sub> = 5D7F <sub>h</sub>
From software version V4.0			
Error response for abort of the <a href="#">pole position identification</a>			
			▶ <a href="#">Adjustment of the pole position identification</a>
<b>Selection list</b> (Lenze setting printed in bold)			
<b>1</b>	<b>Fault</b>		
4	Warning locked		
0	No response		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

## C00641

Parameter   Name:	C00641   <b>PLI 360° current amplitude</b>		Data type: UNSIGNED_32 Index: 23934 <sub>d</sub> = 5D7E <sub>h</sub>
From software version V4.0			
Percentage adjustment of the current amplitude for the <a href="#">pole position identification</a>			
<b>Stop!</b>			
If there is no temperature monitoring in the motor and/or the I2xt motor monitoring is not parameterised correctly, the motor may be permanently damaged when the current amplitude is set too high (e.g. to the maximum value)!			
			▶ <a href="#">Adjustment of the pole position identification</a>
<b>Setting range</b> (min. value   unit   max. value)			<b>Lenze setting</b>
1	%	1000	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00642

C00642

Parameter   Name: <b>C00642   PolePosId 360° ramp time</b>	Data type: UNSIGNED_32 Index: 23933 <sub>d</sub> = 5D7D <sub>h</sub>
From software version V4.0	
Percentage adjustment of the ramp time for the <a href="#">pole position identification</a> <a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
5   %   1000	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00643

Parameter   Name: <b>C00643   PLI 360° traversing direction</b>	Data type: UNSIGNED_32 Index: 23932 <sub>d</sub> = 5D7C <sub>h</sub>
From software version V4.0	
Selection of the traversing direction for the <a href="#">pole position identification</a> <a href="#">▶ Adjustment of the pole position identification</a>	
Selection list (Lenze setting printed in bold)	
<b>0</b> Right rotating field	
1 Left rotating field	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00644

Parameter   Name: <b>C00644   PolePosId 360° fault tol.</b>	Data type: INTEGER_32 Index: 23931 <sub>d</sub> = 5D7B <sub>h</sub>
From software version V4.0	
Fault tolerance for the plausibility check of the <a href="#">pole position identification</a> <a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
-6.0   °   30.0	<b>0.0 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10	

C00645

Parameter   Name: <b>C00645   PLI 360° absolute current amplitude</b>	Data type: UNSIGNED_32 Index: 23930 <sub>d</sub> = 5D7A <sub>h</sub>
From software version V7.0	
<a href="#">▶ Adjustment of the pole position identification</a>	
Display range (min. value   unit   max. value)	
0.00   A   1000.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

C00646

Parameter   Name: <b>C00646   PLI min.mov. curr. amplitude</b>	Data type: UNSIGNED_32 Index: 23929 <sub>d</sub> = 5D79 <sub>h</sub>
From software version V4.0	
Percentage adjustment of the current amplitude for the <a href="#">pole position identification</a> <b>Stop!</b> If there is no temperature monitoring in the motor and/or the I2xt motor monitoring is not parameterised correctly, the motor may be permanently damaged when the current amplitude is set too high (e.g. to the maximum value)! <a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
1   %   1000	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	



C00647

Parameter   Name: <b>C00647   PolePosId min.mov. cur.rise rate</b>	Data type: UNSIGNED_32 Index: 23928 <sub>d</sub> = 5D78 <sub>h</sub>
From software version V4.0	
Percentage adjustment of the rate of current rise for the <a href="#">pole position identification</a>	
<a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
5   %   1000	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00648

Parameter   Name: <b>C00648   PolePosId min.mov. gain</b>	Data type: UNSIGNED_32 Index: 23927 <sub>d</sub> = 5D77 <sub>h</sub>
From software version V4.0	
P component of the PI controller for the <a href="#">pole position identification</a>	
<a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
0.00     10.00	<b>0.00</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

C00649

Parameter   Name: <b>C00649   PI min. mov. reset time</b>	Data type: UNSIGNED_32 Index: 23926 <sub>d</sub> = 5D76 <sub>h</sub>
From software version V4.0	
I component of the PI controller for the <a href="#">pole position identification</a>	
<a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
0.01   ms   6000.00	<b>62.50 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

C00650

Parameter   Name: <b>C00650   PolePosId min.mov. max.perm.mov.</b>	Data type: INTEGER_32 Index: 23925 <sub>d</sub> = 5D75 <sub>h</sub>
From software version V4.0	
Max. movement permitted during the <a href="#">pole position identification</a>	
<a href="#">▶ Adjustment of the pole position identification</a>	
Setting range (min. value   unit   max. value)	Lenze setting
1   °   90	<b>20 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C00651

Parameter   Name: <b>C00651   PI min. motion absolute cur. amp.</b>	Data type: UNSIGNED_32 Index: 23924 <sub>d</sub> = 5D74 <sub>h</sub>
From software version V7.0	
<a href="#">▶ Adjustment of the pole position identification</a>	
Display range (min. value   unit   max. value)	
0.00   A   1000.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

C00691

Parameter   Name: <b>C00691   Total speed setpoint</b>	Data type: INTEGER_32 Index: 23884 <sub>d</sub> = 5D4C <sub>h</sub>
Display range (min. value   unit   max. value)	
-200.00   %   200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00692

C00692

Parameter   Name:	C00692   Speed setpoint [%]		Data type: INTEGER_32 Index: 23883 <sub>d</sub> = 5D4B <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00693

Parameter   Name:	C00693   Actual speed [%]		Data type: INTEGER_32 Index: 23882 <sub>d</sub> = 5D4A <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00694

Parameter   Name:	C00694   Speed controller output		Data type: INTEGER_32 Index: 23881 <sub>d</sub> = 5D49 <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00695

Parameter   Name:	C00695   Total torque setpoint		Data type: INTEGER_32 Index: 23880 <sub>d</sub> = 5D48 <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00696

Parameter   Name:	C00696   Torque setpoint [%]		Data type: INTEGER_32 Index: 23879 <sub>d</sub> = 5D47 <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00697

Parameter   Name:	C00697   Filtered torque setpoint		Data type: INTEGER_32 Index: 23878 <sub>d</sub> = 5D46 <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00698

Parameter   Name:	C00698   Actual torque [%]		Data type: INTEGER_32 Index: 23877 <sub>d</sub> = 5D45 <sub>h</sub>		
Display range (min. value   unit   max. value)					
-200.00	%	200.00			
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP	<input type="checkbox"/> No transfer	Scaling factor: 100

C00730

Parameter   Name:	C00730   GDO general parameters		Data type: INTEGER_32 Index: 23845 <sub>d</sub> = 5D25 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00731

Parameter | Name: **C00731 | GDO channel 1/trigger 1** Data type: INTEGER\_32  
Index: 23844<sub>d</sub> = 5D24<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00732

Parameter | Name: **C00732 | GDO channel 2/trigger 2** Data type: INTEGER\_32  
Index: 23843<sub>d</sub> = 5D23<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00733

Parameter | Name: **C00733 | GDO channel 3** Data type: INTEGER\_32  
Index: 23842<sub>d</sub> = 5D22<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00734

Parameter | Name: **C00734 | GDO channel 4** Data type: INTEGER\_32  
Index: 23841<sub>d</sub> = 5D21<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00735

Parameter | Name: **C00735 | GDO channel 5** Data type: INTEGER\_32  
Index: 23840<sub>d</sub> = 5D20<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00736

Parameter | Name: **C00736 | GDO channel 6** Data type: INTEGER\_32  
Index: 23839<sub>d</sub> = 5D1F<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00737

Parameter | Name: **C00737 | GDO channel 7** Data type: INTEGER\_32  
Index: 23838<sub>d</sub> = 5D1E<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00738

Parameter | Name: **C00738 | GDO channel 8** Data type: INTEGER\_32  
Index: 23837<sub>d</sub> = 5D1D<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00739

Parameter | Name: **C00739 | GDO status information** Data type: INTEGER\_32  
Index: 23836<sub>d</sub> = 5D1C<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00770

Parameter | Name: **C00770 | MCTRL\_dnMotorPosAct** Data type: UNSIGNED\_32  
Index: 23805<sub>d</sub> = 5CFD<sub>h</sub>

Internal motor control (MCTRL) signal

Display range (min. value   unit   max. value)		
0	Incr.	4294967295

Subcodes	Information
C00770/1	Low word
C00770/2	High word

Read access  Write access  CINH  PLC STOP  No transfer      Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00771

**C00771**

Parameter   Name: <b>C00771   MCTRL_dnLoadPosAct</b>		Data type: UNSIGNED_32 Index: 23804 <sub>d</sub> = 5CFCh
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
0	Incr.	4294967295
<b>Subcodes</b>	<b>Information</b>	
C00771/1	Low word	
C00771/2	High word	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

**C00772**

Parameter   Name: <b>C00772   MCTRL_dnMotorSpeedAct</b>		Data type: INTEGER_32 Index: 23803 <sub>d</sub> = 5CFBh
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

**C00773**

Parameter   Name: <b>C00773   MCTRL_dnLoadSpeedAct</b>		Data type: INTEGER_32 Index: 23802 <sub>d</sub> = 5CFAh
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

**C00774**

Parameter   Name: <b>C00774   MCTRL_dnTorqueAct</b>		Data type: INTEGER_32 Index: 23801 <sub>d</sub> = 5CF9h
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

**C00775**

Parameter   Name: <b>C00775   MCTRL_dnOutputSpeedCtrl</b>		Data type: INTEGER_32 Index: 23800 <sub>d</sub> = 5CF8h
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

**C00776**

Parameter   Name: <b>C00776   MCTRL_dnInputJerkCtrl</b>		Data type: INTEGER_32 Index: 23799 <sub>d</sub> = 5CF7h
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00777

Parameter   Name:	<b>C00777   MCTRL_dnInputTorqueCtrl</b>		Data type: INTEGER_32 Index: 23798 <sub>d</sub> = 5CF6 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 100

C00778

Parameter   Name:	<b>C00778   MCTRL_dnFluxAct</b>		Data type: INTEGER_32 Index: 23797 <sub>d</sub> = 5CF5 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 100

C00779

Parameter   Name:	<b>C00779   MCTRL_dnDCBusVoltage</b>		Data type: INTEGER_32 Index: 23796 <sub>d</sub> = 5CF4 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	V	1000	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 1

C00780

Parameter   Name:	<b>C00780   MCTRL_dnImotAct</b>		Data type: INTEGER_32 Index: 23795 <sub>d</sub> = 5CF3 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-500.00	A	500.00	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 100

C00781

Parameter   Name:	<b>C00781   MCTRL_dwMaxMotorSpeed</b>		Data type: UNSIGNED_32 Index: 23794 <sub>d</sub> = 5CF2 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	rpm	480000	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 1

C00782

Parameter   Name:	<b>C00782   MCTRL_dwMaxMotorTorque</b>		Data type: UNSIGNED_32 Index: 23793 <sub>d</sub> = 5CF1 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0.000	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 1000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00783

C00783

Parameter   Name:			Data type: UNSIGNED_32
<b>C00783   MCTRL_dwMotorVoltageAct</b>			Index: 23792 <sub>d</sub> = 5CF0 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	V	2000	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1			

C00784

Parameter   Name:			Data type: INTEGER_32
<b>C00784   MCTRL_dnMotorFreqAct</b>			Index: 23791 <sub>d</sub> = 5CEF <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-800.0	Hz	800.0	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 10			

C00786

Parameter   Name:			Data type: INTEGER_32
<b>C00786   MCTRL_dnlxtLoad</b>			Index: 23789 <sub>d</sub> = 5CED <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 100			

C00787

Parameter   Name:			Data type: INTEGER_32
<b>C00787   MCTRL_dnFlyingSpeedAct</b>			Index: 23788 <sub>d</sub> = 5CEC <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1			

C00788

Parameter   Name:			Data type: INTEGER_32
<b>C00788   MCTRL_dwMaxEffMotorTorque</b>			Index: 23787 <sub>d</sub> = 5CEB <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0.000	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1000			

C00789

Parameter   Name:			Data type: INTEGER_32
<b>C00789   MCTRL_dwMaxDeviceCurrent</b>			Index: 23786 <sub>d</sub> = 5CEA <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0.00	A	21474836.47	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 100			

## C00790

Parameter   Name: <b>C00790   MCTRL_dnI2xtLoad</b>	Data type: INTEGER_32 Index: 23785 <sub>d</sub> = 5CE9 <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

## C00791

Parameter   Name: <b>C00791   MCTRL_dnDeltaMotorPos_p</b>	Data type: INTEGER_32 Index: 23784 <sub>d</sub> = 5CE8 <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-2147483647	Incr. 2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00792

Parameter   Name: <b>C00792   MCTRL_dnOutputPosCtrlMotor_s</b>	Data type: INTEGER_32 Index: 23783 <sub>d</sub> = 5CE7 <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-200	% 200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00800

Parameter   Name: <b>C00800   MCTRL_dnPosSet</b>	Data type: UNSIGNED_32 Index: 23775 <sub>d</sub> = 5CDF <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
0	Incr. 4294967295
<b>Subcodes</b>	<b>Information</b>
C00800/1	Low word
C00800/2	High word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00802

Parameter   Name: <b>C00802   MCTRL_dnSpeedAdd</b>	Data type: INTEGER_32 Index: 23773 <sub>d</sub> = 5CDD <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-480000	rpm 480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00803

Parameter   Name: <b>C00803   MCTRL_dnTorqueAdd</b>	Data type: INTEGER_32 Index: 23772 <sub>d</sub> = 5CDC <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-2147483.647	Nm 2147483.647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1000	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00804

C00804

Parameter   Name:	<b>C00804   MCTRL_dnAccelerationAdd</b>		Data type: INTEGER_32 Index: 23771 <sub>d</sub> = 5CD <sub>Bh</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-2147483.647	1/s <sup>2</sup>	2147483.647	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 1000

C00805

Parameter   Name:	<b>C00805   MCTRL_dnSpeedLowLimit</b>		Data type: INTEGER_32 Index: 23770 <sub>d</sub> = 5CD <sub>Ah</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 1

C00806

Parameter   Name:	<b>C00806   MCTRL_dnTorqueLowLimit</b>		Data type: INTEGER_32 Index: 23769 <sub>d</sub> = 5CD <sub>9h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 100

C00807

Parameter   Name:	<b>C00807   MCTRL_dnTorqueHighLimit</b>		Data type: INTEGER_32 Index: 23768 <sub>d</sub> = 5CD <sub>8h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 100

C00808

Parameter   Name:	<b>C00808   MCTRL_dnPosCtrlOutLimit</b>		Data type: INTEGER_32 Index: 23767 <sub>d</sub> = 5CD <sub>7h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 1

C00809

Parameter   Name:	<b>C00809   MCTRL_dnTorqueCtrlAdapt</b>		Data type: INTEGER_32 Index: 23766 <sub>d</sub> = 5CD <sub>6h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH	<input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer    Scaling factor: 100



## C00810

Parameter   Name:	<b>C00810   MCTRL_dnSpeedCtrlAdapt</b>		Data type: INTEGER_32 Index: 23765 <sub>d</sub> = 5CD5 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

## C00811

Parameter   Name:	<b>C00811   MCTRL_dnPosCtrlAdapt</b>		Data type: INTEGER_32 Index: 23764 <sub>d</sub> = 5CD4 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

## C00812

Parameter   Name:	<b>C00812   MCTRL_dnMotorPosRefValue</b>		Data type: UNSIGNED_32 Index: 23764 <sub>d</sub> = 5CD3 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	Incr.	4294967295	
<b>Subcodes</b>		<b>Information</b>	
C00812/1		Low word	
C00812/2		High word	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00813

Parameter   Name:	<b>C00813   MCTRL_dnLoadPosRefValue</b>		Data type: UNSIGNED_32 Index: 23762 <sub>d</sub> = 5CD2 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	Incr.	4294967295	
<b>Subcodes</b>		<b>Information</b>	
C00813/1		Low word	
C00813/2		High word	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00814

Parameter   Name:	<b>C00814   MCTRL_dnBoost</b>		Data type: INTEGER_32 Index: 23761 <sub>d</sub> = 5CD1 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-1000	V	1000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00815

Parameter   Name:	<b>C00815   MCTRL_dnSpeedCtrlIntegrator</b>		Data type: INTEGER_32 Index: 23760 <sub>d</sub> = 5CD0 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-2147483.647	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00816

**C00816**

Parameter   Name: <b>C00816   MCTRL_dnFieldWeak</b>	Data type: INTEGER_32 Index: 23759 <sub>d</sub> = 5CCF <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

**C00817**

Parameter   Name: <b>C00817   MCTRL_dnSpeedSet_s</b>	Data type: INTEGER_32 Index: 23758 <sub>d</sub> = 5CCE <sub>h</sub>
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-480000	rpm 480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

**C00818**

Parameter   Name: <b>C00818   MCTRL_dnMvorAdapt</b>	Data type: INTEGER_32 Index: 23757 <sub>d</sub> = 5CCD <sub>h</sub>
<a href="#">From software version V1.5</a>	
Internal motor control (MCTRL) signal	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

**C00854**

Parameter   Name: <b>C00854   ID status</b>	Data type: UNSIGNED_32 Index: 23721 <sub>d</sub> = 5CA9 <sub>h</sub>
<a href="#">From software version V3.0</a>	
<b>Display range (min. value   unit   max. value)</b>	
0	100
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

**C00878**

Parameter   Name: <b>C00878   Status DCTRL control input</b>	Data type: UNSIGNED_8 Index: 23697 <sub>d</sub> = 5C91 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>	
0	1
<b>Subcodes</b>	<b>Information</b>
C00878/1	Status of control inputs
C00878/...	
C00878/5	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C00909

Parameter   Name: <b>C00909   Speed limitation</b>		Data type: INTEGER_16 Index: 23666 <sub>d</sub> = 5C72 <sub>h</sub>
Speed limitation for speed setpoint		
<ul style="list-style-type: none"> <li>For the upper speed limit value only positive values are permissible (0.0 % ... 175.0 %).</li> <li>For the lower speed limit value only negative values are permissible (-175.0 % ... 0.0 %).</li> </ul>		
Setting range (min. value   unit   max. value)		
-175.0	%	175.0
Subcodes	Lenze setting	Information
C00909/1	175.0 %	Upper speed limit value
C00909/2	-175.0 %	Lower speed limit value
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C00950

Parameter   Name: <b>C00950   VFC: V/f characteristic shape</b>		Data type: UNSIGNED_32 Index: 23625 <sub>d</sub> = 5C49 <sub>h</sub>
<a href="#">From software version V3.0</a>		
<a href="#">▶ V/f control</a>		
Selection list (Lenze setting printed in bold)		
<b>0</b>	<b>Linear (V/f)</b>	
1	Quadratic (V/f <sup>2</sup> )	
2	Curve	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00951

Parameter   Name: <b>C00951   VFC: V/f base frequency</b>		Data type: INTEGER_32 Index: 23624 <sub>d</sub> = 5C48 <sub>h</sub>
<a href="#">From software version V3.0</a>		
<a href="#">▶ V/f control</a>		
Setting range (min. value   unit   max. value)		Lenze setting
1	Hz	5000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00952

## C00952

Parameter | Name: **C00952 | VFC: Frequency interpol. point n** Data type: INTEGER\_32  
Index: 23623<sub>d</sub> = 5C47<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)		
-5000	Hz	5000
Subcodes	Lenze setting	Information
C00952/1	-50 Hz	
C00952/2	-40 Hz	
C00952/3	-30 Hz	
C00952/4	-20 Hz	
C00952/5	-10 Hz	
C00952/6	0 Hz	
C00952/7	10 Hz	
C00952/8	20 Hz	
C00952/9	30 Hz	
C00952/10	40 Hz	
C00952/11	50 Hz	

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C00953

Parameter | Name: **C00953 | VFC: Voltage interpol. point n** Data type: INTEGER\_32  
Index: 23622<sub>d</sub> = 5C46<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)		
0.00	V	1000.00
Subcodes	Lenze setting	Information
C00953/1	400.00 V	
C00953/2	320.00 V	
C00953/3	240.00 V	
C00953/4	160.00 V	
C00953/5	80.00 V	
C00953/6	0.00 V	
C00953/7	80.00 V	
C00953/8	160.00 V	
C00953/9	240.00 V	
C00953/10	320.00 V	
C00953/11	400.00 V	

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 100

## C00954

Parameter | Name: **C00954 | VFC: Activat. interpol. point n** Data type: UNSIGNED\_32  
Index: 23621<sub>d</sub> = 5C45<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Selection list		
0	Off	
1	ON	
Subcodes	Lenze setting	Information
C00954/1	1: ON	
C00954/2	1: ON	
C00954/3	1: ON	
C00954/4	1: ON	
C00954/5	1: ON	
C00954/6	1: ON	
C00954/7	1: ON	
C00954/8	1: ON	
C00954/9	1: ON	
C00954/10	1: ON	
C00954/11	1: ON	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C00955

Parameter | Name: **C00955 | VFC: Vmax reduction** Data type: UNSIGNED\_32  
Index: 23620<sub>d</sub> = 5C44<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)	Lenze setting
0   V   500	<b>0 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1	

## C00957

Parameter | Name: **C00957 | VFC: VVC current setpoint** Data type: INTEGER\_32  
Index: 23618<sub>d</sub> = 5C42<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)	Lenze setting
0.00   A   1500.00	<b>0.00 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 100	

## C00958

Parameter | Name: **C00958 | VFC: VVC gain** Data type: UNSIGNED\_32  
Index: 23617<sub>d</sub> = 5C41<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)	Lenze setting
0.00   V/A   750.00	<b>0.00 V/A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 100	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00959

C00959

Parameter | Name: **C00959 | VFC: VVC reset time** Data type: UNSIGNED\_32  
Index: 23616<sub>d</sub> = 5C40<sub>h</sub>

From software version V3.0

▶ [V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.01	ms	2000.00	<b>2000.00 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00960

Parameter | Name: **C00960 | VFC: V/f voltage boost** Data type: INTEGER\_32  
Index: 23615<sub>d</sub> = 5C3F<sub>h</sub>

From software version V3.0

▶ [V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	V	1000	<b>0 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00961

Parameter | Name: **C00961 | VFC: Load - cw/ccw-operation** Data type: UNSIGNED\_32  
Index: 23614<sub>d</sub> = 5C3E<sub>h</sub>

From software version V3.0

▶ [V/f control](#)

Selection list (Lenze setting printed in bold)	
<b>0</b>	<b>CW: mot. / CCW: mot.</b>
1	CW: mot. / CCW: regen.
2	CW: regen. / CCW: mot.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1	

C00962

Parameter | Name: **C00962 | VFC: Load adjustment** Data type: UNSIGNED\_32  
Index: 23613<sub>d</sub> = 5C3D<sub>h</sub>

From software version V3.0

▶ [V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00	%	200.00	<b>20.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00963

Parameter | Name: **C00963 | VFC: Gain - I<sub>max</sub> controller** Data type: UNSIGNED\_32  
Index: 23612<sub>d</sub> = 5C3C<sub>h</sub>

From software version V3.0

▶ [V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.000	Hz/A	1000.000	<b>0.001 Hz/A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00964

Parameter | Name: **C00964 | VFC: Reset time - I<sub>max</sub> contr.** Data type: UNSIGNED\_32  
Index: 23611<sub>d</sub> = 5C3B<sub>h</sub>

From software version V3.0

▶ [V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
1.0	ms	2000.0	<b>100.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00965

Parameter | Name: **C00965 | VFC: Gain - slip compensation** Data type: INTEGER\_32  
Index: 23610<sub>d</sub> = 5C3A<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
-200.00	%	200.00	<b>0.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00966

Parameter | Name: **C00966 | VFC: Time const. - slip compens.** Data type: UNSIGNED\_32  
Index: 23609<sub>d</sub> = 5C39<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
1	ms	6000	<b>2000 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00967

Parameter | Name: **C00967 | VFC: Gain - oscillation damping** Data type: INTEGER\_32  
Index: 23608<sub>d</sub> = 5C38<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
-100	%	100	<b>20 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00968

Parameter | Name: **C00968 | VFC: Time const. - oscill. damp.** Data type: INTEGER\_32  
Index: 23607<sub>d</sub> = 5C37<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
1	ms	600	<b>5 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00969

Parameter | Name: **C00969 | VFC: Limitation - oscill. damp.** Data type: INTEGER\_32  
Index: 23606<sub>d</sub> = 5C36<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.1	Hz	20.0	<b>0.2 Hz</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00970

Parameter | Name: **C00970 | VFC: ramp-end frequ. - oscill. damp.** Data type: INTEGER\_32  
Index: 23605<sub>d</sub> = 5C35<sub>h</sub>

From software version V5.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	%	100	<b>0 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00971

C00971

Parameter | Name: **C00971 | VFC: Influence - speed controller** Data type: UNSIGNED\_32  
Index: 23604<sub>d</sub> = 5C34<sub>h</sub>

From software version V3.0 [▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00	%	100.00	<b>10.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00972

Parameter | Name: **C00972 | VFC: Gain - speed controller** Data type: UNSIGNED\_32  
Index: 23603<sub>d</sub> = 5C33<sub>h</sub>

From software version V3.0 [▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.000	Hz/rpm	1000.000	<b>0.000 Hz/rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00973

Parameter | Name: **C00973 | VFC: Reset time - speed contr.** Data type: UNSIGNED\_32  
Index: 23602<sub>d</sub> = 5C32<sub>h</sub>

From software version V3.0 [▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
1.0	ms	6000.0	<b>6000.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00974

Parameter | Name: **C00974 | DC brake: Current** Data type: INTEGER\_32  
Index: 23601<sub>d</sub> = 5C31<sub>h</sub>

From software version V3.0 [▶ DC-injection braking](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00	A	500.00	<b>0.00 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00975

Parameter | Name: **C00975 | DC brake: Current for quick stop** Data type: INTEGER\_32  
Index: 23600<sub>d</sub> = 5C30<sub>h</sub>

From software version V3.0 [▶ DC-injection braking](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00	A	500.00	<b>0.00 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00976

Parameter | Name: **C00976 | DC brake: Activat. by quick stop** Data type: UNSIGNED\_32  
Index: 23599<sub>d</sub> = 5C2F<sub>h</sub>

From software version V3.0 [▶ DC-injection braking](#)

Selection list (Lenze setting printed in bold)		Lenze setting
0	Off	
1	ON	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



## C00977

Parameter | Name: **C00977 | Min. inh-time aft. overvolt** Data type: UNSIGNED\_32  
Index: 23598<sub>d</sub> = 5C2E<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Setting range (min. value   unit   max. value)			Lenze setting
1	ms	10000	<b>500 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00980

Parameter | Name: **C00980 | VFC: Override point of field weakening** Data type: INTEGER\_32  
Index: 23599<sub>d</sub> = 5C2B<sub>h</sub>

Setting range (min. value   unit   max. value)			Lenze setting
-500	Hz	500	<b>0 Hz</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00985

Parameter | Name: **C00985 | SLVC: Gain - flux controller** Data type: UNSIGNED\_32  
Index: 23590<sub>d</sub> = 5C26<sub>h</sub>

From software version V3.0

[▶ Sensorless vector control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00		21474836.47	<b>0.00</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

## C00986

Parameter | Name: **C00986 | SLVC: Gain - cross curr. contr.** Data type: UNSIGNED\_32  
Index: 23589<sub>d</sub> = 5C25<sub>h</sub>

From software version V3.0

[▶ Sensorless vector control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00		21474836.47	<b>0.00</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

## C00987

Parameter | Name: **C00987 | SLVC: Gain - torque controller** Data type: UNSIGNED\_32  
Index: 23588<sub>d</sub> = 5C24<sub>h</sub>

From software version V3.0

[▶ Sensorless vector control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Hz/A	1000.0000	<b>0.5000 Hz/A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

## C00988

Parameter | Name: **C00988 | SLVC: Reset time - torque contr.** Data type: UNSIGNED\_32  
Index: 23587<sub>d</sub> = 5C23<sub>h</sub>

From software version V3.0

[▶ Sensorless vector control](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.01	ms	2000.00	<b>10.00 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00989

C00989

Parameter | Name: **C00989 | SLVC: Time const.- Para. adj.** Data type: UNSIGNED\_32  
Index: 23586<sub>d</sub> = 5C22<sub>h</sub>

From software version V3.0 ▶ [Sensorless vector control](#)

Setting range (min. value   unit   max. value)		
0	ms	20000
Subcodes	Lenze setting	Information
C00989/1	20000 ms	SLVC: Time const.- Para.Rs adj.
C00989/2	20000 ms	SLVC: Time const.- Para.Lh adj.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00990

Parameter | Name: **C00990 | Flying restart: Activation** Data type: UNSIGNED\_32  
Index: 23585<sub>d</sub> = 5C21<sub>h</sub>

From software version V8.0

Shifting the override point for field weakening

- In the VFCplus operating mode the pull-out protection function or the maximally permissible current in the field weakening range can be adapted.

From software version V3.0 ▶ [Flying restart function](#)

**Note!**  
Only deactivate the flying restart for the V/f control or sensorless vector control if it is ensured that the drive is always at standstill in the case of controller enable!

▶ [Flying restart function](#)

Selection list (Lenze setting printed in bold)	
0	<b>Off</b>
1	<b>ON</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1	

C00991

Parameter | Name: **C00991 | Flying restart: Current** Data type: INTEGER\_32  
Index: 23584<sub>d</sub> = 5C20<sub>h</sub>

From software version V3.0 ▶ [Flying restart function](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	%	100	<b>15 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00992

Parameter | Name: **C00992 | Flying restart: Start frequency** Data type: INTEGER\_32  
Index: 23583<sub>d</sub> = 5C1F<sub>h</sub>

From software version V3.0 ▶ [Flying restart function](#)

Setting range (min. value   unit   max. value)			Lenze setting
-600.0	Hz	600.0	<b>20.0 Hz</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

## C00993

Parameter | Name: **C00993 | Flying restart: Integration time** Data type: UNSIGNED\_32  
Index: 23582<sub>d</sub> = 5C1E<sub>h</sub>

From software version V3.0

[▶ Flying restart function](#)

Setting range (min. value   unit   max. value)			Lenze setting
1	ms	6000	<b>60 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00994

Parameter | Name: **C00994 | Flying restart: Min. deviation** Data type: UNSIGNED\_32  
Index: 23581<sub>d</sub> = 5C1D<sub>h</sub>

From software version V3.0

[▶ Flying restart function](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00	°	90.00	<b>5.00 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

## C00995

Parameter | Name: **C00995 | Flying restart: Delay time** Data type: UNSIGNED\_32  
Index: 23580<sub>d</sub> = 5C1C<sub>h</sub>

From software version V3.0

[▶ Flying restart function](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	ms	10000	<b>0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C00998

Parameter | Name: **C00998 | VFC: Frequency setpoint** Data type: INTEGER\_32  
Index: 23577<sub>d</sub> = 5C19<sub>h</sub>

From software version V3.0

[▶ V/f control](#)

Display range (min. value   unit   max. value)		
-800.0	Hz	800.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01120

C01120

Parameter | Name: **C01120 | Sync source** Data type: UNSIGNED\_8  
Index: 23455<sub>d</sub> = 5B9F<sub>h</sub>

Selection of the source for the synchronisation signals.

- The drive can only be synchronised by one source.

**Note:**  
Set the selection "2: CAN module" for the communication module CANopen (E94AYCCA).  
▶ ["CAN on board" system bus: sync telegram](#)

Selection list (Lenze setting printed in bold)	
0	<b>Off</b>
1	CAN on board
2	CAN module
4	Module in MXI1
5	Module in MXI2
6	Digital input 1
7	Digital input 2
8	Digital input 3
9	Digital input 4
10	Digital input 5
11	Digital input 6
12	Digital input 7
13	Digital input 8

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C01121

Parameter | Name: **C01121 | Sync cycle time** Data type: UNSIGNED\_32  
Index: 23454<sub>d</sub> = 5B9E<sub>h</sub>

Time interval at which the phase control loop (PLL) in the controller expects the synchronisation signals.

- The time interval set must correspond to the cycle of the synchronisation source.

**Note:** For synchronisation via the system bus (CANopen), only integer multiples of 1000 µs should be set.  
Example: For the system bus, the interval between two synchronisation signals is set to 2 ms. If the system bus is to be used as the synchronisation source, a synchronisation cycle of 2000 µs must be set in C01121.  
▶ ["CAN on board" system bus: sync telegram](#)

Setting range (min. value   unit   max. value)			Lenze setting
250	µs	20000	<b>1000 µs</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C01122

Parameter | Name: **C01122 | Sync phase position** Data type: UNSIGNED\_32  
Index: 23453<sub>d</sub> = 5B9D<sub>h</sub>

The phase position defines the zero point of time for the application relating to the synchronisation signal (bus cycle). Since PDO processing is integrated in the system part of the application, the instant of the PDO acceptance also changes if the phase position is changed.

- If 0 is set, the application is started together with the synchronisation signal.
- If a value > 0 is set, the application starts by the set time interval before the synchronisation signal arrives (the phase position acts negatively).

Example: If the phase position is set to 400 µs, the system part of the application starts 400 µs before the synchronisation signal arrives.

From software version V3.0:  
The effect of the sync phase position can be affected by the application cycle set in [C01130](#). For the Lenze setting of [C01130](#) the behaviour remains as before.  
▶ ["CAN on board" system bus: sync telegram](#)

Setting range (min. value   unit   max. value)			Lenze setting
0	µs	64000	<b>400 µs</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C01123

Parameter   Name: <b>C01123   Sync tolerance</b>			Data type: UNSIGNED_32 Index: 23452 <sub>d</sub> = 5B9C <sub>h</sub>
Time slot for monitoring the synchronisation signal via the <b>LS_SyncInput</b> system block			
<ul style="list-style-type: none"> <li>If the last synchronisation signal amounted to approx. the expected value within this time slot, the <b>SYNC_bSynclnsideWindow</b> output of the <b>LS_SyncInput</b> system block is set to TRUE.</li> <li>This setting does not affect the synchronisation process.</li> </ul>			
<a href="#">"CAN on board" system bus: sync telegram</a>			
Setting range (min. value   unit   max. value)			Lenze setting
0	µs	1000	<b>0 µs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C01124

Parameter   Name: <b>C01124   Sync-PLL increment</b>			Data type: UNSIGNED_8 Index: 23451 <sub>d</sub> = 5B9B <sub>h</sub>
When the cycle times of the synchronisation signal and the phase control loop (PLL) differ, this setting defines the increment to be used to readjust the phase control loop.			
<ul style="list-style-type: none"> <li>If the system bus (CANopen) is used as the synchronisation source, the recommended value is 109 ns.</li> </ul>			
<a href="#">"CAN on board" system bus: sync telegram</a>			
Selection list (Lenze setting printed in bold)			
1	7 ns		
2	15 ns		
3	23 ns		
4	31 ns		
5	39 ns		
6	46 ns		
7	54 ns		
8	62 ns		
9	70 ns		
10	78 ns		
11	85 ns		
12	93 ns		
13	101 ns		
14	<b>109 ns</b>		
15	117 ns		
16	125 ns		
17	132 ns		
18	140 ns		
19	148 ns		
20	156 ns		
21	164 ns		
22	171 ns		
23	179 ns		
24	187 ns		
25	195 ns		
26	203 ns		
27	210 ns		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01125

C01125

Parameter | Name: **C01125 | Service code** Data type: UNSIGNED\_32  
Index: 23450<sub>d</sub> = 5B9A<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01126

Parameter | Name: **C01126 | Service code** Data type: UNSIGNED\_32  
Index: 23449<sub>d</sub> = 5B99<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01127

Parameter | Name: **C01127 | Service code** Data type: UNSIGNED\_32  
Index: 23448<sub>d</sub> = 5B98<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01128

Parameter | Name: **C01128 | Service code** Data type: UNSIGNED\_32  
Index: 23447<sub>d</sub> = 5B97<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01129

Parameter | Name: **C01129 | Service code** Data type: UNSIGNED\_32  
Index: 23446<sub>d</sub> = 5B96<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01130

Parameter | Name: **C01130 | CAN SYNC application cycle** Data type: UNSIGNED\_16  
Index: 23445<sub>d</sub> = 5B95<sub>h</sub>

[From software version V3.0](#)

This parameter affects the effect of the sync phase position ([C01122](#)) regarding the instant of acceptance of the synchronous PDOs in the application and the instant of transmission of the synchronous PDOs on the system bus (CANopen).

- The resulting PDO delay can be calculated with the following formula taking into account an internal processing time of 150 µs: PDO delay = ([C01121](#) - [C01122](#) + 150 µs) modulo C01130
- For the Lenze setting, the behaviour remains as before, the sync phase position ([C01122](#)) is always calculated modulo 1000.
- The set value is automatically rounded down to multiples of 1000 µs.

▶ [Effect of C01130 on the sync phase position](#)

**Note:** Setting the application cycle to a higher value than the sync cycle time ([C01121](#)) results in undefined behaviour. The same applies if the value set for the sync phase position ([C01122](#)) is higher than the sync cycle time ([C01121](#)). In this case, the drive usually cannot send synchronous PDOs on the system bus anymore.

▶ ["CAN on board" system bus: sync telegram](#)

Setting range (min. value   unit   max. value)			Lenze setting
1000	µs	65000	<b>1000 µs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C01190

Parameter | Name: **C01190 | Motor thermal sensor** Data type: UNSIGNED\_32  
Index: 23385<sub>d</sub> = 5B59<sub>h</sub>

▶ [Motor temperature monitoring](#)

Selection list (Lenze setting printed in bold)	Information
<b>0</b> KTY83-110	Lenze standard KTY83-110 (MDSKX, MCS06)
1 Spec. characteristic	Characteristic defined via <a href="#">C01191</a> and <a href="#">C01192</a> .
2 KTY83-110 + 2 x PTC	Lenze standard KTY83-110 + 2 x PTC 150°C (MCS09-MCS19)
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1	

## C01191

Parameter | Name: **C01191 | Spec. charact.: temperature** Data type: UNSIGNED\_32  
Index: 23384<sub>d</sub> = 5B58<sub>h</sub>

The special thermal sensor characteristic is selected by setting [C01190](#)="1"

▶ [Motor temperature monitoring](#)

Setting range (min. value   unit   max. value)		
0	°C	255
Subcodes	Lenze setting	Information
C01191/1	25 °C	Value 1 for spec. thermal sensor characteristic
C01191/2	150 °C	Value 2 for spec. thermal sensor characteristic
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01192

Parameter | Name: **C01192 | Spec. characteristic: resistance** Data type: UNSIGNED\_32  
Index: 23383<sub>d</sub> = 5B57<sub>h</sub>

The special thermal sensor characteristic is selected by setting [C01190](#)="1"

▶ [Motor temperature monitoring](#)

Setting range (min. value   unit   max. value)		
0	Ohm	30000
Subcodes	Lenze setting	Information
C01192/1	1000 Ohm	Value 1 for spec. thermal sensor characteristic
C01192/2	2225 Ohm	Value 2 for spec. thermal sensor characteristic
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01193

Parameter | Name: **C01193 | Motor temp. feedback system** Data type: UNSIGNED\_16  
Index: 23382<sub>d</sub> = 5B56<sub>h</sub>

Selection of feedback system for motor temperature detection.

▶ [Motor temperature monitoring](#)

Selection list (Lenze setting printed in bold)	
<b>0</b>	Speed feedback
1	X7 (Input Resolver)
2	X8 (Input Encoder)
3	Reserved
4	Reserved
5	X7 and X8 parallel
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1	

## C01194

Parameter | Name: **C01194 | Motor operating temperature** Data type: INTEGER\_32  
Index: 23381<sub>d</sub> = 5B55<sub>h</sub>

Setting range (min. value   unit   max. value)		Lenze setting
1	°C	200
		<b>140 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01195

## C01195

Parameter   Name: <b>C01195   Influence winding I<sup>2</sup>xt mon.</b>		Data type: UNSIGNED_32 Index: 23380 <sub>d</sub> = 5B54 <sub>h</sub>
I <sup>2</sup> xt motor monitoring: Influence of the winding temperature		
<ul style="list-style-type: none"> <li>By setting "0 %", the time constant for the winding is not considered and the thermal model is only calculated with the time constant set for the housing/laminated core.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	%	100
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01196

Parameter   Name: <b>C01196   S1 torque characteristic I<sup>2</sup>xt mon.</b>		Data type: UNSIGNED_32 Index: 23379 <sub>d</sub> = 5B53 <sub>h</sub>
I <sup>2</sup> xt motor monitoring: Speed-dependent evaluation of the motor current		
<ul style="list-style-type: none"> <li>By selecting a characteristic, the permissible motor current is evaluated depending on speed for calculating the thermal motor utilisation.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	%	600
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C01196/1	0 %	S1 torque characteristic n1/nn
C01196/2	100 %	S1 torque characteristic I1/In
C01196/3	0 %	S1 torque characteristic n2/nn
C01196/4	100 %	S1 torque characteristic I2/In
C01196/5	100 %	S1 torque characteristic n3/nn
C01196/6	100 %	S1 torque characteristic I3/In
C01196/7	100 %	S1 torque characteristic n4/nn
C01196/8	100 %	S1 torque characteristic I4/In
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01198

Parameter   Name: <b>C01198   Async. motor: Stall protection</b>		Data type: UNSIGNED_32 Index: 23377 <sub>d</sub> = 5B51 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	%	100
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01199

Parameter   Name: <b>C01199   Enhanced Power</b>		Data type: UNSIGNED_32 Index: 23376 <sub>d</sub> = 5B50 <sub>h</sub>
From software version V3.0		
<b>Stop!</b>		
During operation with increased continuous power, the max. permissible ambient temperature is reduced to 40 °C. The overload current must be reduced. An overload current of 180 % for 10 s is no longer permissible during operation with increased continuous power.		
▶ <a href="#">Operation with increased continuous power</a>		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Enhanced Power off</b>	
1	Enhanced Power Mode 1 on	
2	Enhanced Power Mode 2 on	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



## C01200

Parameter | Name: **C01200 | Dual motor temperature** Data type: INTEGER\_32  
Index: 23375<sub>d</sub> = 5B4F<sub>h</sub>

From software version V7.0

▶ [Motor temperature monitoring](#)  
▶ [Motor temperature monitoring of a second motor](#)

Display range (min. value   unit   max. value)		
-200	°C	200
Subcodes		Information
C01200/1		Motor temperature via X7
C01200/2		Motor temperature via X8
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01201

Parameter | Name: **C01201 | Delay time for fan start** Data type: UNSIGNED\_32  
Index: 23374<sub>d</sub> = 5B4E<sub>h</sub>

Selection list (Lenze setting printed in bold)		Information
<b>0</b>	Via power section serial no.	
1	500 ms	
2	1000 ms	
3	1500 ms	
4	2000 ms	
5	2500 ms	
6	3000 ms	
7	3500 ms	
8	4000 ms	
9	4500 ms	
10	5000 ms	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01203

Parameter | Name: **C01203 | Counter: Brake chopper overload** Data type: UNSIGNED\_16  
Index: 23372<sub>d</sub> = 5B4C<sub>h</sub>

Display range (min. value   unit   max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01204

Parameter | Name: **C01204 | Counter: Ixt overload** Data type: UNSIGNED\_16  
Index: 23371<sub>d</sub> = 5B4B<sub>h</sub>

Display range (min. value   unit   max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C01205

Parameter | Name: **C01205 | Counter: DC bus overvoltage** Data type: UNSIGNED\_16  
Index: 23370<sub>d</sub> = 5B4A<sub>h</sub>

Display range (min. value   unit   max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01206

C01206

Parameter   Name:		Data type: UNSIGNED_16 Index: 23369 <sub>d</sub> = 5B49 <sub>h</sub>
<b>C01206   Counter: Mains switching</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C01208

Parameter   Name:		Data type: UNSIGNED_16 Index: 23367 <sub>d</sub> = 5B47 <sub>h</sub>
<b>C01208   Counter: Heatsink overtemp.</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C01209

Parameter   Name:		Data type: UNSIGNED_16 Index: 23366 <sub>d</sub> = 5B46 <sub>h</sub>
<b>C01209   Counter: Housing overtemp.</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C01210

Parameter   Name:		Data type: UNSIGNED_8 Index: 23365 <sub>d</sub> = 5B45 <sub>h</sub>
<b>C01210   Counter: Internal</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		255
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C01211

Parameter   Name:		Data type: UNSIGNED_32 Index: 23364 <sub>d</sub> = 5B44 <sub>h</sub>
<b>C01211   Service code</b>		
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C01212

Parameter   Name:		Data type: UNSIGNED_16 Index: 23363 <sub>d</sub> = 5B43 <sub>h</sub>
<b>C01212   Counter: Power section overload</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C01213

Parameter   Name:		Data type: UNSIGNED_32 Index: 23362 <sub>d</sub> = 5B42 <sub>h</sub>
<b>C01213   Service code DataFlash</b>		
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

## C01214

Parameter | Name: **C01214 | Internal clock** Data type: VISIBLE\_STRING  
Index: 23361<sub>d</sub> = 5B41<sub>h</sub>

Display of the system time of the controller in the format "dd/mm/yyyy hh:mm:ss"

- Time and date are set via [C01215](#).

If the MM440 memory module with real-time clock is plugged into the controller, the internal clock is adjusted to the real-time clock every time the mains is switched on and every 24 hours at 0:00 o'clock.

- The daily adjustment is executed on a low-priority level. This is why it may take some seconds until the adjusted time is displayed.
- During the adjustment process, status information of the real-time clock is also queried and entered into the logbook.

**Note:**

If a memory module without real-time clock is plugged into the controller, the internal clock is initialised with "01.01.1970 00:00:00" every time the mains is switched on.

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C01215

Parameter | Name: **C01215 | Set time and date** Data type: UNSIGNED\_16  
Index: 23360<sub>d</sub> = 5B40<sub>h</sub>

From software version V1.5

Setting of the system time of the controller displayed in [C01214](#).

- If the MM440 memory module with real-time clock is plugged into the controller, the real-time clock is set simultaneously.

Set time and date.

- Before writing to a subcode for the first time, the current time information according to the internal clock is displayed in the subcodes.
- When a value has been written into a subcode, the displays in the subcodes freeze to the last values.
- The new system time set is only accepted after a value has been written into each subcode at least once.
- After the new system time has been accepted, the display in the subcodes is updated according to the internal clock.

**Note:**

If a memory module without real-time clock is plugged into the controller, the internal clock is initialised with "01.01.1970 00:00:00" every time the mains is switched on.

Setting range (min. value   unit   max. value)		
0		65535
Subcodes	Lenze setting	Information
C01215/1	0	Seconds
C01215/2	0	Minutes
C01215/3	0	Hours
C01215/4	1	Day
C01215/5	1	Month
C01215/6	1970	Year

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C01217

Parameter | Name: **C01217 | Service code** Data type: VISIBLE\_STRING  
Index: 23358<sub>d</sub> = 5B3E<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

## C01218

Parameter | Name: **C01218 | Service code** Data type: UNSIGNED\_32  
Index: 23357<sub>d</sub> = 5B3D<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01220

C01220

Parameter | Name: **C01220 | MEC history: RAM address** Data type: UNSIGNED\_32  
Index: 23355<sub>d</sub> = 5B3B<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01221

Parameter | Name: **C01221 | MEC history: RAM value** Data type: UNSIGNED\_32  
Index: 23354<sub>d</sub> = 5B3A<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01222

Parameter | Name: **C01222 | MEC history: Flash value** Data type: UNSIGNED\_32  
Index: 23353<sub>d</sub> = 5B39<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01223

Parameter | Name: **C01223 | MEC history: Error number** Data type: UNSIGNED\_32  
Index: 23352<sub>d</sub> = 5B38<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C01230

Parameter | Name: **C01230 | Resp. to communication task overflow** Data type: UNSIGNED\_8  
Index: 23345<sub>d</sub> = 5B31<sub>h</sub>

Selection list (Lenze setting printed in bold)	Information
<b>1</b> Fault	
2 Trouble	
3 Quick stop by trouble	
4 Warning locked	
5 Warning	
6 Information	
0 No response	

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C01501

Parameter | Name: **C01501 | Resp. to comm. error with MXI1** Data type: UNSIGNED\_32  
Index: 23074<sub>d</sub> = 5A22<sub>h</sub>

Response to communication error between "intelligent" module in module slot 1 and basic device

Selection list (Lenze setting printed in bold)	Information
<b>0</b> No response	
1 Fault	
3 Quick stop by trouble	
4 Warning locked	
5 Warning	

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C01502

Parameter   Name: <b>C01502   Resp. to comm. error with MXI2</b>	Data type: UNSIGNED_32 Index: 23073 <sub>d</sub> = 5A21 <sub>h</sub>
Response to communication error between "intelligent" module in module slot 2 and standard device	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>No response</b>
1	Fault
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C01510

Parameter   Name: <b>C01510   Ethernet IP address client x</b>	Data type: VISIBLE_STRING Index: 23065 <sub>d</sub> = 5A19 <sub>h</sub>
Display of the three possible server channels	
<ul style="list-style-type: none"> <li>If a client is connected via one of these server channels, the IP address and the port of the client will be indicated in the form of "xxx.xxx.xxx.xxx : yyyy".</li> <li>If no client is connected via the server channel, "---.---.---.--- : ----" will be indicated.</li> </ul>	
<b>Subcodes</b>	
C01510/1	Server channel 1 ... 3
C01510/...	
C01510/3	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C01511

Parameter   Name: <b>C01511   Ethernet status client x</b>	Data type: UNSIGNED_8 Index: 23064 <sub>d</sub> = 5A18 <sub>h</sub>
Status of the three possible server channels	
<b>Selection list</b> (display only)	
0	Not connected
1	Connected
2	Stop
3	Unknown status
<b>Subcodes</b>	
C01511/1	State of server channels 1 ... 3
C01511/...	
C01511/3	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01902

C01902

Parameter | Name: **C01902 | Diagnostics X6: Max. baud rate** Data type: UNSIGNED\_32  
Index: 22673<sub>d</sub> = 5891<sub>h</sub>

Maximum permissible baud rate of the standard device after determination of the baud rate at the diagnostic interface X6

- Communication starts with the default standard device baud rate of 19200 baud.

Selection list (Lenze setting printed in bold)	
9600	9600 baud
19200	19.200 baud
38400	38.400 baud
57600	57.600 baud
115200	115.200 baud
230400	230.400 baud
375000	375.000 baud
750000	750.000 baud
1500000	1.500.000 baud
<b>3000000</b>	<b>3.000.000 baud</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C01903

Parameter | Name: **C01903 | Diagnostics X6: Change baud rate** Data type: UNSIGNED\_32  
Index: 22672<sub>d</sub> = 5890<sub>h</sub>

New determination of the baud rate at the diagnostic interface X6

Selection list (Lenze setting printed in bold)	
1	Set a higher baud rate
<b>0</b>	<b>Ignore changes</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C01905

Parameter | Name: **C01905 | Diagnostics X6: Curr. baud rate** Data type: UNSIGNED\_32  
Index: 22670<sub>d</sub> = 588E<sub>h</sub>

Current baud rate at diagnostics interface X6

Display range (min. value   unit   max. value)	
0	3000000

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02104

Parameter | Name: **C02104 | Program auto-start** Data type: UNSIGNED\_32  
Index: 22471<sub>d</sub> = 57C7<sub>h</sub>

Selection list (Lenze setting printed in bold)	
0	Off
<b>1</b>	<b>Autom. after mains connection</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02108

Parameter | Name: **C02108 | Program status** Data type: UNSIGNED\_8  
Index: 22467<sub>d</sub> = 57C3<sub>h</sub>

Selection list (display only)	
1	Program stopped
0	Program is running
2	Program stopped at breakpoint

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02109

Parameter   Name: <b>C02109   Program runtime</b>		Data type: UNSIGNED_16 Index: 22466 <sub>d</sub> = 57C2 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	µs	65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02110

Parameter   Name: <b>C02110   User code memory load</b>		Data type: UNSIGNED_32 Index: 22465 <sub>d</sub> = 57C1 <sub>h</sub>
From software version V2.0		
<b>Display range (min. value   unit   max. value)</b>		
0	%	100
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02111

Parameter   Name: <b>C02111   Resp. to task overflow</b>		Data type: UNSIGNED_8 Index: 22464 <sub>d</sub> = 57C0 <sub>h</sub>
From software version V5.0		
Response to a task overflow in the application or user task.		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>1</b>	<b>Fault</b>	
3	Quick stop by trouble	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02113

Parameter   Name: <b>C02113   Program name</b>		Data type: VISIBLE_STRING Index: 22462 <sub>d</sub> = 57BE <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02121

Parameter   Name: <b>C02121   Runtime ApplicationTask</b>		Data type: UNSIGNED_32 Index: 22454 <sub>d</sub> = 57B6 <sub>h</sub>
▶ <a href="#">Runtime measurement</a>		
<b>Display range (min. value   unit   max. value)</b>		
0	µs	3600000000
<b>Subcodes</b>		<b>Information</b>
C02121/1		Curr. runtime ApplicationTask
C02121/2		Max. runtime ApplicationTask
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02122

Parameter   Name: <b>C02122   Runtime UserTask</b>		Data type: UNSIGNED_32 Index: 22453 <sub>d</sub> = 57B5 <sub>h</sub>
▶ <a href="#">Runtime measurement</a>		
<b>Display range (min. value   unit   max. value)</b>		
0	µs	3600000000
<b>Subcodes</b>		<b>Information</b>
C02122/1		Curr. runtime UserTask
C02122/2		Max. runtime UserTask
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02123

## C02123

Parameter   Name: <b>C02123   Runtime IdleTask</b>		Data type: UNSIGNED_32 Index: 22452 <sub>d</sub> = 57B4 <sub>h</sub>
<a href="#">▶ Runtime measurement</a>		
<b>Display range (min. value   unit   max. value)</b>		
0	µs	3600000000
<b>Subcodes</b>		<b>Information</b>
C02123/1		Curr. runtime IdleTask
C02123/2		Max. runtime IdleTask
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02520

Parameter   Name: <b>C02520   Gearbox factor numerator: Motor</b>		Data type: INTEGER_32 Index: 22055 <sub>d</sub> = 5627 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1		2147483647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02521

Parameter   Name: <b>C02521   Gearbox factor denom.: Motor</b>		Data type: INTEGER_32 Index: 22054 <sub>d</sub> = 5626 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1		2147483647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02522

Parameter   Name: <b>C02522   Gearbox factor num.: Pos. enc.</b>		Data type: INTEGER_32 Index: 22053 <sub>d</sub> = 5625 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1		2147483647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02523

Parameter   Name: <b>C02523   Gearbox fac. denom.: Pos. enc.</b>		Data type: INTEGER_32 Index: 22052 <sub>d</sub> = 5624 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1		2147483647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02524

Parameter   Name: <b>C02524   Feed constant</b>		Data type: UNSIGNED_32 Index: 22051 <sub>d</sub> = 5623 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0001	Unit/rev.	214748.3647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000



## C02525

Parameter | Name: **C02525 | Unit** Data type: UNSIGNED\_32  
Index: 22050<sub>d</sub> = 5622<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)		Information
0	User-defined	The text entered in <a href="#">C02526</a> is displayed for the unit.
1	Incr.	
2	µm	
3	mm	
4	m	
5	inch	
6	yard	
7	°	

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02526

Parameter | Name: **C02526 | User-defined unit** Data type: VISIBLE\_STRING  
Index: 22049<sub>d</sub> = 5621<sub>h</sub>

User-defined unit which is displayed when [C02525](#)="0" is selected.

[▶ Drive interface](#)

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02527

Parameter | Name: **C02527 | Motor mounting direction** Data type: UNSIGNED\_32  
Index: 22048<sub>d</sub> = 5620<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)	
0	<b>Motor rotating CW</b>
1	Motor rotating CCW

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02528

Parameter | Name: **C02528 | Traversing range** Data type: UNSIGNED\_32  
Index: 22047<sub>d</sub> = 561F<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)	
0	<b>Unlimited</b>
1	Limited
2	Modulo

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02529

Parameter | Name: **C02529 | Position encoder mounting dir.** Data type: UNSIGNED\_32  
Index: 22046<sub>d</sub> = 561E<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)	
0	<b>Encoder rotating CW</b>
1	Encoder rotating CCW

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02530

## C02530

Parameter | Name: **C02530 | Active function state** Data type: INTEGER\_32  
Index: 22045<sub>d</sub> = 561D<sub>h</sub>

Displays the basic drive function that currently controls the drive.

► [Basic drive functions: Internal state machine](#)

Selection list (display only)	
0	Program stopped
1	Initial/boot state active
2	Torque follower active
3	Speed follower active
4	Position follower active
5	Setpoint follower active
6	Positioning active
7	Homing active
8	Manual jog active
9	Brake test active
10	Drive at standstill
11	Drive is stopped
12	Quick stop active
13	Reserve 1
14	Controller is not ready
15	Initialisation
16	Fault
17	Manual control open loop active
18	Pole position identification active

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02531

Parameter | Name: **C02531 | Gearbox factors (decimal)** Data type: UNSIGNED\_32  
Index: 22044<sub>d</sub> = 561C<sub>h</sub>

**Note:** In subcode 3 the effective gearbox factor resulting from the motor and the load is displayed if a separate position encoder is configured and the position control is activated (C02570="2"). For a different encoder configuration (without a separate position encoder) the value "1" is shown in subcode 3.

► [Drive interface](#)

Display range (min. value   unit   max. value)		
0.000		2147483.647

Subcodes	Information
C02531/1	Motor gearbox factor (dec.)
C02531/2	Pos. enc. gearbox factor (dec.)
C02531/3	Effective gearbox factor (dec.)

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1000

## C02532

Parameter | Name: **C02532 | Resolution of a unit** Data type: UNSIGNED\_32  
Index: 22043<sub>d</sub> = 561B<sub>h</sub>

► [Drive interface](#)

Display range (min. value   unit   max. value)		
0	Incr./unit	2147483647

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02533

Parameter   Name: <b>C02533   Time unit</b>	Data type: UNSIGNED_32 Index: 22042 <sub>d</sub> = 561A <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Selection list (display only)</b>	
2 s	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02534

Parameter   Name: <b>C02534   Used time unit</b>	Data type: VISIBLE_STRING Index: 22041 <sub>d</sub> = 5619 <sub>h</sub>
Display of the time unit as a character string	
<a href="#">▶ Drive interface</a>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02535

Parameter   Name: <b>C02535   Used unit</b>	Data type: VISIBLE_STRING Index: 22040 <sub>d</sub> = 5618 <sub>h</sub>
Display of the unit set in <a href="#">C02525</a> and <a href="#">C02526</a> as a character string	
<a href="#">▶ Drive interface</a>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02536

Parameter   Name: <b>C02536   Cycle</b>	Data type: UNSIGNED_32 Index: 22039 <sub>d</sub> = 5617 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
0.0000      Unit      214748.3647	<b>360.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000	

C02537

Parameter   Name: <b>C02537   Speed unit</b>	Data type: VISIBLE_STRING Index: 22038 <sub>d</sub> = 5616 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02538

Parameter   Name: <b>C02538   Acceleration unit</b>	Data type: VISIBLE_STRING Index: 22037 <sub>d</sub> = 5615 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02539

Parameter   Name: <b>C02539   Max. presentable position</b>	Data type: INTEGER_32 Index: 22036 <sub>d</sub> = 5614 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647      Unit      214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02540

C02540

Parameter   Name: <b>C02540   Max. presentable speed</b>	Data type: INTEGER_32 Index: 22035 <sub>d</sub> = 5613 <sub>h</sub>	
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02541

Parameter   Name: <b>C02541   Max. presentable acceleration</b>	Data type: INTEGER_32 Index: 22034 <sub>d</sub> = 5612 <sub>h</sub>	
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s <sup>2</sup>	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02542

Parameter   Name: <b>C02542   Load reference speed</b>	Data type: UNSIGNED_32 Index: 22033 <sub>d</sub> = 5611 <sub>h</sub>	
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0.000	rpm	4294967.295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02543

Parameter   Name: <b>C02543   Load reference torque</b>	Data type: UNSIGNED_32 Index: 22032 <sub>d</sub> = 5610 <sub>h</sub>	
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0.000	Nm	4294967.295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02544

Parameter   Name: <b>C02544   Reference speed</b>	Data type: INTEGER_32 Index: 22031 <sub>d</sub> = 560F <sub>h</sub>	
From software version V1.5		
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02545

Parameter   Name: <b>C02545   Reference S-ramp time</b>	Data type: UNSIGNED_32 Index: 22030 <sub>d</sub> = 560E <sub>h</sub>		
From software version V7.0			
<a href="#">▶ Drive interface</a>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.000	s	2147483.647	<b>0.001 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000	

## C02547

Parameter   Name: <b>C02547   DI_dnState</b>	Data type: INTEGER_32 Index: 22028 <sub>d</sub> = 560C <sub>h</sub>
Bit coded status of the <a href="#">drive interface</a> .	
<b>Display range (min. value   unit   max. value)</b>	
-2147483648	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02548

Parameter   Name: <b>C02548   DI_bErrors</b>	Data type: UNSIGNED_32 Index: 22027 <sub>d</sub> = 560B <sub>h</sub>
Display of the digital error signals of the <a href="#">drive interface</a> .	
<b>Selection list (display only)</b>	
0 FALSE	
1 TRUE	
<b>Subcodes</b>	<b>Information</b>
C02548/1	DI_bResetError1
C02548/2	DI_bResetError2
C02548/3	DI_bResetError3
C02548/4	DI_bSetExternError
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02549

Parameter   Name: <b>C02549   Drive interface: Signals</b>	Data type: UNSIGNED_32 Index: 22026 <sub>d</sub> = 560A <sub>h</sub>
Display of the digital signals of the <a href="#">drive interface</a> .	
<b>Selection list (display only)</b>	
0 FALSE	
1 TRUE	
<b>Subcodes</b>	<b>Information</b>
C02549/1	DI_bSetCInh
C02549/2	Reserved
C02549/3	Reserved
C02549/4	DI_bSwitchOn
C02549/5	Reserved
C02549/6	DI_bReady
C02549/7	DI_bFailActive
C02549/8	DI_bImpActive
C02549/9	DI_bCinhActive
C02549/10	DI_bWarningActive
C02549/11	DI_bUVDetected
C02549/12	DI_bOVDetected
C02549/13	DI_bMainSupplyOk
C02549/14	DI_bReadyToSwitchOn
C02549/15	DI_bOperationEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02550

C02550

Parameter | Name: **C02550 | Setpoint interpolation** Data type: UNSIGNED\_32  
Index: 22025<sub>d</sub> = 5609<sub>h</sub>

[▶ Motor interface](#)

Selection list	
0	Off
1	ON

Subcodes	Lenze setting	Information
C02550/1	1: ON	Position setpoint interpolat.
C02550/2	1: ON	Speed setpoint interpolat.
C02550/3	1: ON	Torque setpoint interpolat.

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02552

Parameter | Name: **C02552 | Position setpoint (mctrl)** Data type: INTEGER\_32  
Index: 22023<sub>d</sub> = 5607<sub>h</sub>

[▶ Motor interface](#)

Display range (min. value   unit   max. value)		
-214748.3647	Unit	214748.3647

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 10000

C02553

Parameter | Name: **C02553 | Position controller gain** Data type: UNSIGNED\_32  
Index: 22022<sub>d</sub> = 5606<sub>h</sub>

[▶ Motor interface](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.00	1/s	1000.00	<b>20.00 1/s</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 100

C02554

Parameter | Name: **C02554 | Position controller reset time** Data type: UNSIGNED\_32  
Index: 22021<sub>d</sub> = 5605<sub>h</sub>

[▶ Motor interface](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.001	s	60.000	<b>60.000 s</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1000

C02555

Parameter | Name: **C02555 | D component position controller** Data type: UNSIGNED\_32  
Index: 22020<sub>d</sub> = 5604<sub>h</sub>

[▶ Motor interface](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.000		100.000	<b>0.000</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1000

C02556

Parameter | Name: **C02556 | Pos. contr. limitation** Data type: INTEGER\_32  
Index: 22019<sub>d</sub> = 5603<sub>h</sub>

[▶ Motor interface](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s	214748.3647	<b>214748.3647 Unit/s</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 10000

## C02557

Parameter   Name: <b>C02557   Phase controller output</b>	Data type: INTEGER_32 Index: 22018 <sub>d</sub> = 5602 <sub>h</sub>
<a href="#">▶ Motor interface</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit/s 214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000	

## C02558

Parameter   Name: <b>C02558   Pos. contr. output</b>	Data type: INTEGER_32 Index: 22017 <sub>d</sub> = 5601 <sub>h</sub>
<a href="#">▶ Motor interface</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit/s 214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000	

## C02559

Parameter   Name: <b>C02559   Internal torque limits</b>	Data type: INTEGER_32 Index: 22016 <sub>d</sub> = 5600 <sub>h</sub>
<a href="#">▶ Motor interface</a>	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<b>Subcodes</b>	<b>Information</b>
C02559/1	Upper int. torque limit
C02559/2	Lower int. torque limit
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

## C02560

Parameter   Name: <b>C02560   Messages - motor interface</b>	Data type: UNSIGNED_32 Index: 22015 <sub>d</sub> = 55FF <sub>h</sub>
<a href="#">▶ Motor interface</a>	
<b>Display range (min. value   unit   max. value)</b>	
0	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02561

Parameter   Name: <b>C02561   Speed feedfor. control gain</b>	Data type: INTEGER_32 Index: 22014 <sub>d</sub> = 55FE <sub>h</sub>
From software version V1.5 Percentage reduction of the speed feedforward control of the profile generator	
<ul style="list-style-type: none"> <li>• Required in some applications if a 100 % speed feedforward control causes overshoots.</li> <li>• Only effective for the basic functions "Positioning", "Homing" and "Manual jog".</li> </ul>	
<a href="#">▶ Motor interface</a>	
<b>Setting range (min. value   unit   max. value)</b>	
50.00	% 100.00
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	
<b>Lenze setting</b>	
100.00 %	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02562

C02562

Parameter   Name: <b>C02562   Filter time constant</b>		Data type: UNSIGNED_32 Index: 22013 <sub>d</sub> = 55FD <sub>h</sub>
From software version V7.0		
<a href="#">▶ Motor interface</a>		
Setting range (min. value   unit   max. value)		Lenze setting
0.000	s	60.000
		<b>0.002 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02567

Parameter   Name: <b>C02567   Control mode</b>		Data type: UNSIGNED_32 Index: 22008 <sub>d</sub> = 55F8 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
Selection list (display only)		
0	Position control	
1	Speed control	
2	Torque control	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02568

Parameter   Name: <b>C02568   Motor interface: % signals</b>		Data type: INTEGER_32 Index: 22007 <sub>d</sub> = 55F7 <sub>h</sub>
Display of the scaled signals of the <a href="#">motor interface</a> .		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
Subcodes	Information	
C02568/1	MI_dnPosCtrlAdaptLoad_n	
C02568/2	MI_dnPosCtrlAdaptMotor_n	
C02568/3	MI_dnSpeedCtrlAdapt_n	
C02568/4	MI_dnTorqueHighLimit_n	
C02568/5	MI_dnTorqueLowLimit_n	
C02568/6	MI_dnTorqueCtrlAdapt_n	
C02568/7	MI_dnFluxSetpoint_n	
C02568/8	MI_dnInertiaAdapt_n	
C02568/9	MI_dnBoostSet_n	
C02568/10	MI_dnTorqueAdd_n	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100



## C02569

Parameter   Name: <b>C02569   Motor interface.: Dig. signals</b>		Data type: UNSIGNED_32 Index: 22006 <sub>d</sub> = 55F6 <sub>h</sub>
Display of the digital signals of the <a href="#">motor interface</a> .		
Selection list (display only)		
0	FALSE	
1	TRUE	
Subcodes	Information	
C02569/1	Reserved	
C02569/2	MI_bResetSpeedCtrlIntegrator	
C02569/3	MI_bLimitationActive	
C02569/4	MI_bPosCtrlLimited	
C02569/5	MI_bSpeedSetPointLimited	
C02569/6	MI_bSpeedCtrlLimited	
C02569/7	MI_bTorqueSetpointLimited	
C02569/8	MI_bCurrentSetpointLimited	
C02569/9	MI_bSpeedBelowC19	
C02569/10	MI_bSpeedFollowingError	
C02569/11	MI_bMotorOverloadWarning	
C02569/12	MI_bMotorOrientationInverse	
C02569/13	MI_bFlyingSyncBusy	
C02569/14	MI_bClampsActive	
C02569/15	MI_bMagnetisationFinished	
C02569/16	MI_bFlyingSyncBlocked	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02570

Parameter   Name: <b>C02570   Position control structure</b>		Data type: UNSIGNED_32 Index: 22005 <sub>d</sub> = 55F5 <sub>h</sub>
Chapter " <a href="#">Controller configuration</a> " provides you with more information on parameter setting.		
▶ <a href="#">Encoder evaluation</a>		
Selection list (Lenze setting printed in bold)		Information
<b>1</b>	<b>Phase controller is active</b>	Motor encoder selection is effected in <a href="#">C00495</a> .
2	Position controller active (&lt;= FW V5.xx)	Position controller selection is effected in <a href="#">C00490</a> .
3	Position controller is active	Position controller selection is effected in <a href="#">C00490</a> .
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02571

Parameter   Name: <b>C02571   Source - actual position</b>		Data type: UNSIGNED_32 Index: 22004 <sub>d</sub> = 55F4 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

## C02572

Parameter   Name: <b>C02572   Speed setpoint (enc. eval.)</b>		Data type: INTEGER_32 Index: 22003 <sub>d</sub> = 55F3 <sub>h</sub>
▶ <a href="#">Encoder evaluation</a>		
Display range (min. value   unit   max. value)		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02573

C02573

Parameter   Name: <b>C02573   Position setpoint (enc. eval.)</b>	Data type: INTEGER_32 Index: 22002 <sub>d</sub> = 55F2 <sub>h</sub>	
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10000		

C02574

Parameter   Name: <b>C02574   Actual speed (enc. eval.)</b>	Data type: INTEGER_32 Index: 22001 <sub>d</sub> = 55F1 <sub>h</sub>	
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10000		

C02575

Parameter   Name: <b>C02575   Actual position (enc. eval.)</b>	Data type: INTEGER_32 Index: 22000 <sub>d</sub> = 55F0 <sub>h</sub>	
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10000		

C02576

Parameter   Name: <b>C02576   Following error</b>	Data type: INTEGER_32 Index: 21999 <sub>d</sub> = 55EF <sub>h</sub>	
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10000		

C02577

Parameter   Name: <b>C02577   External actual position</b>	Data type: INTEGER_32 Index: 21998 <sub>d</sub> = 55EE <sub>h</sub>	
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10000		

C02578

Parameter   Name: <b>C02578   Offset actual pos. value/setp.</b>	Data type: INTEGER_32 Index: 21997 <sub>d</sub> = 55ED <sub>h</sub>	
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 10000		

## C02579

Parameter   Name: <b>C02579   Encoder eval.: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21996 <sub>d</sub> = 55EC <sub>h</sub>
Display of the digital signals of the <a href="#">encoder evaluation</a> .		
<b>Selection list (display only)</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02579/1		FDB_bResolverError
C02579/2		FDB_bSinCosSignalError
C02579/3		FDB_bEncoderComError
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02580

Parameter   Name: <b>C02580   Operating mode brake</b>		Data type: UNSIGNED_32 Index: 21995 <sub>d</sub> = 55EB <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Brake control off</b>	
1	Directly with brake module	
2	Autom. with brake module	
11	Directly - external switching	
12	Autom. - external switching	
22	Autom. - DC brake	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02581

Parameter   Name: <b>C02581   Threshold - brake activation</b>		Data type: INTEGER_32 Index: 21994 <sub>d</sub> = 55EA <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	rpm	50000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02582

Parameter   Name: <b>C02582   Brake resp. to pulse inhibit</b>		Data type: UNSIGNED_32 Index: 21993 <sub>d</sub> = 55E9 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Activate the brake immediately</b>	
1	Activate brake at n &lt; nmin	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02583

Parameter   Name: <b>C02583   Status input monitoring</b>		Data type: UNSIGNED_32 Index: 21992 <sub>d</sub> = 55E8 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Not active</b>	
1	Active	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02585

C02585

Parameter | Name: **C02585 | Brake control polarity** Data type: UNSIGNED\_32  
Index: 21990<sub>d</sub> = 55E6<sub>h</sub>

▶ Basic function "[Brake control](#)"

Selection list (Lenze setting printed in bold)	
<b>0</b>	Not inverted
1	Inverted

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02586

Parameter | Name: **C02586 | Starting torque 1** Data type: INTEGER\_32  
Index: 21989<sub>d</sub> = 55E5<sub>h</sub>

▶ Basic function "[Brake control](#)"

Setting range (min. value   unit   max. value)			Lenze setting
-21474836.47	Nm	21474836.47	<b>0.00 Nm</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 100

C02587

Parameter | Name: **C02587 | Starting torque 2** Data type: INTEGER\_32  
Index: 21988<sub>d</sub> = 55E4<sub>h</sub>

▶ Basic function "[Brake control](#)"

Setting range (min. value   unit   max. value)			Lenze setting
-21474836.47	Nm	21474836.47	<b>0.00 Nm</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 100

C02588

Parameter | Name: **C02588 | Source of starting torque** Data type: UNSIGNED\_32  
Index: 21987<sub>d</sub> = 55E3<sub>h</sub>

▶ Basic function "[Brake control](#)"

Selection list (Lenze setting printed in bold)	
<b>0</b>	Starting torque 1/2
1	Stopping value

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02589

Parameter | Name: **C02589 | Brake closing time** Data type: UNSIGNED\_32  
Index: 21986<sub>d</sub> = 55E2<sub>h</sub>

▶ Basic function "[Brake control](#)"

Setting range (min. value   unit   max. value)			Lenze setting
0	ms	60000	<b>100 ms</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02590

Parameter | Name: **C02590 | Brake opening time** Data type: UNSIGNED\_32  
Index: 21985<sub>d</sub> = 55E1<sub>h</sub>

▶ Basic function "[Brake control](#)"

Setting range (min. value   unit   max. value)			Lenze setting
0	ms	60000	<b>100 ms</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02591

Parameter   Name: <b>C02591   Waiting time - state monitoring</b>		Data type: UNSIGNED_32 Index: 21984 <sub>d</sub> = 55E0 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0	ms	60000	<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C02593

Parameter   Name: <b>C02593   Waiting time - brake activation</b>		Data type: UNSIGNED_32 Index: 21982 <sub>d</sub> = 55DE <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.000	s	1000.000	<b>0.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

## C02594

Parameter   Name: <b>C02594   Test torque</b>		Data type: INTEGER_32 Index: 21981 <sub>d</sub> = 55DD <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
-21474836.47	Nm	21474836.47	<b>0.00 Nm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

## C02595

Parameter   Name: <b>C02595   Permissible angle of rotation</b>		Data type: INTEGER_32 Index: 21980 <sub>d</sub> = 55DC <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0	°	360	<b>5 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C02596

Parameter   Name: <b>C02596   Grinding speed</b>		Data type: INTEGER_32 Index: 21979 <sub>d</sub> = 55DB <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0	rpm	300	<b>100 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C02597

Parameter   Name: <b>C02597   Accel./decel. time - grinding</b>		Data type: UNSIGNED_32 Index: 21978 <sub>d</sub> = 55DA <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.000	s	60.000	<b>1.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02598

C02598

Parameter   Name: <b>C02598   Grinding ON time</b>		Data type: UNSIGNED_32 Index: 21977 <sub>d</sub> = 55D9 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.2	s	2.0	<b>0.5 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C02599

Parameter   Name: <b>C02599   Grinding OFF time</b>		Data type: UNSIGNED_32 Index: 21976 <sub>d</sub> = 55D8 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.2	s	2.0	<b>0.5 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C02600

Parameter   Name: <b>C02600   Acceleration time feedf. control</b>		Data type: UNSIGNED_32 Index: 21975 <sub>d</sub> = 55D7 <sub>h</sub>	
From software version V3.0			
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.000	s	1000.000	<b>0.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02601

Parameter   Name: <b>C02601   Ref. for Accel. time of brake</b>		Data type: UNSIGNED_32 Index: 21974 <sub>d</sub> = 55D6 <sub>h</sub>	
From software version V3.0			
▶ Basic function " <a href="#">Brake control</a> "			
Selection list (Lenze setting printed in bold)			
<b>0</b>	<b>Motor reference value</b>		
1	Current starting value		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02602

Parameter   Name: <b>C02602   Source for feedf. control brake</b>		Data type: UNSIGNED_32 Index: 21973 <sub>d</sub> = 55D5 <sub>h</sub>	
From software version V3.0			
▶ Basic function " <a href="#">Brake control</a> "			
Selection list (Lenze setting printed in bold)			
<b>0</b>	<b>Torque</b>		
1	Speed		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02603

Parameter   Name: <b>C02603   Threshold 1 for opening brake</b>		Data type: INTEGER_32 Index: 21972 <sub>d</sub> = 55D4 <sub>h</sub>	
From software version V3.0			
▶ Basic function " <a href="#">Brake control</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
-50000	rpm	50000	<b>0 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C02604

Parameter | Name: **C02604 | Threshold 2 for opening brake** Data type: INTEGER\_32  
Index: 21971<sub>d</sub> = 55D3<sub>h</sub>

From software version V3.0 ▶ Basic function "[Brake control](#)"

Setting range (min. value   unit   max. value)			Lenze setting
-50000	rpm	50000	0 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

## C02607

Parameter | Name: **C02607 | BRK\_dnState** Data type: INTEGER\_32  
Index: 21968<sub>d</sub> = 55D0<sub>h</sub>

Bit coded status of the basic function "[Brake control](#)".

Display range (min. value   unit   max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 1		

## C02608

Parameter | Name: **C02608 | BRK\_dnTorqueAdd\_n** Data type: INTEGER\_32  
Index: 21967<sub>d</sub> = 55CF<sub>h</sub>

Display of the additive torque value of the basic function "[brake control](#)".

Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 100		

## C02609

Parameter | Name: **C02609 | Brake control: Dig. signals** Data type: UNSIGNED\_32  
Index: 21966<sub>d</sub> = 55CE<sub>h</sub>

Display of the digital signals of the basic function "[brake control](#)".

Selection list (display only)	
0	FALSE
1	TRUE

Subcodes	Information
C02609/1	BRK_bReleaseBrake
C02609/2	BRK_bStartingTorque2
C02609/3	BRK_bBrakeApplied
C02609/4	BRK_bBrakeTest
C02609/5	BRK_bBrakeGrindIn
C02609/6	BRK_bReleaseBrakeOut
C02609/7	BRK_bBrakeReleased
C02609/8	BRK_bError
C02609/9	BRK_bCInhActive
C02609/10	BRK_bDisableStop
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1	

## C02610

Parameter | Name: **C02610 | Deceleration time for stop** Data type: UNSIGNED\_32  
Index: 21965<sub>d</sub> = 55CD<sub>h</sub>

▶ Basic function "[Stop](#)"

Setting range (min. value   unit   max. value)			Lenze setting
0.000	s	1000.000	1.000 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02611

C02611

Parameter   Name: <b>C02611   S-ramp time for stop</b>		Data type: UNSIGNED_32 Index: 21964 <sub>d</sub> = 55CCh
▶ Basic function " <a href="#">Stop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.000	s	10.000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02612

Parameter   Name: <b>C02612   Ref. for decel. time of stop</b>		Data type: UNSIGNED_32 Index: 21963 <sub>d</sub> = 55CBh
▶ Basic function " <a href="#">Stop</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Motor reference speed (C00011)</b>	
1	Current speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02616

Parameter   Name: <b>C02616   STP_dnState</b>		Data type: INTEGER_32 Index: 21959 <sub>d</sub> = 55C7h
Bit coded status of the basic function " <a href="#">Stop</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02617

Parameter   Name: <b>C02617   STP_bStopActive</b>		Data type: UNSIGNED_32 Index: 21958 <sub>d</sub> = 55C6h
Status of the basic function " <a href="#">Stop</a> ".		
<b>Selection list (display only)</b>		
0	Normal stop not active	
1	Normal stop active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02619

Parameter   Name: <b>C02619   Quick stop: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21956 <sub>d</sub> = 55C4h
Display of the digital signals of the basic function " <a href="#">Quick stop</a> ".		
<b>Selection list (display only)</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>	<b>Information</b>	
C02619/1	QSP_bActivate1	
C02619/2	QSP_bActivate2	
C02619/3	QSP_bActivate3	
C02619/4	QSP_bActive	
C02619/5	QSP_bActivateDCBrake	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1



## C02620

Parameter   Name: <b>C02620   Manual jog: Speed 1</b>			Data type: INTEGER_32 Index: 21955 <sub>d</sub> = 55C3 <sub>h</sub>
▶ Basic function " <a href="#">Manual jog</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s	214748.3647	<b>360.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

## C02621

Parameter   Name: <b>C02621   Manual jog: Speed 2</b>			Data type: INTEGER_32 Index: 21954 <sub>d</sub> = 55C2 <sub>h</sub>
▶ Basic function " <a href="#">Manual jog</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s	214748.3647	<b>720.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

## C02622

Parameter   Name: <b>C02622   Manual jog: Acceleration</b>			Data type: INTEGER_32 Index: 21953 <sub>d</sub> = 55C1 <sub>h</sub>
▶ Basic function " <a href="#">Manual jog</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>360.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

## C02623

Parameter   Name: <b>C02623   Manual jog: Deceleration</b>			Data type: INTEGER_32 Index: 21952 <sub>d</sub> = 55C0 <sub>h</sub>
▶ Basic function " <a href="#">Manual jog</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>1440.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

## C02624

Parameter   Name: <b>C02624   Manual jog: S-ramp time</b>			Data type: UNSIGNED_32 Index: 21951 <sub>d</sub> = 55BF <sub>h</sub>
▶ Basic function " <a href="#">Manual jog</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.000	s	10.000	<b>0.100 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

## C02625

Parameter   Name: <b>C02625   Manual jog: Step size</b>			Data type: INTEGER_32 Index: 21950 <sub>d</sub> = 55BE <sub>h</sub>
From software version V5.0			
Step distance for " <a href="#">Manual jog with step limitation</a> " mode.			
▶ Basic function " <a href="#">Manual jog</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit	214748.3647	<b>360.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02626

## C02626

Parameter | Name: **C02626 | Manual jog:Index Stop position** Data type: INTEGER\_32  
Index: 21949<sub>d</sub> = 55BD<sub>h</sub>

From software version V5.0

Selection of the breakpoint positions for "[Manual jog with breakpoint](#)" mode.

- In connection with a function block instance of type **L\_PosPositionerTable**:  
The index [1...75] of the table position in the VTPOS table has to be specified, which contains the intermediate stop position x that is to be used.
- In connection with a function block instance of type **L\_PosProfileTable**:  
The index [1...4] of the profile data set in the VTPOS table has to be specified, which contains the intermediate stop position x that is to be used.

► Basic function "[Manual jog](#)"

Setting range (min. value   unit   max. value)		
0		75
Subcodes	Lenze setting	Information
C02626/1	0	Index of the breakpoint positions 1 ... 16
C02626/...		
C02626/16		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C02627

Parameter | Name: **C02627 | Manual jog:Selected Stop position** Data type: INTEGER\_32  
Index: 21948<sub>d</sub> = 55BC<sub>h</sub>

From software version V5.0

Display of the breakpoint positions selected via [C02626/1...16](#) for "[Manual jog with breakpoints](#)".

► Basic function "[Manual jog](#)"

Display range (min. value   unit   max. value)		
-214748.3648	Unit	214748.3647
Subcodes	Information	
C02627/1	Breakpoint position 1 ... 16	
C02627/...		
C02627/16		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000		

## C02637

Parameter | Name: **C02637 | MAN\_dnSpeedOverride\_n** Data type: INTEGER\_32  
Index: 21938<sub>d</sub> = 55B2<sub>h</sub>

From software version V5.0

Display of the speed override for the basic function "[Manual jog](#)".

Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100		

## C02638

Parameter | Name: **C02638 | Manual jog: Status** Data type: INTEGER\_32  
Index: 21937<sub>d</sub> = 55B1<sub>h</sub>

Status of the basic function "[Manual jog](#)".

Display range (min. value   unit   max. value)		
0		8
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C02639

Parameter   Name: <b>C02639   Manual jog: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21936 <sub>d</sub> = 55B0 <sub>h</sub>
Display of the digital signals of the basic function " <a href="#">Manual jog</a> ".		
<b>Selection list (display only)</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>	<b>Information</b>	
C02639/1	MAN_bEnable	
C02639/2	MAN_bJogPositive	
C02639/3	MAN_bJogNegative	
C02639/4	MAN_bActivateJogSpeed2	
C02639/5	MAN_bReleaseLimitSwitch	
C02639/6	MAN_bEnabled	
C02639/7	MAN_bActive	
C02639/8	MAN_bStepMode	
C02639/9	MAN_bIntermediateStopMode	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02640

C02640



# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02640

Parameter | Name: **C02640 | Homing mode** Data type: UNSIGNED\_32  
Index: 21935<sub>d</sub> = 55AF<sub>h</sub>

Selection of the way homing is to be carried out.

▶ Basic function "[Homing](#)"

Selection list (Lenze setting printed in bold)	Information
0 <b>cw_Rn_TP</b>	Positive direction - via home mark - to TP ▶ <a href="#">Process description</a>
1 <b>ccw_Rn_TP</b>	Negative direction - via home mark - to TP ▶ <a href="#">Process description</a>
2 <b>cw_Lp_ccw_Rn_TP</b>	Pos. direction - reversing to limit switch - via home mark - to TP ▶ <a href="#">Process description</a>
3 <b>ccw_Ln_cw_Rn_TP</b>	Neg. direction - reversing to limit switch - via home mark - to TP ▶ <a href="#">Process description</a>
4 <b>cw_Rp_ccw_Rn_TP</b>	Pos. direction - reversing to home mark - to TP ▶ <a href="#">Process description</a>
5 <b>ccw_Rp_cw_Rn_TP</b>	Neg. direction - reversing to home mark - to TP ▶ <a href="#">Process description</a>
8 <b>cw_TP</b>	Positive direction to touch probe ▶ <a href="#">Process description</a>
9 <b>ccw_TP</b>	Negative direction to touch probe ▶ <a href="#">Process description</a>
10 <b>cw_Lp_ccw_TP</b>	Pos. direction - reversing to limit switch - to TP ▶ <a href="#">Process description</a>
11 <b>ccw_Ln_cw_TP</b>	Neg. direction - reversing to limit switch - to TP ▶ <a href="#">Process description</a>
12 <b>cw_Lp</b>	Positive direction to limit switch ▶ <a href="#">Process description</a>
13 <b>ccw_Ln</b>	Negative direction to limit switch ▶ <a href="#">Process description</a>
14 <b>cw_Trq_Lim</b>	Positive direction to torque limit ▶ <a href="#">Process description</a>
15 <b>ccw_Trq_Lim</b>	Negative direction to torque limit ▶ <a href="#">Process description</a>
<b>100 Set home pos. directly</b>	Set home pos. directly ▶ <a href="#">Process description</a>
1001 DS402 homing method 01	From software version V3.0 also the homing methods in accordance with DS402 are provided. ▶ <a href="#">Overview of DS402 homing modes</a>

Parameter	Name:	Data type: UNSIGNED_32
<b>C02640</b>	<b>Homing mode</b>	Index: 21935 <sub>d</sub> = 55AF <sub>h</sub>
1002	DS402 homing method 02	
1003	DS402 homing method 03	
1004	DS402 homing method 04	
1005	DS402 homing method 05	
1006	DS402 homing method 06	
1007	DS402 homing method 07	
1008	DS402 homing method 08	
1009	DS402 homing method 09	
1010	DS402 homing method 10	
1011	DS402 homing method 11	
1012	DS402 homing method 12	
1013	DS402 homing method 13	
1014	DS402 homing method 14	
1015	DS402 homing method 15	
1016	DS402 homing method 16	
1017	DS402 homing method 17	
1018	DS402 homing method 18	
1019	DS402 homing method 19	
1020	DS402 homing method 20	
1021	DS402 homing method 21	
1022	DS402 homing method 22	
1023	DS402 homing method 23	
1024	DS402 homing method 24	
1025	DS402 homing method 25	
1026	DS402 homing method 26	
1027	DS402 homing method 27	
1028	DS402 homing method 28	
1029	DS402 homing method 29	
1030	DS402 homing method 30	
1031	DS402 homing method 31	
1032	DS402 homing method 32	
1033	DS402 homing method 33	
1034	DS402 homing method 34	
1035	DS402 homing method 35	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

## C02641

Parameter	Name:	Data type: UNSIGNED_32
<b>C02641</b>	<b>Action after detect Home position</b>	Index: 21934 <sub>d</sub> = 55AE <sub>h</sub>
From software version V4.0		
▶ Basic function " <a href="#">Homing</a> "		
<b>Selection list</b> (Lenze setting printed in bold)		
<b>0</b>	<b>Move absolute on target position</b>	
1	Move relative by Target position	
2	Stop immediately	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02642

C02642

Parameter   Name: <b>C02642   Home position</b>			Data type: INTEGER_32 Index: 21933 <sub>d</sub> = 55AD <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
-214748.3647	Unit	214748.3647	<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02643

Parameter   Name: <b>C02643   Homing: Target position</b>			Data type: INTEGER_32 Index: 21932 <sub>d</sub> = 55AC <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
-214748.3647	Unit	214748.3647	<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02644

Parameter   Name: <b>C02644   Homing: Speed 1</b>			Data type: INTEGER_32 Index: 21931 <sub>d</sub> = 55AB <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s	214748.3647	<b>360.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02645

Parameter   Name: <b>C02645   Homing: Acceleration 1</b>			Data type: INTEGER_32 Index: 21930 <sub>d</sub> = 55AA <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>720.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02646

Parameter   Name: <b>C02646   Homing: Speed 2</b>			Data type: INTEGER_32 Index: 21929 <sub>d</sub> = 55A9 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s	214748.3647	<b>0.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02647

Parameter   Name: <b>C02647   Homing: Acceleration 2</b>			Data type: INTEGER_32 Index: 21928 <sub>d</sub> = 55A8 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "			
Setting range (min. value   unit   max. value)			Lenze setting
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>360.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000



## C02648

Parameter   Name: <b>C02648   Homing: S-ramp time</b>		Data type: INTEGER_32 Index: 21927 <sub>d</sub> = 55A7 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0	ms	10000
		<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02649

Parameter   Name: <b>C02649   Homing: Torque limit</b>		Data type: INTEGER_32 Index: 21926 <sub>d</sub> = 55A6 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0.00	%	200.00
		<b>10.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C02650

Parameter   Name: <b>C02650   Homing: Blocking time</b>		Data type: UNSIGNED_32 Index: 21925 <sub>d</sub> = 55A5 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0.000	s	120.000
		<b>1.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

## C02651

Parameter   Name: <b>C02651   Homing: TP configuration</b>		Data type: UNSIGNED_32 Index: 21924 <sub>d</sub> = 55A4 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0		4294967295
		<b>16</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02652

Parameter   Name: <b>C02652   Ref. pos. after mains switching</b>		Data type: UNSIGNED_32 Index: 21923 <sub>d</sub> = 55A3 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
Selection list (Lenze setting printed in bold)		
0	Delete	
1	Retain	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02653

Parameter   Name: <b>C02653   Max. rot. ang. aft. mns. swtch.</b>		Data type: INTEGER_32 Index: 21922 <sub>d</sub> = 55A2 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0	°	1000000
		<b>180 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02655

C02655

Parameter   Name: <b>C02655   HM_dnSpeedOverride_n</b>	Data type: INTEGER_32 Index: 21920 <sub>d</sub> = 55A0 <sub>h</sub>
From software version V5.0	
Display of the speed override for the basic function " <a href="#">Homing</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

C02656

Parameter   Name: <b>C02656   Actual position (homing)</b>	Data type: INTEGER_32 Index: 21919 <sub>d</sub> = 559F <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit 214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000	

C02657

Parameter   Name: <b>C02657   HM_dnState</b>	Data type: INTEGER_32 Index: 21918 <sub>d</sub> = 559E <sub>h</sub>
Bit coded status of the basic function " <a href="#">Homing</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-2147483648	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02658

Parameter   Name: <b>C02658   HM_dnHomePos_p</b>	Data type: INTEGER_32 Index: 21917 <sub>d</sub> = 559D <sub>h</sub>
Display of the <i>HM_dnHomePos_p</i> input signal of the basic function " <a href="#">Homing</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000	

C02659

Parameter   Name: <b>C02659   Homing: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21916 <sub>d</sub> = 559C <sub>h</sub>
Display of the digital signals of the basic function " <a href="#">Homing</a> ".	
<b>Selection list (display only)</b>	
0	FALSE
1	TRUE
Subcodes	Information
C02659/1	HM_bEnable
C02659/2	HM_bActivateHoming
C02659/3	HM_bHomingMark
C02659/4	HM_bLoadHomePos
C02659/5	HM_bResetHomePos
C02659/6	HM_bEnabled
C02659/7	HM_bActive
C02659/8	HM_bDone
C02659/9	HM_bHomePosAvailable
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02670

Parameter   Name: <b>C02670   Tolerance for POS_bActPosInTarget</b>		Data type: INTEGER_32 Index: 21905 <sub>d</sub> = 5591 <sub>h</sub>
From software version V1.5		
Tolerance window for actual value-based evaluation "Target position reached" (Output <i>POS_bActPosInTarget</i> )		
▶ Basic function " <a href="#">Positioning</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0.0000	Unit	214748.3647
		<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

## C02671

Parameter   Name: <b>C02671   Tolerance for POS_bDriveInTarget</b>		Data type: INTEGER_32 Index: 21904 <sub>d</sub> = 5590 <sub>h</sub>
From software version V5.0		
Tolerance window for actual value and setpoint-based evaluation "Drive in the target" (Output <i>POS_bDriveInTarget</i> )		
▶ Basic function " <a href="#">Positioning</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0.0001	Unit	214748.3647
		<b>2.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

## C02672

Parameter   Name: <b>C02672   Hysteresis for POS_bDriveInTarget</b>		Data type: INTEGER_32 Index: 21903 <sub>d</sub> = 558F <sub>h</sub>
From software version V5.0		
Hysteresis window for actual value and setpoint-based evaluation "Drive in the target" (Output <i>POS_bDriveInTarget</i> )		
▶ Basic function " <a href="#">Positioning</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0.0000	Unit	214748.3647
		<b>1.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

## C02673

Parameter   Name: <b>C02673   Activate DriveInTarget Modulo</b>		Data type: UNSIGNED_32 Index: 21902 <sub>d</sub> = 558E <sub>h</sub>
From software version V5.0		
For actual value and setpoint-based evaluation "Drive in target" (output <i>POS_bDriveInTarget</i> ): Definition how the modulo evaluation is to be carried out if the actual position value enters the tolerance and hysteresis window again.		
▶ Basic function " <a href="#">Positioning</a> "		
Selection list (Lenze setting printed in bold)		
0	Only setpoint Cycle	
<b>1</b>	<b>All cycles</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02674

Parameter   Name: <b>C02674   POS_dwActualProfileNumber</b>		Data type: UNSIGNED_32 Index: 21901 <sub>d</sub> = 558D <sub>h</sub>
Current profile of the basic function " <a href="#">Positioning</a> ".		
Display range (min. value   unit   max. value)		
0		1000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02675

## C02675

Parameter   Name:	<b>C02675   POS_dnState</b>		Data type: INTEGER_32 Index: 21900 <sub>d</sub> = 558C <sub>h</sub>
Bit coded status of the basic function " <a href="#">Positioning</a> ".			
<b>Display range (min. value   unit   max. value)</b>			
-2147483648		2147483647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1			

## C02676

Parameter   Name:	<b>C02676   POS_dnProfileSpeed_s</b>		Data type: INTEGER_32 Index: 21899 <sub>d</sub> = 558B <sub>h</sub>
Display of the max. speed of the current profile of the basic function " <a href="#">Positioning</a> ".			
<b>Display range (min. value   unit   max. value)</b>			
-214748.3647		214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000			

## C02677

Parameter   Name:	<b>C02677   Positioning: % signals</b>		Data type: INTEGER_32 Index: 21898 <sub>d</sub> = 558A <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Positioning</a> ".			
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<b>Subcodes</b>		<b>Information</b>	
C02677/1		POS_dnSpeedOverride_n	
C02677/2		POS_dnAccOverride_n	
C02677/3		POS_dnDecOverride_n	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100			

## C02678

Parameter   Name:	<b>C02678   Positioning: Pos. signals</b>		Data type: INTEGER_32 Index: 21897 <sub>d</sub> = 5589 <sub>h</sub>
Display of the position signals of the basic function " <a href="#">Positioning</a> ".			
<b>Display range (min. value   unit   max. value)</b>			
-214748.3647	Unit	214748.3647	
<b>Subcodes</b>		<b>Information</b>	
C02678/1		POS_dnSetPos_p	
C02678/2		POS_dnProfileTarget_p	
C02678/3		POS_dnActPosRelative_p	
C02678/4		POS_dnSetPosRelative_p	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10000			

## C02679

Parameter   Name: <b>C02679   Positioning: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21896 <sub>d</sub> = 5588 <sub>h</sub>
Display of the digital signals of the basic function " <a href="#">Positioning</a> ".		
<b>Selection list (display only)</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>	<b>Information</b>	
C02679/1	POS_bEnable	
C02679/2	POS_bStart	
C02679/3	POS_bAbort	
C02679/4	POS_bRestart	
C02679/5	POS_bEnableOverride	
C02679/6	POS_bDisableTP	
C02679/7	POS_bEnabled	
C02679/8	POS_bActive	
C02679/9	POS_bDone	
C02679/10	POS_bInTarget	
C02679/11	POS_bActPosInTarget	
C02679/12	POS_bDrivelnTarget	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02680

Parameter   Name: <b>C02680   Source position setpoint</b>		Data type: UNSIGNED_32 Index: 21895 <sub>d</sub> = 5587 <sub>h</sub>
▶ Basic function " <a href="#">Positioning</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Position setpoint input</b>	
1	From add. speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02681

Parameter   Name: <b>C02681   Source add. speed</b>		Data type: UNSIGNED_32 Index: 21894 <sub>d</sub> = 5586 <sub>h</sub>
▶ Basic function " <a href="#">Positioning</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Add. speed input</b>	
1	From position setpoint	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02685

Parameter   Name: <b>C02685   PF_dnMotorAcc_x</b>		Data type: INTEGER_32 Index: 21890 <sub>d</sub> = 5582 <sub>h</sub>
Display of the motor acceleration of the basic function " <a href="#">Position follower</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
-7680000.0		7680000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02686

C02686

Parameter   Name: <b>C02686   PF_dnSpeedAdd1_s</b>		Data type: INTEGER_32 Index: 21889 <sub>d</sub> = 5581 <sub>h</sub>
Display of the speed feedforward control value of the basic function " <a href="#">Position follower</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
-480000.0	rpm	480000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02687

Parameter   Name: <b>C02687   Position follower: % signals</b>		Data type: INTEGER_32 Index: 21888 <sub>d</sub> = 5580 <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Position follower</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>		<b>Information</b>
C02687/1	PF_dnSpeedAdd2_n	
C02687/2	PF_dnTorqueAdd_n	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02688

Parameter   Name: <b>C02688   PF_dnPositionSet_p</b>		Data type: INTEGER_32 Index: 21887 <sub>d</sub> = 557F <sub>h</sub>
Display of the position signals of the basic function " <a href="#">Position follower</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3648	Revolution	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02689

Parameter   Name: <b>C02689   Position follower: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21886 <sub>d</sub> = 557E <sub>h</sub>
Display of the digital signals of the basic function " <a href="#">Position follower</a> ".		
<b>Selection list (display only)</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02689/1	PF_bEnable	
C02689/2	PF_bEnabled	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02692

Parameter   Name: <b>C02692   SF_dnMotorAcc_x</b>		Data type: INTEGER_32 Index: 21883 <sub>d</sub> = 557B <sub>h</sub>
Display of the motor acceleration of the basic function " <a href="#">Speed follower</a> ".		
<b>Display range (min. value   unit   max. value)</b>		
-7680000.0		7680000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C02693

Parameter   Name: <b>C02693   SF_dnSpeedAdd_s</b>	Data type: INTEGER_32 Index: 21882 <sub>d</sub> = 557A <sub>h</sub>
Display of the additive speed setpoint of the basic function " <a href="#">Speed follower</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-480000.0	rpm 480000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10	

## C02694

Parameter   Name: <b>C02694   Speed follower: % signals</b>	Data type: INTEGER_32 Index: 21881 <sub>d</sub> = 5579 <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Speed follower</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<b>Subcodes</b>	<b>Information</b>
C02694/1	SF_dnSpeedSet_n
C02694/2	SF_dnTorqueAdd_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

## C02695

Parameter   Name: <b>C02695   Speed follower: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21880 <sub>d</sub> = 5578 <sub>h</sub>
Display of the digital signals of the basic function " <a href="#">Speed follower</a> ".	
<b>Selection list (display only)</b>	
0	FALSE
1	TRUE
<b>Subcodes</b>	<b>Information</b>
C02695/1	SF_bEnable
C02695/2	SF_bEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02698

Parameter   Name: <b>C02698   Torque follower: % signals</b>	Data type: INTEGER_32 Index: 21877 <sub>d</sub> = 5575 <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Torque follower</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-200.00	% 200.00
<b>Subcodes</b>	<b>Information</b>
C02698/1	TF_TorqueSet_n
C02698/2	TF_dnSpeedHighLimit_n
C02698/3	TF_dnSpeedLowLimit_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02699

C02699

Parameter   Name: <b>C02699   Torque follower: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21876 <sub>d</sub> = 5574 <sub>h</sub>
Display of the digital signals of the basic function " <a href="#">Torque follower</a> ".		
<b>Selection list (display only)</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>	<b>Information</b>	
C02699/1	TF_bEnable	
C02699/2	TF_bEnabled	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02700

Parameter   Name: <b>C02700   Software limits pos. effective</b>		Data type: UNSIGNED_32 Index: 21875 <sub>d</sub> = 5573 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Deactivated</b>	
1	Activated	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02701

Parameter   Name: <b>C02701   Software limit positions</b>		Data type: INTEGER_32 Index: 21874 <sub>d</sub> = 5572 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02701/1	0.0000 Unit	Positive software limit position
C02701/2	0.0000 Unit	Negative software limit position
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02702

Parameter   Name: <b>C02702   Limitations effective</b>		Data type: UNSIGNED_32 Index: 21873 <sub>d</sub> = 5571 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Deactivated</b>	
1	Activated	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02703

Parameter   Name: <b>C02703   Max. speed</b>		Data type: INTEGER_32 Index: 21872 <sub>d</sub> = 5570 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0000	Unit/s	214748.3647 <b>3600.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000



## C02704

Parameter   Name: <b>C02704   Max. speed [rpm]</b>		Data type: INTEGER_32 Index: 21871 <sub>d</sub> = 556F <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Display range (min. value   unit   max. value)</b>		
0.0	rpm	214748364.7
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C02705

Parameter   Name: <b>C02705   Max. acceleration</b>		Data type: INTEGER_32 Index: 21870 <sub>d</sub> = 556E <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0000	Unit/s <sup>2</sup>	214748.3647 <b>3600.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

## C02706

Parameter   Name: <b>C02706   Min. S-ramp time</b>		Data type: UNSIGNED_32 Index: 21869 <sub>d</sub> = 556D <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	ms	10000 <b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02707

Parameter   Name: <b>C02707   Permissible direction of rot.</b>		Data type: UNSIGNED_32 Index: 21868 <sub>d</sub> = 556C <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Positive and negative</b>	
1	Positive only	
2	Negative only	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02708

Parameter   Name: <b>C02708   Limited speed</b>		Data type: INTEGER_32 Index: 21867 <sub>d</sub> = 556B <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.0000	Unit/s	214748.3647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02708/1	3600.0000 Unit/s	Limited speed 1 ... 4
C02708/2	7200.0000 Unit/s	
C02708/3	14400.0000 Unit/s	
C02708/4	28800.0000 Unit/s	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02709

C02709

Parameter   Name: <b>C02709   Limited speed [rpm]</b>		Data type: INTEGER_32 Index: 21866 <sub>d</sub> = 556A <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Display range (min. value   unit   max. value)</b>		
0.0	rpm	214748364.7
<b>Subcodes</b>		<b>Information</b>
C02709/1		Limited speed 1 ... 4
C02709/2		
C02709/3		
C02709/4		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02710

Parameter   Name: <b>C02710   Delay lim. speed</b>		Data type: UNSIGNED_32 Index: 21865 <sub>d</sub> = 5569 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.0000	Unit/s <sup>2</sup>	214748.3647
<b>Subcodes</b>		<b>Lenze setting</b>
C02710/1		0.0100 Unit/s <sup>2</sup>
C02710/2		0.0100 Unit/s <sup>2</sup>
C02710/3		0.0100 Unit/s <sup>2</sup>
C02710/4		0.0100 Unit/s <sup>2</sup>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02711

Parameter   Name: <b>C02711   S-ramp time lim. speed</b>		Data type: UNSIGNED_32 Index: 21864 <sub>d</sub> = 5568 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0	ms	10000
<b>Subcodes</b>		<b>Lenze setting</b>
C02711/1		100 ms
C02711/2		100 ms
C02711/3		100 ms
C02711/4		100 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02712

Parameter   Name: <b>C02712   Decel. time lim. speed</b>		Data type: UNSIGNED_32 Index: 21863 <sub>d</sub> = 5567 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Display range (min. value   unit   max. value)</b>		
0	ms	10000
<b>Subcodes</b>		<b>Information</b>
C02712/1		Deceleration times for limited speed 1 ... 4
C02712/2		
C02712/3		
C02712/4		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02713

Parameter   Name: <b>C02713   Max. dist. manual control</b>		Data type: UNSIGNED_32 Index: 21862 <sub>d</sub> = 5566 <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
Setting range (min. value   unit   max. value)		Lenze setting
0.0000	Unit	214748.3647
		<b>360.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

## C02714

Parameter   Name: <b>C02714   Max. dist. manual jog [inc.]</b>		Data type: UNSIGNED_32 Index: 21861 <sub>d</sub> = 5565 <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
Display range (min. value   unit   max. value)		
0	Incr.	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02715

Parameter   Name: <b>C02715   Limitation active</b>		Data type: UNSIGNED_32 Index: 21860 <sub>d</sub> = 5564 <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
Selection list (display only)		
0	Deactivated	
1	Activated	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02716

Parameter   Name: <b>C02716   Resp. to limitation</b>		Data type: UNSIGNED_32 Index: 21859 <sub>d</sub> = 5563 <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
Selection list		
1	Fault	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Information
C02716/1	6: Information	Resp. to rotation limitation
C02716/2	3: Quick stop by trouble	Resp. to SW lim. pos. exceeded
C02716/3	6: Information	Resp. to max. value exceeded
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02717

Parameter   Name: <b>C02717   LIM_dwControl</b>		Data type: UNSIGNED_32 Index: 21858 <sub>d</sub> = 5562 <sub>h</sub>
Bit coded control word of the basic function " <a href="#">"Limiter"</a> ".		
Display range (min. value   unit   max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02718

C02718

Parameter   Name: <b>C02718   LIM_dnState</b>	Data type: INTEGER_32 Index: 21857 <sub>d</sub> = 5561 <sub>h</sub>
Status of the basic function " <a href="#">Limiter</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
0	1
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02719

Parameter   Name: <b>C02719   Limiter: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21856 <sub>d</sub> = 5560 <sub>h</sub>
Display of the digital input signals of the basic function " <a href="#">Limiter</a> ".	
<b>Selection list (display only)</b>	
0 FALSE	
1 TRUE	
<b>Subcodes</b>	<b>Information</b>
C02719/1	LIM_bLimitSwitchPositive
C02719/2	LIM_bLimitSwitchNegative
C02719/3	LIM_bActivateLimitedSpeed1
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02720

Parameter   Name: <b>C02720   observation software limit positions</b>	Data type: UNSIGNED_32 Index: 21855 <sub>d</sub> = 555F <sub>h</sub>
From software version V4.0	
▶ Basic function " <a href="#">Limiter</a> "	
<b>Selection list (Lenze setting printed in bold)</b>	
0 <b>Based on set value</b>	
1 Based on set and actual value	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02730

Parameter   Name: <b>C02730   Analog inputs: Gain</b>	Data type: INTEGER_32 Index: 21845 <sub>d</sub> = 5555 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	200.00	
%		
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02730/1	100.00 %	Gain - analog input 1
C02730/2	100.00 %	Analog input 2: Gain
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100		

C02731

Parameter   Name: <b>C02731   Analog inputs: Offset</b>	Data type: INTEGER_32 Index: 21844 <sub>d</sub> = 5554 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	200.00	
%		
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02731/1	0.00 %	Offset - analog input 1
C02731/2	0.00 %	Analog input 2: Offset
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100		

## C02732

Parameter   Name: <b>C02732   Analog inputs: Dead band</b>		Data type: INTEGER_32 Index: 21843 <sub>d</sub> = 5553 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
0.00	%	100.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02732/1	0.00 %	Dead band - analog input 1
C02732/2	0.00 %	Analog input 2: Dead band
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C02733

Parameter   Name: <b>C02733   Analog outputs: Gain</b>		Data type: INTEGER_32 Index: 21842 <sub>d</sub> = 5552 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02733/1	100.00 %	Gain - analog output 1
C02733/2	100.00 %	Analog output 2: Gain
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C02734

Parameter   Name: <b>C02734   Analog outputs: Offset</b>		Data type: INTEGER_32 Index: 21841 <sub>d</sub> = 5551 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02734/1	0.00 %	Offset - analog output 1
C02734/2	0.00 %	Analog output 2: Offset
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

## C02760

Parameter   Name: <b>C02760   Activate encoder</b>		Data type: UNSIGNED_32 Index: 21815 <sub>d</sub> = 5537 <sub>h</sub>
From software version V7.0		
▶ Encoder evaluation: <a href="#">Provision of the encoder signal of input X8</a>		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Deactivated</b>	
1	Activated	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02761

Parameter   Name: <b>C02761   Multiturn resolution</b>		Data type: UNSIGNED_32 Index: 21814 <sub>d</sub> = 5536 <sub>h</sub>
From software version V7.0		
▶ Encoder evaluation: <a href="#">Provision of the encoder signal of input X8</a>		
<b>Display range (min. value   unit   max. value)</b>		
0	Rev	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02762

C02762

Parameter | Name: **C02762 | Encoderpos** Data type: INTEGER\_32  
Index: 21813<sub>d</sub> = 5535<sub>h</sub>

From software version V7.0 ▶ Encoder evaluation: [Provision of the encoder signal of input X8](#)

Display range (min. value   unit   max. value)		
-2147483647	Steps	2147483647

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02763

Parameter | Name: **C02763 | Encoderrev** Data type: INTEGER\_32  
Index: 21812<sub>d</sub> = 5534<sub>h</sub>

From software version V7.0 ▶ Encoder evaluation: [Provision of the encoder signal of input X8](#)

Display range (min. value   unit   max. value)		
-2147483647	Steps	2147483647

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02764

Parameter | Name: **C02764 | Encoderspeed** Data type: INTEGER\_32  
Index: 21811<sub>d</sub> = 5533<sub>h</sub>

From software version V7.0 ▶ Encoder evaluation: [Provision of the encoder signal of input X8](#)

Display range (min. value   unit   max. value)		
-214748364.7	rpm	214748364.7

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 10

C02765

Parameter | Name: **C02765 | Enc\_bError** Data type: UNSIGNED\_32  
Index: 21810<sub>d</sub> = 5532<sub>h</sub>

From software version V7.0 ▶ Encoder evaluation: [Provision of the encoder signal of input X8](#)

Selection list (display only)	
0	FALSE
1	TRUE

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

C02770

Parameter | Name: **C02770 | Operating mode** Data type: UNSIGNED\_32  
Index: 21805<sub>d</sub> = 552D<sub>h</sub>

From software version V7.0 ▶ Basic function "[Manual jog open loop](#)"

Selection list (Lenze setting printed in bold)	
0	Deactivate
1	Activate

Subcodes	Lenze setting	Information
C02770/1	0: Deactivate	EnableManualMode
C02770/2	0: Deactivate	JogPositive
C02770/3	0: Deactivate	JogNegative
C02770/4	0: Deactivate	SelectTab1
C02770/5	0: Deactivate	SelectTab2

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02771

Parameter | Name: **C02771 | Frequency** Data type: INTEGER\_32  
Index: 21804<sub>d</sub> = 552C<sub>h</sub>

From software version V7.0

► Basic function "[Manual jog open loop](#)"

Setting range (min. value   unit   max. value)		
0.0	Hz	1000.0
Subcodes	Lenze setting	Information
C02771/1	1.0 Hz	Frequency 1
C02771/2	1.0 Hz	Frequency 2
C02771/3	1.0 Hz	Frequency 3
C02771/4	1.0 Hz	Frequency 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C02772

Parameter | Name: **C02772 | Starting angle** Data type: INTEGER\_32  
Index: 21803<sub>d</sub> = 552B<sub>h</sub>

From software version V7.0

► Basic function "[Manual jog open loop](#)"

Setting range (min. value   unit   max. value)		
-180.0	°	180.0
Subcodes	Lenze setting	Information
C02772/1	0.0 °	Startangle 1
C02772/2	0.0 °	Startangle 2
C02772/3	0.0 °	Startangle 3
C02772/4	0.0 °	Startangle 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

## C02773

Parameter | Name: **C02773 | Current** Data type: INTEGER\_32  
Index: 21802<sub>d</sub> = 552A<sub>h</sub>

From software version V7.0

100 %  $\frac{1}{2} I_{\max\_device}$  ([C00022](#))

► Basic function "[Manual jog open loop](#)"

Setting range (min. value   unit   max. value)		
0.00	%	100.00
Subcodes	Lenze setting	Information
C02773/1	10.00 %	Current 1
C02773/2	10.00 %	Current 2
C02773/3	10.00 %	Current 3
C02773/4	10.00 %	Current 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02774

## C02774

Parameter   Name: <b>C02774   Acceleration time</b>		Data type: INTEGER_32 Index: 21801 <sub>d</sub> = 5529 <sub>h</sub>
From software version V7.0		
▶ Basic function " <a href="#">Manual jog open loop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.001	s	2147483.647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02774/1	1.000 s	Acceleration time 1
C02774/2	1.000 s	Acceleration time 2
C02774/3	1.000 s	Acceleration time 3
C02774/4	1.000 s	Acceleration time 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

## C02775

Parameter   Name: <b>C02775   Deceleration time</b>		Data type: INTEGER_32 Index: 21800 <sub>d</sub> = 5528 <sub>h</sub>
From software version V7.0		
▶ Basic function " <a href="#">Manual jog open loop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.001	s	2147483.647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02775/1	1.000 s	Deceleration time 1
C02775/2	1.000 s	Deceleration time 2
C02775/3	1.000 s	Deceleration time 3
C02775/4	1.000 s	Deceleration time 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

## C02776

Parameter   Name: <b>C02776   Time</b>		Data type: INTEGER_32 Index: 21799 <sub>d</sub> = 5527 <sub>h</sub>
From software version V7.0		
▶ Basic function " <a href="#">Manual jog open loop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.001	s	2147483.647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02776/1	1.000 s	Max. activation time 1
C02776/2	1.000 s	Max. activation time 2
C02776/3	1.000 s	Max. activation time 3
C02776/4	1.000 s	Max. activation time 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

## C02779

Parameter   Name: <b>C02779   MOL_SetpointCurrent</b>		Data type: UNSIGNED_32 Index: 21796 <sub>d</sub> = 5524 <sub>h</sub>
From software version V7.0		
Maximum current of the selected profile parameter set.		
▶ Basic function " <a href="#">Manual jog open loop</a> "		
<b>Display range (min. value   unit   max. value)</b>		
0.00	A	42949672.95
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100



## C02780

Parameter   Name: <b>C02780   MOL_dnState</b>	Data type: INTEGER_32 Index: 21795 <sub>d</sub> = 5523 <sub>h</sub>
From software version V7.0 Status of the basic function " <a href="#">Manual jog open loop</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-2147483648	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02781

Parameter   Name: <b>C02781   ManualJogOpenLoop: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21794 <sub>d</sub> = 5522 <sub>h</sub>
From software version V7.0 Display of the digital signals of the basic function " <a href="#">Manual jog open loop</a> ".	
<b>Selection list (display only)</b>	
0	FALSE
1	TRUE
<b>Subcodes</b>	<b>Information</b>
C02781/1	MOL_bEnable
C02781/2	MOL_bJogPositive
C02781/3	MOL_bJogNegative
C02781/4	MOL_bSelectTab1
C02781/5	MOL_bSelectTab2
C02781/6	MOL_bEnabled
C02781/7	MOL_bActive
C02781/8	MOL_bDone
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02785

Parameter   Name: <b>C02785   PPI activation</b>	Data type: UNSIGNED_32 Index: 21790 <sub>d</sub> = 551E <sub>h</sub>
From software version V7.0 <span style="float: right;">▶ Basic function "<a href="#">pole position identification</a>"</span>	
<b>Selection list (Lenze setting printed in bold)</b>	
0	<b>PPI disabled</b>
1	PPI active
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02786

Parameter   Name: <b>C02786   PPI mode</b>	Data type: UNSIGNED_32 Index: 21789 <sub>d</sub> = 551D <sub>h</sub>
From software version V7.0 <span style="float: right;">▶ Basic function "<a href="#">pole position identification</a>"</span>	
<b>Selection list (Lenze setting printed in bold)</b>	
0	<b>360°</b>
1	&lt;20°
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02787

## C02787

Parameter   Name: <b>C02787   PPI_dnState</b>	Data type: INTEGER_32 Index: 21788 <sub>d</sub> = 551C <sub>h</sub>
From software version V7.0	
Status of the basic function " <a href="#">pole position identification</a> ".	
<b>Display range (min. value   unit   max. value)</b>	
-2147483648	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02788

Parameter   Name: <b>C02788   PolePosition setpoint</b>	Data type: INTEGER_32 Index: 21787 <sub>d</sub> = 551B <sub>h</sub>
From software version V7.0	
▶ Basic function " <a href="#">pole position identification</a> "	
<b>Display range (min. value   unit   max. value)</b>	
-214748364.8	214748364.7 °
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10	

## C02789

Parameter   Name: <b>C02789   PolePositionIdentification: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21786 <sub>d</sub> = 551A <sub>h</sub>
From software version V7.0	
Display of the digital signals of the basic function " <a href="#">pole position identification</a> ".	
<b>Selection list (display only)</b>	
0	FALSE
1	TRUE
<b>Subcodes</b>	<b>Information</b>
C02789/1	PPI_bEnable
C02789/2	PPI_bStart
C02789/3	PPI_bLoadPolePosition
C02789/4	PPI_bResetPolePosition
C02789/5	PPI_bEnabled
C02789/6	PPI_bActive
C02789/7	PPI_bDone
C02789/8	PPI_bError
C02789/9	PPI_bPolePositionAvailable
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02800

Parameter   Name: <b>C02800   Analog input x: Input signal</b>	Data type: INTEGER_16 Index: 21775 <sub>d</sub> = 550F <sub>h</sub>
Scaling: -16384 ≙ -100 %, +16383 ≙ +100 %	
<b>Display range (min. value   unit   max. value)</b>	
-16384	16383
<b>Subcodes</b>	<b>Information</b>
C02800/1	Input signal - analog input 1
C02800/2	Analog input 2: Input signal
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

## C02801

Parameter   Name: <b>C02801   Analog output x: Output signal</b>		Data type: INTEGER_16 Index: 21774 <sub>d</sub> = 550E <sub>h</sub>
Scaling: -16384 ≙ -100 %, +16383 ≙ +100 %		
<b>Display range (min. value   unit   max. value)</b>		
-16384		16383
<b>Subcodes</b>		<b>Information</b>
C02801/1		Output signal - analog output 1
C02801/2		Analog output 2: Output signal
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02802

C02802

Parameter   Name:		Data type: BITFIELD_32
<b>C02802   Status word: Digital outputs</b>		Index: 21773 <sub>d</sub> = 550D <sub>h</sub>
Display of the hexadecimal value of the digital outputs		
<ul style="list-style-type: none"> <li>Important: All digital levels are indicated without considering the level logic. Internal signals are displayed as well.</li> </ul>		
<b>Display area</b>		
0x00000000		0xFFFFFFFF
<b>Value is bit-coded:</b>		
Bit 0	Dig. output. 1: Terminal state	
Bit 1	Dig. output. 2: Terminal state	
Bit 2	Dig. output. 3: Terminal state	
Bit 3	Dig. output. 4: Terminal state	
Bit 4	Reserved	
Bit 5	Reserved	
Bit 6	Reserved	
Bit 7	Reserved	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Reserved	
Bit 11	Reserved	
Bit 12	Reserved	
Bit 13	Reserved	
Bit 14	Reserved	
Bit 15	Reserved	
Bit16	Reserved	
Bit 17	Reserved	
Bit 18	Reserved	
Bit 19	Reserved	
Bit 20	Reserved	
Bit 21	Reserved	
Bit 22	Reserved	
Bit 23	Reserved	
Bit 24	Reserved	
Bit 25	Reserved	
Bit 26	Reserved	
Bit 27	Reserved	
Bit 28	Reserved	
Bit 29	Reserved	
Bit 30	Reserved	
Bit 31	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02803

Parameter | Name: **C02803 | Status word: Digital inputs** Data type: BITFIELD\_32  
Index: 21772<sub>d</sub> = 550C<sub>h</sub>

Display of the hexadecimal value of the digital inputs

- Important: All digital levels are indicated without considering the level logic. Internal signals are displayed as well.

Display area	
0x00000000	0xFFFFFFFF
Value is bit-coded:	
Bit 0	Dig. input. 1: Terminal state
Bit 1	Dig. input. 2: Terminal state
Bit 2	Dig. input. 3: Terminal state
Bit 3	Dig. input. 4: Terminal state
Bit 4	Dig. input. 5: Terminal state
Bit 5	Dig. input. 6: Terminal state
Bit 6	Dig. input. 7: Terminal state
Bit 7	Dig. input. 8: Terminal state
Bit 8	Reserved
Bit 9	Reserved
Bit 10	Reserved
Bit 11	Reserved
Bit 12	Reserved
Bit 13	Reserved
Bit 14	Reserved
Bit 15	Reserved
Bit 16	Reserved
Bit 17	Reserved
Bit 18	Reserved
Bit 19	Reserved
Bit 20	Reserved
Bit 21	Reserved
Bit 22	Reserved
Bit 23	Reserved
Bit 24	Reserved
Bit 25	Reserved
Bit 26	Reserved
Bit 27	Reserved
Bit 28	Reserved
Bit 29	Reserved
Bit 30	Reserved
Bit 31	Reserved

Read access    Write access    CINH    PLC STOP    No transfer   Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02810

## C02810

Parameter   Name: <b>C02810   Touch probe x: Delay time</b>		Data type: UNSIGNED_32 Index: 21765 <sub>d</sub> = 5505 <sub>h</sub>
<p>The delay time set will be considered when the position is determined at the time of touch probe and will be used to compensate for dead times, if necessary.</p> <ul style="list-style-type: none"> <li>Please observe the setting of the input filter for the digital inputs (<a href="#">C02830</a>).</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	μs	7000
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02810/1	0 μs	TP1 (DI1): Delay time
C02810/2	0 μs	TP2 (DI2): Delay time
C02810/3	0 μs	TP3 (DI3): Delay time
C02810/4	0 μs	TP4 (DI4): Delay time
C02810/5	0 μs	TP5 (DI5): Delay time
C02810/6	0 μs	TP6 (DI6): Delay time
C02810/7	0 μs	TP7 (DI7): Delay time
C02810/8	0 μs	TP8 (DI8): Delay time
C02810/9	0 μs	TPM (motor encoder): Delay time
C02810/10	0 μs	TPL (pos. encoder): Delay time
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02830

Parameter   Name: <b>C02830   Digital inputs: Delay time</b>		Data type: UNSIGNED_8 Index: 21745 <sub>d</sub> = 54F1 <sub>h</sub>
<p>Input filter for digital inputs</p> <ul style="list-style-type: none"> <li>Can be used to filter out "spikes" at the digital inputs, if necessary.</li> <li>Each digital input is assigned to a subcode.</li> <li>Since the filter is a "counting" filter, the indicated times are only approximate values.</li> </ul>		
<b>Selection list (Lenze setting printed in bold)</b>		<b>Information</b>
0	<b>2 μs</b>	Filter time
1	4 μs	
2	8 μs	
3	16 μs	
4	32 μs	
5	64 μs	
6	128 μs	
7	256 μs	
8	512 μs	
9	1024 μs	
10	2048 μs	
11	4096 μs	
12	8192 μs	
13	16384 μs	
14	32768 μs	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02830/1	0: 2 μs	Setting for digital input 1 ... 8
C02830/...		
C02830/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02850

Parameter | Name: **C02850 | Service code** Data type: UNSIGNED\_32  
Index: 21725<sub>d</sub> = 54DD<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

## C02851

Parameter | Name: **C02851 | Service code** Data type: UNSIGNED\_32  
Index: 21724<sub>d</sub> = 54DC<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

## C02852

Parameter | Name: **C02852 | Service code** Data type: UNSIGNED\_16  
Index: 21723<sub>d</sub> = 54DB<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

## C02853

Parameter | Name: **C02853 | Lss sat. characteristic** Data type: UNSIGNED\_16  
Index: 21722<sub>d</sub> = 54DA<sub>h</sub>

**Setting range (min. value | unit | max. value)**  
0                      %                      400

Subcodes	Lenze setting	Information
C02853/1	100 %	Saturation characteristic to correct the leakage inductance and the current controller parameters. <ul style="list-style-type: none"> <li>The saturation characteristic is defined by 17 interpolation points which are distributed linearly on the x axis.</li> <li>Interpolation point 17 represents 100 % of the maximum motor current in the process (<a href="#">C02855</a>).</li> <li>The values to be entered in the subcodes represent the y values of the interpolation points 1 ... 17.</li> </ul> <a href="#">▶ Correction of the leakage inductance via saturation characteristic</a>
C02853/2	100 %	
C02853/3	100 %	
C02853/4	100 %	
C02853/5	100 %	
C02853/6	100 %	
C02853/7	100 %	
C02853/8	100 %	
C02853/9	100 %	
C02853/10	100 %	
C02853/11	100 %	
C02853/12	100 %	
C02853/13	100 %	
C02853/14	100 %	
C02853/15	100 %	
C02853/16	100 %	
C02853/17	100 %	

Read access    Write access    CINH    PLC STOP    No transfer   Scaling factor: 1

## C02854

Parameter | Name: **C02854 | Service code** Data type: UNSIGNED\_32  
Index: 21721<sub>d</sub> = 54D9<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02855

C02855

Parameter   Name: <b>C02855   I<sub>max</sub> f. Lss sat. characteristic</b>	Data type: UNSIGNED_32 Index: 21720 <sub>d</sub> = 54D8 <sub>h</sub>
Maximum motor current in the process	
<ul style="list-style-type: none"> <li>• Defines the interpolation point 17 of the saturation characteristic set in <a href="#">C02853</a>.</li> </ul>	
<ul style="list-style-type: none"> <li>▶ <a href="#">Correction of the leakage inductance via saturation characteristic</a></li> </ul>	
Setting range (min. value   unit   max. value)	Lenze setting
0.0   A   6000.0	<b>5.4 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 10	

C02856

Parameter   Name: <b>C02856   Service code</b>	Data type: VISIBLE_STRING Index: 21719 <sub>d</sub> = 54D7 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C02857

Parameter   Name: <b>C02857   Service code</b>	Data type: VISIBLE_STRING Index: 21718 <sub>d</sub> = 54D6 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C02858

Parameter   Name: <b>C02858   Electronic nameplate status</b>	Data type: UNSIGNED_8 Index: 21717 <sub>d</sub> = 54D5 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C02859

Parameter   Name: <b>C02859   Activate Lss sat. char.</b>	Data type: UNSIGNED_8 Index: 21716 <sub>d</sub> = 54D4 <sub>h</sub>
<ul style="list-style-type: none"> <li>▶ <a href="#">Correction of the leakage inductance via saturation characteristic</a></li> </ul>	
Selection list (Lenze setting printed in bold)	
0   <b>Off</b>	
1   <b>ON</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02860

Parameter   Name: <b>C02860   R<sub>r</sub> adjustment</b>	Data type: UNSIGNED_32 Index: 21715 <sub>d</sub> = 54D3 <sub>h</sub>
Setting range (min. value   unit   max. value)	Lenze setting
50.00   %   200.00	<b>100.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	

C02861

Parameter   Name: <b>C02861   L<sub>h</sub> adjustment</b>	Data type: UNSIGNED_32 Index: 21714 <sub>d</sub> = 54D2 <sub>h</sub>
Setting range (min. value   unit   max. value)	Lenze setting
50.00   %   200.00	<b>100.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 100	



## C02862

Parameter | Name: **C02862 | Service code** Data type: UNSIGNED\_16  
Index: 21713<sub>d</sub> = 54D1<sub>h</sub>

From software version V7.0  
 ▶ [Resolver error compensation](#)

Setting range (min. value   unit   max. value)		
0		100

Subcodes	Lenze setting	Information
C02862/1	100	Gain of cosine track
C02862/2	100	Gain of sine track

Read access
  Write access
  CINH
  PLC STOP
  No transfer
 Scaling factor: 1

## C02863

Parameter | Name: **C02863 | Service code** Data type: INTEGER\_16  
Index: 21712<sub>d</sub> = 54D0<sub>h</sub>

From software version V7.0  
 ▶ [Resolver error compensation](#)

Setting range (min. value   unit   max. value)		Lenze setting
-100		0

Read access
  Write access
  CINH
  PLC STOP
  No transfer
 Scaling factor: 1

## C02864

Parameter | Name: **C02864 | Service code** Data type: INTEGER\_32  
Index: 21711<sub>d</sub> = 54CF<sub>h</sub>

**Display range (min. value | unit | max. value)**

-2147483647		2147483647
-------------	--	------------

Read access
  Write access
  CINH
  PLC STOP
  No transfer
 Scaling factor: 1

## C02865

Parameter | Name: **C02865 | Adaptation of Ur** Data type: UNSIGNED\_32  
Index: 21710<sub>d</sub> = 54CE<sub>h</sub>

Setting range (min. value   unit   max. value)			Lenze setting
50.00	%	200.00	100.00 %

Read access
  Write access
  CINH
  PLC STOP
  No transfer
 Scaling factor: 100

## C02866

Parameter | Name: **C02866 | Curr. control par. of C75 C76** Data type: UNSIGNED\_8  
Index: 21709<sub>d</sub> = 54CD<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

## C02900

Parameter | Name: **C02900 | User Password** Data type: VISIBLE\_STRING  
Index: 21675<sub>d</sub> = 54AB<sub>h</sub>

From software version V3.0

If the cam data are provided with a user password, the defined user password must be entered once to execute the following actions:

- Changing the cam data via parameter setting
- Loading/saving the cam data

**Validity**

The user password entered is maintained until the next download, mains switching, or until reset by the user (logout).

- You can "logout" deliberately by entering an invalid password.

▶ Basic function "[Cam data management](#)"

Read access
  Write access
  CINH
  PLC STOP
  No transfer

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02901

## C02901

Parameter   Name: <b>C02901   CamMemory</b>		Data type: UNSIGNED_32 Index: 21674 <sub>d</sub> = 54AA <sub>h</sub>
From software version V5.0		
▶ Basic function "Cam data management": <a href="#">Memory mapping</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<b>Subcodes</b>	<b>Information</b>	
C02901/1	Size of the memory for quick download to RAM	
C02901/2	Size of the memory for "Online change"	
C02901/3	Size of the memory from which the cam data are processed.	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02902

Parameter   Name: <b>C02902   Timestamp</b>		Data type: UNSIGNED_32 Index: 21673 <sub>d</sub> = 54A9 <sub>h</sub>
From software version V3.0		
▶ Basic function " <a href="#">Cam data management</a> "		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<b>Subcodes</b>	<b>Information</b>	
C02902/1	Time stamp of the cam data in the controller	
C02902/2	Time stamp of the cam data which are currently being processed in the controller.	
C02902/3	Time stamp of the cam data in the controller which have already been converted into the internal format.	
C02902/4	Time stamp of the cam data in the memory module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02903

Parameter   Name: <b>C02903   GUID</b>		Data type: OCTET_STRING Index: 21672 <sub>d</sub> = 54A8 <sub>h</sub>
From software version V3.0		
▶ Basic function " <a href="#">Cam data management</a> "		
<b>Display range (min. value   unit   max. value)</b>		
<b>Subcodes</b>	<b>Information</b>	
C02903/1	GUID of the cam data in the controller	
C02903/2	GUID of the cam data which are currently being processed in the controller.	
C02903/3	GUID of the cam data in the controller which have already been converted into the internal format.	
C02903/4	GUID of the cam data in the memory module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

## C02905

Parameter | Name: **C02905 | Online Change Mode** Data type: UNSIGNED\_32  
Index: 21670<sub>d</sub> = 54A6<sub>h</sub>

From software version V3.0

▶ Basic function "Cam data management": [Online change mode](#)

Selection list (Lenze setting printed in bold)	
10	Manual activation
15	Automatic activation
<b>16</b>	<b>Automatic activation with controller inhibit</b>

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02906

Parameter | Name: **C02906 | Online Change State** Data type: UNSIGNED\_32  
Index: 21669<sub>d</sub> = 54A5<sub>h</sub>

From software version V3.0

▶ Basic function "Cam data management": [Online change mode](#)

Selection list (display only)	
0	Ready
5	Initialisation
7	Saving is active
8	Loading is active
11	Waiting for controlled acceptance

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02908

Parameter | Name: **C02908 | Product Count** Data type: UNSIGNED\_32  
Index: 21667<sub>d</sub> = 54A3<sub>h</sub>

From software version V3.0

Display of the highest product number +1 of the cam data currently being processed

▶ Basic function "[Cam data management](#)"

Display range (min. value   unit   max. value)		
0		0

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02909

Parameter | Name: **C02909 | Active Product** Data type: UNSIGNED\_32  
Index: 21666<sub>d</sub> = 54A2<sub>h</sub>

From software version V3.0

Display of the product number of the active product of the cam data currently being processed

▶ Basic function "[Cam data management](#)"

Display range (min. value   unit   max. value)		
0		0

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

## C02910

Parameter | Name: **C02910 | Product Name** Data type: VISIBLE\_STRING  
Index: 21665<sub>d</sub> = 54A1<sub>h</sub>

From software version V3.0

▶ Basic function "[Cam data management](#)"

Read access  Write access  CINH  PLC STOP  No transfer Scaling factor: 1

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02911

C02911

Parameter   Name: <b>C02911   Product Choice</b>		Data type: UNSIGNED_32 Index: 21664 <sub>d</sub> = 54A0 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		47 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C02912

Parameter   Name: <b>C02912   Number Of Products</b>		Data type: UNSIGNED_32 Index: 21663 <sub>d</sub> = 549F <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		65536
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02919

Parameter   Name: <b>C02919   Number Of Cam Tracks</b>		Data type: UNSIGNED_32 Index: 21656 <sub>d</sub> = 5498 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02920

Parameter   Name: <b>C02920   Cam Track Choice</b>		Data type: UNSIGNED_32 Index: 21655 <sub>d</sub> = 5497 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		65535 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C02921

Parameter   Name: <b>C02921   Cam Track Type</b>		Data type: UNSIGNED_32 Index: 21654 <sub>d</sub> = 5496 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Selection list (display only)</b>		
1 Linear		
5 Spline		
11 LinearPC		
15 SplinePC		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02922

Parameter   Name: <b>C02922   Number Of Cam Data Points</b>	Data type: UNSIGNED_32 Index: 21653 <sub>d</sub> = 5495 <sub>h</sub>
From software version V3.0	
<a href="#">▶ Changing cam data via parameterisation</a>	
<b>Display range (min. value   unit   max. value)</b>	
0	65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer                   Scaling factor: 1	

C02923

Parameter   Name: <b>C02923   Cam Data Point Choice</b>	Data type: UNSIGNED_32 Index: 21652 <sub>d</sub> = 5494 <sub>h</sub>
From software version V3.0	
<a href="#">▶ Changing cam data via parameterisation</a>	
<b>Setting range (min. value   unit   max. value)</b>	
0	65535
<b>Lenze setting</b>	
0	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer                   Scaling factor: 1	

C02924

Parameter   Name: <b>C02924   Change Cam Data Point X</b>	Data type: INTEGER_32 Index: 21651 <sub>d</sub> = 5493 <sub>h</sub>
From software version V3.0	
<a href="#">▶ Changing cam data via parameterisation</a>	
<b>Setting range (min. value   unit   max. value)</b>	
-214748.3647	214748.3647
Unit	
<b>Lenze setting</b>	
0.0000 Unit	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer                   Scaling factor: 10000	

C02925

Parameter   Name: <b>C02925   Change Cam Data Point Y</b>	Data type: INTEGER_32 Index: 21650 <sub>d</sub> = 5492 <sub>h</sub>
From software version V3.0	
<a href="#">▶ Changing cam data via parameterisation</a>	
<b>Setting range (min. value   unit   max. value)</b>	
-214748.3647	214748.3647
Unit	
<b>Lenze setting</b>	
0.0000 Unit	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer                   Scaling factor: 10000	

C02926

Parameter   Name: <b>C02926   Change Cam Data Point M</b>	Data type: INTEGER_32 Index: 21649 <sub>d</sub> = 5491 <sub>h</sub>
From software version V3.0	
<a href="#">▶ Changing cam data via parameterisation</a>	
<b>Setting range (min. value   unit   max. value)</b>	
-200.00	200.00
%	
<b>Lenze setting</b>	
0.00 %	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer                   Scaling factor: 100	

C02927

Parameter   Name: <b>C02927   Auto Inc Cam Data Points</b>	Data type: UNSIGNED_32 Index: 21648 <sub>d</sub> = 5490 <sub>h</sub>
From software version V3.0	
<a href="#">▶ Changing cam data via parameterisation</a>	
<b>Selection list (Lenze setting printed in bold)</b>	
0	Deactivate
1	Activate
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer                   Scaling factor: 1	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list

C02939

Parameter   Name:	<b>C02939   Number Of Cont Tracks</b>	Data type: UNSIGNED_32 Index: 21636 <sub>d</sub> = 5484 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C02940

Parameter   Name:	<b>C02940   Cont Track Choice</b>	Data type: UNSIGNED_32 Index: 21635 <sub>d</sub> = 5483 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		65535
<input checked="" type="checkbox"/> Read access	<input checked="" type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer
Scaling factor: 1		

C02941

Parameter   Name:	<b>C02941   Cont Type</b>	Data type: UNSIGNED_32 Index: 21634 <sub>d</sub> = 5482 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Selection list (display only)</b>		
1	Pos. position cam	
2	Neg. position cam	
3	Bidirect. position cam	
11	Pos. time cam	
12	Neg. time cam	
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C02942

Parameter   Name:	<b>C02942   Number Of Cont Data Points</b>	Data type: UNSIGNED_32 Index: 21633 <sub>d</sub> = 5481 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer
Scaling factor: 1		

C02943

Parameter   Name:	<b>C02943   Cont Data Point Choice</b>	Data type: UNSIGNED_32 Index: 21632 <sub>d</sub> = 5480 <sub>h</sub>
From software version V3.0		
<a href="#">▶ Changing cam data via parameterisation</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		65535
<input checked="" type="checkbox"/> Read access	<input checked="" type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer
Scaling factor: 1		

## C02944

Parameter | Name: **C02944 | Cont Pos X0** Data type: INTEGER\_32  
Index: 21631<sub>d</sub> = 547F<sub>h</sub>

From software version V3.0 [▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
-214748.3647	Unit	214748.3647	<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000

## C02945

Parameter | Name: **C02945 | Cont Pos X1** Data type: INTEGER\_32  
Index: 21630<sub>d</sub> = 547E<sub>h</sub>

From software version V3.0 [▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
-214748.3647	Unit	214748.3647	<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000

## C02946

Parameter | Name: **C02946 | Cont Time** Data type: UNSIGNED\_32  
Index: 21629<sub>d</sub> = 547D<sub>h</sub>

From software version V3.0 [▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
0.0000	ms	214748.3647	<b>0.0000 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000

## C02959

Parameter | Name: **C02959 | Number of Pos Tracks** Data type: UNSIGNED\_32  
Index: 21616<sub>d</sub> = 5470<sub>h</sub>

From software version V3.0 [▶ Changing cam data via parameterisation](#)

Display range (min. value   unit   max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 1		

## C02960

Parameter | Name: **C02960 | Pos Track Choice** Data type: UNSIGNED\_32  
Index: 21615<sub>d</sub> = 546F<sub>h</sub>

From software version V3.0 [▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
0		65535	<b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 1

## C02962

Parameter | Name: **C02962 | Number of Pos Data Points** Data type: UNSIGNED\_32  
Index: 21613<sub>d</sub> = 546D<sub>h</sub>

From software version V3.0 [▶ Changing cam data via parameterisation](#)

Display range (min. value   unit   max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		
Scaling factor: 1		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list

C02963

Parameter | Name: **C02963 | Pos Data Point Choice** Data type: UNSIGNED\_32  
Index: 21612<sub>d</sub> = 546C<sub>h</sub>

From software version V3.0

[▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
0		65535	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 1

C02964

Parameter | Name: **C02964 | Change Pos Data Point X** Data type: INTEGER\_32  
Index: 21611<sub>d</sub> = 546B<sub>h</sub>

From software version V3.0

[▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
-214748.3647	Unit	214748.3647	0.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000

C02965

Parameter | Name: **C02965 | Change Pos Data Point Y** Data type: INTEGER\_32  
Index: 21610<sub>d</sub> = 546A<sub>h</sub>

From software version V3.0

[▶ Changing cam data via parameterisation](#)

Setting range (min. value   unit   max. value)			Lenze setting
-214748.3647	Unit	214748.3647	0.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000

C02996

Parameter | Name: **C02996 | Service code** Data type: UNSIGNED\_32  
Index: 21579<sub>d</sub> = 544B<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02997

Parameter | Name: **C02997 | Service code** Data type: UNSIGNED\_32  
Index: 21578<sub>d</sub> = 544A<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02998

Parameter | Name: **C02998 | Service code** Data type: UNSIGNED\_32  
Index: 21577<sub>d</sub> = 5449<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02999

Parameter | Name: **C02999 | Service code** Data type: UNSIGNED\_32  
Index: 21576<sub>d</sub> = 5448<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**



## 14.3 Attribute table

The Attribute table contains information required for communicating with the controller via parameters.

### How to read the table of attributes:

Column		Meaning	Entry	
Code		Parameter designation	Cxxxxx	
Name		Short parameter text (display text)	Text	
Index	dec	Index under which the parameter is addressed. The subindex of array variables corresponds to the Lenze subcode number.	24575 - Lenze code number	Only required for access via bus system.
	hex		5FFF <sub>h</sub> - Lenze code number	
Data	DS	Data structure	E	Single variable (only one parameter element)
			A	Array variable (several parameter elements)
	DA	Number of array elements (subcodes)	Number	
	DT	Data type	BITFIELD_8	1 byte bit-coded
			BITFIELD_16	2 bytes bit-coded
			BITFIELD_32	4 bytes bit-coded
			INTEGER_8	1 byte with sign
			INTEGER_16	2 bytes with sign
			INTEGER_32	4 bytes with sign
			UNSIGNED_8	1 byte without sign
UNSIGNED_16			2 bytes without sign	
Factor	Factor for data transmission via bus system, depending on the number of decimal positions	UNSIGNED_32	4 bytes without sign	
		VISIBLE_STRING	ASCII string	
Access	R	Read access	<input checked="" type="checkbox"/> Reading allowed	
	W	Write access	<input checked="" type="checkbox"/> Writing allowed	
	CINH	Controller inhibit required	<input checked="" type="checkbox"/> Writing only possible when controller is inhibited	

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00002</a>	Device commands	24573	5FFD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00003</a>	Device command status	24572	5FFC	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00004</a>	Service password	24571	5FFB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00005</a>	Application selection	24570	5FFA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00006</a>	Select motor control	24569	5FF9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00007</a>	Active application	24568	5FF8	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00008</a>	Device command progress	24567	5FF7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00011</a>	Motor reference speed	24564	5FF4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00018</a>	Switching frequency	24557	5FED	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00019</a>	Threshold - standstill recognition	24556	5FEC	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00022</a>	Maximum current	24553	5FE9	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00034</a>	Config. analog input 1	24541	5FDD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00050</a>	Speed setpoint [rpm]	24525	5FCD	A	2	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00051</a>	Actual speed [rpm]	24524	5FCC	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00052</a>	Motor voltage	24523	5FCB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00053</a>	DC-bus voltage	24522	5FCA	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00054</a>	Motor current	24521	5FC9	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00055</a>	Phase currents	24520	5FC8	A	4	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00056</a>	Torque setpoint	24519	5FC7	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00057</a>	Torque	24518	5FC6	A	2	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00058</a>	Pole position	24517	5FC5	A	3	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00059</a>	Motor - number of pole pairs	24516	5FC4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00060</a>	Rotor position	24515	5FC3	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00061</a>	Heatsink temperature	24514	5FC2	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00062</a>	Temperature inside the controller	24513	5FC1	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00063</a>	Motor temperature	24512	5FC0	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00064</a>	Device utilisation (lxt)	24511	5FBF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00065</a>	Ext. 24-V voltage	24510	5FBE	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00066</a>	Thermal motor load (l*xt)	24509	5FBD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00068</a>	Capacitor temperature	24507	5FBB	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00069</a>	CPU temperature	24506	5FBA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00070</a>	Speed controller gain	24505	5FB9	E	1	UNSIGNED_32	100000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00071</a>	Speed controller reset time	24504	5FB8	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00072</a>	Speed controller rate time	24503	5FB7	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00074</a>	Feedfwd. ctrl. - current contr.	24501	5FB5	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00075</a>	Current controller gain	24500	5FB4	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00076</a>	Current contr. reset time	24499	5FB3	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00077</a>	Field controller gain	24498	5FB2	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00078</a>	Field contr. reset time	24497	5FB1	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00079</a>	Mutual motor inductance	24496	5FB0	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00080</a>	Resolver - number of pole pairs	24495	5FAF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00081</a>	Rated motor power	24494	5FAE	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00082</a>	Motor rotor resistance	24493	5FAD	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C00083</a>	Motor - rotor time constant	24492	5FAC	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00084</a>	Motor stator resistance	24491	5FAB	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00085</a>	Motor stator leakage induct.	24490	5FAA	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00087</a>	Rated motor speed	24488	5FA8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00088</a>	Rated motor current	24487	5FA7	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00089</a>	Rated motor frequency	24486	5FA6	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00090</a>	Rated motor voltage	24485	5FA5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00091</a>	Motor - cosine phi	24484	5FA4	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00092</a>	Motor magnetising current	24483	5FA3	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00093</a>	Field weakening for SM	24482	5FA2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00099</a>	Firmware version	24476	5F9C	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00100</a>	Resol. of an encoder revolution	24475	5F9B	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00105</a>	Quick stop decel. time	24470	5F96	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00106</a>	Quick stop S-ramp time	24469	5F95	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00107</a>	Ref. for quick stop dec. time	24468	5F94	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00114</a>	Digital inp. x - terminal pol.	24461	5F8D	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00118</a>	Dig. output x: terminal pol.	24457	5F89	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00120</a>	Motor overload protection (l*xt)	24455	5F87	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00121</a>	Motor temp. warning threshold	24454	5F86	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00122</a>	Heatsink temp. warn. threshold	24453	5F85	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00123</a>	Warning threshold device util.	24452	5F84	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00126</a>	CPU temp. warning threshold	24449	5F81	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00127</a>	Mot. overload warning threshold	24448	5F80	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00128</a>	Therm. motor time constant	24447	5F7F	A	2	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00129</a>	Brake resistor value	24446	5F7E	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00130</a>	Rated power of brake resistor	24445	5F7D	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00131</a>	Rated quantity of heat for brake res.	24444	5F7C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00133</a>	Ref.: Brake chopper utilisation	24442	5F7A	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00134</a>	Min. brake resistance	24441	5F79	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00137</a>	Brake transistor utilisation	24438	5F76	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00138</a>	Brake resistor utilisation	24437	5F75	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00142</a>	Autom. restart after mains ON	24433	5F71	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00150</a>	Status word device control 1	24425	5F69	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00155</a>	Status word device control 2	24420	5F64	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00156</a>	Status/Control word MCTRL	24419	5F63	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00158</a>	Controller inhibit by (source)	24417	5F61	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00159</a>	Quick stop by (source)	24416	5F60	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00162</a>	Masked error number	24413	5F5D	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00166</a>	Error description	24409	5F59	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00168</a>	Error number	24407	5F57	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00169</a>	Logbook event filter	24406	5F56	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00173</a>	Mains voltage	24402	5F52	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00174</a>	Undervoltage (LU) threshold	24401	5F51	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00178</a>	Elapsed-hour meter	24397	5F4D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00179</a>	Power-on time meter	24396	5F4C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00180</a>	Service code	24395	5F4B	E	1	VISIBLE_STRING		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00181</a>	Red. brake chopper threshold	24394	5F4A	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00183</a>	Device state	24392	5F48	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00185</a>	Mains recov. detect. threshold	24390	5F46	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00186</a>	ENP: Identified motor type	24389	5F45	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00187</a>	ENP: Identified serial number	24388	5F44	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00188</a>	ENP: Status	24387	5F43	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00199</a>	Device name	24376	5F38	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00200</a>	Firmware product type	24375	5F37	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00201</a>	Firmware compilation date	24374	5F36	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00202</a>	Autom. ENP data transfer	24373	5F35	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00203</a>	HW product types	24372	5F34	A	9	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00204</a>	HW serial numbers	24371	5F33	A	9	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00205</a>	HW descriptions	24370	5F32	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00206</a>	HW manufacturing data	24369	5F31	A	8	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00208</a>	HW manufacturer	24367	5F2F	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00209</a>	HW countries of origin	24366	5F2E	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00210</a>	HW versions	24365	5F2D	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00211</a>	Application: Version	24364	5F2C	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00212</a>	Application: Type code	24363	5F2B	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00213</a>	Application: compilation date	24362	5F2A	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00214</a>	Required safety module	24361	5F29	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00218</a>	Application: ID number	24357	5F25	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00227</a>	Behav. at parameter set changeover	24348	5F1C	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00254</a>	Phase controller gain	24321	5F01	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00270</a>	Freq. - current setpoint filter	24305	5EF1	A	2	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00271</a>	Width - current setp. filter	24304	5EF0	A	2	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00272</a>	Depth - current setp. filter	24303	5EEF	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00273</a>	Moment of inertia	24302	5EEE	A	2	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00274</a>	Max. acceleration change	24301	5EED	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00275</a>	Signal source - speed setpoint	24300	5EEC	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00276</a>	Signal source - torque setpoint	24299	5EEB	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00280</a>	Filter time const. DC detection	24295	5EE7	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00281</a>	Filter for PWM adjustment	24294	5EE6	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00311</a>	CAN TPDO1 mask byte x	24264	5EC8	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00312</a>	CAN TPDO2 mask byte x	24263	5EC7	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00313</a>	CAN TPDO3 mask byte x	24262	5EC6	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00314</a>	CAN TPDO4 mask byte x	24261	5EC5	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00320</a>	CAN TPDOx identifier	24255	5EBF	A	4	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00321</a>	CAN RPDOx identifier	24254	5EBE	A	4	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00322</a>	CAN TPDOx Tx mode	24253	5EBD	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00323</a>	CAN RPDOx Rx mode	24252	5EBC	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00324</a>	CAN TPDOx delay time	24251	5EBB	A	4	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00343</a>	CAN TPDO counter	24232	5EA8	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00344</a>	CAN RPDO counter	24231	5EA7	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00345</a>	CAN error	24230	5EA6	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00346</a>	CAN heartbeat activity	24229	5EA5	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00347</a>	CAN heartbeat status	24228	5EA4	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00348</a>	CAN status DIP switch	24227	5EA3	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00349</a>	CAN setting of DIP switch	24226	5EA2	A	2	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00350</a>	CAN node address	24225	5EA1	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00351</a>	CAN baud rate	24224	5EA0	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00352</a>	CAN slave/master	24223	5E9F	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00356</a>	CAN TPDOx cycle time	24219	5E9B	A	4	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00357</a>	CAN RPDOx monitoring time	24218	5E9A	A	4	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00359</a>	CAN status	24216	5E98	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00360</a>	CAN telegram and error counter	24215	5E97	A	8	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00361</a>	CAN bus load	24214	5E96	A	6	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00367</a>	CAN SYNC Rx identifier	24208	5E90	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00368</a>	CAN SYNC Tx identifier	24207	5E8F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00369</a>	CAN sync transmission cycle time	24206	5E8E	A	3	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00372</a>	CAN SDO server Rx identifier	24203	5E8B	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00373</a>	CAN SDO server Tx identifier	24202	5E8A	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00374</a>	CAN SDO client node address	24201	5E89	A	10	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00375</a>	CAN SDO client Rx identifier	24200	5E88	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00376</a>	CAN SDO client Tx identifier	24199	5E87	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00377</a>	CAN SDO server node address	24198	5E86	A	10	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00378</a>	CAN delay boot-up - operational	24197	5E85	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00381</a>	CAN Heartbeat Producer Time	24194	5E82	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00382</a>	CAN guard time	24193	5E81	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00383</a>	CAN Life Time Factor	24192	5E80	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00385</a>	CAN Heartbeat Consumer Time	24190	5E7E	A	32	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00386</a>	CAN Node Guarding	24189	5E7D	A	32	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00387</a>	CAN Node Guarding Activity	24188	5E7C	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00388</a>	CAN node guarding status	24187	5E7B	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00390</a>	CAN Error Register (DS301V402)	24185	5E79	E	1	BITFIELD_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00391</a>	CAN Emergency Object	24184	5E78	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00392</a>	CAN emergency delay time	24183	5E77	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00393</a>	CAN result - bus scan	24182	5E76	A	128	UNSIGNED_8	1	<input checked="" type="checkbox"/>		

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00394</a>	CAN Predefined Error Field (DS301V402)	24181	5E75	A	10	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00398</a>	Test mode motor control	24177	5E71	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00399</a>	Settings for test mode	24176	5E70	A	2	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00413</a>	Hiperface: detected TypeCode	24162	5E62	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00414</a>	Hiperface: TypeCode	24161	5E61	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00415</a>	Hiperface: number of rev.	24160	5E60	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00417</a>	Dynamic of resolver evaluation	24158	5E5E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00418</a>	Activate resolver error compensation	24157	5E5D	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00420</a>	Encoder - number of increments	24155	5E5B	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00421</a>	Encoder voltage	24154	5E5A	E	1	UNSIGNED_16	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00422</a>	Encoder type	24153	5E59	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00423</a>	SSI encoder: Bit rate	24152	5E58	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00424</a>	Ssi-encoder: Data word length	24151	5E57	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00427</a>	TTL encoder signal evaluation	24148	5E54	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00435</a>	SSI encoder: Partword starting position	24140	5E4C	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00436</a>	SSI encoder: Partword length	24139	5E4B	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00437</a>	SSI encoder: Partword data coding	24138	5E4A	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00443</a>	Status: Digital inputs	24132	5E44	A	12	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00444</a>	Status: Digital outputs	24131	5E43	A	18	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00464</a>	Keypad: Mode	24111	5E2F	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00465</a>	Keypad: Welcome screen time-out	24110	5E2E	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00466</a>	Keypad: Default parameters	24109	5E2D	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00467</a>	Keypad: Default welcome screen	24108	5E2C	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00469</a>	Keypad: Fct. STOP key	24106	5E2A	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00490</a>	Position encoder selection	24085	5E15	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00494</a>	Motor standstill time constant	24081	5E11	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00495</a>	Motor encoder selection	24080	5E10	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00497</a>	Act. speed value time constant	24078	5E0E	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00569</a>	Resp. brake trans. Ixt &gt; C00570	24006	5DC6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00570</a>	Warning thres. brake transistor	24005	5DC5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00571</a>	Resp. brake res. Ixt &gt; C00572	24004	5DC4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00572</a>	Warning thres. brake resistor	24003	5DC3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00573</a>	Resp. to overload brake trans.	24002	5DC2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00574</a>	Resp. to overtemp. brake resist.	24001	5DC1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00576</a>	Speed monitoring tolerance	23999	5DBF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00577</a>	Field weakening controller gain	23998	5DBE	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00578</a>	Field weak. contr. reset time	23997	5DBD	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00579</a>	Resp. to speed monitoring	23996	5DBC	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00580</a>	Resp. to encoder open circuit	23995	5DBB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00581</a>	Resp. to external fault	23994	5DBA	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00582</a>	Resp. to heatsink temp. &gt; C00122	23993	5DB9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00583</a>	Resp. to motor KTY overtemp.	23992	5DB8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00584</a>	Resp. to motor temp. &gt; C00121	23991	5DB7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00585</a>	Resp. to motor PTC overtemp.	23990	5DB6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00586</a>	Resp. to resolver open circuit	23989	5DB5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00587</a>	Fan control status	23988	5DB4	E	1	BITFIELD_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00588</a>	Resp. to failure t. sensor drive	23987	5DB3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00589</a>	Resp. to CPU temp &gt; C00126	23986	5DB2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00591</a>	Resp. to CAN-RPDOx error	23984	5DB0	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00594</a>	Reaktion Resp. temp. sensor motor X7/X8	23981	5DAD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00595</a>	Resp. to CAN bus OFF	23980	5DAC	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00596</a>	Threshold max. speed reached	23979	5DAB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00597</a>	Resp. to motor phase failure	23978	5DAA	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00598</a>	Resp. to open circuit AIN1	23977	5DA9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00599</a>	Motor phase failure threshold	23976	5DA8	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00600</a>	Resp. to DC bus overvoltage	23975	5DA7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00601</a>	Resp. to encoder comm. error	23974	5DA6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00604</a>	Resp. to device overload &gt; C00123	23971	5DA3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00606</a>	Resp. to motor overload &gt; C00127	23969	5DA1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00607</a>	Resp. to max. speed reached	23968	5DA0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00610</a>	Resp. to failure heatsink fan	23965	5D9D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00611</a>	Resp. to failure integral fan	23964	5D9C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00612</a>	Resp. to CAN node guarding error	23963	5D9B	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00613</a>	Resp. to CAN heartbeat error	23962	5D9A	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00614</a>	Resp. to CAN life guarding error	23961	5D99	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00615</a>	Resp. to imp. device config.	23960	5D98	A	5	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00618</a>	No. of CRC cycles	23957	5D95	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00619</a>	Resp. to motor current &gt; C00620	23956	5D94	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00620</a>	Ultimate motor current I_ult	23955	5D93	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00621</a>	Resp. to encoder pulse deviation	23954	5D92	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00625</a>	CAN behaviour in case of fault	23950	5D8E	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00635</a>	Resp to new firmw. standard dev.	23940	5D84	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00636</a>	Resp. to new module in MXI1	23939	5D83	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00637</a>	Resp. to new module in MXI2	23938	5D82	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00640</a>	Resp. to pole pos. id. monit.	23935	5D7F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00641</a>	PolePosId 360° current amp.	23934	5D7E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00642</a>	PolePosId 360° ramp time	23933	5D7D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00643</a>	PolePosId 360° travel dir.	23932	5D7C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00644</a>	PolePosId 360° fault tol.	23931	5D7B	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00645</a>	PolePosId 360° absolute cur. amp.	23930	5D7A	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00646</a>	PolePosId min.mov. cur. amp.	23929	5D79	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00647</a>	PolePosId min.mov. cur.rise rate	23928	5D78	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00648</a>	PolePosId min.mov. gain	23927	5D77	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00649</a>	PLI min. mov. reset time	23926	5D76	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00650</a>	PolePosId min.mov. max.perm.mov.	23925	5D75	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00651</a>	PolePosId min.mov. absolute cur. amp.	23924	5D74	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00691</a>	Total speed setpoint	23884	5D4C	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00692</a>	Speed setpoint [%]	23883	5D4B	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00693</a>	Actual speed [%]	23882	5D4A	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00694</a>	Speed controller output	23881	5D49	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00695</a>	Total torque setpoint	23880	5D48	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00696</a>	Torque setpoint [%]	23879	5D47	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00697</a>	Filtered torque setpoint	23878	5D46	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00698</a>	Actual torque [%]	23877	5D45	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00770</a>	MCTRL_dnMotorPosAct	23805	5CFD	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00771</a>	MCTRL_dnLoadPosAct	23804	5CFC	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00772</a>	MCTRL_dnMotorSpeedAct	23803	5CFB	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00773</a>	MCTRL_dnLoadSpeedAct	23802	5CFA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00774</a>	MCTRL_dnTorqueAct	23801	5CF9	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00775</a>	MCTRL_dnOutputSpeedCtrl	23800	5CF8	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00776</a>	MCTRL_dnInputJerkCtrl	23799	5CF7	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00777</a>	MCTRL_dnInputTorqueCtrl	23798	5CF6	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00778</a>	MCTRL_dnFluxAct	23797	5CF5	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00779</a>	MCTRL_dnDCBusVoltage	23796	5CF4	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00780</a>	MCTRL_dnImotAct	23795	5CF3	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00781</a>	MCTRL_dwMaxMotorSpeed	23794	5CF2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00782</a>	MCTRL_dwMaxMotorTorque	23793	5CF1	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00783</a>	MCTRL_dwMotorVoltageAct	23792	5CF0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00784</a>	MCTRL_dnMotorFreqAct	23791	5CEF	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00786</a>	MCTRL_dnIxtLoad	23789	5CED	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00787</a>	MCTRL_dnFlyingSpeedAct	23788	5CEC	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00788</a>	MCTRL_dwMaxEffMotorTorque	23787	5CEB	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00789</a>	MCTRL_dwMaxDeviceCurrent	23786	5CEA	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00790</a>	MCTRL_dnl2xtLoad	23785	5CE9	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00791</a>	MCTRL_dnDeltaMotorPos_p	23784	5CE8	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00792</a>	MCTRL_dnOutputPosCtrlMotor_s	23783	5CE7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00800</a>	MCTRL_dnPosSet	23775	5CDF	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00802</a>	MCTRL_dnSpeedAdd	23773	5CDD	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00803</a>	MCTRL_dnTorqueAdd	23772	5CDC	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00804</a>	MCTRL_dnAccelerationAdd	23771	5CDB	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00805</a>	MCTRL_dnSpeedLowLimit	23770	5CDA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00806</a>	MCTRL_dnTorqueLowLimit	23769	5CD9	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00807</a>	MCTRL_dnTorqueHighLimit	23768	5CD8	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00808</a>	MCTRL_dnPosCtrlOutLimit	23767	5CD7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00809</a>	MCTRL_dnTorqueCtrlAdapt	23766	5CD6	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00810</a>	MCTRL_dnSpeedCtrlAdapt	23765	5CD5	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00811</a>	MCTRL_dnPosCtrlAdapt	23764	5CD4	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00812</a>	MCTRL_dnMotorPosRefValue	23763	5CD3	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00813</a>	MCTRL_dnLoadPosRefValue	23762	5CD2	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00814</a>	MCTRL_dnBoost	23761	5CD1	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00815</a>	MCTRL_dnSpeedCtrlIntegrator	23760	5CD0	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00816</a>	MCTRL_dnFieldWeak	23759	5CCF	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00817</a>	MCTRL_dnSpeedSet_s	23758	5CCE	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00818</a>	MCTRL_dnMvorAdapt	23757	5CCD	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00854</a>	ID status	23721	5CA9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00878</a>	Status DCTRL control input	23697	5C91	A	5	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00909</a>	Speed limitation	23666	5C72	A	2	INTEGER_16	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00950</a>	VFC: V/f characteristic shape	23625	5C49	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00951</a>	VFC: V/f base frequency	23624	5C48	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00952</a>	VFC: Frequency interpol. point n	23623	5C47	A	11	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00953</a>	VFC: Voltage interpol. point n	23622	5C46	A	11	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00954</a>	VFC: Activat. interpol. point n	23621	5C45	A	11	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00955</a>	VFC: Vmax reduction	23620	5C44	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00957</a>	VFC: VVC current setpoint	23618	5C42	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00958</a>	VFC: VVC gain	23617	5C41	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00959</a>	VFC: VVC reset time	23616	5C40	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00960</a>	VFC: V/f voltage boost	23615	5C3F	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00961</a>	VFC: Load - cw/ccw-operation	23614	5C3E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00962</a>	VFC: Load adjustment	23613	5C3D	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00963</a>	VFC: Gain - Imax controller	23612	5C3C	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00964</a>	VFC: Reset time - lmax controller	23611	5C3B	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00965</a>	VFC: Gain - slip compensation	23610	5C3A	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00966</a>	VFC: Time const. - slip compens.	23609	5C39	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00967</a>	VFC: Gain - oscillation damping	23608	5C38	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00968</a>	VFC: Time const. - oscill. damp.	23607	5C37	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00969</a>	VFC: Limitation - oscill. damp.	23606	5C36	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00970</a>	VFC: ramp-end frequ. - oscill. damp.	23605	5C35	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00971</a>	VFC: Influence - speed controller	23604	5C34	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00972</a>	VFC: Gain - speed controller	23603	5C33	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00973</a>	VFC: Reset time - speed contr.	23602	5C32	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00974</a>	DC brake: Current	23601	5C31	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00975</a>	DC brake: Current for quick stop	23600	5C30	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00976</a>	DC brake: Activat. by quick stop	23599	5C2F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00977</a>	Min. inh-time aft. overvolt.	23598	5C2E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00980</a>	VFC: Override point of field weakening	23595	5C2B	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00985</a>	SLVC: Gain - flux controller	23590	5C26	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00986</a>	SLVC: Gain - cross curr. contr.	23589	5C25	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00987</a>	SLVC: Gain - torque controller	23588	5C24	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00988</a>	SLVC: Torque controller reset time	23587	5C23	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00989</a>	SLVC: Time const.- Para. adj.	23586	5C22	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00990</a>	Flying restart: Activation	23585	5C21	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00991</a>	Flying restart: Current	23584	5C20	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00992</a>	Flying restart: Start frequency	23583	5C1F	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00993</a>	Flying restart: Integration time	23582	5C1E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00994</a>	Flying restart: Min. deviation	23581	5C1D	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00995</a>	Flying restart: Delay time	23580	5C1C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00998</a>	VFC: Frequency setpoint	23577	5C19	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C01120</a>	Sync source	23455	5B9F	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01121</a>	Sync cycle time	23454	5B9E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01122</a>	Sync phase position	23453	5B9D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01123</a>	Sync tolerance	23452	5B9C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01124</a>	Sync-PLL increment	23451	5B9B	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01130</a>	CAN SYNC application cycle	23445	5B95	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01190</a>	Motor thermal sensor	23385	5B59	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01191</a>	Spec. characteristic: temperature	23384	5B58	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01192</a>	Spec. characteristic: resistance	23383	5B57	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01193</a>	Motor temp. feedback system	23382	5B56	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C01194</a>	Motor operating temperature	23381	5B55	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01195</a>	Influence winding I <sup>2</sup> xt mon.	23380	5B54	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01196</a>	S1 torque characteristic I <sup>2</sup> xt mon.	23379	5B53	A	8	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01198</a>	Async. motor: Stall protection	23377	5B51	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01199</a>	Enhanced power	23376	5B50	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C01200</a>	Dual motor temperature	23375	5B4F	A	2	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C01201</a>	Delay time for fan start	23374	5B4E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01203</a>	Counter: Brake chopper overload	23372	5B4C	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01204</a>	Counter: Ixt overload	23371	5B4B	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01205</a>	Counter: DC bus overvoltage	23370	5B4A	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01206</a>	Counter: Mains switching	23369	5B49	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01208</a>	Counter: Heatsink overtemp.	23367	5B47	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01209</a>	Counter: Housing overtemp.	23366	5B46	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01210</a>	Counter: internal	23365	5B45	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		



Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C01212</a>	Counter: Power section overload	23363	5B43	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01214</a>	Internal clock	23361	5B41	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C01215</a>	Set time and date	23360	5B40	A	6	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01230</a>	Resp. to communication task overflow	23345	5B31	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01501</a>	Resp. to comm. error with MXI1	23074	5A22	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01502</a>	Resp. to comm. error with MXI2	23073	5A21	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01510</a>	Ethernet IP address client x	23065	5A19	A	3	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C01511</a>	Ethernet status client x	23064	5A18	A	3	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C01902</a>	Diagnostics X6: Max. baud rate	22673	5891	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01903</a>	Diagnostics X6: Change baud rate	22672	5890	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01905</a>	Diagnostics X6: Curr. baud rate	22670	588E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02104</a>	Program auto-start	22471	57C7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02108</a>	Program status	22467	57C3	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C02109</a>	Program runtime	22466	57C2	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C02110</a>	User code: Memory utilisation	22465	57C1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02111</a>	Resp. to task overflow	22464	57C0	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02113</a>	Program name	22462	57BE	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02121</a>	Runtime ApplicationTask	22454	57B6	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02122</a>	Runtime UserTask	22453	57B5	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02123</a>	Runtime IdleTask	22452	57B4	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02520</a>	Gearbox factor numerator: Motor	22055	5627	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02521</a>	Gearbox factor denom.: Motor	22054	5626	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02522</a>	Gearbox factor num.: Pos. enc.	22053	5625	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02523</a>	Gearbox fac. denom.: Pos. enc.	22052	5624	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02524</a>	Feed constant	22051	5623	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02525</a>	Unit	22050	5622	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02526</a>	User-defined unit	22049	5621	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02527</a>	Motor mounting direction	22048	5620	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02528</a>	Traversing range	22047	561F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02529</a>	Position encoder mounting dir.	22046	561E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02530</a>	Active function state	22045	561D	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02531</a>	Gearbox factors (decimal)	22044	561C	A	3	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C02532</a>	Resolution of a unit	22043	561B	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02533</a>	Time unit	22042	561A	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02534</a>	Used time unit	22041	5619	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02535</a>	Used unit	22040	5618	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02536</a>	Cycle	22039	5617	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02537</a>	Speed unit	22038	5616	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02538</a>	Acceleration unit	22037	5615	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02539</a>	Max. presentable position	22036	5614	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02540</a>	Max. presentable speed	22035	5613	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02541</a>	Max. presentable acceleration	22034	5612	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02542</a>	Load reference speed	22033	5611	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C02543</a>	Load reference torque	22032	5610	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C02544</a>	Reference speed	22031	560F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02545</a>	Reference Jerktime	22030	560E	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02547</a>	DI_dnState	22028	560C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02548</a>	DI_bErrors	22027	560B	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02549</a>	Drive interface: Signals	22026	560A	A	15	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02550</a>	Setpoint interpolation	22025	5609	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02552</a>	Position setpoint (motor interface)	22023	5607	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02553</a>	Position controller gain	22022	5606	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02554</a>	Position controller reset time	22021	5605	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02555</a>	D component position controller	22020	5604	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02556</a>	Pos. contr. limitation	22019	5603	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02557</a>	Phase controller output	22018	5602	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02558</a>	Pos. contr. output	22017	5601	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02559</a>	Internal torque limits	22016	5600	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02560</a>	Messages - motor interface	22015	55FF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02561</a>	Speed feedforw. control gain	22014	55FE	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02562</a>	Filter time constant	22013	55FD	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02567</a>	Control mode	22008	55F8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02568</a>	Motor interface: % signals	22007	55F7	A	10	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02569</a>	Motor interface.: Dig. signals	22006	55F6	A	16	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02570</a>	Position control structure	22005	55F5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02572</a>	Speed setpoint (enc. eval.)	22003	55F3	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02573</a>	Position setpoint (enc. eval.)	22002	55F2	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02574</a>	Actual speed (enc. eval.)	22001	55F1	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02575</a>	Actual position (enc. eval.)	22000	55F0	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02576</a>	Following error	21999	55EF	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02577</a>	External actual position	21998	55EE	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02578</a>	Offset actual pos. value/setp.	21997	55ED	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02579</a>	Encoder eval.: Dig. signals	21996	55EC	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02580</a>	Operating mode brake	21995	55EB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02581</a>	Threshold - brake activation	21994	55EA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02582</a>	Brake resp. to pulse inhibit	21993	55E9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02583</a>	Status input monitoring	21992	55E8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02585</a>	Brake control polarity	21990	55E6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02586</a>	Starting torque 1	21989	55E5	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02587</a>	Starting torque 2	21988	55E4	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02588</a>	Source of starting torque	21987	55E3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02589</a>	Brake closing time	21986	55E2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02590</a>	Brake opening time	21985	55E1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02591</a>	Waiting time - status monitoring	21984	55E0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02593</a>	Waiting time - brake activation	21982	55DE	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02594</a>	Test torque	21981	55DD	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02595</a>	Permissible angle of rotation	21980	55DC	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02596</a>	Grinding speed	21979	55DB	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02597</a>	Accel./decel. time - grinding	21978	55DA	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02598</a>	Grinding ON time	21977	55D9	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02599</a>	Grinding OFF time	21976	55D8	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02600</a>	Acceleration time feedf. control	21975	55D7	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02601</a>	Ref. for Accel. time of brake	21974	55D6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02602</a>	Source for feedf. control brake	21973	55D5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02603</a>	Threshold 1 for opening brake	21972	55D4	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02604</a>	Threshold 2 for opening brake	21971	55D3	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02607</a>	BRK_dnState	21968	55D0	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02608</a>	BRK_dnTorqueAdd_n	21967	55CF	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02609</a>	Brake control: Dig. signals	21966	55CE	A	10	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02610</a>	Deceleration time for stop	21965	55CD	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02611</a>	S-ramp time for stop	21964	55CC	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02612</a>	Ref. for decel. time of stop	21963	55CB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02616</a>	STP_dnState	21959	55C7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02617</a>	STP_bStopActive	21958	55C6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02619</a>	Quick stop: Dig. signals	21956	55C4	A	5	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02620</a>	Manual jog: Speed 1	21955	55C3	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02621</a>	Manual jog: Speed 2	21954	55C2	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02622</a>	Manual jog: Acceleration	21953	55C1	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02623</a>	Manual jog: Deceleration	21952	55C0	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02624</a>	Manual jog: S-ramp time	21951	55BF	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02625</a>	Manual jog: Step size	21950	55BE	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02626</a>	Manual jog: Index stop position	21949	55BD	A	16	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02627</a>	Manual jog: Selected stop position	21948	55BC	A	16	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02637</a>	MAN_dnSpeedOverride_n	21938	55B2	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02638</a>	Manual jog: Status	21937	55B1	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02639</a>	Manual jog: Dig. signals	21936	55B0	A	9	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02640</a>	Homing mode	21935	55AF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02641</a>	Action after detect home position	21934	55AE	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02642</a>	Home position	21933	55AD	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02643</a>	Homing: Target position	21932	55AC	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02644</a>	Homing: Speed 1	21931	55AB	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02645</a>	Homing: Acceleration 1	21930	55AA	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02646</a>	Homing: Speed 2	21929	55A9	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02647</a>	Homing: Acceleration 2	21928	55A8	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02648</a>	Homing: S-ramp time	21927	55A7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02649</a>	Homing: Torque limit	21926	55A6	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02650</a>	Homing: Blocking time	21925	55A5	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02651</a>	Homing: TP configuration	21924	55A4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02652</a>	Ref. pos. after mains switching	21923	55A3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02653</a>	Max. rot. ang. aft. mns. swtch.	21922	55A2	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02655</a>	HM_dnSpeedOverride_n	21920	55A0	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02656</a>	Actual position (homing)	21919	559F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02657</a>	HM_dnState	21918	559E	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02658</a>	HM_dnHomePos_p	21917	559D	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02659</a>	Homing: Dig. signals	21916	559C	A	9	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02670</a>	Tolerance for POS_bActPosInTarget	21905	5591	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02671</a>	Tolerance for POS_bDrivelnTarget	21904	5590	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02672</a>	Hysteresis for POS_bDrivelnTarget	21903	558F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02673</a>	Activate DrivelnTarget Modulo	21902	558E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02674</a>	POS_dwActualProfileNumber	21901	558D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02675</a>	POS_dnState	21900	558C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02676</a>	POS_dnProfileSpeed_s	21899	558B	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02677</a>	Positioning: % signals	21898	558A	A	3	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02678</a>	Positioning: Pos. signals	21897	5589	A	4	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02679</a>	Positioning: Dig. signals	21896	5588	A	12	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02680</a>	Source position setpoint	21895	5587	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02681</a>	Source add. speed	21894	5586	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02685</a>	PF_dnMotorAcc_x	21890	5582	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02686</a>	PF_dnSpeedAdd1_s	21889	5581	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02687</a>	Position follower: % signals	21888	5580	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02688</a>	PF_dnPositionSet_p	21887	557F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02689</a>	Position follower: Dig. signals	21886	557E	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02692</a>	SF_dnMotorAcc_x	21883	557B	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02693</a>	SF_dnSpeedAdd_s	21882	557A	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02694</a>	Speed follower: % signals	21881	5579	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02695</a>	Speed follower: Dig. signals	21880	5578	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02698</a>	Torque follower: % signals	21877	5575	A	3	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02699</a>	Torque follower: Dig. signals	21876	5574	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02700</a>	Software limits pos. effective	21875	5573	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02701</a>	Software limit positions	21874	5572	A	2	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02702</a>	Limitations effective	21873	5571	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02703</a>	Max. speed	21872	5570	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02704</a>	Max. speed [rpm]	21871	556F	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02705</a>	Max. acceleration	21870	556E	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02706</a>	Min. S-ramp time	21869	556D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02707</a>	Permissible direction of rot.	21868	556C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02708</a>	Limited speed	21867	556B	A	4	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02709</a>	Limited speed [rpm]	21866	556A	A	4	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02710</a>	Delay lim. speed	21865	5569	A	4	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02711</a>	S-ramp time lim. speed	21864	5568	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02712</a>	Decel. time lim. speed	21863	5567	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02713</a>	Max. dist. manual control	21862	5566	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02714</a>	Max. dist. manual jog [inc.]	21861	5565	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02715</a>	Limitation active	21860	5564	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02716</a>	Resp. to limitation	21859	5563	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02717</a>	LIM_dwControl	21858	5562	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02718</a>	LIM_dnState	21857	5561	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02719</a>	Limiter: Dig. signals	21856	5560	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02720</a>	Software limit position monitoring	21855	555F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02730</a>	Analog inputs: Gain	21845	5555	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02731</a>	Analog inputs: Offset	21844	5554	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02732</a>	Analog inputs: Dead band	21843	5553	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02733</a>	Analog outputs: Gain	21842	5552	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02734</a>	Analog outputs: Offset	21841	5551	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02760</a>	Activate Encoder	21815	5537	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02761</a>	Resolution Multiturn	21814	5536	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02762</a>	Encoder position	21813	5535	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02763</a>	Encoder revolution	21812	5534	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02764</a>	Encoderspeed	21811	5533	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02765</a>	ENC_bError	21810	5532	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02770</a>	Mode of operation	21805	552D	A	5	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02771</a>	Frequency	21804	552C	A	4	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02772</a>	Start angle	21803	552B	A	4	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02773</a>	Current	21802	552A	A	4	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02774</a>	Acceleration time	21801	5529	A	4	INTEGER_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02775</a>	Deceleration time	21800	5528	A	4	INTEGER_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02776</a>	Duration time	21799	5527	A	4	INTEGER_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02779</a>	Mol_SetpointCurrent	21796	5524	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02780</a>	Mol_dnState	21795	5523	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02781</a>	ManualJogOpenLoop: Dig. signals	21794	5522	A	8	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02785</a>	Activation of PPI	21790	551E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02786</a>	Mode of PPI	21789	551D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02787</a>	Ppi_dnState	21788	551C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02788</a>	PolePosition Setpoint	21787	551B	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02789</a>	PolePositionIdentification: Dig. signals	21786	551A	A	9	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02800</a>	Analog input x: Input signal	21775	550F	A	2	INTEGER_16	1	<input checked="" type="checkbox"/>		
<a href="#">C02801</a>	Analog output x: Output signal	21774	550E	A	2	INTEGER_16	1	<input checked="" type="checkbox"/>		
<a href="#">C02802</a>	Status word: Digital outputs	21773	550D	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02803</a>	Status word: Digital inputs	21772	550C	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02810</a>	Touch probe x: Delay time	21765	5505	A	10	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02830</a>	Digital inputs: Delay time	21745	54F1	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02853</a>	Lss sat. characteristic	21722	54DA	A	17	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02855</a>	lmax f. Lss sat. characteristic	21720	54D8	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02859</a>	Activate Lss sat. char.	21716	54D4	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02860</a>	Rr adjustment	21715	54D3	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02861</a>	Lh adjustment	21714	54D2	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02862</a>	Service code	21713	54D1	A	2	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02863</a>	Service code	21712	54D0	E	1	INTEGER_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02864</a>	Service code	21711	54CF	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02865</a>	Adaptation of Ur	21710	54CE	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02900</a>	User Password	21675	54AB	E	1	VISIBLE_STRING		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02901</a>	CamMemory	21674	54AA	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02902</a>	Time stamp of cam data	21673	54A9	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02903</a>	GUID cam data	21672	54A8	A	4	OCTET_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02905</a>	Online Change Mode	21670	54A6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02906</a>	Online change status	21669	54A5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02908</a>	Number Of Products	21667	54A3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02909</a>	Active Product	21666	54A2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02910</a>	Product Name	21665	54A1	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02911</a>	Product Choice	21664	54A0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02912</a>	Number Of Products	21663	549F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02919</a>	Number of curve tracks	21656	5498	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02920</a>	Cam Track Choice	21655	5497	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02921</a>	Cam Track Type	21654	5496	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02922</a>	Number of Cam Data Points	21653	5495	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02923</a>	Cam Data Point Choice	21652	5494	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02924</a>	Change Cam Data Point X	21651	5493	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02925</a>	Change Cam Data Point Y	21650	5492	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02926</a>	Change Cam Data Point M	21649	5491	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02927</a>	Auto Inc Cam Data Points	21648	5490	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02939</a>	Number of Cont Tracks	21636	5484	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02940</a>	Cont Track Choice	21635	5483	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02941</a>	Cont Type	21634	5482	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02942</a>	Number of Cont Data Points	21633	5481	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02943</a>	Cont Data Point Choice	21632	5480	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02944</a>	Cont Pos X0	21631	547F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02945</a>	Cont Pos X1	21630	547E	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02946</a>	Cont Time	21629	547D	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02959</a>	Number of Position Tracks	21616	5470	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02960</a>	Pos Track Choice	21615	546F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02962</a>	Number of Pos Data Points	21613	546D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02963</a>	Pos Data Point Choice	21612	546C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02964</a>	Change Pos Data Point X	21611	546B	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02965</a>	Change Pos Data Point Y	21610	546A	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

## 15 Index

### Symbols

"CAN on board" system bus [292](#)

"Online" tab [564](#)

### Figures

100 % (error message) [653](#)

3 s (error message) [680](#)

4 mA (error message) [667](#)

60 s (error message) [681](#)

### A

Absolute value encoder

Communication error (error message) [658](#)

Accel./decel. time - grinding (C02597) [837](#)

Acceleration has been limited (error message) [695](#)

Acceleration reduction [383](#)

Acceleration time (C02774) [864](#)

Acceleration time feedf. control (C02600) [838](#)

Acceleration unit (C02538) [827](#)

Access protection [566](#)

Action after detect Home position (C02641) [847](#)

Activate DriveInTarget Modulo (C02673) [851](#)

Activate encoder (C02760) [861](#)

Activate Lss sat. char. (C02859) [872](#)

Activate resolver error compensation (C00418) [772](#)

Active application (C00007) [725](#)

Active function state (C02530) [826](#)

Active Product (C02909) [875](#)

Actual position (enc. eval.) (C02575) [834](#)

Actual position (homing) (C02656) [850](#)

Actual speed (enc. eval.) (C02574) [834](#)

Actual speed [%] (C00693) [794](#)

Actual speed [rpm] (C00051) [727](#)

Actual speed filter [158](#), [185](#)

Actual speed value outside the tolerance (C00576) (error message) [657](#)

Actual torque [%] (C00698) [794](#)

Actual value detection [158](#)

Adaptation of Ur (C02865) [873](#)

Analog input 1

Master current &lt [667](#)

Analog input x

Input signal (C02800) [866](#)

Analog inputs [274](#)

Dead band (C02732) [861](#)

Gain (C02730) [860](#)

Offset (C02731) [860](#)

Analog output x

Output signal (C02801) [867](#)

Analog outputs [277](#)

Gain (C02733) [861](#)

Offset (C02734) [861](#)

Angular drift monitoring (encoder) [263](#)

Application

Compiler date (C00213) [746](#)

ID number (C00218) [747](#)

Type code (C00212) [746](#)

Version (C00211) [746](#)

Application and device are incompatible (error message) [674](#)

Application has started (error message) [648](#)

Application is stopped (error message) [647](#), [648](#)

Application notes [21](#)

Application selection (C00005) [725](#)

Application unit [40](#)

ApplicationTask

Overflow (error message) [646](#)

Async. motor

Stall protection (C01198) [816](#)

Asynchronous machine in the field weakening range [165](#)

Attribute table [881](#)

Auto Inc Cam Data Points [576](#)

Auto Inc Cam Data Points (C02927) [877](#)

Auto increment CAM grid points [576](#)

Autom. ENP data transfer (C00202) [744](#)

Autom. restart after mains ON (C00142) [736](#)

Automatic restart [112](#)

Automatic switching frequency reduction [115](#)

### B

Band-stop filter [159](#)

Basic drive functions [375](#)

Basic function "Limiter" [368](#)

Basic functions [375](#)

Behaviour after task overflow [114](#), [290](#)

Behaviour due to change of parameter set (C00227) [747](#)

Behaviour of the outputs after a system event [290](#)

Block function in wrong MEC task (error message) [681](#)

Brake chopper [265](#), [268](#)

I<sub>xt</sub> &gt [665](#)

Brake chopper monitoring [268](#)

Brake chopper utilisation [268](#)

Brake closing time (C02589) [836](#)

Brake control [528](#)

Dig. signals (C02609) [839](#)

Brake control polarity (C02585) [836](#)

Brake opening time (C02590) [836](#)

Brake resistor [269](#)

I<sub>xt</sub> overload (error message) [659](#)

I<sub>2t</sub> &gt [665](#)

Brake resistor monitoring [269](#)

Brake resistor utilisation [269](#)

Brake resistor utilisation (C00138) [736](#)

Brake resistor value (C00129) <a href="#">735</a>	C1196 <a href="#">816</a>
Brake resp. to pulse inhibit (C02582) <a href="#">835</a>	C1198 <a href="#">816</a>
Brake transistor <a href="#">265</a>	C1199 <a href="#">816</a>
Ixt overload (error message) <a href="#">659</a>	C120 <a href="#">734</a>
Overcurrent (error message) <a href="#">660</a>	C1200 <a href="#">817</a>
Brake transistor utilisation (C00137) <a href="#">736</a>	C1201 <a href="#">817</a>
Braking operation <a href="#">265</a>	C1203 <a href="#">817</a>
Breakpoint reached (error message) <a href="#">647</a>	C1204 <a href="#">817</a>
BRK_dnState (C02607) <a href="#">839</a>	C1205 <a href="#">817</a>
BRK_dnTorqueAdd_n (C02608) <a href="#">839</a>	C1206 <a href="#">818</a>
	C1208 <a href="#">818</a>
	C1209 <a href="#">818</a>
	C121 <a href="#">734</a>
	C1210 <a href="#">818</a>
	C1211 <a href="#">818</a>
	C1212 <a href="#">818</a>
	C1213 <a href="#">818</a>
	C1214 <a href="#">819</a>
	C1215 <a href="#">819</a>
	C1217 <a href="#">819</a>
	C1218 <a href="#">819</a>
	C122 <a href="#">734</a>
	C1220 <a href="#">820</a>
	C1221 <a href="#">820</a>
	C1222 <a href="#">820</a>
	C1223 <a href="#">820</a>
	C123 <a href="#">734</a>
	C1230 <a href="#">820</a>
	C126 <a href="#">735</a>
	C127 <a href="#">735</a>
	C128 <a href="#">735</a>
	C129 <a href="#">735</a>
	C130 <a href="#">735</a>
	C131 <a href="#">735</a>
	C132 <a href="#">736</a>
	C133 <a href="#">736</a>
	C134 <a href="#">736</a>
	C137 <a href="#">736</a>
	C138 <a href="#">736</a>
	C142 <a href="#">736</a>
	C150 <a href="#">737</a>
	C1501 <a href="#">820</a>
	C1502 <a href="#">821</a>
	C1510 <a href="#">821</a>
	C1511 <a href="#">821</a>
	C155 <a href="#">738</a>
	C156 <a href="#">738</a>
	C158 <a href="#">739</a>
	C159 <a href="#">739</a>
	C162 <a href="#">740</a>
	C166 <a href="#">740</a>
	C167 <a href="#">740</a>
	C168 <a href="#">740</a>
<b>C</b>	
C00120 (error message) <a href="#">653</a>	
C00121 (C00584) <a href="#">782</a>	
C00121 (error message) <a href="#">651</a>	
C00122 (C00582) <a href="#">782</a>	
C00122 (error message) <a href="#">650</a>	
C00123 (C00604) <a href="#">786</a>	
C00123 (error message) <a href="#">653</a>	
C00126 (C00589) <a href="#">784</a>	
C00126 (error message) <a href="#">651</a>	
C00127 (C00606) <a href="#">787</a>	
C00127 (error message) <a href="#">653</a>	
C00570 (C00569) <a href="#">779</a>	
C00570 (error message) <a href="#">665</a>	
C00572 (C00571) <a href="#">779</a>	
C00572 (error message) <a href="#">665</a>	
C00596 (error message) <a href="#">660</a>	
C00620 (C00619) <a href="#">789</a>	
C00620 (error message) <a href="#">659</a>	
C100 <a href="#">733</a>	
C105 <a href="#">733</a>	
C106 <a href="#">733</a>	
C107 <a href="#">733</a>	
C11 <a href="#">726</a>	
C1120 <a href="#">812</a>	
C1121 <a href="#">812</a>	
C1122 <a href="#">812</a>	
C1123 <a href="#">813</a>	
C1124 <a href="#">813</a>	
C1125 <a href="#">814</a>	
C1126 <a href="#">814</a>	
C1127 <a href="#">814</a>	
C1128 <a href="#">814</a>	
C1129 <a href="#">814</a>	
C1130 <a href="#">814</a>	
C114 <a href="#">733</a>	
C118 <a href="#">734</a>	
C1190 <a href="#">814</a>	
C1191 <a href="#">815</a>	
C1192 <a href="#">815</a>	
C1193 <a href="#">815</a>	
C1194 <a href="#">815</a>	
C1195 <a href="#">816</a>	

C169	<a href="#">740</a>	C2520	<a href="#">824</a>
C171	<a href="#">741</a>	C2521	<a href="#">824</a>
C173	<a href="#">741</a>	C2522	<a href="#">824</a>
C174	<a href="#">742</a>	C2523	<a href="#">824</a>
C175	<a href="#">742</a>	C2524	<a href="#">824</a>
C176	<a href="#">742</a>	C2525	<a href="#">825</a>
C177	<a href="#">742</a>	C2526	<a href="#">825</a>
C178	<a href="#">742</a>	C2527	<a href="#">825</a>
C179	<a href="#">742</a>	C2528	<a href="#">825</a>
C18	<a href="#">726</a>	C2529	<a href="#">825</a>
C180	<a href="#">742</a>	C2530	<a href="#">826</a>
C181	<a href="#">743</a>	C2531	<a href="#">826</a>
C183	<a href="#">743</a>	C2532	<a href="#">826</a>
C185	<a href="#">743</a>	C2533	<a href="#">827</a>
C186	<a href="#">743</a>	C2534	<a href="#">827</a>
C187	<a href="#">743</a>	C2535	<a href="#">827</a>
C188	<a href="#">744</a>	C2536	<a href="#">827</a>
C19	<a href="#">726</a>	C2537	<a href="#">827</a>
C1902	<a href="#">822</a>	C2538	<a href="#">827</a>
C1903	<a href="#">822</a>	C2539	<a href="#">827</a>
C1905	<a href="#">822</a>	C254	<a href="#">748</a>
C198	<a href="#">744</a>	C2540	<a href="#">828</a>
C199	<a href="#">744</a>	C2541	<a href="#">828</a>
C2	<a href="#">712</a>	C2542	<a href="#">828</a>
C200	<a href="#">744</a>	C2543	<a href="#">828</a>
C201	<a href="#">744</a>	C2544	<a href="#">828</a>
C202	<a href="#">744</a>	C2545	<a href="#">828</a>
C203	<a href="#">744</a>	C2547	<a href="#">829</a>
C204	<a href="#">745</a>	C2548	<a href="#">829</a>
C205	<a href="#">745</a>	C2549	<a href="#">829</a>
C206	<a href="#">745</a>	C2550	<a href="#">830</a>
C208	<a href="#">746</a>	C2552	<a href="#">830</a>
C209	<a href="#">746</a>	C2553	<a href="#">830</a>
C210	<a href="#">746</a>	C2554	<a href="#">830</a>
C2104	<a href="#">822</a>	C2555	<a href="#">830</a>
C2108	<a href="#">822</a>	C2556	<a href="#">830</a>
C2109	<a href="#">823</a>	C2557	<a href="#">831</a>
C211	<a href="#">746</a>	C2558	<a href="#">831</a>
C2110	<a href="#">823</a>	C2559	<a href="#">831</a>
C2111	<a href="#">823</a>	C2560	<a href="#">831</a>
C2113	<a href="#">823</a>	C2561	<a href="#">831</a>
C212	<a href="#">746</a>	C2562	<a href="#">832</a>
C2121	<a href="#">823</a>	C2567	<a href="#">832</a>
C2122	<a href="#">823</a>	C2568	<a href="#">832</a>
C2123	<a href="#">824</a>	C2569	<a href="#">833</a>
C213	<a href="#">746</a>	C2570	<a href="#">833</a>
C214	<a href="#">747</a>	C2571	<a href="#">833</a>
C217	<a href="#">747</a>	C2572	<a href="#">833</a>
C218	<a href="#">747</a>	C2573	<a href="#">834</a>
C219	<a href="#">747</a>	C2574	<a href="#">834</a>
C22	<a href="#">726</a>	C2575	<a href="#">834</a>
C225	<a href="#">747</a>	C2576	<a href="#">834</a>
C227	<a href="#">747</a>	C2577	<a href="#">834</a>



C2578	<a href="#">834</a>	C2648	<a href="#">849</a>
C2579	<a href="#">835</a>	C2649	<a href="#">849</a>
C2580	<a href="#">835</a>	C2650	<a href="#">849</a>
C2581	<a href="#">835</a>	C2651	<a href="#">849</a>
C2582	<a href="#">835</a>	C2652	<a href="#">849</a>
C2583	<a href="#">835</a>	C2653	<a href="#">849</a>
C2585	<a href="#">836</a>	C2655	<a href="#">850</a>
C2586	<a href="#">836</a>	C2656	<a href="#">850</a>
C2587	<a href="#">836</a>	C2657	<a href="#">850</a>
C2588	<a href="#">836</a>	C2658	<a href="#">850</a>
C2589	<a href="#">836</a>	C2659	<a href="#">850</a>
C2590	<a href="#">836</a>	C2670	<a href="#">851</a>
C2591	<a href="#">837</a>	C2671	<a href="#">851</a>
C2593	<a href="#">837</a>	C2672	<a href="#">851</a>
C2594	<a href="#">837</a>	C2673	<a href="#">851</a>
C2595	<a href="#">837</a>	C2674	<a href="#">851</a>
C2596	<a href="#">837</a>	C2675	<a href="#">852</a>
C2597	<a href="#">837</a>	C2676	<a href="#">852</a>
C2598	<a href="#">838</a>	C2677	<a href="#">852</a>
C2599	<a href="#">838</a>	C2678	<a href="#">852</a>
C2600	<a href="#">838</a>	C2679	<a href="#">853</a>
C2601	<a href="#">838</a>	C2680	<a href="#">853</a>
C2602	<a href="#">838</a>	C2681	<a href="#">853</a>
C2603	<a href="#">838</a>	C2685	<a href="#">853</a>
C2604	<a href="#">839</a>	C2686	<a href="#">854</a>
C2607	<a href="#">839</a>	C2687	<a href="#">854</a>
C2608	<a href="#">839</a>	C2688	<a href="#">854</a>
C2609	<a href="#">839</a>	C2689	<a href="#">854</a>
C2610	<a href="#">839</a>	C2692	<a href="#">854</a>
C2611	<a href="#">840</a>	C2693	<a href="#">855</a>
C2612	<a href="#">840</a>	C2694	<a href="#">855</a>
C2616	<a href="#">840</a>	C2695	<a href="#">855</a>
C2617	<a href="#">840</a>	C2698	<a href="#">855</a>
C2619	<a href="#">840</a>	C2699	<a href="#">856</a>
C2620	<a href="#">841</a>	C270	<a href="#">748</a>
C2621	<a href="#">841</a>	C2700	<a href="#">856</a>
C2622	<a href="#">841</a>	C2701	<a href="#">856</a>
C2623	<a href="#">841</a>	C2702	<a href="#">856</a>
C2624	<a href="#">841</a>	C2703	<a href="#">856</a>
C2625	<a href="#">841</a>	C2704	<a href="#">857</a>
C2626	<a href="#">842</a>	C2705	<a href="#">857</a>
C2627	<a href="#">842</a>	C2706	<a href="#">857</a>
C2637	<a href="#">842</a>	C2707	<a href="#">857</a>
C2638	<a href="#">842</a>	C2708	<a href="#">857</a>
C2639	<a href="#">843</a>	C2709	<a href="#">858</a>
C2640	<a href="#">846</a>	C271	<a href="#">748</a>
C2641	<a href="#">847</a>	C2710	<a href="#">858</a>
C2642	<a href="#">848</a>	C2711	<a href="#">858</a>
C2643	<a href="#">848</a>	C2712	<a href="#">858</a>
C2644	<a href="#">848</a>	C2713	<a href="#">859</a>
C2645	<a href="#">848</a>	C2714	<a href="#">859</a>
C2646	<a href="#">848</a>	C2715	<a href="#">859</a>
C2647	<a href="#">848</a>	C2716	<a href="#">859</a>

C2717	<a href="#">859</a>	C2860	<a href="#">872</a>
C2718	<a href="#">860</a>	C2861	<a href="#">872</a>
C2719	<a href="#">860</a>	C2862	<a href="#">873</a>
C272	<a href="#">748</a>	C2863	<a href="#">873</a>
C2720	<a href="#">860</a>	C2864	<a href="#">873</a>
C273	<a href="#">748</a>	C2865	<a href="#">873</a>
C2730	<a href="#">860</a>	C2866	<a href="#">873</a>
C2731	<a href="#">860</a>	C2900	<a href="#">873</a>
C2732	<a href="#">861</a>	C2901	<a href="#">874</a>
C2733	<a href="#">861</a>	C2902	<a href="#">874</a>
C2734	<a href="#">861</a>	C2903	<a href="#">874</a>
C274	<a href="#">749</a>	C2905	<a href="#">875</a>
C275	<a href="#">749</a>	C2906	<a href="#">875</a>
C276	<a href="#">749</a>	C2908	<a href="#">875</a>
C2760	<a href="#">861</a>	C2909	<a href="#">875</a>
C2761	<a href="#">861</a>	C2910	<a href="#">875</a>
C2762	<a href="#">862</a>	C2911	<a href="#">876</a>
C2763	<a href="#">862</a>	C2912	<a href="#">876</a>
C2764	<a href="#">862</a>	C2919	<a href="#">876</a>
C2765	<a href="#">862</a>	C2920	<a href="#">876</a>
C2770	<a href="#">862</a>	C2921	<a href="#">876</a>
C2771	<a href="#">863</a>	C2922	<a href="#">877</a>
C2772	<a href="#">863</a>	C2923	<a href="#">877</a>
C2773	<a href="#">863</a>	C2924	<a href="#">877</a>
C2774	<a href="#">864</a>	C2925	<a href="#">877</a>
C2775	<a href="#">864</a>	C2926	<a href="#">877</a>
C2776	<a href="#">864</a>	C2927	<a href="#">877</a>
C2779	<a href="#">864</a>	C2939	<a href="#">878</a>
C2780	<a href="#">865</a>	C2940	<a href="#">878</a>
C2781	<a href="#">865</a>	C2941	<a href="#">878</a>
C2785	<a href="#">865</a>	C2942	<a href="#">878</a>
C2786	<a href="#">865</a>	C2943	<a href="#">878</a>
C2787	<a href="#">866</a>	C2944	<a href="#">879</a>
C2788	<a href="#">866</a>	C2945	<a href="#">879</a>
C2789	<a href="#">866</a>	C2946	<a href="#">879</a>
C280	<a href="#">749</a>	C2959	<a href="#">879</a>
C2800	<a href="#">866</a>	C2960	<a href="#">879</a>
C2801	<a href="#">867</a>	C2962	<a href="#">879</a>
C2802	<a href="#">868</a>	C2963	<a href="#">880</a>
C2803	<a href="#">869</a>	C2964	<a href="#">880</a>
C281	<a href="#">750</a>	C2965	<a href="#">880</a>
C2810	<a href="#">870</a>	C2996	<a href="#">880</a>
C2830	<a href="#">870</a>	C2997	<a href="#">880</a>
C2850	<a href="#">871</a>	C2998	<a href="#">880</a>
C2851	<a href="#">871</a>	C2999	<a href="#">880</a>
C2852	<a href="#">871</a>	C3	<a href="#">716</a>
C2853	<a href="#">871</a>	C308	<a href="#">750</a>
C2854	<a href="#">871</a>	C309	<a href="#">750</a>
C2855	<a href="#">872</a>	C310	<a href="#">750</a>
C2856	<a href="#">872</a>	C311	<a href="#">750</a>
C2857	<a href="#">872</a>	C312	<a href="#">751</a>
C2858	<a href="#">872</a>	C313	<a href="#">751</a>
C2859	<a href="#">872</a>	C314	<a href="#">752</a>

C320	<a href="#">752</a>	C394	<a href="#">770</a>
C321	<a href="#">753</a>	C395	<a href="#">770</a>
C322	<a href="#">753</a>	C396	<a href="#">771</a>
C323	<a href="#">754</a>	C397	<a href="#">771</a>
C324	<a href="#">754</a>	C398	<a href="#">771</a>
C325	<a href="#">754</a>	C399	<a href="#">771</a>
C326	<a href="#">754</a>	C4	<a href="#">725</a>
C327	<a href="#">754</a>	C413	<a href="#">771</a>
C328	<a href="#">754</a>	C414	<a href="#">772</a>
C329	<a href="#">755</a>	C415	<a href="#">772</a>
C330	<a href="#">755</a>	C416	<a href="#">772</a>
C335	<a href="#">755</a>	C417	<a href="#">772</a>
C336	<a href="#">755</a>	C418	<a href="#">772</a>
C337	<a href="#">755</a>	C420	<a href="#">773</a>
C338	<a href="#">755</a>	C421	<a href="#">773</a>
C34	<a href="#">726</a>	C422	<a href="#">773</a>
C343	<a href="#">755</a>	C423	<a href="#">773</a>
C344	<a href="#">755</a>	C424	<a href="#">773</a>
C345	<a href="#">756</a>	C427	<a href="#">773</a>
C346	<a href="#">756</a>	C435	<a href="#">774</a>
C347	<a href="#">756</a>	C436	<a href="#">774</a>
C348	<a href="#">756</a>	C437	<a href="#">775</a>
C349	<a href="#">757</a>	C443	<a href="#">775</a>
C350	<a href="#">757</a>	C444	<a href="#">776</a>
C351	<a href="#">758</a>	C464	<a href="#">776</a>
C352	<a href="#">758</a>	C465	<a href="#">776</a>
C356	<a href="#">758</a>	C466	<a href="#">777</a>
C357	<a href="#">759</a>	C467	<a href="#">777</a>
C359	<a href="#">759</a>	C468	<a href="#">777</a>
C360	<a href="#">760</a>	C469	<a href="#">777</a>
C361	<a href="#">760</a>	C490	<a href="#">777</a>
C367	<a href="#">761</a>	C494	<a href="#">777</a>
C368	<a href="#">761</a>	C495	<a href="#">778</a>
C369	<a href="#">761</a>	C497	<a href="#">778</a>
C372	<a href="#">762</a>	C5	<a href="#">725</a>
C373	<a href="#">763</a>	C50	<a href="#">727</a>
C374	<a href="#">764</a>	C51	<a href="#">727</a>
C375	<a href="#">764</a>	C512	<a href="#">778</a>
C376	<a href="#">765</a>	C513	<a href="#">778</a>
C377	<a href="#">765</a>	C514	<a href="#">778</a>
C378	<a href="#">765</a>	C515	<a href="#">778</a>
C379	<a href="#">765</a>	C516	<a href="#">778</a>
C381	<a href="#">766</a>	C52	<a href="#">727</a>
C382	<a href="#">766</a>	C53	<a href="#">727</a>
C383	<a href="#">766</a>	C54	<a href="#">727</a>
C385	<a href="#">767</a>	C55	<a href="#">727</a>
C386	<a href="#">767</a>	C56	<a href="#">728</a>
C387	<a href="#">768</a>	C569	<a href="#">779</a>
C388	<a href="#">768</a>	C57	<a href="#">728</a>
C390	<a href="#">768</a>	C570	<a href="#">779</a>
C391	<a href="#">769</a>	C571	<a href="#">779</a>
C392	<a href="#">770</a>	C572	<a href="#">779</a>
C393	<a href="#">770</a>	C573	<a href="#">780</a>

C574	<a href="#">780</a>	C644	<a href="#">792</a>
C576	<a href="#">780</a>	C645	<a href="#">792</a>
C577	<a href="#">780</a>	C646	<a href="#">792</a>
C578	<a href="#">780</a>	C647	<a href="#">793</a>
C579	<a href="#">781</a>	C648	<a href="#">793</a>
C58	<a href="#">728</a>	C649	<a href="#">793</a>
C580	<a href="#">781</a>	C65	<a href="#">729</a>
C581	<a href="#">781</a>	C650	<a href="#">793</a>
C582	<a href="#">782</a>	C651	<a href="#">793</a>
C583	<a href="#">782</a>	C66	<a href="#">729</a>
C584	<a href="#">782</a>	C68	<a href="#">729</a>
C585	<a href="#">782</a>	C69	<a href="#">729</a>
C586	<a href="#">783</a>	C691	<a href="#">793</a>
C587	<a href="#">783</a>	C692	<a href="#">794</a>
C588	<a href="#">783</a>	C693	<a href="#">794</a>
C589	<a href="#">784</a>	C694	<a href="#">794</a>
C59	<a href="#">728</a>	C695	<a href="#">794</a>
C591	<a href="#">784</a>	C696	<a href="#">794</a>
C594	<a href="#">784</a>	C697	<a href="#">794</a>
C595	<a href="#">785</a>	C698	<a href="#">794</a>
C596	<a href="#">785</a>	C7	<a href="#">725</a>
C597	<a href="#">785</a>	C70	<a href="#">730</a>
C598	<a href="#">785</a>	C71	<a href="#">730</a>
C599	<a href="#">786</a>	C72	<a href="#">730</a>
C6	<a href="#">725</a>	C730	<a href="#">794</a>
C60	<a href="#">728</a>	C731	<a href="#">795</a>
C600	<a href="#">786</a>	C732	<a href="#">795</a>
C601	<a href="#">786</a>	C733	<a href="#">795</a>
C604	<a href="#">786</a>	C734	<a href="#">795</a>
C606	<a href="#">787</a>	C735	<a href="#">795</a>
C607	<a href="#">787</a>	C736	<a href="#">795</a>
C61	<a href="#">728</a>	C737	<a href="#">795</a>
C610	<a href="#">787</a>	C738	<a href="#">795</a>
C611	<a href="#">787</a>	C739	<a href="#">795</a>
C612	<a href="#">788</a>	C74	<a href="#">730</a>
C613	<a href="#">788</a>	C75	<a href="#">730</a>
C614	<a href="#">789</a>	C76	<a href="#">730</a>
C615	<a href="#">789</a>	C77	<a href="#">730</a>
C618	<a href="#">789</a>	C770	<a href="#">795</a>
C619	<a href="#">789</a>	C771	<a href="#">796</a>
C62	<a href="#">729</a>	C772	<a href="#">796</a>
C620	<a href="#">790</a>	C773	<a href="#">796</a>
C621	<a href="#">790</a>	C774	<a href="#">796</a>
C625	<a href="#">790</a>	C775	<a href="#">796</a>
C63	<a href="#">729</a>	C776	<a href="#">796</a>
C635	<a href="#">790</a>	C777	<a href="#">797</a>
C636	<a href="#">791</a>	C778	<a href="#">797</a>
C637	<a href="#">791</a>	C779	<a href="#">797</a>
C64	<a href="#">729</a>	C78	<a href="#">730</a>
C640	<a href="#">791</a>	C780	<a href="#">797</a>
C641	<a href="#">791</a>	C781	<a href="#">797</a>
C642	<a href="#">792</a>	C782	<a href="#">797</a>
C643	<a href="#">792</a>	C783	<a href="#">798</a>

C784	<a href="#">798</a>	C960	<a href="#">806</a>
C786	<a href="#">798</a>	C961	<a href="#">806</a>
C787	<a href="#">798</a>	C962	<a href="#">806</a>
C788	<a href="#">798</a>	C963	<a href="#">806</a>
C789	<a href="#">798</a>	C964	<a href="#">806</a>
C79	<a href="#">731</a>	C965	<a href="#">807</a>
C790	<a href="#">799</a>	C966	<a href="#">807</a>
C791	<a href="#">799</a>	C967	<a href="#">807</a>
C792	<a href="#">799</a>	C968	<a href="#">807</a>
C8	<a href="#">725</a>	C969	<a href="#">807</a>
C80	<a href="#">731</a>	C970	<a href="#">807</a>
C800	<a href="#">799</a>	C971	<a href="#">808</a>
C802	<a href="#">799</a>	C972	<a href="#">808</a>
C803	<a href="#">799</a>	C973	<a href="#">808</a>
C804	<a href="#">800</a>	C974	<a href="#">808</a>
C805	<a href="#">800</a>	C975	<a href="#">808</a>
C806	<a href="#">800</a>	C976	<a href="#">808</a>
C807	<a href="#">800</a>	C977	<a href="#">809</a>
C808	<a href="#">800</a>	C980	<a href="#">809</a>
C809	<a href="#">800</a>	C985	<a href="#">809</a>
C81	<a href="#">731</a>	C986	<a href="#">809</a>
C810	<a href="#">801</a>	C987	<a href="#">809</a>
C811	<a href="#">801</a>	C988	<a href="#">809</a>
C812	<a href="#">801</a>	C989	<a href="#">810</a>
C813	<a href="#">801</a>	C99	<a href="#">732</a>
C814	<a href="#">801</a>	C990	<a href="#">810</a>
C815	<a href="#">801</a>	C991	<a href="#">810</a>
C816	<a href="#">802</a>	C992	<a href="#">810</a>
C817	<a href="#">802</a>	C993	<a href="#">811</a>
C818	<a href="#">802</a>	C994	<a href="#">811</a>
C82	<a href="#">731</a>	C995	<a href="#">811</a>
C83	<a href="#">731</a>	C998	<a href="#">811</a>
C84	<a href="#">731</a>	Cam data	
C85	<a href="#">731</a>	Invalid product number (error message)	<a href="#">704</a>
C854	<a href="#">802</a>	Invalidated due to change of mechanical data (error message)	<a href="#">704</a>
C87	<a href="#">731</a>	Serial number MM does not match (error message)	<a href="#">697</a>
C878	<a href="#">802</a>	Cam data are corrupted (error message)	<a href="#">697</a>
C88	<a href="#">732</a>	Cam data locked due to incorrect password (error message)	<a href="#">697</a>
C89	<a href="#">732</a>	Cam data locked due to incorrect safety key (error message)	<a href="#">698</a>
C90	<a href="#">732</a>	Cam data management	<a href="#">563</a>
C909	<a href="#">803</a>	Cam Data Point Choice (C02923)	<a href="#">877</a>
C91	<a href="#">732</a>	Cam data restored (error message)	<a href="#">697</a>
C92	<a href="#">732</a>	Cam Track Choice (C02920)	<a href="#">876</a>
C93	<a href="#">732</a>	Cam Track Type (C02921)	<a href="#">876</a>
C950	<a href="#">803</a>	CamMemory (C02901)	<a href="#">874</a>
C951	<a href="#">803</a>	CAN baud rate (C00351)	<a href="#">758</a>
C952	<a href="#">804</a>	CAN baud rate setting	<a href="#">297</a>
C953	<a href="#">804</a>	CAN behaviour in case of fault (C00625)	<a href="#">790</a>
C954	<a href="#">805</a>	CAN bus load (C00361)	<a href="#">760</a>
C955	<a href="#">805</a>	CAN delay boot-up - Operational (C00378)	<a href="#">765</a>
C957	<a href="#">805</a>		
C958	<a href="#">805</a>		
C959	<a href="#">806</a>		

- CAN emergency delay time (C00392) [770](#)
- CAN Emergency Object (C00391) [769](#)
- CAN error (C00345) [756](#)
- CAN Error Register (DS301V402) (C00390) [768](#)
- CAN Guard Time (C00382) [766](#)
- CAN heartbeat activity (C00346) [756](#)
- CAN Heartbeat Consumer Time (C00385) [767](#)
- CAN Heartbeat Producer Time (C00381) [766](#)
- CAN heartbeat status (C00347) [756](#)
- CAN Life Time Factor (C00383) [766](#)
- CAN module (MXI1)
  - Basic configuration invalid (error message) [683](#)
  - Bus off (error message) [683](#)
  - Faulty emergency configuration (error message) [684](#)
  - Faulty NMT master configuration (error message) [685](#)
  - Faulty NMT slave configuration (error message) [684](#)
  - Heartbeat error index 1 ... 32 (error message) [683](#)
  - Invalid node address 0 (error message) [683](#)
  - Lifeguarding error (error message) [684](#)
  - Node guarding error 1 ... 32 (error message) [684](#)
- CAN module (MXI1) PDO manager
  - Faulty configuration (error message) [687](#)
- CAN module (MXI1) RPDO1
  - Telegram not received or faulty (error message) [685](#)
- CAN module (MXI1) RPDO2
  - Telegram not received or faulty (error message) [685](#)
- CAN module (MXI1) RPDO3
  - Telegram not received or faulty (error message) [685](#)
- CAN module (MXI1) RPDO4
  - Telegram not received or faulty (error message) [686](#)
- CAN module (MXI1) RPDO5
  - Telegram not received or faulty (error message) [686](#)
- CAN module (MXI1) RPDO6
  - Telegram not received or faulty (error message) [686](#)
- CAN module (MXI1) RPDO7
  - Telegram not received or faulty (error message) [686](#)
- CAN module (MXI1) RPDO8
  - Telegram not received or faulty (error message) [686](#)
- CAN module (MXI1) SDO client
  - Faulty configuration (error message) [687](#)
- CAN module (MXI1) SDO server
  - Faulty configuration (error message) [687](#)
- CAN module (MXI2)
  - Basic configuration invalid (error message) [689](#)
  - Bus off (error message) [688](#)
  - Faulty emergency configuration (error message) [690](#)
  - Faulty NMT master configuration (error message) [690](#)
  - Faulty NMT slave configuration (error message) [690](#)
  - Heartbeat error index 1 ... 32 (error message) [689](#)
  - Invalid node address 0 (error message) [689](#)
  - Lifeguarding error (error message) [689](#)
  - Node guarding error 1 ... 32 (error message) [690](#)
- CAN module (MXI2) PDO manager
  - Faulty configuration (error message) [692](#)
- CAN module (MXI2) RPDO1
  - Telegram not received or faulty (error message) [691](#)
- CAN module (MXI2) RPDO2
  - Telegram not received or faulty (error message) [691](#)
- CAN module (MXI2) RPDO3
  - Telegram not received or faulty (error message) [691](#)
- CAN module (MXI2) RPDO4
  - Telegram not received or faulty (error message) [691](#)
- CAN module (MXI2) RPDO5
  - Telegram not received or faulty (error message) [691](#)
- CAN module (MXI2) RPDO6
  - Telegram not received or faulty (error message) [692](#)
- CAN module (MXI2) RPDO7
  - Telegram not received or faulty (error message) [692](#)
- CAN module (MXI2) RPDO8
  - Telegram not received or faulty (error message) [692](#)
- CAN module (MXI2) SDO client
  - Faulty configuration (error message) [693](#)
- CAN module (MXI2) SDO server
  - Faulty configuration (error message) [693](#)
- CAN node address (C00350) [757](#)
- CAN node address setting [296](#)
- CAN Node Guarding (C00386) [767](#)
- CAN Node Guarding Activity (C00387) [768](#)
- CAN node guarding status (C00388) [768](#)
- CAN on board [292](#)
  - Basic configuration invalid (error message) [669](#)
  - Bus off (error message) [668](#)
  - Faulty emergency configuration (error message) [670](#)
  - Faulty NMT master configuration (error message) [670](#)
  - Faulty NMT slave configuration (error message) [670](#)
  - Heartbeat error index 1 ... 32 (error message) [669](#)
  - Invalid node address 0 (error message) [669](#)
  - Lifeguarding guarding error (error message) [669](#)
  - Node guarding error 1 ... 32 (error message) [670](#)
- CAN on board PDO manager
  - Faulty configuration (error message) [671](#)
- CAN on board RPDO1
  - Telegram not received or faulty (error message) [671](#)
- CAN on board RPDO2
  - Telegram not received or faulty (error message) [671](#)
- CAN on board RPDO3
  - Telegram not received or faulty (error message) [671](#)
- CAN on board RPDO4
  - Telegram not received or faulty (error message) [671](#)
- CAN on board SDO client
  - Faulty configuration (error message) [672](#)
- CAN on board SDO server
  - Faulty configuration (error message) [672](#)
- CAN predefined error field (DS301V402) (C00394) [770](#)
- CAN result - bus scan (C00393) [770](#)
- CAN RPDO counter (C00344) [755](#)

- CAN RPDOx identifier (C00321) [753](#)
- CAN RPDOx monitoring time (C00357) [759](#)
- CAN RPDOx Rx mode (C00323) [754](#)
- CAN SDO client node address (C00374) [764](#)
- CAN SDO client Rx identifier (C00375) [764](#)
- CAN SDO client Tx identifier (C00376) [765](#)
- CAN SDO server node address (C00377) [765](#)
- CAN SDO server Rx identifier (C00372) [762](#)
- CAN SDO server Tx identifier (C00373) [763](#)
- CAN setting of DIP switch (C00349) [757](#)
- CAN slave/master (C00352) [758](#)
- CAN status (C00359) [759](#)
- CAN status DIP switch (C00348) [756](#)
- CAN SYNC application cycle (C01130) [814](#)
- CAN SYNC Rx identifier (C00367) [761](#)
- CAN SYNC transmit cycle time (C00369) [761](#)
- CAN SYNC Tx identifier (C00368) [761](#)
- CAN telegram and error counter (C00360) [760](#)
- CAN TPDO counter (C00343) [755](#)
- CAN TPDO1 mask byte x (C00311) [750](#)
- CAN TPDO2 mask byte x (C00312) [751](#)
- CAN TPDO3 mask byte x (C00313) [751](#)
- CAN TPDO4 mask byte x (C00314) [752](#)
- CAN TPDOx cycle time (C00356) [758](#)
- CAN TPDOx delay time (C00324) [754](#)
- CAN TPDOx identifier (C00320) [752](#)
- CAN TPDOx Tx mode (C00322) [753](#)
- CAN/EPL device type (C219) [747](#)
- Capacitor temperature (C00068) [729](#)
- Change Cam Data Point M (C02926) [877](#)
- Change Cam Data Point X (C02924) [877](#)
- Change Cam Data Point Y (C02925) [877](#)
- Change of the basic function [383](#)
- Change Pos Data Point X (C02964) [880](#)
- Change Pos Data Point Y (C02965) [880](#)
- Changing cam data via parameterisation [575](#)
- Check configuration (C225) [747](#)
- Chopper frequency (C00018) [726](#)
- Clock [819](#)
- COB-ID [299](#)
- COB-ID EMCY (I-1014) [348](#)
- COB-ID SYNC message (I-1005) [344](#)
- Code number duplicated (error message) [678](#)
- Code refresh (error message) [643](#)
- Combination memory module/device not possible (error message) [642](#)
- Combination MXI1/MXI2 not possible (error message) [641](#)
- Combination of module in MXI1/device not possible (error message) [642](#)
- Combination of module in MXI2/device not possible (error message) [642](#)
- Communication cycle period (I-1006) [345](#)
- Communication error between device and device module (error message) [668](#)
- Communication task
  - Standstill &gt; [680](#)
- Communication with module in MXI1 interrupted (error message) [668](#)
- Communication with module in MXI2 interrupted (error message) [668](#)
- Communication with safety module interrupted (error message) [681](#)
- Config. analog input 1 (C00034) [726](#)
- Configure exception handling [290](#)
- ConnectTable active (error message) [676](#)
- Consumer heartbeat time (I-1016) [349](#)
- Cont Data Point Choice (C02943) [878](#)
- Cont Pos X0 (C02944) [879](#)
- Cont Pos X1 (C02945) [879](#)
- Cont Time (C02946) [879](#)
- Cont Track Choice (C02940) [878](#)
- Cont Type (C02941) [878](#)
- Control card
  - Supply voltage (24 V DC) too low (error message) [649](#)
- Control card is defect (error message) [637](#), [638](#)
- Control card is defect (UB18 neg.) (error message) [654](#)
- Control card is defect (UB24) (error message) [654](#)
- Control card is defect (UB8) (error message) [654](#)
- Control card is defect (VCC15 neg.) (error message) [654](#)
- Control card is defect (VCC15) (error message) [654](#)
- Control card is defect (VCC5) (error message) [654](#)
- Control card is incompatible (error message) [639](#)
- Control mode (C02567) [832](#)
- Control of two motor brakes [562](#)
- Controlled operation (without feedback) [410](#)
- Controller
  - Clamp operation (error message) [666](#)
  - Overload during acceleration phases (error message) [663](#)
  - Pulse inhibit is active (error message) [650](#)
- Controller enabled (error message) [649](#)
- Controller in STO state (error message) [650](#)
- Controller inhibit by (source) (C00158) [739](#)
- Correction of the leakage inductance [210](#)
- Counter
  - Brake chopper overload (C01203) [817](#)
  - DC bus overvoltage (C01205) [817](#)
  - Heatsink overtemp. (C01208) [818](#)
  - Housing overtemp. (C01209) [818](#)
  - Internal (C01210) [818](#)
  - Ixt overload (C01204) [817](#)
  - Mains switching (C01206) [818](#)
  - Power section overload (C01212) [818](#)
- CPU
  - Overtemperature (error message) [651](#)
  - Temperature &gt; [651](#)
  - Thermal detector is defect (error message) [652](#)

CPU temp. warning threshold (C00126) [735](#)  
CPU temperature (C00069) [729](#)  
Curr. control par. of C75 C76 (C2866) [873](#)  
Current (C02773) [863](#)  
Current contr. reset time (C00076) [730](#)  
Current controller gain (C00075) [730](#)  
Current setpoint filter [159](#)  
Cycle (C02536) [827](#)  
Cyclic task  
Standstill &gt; [681](#)

## D

D component position controller (C02555) [830](#)  
Data type [706](#)  
Date [819](#)  
DC brake  
Activat. by quick stop (C00976) [808](#)  
Current (C00974) [808](#)  
Current for quick stop (C00975) [808](#)  
DC bus overvoltage (error message) [657](#)  
DC bus undervoltage (error message) [657](#)  
DC-bus capacitor  
Thermal detector is defect (error message) [652](#)  
DC-bus voltage (C00053) [727](#)  
DC-injection braking [221](#), [395](#)  
Decel. time lim. speed (C02712) [858](#)  
Deceleration has been limited (error message) [696](#)  
Deceleration time (C02775) [864](#)  
Deceleration time for stop (C02610) [839](#)  
Delay lim. speed (C02710) [858](#)  
Delay time for fan start (C01201) [817](#)  
Depth - current setp. filter (C00272) [748](#)  
Device command status (C00003) [716](#)  
Device command transferred incorrectly (error message) [655](#)  
Device commands (C00002) [712](#)  
Device commands, commands  
See device commands, C2 (device command), C3 (device command status) [49](#)  
Device name (C00199) [744](#)  
Device state (C00183) [743](#)  
Device states [105](#)  
Device type (I-1000) [342](#)  
Device utilisation (Ixt) (C00064) [729](#)  
Device utilisation Ixt &gt; [653](#)  
DFIN (MXI1)  
Signal error enable/lamp control (error message) [682](#)  
Supply cannot be corrected anymore (error message) [682](#)  
Track error A-/A (error message) [682](#)  
Track error B-/B (error message) [682](#)  
Track error Z-/Z (error message) [682](#)  
DFIN (MXI2)

Signal error enable/lamp control (error message) [688](#)  
Supply cannot be corrected anymore (error message) [688](#)  
Track error A-/A (error message) [687](#)  
Track error B-/B (error message) [687](#)  
Track error Z-/Z (error message) [688](#)  
DFOUT (MXI1)  
Maximum frequency reached (error message) [682](#)  
DFOUT (MXI2)  
Maximum frequency reached (error message) [688](#)  
DI\_bErrors (C02548) [829](#)  
DI\_dnState (C02547) [829](#)  
Diagnostics X6  
Change baud rate (C01903) [822](#)  
Curr. baud rate (C01905) [822](#)  
Max. baud rate (C01902) [822](#)  
Dig. input x  
Terminal polarity (C00114) [733](#)  
Dig. output x  
Terminal polarity (C00118) [734](#)  
Digital inputs [279](#)  
Delay time (C02830) [870](#)  
Digital outputs [281](#)  
DIP switches of the memory module [296](#)  
Disconnection in the case of par. storage (error message) [678](#)  
Distribution cam data memory [565](#)  
Division by zero (error message) [647](#)  
Double motor [232](#), [562](#)  
Drive interface [35](#)  
Signals (C02549) [829](#)  
Drive-based safety [367](#)  
DRIVE-ERROR LED [106](#), [612](#)  
DRIVE-READY LED [106](#), [612](#)  
Dual motor temperature (C01200) [817](#)  
Dynamic of resolver evaluation (C00417) [772](#)  
Dynamics of the actual value detection [158](#)

## E

Earth fault detected (error message) [657](#)  
Elapsed hour meter (C00178) [742](#)  
Electronic cam [563](#)  
Electronic nameplate  
Checksum error (error message) [642](#)  
Communication error (error message) [641](#)  
Data are incompatible (error message) [654](#)  
Data loaded (error message) [662](#)  
Data outside the parameter limits (error message) [663](#)  
Encoder protocol unknown (error message) [662](#)  
Encoder signal unknown (error message) [662](#)  
Not found (error message) [662](#)  
Electronic nameplate status (C2858) [872](#)  
E-mail to Lenze [919](#)  
Emergency telegram [339](#)



EN 60204-1	<a href="#">367</a>	0x0068000a	<a href="#">639</a>
EN 954	<a href="#">367</a>	0x0068000b	<a href="#">639</a>
ENC_bError (C02765)	<a href="#">862</a>	0x0068000c	<a href="#">639</a>
Encoder		0x0068000d	<a href="#">639</a>
Open circuit (error message)	<a href="#">659</a>	0x0068000e	<a href="#">639</a>
Time-out error (error message)	<a href="#">666</a>	0x0068000f	<a href="#">639</a>
Encoder - number of increments (C00420)	<a href="#">773</a>	0x00680010	<a href="#">640</a>
Encoder angular drift monitoring	<a href="#">263</a>	0x00680011	<a href="#">640</a>
Encoder evaluation	<a href="#">241</a>	0x00680012	<a href="#">640</a>
Dig. signals (C02579)	<a href="#">835</a>	0x00680013	<a href="#">640</a>
Encoder monitoring		0x00680014	<a href="#">640</a>
Pulse deviation detected (error message)	<a href="#">665</a>	0x00680015	<a href="#">640</a>
Encoder revolution (C02763)	<a href="#">862</a>	0x00680016	<a href="#">641</a>
Encoder signal X8	<a href="#">258</a>	0x00680017	<a href="#">641</a>
Encoder type (C00422)	<a href="#">773</a>	0x00680018	<a href="#">641</a>
Encoder voltage (C00421)	<a href="#">773</a>	0x00680019	<a href="#">641</a>
Encoderrev (C02762)	<a href="#">862</a>	0x0068001a	<a href="#">641</a>
Encoderspeed (C02764)	<a href="#">862</a>	0x0068001b	<a href="#">641</a>
EnDat encoder		0x0068001c	<a href="#">642</a>
Battery empty (error message)	<a href="#">661</a>	0x0068001d	<a href="#">642</a>
Command error (error message)	<a href="#">667</a>	0x0068001e	<a href="#">642</a>
Lamp error (error message)	<a href="#">660</a>	0x0068001f	<a href="#">642</a>
Overcurrent (error message)	<a href="#">661</a>	0x00680020	<a href="#">642</a>
Overvoltage (error message)	<a href="#">661</a>	0x00680021	<a href="#">642</a>
Position error (error message)	<a href="#">661</a>	0x00680022	<a href="#">643</a>
Position initialisation error (error message)	<a href="#">667</a>	0x00680023	<a href="#">643</a>
Signal error (error message)	<a href="#">661</a>	0x00680024	<a href="#">643</a>
Transmission error (error message)	<a href="#">666</a>	0x00690000	<a href="#">643</a>
Undervoltage (error message)	<a href="#">661</a>	0x00690001	<a href="#">643</a>
Enhanced Power (C01199)	<a href="#">816</a>	0x00690002	<a href="#">643</a>
ENP		0x00690003	<a href="#">644</a>
Identified motor type (C00186)	<a href="#">743</a>	0x00690004	<a href="#">644</a>
Identified serial number (C00187)	<a href="#">743</a>	0x00690005	<a href="#">644</a>
Status (C00188)	<a href="#">744</a>	0x00690006	<a href="#">644</a>
Error behaviour (I-1029)	<a href="#">350</a>	0x00690007	<a href="#">644</a>
Error description (C00166)	<a href="#">740</a>	0x00690008	<a href="#">644</a>
Error during initialisation (error message)	<a href="#">681</a>	0x00690009	<a href="#">645</a>
Error message "Unknown error"	<a href="#">628</a> , <a href="#">636</a>	0x0069000a	<a href="#">645</a>
Error messages	<a href="#">623</a>	0x0069000b	<a href="#">645</a>
Error messages (short overview)	<a href="#">628</a>	0x0069000c	<a href="#">645</a>
Error messages (system bus)	<a href="#">321</a>	0x0069000d	<a href="#">645</a>
Error number	<a href="#">623</a>	0x006a0000	<a href="#">645</a>
0x00650000	<a href="#">636</a>	0x006a0001	<a href="#">646</a>
0x00650001	<a href="#">636</a>	0x006a0002	<a href="#">646</a>
0x00650002	<a href="#">636</a>	0x006a0003	<a href="#">646</a>
0x00650003	<a href="#">637</a>	0x006a0004	<a href="#">646</a>
0x00680000	<a href="#">637</a>	0x006a0005	<a href="#">646</a>
0x00680001	<a href="#">637</a>	0x006a0006	<a href="#">647</a>
0x00680002	<a href="#">637</a>	0x006a000d	<a href="#">647</a>
0x00680003	<a href="#">637</a>	0x006a000e	<a href="#">647</a>
0x00680004	<a href="#">638</a>	0x006a000f	<a href="#">647</a>
0x00680005	<a href="#">638</a>	0x006a0010	<a href="#">647</a>
0x00680006	<a href="#">638</a>	0x006a0011	<a href="#">647</a>
0x00680007	<a href="#">638</a>	0x006a0012	<a href="#">648</a>
0x00680008	<a href="#">638</a>	0x006a0013	<a href="#">648</a>
0x00680009	<a href="#">638</a>	0x006a0014	<a href="#">648</a>
		0x006a0015	<a href="#">648</a>
		0x006a0016	<a href="#">648</a>

0x006a0017	<a href="#">649</a>	0x007b001a	<a href="#">658</a>
0x006a001a	<a href="#">649</a>	0x007b001b	<a href="#">659</a>
0x006f0000	<a href="#">649</a>	0x007b001c	<a href="#">659</a>
0x00720000	<a href="#">649</a>	0x007b001d	<a href="#">659</a>
0x00750000	<a href="#">649</a>	0x007b001e	<a href="#">659</a>
0x00750001	<a href="#">649</a>	0x007b001f	<a href="#">659</a>
0x00750003	<a href="#">650</a>	0x007b0020	<a href="#">660</a>
0x00750005	<a href="#">650</a>	0x007b0021	<a href="#">660</a>
0x00750006	<a href="#">650</a>	0x007b0023	<a href="#">660</a>
0x00770000	<a href="#">650</a>	0x007b0024	<a href="#">660</a>
0x00770001	<a href="#">650</a>	0x007b0025	<a href="#">660</a>
0x00770002	<a href="#">651</a>	0x007b0026	<a href="#">660</a>
0x00770003	<a href="#">651</a>	0x007b0027	<a href="#">661</a>
0x00770008	<a href="#">651</a>	0x007b0028	<a href="#">661</a>
0x00770009	<a href="#">651</a>	0x007b0029	<a href="#">661</a>
0x0077000a	<a href="#">651</a>	0x007b002a	<a href="#">661</a>
0x0077000b	<a href="#">652</a>	0x007b002b	<a href="#">661</a>
0x0077000c	<a href="#">652</a>	0x007b002c	<a href="#">661</a>
0x0077000d	<a href="#">652</a>	0x007b002d	<a href="#">661</a>
0x0077000e	<a href="#">652</a>	0x007b002e	<a href="#">662</a>
0x0077000f	<a href="#">652</a>	0x007b002f	<a href="#">662</a>
0x00770010	<a href="#">653</a>	0x007b0030	<a href="#">662</a>
0x00770011	<a href="#">653</a>	0x007b0031	<a href="#">662</a>
0x00780000	<a href="#">653</a>	0x007b0032	<a href="#">662</a>
0x00780001	<a href="#">653</a>	0x007b0033	<a href="#">662</a>
0x00780002	<a href="#">653</a>	0x007b0034	<a href="#">663</a>
0x00780003	<a href="#">653</a>	0x007b0035	<a href="#">663</a>
0x00780004	<a href="#">654</a>	0x007b0036	<a href="#">663</a>
0x00780005	<a href="#">654</a>	0x007b0037	<a href="#">663</a>
0x00780006	<a href="#">654</a>	0x007b0038	<a href="#">663</a>
0x00780007	<a href="#">654</a>	0x007b0039	<a href="#">663</a>
0x00780008	<a href="#">654</a>	0x007b003a	<a href="#">664</a>
0x00780009	<a href="#">654</a>	0x007b003b	<a href="#">664</a>
0x0078000a	<a href="#">654</a>	0x007b003c	<a href="#">664</a>
0x00790000	<a href="#">655</a>	0x007b003d	<a href="#">664</a>
0x00790001	<a href="#">655</a>	0x007b003e	<a href="#">665</a>
0x00790002	<a href="#">655</a>	0x007b003f	<a href="#">665</a>
0x007b0001	<a href="#">655</a>	0x007b0040	<a href="#">665</a>
0x007b0002	<a href="#">655</a>	0x007b0041	<a href="#">665</a>
0x007b0003	<a href="#">655</a>	0x007b0042	<a href="#">665</a>
0x007b0004	<a href="#">655</a>	0x007b0047	<a href="#">666</a>
0x007b0006	<a href="#">656</a>	0x007b004a	<a href="#">666</a>
0x007b0007	<a href="#">656</a>	0x007b004c	<a href="#">666</a>
0x007b0009	<a href="#">656</a>	0x007b004d	<a href="#">666</a>
0x007b000a	<a href="#">656</a>	0x007b004e	<a href="#">666</a>
0x007b000b	<a href="#">656</a>	0x007b004f	<a href="#">667</a>
0x007b000c	<a href="#">656</a>	0x007b0050	<a href="#">667</a>
0x007b000d	<a href="#">656</a>	0x007c0000	<a href="#">667</a>
0x007b000e	<a href="#">657</a>	0x007c0001	<a href="#">667</a>
0x007b000f	<a href="#">657</a>	0x007d0000	<a href="#">667</a>
0x007b0010	<a href="#">657</a>	0x007d0001	<a href="#">668</a>
0x007b0011	<a href="#">657</a>	0x007f0002	<a href="#">668</a>
0x007b0012	<a href="#">657</a>	0x007f0003	<a href="#">668</a>
0x007b0013	<a href="#">657</a>	0x007f0004	<a href="#">668</a>
0x007b0014	<a href="#">658</a>	0x00830000	<a href="#">668</a>
0x007b0017	<a href="#">658</a>	0x00830001	<a href="#">669</a>
0x007b0018	<a href="#">658</a>	0x00830002	<a href="#">669</a>
0x007b0019	<a href="#">658</a>	0x00840000	<a href="#">669</a>

0x00840020	<a href="#">669</a>	0x00910008	<a href="#">679</a>
0x00840021	<a href="#">670</a>	0x00910009	<a href="#">680</a>
0x00850000	<a href="#">670</a>	0x0091000a	<a href="#">680</a>
0x00860000	<a href="#">670</a>	0x0091000b	<a href="#">680</a>
0x00860020	<a href="#">670</a>	0x0091000c	<a href="#">680</a>
0x00870000	<a href="#">671</a>	0x0091000d	<a href="#">680</a>
0x00870001	<a href="#">671</a>	0x0091000e	<a href="#">680</a>
0x00870002	<a href="#">671</a>	0x0091000f	<a href="#">681</a>
0x00870003	<a href="#">671</a>	0x00910010	<a href="#">681</a>
0x00870008	<a href="#">671</a>	0x00910011	<a href="#">681</a>
0x00880000	<a href="#">672</a>	0x00910012	<a href="#">681</a>
0x00890000	<a href="#">672</a>	0x00920000	<a href="#">681</a>
0x008c0000	<a href="#">672</a>	0x00920001	<a href="#">681</a>
0x008c0001	<a href="#">672</a>	0x00990000	<a href="#">682</a>
0x008c0002	<a href="#">672</a>	0x00990001	<a href="#">682</a>
0x008c0003	<a href="#">672</a>	0x00990002	<a href="#">682</a>
0x008c0004	<a href="#">673</a>	0x00990003	<a href="#">682</a>
0x008c0005	<a href="#">673</a>	0x00990004	<a href="#">682</a>
0x008c0006	<a href="#">673</a>	0x00990005	<a href="#">682</a>
0x008c0007	<a href="#">673</a>	0x009d0000	<a href="#">683</a>
0x008c0008	<a href="#">673</a>	0x009d0001	<a href="#">683</a>
0x008c0009	<a href="#">673</a>	0x009d0002	<a href="#">683</a>
0x008c000a	<a href="#">674</a>	0x009e0000	<a href="#">683</a>
0x008c000b	<a href="#">674</a>	0x009e0020	<a href="#">684</a>
0x008c000c	<a href="#">674</a>	0x009e0021	<a href="#">684</a>
0x008c000d	<a href="#">674</a>	0x009f0000	<a href="#">684</a>
0x008c000e	<a href="#">674</a>	0x00a00000	<a href="#">684</a>
0x008c000f	<a href="#">674</a>	0x00a00020	<a href="#">685</a>
0x008c0010	<a href="#">675</a>	0x00a10000	<a href="#">685</a>
0x008c0011	<a href="#">675</a>	0x00a10001	<a href="#">685</a>
0x008c0012	<a href="#">675</a>	0x00a10002	<a href="#">685</a>
0x008c0013	<a href="#">675</a>	0x00a10003	<a href="#">686</a>
0x008c0014	<a href="#">675</a>	0x00a10004	<a href="#">686</a>
0x008c0015	<a href="#">675</a>	0x00a10005	<a href="#">686</a>
0x008c0016	<a href="#">676</a>	0x00a10006	<a href="#">686</a>
0x008c0017	<a href="#">676</a>	0x00a10007	<a href="#">686</a>
0x008c0018	<a href="#">676</a>	0x00a10008	<a href="#">687</a>
0x008c001a	<a href="#">676</a>	0x00a20000	<a href="#">687</a>
0x00900000	<a href="#">676</a>	0x00a30000	<a href="#">687</a>
0x00900001	<a href="#">676</a>	0x00aa0000	<a href="#">687</a>
0x00900002	<a href="#">677</a>	0x00aa0001	<a href="#">687</a>
0x00900003	<a href="#">677</a>	0x00aa0002	<a href="#">688</a>
0x00900004	<a href="#">677</a>	0x00aa0003	<a href="#">688</a>
0x00900005	<a href="#">677</a>	0x00aa0004	<a href="#">688</a>
0x00900006	<a href="#">677</a>	0x00aa0005	<a href="#">688</a>
0x00900007	<a href="#">677</a>	0x00ac0000	<a href="#">688</a>
0x00900008	<a href="#">678</a>	0x00ac0001	<a href="#">689</a>
0x00900009	<a href="#">678</a>	0x00ac0002	<a href="#">689</a>
0x0090000a	<a href="#">678</a>	0x00ad0000	<a href="#">689</a>
0x0090000b	<a href="#">678</a>	0x00ad0020	<a href="#">689</a>
0x0090000c	<a href="#">678</a>	0x00ad0021	<a href="#">690</a>
0x00910000	<a href="#">678</a>	0x00ae0000	<a href="#">690</a>
0x00910001	<a href="#">679</a>	0x00af0000	<a href="#">690</a>
0x00910002	<a href="#">679</a>	0x00af0020	<a href="#">690</a>
0x00910003	<a href="#">679</a>	0x00b00000	<a href="#">691</a>
0x00910004	<a href="#">679</a>	0x00b00001	<a href="#">691</a>
0x00910005	<a href="#">679</a>	0x00b00002	<a href="#">691</a>
0x00910006	<a href="#">679</a>	0x00b00003	<a href="#">691</a>

- 0x00b00004 [691](#)
- 0x00b00005 [692](#)
- 0x00b00006 [692](#)
- 0x00b00007 [692](#)
- 0x00b00008 [692](#)
- 0x00b10000 [693](#)
- 0x00b20000 [693](#)
- 0x00b80000 [693](#)
- 0x00b80001 [693](#)
- 0x00b80002 [693](#)
- 0x00b80003 [694](#)
- 0x00b80004 [694](#)
- 0x00b80005 [694](#)
- 0x00b80007 [694](#)
- 0x00b80008 [695](#)
- 0x00b80009 [695](#)
- 0x00b8000a [695](#)
- 0x00b8000b [695](#)
- 0x00b8000c [695](#)
- 0x00b8000d [696](#)
- 0x00b8000e [696](#)
- 0x00b8000f [696](#)
- 0x00b80010 [696](#)
- 0x00b80011 [696](#)
- 0x00b80012 [697](#)
- 0x00b80013 [697](#)
- 0x00b80014 [697](#)
- 0x00b80015 [697](#)
- 0x00b80016 [697](#)
- 0x00b80017 [698](#)
- 0x00b80019 [698](#)
- 0x00b8001a [698](#)
- 0x00b8001b [698](#)
- 0x00b8001c [699](#)
- 0x00b8001d [699](#)
- 0x00b80020 [699](#)
- 0x00b80021 [699](#)
- 0x00b80022 [700](#)
- 0x00b80023 [700](#)
- 0x00b80024 [700](#)
- 0x00b80025 [700](#)
- 0x00b80026 [701](#)
- 0x00b80027 [701](#)
- 0x00b80028 [701](#)
- 0x00b80029 [701](#)
- 0x00b8002a [702](#)
- 0x00b8002b [702](#)
- 0x00b8002c [702](#)
- 0x00b8002d [702](#)
- 0x00b8002e [703](#)
- 0x00b8002f [703](#)
- 0x00b80030 [703](#)
- 0x00b80031 [703](#)
- 0x00b80032 [704](#)
- 0x00b80033 [704](#)
- 0x00b80034 [704](#)
- 0x00b80035 [704](#)
- Error number (C00168) [740](#)
- Error register (I-1001) [342](#)
- Ethernet IP address client x (C01510) [821](#)
- Ethernet status client x (C01511) [821](#)
- Exceptional behaviour [114](#)
- Export logbook entries [619](#)
- Ext. 24-V voltage (C00065) [729](#)
- External actual position (C02577) [834](#)
- External error (error message) [649](#)
- F**
- Failure of a mains phase (error message) [665](#)
- Failure of motor phase U (error message) [661](#)
- Failure of motor phase V (error message) [662](#)
- Failure of motor phase W (error message) [662](#)
- Fan control status (C00587) [783](#)
- Fault during the update of inputs and outputs (error message) [646](#)
- Fault in the control configuration (error message) [649](#)
- Faulty application parameter (error message) [647](#)
- Faulty program download (error message) [646](#)
- Feed constant (C02524) [824](#)
- Feedback [39](#)
- Feedback to Lenze [919](#)
- Feedforward control of torque [163](#)
- Feedfwd. ctrl. - current contr. (C00074) [730](#)
- Field contr. reset time (C00078) [730](#)
- Field controller gain (C00077) [730](#)
- Field weak. contr. reset time (C00578) [780](#)
- Field weakening controller gain (C00577) [780](#)
- Field weakening for SM (C00093) [732](#)
- Field weakening for synchronous machines [215](#)
- File DeviceCFG.dat defect (error message) [672](#)
- File DeviceCFG.dat invalid (error message) [673](#)
- File DeviceCFG.dat is missing (error message) [673](#)
- File ProjectList.dat defect (error message) [672](#)
- File ProjectList.dat invalid (error message) [673](#)
- File ProjectList.dat is missing (error message) [673](#)
- File ProjectSelection.dat defect (error message) [672](#)
- File ProjectSelection.dat invalid (error message) [673](#)
- File ProjectSelection.dat is missing (error message) [672](#)
- Filter for PWM adjustment (C00281) [750](#)
- Filter time const. DC detection (C00280) [749](#)
- Filter time constant (C02562) [832](#)
- Filtered torque setpoint (C00697) [794](#)
- Firmware - compiling date (C00201) [744](#)
- Firmware has been changed (error message) [641](#)
- Firmware is incompatible with control card (error message) [642](#)
- Firmware product type (C00200) [744](#)
- Firmware version (C00099) [732](#)
- Flying restart
  - Activation (C00990) [810](#)
  - Current (C00991) [810](#)

- Delay time (C00995) [811](#)
- Integration time (C00993) [811](#)
- Min. deviation (C00994) [811](#)
- Start frequency (C00992) [810](#)
- Flying restart function [218](#)
- Following error (C02576) [834](#)
- Freq. - current setpoint filter (C00270) [748](#)
- Frequency (C02771) [863](#)
- G**
- GDO channel 1/trigger 1 (C731) [795](#)
- GDO channel 2/trigger 2 (C732) [795](#)
- GDO channel 3 (C733) [795](#)
- GDO channel 4 (C734) [795](#)
- GDO channel 5 (C735) [795](#)
- GDO channel 6 (C736) [795](#)
- GDO channel 7 (C737) [795](#)
- GDO channel 8 (C738) [795](#)
- GDO general parameters (C730) [794](#)
- GDO status information (C739) [795](#)
- Gearbox fac. denom.
  - Pos. enc. (C02523) [824](#)
- Gearbox factor denom.
  - Motor (C02521) [824](#)
- Gearbox factor num.
  - Pos. enc. (C02522) [824](#)
- Gearbox factor numerator
  - Motor (C02520) [824](#)
- Gearbox factors (decimal) (C02531) [826](#)
- General error in the application (error message) [645](#)
- Grinding OFF time (C02599) [838](#)
- Grinding ON time (C02598) [838](#)
- Grinding speed (C02596) [837](#)
- Guard time [331](#)
- Guard time (I-100C) [345](#)
- GUID (C02903) [874](#)
- H**
- Hardware limit positions [522](#)
- Heartbeat not periodic (error message) [679](#)
- Heartbeat protocol [335](#)
- Heatsink
  - Fan is defect (error message) [653](#)
  - Overtemperature (error message) [650](#)
  - Temperature &gt; [650](#)
  - Thermal detector is defect (error message) [651](#)
- Heatsink temp. warn. threshold (C00122) [734](#)
- Heatsink temperature (C00061) [728](#)
- Hiperface
  - detected TypeCode (C00413) [771](#)
  - number of rev. (C00415) [772](#)
  - TypeCode (C00414) [772](#)
- Hiperface encoder
  - Command error (error message) [664](#)
  - Position initialisation error (error message) [664](#)
- Transmission error (error message) [664](#)
- Unknown encoder (error message) [664](#)
- HM\_dnHomePos\_p (C02658) [850](#)
- HM\_dnSpeedOverride\_n (C02655) [850](#)
- HM\_dnState (C02657) [850](#)
- Holding brake [528](#)
- Home position (C02642) [848](#)
- Homing [419](#)
  - Acceleration 1 (C02645) [848](#)
  - Acceleration 2 (C02647) [848](#)
  - Blocking time (C02650) [849](#)
  - Dig. signals (C02659) [850](#)
  - Speed 1 (C02644) [848](#)
  - Speed 2 (C02646) [848](#)
  - S-ramp time (C02648) [849](#)
  - Target position (C02643) [848](#)
  - Torque limit (C02649) [849](#)
  - TP configuration (C02651) [849](#)
- Homing mode (C02640) [846](#)
- Homing mode not allowed (error message) [698](#)
- HW countries of origin (C00209) [746](#)
- HW descriptions (C00205) [745](#)
- HW manufacturer (C00208) [746](#)
- HW manufacturing data (C00206) [745](#)
- HW product types (C00203) [744](#)
- HW serial numbers (C00204) [745](#)
- HW versions (C00210) [746](#)
- Hysteresis for POS\_bDriveInTarget (C02672) [851](#)
- I**
- I-1000 [342](#)
- I-1001 [342](#)
- I-1003 [343](#)
- I-1005 [344](#)
- I-1006 [345](#)
- I-100C [345](#)
- I-100D [345](#)
- I-1010 [346](#)
- I-1011 [347](#)
- I-1014 [348](#)
- I-1015 [348](#)
- I-1016 [349](#)
- I-1017 [349](#)
- I-1018 [350](#)
- I-1029 [350](#)
- I-1200 [351](#)
- I-1201 [352](#)
- I-1202 [354](#)
- I-1203 [354](#)
- I-1204 [354](#)
- I-1205 [354](#)
- I-1206 [355](#)
- I-1207 [355](#)
- I-1208 [355](#)

- I-1209 [355](#)
  - I-1400 [356](#)
  - I-1401 [357](#)
  - I-1402 [357](#)
  - I-1403 [358](#)
  - I-1600 [358](#)
  - I-1601 [359](#)
  - I-1602 [359](#)
  - I-1603 [359](#)
  - I-1800 [360](#)
  - I-1801 [361](#)
  - I-1802 [362](#)
  - I-1803 [362](#)
  - I-1A00 [363](#)
  - I-1A01 [363](#)
  - I-1A02 [364](#)
  - I-1A03 [364](#)
  - ID status (C00854) [802](#)
  - Identifier (CAN) [299](#)
  - Identity object (I-1018) [350](#)
  - IdleTask
    - Overflow (error message) [647](#)
  - IEC 61508 [367](#)
  - Imax f. Lss sat. characteristic (C02855) [872](#)
  - Inching mode [398](#)
  - Incorrect memory module (error message) [640](#)
  - Incorrect safety module (error message) [640](#)
  - Increased continuous power [117](#)
  - Influence winding l<sup>xt</sup> mon. (C01195) [816](#)
  - Inhibit time EMCY (I-1015) [348](#)
  - Inside the device
    - Fan is defect (error message) [653](#)
    - Thermal detector is defective (error message) [652](#)
  - Instant of PDO acceptance [313](#)
  - Instant of PDO transmission [313](#)
  - Int. overflow C02620 (manual jog Speed 1) (error message) [698](#)
  - Int. overflow C02621 (manual jog Speed 2) (error message) [698](#)
  - Int. overflow C02622 (manual jog acceleration) (error message) [699](#)
  - Int. overflow C02623 (manual jog deceleration) (error message) [699](#)
  - Int. overflow C02642 (home position) (error message) [702](#)
  - Int. overflow C02643 (homing Target position) (error message) [703](#)
  - Int. overflow C02644 (homing Speed 1) (error message) [703](#)
  - Int. overflow C02645 (homing Acceleration 1) (error message) [703](#)
  - Int. overflow C02646 (homing Speed 2) (error message) [703](#)
  - Int. overflow C02647 (homing Acceleration 2) (error message) [704](#)
  - Int. overflow C02670 (positioner Tol. for target position) (error message) [704](#)
  - Int. overflow C02701/1 (positive software limit position) (error message) [699](#)
  - Int. overflow C02701/2 (negative software limit position) (error message) [699](#)
  - Int. overflow C02703 (maximum speed) (error message) [700](#)
  - Int. overflow C02705 (maximum acceleration) (error message) [700](#)
  - Int. overflow C02708/1 (decel. limited speed 1) (error message) [701](#)
  - Int. overflow C02708/1 (limited speed 1) (error message) [700](#)
  - Int. overflow C02708/2 (decel. limited speed 2) (error message) [701](#)
  - Int. overflow C02708/2 (limited speed 2) (error message) [700](#)
  - Int. overflow C02708/3 (decel. limited speed 3) (error message) [702](#)
  - Int. overflow C02708/3 (limited speed 3) (error message) [701](#)
  - Int. overflow C02708/4 (decel. limited speed 4) (error message) [702](#)
  - Int. overflow C02708/4 (limited speed 4) (error message) [701](#)
  - Int. overflow C02713 (max. dist. manual control) (error message) [702](#)
  - Internal clock (C01214) [819](#)
  - Internal communication error (DMA) (error message) [663](#)
  - Internal communication error (host MCTRL) (error message) [658](#)
  - Internal communication error (MCTRL host) (error message) [663](#)
  - Internal error
    - See C00180 (error message) [679](#), [680](#)
  - Internal error (event mechanism) (error message) [645](#)
  - Internal error (file system lifetime) (error message) [645](#)
  - Internal error (LDS instance data) (error message) [643](#)
  - Internal error (LDS tasks) (error message) [644](#)
  - Internal error (memory area - logbook) (error message) [643](#)
  - Internal error (message memory) (error message) [644](#)
  - Internal error (message queue) (error message) [644](#)
  - Internal error (name data base) (error message) [644](#)
  - Internal error (semaphores) (error message) [645](#)
  - Internal error (storage blocks) (error message) [644](#)
  - Internal error (task queue) (error message) [644](#)
  - Internal torque limits (C02559) [831](#)
- J**
- Jerk [383](#), [385](#)
  - Jerk has been limited (error message) [696](#)

**K**

## Keypad

- Default parameters (C00466) [777](#)
  - Default welcome screen (C00467) [777](#)
  - Fct. STOP key (C00469) [777](#)
  - Mode (C00464) [776](#)
  - Welcome screen time-out (C00465) [776](#)
- Keypad LCD display [614](#)

**L**

- Layout of the safety information [21](#)
- Layout of the safety instructions [21](#)
- LCD display (keypad) [614](#)
- LED status displays [611](#)
- LED status displays for the system bus [298](#)
- Lenze setting loaded (error message) [676](#)
- Lh adjustment (C02861) [872](#)
- Life guarding event [332](#)
- Life time factor (I-100D) [345](#)
- LIM\_dnState (C02718) [860](#)
- LIM\_dwControl (C02717) [859](#)
- Limit position [519](#), [522](#)
  - Triggering behaviour [521](#)
- Limit switches [522](#)
- Limitation active (C02715) [859](#)
- Limitations effective (C02702) [856](#)
- Limited speed (C02708) [857](#)
- Limited speed [rpm] (C02709) [858](#)
- Limiter [368](#), [513](#)
  - Dig. signals (C02719) [860](#)
- Load reference speed (C02542) [828](#)
- Load reference torque (C02543) [828](#)
- Loading of Lenze setting failed (error message) [677](#)
- Logbook [616](#)
  - Overflow (error message) [636](#)
  - Reset (read error) (error message) [636](#)
  - Reset (version error) (error message) [636](#)
- Logbook - event filter (C00169) [740](#)
- LS\_AnalogInput [276](#)
- LS\_AnalogOutput [278](#)
- LS\_Brake [530](#)
- LS\_CamInterface [569](#)
- LS\_DigitalInput [280](#)
- LS\_DigitalOutput [282](#)
- LS\_DriveInterface [118](#)
- LS\_EncoderX8 [258](#)
- LS\_Feedback [242](#)
- LS\_Homing [421](#)
- LS\_Limiter [513](#)
- LS\_ManualJog [399](#)
- LS\_ManualJogOpenLoop [411](#)
- LS\_MotorInterface [236](#)
- LS\_PolePositionIdentification [582](#)
- LS\_Positioner [483](#)

- LS\_PositionFollower [495](#)
- LS\_quick stop [391](#)
- LS\_SafetyModuleInterface [370](#)
- LS\_SpeedFollower [502](#)
- LS\_SsiEncoderX8 [256](#)
- LS\_Stop [388](#)
- LS\_SyncInput [365](#)
- LS\_TorqueFollower [509](#)
- LS\_TouchProbe1 [288](#)
- LS\_TouchProbe2 [288](#)
- LS\_TouchProbe3 [288](#)
- LS\_TouchProbe4 [288](#)
- LS\_TouchProbe5 [288](#)
- LS\_TouchProbe6 [288](#)
- LS\_TouchProbe7 [288](#)
- LS\_TouchProbe8 [288](#)
- LS\_TouchProbeLoad [289](#)
- LS\_TouchProbeMotor [289](#)
- Lss sat. characteristic (C02853) [871](#)

**M**

- Machine parameters [36](#)
- Mains connection [112](#)
- Mains recov. detect. threshold (C00185) [743](#)
- Mains voltage (C00173) [741](#)
- Mains voltage is switched off (error message) [679](#)
- Mains voltage is switched on (error message) [678](#)
- MAN\_dnSpeedOverride\_n (C02637) [842](#)
- Manual jog [398](#)
  - Acceleration (C02622) [841](#)
  - Deceleration (C02623) [841](#)
  - Dig. signals (C02639) [843](#)
  - Index Stop position (C02626) [842](#)
  - Selected Stop position (C02627) [842](#)
  - Speed 1 (C02620) [841](#)
  - Speed 2 (C02621) [841](#)
  - S-ramp time (C02624) [841](#)
  - Status (C02638) [842](#)
  - Step size (C02625) [841](#)
- Manual jog to software limit position [408](#)
- Manual jog, encoderless [410](#)
- ManualJogOpenLoop
  - Dig. signals (C02781) [865](#)
- Masked Error number (C00162) [740](#)
- Master functionality (CAN) [305](#)
- Max. acceleration (C02705) [857](#)
- Max. acceleration change (C00274) [749](#)
- Max. dist. manual control (C02713) [859](#)
- Max. dist. manual jog [Incr.] (C02714) [859](#)
- Max. presentable acceleration (C02541) [828](#)
- Max. presentable position (C02539) [827](#)
- Max. presentable speed (C02540) [828](#)
- Max. rot. ang. aft. mns. swtch. (C02653) [849](#)
- Max. speed (C02703) [856](#)

- Max. speed [rpm] (C02704) [857](#)
- Maximum acceleration exceeded (error message) [696](#)
- Maximum current [133](#)
- Maximum current (C00022) [726](#)
- Maximum current monitoring [235](#)
- Maximum speed exceeded (error message) [696](#)
- MCTRL\_dnAccelerationAdd (C00804) [800](#)
- MCTRL\_dnBoost (C00814) [801](#)
- MCTRL\_dnDCBusVoltage (C00779) [797](#)
- MCTRL\_dnDeltaMotorPos\_p (C00791) [799](#)
- MCTRL\_dnFieldWeak (C00816) [802](#)
- MCTRL\_dnFluxAct (C00778) [797](#)
- MCTRL\_dnFlyingSpeedAct (C00787) [798](#)
- MCTRL\_dnI2xtLoad (C00790) [799](#)
- MCTRL\_dnImotAct (C00780) [797](#)
- MCTRL\_dnInputJerkCtrl (C00776) [796](#)
- MCTRL\_dnInputTorqueCtrl (C00777) [797](#)
- MCTRL\_dnIxtLoad (C00786) [798](#)
- MCTRL\_dnLoadPosAct (C00771) [796](#)
- MCTRL\_dnLoadPosRefValue (C00813) [801](#)
- MCTRL\_dnLoadSpeedAct (C00773) [796](#)
- MCTRL\_dnMotorFreqAct (C00784) [798](#)
- MCTRL\_dnMotorPosAct (C00770) [795](#)
- MCTRL\_dnMotorPosRefValue (C00812) [801](#)
- MCTRL\_dnMotorSpeedAct (C00772) [796](#)
- MCTRL\_dnMvoraAdapt (C00818) [802](#)
- MCTRL\_dnOutputPosCtrlMotor\_s (C00792) [799](#)
- MCTRL\_dnOutputSpeedCtrl (C00775) [796](#)
- MCTRL\_dnPosCtrlAdapt (C00811) [801](#)
- MCTRL\_dnPosCtrlOutLimit (C00808) [800](#)
- MCTRL\_dnPosSet (C00800) [799](#)
- MCTRL\_dnSpeedAdd (C00802) [799](#)
- MCTRL\_dnSpeedCtrlAdapt (C00810) [801](#)
- MCTRL\_dnSpeedCtrlIntegrator (C00815) [801](#)
- MCTRL\_dnSpeedLowLimit (C00805) [800](#)
- MCTRL\_dnSpeedSet\_s (C00817) [802](#)
- MCTRL\_dnTorqueAct (C00774) [796](#)
- MCTRL\_dnTorqueAdd (C00803) [799](#)
- MCTRL\_dnTorqueCtrlAdapt (C00809) [800](#)
- MCTRL\_dnTorqueHighLimit (C00807) [800](#)
- MCTRL\_dnTorqueLowLimit (C00806) [800](#)
- MCTRL\_dwMaxDeviceCurrent (C00789) [798](#)
- MCTRL\_dwMaxEffMotorTorque (C00788) [798](#)
- MCTRL\_dwMaxMotorSpeed (C00781) [797](#)
- MCTRL\_dwMaxMotorTorque (C00782) [797](#)
- MCTRL\_dwMotorVoltageAct (C00783) [798](#)
- MEC history
  - Error number (C1223) [820](#)
  - Flash value (C1222) [820](#)
  - RAM address (C1220) [820](#)
  - RAM value (C1221) [820](#)
- Memory distribution for cam data [565](#)
- Memory module
  - Faulty file system (error message) [642](#)
  - File system has been formatted (error message) [667](#)
  - File system has been restored (error message) [667](#)
- Memory module has been changed (error message) [641](#)
- Memory module has been removed (error message) [638](#)
- Memory module is defect or missing (error message) [637](#), [639](#)
- Memory module is missing (error message) [637](#)
- Messages - motor interface (C02560) [831](#)
- Min. S-ramp time (C02706) [857](#)
- Minimum brake resistance (C00134) [736](#)
- MM440 [819](#)
- Modulation modes [115](#)
- MOL\_dnState (C02780) [865](#)
- MOL\_SetpointCurrent (C02779) [864](#)
- Moment of inertia (C00273) [748](#)
- Monitoring [620](#)
- Monitoring of limit positions [519](#)
- Mot. overload protection (I<sup>2</sup>t) (C00120) [734](#)
- Mot. overload warning threshold (C00127) [735](#)
- Motor
  - Actual current value &gt; [659](#)
  - Actual speed value &gt; [660](#)
  - Calculated e.m.f. factor unrealistic (error message) [656](#)
  - Calculated flux factor unrealistic (error message) [656](#)
  - Calculated leakage inductance unrealistic (error message) [658](#)
  - Calculated motor impedance unrealistic (error message) [655](#)
  - Calculated mutual inductance unrealistic (error message) [655](#), [656](#)
  - Calculated rotor resistance unrealistic (error message) [656](#)
  - Calculated rotor time constant unrealistic (error message) [656](#)
  - Device current too low for rated magnetisation (error message) [656](#)
  - Overtemperature (error message) [651](#)
  - Phase resistance too high (error message) [655](#)
  - PTC has triggered (error message) [652](#)
  - Rated current &lt; [656](#)
  - Temperature &gt; [651](#)
  - Thermal detector is defect (error message) [652](#)
- Motor - cosine phi (C00091) [732](#)
- Motor - magnetising current (C00092) [732](#)
- Motor - mutual inductance (C00079) [731](#)
- Motor - number of pole pairs (C00059) [728](#)
- Motor - rotor resistance (C00082) [731](#)
- Motor - rotor time constant (C00083) [731](#)
- Motor brake
  - Angular drift with closed brake too high (error message) [694](#)
  - Motor brake
    - Autom. activated after waiting time has elapsed



- (error message) [694](#)
- Status monitoring error (error message) [694](#)
- Motor control
  - Task overflow (error message) [657](#)
- Motor current (C00054) [727](#)
- Motor data are inconsistent (error message) [655](#), [658](#)
- Motor encoder [250](#)
  - Module selected in C00495 not available (error message) [660](#)
- Motor encoder selection (C00495) [778](#)
- Motor holding brake [528](#)
- Motor holding brake control module [528](#)
- Motor interface [123](#)
  - % signals (C02568) [832](#)
  - Dig. signals (C02569) [833](#)
- Motor load I<sub>xt</sub> &gt; [653](#)
- Motor mounting direction (C02527) [825](#)
- Motor operating temperature (C01194) [815](#)
- Motor parameter identification was cancelled (error message) [663](#)
- Motor phase failure [233](#)
- Motor phase failure monitoring [233](#)
- Motor phase failure threshold (C00599) [786](#)
- Motor protection [133](#), [235](#)
- Motor reference speed [133](#)
- Motor reference speed (C00011) [726](#)
- Motor speed [133](#)
- Motor standstill time constant (C00494) [777](#)
- Motor stator leakage induct. (C00085) [731](#)
- Motor stator resistance (C00084) [731](#)
- Motor switched off (error message) [666](#)
- Motor temp. feedback system (C01193) [815](#)
- Motor temp. warning threshold (C00121) [734](#)
- Motor temperature
  - Module selected in C01193 not available (error message) [660](#)
- Motor temperature (C00063) [729](#)
- Motor temperature monitoring (PTC) [231](#)
- Motor thermal sensor (C01190) [814](#)
- Motor voltage (C00052) [727](#)
- Multiturn resolution (C02761) [861](#)
- MXI1
  - CAN module is missing or incompatible (error message) [676](#)
  - Digital frequency module is missing or incompatible (error message) [675](#)
  - Ethernet module is missing or incompatible (error message) [675](#)
  - ICM module is missing or incompatible (error message) [675](#)
  - Module changed during operation (error message) [638](#)
  - Module has been changed (error message) [640](#)
  - Module is defect or missing (error message) [639](#)
  - Module is missing or incompatible (error message) [674](#)
- PROFIBUS module is missing or incompatible (error message) [674](#)
- Wrong module (error message) [640](#)
- MXI2
  - CAN module is missing or incompatible (error message) [676](#)
  - Digital frequency module is missing or incompatible (error message) [675](#)
  - Ethernet module is missing or incompatible (error message) [675](#)
  - ICM module is missing or incompatible (error message) [676](#)
  - Module changed during operation (error message) [638](#)
  - Module has been changed (error message) [641](#)
  - Module is defect or missing (error message) [639](#)
  - Module is missing or incompatible (error message) [674](#)
  - PROFIBUS module is missing or incompatible (error message) [675](#)
  - Wrong module (error message) [640](#)
- N**
  - Negative direction of rotation limited (error message) [695](#)
  - Negative limit switch has triggered (error message) [693](#)
  - Negative software limit switch overtravelled (error message) [695](#)
  - Network management telegram (NMT) [304](#)
  - New application loaded (error message) [646](#)
  - NMT (network management) [304](#)
  - No heartbeat signal detected (error message) [679](#)
  - No parameters for module in MXI1 (error message) [678](#)
  - No parameters for module in MXI2 (error message) [678](#)
  - No. of CRC cycles (C00618) [789](#)
  - Node address [300](#)
  - Node guarding event [332](#)
  - Node guarding protocol [329](#)
  - Node ID [300](#)
  - Node life time [331](#)
  - Number Of Cam Data Points (C02922) [877](#)
  - Number Of Cam Tracks (C02919) [876](#)
  - Number Of Cont Data Points (C02942) [878](#)
  - Number Of Cont Tracks (C02939) [878](#)
  - Number of Pos Data Points (C02962) [879](#)
  - Number of Pos Tracks (C02959) [879](#)
  - Number Of Products (C02912) [876](#)
- O**
  - observation software limit positions (C02720) [860](#)
  - Offset actual pos. value/setp. (C02578) [834](#)
  - Online change mode [573](#)
  - Online Change Mode (C02905) [875](#)

- Online Change State (C02906) [875](#)
- Operating mode (C02770) [862](#)
- Operating mode brake (C02580) [835](#)
- Operation with increased continuous power [117](#)
- Optimise response to setpoint changes [163](#)
- Overcurrent detected (error message) [657](#)
- Overload [117](#)
  
- P**
- Parameter error information (C217) [747](#)
- Parameter set
  - Type of standard device has been changed (error message) [678](#)
  - Version conflict (error message) [677](#)
- Parameter set faulty (error message) [676](#)
- Parameter set loaded (error message) [677](#)
- Parameter set restored (error message) [677](#)
- Parameter set saved (error message) [677](#)
- Parameter set switching [91](#)
- Parameter sets [91](#)
- Password entry [572](#)
- Password for cam data [566](#)
- PDO delay [313](#)
- PDO mapping (MXI1)
  - Faulty configuration (error message) [648](#)
- PDO mapping (MXI2)
  - Faulty configuration (error message) [648](#)
- Permissible angle of rotation (C02595) [837](#)
- Permissible direction of rot. (C02707) [857](#)
- PF\_dnMotorAcc\_x (C02685) [853](#)
- PF\_dnPositionSet\_p (C02688) [854](#)
- PF\_dnSpeedAdd1\_s (C02686) [854](#)
- Phase controller gain (C00254) [748](#)
- Phase controller output (C02557) [831](#)
- Phase currents (C00055) [727](#)
- Plant parameters [132](#)
- PLC configuration invalid (error message) [650](#), [663](#), [668](#), [693](#)
- PLI 360° absolute current amplitude (C00645) [792](#)
- PLI 360° current amplitude (C00641) [791](#)
- PLI 360° traversing direction (C00643) [792](#)
- PLI min. motion absolute cur. amp. (C00651) [793](#)
- PLI min. mov. reset time (C00649) [793](#)
- PLI min.mov. curr. amplitude (C00646) [792](#)
- Pointer access in impermissible memory area (error message) [648](#)
- Pole position (C00058) [728](#)
- Pole position identification [72](#), [74](#), [581](#)
- Pole position recognition cancelled (error message) [666](#)
- PolePosId 360° fault tol. (C00644) [792](#)
- PolePosId 360° ramp time (C00642) [792](#)
- PolePosId min.mov. cur.rise rate (C00647) [793](#)
- PolePosId min.mov. gain (C00648) [793](#)
- PolePosId min.mov. max.perm.mov. (C00650) [793](#)
- PolePosition setpoint (C02788) [866](#)
- PolePositionIdentification
  - Dig. signals (C02789) [866](#)
- Pos Data Point Choice (C02963) [880](#)
- Pos Track Choice (C02960) [879](#)
- Pos. contr. limitation (C02556) [830](#)
- Pos. contr. output (C02558) [831](#)
- POS\_dnProfileSpeed\_s (C02676) [852](#)
- POS\_dnState (C02675) [852](#)
- POS\_dwActualProfileNumber (C02674) [851](#)
- Position control structure (C02570) [833](#)
- Position controller gain (C02553) [830](#)
- Position controller reset time (C02554) [830](#)
- Position encoder [251](#)
  - Module selected in C00490 not available (error message) [660](#)
- Position encoder mounting dir. (C02529) [825](#)
- Position encoder selection (C00490) [777](#)
- Position follower [494](#)
  - % signals (C02687) [854](#)
  - Dig. signals (C02689) [854](#)
- Position setpoint (enc. eval.) (C02573) [834](#)
- Position setpoint (mctrl) (C02552) [830](#)
- Position target outside the software limit positions (error message) [696](#)
- Position value faulty (error message) [681](#)
- Positioning [482](#)
  - % signals (C02677) [852](#)
  - Dig. signals (C02679) [853](#)
  - Pos. signals (C02678) [852](#)
- Positive direction of rotation limited (error message) [695](#)
- Positive limit switch has triggered (error message) [693](#)
- Positive software limit switch overtravelled (error message) [694](#)
- Power section incompatible (error message) [639](#)
- Power section is defect (error message) [637](#), [638](#), [665](#)
- Power section was changed (error message) [640](#)
- Power-on time meter (C00179) [742](#)
- PPI activation (C02785) [865](#)
- PPI mode (C02786) [865](#)
- PPI\_dnState (C02787) [866](#)
- Pre-defined error field (I-1003) [343](#)
- Producer heartbeat time (I-1017) [349](#)
- Product change-over [578](#)
- Product Choice (C02911) [876](#)
- Product Count (C02908) [875](#)
- Product Name (C02910) [875](#)
- Profile data [563](#)
- Program auto-start (C02104) [822](#)
- Program name (C02113) [823](#)
- Program runtime (C02109) [823](#)
- Program status (C02108) [822](#)
- Progress of device command (C00008) [725](#)

Project is not available (error message) [674](#)  
 Project is not loaded (error message) [673](#)  
 PTC [231](#)

## Q

QSP [391](#)  
 Quick stop [391](#)  
   Dig. signals (C02619) [840](#)  
 Quick stop by (source) (C00159) [739](#)  
 Quick stop decel. time (C00105) [733](#)  
 Quick stop S-ramp time (C00106) [733](#)

## R

Rated magnetising current (error message) [656](#)  
 Rated motor current (C00088) [732](#)  
 Rated motor current. See rated motor current  
 Rated motor frequency (C00089) [732](#)  
 Rated motor power (C00081) [731](#)  
 Rated motor speed (C00087) [731](#)  
 Rated motor voltage (C00090) [732](#)  
 Rated power of brake resistor (C00130) [735](#)  
 Rated quantity of heat for brake res. (C00131) [735](#)  
 Read error service register (error message) [649](#)  
 Real-time clock [819](#)  
   Battery empty, time lost (error message) [643](#)  
   Change battery (error message) [643](#)  
 Real-time clock is defective (error message) [643](#)  
 Red. brake chopper threshold (C00181) [743](#)  
 Ref.  
   Brake chopper utilisation (C00133) [736](#)  
 Ref. for Accel. time of brake (C02601) [838](#)  
 Ref. for decel. time of stop (C02612) [840](#)  
 Ref. for quick stop dec. time (C00107) [733](#)  
 Ref. pos. after mains switching (C02652) [849](#)  
 Reference search [425](#)  
 Reference setting [425](#)  
 Reference speed (C02544) [828](#)  
 Reference S-ramp time (C02545) [828](#)  
 Required licence missing (error message) [674](#)  
 Required safety module (C00214) [747](#)  
 Reset of error message [122](#), [627](#)  
 Resol. of an encoder revolution (C00100) [733](#)  
 Resolution of a unit (C02532) [826](#)  
 Resolver  
   Calculated acceleration unrealistic (error message) [659](#)  
   Open circuit (error message) [658](#)  
 Resolver - number of pole pairs (C00080) [731](#)  
 Resolver error compensation [261](#)  
 Resp to new firmw. standard dev. (C00635) [790](#)  
 Resp. brake res. i<sup>2</sup>t &gt; [779](#)  
 Resp. brake trans. Ixt &gt; [779](#)  
 Resp. temp. sensor motor X7/X8 (C00594) [784](#)  
 Resp. to CAN bus OFF (C00595) [785](#)

Resp. to CAN heartbeat error (C00613) [788](#)  
 Resp. to CAN life guarding error (C00614) [789](#)  
 Resp. to CAN node guarding error (C00612) [788](#)  
 Resp. to CAN-RPDOx error (C00591) [784](#)  
 Resp. to comm. error with MXI1 (C01501) [820](#)  
 Resp. to comm. error with MXI2 (C01502) [821](#)  
 Resp. to communication task overflow (C01230) [820](#)  
 Resp. to CPU temp. &gt; [784](#)  
 Resp. to DC bus overvoltage (C00600) [786](#)  
 Resp. to device overload &gt; [786](#)  
 Resp. to encoder comm. error (C00601) [786](#)  
 Resp. to encoder open circuit (C00580) [781](#)  
 Resp. to encoder pulse deviation (C00621) [790](#)  
 Resp. to external fault (C00581) [781](#)  
 Resp. to failure heatsink fan (C00610) [787](#)  
 Resp. to failure integral fan (C00611) [787](#)  
 Resp. to failure t. sensor drive (C00588) [783](#)  
 Resp. to heatsink temp. &gt; [782](#)  
 Resp. to imp. device config. (C00615) [789](#)  
 Resp. to limitation (C02716) [859](#)  
 Resp. to max. speed reached (C00607) [787](#)  
 Resp. to motor current &gt; [789](#)  
 Resp. to motor KTY overtemp. (C00583) [782](#)  
 Resp. to motor overload &gt; [787](#)  
 Resp. to motor phase failure (C00597) [785](#)  
 Resp. to motor PTC overtemp. (C00585) [782](#)  
 Resp. to motor temp. &gt; [782](#)  
 Resp. to new module in MXI1 (C00636) [791](#)  
 Resp. to new module in MXI2 (C00637) [791](#)  
 Resp. to open circuit AIN1 (C00598) [785](#)  
 Resp. to overload brake trans. (C00573) [780](#)  
 Resp. to overtemp. brake resist. (C00574) [780](#)  
 Resp. to pole pos. id. monit. (C00640) [791](#)  
 Resp. to resolver open circuit (C00586) [783](#)  
 Resp. to speed monitoring (C00579) [781](#)  
 Resp. to task overflow (C02111) [823](#)  
 Restart [112](#)  
 Restore default parameters (I-1011) [347](#)  
 Retain memory of the application faulty (error message) [649](#)  
 Retract limit switch [409](#)  
 Rotor position (C00060) [728](#)  
 RPDO1 communication parameter (I-1400) [356](#)  
 RPDO1 mapping parameter (I-1600) [358](#)  
 RPDO2 communication parameter (I-1401) [357](#)  
 RPDO2 mapping parameter (I-1601) [359](#)  
 RPDO3 communication parameter (I-1402) [357](#)  
 RPDO3 mapping parameter (I-1602) [359](#)  
 RPDO4 communication parameter (I-1403) [358](#)  
 RPDO4 mapping parameter (I-1603) [359](#)  
 Rr adjustment (C02860) [872](#)  
 Runtime ApplicationTask (C02121) [823](#)  
 Runtime error (error message) [647](#)

- Runtime IdleTask (C02123) [824](#)
- Runtime measurement [65](#)
- Runtime UserTask (C02122) [823](#)
  
- S**
- S1 torque characteristic l<sup>3</sup>xt mon. (C01196) [816](#)
- Safety engineering [367](#)
- Safety instructions [21](#)
- Safety module [367](#)
  - Incompatible with setting in C00214 (error message) [681](#)
  - Interface [373](#), [517](#)
- Safety module has been changed (error message) [641](#)
- Safety module has been removed (error message) [638](#)
- Safety module is defect or missing (error message) [637](#), [639](#)
- Saturation characteristic [210](#)
- Saving of parameters failed (error message) [677](#)
- Scaling of physical quantities [28](#)
- SDO1 server parameter (I-1200) [351](#)
- SDO10 server parameter (I-1209) [355](#)
- SDO2 server parameter (I-1201) [352](#)
- SDO3 server parameter (I-1202) [354](#)
- SDO4 server parameter (I-1203) [354](#)
- SDO5 server parameter (I-1204) [354](#)
- SDO6 server parameter (I-1205) [354](#)
- SDO7 server parameter (I-1206) [355](#)
- SDO8 server parameter (I-1207) [355](#)
- SDO9 server parameter (I-1208) [355](#)
- Select motor control [129](#)
- Select motor control (C00006) [725](#)
- Sensorless vector control (SLVC) [172](#)
- Service code (C00180) [742](#)
- Service code (C02862) [873](#)
- Service code (C02863) [873](#)
- Service code (C02864) [873](#)
- Service code (C1125) [814](#)
- Service code (C1126) [814](#)
- Service code (C1127) [814](#)
- Service code (C1128) [814](#)
- Service code (C1129) [814](#)
- Service code (C1211) [818](#)
- Service code (C1217) [819](#)
- Service code (C1218) [819](#)
- Service code (C132) [736](#)
- Service code (C167) [740](#)
- Service code (C171) [741](#)
- Service code (C175) [742](#)
- Service code (C176) [742](#)
- Service code (C177) [742](#)
- Service code (C198) [744](#)
- Service code (C2850) [871](#)
- Service code (C2851) [871](#)
- Service code (C2852) [871](#)
- Service code (C2854) [871](#)
- Service code (C2856) [872](#)
- Service code (C2857) [872](#)
- Service code (C2996) [880](#)
- Service code (C2997) [880](#)
- Service code (C2998) [880](#)
- Service code (C2999) [880](#)
- Service code (C308) [750](#)
- Service code (C309) [750](#)
- Service code (C310) [750](#)
- Service code (C325) [754](#)
- Service code (C326) [754](#)
- Service code (C327) [754](#)
- Service code (C328) [754](#)
- Service code (C329) [755](#)
- Service code (C330) [755](#)
- Service code (C335) [755](#)
- Service code (C336) [755](#)
- Service code (C337) [755](#)
- Service code (C338) [755](#)
- Service code (C379) [765](#)
- Service code (C395) [770](#)
- Service code (C396) [771](#)
- Service code (C397) [771](#)
- Service code (C416) [772](#)
- Service code (C468) [777](#)
- Service code (C512) [778](#)
- Service code (C513) [778](#)
- Service code (C514) [778](#)
- Service code (C515) [778](#)
- Service code (C516) [778](#)
- Service code DataFlash (C1213) [818](#)
- Service password (C00004) [725](#)
- Servo control (SC) [151](#)
- Set time and date (C01215) [819](#)
- Setpoint interpolation (C02550) [830](#)
- Setting of actual speed filter [158](#), [185](#)
- Setting the baud rate for CAN [297](#)
- Setting the error response [621](#)
- Setting the field weakening for asynchronous machines [165](#)
- Setting the node address for CAN [296](#)
- Setting the S-ramp time [385](#)
- Settings for test mode (C00399) [771](#)
- SF\_dnMotorAcc\_x (C02692) [854](#)
- SF\_dnSpeedAdd\_s (C02693) [855](#)
- Short overview of error messages [628](#)
- Signal flow
  - Encoder evaluation [245](#)
  - Monitoring [223](#)
  - Position follower [497](#)
  - Sensorless vector control [189](#)
  - Servo control for asynchronous motor [170](#)
  - Servo control for synchronous motor [168](#)

- Speed follower [504](#)
  - Torque follower [510](#)
  - V/f control [205](#)
  - V/f control closed loop [207](#)
  - Signal source - speed setpoint (C00275) [749](#)
  - Signal source - torque setpoint (C00276) [749](#)
  - SLVC
    - Gain - cross curr. contr. (C00986) [809](#)
    - Gain - flux controller (C00985) [809](#)
    - Gain - torque controller (C00987) [809](#)
    - Reset time - torque contr. (C00988) [809](#)
    - Time const.- Para. adj. (C00989) [810](#)
  - Software limit positions [519](#)
    - Triggering behaviour [521](#)
  - Software limit positions (C02701) [856](#)
  - Software limits pos. effective (C02700) [856](#)
  - Source - actual position (C2571) [833](#)
  - Source add. speed (C02681) [853](#)
  - Source for feedf. control brake (C02602) [838](#)
  - Source of starting torque (C02588) [836](#)
  - Source position setpoint (C02680) [853](#)
  - Spec. characteristic
    - resistance (C01192) [815](#)
    - temperature (C01191) [815](#)
  - Speed act. val. time const. (C00497) [778](#)
  - Speed contr. reset time (C00071) [730](#)
  - Speed contr.D component (C00072) [730](#)
  - Speed controller gain (C00070) [730](#)
  - Speed controller output (C00694) [794](#)
  - Speed feedforw. control gain (C02561) [831](#)
  - Speed follower [502](#)
    - % signals (C02694) [855](#)
    - Dig. signals (C02695) [855](#)
  - Speed has been limited (error message) [695](#)
  - Speed limitation (C00909) [803](#)
  - Speed monitoring tolerance (C00576) [780](#)
  - Speed setpoint (enc. eval.) (C02572) [833](#)
  - Speed setpoint [%] (C00692) [794](#)
  - Speed setpoint [rpm] (C00050) [727](#)
  - Speed unit (C02537) [827](#)
  - S-ramp time for stop (C02611) [840](#)
  - S-ramp time lim. speed (C02711) [858](#)
  - SSI encoder [255](#)
    - bit rate (C00423) [773](#)
    - data word length (C00424) [773](#)
    - partword data coding (C00437) [775](#)
    - partword length (C00436) [774](#)
    - partword start position (C00435) [774](#)
  - Start acceleration [383](#)
  - Starting angle (C02772) [863](#)
  - Starting performance [112](#)
  - Starting torque 1 (C02586) [836](#)
  - Starting torque 2 (C02587) [836](#)
  - State bus [283](#)
  - Status
    - Digital inputs (C00443) [775](#)
    - Digital outputs (C00444) [776](#)
    - Status DCTRL control input (C00878) [802](#)
    - Status displays [611](#)
    - Status input monitoring (C02583) [835](#)
    - Status word
      - Digital inputs (C02803) [869](#)
      - Digital outputs (C02802) [868](#)
    - Status word device control 1 (C00150) [737](#)
    - Status word device control 2 (C00155) [738](#)
    - Status/Control word MCTRL (C00156) [738](#)
    - Stop [387](#)
    - Store parameters (I-1010) [346](#)
    - STP\_bStopActive (C02617) [840](#)
    - STP\_dnState (C02616) [840](#)
    - Switching frequency reduction [116](#)
    - Sync cycle time (C01121) [812](#)
    - Sync phase position [313](#)
    - Sync phase position (C01122) [812](#)
    - Sync source (C01120) [812](#)
    - Sync telegram [310](#)
    - Sync tolerance (C01123) [813](#)
    - Synchronisation of PDOs [310](#)
    - Sync-PLL increment (C01124) [813](#)
    - System block "LS\_Limiter" [368](#)
    - System block "LS\_SafetyModuleInterface" [368](#)
    - System event [290](#)
    - System fault messages [623](#)
    - System task
      - Task overflow (error message) [680](#)
    - System task 1
      - Task overflow (error message) [680](#)
    - System task 2
      - Task overflow (error message) [680](#)
    - System task 3
      - Task overflow (error message) [680](#)
- ## T
- Task overflow [114](#), [290](#)
  - Task runtimes [65](#)
  - Temperature inside the controller (C00062) [729](#)
  - Temperature monitoring of a second motor [232](#)
  - Test mode motor control (C00398) [771](#)
  - Test torque (C02594) [837](#)
  - Therm. motor time constant (C00128) [735](#)
  - Thermal motor load (I<sup>2</sup>t) (C00066) [729](#)
  - Threshold - brake activation (C02581) [835](#)
  - Threshold - standstill recognition (C00019) [726](#)
  - Threshold 1 for opening brake (C02603) [838](#)
  - Threshold 2 for opening brake (C02604) [839](#)
  - Threshold max. speed reached (C00596) [785](#)
  - Time [819](#)
  - Time (C02776) [864](#)
  - Time constant of actual speed filter [158](#), [185](#)

- Time error - controller interface (error message) [655](#)
- Time unit (C02533) [827](#)
- Time-out torque feedforward control - brake (error message) [697](#)
- Timestamp (C02902) [874](#)
- Tolerance for POS\_bActPosInTarget (C02670) [851](#)
- Tolerance for POS\_bDriveInTarget (C02671) [851](#)
- Torque (C00057) [728](#)
- Torque feedforward control [163](#)
- Torque follower [508](#)
  - % signals (C02698) [855](#)
  - Dig. signals (C02699) [856](#)
- Torque setpoint (C00056) [728](#)
- Torque setpoint [%] (C00696) [794](#)
- Total speed setpoint (C00691) [793](#)
- Total torque setpoint (C00695) [794](#)
- Touch probe detection [285](#)
- Touch probe x
  - Delay time (C02810) [870](#)
- TPDO1 communication parameter (I-1800) [360](#)
- TPDO1 mapping parameter (I-1A00) [363](#)
- TPDO2 communication parameter (I-1801) [361](#)
- TPDO2 mapping parameter (I-1A01) [363](#)
- TPDO3 communication parameter (I-1802) [362](#)
- TPDO3 mapping parameter (I-1A02) [364](#)
- TPDO4 communication parameter (I-1803) [362](#)
- TPDO4 mapping parameter (I-1A03) [364](#)
- Track change-over [578](#)
- Travel range monitoring [513](#)
- Traversing range (C02528) [825](#)
- TTL encoder signal evaluation (C00427) [773](#)
- U**
- Ultimate motor current I<sub>ult</sub> [133](#), [235](#)
- Ultimate motor current I<sub>ult</sub> (C00620) [790](#)
- Undervoltage (LU) threshold (C00174) [742](#)
- Unit [40](#)
- Unit (C02525) [825](#)
- Unknown error (error message) [628](#), [636](#)
- Update cam data [568](#)
- Used time unit (C02534) [827](#)
- Used unit (C02535) [827](#)
- User code
  - Memory load (C02110) [823](#)
- User Password (C02900) [873](#)
- User-defined unit (C02526) [825](#)
- UserTask
  - Overflow (error message) [646](#)
- V**
- V/f control (VFCplus) [190](#)
- V/f control closed loop (VFCplus) [206](#)
- VFC
  - Activat. interpol. point n (C00954) [805](#)
- Frequency interpol. point n (C00952) [804](#)
- Frequency setpoint (C00998) [811](#)
- Gain - lmax controller (C00963) [806](#)
- Gain - oscillation damping (C00967) [807](#)
- Gain - slip compensation (C00965) [807](#)
- Gain - speed controller (C00972) [808](#)
- Influence - speed controller (C00971) [808](#)
- Limitation - oscill. damp. (C00969) [807](#)
- Load - cw/ccw-operation (C00961) [806](#)
- Load adjustment (C00962) [806](#)
- min. inh-time aft. overvolt. (C00977) [809](#)
- Override point of field weakening (C00980) [809](#)
- ramp-end frequ. - oscill. damp. (C00970) [807](#)
- Reset time - lmax contr. (C00964) [806](#)
- Reset time - speed contr. (C00973) [808](#)
- Time const. - oscill. damp. (C00968) [807](#)
- Time const. - slip compens. (C00966) [807](#)
- V/f base frequency (C00951) [803](#)
- V/f characteristic shape (C00950) [803](#)
- V/f voltage boost (C00960) [806](#)
- Vmax reduction (C00955) [805](#)
- Voltage interpol. point n (C00953) [804](#)
- VVC current setpoint (C00957) [805](#)
- VVC gain (C00958) [805](#)
- VVC reset time (C00959) [806](#)
- VFCplus [206](#)
- Violation of time slice (error message) [655](#)
- W**
- Waiting time - brake activation (C02593) [837](#)
- Waiting time - state monitoring (C02591) [837](#)
- Warning thres. brake resistor (C00572) [779](#)
- Warning thres. brake transistor (C00570) [779](#)
- Warning threshold device util. (C00123) [734](#)
- Width - current setp. filter (C00271) [748](#)
- X**
- X8 (encoder signal) [258](#)